

Please note the following changes to user's manual IM04L05A01-61E.

■ Page 1-9 "Required PC System Environment"

The DAQSIGNIN (revision 4.04 and later) can be used under Windows Vista. The PC system requirements were changed as follows;

Operating System (OS)

OS	Version
Windows 98	Windows 98, Windows 98 Second Edition
Windows Me	Windows Millennium Edition
Windows NT	Windows NT 4.0
Windows 2000	Windows 2000 Professional SP4
Windows XP	Windows XP Home Edition SP2
	Windows XP Professional SP2 (excluding the Windows XP Professional x64 Edition)
Windows Vista	Windows Vista Home Premium (excluding the 64-bit edition)
	Windows Vista Business (excluding the 64-bit edition)

Hardware

PC	OS	Conditions
CPU	98, Me, NT	MMX 166 MHz or higher (PentiumII 266 MHz or higher is recommended)
	2000, XP	Pentium IV 1.6 GHz or higher
	Vista	Pentium IV 3.0 GHz or higher
Main Memory	98, Me, NT	64 MB or more
	2000, XP	512 MB or more
	Vista	2 GB or more
Hard Disk	all	A free space of 200 MB or more. However, some application may require more memory.
CD-ROM	all	A CD-ROM drive supported by the OS
Mouse	all	A mouse supported by the OS
Monitor	2000, XP	A monitor supported by the OS of 1024 x 768 dpi or higher and 65536 colors or more.
	Vista	A video card recommended for use with the OS and a monitor supported by the OS of 1024 x 768 dpi or higher and 65,536 colors or more.
Printer	all	A printer supported by the OS
Interface Board	all	An Ethernet card supported by the OS (10BASE-T or 100BASE-TX)

■ Page 2-13 Please note the underlined changes to "Note."

Note

- You can select and export multiple data.
.....
- Data cannot be exported to another name in the following cases.
 - If any of the files making up the batch data is missing.
 - If the data has the number of samples beyond the Viewer's limit (see "Functions of the Viewer", section 1.1)
 - If any of the files making up the batch data is damaged.
 - If the continuous data file is damaged.
 - If the file was saved using the DX100P/DX200P keys displayed in yellow on the Batch/Continuous tab of the DAQSIGNIN Manager screen (see "Data Storage While Data Acquisition Is Stopped" (page 1-30 of IM04L05A01-01E or page 1-31 of IM04L06A01-01E)), or if including that data.
 - If the exporting fails, a message is displayed followed by the information in a dialog box.
.....