User's Manual

Power Viewer Software For the PZ4000 Power Analyzer

Please note the following changes to your user's manual (IM253734-61E).

Chapter 3, Saving and Loading Data

When saving waveform data, numeric values, and setup parameters to files for loading at a later time, the path names to the files (including the drive and directory names) may not exceed 95 characters. The backslash character for delimiting directories (\) counts as 1 character.

