


TM 55-1945-227-24P

TECHNICAL MANUAL

**REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL)
FOR**

**MODULAR CAUSEWAY SYSTEM (MCS)
FLOATING CAUSEWAY (FC)
NSN 1945-01-505-1665 (EIC WBP)**



DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

MAY 2006

LIST OF EFFECTIVE PAGES / WORK PACKAGES

Dates of issue for original and changed pages / work packages are:

Original 2 May 2006

**TOTAL NUMBER OF PAGES FOR FRONT AND REAR MATTER IS 22 AND TOTAL
NUMBER OF WORK PACKAGES IS 39 CONSISTING OF THE FOLLOWING:**

Page / WP No.	*Change No.	Page / WP No.	*Change No.
Title	0	WP 00038 00 (2 pgs)	0
List of Effective Pages (A-B pgs)	0	WP 00039 00 (6 pgs)	0
Title Block Page (2 pgs)	0		
Table of Contents (i-ii pgs)	0		
Chp 1 title page (2 pgs)	0		
WP 00001 00 (6 pgs)	0		
WP 00002 00 (4 pgs)	0		
WP 00003 00 (4 pgs)	0		
WP 00004 00 (4 pgs)	0		
WP 00005 00 (4 pgs)	0		
WP 00006 00 (4 pgs)	0		
WP 00007 00 (4 pgs)	0		
WP 00008 00 (4 pgs)	0		
WP 00009 00 (4 pgs)	0		
WP 00010 00 (4 pgs)	0		
WP 00011 00 (4 pgs)	0		
WP 00012 00 (4 pgs)	0		
WP 00013 00 (4 pgs)	0		
WP 00014 00 (4 pgs)	0		
WP 00015 00 (4 pgs)	0		
WP 00016 00 (4 pgs)	0		
WP 00017 00 (4 pgs)	0		
WP 00018 00 (6 pgs)	0		
WP 00019 00 (6 pgs)	0		
WP 00020 00 (6 pgs)	0		
WP 00021 00 (4 pgs)	0		
WP 00022 00 (4 pgs)	0		
WP 00023 00 (6 pgs)	0		
WP 00024 00 (6 pgs)	0		
WP 00025 00 (8 pgs)	0		
WP 00026 00 (6 pgs)	0		
WP 00027 00 (6 pgs)	0		
WP 00028 00 (6 pgs)	0		
WP 00029 00 (4 pgs)	0		
WP 00030 00 (4 pgs)	0		
WP 00031 00 (4 pgs)	0		
WP 00032 00 (4 pgs)	0		
WP 00033 00 (8 pgs)	0		
WP 00034 00 (4 pgs)	0		
WP 00035 00 (8 pgs)	0		
WP 00036 00 (4 pgs)	0		
WP 00037 00 (2 pgs)	0		

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C. 2 MAY 2006

TECHNICAL MANUAL

REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL) FOR

MODULAR CAUSEWAY SYSTEM (MCS) FLOATING CAUSWAY NSN 1945-01-505-1665 (EIC WBP)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <https://aebs.ria.army.mil>. The DA Form 2028 is located under the Public Applications section in the AEPS Public Home Page. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or E-mail your letter or DA Form 2028 direct to: AMSTA-LC-LMIT / TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

TABLE OF CONTENTS

	<u>WP Sequence No.</u>
INTRODUCTION	0001 00
GROUP 01	
Fig. 1 Intermediate Section Assembly	0002 00
Fig. 2 Center Module Assembly	0003 00
Fig. 3 Right End Rake	0004 00
Fig. 4 Center End Rake	0005 00
Fig. 5 Left End Rake	0006 00
Fig. 6 D-Ring Assembly	0007 00
Fig. 7 Mooring Cleat Assembly.....	0008 00
GROUP 02	
Fig. 8 Beach Sea Section Assembly	0009 00
Fig. 9 Center Module Assembly	0010 00
Fig. 10 Right End Rake	0011 00
Fig. 11 Center End Rake	0012 00
Fig. 12 Left End Rake.....	0013 00
Fig. 13 Beach End Module Assembly.....	0014 00
Fig. 14 D-Ring Assembly	0015 00
Fig. 15 Mooring Cleat Assembly.....	0016 00
Fig. 16 Rhino Horn Assembly.....	0017 00
GROUP 03	
Fig. 17 Ship Fendering, 3 X 5 and 5 X 10	0018 00
Fig. 18 Ship Fendering, 4 X 12 and Mooring Bitts.....	0019 00
Fig. 19 Ship Fendering, 3 X 5 and 5 X 10	0020 00
Fig. 20 Right Corner Fender and Mounting Assembly.....	0021 00
Fig. 21 Left Corner Fender and Mounting Assembly.....	0022 00
Fig. 22 Offshore Mooring Container Stowage	0023 00
Fig. 23 Offshore Leg Mooring System.....	0024 00
Fig. 24 Onshore Mooring Container Stowage	0025 00
Fig. 25 Onshore Outer Leg Mooring System.....	0026 00
Fig. 26 Onshore Inner Leg Mooring System.....	0027 00
Fig. 27 Light System.....	0028 00
Fig. 28 Deck Matt Stowage	0029 00
Fig. 29 Basic Issue Item Container.....	0030 00
Fig. 30 Generator Container Exterior Components	0031 00
Fig. 31 Generator Container Fuel Level Indicating Panel.....	0032 00
Fig. 32 Generator Container Electrical Components	0033 00
Fig. 33 Personnel Shelter Exterior Components	0034 00
Fig. 34 Personnel Shelter Interior Components	0035 00
Fig. 35 Personnel Shelter Head Components	0036 00
GROUP 04	
Fig. 36 Special Tools	0037 00
National Stock Number Index	0038 00
Part Number Index	0039 00

CHAPTER 1

REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL) FOR MODULAR CAUSEWAY SYSTEM (MCS) FLOATING CAUSEWAY (FC)

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**FLOATING CAUSEWAY
EIC TBD****INTRODUCTION****SCOPE**

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of &pim.maint; maintenance of the &pim.item;. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance, and recoverability (SMR) codes.

GENERAL

In addition to the Introduction work package, the RPSTL is divided into the following work packages.

Repair Parts List Work Packages. Work packages containing lists of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. These work packages also include parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Sending units, brackets, filters, and bolts are listed with the component they mount on. Bulk materials are listed by item name in FIG. BULK at the end of the work packages. Repair parts kits are listed separately in their own functional group and work package. Repair parts for reparable special tools are also listed in a separate work package. Items listed are shown on the associated illustrations.

Special Tools List Work Packages. Work packages containing lists of special tools, special TMDE, and special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in the DESCRIPTION AND USABLE ON CODE (UOC) column). Tools that are components of common tool sets and/or Class VII are not listed.

Cross-Reference Indexes Work Packages. There are two cross-reference indexes work packages in this RPSTL: the National Stock Number (NSN) Index work package and the Part Number (P/N) Index work package. The National Stock Number Index work package refers you to the figure and item number. The Part Number Index work package refers you to the figure and item number.

EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES

ITEM NO (Column (1)). Indicates the number used to identify items called out in the illustration.

SMR CODE (Column (2)). The SMR code containing supply/requisitioning information, maintenance level authorization criteria, and disposition instruction, as shown in the following breakout:

Source	Maintenance	Recoverability
Code	Code	Code
<u>XX</u>	<u>XX</u>	X
1st two positions: How to get an item.	3rd position: Who can install, replace, or use the item.	4th position: Who can do complete repair* on the item.
		5th position: Who determines disposition action on unserviceable items.

*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

Source Code. The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

<u>Source Code</u>	<u>Application/Explanation</u>
PA	Stock items, use the applicable NSN to requisition/request items with these source codes. They are authorized to the level indicated by the code entered in the 3rd position of the SMR code.
PB	
PC	
PD	
PE	
PF	
PG	
KD	Items coded PC are subject to deterioration.
KF	
KB	
MO-Made at unit/AVUM level	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance level indicated in the 3rd position of the SMR code. The complete kit must be requisitioned and applied.
MF-Made at DS/AVIM level	
MH-Made at GS level	
ML-Made at SRA	
MD-Made at depot	
AO-Assembled by unit/ AVUM level	Items with these codes are not to be requisitioned/requested individually. They must be made from bulk material which is identified by the P/N in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the bulk material group work package of the RPSTL. If the item is authorized to you by the 3rd position code of the SMR code, but the source code indicates it is made at higher level, order the item from the higher level of maintenance.
AF-Assembled by DS/ AVIM level	
AH-Assembled by GS level	
AL-Assembled by SRA	
AD-Assembled by depot	
XA	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3rd position of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.
XB	Do not requisition an "XA" coded item. Order the next higher assembly. (Refer to NOTE below.)
XC	If an item is not available from salvage, order it using the CAGEC and P/N.
XD	Installation drawings, diagrams, instruction sheets, field service drawings; identified by manufacturer's P/N.
	Item is not stocked. Order an XD-coded item through normal supply channels using the CAGEC and P/N given, if no NSN is available.

NOTE

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes except for those items source coded "XA" or those aircraft support items restricted by requirements of AR750-1.

Maintenance Code. Maintenance codes tell you the level(s) of maintenance authorized to use and repair support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follow:

Third Position. The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following levels of maintenance.

Maintenance <u>Code</u>	<u>Application/Explanation</u>
C —	Crew operator maintenance done within unit/AVUM maintenance.
O —	Unit level/AVUM maintenance can remove, replace, and use the item.
F —	Direct support/AVIM maintenance can remove, replace, and use the item.
H —	General support maintenance can remove, replace, and use the item.
L —	Specialized repair activity can remove, replace, and use the item.
D —	Depot can remove, replace, and use the item.

Fourth Position. The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (perform all authorized repair functions.)

NOTE

Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.

Maintenance <u>Code</u>	<u>Application/Explanation</u>
O —	Unit/AVUM is the lowest level that can do complete repair of the item.
F —	Direct support/AVIM is the lowest level that can do complete repair of the item.
H —	General support is the lowest level that can do complete repair of the item.
L —	Specialized repair activity is the lowest level that can do complete repair of the item.
D —	Depot is the lowest level that can do complete repair of the item.
Z —	Nonreparable. No repair is authorized.
B —	No repair is authorized. No parts or special tools are authorized for maintenance of "B" coded item. However, the item may be reconditioned by adjusting, lubricating, etc., at the user level

Recoverability Code. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is shown in the fifth position of the SMR code as follows:

Recoverability <u>Code</u>	<u>Application/Explanation</u>
Z —	Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.
O —	Reparable item. When uneconomically repairable, condemn and dispose of the item at the unit level.
F —	Reparable item. When uneconomically repairable, condemn and dispose of the item at the direct support level.
H —	Reparable item. When uneconomically repairable, condemn and dispose of the item at the general support level.
D —	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item are not authorized below depot level.
L —	Reparable item. Condemnation and disposal not authorized below Specialized Repair Activity (SRA).
A —	Item requires special handling or condemnation procedures because of specific reasons (such as precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

NSN (Column (3)). The NSN for the item is listed in this column.

CAGEC (Column(4)). The Commercial and Government Entity Code (CAGEC) is a five-digit code which is used to identify the manufacturer, distributor, or Government agency/activity that supplies the item.

PART NUMBER (Column(5)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When you use an NSN to requisition an item, the item you receive may have a different P/N form than the number listed.

DESCRIPTION AND USABLE ON CODE (UOC) (Column (6)). This column includes the following information:

The federal item name, and when required, a minimum description to identify the item.

P/Ns of bulk materials are referenced in this column in the line entry to be manufactured or fabricated.

Hardness Critical Item (HCI). A support item that provides the equipment with special protection from electromagnetic pulse (EMP) damage during a nuclear attack.

The statement END OF FIGURE appears just below the last item description in column (6) for a given figure in both the repair parts list and special tools list work packages.

QTY (Column(7)). The QTY (quantity per figure) column indicates the quantity of the item used in the breakout shown on the illustration/figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column instead of a quantity indicates that the quantity is variable and quantity may change from application to application.

EXPLANATION OF CROSS-REFERENCE INDEXES WORK PACKAGES FORMAT AND COLUMNS

1. National Stock Number (NSN) Index Work Package.

STOCK NUMBER Column. This column lists the NSN in National item identification number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN.

NSN
(e.g., 5385-01-574-1476)

When using the column to locate an item, ignore the first four digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

FIG. Column. This column lists the number of the figure where the item is identified/located. The figures are in numerical order in the repair parts list and special tools list work packages.

ITEM Column. The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

2. Part Number (P/N) Index Work Package. P/Ns in this index are listed in ascending alphanumeric sequence (vertical arrangement of letter and number combinations which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order.)

PART NUMBER Column. Indicates the P/N assigned to the item.

FIG. Column. This column lists the number of the figure where the item is identified/located in the repair parts list and special tools list work packages.

ITEM Column. The item number is the number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

SPECIAL INFORMATION

Fabrication Instructions. Bulk materials required to manufacture items are listed in the bulk material functional group of this RPSTL. Part numbers for bulk material are also referenced in the Description Column of the line item entry for the item to be manufactured/fabricated. Detailed fabrication instructions for items source coded to be manufactured or fabricated are found in TM 55-1945-227-24.

Index Numbers. Items which have the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the NSN / P/N index work packages and the bulk material list in the repair parts list work package.

Associated Publications. The publication(s) listed below pertains to the Floating Causeway:

<u>Publication</u>	<u>Short Title</u>
TM 55-1945-227-10	Operator's Manual
TM 55-1945-227-24	Unit, Direct Support and General Support Maintenance Manual

HOW TO LOCATE REPAIR PARTS

1. When NSNs or P/Ns Are Not Known.

First. Using the table of contents, determine the assembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and lists are divided into the same groups.

Second. Find the figure covering the functional group or the subfunctional group to which the item belongs.

Third. Identify the item on the figure and note the number(s).

Fourth. Look in the repair parts list work packages for the figure and item numbers. The NSNs and part numbers are on the same line as the associated item numbers.

2. When NSN Is Known.

First. If you have the NSN, look in the STOCK NUMBER column of the NSN index work package. The NSN is arranged in NIIN sequence. Note the figure and item number next to the NSN.

Second. Turn to the figure and locate the item number. Verify that the item is the one you are looking for.

3. When P/N Is Known.

First. If you have the P/N and not the NSN, look in the PART NUMBER column of the P/N index work package. Identify the figure and item number.

Second. Look up the item on the figure in the applicable repair parts list work package.

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

INTERMEDIATE SECTION ASSEMBLY REPAIR PARTS LIST




Figure 1. Intermediate Section Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 1, INTERMEDIATE SECTION ASSEMBLY						
1	XDOLL		34712	E19193	INTMD SECTION ASSY	1
2	PAOLL	2040-01-092-3081	34712	E02783	.FLEXOR COUPLING, PON.....	2
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

CENTER MODULE ASSEMBLY REPAIR PARTS LIST




Figure 2. Center Module Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 2, CENTER MODULE ASSEMBLY						
1	PBOLL	1945-01-495-4738	34712	E02803	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	20
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	20
4	XDOZZ		39428	94805A125	.NUT, HEXAGON.....	20
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-1	.PLATE, IDENTIFICATIO	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	20
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	20
9	XDOZZ		34712	E04251	.SPRING, PIN.....	20
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	3
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

RIGHT END RAKE REPAIR PARTS LIST




Figure 3. Right End Rake (Sheet 1 of 2)




Figure 3. Right End Rake (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 3, RIGHT END RAKE						
1	PFOLZ	1945-01-495-4684	34712	E02813	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-4	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
11	XDOZZ		34712	E04842	.CHUTE BOLT ASSEMBLY	2
12	XDOZZ		34712	E38052	.COVER, BOLT, RIGHT	1
13	PAOZZ	5305-01-485-8084	39428	93190A626	.SCREW, CAP, HEXAGON H.....	4
14	XDOZZ		75535	1018026	.SHACKLE, ANCHOR.....	2
15	XDOZZ		34712	E06811	.CHAIN, COIL.....	1
16	PAOZZ	2540-01-495-8321	34712	E04872	.BRACKET, TOW HOOK	1
17	XDOZZ		34712	E38082	.COVER, BOLT, LEFT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

CENTER END RAKE REPAIR PARTS LIST




Figure 4. Center End Rake

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 4, CENTER END RAKE						
1	PBOLL	1945-01-495-4838	34712	E02823	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-3	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

LEFT END RAKE REPAIR PARTS LIST




Figure 5. Left End Rake (Sheet 1 of 2)




Figure 5. Left End Rake (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 5, LEFT END RAKE						
1	PBOLL	1945-01-495-4842	34712	E02833	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-2	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
11	XDOZZ		34712	E04842	.CHUTE BOLT ASSEMBLY	2
12	XDOZZ		34712	E38052	.COVER, BOLT, RIGHT	1
13	PAOZZ	5305-01-485-8084	39428	93190A626	.SCREW, CAP, HEXAGON H.....	4
14	XDOZZ		75535	1018026	.SHACKLE, ANCHOR	2
15	XDOZZ		34712	E06811	.CHAIN, COIL.....	1
16	PAOZZ	2540-01-495-8321	34712	E04872	.BRACKET, TOW HOOK	1
17	XDOZZ		34712	E38082	.COVER, BOLT, LEFT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

D-RING ASSEMBLY REPAIR PARTS LIST




Figure 6. D-Ring Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 6, D-RING ASSEMBLY						
1	XDOOO		34712	E07803	D-RING ASSEMBLY	1
2	XAOZZ		34712	E26502	.D-RING, WELDMENT	1
3	XDOZZ		34712	E07671	.PLATE, KEEPER	1
4	XDOZZ		39428	90499A845	.NUT, HEXAGON	1
5	XDOZZ		39428	92620A928	.CAPSCREW, HEX HEAD.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

MOORING CLEAT ASSEMBLY REPAIR PARTS LIST




Figure 7. Mooring Cleat Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 01						
FIGURE 7, MOORING CLEAT ASSEMBLY						
1	XDOOO		34712	E07723	MOORING, CLEAT ASSY	1
2	XAOZZ		34712	E26492	.CLEAT, WELDMENT.....	1
3	XDOZZ		34712	E07671	.PLATE, KEEPER	1
4	XDOZZ		39428	90499A845	.NUT, HEXAGON.....	1
5	XDOZZ		39428	92620A928	.CAPSCREW, HEX HEAD.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

BEACH SEA SECTION ASSEMBLY REPAIR PARTS LIST




Figure 8. Beach Sea Section Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 8, BEACH SEA SECTION ASSEMBLY						
1	XDOLL		34712	E19183	BEACH SEA SECT ASSY	1
2	PAOLL	2040-01-092-3081	34712	E02783	.FLEXOR COUPLING, PON.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

CENTER MODULE ASSEMBLY REPAIR PARTS LIST




Figure 9. Center Module Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 9, CENTER MODULE ASSEMBLY						
1	PBOLL	1945-01-495-4738	34712	E02803	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	20
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	20
4	XDOZZ		39428	94805A125	.NUT, HEXAGON.....	20
5	XDOZZ		34712	E13011-1	.PLATE, IDENT	1
6	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
7	XDOZZ		39428	93190A722	.BOLT, HEX	20
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	20
9	XDOZZ		34712	E04251	.SPRING, PIN.....	20
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	3
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

RIGHT END RAKE PARTS LIST




Figure 10. Right End Rake (Sheet 1 of 2)




Figure 10. Right End Rake (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 10, RIGHT END RAKE						
1	PBOLL	1945-01-495-4684	34712	E02813	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-4	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
11	XDOZZ		34712	E04842	.CHUTE BOLT ASSEMBLY	2
12	XDOZZ		34712	E38052	.COVER, BOLT, RIGHT	1
13	PAOZZ	5305-01-485-8084	39428	93190A626	.SCREW, CAP, HEXAGON H.....	4
14	XDOZZ		75535	1018026	.SHACKLE, ANCHOR	2
15	XDOZZ		34712	E06811	.CHAIN, COIL.....	1
16	PAOZZ	2540-01-495-8321	34712	E04872	.BRACKET, TOW HOOK	1
17	XDOZZ		34712	E38082	.COVER, BOLT, LEFT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

CENTER END RAKE REPAIR PARTS LIST




Figure 11. Center End Rake

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 11, CENTER END RAKE						
1	PBOLL	1945-01-495-4838	34712	E02823	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-3	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

LEFT END RAKE PARTS LIST




Figure 12. Left End Rake (Sheet 1 of 2)




Figure 12. Left End Rake (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 12, LEFT END RAKE						
1	PBOLL	1945-01-495-4842	34712	E02833	PONTOON, SECTIONAL.....	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	6
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	6
4	XDOZZ		39428	94805A125	.NUT, HEXAGON	6
5	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
6	XDOZZ		34712	E13011-2	.PLATE, IDENT	1
7	XDOZZ		39428	93190A722	.BOLT, HEX	6
8	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	6
9	XDOZZ		34712	E04251	.SPRING, PIN.....	6
10	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
11	XDOZZ		34712	E04842	.CHUTE BOLT ASSEMBLY	2
12	XDOZZ		34712	E38052	.COVER, BOLT, RIGHT	1
13	PAOZZ	5305-01-485-8084	39428	93190A626	.SCREW, CAP, HEXAGON H.....	4
14	XDOZZ		75535	1018026	.SHACKLE, ANCHOR	2
15	XDOZZ		34712	E06811	.CHAIN, COIL.....	1
16	PAOZZ	2540-01-495-8321	34712	E04872	.BRACKET, TOW HOOK	1
17	XDOZZ		34712	E38082	.COVER, BOLT, LEFT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

BEACH END MODULE ASSEMBLY REPAIR PARTS LIST




Figure 13. Beach End Module Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 13, BEACH END MODULE ASSEMBLY						
1	PBOLL	3990-01-495-4848	34712	E02853	PLATFORM, VEHICLE	1
2	PFOZZ	1945-01-495-5249	34712	E04282	.GUILLOTINE, INTERCON	2
3	XDOZZ		34712	E07531	.PLATE, LOCKING.....	2
4	XDOZZ		39428	94805A125	.NUT, HEXAGON.....	2
5	XDOZZ		34712	E07218	.PLUG, PIPE.....	1
6	XDOZZ		39428	93190A722	.BOLT, HEX	2
7	XDOZZ		34712	E04222	.PIN, CONNECTOR.....	2
8	XDOZZ		34712	E04251	.SPRING, PIN.....	2
9	PAOZZ	5305-01-188-9622	39428	91654A144	.SCREW, DRIVE	4
10	XDOZZ		34712	E13011-5	.PLATE, IDENT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

D-RING ASSEMBLY REPAIR PARTS LIST




Figure 14. D-Ring Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 14, D-RING ASSEMBLY						
1	XDOOO		34712	E07803	D-RING ASSEMBLY	1
2	XAOZZ		34712	E26502	.D-RING, WELDMENT	1
3	XDOZZ		34712	E07671	.PLATE, KEEPER	1
4	XDOZZ		39428	90499A845	.NUT, HEXAGON	1
5	XDOZZ		39428	92620A928	.CAPSCREW, HEX HEAD.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

MOORING CLEAT ASSEMBLY REPAIR PARTS LIST




Figure 15. Mooring Cleat Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 15, MOORING CLEAT ASSEMBLY						
1	XDOOO		34712	E07723	MOORING, CLEAT ASSY	1
2	XAOZZ		34712	E26492	.CLEAT, WELDMENT.....	1
3	XDOZZ		34712	E07671	.PLATE, KEEPER	1
4	XDOZZ		39428	90499A845	.NUT, HEXAGON.....	1
5	XDOZZ		39428	92620A928	.CAPSCREW, HEX HEAD.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

RHINO HORN ASSEMBLY REPAIR PARTS LIST

1
2 Thru 4




Figure 16. Rhino Horn Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 02						
FIGURE 16, RHINO HORN ASSEMBLY						
1	XDOOO		34712	E07733	RHINO HORN, ASSY	1
2	XDOZZ		7J925	N2H150CP	.NUT, HEXAGON.....	1
3	XAOZZ		34712	E26482	.RHINO HORN, WELDMENT	1
4	XDOZZ		7J925	P3F5	.CAPSCREW, HEX HEAD.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

SHIP FENDERING, 3 X 5 AND 5 X 10 PARTS LIST

1
2 Thru 18




Figure 17. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 1 of 4)




Figure 17. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 2 of 4)




Figure 17. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 3 of 4)




Figure 17. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 4 of 4)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 17, SHIP FENDERING, 3 X 5 AND 5 X 10						
1	XCOLL		34712	E50745	FENDERING, 3X5, 5X10	1
2	XDOZZ		34712	E34168	.STOP, TRACK.....	3
3	XDOZZ		5K136	DAR-S-4219-24	.TIE DOWN	8
4	XDOZZ		50194	1/2" LLLC	.CHAIN, OPEN LINK	28
5	PAOZZ	4030-00-343-5433	75535	1019515	.SHACKLE	56
6	XDOZZ		7L350	G03X05-2579	.FENDERS, 3 X 5.....	14
7	XAOZZ		34712	E34102	.PALLET, 3X5 FENDER.....	1
8	XDOZZ		34712	E45478	.STOP, TRACK.....	1
9	XAOZZ		34712	E33802	.PALLET, 5X10 FENDER	1
10	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	2
11	PAOZZ	4030-01-499-9284	75535	1019472	.SHACKLE	4
12	XDOZZ		75535	1019597	.SHACKLE	2
13	XDOZZ		7L350	G05X10-2237	.FENDER, 5 X 10.....	1
14	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	2
15	XAOZZ		34712	E50752	.PALLET, 3X5 FENDER	2
16	XDOZZ		1B651	A-150	.TARPAULIN.....	1
17	XAOZZ		1B651	CABLE 110	.TILTROPE.....	1
18	XDOZZ		1RQA1	CMBOW400	.CEILING BOW	19
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

SHIP FENDERING, 4 X 12 AND MOORING BITTS PARTS LIST

1
2 Thru 18




Figure 18. Ship Fendering, 4 X 12 and Mooring Bitts (Sheet 1 of 4)




Figure 18. Ship Fendering, 4 X 12 and Mooring Bitts (Sheet 2 of 4)




Figure 18. Ship Fendering, 4 X 12 and Mooring Bitts (Sheet 3 of 4)




Figure 18. Ship Fendering, 4 X 12 and Mooring Bitts (Sheet 4 of 4)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 18, SHIP FENDERING, 4 X 12 AND MOORING BITTS						
1	XCOLL		34712	E50695	4X12 FEND, MOOR BITT	1
2	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	4
3	XDOZZ		34712	E34168	.STOP, TRACK.....	5
4	XDOZZ		5K136	DAR-S-4220-24	.TIE DOWN	2
5	XDOZZ		34712	E45478	.STOP, TRACK.....	1
6	XDOZZ		34712	E33382	.PALLET, FENDER.....	2
7	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	12
8	PAOZZ	4030-01-499-9284	75535	1019472	.SHACKLE	24
9	XDOZZ		75535	1019597	.SHACKLE	8
10	XDOZZ		7L350	G04X12-2456	.FENDER, 4 X 12.....	4
11	XDOZZ		34712	E32718	.BITT, MOORING	8
12	XDOZZ		34712	E33302	.PALLET, MOORING BITT.....	1
13	XAOZZ		3AJ34	60513	.STRAP, TIE DOWN.....	1
14	XDOZZ		34712	E35863	.ASSEMBLY, CONT, PUSH	1
15	XDOZZ		34712	E33832	.PALLET, MOORING BITT.....	1
16	XDOZZ		1B651	A-150	.TARPAULIN.....	1
17	XDOZZ		1B651	CABLE 110	.TILTROPE.....	1
18	XDOZZ		1RQA1	CMBOW400	.CEILING BOW	19
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

SHIP FENDERING, 3 X 5 AND 5 X 10 PARTS LIST

1
[2 Thru 17]




Figure 19. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 1 of 3)




Figure 19. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 2 of 3)




Figure 19. Ship Fendering, 3 X 5 and 5 X 10 (Sheet 3 of 3)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 19, SHIP FENDERING, 3 X 5 AND 5 X 10						
1	XCOLL		34712	E50735	FENDERING, 3X5, 5X10	1
2	XDOZZ		5K136	DAR-S-4219-24	.TIE DOWN	8
3	XDOZZ		34712	E34168	.STOP, TRACK.....	3
4	XDOZZ		34712	E45478	.STOP, TRACK.....	1
5	XAOZZ		34712	E33802	.PALLET, 5X10 FENDER	1
6	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	2
7	PAOZZ	4030-01-499-9284	75535	1019472	.SHACKLE	4
8	XDOZZ		75535	1019597	.SHACKLE	2
9	XDOZZ		7L350	G05X10-2237	.FENDER, 5 X 10.....	1
10	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	2
11	XAOZZ		34712	E34102	.PALLET, 3X5 FENDER	4
12	XDOZZ		7L350	G03X05-2579	.FENDERS, 3 X 5.....	16
13	PAOZZ	4030-00-343-5433	75535	1019515	.SHACKLE	64
14	XDOZZ		50194	1/2" LLLC	.CHAIN, OPEN LINK	32
15	XDOZZ		1B651	A-150	.TARPAULIN.....	1
16	XAOZZ		1B651	CABLE 110	.TILTROPE.....	1
17	XDOZZ		1RQA1	CMBOW400	.CEILING BOW	19
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

RIGHT CORNER FENDER AND MOUNTING ASSEMBLY REPAIR PARTS LIST




Figure 20. Right Corner Fender and Mounting Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 20, RIGHT CORNER FENDER AND MOUNTING ASSEMBLY						
1	XDOOO		34712	E34553	CORNER FENDER, RH.....	1
2	XDOZZ		34712	E34611	.BAR, BACKING.....	2
3	XDOZZ		34712	E34621	.BAR, BACKING.....	2
4	XDOZZ		39428	91845A310	.HEX NUT	13
5	XDOZZ		39428	92141A033	.WASHER.....	16
6	XDOZZ		34712	E34398	.SHEET, TOP.....	1
7	XDOZZ		34712	E34648	.FENDER, RUBBER	2
8	XDOZZ		39428	92240A722	.CAPSCREW, HEXHD	10
9	XDOZZ		34712	E34232	.FENDER, CORNER, RH.....	1
10	XDOZZ		39428	92186A723	.CAPSCREW, HEXHD	3
11	XDOZZ		34712	E34658	.FENDER, RUBBER	2
12	XDOLL		34712	E34763	MOUNTING ASSEMBLY	1
13	XDOZZ		34712	E42369	.NUT, HEAVY.....	1
14	XDOZZ		39428	92141A044	.WASHER, PLAIN	1
15	XDOZZ		34712	E34412	.DOG WELDMENT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

LEFT CORNER FENDER AND MOUNTING ASSEMBLY REPAIR PARTS LIST

1
2 Thru 11 | 12
| 13 Thru 15




Figure 21. Left Corner Fender and Mounting Assembly

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 21, LEFT CORNER FENDER AND MOUNTING ASSEMBLY						
1	XDOOO		34712	E34793	CORNER FENDER, LH	1
2	XDOZZ		34712	E34621	.BAR, BACKING	2
3	XDOZZ		34712	E34728	.SHEET, TOP	1
4	XDOZZ		39428	91845A310	.HEX NUT	13
5	XDOZZ		39428	92141A033	.WASHER	16
6	XDOZZ		34712	E34611	.BAR, BACKING	2
7	XDOZZ		34712	E34658	.FENDER, RUBBER	2
8	XDOZZ		39428	92240A722	.CAPSCREW, HEXHD	10
9	XDOZZ		39428	92186A723	.CAPSCREW, HEXHD	3
10	XDOZZ		34712	E34262	.FENDER, CORNER, LH	1
11	XDOZZ		34712	E34648	.FENDER, RUBBER	2
12	XDOLL		34712	E34763	MOUNTING ASSEMBLY	1
13	XDOZZ		34712	E42369	.NUT, HEAVY	1
14	XDOZZ		39428	92141A044	.WASHER, PLAIN	1
15	XDOZZ		34712	E34412	.DOG WELDMENT	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

OFFSHORE MOORING CONTAINER STOWAGE PARTS LIST

1
2 Thru 17




Figure 22. Offshore Mooring Container Stowage (Sheet 1 of 4)




Figure 22. Offshore Mooring Container Stowage (Sheet 2 of 4)




Figure 22. Offshore Mooring Container Stowage (Sheet 3 of 4)




Figure 22. Offshore Mooring Container Stowage (Sheet 4 of 4)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 22, OFFSHORE MOORING CONTAINER STOWAGE						
1	XCOLL		34712	E49913	OFFSHORE MOOR CONT	1
2	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	9
3	PAOZZ	5305-01-190-2200	96906	MS35307-511	.SCREW, CAP, HEXAGON H .875-9UNC-2A X 2.50 SST 316	8
4	XDOZZ		34712	E58041	.BAR, TIE	4
5	XDOZZ		34712	E57891	.STOP, TRACK	4
6	PAOZZ	5310-00-584-7796	80205	MS15795-824	.WASHER, FLAT	8
7	PAOZZ	5310-00-764-6610	96906	MS51971-9	.NUT, HEX .875-9UNC-2A X 2.50 SST 316	8
8	XDOZZ		34712	E49752	.PALLET, ANCHOR	1
9	XDOZZ		34712	E49952	.PALLET, ANCHOR	1
10	XDOZZ		34712	0006880	.CAPSCREW, HEX	8
11	XDOZZ		34712	0004177	.HEX NUT	8
12	XDOZZ		34712	E49922	.PALLET, CABLE	1
13	XDOZZ		34712	E49932	.PALLET, CABLE	1
14	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	4
15	XDOZZ		34712	0003288	.WASHER, PL HDN	4
16	XDOZZ		34712	0007934	.HEX NUT	4
17	XDOZZ		34712	E57911	.HOOK	4
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

OFFSHORE LEG MOORING SYSTEM PARTS LIST




Figure 23. Offshore Leg Mooring System (Sheet 1 of 2)




Figure 23. Offshore Leg Mooring System (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 23, OFFSHORE LEG MOORING SYSTEM						
1	XDOOO		34712	E50123	ASSY, OFF, LEG, MOOR	1
2	XDOZZ		34712	E49532	.PADEYE, DEADMAN	1
3	XDOZZ		75535	1019613	.SHACKLE	8
4	XDOZZ		34712	E50013	.WIRE ROPE	2
5	PAOZZ	4030-01-495-8304	75535	1016215	.SWIVEL, LINK AND LIN	1
6	PAOZZ	4030-01-439-6426	75535	1019551	.SHACKLE	1
7	XDOZZ		34712	E50053	.WIRE ROPE	1
8	PAOZZ	5975-01-048-2922	96906	MS3367-6-0	.STRAP, TIEDOWN, ELECT	2
9	XDOZZ		ZZZZZ	4403	.BUOY, 24" ROUND ANC	1
10	XDOZZ		34712	E50073	.WIRE ROPE	1
11	XDOZZ		34712	E50043	.WIRE ROPE	1
12	XDOLL		34712	E35733	.ANCHOR ASSEMBLY	2
13	XDOZZ		34712	E33151	..LINK	1
14	XDOZZ		34712	E35592	..SHANK MACHINING	1
15	PAOZZ	4030-01-186-7197	83644	82043	..SHACKLE	1
16	XDOZZ		34712	E33112	..STABILIZER	2
17	XDOZZ		34712	E33192	..FLUKE ASSEMBLY	1
18	XDOZZ		34712	E35621	..STOPPER	2
19	XDOZZ		39428	93190A716	..CAPSCREW, HEX	4
20	XDOZZ		39428	91845A310	..HEX NUT	4
21	XDOZZ		39428	93190A714	..CAPSCREW, HEX HEAD	2
22	XDOZZ		34712	0000901	..LOCKWASHER, SPRING	2
23	XDOZZ		34712	E33121	..WASHER	2
24	XDOZZ		34712	E33141	..PIN, TRUNION	1
25	XDOZZ		34712	E33131	..PIN	1
END OF FIGURE						

55-1945-227-24P

0024 00

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

ONSHORE MOORING CONTAINER PARTS LIST

1
2 Thru 24




Figure 24. Onshore Mooring Container Stowage (Sheet 1 of 5)




Figure 24. Onshore Mooring Container Stowage (Sheet 2 of 5)





Figure 24. Onshore Mooring Container Stowage (Sheet 3 of 5)




Figure 24. Onshore Mooring Container Stowage (Sheet 4 of 5)




Figure 24. Onshore Mooring Container Stowage (Sheet 5 of 5)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 24, ONSHORE MOORING CONTAINER STOWAGE						
1	XCOLL		34712	E50213	ONSHORE MOOR CONT	1
2	XDOZZ		34712	E51382	.PALLET, STORAGE BOX.....	1
3	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	7
4	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	6
5	XDOZZ		34712	E51312	.PALLET, BOTTOM, ANCH	2
6	XDOZZ		34712	E34168	.STOP, TRACK.....	5
7	XDOZZ		34712	E50883	.PALLET, CABLE, MOORNG.....	2
8	XDOZZ		34712	E52171	.PLYWOOD, TREATED	2
9	XDOZZ		39428	91845A310	.HEX NUT	6
10	PAOZZ	5310-01-466-2744	39428	90107A033	.WASHER, FLAT	6
11	XDOZZ		34712	0006113	.CAPSCREW	10
12	PAOZZ	5310-01-415-7132	0DHG4	PL50301100 ITEM 20	.WASHER, FLAT	13
13	XDOZZ		34712	0002433	.HEX NUT	13
14	XDOZZ		34712	E51842	.COVER	1
15	XDOZZ		34712	E51752	.PALLET, HDWR, STORAGE.....	1
16	XDOZZ		34712	E51772	.DRAWER, HDWR, STORAGE	3
17	XDOZZ		34712	0008615	.CAPSCREW	3
18	XDOZZ		34712	E45478	.STOP, TRACK.....	1
19	XDOZZ		34712	E51652	.PALLET, ANCHOR, TOP.....	1
20	XDOZZ		39428	6502A3	.WRENCH, ADJUSTABLE.....	2
21	XDOZZ		39428	5855A11	.HAMMER, BALL, PEEN	1
22	XDOZZ		39428	6511A4	.PLIERS, COMBINATION	1
23	XDOZZ		39428	6229A55	.SHOVEL	2
24	XDOZZ		39428	6428A63	.BAG, NYLON, TOOL.....	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

ONSHORE OUTER LEG MOORING SYSTEM PARTS LIST




Figure 25. Onshore Outer Leg Mooring System (Sheet 1 of 3)




Figure 25. Onshore Outer Leg Mooring System (Sheet 2 of 3)




Figure 25. Onshore Outer Leg Mooring System (Sheet 3 of 3)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 25, ONSHORE OUTER LEG MOORING SYSTEM						
1	XDOOO		34712	E52003	ASSY, ONSH MOOR LEG.....	1
2	XDOZZ		34712	E51592	.PADEYE, DEADMAN	1
3	PAOZZ	4030-00-169-9297	81348	RRC271	.SHACKLE	2
4	XDOZZ		34712	E51573	.WIRE ROPE	2
5	XDOZZ		34712	E51608-5	.STOP, CARPENTER.....	2
6	PAOZZ	4030-00-533-3900	75535	1018534	.SHACKLE	7
7	PAOZZ	4010-01-344-9148	75535	1014431	.LINK, CHAIN, DETACHAB	8
8	XDOZZ		75535	SPECTRUM 3	.CHAIN.....	4
9	PAOZZ	5365-01-036-7243	75535	S-643	.RING, WELDLESS	2
10	PFOZZ	5315-00-664-3798	75535	169515	.BLOCK, SNATCH	1
11	PAOZZ	3950-01-495-8333	12708	TU-32	.HOIST, WIRE ROPE.....	1
12	PFOZZ	4010-01-477-0498	75535	1014324	.LINK, MASTER.....	1
13	XDOZZ		34712	E51902	.PLATE, FLOUNDER.....	1
14	PAOZZ	4030-00-162-9668	75535	1018516	.SHACKLE	2
15	XDOZZ		34712	E52028	.ASSY, ROPE, WIRE	1
16	XDOZZ		34712	E52038	.ASSY, ROPE, WIRE	1
17	PAOZZ	4030-00-185-0489	81348	RR-C-271D TY 4A GR A CL 2	.SHACKLE	4
18	XDOFF		34712	E51453	.ASSY, ANCHOR, MOORING	4
19	XDOZZ		34712	E51561	..SHANK.....	1
20	PAOZZ	4030-01-499-9284	75535	1019472	..SHACKLE	1
21	XDOZZ		34712	E51473	..ASSY, FLUKE	1
22	PAOZZ	5315-00-236-8382	80205	MS24665-641	..PIN, COTTER	2
23	XDOZZ		34712	E51461	..STABILIZER.....	1
24	XDOZZ		96906	MS51107-125	..SCREW, HEX HEAD	1
25	XDOZZ		75535	1018874	..SHACKLE, CHAIN ROUND PIN..	1
26	PAOZZ	5310-00-768-0318	96906	MS51967-14	..NUT, PLAIN, HEXAGON .500-13 UNC-2B	1

0026 00

TM 55-1945-227-24P

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
27	PAOZZ	5315-00-234-1864	80205	MS24665-302	..PIN, COTTER 3/32 DIA X 1.00 L .	1
28	XDOLL		34712	E52143	.ASSY, ANCHOR, PENDANT	1
29	XDOZZ		04ZJ6	260044	..FLAG	1
30	XDOZZ		34712	E52143 ITEMS 1,2,3,5	..BAR ASSEMBLY	1
31	PAOZZ	4030-00-185-0481	75535	1018375	..SHACKLE	1

END OF FIGURE

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

ONSHORE INNER LEG MOORING SYSTEM PARTS LIST




Figure 26. Onshore Inner Leg Mooring System (Sheet 1 of 3)




Figure 26. Onshore Inner Leg Mooring System (Sheet 2 of 3)




Figure 26. Onshore Inner Leg Mooring System (Sheet 3 of 3)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 26, ONSHORE INNER LEG MOORING SYSTEM						
1	XDOOO		34712	E52343	ASSY, IN, ON, MOOR LEG	1
2	XDOZZ		34712	E51952	.PADEYE, DEADMAN	1
3	PAOZZ	4030-00-169-9297	81348	RRC271	.SHACKLE	1
4	XDOZZ		34712	E51573	.WIRE ROPE	1
5	XDOZZ		34712	E51608-5	.STOP, CARPENTER.....	2
6	PAOZZ	4030-00-533-3900	75535	1018534	.SHACKLE	7
7	PAOZZ	4010-01-344-9148	75535	1014431	.LINK, CHAIN, DETACHAB	8
8	XDOZZ		75535	SPECTRUM 3	.CHAIN	4
9	PAOZZ	5365-01-036-7243	75535	S-643	.RING, WELDLESS	2
10	PAOZZ	5315-00-664-3798	75535	169515	.BLOCK, SNATCH	1
11	PAOZZ	3950-01-495-8333	12708	TU-32	.HOIST, WIRE ROPE	1
12	PAOZZ	4010-01-477-0498	75535	1014324	.LINK, MASTER	1
13	XDOZZ		34712	E51902	.PLATE, FLOUNDER	1
14	PAOZZ	4030-00-162-9668	75535	1018516	.SHACKLE	2
15	XDOZZ		34712	E52028	.ASSY, ROPE, WIRE	1
16	XDOZZ		34712	E52038	.ASSY, ROPE, WIRE	1
17	PAOZZ	4030-00-185-0489	81348	RR-C-271D TY 4A GR A CL 2	.SHACKLE	4
18	XDOFF		34712	E51453	.ASSY, ANCHOR, MOORING	4
19	XDOZZ		34712	E51561	..SHANK	1
20	PAOZZ	4030-01-499-9284	75535	1019472	..SHACKLE	1
21	XDOZZ		34712	E51473	..ASSY, FLUKE	1
22	PAOZZ	5315-00-236-8382	80205	MS24665-641	..PIN, COTTER	2
23	XDOZZ		34712	E51461	..STABILIZER	1
24	XDOZZ		96906	MS51107-125	..SCREW, HEX HEAD	1
25	XDOZZ		75535	1018874	..SHACKLE, CHAIN	1
26	PAOZZ	5310-00-768-0318	96906	MS51967-14	..NUT, PLAIN, HEXAGON	1
27	PAOZZ	5315-00-234-1864	80205	MS24665-302	..PIN, COTTER 3/32 DIA X 1.00 L ..	1

0027 00

TM 55-1945-227-24P

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
28	XDOLL		34712	E52143	.ASSY, ANCHOR, PENDANT	1
29	XDOZZ		04ZJ6	260044	..FLAG	1
30	XDOZZ		34712	E52143 ITEMS 1,2,3,5	..BAR ASSEMBLY	1
31	PAOZZ	4030-00-185-0481	75535	1018375	..SHACKLE	1

END OF FIGURE

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

LIGHT SYSTEM PARTS LIST

1
2 Thru 15




Figure 27. Light System (Sheet 1 of 3)




Figure 27. Light System (Sheet 2 of 3)




Figure 27. Light System (Sheet 3 of 3)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 27, LIGHT SYSTEM						
1	XDOLL		34712	E33585	LIGHTING SYSTEM	1
2	XDOZZ		5K136	DAR-S-4205-24	.TIE DOWN	4
3	XDOZZ		34712	E34168	.STOP, TRACK.....	3
4	XDOZZ		34712	E45478	.STOP, TRACK.....	1
5	XDOZZ		34712	E35322	.PALLET, LIGHTING	2
6	XDOZZ		75535	HG-223	.TURNBUCKLE	8
7	PFOZZ	6220-01-505-1610	34712	E35658	.FLOODLIGHT, ELECTRIC	2
8	XDOZZ		34712	E42991	.INDICATOR, ANGLE.....	8
9	XDOZZ		1TL62	1001046	.LIGHT SUPPORT (LH).....	1
10	PAOZZ	5315-01-457-2385	39428	98497A661	.PIN, QUICK RELEASE	4
11	XDOZZ		1TL62	1001017	.RH-LIGHT SUPPORT.....	2
12	XDOZZ		1TL62	1001032	.LH-LIGHT SUPPORT	2
13	XDOZZ		1TL62	1001022	.END BRACKET.....	2
14	XDOZZ		1TL62	1001019	.LIGHT SUPPORT (RH).....	1
15	XDOZZ		5K136	DAR-S-4203-8	.TIE DOWN	2
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

DECK MATT STOWAGE PARTS LIST

1
[2 Thru 20] 15
[16 Thru 18]




Figure 28. Deck Matt Stowage (Sheet 1 of 2)




Figure 28. Deck Matt Stowage (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 28, DECK MATT STOWAGE						
1	XDOLL		34712	E50685	DECK MATT STOWAGE	1
2	XDOZZ		34712	E33811	.DECK MATTING	24
3	XDOZZ		5K136	DAR-S-4203-24	.TIE DOWN	3
4	XDOZZ		34712	E34352	.PALLET, DECK MATT	1
5	PEOZZ	5120-00-199-7765	39428	5547A24	.SOCKET, SOCKET WRENC 3/4",1- 5/8"	1
6	PEOZZ	8105-01-438-9279	39428	6565A11	.BAG, TOOLS AND SPARE	1
7	PEOZZ	5120-01-514-2231	45225	1923	.SOCKET, SOCKET WRENC	1
8	PEOZZ	5120-00-144-5207	39428	5523A38	.ADAPTER, SOCKET WREN 1/2"-3/ 4"	1
9	PAOZZ	3990-01-449-9718	94658	35MTC/1561	.TIE DOWN, CARGO, VEHIC.....	4
10	PAOZZ	4030-01-499-9284	75535	1019472	.SHACKLE	4
11	XDOZZ		5K136	DAR-S-4219-24	.TIE DOWN	8
12	XDOOO		34712	E34793	.CORNER FENDER, LH	4
13	XDOOO		34712	E34553	.CORNER FENDER, RH	4
14	XDOLL		34712	E34763	.MOUNTING ASSEMBLY	8
15	XDOOO		34712	E33823	.LOCKDOWN ASSEMBLY	30
16	XDOZZ		34712	E33972	..DOG WELDMENT	1
17	XDOZZ		34712	E33982	..WASHER WELDMENT	1
18	XDOZZ		39428	91845A038	..NUT, HEXAGON	1
19	XDOOO		34712	E07803	.D-RING ASSEMBLY	8
20	XDOOO		34712	E07723	.MOORING, CLEAT ASSY	8
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

BASIC ISSUE ITEM CONTAINER PARTS LIST

1
2 Thru 7




Figure 29. Basic Issue Item Container (Sheet 1 of 2)




Figure 29. Basic Issue Item Container (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 29, BASIC ISSUE ITEM CONTAINER						
1	XDFLL		34712	E51008	CONTAINER, BII	1
2	XDFZZ		5Y992	ST600	.CABINET, SHELF	6
3	XDFZZ		5Y992	STC13508	.CABINET, FILE	4
4	XDFZZ		5Y992	STC13506	.CABINET, FILE	2
5	PAFZZ	4030-00-185-0489	81348	RR-C-271D TY 4A GR A CL 2	.SHACKLE	6
6	XDFZZ		1TL62	1001058	.NET, CARGO	1
7	PAFZZ	3940-01-449-2385	098P0	B9154-090-168-2R- 14C	.NET, DRAFT COVER	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

GENERATOR CONTAINER EXTERIOR COMPONENTS PARTS LIST




Figure 30. Generator Container Exterior Components (Sheet 1 of 2)




Figure 30. Generator Container Exterior Components (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 30, GENERATOR CONTAINER EXTERIOR COMPONENTS						
1	XDOLL		34712	E33228	GENERATOR CONTAINER.....	1
2	XDFFF		64747	P0001095-001	.DOOR, WEATHERTIGHT.....	1
3	XDFZZ		64747	0411-2402	..OVAL MACH SCREWS	20
4	XDFZZ		64747	0611-9506	..FLAT BAR RETAINER	1
5	XDFZZ		64747	0331-2006	..GLAZING TAPE	2
6	XDFZZ		64747	0311-2009	..WINDOW, GLASS	1
7	XDFZZ		64747	0331-2021	..SETTING BLOCK	4
8	XDFZZ		64747	0331-2007	..SILICONE SEALANT	1
9	XDFZZ		64747	0251-1001	..DOG SET	2
10	XDFZZ		64747	0422-1002	..LOCK SET	1
11	PAFZZ	5330-01-479-8995	64747	0631-9820	..GASKET	1
12	XDOOO		1TL62	1001016	.STAIR ASSEMBLY	1
13	XDOZZ		39428	90640A129	..LOCK NUT	4
14	XDOZZ		39428	90108A413	..FLAT WASHER	4
15	PAOZZ	5305-01-457-4553	96906	MS51960-69L	..SCREW, MACHINE, FLAT	4
16	XDOZZ		34712	E33228-84	.LOUVER COVER ASSY	1
17	XDOZZ		39428	92147A030	.WASHER, LOCK, SPRING	20
18	XDOZZ		39428	9319A583	.BOLT, HEX HEAD	20
19	XDOZZ		34712	E33228-87	.COVER ASSEMBLY	1
20	XDOZZ		34712	E33228-86	.COVER ASSEMBLY	1
21	XAOZZ		34712	E33228-51	.LATCH	1
22	XDOZZ		34712	E33228-85	.LOUVER COVER ASSY	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

GENERATOR CONTAINER FUEL LEVEL INDICATING PANEL PARTS LIST





Figure 31. Generator Container Fuel Level Indicating Panel (Sheet 1 of 2)




Figure 31. Generator Container Fuel Level Indicating Panel (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 31, GENERATOR CONTAINER FUEL LEVEL INDICATING PANEL						
1	XDFFF		1PL62	1001003	BOX,INDICATOR PANEL.....	1
2	XDFZZ		39428	90286A310	.MS SELF TAPPING	2
3	XDFZZ		01121	CAT NO. 592	.TRANSFORMER	1
4	XDFZZ		39428	92446A192	.MACHINE SCREW PN HD.....	2
5	XDFZZ		01121	3004100	.FUSE HOLDER.....	1
6	XDFZZ		0YM33	740-3014	.FUSE.....	1
7	XDFZZ		01121	700HA32A24	.RELAY.....	5
8	XDFZZ		01121	700HN125	.RELAY PLUG	5
9	PAFZZ	6220-01-495-7655	01121	800T-QS24R	.LIGHT, INDICATOR.....	5
10	PAFZZ	6240-01-026-1376	56365	25501-01024	..LAMP, INCANDESCENT.....	9
11	PAFZZ	6220-01-526-9733	01121	800T-N122R	..LENS, LIGHT.....	5
12	PAFZZ	6220-01-495-7659	01121	800T-QS24A	.LIGHT, INDICATOR.....	2
13	PAFZZ	6210-01-178-4548	01121	800T-N122A	..LENS, LIGHT.....	2
14	XDFFF		01121	800T-QS24G	.PILOT LAMP, GREEN.....	2
15	PAFZZ	6650-01-292-1242	01121	800T-N122G	..CAP, LENS.....	2
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

GENERATOR CONTAINER ELECTRICAL COMPONENTS PARTS LIST




Figure 32. Generator Container Electrical Components (Sheet 1 of 4)




Figure 32. Generator Container Electrical Components (Sheet 2 of 4)





Figure 32. Generator Container Electrical Components (Sheet 3 of 4)




Figure 32. Generator Container Electrical Components (Sheet 4 of 4)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 32, GENERATOR CONTAINER ELECTRICAL COMPONENTS						
1	XDOZZ		04055	734/78	BATTERY.....	1
2	XDOZZ		31117	FF60M	TIMER	1
3	XDOZZ		39428	91773A194	PHILLIPS MACH SCREW #8-32 X 1/ 2"	5
4	XDOZZ		39428	71695K45	RECEPTACLE COVER	1
5	XDOOO		39428	7462K22	DUPLEX RECEPTACLE	1
6	XDOZZ		39428	71695K41	OUTLET SWITCH BOX	1
7	XDOZZ		39428	9185A185	NUT, HEAVY, HEX	1
8	XDOZZ		39428	92147A030	WASHER, LOCK, SPRING	1
9	PAOZZ	5310-00-625-5756	80205	MS15795-812	WASHER, FLAT	1
10	XDOZZ		0FDK5	33-94167-HP-E292	FM ELEC RECEPTACLE.....	1
11	PAOZZ	5310-01-229-6260	39428	92146A029	WASHER, LOCK	4
12	PAOZZ	5305-01-488-6983	39428	92240A544	SCREW, CAP, HEXAGON H	4
13	XDOOO		56365	QO312L125G	DISTR PANEL, ELECT	1
14	XDOZZ		56365	40205-130-02	.SCREW, MOUNTING	4
15	XDOZZ		56365	QOC16US	.PANEL COVER.....	1
16	PAOZZ	5925-01-111-7562	81348	WC375/1-003	CIRCUIT BREAKER	5
17	XDOZZ		25795	4P750	PH SCREW, SELF TAP	3
18	XDOZZ		25795	4P490	FLAT WASHER	3
19	PAOZZ	5930-00-296-5290	81349	M15743/3-002	SWITCH, ROTARY	1
20	PAOZZ	5930-00-263-1497	14280	D323N	SWITCH, DISCONNECT.....	1
21	XDOZZ		75915	FLNR070	FUSE	3
22	XDOOO		34712	E50629	FIXTURE, INCANDESCEN	1
23	PAOZZ	6210-01-163-7083	95405	INX2004C	.GLOBE, ELECTRIC LIGH.....	1
24	XDOZZ		95405	INX2006	.GLOBE	1
25	XDOZZ		39428	8357K16	.LAMP, MARINE.....	1
26	PAOZZ	5305-01-218-9767	39428	91773A242	.SCREW, MACHINE	4

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
27	PAOZZ	5330-01-414-6600	95405	GKT3000	.GASKET, JUNCTION BOX.....	1
28	PAOZZ	5305-01-357-3985	39428	91792A540	SCREW, MACHINE	5
29	PAOZZ	5310-01-106-5270	57583	12845-00	WASHER, FLAT	5
30	XDOZZ		39428	3259T11	NUT, CLAMP	5
31	XDOZZ		85213	M3-40-3-2C	LIGHT FIXTURE	1
32	XDOZZ		62607	046677-36932-2	FLOURESCENT TUBE	3
33	PAOZZ	6210-00-295-2838	81349	M16377/42-003	FILTER, INDICATOR LI	1
34	PAOZZ	5340-00-776-5920	81349	M16377-53-002	GRIP, HANDLE	1
35	PAOZA	6230-00-578-7401	81349	M16377/54-2438	HOLDER, LIGHT	1
36	PAOZZ	6230-00-783-6519	81349	M16377-53-001	BODY ASSEMBLY, LANTE	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

PERSONNEL SHELTER EXTERIOR COMPONENTS REPAIR PARTS LIST




Figure 33. Personnel Shelter Exterior Components

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 33, PERSONNEL SHELTER EXTERIOR COMPONENTS						
1	XDOLL		34712	E32708	PERSONNEL SHELTER	1
2	XDOZZ		81349	MIL-B-857	.NUT, PLAIN, HEXAGON.....	1
3	PAOZZ	5310-00-974-6623	80205	MS35338-140	.WASHER, LOCK.....	1
4	PAOZZ	5310-00-167-0803	80205	NAS1149C0563R	.WASHER, FLAT	1
5	XDOZZ		1TL62	1001028	.COVER ASSEMBLY	1
6	XDFFF		64747	P001095-001	.DOOR, WEATHERTIGHT.....	1
7	XDFZZ		64747	0411-2402	..OVAL MACH SCREWS	20
8	XDFZZ		64747	0611-9506	..FLAT BAR RETAINER	1
9	XDFZZ		64747	0331-2006	..GLAZING TAPE	2
10	XDFZZ		64747	0311-2009	..WINDOW, GLASS	1
11	XDFZZ		64747	0331-2021	..SETTING BLOCK	4
12	XDFZZ		64747	0331-2007	..SILICONE SEALANT	1
13	XDFZZ		64747	0422-1002	..LOCK SET	1
14	XDFZZ		64747	0251-1001	..DOG SET	2
15	PAFZZ	5330-01-479-8995	64747	0631-9820	..GASKET	1
16	XDFZZ		64747	2407-0003-3	.GASKET, SCUTTLE	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

**FLOATING CAUSEWAY
EIC TBD**

PERSONNEL SHELTER INTERIOR COMPONENTS PARTS LIST




Figure 34. Personnel Shelter Interior Components (Sheet 1 of 5)




Figure 34. Personnel Shelter Interior Components (Sheet 2 of 5)




Figure 34. Personnel Shelter Interior Components (Sheet 3 of 5)




Figure 34. Personnel Shelter Interior Components (Sheet 4 of 5)




Figure 34. Personnel Shelter Interior Components (Sheet 5 of 5)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 34, PERSONNEL SHELTER INTERIOR COMPONENTS						
1	XDOOO		1TL62	1001023	.ASSEMBLY, BENCH.....	3
2	XDOZZ		1TL62	1001023-1	..BENCH.....	1
3	XDOZZ		39428	90935A245	..MACHINE SCREW	40
4	XDOZZ		39428	91478A583	..HEX HD LAG SCREW.....	64
5	XDOZZ		39428	90108A030	..WASHER, FLAT.....	64
6	XDOOO		1TL62	1001026	.ASSEMBLY, TABLE	1
7	XDOZZ		1TL62	1001026-1	..TABLE TOP	1
8	XDOOO		1TL62	1001025	.ASSEMBLY, BENCH.....	1
9	XDOZZ		1TL62	1001025-1	..BENCH.....	1
10	XDOOO		1TL62	1001024	.ASSEMBLY, BENCH.....	1
11	XDOZZ		1TL62	1001024-1	..BENCH.....	1
12	PAOZZ	8520-00-782-3554	80244	8520-00-782-3554	.HAND CLEANER	1
13	PAOZZ	4510-01-470-9561	23989	LIN001	.LINER, LATRINE.....	1
14	XDOZZ		55962	52CQ-512-3 CPRC	.AIR CONDITIONER	1
15	XDOZZ		82851	N226399	.HINGE SET.....	3
16	XDOZZ		34712	E32708-4	.DOOR, INTERIOR	1
17	XDOZZ		66821	LF5302	.SET, LOCK	1
18	XDOZZ		80244	A-A-393 TY1CL1SZ10	.EXTINGUISHER, FIRE.....	2
19	XDOOO		1TL62	1001004	.CHARGER, RADIO.....	1
20	XDOZZ		39428	90640A129	..LOCK NUT.....	4
21	XDOZZ		39428	90108A413	..FLAT WASHER	4
22	XDOZZ		1TL62	1001004-4	..STRAP TIE DOWN	2
23	PAOZZ	5340-00-776-5920	81349	M16377-53-002	.GRIP, HANDLE	1
24	PAOZZ	6230-00-578-7401	81349	M16377/54-2438	.HOLDER, LIGHT.....	1
25	PAOZZ	6230-00-783-6519	81349	M16377-53-001	.BODY ASSEMBLY, LANTE.....	1
26	PAOZO	6210-00-548-0222	81349	M16377/12-333.1	.FIXTURE, LIGHTING	1
27	XDOZZ		39428	98019A315	.FLAT WASHER	4

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
28	XDOZZ		39428	94074A147	.SCREW, SELF TAPPING	4
29	PAOZZ	6210-00-295-2838	81349	M16377/42-003	.FILTER, INDICATOR LI.....	2
30	PAOZZ	6240-00-152-2996	58536	A-A-55005-1	.LAMP, FLUORESCENT	3
31	PAOZZ	6650-01-495-6762	85213	B-1723-NS	.CAP, LENS	1
32	PAOZZ	5925-00-062-3743	56303	QO230	.BREAKER, CIRCUIT	1
33	PAOZZ	5925-00-967-9874	56365	QO220	.BREAKER, CIRCUIT	1
34	PAOZZ	5925-01-496-3104	56365	QO220SWN	.BREAKER, CIRCUIT	2
35	PAOZZ	5925-01-496-3147	56365	QO215SWN	.BREAKER, CIRCUIT	4
36	PAOZZ	5975-00-947-3068	28488	5094-0	.PLATE, ELECTRICAL.....	1
37	XDOZZ		74545	HBL8300GY	.RECEPTACLE ELECTRIC	1
38	PAOZZ	5975-01-334-9847	56501	WGF100-CV	.PLATE, WALL, ELECTRIC.....	1
39	PAOZZ	5925-01-128-6284	60969	TGTR115	.INTERRUPTER, GROUND.....	1
40	XDOOO		1TL62	1001020	.JUNCTION BOX	1
41	XDOZZ		1TL62	1001020-2	..GASKET.....	1
42	XDOZZ		1TL62	1001020-3	..PLATE, COVER	1
43	XDOZZ		39428	91772A245	..MACHINE SCREW	4
44	PAOZZ	5305-00-021-3668	80205	MS35307-310	.SCREW, CAP, HEXAGON H.....	4
45	XDOZZ		0FDK5	33-94167-HP-E292	.FM ELEC RECEPTACLE	1
46	XDOZZ		96906	MS16628-1	.HEX NUT	4

END OF FIGURE

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

FLOATING CAUSEWAY
EIC TBD

PERSONNEL SHELTER HEAD COMPONENTS PARTS LIST




Figure 35. Personnel Shelter Head Components (Sheet 1 of 2)




Figure 35. Personnel Shelter Head Components (Sheet 2 of 2)

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 03						
FIGURE 35, PERSONNEL SHELTER HEAD COMPONENTS						
1	XDOZZ		09295	S130	.VENTILATOR	1
2	PAOZZ	5930-00-296-5290	81349	M15743/3-002	.SWITCH, ROTARY	1
3	XDOOO		1NWH3	55M-122-18G-.187PC/.125AP-120MAG	.LIGHT FIXTURE, HEAD	1
4	XDOZZ		1NWH3	OVS-8/32 X 1.5"	..OVAL HEAD SCREW	2
5	XDOZZ		1NWH3	OVS-8/32 X 3/4"	..OVAL HEAD SCREW	3
6	XDOZZ		39428	99663A213	..SCREW, SELF-TAPPING	2
7	XDOZZ		1NWH3	2-F20T12CW	..LAMP, FLOURESCENT	2
8	XDOZZ		0TEH8	5M494	..DRYWALL SCREW	4
9	XDOZZ		0TEH8	2X037	..FENDER WASHER,3/16"	4
10	PAOZZ	5945-01-301-4095	77342	KRPA-11AG-120	.RELAY, ELECTROMAGNET.....	1
11	XDOZZ		39428	48925K18	.PIPE	1
12	XDOZZ		39428	1056-44	.COUPLING, PIPE	1
13	XDOZZ		39428	9102K243	.COUPLING, PIPE	1
14	PBOZZ	4510-01-470-8101	23989	MODEL WB	.TOILET, ENCLOSED	1
END OF FIGURE						

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCEFLOATING CAUSEWAY
EIC TBDSPECIAL TOOLS PARTS LIST

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 04						
FIGURE 36, SPECIAL TOOLS						
1	PEOZZ	5180-01-500-1548	0XWR1	07909-33102	TOOL KIT, VALVE SEAT	1
2	PEHZZ	5120-01-486-5065	0WXR1	07916-09032	PULLER, MECHANICAL	1
3	PEHZZ	5120-01-479-5832	0XWR1	07909-31661	ALIGNING TOOL, ROTAT	1
END OF FIGURE						

**UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
FLOATING CAUSEWAY
EIC TBD
NATIONAL STOCK NUMBER INDEX**

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-00-021-3668	34	44	5975-01-048-2922	23	8
5925-00-062-3743	34	32	2040-01-092-3081	1	2
5120-00-144-5207	28	8		8	2
6240-00-152-2996	34	30	5310-01-106-5270	32	29
4030-00-162-9668	25	14	5925-01-111-7562	32	16
	26	14	5925-01-128-6284	34	39
5310-00-167-0803	33	4	6210-01-163-7083	32	23
4030-00-169-9297	25	3	6210-01-178-4548	31	13
	26	3	4030-01-186-7197	23	15
4030-00-185-0481	25	31	5305-01-188-9622	2	5
	26	31		3	5
4030-00-185-0489	25	17		4	5
	26	17		5	5
	29	5		9	6
5120-00-199-7765	28	5		10	5
5315-00-234-1864	25	27		11	5
	26	27		12	5
5315-00-236-8382	25	22		13	9
	26	22	5305-01-190-2200	22	3
5930-00-263-1497	32	20	5305-01-218-9767	32	26
6210-00-295-2838	32	33	5310-01-229-6260	32	11
	34	29	6650-01-292-1242	31	15
5930-00-296-5290	32	19	5945-01-301-4095	35	10
	35	2	5975-01-334-9847	34	38
4030-00-343-5433	17	5	4010-01-344-9148	25	7
	19	13		26	7
4030-00-533-3900	25	6	5305-01-357-3985	32	28
	26	6	5330-01-414-6600	32	27
6210-00-548-0222	34	26	5310-01-415-7132	24	12
6230-00-578-7401	32	35	8105-01-438-9279	28	6
	34	24	4030-01-439-6426	23	6
5310-00-584-7796	22	6	3940-01-449-2385	29	7
5310-00-625-5756	32	9	3990-01-449-9718	28	9
5315-00-664-3798	25	10	5315-01-457-2385	27	10
	26	10	5305-01-457-4553	30	15
5310-00-764-6610	22	7	5310-01-466-2744	24	10
5310-00-768-0318	25	26	4510-01-470-8101	35	14
	26	26	4510-01-470-9561	34	13
5340-00-776-5920	32	34	4010-01-477-0498	25	12
	34	23		26	12
8520-00-782-3554	34	12	5120-01-479-5832	36	3
6230-00-783-6519	32	36	5330-01-479-8995	30	11
	34	25		33	15
5975-00-947-3068	34	36	5305-01-485-8084	3	13
5925-00-967-9874	34	33		5	13
5310-00-974-6623	33	3		10	13
6240-01-026-1376	31	10		12	13
5365-01-036-7243	25	9	5120-01-486-5065	36	2
	26	9	5305-01-488-6983	32	12

0038 00

TM 55-1945-227-24P

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
1945-01-495-4684	3	1			
	10	1			
1945-01-495-4738	2	1			
	9	1			
1945-01-495-4838	4	1			
	11	1			
1945-01-495-4842	5	1			
	12	1			
3990-01-495-4848	13	1			
1945-01-495-5249	2	2			
	3	2			
	4	2			
	5	2			
	9	2			
	10	2			
	11	2			
	12	2			
	13	2			
6650-01-495-6762	34	31			
6220-01-495-7655	31	9			
6220-01-495-7659	31	12			
4030-01-495-8304	23	5			
2540-01-495-8321	3	16			
	5	16			
	10	16			
	12	16			
3950-01-495-8333	25	11			
	26	11			
5925-01-496-3104	34	34			
5925-01-496-3147	34	35			
4030-01-499-9284	17	11			
	18	8			
	19	7			
	25	20			
	26	20			
	28	10			
5180-01-500-1548	36	1			
6220-01-505-1610	27	7			
5120-01-514-2231	28	7			
6220-01-526-9733	31	11			

**UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
FLOATING CAUSEWAY
EIC TBD
PART NUMBER INDEX**

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
A-150	17	16		11	8
	18	16		12	8
	19	15		13	7
A-A-393 TY1CL1SZ10	34	18	E04251	2	9
A-A-55005-1	34	30		3	9
B-1723-NS	34	31		4	9
B9154-090-168-2R-14C	29	7		5	9
CABLE 110	17	17		9	9
	18	17		10	9
	19	16		11	9
CAT NO. 592	31	3		12	9
CMBOW400	17	18	E04282	2	8
	18	18		3	2
	19	17		4	2
D323N	32	20		5	2
DAR-S-4203-24	28	3		9	2
DAR-S-4203-8	17	10		10	2
	18	7		11	2
	19	6		12	2
	22	2		13	2
	24	3	E04842	3	11
	27	15		5	11
DAR-S-4205-24	17	14		10	11
	18	2		12	11
	19	10	E04872	3	16
	22	14		5	16
	24	4		10	16
	27	2		12	16
DAR-S-4219-24	17	3	E06811	3	15
	19	2		5	15
	28	11		10	15
DAR-S-4220-24	18	4		12	15
E02783	1	2	E07218	2	10
	8	2		3	10
E02803	2	1		4	10
	9	1		5	10
E02813	3	1		9	10
	10	1		10	10
E02823	4	1		11	10
	11	1		12	10
E02833	5	1		13	5
	12	1			
E02853	13	1			
E04222	2	8			
	3	8			
	4	8			
	5	8			
	9	8			
	10	8			

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
E07531	2	3	E33802	17	9
	3	3		19	5
	4	3	E33811	28	2
	5	3	E33823	28	15
	9	3	E33832	18	15
	10	3	E33972	28	16
	11	3	E33982	28	17
	12	3	E34102	17	7
	13	3		19	11
E07671	6	3	E34168	17	2
	7	3		18	3
	14	3		19	3
	15	3		24	6
E07723	7	1		27	3
	15	1	E34232	20	9
	28	20	E34262	21	10
E07733	16	1	E34352	28	4
E07803	6	1	E34398	20	6
	14	1	E34412	20	15
	28	19		21	15
E13011-1	2	6	E34553	20	1
	9	5		28	13
E13011-2	5	6	E34611	20	2
	12	6		21	6
E13011-3	4	6	E34621	20	3
	11	6		21	2
E13011-4	3	6	E34648	20	7
	10	6		21	11
E13011-5	13	10	E34658	20	11
E19183	8	1		21	7
E19193	1	1	E34728	21	3
E26482	16	3	E34763	20	12
E26492	7	2		21	12
	15	2		28	14
E26502	6	2	E34793	21	1
	14	2		28	12
E32708	33	1	E35322	27	5
E32708-4	34	16	E35592	23	14
E32718	18	11	E35621	23	18
E33112	23	16	E35658	27	7
E33121	23	23	E35733	23	12
E33131	23	25	E35863	18	14
E33141	23	24	E38052	3	12
E33151	23	13		5	12
E33192	23	17		10	12
E33228	30	1		12	12
E33228-51	30	21	E38082	3	17
E33228-84	30	16		5	17
E33228-85	30	22		10	17
E33228-86	30	20		12	17
E33228-87	30	19	E42369	20	13
E33302	18	12		21	13
E33382	18	6	E42991	27	8
E33585	27	1			

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
E45478	17	8	E52143	ITEMS 1,2,3,5	25 30
	18	5		26	30
	19	4	E52171	24	8
	24	18	E52343	26	1
	27	4	E57891	22	5
E49532	23	2	E57911	22	17
E49752	22	8	E58041	22	4
E49913	22	1	FF60M	32	2
E49922	22	12	FLNR070	32	21
E49932	22	13	G03X05-2579	17	6
E49952	22	9		19	12
E50013	23	4	G04X12-2456	18	10
E50043	23	11	G05X10-2237	17	13
E50053	23	7		19	9
E50073	23	10	GKT3000	32	27
E50123	23	1	HBL8300GY	34	37
E50213	24	1	HG-223	27	6
E50629	32	22	INX2004C	32	23
E50685	28	1	INX2006	32	24
E50695	18	1	KRPA-11AG-120	35	10
E50735	19	1	LF5302	34	17
E50745	17	1	LIN001	34	13
E50752	17	15	M15743/3-002	32	19
E50883	24	7		35	2
E51008	29	1	M16377-53-001	32	36
E51312	24	5		34	25
E51382	24	2	M16377-53-002	32	34
E51453	25	18		34	23
	26	18	M16377/12-333.1	34	26
E51461	25	23	M16377/42-003	32	33
	26	23		34	29
E51473	25	21	M16377/54-2438	32	35
	26	21		34	24
E51561	25	19	M3-40-3-2C	32	31
	26	19	MIL-B-857	33	2
E51573	25	4	MODEL WB	35	14
	26	4	MS15795-812	32	9
E51592	25	2	MS15795-824	22	6
E51608-5	25	5	MS16628-1	34	46
	26	5	MS24665-302	25	27
E51652	24	19		26	27
E51752	24	15	MS24665-641	25	22
E51772	24	16		26	22
E51842	24	14	MS3367-6-0	23	8
E51902	25	13	MS35307-310	34	44
	26	13	MS35307-511	22	3
E51952	26	2	MS35338-140	33	3
E52003	25	1	MS51107-125	25	24
E52028	25	15		26	24
	26	15	MS51960-69L	30	15
E52038	25	16	MS51967-14	25	26
	26	16		26	26
E52143	25	28	MS51971-9	22	7
	26	28	N226399	34	15
			N2H150CP	16	2

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
NAS1149C0563R	33	4	0611-9506	30	4
OVS-8/32 X 1.5"	35	4		33	8
OVS-8/32 X 3/4"	35	5	0631-9820	30	11
PL50301100 ITEM 20	24	12		33	15
P0001095-001	30	2	07909-31661	36	3
P001095-001	33	6	07909-33102	36	1
P3F5	16	4	07916-09032	36	2
QO215SWN	34	35		33	15
QO220	34	33	1/2" LLLC	17	4
QO220SWN	34	34		19	14
QO230	34	32	1001003	31	1
QO312L125G	32	13	1001004	34	19
QOC16US	32	15	1001004-4	34	22
RR-C-271D TY 4A GR A CL	25	17	1001016	30	12
2			1001017	27	11
	26	14	1001019	27	14
	29	5	1001020	34	40
RRC271	25	3	1001020-2	34	41
	26	3	1001020-3	34	42
S-643	25	9	1001022	27	13
	26	9	1001023	34	1
S130	35	1	1001023-1	34	2
SPECTRUM 3	25	8	1001024	34	10
	26	8	1001024-1	34	11
ST600	29	2	1001025	34	8
STC13506	29	4	1001025-1	34	9
STC13508	29	3	1001026	34	6
TGTR115	34	39	1001026-1	34	7
TU-32	25	11	1001028	33	5
	26	11	1001032	27	12
WC375/1-003	32	16	1001046	27	9
WGF100-CV	34	38	1001058	29	6
0000901	23	22	1014324	25	12
0002433	24	13		26	12
0003288	22	15	1014431	25	7
0004177	22	11		26	7
0006113	24	11	1016215	23	5
0006880	22	10	1018026	3	14
0007934	22	16		5	14
0008615	24	17		10	14
0251-1001	30	9		12	14
	33	14	1018375	25	31
0311-2009	30	6		26	31
	33	10	1018455	26	17
0331-2006	30	5	1018516	25	14
	33	9	1018534	25	6
0331-2007	30	8		26	6
	33	12	1018874	25	25
0331-2021	30	7		26	25
	33	11	1019472	17	11
0411-2402	30	3		18	8
	33	7		19	7
0422-1002	30	10		25	20
	33	13		26	20
046677-36932-2	32	32		28	10

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
1019515	17	5	82043	23	15
	19	13	8357K16	32	25
1019551	23	6	8520-00-782-3554	34	12
1019597	17	12	90107A033	24	10
	18	9	90108A030	34	5
	19	8	90108A413	30	14
1019613	23	3		34	21
1056-44	35	12	90286A310	31	2
12845-00	32	29	90499A845	6	4
169515	25	10		7	4
	26	10		14	4
1923	28	7		15	4
2-F20T12CW	35	7	90640A129	30	13
2407-0003-3	33	16		34	20
25501-01024	31	10	90935A245	34	3
260044	25	29	9102K243	35	13
	26	29	91478A583	34	4
2X037	35	9	91654A144	2	5
3004100	31	5		3	5
3259T11	32	30		4	5
33-94167-HP-E292	32	10		5	5
	34	45		9	6
35MTC/1561	28	9		10	5
40205-130-02	32	14		11	5
4403	23	9		12	5
48925K18	35	11		13	9
4P490	32	18	91772A245	34	43
4P750	32	17	91773A194	32	3
5094-0	34	36	91773A242	32	26
52CQ-512-3 CPRC	34	14	91792A540	32	28
5523A38	28	8	91845A038	28	18
5547A24	28	5	91845A310	20	4
55M-122-18G-.187PC/.125AP-120MAG	35	3		21	4
				23	20
5855A11	24	21		24	9
5M494	35	8	9185A185	32	7
60513	18	13	92141A033	20	5
6229A55	24	23		21	5
6428A63	24	24	92141A044	20	14
6502A3	24	20		21	14
6511A4	24	22	92146A029	32	11
6565A11	28	6	92147A030	30	17
700HA32A24	31	7		32	8
700HN125	31	8	92186A723	20	10
71695K41	32	6		21	9
71695K45	32	4	92240A544	32	12
734/78	32	1	92240A722	20	8
740-3014	31	6		21	8
7462K22	32	5	92446A192	31	4
800T-N122A	31	13	92620A928	6	5
800T-N122G	31	15		7	5
800T-N122R	31	11		14	5
800T-QS24A	31	12		15	5
800T-QS24G	31	14	93190A626	3	13
800T-QS24R	31	9		5	13

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
	10	13			
	12	13			
93190A714	23	21			
93190A716	23	19			
93190A722	2	7			
	3	7			
	4	7			
	5	7			
	9	7			
	10	7			
	11	7			
	12	7			
	13	6			
9319A583	30	18			
94074A147	34	28			
94805A125	2	4			
	3	4			
	4	4			
	5	4			
	9	4			
	10	4			
	11	4			
	12	4			
	13	4			
98019A315	34	27			
98497A661	27	10			
99663A213	35	6			

The following format must be used if submitting an electronic 2028. The subject line must be exactly the same and all fields must be included; however, only the following fields are mandatory: 1, 3, 4, 5, 6, 7, 8, 9, 10, 13, 15, 16, 17 and 27.

From: "Whomever" whomever@avma27.army.mil
To: whomever@avma27.army.mil
To: TACOM-TECH-PUBS@ria.army.mil

Subject: DA Form 2028

1. **From:** Joe Smith
2. **Unit:** home
3. **Address:** 4300 Park
4. **City:** Hometown
5. **St.:** MO
6. **Zip:** 77777
7. **Date Sent:** 19-OCT-93
8. **Pub no:** 55-1915-200-10
9. **Pub Title:** TM
10. **Publication Date:** 11-APR-88
11. **Change Number:** 12
12. **Submitter Rank:** MSG
13. **Submitter Name:** Joe
14. **Submitter FName:** T
15. **Submitter Lname:** Smith
16. **Submitter Phone:** 123-123-1234
17. **Problem:** 1
18. **Page:** 1
19. **Paragraph:** 3
20. **Line:** 4
21. **NSN:** 5
22. **Reference:** 6
23. **Figure:** 7
24. **Table:** 8
25. **Item:** 9
26. **Total:** 123
27. **Text:**

This is the text for the problem below line 27.

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS <small>For use of this form, see AR 25-30; the proponent agency is OAASA</small>						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE Date form is filled out	
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) Mailing address found on title block page.						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>) Your mailing address.		
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS								
PUBLICATION/FORM NUMBER						DATE	TITLE	
TM XX-XXXX-XX-XX						Date of the TM	Title of the TM	
ITEM	PAGE	PARA-GRAF	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON		
	0019 00-1	3	1	1		Step No. 2 says to secure doors open with locking bar or hooks from where to what? The bars or hooks are not identified.		
	0019 00-4	4	1	1		Step No. 19 states to remove locking bar, pins or hooks from where to what? The bars, pins or hooks are not identified. Where are they stored?		
<i>* Reference to line numbers within the paragraph or subparagraph.</i>								
TYPED NAME, GRADE OR TITLE			TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE		
Doe, John, CPL			755-1313			CPL John Doe		

TO: <i>(Forward direct to addressee listed in publication)</i>				FROM: <i>(Activity and location) (Include ZIP Code)</i>				DATE
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM XX-XXXX-XX-XX				DATE Date of the TM		TITLE Title of the TM		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE Doe, John, CPL			TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION 755-1313			SIGNATURE CPL John Doe		

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE	
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)		
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS								
PUBLICATION/FORM NUMBER						DATE	TITLE	
ITEM	PAGE	PARA-GRAF	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON		
* Reference to line numbers within the paragraph or subparagraph.								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i>				FROM: <i>(Activity and location) (Include ZIP Code)</i>				DATE
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 55-1945-227-24P				DATE 2 APRIL 2006	TITLE Repair Parts and Special Tools List (RPSTL) for Modular Causeway System (MCS), Floating Causeway (FC)			
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE	
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)		
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS								
PUBLICATION/FORM NUMBER						DATE	TITLE	
ITEM	PAGE	PARA-GRAF	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON		
* Reference to line numbers within the paragraph or subparagraph.								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i>				FROM: <i>(Activity and location) (Include ZIP Code)</i>				DATE
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 55-1945-227-24P				DATE 2 APRIL 2006		TITLE Repair Parts and Special Tools List (RPSTL) for Modular Causeway System (MCS), Floating Causeway (FC)		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE			TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE		

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE	
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)		
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS								
PUBLICATION/FORM NUMBER						DATE	TITLE	
ITEM	PAGE	PARA-GRAF	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON		
* Reference to line numbers within the paragraph or subparagraph.								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i>				FROM: <i>(Activity and location) (Include ZIP Code)</i>				DATE
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 55-1945-227-24P				DATE 2 May 2006		TITLE Repair Parts and Special Tools List (RPSTL) for Modular Causeway System (MCS), Floating Causeway (FC)		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:



JOYCE E. MORROW
*Administrative Assistant to the
Secretary of the Army*

0420311

To be distributed in accordance with the initial distribution number (IDN) 256811 requirements for
TM 55-1945-227-24P.

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29,573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.356	metric tons	short tons	1.102
pound-inches	newton-meters	.11296			

Temperature (Exact)

°F Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
--------------------------------	----------------------------	---------------------	----

PIN: 081690-000