TECHNICAL MANUAL

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL INCLUDING REPAIR PARTS LIST

FOR

SPRAY GUN, PAINT MODELS B-9900, B-9900-B NSN 4940-00-261-8415

(METALCRAFT, INC.)

HEADQUARTERS, DEPARTMENT OF THE ARMY

OCTOBER 1980

Technical Manual

No. 9-4940-424-14&P

HEADQUARTERS DEPARTMENT OF THE ARMY Washington, DC, 24 October 1980

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL INCLUDING REPAIR PARTS LIST FOR SPRAY GUN, PAINT MODELS B-9900, B-9900-B (NSN 4940-00-261-8415)

REPORTING OF ERRORS

You can help Improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, US Army Armament Material Readiness Command, ATTN: DRSAR-MAS, Rock Island, IL 61299. A reply will be furnished direct to you.

NOTE

This manual is published for the purpose of identifying an authorized commercial manual for the use of the personnel to whom this spray gun is issued.

Manufactured by Metalcraft, Inc. 718 Debelius Avenue Baltimore, MD 21205

Procured under Contract No. DAAA09-77-C-6540

This technical manual is an authentication of the manufacturers' commercial literature and does not conform with the format and content specified in AR 310-3, Military Publications. This technical manual does, however, contain available information that is essential to the operation and maintenance of the equipment.

INSTRUCTIONS FOR REQUISITIONING PARTS

NOT IDENTIFIED BY NSN

When requisitioning parts not identified by National Stock Number, it is mandatory that the following information be furnished the supply officer.

- 1 Manufacturer's Federal Supply Code Number 06535
- 2 Manufactureris Part Number exactly as listed herein.
- 3 Nomenclature exactly as listed herein, including dimensions, if necessary.
- 4 Manufacturer's Model Number Model B-9900; B-9900-B
- 5 Manufacturer's Serial Number (End Item)
- 6 Any other information such as Type, Frame Number, and Electrical Characteristics, if applicable.
- 7 If DD Form 1348 is used, fill in all blocks except 4, 5, 6, and Remarks field in accordance with AR 725-50.

Complete Form as Follows:

- In blocks 4, 5, 6, list manufacturer's Federal Supply Code Number - 06535 followed by a colon and manufacturer's Part Number for the repair part.

Model: B-9900; B-9900-B Serial: (of end item) N/A

Any other pertinent information such as Frame Number, Type, Dimensions, etc.

OPERATING AND MAINTENANCE INSTRUCTIONS PRODUCTION HEAVY DUTY SPRAY GUNS



OPERATIONS

CONNECTIONS:

When used with a Siphon Feed Cup, attach the gun to the Fluid Inlet Nipple and connect the Air Hose to the Air Inlet Nipple (see Fig. 1). When used with a Pressure Feed Tank, Air Hose and Fluid Hose both are required to connect the Spray Gun to the Tank. The Fluid Hose is Black, the Ail Hose is Red. Attach one end Of the Fluid Hose to the Fluid Outlet on the Pressure Tank and the other end of the Fluid Hose to the Fluid Inlet Nipple On the Spray Gun. Attach one ad of the Air Hose to the Air Outlet Valve on the Pressure Tank and connect the other end of the Air Hose to the Air Inlet Nipple of the Spray Gun (Fig. 1).

Note: It is recommended Air Hose of not less that 5/16 I.D. and Fluid Hose of not less than 3/8 I.D. be used. Never use too small of Air Hose as this Will starve the Spray Gun due to the excessive Pressure Drop in the Atomizing Air Pressure.

OPERATIONS

GENERAL:

The first step of Spray Gun operation is the adjustment of the Spray for uniformity over the desired width, too much Air Pressure, i.e., too much atomizing Air Pressure at the Nozzle for the particular material being used will thin out the center of the spray pattern. It will cause excessive atomization or vapor about the main body of the spray. This condition can be controlled by lowering either Air Pressure at the Air Separator or adjusting the Regulator on top of the Pressure Tank or by properly setting the Air Adjustment Valve. An insufficient Air Pressure, i.e., too little air pressure at the Spray Gun Nozzle for the particular material to be used causes a spatter effect, the material covering the surfaces in small beads, drops or dots. This condition is controlled by increasing the Air Pressure at the Air Separator or at the Pressure Tank.

The width of the Spray is controlled by the Air Adjustment valve (Fig. 1). Turn the Air Adjustment Valve clockwise to decrease the spray, counter clockwise to increase the spray. To produce a round spray pattern or spot, close the Air Adjustment Valve.

The amount of material flow is controlled by the fluid Adjustment Screw (Fig. 1). Turn Adjusting Screw to the right to decrease the amount of Fluid flow and to the left to increase it.

With certain materials, too wide a spray adjustment will cause the spray pattern to split, i.e., the pattern becomes thin in the center and heavy at the ends, when this occurs, reduce the width of the spray.

Excessive material flow for the speed of stroke will cause runs or sags on the surface. Regulate the fluid flow to your speed of stroke.

The atomizing air pressure passing into the Spray Gun Nozzle is regulated to meet varying conditions of size of Gun Nozzle, weight or viscosity of paint, the material of the surfaces to be sprayed and the desired speed of gun operation. The atomization pressure will range from 20 to 80 pounds. Although for average materials and conditions, pressure from 40 to 60 pounds will be most satisfactory. Always use the lowest pressure that will give the desired results. A little experience will teach the Operator the most satisfactory pressures for the materials used.

Materials should be stirred thoroughly and reduced according to manufacturer's instructions; then strained into material container through cheese cloth or wire screen of such mesh or gauge as to remove all lumps, skins, etc. The straining of all material before introduction into the material container is of utmost importance, as it will prevent the consequent obstruction of spray gun passages.

A short practice period, using a cardboard, wood or metal surface is recommended so as to become familiar with the adjustments and operation of the spray gun. Do not attempt to operate the spray gun too rapidly at first. Learn to adjust and handle it and speed will follow.

The stroke is made with a free arm motion, keeping the gun body perpendicular to, and from arr equal distance from the surface at all points of the stroke. Keep the gun 6 to 8 inches from the surface to be sprayed and move it across the surface with steady, even strokes.

MAINTENANCE

LUBRICATION

DO NOT IMMERSE GUN IN SOLVENTS - THIS DESTROYS LUBRICANTS.

Proper lubrication of the spray gun is essential to assure continued perfect operation.

LUBRICATE DAILY all bearing surfaces and moving parts with a light oil. The points of lubrication, refer to SPRAY GUN ASSEMBLY SECTIONAL DRAWING and see also Figure 1, required are: (A) the front and rear bearing surfaces of FLUID NEEDLE Item 22 (B) bearing surface of AIR VALVE STEM Item 8.

Occasional oiling applied to the threads on AIR ADJUSTING VALVE Item 4 and FLUID NEEDLE ADJUST ING SCREW Item 5 is recommended to maintain the smooth easy adjusting action.

Fluid Needle Spring Item 6 in fluid adjusting mechanism should be kept coated with a covering of light grease or vaseline.

Fluid Needle Packing and Air Valve Stem Packing Item 9 should be removed occasionally and inspected. Keep packing soft by occasional lubrication.

CARE AND CLEANING

Spray Gun troubles are usually caused by neglect or improper cleaning.

Keep Gun lubricated.

Keep Packing Nuts around Fluid Needle and Air Valve Stem tight. Do not tighten so securely that parts cannot move freely.

Keep Gun clean. It is not necessary to take spray gun apart to clean it. Spray clean solvent through gun and wash off outside with clean solvent.

Do not allow Gun to get so dirty that soaking of complete gun becomes necessary.

Do not use caustic alkaline solutions for cleaning as they destroy aluminum alloy.

An unbalanced or distorted spray indicates a dirty air cap. Remove Air Cap and wash thouroughly in clean solvent. If reaming of air cap holes is necessary, use match stick, broom bristle or other soft implement. Never use a hard or sharp instrument for this purpose, as it may permanently damage the cap.

Do not remove spray gun parts unless absolutely necessary.

Check condition of gaskets when rmoving parts which seal On gasket.

Always make certain the Fluid Nozzle is securely tightened when replacing. The Fluid Nozzle size is 1" Hex.

SECTION	III REPAI	IR PARTS												
(1) (2)		(2)	(3)		(4)	(5)	(6)				(7)			
SOURCE MAINT. AND										15 DAY ORGANIZATIONAL				
RECOV.	CODE						INC	MAINT. ALLOWANCE				ILLUSTRATION		
(A) (B)		(C)	FEDERAL STOCK	DESCRIPTION				(A)	(B)	(C)	(D)	(A)	(B)	
			NO.			OF	UNIT					FIGURE	ITEM	
SOURCE	MAINT.	RECOV.		REFERENCE NUMBER AND MFR CODE	USABLE ON CODE	ISSUE		1-5	6-20	21-50	51-100	NO.	NO.	
P	0		4940-474-8820	TIP,FLUID W/GASKET AV-601-E(17431)	вC	EA	1	*	1	2	4	1	1	
P	0		4940-474-8821	TIP,FLUID W/GASKET AV-601-FX(17431)	A	EA	1	*	1	2	4	1	1	
P	0		4940-422-8771	PACKING FLUID NEEDLE A-23(17431)	ABC	EA	1	1	2	4	б	1	2	
P	0		4940-474-7845	NEEDLE,FLUID MBC-444-FX(17431)	A	EA	1	*	1	2	4	1	3	
P	0		4940-422-8776	NEEDLE, SPRAY GUN FLUID MBC-444-E(17431)	ВC	EA	1	*	1	2	4	1	3	
P	0		4940-474-8850	VALVE, SPREADER ADJUSTMENT ASSEMBLY MBC-416-1(17431)	ABC	EA	1	*	*	1	2	1	4	
P	0		4940-474-9016	SPRING, HELICAL COMPESSION MBC-29(17431)	ABC	EA	1	1	2	4	6	1	5	
P	0		4940-422-8812	PLUNGER, SPRAY GUN MBC-33(17431)	ABC	EA	1	*	1	2	4	1	6	
P	0		4940-449-9301	CYLINDER AND GASKET MBC-415(17431)	ABC	EA	1	*	*	1	2	1	7	
P	0		4730-346-1768	ADAPTER, STRAIGHT 1/4 IN. NPT P-MB-51(17431)	ABC	EA	1	1	2	4	6	1	8	
P	0		5330-641-2215	GASKET,ASBESTOS-COPPER, 0.436 IN. ID, 33/64 IN. OD,	ABC	EA	1	1	2	4	6	1	9	
				1/16 IN. THK MB-72(17431).										
P	0		5330-801-5855	PACKING, AIR VALVE MB-26(17431)	ABC	EA	1	1	2	4	6	1	10	
P	0		5310-474-7878	NUT, PACKING AIR VALVE ASSEMBLY MB-138(17341)	ABC	EA	1	*	1	2	4	1	11	
				SECTION III										
				TOOLS AND SUPPORT EQUIPMENT										
P	0		5120-422-8932	WRENCH, BOX AND OPEN END COMBINATION WR-101(17431)	ABC	EA	1	1	2	4	6	1	12	

SECTION IV. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

	FIGURE	ITEM		FIGURE	ITEM		
STOCK NUMBER	NO.	NO.	STOCK NUMBER	NO.	NO.		
4730-436-1768	1	8	4940-474-8821	1	1		
4940-422-8771	1	2	4940-474-8850	1	4		
4940-422-8776	1	3	4940-474-9016	1	5		
4940-422-8812	1	6	5120-422-8932	1	12		
4940-449-9301	1	7	5310-474-7878	1	11		
4940-474-7845	1	3	5330-641-2215	1	9		
4940-474-8820	1	1	5330-801-5855	1	10		
REFERENCE	MFR	FIG	ITEM	REFERENCE	MFR	FIG	ITEM
NO.	CODE	NO.	NO.	NO.	CODE	NO.	NO.
A-23	17431	1	2	MBC-33	17431	1	6
AV-601-E	17431	1	1	MBC-415	17431	1	7
AV-601-EX	17431	1	1	MBC-416-1	17431	1	4
MB-138	17431	1	11	MBC-444-E	17431	1	3
MB-26	17431	1	10	MBC-444-FX	17431	1	3
MB-72	17431	1	9	P-MB-51	17431	1	8
MBC-29	17431	1	5	WR-101	17431	1	12



By Order of the secretary of the Army:

E. C. MEYER General, United States Army Chief of Staff

Official:

J. C. PENNTNGTON Major General, United States Army The Adjutant General

% U.S. COVERNMENT PRINTING OFFICE : 1983 0 ~ 381-302 (1026)

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS SOMETTING WRONG WITH THIS PUBLICATION? FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) THEN. JOT DOWN THE DOPE ABOUT IT ON THIS Your mailing address FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT DATE SENT IN THE MAIL! Date you fill out this form PUBLICATION NUMBER PUBLICATION DATE PUBLICATION TITLE Date of TM Title of TM TM 9-XXXX-XXX-XX BE EXACT. PIN-POINT WHERE IT IS IN THIS SPACE TELL WHAT IS WRONG PARA-GRAPH FIGURE TABLE AND WHAT SHOULD BE DONE ABOUT IT: PAGE A&C) NO Callouts for air cap and fluid adjusting screw are switched. TEAR ALONG PERFORATED LINI 5 What is the part number for the Dring (model B-9900)? It is not listed. SALMORE PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER SIGN HERE ⁶⁹³/XXXX THERESA A. GRAY, SSGT. A 1 JUL 79 2028-2 PREVIOUS EDITIONS P.S.--IF YOUR OUTFIT WANTS TO KNOW BOUT YOUR > ARE OBSOLETE. RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

REVERSE OF DA FORM 2028-2

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS PENALTY FOR PRIVATE USE \$300 POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314

1

TEAN ALONG PERFORATED LINE

1

|

1

Commander US Army Armament Materiel Readiness Command AFTN: DRSAR-MAS Rock Island, IL 61299

THEN.		a second s		
THEN DOPE A	FRO	DM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)		
	JOT DOWN THE			
FORM, C	CAREFULLY TEAR IT			
IN THE	MAIL'	ESENT		
		PUBLICATION TITLE Maintenance Manual		
TM 9-4940-424-14&P	24 Oct 1980	Spray Gun, Paint (Mods B-9900, B-9900-B)		
BE EXACT PIN-POINT WHERE IT IS	IN THIS SPACE TELL WHAT	I B-9900-D)		
PAGE PARA- FIGURE TABLE NO GRAPH NO NO	AND WHAT SHOULD BE DO	DNE ABOUT IT:		
PRINTED NAME, GRADE OR TITLE, AND TELE	PHONE NUMBER SIGN	HERE:		

$\langle \langle \rangle$			THEN	SOMI	FROM	B WRONG	WITH THIS PUBLICATION
E I		X	FORM, C. OUT, FOI IN THE	AREFULLY TEAR I LD IT AND DROP MAIL!		SENT	n fi Tanan an
PUBLICAT	10N NUME 9-494(BER 0-424-1	4&P	PUBLICATI 24 Oct	date 1980	PUBLICATION TH Spray Gun, B-9900-B)	'LE Maintenance Manual Paint (Mods B-9900,
BE EXAC	PARA-	FIGURE	RE IT IS	IN THIS SPACE TE AND WHAT SHOU	LL WHAT	IS WRONG IE ABOUT IT:	2013 – Anger House, e Long, general de la la la la companya en la companya de la companya en la companya de la
PRINTED N	AME, GRAD	E OR TITLE.	AND TELEPH	ONE NUMBER	SIGN HE	196. 196.	

-

/			Some	THON (e wrone •	ITH THIS PUBLICATION		
25		THEN DOPE ABO FORM, CA OUT, FOL.	OT DOWN THE OUT IT ON THIS REFULLY TEAR IT D IT AND DROP IT	FRO	M: (PRINT YOUR UNIT	S COMPLETE ADDRESS)		
	N.F.	IN THE N	AAIL'		SENT			
PUBLICAT			PUBLICATION DATE		PUBLICATION TITLE Maintenance Manual Spray Gum, Paint (Mods 8-9900)			
BE EXAC	M 9-4940-42	4-14&P	24 UCT	24 Oct 1980 B-9900-B)				
PRINTED	AME. GRADE OR TIT	TLE. AND TELEPH		SIGN H	ERE			

and the Westman and the Westman and States

FOLD BACK

DEPARTMENT OF THE ARMY

- -

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314

-

- -- --

1

TEAR ALONG PERFORATED LINE

I

|

OFFICIAL BUSINESS PERALTY FOR PRIVATE USE \$300

> Commander US Army Armament Materiel Readiness Command ATTN: DRSAR-MAS Rock Island, JL 61299

TM 9-4940-424-14&P SPRAY GUN, PAINT - 1980

este en se ante den contra en location 16 18.0 COLASS	540 N C451	46511			EA	3117 62162	山田である。 タオモン・オモイルシア こうご タイマット・
	CCR USA CARCCA MAT REAU Actv Aiin Erymcmaf	LEXINGIÓN	$\left\{ \left $	1 N 5-454(-454-148P	A2566 preserve 1997 and 25	420236 NE	