

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

TEST BENCH SET, ATTITUDE-HEADING
REFERENCE SET AN/ASM-298
(NSN 4920-00-851-8749)

HEADQUARTERS, DEPARTMENT OF THE ARMY

NOVEMBER 1978

TECHNICAL MANUAL
No. 11-6615-252-24P

{

*TM 11-6615-252-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 9 November 1978

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TEST BENCH SET, ATTITUDE-HEADING REFERENCE SET AN/ASM-298
(NSN 4920-00-851-8749)
Current as of 26 June 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus	Figure
SECTION	I. INTRODUCTION	1		
	II. REPAIR PARTS LIST	5		
Group	00 Test Bench Set, Attitude-Heading Reference Set AN/ASM-298.....	5	1-4	
	01 Cable Assembly CX-10374/ASM-298	15	5	
	02 Cable Assembly CX-10375/ASM-298	16	6	
	03 Cable Assembly CX-10376/ASM-298	17	7	
	04 Cable Assembly CX-10377/ASM-298	18	8	
	05 Cable Assembly CX-10378/ASM-298	19	9	
	06 Cable Assembly CX-10379/ASM-298	20	10	
	07 Cable Assembly CX-10380/ASM-298	21	11	
	08 Cable Assembly CX-10381/ASM-298	22	12	
SECTION	III. Special tools list (Not applicable)			
	IV. National stock number and part number index	23		

*This manual supersedes TM 11-6615-252-24P, 12 May 1977.

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the ANIASM-298. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section I. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code*. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA-	Item procured and stocked for anticipated or known usage.
XD-A	support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be

used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O--	Support item is removed, replaced, used at the organizational level.
H-	Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
H-	The lowest maintenance level capable of complete repair of the support item is the general support level.
Z-	Nonrepairable. No repair is authorized.

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability codes</i>	<i>Definition</i>
Z-	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in position 3.
H-	Reparable item. When uneconomically repairable, condemn and dispose at the general support level.

c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm,

corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

The following publications pertain to the AN/ASM-28 and

its components: TM 11-6615-252-12, Test Bench Set, Attitude-Heading Reference Set ANIASM-298 TM 11-6615-252-45. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298 5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) Second. Find the illustration covering the functional group to which the item belongs.

(3) Third. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock or part number is known.


(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) Second. After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations Not applicable.

Not applicable.

(Next printed page is 4)



ELOX000I

Figure 1. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298.

SECTION II

TM 11-4415-252-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 00 TEST BENCH SET, ATTITUDE-HEADING REFERENCE SET AN/ASM-298		
1	1	PAHHH	4920-00-851-8752	1951K19G703	97424	CABLE ASSEMBLY.CX-10377/ASM-298.....	EA	1
1	2	PAHHH	4920-00-851-8746	1951K19G707	97424	CABLE ASSEMBLY, CX-10381/ASM-298.....	EA	1
1	3	PAHHH	4920-00-851-8739	1951K19G706	97424	CABLE ASSEMBLY, CX-10380/ASM-298.....	EA	1
1	4	PAHHH	4920-00-852-6491	1951K19G704	97424	CABLE ASSEMBLY.CX-10378/ASM-298.....	EA	1
1	5	PAHHH	4920-00-852-6520	1951K19G701	97424	CABLE ASSEMBLY, CX-10375/ASM-298.....	EA	1
1	6	PAHHH	4920-00-852-6506	1951K19G700	97424	CABLE ASSEMBLY, CX-10374/ASM-298.....	EA	1
1	7	PAHHH	4920-00-852-6508	1951K19G702	97424	CABLE ASSEMBLY, CX-10376/ASM-298.....	EA	1
1	8	PAHHH	4920-00-852-5292	1951K19G705	97424	CABLE ASSEMBLY, CX-10379/ASM-298.....	EA	1
1	9	PAHHH	4920-00-851-8750	8368K20G700	97424	TEST BENCH SET, TS2366/ASM-298.....	EA	1
					5			




Figure 2. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298, Case Assembly and Lamps.

SECTION II

TM 11-4415-252-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
2	1	PAHHH	4920-00-851-8773 5999-00-186-8944	2826K84G700	97424	COVER ASSEMBLY.....	EA	1
	2	XDHZZ		6685K11P001	97424	PLATE, IDENTIFICATION.....	EA	1
	3	XDHZZ		6685K12P001	97424	PLATE, IDENTIFICATION.....	EA	1
	4	PAHZZ		146	79963	TERMINAL	EA	1
	5	XDHZZ		2166K87P009	97424	COVER.....	EA	1
	6	XDHZZ		6685K10P001	97424	PLATE, IDENTIFICATION.....	EA	2
	7	XDHZZ		N54P9006	24446	SCREW	EA	12
	8	XDHZZ		RS39090SS3	73484	WASHER, SEAL	EA	4
	9	PAHZZ		5935-00-811-6893	10-101960-223	CAP, PROTECTIVE	EA	4
	10	PAHZZ		5999-00-702-9230	10-101960-14-3	CAP, DUST	EA	3
	11	PAHZZ		6210-00-959-8174	1H75LC16RN	HOLDER, LAMP	EA	7
	12	PAHZZ		5920-00-892-9311	FHN26G1	HOLDER, FUSE	EA	6
	13	PAHZZ		5340-00-804-1519	1270-1	HANDLE	EA	2
	14	PADZZ		5355-00-579-6390	1S91528-2F2B	KNOB, SKIRTED	EA	18
	15	XDHZZ		2168K72G700	97424	CASE ASSEMBLY.....	EA	1
	16	XDHZZ		2168K72P001	97424	CASE, HALF.....	EA	1
	17	XDHZZ		5559K84P001	97424	PANEL, TESTER.....	EA	1
	18	PAHZZ		LH75LC16CN	81349	HOLDER, LAMP	EA	1




Figure 3. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298, Front Panel Controls.

SECTION II

TM 11-4415-252-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		QTY INC IN UNIT	
								U/M
3	1	PAHZZ	5935-00-827-1547	M53112E22-55S	96906	CONNECTOR, RECEPTACLE.....	EA	1
3	2	XDHZZ		N54P9006	24446	SCREW	EA	4
3	3	XDHZZ		N535649-43	96906	NUT, HEXAGON	EA	4
3	4	XDHZZ		8916K70P001	97424	WASHER, SEAL	EA	4
3	5	PAHZZ	5935-00-826-0845	M5S3112E22-5SN	96906	CONNECTOR, RECEPTACLE.....	EA	1
3	6	PADZZ	6240-00-155-8707	MS525231-1819	96906	LAMP, INCANDESCENT.....	EA	6
3	7	PAHZZ	5935-00-804-5125	PT02E14-18	77820	CONNECTOR, RECEPTACLE.....	EA	1
3	8	PAHZZ	5935-00-825-8862	MS3112E1-19S	96906	CONNECTOR, RECEPTACLE.....	EA	1
3	9	XDHZZ		4199K71P001	97424	SCREW	EA	28
3	10	PAHZZ	5310-00-926-5876	M535338-154	96906	WASHER, LOCK	EA	32
3	11	PADZZ	5920-00-280-4960	F02A250V2A	81349	FUSE	EA	4
3	12	PADZZ	5920-00-296-0451	F02A250V1-8A	81349	FUSE	EA	2
3	13	XDHZZ		53-1900-9C11	91812	SWITCH, ROTARY	EA	2
3	14	XDHZZ		53-1902-1C3	91812	SWITCH, ROTARY	EA	1
3	15	XDHZZ		531902-2C2	91812	SWITCH, ROTARY	EA	1
3	16	XDHZZ		531902-3C3	91812	SWITCH, ROTARY	EA	1
3	17	XDHZZ		N58P16009	24446	SCREW	EA	10
3	18	XDHZZ		5811KB1P01	97424	POST, SUPPORT.....	EA	10
3	19	XDHZZ		4149K71P011	97424	WASHER, LOCK	EA	10
3	20	XDHZZ	-	53-1901-4C5	91812	SWITCH, ROTARY	EA	1
3	21	XDHZZ		4149K71P010	97424	SCREW	EA	20
3	22	PAHZZ	5310-00-934-9759	M535649-284	96906	NUT, HEXAGON	EA	10
3	23	XDHZZ		N400P38	24446	WASHER, PLAIN	EA	10
3	24	XDHZZ		N54P13006	24446	SCREW	EA	8
3	25	PAHZZ	5310-00-883-9385	M535338-155	96906	WASHER, LOCK	EA	8
3	26	PAHZZ	5310-00-934-9761	MS-35649-264	96906	NUT, HEXAGON	EA	8
3	27	XDHZZ		56-1900-3C24C	91812	SWITCH, ROTARY	EA	1
3	28	XDHZZ		53-190L-2C5	91812	SWITCH ROTARY	EA	1
3	29	XDHZZ		53-1901-3C6	91812	SWITCH, ROTARY	EA	3
3	30	XDHZZ		56-1900-2C20	91812	SWITCH, ROTARY	EA	1
3	31	XDHZZ		53-1901-2C8	91812	SWITCH, ROTARY	EA	2
3	32	XDHZZ		51900-3C18	91812	SWITCH, ROTARY	EA	1
3	33	XDHZZ		N54P15012	24446	SCREW	EA	28
3	34	PAHZZ	5310-00-869-4199	M535338-156	96906	WASHER, LOCK	EA	28
3	35	PAHZZ	5950-00-879-8939	5-1359	58474	TRANSFORMER	EA	3
3	36	XDHZZ		1501-103	83330	JACK, INSIDE	EA	4
3	37	PAHZZ	5935-00-578-3489	1501-102	83330	JACK, INSIDE	EA	1
3	38	PADZZ	6240-00-223-9100	NE51	24446	LAMP, NEON	EA	2
3	39	XDHZZ		8155K93P061	97424	SWITCH, PUSH	EA	1
3	40	PAHZZ	5930-00-556-9530	23AT3	91929	SWITCH, TOGGLE	EA	1

SECTION II

TM 11-4415-252-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
3	41	XDHZZ	5930-00-818-6812	8089K9PD001 23AT1	97424, 91929	SUPPORT, SWITCH	EA	2
3	42	PAHZZ	5935-00-850-6522	NS3112E145P	96906	SWITCH, TOGGLE	EA	1
3	43	PAHZZ	5935-00-714-7882	PT02E22-325	77820	CONNECTOR, RECEPTACLE.....	EA	1
3	44	PAHZZ	5935-00-929-4969	PT02E22-365 6685K13	77620 97424	CONNECTOR, RECEPTACLE..... PLATE, IDENTIFICATION.....	EA	1
3	45	PAHZZ						
3	46	XDHZZ						
					10			




Figure 4. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298, Rear Panel (Sheet 1 of 2).




Figure 4. Test Bench Set, Attitude-Heading Reference Set AN/ASM-298, Rear Panel (Sheet 2 of 2).

SECTION II

TM 11-4415-252-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
4	1	XDHZZ		1586K71G700	97424	TERMINAL BOARD ASSEMBLY.....	EA	1
4	2	PAHZZ	5905-00-855-4475	RWP21F18R2F	81349	RESISTOR, FIXED, WIRE WOUND PRECISION	EA	1
4	3	XDHZZ		100-200-8A40	99378	CLIP	EA	1
4	4	PAHZZ	5940-00-688-2540	FT-S136TUR	98291	TERMINAL	EA	1
4	5	PAHZZ	5905-00-901-7943	RWP21F1001F	81349	RESISTOR, FIXED, WIRE WOUND PRECISION	EA	2
4	6	PAHZZ	5905-00-082-5071	CHDLNF10AK	81349	CAPACITOR, FIXED, PAPER	EA	2
4	7	PAHZZ	5345-00-291-5342	MS21919G8	96906	CLAMP, CABLE	EA	4
4	8	XDHZZ		ST250L5	98291	TERMINAL	EA	77
4	9	PAHZZ	5340-00-291-9403	MS21991G12	96906	CLAMP, CABLE	EA	4
4	10	PAHZZ	5905-00-843-2392	RBSCE39001S	81349	RESISTOR, FIXED, WIRE WOUND	EA	2
4	11	PAHZZ	5910-00-926-8204	CH30FD472G03	81349	CAPACITOR, FIXED, MICA	EA	1
4	12	PAHZZ	5905-00-843-2390	RB58CE330018	81349	RESISTOR, FIXED, WIRE WOUND	EA	2
4	13	XDHZZ		RB58E60008	81349	RESISTOR, FIXED, WIRE WOUND	EA	1
4	14	PAHZZ	5905-00-855-4445	RB58CE50008	81349	RESISTOR, FIXED, WIRE WOUND	EA	1
4	15	PAHZZ	5910-00-056-8166	CL258J101TP3	81349	CAPACITOR.....	EA	1
4	16	XDHZZ		RB58CE8000008	81349	RESISTOR, FIXED, WIRE WOUND	EA	1
4	17	XDHZZ		427	91265	GROMMET	EA	1
4	18	PAHZZ	5905-00-784-4641	RB58CE1000008	91349	RESISTOR, FIXED, WIRE WOUND	EA	5
4	19	PAHZZ		RNC6K4021FS	81349	RESISTOR, FIXED, FILM.....	EA	1
4	20	XDHZZ		RB58CE820R08	81349	RESISTOR, FIXED, WIRE WOUND	EA	1
4	21	PADZZ	5940-00-176-7692	2401-06-00	78189	TERMINAL	EA	1
4	22	XDHZZ		5480300P6	97424	BUSHING	EA	1
4	23	XDHZZ		29F2225G4	24446	CAPACITOR.....	EA	1
4	24	XDHZZ		6002-25CC	91506	CLIP	EA	1
4	25	XDHZZ		1N2985	04713	DIODE, BREAKDOWN.....	EA	1
4	26	XDHZZ	5940-00-159-1293	2104-08-00	97424	TERMINAL	EA	1
4	27	XDHZZ	5940-00-156-1344	2104-08-00	78189	TERMINAL	EA	1
4	28	PDHZZ	5961-00-892-0824	JAN1N2843	04113	DIODE, BREAKDOWN.....	EA	1
4	29	XDHZZ		764OK76P001	97424	HEAT SINK.....	EA	2
4	30	XDHZZ		N54P9004	24446	SCREW	EA	4
4	31	PAHZZ	5340-00-104-7581	MS2196G4	96906	CLAMP, CABLE	EA	2
4	32	XDHZZ		N400P35	24446	WASHER, PLAIN	EA	2
4	33	XDHZZ		N54P5010	24446	SCREW	EA	4
4	34	PAHZZ	5310-00-938-2031	MS35649-224	96906	NUT, HEXAGON	EA	16
4	35	PAHZZ	5310-00-934-0226	MS35338-153	96908	WASHER, LOCK	EA	16
4	36	PAHZZ	5905-00-918-9333	RN74U2210F	81349	RESISTOR, FIXED, WIRE WOUND PRECISION	EA	1
4	37	PAHZZ	5905-00-855-4475	RN74U18R2F	81349	RESISTOR, FIXED, WIRE WOUND PRECISION	EA	1
4	38	XDHZZ		R8SCE112502D	81349	RESISTOR, FIXED, WIRE WOUND	EA	1
4	39	XDHZZ		P31F1H6A	96906	RELAY.....	EA	3
4	40	PAHZZ	5945-00-127-7323	PA26F1H6A	99699	RELAY.....	EA	3

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		QTY INC IN UNIT	
								U/M
4	41	XDHZZ		N54P15006	24446	SCREW		EA 6
4	42	PAHZZ	5310-00-934-9759	MS35649-284	96906	NUT, HEXAGON		EA 6
4	43	PAHZZ	530-00-869-4199	MS35338-156	96906	WASHER, LOCK		EA 6
4	44	XDHZZ		RB5BCE499000	81349	RESISTOR, FIXED, WIRE WOUND		EA 2
4	45	XDHZZ		8608K76P026	97424	TRANSFORMER, POWER		EA 1
4	46	PAHZZ	5905-00-752-3804	22451-203	80294	RESISTOR, VARIABLE		EA 1
4	47	PAHZZ	5310-00-869-9576	MS3533B-157	96906	WASHER, LOCK		EA 1
4	48	XDHZZ		5480300P2	97424	BUSHING		EA 2
4	49	XDHZZ		5462297P4	97424	WASHER, MICA		EA 3
4	50	PAHZZ	5905-00-687-1557	22451-502	80294	POT, TRIM		EA 1
4	51	PAHZZ	5970-00-043-2921	732	08530	INSULATOR		EA 2
4	52	XOHZZ		N54PS006	24446	SCREW		EA 12
4	53	PAHZZ	5905-00-981-5200	R85BCE1R000B	81349	RESISTOR, FIXED, WIRE WOUND		EA 1
4	54	PAHZZ	5961-00-087-6047	JAN1N6458	81349	SEMICONDUCTOR DEVICE, DIODE		EA 2
4	55	XDHZZ		860681KP003	97424	TRANSFORMER, POWER		EA 1
4	56	PAHZZ	5961-00-087-6047	JAN1N645	81349	SEMICONDUCTOR DEVICE, DIODE		EA 2
4	57	XDHZZ		4UOR6D	81549	RESISTOR, FIXED, WIRE WOUND PRECISION		EA 1
4	58	XDHZZ		5360K76G700	97424	MOTOR ASSEMBLY, SYNCHRONIZER		EA 1
4	59	PAHZZ	5310-00-883-9385	MS35338-155	96906	WASHER, LOCK		EA 16
4	60	XDHZZ		5674K62P001	97424	PLATE, RIGHT HAND		EA 1
4	61	PAHZZ	6625-00-883-8329	G40412	00328	COUPLING		EA 2
4	62	XDHZZ		5674K81P001	97424	PLATE, LEFT HAND		EA 1
4	63	XDHZZ		N54P13012	24446	SCREW		EA 2
4	64	XDHZZ		N400P7	24446	WASHER, PLAIN		EA 2
4	65	PAHZZ	5310-00-934-9761	MS35649-224	96906	NUT, HEXAGON		EA 14
4	66	PAHZZ	3010-00-879-9723	P24154	02005	MOTOR		EA 1
4	67	XDHZZ		5674KB0P001	97424	PLATE, BASE		EA 1
4	68	PAHZZ	6105-00-879-9565	P24155	02005	MOTOR		EA 1
4	69	XDHZZ		N54P13004	24446	SCREW		EA 4
4	70	XDHZZ		7835K31P001	97424	SPACER		EA 1
4	71	XDHZZ		7834K70P003	97424	SPACER		EA 3
4	72	XDHZZ		C137	57533	CLAMP, MOUNTING		EA 6
4	73	XDHZZ		N54P7005	24446	SCREW		EA 6
4	74	XDHZZ		N406P4	24446	WASHER, LOCK		EA 6
4	75	XDHZZ		N54P13008	24446	SCREW		EA 12
4	76	PAHZZ	5990-00-519-6278	CGH11B2	86197	SYNCHRONIZATION TRANSMITTER		EA 2




Figure 5. Cable Assembly CX-10374/ASA-298.

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		QTY INC IN UNIT	
						GROUP 01 CABLE ASSEMBLY CX-L0374/ASM-298		
5	1	XDHZZ		5195K73P38	97424	MARKER, WIRE	EA	1
5	2	PAHZZ	5365-00-141-6944	MS39056-4	96906	BUSHING	EA	2
5	3	PAHZZ	5365-00-663-2L25	MS39056-5	96906	BUSHING	EA	1
5	4	PAHZZ	5935-00-d99-6869	MS3107A20-4P	96906	CONNECTOR, PLUG.....	EA	1
5	5	XDHZZ		5195K73P37	97424	MARKER, WIRE	EA	1
5	6	XDHZZ		5195K73P39	97424	MARKER, WIRE	EA	1
5	7	PAHZZ	536-00-598-546	MS539056-6	96906	BUSHING	EA	1
5	8	PAHZZ	5935-00-71B-8765	M5311L6F14-5S	96906	CONNECTOR, PLUG.....	EA	1
5	9	XDHZZ	5935-00-223-0572	MS3057-12A	96906	CLAMP	EA	1




Figure 6. Cable Assembly CX-10375/ASM-298.

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		QTY INC IN UNIT	
						GROUP 02 CABLE ASSEMBLY CX-10375/ASM-298		
6	1	XDHZZ		5195K73P040	91724	MARKER, WIRE	EA	1
6	2	PAHZZ	5935-00-059-4564	PT06E22-32PSR	77820	CONNECTOR, PLUG	EA	1
6	3	PAHZZ	5365-00-820-4535	MS39053-3	9696	BUSHING	EA	7
6	4	PAHZZ	5365-00-141-6944	MS39056-4	96906	BUSHING	EA	2
6	5	PAHZZ	5365-00-663-2125	MS39056-5	96906	BUSHING	EA	2
6	6	XDHZZ		5195K73P41	97424	MARKER, WIRE	EA	1
6	7	XDHZZ		519SKT3P42	974, 24	MARKER, WIRE	EA	I1
6	8	PAHZZ	5365-00-598-5416	MS39056-6	96906	BUSHING	EA	1
6	9	PAHZZ	5935-00-903-7486	M524266R1682456	96906	CONNECTOR, RECEPTACLE	EA	1




Figure 7. Cable Assembly CX-10376/ASM-298.

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	QTY U/M	INC IN UNIT
7	1	XDHZZ		5195K73P43	97424	GROUP 03 CABLE ASSEMBLY CX-10G36/, ASM-298		
7	2	PAHZZ	5935-00-853-2489	PT06E22-36PSR	77820	MARKER, WIRE	EA	1
7	3	PAHZZ	5365-00-820-4535	MS39056-3	96906	CONNECTOR, PLUG.....	EA	1
7	4	PAHZZ	5365-00-141-6944	MS39056-4	96906	BUSHING	EA	2
7	5	PAHZZ	5365-00-663-2125	MS39056-5	96906	8USHING.....	EA	2
7	6	XDHZZ		5195K73P44	97424	BUSHING	EA	2
7	7	XDHZZ		5195K73P45	97424	MARKER, WIRE	EA	1
7	8	PAHZZ	5365-00-598-5416	MS39056-6	96906	MARKER .WIRE	EA	1
7	9	PAHZZ	5935-00-950-7726	MS24266R16B24SN	96906	BUSHING	EA	1
						CONNECTOR, RECEPTACLE.....	EA	1




Figure 8. Cable Assembly CX-10377/ASM-298.

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	QTY INC IN UNIT	
						GROUP 04 CABLE ASSEMBLY CX-10377/AS-298		
8	1	XDHZZ		5195K73P46	9724z	MARKER, WIRE	EA	1
8	2	PAHZZ	5935-00-892-9329	MS3116F22-55P	96906	CONNECTOR, PLUG	EA	1
8	3	PAHZZ	5365-00-820-4535	MS39056-3	96906	BUSHING	EA	1
8	4	PAHZZ	5365-00-141-6944	5139056-4	96906	BUSHING	EA	2
8	5	XDHZZ		5195K1t3P48	97424	MARKER, WIRE	EA	1
8	6	XDHZZ		5195K73P47	91424	MARKER, WIRE	EA	1
8	7	XDHZZ		5195K73P49	97424	MARKER, WIRE	EA	1
8	8	PAHZZ	5350-00-905-8939	MS24266R18B31SN	96906	CONNECTOR, RECEPTACLE	EA	1
8	9	PAHZZ	5935-00-902-2654	MS24266R61824P6	96906	CONNECTOR, RECEPTACLE	EA	1
8	10	PAHZZ	5365-00-598-5416	M4390566	96906	BUSHING	EA	2




Figure 9. Cable Assembly CX-10378/ASM-298.

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		QTY U/M	INC IN UNIT
9	1	XDHZZ		5195K73P50	97424	GROUP 05 CABLE ASSEMBLY CX-10378/ASM-298		
9	2	PAHZZ	5935-C0-081-4340	MS24266R22B555N	96906	MARKER, WIRE	EA	1
9	3	PAHZZ	5365-00-598-5416	MS39056-6	96906	CONNECTOR, RECEPTACLE	EA	1
9	4	PAHZZ	5365-00-141-6943	MS39056-7	96906!	BUSHING	EA	2
9	5	XDHZZ		5195K73P52	97424	BUSHING	EA	2
9	6	XDHZZ		5195K73P51	97424	MARKER, WIRE	EA	1
9	7	PAHZZ	5935-00-892-9330	MS3116F22-55PW	96906	MARKER, WIRE	EA	1
						CONNECTOR, PLUG	EA	1




Figure 10. Cable Assembly CX-10379/ASM-298.

(1) ILLUSTRATION		(2)	(3) NATIONAL STOCK NUMBER	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE		PART NUMBER	FSCM	USABLE ON CODE	QTY U/M	INC IN UNIT
						GROUP 06 CABLE ASSEMBLY CX-10379/ASM-296		
10	1	XDHZZ		5195K73P53	97424	MARKER, WIRE	EA	1
10	2	PAHZZ	5365-00-820-4535	MS39056-3	96906	BUSHING.....	EA	2
10	3	PAHZZ	5365-00-141-6944	MS39056-4	96906	BUSHING	EA	1
10	4	PAHZZ	5365-00-598-5282	MS39056-Z	96906	BUSHING	EA	2
10	5	PAHZZ	5935-00-892-9330	MS31L16F22-55P	96906	CONNECTOR, PLUG.....	EA	1
10	6	XDHZZ		5195K73P54	97242	MARKER, WIRE	EA	1
10	7	PAHZZ	5935-00-903-8015	MS24266R1415PN	96906	CONNECTOR, RECEPTACLE.....	EA	1
10	8	PAHZZ	5365-00-663-2125	MS39056-5	96906	BUSHING	EA	1
10	9	XDHZZ	5365-00-598-5416	MS39056-6	96906	BUSHING	EA	1
10	10	XDHZZ		5195K73P55	97424	MARKER, WIRE	EA	1




Figure 11. Cable Assembly CX-10380/ASM-298.

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION USABLE ON CODE	(7) QTY U/M	(8) INC IN UNIT
11	1	XDHZZ		5195K73P56	GROUP 07 CABLE ASSEMBLY CX-L0380/ASM-298		
11	2	PAHZZ	5935-00-635-4959	PT06E14-18SSR	MARKER, WIRE.....	EA	1
11	3	PAHZZ	5365-00-835-4959	MS39056-2	CONNECTOR, PLUG.....	EA	1
11	4	XDHZZ		5195K73P57	BUSHING	EA	2
11	5	XDHZZ		5195K73P58	MARKER, WIRE.....	EA	1
11	6	PAHZZ	5935-00-809-5302	PT06E14-18P5R	MARKER, WIRE.....	EA	1
				77820	CONNECTOR, PLUG.....	EA	1




Figure 12. Cable Assembly CX-10381/ASM-298.

(1) ILLUSTRATION (a) FIG NO.		(2) ITEM NO.	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) QTY INC IN UNIT U/M	(8)
						GROUP 08 CABLE ASSEMBLY CX-10331/ASM-298		
12	1	PAHZZ	5935-00-967-6467	MS24266R16824PN	96906	CONNECTOR, RECEPTACLE.....	EA	1
12	2	PAHZZ	5365-00-598-5282	M539056-2	96906	BUSHING	EA	1
12	3	XDHZZ		5195K73P60	97424	MARKER, WIRE	EA	1
12	4	XDHZZ		5195K73P63	97424	MARKER, WIRE	EA	1
12	5	XDHZZ		5195K73P59	97424	MARKER, WIRE	EA	1
12	6	PAHZZ	5935-00-779-8294	MS3116F14-19P	96906	CONNECTOR, PLUG.....	EA	1
12	7	PAHZZ	5365-00-820-4535	MS39056-3	96906	BUSHING	EA	3
12	8	PAHZZ	5935-00-904-48961	MS3116F14-15S	96906	CONNECTOR, PLUG.....	EA	1
12	9	PAHZZ	5365-00-141-6944	M539056-4	96906	BUSHING	EA	2
12	10	XDHZZ		5195K13P62	97424	MARKER, WIRE	EA	1
12	11	PAHZZ	5935-00-813-2023	PT06E16-235SR	77820	CONNECTOR, PLUG.....	EA	1
12	12	PAHZZ	5365-00-663-2125	M539056-5	96906	BUSHING	EA	1
12	13	XDHZZ		5195K73P61	97424	MARKER, WIRE	EA	1

**CROSS-REFERENCE-INDEXES
NATIONAL STOCK NUMBER INDEX**

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM		
PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
5970-00-043-2921	4	51	5340-00-804-1519	2	13		
5910-00-056-8166	4	15	5935-00-804-5125	3	7		
5935-00-059-4564	6	2	5935-00-809-5302	11	6		
6210-00-067-8385	2	18	5935-00-811-6893	2	9		
5935-00-081-4340	9	2	5935-00-813-2023	12	11		
5910-00-082-5071	4	6	5930-00-818-6812	3	42		
5945-00-127-7323	4	40	5365-00-820-4535	6	3		
5365-00-141-6943	9	4	5365-00-820-4535	7	3		
5365-00-141-6944	5	2	5365-00-820-4535	8	3		
5365-00-141-6944	6	4	5365-00-820-4535	10	2		
5365-00-141-6944	7	4	5365-00-820-4535	12	7		
5365-00-141-6944	8	4	5935-00-825-8862	3	8		
5365-00-141-6944	10	3	5935-00-826-0845	3	5		
5365-00-141-6944	12	9	5935-00-827-1547	3	1		
6240-00-155-8707	3	6	5935-00-835-4959	11	2		
5940-00-156-7344	4	27	5905-00-843-2390	4	12		
5940-00-159-1293	4	26	5905-00-843-2392	4	10		
5940-00-176-7692	4	21	5935-00-850-6522	3	43		
5899-00-186-8944	2	4	4920-00-851-8738	1	3		
5935-00-223-0572	5	9	4920-00-851-8746	1	2		
6240-00-223-9100	3	38	4920-00-851-8750	1	9		
5920-00-280-4960	3	11	4920-00-851-8752	1	1		
5340-00-291-5342	4	7	4920-00-851-8773	2	1		
5920-00-296-0451	3	12	4920-00-852-6492	1	8		
5340-00-298-9403	4	9	4920-00-852-6497	1	4		
5990-00-519-6278	4	76	4920-00-852-6506	1	6		
5930-00-556-9530	3	40	4920-00-852-6508	1	7		
			4920-00-852-6520	1	5		
5355-00-579-6390	2	11	5935-00-853-2489	7	2		
5365-00-598-5282	10	4	5905-00-855-4445	4	14		
5365-00-598-5282	11	3	5905-00-855-4475	4	2		
5365-00-598-5282	12	2	5950-00-879-8939	3	35		
5365-00-598-5416	5	7	6105-00-879-9565	4	68		
5365-00-598-5416	6	8	3010-00-879-9723	4	66		
5365-00-598-5416	7	8	6625-00-883-8329	4	61		
5365-00-598-5416	8	10	5961-00-892-0824	4	28		
5365-00-598-5416	9	3	5920-00-892-9311	2	12		
5365-00-598-5416	10	9	5935-00-892-9329	8	2		
			5935-00-892-9330	9	7		
5365-00-663-2125	5	3	5935-00-892-9330	10	5		
5365-00-663-2125	6	5	5935-00-899-6869	5	4		
5365-00-663-2125	7	5	5905-00-901-7943	4	5		
5365-00-663-2125	10	8	5935-00-902-2654	8	9		
5365-00-663-2125	12	12	5935-00-903-7486	6	9		
5905-00-687-1557	4	50	5935-00-903-8015	10	7		
5599-00-702-9230	2	10	5935-00-904-4896	12	8		
5935-00-714-7882	3	44	5935-00-905-8939	8	8		
			5935-00-929-4969	3	45		
5905-00-752-3804	4	46	5935-00-950-7726	7	9		
5935-00-779-8294	12	6	6210-00-959-8174	2	11		
5935-00-781-8765	5	8	5935-00-967-6467	12	1		
5905-00-784-4641	4	18	5905-00-981-5200	4	53		
PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
CGH1182	86197	4	76	MS2426bR22B55SN	96906	9	2
CH09AINFIOAK	81349	4	6	MS25231-1819	96906	3	6
CL258J101TP3	81349	4	15	MS3057-12A	96906	5	9
C137	57533	4	72	MS3112E14-195	96906	5	4
FHN26G1	81349	2	12	M5S311ZE14-5P	96906	3	43
FT-SM36TUR	98291	4	4	MS3112E22-55S	96906	3	1
F02A250OV2A	81349	3	11	MS3112E22-55SW	96906	3	5
G404-12	00328	4	61	M53116F14-155	96906	12	8
JANIN2843B	04713	4	28	MS3116F14-19P	96906	12	6
JAN1N645	81349	4	56	M53116F14-5S	96906	5	8
LH75LC16CN	81349	2	18	MS3116F22-55P	96906	8	2
M521919G12	96906	4	9	MS3116F22-55PW	96906	9	7
MS21919G4	96906	4	31	MS3116FZZ2-55PW	96906	10	5
MS21919G8	96906	4	7				
MS24266R1415PN	96906	10	7				
MS24266R16B24PN	96906	12	1				
MS24266R16824P6	96906	8	9				
MS24266R16B245N	96906	7	9				
MS24266R16824S6	96906	6	9				
MS24266R18B315SN	96906	8	8	MS35649-43	96906	3	3

SECTION IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

PART NUMBER	FIG. FSCM	ITEM NO.	PART NUMBER	FIG. FSCM	ITEM NO.
MS39056-2	96906	10	4	1N2988	038Z77
MS39056-2	96906	11	3	10-101960-14-3	77820
MS39056-2	96906	12	2	10-101960-223	77820
MS39056-3	96906	6	3	100-20G0-840	99378
MS39056-3	96906	7	3	1270-1	71279
MS39056-3	96906	8	3	146	79963
MS39056-3	96906	10	2	1586K71G700	97424
MS39056-3	96906	12	7	1951K19G701	97424
MS39056-3	96906	5	2	1951K19G702	97424
MS39056-4	96906	6	4	1951K19G703	97424
MS39056-4	96906	7	4	1951K19G704	97424
MS39056-4	96906	8	4	1951K19G705	97424
MS39056-4	96906	10	3	1951K19G706	97424
MS39056-4	96906	12	9	2104-06-00	78189
MS39056-5	96906	5	3	2104-0800	78189
MS39056-5	96906	6	5	2168K72G700	91424
MS39056-5	96906	7	5	2168K72P001	97424
MS39056-5	96906	10	8	22451-203	80294
MS39056-5	96906	12	12	22451-502	80294
MS39056-6	96906	5	7	23AT1	91929
M539056-6	96906	6	8	23AT3	91929
MSS39056-6	96906	7	8	2401-06-00	78189
MS39056-6	96906	8	10	2826K84G700	97424
NS39056-6	96906	9	3	29F2225G4	24446
MSS39056-6	96906	10	9	4149K71P010	97424
MS39056-7	96906	9	4	4149K71P0II	97424
MS91528-2F2B	96906	2	14	4199K71P001	97424
NE51	24446	3	38	427	91265
N400P35	24446	4	32	5-1359	58474
N400P38	24446	3	23		35
N400P7	24446	4	64	5195K73P040	97424
N406P4	24446	4	74	5195K73P37	97424
N54P13004	24446	4	69	5195K73P38	97424
N54P13006	24446	3	24	5195K73P39	97424
N54PI3C08	24446	4	75	5195K73P41	97424
N54P13012	24446	4	63	5195K73P42	97424
N54P15006	24446	4	41	5195K73P43	97424
N54PI5012	24446	3	33	5195K73P44	97424
N54P5006	24446	4	52	5195K73P45	97424
N54P5010	24446	4	33	5195K73P46	97424
N54P7005	24446	4	73	5195K73P47	97424
N54P9004	24446	4	30	5195K73P48	97424
N54P9006	24446	2	7	5195K73P49	97424
N54P9006	24446	3	2	5195K73P50	97424
N58P16009	24446	3	17	5195K73P51	97424
PA26F1H6A	99699	4	40	5195K73P52	97424
				5195K73P53	97424
PT02EI4-18S	77820	3	7	5195K73P54	97242
PTOZE22-32S	77820	3	44	5195K73P55	97424
PT02E22-36S	77820	3	45	5195K73P56	97424
PT06E14-18PSR	77820	11	6	5195K73P57	97424
PT06E14-I8SSR	77820	11	2	5195K73P58	97424
PTO6EI6-23SSR	77820	12	11	5195K73P59	97424
PT06E22-32PSR	77820	6	2	5195K73P60	97424
PT06E22-36PSR	77820	7	2	5195K73P62	97424
P24154	02005	4	66	5195K73P62	97424
P24155	02005	4	68	5195K73P63	97424
R858CEI00008	81349	4	53	53-1900-9C11	91812
RB58CEI00008B	81349	4	18	53-1901-2C5	91812
R858CE125020	81349	4	38	53-1901-2C8	91812
R858CE330018	81349	4	12	53-1901-3C6	91812
R858CE39001B	81349	4	10	53-1901-4C5	91812
RB58CE49900D	81349	4	44	53-1902-1C3	91812
RB58CESC0008	81349	4	14	53-1902-2C2	91812
R858CE60000B	81349	4	13	53-1902-3C3	91812
RB58CEB0000B	'81349	4	16	5360K76G700	97424
RB58CE820R0B	81349	4	20	5462297P4	97424
				5480300P2	97424
RS39090SS3	73484	2	8	5480300P6	97424
RWP21F I001F	81349	4	5	5559K84P001	97424
				56-1900-2C20	91812
RNPZ 1F 18R2F	81349	4	2	56-1900-3C18	91812
				5674K80P001	97424
ST250L5	98291	4	8	5674K81P001	97424
1H75LC16RN	81349	2	11	5674K82P001	97424

SECTION IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

PART NUMBER	FIG. FSCM	ITEM NO.	PART NUMBER	FIG. FSCM	ITEM NO.
5E11KB1P01	97424	3	18	7834K70P003	97424
6002-25CC	91506	4	24	7835K31P001	97424
6685K1P0001	97424	2	6	8089K89P001	97424
6685K11P001	97424	2	2	8368K20G700	97424
6685K12P001	97424	2	3	8608K76P026	97424
6685K13	97424	3	46	8608K81P003	97424
732	08530	4	51	8916K70P001	97424
7640K76P001	97424	4	29		3

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.
5961-00-087-6047	4	56
5905-00-224-8147	4	19
5935-00-578-3489	3	37
5940-00-688-2540	4	4
5905-00-855-4475	4	37
5905-00-918-9333	4	36
5910-00-926-8204	4	11

LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FIG. FSCM	ITEM NO.
CM30FD472G03	81349	11
F02A250v1-8A	81349	12
P31F1H6A	99699	39
RNC65K4021FS	81349	19
RW74U18R2F	81349	37
RW74U2210F	81349	36
RW74U80R6D	81349	57
1501-102	83330	37
1501-103	83330	36
2166K87P009	07424	5
56-1900-3C24C	91812	27
8155K93P061	79424	39

ADDITIONAL LATEST NATIONAL STOCK NUMBER ASSIGNMENTS ADDITIONAL LATEST PART NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. ITEM NO. NO.
5961-00-087-6047	4	54	JAN1N645	81349	4 54
5340-00-104-7581	4	31	M535338-153	96906	4 35
5310-00-869-4199	3	34	MS35338-154	96906	3 10
5310-00-869-4199	4	43	M535338-155	96906	3 25
5310-00-869-9576	4	47	M535338-155	96906	4 59
5310-00-883-9385	3	25	M535338-156	96906	3 34
5310-00-883-9385	4	59	M535338-156	96906	4 43
5310-00-926-5876	3	10	M535338-157	96906	4 47
5310-00-934-0226	4	35	M535649-224	96906	4 34
5310-00-934-9759	3	22	M535649-224	96906	4 65
5310-00-934-9759	4	42	M535649-264	96906	3 26
5310-00-934-9761	3	26	MS35649-284	96906	3 22
5310-00-934-9761	4	65	MS35649-284	96906	4 42
5310-00-938-2013	4	34			

U.S. GOVERNMENT PRINTING OFFICE: 1979-603-028/619

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN. . JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS
ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 012164-000