TM 11-6625-293-12P
CHANGE C1

HEADQUARTERS
DEPARTMENT OF THE ARMY

No. 1

Washington, DC, 9 July 1984

OPERATOR'S, ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS WAVEMETER FR-91/U AND FR-91A/U (6625-00-532-4232)

TM 11-6625-293-12P, 30 December 1959, is changed as follows:-

Page 4, Section IV is added after Section III.

SECTION IV

CROSS REFERENCE INDEX. The Cross-Reference Index is a cross-reference listing of part number to National Stock Number.

- a. of Cross-Reference Index . To order a part listed in the Cross-Reference Index, note part number and then cross-reference that part number to the National Stock Number in the cross-reference index. Then order through normal ordering channels.
- b. Ordering Part Numbers Without National Stock Number. If the part number does not have a National Stock Number, then order the part through normal ordering channels using the part number and the FSCM.

CROSS REFERENCE INDEX FORMAT

Parts With AN FSN

| FSN | NEW NSN | FSCM | PART NUMBER |
|-------------|---------------|-------|------------------|
| | | | |
| 5000400050 | 5000004000050 | 00000 | 00 5 407050 |
| 59801606850 | 5980001606850 | 80063 | SC-B-107852 |
| 53551606850 | 5355001606850 | 49671 | K845607-1 |
| 66255324232 | 6625005324232 | 80058 | FR-91/U FR-91A/U |
| 66255324232 | 6625005324232 | 80058 | FR-91/U FR-91A/U |
| 66257018381 | NONE | 10138 | 50133 |

CROSS REFERENCE INDEX FORMAT

Parts With AN FSN

| OLD PART UNMBER | NEW NSN | FSCM | NEW PART NUMBER |
|-----------------|---------|-------|------------------------|
| | | | |
| 1032 | | 76493 | |
| | | | |
| 2196 | | 83330 | |
| 270 | | 13957 | |
| 44334N | | 21192 | |

| В١ | Order | of the | Secretary | of | the | Army | / : |
|----|-------|--------|-----------|----|-----|------|------------|
|----|-------|--------|-----------|----|-----|------|------------|

JOHN A. WICKHAM JR. General, United States Army Chief of Staff

Official:

ROBERT M. JOYCE Major General, United States Army Tile Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-36B, Operator /Crew Maintenance requirements for FR-91A/U.

a-U.S. GOVER-NMENT PRINTING OFFICE: 1984-705-046/4125

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR'S, ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

WAVEMETER FR-91/U AND FR-91A/U

Headquarters. Department of the Army. Washington 25, D. C. 30 December 1959

| | | Paragraph | Page |
|-----------|--------------------------------------|-----------|------|
| SECTION I | INTRODUCTION | σ. | Ū |
| | Scope | 1 | 1 |
| | Parts for maintenance | 2 | 2 |
| | Additional repair parts | 3 | 2 |
| | Comments or Suggestions | 4 | 2 |
| II | FIRST ECHELON FUNCTIONAL PARTS LIST | | 3 |
| III | SECOND ECHELON FUNCTIONAL PARTS LIST | | 4 |

SECTION I.

INTRODUCTION

1. Scope

- a. This manual includes an Operator's Maintenance Repair Parts and Special Tools List, and Organizational Maintenance Repair Parts and Special Tools List.
- b. The Operator's Maintenance Repair Parts and Special Tools List lists items supplied for initial operation and for running spares. The list includes accessories, parts, and material *issued* as part of the major end item. All items authorized for basic operator maintenance of the equipment are also listed.
- c. The Organizational Maintenance Repair Parts and Special Tools List lists the quantities of repair parts authorized for organizational maintenance and is a basis for requisitioning by organizations which are authorized the major item of equipment. End items of equipments

are issued on the basis of allowances prescribed in equipment authorization tables and other documents that are a basis for requisitioning.

- d. Columns are as follows:
 - (1) Source,)Maintenance, and recoverability code. Not used.
 - (2) Federal stock number i. The stock number column lists the 11-digit Federal stock number. In the absence of a Federal stock number an interim number i.e. ttL8Ra41c-12, which appears in the description column indicates an applicable Federal Stock Number is in the process of assignment. The L number may be used in emergencies to identify items.

^{*}This manual supersedes the first and second echelon portion of DA Supply Manual SIG 7 & 8 FR-91/U, 23 September 1955.

- (3) Designation by model. The dagger indicates the model in which the part is used.
- (4) Description. Nomenclature o r t h e standard item name and brief identifying data for each item is listed in this column. When requisitioning, enter the nomenclature and description on the requisition.
- (5) Unit of issue. The unit of issue is the supply term applied to the smallest quantity by which the individual item is counted for procurement, storage, requisitioning, allowances, and issue purposes.
- (6) Expendability. Expendable items are indicated by the letter X; nonexpendable items are indicated by NX.
- (7) Quantity authorized. Under Items Comprising an Operable Equipment the column lists the quantity of items supplied for the initial operation of the equipment. Under "Running Spares and Accessories" the quantities listed are those issued initially with the equipment as spare parts. The quantities are authorized to be kept on hand by the operator for maintenance of the equipment.
- (8) Quantity incorporated in unit. This column lists the quantity of each particular part found in a given assembly, component, or equipment.
- (9) Organizational. The quantities indicated in these columns are maximum levels of repair parts authorized to be kept on hand by units performing organizational

- maintenance. The quantities are based on 100 equipments to be maintained for a 15-day period.
- (10) *Illustration*. The item No. column lists the reference designations used for identification of the items in the illustration or text of the manual.

2. Parts for Maintenance

When this equipment is used by signal service organizations organic to the theater headquarters or communication zones to provide theater communications, those repair parts authorized up to and including fourth echelon are authorized for stockage by the organization operating this equipment.

3. Additional Repair Parts

Additional repair parts which may be required for performing organizational maintenance, but are not authorized for stockage in the prescribed load are identified by an asterisk and are to be requisitioned as required, for immediate use only. Refer to AR 700-18.

4. Comments or Suggestions

Any comments concerning omissions and discrepancies in this manual will be prepared on DA Form 2028 and forwarded directly to Commanding Officer, U. S. Army Signal Equipment Support Agency, Fort Monmouth, N. J.

ATTN: SIGFM/ES-ML.

SECTION II. FIRST ECHELON FUNCTIONAL PARTS LIST

| _ | | (1) | (2) | | | (3) | | | (4) | (5) | (6) | (7) | (8) | (9) |
|---|---|-----|---------------|-------------|-------------|-----|-------------|--|---|----------|-----------------|---------------|-------------|-----|
| | SOURCE MAINTENANCE AND RECOVERABILIT | | FEDERAL | DESIGNATION | | N | DESCRIPTION | | EXPEND- | QUANTITY | ILLUSTRATION | | | |
| R | | | STOCK NUMBER | | BY Model | | | | | ABILITY | AUTHO- RIZED | FIGURE NO. | ITEM NO. | |
| | | | | 1 | 2 | | | | ITEM(S COMPRISING AN OPERABLE EQUIPMENT | | | | | |
| | | | | | | | | | WAVEMETER FR-91/U, FR-91A/U | | | | | |
| | | | | | | | | | NOTE: Model Column I refers to FR-91/U; Column 2 refers to FR-91A/U | | | | | |
| | | | 6625-532-4232 | + | + | | | | WAVEMETER FR- 91/U, FR-91A/U | ea | NX | | | |
| | | | Ord. thru AGC | | + | | | | TECHNICAL MANUAL TM 11-6625-2693- | ea | NX | 2 | | |
| | | | 6625-701-8381 | | | | | | CASE, WAVEMETER, Freq. Stds. No. 5013325-'tg L-838 1 | ea | X | 1 | | |
| | | | | | | | | | RUNNING SPARES AND ACCESSORY ITEMS | | | | | |
| | | | | | | | | | WAVEMETER FR-91/U: FR-91A/U | | | | | |
| | | | | | | | | | NO PARTS AUTIIORIZED FOR STORAGE AT FIRST ECHELON | | | | | |

FR-91/U; FR-91 A/U

(4) (8) (1) (2) (3) (6) (7) (9) (10) (5) Organizational **ILLUSTRATION** 15 DAYS SOURCE MAINTENANCE DESIGNATION QUANTITY **MAINTENANCE ALLOWANCE** INCORPO-**DESCRIPTION** AND **PER 100** RATED **FEDERAL** BY RECOVERABILITY UNIT **FIGURE EQUIPS** IN STOCK NUMBER EXPEND-OF ITEM CODE NO. UNIT ISSU ABILITY MODEL NO. 2ND 2 WAVEMETER FR-91/U: FR-9LA/U NOTE: Model Column I refers to FR-91/U: Model Column 2 refers to FR-91A/U WAVEMETER FR-91/U; FR-91A/U 6625-32-42352 ea NX BUMPER, RUBBER: Helmn-Smeth No. 2196 (ttL9Se38-7) X H2 thru ea Н9 CATCH, CABINET DOOR: Seiset Hdwre No. 270(ttL9Se38-9) H12 ea X H₁₀ H_{I1} CATCH, LU(GAGE: Excelsior No. 44334N (+ttL95e38-10) ea X 2 DOOR KNOBS: Miller Ind No. 1032 (+ttL9Se38-14) ea X MP4 5980-160-6850 KNOB:bar type; Sig. Dwg. No. SC-B-107852 ea X 5355-160-6850 KOB: Davies No. 2300 ea X MP1

FR-91/U; FR-91A/U

. L. LEMNITZER, General, United States Army, Chief of Staff.

Official:

R. V. LEE,

Major General, United States Army, The Adjutant General.

DISTRIBUTION:

Active Army:

Def Atomic Spt Agey (5) USASA (2) CNGB (1) Tech Stf, DA (1) except CSigO (18) Tech Stf Bd (1) USA Arty Bd (1) USA Armor Bd (1) USA Inf Bd (1) USA AD Bd (1) USA Abn & Elct Bd (1) USA Avn Bd (1) USA ATB (1) USCONARC (2) US ARADCOM (2) US ARADCOM Rgn (2) OS Maj Comd (5) OS Base Comd (5) Log Comd (5) MDW (1) Armies (5) except First USA (7) Corps (2) Div (2) USATC (2) Ft Belvoir (5) Svc Colleges (5) Br Svc Sch (5) except

USASCS (25)

GENDEP (2) except Atlanta GENDEP (none) Sig Sec, GENDEP (10) Sig Dep (17) Army Pictorial Cen (2) Engr Maint Cen (1) USA Ord Msl Comd (3) USASSA (15) USASSAMRO (1) USA Sig Pub Agcy (8) USA Sig Engr Agcy (1) USA Comm Agcy (2) USA Sig Eqp Spt Agcy (2) USA Sig Msl Spt Agcy (13) WRAMC (1) AFIP (1) AMS (1) Ports of Emb (OS) (2) Trans Terminal Comd (1) Army Terminals (1) OS Sup Agcy (1) Yuma Test Sta (2) USA Elct PG (1) Sig Lab (5) Sig Fld Maint Shops (3) USA Corps (Res) (1) JBUSMC (2)

NG: State AG (3); units-same as Active Army except allowance is one copy to each unit. *USAR:* None.

For explanation of abbreviations used see AR 320-50.

| | RECOMMENDED CHANGES TO | EQUIPMENT TECHNICAL PUBLICATIONS |
|--|--|--------------------------------------|
| 752 | Something | WRONG WITH THIS PUBLICATION? |
| DOPE ALL FORM, C | JOT DOWN THE BOUT IT ON THIS AREFULLY TEAR IT LD IT AND DROP IT | (PRINT YOUR UNIT'S COMPLETE ADDRESS) |
| The state of the s | | |
| PUBLICATION NUMBER | PUBLICATION DATE | Publication title |
| BE EXACTPIN-POINT WHERE IT IS | IN THIS SPACE TELL WHAT IS | WRONG |
| PAGE GRAPH FIGURE NO. | AND WHAT SHOULD BE DON! | |
| PRINTED NAME, GRADE OR TITLE, AND TELEP | HONE NUMBER . SIGN HE | FRE: |

DA 15017. 2028-2

PREVIOUS EDITIONS
• ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.