

# L05-6675-323-12

16 SEPTEMBER 1983

## TOPOGRAPHIC SUPPORT SYSTEM

### ANALYSIS SECTION

### MODEL ADC-TSS-12

NSN: 6675-01-105-5761


Reference TM5-6675-323-14 and C9100-IL


Intervals and the related manhour times are based on normal operation. The manhour time specified is the time you need to do all the services prescribed for a particular interval. Decrease the interval and lubricate more frequently if your lubricants have been contaminated or you are operating under adverse conditions, including longer than usual operating hours. The intervals between lubrications may be extended during periods of low activity, but only if adequate preser-

vation precautions have been taken. The lowest level of maintenance authorized to lubricate a point is indicated by one of the following symbols: Operator/Crew (C) and Organizational Maintenance (O). Clean all fittings, plugs, and caps before removal and/or lubrication. Remove all excess oil or grease after lubrication. If possible, exercise moving parts to distribute lubricant evenly. Lubricate all oil can points after washing or fording.

LUBRICANT ● INTERVAL

INTERVAL ● LUBRICANT





TOTAL MAN - HR		TOTAL MAN - HR	
<u>INTERVAL</u>	<u>MAN - HR</u>	<u>INTERVAL</u>	<u>MAN - HR</u>
M	0.3	Q	0.6

KEY

LUBRICANTS		EXPECTED TEMPERATURES	INTERVALS
OGP (MIL-L-7870)	LUBRICATING OIL, GENERAL PURPOSE, LOW TEMPERATURE	All Temperatures	M MONTHLY
	PERSONNEL DOOR AND CARGO DOOR HINGES		Q QUARTERLY
	PERSONNEL DOOR LATCHES		
	CARGO DOOR LATCHES		
	RETRACTABLE STEP HINGE		
	EXHAUST FAN COVER		
	AIR VENT HINGE		

NOTES

1. Before lubricating, wipe all points free of dirt, grease or dust.
2. Wipe all surplus oil from surfaces after lubrication.
3. When lubricating hinges, be sure oil covers entire length of hinge.
4. OIL CAN POINTS. In accordance with the intervals listed in this Lubrication Order, lubricate the Door Hinges and Latches, Step Hinges, Air Vent Hinge and Exhaust Fan Cover Hinge with OGP.

Copy of this Lubrication Order will remain with the equipment at all times; instructions contained herein are mandatory.

By Order of the Secretary of the Army:

**JOHN A. WICKHAM, JR.**  
General, United States Army  
Chief of Staff

Official:

**ROBERT M. JOYCE**  
Major General, United States Army  
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A,  
Operator maintenance requirements for Mapping.