#### TECHNICAL MANUAL

# ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

F O R

# MODULAR COLLECTIVE PROTECTION EQUIPMENT (MCPE)

(NSN 4240-00-229-2610)

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS, MISSOURI, TO MEET YOUR NEEDS WHILE WE REPLENISH OUR REGULAR STOCK.

TECHNICAL MANUAL

No. 11-7440-294-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 10 September 1985

### ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

## MODULAR COLLECTIVE PROTECTION EQUIPMENT (MCPE) (NSN 4240-00-229-2610)

Current as of 1 April 1985

#### REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-ME-MP, Fort Monmouth, New Jersey 07703-5007. A reply will be furnished direct to you.

#### TABLE OF CONTENTS

			Illus
		Page	Figure
Section I.	Introduction	1	
II.	Repair Parts List	5	
	Modular Collective Protection Equipment		1
. 01	Duct Assembly, Transition	7	2
	Platform Assembly		3
03	Support Assembly (No parts authorized)		
04	Bracket Assembly, Cradle	11	4
Section III.	Special Tools List (Not applicable)		
IV.	National Stock Number and Part Number Index	12	

#### **SECTION I**

#### INTRODUCTION

#### 1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support and general support maintenance of the MCPE. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

#### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.
- b. Section III. Special Tools List. Not applicable.
- c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

#### 3. Explanation of Columns

- a. Illustration. This column is divided as follows:
- (1) Figure number. Indicates the figure number of the illustration on which the item is shown.
- (2) *Item number*. The number used to identify item called out in the illustration.

- b. Source, Maintenance, and Recoverability (SMR) Codes.
- (1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

#### Code Definition

- PA Item procured and stocked for anticipated or known usage.
- XB Item is not procured or stocked. If not available through salvage, requisition.

#### NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

#### Code Application/Explanation

- O Support item is removed, replaced, used at the organizational level.
- F Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

#### Code Application/Explanation

- F The lowest maintenance level capable of complete repair of the support item is the direct support level.
- Z Nonreparable. No repair is authorized.
- (3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

#### Recoverability

Code

Definition

- Z Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- F Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.
- c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.
- d. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- e. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

#### **NOTE**

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. Items that are included in kits and sets are listed below the name of the kit or set indicated in the quantity incorporated in unit column.
- g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

#### 4. Special Information

a. The following publication pertains to the MCPE and its components:

TM 11-7440-294-14, Modular Collective Protection Equipment (MCPE)

b. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN'S are established and published, submit exception requisitions to Commander: US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-MM, Fort Monmouth, NJ 07703-5007 for the part required to support your equipment.

#### 5. How to Locate Repair Parts

- a. When National stock number or part number is unknown.
- (1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings and divided into the same groups.
- (2) Second. Find the illustration covering the functional group to which the item belongs.

- (3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.
- (4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- b. When National stock number or part number is known.
- (1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent


National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) Second. After finding the figure and item number, locate the figure and item number in the repair parts list.

#### 6. Abbreviations

Not applicable.

(Next printed page is 4.1)



EL8X0001

Figure 1. Modular Collective Protection Equipment (MCPE) (Sheet 1 of 2).

#### TM 11-7440-294-24P




Figure 1. Modular Collective Protection Equipment (MCPE) (Sheet 2 of 2).

SECTION II TM11-7440-294-24P REPAIR PARTS LIST (8) (1) (2) (3) (4) (5) (6) (7) ILLUS-OTY TRATION SMR NATIONAL FSCM PART DESCRIPTION U\M INC (a) (b) CODE STOCK NUMBER HISARLE. IN FIG. ITEM NUMBER ON UNIT NO. NO. CODE GROUP 00 MODULAR COLLECTIVE PROTECTION ECHTPMENT 1 1 PAFZZ 4240-01-145-4714 81361 M10 ENTRANCE, PROTECTIVE EΑ 1 2 XBFZZ 81361 D5-19-6628 VALVE ASSY, AIR FLOW 1 1 EΑ 1 3 XBFZZ 81361 C5-19-6170-40 CABLE ASSY, SP ELECT EΑ 1 1 4 XBFZZ 81361 C5-19-6162-10 CABLE ASSY, SP ELECT EΑ 1 5 PAFZZ 4720-01-063-4567 81361 C5-19-6181-2030 HOSE, AIR DUCT EΑ 2 1 PAFZZ 4240-01-057-3378 81361 E5-19-6376 CONTROL MODULE UNIT 1 EΑ 7 1 DAFZZ 4730-01-049-0805 81361 C5-19-6182 COUPLING.AIR DUCT FΔ 1 1 8 PAFZZ 4720-01-074-9220 81361 C5-19-6181-10 HOSE, AIR DUCT EΑ 6 PAFZZ 4240-01-068-8645 81361 E5-19-6387 POWER DISTRIBUTION EΑ 4240-00-237-0227 81361 1 10 FLTR UNIT, GAS PARCLT 1 PAFZZ M56 EΑ 1 11 XBOFF 80063 SC-D-913385 DUCT ASSY, TRANS (SEE FIGURE 2 FOR BREAKDOWN) EΑ 1 1 12 XBOFF 80063 SC-D-913383 PLATFORM ASSEMBLY (SEE FIGURE 3 FOR BREAKDOWN) EΑ 1 1 13 XBFZZ 80063 SC-D-913366 SUPPORT ASSEMBLY 1 EΑ 5305-01-014-7483 96906 MS35307-306 SCREW.CAP.HEXAGON H 1 14 PAFZZ 8 EΑ 1 15 PAFZZ 5310-00-933-8121 96906 MS35338-139 WASHER, LOCK EΑ 18 16 PAFZZ 5310-00-582-5677 96906 MS15795-810 WASHER, FLAT 18 17 XBFZZ 80063 SC-D-681076-38 NUT, BLIND 1 8 EΑ BRACKET ASSY, CRADLE (SEE FIGURE 4 FOR BREAKDOWN) 1 18 XBFFF 80063 SC-D-913400 EΑ 1 1 19 PAFZZ 5306-00-637-9674 96906 MS35307-336 BOLT, MACHINE EΑ 12 1 20 PAFZZ 5310-00-974-6623 96906 MS35338-140 WASHER, LOCK EΑ 12 1 21 PAFZZ 5310-00-802-4701 96906 MS15795-813 WASHER, FLAT 12 EΑ 1 2.2 XBFZZ 80063 SC-D-681076-54 NUT, BLIND EΑ 12

MS35307-310

MS35307-308

SC-D-681076-46

SC-D-681076-44 NUT.BLIND

SCREW.CAP.HEXAGON H

SCREW, CAP, HEXAGON H

NUT, BLIND

EΑ

EΑ

EΑ

EΑ

8

8

8

8

1

1

1

1

23

24

25

26

PAFZZ

XBFZZ

PAFZZ


XBFZZ

5305-00-021-3668 96906

5305-00-207-8253 96906

80063

80063



EL8XO003

Figure 2. Duct Assembly, Transition.

(1)		(2)	(3)	(4)	(5)	(6)		(7)	(8)
ILLUS TRATI		SMR	NATIONAL	FSCM	PART	DESCRIPTION		U\M	QTY INC
(a)	(b)	CODE	STOCK		NUMBER		USABLE	5 (	IN
FIG.	ITEM		NUMBER				ON		UNIT
NO.	NO.						CODE		

TM11-7440-294-24P

GROUP 01 DUCT ASSEMBLY. TRANSITION

1

1

2 1 XBFZZ 80063 SC-D-913387 BRACKET, TRANSITION EA
2 2 XBFZZ 80063 SC-D-913389 HOUSING, TRANSITION EA

SECTION II

2 3 XBFZZ 80063 SC-C-913388 PLATE, TRANSITION EA 1
2 4 XBFZZ 80063 SC-B-913386 GASKET, DUCT EA 1




Figure 3. Platform Assembly.

TM11-7440-294-24P

						TM11-7440-294-24P			
SECTI (1) ILLUS		(2)	(3)	(4)	(5)	(6)		(7)	(8) QTY
TRATI (a) FIG. NO.	ON (b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	U\M	INC IN UNIT
						GROUP 02 PLATFORM	ASSEMBLY		
3	1	XBFZZ		80063	SC-C-913406-002	SNAP CHAIN ASSEMBLY	ľ	EA	1
3	2	XBFZZ		80063	SC-C-913406-001	SNAP CHAIN ASSEMBLY	ľ	EA	1
3	3	XBFZZ		56996	B4024798	PLATFORM WLD ASSY		EA	1
3	4	XBFZZ		80063	SC-C-913415	PIPE, WELDED ASSY		EA	1
3	5	PAFZZ	5306-00-655-6170	96906	MS35307-338	SCREW		EA	8
3	6	XBFZZ		80063	SC-D-913378-001	STEP SUPPORT ASSY		EA	1
3	7	PAFZZ	5310-00-880-5977	96906	MS15795-811	WASHER, FLAT		EA	18
3	8	PAFZZ	5310-00-974-6623	96906	MS35338-140	WASHER, LOCK		EA	18
3	9	PAFZZ	5310-00-767-0445	96906	MS51971-2	NUT, PLAIN HEXAGON		EA	18
3	10	XBFZZ		80063	SC-D-913377	STEP		EA	1
3	11	XBFZZ		96906	MS24693-C118	SCREW, FLAT HEAD		EA	1
3	12	XBFZZ		80063	SC-D-913378-002	STEP SUPORT ASSY		EA	1
3	13	XBFZZ		80063	SC-C-866485	LANYARD ASSEMBLY		EA	1
3	14	PAFZZ	5305-00-854-9351	96906	MS24630-23	SCREW PAN HEAD		EA	1
3	15	XBFZZ		96906	MS17988 C812	PIN QUIK RELEASE		EA	1
3	16	XBFZZ		56996	B4024797	PLATFORM WLD ASSY		EA	
3	17	XBFZZ		80063	SC-D-913414	GRATE WELDED ASSY		EA	
3	18	XBFZZ		80063	SC-C-913409	PIPE WELDED ASSY		EA	
3	19	XBFZZ		56996	B4024796	PLATFORM WLD ASSY		EA	
3	20	XBFZZ		80063	SC-D-913382	PLATFORM SUB ASSY		EA	
3	21	XBFZZ		96906	MS24693096	SCREW		EA	8
3	22	XBFZZ		56996	B4024799	CLINCH NET		EA	18
3	23	XBFZZ		80063	SC-C-913411	FLOOR BLANGE		EA	8
3	24	XBFZZ		80063	SC-C-913363	ARM BRACKET		EA	
3	25	PAFZZ	5306-00-637-9675	96906				EA	




Figure 4. Bracket Assembly, Cradle.

SECTION II TM11-7440-294-24P

(1) ILLUS	_	(2)	(3)	(4)	(5)	(6)	(7)	(8) QTY
TRATI (a) FIG. NO.	ON (b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION USABLE ON CODE	U\M	INC IN UNIT
						GROUP 04 BRACKET ASSEBLY CRADLE		
4	1	XBFZZ		80063	SC-C-913397	GASKET	EA	1
4	2	XBFZZ		80063	SC-C-913391	GASKET	EA	1
4	3	XBFZZ		80063	SC-C-913396	GASKET	EA	1
4	4	XBFZZ		80063	SC-C-913392	GASKET	EA	1
4	5	XBFZZ		80063	SC-D-913399	CRADLE BRACKET	EA	1
4	6	XBFZZ		80063	SC-C-913393	GASKET	EA	1
4	7	XBFZZ		80063	SC-C-913395	GASKET	EA	1
4	8	XBFZZ		80063	SC-C-913394	GASKET	EA	1

SECTION IV TM11-7440-294-24P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL	FIGURE	ITEN
STOCK NUMBER	NO.	NO.
5305-00-021-3668	1	23
5305-00-207-8253	1	25
4240-00-237-0227	1	10
5310-00-582-5677	1	16
5306-00-637-9674	1	19
5306-00-637-9675	3	25
5306-00-655-6170	3	5
5310-00-767-0445	3	9
5310-00-802-4701	1	21
5305-00-854-9351	3	14
5310-00-880-5977	3	7
5310-00-933-8121	1	15
5310-00-974-6623	1	20
5310-00-974-6623	3	8
5305-01-014-7483	1	14
4730-01-049-0805	1	7
4240-01-057-3378	1	6
4720-01-063-4567	1	5
4240-01-068-8645	1	9
4720-01-074-9220	1	8
4240-01-145-4714	1	1

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

		NATIONAL STOCK NOMBE.	K AND FAKT	NONDER	INDEX				
		NATIONAL	FIGURE	ITEM			NATIONAL	FIGURE	ITEM
FSCM	PART NUMBER	STOCK NUMBER	NO.	NO.	FSCM	PART NUMBER	STOCK NUMBER	NO.	NO.
10011	TIMET HOLDER	Diodic Hondell	1.0.	1.0.	1 0 011	TIME NOTEDIA	DIOON NONDEN	1.0.	1.0.
56996	B4024796		3	19	80063	SC-D-913399		4	5
56996	B4024797		3	16	80063	SC-D-913400		1	18
56996	B4024798		3	3	80063	SC-D-913414		3	17
56996			3	22	80003	20-0-313414		3	Ι/
	B4024799								
81361	C5-19-6162-10		1	4					
81361	C5-19-6170-40		1	3					
81361	C5-19-6181-10	4720-01-074-9220	1	8					
81361	C5-19-6181-2030	4720-01-063-4567	1	5					
81361	C5-19-6182	4730-01-049-0805	1	7					
81361	D5-19-6628		1	2					
81361	E5-19-6376	4240-01-057-3378	1	6					
81361	E5-19-6387	4240-01-068-8645	1	9					
96906	MS15795-810	5310-00-582-5677	1	16					
96906	MS15795-811	5310-00-880-5977	3	7					
96906	MS15795-813	5310-00-802-4701	1	21					
96906	MS17988-C812		3	15					
96906	MS24630-23	5305-00-854-9351	3	14					
96906	MS24693-C118	3303 00 034 3331	3	11					
96906	MS24693-C96	5205 01 014 5402	3	21					
96906	MS35307-306	5305-01-014-7483	1	14					
96906	MS35307-308	5305-00-207-8253	1	25					
96906	MS35307-310	5305-00-021-3668	1	23					
96906	MS35307-332	5306-00-637-9675	3	25					
96906	MS35307-336	5306-00-637-9674	1	19					
96906	MS35307-338	5306-00-655-6170	3	5					
96906	MS35338-139	5310-00-933-8121	1	15					
96906	MS35338-140	5310-00-974-6623	1	20					
96906	MS35338-140	5310-00-974-6623	3	8					
96906	MS51971-2	5310-00-767-0445	3	9					
81361	M10	4240-01-145-4714	1	1					
81361	M56	4240-00-237-0227	1	10					
80063	SC-B-913386	1210 00 237 0227	2	4					
80063	SC-C-866485		3	13					
80063			3	24					
	SC-C-913363								
80063	SC-C-913388		2	3					
80063	SC-C-913391		4	2					
80063	SC-C-913392		4	4					
80063	SC-C-913393		4	6					
80063	SC-C-913394		4	8					
80063	SC-C-913395		4	7					
80063	SC-C-913396		4	3					
80063	SC-C-913397		4	1					
80063	SC-C-913406-001		3	2					
80063	SC-C-913406-002		3	1					
80063	SC-C-913409		3	18					
80063	SC-C-913411		3	23					
80063	SC-C-913415		3	4					
80063	SC-D-681076-38		1	17					
80063	SC-D-681076-44		1	26					
80063	SC-D-681076-46		1	24					
80063	SC-D-681076-54		1	22					
80063	SC-D-913366		1	13					
80063	SC-D-913377		3	10					
80063	SC-D-913377 SC-D-913378-001		3	6					
	SC-D-913378-001 SC-D-913378-002								
80063			3	12					
80063	SC-D-913382		3	20					
80063	SC-D-913383		1	12					
80063	SC-D-913385		1	11					
80063	SC-D-913387		2	1					
80063	SC-D-913389		2	2					

#### RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG

WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) Commander

Stateside Army Depot ATTN: AMSTA-US Stateside, N.J. 07703-5007

OUT. FOLD IT AND DROP IT IN THE MAIL!

JOT DOWN THE DOPE ABOUT IT ON THIS

FORM. CAREFULLY TEAR IT

DATE SENT

10 July 1978

**PUBLICATION NUMBER** 

TM 11-7440-294-24P

THEN

PUBLICATION DATE

23 Jan 78

PUBLICATION TITLE

Modular Collective Protection Equipment (MCPE)

L			• • •		L	. <b>5 Juli</b> 7 G	Modular Concentre Protection Equipment (MCFE)
	T PIN-					TELL WHAT I	
PAGE NO	PARA- GRAPH	FIGURE NO	TABLE NO	AND W	HAT SH	OULD BE DON	E ABOUT IT:
,,				_			
33						2, change the NS Accuracy.	N to read: 5835-00-134-9186.
44		19				·	our stion has disam as 5)
44		19		R	leason: 1	it is a separate it	unction box (item no. 5). em and is not called out on figure 19.
45				Δ	dd the c	over of the im.	on box as an item in the listing for figure 19.
73				R	eason: S	Same as above.	ook as an item in the fishing for righte 17.
							•
						•	
							•
							al E
							CAIL
							SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SSG I. M. DeSpirit of

999-1776

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

AND F. ENT OF T DOD 314 POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY



OFFICIAL BUSINESS OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander

US Army Communications-Electronics Command and Fort Monmouth

ATTN: AMSEL-ME-MP

Fort Monmouth, New Jersey 07703-5007

#### RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH

WITH THIS PUBLICATION?

THEN. JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

**PUBLICATION NUMBER** 

TM 11-7440-294-24P

PUBLICATION DATE
10 Sept 1985

PUBLICATION TITLE

Modular Collective Protection Equipment (MCPE)

BE EXAC	T PIN-	POINT WH	ERE IT IS	IN THIS SPACE TELL WHAT IS WRONG
PAGE NO	PARA-	FIGURE	TABLE	AND WHAT SHOULD BE DONE ABOUT IT:
NO	GRAPH	NO	NO	
<b>!</b> }	1 '	1 1	1 7	
	1 1	1 1	1 7	
<b>i</b>	I = I	1 1	I = I	•
i l	į 1	1 1	1 1	
<b>!</b> !	, ,	1 1	1 1	
l j	, ,	I = I	1 1	
l j	, I	I = I	( 1	
1 1	, ,	I = I	1 1	
1 1	i J	I = I	1 1	
1 [	, ,	, ,	1 1	
1 1	ı İ	1 1	1 1	
1 1	, 1	, ,	1 1	1
1 1	, 1	, )	1	1
i 1	, J	, ,	1 1	1
}	, 1	, 1	1	$I \rightarrow$
	, 1	, 1	1 1	
1	, ,	, 1	1	
i 1	J	, 1	, J	ı
	. 1	,	, 1	
	. ,	, }	, 1	ı
	. ,	.	i	
	J	, ,	ı	
}	ļ	, }	, J	
	J	.	,	
. [		,	,	
	1		. }	
. ]	ļ		,	
	I	. 1	,	
	1	. 1	. 1	
	1	1	`	
	Ì		'	
PRINTED	JAME, GR	ADE OR TI	TLE, AND	D TELEPHONE NUMBER SIGN HERE

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK


DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: AMSEL-ME-MP
Fort Monmouth, New Jersey 07703-5007



FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: AMSEL-ME-MP
Fort Monmouth, New Jersey 07703-5007

#### RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



### SOMETHING WRONG

WITH THIS PUBLICATION?

THEN JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

**PUBLICATION NUMBER** 

PUBLICATION DATE

PUBLICATION TITLE

TM 11-7440-294-24P

10 Sept 1985

Modular Collective Protection Equipment (MCPE)

				IN THIS	SPACE TELL	WHAT	IS WRONG	
PAGE NO	PARA- GRAPH	FIGURE NO	TABLE	AND WH	IAT SHOULD	BE DON	NE ABOUT IT:	
NO	GHAPH	NO	NO	!				
	}		1	ł				
		ł						
			1					•
		1	}					
		ļ						
			ı					
	}	Í						
	]							
	ļ	<b> </b>						
		ŀ						
	1		j					
	į	į	j					
	1	l						,
PRINTED	NAME, GR	ADE OR T	ITLE, AN	TELEPHO	NE NUMBER	SIGN HE	RE	

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: AMSEL-ME-MP
Fort Monmouth, New Jersey 07703-5007

By Order of the Secretary of the Army:

JOHN A. WICKHAM JR. General, United States Army Chief of Staff

Official:

DONALD J. DELANDRO Brigadier General, United States Army The Adjutant General

Distribution:

To be distributed in accordance with special list.

\* U.S. GOVERNMENT PRINTING OFFICE: 1987 0 - 181-421 (70497)