NOTE TO USERS

PCI Chassis Recommendations

The NI PCI-4070 is designed to operate in any ATX-compliant industrial or personal computer. Normal operating conditions for the NI PCI-4070 include the following:

- Covers for all sides of the industrial chassis or personal computer must be installed.
- All PCI filler panels must be installed to close off unused PCI slots.



Caution For optimal electromagnetic compatibility (EMC) performance and input protection, you *must* install the front panel screw.

• The PCI front panel bracket on the NI PCI-4070 must have a firm, direct, metal-to-metal mounting connection to assure proper grounding. Some computer manufacturers use a securing lever made of plastic; such a lever is unacceptable for safety reasons and must be removed. Also, the NI PCI-4070 must be screwed down. Otherwise, you must use a different computer chassis.



National Instruments™, NI™, and ni.com™ are trademarks of National Instruments Corporation. Product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: Help»Patents in your software, the patents.txt file on your CD, or ni.com/patents. © 2003 National Instruments Corp. All rights reserved.



323766A-01

Dec03