



This manual is for reference and historical purposes, all rights reserved.

This creation is copyright© by M. Butkus, NJ, U.S.A.

These creations may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

If you find this manual useful, how about a donation of \$2 to:

M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701

and send your e-mail address so I can thank you.

Most other places would charge you \$7.50 for a electronic copy or

\$18.00 for a hard to read Xerox copy.

This will allow me to continue this site, buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

If you use Pay Pal, go to my web site

www.orphancameras.com and choose the secure PayPal donation icon.

SERVICE MANUAL

EXPLODED VIEWS

for


mamiya/sekor 1000DTL and 500DTL






MAMIYA CAMERA CO., LTD.


TOKYO JAPAN


Donated to www.orphancameras.com





DETAIL for A




























DETAIL for dWP 1114(H)K2



DETAIL for dWP 1211K2

DETAIL for TL 2100



The parts indicated by part numbers on this page, are exclusively used for the mamiya/sekor 500 DTL (without built-in selftimer).

