

Adjustment Item List

			Adjust Mode						Tech. Rep. Mode																								
Check Items	10.3 mm ± 2.0 mm	11.3 mm ± 1.5 mm	20 mm ± 1.0 mm	20 mm ± 1.0 mm	200 mm ± 2.0 mm	300 mm ± 3.0 mm	Org. Detect Sensor	ATDC Sensor Adjust	Paper Feeding Test	Manual Bypass Paper Width Detect Adjust	Hard Disk Format	P/C Counter Clear	I/C Counter Clear	Developer Counter Clear	Each Counter	Registration Loop	Zoom Adjust	Feed (CD)	Feed (FD)	Edge Erase (Leading)	Edge Erase (Trailing)	Edge Erase (Right/Left)	Loop Adjustment	Set	Set	Scanner Position Adjustment	Remount	EEPROM	Installing the IU	Replacement of the Developer	Jig	Firmware Upgrade	
	Registration (CD)	Registration (FD)	Registration (CD)	Registration (FD)	Zoom Adjust (CD)	Zoom Adjust (FD)	F7-1	F8	F1	FD	PM Counter	Sheet-through-ADF	Printer	Hard Disk	Original Size Detecting Option																		
	Registration (CD)	Registration (FD)	Registration (CD)	Registration (FD)	Zoom Adjust (CD)	Zoom Adjust (FD)	F7-1	F8	F1	FD	PM Counter	Sheet-through-ADF	Printer	Hard Disk	Original Size Detecting Option																		
PM	Manual Bypass Paper Take-Up Roller	Replace								2					1																		
	1st Separator Roll Assy	Replace								2					1																		
	1st Paper Take-up Roller	Replace								2					1																		
	1st Pickup Roller	Replace								2					1																		
	1st Separator Roll Assy	Replace								2					1																		
	2nd Paper Take-up Roller	Replace								2					1																		
	2nd Pickup Roller	Replace								2					1																		
	2nd Separator Roll Assy	Replace								2					1																		
	Synchronizing Roller Bushing	Replace								1												(2)											
	Synchronizing Roller Gear	Replace								1												(2)											
	Image Transfer Roller Unit	Replace													1																		
	Ozone Filter	Replace																															
	PC Drum Unit	Replace							3				1	(1)															2				
	Developer	Replace							3				1	(1)															2				
	Developing Unit	Replace							4				1	(1)	2														3				
	Ds Collar	Cleaning																															
	Fusing Unit	Replace													1																		
Part other than PM	ATDC Sensor	Replace							4	1			1	(1)						3	4	5							3	2			
	Master Board (PWB-A)	Replace																													1		
	PH Unit	Replace	1	2	6	5	4	3									7	8	9														
	CCD Unit	Replace			2		1																										
	Scanner Drive Cable	Install				3		2																			1						
	Scanner Unit	Install																									1						
	Manual Bypass Unit	Replace								1																							
	Hard Disk Drive	Install									2													1									
Mounting of the Original Size Detecting Sensors (Option)		Install																						1									
Ref. Page		D-52	D-53	D-63	D-64	D-65	D-66	S-30	S-31	S-30	S-31	-	S-28	S-28	S-28	S-29	S-23	S-23	S-23	S-23	S-21	S-21	S-21	S-22	-	D-69	D-50	D-81	-	E-34	D-74		

NOTE: Be sure to record the data of Utility Mode, Tech. Rep. Mode, and Security Mode before performing a memory clear.