



## Chapter 11 Wiring/Circuit Diagrams

1312/1312F WIRING DIAGRAM FOR 120V .....	11-1
UNIT PSU (1/3) FOR 120V .....	11-3
UNIT PSU MAIN REGULATOR (2/3) FOR 120V .....	11-4
UNIT PSU LAMP REGULATOR (3/3) FOR 120V .....	11-5
UNIT FUSE .....	11-9
UNIT MAIN (1/9) .....	11-10
UNIT MAIN CONTROL (2/9) .....	11-11
UNIT MAIN OPERATION I/F (3/9) .....	11-12
UNIT MAIN FUSER I/F (4/9) .....	11-13
UNIT MAIN POWER SUPPLY I/F (5/9) .....	11-14
UNIT MAIN CLUTCH I/F (6/9) .....	11-15
UNIT MAIN LOWER CASSETTE I/F (7/9) .....	11-16
UNIT MAIN STEPPING MOTOR I/F (8/9) .....	11-17
UNIT MAIN EXTIO I/F (9/9) .....	11-18
UNIT OPERATION (1/2) .....	11-19
UNIT OPERATION (2/2) .....	11-20
UNIT HV (1/4) .....	11-21
UNIT HV HIGH VOLTAGE (2/4) .....	11-22
UNIT HV STEPPING MOTOR (3/4) .....	11-23
UNIT HV TONER MOTOR (4/4) .....	11-24
UNIT ERASE .....	11-25
UNIT SIDE ERASE .....	11-26
PF-105/105H WIRING DIAGRAM .....	11-27
UNIT CASSETTE FEEDER .....	11-28


## 1312 Wiring Diagram for 120V




## 1312 Wiring Diagram for 120V to 240V




## UNIT PSU (1/3) for 120V




# UNIT PSU MAIN REGULATOR (2/3) for 120V








# UNIT PSU MAIN REGULATOR (2/3) for 220V to 240V






# UNIT PSU LAMP REGULATOR (3/3) for 220V to 240V




## UNIT FUSE







## UNIT MAIN CONTROL (2/9)



# UNIT MAIN OPERATION I/F (3/9)





## UNIT MAIN FUSER I/F (4/9)






# UNIT MAIN CLUTCH I/F (6/9)






UNIT MAIN LOWER CASSETTE I/F (7/9)









## UNIT OPERATION (1/2)



UNIT OPERATION (2/2)




## UNIT HV (1/4)




Note: \*\*\* are not installed for without SDH models.

# UNIT HV HIGH VOLTAGE (2/4)




# UNIT HV STEPPING MOTOR (3/4)




Note: \*\*\* are not installed for without SDH models.




# UNIT HV TONER MOTOR (4/4)




# UNIT ERASE



UNIT SIDE ERASE



## PF-105/105H Connection Diagram



UNIT CASSETTE FEEDER

