
R0206
(FG HEAD)
P0201
CURR LIMIT 1
CAP ET 2
CAP ED/S 3
CAP FG1 4
GND(FG) 5
REG 5V 6
GND(MOTOR) 7
LOAD MOTOR(-) 8
LOAD MOTOR(+) 9
PS 14V 10
UNLOADING Ⓗ 11
LOADING Ⓗ 12
TO SYSTEM CONTROL & SERVO SECTION P2501(F-15)
C0201
R0207
HOLE SENSOR H3
R0208
HOLE SENSOR H1
R0209
HOLE SENSOR H2
IC0201
(CAPSTAN MOTOR DRIVE)
RCC SET
H3-
H3+
H1-
H1+
H2-
H2+
FG/S
GND
VH+
EC
VCC
ECR
TL
PCV
PC1
POSITION SIGNAL PROCESS
DIFFERENTIAL AMP
TORQUE DIRECTION
HALL POWER
EC AMP
TL AMP
AMP
VM1
TSD
CONTROL LOGIC
DRIVER
DRIVER
VCC 28
NC 27
VM1 26
A3 25
A1 24
ATC 23
A2 22
OUT2 21
RNF 20
OUT1 19
VM2 18
17
RIN 16
FIN 15
R0201
R0211
C0206
C0207
R0212
R0213
Q0203
Q0202
Q0201
R0210
D0203
TL0204
TL0202
TL0203
TL0201
L0201
C0208
C0209
C0210
R0204
CAPSTAN MOTOR MAIN COIL
TL0205
D
C
B
A
1
2
3
4
5
6
7