VIDEO SIGNAL PATH

AUDIO SIGNAL PATH

R0714 5600

R0732 4700

R0713 0

LB0701 VLP0147

C0724 220P

R0740 270

R0717 470

R0711 180

R0745 3.3M

C0707 50V2.2

T0701 EQV5EC081P

R0731 100

R0727 0

C0719 0.1

C0708 50V 0.47

C0717 33P

R0742 150

Q0702 2SD601A (AMP)

R0741 220

C0721 56P

R0743 1K

PK0701

DU7601-19	SW1	1
DU7601-20	SW2	2
DU7601-21	———	3
DU7601-22	SIF/QPSK	4
DU7601-23	AFC S-CURVE	5
DU7601-24	TUNER VIDEO	6
DU7601-25	TUNER 5V	7
DU7601-26	———	8
DU7601-27	GND	9

TO POWER SUPPLY/ RF SECTION DU7601 (D-10)

1.6 2.4 2.6 5.0

IC0701 LA75503

3.1 2.4 1.6 3.0 2.7 2.2 3.3 4.3 4.3 1.8 0 1.3

BPF, BPF, LIM AMP, FM DET, DEEMPHP, AMP SW, EQ AMP, TRAP, S PLL, FIL CONT, LPF, VCO, FLL, AGC, AFT AMP, VIDEO DET, APC DET, 1ST SIF DET, VIF AMP, IF AGC, 1ST AMP, RF AGC

2.6 2.4 2.2 3.3 2.8 2.8 5.0 1.6 0.1 4.0 2.4

D0702 0

C0701 1

C0713 6V330

C0704 0.033

R0705 4700

R0708 10K

C0714 1

VR0701 10KB

R0707 39K

C0702 1000P

C0703 1

R0719 4700

C0712 0.1

X0704 VLF1497

C0710 0.01

L0703 2.2u

L0701 0.27u

X0702 VLF1431

X0701 VLF1430

R0725 100

C0715 3P

C0711 16V22

R0715 22K

R0709 100K

PP0701 (TO TUNER UNIT)

4MHz	1
AGC	2
IF	3
GND	4

NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-HS820EE
TV DEMODULATOR PACK SCHEMATIC DIAGRAM