
REC AUDIO SIGNAL
PB AUDIO SIGNAL
MAIN C.B.A.
UHF/VHF TUNER/TV DEMODULATOR UNIT
RF
AUDIO
AUDIO
(WITHOUT Hi-Fi AUDIO)
C4018
R4018
Q4001
+5V
Q4002
Q4003
IC3001 (AUDIO PROCESS)
(WITHOUT FRONT A/V JACK /WITHOUT Hi-Fi AUDIO)
AUDIO IN 1
J4002
TUNER
LINE
PB
AGC DET
AGC
REC-OFF
REC AMP
REC-ON
MUTE
PB AMP
LINE AMP
AUDIO MUTE(H)
I2C CONTROL
(WITH FRONT A/V JACK /WITHOUT Hi-Fi AUDIO)
NOT USED
IC4151 (INPUT SELECT)
LINE1
LINE2
(FROM IC6001(19)) INPUT SELECT 2
OPERATION C.B.A.
AUDIO IN 2
P6302
P6320
AUDIO IN 2
(TO/FROM IC6001(17)) I2C SERIAL DATA
(FROM IC6001(18)) I2C SERIAL CLOCK
(FROM IC6001(59)) AUDIO MUTE(H)
(WITH Hi-Fi AUDIO)
(FROM IC4201(61)) NORMAL AUDIO
(TO IC4201(62)) NORMAL AUDIO
(TO IC3801(3)) AUDIO
(WITH ADVANCE)
J4003
Q4006
Q4004
DRIVE
AUDIO OUT
J4001
R4013
(WITHOUT Hi-Fi AUDIO)
BIAS OSC
T4101, Q4101
P6202
P6202
P3551
P3551
P4001
P4001
HEAD AMP C.B.A.
P2601
P2601
P3501
P3501
P4091
P4091
P4091
P4091
AUDIO CONTROL HEAD UNIT
P4092
P4092
P4092
P4092
AUDIO HEAD
AUDIO ERASE HEAD
FULL ERASE HEAD UNIT
PIN
PIN
FULL ERASE HEAD