
REC AUDIO SIGNAL
PB AUDIO SIGNAL
MAIN C.B.A.
UHF/VHF TUNER/TV DEMODULATOR UNIT
RF
14
AUDIO
AUDIO
1
(WITHOUT Hi-Fi AUDIO)
C4018
R4018
Q4001
+5V
Q4002
Q4003
IC3001 (AUDIO PROCESS)
56
(WITHOUT FRONT A/V JACK)
J4002
AUDIO IN 1
71
73
TUNER
LINE
PB
AGC DET
AGC
MUTE
REC-OFF
REC-ON
REC AMP
PB AMP
65
60
57
58
LINE AMP
AUDIO MUTE(H)
I2C CONTROL
69
75
7
8
(WITH MONAURAL FRONT A/V JACK)
NOT USED
IC4151
(INPUT SELECT)
LINE1
LINE2
13
14
12
11
(FROM IC6001(19))
INPUT SELECT 2
OPERATION C.B.A.
AUDIO IN 2
P6302
P6320
19
19
(TO/FROM IC6001(17))
I2C SERIAL DATA
(FROM IC6001(18))
I2C SERIAL CLOCK
(FROM IC6001(59))
AUDIO MUTE(H)
(WITH Hi-Fi AUDIO)
(FROM IC4201(61))
NORMAL AUDIO
(TO IC4201(62))
NORMAL AUDIO
(TO IC3801(3))
AUDIO
(WITH ADVANCE)
J4003
Q4006
Q4004
DRIVE
AUDIO OUT
J4001
R4013
(WITHOUT Hi-Fi AUDIO)
BIAS OSC
T4101, Q4101
P6202
3
P6202
1
P3551
3
P3551
4
HEAD AMP C.B.A
P2601
3
P2601
1
P3501
3
P3501
4
P4091
2
P4091
1
P4091
4
P4091
3
AUDIO CONTROL HEAD UNIT
P4092
2
P4092
1
P4092
4
P4092
3
AUDIO HEAD
AUDIO ERASE HEAD
FULL ERASE HEAD UNIT
P4001
2
P4001
1
PIN
2
PIN
1
FULL ERASE HEAD