VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
AUDIO MAIN SIGNAL PATH IN REC MODE
AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE

IC3001 AN3531NFBS

QR4002 UN2211 (PAL 9H Ⓗ :ON)
QR4004 UN2212 (PAL 9H Ⓗ :ON)
QR3003 UN2213 (SP:ON)
QR3004 UN2213 (LP:ON)
QR3011 UN2213 (INV.)
QR3008 UN2213 (INV.)
QR3005 UN2213 (PB:ON)
QR3012 UN2213 (V.EE Ⓗ:ON)

PICTURE 1
IIC CLOCK
IIC DATA
SECAM Ⓛ
V.EE Ⓗ
ROTARY SW
SP Ⓛ

NOTE:THE MEASUREMENT MODE OF THE DC VLOLTAGE IN THE BRACKETS( )ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR.(SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.(SP MODE)

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.