:VIDEO SIGNAL PATH　:SIGNAL PATH　:C SIGNAL PATH

TO CONTROL SECTION <B-33>
A36 3.3V(D)
A37 3.3V(V)
A35 5V(D)
A38 GND
A39 V GND

P59201 (TO JACK P53001 <B-1>)
Y IN
C IN
V GND
VIDEO IN
V GND
V GND
S-VHS DET
EDIT DATA
EDIT CLOCK
GND

IC201
C1ZBZ0001964
(YC SEPARATOR/DECODER/ ENCODER/MEMORY CONTROL)

TO CONTROL SECTION <E-33>
A33 LCD Y
A34 LCD C
A40 NHD

TO CONTROL SECTION <E-1,G-1>
A4 RESET
A32 WE0
A29 RD
A30 CS4
A31 NIRQB
A28 NIRQA

NOTE:DO NOT ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-APD1E/B/EN
VIDEO SECTION IN MAIN SCHEMATIC DIAGRAM