
:VIDEO MAIN SIGNAL PATH
IC480
L2ES00000004
(GYRO SENSOR)
IC481
L2ES00000003
(GYRO SENSOR)
IC482
C0ABAA000042
IC451
C0JBAS000065
IC453
C0ABAA000045
IC452
C0ABCA000042
TO
S JACK FLEX.CARD
FP452
TO
MAIN CONNECTION
FP451
DV TERMINAL
JK3801
K2NC89Z00002
EDIT (E) (MINI)
JK6401
K2HZ108B0003
TO FRAME GND
NOTE:
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.
NOTE:
THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS REC MODE.