
LENS UNIT
CCD FLEX. CARD C.B.A.
PS201
PP101
FP501
FP301
CAMERA SUB C.B.A.
FP4001
FP4903
REMOTE CONTROL RECIEVER
TALLY
JK4901
MIC JACK
JK4902
AV IN/OUT PHONES
JK2501
DIGITAL STILL PICTURE
FP4902
MF UNIT
FP4904
FP441
AWT
AF/MF
AWT SENSOR C.B.A.
FP4901
FP4802
FP4803
MICHRO PHONE
MIC UNIT
FRONT-B C.B.A.
FP701
PP301
PS3004
MONITOR C.B.A.
MONITOR LCD PANEL
FP901
FP903
TO FP601
FP904
FP602
FP905
HALL SENSOR FLEX. CARD
CAMERA OPERATION FLEX.CARD C.B.A.
AUTO
MANUAL
AE LOCK
TITLE
MULT
MEMU
W.B
FP303
CAMERA MAIN C.B.A.
VTR MAIN C.B.A.