
B
A
1
2
3
4
TO
POWER
8
7 PLAY
6 SCAN3
5 PAUSE
4 STOP
3 SCAN4
2 FF
1 REW
TO
FP1003
FF
REW
STOP
PAUSE
PLAY