GETTING STARTED

1

Insert CD, then choose Install NI-488.2 Software for Windows.

NI-488.2 Software for Windows

- INNOVATION · PERFORMANCE · COMPATIBILITY
- Install NI-488.2 Software for Windows
- View Documentation
- Visit National Instruments Website
- Explore CD
- Exit

- Install and Launch LabVIEW Evaluation
- Install LabWindows/CVI Evaluation
- Install ComponentWorks Evaluation
- Install HiQ Student Edition

2

Shut down, then power off computer.

- Programs
- Documents
- Settings
- Find
- Help
- Run..
- Shut Down..
- Start

Shut Down Windows

Are you sure you want to:
- Shut down the computer?
- Restart the computer?
- Restart the computer in MS-DOS mode?
- Close all programs and log on as a different user?

[Yes] [No] [Help]

Power Off Computer

3

Install hardware*, then power on computer.

Power On Computer

* **For Help** installing your hardware, refer to the GPIB Hardware Guide (available on the CD through View Documentation).

(Continued)

4 Run NI-488.2 Getting Started Wizard.

NI-488.2 Getting Started Wizard

Click on the following steps to use the NI-488.2 Software for Windows with your GPIB instruments:

▶ **Verify your hardware and software installation**

■ Communicate with your instrument

Learn more about National Instruments software

☐ Do not show at Windows startup   Exit

NATIONAL INSTRUMENTS™

322271A-01   020899