AH-9130G-MC FICHE 1 OF 2 RK6 FCTNL CTRL CZR6KG0 MAR 1982 COPYRIGHT0 76-81 MADE IN USA RK611 RK06,RK07

FCTNL CTRL CZR6KG0 AH-9130G-MC FICHE 2 OF 2 MAR 1982 COPYRIGHT0 76-81 RK611 RK06.RK07 RK6 MADE IN USA

CZ

.REM ?

IDENTIFICATION

PRODUCT CODE:

AC-9128G-MC

PRODUCT NAME:

CZR6KGO RK611 FCINL CTRL

DATE:

AUGUST 10 1981

MAINTAINER:

DIAGNOSTIC GROUP

AUTHOR:

BRIAN LEBLANC

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILLIATED COMPANIES.

COPYRIGHT (C) 1976,1981 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:
DIGITAL PDP UNIBUS MASSBUS
DECUS DECTAPE

TABLE OF CONTENTS

1.0 ABSTRACT REQUIREMENTS HARDWARE REQUIREMENTS PRELIMINARY PROGRAMS OPERATING PROCEDURE LOADING PROCEDURE 3.0123456789 STARTUP PROCEDURE
CONSOLE SWITCH REGISTER
SOFTWARE SWITCH REGISTERS
CONTROL C (^C) OPERATION
CONTROL S (^S) OPERATION
CONTROL Q (^Q) OPERATION
UNIBUS ADDRESS EXECUTION TIM 4.0 PROGRAM DESCRIPTION 5.0 ERROR REPORTING 6.0 SUBROUTINES 7.0 REVISION HISTORY

ZR6KGO RK6 FCTNL CTRL DIAG

28-AUG-81 15:16

CZR6KG.P11

1.0 ABSTRACT

THE RK611 FUNCTIONAL CONTROLLER DIAGNOSTIC (CZR6K) IS A SERIES OF TESTS THAT COMPLETES THE TESTING OF AN RK611/RK06-RK07 SUBSYSTEM. THE DISKLESS CONTROLLER DIAGNOSTIC AND THE RK06-RK07 DRIVE DIAGNOSTIC ARE PREREQUISITES TO THE RUNNING OF THIS PROGRAM. THE PURPOSE OF THIS PROGRAM IS TO TEST THOSE AREAS IN THE CONTROLLER THAT COULD NOT BE TESTED IN A DISKLESS ENVIRONMENT AND THOSE AREAS OF THE DRIVE THAT COULD NOT BE TESTED UNTIL CONTROLLER OPERATION IN A DIAGNOSTIC OR MAINTENANCE MODE HAS BEEN TESTED.

THE TESTS PERFORMED ARE MAINLY FUNCTIONALLY ORIENTED BUT DIAGNOSTIC MODE IS USED IN NUMEROUS OCCASSIONS TO ACCOMPLISH THE OBJECTIVES, MAINLY THE FORCING OF ERRORS. IN THESE CASES, THE CONTROLLER IS PLACED IN DIAGNOSTIC MODE AND OPERATION IS CLOCKED PART WAY THROUGH. DIAGNOSTIC MODE IS THEN RESET AND THE CONTROLLER ALLOWED TO COMPLETE THE OPERATION. DEPENDING ON THE OPERATION AND HOW FAR THROUGH IT BEFORE DIAGNOSTIC MODE IS RESET VARIOUS ERROR CONDITIONS CAN BE MADE TO OCCUR. THIS DOCUMENT DOES NOT ATTEMPT TO EXPLAIN WHY THESE ERROR CONDITIONS ARE SET BUT THE INDIVIDUAL TEST DESCRIPTIONS SPECIFY WHAT ERROR IS BEING FORCED AND THE PROCEDURE USED TO FORCE IT.

CAUTION

THIS PROGRAM SHOULD BE HALTED ONLY BY TYPING A ^C. IF THE PROGRAM IS HALTED USING THE HALT KEY THE POSSIBILITY EXISTS THAT THE CARTRIDGE FORMAT WILL BE INCORRECT, THE CYLINDER ADDRESS IN THE DRIVE MAY BE INVALID, OR THE DRIVE MAY NOT BE READY.

- 2.0 REQUIREMENTS
- 2.1 HARDWARE REQUIREMENTS

PDP-11 SYSTEM (16K MEMORY)
CONSOLE TERMINAL
DECTAPE, PAPERTAPE, OR DISK
LINE CLOCK (KW11-L) (OPTIONAL)
PARITY OPTION (MM11) (OPTIONAL)
RK611 CONTROLLER
AT LEAST 1 AND UP TO 8 RK06-RK07 DRIVES
FORMATTED RK06K ON EACH DRIVE

2.2 PRELIMINARY PROGRAMS

C

28-AUG-81 15:16

THE RK611 DISKLESS CONTROLLER DIAGNOSTIC (ALL PARTS) AND THE

UNIBUS RKO6-RKO7 DRIVE DIAGNOSTIC (ALL PARTS) SHOULD HAVE RUN SUCCESSFULLY.

- 3.0 OPERATING PROCEDURE
- 3.1 LOADING PROCEDURE

THE PROGRAM CAN BE LOADED FROM BINARY TAPE USING THE ABSOLUTE LOADER OR FROM XXDP MEDIA SUPPORTED BY XXDP.

IT CAN BE LOADED AND RUN UNDER APT OR ACT AND IT CAN BE CHAINED BY XXDP.

3.2 STARTUP PROCEDURE

> THE PROGRAM START LOCATION IS 200(8). THIS START WILL AUTOMATICALLY SIZE THE SYSTEM UNLESS RUNNING UNDER APT. THE PROGRAM ASSUMES THE STANDARD UNIBUS ADDRESS, VECTOR ADDRESS, AND BUS PRIORITY LEVEL (177440, 210, AND 4 RESPECTIVELY). IF STARTED AT 200 AND THE XXDP MEDIA IS RKO6 (PROGRAM LOADED FROM RKO6) DRIVE O IS NOT TESTED.

LOCATION 204(8) IS THE PROGRAM RESTART.

LOCATION 214(8) IS THE PARAMETERIZATION START LOCATION. OPERATOR WILL BE ASKED TO IDENTIFY THE BUS ADDRESS, VECTOR ADDRESS, AND BUS PRIORITY. IF THE PROGRAM WAS LOADED FROM RKO6, THE OPERATOR WILL BE ASKED TO MOUNT A WORK CARTRIDGE ON DRIVE O OR TO PLACE IT OFF-LINE IF IT IS NOT TO BE TESTED.

LOCATION 220(8) IS THE PHASE LOCKED LOOP CLOCK ADJUSTMENT START. THE PROGRAM FIRST RUNS THE FIRST THREE TESTS AND THEN JUMPS TO THE ADJUSTMENT ROUTINE. THE PROGRAM WILL CONTINUE TO LOOP IN THIS ROUTINE UNTIL THE PROCESSOR IS HALTED.

ALL DRIVES THAT ARE TO BE TESTED MUST BE ON-LINE, READY, AND WRITE LOCK RESET. IF ALL THREE CONDITIONS ARE NOT MET, THAT DRIVE IS NOT TESTED.

3.3 CONSOLE SWITCH REGISTER

> THE CONSOLE SWITCH REGISTER IS USED TO PROVIDE PROGRAM CONTROL AS DESCRIBED BELOW:

SW15 - HALT ON ERROR

SW14 - LOOP ON TEST

SW13 - INHIBIT ERROR REPORT

SW12 - ABORT PROGRAM AFTER 20 ERRORS SW11 - INHIBIT ITERATIONS

SW10 - BELL ON ERROR

SW09 - LOOP ON ERROR

SWO8 - EXECUTE TEST NUMBER SPECIFIED IN SW<7-0>.

145-67-8901-235-67-8901-235-67-8901-

SW<7-0> - EXECUTE THIS TEST IF SW08 SET.

EXECUTING A SPECIFIC TEST MUST BE USED WITH CAUTION. TESTS REQUIRE OTHERS TO BE RUN TO FORMAT THE PACK IN A SPECIFIC MANNER OR WRITE SPECIFIC DATA. TESTS THAT REQUIRE OTHERS TO BE RUN INDICATE THIS IN THE TEST DESCRIPTION. IT IS SUGGESTED THAT THE PROGRAM BE RUN IN THE DEFAULT SEQUENCE THE FIRST TIME AFTER IT HAS BEEN LOADED.

NOTE: TEST 3 MUST BE RUN BEFORE ANY SUBSEQUENT TEST. THIS TEST DETERMINES WHICH DRIVES ARE ON THE DRIVE BUS FOR ALL FOLLOWING TESTS. LIKEWISE, TEST 20 MUST BE RUN BEFORE ANY TEST SUBSEQUENT TO IT. THIS TEST READS THE BAD SECTOR FILES AND BUILDS TABLES USED BY THE FOLLOWING TESTS. THESE TESTS, HAVING BEEN RUN ONCE, NEED NOT BE RUN AGAIN IF A DIFFERENT TEST IS SELECTED.

'SOFTWARE' SWITCH REGISTER 3.4

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E., AN 11/04 OR 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS AT A HIGHER PRIORITY PROCESSING AN RKO6 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

SWR = NNNNNN

NEW = '

EACH TIME SWITCH SETTINGS ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROES ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS. THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

3.5 CONTROL C (^C) OPERATION

IF °C IS TYPED AT ANY TIME DURING THE PROGRAM EXECUTION THE PROGRAM IS HALTED IMMEDIATELY. IF A MONITOR IS PRESENT (XXDP CHAIN, ACT, APT) THE PROGRAM RETURNS CONTROL TO THE MONITOR. IF NO MONITOR IS PRESENT, THE CPU IS HALTED. DEPRESSING THE CONTINUE KEY WILL DO A PROGRAM RESTART.

3.6 CONTROL S (AS) OPERATION

IF "S IS TYPED AT ANY TIME THE PROGRAM WILL GO INTO A STALL

LOOP UNTIL A CONTROL Q (AQ) IS TYPED.

3.7 CONTROL Q (^Q) OPERATION

IF A AS HAS BEEN TYPED, TYPING THE AG CANCELS THE STALL INITIATED BY THE AS.

3.8 UNIBUS ADDRESSES

STANDARD UNIBUS ADDRESSES ARE ASSUMED FOR THE KW11-L AND MM11 OPTIONS. THESE ADDRESSES MAY BE CHANGED BY CHANGE THE APPROPRIATE MEMORY LOCATIONS. THE FOLLOWING TAGS AND LOCATIONS HAVE BEEN USED:

KW11-L TAG LOCATION
UNIBUS ADDRESS KWLADD 1710
VECTOR ADDRESS KWLVEC 1712

3.9 EXECUTION TIME

THE FIRST PASS OF THE PROGRAM FOR ONE DRIVE IS APPROXIMATELY 65 SECONDS AND EACH SUBSEQUENT PASS IS APPROXIMATELY 2 MINUTES 20 SECONDS.

THE EXECUTION TIME FOR MULTIPLE DRIVES IN THE FIRST PASS IS:

((NUMBER OF DRIVES) X 45 SEC) + 20 SEC

FOR SUBSEQUENT PASSES THE RUN TIME IS THE PRODUCT OF 2 MINUTES 20 SECONDS TIMES THE NUMBER OF DRIVES PLUS 25 SECONDS FOR EACH DRIVE AFTER THE FIRST.

4.0 PROGRAM DESCRIPTION

THE FOLLOWING TEST SEQUENCE IS EXECUTED ASSUMING TWO OR MORE DRIVES.

FIRST PASS - FIRST DRIVE: ALL TESTS UP TO THE MULTI-DRIVE OPERATIONS ARE PERFORMED ONCE.

FIRST PASS - ALL REMAINING DRIVES: STATUS VALID TESTS UP TO THE MULTI-DRIVE OPERATIONS ARE PERFORMED ONCE ON EACH DRIVE.

THEN MULTI-DRIVE OPERATIONS ARE PERFORMED ONCE ON EACH COMBINATION OF DRIVES.

SECOND AND ALL SUBSEQUENT PASSES:
THE SAME SEQUENCE OF TESTING IS REPEATED EXCEPT FOR TEST
ITERATIONS WHICH ARE SPECIFIED FOR EACH TEST.

**BASIC INTERFACE AND OPTION TESTS

TEST 1 RK611 BASE ADDRESS TEST

CHECK THAT READING THE RK611 BASE ADDRESS (RKCS1) DOES NOT CAUSE A NON-EXISTANT MEMORY TRAP.

TEST 2 INTERRUPT VECTOR ADDRESS TEST CHECK THAT THE INTERRUPT VECTOR FOR THE RK611 IS SET TO THE EXPECTED ADDRESS.

TEST 3 SELECT ALL DRIVES

IF NOT RUNNING IN APT AUTOMATIC ENVIRONMENT, DETERMINE WHAT DRIVES ARE ON-LINE BY SELECTING ALL DRIVES. IF NON-EXISTENT DRIVE REPORTED MAKE SURE STATUS VALID IS RESET. IF DRIVE PRESENT MAKE SURE NO ERROR EXISTS, DRIVE IS CYCLED UP, AND STATUS VALID SET, AND DSC RESET.

IF RUNNING IN APT AUTOMATIC ENVIRONMENT, THE DRIVES IDENTIFIED IN ETABLE ARE TESTED FOR NO ERROR, DRIVE CYCLED UP, AND STATUS VALID SET.

IF LOCATION 41 INDICATES THE XXDP MEDIA IS ON THE RK06, DRIVE O WILL ONLY BE TESTED IF THE PARAM START (214) WAS USED. IF THE AUTOMATIC START (200) IS USED, DRIVE O IS NOT TESTED. THE RESTART (204) WILL RETAIN THE TEST STATUS OF DRIVE O.

IF THE PARAM START IS USED, THE OPERATOR MUST EITHER PLACE DRIVE O OFF LINE IF IT IS NOT TO BE TESTED OR UNLOADED AND A SCRATCH MEDIA MOUNTED IF IT IS TO BE TESTED. THE PROGRAM WILL MONITOR OFF LINE AND VOLUME VALID TO DETERMINE THE TEST STATUS OF DRIVE O.

ALL DRIVES TO BE TESTED MUST BE CN-LINE, CYCLED UP, AND WRITE LOCK RESET. ADDRESSES OF DRIVES THAT ARE NON-EXISTANT EITHER BECAUSE THE DRIVE DOES NOT EXIST OR IS OFF-LINE ARE USED TO VERIFY NON-EXISTANT DRIVE ERROR DETECTION. DRIVES THAT ARE ON-LINE BUT NOT CYCLED UP OR ARE WRITE LOCKED ARE NOT TESTED.

AT COMPLETION OF THE TEST A MESSAGE WILL BE GIVEN TO IDENTIFY THE DRIVES TO BE USED IN TESTING.

NOTE: THIS TEST MUST BE RUN AT LEAST ONCE BEFORE ANY OTHER TEST THAT FOLLOWS.

THE DETERMINATION OF WHETHER EACH DRIVE IS AN RKO6 OR RKO7 IS MADE IN THIS TEST, AND

A TABLE IS FILLED ACCORDINGLY.

TEST 4 RELEASE ALL DRIVES

RELEASE ALL DRIVES. MAKE SURE NO ERROR SETS AND STATUS VALID IS RESET.

TEST 5 NON-STANDARD MESSAGES AND SVAL

PICK ONE OF THE AVAILABLE DRIVES AND GET NON-STANDAD MESSAGES. MAKE SURE NO ERROR OCCURS AND STATUS VALUD DOES NOT SET AND THAT NON-STANDARD MESSAGES CAUSE STATUS VALID TO RESET.

TEST 6 WRITING CS2 AND STATUS VALID

SELECT AN AVAILABLE DRIVE. MAKE SURE STATUS VALID IS SET. WRITE COMMAND AND STATUS REGISTER 2. MAKE SURE STATUS VALID RESETS.

TEST 7 DRIVE TYPE ERROR

CREATE A DRIVE TYPE ERORR MAKE SURE DRIVE TYPE ERROR SETS AND STATUS VALID SETS.

TEST 10 STATUS VALID AND PARITY ERROR

ISSUE A SELECT TO AN AVAILIABLE DRIVE WITH BAD PARITY. MAKE SURE SPAR, CONTROLLER ERROR, ATTENTION, DRIVE STATUS CHANGES, DRPAR, DRIVE INTERRUPT, AND STATUS VALID SET, ISSUE A CONTROLLER CLEAR. MAKE SURE DRIVE INTERRUPT AND ATTENTION ARE STILL SET. SELECT DRIVE AGAIN WITH GOOD PARITY. MAKE SURE ATTENTION, DRIVE STATUS CHANGE, DRPAR, CONTROLLER ERROR, DRIVE INTERRUPT, AND STATUS VALID ARE SET AND SPAR IS RESET. ISSUE A CONTROLLER CLEAR. GET NON-STANDARD MESSAGES AND MAKE SURE ONLY DRIVE INTERRUPT AND ATTENTION ARE SET. CLEAR ATTENTION WITH DRIVE CLEAR. REPEAT FOR ALL AVAILIABLE DRIVES.

TEST 11 UNIT FIELD ERROR ON RELEASE

ISSUE A SUBSYSTEM CLEAR. SELECT AN AVAILABLE DRIVE. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A RELEASE COMMAND. CLOCK THROUGH PHASE ADDRESS 2. TURN OFF DIAGNOSTIC MODE. MAKE SURE UNIT FIELD ERROR SETS.

TEST 12 UNIT FIELD ERROR ON SELECT

ISSUE A SUBSYSTEM CLEAR. SELECT AN AVAILABLE DRIVE.

PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT COMMAND WITH MESSAGE ID = 3 AND DRIVE SELECTED = 0. CLOCK THROUGH PHASE ADDRESS 6. TURN OFF DIAGNOSTIC

MODE. MAKE SURE UNIT FIELD ERROR SETS.

**ATTENTION HANDLING BY CONTROLLER

TEST 13 DOUBLE INTERRUPT

ISSUE A SUBSYSTEM CLEAR. ISSUE A RECALIBRATE. MAKE SURE STATUS VALID IS SET. CHECK THAT SECOND INTERRUPT OCCURS. AFTER SECOND INTERRUPT CHECK THAT STATUS VALID IS RESET. ISSUE SELECT AND MAKE SURE STATUS VALID SETS. CLEAR DRIVE. CHECK THAT DRIVE STATUS CHANGE SETS (BIT 14 OF DRIVE STATUS REGISTER)

TEST 14 SINGLE INTERRUPT FROM ATTENTION

DO A SEEK TO CYLINDER O. WAIT FOR INTERRUPT FROM DRIVE ATTENTION. LOWER PRIORITY AGAIN AND MAKE SURE ANOTHER INTERRUPT DOES NOT OCCUR. CLEAR DRIVE.

TEST 15 RESET ATTENTIONS WITH UNIBUS INIT

DO A SEEK TO CYLINDER O ON ALL AVAILIABLE DRIVES. ISSUE A RESET. MAKE SURE ALL ATTENTION RESET.

**ILLEGAL DISK ADDRESS ERROR TESTS

TEST 16 ILLEGAL DISK ADDRESS (PART 1)

ISSUE A SEEK TO CYLINDER O, HEAD 3. MAKE SURE ILLEGAL ADDRESS ERROR AND SEEK INCOMPLETE SETS. CLEAR CONTROLLER AND CLEAR DRIVE. REPEAT FOR HEADS 4-7. CHECKING THAT BOTH IDAE AND SEEK INCOMPLETE SET FOR HEAD 7 AND IDAE ALONE SETS FOR HEADS 4, 5, AND 6.

TEST 17 ILLEGAL DISK ADDRESS (PART 2)

ISSUE A SEEK TO CYLINDER 1000, HEAD O. MAKE SURE ILLEGAL DISK ADDRESS ERROR SETS. CLEAR CONTROLLER AND DRIVE THIS TEST IS BYPASSED BY THE RKO7 CONTROLLER BECAUSE IT DOES NOT RECOGNIZE ANY ILLEGAL DISK ADDRESS.

**WRITE HEADER TESTS

CZR6KG.P11

TEST 20 READ BAD SECTOR INFORMATION

ISSUE A READ DATA OF 400 WORDS TO CYLINDER 632, TRACK 2 TO GET THE FACTORY DETECTED BAD SECTOR FILE, 26 SECTOR MODE. CYLINDER 1456 IS USED FOR THE RKO7.

IF AN ERROR OCCURS, READ SECTOR 2, 4, 6, OR 10(8) UNTIL A SUCCESSFUL READ IS DONE. IF NONE READ SUCCESSFULLY REMOVE THIS DRIVE FROM TEST. WHEN A READ IS SUCCESSFUL, TEST THAT THE PACK IS NOT AN ALIGNMENT PACK AND STORE THE ENTRIES FOR LATER USE.

REPEAT THIS SERIES OF OPERATIONS FOR FACTORY DETECTED BAD SECTORS 24 SECTOR MODE, SOFTWARE DETECTED BAD SECTORS 26 SECTOR MODE, AND SOFTWARE DETECTED BAD SECTORS 24 SECTOR MODE. IF THE NUMBER OF BAD SECTORS FOR 24 OR 26 SECTOR MODE EXCEED 20(10) THE DRIVE IS REMOVED FROM TESTING.

NOTE: THIS TEST IS RUN IN THE FIRST (QUICK VERIFY) PASS ONLY.

TEST 21 FORMAT IN 26 SECTOR FORMAT

FORMAT CYLINDER 312. TRACK 0 AND TRACK 1 FOR 26 SECTOR FORMAT. VERIFY FORMAT AND THAT DATA LATE DID NOT OCCUR WITH WRITE HEADER ON IN READING DATA BUFFER AFTER READ HEADER.

HEADER RECOGNITION TESTS ********

TEST 22 BAD SECTOR ERROR

FORMAT CYLINDER 312, TRACK O, ON SCRATCH PACK TO HAVE SECTOR O (BIT 15 OR WORD 2 OF HEADER RESET) AND SECTOR 1 (BIT 14 OR WORD 2 OF HEADER RESET) TO BE BAD SECTORS AND ALL OTHER SECTORS GOOD.

ISSUE A WRITE DATA OR 400 WORDS TO CYLINDER 312, TRACK O, SECTOR O. MAKE SURE BAD SECTOR ERROR SETS. ISSUE A WRITE DATA TO CYLINDER O, TRACK O, SECTOR 1 OF 400 WORDS. MAKE SURE BAD SECTOR ERROR SET. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER O, TRACK O, SECTOR 2. MAKE SURE NO ERROR SETS.

TEST 23 HEADER VRC ERROR

FORMAT CYLINDER 312, TRACK O, ON SCRATCH PACK TO HAVE 16 SECTORS WITH BAD HEADER VRC. ISSUE A WRITE DATA OF EACH OF THE SECTORS WITH A BAD HEADER VRC. MAKE SURE HEADER VRC ERROR SETS. ISSUE A WRITE DATA TO A GOOD HEADER AND MAKE SURE NO ERROR OCCURS.

TEST 24 BAD SECTOR ERROR AND HVRC ERROR

FORMAT CYLINDER 312, TRACK O SUCH THAT SECTOR ZERO HAS BOTH A BAD SECTOR ERROR AND HEADER 'RC. ISSUE A WRITE

DATA TO CYLINDER O, TRACK O, SECTOR O. MAKE SURE ONLY HEADER VRC ERROR SETS.

TEST 25 OPERATION INCOMPLETE

FORMAT CYLINDER 312, TRACK O SUCH THAT SECTOR 21 HAS THE WRONG FORMAT. ISSUE A WRITE DATA OF 400 TO CYLINER O, TRACK O, SECTOR 21. MAKE SURE OPI SET.

TEST 26 OPI WITH HVRC ERROR

FORMAT CYLINDER 312, TRACK O SUCH THAT A HEADER VRC ERROR IS PRESENT AND SECTOR 17 HAS THE WRONG FORMAT. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER 312, TRACK O, SECTOR 17. THAT BOTH OPERATION INCOMPLETE AND HEADER VRC SET.

TEST 27 HVRC IGNORE ON NON-ADDRESSED SECTOR

FORMAT CYLINDER 312, TRACK O SUCH THAT SECTOR 20 HAS AN HVRC ERROR. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER 312, TRACK O, AND SECTOR 21. MAKE SURE HVRC IS NOT SET AT THE END OF THE OPERATION.

TEST 30 WRITE AND READ ONE SECTOR

FORMAT CYLINDER 312, ALL TRACKS AND CYLINDER 313, TRACK 2 TO AGREED WITH BAD SECTOR INFORMATION. ISSUE A WRITE DATA OF ONE SECTOR ON CYLINDER 312, TRACK 0. READ IT BACK TO MAKE SURE IT AGREES WITH WHAT IS WRITTEN.

TEST 31 WRITE DATA WITH BUS ADDRESS INCREMENT INHIBIT

ISSUE A WRITE DATA OF ONE SECTOR TO CYLINDER 312, TRACK 2, SECTOR 12 WITH INHIBIT BUS ADDRESS INCREMENT. READ DATA BACK TO MAKE SURE EVERY WORD IS THE SAME AND CORRECT.

TEST 32 WRITE DATA ADDRESS GREATER THAN 32K

CZR6KG.P11

28-AUG-81 15:16

ISSUE A WRITE DATA OF 400 WORDS WITH ADDRESS = 177770. MAKE SURE CORRECT DATA IS ON DISK.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 32K OF MEMORY IS PRESENT.

TEST 33 READ DATA ADDRESS GREATER THAN 32K

ISSUE A READ DATA OF 400 WORDS WITH ADDRESS = 177770. CHECK MEMORY FOR CORRECT TRANSFER.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 32K OF MEMORY IS PRESENT.

TEST 34 WRITE DATA ADDRESS GREATER THAN 64K

ISSUE A WRITE DATA OF 400 WORDS WITH ADDRESS = 377770. MAKE SURE CORRECT DATA IS ON DISK.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 64K OF MEMORY IS PRESENT.

TEST 35 READ DATA ADDRESS GREATER THAN 64K

ISSUE A READ DATA OF 400 WORDS WITH ADDRESS = 377770. CHECK MEMORY FOR CORRECT TRANSFER.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 64K OF MEMORY IS PRESENT.

TEST 36 WRITE DATA ADDRESS GREATER THAN 96K

ISSUE A WRITE DATA OF 400 WORDS WITH ADDRESS = 577770. MAKE SURE CORRECT DATA IS ON DISK.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 96K OF MEMORY IS PRESENT.

TEST 37 READ DATA ADDRESS GREATER THAN 96K

ISSUE A READ DATA OF 400 WORDS WITH ADDRESS = 577770.

CHECK MEMORY FOR CORRECT TRANSFER.

NOTE: THIS TEST IS ONLY EXECUTED IF MORE THAN 96K OF MEMORY IS PRESENT.

TEST 40 PARTIAL SECTOR WRITE DATA

O, SECTOR O MAKE SURE THE SECTOR WAS ZERO FILLED CORRECTLY.

TEST 41 PARTIAL SECTOR READ DATA

WRITE CYLINDER 312, TRACK O, SECTOR ZERO WITH A KNOWN CONFIGURATION. ISSUE A READ DATA OF 103 WORDS TO CYLINDER 312, TRACK O, SECTOR O. MAKE SURE ONLY 103 WORDS GET TRANSFERRED TO MEMORY.

TEST 42 WRITE DATA WITH NON-EXISTENT MEMORY

ISSUE A WRITE DATA OF 1 WORD USING ADDRESS 776000. MAKE SURE NON-EXISTENT MEMORY SETS.

TEST 43 READ DATA WITH NON-EXISTENT MEMORY

ISSUE A READ DATA OF 1 WORD USING ADDRESS 776000. MAKE SURE NON-EXISTENT MEMORY SETS.

TEST 44 UNIBUS PARITY ERROR

INITIALIZE A MEMORY LOCATION WITH BAD PARITY. ISSUE A WRITE DATA OF 400 WORDS STARTING AT A LOCATION 112 WORDS BEFORE THE LOCATION WITH BAD PARITY. MAKE SURE THAT UNIBUS PARITY ERROR SETS.

NOTE: THIS TEST IS ONLY EXECUTED IF MEMORY PARITY OPTION EXISTS FOR BUFFER. IT WILL NOT BE EXECUTED ON 'ECC' TYPE MEMORY.

**MULTIPLE SECTOR OPERATIONS

TEST 45 TWO SECTOR WRITE DATA (PART 1)

ISSUE A WRITE DATA OF 1000 WORDS TO CYLINDER 312, TRACK O, SECTOR O. READ DATA BACK ONE SECTOR AT A TIME AND MAKE SURE IT IS CORRECT.

TEST 46 TWO SECTOR WRITE DATA (PART 2)

ISSUE A WRITE DATA OF 1000 WORDS TO CYLINDER 312, TRACK O, SECTOR 23. READ DATA BACK ONE SECTOR AT A TIME AND MAKE SURE A MID-TRANSFER SEEK DID NOT TAKE PLACE.

TEST 47 TWO SECTOR WRITE DATA (PART 3)

ISSUE A WRITE DATA OF 401 WORDS TO CYLINDER 312, TRACK O, SECTOR 10. READ DATA BACK ONE SECTOR AT A TIME AND CHECK ZERO FILL OF SECOND SECTOR.

TEST 50 MID-TRANSFER SEEK ON WRITE (PART 1)

ISSUE A WRITE DATA OF 1000 WORDS TO CYLINDER 312.

TRACK O, SECTOR 25. READ DATA BACK ONE SECTOR AT A TIME AND MAKE SURE A MID-TRANSFER SEEK DID TAKE PLACE.

TEST 51 MID-TRANSFER SEEK ON WRITE (PART 2)

ISSUE A WRITE DATA OF 1000 WORDS TO CYLINDER 312, TRACK 2, SECTOR 25. READ DATA BACK ONE SECTOR AT A TIME AND MAKE SURE A MID-TRANSFER SEEK DID TAKE PLACE.

TEST 52 TWO SECTOR READ DATA (PART 1)

ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312, TRACK O. SECTOR O. VERIFY THAT CORRECT DATA IS READ.

NOTE: TWO SECTOR WRITE DATA (PART 1) MUST BE EXECUTED BEFORE THIS TEST.

TEST 53 TWO SECTOR READ DATA (PART 2)

ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312, TRACK O. SECTOR 23. VERIFY THAT CORRECT DATA IS READ AND A MID-TRANSFER SEEK DOES NOT OCCUR.

NOTE: TWO SECTOR WRITE DATA (PART 2) MUST BE EXECUTED BEFORE THIS TEST.

TEST 54 TWO SECTOR READ DATA (PART 3)

ISSUE A READ DATA OF 401 WORDS TO CYLINDER 312, TRACK O. SECTOR 10. VERIFY THAT ALL 401 WORDS ARE PLACED IN MEMORY.

NOTE: TWO SECTOR WRITE DATA (PART 3) MUST BE EXECUTED

BEFORE THIS TEST.

TEST 55 MID-TRANSFER SEEK ON READ (PART 1)

ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312, TRACK O. SECTOR 25. VERIFY THAT CORRECT DATA IS READ AND A MID-TRANSFER SEEK DOES OCCUR.

NOTE: MID-TRANSFER SEEK ON WRITE (PART 1) MUST BE EXECUTED BEFORE THIS TEST.

TEST 56 MID-TRANSFER SEEK ON READ (PART 2)

ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312, TRACK 2. SECTOR 25. VERIFY THAT CORRECT DATA IS READ AND A MID-TRANSFER SEEK DOES OCCUR.

NOTE: MID-TRANSFER SEEK ON WRITE (PART 2) MUST BE EXECUTED BEFORE THIS TEST.

TEST 57 CYLINDER ADDRESS OVERFLOW (PART 1) ISSUE A READ DATA OF 400 WORDS TO CYLINDER 632. TRACK 2. SECTOR 25. MAKE SURE CYLINDER ADDRESS OVERFLOW ERROR DOES NOT OCCUR. CYLINDER 1456 IS USED FOR THE RKO7. TEST 60 CYLINDER ADDRESS OVERFLOW (PART 2) ISSUE A READ DATA OF 401 WORDS TO CYLINDER 632, TRACK 2. SECTOR 25. MAKE SURE CYLINDER ADDRESS OVERFLOW ERROR DOES OCCUR. CYLINDER 1456 IS USED FOR THE RK07. ********** **18 BIT DATA TRANSFER TESTS ******************* TEST 61 FORMAT IN 24 SECTOR FORMAT FORMAT CYLINDER 312, TRACK O, AND TRACK 1 FOR 24 SECTOR FORMAT. VERIFY FORMAT AND THAT DATA LATE DID NOT OCCUR WITH WRITE HEADER ON IN READING DATA BUFFER AFTER READ HEADER. TEST 62 24 SECTOR FORMAT DATA TRANSFER (PART 1) ISSUE A WRITE DATA OF 400 WORDS IN 24 SECTOR FORMAT TO CYLINDER 312, TRACK O, SECTOR O. READ SECTOR BACK AND MAKE SURE IT IS CORRECT. TEST 63 24 SECTOR FORMAT DATA TRANSFER (PART 2) ISSUE A WRITE DATA OF 1000 WORDS IN 24 SECTOR FORMAT TO CYLINDER 312, TRACK O, SECTOR 23. READ SECTOR BACK AND MAKE SURE IT IS CORRECT. MAKE SURE THAT MID-TRANSFER SEEK HAS TAKEN PLACE. **SPECIAL DATA TRANSFER TESTS ********** TEST 64 MULTI-SECTOR DATA TRANSFER AND BSE FORMAT CYLINDER 312, TRACK 0 IN 26 SECTOR FORMAT WITH SECTOR 1 MARKED BAD. ISSUE A WRITE DATA OF 1000 WORDS TO CYLINDER 312, TRACK 0, SECTOR 0. MAKE SURE BAD SECTOR ERROR SETS AND RKDA IS CORRECT. READ SECTOR O AND MAKE SURE IT IS CORRECT. ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312. TRACK O, SECTOR O. MAKE SURE BAD SECTOR ERROR SETS AND THE PREVIOUS SECTOR IS LOADED CORRECTLY INTO MEMORY. TEST 65 FORMAT TEST

FORMAT CYLINDER 312, TRACKS 0 AND 1 IN 26 SECTOR FORMAT. MAKE SURE NO ERRORS SET. READ SECTORS 0-25 AND MAKE SURE DATA CHECK DOES NOT OCCUR.

................

**WRITE CHECK TESTS

TEST 66 WRITE-CHECK WITH NO ERROR

WRITE CYLINDER 312, TRACK O, SECTOR O WITH A KNOWN PATTERN. DO A WRITE-CHECK OF 400 WORDS. MAKE SURE NO ERROR OCCURS.

TEST 67 WRITE CHECK ERROR (PART 1)

WRITE CYLINDER 312, TRACK O, SECTOR O WITH ALL ZEROES. WRITE CHECK CYLINDER 312, TRACK O, SECTOR O WITH SAME. DATA EXCEPT WORD 110 HAS ONE OF THE FOLLOWING CONFIGURATIONS:

000001 000020 000400 010000 000002 000040 001000 02000 040000 000010 000200 040000 000010 000200 004000 100000

MAKE SURE WRITE CHECK ERROR SET FOR EACH OF THE CONFIGURATIONS AND THAT THE BUS ADDRESS AND WORD COUNT IS CORRECT.

TEST 70 WRITE CHECK ERROR (PART 2)

WRITE CYLINDER 312, TRACK O, SECTOR O WITH 17777 IN ALL WORDS. WRITE CHECK CYLINDER 312, TRACK O, SECTOR O WITH THE SAME DATA EXCEPT WORD 120 HAS ONE OF THE FOLLWOING CONFIGURATIONS:

177776 177757 177377 167777 177775 177737 176777 157777 177773 177677 175777 137777 177767 177577 173777 077777

MAKE SURE WRITE CHECK ERROR SET FOR EACH OF THE CONFIGURATIONS AND THAT THE BUS ADDRESS AND WORD COUNT IS CORRECT.

TEST 71 WRITE CHECK OF PARTIAL SECTOR

WRITE CYLINDER 312, TRACK O, SECTOR WITH A KNOWN CONFIGURATIONS. ISSUE A WRITE CHECK COMMAND OF 110 WORDS MAKING SURE THE 11-TTH WORD IS DIFFERENT THAN DATA ON DISK. MAKE SURE WRITE CHECK ERROR DOES NOT SET.

CZR6KGO RK6 FCTNL CTRL DIAG

28-AUG-81 15:16

CZR6KG.P11

**MAXIMUM DATA TRANSFER AND CONTROLLER TIME OUT

TEST 72 MAXIMUM DATA TRANSFER (PART 1)

IN THE FIRST PASS OF THE PROGRAM, THE HEADERS OF THE FIRST 4 CYLINDERS ARE WRITTEN. THIS IS DONE TO INSURE THE FORMAT IS CORRECT.

ZERO OUT THE FIRST 256 SECTORS OF THE DISK WITH ONE SECTOR WRITES. ISSUE A SEEK TO CYLINDER O, TRACK O. ISSUE A WRITE DATA OF MAXIMUM DATA TRANSFER 200000 WORDS TO CYLINDER O, TRACK O, SECTOR O. MAKE SURE CONTROLLER TIME OUT IS NOT SET. CHECK CYLINDER ADDRESS, DISK ADDRESS, BUS ADDRESS AND WORD COUNT. READ EACH SECTOR TO MAKE SURE IT WAS WRITTEN CORRECTLY.

NOTE: THIS TEST IS EXECUTED ONLY IF NO BAD SECTORS

ARE PRESENT IN THE FIRST 256 SECTORS ON THE PACK.

TEST 73 MAXIMUM DATA TRANSFER (PART 2)

ZERO OUT FIRST 256 SECTORS OF THE DISK WITH 200000 WORD WRITE. SEEK TO CYLINDER 632. ISSUE A WRITE OF MAXIMUM DATA TRANSF 200000 WORD WRITE. MAKE SURE CONTROLLER TIME C. IS NOT SET. CHECK CYLINDER ADDRESS DISK ADDRESS, BUS ADDRESS AND WORD COUNT. SEEK TO CYLINDER 632. ISSUE A WRITE CHECK OF 200000 WORDS. MAKE SURE NO ERROR SETS.

NOTE: THIS TEST IS EXECUTED ONLY IF NO BAD SECTORS ARE PRESENT IN THE FIRST 256 SECTORS ON THE PACK.

CYLINDER 1456 IS USED FOR THE RK07.

TEST 74 CONTROLLER TIME OUT

SEEK TO CYLINDER 632. ISSUE A RECALIBRATE AND DO NOT WAIT FOR SECOND INTERRUPT. NOW ISSUE A READ HEADER OF CYLINDER O, TRACK O. MAKE SURE CONTROLLER TIME GUT SETS.

CYLINDER 1456 IS USED FOR THE RKO7.

TEST 75 LIMIT DETECT ON DATA TRANSFER

ISSUE A SUBSYSTEM CLEAR. ISSUE A RECALIBRATE. ISSUE

A SEEK TO CYLINDER 2 WITH BAD PARITY. ISSUE A DRIVE CLEAR. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER 1, TRACK 0, HEAD 0. SEEK INCOMPLETE BECAUSE OF OUTER

TEST 76 PROGRAMMING ERROR

ISSUE A SUBSYSTEM CLEAR. ISSUE A READ DATA OF 400 WORDS ON CYLINDER O, TRACK O, SECTOP O. DURING READ ISSUE A WRITE TO THE SPARE REGISTER. MAKE SURE PROGRAMMING ERROR SETS.

TEST 77 ECC HARD

ISSUE A SUBSYSTEM CLEAR. ISSUE A WRITE DATA WORDS CONSISTING OF 177777 TO CYLINDER O, TRACK O, SECTOR O. NOW WRITE ALL ZEROS TO CYLINDER O, TRACK O, SECTOR O. DURING WRITE ISSUE CONTROLLER CLEAR. MAKE SURE PROGRAMMING ERROR IS RESET. NOW ISSUE A READ DATA TO CYLINDER O, TRACK O, HEAD O AND AN ECC HARD ERROR SHOULD SET.

TEST 100 DRIVE TIMING ERROR

ISSUE A SUBSYSTEM CLEAR. SEEK TO CYLINDER 632. ISSUE A RECALIBRATE BUT DO NOT WAIT FOR SECOND INTERRUPT. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A READ HEADER OF CYLINDER O, TRACK O. CLOCK THROUGH SEEK AND DRIVE CLEAR MESSAGES. TURN OFF DIAGNOSTIC MODE. DRIVE TIMING ERROR SHOULD SET BECAUSE OF NO DATA TRANSISTIONS ON DATA LINE.

ERROR FORCING IN DRIVE *********

TEST 101 INITIALIZE CLEARING SACK

ISSUE A SUBSYSTEM CLEAR. SELECT AN AVAILABLE DRIVE.
ISSUE A SUBSYSTEM CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT COMMAND WITH MESSAGE ID = 3 AND DRIVE SELECTED = 0. CLOCK THROUGH PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE. MAKE SURE UNIT FIELD ERROR DOES NOT SET.

TEST 102 DRIVE OFF TRACK

ISSUE A SUBSYSTEM CLEAR. ISSUE A RECALIBRATE. OFFSET OF +1200 MICRO-INCHES. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A WRITE DATA OF 1 WORD TO CYLINDER O, TRACK O, SECTOR O. CLOCK THROUGH SEEK AND DRIVE CLEAR MESSAGES. TURN OFF DIAGNOSTIC MODE. DRIVE OFF TRACK SHOULD SET IN DRIVE. REPEAT FOR ALL AVAILIABLE DRIVES.

TEST 103 FILE UNSAFE

ISSUE A SUBSYSTEM CLEAR. ISSUE A RECLAIBRATE. ISSUE A READ HEAD OF CYLINDER O, TRACK O IN 24 SECTOR FORMAT. DO A SELECT COMMAND IN 26 SECTOR FORMAT. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A WRITE HEADER TO CYLINDER O, TRACK O, ONE WORD IN 26 SECTOR FORMAT. CLOCK THROUGH SEEK AND DRIVE CLEAR MESSAGES. SIMULATE INDEX PULSE. TURN OFF DIAGNOSTIC MODE. FILE UNSAFE SHOULD SET BECAUSE OF ATTEMPTING TO WRITE THROUGH SECTOR PULSE. REPEAT FOR ALL AVAILIABLE DRIVES.

TEST 104 DUMMY TEST FOR PREVIOUS TEST EXIT

THIS TEST IS PRESENT TO MAKE \$SW08TB TABLE HAVE AN ENTRY WHICH RELATES TO 'NEWDRY'. THIS IS NECESSARY IF AN ERROR OCCURS IN THE PRECEDING TEST AND THAT ERROR ABORTS THE TEST. IF THIS TEST WERE NOT PRESENT, THE PROGRAM WOULD SKIP THE 'NEWDRY' ROUTINE AND GO TO THE TEST FOLLOWING 'NEWDRY'.

IN ADDITION, THE DRIVE IS CLEARED AND THE HEADS ARE

ALLOWED TO RELOAD. THIS MUST BE DONE TO PREVENT UNEXPECTED INTERRUPTS FROM THE DRIVE BECOMING READY AT A LATER TIME.

**MULTI-DRIVE OPERATIONS

TEST 105 RESET ATTENTIONS WITH UNIBUS INIT

DO A RECALIBRATE ON ALL AVAILIABLE DRIVES. ISSUE A RESET. MAKE SURE ALL ATTENTION RESET.

TEST 106 RESET ATTENTIONS WITH SUBSYSTEM CLEAR

DO A RECALIBRATE ON ALL AVAILABLE DRIVES. ISSUE A SUBSYSTEM CLEAR. MAKE SURE ALL ATTENTIONS RESET.

TEST 107 SVAL AND ATTENTION FROM OTHER DRIVE

DO A RECALIBRATE ON ONE AVAILABLE DRIVE. DO A SELECT ON ANOTHER AVAILABLE DRIVE. MAKE SURE STATUS VALID IS SET. WAIT FOR SECOND INTERRUPT FROM RECALIBRATE MAKE SURE STATUS VALID REMAINS SET AND DRIVE STATUS CHANGE REMAINS RESET.

REPEAT FOR ALL COMBINATIONS OF TWO AVAILIABLE DRIVES.

NOTE: THIS TEST WILL ONLY BE DONE IF AT LEAST TWO DRIVES ARE AVAILABLE.

1045 1046

1048 1049 1050

1051

1053

1062 1063

1064 1065 1066

1067 1068

1069

1070

1071

1072

1081

1082

1083 1084

1085 1086 1087

1088 1089

TEST 110 OVERLAPPED OPERATIONS

DO A RECALIBRATE ON BOTH DRIVE A AND DRIVE B. ISSUE A SEEK ON DRIVE A TO CYLINDER 1. IMMEDIATELY ISSUE A WRITE DATA TO CYLINDER 100, TRACK 0, HEAD 0 ON DRIVE B. AT THE END OF THE DATA TRANSFER NO ERRORS SHOULD BE SET AND DRIVE A HAS ATTENTION SET.

REPEAT FOR ALL COMBINATIONS OF TWO DRIVES.

NOTE: IF ONLY ONE DRIVE IS AVAILABLE THE TEST WILL NOT BE DONE.

5.0 ERROR REPORTING

A DETAILED DESCRIPTION OF THE ERROR FORMATS AND REPORTS CONTENTS IS GIVEN HERE. THIS IS ESSENTIALLY THE SAME AS CAN BE FOUND IN THE LISTING COMMENTS UNDER THE ERROR POINTER TABLE.

ERROR POINTER TABLE:

THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR. THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.

NOTE1: IF \$ITEMB IS O THE ONLY PERTINENT DATA IS (\$ERRPC). NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS

EXPLAINED AS FOLLOWS:

EM ;; POINTS TO THE ERROR MESSAGE

DH ;; POINTS TO THE DATA HEADER

DT ;; POINTS TO THE DATA

DF ;; POINTS TO THE DATA

EM AND DH ARE ASCIZ DATA. EM IS ALWAYS A MESSAGE BUT DH CAN

BE A MESSAGE OR A SET OF COLUMN LABELS SPACED ACCROSS THE

PAGE, DT IS A STRING OF WORDS THAT POINT TO THE DATA TO BE TYPED, AND DF IS A STRING OF WORDS THAT TELL HOW THE DT WORDS ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED, FOR A PARTICULAR FORMAT, IT IS REPLACED WITH A ZERO. THE NORMAL USAGE OF THE ERROR TABLE IS TO HAVE A TABLE ENTRY FOR EACH ERROR MESSAGE THAT CAN OCCUR. IN THE INTEREST OF ECONOMICS OF CORE MEMORY, THIS PROGRAM USES THE ERROR TABLE IN A SIGHTLY DIFFERENT MANNER AS DESCRIBED BELOW.

THE ERROR TABLE ENTRIES MAKE UP A SET OF REPORT FORMATS THAT

1144

1145

ARE USED THROUGHOUT THE PROGRAM. WHEN AN ERROR IS TO BE REPORTED, THE TABLE ENTRY THAT PROVIDES THE DESIRED FORMAT IS CHOSEN FROM THE DEFINED SET. THE TABLE ENTRY CHOSEN IS THEN ALTERED BY CHANGING THE FIRST (AND POSSIBLY THE SECOND) WORD TO CONTAIN THE ADDRESS OF THE ASCIZ STRING THAT MAKES UP THE MESSAGE PORTION OF THE REPORT. THE DATA FIELDS FOR THAT ENTRY ARE NEVER CHANGED, NOR ARE THE COLUMN LABELS OR POSITIONS.

THE FORMAT THAT EACH TABLE ENTRY PROVIDES IS SHOWN BELOW WITH THE DEFINITION OF THE ENTRY. ALL DATA FIELDS ARE TYPED IN OCTAL.

RKASOF

T.ASOF

RKDCYL RKDA

T.DCYL T.DA

ERROR ITEM 1 (MESSAGE) TST NUM ERR PC DRIVE STESTN SERRPC DRVNUM

ERROR ITEM 2 (MESSAGE) (MESSAGE) TST NUM ERR PC DRIVE STESTN SERRPC DRVNUM RKCS1 RKCS2 RKER RKDS T.CS1 T.CS2 T.DS T.ER RKBA RKWC

ERROR ITEM 3 (MESSAGE) TST NUM ERR PC DRIVE

T.WC

T.BA

STESTN SERRPC DRVNUM RKCS2 T.CS2 RKCS1 RKER RKASOF RKDS RKMR1 T.CS1 T.DS T.ER T.ASF T.MR1

ERROR ITEMS 4,5,6, AND 7 ARE USED TO REPORT ERRORS THAT ARE THE RESULT OF A HARDWARE ERROR INDICATOR BEING SET WHEN NOT EXPECTED, NOT SET WHEN IT IS EXPECTED, OR BOTH. THE ERROR REPORT WILL CONTAIN (1) ALL THE ERRORS THAT WERE DETECTED, (2) ALL THE EXPECTED ERRORS THAT DID NOT OCCUR, OR (3) ALL THE EXPEDIED BUT NOT SET ERRORS AND THE UNEXPECTED BUT SET ERRORS.

THE MESSAGE ITSELF EXPLAINS THE CIRCUMSTANCE FOR THE REPORT. INCLUDED IN THE REPORT WILL BE ONE OR MORE OF THE FOLLOWING STATEMENTS:

"THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION:" "THE ABOVE ARE UNEXPECTED ERRORS SET IN OPERATION:"
"THE ABOVE ARE ERRORS SET IN OPERATION:"

PRECEEDING ANY ONE OF THESE LINES WILL BE ONE OR MORE LINES THAT SPECIFY THE EXACT ERROR. FOLLOWING THE LAST LINE WILL BE A LINE THAT IDENTIFIES THE OPERATION BEING PERFORMED.

CZ

1158

1159 1160

1161 1162 1163

1164 1165

1166

1167

1168

1169

1170

1171 1172

1173 1174

1175

1180

1181

1182 1183

1184 1185

1186

1187

1188

1189

1190

1191 1192

1193

1194

1195

1196

1197 1198 1199

1200

```
EXAMPLE:
1146
                                                  NON-EXISTANT DRIVE
1148
                                                  THE ABOVE ARE ERRORS SET IN OPERATION:
1149
                                                 DRIVE SELECT
1150
1151
                                                 (ADDITIONAL LINES OF INFORMATION)
1152
1153
                                                 THIS IS THE RESULT OF AN ERROR SET IN A SELECT OPERATION.
1154
1155
1156
1157
                                                 EXAMPLE:
```

NON-EXISTANT DRIVE THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION: DRIVE SELECT

(ADDITIONAL LINES OF INFORMATION)

THIS IS THE RESULT OF AN EXPECTED ERROR THAT DID NOT OCCUR, I.E. A NON-EXISTANT DRIVE WAS ADDRESSED BUT NED WAS NOT SET.

EXAMPLE: NON-EXISTANT MEMORY THE ABOVE ARE UNEXPECTED ERRORS SET IN OPERATION: UNIBUS PARITY ERROR THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION: WRITE DATA

(ADDITIONAL LINES OF INFORMATION)

THIS IS AN EXAMPLE OF NON-EXISTANT MEMORY BEING SET WHEN UNIBUS PARITY ERROR WAS EXPECTED.

ERROR ITEM 4 (DESCRIPTION OF ERROR) ERROR IN OPERATION (DESCRIPTION OF OPERATION) TST NUM ERR PC DRIVE STESTN SERRPC DRVNUM RKCS2 RKCS1 RKDS RKER RKASOF RKDCYL RKDA T.CS2 T.CS1 T.DS T.ER T.ASOF T.DCYL T.DA RKBA RKWC T.BA T.WA A00 B00 \$REG10 \$REG11 \$REG12 \$REG13 \$REG14 \$REG15 \$REG16 \$REG17

THE ERRORS REPORTED BY THIS FORMAT ARE: CONTROLLER DETECTED DRIVE BUS ERROR DRIVE DETECTED DRIVE BUS ERROR SEEK INCOMPLETE NON-EXECUTABLE DRIVE FUNCTION DRIVE TIMING ERROR DRIVE UNSAFE AC LOW SPINDLE SPEED LOSS DRIVE OFF TRACK

ILLEGAL DRIVE ADDRESS ERROR CYLINDER OVERFLOW DRIVE TYPE ERROR FORMAT ERROR WRITE LOCK ERROR

ERROR ITEM 5
THIS ENTRY IS THE SAME AS ITEM 4 WITH THE ADDITION OF A MESSAGE THAT FOLLOWS. THIS MESSAGE IS:

"ANY FIELD WITH ALL ONES MUST BE CONSIDERED INVALID"

THIS REPORT WILL BE PRINTED WHEN THE GATHERING OF DATA FOR ACCOMPLISHED WITHOUT ERROR.

ERROR ITEM 6

(DESCRIPTION OF ERROR)
ERROR IN OPERATION
(DESCRIPTION OF OPERATION)
IST NUM ERR PC DRIVE
\$TESTN \$ERRPC DRVNUM
RKCS1 RKCS2 RKDS RKER RKASOF RKDCYL RKDA
T.CS1 T.CS2 T.DS T.ER T.ASOF T.DCYL T.DA
RKBA RKWC
T.BA T.WC

THE ERRORS REPORTED BY THIS FORMAT ARE:
DATA CHECK
WRITE CHECK

ECC HARD
DATA LATE
OPERATION INCOMPLETE
HEADER VRC ERROR
BAD SECTOR ERROR

ERROR ITEM 7
(DESCRIPTION OF ERROR)
ERROR IN OPERATION
(DESCRIPTION OF OPERATION)
TST NUM ERR PC DRIVE
\$TESTN \$ERRPC DRVNUM
RKCS1 RKCS2 RKDS RKER RKASOF
T.CS1 T.CS2 T.DS T.ER T.ASOF

THE ERRORS REPORTED BY THIS FORMAT ARE:
NON-EXISTANT DRIVE
NON-EXISTANT MEMORY
CONTROLLER TIME OUT
UNIT FIELD ERROR
MULTIPLE DRIVE SELECT
PROGRAMMING ERROR
UNIBUS PARITY ERROR

CZ

```
ILLEGAL FUNCTION CODE
```

DESCRIPTON OF OPERATION CAN BE ANY COMMAND, EITHER LEGAL OR ILLEGAL.

ERROR ITEM 10

(DESCRIPTION OF ERROR)

ERROR AT COMPLETION OF OPERATION

(DESCRIPITON OF OPERATION)

TST NUM ERR PC DRIVE

\$TESTN ERRPC DRVNUM

EXPT IS

\$REG10 \$REG11

THE ERRORS REPORTED BY THIS FORMAT ARE SOFTWARE DETECTED BY COMPARING EXPECTED RESULTS WITH ACTUAL RESULTS. THE SPECIFIC ERRORS ARE:

WORD COUNT INCORRECT
BUS ADDRESS INCORRECT
CYLINDER ADDRESS INCORRECT
TRACK ADDRESS INCORRECT
SECTOR ADDRESS INCORRECT

ERROR ITEM 11

(ERROR INDICATOR OR STATUS BIT)

NOT SET AS A RESULT OF

(ANOTHER ERROR INDICATOR, STATUS BIT, OR OPERATION

TST NUM ERR PC DRIVE

\$TESTN \$ERRPC DRVNUM

RKCS1 RKCS2 RKDS RKER RKASOF RKMR1

T.CS1 T.CS2 T.DS T.ER T.ASOF T.MR1

ERROR ITEM 12 THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS:

"NOT RESET AS A RESULT OF"

ERROR ITEM 13
THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS:

"SET AS A RESULT OF"

ERROR ITEM 14
THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS:

"RESET AS A RESULT OF"

ERROR ITEM 15
(HEADER WORD MISCOMPARE) OR (DATA MISCOMPARE)
TST NUM ERR PC DRIVE
STESTN SERRPC DRVNUM
GOOD BAD WORD NUM
SREG10 SREG11 SREG12

ERROR ITEM 16
ADDITIONAL LINES OF GOOD, BAD, WORD NUM FOR ERROR 15.

.0 SUBROUTINES

IN THE INTEREST OF CONSERVING MEMORY, IT IS NECESSARY TO MAKE EXTENSIVE USE OF SUBROUTINES. HOWEVER, IN THE INTEREST OF PRESERVING CODE READABILITY, SUBROUTINE NAMING IS DESCRIPTIVE OF THE FUNCTION PERFORMED. THE SUBROUTINE FUNCTION IS KEPT SMALL AND IN GENERAL A SUBROUTINE ONLY PERFORMS ONE FUNCTION, I.E., LOAD THE RK611 REGISTER AND START AN OPERATION (TLOADRK) OR WAIT A SPECIFIED NUMBER OF MILLISECONDS FOR AN INTERRUPT (TWATNN WHERE NN VARIES FROM CALL TO CALL AND IS THE TIME TO WAIT). THE FOLLOWING IS A DESCRIPTION OF THE SUBROUTINES NOT PROVIDED BY SYSMAC:

LINE CLOCK CALIBRATE

WAITS FOR A LINE CLOCK INTERRUPT TO CALIBRATE THE INTERRUPTS TO A MEANINGFUL TIME VALUE. IN ADDITION IT PRESETS THE TIMENT IF THERE IS NO LINE CLOCK. TIMENT IS USED IN THE LINE CLOCK SIMULATOR.

CALL: JSR PC, CLKCAL

OPTION PRESENT TEST AND SETUP

THIS ROUTINE CHECKS IF THE MEMORU PARITY OPTION AND THE LINE CLOCK ARE ON THE SYSTEM. FLAGS ARE SET IF PRESENT; CLEARED OTHERWISE, AND THE APPROPRIATE INTERRUPT VECTORS ARE SET UP.

CALL: JSR PC, OPTIST

LINE CLOCK SIMULATION ROUTINE

THIS ROUTINE IS USED TO SIMULATE THE LINE CLOCK. TO DO THIS THE VALUE STORED IN MILCNT IS USED AS THE BASE AND REPRESENTS THE NUMBER OF TIMES A DECREMENT AND BRANCH LOOP CAN BE DONE IN 1 MILLISECOND. THE TIMENT VALUE IS DECREMENTED AND IF IT REACHED O THE LINE CLOCK TICK COUNTER IS BUMPED. THEN THE TIMENT IS RESET TO 16 (REPRESENTS 16 MILLISECONDS PER LINE CLOCK TICK).

THUS THE ROUTINE RETURNS TO THE CALLER AFTER 1

1370 1371 1372 1373 1374 1375 1376 1377 1378 1381 1382 1383 1384 1385 1386 1387 1388 MILLISECOND AND BUMPS THE LINE CLOCK TICK COUNTER FOR EACH 16 CALLS. CALL: JSR PC MYTIME *********** WAIT FOR INTERRUFT ROUTINE THE ROUTINE IS ENTERED BY ONE OF FOURTEEN TRAP CALLS. THE CALL SPECIFIES HOW MANY TICKS OF THE LINE CLOCK ARE TO ELAPSE WHILE WAITING FOR INTERRUPT. IF INTERRUPT DOES NOT OCCUR IN THAT PERIOD OF TIME, AN ERROR MESSAGE IS PREPARED (BUT NOT PRINTED IN THE ROUTINE) AND THEN RETURNS TO THE LOCATION FOLLOWING THE CALL. IF INTERRUPT OCCURS THE RETURN IS BUMPED BY 2. NORMALLY AN ERROR CALL WILL BE IN THE LOCATION AFTER THE CALL TO INTERRUPT WAIT. 1389 1390 CALL: TWAT16 THROUGH TWAT159, TWAT1S, TWAT2S, TWATES, AND TWATIM 1391 1392 1393 1394 1395 1396 1397 1398 "L" REGISTER LOADING ROUTINE THE PARAMETERS FOLLOWING THE CALL ARE TRANSFERRED INTO THE "L" REGISTERS L.CS1-L.DCYL. L.MR1 IS NOT LOADED IN THIS MANNER SINCE IT IS NOT COMMONLY LOADED FOR AN OPERATION. L.CS2 IS LOADED FROM DRVNUM. 1400 1401 1402 R4. LRI TAD CALL: 1404 COMMAND 1405 WORD COUN" 1406 BUS ADDRE -1407 .BYTE SECTOR ADDRESS .BYTE TRACK ADDRESS 1408 1409 CYLINDER ADDRESS 1410 1411 *********** 1412 1413 LOAD RK611 FOR OPERATION ************************************** 1414 THE REGISTER SETUP STORAGE IS TRANSFERRED TO THE RK611 REGISTER. THIS IS A STRAIGHT TRANSFER WITH NO CHECKING OR MANIPULATION OF THE REGISTER CONTENTS. 1415 1416 1417 1418 1419 1420 1421 1422 1423 1424 1425 L.CS1 IS TRANSFERRED LAST AS IT SHOULD BE IF THE GO BIT IS SET. CALL: TLOADRK STORE RK611 REGISTERS

CZ

ALL THE RK611 REGISTERS ARE STORED IN THE TEST TABLE TWITH THE EXCEPTION OF THE DATA BUFFER WHICH IS NOT STORED IN THIS ROUTINE.

CALL: TGETRK

BIT COUNTER IN A WORD

THE WORD WHOSE BITS MUST BE COUNTED IS PLACED ON THE STACK BY THE CALLING ROUTINE. THE NUMBER OF BITS FOUND IN THE WORD ARE PASSED BACK ON THE STACK.

CALL: JSR R4, BITCHT

MAINTENANCE CLOCK ROUTINE

THE PARAMETERS PASSED TO THIS ROUTINE ARE LOCATED IN THE ADDRESS AFTER THE CALL. THE FIRST BYTE CANTAINS THE NUMBER OF PHASES ADDRESSES THE CALLING ROUTINE WANTS THE CONTROLLER CLOCKED THROUGH AND THE SECOND BYTE CONTAINS THE NUMBER OF CLOCK TRANSITIONS (PARTIAL PHASES) TO BE DONE.

CALL: JSR R4, MCLOCK

.BYTE

; NUMBER OF CLOCK TRANSISTIONS

.BYTE

:NUMBER OF PHASE ADDRESSES

READ AND SORT HEADERS

THE HEADERS IN THE CYLINDER AND TRACK SPECIFIED BY THE FIELDS IN THE "L" REGISTERS ARE READ AND STORED IN ASSCENDING ORDER. CONTROLLER ERRORS ARE CHECKED IN THE READ HEADER OPERATION AND DATA LATE IS CHECKED AFTER EACH READ OF THE DATA BUFFER.

CALL: JSR R4, RDSTHD

TCHKOP :

RETURN POINT IF CERR IN READ

HDR OR 5

ERROR 4 : OR 5, 6, 7

ERROR 13 : RETURN IF DATA LATE IN DB

:UNLOAD

ERROR 2 :RETURN IF TO SLOW OR :IF HDR O NOT FOUND

GET DRIVE STATUS

1482 1483 THIS ROUTINE GETS ALL THE DRIVE STATUS AND PLACES IT IN \$REG10 THROUGH \$REG17. THESE REGISTORS ARE FIRST CLEARED TO ALL ONES AND THEN IF ERROR OCCURS WHILE GETTING STATUS, THE 1'S ARE LEFT IN THE REGISTERS. 1484 1486 1487 1488 1489 JSR R4.GETDRS CALL: 1490 BR ERROR PROCESSING ERROR RETURN 1491 BR NO ERROR PROCESSING GOOD RETURN 1492 ******************* 1494 SUBSYSTEM INITIALIZE AND INITIALIZE STATE TEST 1496 THE SUBSYSTEM IS INITIALIZED WITH A SUBSYSTEM CLEAR 1498 COMMAND. CERR AND DI ARE MONITORED FOR A SHORT PEIROD 1499 OF TIME DURING WHICH THEY SHOULD BOTH RESET. 1500 1501 IF THEY DO RESET, READY IS TESTED TO INSURE IF SETS. 1502 1503 IF ANY OF THESE THREE CONDITIONS ARE NOT MET AN 1504 APPROPRIATE ERROR MESSAGE IS PREPARED AND REPORTED 1505 WHEN THE ROUTINE RETURN TO THE CALL. IF EVERY THING 1506 IS GOOD, THE RETURN SKIPS OVER THE ERROR CALL AND TEST 1507 ABORT. 1508 1509 THE USUAL CALL TO THIS ROUTINE WILL BE FOLLOWED BY AN ERROR MESSAGE AND BRANCH TO END OF TEST. THIS IS DONE 1510 1511 BECAUSE FAILURE TO INITIALIZE CORRECTLY IS FATAL TO 1512 1513 1514 1515 1516 1517 THE TEST. CALL: TSSINIT 1518 1519 1520 1521 1522 1523 1524 1525 1526 1527 1528 1529 1530 WORD COUNT AT END OF OPERATION CHECK THIS ROUTINE COMPARES THE CONTENTS OF THE TEST STORAGE FOR THE WORD COUNT AGAINST THE SUPPLIED VALUE. IF UNEQUAL, THE ERROR FLAG (WCERR) IS SET IN GROUP 4 ERROR FLAGS (GRP4ER) R4, CHKWC CALL: JSR :EXPECTED WC VALUE . WORD 1531 1532 BUS ADDRESS AT END OF OPERATION CHECK 1533 1534 1535 THIS ROUTINE COMPUTES THE EXPECTED BUS ADDRESS AT THE 1536 1537 END OF A TRANSFER BY USING THE INITIAL BUS ADDRESS. ADDING IN THE INITIAL WORD COUNT, AND SUBTRACTING ANY

CZR6KG.P11

RESIDUAL WORD COUNT. IF THIS COMPUTED BA DOES NOT EQUAL THE CONTENTS OF RKBA AN ERROR FLAG (BAERR) IS SET IN GROUP 4 ERROR FIELD (GRP4ER)

IF BUS ADDRESS INCREMENT INHIBIT WAS SET, THE EXPECTED BUS ADDRESS IS THE STARTING BUS ADDRESS.

CALL: JSR R4.CHKBA

CYLINDER, TRACK, SECTOR TEST AT END OF OPERATION ************

> THIS ROUTINE CHECKS THAT THE CONTENTS OF THE RKDCYL AND RKDA ARE CORRECT FOR ANY SIZE DATA TRANSFER AT THE END OF THE OPERATION. THE CONTENTS OF THE LOAD REGISTER STORAGE ARE COUNTED ON TO HAVE THE INITIAL VALUES TO MAKE THE NECESSARY CALCULATION.

> ALL THREE VALUES ARE GENERATED AND STORED IN EXPECTED VALUES STORAGE EXPCYL, EXPTRK, EXPSEC. ALL 3 ARE CHECKED AND IF ONE OR MORE ARE WRONG, THE CORRESPONDING BIT IN THE ERROR FLAGS FIELD (GRP4ER) IS SET.

R4.CHKCTS CALL: JSR

OPERATION CHECK ROUTINE ************

> THIS IS WHERE ALL HARDWARE ERROR INDICATORS AND SOME SOFTWARE ERRORS ARE CHECKED. THE GENERAL PROCEDURE FLOW IS AS FOLLOWS: THE ROUTINE IS CALLED WITH A TRAP (TCHKOP). THE LOCATION FOLLOWING THE TRAP CALL WILL HAVE AN ERROR TRAP WHICH THE ROUTINE WILL BYPASS IF NO ERROR IS FOUND. IF AN ERROR IS DETECTED, THE ERROR TRAP CALL IS MODIFIED BY THIS ROUTINE SUCH THAT THE ERROR TABLE ITEM WILL BE THE PROPER ITEM FOR THE FORMAT REQUIRED BY THIS ERROR. THE ERROR TRAP WILL BE MADE EITHER ERROR 4.5.6. 7. OR 10. REFER TO THE ERROR ITEM TABLE FOR A DESCRIPTION OF THE FORMAT AND WHICH ERRORS ARE DISPLAYED IN WHAT FORMAT.

FOR NO EXPECTED ERRORS: CALL: TCHKOP

FOR EXPECTED ERRORS:

. WORD

. WORD

CALL: TCHKWE . WORD

: GROUP 1 EXPECTED ERRORS GROUP 2 EXPECTED ERRORS GROUP 3 EXPECTED ERRORS

WHERE EACH BIT IN THE THREE WORDS FOLLOWING THE CALL

1649

```
REPRESENT A SPECIFIC EPROR. THE BIT ASSIGNMENTS ARE
1595
                                                                                        GIVEN BELOW:
1596
1597
                                                                                                     GROUP 1 ERRORS:
1598
1599
                                                                                                     BIT 0 - CONTROLLER DETECTED DRIVE BUS
                                                                                                                  PARITY ERROR
1600
                                                                                                     BIT 1 - SEEK INCOMPLETE
                                                                                                     BIT 2 - NON-EXECUTABLE DRIVE FUNCTION
BIT 3 - DRIVE DETECTED DRIVE BUS PARITY ERROR
1601
1602
                                                                                                     BIT 4 - FORMAT ERROR
BIT 5 - DRIVE TYPE ERROR
1603
1604
                                                                                                     BIT 6 - AC LOW ERROR
BIT 7 - SPEED LOSS ERROR
BIT 8 - DRIVE OFF TRACK ERROR
BIT 9 - CYLINDER OVERFLOW ERROR
1605
1606
1607
1608
1609
                                                                                                     BIT 10 - ILLEGAL DISK ADDRESS ERROR
                                                                                                     BIT 11 - WRITE LOCK ERROR
BIT 12 - DRIVE TIMING ERROR
BIT 13 - NO CERR WITH OTHER ERROR SET ERROR
1610
1611
1612
1613
                                                                                                     BIT 14 - DRIVE UNSAFE ERROR
                                                                                                     BIT 15 - CERR BUT NO OTHER ERROR SET ERROR
1614
1615
1616
                                                                                                     GROUP 2 ERRORS:
1617
                                                                                                     BIT 0 - ECC HARD ERROR
                                                                                                     BIT 1 - DATA CHECK ERROR
BIT 2 - WRITE CHECK ERROR
BIT 3 - DATA LATE ERROR
1618
1619
1620
1621
1622
1623
                                                                                                     BIT 4 - OPERATION INCOMPLETE ERROR
                                                                                                     BIT 5 - HEADER VRC ERROR
                                                                                                     BIT 6 - BAD SECTOR ERROR
1624
1625
1626
1627
1628
1629
1530
                                                                                                     BROUP 2 ERRORS:
                                                                                                     BIT 0 - NON-EXISTAND DRIVE ERROR
                                                                                                     BIT 1 - CONTROLLER TIMEOUT ERROR
                                                                                                     BIT 2 - UNIT FIELD ERROR
BIT 3 - MULTIPLE DRIVE SELECT ERROR
BIT 4 - PROGRAMMING ERROR
1631
1632
1633
                                                                                                     BIT 5 - NON-EXISTANT MEMORY ERROR
1634
1635
                                                                                                     BIT 6 - UNIBUS PARITY ERROR
BIT 7 - ILLEGAL FUNTION ERROR
1636
1637
1638
                                                                           BAD SECTOR CHECK
1639
1640
1641
                                                                                        THE FIELD WHOSE ADDRESS IS IN THE LOCATION AFTER THE
                                                                                       CALL IS CHECKED TO SEE IF ANY SECTORS ARE LISTED THEREIN THAT HAVE THE CYLINDER AND TRACK ADDRESS SPECIFIED IN L.DCYL AND L.DT. IF A SECTOR IS FOUND IN THIS FIELD THAT IS BAD FOR THAT CYLINDER AND TRACK, THE SECTOR NUMBER IS PLACED ON THE STACK. THE TOTAL NUMBER OF BAD SECTORS IS PLACED ON THE STACK AFTER THE
1642
1644
1645
1646
1647
```

ENTIRE FIELD IS SEARCHED.

1652 1653 1654

1655

1656 1657

1658

1659 1660

1661

1662

1663 1664

1665

1666

1667

1668 1669

1670 1671

1672 1673

1674 1675

1676 1677

1678 1679 1680

1681 1682 1683

1684 1685

1691

1692 1693

1694

1695

1696

1697

1698

1699

1700

1701 1702 1703

1704

1705

```
CALL: JSR R4.BDSRCK
       <ADDRESS OF FIELD TO BE SEARCHED>
```

DATA GENERATION AND COMPARE ROUTINE **********

CALLS: JSR R4. GENCOM CONTROL WORD

> JSR R4, GENCOM CONTROL WORD LENGTH

JSR R4.GENCOM CONTROL WORD RELOCATION CONSTANT LENGTH

RETURN:

RTS R4

R4 IS ADJUSTED IN THE CODE FOR THE FOLLOWING RETURNS: THE FIRST CALL RETURNS TO THE LOCATION FOLLOWING THE CONTROL WORD. THIS IS UNCONDITIONAL.

THE SECOND CALL RETURNS TO THE LOCATION FOLLOWING THE LENGTH IF THE OPERATION REQUIRES DATA COMPARE AND DATA MISCOMPARED. IF DATA IS TO BE GENERATED ONLY OR NO DATA COMPARE ERRORS OCCURRED. THE RETURN IS TO LENGTH

THE THIRD CALL IS IDENTICAL TO THE SECOND.

DEFINITION OF CONTROL WORD:

| BIT 15 | - DO COMPARE OPERATION OF IBUFF (SOURCE) TO |
|--------|---|
| | OBUFF (DESTINATION). EXPECTED VALUES ARE |
| D | IN OBUFF (DESTINATION. |

- RESUME COMPARE OPERATION FROM POINT LEFT BIT 14 BY LAST COMPARE.

BIT 13 - INVOKE MEMORY MANAGEMENT FOR SOURCE (IBUFF).

BIT 12 - INVOKE MEMORY MANAGEMENT FOR DESTINATION (OBUFF).

- REPEAT FIRST WORD OF SELECTED PATTERN BIT 11 THROUGHOUT OBUFF.

- CLEAR IBUFF TO PATTERN SELECTED. BIT 10 BIT 9

- BUILD HEADERS, CONSIDERING BS FILES
- BUILD HEADERS, ALL SECTORS INDICATE GOOD BIT 8 SECTORS.

BIT 7 - HEADER OPERATION SPECIFIED (EITHER COMPARE OR BUILD).

BIT 6 TO 0 - PATTERN SELECT FIELD, OCTAL ENCODED. O INDICATES NO DATA GENERATION, 1 IS ALL

1714 1715 1716

1718

1719

1736 1737 1738

1739

1744

1755

1760 1761

ZEROS, AND 7 IS ALL ONES. OTHER PATTERNS PROVIDED ARE PATTERNS 2-6, 8-16. REFER TO THE PROGRAM LISTING FOR PATO2 THROUGH PAT16.

EXPLANATION OF CALLS: THE CALL WITH CONTROL WORD THE ONLY PARAMETER IS USED FOR BUILDING OR COMPARING HEADERS OR RESUMING A COMPARE OPERATION.

THE CALL WITH CONTROL WORD AND LENGTH AS PARAMETERS IS USED FOR DATA GENERATION CR COMPARE AND FOR IBUFF INITALIZATION.

THE CALL WITH CONTROL WORD, RELOCATION CONSTANT, AND LENGTH IS USED FOR DATA GENERATION OR COMPARE WITH MEMORY MANAGEMENT.

DESCRIPTION:

THIS ROUTINE IS MULTI-PURPOSE AND WILL PERFORM THE FOLLOWING:

- A. BUILD HEADERS, EITHER 20 OR 22 SECTORS/TRACK MODE. THE ROUTINE WILL BUILD THE HEADERS AS ALL GOOD SECTORS (BIT 8) OR TAKE THE BAD SECTOR FILES (HARDWARE OR SOFTWARE) FOR EITHER FORMAT) INTO ACCOUNT AND BUILD THE HEADERS WITH THE SECTORS MARKED BAD IF ANY SECTORS FOR THE CYLINDER - TRACK ARE LISTED THEREIN (BIT 9).
- B. COMPARE THE CONTENTS OF IBUFF AND OBUFF (BIT 15). THE CONTENTS OF THE BUFFER MAY BE HEADERS OR DATA. A HEADER COMPARE OPERATION MAY BE SPECIFIED (BIT 7) WHICH WILL CAUSE THE COMPARE TO BE LIMITED TO 74(8) OR 102(8) WORDS OF HEADERS. THE LENGTH DEPENDS ON THE FORMAT BIT THAT WAS LAST SPECIFIED IN L.CS1. THE HEADERS MAY BE BUILT BEFORE THE COMPARE AS PART OF THE OPERATION (BIT 15 AND BIT 8 OR 9). DATA CAN ALSO BE GENERATED BEFORE THE COMPARE (NON-ZERO BITS 6-0).
- RESUME COMPARE OPERATION. IF A COMPARE OPERATION DETECTS A MISCOMPARE, THE ROUTINE RETURNS TO CALLER BUT STORES PARAMETERS SUCH THAT THE COMPARE CAN BE RESUMED. THIS IS DONE BY CALLING GENCOM WITH BIT 14 SET IN THE CONTROL WORD.
- DATA GENERATION OR COMPARE USING MANAGEMENT. MEMORY MANAGEMENT CAN BE INVOKED FOR EITHER SOURCE OR DESTINATION BUT NOT FOR BOTH. IN THIS MANNER, DATA GENERATION CAN BE MADE TO PLACE DATA ANYWHERE IN AVAILABLE MEMORY. LIKEWISE DATA COMPARE WILL COMPARE THE CONTENTS OF TBUFF TO ANY

| CZR6KG.P11 28-AUG-81 15:16 | 10-AUG-01 17:17 PAGE 34 |
|----------------------------|--|
| 1762 1763 | AREA OF AVAILABLE MEMORY. |
| 1764 | *********************** |
| 1765 1766 PH | ASE LOCKED LOOP CLOCK ADJUSTMENT ROUTINE |
| 1767 | ***************** |
| 1768 | THIS ROUTINE IS ENTERED VIA START LOCATION 220(8). |
| 1769 1770 | THE PROGRAM FIRST RUNS TEST 1, 2, AND 3 TO SET UP THE |
| 1771 | INTERNAL PROGRAM VARIABLES AND THEN JUMPS TO THE CLOCK ADJUST ROUTINE. THE ROUTINE SELECTS THE FIRST |
| 1772 | AVAILABLE DRIVE AND SETS AND RESETS THE DIAGNOSTIC |
| 1773 1774 | MODE BIT IN RKMR1. INSTRUCTIONS ON WHERE TO SCOPE AND |
| 1775 | WHAT TO ADJUST ARE TYPED ON THE CONSOLE. |
| 1776 | THIS ROUTINE WILL LOOP UNTIL THE PROCESSOR IS HALTED. |
| 1777 1778 | |
| 1779 7.0 RF | VISION HISTORY |
| 1780 | |
| 1781 1782 | REVFO 1) ADD CODE IN PROGRAM INITIALIZATION TO |
| 1783 | CLEAR DATA BUFFER MEMORY LOCATIONS 2) MODIFY CHAIN MODE LOOP ADDRESS IN SEOP |
| 1784 | FOR XXDP+ COMPATIBILITY |
| 1785 1786 | 3) MODIFY 'OPTIST' ROUTINE TO SUPPORT NEW |
| 1787 | PROCESSOR AND MEMORY OPTIONS |

```
*** REV 007 ***
1789
1790
                                            .NLIST
                                                    CND, MD, MC, TOC
1791
                                           .LIST
                                                     ME
1792
                                            .ENABL
                                                     ABS, AMA
1793
                167400
                                           $SWR=
                                                     167400
1794
                000001
                                           STN=
                                           .TITLE CZR6KGO RK6 FCTNL CTRL DIAG
:*COPYRIGHT (C) 1976,1981
1795
1796
1797
                                            *DIGITAL EQUIPMENT CORP.
1798
                                            *MAYNARD, MASS. 01754
1799
1800
1801
                                           : * THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
1802
                                            *PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
1803
1804
                                            SBITL OPERATIONAL SWITCH SETTINGS
1805
1806
                                                     SWITCH
                                                                                USE
1807
                                                     -----
1808
                                                       15
                                                                       HALT ON ERROR
1809
                                                                       LOOP ON TEST
1810
                                                       13
                                                                       INHIBIT ERROR TYPEOUTS
1811
                                                       12
                                                                       ABORT PROGRAM AFIER 20 ERRORS
1812
                                                       11
                                                                       INHIBIT ITERATIONS
1813
                                                       10
                                                                       BELL ON ERROR
1814
                                                                       LOOP ON ERROR
1815
                                                                       LOOP ON TEST IN SWR<7:0>
1816
                                            . SBITL
                                                     BASIC DEFINITIONS
1817
1818
                                            :*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
                                           STACK= 1100
1819
                001100
1820
1821
1822
1823
                                           .EQUIV EMT , ERROR
                                                                       :: BASIC DEFINITION OF ERROR CALL
:: BASIC DEFINITION OF SCOPE CALL
                                            .EQUIV IOT, SCOPE
                                           : *MISCELLANEOUS DEFINITIONS
1824
                                                                       :: CODE FOR HORIZONTAL TAB
                000011
                                           HT=
1825
                000012
                                                     12
                                           LF=
                                                                       :: CODE FOR LINE FEED
1826
1827
1828
1829
1830
                000015
                                           CR=
                                                                       :: CODE FOR CARRIAGE RETURN
                000200
                                                                       :: CODE FOR CARRIAGE RETURN-LINE FEED
                                           CRLF=
                                                     200
                                                     177776
                                           PS=
                                                                       :: PROCESSOR STATUS WORD
                                           .EQUIV PS.PSW
STKLMT= 177774
                177774
                                                                       ::STACK LIMIT REGISTER
1831
                177772
                                           PIRQ=
                                                    177772
                                                                       :: PROGRAM INTERRUPT REQUEST REGISTER
1832
1833
                177570
                                           DSWR=
                                                    177570
                                                                       ;; HARDWARE SWITCH REGISTER
                177570
                                           DDISP= 177570
                                                                       : : HARDWARE DISPLAY REGISTER
1834
1835
                                            : *GENERAL PURPOSE REGISTER DEFINITIONS
1836
                                           RO=
                000000
                                                                       :: GENERAL REGISTER
                                                     20
1837
                000001
                                           R1=
                                                     21
                                                                       ;; GENERAL REGISTER
1838
                000002
                                           R2=
R3=
                                                    %2
%3
                                                                       :: GENERAL REGISTER
1839
                000003
                                                                       :: GENERAL REGISTER
1840
                000004
                                           R4=
                                                                       :: GENERAL REGISTER
1841
                000005
                                           R5=
                                                                       :: GENERAL REGISTER
1842
1843
                                                    %6
                000006
                                                                       GENERAL REGISTER
                                           R6=
                000007
                                                                       :: GENERAL REGISTER
```

| CZR6KG.P11 | 28-AUG-81 15:16 | BASIC DEFINITIONS | |
|--|--|---|---|
| 1844 1845 1846 | 000006 000007 | SP= %6 PC= %7 | ::STACK POINTER ::PROGRAM COUNTER |
| 1847 1848 1849 1850 1851 1852 | 000000 000040 000100 000140 000200 000240 000300 000340 | :*PRIORITY LEVEL DEPRO= 0 PR1= 40 PR2= 100 PR3= 140 PR4= 200 PR5= 240 PR6= 300 PR7= 340 | FINITIONS ::PRIORITY LEVEL 0 ::PRIORITY LEVEL 1 ::PRIORITY LEVEL 2 ::PRIORITY LEVEL 3 ::PRIORITY LEVEL 4 ::PRIORITY LEVEL 5 ::PRIORITY LEVEL 6 ::PRIORITY LEVEL 7 |
| 1854 1855 1856 1857 1858 1859 1860 1861 1862 1863 1864 1865 1865 1866 1867 1873 1874 1875 1876 1877 1878 1879 1881 1882 1883 | 100000 040000 020000 010000 004000 001000 000400 000200 000100 000040 000020 000010 000004 000002 000001 | ;*'SWITCH REGISTER' SW15= 100000 SW14= 40000 SW13= 20000 SW12= 10000 SW12= 10000 SW10= 2000 SW09= 1000 SW09= 1000 SW08= 400 SW07= 200 SW06= 100 SW05= 40 SW07= 20 SW01= 2 SW00= 1 -EQUIV SW09, SW9 -EQUIV SW09, SW9 -EQUIV SW07, SW7 -EQUIV SW06, SW6 -EQUIV SW07, SW7 -EQUIV SW06, SW6 -EQUIV SW06, SW6 -EQUIV SW06, SW6 -EQUIV SW07, SW7 -EQUIV SW01, SW1 -EQUIV SW00, SW0 | SWITCH DEFINITIONS |
| 1881 1882 1883 1884 1885 1886 1887 1888 1889 1890 1891 1892 1893 1894 1895 1896 1897 1898 1899 | 100000 040000 020000 010000 004000 002000 001000 000400 000200 000100 000040 000020 000010 000004 | :*DATA BIT DEFINITION BIT15= 100000 BIT14= 40000 BIT13= 20000 BIT12= 10000 BIT10= 2000 BIT10= 2000 BIT09= 1000 BIT08= 400 BIT07= 200 BIT06= 100 BIT06= 100 BIT05= 40 | ONS (BITOO TO BIT15) |

CZR6KGO RK6 FCTNL CTRL DIAG

```
CZR6KG.P11
               28-AUG-81 15:16
                                             BASIC DEFINITIONS
                  000002
                                              BIT01= 2
  1901
                                              BIT00= 1
                                              .EQUIV BITO9,BIT9
 1902
                                              .EQUIV BITO8,BIT8
                                                      BITO7,BIT7
  1904
                                              .EQUIV
  1905
                                              .EQUIV
                                                      BIT06, BIT6
                                                      BIT05, BIT5
  1906
                                              .EQUIV
  1907
                                                      BIT04, BIT4
                                              .EQUIV
  1908
                                                      BITO3,BIT3
                                              . EQUIV
                                                     BIT02,BIT2
BIT01,BIT1
  1909
                                              .EQUIV
  1910
                                              .EQUIV
                                              .EQUIV BITOO,BITO
  1911
  1912
1913
                                              :*BASIC "CPU" TRAP VECTOR ADDRESSES
                                             ERRVEC = 4
                                                                         :: TIME OUT AND OTHER ERRORS
  1914
                  000004
                                                                         :: RESERVED AND ILLEGAL INSTRUCTIONS
                  000010
  1915
                                              RESVEC= 10
  1916
                  000014
                                              TBITVEC=14
  1917
                  000014
                                              TRTVEC= 14
                                                                         :: TRACE TRAP
                                                                         :: BREAKPOINT TRAP (BPT)
  1918
                  000014
                                              BPTVEC= 14
                                                                          :: INPUT/OUTPUT TRAP (IOT) **SCOPE **
                                              IOTVEC= 20
  1919
                  000020
                                             PWRVEC= 24
  1920
                  000024
                                                                          :: POWER FAIL
                                             EMTVEC = 30
                                                                         ::EMULATOR TRAP (EMT) **ERROR**
::'TRAP'' TRAP
::TTY KEYBOARD VECTOR
  1921
                  000030
  1922
1923
                  000034
                                              TRAPVEC=34
                                              TKVEC= 60
                  000060
  1924
                  000064
                                              TPVEC= 64
                                                                         ::TTY PRINTER VECTOR
  1925
1926
1927
                                                                          :: PROGRAM INTERRUPT REQUEST VECTOR
                  000240
                                              PIRQVEC=240
                                              .SBITL MEMORY MANAGEMENT DEFINITIONS
  1928
1929
1930
                                              :*KT11 VECTOR ADDRESS
                  000250
                                              MMVEC= 250
  1931
  1932
1933
                                              :*KT11 STATUS REGISTER ADDRESSES
  1934
                  177572
                                              SRO=
                                                       177572
  1935
                  177574
                                              SR1=
                                                       177574
  1936
                  177576
                                                       177576
                                              SR2=
  1937
                  172516
                                              SR3=
                                                       172516
  1938
  1939
                                              :*KERNEL "I" PAGE DESCRIPTOR REGISTERS
  1940
  1941
                  172300
                                              KIPDRU= 172300
  1942
1943
                  172302
172304
                                              KIPDR1= 172302
                                              KIPDR2= 172304
                  172306
  1944
                                              KIPDR3= 172306
  1945
                  172310
                                              KIPDR4= 172310
                  172312
172314
172316
                                             KIPDR5= 172312
KIPDR6= 172314
  1946
  1947
  1948
                                              KIPDR7= 172316
  1949
  1950
                                              : *KERNEL "I" PAGE ADDRESS REGISTERS
  1951
  1952
                  172340
                                              KIPARO= 172340
  1953
                  172342
                                              KIPAR1= 172342
  1954
                  172344
                                              KIPAR2= 172344
  1955
                  172346
                                              KIPAR3= 172346
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 38
CZR6KGO RK6 FCTNL CTRL DIAG
                                                 MEMORY MANAGEMENT DEFINITIONS
CZR6KG.P11
                28-AUG-81 15:16
                   172350
172352
172354
                                                 KIPAR4= 172350
KIPAR5= 172352
  1957
                                                 KIPAR6= 172354
  1958
                                                 KIPAR7= 172356
  1959
  1960
                   000210
000240
177440
                                                                                         :DEFINE RK611 VECTOR INTERRUPT :DEFINE RK611 PRIORITY
                                                 AVECT1= 210
APRIOR= PR5
  1961
  1962
1963
                                                 ABASE = 177440
                                                                                         : DEFINE RK611 BASE BUS ADDRESS
  1964
  1965
                                                 .SBITL RK611 CONTROLLER REGISTER DEFINITION
  1966
  1967
                   000000
                                                 RKCS1=
                                                                                         CONTROL AND STATUS REGISTER 1
  1968
                   000002
                                                 RKWC=
                                                                                         :WORD COUNT REGISTER
  1969
1970
1971
1972
1973
                   000004
                                                                                         BUS ADDRESS REGISTER
                                                 RKBA=
                                                                                         ; DESIRED TRACK SECTOR REGISTER
; CONTROL AND STATUS REGISTER 2
; DRIVE STATUS REGISTER
; ERROR REGISTER
                                                 RKDA=
                                                 RKCS2=
                   000010
                   000012
                                                 RKDS=
                   000014
                                                 RKER=
  1974
                   000016
                                                 RKASOF = 16
                                                                                         :ATTENTION SUMMARY AND OFFSET REGISTER
                                                 RKDCYL = 20
RKDB = 24
  1975
                                                                                         :DESIRED CYLINDER REGISTER
                   000020
                   000024
                                                                                         : DATA BUFFER
  1976
  1977
                                                 RKMR1=
                                                                                         :MAINTENANCE REGISTER 1
                   000026
                                                 RKMR2=
                                                                                         :MAINTENANCE REGISTER 2
  1978
                   000034
                                                                                         :MAINTENANCE REGISTER 3
  1979
                   000036
                                                 RKMR3=
                                                 RKECPS= 30
                   000030
  1980
                                                                                         :ECC POSITION INFORMATION
                                                 RKECPT = 32
RKSPAR = 22
  1981
                   000032
                                                                                         :ECC PATTERN INFORMATION
  1982
                   000022
                                                                                         :SPARE REGISTER
  1983
  1984
                                                 .SBITL DRIVE COMMANDS
  1985
                                                                                         :SELECT DRIVE
:PACK ACKNOWLEDGE
  1986
                   000101
                                                 SELDRV= 101
  1987
                   000103
                                                 PACK=
                                                           103
  1988
                                                                                         :DRIVE CLEAR
                   000105
                                                           105
                                                 CLEAR=
                                                 UNLOAD= 107
SRTSPL= 111
RECAL= 113
  1989
                                                                                         :UNLOAD
                   000107
  1990
                                                                                         START SPINDLE
                   000111
  1991
                   000113
                                                                                         : RECALIBRATE
                                                 OFFSET= 115
  1492
                   000115
                                                                                         :OFFSET
                                                 SEEK= 117
  1,93
                   000117
                                                                                         : SEEK
  1994
                   000121
                                                 RDDATA= 121
                                                                                         : READ DATA
  1995
                   000123
                                                 WRDATA= 123
                                                                                         : WRITE DATA
  1996
                   000125
                                                 RDHEAD= 125
                                                                                         :READ HEADER
  1997
                   000127
                                                 WRHEAD= 127
                                                                                         ; WRITE HEADER AND DATA
                   000131
  1998
                                                 WRTCHK= 131
                                                                                         :WRITE CHECK
  1999
                   000300
                                                                                         GENERATE INTERRUPT TO CPU
                                                 INTR=
                                                           300
  2000
  2001
2002
2003
                                                 .SBITL CONTROL AND STATUS REGISTER 1 BITS
                    000001
                                                                                         : GO BIT
  2004
2005
2006
2007
2008
2009
2010
2011
                    000100
                                                 IE=
                                                           BIT6
                                                                                         :INTERRUPT ENABLE
                                                                                         CONTROLLER READY
                   000200
                                                           BIT7
                                                 RDY=
                                                                                         BUS ADDRESS BIT 16
BUS ADDRESS BIT 17
CONTROLLER DRIVE TYPE (0=RK06)
                   000400
                                                 BA16=
BA17=
                                                           BIT8
                   001000
                                                           BIT9
                    002000
                                                 CDT=
                                                           BIT10
                    004000
                                                 CTO=
                                                           BIT11
                                                                                         CONTROLLER TIMED OUT WAITING FOR
                                                                                          : DRIVE RESPONSE
```

010000

CFMT=

BIT12

CONTROLLER DRIVE FORMAT (0=26 SECTOR, 1=24 SECTOR)

| CZR6KGO RK6 CZR6KG.P11 | FCTNL CTRL DIAG 28-AUG-81 15:16 | MACY11 | 30(1046) CONTROL | | 15:17 PAGE REGISTER 1 BI | |
|--|--|--------|---|--|-----------------------------|--|
| 2012 2013 2014 2015 2016 | 020000 040000 100000 100000 | | SPAR= DI= CERR= CCLR= | BIT13 BIT14 BIT15 BIT15 | | :DRIVE BU :DRIVE IN :CONTROLL :CONTROLL |
| 2017 2018 2019 2020 2021 2022 2023 | 000007 000010 000020 000040 000100 | | .SBTTL DRVMSK= RLS= RLS= BAI= SCLR= IR= | 7 B113 B114 B115 B116 | | :MASK FOR :DESELECT :BUS ADDR :CLEAR CO :INPUT RE |
| 2024 2025 2026 2027 2028 2029 2030 | 000200 000400 001000 002000 004000 010000 920000 | | OR= UFE= MDS= PGE= NEM= NED= UPE= | BIT7 BIT8 BIT9 BIT10 BIT11 BIT12 BIT13 | | OUTPUT R UNIT FIE MULTIPLE PROGRAMM NON-EXIS NON-EXIS UNIBUS P |

ILF=

BITO

040000

100000

000001

000002

000004

000010

000020

000040

000100

000200

000400

001000

002000

004000

010000

020000

040000

100000

000001

000004

000010

000020

000040

000100

000200

000400

004000

020000

040000

100000

2031

2032

2033 2034

2044

2045

2046

2047

2048

2065

SEQ 0038 SUS PARITY ERROR DETECTED BY CONTROLLER

NTERRUPT CONTROLLER ERROR LERR= BI 115 CCLR=

DRVMSK= 7 MASK FOR DRIVE SELECTION CODE :DESELECT OR RELEASE DRIVE IN BITS 0-2 BIT3 RLS= BAI= **BIT4** BUS ADDRESS INCREMENT INHIBIT CLEAR CONTROLLER AND ALL DRIVES SCLR= BIT5 IR= BIT6 : INPUT READY OUTPUT READY OR= BIT7 UFE= BI18 BIT9 MDS= :MULTIPLE DRIVE SELECT PGE= BIT10 : PROGRAMMING ERROR :NON-EXISTENT MEMORY :NON-EXISTENT DRIVE NEM= BIT11 NED= BIT12 :UNIBUS PARITY ERROR :WRITE CHECK ERROR ;DATA LATE ERROR BIT13 UPE= WCE= BIT14 DLT= BIT15

.SBTTL ERROR REGISTER BIT DEFINITION

SKI= BIT1 SEEK INCOMPLETE NXF= BIT2 :NON-EXECUTABLE DRIVE FUNCTION DRPAR= BIT3 DRIVE DETECTED DRIVE BUS PARITY ERROR FMTE = : FORMAT ERROR BIT4 DTYE= :DRIVE TYPE ERROR BIT5 ECH= BIT6 : ECC HARD BSE= BIT7 ;BAD SECTOR ERROR HVRC= BIT8 :HEADER VRC ERRROR BIT9 COE = CYLINDER ADDRESS OVERFLOW ERROR IDAE= BIT10 ; INVALID DISK ADDRESS ERROR :WRITE LOCK ERROR :DRIVE TIMING ERROR :OPERATION (SEARCH) INCOMPLETE WLE= BIT11 DTE= BIT12 OPI= **BIT13** :DRIVE UNSAFE UNS= **BIT14** DCK= **BIT15** : DATA CHECK .SBTTL STATUS REGISTER BIT DEFINITION

; ILLEGAL FUNCTION CODE

DRA= BITO DRIVE AVAILABLE (CONTROLLER IS SET IF : THIS BIT IS RESET) BIT2 BIT3 OFST= : DRIVE OFFSET ACLO= :AC LOW SPDLSS= BIT4 :SPEED LOSS DROT= BIT5 :DRIVE OFF TRACK : VOLUME VALID VV= **BI16** DRDY= BIT7 : DRIVE READY :DRIVE TYPE (0=RKO6) DDT= BIT8 WRL= BIT11 :WRITE LOCK PIP= BIT13 ; POSITIONING IN PROGRESS DSC= BIT14 : DRIVE STATUS CHANGE SVAL= BIT15 :STATUS VALID

| CEMONOSITI | 20 400 01 13110 | 517105 | | |
|--|--|--|--|--|
| 2068 2069 2070 | | .SBTTL | MAINTENANCE RE | GISTER 1 BIT DEFINITION |
| 2069 2070 2071 2072 | 000017 | MESMSK= | 17 | ;MESSAGE MASK |
| 2072 2073 2074 2075 2076 2077 2078 2079 2080 2081 2082 2083 2084 2085 2086 | C00020 000040 000100 000200 000400 001000 002000 004000 010000 020000 040000 040000 | PAT = DMD = MSP = MIND = MCLK = MERD = MEWD = PCA = PCD = ECCW = WRIGAT = RDGATE = | | ; FORCE EVEN PARITY ON SERCON MESSAGE LINES ; DIAGNOSTIC MODE ; MAINTENANCE SECTOR PULSE ; MAINTENANCE INDEX ; MAINTENANCE CLOCK ; MAINTENANCE ENCODED READ DATA ; MAINTENACNE ENCODED WRITE DATA ; PRECOMPENSATION ADVANCE ; PRECOMPENSATION DELAY ; ECC WORD IS BEING READ OR WRITTEN ; WRITE GATE ; READ GATE |
| 2086 | | .SBTTL | DEFINITION OF | DRIVE STATUS BYTE OO MESSAGE A |
| 2087 2088 2089 2090 2091 2092 2093 2094 2095 2096 2097 2098 | 000040 000100 000200 000400 001000 002000 004000 010000 020000 040000 | S.VV= S.DRY= S.TYPE= S.FORM= S.OFF= S.WRL= S.SPIN= S.PIP= | BIT10 BIT11 BIT12 | ; DRIVE AVAILIABLE ; VOLUME VALID ; DRIVE READY ; DRIVE TYPE ; DRIVE FORMAT ; OFFSET ; WRITE LOCK ; SPINDLE ON ; POSITIONING IN PROGRESS ; DRIVE STATUS CHANGE |
| 2099 | | .SBTTL | DEFINITION OF | DRIVE STATUS BYTE 00 MESSAGE B |
| 2100 2101 2102 2103 2104 2105 2106 2107 2108 2109 2110 | 000040 000100 000200 000400 001000 002000 004000 010000 020000 040000 | | BIT6 BIT7 BIT8 BIT9 BIT10 BIT11 BIT12 BIT13 | :ILLEGAL CYLINDER ADDRESS ;AC LOW ;DRIVE FAULT ;ILLEGAL FUNCTION ;DRIVE DETECTED SERCON PARITY ERROR ;SEEK INCOMPLETE ;WRITE LOCK ERROR ;SPEED LOSS ;DRIVE OFF TRACK ;DRIVE UNSAFE |
| 2111 | | .SBTTL | DEFINITION OF | DRIVE STATUS BYTE 01 MESSAGE A |
| 2113 2114 2115 2116 2117 2118 2119 2120 2121 2122 2123 | 000020 000040 000100 000200 000400 001000 002000 004000 010000 020000 | S.REV= S.LOAD= | BIT5 BIT6 BIT7 BIT8 BIT9 BIT10 BIT11 | TRANSDUCER OK HEADS HOME BRUSHES HOME COR INTERLOCKED CARTRAGE INTERLOCK SPEED OK FORWARD REVERSE HEADS LOADING RETURN TO ZERO |

```
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11
                                               DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE A
                28-AUG-81 15:16
                   040000
                                               S.UNLD= BIT14
                                                                                     :HEADS UNLOADING
  2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2138
2139
2140
                                               .SBITL DEFINITION OF DRIVE STATUS BYTE 01 MESSAGE B
                                                                                      :SECTOR ERROR
:WRITE CLOCK AND NO WRITE GATE
                                               S.SECT= BIT4
                   000020
                   000040
                                               S.WCLK= BIT5
                   000100
                                                                                      :WRITE GATE AND NO TRANSISTIONS
                                               S. WGAT = BIT6
                   000200
                                               S.HDFL= BIT7
                                                                                      :HEAD FAULT
                   000400
                                               S.MHD= BIT8
                                                                                     :MULTIPLE HEAD SELECT
                   001000
                                               S. XERR= BIT9
                                                                                     : INDEX ERROR
                                                                                     :DIBIT ERROR
                   002000
                                               S.DIB= BIT10
                   004000
                                               S.PLO= BIT11
                                                                                     :PLO ERROR
                   010000
                                               S.NMOV= BIT12
                                                                                     :SEEK AND NO MOTION
                   020000
                                               S.LIMD= BIT13
                                                                                     :LIMIT DETECT ON SEEK
                                                                                     : SERVO-BRAKE
                   040000
                                               S.BRKE = BIT14
                                               .SBITL COMMON MASKS
                                               M. DRV=
                   000007
                                                                                      :DRIVE CODE
                   100000
                                               M.PAR= BIT15
                                                                                      : PARITY
                  000003
017760
                                                                                     :BYTE ID
                                               M. ID=
  2145
                                               M. CDIF = 17760
                                                                                     :CYLINDER DIFFERENCE/OFFSET
  2146
                  017760
                                               M.CADD = 17760
                                                                                     :CYLINDER ADDRESS
                   077770
                                               M. SER= 77770
  2147
                                                                                     : DRIVE SERIAL NUMBER
  2148
2149
2150
                   000760
                                               M. SECT = 760
                                                                                     :SECTOR COUNT
                   007000
                                               M. HEAD= 7000
                                                                                      : HEAD DECODE
                                               .SBITL TRAP CATCHER
  2151
                   000000
                                               :*ALL UNUSED LOCATIONS OF THE VECTOR AREA CONTAIN
:*A ''.+2, IOT' SEQUENCE TO CATCH AND PROCESS ILLEGAL
  2153
                           :
  2154
  2155
                                               ** TRAPS AND INTERRUPTS THAT MIGHT OCCUR.
  2156
2157
                                               : * THE 10T TRAP WHICH IS TAKEN ON THE ILLEGAL TRAP/INT
                                                ** TRAPS TO THE $SCOPE ROUTINE WHICH (IF THE RETURN PC IS
                                               :*LESS THAN 1002) JUMPS TO THE SERROR ROUTINE.

:*THE SERROR ROUTINE WILL REPORT THE ERROR AS FOLLOWS:

PC=YYYYYY UNEXPECTED TRAP TO XXX
  2158
  2159
  2160
                                                ** AND RETURN TO THE PROGRAM AT PC=YYYYYY+2
  2161
  2162
2163
2164
                                                **WHERE XXX=LOCATION OF ILLEGAL TRAP
                                                         YYYYYY=PC AT TIME OF TRAP
                                                : *NOTE: IF THE PROCESSOR IS NOT AN 11/05 THE PROGRAM
                                                         CAN BE STARTED AT ADDRESS O AS WELL AS ADDRESS 200.
  2165
  2166
  2167
2168
2169
                  000000
         000000
                                               $40CAT: HALT
                                                                                      ::HALT
         200000
                   000737
                                                         BR
                                                                   .-100
                                                                                      :: BRANCH TO 177700 & TIME OUT (NOT ON
                                                                                     ::11/05)
                                                                                     :: VECTOR TO STARTING ADDRESS
  2170
         000004
                   001772
                                                         . WORD
                                                                  START
  2171
2172
2173
2174
2175
2176
2177
                                                         . WORD
         000006
                   000340
                                                                   340
                                                                                      :: WITH PRIORITY LEVEL 7
                   000174
                                                         .=174
                                                                                      :: SOFTWARE DISPLAY REGISTER
         000174
                   000000
                                               DISPREG: . WORD
         000176
                                                                  0
                   000000
                                               SWREG:
                                                        . WORD
                                                                                      :: SOFTWARE SWITCH REGISTER
                                               .SBITL STARTING ADDRES(ES)
         000200
                   000137
                            001772
                                                         JMP
                                                                   @#START ;; GO TO START OF PROGRAM
                   000137
         000204
                            001762
                                                         JMP
                                                                                     JUMP TO RESTART ROUTINE
                                                                   RESTRI
  2178
                   000214
                                                         .=214
         000214
                   000137 001752
                                                         JMP
                                                                   PARM
                                                                                     : JUMP TO OPERATOR ASSIGNED PARMETERS
```

```
CZR6KGO RK6 FCTNL CTRL DIAG
                                    MACY11 30(1046) 28-AUG-81 15:17 PAGE 42
CZR6KG.P11 28-AUG-81 15:16
                                              STARTING ADDRES(ES)
                                                       .=220
JMP
                  000220
  2181
        000220
                  000137 001742
                                                                SETCLK
                                                                                 JUMP TO SET CLOCK ROUTINE
 2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
                                              .SBITL APT PARAMETER BLOCK
                                              SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
                  000224
                                                       .$x=. ;; SAVE CURRENT LOCATION
                                                       .=24
                                                              SET POWER FAIL TO POINT TO START OF PROGRAM
                  000024
        000024
                  000200
                                                       200
                                                                :: FOR APT START UP
                  000044
                                                                :: POINT TO APT INDIRECT ADDRESS PNIR.
                                                       .=44
         000044
                                                       SAPTHOR : POINT TO APT HEADER BLOCK
                  000224
                  000224
                                                       .=. $X :: RESET LOCATION COUNTER
                                              SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
                                              : INTERFACE SPEC.
        000224
                                              SAPTHD:
 2198
        000224
                                                                         :: TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
:: ADDRESS OF APT MAILBOX (BITS 0-15)
:: RUN TIM OF LONGEST TEST
                  000000
                                              $HIBTS: . WORD
        000226
                  001276
                                              $MBADR: . WORD
                                                                $MAIL
  2200
2201
2202
2203
        000230
                  000024
                                              SISTM: . WORD
                                                                20.
        000232
                  000074
                                              $PASTM: . WORD
                                                                60.
                                                                         ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
                  000740
                                              SUNITM: . WORD
                                                                480.
                                                                          :; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
         000236
                  000031
                                                       . WORD
                                                                $ETEND-$MAIL/2 :: LENGTH MAILBOX-ETABLE (WORDS)
```

```
2204
2205
2206
                                                                                                                                                                                                                 .SBTTL COMMON TAGS
   2207
2208
2209
                                                                                                                                                                                                                                : *THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
                                                                                                                                                                                                                                : *USED IN THE PROGRAM.
                                                                                                                                                                                                                             $CMTAG: .=1100
                                                                                                                     | STANT | STAN
                                                                                   001100
001100
                                                                                                                                                                                                                                                                                                                                                                                                  ::START OF COMMON TAGS
                                                                                  000000
                                   001100
                                                                                     000
                                  001102
                                                                                                     000
                                    001104
                                                                                   000000
                                    001106
                                                                                   000000
                                                                                 000000
                                 001110
001112
001114
001115
001116
001120
001124
001126
001130
001132
001134
001135
001136
001140
001144
001146
001150
001150
                                                                                 000
                                                                                000000
177570
177570
177560
177562
177564
                                                                                  177566
                                    001154
                                                                                                     000
                                    001155
                                                                                                     002
                                    001156
                                                                                                     012
                                   001157
                                                                                                     000
                                    001160
                                                                                  000000
                                 001162
001164
001166
001170
001172
001174
001176
001200
001202
001204
001210
001210
001212
001214
001216
001220
001222
                                                                                 000000
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 44
CZR6KG.P11 28-AUG-81 15:16 COMMON TAGS
                                                                                                                                                       $TMP1: .WORD 0 ::USER DEFINED

$TMP2: .WORD 0 ::USER DEFINED

$TMP3: .WORD 0 ::USER DEFINED

$TMP4: .WORD 0 ::USER DEFINED

$TMP5: .WORD 0 ::USER DEFINED

$TMP6: .WORD 0 ::USER DEFINED

$TMP7: .WORD 0 ::USER DEFINED

$TMP10: .WORD 0 ::USER DEFINED

$TMP11: .WORD 0 ::USER DEFINED

$TMP13: .WORD 0 ::USER DEFINED

$TMP14: .WORD 0 ::USER DEFINED

$TMP15: .WORD 0 ::USER DEFINED

$TMP15: .WORD 0 ::USER DEFINED

$TMP16: .WORD 0 ::USER DEFINED

$TMP17: .WORD 0 ::USER DEFINED

$TMP18: .WORD 0 ::USER DEFINED

$TMP19: .WORD 0 ::USER DEFINED

$TMP18: .WORD 0 ::USER DEFINED

$TMP19: .WORD 0 ::USER DEFINED

$TMP18: .WORD 0 ::USER DEFINED

$TMP19: .WORD 0 ::USER DEFINED

$TMP1
                             001224
001226
001230
001232
001234
001236
001240
001242
001244
                                                                                                                                                                STMP1:
STMP2:
                                                                000000
                                                                                                                                                                                                   . WORD
                                                                                                                                                                                                                                                                                            :: USER DEFINED
        000000
                                                                                                                                       ..... 'STMP4:
                                                                 000000
                                                                000000
                                                               001246
                              001250
001252
001254
001256
001260
001262
001264
001266
001272
                                                                000000
                                                                 000000
                                                                000000
                                                                 000000
                                                                000000
                                                                                                 000377
                                                                  077
015
                                                            000012
                              001274
                                                                                                                                                                  ;;************************
                                                                                                                                                                  .SBITL APT MAILBOX-ETABLE
                                                                                                                                                                  .EVEN
                                                                                                                                         $MAIL:

$MSGTY: .WORD AMSGTY :: MESSAGE TYPE CODE
$FATAL: .WORD AFATAL :: FATAL ERROR NUMBER
$TESTN: .WORD ATESTN :: TEST NUMBER
$PASS: .WORD APASS :: PASS COUNT
$DEVCT: .WORD ADEVCT :: DEVICE COUNT
$UNIT: .WORD AUNIT :: I/O UNIT NUMBER
$MSGAD: .WORD AMSGAD :: MESSAGE ADDRESS
$MSGLG: .WORD AMSGLG :: MESSAGE LENGTH
$ETABLE:
$ENV: .BYTE AENV :: ENVIRONMENT TABLE
$ENVM: .BYTE AENVM :: ENVIRONMENT BYTE
$ENVM: .BYTE AENVM :: ENVIRONMENT MODE BITS
$SWREG: .WORD ASWREG :: APT SWITCH REGISTER
$USWR: .WORD ACPUOP :: CPU TYPE, OPTIONS

**
                                                                                                                                                                                       2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
                               001276
                              001276 000000
001300 000000
001302 000000
001304 000000
                               001306
                                                                000000
                               001310
                                                                000000
                               001312
                                                                 000000
                               001314
                                                                 000000
                               001316
                               001316
                                                                            000
                              001320
                                                                 000000
                                                                 000000
                                001324
                                                                 000000
        2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
                                001326
                                                                                                                                                                   $MAMS1: .BYTE
                                001327
                                                                                                                                                                   $MTYP1: .BYTE
         2311
         2312
        2313 2314 2315
                                                                                                                                                            $MADR1: .WORD AMADR1 ::HIGH ADDRESS.BLK#1

MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE

$MAMS2: .BYTE AMAMS2 ::HIGH ADDRESS,M.S. BYTE
                                001330 000000
                                001332
                                                                             000
```

CZ

AMTYP2 :: MEM.TYPE.BLK#2
AMADR2 :: MEM.LAST ADDRESS.BLK#2
AMAMS3 :: HIGH ADDRESS.M.S.BYTE
AMTYP3 :: MEM.TYPE.BLK#3 \$MTYP2: .BYTE \$MADR2: .WORD \$MAMS3: .BYTE ::HIGH ADDRESS.M.S.BYTE ::MEM.TYPE.BLK#3 ::MEM.LAST ADDRESS.BLK#3 ::HIGH ADDRESS.M.S.BYTE SMTYP3: .BYTE \$MTYP3: BYTE \$MADR3: WORD \$MAMS4: BYTE \$MTYP4: BYTE \$MADR4: WORD \$VECT1: WORD \$VECT2: WORD \$PASE: WORD \$DEVM: WORD \$CDW1: WORD \$ETEND: .MEXIT AMADR3 AMAMS4 ::MEM.TYPE.BLK#4 ::MEM.LAST ADDRESS.BLK#4 ::INTERRUPT VECTOR#1.BUS PRIORITY#1 ::INTERRUPT VECTOR#2BUS PRIORITY#2 AMTYP4 AMADR4 AVECT1 AVECT2 :: BASE ADDRESS OF EQUIPMENT UNDER TEST ABASE ADEVM :: DEVICE MAP ACDW1 :: CONTROLLER DESCRIPTION WORD#1

.

```
8
```

```
.SBITL ERROR POINTER TABLE
                                                    ** THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
                                                    *THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
                                                    : *LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
                                                                          IF $ITEMB IS O THE ONLY PERTINENT DATA IS (SERRPC).
                                                                          EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
                                                    : *NOTE2:
                                                                                     :: POINTS TO THE ERROR MESSAGE
                                                               DH
                                                                                     :: POINTS TO THE DATA HEADER
2341
2342
2343
2344
2345
2346
2348
2349
2350
2351
                                                               DT
                                                                                     :: POINTS TO THE DATA
                                                                                     :: POINTS TO THE DATA FORMAT
                                                               DF
                                                    SERRTB:
        001360
                                                    * EM AND DH ARE ASCIZ DATA. EM IS ALWAYS A MESSAGE BUT DH
ARE A MESSAGE OR A SET OF COLUMN LABELS SPACED ACCROSS
                                                    * THE PAGE, DT IS A STRING OF WORDS THAT POINT TO THE DATA TO THE BE TYPED, AND DF IS A STRING OF WORK THAT TELL HOW THE DT WORDS ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED, FOR A
                                                    * PARTICULAR FORMAT, IT IS REPLACED WITH A ZERO.
                                                    * THE NORMAL USAGE OF THE ERROR TABLE IS TO HAVE A TABLE ENTRY FOR A EACH ERROR MESSAGE THAT CAN OCCUR. IN THE INTEREST OF ECONOMICS
                                                    : * OF CORE MEMORY, THIS PROGRAM USES THE ERROR TABLE IN A
                                                    * SIGHTLY DIFFERENT MANNERS AS DESCRIBED BELOW.
                                                    : * THE ERROR TABLE ENTRIES MAKE UP A SET OF REPORT FORMATS THAT ARE USED
2360
2361
2362
                                                    :* THROUGHOUT THE PROGRAM. WHEN AN ERROR IS TO BE REPORTED. THE
                                                    * TABLE ENTRY THAT PROVIDES THE DESIRED FORMAT IS CHOSEN FROM
                                                    :* THE DEFINED SET. THE TABLE ENTRY CHOSEN IS THEN ALTERED :* BY CHANGING THE FIRST (AND POSSIBLY THE SECOND) WORD TO CONTAIN
2363
2364
2365
2366
2367
2368
2369
2370
2371
                                                    * THE ADDRESS OF THE ASCIZ STRING THAT MAKES UP THE MESSAGE ** PORTION OF THE REPORT. THE DATA FIELDS FOR THAT ENTRY ARE NEVER ** CHANGED, NOR ARE THE COLUMN LABELS OR POSITIONS.
                                                    :* THE FORMAT THAT EACH TABLE ENTRY PROVIDES IS SHOWN BELOW WITH
                                                    * THE DEFINITION OF THE ENTRY. ALL DATA FIELDS ARE TYPED IN OCTAL.
                                                               :ERROR ITEM 1
                                                               (MESSAGE)
                                                               TST NUM ERR PC
                                                                                     DRIVE
                                                               STESTN SERRPC
                                                                                     DRVNUM
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
        001360
                                                               . WORD
        001362
                   057236
                                                               DH001
        001364
                   060610
                                                               DT001
        001366
                   060702
                                                               DF 001
                                                                :ERROR ITEM 2
                                                               (MESSAGE)
                                                               (MESSAGE)
                                                               TST NUM ERR PC DRIVE
                                                               STESTN SERRPC DRVNUM
                                                                  RKCS1
                                                                           RKCS2 RKDS
                                                                                                   RKER
                                                                                                              RKASOF
                                                                                                                        RKDCYL
                                                                                                                                   RKDA
```

MACY11 30(1046) 28-AUG-81 15:17 CZR6KGO RK6 FCTNL CTRL DIAG PAGE 47 CZR6KG.P11 28-AUG-81 15:16 ERROR POINTER TABLE 2387 2388 2389 2390 T.CS1 1.052 T.DS T.ER T.ASOF T.DCYL T.DA RKBA RKWC T.BA T.WC 2391 2392 2393 2394 2395 2396 2397 2398 00 . WORD 001370 EM2N: 000000 001372 .WORD DT002 DF002 000000 DH2N: 060616 001376 060706 : *ERROR ITEM 3 (MESSAGE) TST NUM ERR PC DRIVE STESTN SERRPC DRVNUM RKCS2 T.CS2 RKCS1 RKDS RKER RKASOF RKMR1 : * T.CS1 T.DS T.ER T.AST T.MR1 001400 000000 EM3N: . WORD 0 057264 060566 001402 DH002A 001404 DT003 DF 003 001406 060726 * ERROR ITEMS 4.5.6.87 ARE USED TO REPORT FRORS THAT ARE THE RESULT OF A HARDWARE ERROR INDICATOR BEING SET WHEN NOT EXPECTED. * NOT SET WHEN IT IS EXPECTED, OR BOTH. THE ERROR REPORT WILL * CONTAIN (1) ALL THE ERRORS THAT WERE DETECTED, (2) ALL THE EXPECTED * ERRORS THAT DID NOT OCCUR, OR (3) ALL THE EXPEDIED BUT NOT SET ERRORS * AND THE UNEXPECTED BUT SET ERRORS. * THE MESSAGE ITSELF EXPLAINS THE CIRCUMSTANCE FOR THE REPORT. INCLUDED IN THE REPORT WILL BE ONE OR MORE OF THE FOLLOWING STATEMENTS: "THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION:" "THE ABOVE ARE UNEXPECTED ERRORS SET IN OPERATION:"
"THE ABOVE ARE ERRORS SET IN OPERATION:" * PRECEEDING ANY ONE OF THESE LINES WILL BE ONE OR MORE LINES THAT

* EXAMPLE:

* DRIVE SELECT

* NON-EXISTANT DRIVE

SPECIFY TJE EXACT ERROR. FOLLOWING THE LAST LINE WILL BE A LINE

THAT IDENTIFIES THE OPERATION BEING PERFORMED.

;* THIS IS THE RESULT OF AN ERROR SET IN A SELECT OPERATION.

* THE ABOVE ARE ERRORS SET IN OPERATION:

* (ADDITIONAL LINES OF INFORMATION)

```
CZR6KG.P11
    2434567890123444567890123446667890122447789
   2480
2481
2482
2483
2484
2485
2486
2488
2489
                001410
                                 000000
                                 000000
                001412
                001414
                                 060616
                001416
                                 060736
```

```
: * EXAMPLE:
* NON-EXISTANT DRIVE
* THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION:
: * DRIVE SELECT
* (ADDITIONAL LINES OF INFORMATION)
* THIS IS THE RESULT OF AN EXPECTED ERROR THAT DID NOT OCCUR, I.E.
 * A NON-EXISTANT DRIVE WAS ADDRESSED BUT NED WAS NOT SET.
: * EXAMPLE:
* NON-EXISTANT MEMORY
* THE ABOVE ARE UNEXPECTED ERRORS SET IN OPERATION:
* UNIBUS PARITY ERROR
* THE ABOVE ARE EXPECTED ERRORS THAT DID NOT SET IN OPERATION:
: * WRITE DATA
 * (ADDITIONAL LINES OF INFORMATION)
* THIS IS AN EXAMPLE OF NON-EXISTANT MEMORY BEING SET WHEN UNIBUS
 * PARITY ERROR WAS EXPECTED.
        ERROR ITEM 4
        (DESCRIPTION OF ERROR)
        ERROR IN OPERATION
        (DESCRIPTION OF OPERATION)
        IST NUM ERR PC DRIVE
        STESTN SERRPC DRVNUM
                 RKCS2
T.CS2
          RKCS1
                           RKDS
                                   RKER
                                           RKASOF
                                                     RKDCYL
                                                              RKDA
          T.CS1
                           T.DS
                                   T.ER
                                            T.ASOF
                                                     T.DCYL
                                                              T.DA
        RKBA
                RKWC
                T.WA
        T.BA
          A00
                  B00
                                            A02
          $REG1.0 $REG1.1
                          $REG12 $REG13 $REG14
                                                    $REG15 $REG16 $REG17
        THE ERRORS REPORTED BY THIS FORMAT ARE:
        CONTROLLER DETECTED DRIVE BUS ERROR
        DRIVE DETECTED DRIVE BUS ERROR
        SEEK INCOMPLETE
        NON-EXECUTABLE DRIVE FUNCTION
        DRIVE TIMING ERROR
DRIVE UNSAFE
        AC LOW
        SPINDLE SPEED LOSS
        DRIVE OFF TRACK
        ILLEGAL DRIVE ADDRESS ERROR
        CYLINDER OVERFLOW
        DRIVE TYPE ERROR
        FORMAT ERROR
        WRITE LOCK ERROR
EM4N:
        . WORD
                0
                0
DH4N:
        . WORD
        DT004
        DF 004
        ERROR ITEM 5
        THIS ENTRY IS THE SAME AS ITEM 4 WITH THE ADDITION
```

CZR6KGO RK6 FCTNL CTRL DIAG

28-AUG-81 15:16

CZR6KG.P11

```
2490
2491
2492
2493
2494
                                                         OF A MESSAGE THAT FOLLOWS. THIS MESSAGE IS:
                                                         "ANY FIELD WITH ALL ONES MUST BE CONSIDERED INVALID"
                                              : *
                                                         THIS REPORT WILL BE PRINTED WHEN THE GATHERING OF DATA FOR A00 THRU B03 IS NOT ACCOMPLISHED WITHOUT ERROR.
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
                                               ;*
      001420
001422
001424
                 000000
                                                         . WORD
                                               EM5N:
                                                                   Ŏ
                                               DH5N:
                                                         . WORD
                 060616
                                                         DT005
       001426
                 060766
                                                         DF 005
                                                         ERROR ITEM 6
                                                         (DESCRIPTION OF ERROR)
                                                         ERROR IN OPERATION
(DESCRIPTION OF OPERATION)
                                                         TST NUM ERR PC
                                                                             DRIVE
                                                         STESTN SERRPC
                                                                             DRVNUM
                                                           RKCS1 RKCS2 RKDS RKER RKASOF RKDCYL RKDA
T.CS1 T.CS2 T.DS T.ER T.ASOF T.DCYL T.DA
                                                         RKBA RKWC
                                                         T.BA T.WC
                                                         THE ERRORS REPORTED BY THIS FORMAT ARE:
                                                         DATA CHECK
                                                         WRITE CHECK
                                                         ECC HARD
                                                         DATA LATE
                                                         OPERATION INCOMPLETE
                                                         HEADER VRC ERROR
                                                         BAD SECTOR ERROR
       001430
001432
001434
                                                         . WORD
                 000000
                                               EM6N:
                 000000
                                                         . WORD
                                                                  0
                                               DH6N:
                 060616
                                                         DT006
       001436
                 061022
                                                         DF 006
                                                         ERROR ITEM 7
                                                         (DESCRIPTION OF ERROR)
                                                         ERROR IN OPERATION
                                                         (DESCRIPTION OF OPERATION)
                                                         TST NUM ERR PC DRIVE
                                                         STESTN SERRPC DRVNUM
RKCS1 RKCS2 RKDS
T.CS1 T.CS2 T.DS
                                                                                         RKER
                                                                                                   RKASOF
                                                                                                   T. ASOF
                                                                                         T.ER
                                                         THE ERRORS REPORTED BY THIS FORMAT ARE:
                                                         NON-EXISTANT DRIVE
                                                         NON-EXISTANT MEMORY
                                                         CONTROLLER TIME OUT
                                                         UNIT FIELD ERROR
                                                         MULTIPLE DRIVE SELECT
                                                         PROGRAMMING ERROR
                                                         UNIBUS PARITY ERROR
                                                         ILLEGAL FUNCTION CODE
```

```
CZR6KG.P11
               28-AUG-81 15:16
                                             ERROR POINTER TABLE
                                                       DESCRIPTON OF OPERATION CAN BE ANY COMMAND, EITHER LEGAL OR ILLEGAL
  001440
                  000000
                                             EM7N:
                                                               00
                                                       . WORD
         001442
                  000000
                                             DH7N:
                                                       . WORD
        001444
                  060616
                                                       DT007
        001446
                 061046
                                                       DF 007
                                                       ERROR ITEM 10
                                                       (DESCRIPTION OF ERROR)
                                                       ERROR AT COMPLETION OF OPERATION
                                                       (DESCRIPITON OF OPERATION)
                                                       TST NUM ERR PC DRIVE
                                                       STESTN SERRPC DRVNUM
                                                         EXPT
                                                                  15
                                                         $REG10 $REG11
                                                       THE ERRORS REPORTED BY THIS FORMAT ARE SOFTWARE DETECTED BY
                                                       COMPARING EXPECTED RESULTS WITH ACTUAL RESULTS. THE SPECIFIC
                                                       ERRORS ARE:
                                                      WORD COUNT INCORRECT
BUS ADDRESS INCORRECT
                                                       CYLINDER ADDRESS INCORRECT
                                                       TRACK ADDRESS INCORRECT
                                                       SECTOR ADDRESS INCORRECT
        001450
                  000000
                                             EM10N:
                                                       . WORD
                                                               0
        001452
                  060077
                                                       DH010
        001454
                  060666
                                                       DT015
        001456
                 061066
                                                       DF 010
                                                       ERROR ITEM 11
                                                       (ERROR INDICATOR OR STATUS BIT)
                                                       NOT SET AS A RESULT OF
                                                       (ANOTHER ERROR INDICATOR, STATUS BIT, OR OPERATION
                                                       TST NUN ERR PC DRIVE
                                                      $TESTN $ERRPC DRVNUM
RKCS1 RKCS2 RKDS
T.CS1 T.CS2 T.DS
                                                                                     RKER
                                                                                             RKASOF
                                                                                                        RKMR1
  2583
2584
                                                                                              T.ASOF
                                                                                                        T_MR1
  2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
        001460
                  000000
                                             EM11N:
                                                       . WORD
                  060223
        001462
                                                       DH011
        001464
                  060616
                                                       DT010
        001466
                 061106
                                                       DF 011
                                                       ERROR ITEM 12
                                                       THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS:
                                                       "NOT RESET AS A RESULT OF"
                  000000
        001470
                                             EM12N:
                                                       . WORD
                                                               0
        001472
                  060252
                                                       DH012
                  060616
                                                       DT010
        001476
                 061106
                                                       DF011
  2600
```

"SET AS A RESULT OF"

THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS:

MACY11 30(1046) 28-AUG-81 15:17 PAGE 50

CZR6KGO RK6 FCTNL CTRL DIAG

2601

```
001500
                 000000
                                                EM13N:
                                                          . WORD
                                                                    0
       001502
                 060303
                                                          DH013
       001504
                 060616
                                                          DT010
                                                          DF 011
                 061106
                                                          ERROR ITEM 14
                                               :*
                                                          THIS ERROR IS IDENTICAL TO ITEM 11 EXCEPT THE SECOND LINE IS: "RESET AS A RESULT OF"
                                                . *
                                                EM14N:
       001510
                 000000
                                                          . WORD
                                                                    0
       001512
                 060326
060616
                                                          DH014
                                                          DT010
       001516
                                                          DF011
                 061106
                                                          ERROR ITEM 15
                                                          (HEADER WORD MISCOMPARE) OR (DATA MISCOMPARE)
                                                          TST NUM ERR PC DRIVE
                                                          STESTN SERRPC DRVNUM
                                                            GOOD
                                                                      BAD
                                                                                WORD NUM
                                                            $REG10 $REG11 $REG12
       001520
                 000000
                                               EM15N:
                                                          -WORD 0
       001522
                 057264
                                                          DH002A
       001524
                 060666
                                                          DT015
       001526
                 061130
                                                          DF015
                                                          ERROR ITEM 16
                                                          ADDITIONAL LINES OF GOOD, BAD, WORD NUM FOR ERROR 15
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
       001530
                 000000
       001532
                                                          Ŏ
                 000000
       001534
                 060674
                                                          DT015A
       001536
                 061140
                                                          DF 016
                                                .SBTTL
                                                          REGISTER STORAGE FOR TEST
       001540
                 000000
                                                T. CS1:
                                                          . WORD
       001542
001544
                 000000
                                                T.WC:
                                                          . WORD
                                                                    0
                 000000
                                                T.BA:
                                                                    0
                                                          . WORD
       001546
                 000000
                                                          . WORD
                                                T.DA:
2642
2643
2644
2645
2646
2647
2648
2650
2651
2653
2655
2656
2657
       001550
                 000000
                                                T. CS2:
                                                          . WORD
       001552
                 000000
                                               T.DS:
T.ER:
                                                          . WORD
                                               T.ER: .WORD
T.ASOF: .WORD
                 000000
       001554
                 000000
       001556
       001560
                                               T.DCYL: .WORD
T.SPAR: .WORD
       001562
001564
                 000000
                 000000
                                                T.DB:
                                                          . WORD
       001566
                                                          . WORD
                 000000
                                                T.MR1:
       001570
                 000000
                                                T.ECPS:
                                                          . WORD
                                               T.ECPT: .WORD
T.MR2: .WORD
T.MR3: .WORD
       001572
                 000000
                                                                    0
       001574
                 000000
                                                                    0
       001576
                 000000
                                                                    0
                                                         REGISTER SETUP STORAGE .WORD 100
                                                .SBTTL
                 000100
       001600
                                                L.CS1: .WORD
                                                                                        : PRESET WITH INTERRUPT ENABLE
                                               L.WC:
                                                          . WORD
                                                                    0
```

| | | | | M 4 | |
|--------|----------|-------------|-------|------|----|
| MACY11 | 30(1046) | 28-AUG-81 | 15:17 | PAGE | 52 |
| | REGISTER | SETUP STORA | AGE | | |

| RK6 FCT P11 2 | | MACY11 | 30(1046) REGISTER | 28-AUG | -81 15:17 P | PAGE 52 |
|--|---|--|--|--|--|---|
| 001604 001606 001606 001607 001610 001612 001614 001616 | 000000 000 000 000000 000000 000000 | | L.BA: L.DA: L.DS: L.DT: L.CS2: L.ASOF: L.DCYL: L.MR1: .SBTTL | .WORD .BYTE .BYTE .WORD .WORD .WORD .WORD .WORD .PROGRAM | O O O O O O DEFINED VARIA | IABLES |
| 001620 001622 001624 | 000000 000000 000000 | | RKVEC: RKPRI: SRTFLG: | | 0 0 0. | :RK VECTOR :RK PRIORITY :START FLAG : 0 = 200 : 1 = 214 : -1 = 204 |
| 001626 001630 001632 | 000000 000000 000024 | | DRVBIT: | . WORD | 0 0 2 20 | DRIVE UNDER TEST WORD TO STORE BIT TO INDICATE DRIVE UNDER TEST ERROR COUNTER TO LIMIT ERROR ERRORS REPORTED IN PROGRAM |
| 001634 001636 | 000024 061270 | | | | *D20 BS24 | DATA COMPARE ERROR LIMIT POINTER TO BAD SECTORS 24 SECTOR MODE (FACTORY) |
| 001640 | 061144 | | BSF26P: | .WORD | BS26 | POINTER TO BAD SECTORS 26 SECTOR MODE |
| 001642 | 000000 | | BSS24P: | .WORD | 0 | : (FACTORY) :POINTER TO BAD SECTORS 24 SECT MODE |
| 001644 | 000000 | | BSS26P: | . WORD | 0 | : (SOFTWARE) :POINTER TO BAD SECTORS 26 SECTOR MODE |
| 001646 001650 001652 001654 | 000000 000000 000764 000017 001660 | | BS24CT: MILCNT: | .WORD .WORD | 0 0 2D500 2D15 | : (SOFTWARE) :COUNT OF BAD SECTORS 26 SECTOR MODE :COUNT OF BAD SECTORS 24 SECTOR MODE :COUNT TO APPROXIMATE 1 MILL SEC :COUNTER FOR MYTIME ROUTINE |
| | | | INTSET: | . WORD | 0 | :NON-ZERO IF RKO6 INTERRUPT SINCE |
| 001664 | 000000 | | OPTFLG: | .WORD | 0 | :LAST CLEARED :OPTION FLAGS |
| | 000001 000002 000004 000010 000100 000200 000400 002000 004000 100000 | | | MEMSZB= MEMPYB= SRTINS= PARPRE= BSERPT= FPFMT= CP1170= DRVRPT= | BIT1 BIT2 BIT3 BIT6 BIT7 BIT8 BIT10 BIT11 | DRIVE O TO BE TESTED FLAG MEMORY SIZE REPORT FLAG MEMORY PARITY REPORT FLAG START UP INSTRUCTIONS REPORTED FLAG PARITY PRESENT FLAG BSE HAS BEEN REPORTED FIRST PASS FORMAT SWITCH CP IS 11/70 FLAG DRIVE NUMBERS REPORTED FLAG LINE CLOCK PRESENT |
| 001666 001670 001672 | 000000 000000 000000 | | MEMPAR: | . WORD | 0 0 0 | :LIST OF DRIVES DROPPED :WORD OF PARITY FLAGS :POINTER TO CSR TO USE FOR SETTING BAD |
| 001674 001676 | | | LCLKTK: REFMT: | .WORD | 0 | : PARITY :LINE CLOCK TICK COUNTER :REFCRMAT SWITCH FOR HALT |
| | P11 2 001604 001606 001606 001607 001610 001612 001614 001616 001622 001624 001624 001630 001632 001634 001644 001646 001650 001652 001654 001660 001662 001664 | 001604 000000 001606 000 001607 0000 001610 000000 001612 000000 001614 000000 001620 000000 001622 000000 001624 000000 001630 000000 001632 000024 001634 00024 001636 061270 001640 061144 001642 000000 001650 000000 001650 000000 001652 000764 001654 000000 001654 000000 001660 000000 001660 000000 001660 000000 001660 000000 001664 000000 001664 000000 001665 000000 001666 000000 001666 000000 001666 000000 001666 000000 001666 000000 000000000 0000000000 | P11 | P11 28-AUG-81 15:16 | P11 | P11 |

| CZR6KGO RK6 CZR6KG.P11 | FCTNL CTRL DIAG 28-AUG-81 15:16 | MACY11 | | 28-AUG-81 DEFINED VAR | | PAGE 53 |
|---------------------------|------------------------------------|--------|--|--------------------------|--|---------|
|---------------------------|------------------------------------|--------|--|--------------------------|--|---------|

| CZR6KG. | P11 | 28-AUG-81 | 15:16 | | PROGRAM | DEFINED | VARIABLES | |
|--|--|---|--|------------------|--|--|---|---|
| 2714 2715 2716 2717 2718 2719 2720 2721 2722 2723 2724 | 001700 001702 001704 001706 001710 001712 001714 | 000000 000000 177546 000100 172100 | | | DESHLD: SRCHLD: WRDNUM: WRDCNT: KWLADD: KWLVEC: MEMBAS: MMVECA: | .WORD .WORD .WORD .WORD .WORD .WORD | LOWING 4 VARIABLE OR DATA COMPARE 0 0 0 0 177546 100 172100 114 | ES ARE USED TO STORE PARAMETERS FOR CONTINUATION PROCESS. :DESTINATION HOLD :SOURCE HOLD :WORD NUMBER IN ERROR HOLD :WORDS LEFT IN COMPARE HOLD :KW11-L ADDRESS :KW11-L VECTOR :MM11 ADDRESS :MM11 VECTOR |
| 2716 2717 2718 2719 2720 2721 2723 2724 2725 2726 2727 2738 2738 2738 2738 2738 2738 2738 | 001720 001722 001724 001726 001730 001732 001734 001736 | 000000 000000 000000 000000 000000 00000 | | | DTYPE: TYPTBL: | 000000000 | | :DRV TYP |
| 2738 2739 2740 2741 | | | | | .SBTTL | PROGRAM | SETUP | |
| 2742 | 001742 001750 | | 000002 | 001624 | SETCLK: | MOV BR | #2.SRTFLG START1 | ; SET START FLAG FOR CLOCK ADJUST |
| 2745 2746 | 001752 001760 | 012737 000406 | 000001 | 001624 | PARM: | MOV BR | #1,SRTFLG START1 | SET START FLAG FOR PARMETER START |
| 2749 | 001762 001770 | 012737 000402 | 177777 | 001624 | RESTRT: | MOV BR | #-1,SRTFLG START1 | :LOAD START FLAG FOR PARMETER START |
| 2750 2751 2752 2753 2754 2755 2756 2757 2758 | 001772 001776 002000 002004 002010 002014 | 000005 012706 012746 012746 | 001624 001100 000340 002016 | | START: START1: | CLR RESET MOV MOV MOV RTI | SRTFLG #STACK, SP #PR7, -(SP) #1\$, -(SP) | CLEAR START FLAG RESET THE WHOLE SYSTEM INITIALIZE STACK POINTER LOAD STACK TO LOCK OUT ALL INTERRUPTS LOAD START OF PROGRAM LOAD PSW |
| 2758 2759 2760 2761 | 002016 002022 | 004737 005037 | 045220 001676 | | 1\$: | CLR | PC,\$TKINT REFMT | :INITIALIZE KEYBOARD :CLEAR REFORMAT SWITCH |
| 2761 2762 2763 2764 2765 2766 2767 2768 2769 | 002026 002032 002034 002040 002042 | 005026 022706 001374 012706 | 001100 001140 001100 032576 000340 | 000020 000022 | ;;CLEAR | THE COMM MOV CLR CMP BNE MOV | IZE THE COMMON TA MON TAGS (\$CMTAG) #\$CMTAG,R6 (R6)+ #SWR,R6;;DONE? 6 #STACK,SP EW VECTORS #\$SCOPE,@#IOTVEC #340,@#IOTVEC+2 | ;; FIRST LOCATION TO BE CLEARED ;; CLEAR MEMORY LOCATION ;; LOOP BACK IF NO ;; SETUP THE STACK POINTER ;; IOT VECTOR FOR SCOPE ROUTINE |

| CZR6KGO RK6 F CZR6KG.P11 | CTNL CTRL 28-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) INITIAL | 28-AUG | -81 15:17 PA | 5 GE 54 |
|--|---|--|--|------------------------------------|--|--|--|
| 2770 00206 2771 00206 2772 00207 2773 00216 2774 00217 2775 00217 2776 00217 2777 00217 2778 00217 2779 00217 2780 00217 2781 00216 2782 | 70 012737 76 012737 74 012737 75 012737 76 012737 76 013737 76 005037 76 005037 76 012737 | 033614 000340 047076 000340 046720 000340 032026 001262 001264 000001 002152 002160 | 000030 000032 000034 000036 000024 000026 032020 | ::S17E | MOV MOV MOV MOV MOV CLR CLR MOVB MOV MOV FOR A HAI | #340,a#EMIVEC #\$TRAP,a#TRAPVE #340,a#TRAPVE #\$PWRDN,a#PWR #340,a#PWRVEC \$ENDCT,\$EOPCT \$TIMES \$ESCAPE #1,\$ERMAX #.,\$LPADR #.,\$LPADR #.,\$LPERR RDWARE SWITCH | ::SETUP END-OF-PROGRAM COUNTER ::INITIALIZE NUMBER OF ITERATIONS ::CLEAR THE ESCAPE ON ERROR ADDRESS ::ALLOW ONE ERROR PER TEST ::INITIALIZE THE LOOP ADDRESS FOR SCOPE ::SETUP THE ERROR LOOP ADDRESS REGISTER. IF NOT FOUND OR IT IS |
| 2783 2784 00216 2785 00217 2786 00226 2787 00226 2788 00227 2789 00226 2790 | 72 012737 00 012737 06 012737 14 022777 | 000004 002226 177570 177570 177777 | 000004 001140 001142 176716 | ;;EQUAL | MOV MOV MOV MOV CMP BNE | a#ERRVEC, - (SP | A SOFTWARE SWITCH REGISTER.) ;; SAVE ERROR VECTOR ;; SET UP ERROR VECTOR ;; SETUP FOR A HARDWARE SWICH REGISTER |
| 2791 00222 2792 00222 2793 0022 2794 0022 2795 00222 2796 00222 | 26 012716 32 000002 34 012737 32 012737 | 002234 000176 000174 000004 | 001140 001142 | 64\$: 65\$: 66\$: | BR MCV RTI MOV MOV MOV | 65\$ #65\$,(SP) #SWREG,SWR #DISPREG,DISP (SP)+,@#ERRVE | ;;BRANCH IF NO TIMEOUT ;;SET UP FOR TRAP RETURN ;;POINT TO SOFTWARE SWR |
| 2797 2798 00226 2799 00226 2800 00226 2801 0022 2802 0022 | 00 132737 06 001403 00 012737 | 001304 000200 001320 | 001317 001140 | 67\$: | CLR BITB BEQ MOV | \$PASS #APTSIZE,\$ENV 67\$ #\$SWREG,SWR | ::CLEAR PASS COUNT ::TEST USER SIZE UNDER APT ::YES,USE NON-APT SWITCH ::NO,USE APT SWITCH REGISTER |
| 2803 2804 2805 00223 2806 00230 2807 00230 2808 0023 | 76 005227 02 001046 04 022737 12 001442 | 177777 032162 002362 | 000042 | .SBITL ;:TYPE | THE NAME INC BNE CMP | #-1 68\$ #\$ENDAD . 0#42 | M IF FIRST PASS ;;FIRST TIME? ;;BRANCH IF NO ;;ACT-11? ;;BRANCH IF YES ;;TYPE ASCIZ STRING E SWITCH REGISTER |
| 2809 0023 2810 2811 0023 2812 0023 2813 0023 2814 0023 2815 0023 2816 0023 2817 0023 2818 0023 2819 0023 | 24 001012 26 123727 34 001406 36 023727 34 001005 36 104406 | | 000001 000176 | .SBTTL | TST BNE CMPB BEQ CMP BNE GTSWR | 0E FOR SOFTWAR 0#42 70\$ \$ENV,#1 70\$ SWR,#SWREG 71\$ | :: SWITCH REGISTER :: ARE WE RUNNING UNDER XXDP/ACT? :: BRANCH IF YES :: ARE WE RUNNING UNDER APT? :: BRANCH IF YES :: SOFTWARE SWITCH REG SELECTED? :: BRANCH IF NO :: GET SOFT-SWR SETTINGS |
| 2820 00236 2821 00236 2822 | 00 000417 | 000001 | 001134 | 70\$: 71\$: ::69\$: 68\$: | BR MOVB BR .ASCIZ | 71\$ #1,\$AUTOB 68\$ <crlf>*CZR6KG</crlf> | ::SET AUTO-MODE INDICATOR ::GET OVER THE ASCIZ O RK6 FCTNL CTRL DIAG* <crlf></crlf> |
| 2823 0024 2824 0024 2825 0024 | 20 132737 | 000200 | 001317 | 001: | BITB | #BIT7,\$ENVM | : TEST IF DO NOT SIZE : YES - SKIP |

| CZR6KGO RK6 FCTNL CTRL DIAG | MACY11 30(1046) 28-AUG-81 15:17 PAGE 55 |
|-----------------------------|---|
| CZR6KG.P11 28-AUG-81 15:16 | GET VALUE FOR SOFTWARE SWITCH REGISTER |
| 2824 002/30 00/777 07227/ | ICD DC CC17E |

| 2826 002430 2827 002434 2828 002442 2829 002444 2830 002450 2831 002456 | 103007 104401 012737 000137 | 032234 032574 051165 000001 031772 | 000740 | | JSR CMP BHIS TYPE MOV JMP | PC.\$SIZE \$LSTBK.#740 2\$.OPRO05 #1.\$EOPCT \$EOP | :MAKE SURE MEMORY IS SUFFICIENT :YES - SKIP :MESSAGE (NOT ENOUGH MEMORY) :FORCE END OF PROGRAM |
|--|--|--|--------|---------------|--|--|--|
| 2827 002434 2828 002442 2829 002444 2830 002450 2831 002456 2832 002462 2833 002462 2834 002466 2835 002472 2836 002474 2837 002476 2838 002500 2839 002506 2840 002516 2841 002516 2842 002516 2843 002522 2844 002522 | 012701 005020 005301 001375 122737 | | 000041 | 2\$: 30\$: | MOV MOV CLR DEC BNE CMPB BNE | #IBUFF,R0 #2000,R1 (R0)+ R1 30\$ #13,@#41 | SET UP TO CLEAR 2000 :WORDS OF BUFFER SPACE :LOOP - :UNTIL - :DONE :LOAD FROM XXDP :BRANCH IF NOT |
| 2840 002510 2841 002514 2842 002516 2843 002516 2844 002522 2845 002526 | 104401 000000 013700 012701 013703 | 051236 032574 000006 032572 032316 | | 99\$: | MOV MOV MOV | ,OPROO7 \$LSTBK,RO #6,R1 \$LSTAD,R3 | GET LAST BANK SET SHIFT COUNT GET LAST ADDRESS |
| 2846 002532 2847 002534 | 005004 005737 100005 006100 006104 | 032316 | | 22\$: | CLR TST BPL ROL ROL | \$K111 23\$ R0 R4 | CLEAR R4 FOR OVERFLOW :MEM MANAGE PRESENT? :NO - SKIP :SHIFT BANK LEFT :ADD IN CARRY |
| 2849 002542 2850 002544 2851 002546 2852 002550 2853 002552 2854 002554 2855 002562 | 112737 110437 010337 | 000001 001326 001330 | 001327 | 23\$: | DEC BNE BIS MOVB MOVB MOV | RO,R3 #1.\$MTYP1 R4,\$MAMS1 R3,\$MADR1 | SET BANK BITS IN LAST ADDRESS FORCE MEMORY TYPE TO 1 STORE UPPER MEMORY ADDRESS STORE LOWER ADDRESS |
| 2858 002600 2859 002602 2860 002606 2861 002614 | 001005 104401 052737 | 000010 051766 000010 | 001664 | 3\$: 24\$: | BNE TYPE BIS | 24\$,OPRO16 #SRTINS,OPTFLG | :YES - SKIP :TYPE STARTUP INSTRUCTIONS :SET REPORTED FLAG |
| 2864 002624 2865 002630 2866 002634 | 001122 104401 013746 | 000001 051056 001352 | 001624 | 5\$: | CMP BNE TYPE MOV TYPOC | OPRO01 \$BASE,-(SP) | CHECK IF PARAMETER START NO, START TESTING TYPE 'RK611 BUS ADDRESS () =' SAVE \$BASE FOR TYPEOUT GO TYPEOCTAL ASCII(ALL DIGITS) |
| 2867 002636 2868 002642 2869 002644 2870 002650 2871 002652 2872 002660 | 104401 104412 012637 001407 022737 | 051105 001222 160000 | 001222 | | TYPE RDOCT MOV BEQ CMP | ,0PR002 (SP)+,\$TMP0 7\$ #160000,\$TMP0 | :GET VALUE :CHECK IF <cr> :CHECK IF IN I/O PAGE</cr> |
| 2873 002662 2874 002670 2875 002674 2876 002700 | 104401 013746 042716 | 001222 051113 001346 160000 | 001352 | 7\$: | BHI MOV TYPE MOV BIC | 5\$ \$TMPO,\$BASE .OPRO03 \$VECT1,-(SP) #160000,(SP) | :LOAD NEW BUS ADDRESS :TYPE 'RK611 VECTOR ADDRESS () ='' :GET \$VECT1 FOR TYPOUT :CLEAR PRIORITY BITS |
| 2877 002704 2878 002706 2879 002712 2880 002714 2881 002720 | 104412 012637 | 051105 001222 | | | TYPOC TYPE RDOCT MOV BEQ | .OPR002 (SP)+,\$TMP0 10\$ | GET VALUE CHECK IF <cr></cr> |

CZR6KGO RK6 FCTNL CTRL DIAG

```
CZR6KG.P11 28-AUG-81 15:16
         002722
002730
002732
002740
002746
002752
                   022737
  2883
                              001000
                                        001222
                                                                      #1000,$TMP0
                                                            BLOS
                                                                                           : CHECK IF LEGAL
                                                                      #17777, $VECT1
$TMP0, $VECT1
,0PR004
                   042737
                                        001346
  2884
                              017777
                                                                                           CLEAR OLD VECTOR
  2885
2886
2887
                              001222
                                                                                          :LOAD NEW VECTOR ADDRESS
:TYPE 'RK611 PRIORITY ( ) ="
                                                            BIS
                    104401
                                                  10$:
                                                            TYPE
                    005046
                                                            CLR
                                                                      -(SP)
         002754
  2888
                    113716
                              001347
                                                            MOVB
                                                                      $VE(T1+1, (SP)
  2889
         002760
                                                            ASR
                   006216
                                                                       (SP)
                                                                                          : SHIFT 5 BITS RIGHT
                                                                      (SP)
  2890
         002762
                   006216
                                                            ASR
  2891
         002764
                   006216
                                                            ASR
                                                                       (SP)
  2892
         002766
                   006216
                                                            ASR
                                                                       (SP)
  2893
         002770
                   006216
                                                            ASR
                                                                      (SP)
  2894
         002772
                    104402
                                                            TYPOC
  2895
         002774
                   104401
                             051105
                                                            TYPE
                                                                      .OPR002
  2896
         003000
                   104412
                                                            RDOCT
                                                                                          :GET VALUE
  2897
         003002
                   012637
                              001222
                                                            MOV
                                                                      (SP)+,$TMP0
         003006
  2898
                   001430
                                                            BEQ
                                                                      15$
                                                                                          : CHECK IF <CR>
  2899
         003010
                   022737
                              000007
                                       001222
                                                            CMP
                                                                      #7.$TMP0
                                                                                          : CHECK IF LEGAL
                   103753
  2900
         003016
                                                            BLO
                                                                      10$
  2901
         003020
                   022737
                              000004
                                        001222
                                                            CMP
                                                                      #4.$TMP0
  2902
         003026
                   101347
                                                            BHI
                                                                      10$
                             001222
001222
001222
001222
001222
  2903
         003030
                   006337
                                                            ASL
                                                                      $TMPO
                                                                                        SHIFT 5 BITS LEFT
  2904
         003034
                   006337
                                                                      $TMPO
                                                            ASL
                   006337
006337
006337
042737
053737
  2905
         003040
                                                                      $TMPO
                                                            ASL
  2906
2907
         003044
                                                                      $TMPO
                                                            ASL
         003050
                                                            ASL
                                                                      $TMPO
  2908
                             160000
001222
001304
                                        001347
                                                            BIC
                                                                      #160000, $VECT1+1 ; CLEAR OLD PRIORITY
  2909
         003062
                                        001347
                                                            BIS
                                                                      $TMPO, $VECT1+1 : LOAD RK611 PRIORITY
  2910
         003070
                   005037
                                                                                          SET PASS COUNT TO ZERO
                                                  15$:
                                                                      $PASS
                                                            CLR
  2911
         003074
                   005037
                                                                      DRVDRP
                              001666
                                                            CLR
                                                                                          :CLEAR DROPPED DRIVES LIST
  2912
2913
2914
                                                                      #DRVRPT.OPTFLG : CLEAR DRIVE #'S REPORTED FLAG
PC.OPTTST :SETUP PARITY CHECK & CLOCK
                   042737
         003100
                              094000
                                        001664
                                                            BIC
                                                                      PC.OPTIST
$VECT1.RO
#160000.RO
         003106
                   004737
                              034522
                                                            JSR
                                                                                          STORE VECTOR FOR USE CLEAR PRIORITY BITS
         003112
                   013700
                              001346
                                                            MOV
  2915
         003116
                   042700
                              160000
                                                            BIC
  2916
2917
         003122
                   010037
                              001620
                                                                      RO, RKVEC
                                                            MOV
         003126
                   012710
                             034442 001347
                                                                      #INTHLR. (RO) :SETUP INTERRUPT ADDRESS
$VECT1+1, RKPRI :STORE PRIORITY FOR USE
                                                            MOV
  2918
                   113737
                                       001622
                                                            MOVB
                             001352
  2919
         003140
                   013702
                                                                                          SET BASE ADDRESS
                                                            MOV.
                                                                      $BASE,R2
  2920
2921
2922
2923
2924
2925
2926
2927
                   005037
012746
012746
         003144
                              001264
                                                                                          :CLEAR ESCAPE
:SET PRIORITY
                                                            CLR
                                                                      SESCAPE.
         003150
                             000000
                                                 NEWPAS: MOV
                                                                      #PRO,-(SP)
         003154
                             003162
                                                            MOV
                                                                      #16$,-(SP)
         003160
                   000002
                                                            RTI
         003162
                                                 16$:
                                                  .SBITL **BASIC INTERFACE AND OPTION TESTS
                                                  2928
2929
2930
                                                  : *TEST 1
                                                            RK611 BASE ADDRESS TEST
CHECK THAT READING THE RK611 BASE ADDRESS (RKCS1) DOES NOT CAUSE A NON-EXISTANT MEMORY TRAP. IF A TRAP OCCURS
  2931
                                                            THE PROGRAM IS HALTED.
  2932
2933
2934
2935
2936
2937
         003162
                   000004
                                                  TST1:
                                                            SCOPE
                                                                                       :: DO 100 ITERATIONS
: CLEAN OFF STACK
         003164
                   012737
                              000100
                                       001262
                                                            MOV
                                                                      #100, STIMES
                                                                      #STACK, SP
                   012706
                             001100
                                                            MOV
         003176
                   012701
                              000004
                                                            MO.V
                                                                      #4.R1
                                                                                          :SET POINTER TO VECTOR
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 57
CZR6KGO RK6 FCTNL CTRL DIAG
              28-AUG-81 15:16
                                                     RK611 BASE ADDRESS TEST
CZR6KG.P11
        003202
                 012146
  2938
2939
                                                     MOV
                                                              (R1)+,-(SP)
                                                                                :STORE OLD VECTOR CONTENTS
                                                              (R1),-(SP)
#4,R1
                                                     MOV
        003206
003212
003216
003222
                 012701
                          000004
034434
                                                     MOV
  2940
                                                                                 :RESET POINTER
                 012721
012711
013702
005037
                                                              #NEXINT (R1) + #PR7 (R1)
$BASE R2
  2941
2942
2943
                                                     MOV
                                                                                SET VECTOR TO NEM TEST HANDLER
                          000340
                                                     MOV
                                                                                :SET PRIORITY
                          001352
                                                     MOV
                                                                                SET POINTER TO RK611 BASE ADDRESS
  2944
2945
2946
2947
2948
        003226
                          001662
                                                     CLR
                                                              INTSET
                                                                                :CLEAR INTERRUPT COUNTER
                 012762
        003232
                          000000
                                   000000
                                                     MOV
                                                              #0. RKCS1(R2)
                                                                                :WRITE CS1 TO SEE IN NEM WILL SET
        003240
                                                     NOP
        003242
                 000240
                                                     NOP
                 000240
                                                     NOP
  2949
2950
2951
                                                              INTSET
        003246
                          001662
                                                     TST
                                                                                ; TEST IF COUNTER IS O
        003252
                 001406 012737
                                                                                : YES - SKIP ERROR REPORT
                                                     BEO
                                                              15
        003254
                          053405 001360
                                                     MOV
                                                              #EM1, EM1N
                                                                                :MESSAGE (NON-EXISTANT MEMORY TRAP ERR)
  2952
2953
        003262
                                                     ERROR
                 104001
        003264
                 000137
                                                     JMP
                          043724
                                                              CTRHLT
                                                                                : GO TO CONTROLLED HALT
  2954
        003270
                 012701
                          000006
                                            18:
                                                     MOV
                                                              #6.R1
                                                                                :RESTORE VECTOR
        003274
                 012611
  2955
                                                              (SP)+,(R1)
                                                     MOV
        003276
                                                              (SP) + , -(R1)
  2956
                 012641
                                                     MOV
 2957
2958
  2959
                                            :*TEST 2
                                                              INTERRUPT VECTOR ADDRESS TEST
  2960
2961
                                            : *
                                                     CHECK THAT THE INTERRUPT VECTOR FOR THE RK611 IS SET TO THE
                                                     EXPECTED ADDRESS. IF INTERRUPT VECTOR IS IN ERROR,
                                            : *
  2962
                                                     THE PROGRAM IS HALTED.
  2963
  2964
                                                              *****************
        003300
003302
003310
                 000004
012737
012762
  2965
                                            TST2:
                                                     SCOPE
  2966
2967
                                                              #100,$TIMES :: DO 100 ITERATIONS
#CLR,RKCS2(R2) : CLEAR SUBSYSTEM, SPECIFICALLY TO
                                   001262
                          000100
                                                     MOV
                          005000
                                   000010
                                                     MOV
                                                                                : CLEAR ANY OLD INTERRUPTS
  2968
                 005037
012762
  2969
        003316
                          001662
                                                     CLR
                                                                                 CLEAR INTERRUPT COUNTER
  2970
        003322
                                   000000
                                                     MOV
                                                              #RDY! IE , RKCS1(R2)
                                                                                        :WRITE CS1 TO FORCE INTERRUPT
  2971
        003330
                 000240
                                                     NOP
  2972
2973
2974
        003332
                 000240
                                                     NOP
        003334
                                                     NOP
                 000240
        003336
                 005737
                                                                                : TEST IF INTERRUPT OCCURRED
                          001662
                                                     TST
                                                              INTSET
        003342
  2975
                 001011
                                                                                : YES - SKIP ERROR REPORT
                                                     BNE
  2976
2977
        003344
                 105737
                          001103
                                                              SERFLG
                                                                                : TEST IF ERFLG ALREADY SET. IF SO THE
                                                     TSTB
                                                                                : INTERRUPT WENT TO THE WRONG VECTOR
  2978
                                                                                ; AND MESSAGE HAS BEEN REPORTED.
  2979
        003350
                 001004
                                                     BNE
                                                                                :THEREFORE - EXIT
                 012737
        003352
  2980
2981
2982
2983
2984
2985
2986
2987
2988
                                   001360
                                                              #EM1, EM1N
                                                                                :MESSAGE (NO INTERRUPT)
                          053405
                                                     MOV
        003360
                 104001
                                                     ERROR
                 000137
                          043724
                                                     JMP
                                                              CTRHLT
                                                                                : GO TO CONTROLLED HALT
        003366
                                            .SBTTL **STATUS VALID TESTS
                                            2989
                                            : * TEST 3
                                                              SELECT ALL DRIVES
  2990
  2991
                                                     IF NOT RUNNING IN APT AUTOMATIC ENVIRONMENT.
  2992
                                                     DETERMINE WHAT DRIVES ARE ON-LINE BY
  2993
                                                     SELECTING ALL DRIVES. IF NON-EXISTENT DRIVE REPORTED
```

```
CZR6KG.P11
                28-AUG-81 15:16
                                              13
                                                        SELECT ALL DRIVES
  2994
2995
                                                        MAKE SURE STATUS VALID IS RESET. IF DRIVE
                                                        PRESENT MAKE SURE NO ERROR EXISTS, DRIVE IS CYCLED UP. AND STATUS VALID SET, AND DSC RESET.
  2996
  2997
  2998
                                                        IF RUNNING IN APT AUTOMATIC ENVIRONMENT, THE DRIVES IDENTIFIED IN ETABLE ARE TESTED FOR NO ERROR, DRIVE
  2999
  3000
                                                        CYCLED UP, AND STATUS VALID SET.
  3001
  3002
                                                        IF LOCATION 41 INDICATES THE XXDP MEDIA IS ON
                                                        THE RKOG, DRIVE O WILL ONLY BE TESTED IF THE PARAM
  3003
  3004
                                                        START (214) WAS USED. IF THE AUTOMATIC START (200)
  3005
                                                        IS USED, DRIVE O IS NOT TESTED. THE RESTART (204)
  3006
                                                        WILL RETAIN THE TEST STATUS OF DRIVE O.
  3007
  3008
                                                        IF THE PARAM START IS USED, THE OPERATOR MUST
  3009
                                                        EITHER PLACE DRIVE O OFF LINE IF IT IS NOT TO BE TESTED
  3010
                                                        OR UNLOADED AND A SCRATCH MEDIA MOUNTED IF IT IS TO
  3011
                                                        BE TESTED. THE PROGRAM WILL MONITOR OFF LINE AND VOLUME
  3012
                                                        VALID TO DETERMINE THE TEST STATUS OF DRIVE O.
  3013
  3014
                                                        ALL DRIVES TO BE TESTED MUST BE ON-LINE, CYCLED UP, AND
  3015
                                                        WRITE LOCK RESET. ADDRESSES OF DRIVES THAT ARE NON-
                                                       EXISTANT EITHER BECAUSE THE DRIVE DOES NOT EXIST OR IS OFF-
LINE ARE USED TO VERIFY NON-EXISTANT DRIVE ERROR DETECTION.
  3016
  3017
  3018
                                                        DRIVES THAT ARE ON-LINE BUT NOT CYCLED UP OR ARE WRITE
  3019
                                                        LOCKED ARE NOT TESTED.
  3020
3021
3022
3023
3024
3025
                                                        AT COMPLETION OF THE TEST A MESSAGE WILL BE GIVEN TO
                                                         IDENTIFY THE DRIVES TO BE USED IN TESTING.
                                                        NOTE: THIS TEST MUST BE RUN AT LEAST ONCE BEFORE
                                                                 ANY OTHER TEST THAT FOLLOWS.
  3026
3027
                                                                 THE DETERMINATION OF WHETHER EACH DRIVE IS AN
                                                                 RKO6 OR AN RKO7 IS MADE IN THIS TEST, AND A
  3028
                                                                 TABLE IS MADE ACCORDINGLY.
  3029
  3030
                                               TST3:
         003366
                  000004
                                                        SCOPE
```

MOV

CLR

MOV

MOV

RTI.

MOV

MOV

MOV

MOV

BITB

BNE

TST

BNE

BEQ

15:

TSSINIT

ERROR

#50., STIMES

#PRO,-(SP)

#1\$,-(SP)

RKVEC,R1

#PR7, (R1)

#\$DEVM,R3

50\$

50\$

92\$

\$PASS

#BIT7, SENVM

#DRVRPT, OPTFLG

DTYPE

3

:: DO 50. ITERATIONS

: RK611 INTERRUPTS

: CALL SUBSYSTEM CLEAR AND TEST

GET ADDRESS OF DEVICE MAP

: TEST IF DRIVE #'S REPORTED

:NO - SKIP TO DRIVE SELECT TEST

:NO - SKIP DRIVE SIZING.

: TEST IF SHOULD SIZE

: TEST IF FIRST PASS

:NO - GOTO SIZING

:SET PROCESSOR PRIORITY TO ALLOW

: ASSUME RKO6

GET VECTOR

#INTHLR, (R1) + : LOAD INTERRUPT VECTOR

MACY11 30(1046) 28-AUG-81 15:17

CZR6KGO RK6 FCTNL CTRL DIAG

003370

003376

003402

003404

003406

003416

003420

003424

003430

003434

003440

003446

003450

003454

003456

003464

3031

3032 3033

3034 3035

3036 3037

3038

3039 3040

3041

3042 3043

3044 3045

3046

3047

3048

012737

005037

104416

104003

012746 012746

000002

013701

001007 005737

001004 032737

001402

000062

000000

003420

001620

034442

000340

001354

000200

001304

004000

001262

001317

001664

PAGE 58

| SEQ 0058 |
|----------|

| CZR6KGO CZR6KG.I | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 13 | 28-AUG | -81 15:17 PAGE ALL DRIVES | 59 |
|--|--|--|--|--------------------------------------|---------------------------|---|---|---|
| 3050 3051 3052 3053 3054 3055 3056 3057 3058 3060 3061 3062 3063 | 003466 003472 003474 003502 003504 003512 003514 003520 003536 003536 003542 | 000137 005013 123727 001111 022737 001411 104401 052737 042737 000477 104401 005037 005037 | 004142 000041 000001 051236 000001 051236 001610 001232 | 000013 001624 001666 001664 | 50\$: 92\$: | JMP CLR CMPB BNE CMP BEQ TYPE BIC BR TYPE CLR CLR | 11\$ (R3) @#41,#13 77\$ #1,SRTFLG 2\$,OPRO07 #BITO,DRVDRP #DOTST,OPTFLG 7\$,OPRO06 L.CS2 \$TMP4 | :CLEAR DEVICE MAP :TEST IF RK06 IS LOAD DEVICE :NO - SKIP :WAS START AT PARAM? :YES - SKIP :NO TEST OF DRIVE O :SET DRIVE O DROPPED :DR FLAG - NO TEST DRIVE O :MESSAGE - SWAP PACK ON DRIVE OFF LINE. :SET TO DRIVE O :CLEAR FOR USE AS A SWITCH |
| 3064 3065 | 003552 003560 003566 | 012737 012737 104417 | 000101 | 001600 001264 | 3\$: | MOV MOV TLOADRK | #SELDRY.L.CS1 #4\$,\$ESCAPE | :LOAD FOR SELECT :SET UP ESCAPE IN CASE OF ERR :LOAD RK & DO SELECT |
| 3067 3068 3069 | 003570 | 104423 | | | | TWAT16 ERROR | 2 | ; WAIT 16MS FOR COMPLETION ; NOT DONE ON TIME |
| 3066 3067 3068 3069 3070 3071 3072 3073 3074 3075 3076 3077 | 003574 003576 003604 003606 003614 003616 003624 | 104420 032737 001431 032737 001014 032737 001406 | 100000 010000 000040 | 001540 001550 001554 | | TGETRK BIT BEQ BIT BNE BIT BEQ | #CERR,T.CS1 5\$ #NED,T.CS2 4\$ #DIYE,T.ER 26\$ | :GET RK REGISTER :TEST IF CERR :NO - SKIP :TEST IF NED :YES - SKIP :ELSE SEE IF DRIVE TYPE ERROR :BR IF NO |
| 3078 3079 | 003626 | 012737 | 002000 | 001720 | | MOV | #CDT, DTYPE | ;ELSE SETUP FOR RK07 |
| 3080 3081 3082 3083 | 003634 003636 003640 | 104416 104003 000744 | | | | TSSINIT ERROR BR | 3 3 \$ | :INIT SUBSYS :NOT SUCCESSFUL :AND TRY AGAIN |
| 3084 3085 | 003642 003644 | 104421 104004 | | | 26\$: | T CHKOP ERROR | 4 :OR5.6.7 | CHECK THE OPERATION AND REPORT THE ERROR |
| 3086 3087 3088 3089 3090 3091 3092 3093 3094 3095 3096 | 003646 003652 003660 003666 003670 003674 003676 003704 003714 | 104401 042737 052737 000422 005737 001010 032737 001322 012737 000716 | 051236 000001 000001 001232 000200 177777 | 001664 001666 001552 001232 | 4\$: 5\$: | TYPE BIC BIS BR TST BNE BIT BNE MOV BR | OPROO7 #DOTST.OPTFLG #BITO.DRVDRP 7\$ \$TMP4 6\$ #DRDY.T.DS 3\$ #-1.\$TMP4 3\$ | :IS ABORTED :TYPE NO TEST OF DRIVE O :DR FLAG - NO TEST OF DRIVE O :SET DRV O AS DROPPED :SKIP OVER WAIT FOR PACK MOUNT :TEST FLAG DRIVE READY HAS RESET :YES - SKIP TO CHECK IF IT IS SET AGAIN :ELSE CHECK READY :STILL SET - GET STATUS AGAIN :ELSE SET FLAG TO INDICATE READY WENT LOW :GO GET STATUS AGAIN |
| 3098 3099 | 003716 | 032737 | 000200 | 001552 | 6\$: | BIT | #DRDY,T.DS | :TEST IF READY SET AGAIN :NO - GO GET STATUS AGAIN |
| 3100 3101 3102 3103 3104 3105 | 003726 003734 003742 003744 003750 | 052737 012737 005000 012701 005037 | 000001 004042 000001 001720 | 001664 | 77\$: 7\$: | MOV CLR MOV CLR | #35\$,\$ESCAPE R0 #1,R1 DTYPE | :SET UP ESCAPE IN CASE OF ERR :CLEAR FOR DRIVE NUMBER COUNTER :SET BIT 0 AS DRIVE SELECTOR :INIT TO RKO6 |

| CZR6KGO RK6 | FCTNL CTRL DIAG 28-AUG-81 15:16 | MACY11 30(1046) | 28-AUG-81 | 15:17 DRIVES | PAGE | 60 |
|-------------|------------------------------------|-----------------|------------|-----------------|------|----|
| CZROKO.FII | 20-400-01 13:10 | 13 | SELECT MET | DHIVE | | |

| 3106 3107 3108 | 003754 003762 | 032737 | 000001 | 001664 | | BIT | #DOTST, OPTFLG | :TEST DRIVE 0? :NO - SKIP |
|--|--|--|------------------|------------------|--------------------------|---|--|---|
| 3108 3109 3110 3111 3112 3113 | 003764 | | | | 8\$: | TSSINIT ERROR | 3 | ; INITIALZE SUBSYSTEM ; ERROR IF NOT SUCCESSFUL |
| 3113 3114 3115 3116 | 003770 003774 004002 | 010037 012737 104417 | 001610 000101 | 001600 | | MOV MOV TLOADRK | RO.L.CS2 #SELDRV,L.CS1 | ;LOAD DRIVE NUMBER ;LOAD DRIVE SELECT ;LOAD RK REGS |
| 3117 3118 3119 | 004004 | 104423 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3120 3121 3122 3123 3124 3126 3127 3128 3129 3131 3133 3134 3137 3138 3139 3140 | 004010 004012 004020 004022 004030 004032 004040 004042 004046 004050 | 104420 032737 001031 032737 001404 032737 001403 050137 000406 | 001000 | 201552 | | TGETRK BIT BNE BIT BEQ BIT BEQ BIS BR | #CERR.T.CS1 10\$ #DRDY.T.DS 35\$ #WRL.T.DS 36\$ R1.DRVDRP 9\$ | GET RK REGS ;ERROR? ;YES - SKIP ;ELSE TEST IF DRIVE READY ;NO - SKIP ;ELSE TEST IF WRITE LOCKED ;NO - SKIP ;SET THIS BIT AS DROPPED DRIVE |
| 3130 3131 3132 3133 | 004050 004052 004054 004062 | 006300 | | 001722 | | AS! | RO | ;SET BIT - DRIVE PRESET IN MAP ;SET TABLE WITH DRIVE TYPE INFO |
| 3135 3136 3137 3138 3139 3140 3141 | 004064 004066 004070 004074 004076 004102 | 005200 006301 032701 001022 005037 000730 | 000400 | | 9\$: | INC ASL BIT BNE CLR BR | R0 R1 #BIT8,R1 11\$ DIYPE 8\$ | BUMPS TO NEXT DRIVE SHIFT DRIVE SELECTOR TO NEXT DRIVE. WAS LAST DRIVE DONE? BR IF YES ELSE INIT FOR RK06 TO TEST NEXT DRV |
| 3142 | 004104 004112 004114 004122 | 032737 001364 032737 001404 | 010000 000040 | 001550 001554 | 10\$: | BIT BNE BIT BEQ | #NED.T.CS2 9\$ #DTYE.T.ER 24\$ | :WAS CERR DUE TO NED? :YES - BUMP TO NEXT DRIVE :ELSE SEE IF DRIVE TYPE ERR :BR IF NO |
| 3147 3148 3149 | 004124 004132 | 012737 000714 | 002000 | 001720 | | MOV BR | #CDI.DTYPE 8\$ | :ELSE SET UP FOR RK07 ;AND TRY AGAIN |
| 3150 3151 3152 3153 3154 3155 | 004134 004136 004140 004142 004150 | 104421 104004 000000 032737 001037 | 004000 | 001664 | 24\$: 101\$: 11\$: | TCHKOP ERROR .WORD BIT BNE | 4 : OR5.6.7 0 #DRVRPT.OPTFLG 16\$ | :ELSE REPORT THE ERRORS :TEST IF SHOULD REPORT :NO - SKIP |
| 3156 3157 3158 3159 | 004152 004154 004156 004162 | 005713 001004 104401 000137 | 051317 043724 | | | TST BNE TYPE JMP | (R3) 12\$.OPR008 CTRHLT | :ANY DRIVE AVAILABLE? :BR IF NOT ZERO :ELSE REPORT NO DRIVES AVAILABLE :GO TO CONTROLLED HALT |
| 3160 3161 | 004166 | 012701 | 000200 | | 125: | MOV | #BIT7,R1 | ;SET DRIVE SELECTOR FOR DRIVE 7 |

| CZ | REKG.F | 211 2 | 8-AUG-81 | 15:16 | | 13 | SELECT | ALL DRIVES | |
|----|--------------------------------------|--|--|--|----------------------------|-------|--|--|---|
| | 5165 | 004172 004176 | 012700 104401 | 000007 051402 | | | MOV TYPE | #7,R0 .OPR009 | :SET DRIVE NUMBER TO 7 :TYPE PREFIX TO DRIVE TEST MESSAGE |
| | 164 165 166 167 | 004202 004204 | 030113 | | | 13\$: | BIT | R1 (R3) 15\$ | :TEST IF THIS DRIVE TO BE TESTED :YES - SKIP |
| | 168 | 004206 004210 004212 004214 004222 | 005300 006201 001373 052737 000412 | 004000 | 001664 | 14\$: | DEC ASR BNE BIS BR | RO R1 13\$ #DRVRPT, OPTFLG 16\$ | :ELSE DECREMENT DRIVE NUMBER :SHIFT BIT SELECTOR TO NEXT DRIVE DOWN :IF NOT SHIFTED OUT - LOOP :SET DRIVE #'S REPORTED FLAG :ELSE GO TO STATUS VALID TEST |
| | 3175 | 004224 004230 004236 | 010037 052737 104401 | 004140 000060 | | 15\$: | MOV BIS TYPE | RO,101\$ #BIT4:BIT5,101\$ | :PUT DRIVE NUMBER IN TYPE LOCATION :MAKE IT ASCIZ :TYPE IT |
| | 178 | 004240 004242 004246 | 004140 104401 000757 | 051053 | | | 101\$ TYPE BR | SPACE2 | :TYPE SOME SPACES :LOOP |
| | 5181 5182 5183 5184 5185 | 004250 004252 004256 004264 004272 004300 004304 | 005000 012701 012737 012737 012737 030137 001035 | 000001 177777 177777 004400 001666 | 001240 001630 001264 | 16\$: | CLR MOV MOV MOV BIT BNE | R0 #1,R1 #-1,\$TMP7 #-1,DRVBIT #18\$,\$ESCAPE R1,DRVDRP 18\$ | CLEAR DRIVE NUMBER COUNTER SET DRIVE SELECTOR TO DRIVE O SET \$TMP7 NEGATIVE SET DRIVE SELECT BIT NEGATIVE SET ESCAPE IN CASE OF ERR HAS DRIVE O BEEN DROPPED? YES - SKIP TO DRIVE INC. |
| | 189 | 004306 004310 | 104416 104003 | | | 17\$: | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM ERROR FOR BAD CLEAR |
| | 3192 3193 3194 | 004312 004316 004322 004326 | 010037 | 001610 001626 036134 000101 | 001600 | | MOV MOV JSR MOV | RO.L.CS2 RO.DRVNUM PC.GTYPO #SELDRV.L.CS1 | :SET DRIVE SELECT :SET DRIVE NUMBER :GET DRV TYPE :SET FOR DRIVE SELECT |
| | 197 | 004334 004336 004340 004342 004344 | 104417 104423 104002 030113 001026 | | | | ILOADRK IWAI16 ERROR BII BNE | 2 R1 (R3) 19\$ | :LOAD RK REGS :WAIT FOR INTERRUPT :ERROR TO SLOW/NOT COMPLETE :WAS THAT DRIVE AVAILABLE :YES - SKIP |
| | 3204 | 004346 004350 004352 004354 004356 | 104422 000000 000000 000001 104004 | | | | TCHKWE .WORD .WORD .WORD ERROR | 0 0 1 4 :0R5.6.7 | CHECK THAT ERROR OCCURRED NONE OF GROUP 1 NONE OF GROUP 2 NED IN GROUP 3 ERROR IF NO ERROR OR WRONG ERROR |
| | 209 210 3211 3212 | 004360 004366 004370 004376 | 032737 001404 012737 104003 | 100000 055527 | 001552 | | BIT BEQ MOV ERROR | #SVAL,T.DS 18\$ #EM47,EM3N | :DID STATUS VALID RESET? :YES - SKIP :ELSE MESSAGE (SVAL NOT RESET WITH NED) |
| | 3216 | 004400 004402 004404 004410 | 005200 006301 032701 001063 | 000400 | | 18\$: | INC ASL BIT BNE | R0 R1 #BIT8,R1 21\$ | ;BUMP TO NEXT DRIVE ;SHIFT DRIVE SELECT BIT ;ALL DRIVES CHECKED ;YES - EXIT |
| | 217 | 004412 | 030137 | 001666 | | | BIT | R1.DRVDRP | TEST IF DRIVE HAS BEEN DROPPED |

| ZR6KG. | P11 2 | 8-AUG-81 | 15:16 | TACTI | 13 | SELECT | -81 15:17 PAGE ALL DRIVES | |
|--|--|--|--------------------------------------|------------------|-------|---|--|--|
| 3218 3219 3220 3221 | 004416 004420 004422 004424 | 001370 000732 104421 104004 | | | 19\$: | BNE BR TCHKOP ERROR | 18\$ 17\$ 4 : OR5,6,7 | ;YES - GET NEXT DRIVE ;ELSE CHECK THIS DRIVE ;CHECK NO ERRORS SET ;REPORT ALL ERRORS |
| 3219 3220 32223 32223 32223 32223 32223 32236 32236 32239 32331 32333 32336 32336 32338 32338 32338 32338 | 004426 004434 004436 004444 | 032737 001004 012737 104003 | | 001552 001400 | | BIT BNE MOV ERROR | #SVAL,T.DS 20\$ #EM48,EM3N 3 | : CHECK SVAL SET : YES - SKIP : MESSAGE (NO SVAL FROM EXISTANT DR) |
| 3228 3229 | 004446 004454 | 012737 104417 | 000103 | 001600 | 20\$: | MOV TLOADRK | #PACK,L.CS1 | :ELSE SET TO DO PACK ACK :LOAD RK |
| 3231 3232 | 004456 004460 | 104423 104002 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3234 3235 | 004462 004464 | | | | | TCHKOP ERROR | 4 :OR5,6,7 | : CHECK FOR ANY ERRORS : YES - REPORT & ABORT TEST |
| 3240 | 004466 004474 004476 004504 004506 | 032737 001005 012737 104003 000734 | | 001552 001400 | | BIT BNE MOV ERROR BR | #VV.T.DS 22\$ #EM46.EM3N 3 | :DID VV SET :YES - SKIP :MESSAGE (VV DID NOT SET/ |
| 3241 3242 3243 3244 3245 3246 3247 3248 3249 3250 | 004510 004516 004520 004526 004534 004536 | 032737 001410 012737 012737 104003 000720 | 040000 056604 057044 | 001470 | 22\$: | BIT BEQ MOV MOV ERROR BR | #DSC.T.DS 23\$ #EMDSC.EM12N #EMSCLR.DF011A 3 | :TEST IF DSC RESET :YES - SKIP :'DSC NOT RESET RESULT OF SUBSYS CLEAR" |
| 3251 3252 3253 | 004540 004544 004546 004552 004556 | 005737 100315 010137 010037 000710 | | | 23\$: | TST BPL MOV MOV BR | DRVBIT 18\$ R1.DRVBIT R0.\$IMP7 18\$ | :TEST IF DRVBIT IS NEGATIVE :NO - SKIP :STORE DRIVE SELECT BIT :STORE DRIVE NUMBER TO BE TESTED |
| 3254 3255 3256 3257 3258 3259 3260 3261 3262 3263 | 004560 004560 004564 004572 004576 | 005037 013737 013701 004737 | 001264 001240 001626 036150 | 001626 | 21\$: | CLR MOV MOV JSR | \$ESCAPE \$TMP7,DRVNUM DRVNUM,R1 PC,GTYP1 | :REV 006 :LOAD LOWEST # DRIVE PRESENT INTO DRVNUM :GET DRV TYP |
| 3263 3264 3265 | 004602 004610 004612 | 023727 001002 000137 | 001624 043614 | 000002 | | CMP BNE JMP | SRTFLG.#2 25\$ ADJCLK | :TEST IF CLOCK ADJUST START :NO - SKIP :GO TO ADJUST CLOCK ROUTINE |
| 3266 3267 | 004616 | | | | 25\$: | | | |
| 3268 3269 | | | | | TEST | * * * * * * * * * * * * * * * * * * * | RELEASE ALL DRI | ves |
| 3264 3265 3266 3267 3268 3269 3270 3271 3272 3273 | | | | | | RELEASE SETS AND | ALL DRIVES. MAI D STATUS VALID I | KE SURE NO ERROR S RESET. |

| MACY11 | 30(1046) | 28-AUG-81 | 15:17 | K 5 PAGE | 63 | |
|--------|----------|-------------|--------|-------------|----|--|
| | 14 | RELEASE ALL | DRIVES | | | |

CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16

| 3274 3275 3276 3277 3278 | 004616 004620 004626 004630 | 000004 012737 104416 104003 | 000062 | 001262 | f\$14: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ::DO 50. ITERATIONS :INITIALIZE SUBSYSTEM :BAD INIT |
|--|--|--|--------------------------------------|------------------|---|--|--|---|
| 3280 3281 | 004632 004640 | 013737 012737 | 001626 000101 | 001610 | | MOV | DRVNUM.L.CS2 #SELDRV.L.CS1 | :SET DRIVE NUMBER :SET DRIVE SELECT |
| 3276 3277 3278 3279 3280 3281 3282 3283 3284 3286 3286 3286 3286 3287 3288 3290 3291 3292 3293 3293 | 004646 004650 004652 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3287 3288 | 004654 004656 | 104421 | | | | TCHKOP ERROR | 4 :OR5.6.7 | CHECK FOR ANY ERRORS : REPORT ANY ERRORS |
| 3289 3290 | 004660 | 012737 | 000010 | 001610 | | MOV | #RLS,L.CS2 | SET DRIVE RELEASE, STILL SET FOR SELECT |
| 3292 3293 3294 3294 | 004666 004670 004672 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 . | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3296 3297 3298 3299 3300 3301 3302 3303 | 004674 004676 004700 004706 004710 004716 004720 | 104421 104004 032737 001404 012737 104003 | | 001552 001400 | 1\$: | TCHKOP ERROR BIT BEQ MOV ERROR | 4 : OR 5, 6, OR #SVAL,T.DS 1\$ #EM49,EM3N 3 | ; CHECK FOR ANY ERRORS 7 : REPORT ALL ERRORS ; DID SVAL RESET? ; YES - SKIP ; MESSAGE (SVAL NOT RESET W/RELEASE) |
| 3304 3305 3306 | 004720 | 004737 | 036034 | | ::**** | 5 | NON-STANDARD MES | |
| 3307 3308 3309 3310 3311 3312 3313 | | | | | * | ERROR OF | NDARD MESSAGES. CCURS AND STATUS | LE DRIVES AND GET MAKE SURE NO VALID DOES NOT SET ESSAGES CAUSE STATUS |
| 3314 3315 3316 3317 3318 | 004724 004726 004734 004736 | 000004 012737 104416 104003 | 000062 | 001262 | 1515: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ;;DO 50. ITERATIONS ;CLEAR SUBSYSTEM ;BAD CLEAR MESSAGE |
| 3314 3315 3316 3317 3318 3319 3320 3321 3322 3322 3322 3322 3322 3322 | 004740 004744 004752 004760 004764 004766 004770 004772 | 012701 013737 012737 005037 104417 104423 104421 104404 | 000001 001626 000101 001616 | 001610 001600 | 1\$: | MOV MOV CLR TLOADRK TWAT16 ERROR TCHKOP ERROR | #1,R1 DRVNUM,L.CS2 #SELDRV,L.CS1 L.MR1 2 4;5,6 OR 7 | CLEAR SUBSYSTEM BAD CLEAR MESSAGE PRESET R1 FOR MESSAGE PAIR 1 LOAD DRV NUMBER LOAD SELECT COMMAND LOAD FOR STANDARD STATUS LOAD RK WAIT FOR INTERRUPT TO SLOW/NOT COMPLETE ERROR CHECK OPERATION REPORT ALL ERRORS |
| 3329 | 004776 | 032737 | 100000 | 001552 | | BIT | #SVAL,T.DS | TEST STATUS VALID SET |
| | | | | | | | | |

100000

056444

056461

000003

001552

001470

061112

CZR6KG.P11

005030

005032

005034

005036

005040

005042

005050

005052

005060

005066

005070

005074

005076

005100

005102

005112

005114

005116

005124

005132 005134

005136

005140

005142

3381 3382 3383

3384

3385

| 3330 | 005004 | 001007 | | | BNE | 2\$ | :YES-SKIP | , | | | | |
|----------------------|----------------------------|----------------------------|------------------|------------------|---------------------|---------------------------------------|-----------|-------|--------|----|-------|---------|
| 3333 3333 3334 | 005006 005014 005022 | 012737 012737 104011 | 056444 050250 | 001460 061112 | MOV MOV ERROR | #EMSVAL,EM11N #EMSELD,DF011A 11 | ;"SVAL NO | T SET | RESULT | OF | DRIVE | SELECT" |

2\$:

R1.L.MR1 :LOAD MESSAGE PAIR SELECT

TLOADRK TWAT16

:LOAD RK :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR

ERROR

MOV

MOV

BR

ERROR

TCHKOP 4 :5,6, OR 7 ERROR

: CHECK OPERATION :REPORT ALL ERRORS

BIT #SVAL, T.DS BEQ

1\$

: TEST STATUS VALID RESET : YES-SKIP

MOV

#EMSVAL, EM12N #EMNZPR, DF011A

"SVAL NOT RESET RESULT OF SEL W/ NON-O PAIR"

CMP #3,R1 BEQ 45 R1 INC

:WAS PAIR 3 SELECTED? : YES-SKIF BUMP TO NEXT PAIR

:SKIP TO DO IT.

45:

TS16:

3\$:

: *TEST 6 WRITING CS2 AND STATUS VALID

> SELECT AN AVAILABLE DRIVE. MAKE SURE STATUS VALID IS SET. WRITE COMMAND AND STATUS REGISTER 2. MAKE SURE STATUS VALID RESETS.

104416

104003

013737

012737

104417

104423

104002

104421

104004

005024 010137 001616

104417

104423

104002

104421

104004

032737

001407

012737

012737

104012

022701

001402

005201

000727

SCOPE MOV #50., STIMES TSSINIT 3 ERROR

:: DO 50. ITERATIONS : CLEAR SUBSYSTEM :BAD INIT ERROR

001610 001600

DRVNUM, L.CS2 #SELDRV, L. CS1 :LOAD DRIVE NUMBER :LOAD DRIVE SELECT

TLOADRK TWAT16 ERROR

MOV

MOV

:LOAD RK :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR

TCHKOP ERROR 4 :5.6. OR 7

CHECK OPERATION REPORT ALL ERRORS

BIT #SVAL, T.DS BNE 15

: TEST STATUS VALID SET : YES-SKIP

MOV #EMSVAL,EM11N MOV #EMSELD, DF011A

"SVAL NOT SET RESULT OF DRY SELECT"

032737 005144 100000 001552 005152 001007 005154 012737 001460 056444 005162 012737 050250 061112

003170

104011

001626

000101

ERROR

| CZR6KG. | | 8-AUG-81 | | HACTIT | T10 | STATUS | VALID AND PARITY | ERROR |
|--|--------------------------------------|--------------------------------------|----------------------------|----------------------------|---|---|---|---|
| 3442 3443 3444 3445 3446 3447 3448 3449 | | | | | * | PARITY. CHANGE, AND STA ISSUE A AND MAKE ARE SET | MAKE SURE ATTEM DRPAR, CONTROLLE TUS VALID ARE SE CONTROLLER CLEAR E SURE ONLY DRIVE CLEAR ATTENTION AVAILIABLE DRIVE | |
| 3451 3452 3453 3454 3455 | 005334 005336 005344 005346 | 000004 012737 104416 104003 | 000062 | 001262 | TST10: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ;;DO 50. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 3456 3457 3458 3459 | 005350 005356 005364 | 013737 012737 012737 | 001626 000101 000020 | 001610 001600 001616 | | MOV MOV MOV | DRVNUM,L.CS2 #SELDRV,L.CS1 #PAT,L.MR1 | :LOAD DRIVE NUMBER :LOAD DRIVE SELECT :LOAD EVEN PARITY BIT |
| 3460 3461 3462 3463 | 005372 005374 005376 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | | :LOAD RK REGS-SELECT W/EVEN PARITY :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3464 3465 3466 3467 3468 | 005400 005402 005404 005406 | 104422 000011 000000 000000 | | | | TCHKWE DRPARERI .WORD .WORD | R!SPARERR 0 0 | CHECK OPERATION FOR EXPECTED ERROR DRIVE SELECTED DRIVE BUS PARITY ERROR CONTROLLER DETECTED DRIVE BUS PARITY ERROR |
| 3469 3470 | 005410 | 104004 | | | | ERROR | 4 : OR 5.6.7 | REPORT ANY DIFFERENCES |

| NL CTRL DIAG | MACY11 | 30(1046) | 28-AU | G-81 | 15:17 | B 6 PAGE | 67 |
|--------------------------------|--------|----------|--------|-------|-------|-------------|---------|
| NL CTRL DIAG 8-AUG-81 15:16 | | 110 | STATUS | VALID | AND | PARITY | ERROR |
| 013700 000/00 | | | MOV | #DIT | 0 00 | | - DOLLT |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL I 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 110 | 28-AUG | -81 15:17 PAGE VALID AND PARITY | 67 ERROR |
|--|--|--|----------------------------|----------------------------|-----------------|---------------------------------|---|---|
| 3471 | 005412 | 012700 | 000400 | | | MOV | #B118,R0 | ROUTINE TO DETERMINE WHICH BIT |
| 3471 3472 3473 3474 3475 3476 3477 3478 3481 3482 3483 3484 3486 3487 3488 3489 3491 3492 3493 | 005416 005422 005424 005426 005430 | 013701 001403 006300 005301 001375 | 001626 | | 2\$: | MOV BEQ ASL DEC BNE | DRVNUM,R1 3\$ R0 R1 2\$ | SHOULD BE SET IN ASOF TO INDICATE DRIVE ATTENTION. RO WILL HAVE THE BIT THAT SHOULD BE SET FOR THE DRIVE IN USE |
| 3479 3480 3481 3482 | 005432 005436 005440 005446 | 030037 001007 012737 012737 104011 032737 | 001556 056630 055055 | 001460 061112 | 3\$: | BIT BNE MOV MOV | RO.T.ASOF 4\$ #EMDA.EM11N #EMDPAR.DF011A | :TEST ATTENTION SET :YES-SKIP |
| 3483 3484 3485 | 005454 005456 005464 005466 | 104011 032737 001007 012737 | 040000 | 001540 001460 | 4\$: | ERROR BIT BNE | 11 #DI,T.CS1 5\$ | "DRV ATT NOT SET RESULT OF DRV PARITY ERR" TEST DRIVE INTERRUPT SET YES-SKIP |
| 3487 3488 3488 | 005474 | 012737 | 056564 055055 | 061112 | | MOV MOV ERROR | #EMDI,EM11N #EMDPAR,DF011A | "DRV INT NOT SET RESULT OF DRV PARITY ERR" |
| 3490 3491 | 005504 005512 | 032737 | 040000 | 001552 | 5\$: | BIT . | #DSC,T.DS | :TEST DRIVE STATUS CHANGE SET :YES-SKIP |
| 3492 3493 3494 3495 | 005514 005522 005530 | 012737 012737 104011 | 056604 055055 | 001460 061112 | | MOV MOV ERROR | #EMDSC,EM11N #EMDPAR,DF011A 11 | "DSC NOT SET RESULT OF DRV PARITY ERR" |
| 3496 3497 3498 3499 | 005532 005540 005542 005550 | 032737 001007 012737 012737 | 100000 056444 055055 | 001552 001460 061112 | 6\$: | BIT BNE MOV MOV | #SVAL,T.DS 7\$ #EMSVAL,EM11N #EMDPAR,DF011A | :TEST STATUS VALID SET :YES-SKIP |
| 3500 3501 | 005556 | 104011 | | | | ERROR | 11 | "SVAL NOT SET RESULT OF DRV PAR ERR" |
| 3502 3503 3504 | 005560 | 005037 | 001616 | | 7\$: | CLR | L.MR1 | ;CLEAR PAT IN MR1 |
| 3505 3506 | 005564 005572 | 052737 104417 | 100000 | 001600 | | BIS TLOADRK | #CCLR,L.CS1 | CLEAR CONTROLLER LOAD RK REGS TO DO CLEAR |
| 3509 3510 3511 | 005574 005576 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | :CHECK NO ERRORS SET :REPORT ALL ERRORS STILL SET |
| 3508 3509 3510 3511 3512 3513 3514 3515 | 005600 005604 005606 005614 | 030037 001007 012737 012737 | 001556 056630 | 001510 | | BIT BNE MOV | RO.I.ASOF 8\$ #EMDA.EM14N | :TEST ATTENTION STILL SET :YES-SKIP |
| 3516 | 005622 | 104014 | 056650 | 061112 | | MOV ERROR | #EMCCLR, DF011A | "DRV ATT RESET RESULT OF CONT CLR" |
| 3518 3519 | 005624 005632 | 032737 | 040000 | 001540 | 8\$: | BIT | #DI.T.CS1 | :TEST DRIVE INTERRUPT STILL SET :YES-SKIP |
| 3516 3517 3518 3519 3520 3521 3522 3523 3524 3525 3526 | 005634 005642 005650 | 012737 012737 104014 | 056564 056650 | 001510 061112 | | MOV MOV ERROR | #EMDI EM14N #EMCCLR, DF011A 14 | "DRV INT RESET RESULT OF CONTROLLER CLR" |
| 3524 | 005652 | 012737 | 000101 | 001600 | 9\$: | MOV | #SELDRV,L.CS1 | :LOAD SELECT DRIVE |
| 3526 | 005660 | 104417 | | | | TLOADRK | | :LOAD RK REGS |

| | CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T10 | | -81 15:17 PAGE VALID AND PARITY | |
|---|--|--|--|----------------------------|------------------|-----------------|-----------------------------------|--|--|
| | 3527 3528 | 005662 005664 | 104423 104002 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 3528 3529 3530 3531 3533 3534 3535 3536 3537 3538 3539 3540 | 005666 005670 005672 005674 | 104422 000010 000000 000000 | | | | TCHKWE .WORD .WORD .WORD | 000010 | CHECK THAT ERRORS ARE SET DPAR SET (NO SPAR 1, REPORT ANY DISCREPENCIES |
| | 3535 3536 3537 3538 | 005676 005700 005704 005706 005714 | 104004 030037 001007 012737 012737 | 001556 056630 055055 | 001460 061112 | | ERROR BIT BNE MOV MOV | 4 : OR 5.6.7 RO.T.ASOF 10\$ #EMDA,EM11N #EMDPAR,DF011A | :TEST ATTENTION STILL SET. :YES-SKIP |
| | 3539 3540 | 005722 | 104011 | | | | ERROR | 11 | "DRV ATT NOT SET RESULT OF DRV PARITY ERR" |
| | 3542 3543 | 005724 005732 005734 005742 | 032737 001007 012737 012737 | 040000 | 001540 | 10\$: | BIT BNE MOV | #DI,T.CS1 11\$ #EMDI,EM11N | :TEST DRIVE INTERRUPT STILL SET :YES-SKIP |
| | 3545 | 005750 | 104011 | 055055 | 061112 | | MOV ERROR | #EMDPAR, DF011A | "DRV INT NOT SET RESULT OF DRV PARITY ERR" |
| | 3547 3548 3549 | 005752 005760 005762 | 032737 001007 012737 | 040000 056604 | 001552 | 11\$: | B!T BNE MOV | #DSC.T.DS 12\$ #EMDSC.EM11N | :TEST STATUS CHANGE STILL SET :YES-SKIP |
| | 3550 3551 | 005770 | 012737 | 055055 | 061112 | | MOV ERROR | #EMDPAR, DF011A | "DSC NOT SET RESULT OF DRV PARITY ERR" |
| - | 3554 3555 | 006000 006006 006010 | 032737 001007 012737 | 100000 | 001552 | 12\$: | BIT BNE MOV | #SVAL,T.DS 13\$ #EMSVAL,EM11N | :TEST STATUS VALID STILL SET :YES-SKIP |
| | 3556 3557 3558 | 006016 006024 | 012737 | 055055 | 061112 | | MOV ERROR | #EMDPAR, DF011A | "SVAL NOT SET RESULT OF DRV PARITY ERR" |
| | 3559 3560 | 006026 | 052737 | 100000 | 001600 | 13\$: | BIS | #CCLR,L.CS1 | CLEAR CONTROLLER |
| - | 3561 3562 3563 | 006034 | 104417 | | | | TLOADRK | | :LOAD RK REGS (DO CLEAR) |
| - | 3564 3565 3566 | 006036 006042 | 012701 012737 | 000001 | 001600 | | VOM VOM | #1,R1 #SELDRV,L.CS1 | ; SET COUNTER TO SELECT STATUS PAIR ; LOAD DRIVE SELECT |
| | 3567 3568 3569 3570 | 006050 006054 006056 006060 | 010137 104417 104423 104002 | 001616 | | 14\$: | MOV TLOADRK TWAT16 ERROR | R1,L.MR1 | ;LOAD STATUS PAIR SELECTION ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| | 3572 3573 3574 | 006062 006064 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | CHECK IF ANY ERRORS SET : REPORT ALL ERRORS SET. |
| | 3576 3577 3578 | 006066 006072 006074 006102 006110 | 030037 001007 012737 012737 104014 | 001556 056630 056461 | 001410 061112 | | BIT BNE MOV MOV ERROR | RO.T.ASOF 15\$ #EMDA,EM4N #EMNZPR,DF011A | :TEST ATTENTION STILL SET :YES-SKIP :"ATTENTION RESET RESULT OF NON-O PAIR SEL" |
| | | 006112 006120 | 032737 001007 | 040000 | 001540 | 15\$: | BIT | #DI.T.CS1 | |
| | | | | | | | | | |

| CZR6KGO | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T10 | 28-AUG | -81 15:17 PAGE VALID AND PARITY | 69 ERROR |
|--|--|--|----------------------------|------------------|-----------------|---|---|---|
| 3583 3584 3585 | 006122 006130 006136 | 012737 012737 104014 | 056564 056461 | 001510 061112 | | MOV MOV ERROR | #EMDI,EM14N #EMNZPR,DF011A 14 | "DRV INT RESET RESULT OF NON-O PAIR SELECT" |
| 3587 3588 3589 | 006140 006142 006146 | 005201 022701 001340 | 000004 | | 16\$: | INC CMP BNE | R1 #4,R1 14\$ | :BUMP PAIR SELECT ;ALL PAIRS DONE? ;NO-LOOP |
| 3591 | 006150 | 005037 | 001616 | | | CLR | L.MR1 | CLEAR MR1 |
| 3593 | 006154 | 012737 | 000105 | 001600 | | MOV | #CLEAR,L.CS1 | :LOAD DRIVE CLEAR |
| 3584 3585 3586 3587 3588 3589 3591 3591 3592 3594 3596 3597 3598 3601 3603 3604 3605 | 006162 006164 006166 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :DO DRIVE CLEAR ;WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 3599 3600 3601 | 006170 006172 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | CHECK FOR ANY ERRORS REPORT ALL ERRORS |
| 3602 3603 3604 3605 | 006174 006200 006202 | 012701 005301 001376 | 000020 | | 17\$: | MOV DEC BNE | #20,R1 R1 17\$ | ;SET COUNT FOR SHORT WAIT ;TO ALLOW CONTROLLER TIME TO POLL ;DRIVES |
| 3606 3607 3608 3609 3610 3611 3612 3613 | 006204 006206 006212 006214 006222 006230 | 104420 030037 001407 012737 012737 104012 | 001556 056630 050276 | 001470 061112 | | TGETRK BIT BEQ MOV MOV ERROR | RO,T.ASOF 18\$ #EMDA,EM12N #EMDCLR,DF011A | GET RK REGS :TEST ATTENTION RESET :YES-SKIP :"ATTENTION NOT RESET RESULT OF DRY CLEAR |
| 3615 3616 3617 | 006232 006240 006242 006250 006256 | 032737 001407 012737 012737 104012 | 040000 056564 050276 | | 18\$: | BIT BEQ MOV MOV ERROR | #DI,T.CS1 19\$ #EMDI,EM12N #EMDCLR,DF011A | :TEST DRIVE INTERRUPT RESET :YES-SKIP :'DRV INT NOT RESET RESULT OF DRIVE CLR'' |
| 3618 3619 3620 | 006260 | | | | 19\$: | | | |
| 3621 | | | | | | 1 | UNIT FIELD ERROR | R ON RELEASE |
| 3622 3623 3624 3625 3626 3627 3628 | | | | | * * * * * * * | DRIVE. | PUT CONTROLLER I SE COMMAND. CLOC F DIAGNOSTIC MODE | SELECT AN AVAILABLE IN DIAGNOSTIC MODE. ISSUE IN THROUGH PHASE ADDRESS 2. E. MAKE SURE UNIT FIELD |
| 3626 3627 3628 3629 3630 3631 3632 3633 3634 3635 3636 3637 | 006260 006262 006270 006272 | 000004 012737 104416 104002 | 000062 | 001262 | †\$T11: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ::DO 50. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 3635 3636 | 006274 | 013737 | 001626 | 001610 | | MOV | DRVNUM, L.CS2 #SELDRV, L.CS1 | :SELECT A DRIVE :DO DRIVE SELECT |
| 3637 3638 | 006310 | 104417 | | | | TLOADRK | | :LOAD RK |
| | | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(10 CZR6KG.P11 28-AUG-81 15:16 | | | | | | 30(1046) T11 | 28-AUG- | 28-AUG-81 15:17 PAGE 70 UNIT FIELD ERROR ON RELEASE | | |
|--|--|--------------------------------------|--------------------------------------|------------------|------------------|-----------------|----------------------------------|---|--|--|
| | 3639 3640 3641 | | 104423 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR | |
| | 3642 3643 3644 | | 104421 | | | | TCHKOP ERRCR | 4 : OR 5,6,7 | : CHECK FOR ANY ERRORS : REPORT ALL ERRORS. | |
| | 3645 3646 | 006322 006330 | 052737 012737 | 000010 000040 | | | BIS MOV | #RLS,L.CS2 #DMD,L.MR1 | :LOAD RELEASE :SET DIAGNOSTIC MODE | |
| | 3647 3648 | 006336 | 104417 | | | | TLOADRK | | :LOAD RK | |
| | 3649 3650 3651 3652 3653 | 006340 006344 006345 | 004437 023 002 | 036316 | | | JSR .BYTE .BYTE | R4.MCLOCK | CALL MAINT CLOCK NUMBER OF PHASES NUMBER OF CLOCK XISTIONS | |
| | 3654 | 006346 | 042762 | 000040 | 000026 | | BIC | #DMD,RKMR1(R2) | CLEAR DIAG MODE | |
| | 3654 3655 3656 3657 3658 3659 3660 | 006354 006356 | 104423 104002 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETED | |
| | 3659 3660 3661 3662 3663 | 006360 006362 006364 006366 | 104422 000000 000000 000004 | | | | TCHKWE .WORD .WORD | | CHECK OPERATION WITH ERROR UNIT FIELD ERROR | |
| | 3664 3665 3666 | 006370 006372 006374 | 104004 104416 104002 | | | | TSSINIT ERROR | 2 | : CLEAR SUBSYSTEM TO INSURE UFE RESETS | |
| | 3667 3668 3669 3670 3671 3672 3673 3674 3675 | | | | | *TEST | 2 UNIT FIELD ERROR ON SELECT | | | |
| | | | | | | | DRIVE. A SELECTED TURN OF | UE A SUBSYSTEM CLEAR. SELECT AN AVAILABLE VE. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE ELECT COMMAND WITH MESSAGE ID = 3 AND DRIVE ECTED = 0. CLOCK THROUGH PHASE ADDRESS 6. N OFF DIAGNOSTIC MODE. MAKE SURE UNIT FIELD OR SETS. | | |
| | 3676 3677 3678 3679 3680 3681 | 006376 006400 006406 006410 | 000004 012737 104416 104003 | 000062 | 001262 | 15112: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ::DO 50. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR | |
| | 3683 3684 | 006412 006420 | 013737 012737 | 001626 000101 | 001610 001600 | | MOV MOV | | :LOAD DRIVE NUMBER :LOAD DRIVE SELECT | |
| | 3680 3681 3682 3683 3684 3685 3686 3687 3688 3689 3690 3691 3692 3693 | 006426 006430 006432 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE | |
| | 3690 3691 | 006434 006436 | 104421 104004 | | | | T CHKOP ERROR | 4 : OR 5.6.7 | : CHECK FOR ANY ERROR : REPORT ALL ERRORS | |
| | 3693 3694 | 006440 006446 | 012737 005037 | 000043 001610 | 001616 | | MOV CLR | #DMD!BIT1!BIT0, | L.MR1 :LOAD DIAG MODE & MSG PAIR 3 :LOAD FOR DRIVE 0 | |
| | | | | | | | | | | |

| | RK6 FCT P11 2 | NL (TRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T12 | 28-AUG UNIT FI | -81 15:17 PAGE ELD ERROR ON SEL | 71 ECT | |
|--|--|--|--------------------------------------|----------------------------|-----------------|--|---|---|-----|
| 3695 3696 | 006452 | 104417 | | | | TLOADRK | | ;LOAD RK | |
| 3697 3698 3699 3700 | 006454 006460 006461 | 004437 026 002 | 036316 | | | JSR .BYTE .BYTE | R4, MCLUCK D22 2 | :CALL MAINTENANCE CLOCK :THROUGH PHASE 6 :PLUS 2 TRANSITIONS | |
| 3701 3702 | 006462 | 042762 | 000040 | 000026 | | BIC | #DMD, RKMR1(R2) | CLEAR DIAG MODE | |
| 3703 3704 3705 3706 | 006470 006472 | 104423 104002 | | | | TWAT16 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETED ERROR | |
| 3707 3708 | 006474 | 013737 | 036132 | 006504 | | MOV | HOLD3,1\$ | :EXPECTED ERROR | |
| 3709 3710 3711 3712 3713 | 006502 006504 006506 006510 006512 | 104422 000000 000000 000004 104004 | | | 1\$: | TCHKWE .WORD .WORD .WORD ERROR | 0 | :CHECK OPERATION WITH ERROR :UNIT FIELD ERROR SHOULD SET :REPORT ANY DISCREPENCIES | |
| 3714" 3715 | | | | | .SBTTL | **ATTEN | TION HANDLING BY | CONTROLLER | |
| 3716 3717 3718 3719 3720 3721 3722 3723 3724 3725 3726 3727 3728 | | | | | **TEST | ISSUE A SUBSYSTEM CLEAR. ISSUE A RECALIBRATE. MAKE SURE STATUS VALID IS SET. CHECK THAT SECOND INTERRUPT OCCURS. AFTER SECOND INTERRUPT CHECK THAT STATUS VALID IS RESET. ISSUE SELECT AND MAKE SURE STATUS VALID SETS. CLEAR DRIVE. CHECK THAT DRIVE STATUS CHANGE SETS (BIT 14 OF DRIVE STATUS REGISTER) | | | |
| 3729 3730 3731 3732 3733 3734 3735 3736 3737 3738 3739 | 006514 006516 006524 006526 | 000004 012737 104416 104003 | 000062 | 001262 | is113: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ::DO 50. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR | *** |
| 3735 3736 | 006530 006536 | 013737 012737 | 001626 000113 | 001610 001600 | | MOV MOV | DRVNUM, L.CS2 #RECAL, L.CS1 | :LOAD DRIVE NUMBER :LOAD RECAL | |
| 3740 3741 3742 3743 3744 3745 3746 3747 3748 | 006544 006546 006550 006552 006556 006560 006566 006570 006576 006604 | 104417 104423 104002 005037 104420 032737 001010 012737 012737 104011 000463 | 001662 100000 056444 050337 | 001552 001460 061112 | | TLOADRK TWAT16 ERROR CLR TGETRK BIT BNE MOV MOV ERROR BR | 2 INTSET #SVAL,T.DS 1\$ #EMSVAL,EM11N #EMRCAL,DF011A 11 50\$ | :LOAD RK :WAIT FOR 1ST INTERRUPT :TO SLOW/NOT COMPLETE :CLEAR INTERRUPT FLAG :GET RK REGS :TEST SVAL SET :YES-SKIP :"SVAL NOT SET RESULT OF RECAL :ABORT TEST | • |
| 3749 3750 | 006610 | 104437 | | | 1\$: | TWATES | | :WAIT FOR INTERRUPT | |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 113 | | -81 15:17 PAGE | 72 |
|--|--|--|----------------------------|----------------------------|-----------------|---|---|--|
| 3751 3752 | 006612 006614 | 000401 | | | | BR BR | 2\$ 3\$ | :NO INTERRUPT RETURN :INTERRUPT RETURN |
| 3754 3755 | 006616 006624 | 012737 | 055737 | 001370 | 2\$: | MOV ERROR | #EM50,EM2N | ; ALTER MESSAGE "NO 2ND INTERRUPT OR IT WAS LATE" |
| 3752 3753 3754 3755 3756 3757 3760 3761 3762 3763 3764 3765 3768 3768 3768 3770 3771 3772 3773 3776 3777 | 006626 006630 006636 006640 006646 006654 | 104420 032737 001410 012737 012737 104012 000437 | 100000 056444 056671 | 001552 001470 061112 | 3\$: | TGETRK BIT BEQ MOV MOV ERROR BR | #SVAL,T.DS 4\$ #EMSVAL,EM12N #EM2INT,DF011A 12 50\$ | GET RK REGS TEST SVAC SET NOW NO-SKIP "'SVAL NOT RESET RESULT OF SECOND TEST" |
| 3765 3766 | 006660 006666 006670 | 032737 | 040000 | 001552 001460 | 45: | BIT | #DSC.T.DS 5\$ | :TEST DSC SET BY ATTENTION :YES-SKIP |
| 3768 3769 3770 | 00676 006704 006706 | 012737 012737 104011 000423 | 056604 056671 | 061112 | | MOV MOV ERROR BR | #EMDSC,EM11N #EM2INT,DF011A 11 50\$ | "DSC NOT SET RESULT OF SECOND INTERRUPT" |
| 3772 | 006710 | 012737 | 000101 | 001600 | 5\$: | MOV | #SELDRV,L.CS1 | :LOAD DRIVE SELECT |
| 3774 3775 3776 | 006716 006720 006722 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMFLETE ERROR |
| 3778 | 006724 | 104421 | | | | TCHKOP | | CHECK FOR ANY ERRORS |
| 3779 3780 3781 | 006726 | 104004 | | | | ERROR | 4 : OR 5.6.7 | REPORT ALL ERRORS |
| 3782 3783 3784 3785 3786 3787 3788 3788 | 006730 006736 006740 006746 006754 006756 | 032737 001007 012737 012737 104011 | 100000 056444 050250 | | 50\$: | BIT BNE MOV MOV ERROR | #SVAL,T.DS 50\$ #EMSVAL,EM11N #EMSELD,DF011A | :TEST SVAC SET :YES-SKIP :"SVAL NOT SET RESULT OF DRV SEL. |
| 3789 3790 | | | | | *TEST | 14 | SINGLE INTERRUP | T FROM ATTENTION |
| 3791 3792 3793 3794 3795 | | | | | | DRIVE A | TTENTION. LOWER | PRIORITY AGAIN AND MAKE DOES NOT OCCUR. CLEAR DRIVE. |
| 3796 3797 3798 3799 3800 3801 3802 3803 3804 3805 3806 | 006756 006760 006766 006770 | 000004 012737 104416 104003 | 000062 | 001262 | is114: | SCOPE MOV TSSINIT ERROR | #50.,\$TIMES | ::DO 50. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 3801 3802 | 006772 007000 | 013737 012737 | 001626 000117 | 001610 001600 | | MOV MOV | DRVNUM,L.CS2 #SEEK,L.CS1 | :LOAD DRIVE NUMBER :LOAD SEEK DCYL LEFT AT 0. |
| 3805 3806 | | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETED ERROR |

| 3 | 807 | 007014 | 10//20 | | | | | | |
|-----|---|------------------|----------------------------|--------|---------------|---------|------------------|-------------------------------|--|
| 3 | 810 | | 104420 | | | | TGETRK | | GET RK REGS |
| 3 | 811 | 007016 | 032737 | 040000 | 001540 | | BIT | #DI.T.CS1 | :TEST DI SET |
| 3 | 813 | 007026 | 001010 012737 012737 | 056564 | 001460 | | MOV | #EMDI, EMIIN | :YES-SKIP |
| 3 | 815 | 007034 | 104011 | 056712 | 061112 | | MOV ERROR | #EMSKSF.DF011A | "DI NOT SET RESULT OF SEEK TO SELF" |
| 3 | 816 | 007044 | 000417 | | | | BR | 50\$ | TO SEE MESSEL OF SEEK TO SEEL |
| 3 | 818 | 007046 | 012700 | 000031 | | 2\$: | MOV | *25 00 | LICAN AND DECREMENT A COUNT TO |
| 777 | 820 | 007052 | 005300 | 00003 | | 35: | DEC | #25.,R0 R0 | :LOAD AND DECREMENT A COUNT TO :ZERO. GIVE CONTROLLER A CHANCE TO |
| 3 | 822 | 007054 | 001376 | | | | BNE | 3\$ | INTERRUPT AGAIN. ERROR IF IT DOES. |
| 3 | 823 | 007056 | 022737 | 000001 | 001662 | | CMP BEQ | #1 INTSET | CHECK ONLY ONE INTERRUPT OCCURRED |
| 3 | 825 | 007066 | 012737 | 057064 | 001500 | | MOV | #EMMI,EM13N | , 763-3KIP |
| 3 | 827 | 007102 | 012737 | 056712 | 061112 | | MOV ERROR | #EMSKSF, DF011A | "MULTIPLE INTERRUPTS RESULT OF SEEK TO SELF" |
| 3 | 809 810 811 811 811 811 811 811 811 | 007104 | 104421 | | | 50\$: | TCHKOP | | CHECK FOR ANY ERRORS |
| 3 | 830 831 | 007106 | 104004 | | | ;;**** | ERROR | 4 :OR 5.6.7 | REPORT ALL ERRORS |
| 3 | 832 | | | | | : *TEST | 15 | RESET ATTENTION | IS WITH UNIBUS INIT |
| 3 | 834 | | | | | : | DO A SE | EK TO CYLINDER O | ON ALL AVAILIABLE DRIVES. |
| 3 | 836 | | | | | :: | ISSUE A | RESET. MAKE SU | RE ALL ATTENTION RESET. |
| 3 | 837 838 | 007110 | 000004 | | | TST15: | SCOPE | ********* | ******** |
| 3 | 839 840 | 007112 | 012737 | 000005 | 001262 | | MOV | #5.,\$TIMES | :: DO 5. ITERATIONS |
| 3 | 841 | 007122 | 104003 | | | | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| 3 | 842 843 | 007124 | 013737 | 001626 | 001610 | | MOV | DRVNUM, L.CS2 | ;LOAD DRIVE NUMBER |
| 3 | 844 845 | 007132 | 012737 | 000117 | 001600 | | MOV | #SEEK,L.CS1 | :LOAD SEEK (TO SELF-0) |
| 3 | 846 | 007140 | 104417 | | | | TLOADRK | | LOAD RK REGS |
| 3 | 848 | 007142 | 104423 | | | | TWAT16 ERROR | 2 | ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE |
| 3 | 847 848 849 851 851 855 855 855 855 855 855 855 855 | 007146 | 104420 | | | | TGETRK | | GET RK REGS |
| 3 | 851 | 007150 | 032737 | 040000 | 001540 | | BIT | #DI T CC1 | |
| 3 | 853 | 007156 | 001010 | | | | BNE | #DI.T.CS1 | : TEST DI SET : YES-EXIT |
| 3 | 855 | 007160 007166 | 012737 | 056564 | 001460 061112 | | MOV MOV | #EMDI,EM11N #EMSKSF,DF011A | |
| 3 | 856 857 | 007174 | 104011 | | | | ERROR BR | 11 50 \$ | "DI NOT SET RESULT OF SEEK TO SELF |
| 3 | 858 | 007200 | 005037 | 001662 | | 14. | | | CLEAD INTERCURY CO. T. T. |
| 3 | 860 | 007204 | 000005 | | | 18: | CLR RESET | INTSET | CLEAR INTERRUPT COUNTER OUNTBUS RESET |
| 3 | 861 862 | 007206 | 004737 | 045220 | | | JSR | PC.STKINT | RESET KEYBOARD INTERRUPT |
| | | | | | | | | | |

| CZR6K | GO RK6 FCT | NL CTRL | DIAG 15:16 | MACY11 | 30(1046) | 28-AUG RESET A | -81 15:17 PAGE TTENTIONS WITH U | 74 INIBUS INIT |
|--|--|--------------------------------------|----------------------------|------------------|----------|--------------------------|---|---|
| 386 386 386 386 386 386 387 387 387 387 388 388 388 388 388 388 | 3 007212 4 007216 5 007222 6 007230 | 005037 004737 022737 001372 | 001674 035314 000012 | 001674 | 58: | CLR JSR CMP BNE | | :CLEAR TICK COUNTER ;CALL TIMER ;COUNT 10 TICKS (MILLISECONDS)? ;NO - LOOP |
| 386 386 | 8 007232 9 007240 | 012762 004737 | 000100 034522 | 000000 | | MOV JSR | #IE.RKCS1(R2) PC.OPTIST | SET IE FOR ANY STRAY INTERRUPTS |
| 387 387 | 1 007244 2 007246 | 104423 | | | | TWAT16 BR | 2\$ | :WAIT 16 MS FOR AN INTERRUPT :NONE IS EXPECTED SO RETURN SHOULD BE |
| 387 387 | 4 007250 5 007256 | 012737 | 056727 056771 | 001500 061112 | | MOV MOV | #EMRSET, DF011A | HERE-BR TO CONTINUE TEST. |
| 387 | 6 007264 7 007266 | 104013 | | | | ERROR BR | 13 50\$ | "UNEXECUTED INTERRUPT RESULT OF RESET" |
| 387 388 388 | 7 007266 8 007270 9 007272 0 007300 | 104420 032737 001407 | 040000 | | 2\$: | TGETRK BIT BEQ | 50\$ | GET RK REGS TEST DI RESET YES-SKIP |
| 388 388 | 1 007302 2 007310 3 007316 | 012737 012737 104012 | 056771 | 001470 061112 | | MOV MOV ERROR | WEMDI, EM12N WEMRSET, DF011A | "DI NOT RESET RESULT OF RESET" |
| 388 | 5 007320 | | | | 50\$: | | | |
| 388 | 7 | | | | .SBTTL | **ILLEG | AL DISK ADDRESS | ERROR TESTS |
| 388 | 9 | | | | ;;**** | ****** | ***** | ****** |
| 389 | 1 | | | | :*TEST | | ILLEGAL DISK AD | |
| 389 389 389 389 389 389 389 | 6 | | | | ** | CLEAR C CHECKIN | ADDRESS ERROR A ONTROLLER AND CL G THAT BOTH IDAE | R O, HEAD 3. MAKE SURE ND SEEK INCOMPLETE SETS. EAR DRIVE. REPEAT FOR HEADS 4-7, AND SEEK INCOMPLETE SET FOR ETS FOR HEADS 4, 5, AND 6. |
| 389 | 8 | 000004 | | | | SCOPE | ****** | ******* |
| 389 390 390 390 390 390 390 390 391 | 0 007322 | 012737 | 0000012 | 001262 | 13110. | MOV MOV | #10.,\$TIMES #3,R1 | :: DO 10. ITERATIONS :PRESET FOR SELECTING TRACK 3 |
| 390 390 | 3 007334 4 007336 | 104416 | | | | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM |
| 390 390 | 6 007340 7 007346 | 012737 013737 | 000113 001626 | 001600 001610 | | MOV MOV | #RECAL.L.CS1 DRVNUM,L.CS2 | :SET UP TO RECAL :LOAD DRIVE |
| 390 | 007354 | 104417 | | | | TLOADRK | | :LOAD RK REGS |
| 391 391 391 | 007356 007360 | 104423 104002 | | | | TWAT16 ERROR | 2 | :WAIT FOR 1ST INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 391 | 007362 | 005037 | 001662 | | | CLR | INTSET | CLEAR INTERRUPT FLAG |
| 391 391 391 391 | 7 007370 | 104437 104002 | | | | TWAT8S ERROR | 2 | ; WAIT FOR INTERRUPT |
| ,,,, | | | | | | | | |

| C | ZR6KG0 ZR6KG.F | RK6 FCTI | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30 (1046) 116 | 28-AUG- | -81 15:17 PAGE DISK ADDRESS (PA | 75 ART 1) |
|---|--|--------------------------------------|--------------------------------------|----------------------------|------------------|------------------|----------------------------------|--|--|
| | 3919 | 007372 | 012737 | 007400 | 001110 | | MOV | #1\$, \$LPERR | SET LOCAL LOOP ON ERROR |
| | 3921 3922 3923 | 007400 007402 | 104416 | | | 1\$: | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM ;BAD INIT ERROR |
| | 3924 3925 3926 | 007404 007412 007420 | 013737 012737 110137 | 001626 000117 001607 | 001610 001600 | | MOV MOV MOVB | DRVNUM,L.CS2 #SEEK,L.CS1 R1,L.DT | :LOAD DRIVE NUMBER :LOAD SEEK :LOAD TRACK |
| | 3928 3929 3930 | 007426 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE |
| | 3921 3922 3923 3924 3924 3926 3926 3926 3931 3933 3933 3933 3933 3938 3938 3938 | 007432 007436 007440 007444 | 032701 001403 032701 001007 | 000001 | | | BIT BEQ BIT BNE | #BITO,R1 2\$ #BIT1,R1 3\$ | :TEST IF HEAD ADDRESS HAS BIT 0 :NO - SKIP :TEST IF HEAD ADDRESS HAS BOTH 0 AND 1 :YES-GO CHECK BOTH IDAE AND SKI SET |
| | 3937 3938 3939 3940 | 007450 007452 007454 | 104422 002000 000000 000000 | | | 2\$: | TCHKWE IDAERR 0 0 | | CHECK OPERATION WITH ERROR |
| | 3941 3942 3943 3944 | 007456 007460 007462 | 104004 104415 000406 | | | | ERROR SCOP1 BR | 4 : OR 5,6,7 4\$ | ;REPORT ALL DISCREPANCIES ;LOCAL LGOP ON ERROR |
| | 3946 | 007464 007466 007470 007472 | 104422 002002 000000 000000 | | | 3\$: | TCHKWE IDAERR!S | SKIERR | CHECK OPERATION WITH ERROR FILLEGAL DISK ADDRESS ERROR SEEK INCOMPLETE |
| | 3948 3949 3950 3951 3952 | 007474 | 104004 | | | | ERROR SCOP1 | 4 :OR 5,6.7 | REPORT ANY DISCREPANCIES :LOCAL LOOP ON ERROR TO 1\$ |
| | 3954 | 00/302 | 022701 | 000010 | | 4\$: | INC (MP BNE | R1 #8.,R1 1\$ | :ELSE BUMP TO NEXT ILLEGAL TRACK :ALL ILLEGAL TRACKS SELECTED? :NO-LOOP |
| | 3955 3956 3957 | | | | | *TEST | 17 | ILLEGAL DISK ADD | RESS (PART 2) |
| | 3956 3957 3958 3959 3960 3961 3962 | | | | | | THIS TES | DISK ADDRESS ERR | R 1000, HEAD O. MAKE SURE ROR SETS. CLEAR CONTROLLER AND DRIVE OR THE RKO7 BECAUSE THE RKO7 OGNIZE THE ILLEGAL DISK ADDRESS |
| | 3963 3964 3965 3966 3967 3969 3970 3971 3972 | 007510 007512 007520 007522 | 000004 012737 104416 104003 | 000012 | 001262 | 1S117: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| | 3969 3970 | 007524 007532 | 012737 013737 | 000113 001626 | 001600 001610 | | | #RECAL,L.CS1 DRVNUM,L.CS2 | :LOAD RECALIBRATE :LOAD DRIVE |
| | 3972 3973 | 007540 | 104417 | | | | TLOADRK | | :LOAD RK REGS |
| | | 007542 | 104423 | | | | TWAT16 | | :WAIT FOR 1ST INTERRUPT |
| | | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 117 | 28-AUG- | -81 15:17 PAGE DISK ADDRESS (PA | 76 ART 2) |
|--|--------------------------------------|----------------------------|----------------------------|------------------|---|--|---|--|
| 3975 | 007544 | 104002 | | | | ERROR | 2 | : TO SLOW/NOT COMPLETE ERROR |
| 3976 3977 | 007546 | 005037 | 001662 | | | CLR | INTSET | CLEAR INTERRUPT FLAG |
| 3979 3980 | 007552 007554 | 104437 104002 | | | | TWAT8S ERROR | 2 | ; WAIT FOR INTERRUPT |
| 3982 | 007556 | 012737 | 007564 | 001110 | | MOV | #1\$,\$LPERR | SET LOOP TO BYPASS RECAL |
| 3984 3985 | 007564 007566 | 104416 104003 | | | 1\$: | TSSINIT ERROR | 3 | ;CLEAR SUBSYSTEM |
| 3977 3978 3979 3980 3981 3982 3983 3984 3985 3986 3987 3988 3989 3990 3991 | 007570 007576 007604 007610 | 012737 | 001626 000117 001720 | 001610 001600 | • | MOV MOV TST BEQ MOV MOV | DRVNUM, L.CS2 #SEEK,L.CS1 DIYPE 2\$ #1777,L.DCYL # <idaerr!skierr< td=""><td>;LOAD DRIVE NUMBER ;LOAD SFEK ;SEE IF RKO6 ;BR IF YES ;ELSE LOAD RKO7 ILL CYL ;4\$;EXP RKO7 ERR</td></idaerr!skierr<> | ;LOAD DRIVE NUMBER ;LOAD SFEK ;SEE IF RKO6 ;BR IF YES ;ELSE LOAD RKO7 ILL CYL ;4\$;EXP RKO7 ERR |
| 3993 3994 3995 3996 3997 3998 | 007612 | 000137 | 007644 | | | BR JMP | TST20 | ;RKO7 CONTROLLER ;DOES NOT RECOGNIZE ;ILLEGAL DISK ADDRESS ;REV 006 THE ABOVE THREE LINES |
| 3999 4000 4001 | 007616 | 012737 | 001000 | 001614 | 2\$: ; | MOV MOV | #1000,L.DCYL #IDAERR,4\$ | :LOAD DKO6 ILL CYL :EXP RKO6 ERR |
| 4002 4003 4004 4005 | 007624 007626 007630 | 104417 104423 104002 | | | 3\$: | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4006 4007 4008 4009 | 007632 007634 007636 007640 | 002000 000000 000000 | | | 4\$: | TCHKWE .WORD .WORD .WORD | IDAERR 0 0 | CHECK OPERATION WITH ERROR DISK ADDRESS ERROR |
| 4010 4011 4012 | 007642 | 104004 | | | CDITI | ERROR | HEADER TESTS | REPORT ANY DISCREPANCIES |
| 4013 | | | | | | WK11E | | ******** |
| 4015 | | | | | *TEST | 20 | READ BAD SECTOR | |
| 4017 4018 4019 | | | | | ;* | TRACK 2 | READ DATA OF 400 TO GET THE FACTO FILE, 26 SECTOR M | O WORDS TO CYLINDER 632, DRY DETECTED BAD MODE. |
| 4020 | | | | | | CYLINDE | R 1456 IS USED FO | OR THE RKO7. |
| 4022 4023 4024 4025 4026 4027 | | | | | * | A SUCCES REMOVE TEST TH | SSFUL READ IS DOM THIS DRIVE FROM T | SECTOR 2, 4, 6, OR 10(8) UNTIL NE. IF NONE READ SUCCESSFULLY TEST. WHEN A READ IS SUCCESSFUL, OT AN ALIGNMENT PADK AND ATER USE. |
| 4028 4029 4030 | | | | | : | REPEAT BAD SEC | THIS SERIES OF OF TORS 24 SECTOR MO | PERATIONS FOR FACTORY DETECTED DDE, SOFTWARE DETECTED |

| CZ | R6KGO | RK6 FCT | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 120 | 28-AUG- READ BAL | -81 15:17 PAGE SECTOR INFORMA | 77 |
|----|--|--|--|------------------|--------|-----------------|---|----------------------------------|--|
| | 4031 4032 4033 4034 4035 4036 4037 4038 | | | | | ** | BAD SECTORS SECTORS 24 OR 26 FROM TES | SECTOR MODE EX | ODE, AND SOFTWARE DETECTED BAD IF THE NUMBER OF BAD SECTORS FOR CEED 20(10) THE DRIVE IS REMOVED |
| | 4037 4038 4039 4040 | 007644 007646 | 000004 012737 | 000001 | 001262 | TST20: | SCOPE MOV | #1,\$TIMES | ;;DO 1 ITERATION |
| | 4041 4042 4043 | | | | | | TSSINIT ERROR | 3 | CLEAR SUBSYS FROM LAST IDAERR BAD INIT ERROR |
| | 4044 4045 4046 | | | | | | MOV MOV | #RECAL,L.CS1 DRVNUM,L.CS2 | ;DO RECAL CMD |
| | 4047 | | | | | | TLOADRK TWAT16 | | :LOAD 'L' REGS INTO RK REGS |
| | 4049 | | | | | : | ERROR | 2 | ;NO INTR |
| | 4051 | | | | | : | CLR | INTSET | CLR INIT FLAG |
| | 4053 4054 4055 | | | | | | TWAT8S ERROR | 2 | ; WAIT FOR 2'N INTR ; NOT THERE |
| | 4056 4057 4058 | 007654 007660 | 105037 005000 | 007722 | | • | CLRB | 2\$ R0 | CLEAR SECTOR POINTER |
| | 4059 4060 4061 4062 4063 | 007662 007664 007670 007676 007700 | 005005 013703 012737 104416 104003 | 001640 097676 | 001110 | 1\$: | CLR MOV MOV TSSINIT ERROR | R5 BSF26P,R3 #1\$,\$LPERR | CLEAR R5 FOR BAD SECTOR COUNTING SET POINT IN TO STORE BS 26 SECT FORMAT SET ERROR RETURN ADDRESS FOR INTERNAL LOOP CLEAR SUBSYSTEM BAD INIT ERROR |
| | 4064 | 007702 | 013737 | 036120 | 007724 | | MOV | LSTCYL,15\$ | |
| | 4066 4067 4068 4069 4070 4071 4072 4073 | 007710 007714 007716 007720 007722 007723 007724 | 004437 000121 177400 070414 000 002 000000 | 035674 | | 2\$: 15\$: | JSR RDDATA -400 IBUFF .BYTE .BYTE | R4,LRLOAD 0 2 | :LOAD 'L' REGS WITH : READ DATA : WORD COUNT : BUFFER ADDRESS : SECTOR ADDRESS : TRACK ADDRESS : CYLINDER ADDRESS 632/1456 |
| | 4068 4069 4070 4071 4072 4073 4074 4075 4076 4077 4078 4079 4080 4081 4082 4083 4084 4085 | 007726 007730 007732 007734 007736 007740 | 104417 104431 104002 104421 104004 104415 | | | | TLOADRK TWAT112 ERROR TCHKOP ERROR SCOP1 | 2 4 ; OR 5,6,7 | :LOAD "L" REGS INTO RK :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK FOR ANY ERRORS :REPORT ALL ERRORS :LOOP TO 1\$ IF SW 9 SET |
| | 4082 4083 4084 4085 | 007742 007746 007750 007752 | 105737 001502 005700 001023 | 001103 | | | TSTB BEQ TST BNE | \$ERFLG 7\$ RO 3\$ | :TEST FOR ERROR IN OPERATION :NO-SKIP :GETTING A BS FACTORY SECTOR 26 SECT FORMAT? :NO-SKIP |
| | 4086 | 007754 | 062737 | 000002 | 007722 | | ADD | #2,2\$ | NEXT SECTOR ADDRESS |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T20 | 28-AUG | -81 15:17 PAGE D SECTOR INFORMA | 78 |
|--|--|--|--------------------------------------|----------------------------|-----------------|--|--|---|
| 4087 4088 4089 | 007762 007770 007772 010000 010002 010010 | 122737 001066 012737 | 000012 056036 | 007722 001360 | | CMPB BNE MOV | #10.,2\$ 6\$ #EM51,EM1N | :PAST APPLICABLE SECTORS? :NO-SKIP |
| 4090 4091 4092 4093 | 010000 010002 010010 010016 | 104001 043737 053737 000137 | 001630 001630 027716 | 001354 001666 | 25\$: | ERROR BIC BIS JMP | DRVBIT, SDEVM DRVBIT, DRVDRP NEWDRV | CLEAR DRIVE FROM DRIVE MAP SET DRIVE DROPPED ABORT TEST PASS. |
| 4087 4088 4089 4090 4091 4092 4093 4094 4095 4096 4097 4098 4101 4102 4103 4104 4107 4108 4109 4110 4111 | 010022 010026 010030 010036 010044 010046 010054 010056 | 022700 001014 062737 122737 001040 012737 104001 000751 | 000001 000002 000026 056036 | 007722 007722 001360 | 3\$: | CMP BNE ADD CMPB BNE MOV ERROR BR | #1,R0 4\$ #2,2\$ #22.,2\$ 6\$ #EM51,EM1N 1 25\$ | :GETTING A BS SOFT SECTOR 26 SECT FORMAT? :NO-SKIP :NEXT SECTOR ADDRESS :PAST APPLICABLE SECTORS? :NO-SKIP :"CANNOT READ BS FILES" |
| 4103 4104 4105 4106 4107 4108 | 010060 010064 010066 010074 010102 | 022700 001014 062737 122737 001021 | 000002 000002 000013 | 007722 007722 | 4\$: | CMP BNE ADD CMPB BNE | #2.R0 5\$ #2.2\$ #112\$ | :GETTING A BS FACT SECTOR 24 SECTOR FORMAT? :NO-SKIP :NEXT SECTOR ADDRESS :PAST APPLICABLE SECTORS? :NO-SKIP |
| 4110 4111 4112 4113 | 010104 010112 010114 | 012737 104001 000732 | 056036 | 001360 | | MOV ERROR BR | #EM51,EM1N 1 25\$ | ;"CANNOT READ BS FILES" |
| 4114 4115 4116 4117 4118 4119 4120 | 010116 010124 010132 010134 010142 010144 | 062737 122737 001005 012737 104001 000716 | 000002 000027 056036 | 007722 007722 001360 | 5\$: | ADD CMPB BNE MOV ERROR BR | #2,2\$ #23.,2\$ 6\$ #EM51,EM1N 1 25\$ | :NEXT SECTOR (BS SOFT 24 SECT MODE) :PAST APPLICABLE SECTORS? :NO-SKIP :'CANNOT READ BS FILES |
| 4121 4122 4123 | 010146 010152 | 105037 000651 | 001103 | | 6\$: | CLRB BR | \$ERFLG 1\$ | CLEAR ERROR FLAG DO NEXT READ |
| 4124 4125 | 010154 | 005737 001405 012737 | 070422 056131 | 001740 | 7\$: | TST BEQ | IBUFF+6 8\$ | :CHECK FOR ALIGNMENT PACK :NO-SKIP |
| 4124 4125 4126 4127 4128 4129 4130 4131 4132 4133 | 010162 010170 010172 | 104001 000703 | 030131 | 001360 | | MOV ERROR BR | #EM52,EM1N 1 25\$ | ; "ALIGNMENT PACK. DRIVE ABORTING" |
| 4130 | 010174 | 012701 | 070424 | | 8\$: | MOV | #IBUFF+10,R1 | SET TO START OF BAD SECTOR DATA |
| 4132 4133 4134 4135 4136 4137 4138 4139 4140 4141 | 010200 010204 010206 010210 010212 010214 010220 | 022711 001422 012123 012123 005205 022705 001367 | 000025 | | 9\$: | CMP BEQ MOV MOV INC CMP BNE | #-1,(R1) 11\$ (R1)+,(R3)+ (R1)+,(R3)+ R5 #21.,R5 | :TEST IF WORD ALL ONES (END OF DATA) :YES-SKIP :STORE CYLINDER : TRACK AND SECTOR :BUMP ERROR COUNTER :DOES IT TOTAL 20 FOR THIS FORMAT? :NO-TEST AND MORE NEXT ADDRESS |
| 4139 4140 | 010222 010230 | 012737 104001 | 2737 056227 001360 1 0001 | MOV ERROR | #EM53,EM1N 1 | TO MANY BAD SECTORS | | |
| 4141 | 010232 010240 | 043737 053737 | 001630 001630 | 001354 001666 | 10\$: | BIC | DRVBIT, \$DEVM DRVBIT, DRVDRP | CLEAR DRIVE FROM TESTING SET DRIVE DROPPED |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T20 | 28-AUG READ BA | -81 15:17 PAGE D SECTOR INFORMA | 79 TION |
|--|--|--|--|--------|-----------------|---|---|---|
| 4143 | | 000137 | 027716 | | | JMP | NEWDRV | ;ABORT PASS |
| 4145 4146 4147 4148 4149 4150 4151 4152 4153 | 010252 010254 010260 010262 010266 010272 010300 010304 010310 010316 | 005200 022700 001011 012723 010337 112737 000137 | 000001 177777 001644 000012 007676 | 007722 | 11\$: | INC CMP BNE MOV MOV MOVB JMP | R0 #1,R0 12\$ #-1,(R3)+ R3,BSS26F #12,2\$ 1\$ | :BUMP TO NEXT :NOW TESTING BS SOFT 26 SECTOR MODE? :NO-SKIP :INSERT END OF FIELD FLAG :SET POINTER TO BAD SECTOR SOFTWARE FIELD :SET TO FIRST SECTOR THIS MODE :GO READ IT. |
| 4152 4153 4154 4155 4156 4157 4158 4159 4160 | 010304 010310 010312 010316 010324 010330 010332 010336 | 022700 001014 012723 112737 010537 005005 013703 000137 | 000002 177777 000001 001646 001636 007676 | 007722 | 12\$: | CMP BNE MOV MOVB MOV CLR MOV JMP | #2,R0 13\$ #-1,(R3)+ #1,2\$ R5,BS26CT R5 BSF24P,R3 1\$ | :NOW TESTING BS FACT 24 SECTOR MODE? :NO-SKIP :INSERT END OF FIELD FLAG :SET TO FIRST SECTOR THIS MODE :STORE TOTAL BS COUNT 26 SECTOR MODE :CLEAR COUNTER FOR COUNTING 24 SECT BS :SET POINTER FOR STORING BS :GO READ |
| 4161 4162 4163 4164 4165 4166 4167 4168 | 010342 010346 010350 010354 010360 010366 | 022700 001011 012723 010337 112737 000137 | 000003 177777 001642 000013 007676 | 007722 | 13\$: | CMP BNE MOV MOV MOVB JMP | #3,R0 14\$ #-1,(R3)+ R3,BSS24P #13,2\$ 1\$ | :NOW TESTING BS SOFT 24 SECTOR MODE :NO-SKIP :INSERT END OF FIELD FLAG :STORE POINTER TO BSS 24 SECTOR MODE :GET START OF FIELDS BSS 24 SECT MODE :GO READ IT |
| 4168 4169 4170 4171 | 010372 010376 | 012723 010537 | 177777 001650 | | 14\$: | MOV MOV | #-1,(R3)+ R5,BS24CT | :INSERT END OF FIELD FLAG :STORE COUNT BSS 24 SECTOR MODE |
| 4172 4173 4174 | 010402 | 012700 | 061144 | | : | MOV MOV | #BS26,R0 #BS24+52.,R3 | GET START OF BAD SECTOR BUFFER GET END OF BUFFER |
| 4175 4176 4177 4178 4179 | | | | | 27\$: | CMP BEQ CMP | #312,(R0)+ 26\$ R0,R3 | :TEST IF ANY SECTORS BAD IN CYL 312 :YES - GET OUT :CHECK IF ALL OF BUFFER TESTED |
| 4180 4181 4182 4183 4184 | 010406 010410 010414 010416 | 005003 022710 001404 022720 | 177777 000312 | | ; 27\$: | BNE BR CLR CMP BEQ CMP | 27\$ 28\$ R3 #-1,(R0) 16\$ #312,(R0)+ | :NO - LOOP :EXIT :COUNT :AT THE END OF TABLE ? :BRANCH IF SO :CYL 312 BAD ? :BRANCH IF NOT TRY AGAIN |
| 4180 4181 4182 4183 4184 4185 4186 4187 4188 4189 4190 4191 4192 4193 4194 4195 4196 | 010414 010416 010422 010424 010426 010430 010434 | 022720 001372 000424 005203 020327 001003 013700 | 000001 001644 | | 16\$: | BNE BR INC CMP BNE MOV | 27\$ 26\$ R3 R3,#1 17\$ BSS26P,R0 | BRANCH IF NOT TRY AGAIN ELSE ERROR SEE IF 1 ST HALF OF BS 26 TABLE BRANCH IF NOT MOVE UP THE TABLE |
| 4191 4192 4193 4194 4195 | 010442 010444 010450 010452 010456 | 000762 020327 001003 012700 000754 | 000002 061270 | | 17\$: | BR CMP BNE MOV BR | 27\$ R3,#2 18\$ #BS24,R0 27\$ | SEE IF DID 2 ND HALF OF BS26 TABLE BRANCH IF NOT ELSE MOVE UP 1 ST HALF |
| 4196 4197 4198 | 010460 010464 010466 | 020327 001003 013700 | 000003 001642 | | 18\$: | CMP BNE MOV | R3,#3 19\$ BSS24P,R0 | SEE IF DID 1 ST HALF OF BS24 TABLE BRANCH IF NOT ELSE MOVE UP 2ND HALF OF BS24 |

| CZR6KG | RK6 FCT | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 120 | 28-AUG- READ BAI | -81 15:17 PAGE D SECTOR INFORMA | 80 |
|---|--|--|--------------------------------------|------------------|---|---|---|---|
| 4199 4200 | | 000746 000406 | | | 19\$:. | BR BR | 27 \$ 28 \$ | ;ALL DONE |
| 4202 4203 4204 | 010476 010504 010506 | 012737 104001 000137 | 057110 010002 | 001360 | 26\$: | MOV ERROR JMP | #DRVABT,EM1N 1 25\$ | "BAD SECTOR IN AREA FOR TEST" |
| 4206 | 010512 | | | | 28\$: | | | |
| 4208 | | | | | ::**** :*TEST | ******** | FORMAT IN 26 SE | CTOR FORMAT |
| 4210 4211 4212 4213 4214 4215 | | | | | * | OCCUR W. | CYLINDER 312, TR VERIFY FORMAT ITH WRITE HEADER AFTER READ HEADE | ACK O AND TRACK 1 FOR 26 SECTOR AND THAT DATA LATE DID NOT OR IN READING DATA R. |
| 4216 4217 4218 4219 4220 4221 4222 4223 | 010512 010514 010522 010530 010534 010540 010542 | 000004 012737 012737 105037 105037 104416 104003 | 000012 000312 010653 010557 | 001262 001676 | 15121: | SCOPE MOV MOV CLRB CLRB TSSINIT ERROR | #10.,\$TIMES #312,REFMT 10\$ 11\$ | ;;DO 10. ITERATIONS ;SET REFORMAT SWITCH ;CLEAR SECTOR POINTER ;CLEAR TRACK POINTER ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 4203 4203 4203 4203 4205 4206 4206 4207 4208 4211 4211 4211 4211 4212 4222 4222 422 | 010544 010550 010552 010554 010556 010557 010560 | 004437 000127 177676 072414 000 000 000312 | 035674 | | 9\$: 11\$: | JSR WRHEAD -102 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REGS :WRITE HEADER :WORD CNT FOR 26 SECTOR MODE :BUFFER :SECTOR 0 :TRACK 0 :CYL 0 |
| 4232 4233 4234 4235 4236 | 010562 010566 010570 010576 010600 | 004437 000600 012737 000402 | 04 <i>2</i> 260 010600 | 001110 | 1116. | JSR 000600 MOV BR | R4, GENCOM #111\$, \$LPERR 1\$ | GENERATE DATA BUILD HEADERS-NO BAD SECTORS SET LOCAL LOOP ON ERROR SKIP INIT |
| 4234 4235 4236 4237 4238 4240 4241 4242 4243 4244 4245 4246 4247 | 010600 010600 010602 010604 010606 010610 | 104416 104003 104417 104431 104002 | | | | TSSINIT ERROR TLOADRK TWAT112 ERROR | | CLEAR SUBSYSTEM BAD INIT ERROR LOAD RK REGS WAIT FOR INTERRUPT TO SLOW/NOT COMPLETE ERROR |
| 4244 | 010612 010614 | 104421 | | | | TCHKOP ERROR | 4 : OR 5,6,7 | CHECK FOR ANY ERRORS REPORT ALL ERRORS |
| 4246 | 010616 | 104415 | | | | SCOP1 | | ;INTERNAL LOOP TO 111\$ |
| 4248 4249 4250 4251 4252 4253 4254 | 010620 010626 010630 010634 010640 010644 | 012737 010203 062703 012701 004437 000125 | 010660 000024 070414 035674 | 001110 | | MOV MOV ADD MOV JSR RDHEAD | #112\$,\$LPERR R2,R3 #RKDB,R3 #IBUFF,R1 R4,LRLOAD | SET LOCAL LOOP ON ERROR BUILD POINTER TO RKDB SET POINTER TO BUFFER LOAD 'L' REGS READ HEADER |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 8-AUG-81 | 15:16 | MACY11 | 30(1046) 121 | | -81 15:17 PAGE IN 26 SECTOR FOR | |
|--|--|--|------------------|----------------------------|-----------------|---|--|---|
| 4256 4257 4258 4259 | 010646 010650 010652 010653 010654 | 000000 000000 000 000 000 000312 | | | 10\$: | | 0 | :NO WORDS COUNT :NO BUFFER :SECTOR 0 : TRACK 0 : CYL 312 |
| 4260 4261 4262 | 010656 010660 | 000402 | | | 112\$: | BR | 2\$ | ; SKIP INIT |
| 4263 4264 4265 4266 4267 4268 4269 4270 4271 4272 4273 4274 4275 4276 | 010660 010662 010664 010666 010670 | 104416 104003 104417 104423 104002 | | | 2\$: | TLOADRK TWAT16 | 2 | CLEAR SUBSYSTEM BAD INIT ERROR LOAD RK REGS WAIT FOR INTERRUPT TO SLOW/NOT COMPLETE ERROR |
| 4269 4270 4271 4272 4273 | 010672 010674 010676 010702 010704 | 104421 104004 012700 011321 104420 | 000003 | | 58: | TCHKOP ERROR MOV MOV TGETRK | 4; OR 5,6,7 #3,R0 (R3),(R1)+ | CHECK FOR ANY ERRORS REPORT ALL ERRORS SET COUNT GET RKDB GET RK REGS |
| 4274 | 010706 | 032737 | 100000 | 001550 | | BIT | #DLT,T.CS2 | :TEST IF DATA LATE :NO-SKIP |
| 4277 | 010716 010724 010732 010734 | 012737 012737 104013 104415 | 054631 056777 | 054260 061112 | | MOV MOV ERROR SCOP1 | #EMDLT,EM13 #EMRDB,DF011A 13 | : DATA LATE SET RESULT OF DB READ :LOCAL LOOP TO 112\$ |
| 4280 4281 4282 4283 4284 4285 | 010736 010744 010746 010754 | 032737 001410 012737 012737 | 057023 | 001540 001500 061112 | 38: | BIT BEQ MOV MOV | #CERR,T.CS1 4\$ #EMCERR,EM13N #EMRDB,DF011A | :TEST IF CONT ERROR SET :NO-SKIP |
| 4286 4287 4288 4289 4290 | 011000 | 104013 104415 005300 001344 012737 000402 | 011002 | 001110 | 4\$: | ERROR SCOP1 DEC BNE MOV BR | RO 5\$ #117\$,\$LPERR 7\$ | CERR SET RESULT OF READ DB LOCAL LOOP TO 112\$ DEC COUNT LOOP IF NOT ZERO SET LOCAL LOOP 117\$ SKIP INIT |
| 4291 4292 4293 4294 4295 4296 4297 4298 4299 4300 | 011002 011002 011004 011006 011012 011014 011016 | 104416 104003 004437 104421 104004 104013 | 036362 | | 117\$: 7\$: | TSSINIT ERROR JSR TCHKOP ERROR ERROR | 3 R4,RDSTHD 4; OR 5,6,7 | CLEAR SUBSYSTEM BAD INIT ERROR GO READ & SEQUENCE HEADERS CONTROLLER ERROR RETURN REPORT ALL ERRORS 'DATA LATE SET RESULT OF DATA BUFFER READ' |
| 4298 4299 | 011020 | 104002 | | | | ERROR | 2 | "'DATA LATE SET RESULT OF DATA BUFFER READ' "OPERATION TO SLOW" MESSAGE OR "HEADER O NOT FOUND" MESSAGE |
| 4300 4301 4302 4303 4304 4305 | 011022 011026 011030 011032 | 004437 100200 000414 104015 | 042260 | | | JSR 100200 BR ERROR | R4, GENCOM | COMPARE IBUF & OBUFF (HEADERS) GOOD RETURN-NO MISCOMPARES REPORT 1ST MSCOMPARES |
| 4306 4307 4308 4309 | 011034 011040 011042 011044 | 013700 005300 001407 004437 | 001634 | | 125: | MOV DEC BEQ JSR | ERRLMT,RO RO 6\$ R4,GENCOM | GET ERROR LIMIT DECREMENT IT EXIT IF ZERO |
| 4310 | 011044 | 004437 | 042200 | | | Jak | N4, ULNCOM | |

| CZR | ekgo. | RK6 FCTI | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 121 | 28-AUG FORMAT | -81 15:17 PAGE IN 26 SECTOR FOR | 82 MAT | | | |
|---|--|--|---|--------------------------------------|------------------|---|---|--|--|--|--|--|
| 444 | 311 312 313 314 315 | 011050 011052 011054 011056 011060 | 040000 000403 104016 000770 104415 | | | | 040000 BR ERROR BR SCOP1 | 6\$ 16 12\$ | RESUME COMPARE GOOD RETURN-NO MORE ERRORS REPORT NEXT ERROR LINE LOOP LOCAL ERROR LOOP TO 117\$ | | | |
| 444 | 317 | 011062 011066 | 105737 001010 | 001607 | | 6\$: | TSTB BNE | L.DT 8\$ | :WAS TRACK 1 JUST DONE? | | | |
| 4444 | 316 317 318 319 320 321 322 | 011070 011076 011104 | 112737 112737 000137 | 000001 000001 010544 | 010557 010653 | | MOVB MOVB JMP | #1.11\$ #1.10\$ 9\$ | :CHANGE PARAM TO LOAD "L" WITH :TRACK 2 :JUMP TO DO ENTIRE TEST ON TRK 1 | | | |
| - 4 | 324 | 011110 | | | | 8\$: | | | | | | |
| 4 | 326 327 | | | | | .SBTTL | **HEADE | R RECOGNITION TE | STS | | | |
| 4 | 328 | | | | | : *TEST | 22 | BAD SECTOR ERROR | ************************************** | | | |
| 444 | 330 331 332 333 334 335 | | | | • | * | SECTOR (| CYLINDER 312, TRA O (BIT 15 OR WORL OR WORD 2 OF HEA OTHER SECTORS GO | ACK O, ON SCRATCH PACK TO HAVE D 2 OF HEADER RESET) AND SECTOR 1 ADER RESET) TO BE BAD SECTORS DOD. | | | |
| 444444444444444444444444444444444444444 | 336 337 338 339 340 341 | | | | | * | ISSUE A WRITE DATA OR 400 WORDS TO CYLINDER 312, TRACK O, SECTOR O. MAKE SURE BAD SECTOR ERROR SETS. ISSUE A WRITE DATA TO CYLINDER O, TRACK O, SECTOR 1 OF 400 WORDS. MAKE SURE BAD SECTOR ERROR SET. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER O, TRACK O, SECTOR 2. MAKE SURE NO ERROR SETS. | | | | | |
| 444 | 343 344 345 346 347 348 | 011110 011112 011120 011126 011130 | 000004 012737 012737 104416 104003 | 000012 000312 | 001262 001676 | TST22: | SCOPE | | ;;DO 10. ITERATIONS ;SET REFORMAT SWITCH ;CLEAR SUBSYSTEM ;BAD INIT ERROR | | | |
| 444444444444444444444444444444444444444 | 350 351 352 353 354 355 356 357 | 011132 011136 011140 011142 011144 011145 011146 | 004437 000127 177676 072414 000 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE .BYTE | R4.LRLOAD 0 | :LOAD 'L' REGS. ;WRITE HEADER :WORD COUNT FOR 26 SECTOR MODE ;BUFFER ADDRESS :SECTOR :TRACK :CYLINDER | | | |
| 4 | 358 359 360 361 | 011150 011154 | 004437 000600 | 042260 | | | JSR 600 | R4,GENCOM | GENERATE HEADERS | | | |
| 4444 | 362 363 364 365 366 | 011156 011162 011166 011172 011174 | 012700 042720 042720 005720 042720 | 072416 100000 100000 040000 | | | MOV BIC TST BIC | #OBUFF+2,R0 #BIT15,(R0)+ #BIT15,(R0)+ (R0)+ #BIT14,(R0)+ | RESET BIT 15 IN WORD 2 OF SECTOR O HEADER AND BIT 14: IN WORD 2 OF SECTOR 1 HEADER. ALSO CORRECT THE VRC | | | |
| | | | | | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T22 | 28-AUG | -81 15:17 PAGE TOR ERROR | 83 |
|--|--|--|------------------|------------------|------------------------------|---|--|---|
| 4367 | 011200 | 042710 | 040000 | | | BIC | #BIT14,(RO) | |
| 4369 4370 4371 | | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4368 43671 43671 43777 43777 43777 43777 43777 43777 43777 43777 4377 4077 40 | 011212 011214 011216 011224 011226 011230 011234 011236 011240 011242 011243 011244 | 072414 000 000 | 011224 | | 4\$: 5\$: | TCHKOP ERROR MOV TSSINIT ERROR JSR WRDATA -400 OBUFF BYTE BYTE 312 | 4 : OR 5,6,7 #4\$,\$LPERR 3 R4,LRLOAD | CHECK IF ANY ERRORS REPORT ALL ERRORS SET LOCAL LOOP ON ERROR LOAD 'L' REGS WRITE DATA WORD COUNT BUS ADDRESS SECT 0 TRACK 0 CYL 312 |
| 4386 4387 4388 | 011246 011250 011252 | 104417 104424 104002 | | | 1\$: | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4390 4391 | 011254 011262 | 022737 001415 | 000002 | 011242 | | CMP BEQ | #2.5\$ 6\$ | :JUST READ SECTOR 2? :YES - SKIP |
| 4393 4394 4395 4396 4397 | 011264 011266 011270 011272 011274 | 104422 000000 000100 000000 104004 | | | | TCHKWE 0 100 0 ERROR | 4 · OR 5 6 7 | :CHECK OPERATION WITH ERROR :EXPECTED BSE :REPORT ANY DISCREPENCIES |
| 4399 | 011276 | | | | | SCOP1 | 4 , 00 3,0,1 | :LOCAL ERROR LOOP TO 4\$ |
| 4400 4401 4402 4403 4404 4405 | 011300 011306 011310 011314 | 122737 001405 105237 000743 | 000002 011242 | 011242 | | CMPB BEQ INCB BR | #2.5\$ 7\$ 5\$ 4\$ | :WAS SECTOR SET TO 2 :YES-SKIP :BUMP TO NEXT SECTOR :LOOP |
| 4406 | 011316 011320 | 104421 104004 | | | 6\$: | TCHKOP ERROR | 4 : OR 5,6.7 | CHECK FOR GOOD OPERATION REPORT ALL ERRORS |
| 4408 4409 4410 4411 4412 4413 4414 4415 4416 4417 | 011322 | | | | 7\$: :****** :*TEST : | FORMAT (16 SECTO OF EACH SURE HEA | ORS WITH BAD HEAD OF THE SECTORS O ADER VRC ERROR SI | ACK O. ON SCRATCH PACK TO HAVE DER VRC. ISSUE A WRITE DATA WITH A BAD HEADER VRC. MAKE ETS. ISSUE A WRITE DATA TO SURE NO ERROR OCCURS. |
| 4419 4420 4421 4422 | 011322 011324 011332 | 000004 012737 012737 | 000012 | 001262 001676 | 15123: | SCOPE MOV MOV | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 123 | 28-AUGHEADER | -81 15:17 P | 7 PAGE 84 |
|--|--|---|------------------|--------|-----------------|---|---|--|
| 4424 | 011340 011342 | 104416 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 4427 4428 4429 4431 4433 4433 4434 | N 4 4 7 E / | 004437 000127 177676 072414 000 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE .BYTE | R4.LRLUAD | :LOAD 'L' REGS :WRITE HEADER :WORD COUNT :BUFF ADD :SECT :TRACK :CYL |
| 4434 | 011362 011366 | 004437 000600 | 042260 | | | JSR 600 | R4, GENCOM | BUILD HEADERS NO BSE |
| 4437 4438 4439 4440 4441 4442 | 011404 | 012703 030310 001402 040310 000401 | 072420 000001 | | 1\$: | BIC | #OBUFF+4,R0 #BITO,R3 R3,(R0) 2\$ R3,(R0) 3\$ | :SET FOR BIT CHANGE SELECT :CHECK A VRC BIT :SKIP IF ZERO :ELSE CLEAR IT :SKIP |
| 4443 4444 4445 | 011410 | 050310 062700 | 000006 | | 2\$: 3\$: | BIS ADD | R3.(R0) #6.R0 | : IF ZERO SET IT :BUMP TO NEXT VRC WORD |
| 4446 4447 4448 | 011416 011420 | 006303 001367 | | | | ASL | R3 1\$ | :SHIFT THE SELECT :IF BIT NOT SHIFTED OUT-LOOP |
| 4449 4450 4451 4452 4453 4454 | 011424 011426 011430 | 104417 104431 104002 104421 104004 | | | | TLOADRK TWAT112 ERROR TCHKOP ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION COMPLETE :REPORT ALL ERRORS |
| 4455 | 011434 011442 011444 | 012737 104416 104003 | 011442 | 001110 | 4\$: | | #45.SLPERR | :SET LOCAL LOOP :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 4459 4460 4461 4462 4463 4464 4465 4466 | 011446 011452 011454 011456 011460 011461 011462 | 004437 000123 177400 072414 000 000 000 | 035674 | | 5\$: | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD 0 | :LOAD 'L' REGS :WRITE DATA :WORD COUNT :BUFFER ADD :SECT :TRACK :CYL |
| 4467 4468 4469 4470 | 011464 011466 011470 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REG :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4471 4472 4473 | 011472 011500 | 022737 001415 | 000020 | 011460 | | CMP BEQ | #16.,5\$ 6\$ | :WAS THIS WRITE SECTOR 16? :YES-SKIP :ELSE |
| 4474 4475 4476 4477 | 011502 011504 011506 011510 | 104422 000000 000040 000000 | | | | TCHKWE 0 40 | | CHECK OPERATION WITH ERROR HVRC EM EXPECTED |
| 4478 | 011512 | 104004 | | | | ERROR | 4 : OR 5.6.7 | REPORT ANY DISCREPENCIES |

CZR6KGO RK6 FCTNL CTRL DIAG MACV11 30(1046) 28-AUG-81 15:17 PAGE 85 CZR6KG.P11 28-AUG-81 15:16 T23 HEADER VRC ERROR 4479 4480 011514 104415 4481 4482 011516 105237 4483 011522 022737 4484 011530 003744 4485 011532 000402 4486 011534 104421 4487 011536 104004 4488 4489 011540 SCOP1 :LOCAL LOOP TO 4\$:BUMP SECTOR IN "L" REG :IF SECTOR IS 16 OR LESS :LOOP INCB CMP BLE 5\$ #16.5\$ 4\$ 011460 000016 011460 ELSE EXIT 7\$ BR CHECK LAST OPERATION NO ERRORS TCHKOP 68: 4: 04 5.6.7 ERROR 4489 011540 75:

| | | | | | ** TEST | 26 | BAD SECTOR ERRO | AND HVRC ERROR |
|---|--|---|--------|------------------|---------|---|--|---|
| | | | | | | | CYLINDER 312, TR BAD SECTOR ERROR NDER O, TRACK O, ETS. | ACK O SUCH THAT SECTOR ZERO HAS AND HEADER VRC. ISSUE A WRITE DATA SECTOR O. MAKE SURE ONLY HEADER VA |
| | 011540 011542 011550 011556 011560 | 000004 012737 012737 104416 104003 | 000012 | 001267 001676 | f\$124: | MOV | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH :CLEAR SUBSYSTEM :BAD INIT ERROR |
| | 011562 011566 011570 011572 011574 011575 011576 | 000127 177676 072414 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE 312 | R4.LRLOAD | :LOAD 'L' REG :WRITE HEADER :WORD CNT FOR 26 SECTOR MODE :BUFF ADD :SECTOR :TRACK :CYLINDER |
| | 011600 011604 | 004437 000600 | 042260 | | | JSR 600 | R4, GENCOM | ;BUILD HEADERS-NO BSE |
| 1 | 011606 | 042737 | 100000 | 072416 | | BIC | #BIT15,08UFF+2 | CLEAR BIT TO SET BSE, LEAVE VAC BA |
| | 011614 011616 011620 | 104431 | | | | TLOADRK TWAT112 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 011622 011624 | | | | | TCHKOP ERROR | | : CHECK FOR ANY ERRORS : REPORT ALL ERRORS |
| | 011626 011632 011634 011636 011640 011641 011642 | 004437 000123 177400 072414 000 000 000 000312 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4.LRLOAD | :LOAD 'L' REGS :WRITE DATA :WORD COUNT :BUFF ADD :SECTOR :TRACK :CYLINDER |
| | 011644 011646 011650 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 011652 | 104422 | | | | TCHKWE | | CHECK OPERATION WITH EXPECTED ERR |
| | 011654 011656 011660 | 000000 000040 000000 | | | | 000 | | ;HVRC ERR EXPECTED |
| | 011662 | 104004 | | | | ERROR | 4 : OR 5.6.7 | REPORT ALL DISCREPENCIES |

| CZR6KGO CZR6KG.F | RK6 FCTI | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T25 | 28-AUG- | -81 15:17 PAGE ON INCOMPLETE | 87 |
|--|--|--|------------------|------------------|-----------------|---|---|--|
| 4546 4547 4548 4549 | | | | | : | WRONG FO | CYLINDER 312, TRA DRMAT. ISSUE A N , SECTOR 21. MAN | ACK O SUCH THAT SECTOR 21 HAS THE WRITE DATA OF 400 TO CYLINER O. KE SURE OPI SET. |
| 4550 4551 4552 4553 4554 4555 4556 | 011664 011666 011674 011702 011704 | 000004 012737 012737 104416 104003 | 000012 | 001262 001676 | 15125: | SCOPE MOV MOV TSSINIT ERROR | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 4558 4559 4560 4561 4562 4563 | 011712 | 177676 072414 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE 312 | R4,LRLOAD 0 | :LOAD 'L' REGS :WRITE HEADER :WORD COUNT FOR 26 SECT MODE :BUFF ADD :SECTOR :TRACK :CYLINDER |
| 4564 4565 4566 4567 | 011724 011730 | 004437 000600 | 042260 | | | JSR 600 | R4.GENCOM | :BUILD HEADERS-NO BSE ERRORS |
| 4568 4569 | 011732 011740 | 052737 052737 | 001000 001000 | 072614 072616 | | BIS | #BIT9,0BUFF+200 #BIT9,0BUFF+202 | CHANGE FORMAT IN SECTOR 25 |
| 4568 4569 4570 4571 4572 4573 4574 4575 | 011746 011750 011752 | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |
| 4010 | 011754 011756 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | : CHECK FOR ANY ERRORS : REPORT ALL ERRORS |
| 4579 4580 4581 4582 4583 | 011760 011764 011766 011770 011772 011773 011774 | 000123 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4, LRL OAD | :LOAD "L" REGS :WRITE DATA :400 WORDS :BUFF ADD :SECTOR 25 :TRACK 0 :CYL 312 |
| 4584 4585 4586 4587 4588 4589 4590 | 011776 012000 012002 | 104417 104425 104002 | | | | TLOADRK TWAT48 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |
| 4590 4591 | 012004 012006 | 104422 | | | | TCHKWE | | CHECK OPERATION EXPECTED ERROR |
| 4591 4592 4593 4594 | 012010 012012 012014 | 000020 000000 104004 | | | | 20 0 ERROR | 4 : OR 5.6.7 | :OPI EXPECTED :REPORT ANY DISCREPENCIES |
| 4595 4596 4597 | | | | | TEST | 26 | OPI WITH HVRC E | RROR |
| 4598 4599 4600 4601 | | | | | | ERROR IS | S PRESENT AND SEC WRITE DATA OF 40 | ACK O SUCH THAT A HEADER VRC CTOR 17 HAS THE WRONG FORMAT. 00 WORDS TO CYLINDER 312, AT BOTH OPERATION INCOMPLETE |

| | | | | | : | | DER VRC SET. | |
|---|---|--|--|------------------|--------|--|--|---|
| 6 01 7 01 8 01 | 12016 12020 12026 12034 12036 | 000004 012737 012737 104416 104003 | 000012 | 001262 001676 | 15126: | SCOPE MOV MOV TSSINIT ERROR | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 0000000 | 12040 12044 12046 12050 12052 12053 12054 | 004437 000127 177676 072414 000 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE .BYTE 312 | R4.LRLOAD | :LOAD "L" REGS :WRITE HEADER :WORD COUNT FOR 26 SECT MODE :BUS ADDRESS :SECTOR :TRACK :CYLINDER |
| 0 01 | 12056 12062 | 004437 000600 | 042260 | | | JSR 600 | R4, GENCOM | ;BUILD HEADER- NO BSE ERRORS |
| 000000000000000000000000000000000000000 | 12064 12070 12074 12100 12104 12110 12112 12116 12120 | 012700 052720 052720 062700 032710 001403 042710 000402 052710 | 072550 001000 001000 000004 000001 000001 | | 15: | MOV BIS BIS ADD BIT BEQ BIC BR BIS | #OBUFF+134,R0 #BIT9,(R0)+ #BIT9,(R0)+ #4,R0 #BIT0,(R0) 1\$ #BIT0,(R0) 2\$ #BIT0,(R0) | :GET ADDRESS 2ND WORD HDR 17(8 :SET FORMAT 24 SECT PER TRACK :SET VRC BIT :BUMP TO HVRC WORD HDR 20(8) :TEST BIT 0 :RESET-SKIP :CLEAR BIT |
| 0 | 12126 | 104417 104431 104002 | | | 2\$: | TLOADRK TWAT112 ERROR | | :FORCE OPI AND HVRC ERROR :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 0. | 12132 12134 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5,6,7 | :CHECK FOR ANY ERRORS :YES-REPORT ALL ERRORS |
| 000000 | 12136 12142 12144 12146 12150 12151 12152 | 004437 000123 177400 072414 017 000 000312 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE .BYTE 312 | R4.LRLOAD | :LOAD 'L' REGS :WRITE DATA :400 WORDS :BUFF ADDRESS :SECT 17 :TRACK 0 :CYLINDER 312 |
| 9 0 | 12154 12156 12160 | 104417 104425 104002 | | | | TLOADRK TWAT48 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |
| 2 0 | 12162 12164 12166 12170 12172 | 104422 000000 000060 000000 104004 | | | | TCHKWE 0 60 0 ERROR | 4 :OR 5.6.7 | CHECK WITH EXPECTED ERROR HVRC ERR & OPI EXPECTED |

| CZR6KG. | 211 2 | 8-AUG-81 | 15:16 | | 127 | HVRC IG | -81 15:17 PAGE NORE ON NON-ADD | RESSED SECTOR |
|--|--|--|------------------|------------------|--------|---|--|---|
| 4659 4650 4661 4662 4663 | | | | | | FORMAT ERROR. AND SEC END OF | CYLINDER 312, THE OPERATION | RACK O SUCH THAT SECTOR 20 HAS AN HVRC ATA OF 400 WORDS TO CYLINDER 312, TRACK O. RE HVRC IS NOT SET AT THE |
| 4664 4665 4666 4667 | 012174 012176 012204 | 000004 012737 012737 | 000012 000312 | 001262 001676 | TST27: | SCOPE MOV MOV | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH |
| 4668 4669 4670 | 012212 012214 | 104416 104003 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 4671 4672 4673 4674 4675 4676 4678 4679 | 012216 012222 012224 012226 012230 012231 012232 | 004437 000127 177676 072414 000 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE .BYTE 312 | R4,LRLOAD 0 | :LOAD 'L' REGISTERS :WRITE HEADER :WORD COUNT FOR 26 SECTOR MODE :BUFF ADD :SECTOR :TRACK :CYLINDER |
| 4680 4681 4682 | 012234 | 004437 | 042260 | | | JSR 600 | R4, GENCOM | ;BUILD HEADERS-NO BSE ERRORS |
| 4683 4684 4685 4686 4687 4688 4689 | 0122/2 | 012700 012701 030110 001402 040110 000401 050110 | 072560 000002 | | 1\$: | MOV MOV BIT BEQ BIC BR BIS | #0BUFF+144,R0 #BIT1,R1 R1,(R0) 1\$ R1,(R0) 2\$ R1,(R0) | :ADDRESS OF HEAD 20 HVRC WORD :BIT 1 CONSTANT :TEST BIT 1 SET :RESET-SKIP :ELSE CLEAR BIT 1 :SKIP :SET BIT 1 |
| 4690 4691 4692 4693 | 012264 012266 012270 | 104417 104431 104002 | | | 2\$: | TLOADRK TWAT112 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |
| 4594 4695 4696 | 012272 012274 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | CHECK FOR ANY ERROR REPORT ALL ERRORS |
| 4697 4698 4699 4700 4701 4702 4703 4704 4705 4706 4707 4708 4709 4710 | 012276 012302 012304 012306 012310 012311 012312 012314 012320 | 004437 000123 177400 072414 021 000 000312 104417 104424 104002 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 TLOADRK TWAT32 ERROR | R4.LRLOAD 21 0 | :LOAD 'L' REGISTER :WRITE DATA :WORD COUNT :BUFF ADD :SECTOR :TRACK :CYLINDER :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4711 | | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5.6.7 | CHECK FOR ANY ERROR ; REPORT ALL ERRORS. |
| 4712 | | | | | .SBTTL | **DATA | TRANSFER TESTS | |

| 4714 | P11 2 | NL CTRL 8-AUG-81 | 15:16 | MACY11 | 30(1046) **DATA | TRANSFER | -81 15:17 PAGE TESTS | : 90 |
|--|--|--|------------------|------------------|---|---|--|---|
| 4715 | | | | | | 30 | WRITE AND READ | ONE SECTOR |
| 4717 4718 4719 4720 4721 4722 | | | | | * | FORMAT TO AGREE OF ONE MAKE SUI | CYLINDER 312, AL ED WITH BAD SECT SECTOR ON CYLING RE IT AGREES WIT | LL TRACKS AND CYLINDER 313, TRACK OF TOR INFORMATION. ISSUE A WRITE DATA DER 312, TRACK O. READ IT BACK TO THE WHAT IS WRITTEN. |
| 4723 4724 4725 4726 4727 4728 | 012326 012330 012336 012344 012346 | 000004 012737 012737 104416 104003 | 000012 000312 | 001262 001676 | 15130: | SCOPE MOV MOV TSSINIT ERROR | #10.,\$TIMES #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 4729 4730 4731 | 012350 012356 | 012737 105037 | 000312 012375 | 012376 | | MOV CLRB | #312,7\$ 2\$ | :PRESET CYL POINTER :CLEAR TRACK POINTER |
| 4732 4733 4734 4735 4736 4737 4738 4739 | 012366 | 004437 000127 177676 072414 000 000 000312 | 035674 | | 1\$: 2\$: 7\$: | JSR WRHEAD -102 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REG :WRITE HEADER :WORD COUNT FOR 26 SECTOR MODE :BUFF ADDRESS :SECTOR :TRACK :CYLINDER |
| 4740 4741 4742 4743 | 012400 012404 | 004437 001200 | 042260 | | | JSR 1200 | R4,GENCOM | BUILD HDRS-INCLUDE BAD SECTORS |
| 4744 4745 4746 | 012406 012410 012412 | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4747 4748 4749 | 012414 012416 | 104421 104004 | | | | TCHKOP ERROR | 4 : OR 5,6,7 | CHECK FOR ANY ERRORS REPORT ALL ERRORS |
| 4750 4751 4752 4753 4754 4755 4756 | 012420 012426 012430 012436 012440 012444 | 022737 001414 123727 001403 105237 000746 | | 012376 000002 | | CMP BEQ CMPB BEQ INCB BR | #313,7\$ 3\$ 2\$,#2 8\$ 2\$ 1\$ | :TEST IF DONE 313 TK 0 :YES - SKIP :DID WE JUST FORMAT TRACK 2 :YES-SKIP :BUMP TO NEXT TRACK :GO FORMAT NEXT TRACK |
| 4757 4758 4759 4760 | 012446 012452 012456 | 105037 005237 000741 | 012375 012376 | | 8\$: | CLRB INC BR | 2\$ 7\$ 1\$ | CLEAR TRACK POINTER BUMP CYL TO 313 GO FORMAT 313 TK 0 |
| 4761 4762 4763 4764 4765 4766 4767 4768 4769 | 012460 012464 012466 012470 012472 012473 012474 | 004437 000123 177400 072414 012 000 000312 | 035674 | | 3\$: | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REGS :WRITE DATA :ONE SECTOR WORD COUNT :BUFF ADDRESS :SECTOR 12 :TRACK 0 :CYLINDER 312 |
| | OTTO THE RESERVE OF THE PARTY O | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-A | M 7 AUG-81 15:17 PAGE 91 E AND READ ONE SECTOR | |
|---|---|---|------|
| 4770 012476 004437 042260 4771 012502 000001 4772 012504 000400 4773 012506 012737 012514 4774 012514 104417 4775 012516 104431 4776 012520 104002 4777 | 001110 MOV | R4.GENCOM ;BUILD DATA PATTERN 1 ;400 WORDS LONG #4\$,\$LPERR ;SET FOR LOCAL LOOP ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR | |
| 4778 012522 104421 4779 012524 104004 | T CHKO ERROR | CHECK FOR ANY ERRORS | |
| 4780 4781 012526 004437 035674 4782 012532 000121 4783 012534 177400 4784 012536 070414 4785 012540 012 4786 012541 000 4787 012542 000312 4788 | | READ DATA :400 WORDS :BUFF ADD :SECTOR 12 | |
| 4789 012544 104417 4790 012546 104424 4791 012550 104002 | TLOAD TWATS ERROR | CRK :LOAD RK 32 :WAIT FOR INTERRUPT R 2 :TO SLOW/NOT COMPLETE | |
| 4792 4793 012552 104421 4794 012554 104004 | T CHK(ERROR | | |
| 4795 4796 012556 004437 042260 4797 012562 100001 4798 012564 000400 4799 012566 000413 4800 012570 104015 | JSR 10000 400 BR ERROR | 30 COMPARE DATA TO PATTERN 1 3400 WORDS LONG 35 GOOD RETURN-NO DATA ERRORS | |
| 4801 4802 012572 013700 001634 4803 012576 005300 4804 012600 001406 4805 012602 004437 042260 4806 012606 040000 4807 012610 000402 4808 012612 104016 4809 012614 000770 4810 012616 005037 001676 | 5\$: MOV BEQ JSR 04000 BR ERROR BR CLR | 6\$;EXIT IF NO MORE ERRORS | |
| 4811 4812 4813 4814 4815 4816 4817 4818 4819 | ** ISSUE ** TRACE ** ADDRE ** EVER | WRITE DATA WITH BUS ADDRESS INCREMENT INHIBIT A WRITE DATA OF ONE SECTOR TO CYLINDER 312, C2, SECTOR 12 WITH INHIBIT BUS ESS INCREMENT. READ DATA BACK TO MAKE SURE Y WORD IS THE SAME AND CORRECT. | |
| 4820 4821 012622 000004 4822 012624 012737 000012 4823 | TST31: SCOPE | | **** |
| 4824 012632 104416 4825 012634 104003 | TSSIM ERROR | CLEAR SUBSYSTEM BAD INIT ERROR | |

| | | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T31 | 28-AUG- WRITE D | -81 15:17 PAGE ATA WITH BUS ADD | 92 RESS INCREMENT INHIBIT |
|---|--|--|--|----------------------------|--------|-----------------|--|---|---|
| | 4826 4827 4828 4829 4830 4831 4832 4833 | 012642 012644 012646 012650 | 004437 000123 177400 072414 012 001 000312 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REGS :WRDATA :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 12 :TRACK 1 :CYLINDER 312 |
| | 4835 4836 4837 4838 | 012654 012662 012666 012670 | 052737 004437 000016 000400 | 000020 042260 | 001610 | | BIS JSR 16 400 | #BAI,L.CS2 R4,GENCOM | :SET INCREMENT INHIBIT :BUILD PATTERN :PATTERN 16 :400 WORDS |
| - | 4841 | 012674 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 4844 4845 | 012700 012702 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7, | ; CHECK OPERATION FOR ANY ERRORS 10 ; REPORT ALL ERRORS |
| | 4848 4849 4850 4851 4852 | 012710 012712 012714 | 004437 000121 177400 070414 012 001 000312 | 035674 | | | JSR RDDATA -400 IBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD "L" REGS :RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 12 :TRACK 1 :CYLINDER 312 |
| | 4855 | 012722 012726 012732 | 012700 012701 012703 | 000377 072416 072414 | | | | | SET COUNT TO SET OBUFF TO BE ALL THE FIRST WORD OF PATTERN |
| | 4859 4860 4861 4862 | 012736 012740 012742 | 011321 005300 001375 | | | 1\$: | MOV DEC BNE | (R3),(R1)+ R0 1\$ | :MOV THE WORD :LOOP UNTIL ALL WORDS SET |
| | 4863 4864 | 012744 012746 012750 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 4867 4868 | 012752 012754 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |
| | 4871 4872 4873 4874 4875 4876 4877 4878 4879 4880 | 012756 012762 012764 012766 012770 012772 012776 013000 013002 013010 | 004437 100000 000400 000413 104015 013700 005300 001406 004437 040000 000402 | 042260 001634 042260 | | 64\$: | JSR 100000 400 BR ERROR MOV DEC BEQ JSR 40000 BR | R4,GENCOM 2\$ 15 ERRLMT,R0 R0 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE NO MORE ERRORS - EXIT |
| | 4881 | 013012 | 104016 | | | | FRRAR | 16 | DEDOOT NEYT EDDOO |

ERROR

16

:NO MORE ERRORS - EXIT :REPORT NEXT ERROR

4881

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30 (1046) 131 | 28-AUG- WRITE D | -81 15:17 PAGE ATA WITH BUS ADD | |
|--|--|--|--|------------------|----------------------|---|--|---|
| 4882 4883 | 013014 013016 | 000770 | | | 65\$: | BR | 64\$ | ;L00P |
| 4884 4885 4886 4887 4888 4889 4890 4891 | 013016 | | | | *TEST | | WRITE DATA ADDR | ESS GREATER THAN 32K OO WORDS WITH ADDRESS = 177770. IS ON DISK. |
| 4892 4893 4894 | | | | | * | NOTE: | THIS TEST IS ON OF MEMORY IS PR | LY EXECUTED IF MORE THAN 32K ESENT. |
| 4895 4896 4897 4898 4899 | 013016 013020 013026 013034 | 000004 012737 123727 002016 | 000012 001326 | 001262 000001 | TST32: | SCOPE MOV CMPB BGE | #10.,\$TIMES \$MAM\$1,#1 2\$ | ;;DO 10. ITERATIONS ;TEST IF >32K MEM ;YES-SKIP |
| 4900 4901 4902 | 013036 013044 | 032737 001011 | 000002 | 001664 | | BIT | #MEMSZB,OPTFLG | :TEST IF REPORT ALREADY MADE :YES -SKIP |
| 4903 4904 4905 4906 4907 4908 4909 4910 | 013046 013052 013056 013064 013070 013072 013100 | 104401 104401 052737 104401 000470 012737 | 051573 051736 000002 051752 013100 | 001664 | 1\$: 2\$: 5\$: | TYPE TYPE BIS TYPE BR MOV | .OPRO11 .OPRO12 #MEMSZB.OPTFLG .OPRO15 4\$ #5\$,\$LPERR | :"INSUFFICIENT MEMORY DATA TRANSFER WITH :ADDRESS >32K :SET FLAG :BYPASSED" :EXIT :SET LOCAL LOOP ON ERROR ADDRESS |
| 4911 4912 4913 | 013100 013102 | 104416 104003 | | |).p. | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| 1011 | 013104 013110 013112 013114 013116 013117 013120 013122 013126 013130 013132 | 004437 000123 177400 177770 016 000 000312 004437 010010 001777 000400 | 035674 | | | JSR WRDATA -400 177770 .BYTE .BYTE 312 JSR 10010 1777 400 | R4, LRLOAD 16 0 R4, GENCOM | ;LOAD 'L' REGS ;WRITE DATA ;400 WORDS ;BUS ADDRESS IN 32K -10 BYTES ;SECTOR 16 ;TRACK 0 ;CYLINDER 312 ;GENERATE DATA ;PATTERN 10, MEM. MANAGEMENT FOR DEST. ;RELOCATION ARGUMENT ;400 WORDS |
| 4925 4926 4927 4928 4929 4930 | 013134 013136 013140 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 4939 4930 4931 4932 4933 | 013142 013144 013146 | 104421 104004 104415 | | | | TCHKOP ERROR SCOP1 | 4 ;OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :LOCAL LOOP ON ERROR TO 5\$ |
| 4935 4934 4935 4936 4937 | 013150 013154 013156 | 004437 002007 001000 | 042260 | | | JSR 2007 1000 | R4,GENCOM | CLEAR IBUFF TO 1'S. |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 132 | 28-AUG- | -81 15:17 ATA ADDRESS | PAGE 94 GREATER THAN 32K |
|--|--|--|------------------|------------------|-----------------|--|--|---|
| 4938 4939 4940 4941 4942 4943 4945 4946 4947 4948 4949 4950 4951 4953 4954 4955 4956 4957 4958 4959 4960 4961 | 013160 013164 013166 013170 013172 013173 013174 013176 013200 013202 013204 013206 013210 013214 013216 013220 013224 013224 013226 013232 013234 013236 013236 013236 013236 013236 013250 013250 | 004437 000121 177400 070414 016 000 000312 104417 104002 104421 104004 104421 104004 004437 110000 000413 104015 013700 005300 001406 004437 050000 | | | 648: | BYTE 312 TLOADRK TWAT32 ERROR TCHKOP ERROR 110000 1777 400 BR ERROR MOV DE C BEQ JSR 50000 | 4 ; OR 5, 6 R4, GENCOM 4\$ 15 ERRLMT, R0 R0 65\$ R4, GENCOM | ; RDDATA ; -400 WORDS ; IBUFF IS BUFF ADDRESS ; SECTOR 16 ; TRACK 0 ; CYLINDER 312 ; LOAD RK REGS ; WAIT FOR INTERRUPT ; TO SLOW/NOT COMPLETE ERROR ; CHECK OPERATION FOR ANY ERRORS 7. 10 ; REPORT ALL ERRORS ; COMPARE ; MEMORY MANAGEMENT FOR DESTINATION ; RELOCATION ARGUMENT ; 400 WORDS ; NO ERROR-SKIP ; REPORT FIRST MISCOMPARE ; GET ERROR LIMIT ; DECREMENT COUNT ; IF ZERO - EXIT ; CONTINUE DATA COMPARE |
| 4962 4963 4964 | 013246 013250 013252 | 104016 000770 | | | 65\$: | ERROR BR | 65\$ 16 64\$ | REPORT NEXT ERROR |
| 4965 4966 4967 4968 4969 | 013252 | | | | 4\$: :*IEST | 33 | READ DATA A | DDRESS GREATER THAN 32K |
| 4970 4971 4972 | | | | | | | | F 400 WORDS WITH ADDRESS = 177770. RRECT TRANSFER. |
| 4973 4974 4975 | | | | | | NOTE: | THIS TEST I OF MEMORY I | S ONLY EXECUTED IF MORE THAN 32K S PRESENT. |
| 4976 4977 4978 4979 4980 4981 4982 4983 4984 | 013252 013254 013262 013270 | 000004 012737 123727 002001 | 000012 001326 | 001262 000001 | 15133: | SCOPE MOV CMPB BGE | #10.,\$TIMES \$MAMS1,#1 2\$ | ;:DO 10. ITERATIONS :CHECK IF >32K MEMORY :YES-SKIP |
| 4982 | 013272 | 000462 | | | 1\$: | BR | 5\$ | :EXIT |
| 4984 | 013274 | 012737 | 013302 | 001110 | 25: | MOV | #3\$,\$LPERR | ; SET LOCAL ERROR LOOP |
| 4986 4987 4988 4989 4990 4991 4992 4993 | 013302 013302 013304 013306 013312 013314 013316 013320 | 104416 104003 004437 000123 177400 072414 017 | 035674 | | 3\$: | TSSINIT ERROR JSR WRDATA -400 OBUFF .BYTE | 3 R4.LRLOAD | CLEAR SUBSYSTEM BAD INIT ERROR LOAD 'L' REGS WRDATA -400 WORDS OBUFF IS BUFF ADDRESS SECTOR 17 |

| CZR6KGO CZR6KG. | RK6 FC | TNL CTRL 28-AUG-81 | DIAG 15:16 | MACY11 | 30 (1046) 133 | 28-AUG | -81 15:17 PAG TA ADDRESS GREA | E 95 TER THAN 32K |
|--|--|--|----------------------------|----------------------------|------------------------|---|--|---|
| 4994 4995 4996 4997 4998 4999 | 013321 013322 013324 013330 013332 | 000312 004437 000011 | 042260 | | | .BYTE 312 JSR 11 400 | O R4,GENCOM | :TRACK 0 :CYLINDER 312 :GENERATE DATA IN OBUFF :PATTERN 11 :400 WORDS |
| 5000 5001 5002 | 013334 013336 013340 | 104430 | | | | TLOADRK TWAT96 ERROR | 2 . | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5003 5004 5005 5006 5007 5008 5009 5010 5011 5012 5013 | 013342 013344 013346 013352 013354 013356 013361 013362 | 104004 004437 000121 177400 177770 017 000 | 035674 | | | TCHKOP ERROR JSR RDDATA -400 177770 .BYTE .BYTE 312 | 4 : OR 5, 6, 7 R4, LRLOAD | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :LOAD 'L' REG :READ DATA :400 WORDS :ACCROSS 32K BOUNDARY :SECTOR 17 :TRACK 0 :CYL 312 |
| 5013 5014 5015 5016 5017 5018 5019 5020 5021 5022 5023 5024 5025 5026 5027 5028 5029 5031 5032 5033 5034 | 013364 013366 013370 013372 013374 013376 013402 013404 013410 013412 013414 013420 013422 013434 013436 013436 013440 013440 | 104424 104002 104421 104004 004437 120000 001777 000400 000413 104015 013700 005300 001406 004437 060000 000402 104016 000770 | 042260 001634 042260 | | 64\$: 65\$: 5\$: | TLOADRK TWAT32 ERROR TCHKOP- ERROR JSR 120000 1777 400 BR ERROR MOV DEC BEQ JSR 60000 BR ERROR BR 60000 BR ERROR BR | 2 4 ; OR 5, 6, 7 R4.GENCOM 5\$ 15 ERRLMT, RO RO 65\$ R4.GENCOM | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :COMPARE DATA :MEMORY MANAGEMENT WITH SOURCE :RELOCATION ARGUMENT :COMPARE 400 WORDS :NO MISCOMPARE-EXIT :REPORT FIRST MISCOMPARE :GET ERROR LIMIT :DECREMENT COUNT :IF ZERO - EXIT :CONTINUE DATA COMPARE :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 5035 5036 5037 | | | | | *TEST | 34 | | RESS GREATER THAN 64K |
| 5038 5039 5040 | | | | | | | WRITE DATA OF RE CORRECT DATA | 400 WORDS WITH ADDRESS = 377770. IS ON DISK. |
| 5041 5042 5043 | | | | | : | NOTE: | THIS TEST IS O | NLY EXECUTED IF MORE THAN 64K RESENT. |
| 5044 5045 5046 5047 5048 5049 | 013440 013442 013450 013456 013460 | 012737 123727 002016 | 000012 001326 000002 | 001262 000002 001664 | f\$134: 6\$: | SCOPE MOV CMPB BGE BIT | 2\$ | ::DO 10. ITERATIONS :CHECK IF >64K MEMORY :YES-SKIP :TEST IF REPORT FLAG SET |

| | | E 8 | |
|---|------------------------|--|---|
| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) T34 | 28-AUG-81 15:17 PAGE WRITE DATA ADDRESS GREAT | 96 TER THAN 64K |
| 5050 013466 001011 | | BNE 1\$ | ;NO-SKIP |
| 5056 013512 000467 | 001664 | TYPE .OPRO11 TYPE .OPRO13 TYPE .OPRO15 BIS #MEMSZB.OPTFLG BR 5\$ | :"INSUFFICIENT MEMORY-DATA XFER WITH :ADDRESS >64K :BYPASSED" ;SET FLAG |
| 5057 5058 013514 012737 013522 | 001110 25: | MOV #3\$, \$LPERR | SET LOCAL LOOP ON ERROR |
| 5059 5060 013522 5061 013522 104416 5062 013524 104003 5063 013526 004437 042260 5064 013532 010011 5065 013534 003777 5066 013536 000400 | 3\$: | ISSINIT ERROR 3 JSR R4,GENCOM 10011 3777 400 | CLEAR SUBSYSTEM BAD INIT ERROR GENERATE DATA, PATTERN 11 MEM MANAGEMENT ON DESTINATION RELOCATION ARGUMENT 400 WORDS |
| 5067 5068 013540 004437 035674 5069 013544 000523 5070 013546 177400 5071 013550 177770 5072 013552 020 5073 013553 000 5074 013554 000312 | | JSR R4, LRLOAD WRDATA!BA16 -400 177770 .BYTE 20 .BYTE 0 | :LOAD 'L' REGS ;WRITE DATA AND SET BA16 :400 WORDS ;ACCROSS 64K BOUNDARY :SECTOR 20 :TRACK 0 :CYLINDER 312 |
| 5075 5076 013556 104417 5077 013560 104430 5078 013562 104002 5079 | | TLOADRK TWAT96 ERROR 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5080 013564 104421 5081 013566 104004 5082 013570 004437 042260 5083 013574 002007 5084 013576 001000 | | TCHKOP ERROR 4 : OR 5, 6, 7, JSR R4,GENCOM 2007 1000 | ; CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS ; CLEAR IBUFF TO 1'S |
| 5085 5086 013600 004437 035674 5087 013604 000121 5088 013606 177400 5089 013610 070414 5090 013612 020 5091 013613 000 5092 013614 000312 5093 013616 104417 5094 013620 104424 5095 013622 104002 | | JSR R4,LRLOAD RDDATA -400 IBUFF .BYTE 20 .BYTE 0 312 TLOADRK TWAT32 ERROR 2 | :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 20 :TRACK 0 :CYLINDER 312 :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5096 5097 013624 104421 5098 013626 104004 5099 013630 004437 042260 5100 013634 110000 5101 013636 003777 5102 013640 000400 5103 013642 000413 5104 013644 104015 | | TCHKOP ERROR 4: OR 5, 6, 7, JSR R4.GENCOM 110000 3777 400 BR 5\$ ERROR 15 | CHECK OPERATION FOR ANY ERRORS CHECK DATA MEMORY MANAGEMENT WITH DESTINATION RELOCATION ARGUMENT HOW WORDS NO MISCOMPARES-SKIP REPORT FIRST ERROR |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 134 | 28-AUG WRITE D | -81 15:17 PAGE ATA ADDRESS GREA | 97 TER THAN 64K |
|--|--|--|--------------------------|--------|-----------------|---|---|---|
| 5106 5107 5108 5109 | 013646 013652 013654 013656 | 013700 005300 001406 004437 050000 | 001634 | | 64\$: | MOV DEC BEQ JSR 50000 | ERRLMT, RO RO 65\$ R4, GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 5111 5112 5113 5114 5115 | 013652 013654 013656 013662 013664 013666 013670 013672 013672 | 000402 104016 000770 | | | 65\$: 5\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 5116 5117 5118 | | | | | : TEST | ****** 35 | READ DATA ADDRE | SS GREATER THAN 64K |
| 5119 5120 | | | | | : | ISSUE A | READ DATA OF 40 | 00 WORDS WITH ADDRESS = 377770. |
| 5122 5123 5124 | | | | | * | NOTE: | THIS TEST IS ON OF MEMORY IS PR | NLY EXECUTED IF MORE THAN 64K |
| 5125 5126 5127 5128 5129 5130 | 013672 013674 013702 013710 013712 | 000004 012737 123727 002001 000462 | 00001 <i>2</i> 001326 | 001262 | 1\$: | SCOPE MOV CMPB BGE BR | #10.,\$TIMES \$MAM\$1,#2 2\$ 5\$ | ;;DO 10. ITERATIONS ;CHECK IF >64K MEMORY ;YES-SKIF ;EXIT |
| 5132 | 013714 | 012737 | 000032 | 001110 | 2\$: | MOV | #32,\$LPERR | SET LOCAL LOOP ON ERROR |
| 5119 5120 5121 5122 5122 5122 5122 5123 5124 5126 5127 5128 5129 5133 5133 5133 5133 5141 5142 5144 5144 5144 5144 5144 | 013734 | 104416 104003 004437 000123 177400 072414 021 000 000312 004437 000012 000400 | 035674 | | 3\$: | TSSINIT ERROR JSR WRDATA -400 OBUFF .BYTE .BYTE 312 JSR 12 400 | 3 R4,LRLOAD 21 0 R4,GENCOM | CLEAR SUBSYSTEM BAD INIT ERROR LOAD 'L' REGS WRDATA -400 WORDS OBUFF IS BUFF ADDRESS SECTOR 21 TRACK 0 CYLINDER 312 GENERATE DATA PATTERN 12 400 WORDS |
| 5147 5148 5149 5150 | 013754 013756 013760 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 5144 5145 5146 5147 5148 5150 5151 5152 5154 5155 5156 5157 5160 5161 | 013762 013764 013766 013772 013774 013776 014000 014001 014002 | 104421 104004 004437 000521 177400 177770 021 000 000312 | 035674 | | | TCHKOP ERROR JSR RDDATA!! -400 177770 .BYTE .BYTE 312 | 4 : OR 5, 6, 7, R4 LRLOAD BA16 | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :LOAD 'L' REGS :READ DATA AND SET BA16 :400 WORDS :ACCROSS 64K BOUNDARY :FROM SECTOR 21 :TRACK 0 :CYLINDER 312 |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 98
CZR6KG.P11 28-AUG-81 15:16
                                           T35
                                                     READ DATA ADDRESS GREATER THAN 64K
  5162
5163
        014004
                                                     TLOADRK
                                                                               :LOAD RK REGS
                 104417
        014006
                 104424
                                                     TWAT-32
                                                                               :WAIT FOR INTERRUPT
                                                     ERROR
                                                                               :TO SLOW/NOT COMPLETE ERROR
        014010
  5164
                 104002
                                                             4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
R4.GENCOM : COMPARE DATA
  5165
  5166
        014012
                 104421
                                                     TCHKOP
  5167
        014014
                 104004
                                                     ERROR
                 004437
  5168
        014016
                          042260
                                                     JSR
                                                     120000
  5169
5170
        014022
                 120000
                                                                               :MEM MANAGEMENT WITH SOURCE
        014024
                 003777
                                                                               : RELOCATION ARGUMENT
        014026
                                                     400
  5171
                 000400
                                                                               :400 WORDS
  5172
5173
        014030
                                                     BR
                                                                               :NO MISCOMPARES-SKIP
                 000413
                                                             15
                                                                               REPORT FIRST ERROR
                                                     ERROR
        014032
                 104015
  5174
  5175
        014034
                 013700
                          001634
                                                             ERRLMT . RO
                                                                               :GET ERROR LIMIT
                                                     MOV
  5176
        014040
                 005300
                                            645:
                                                     DEC
                                                                               : DECREMENT COUNT
                                                             RO
  5177
                                                             65$
        014042
                 001406
                                                     BEQ
                                                                               : IF ZERO - EXIT
                 004437
                                                             R4, GENCOM
                                                                               CONTINUE DATA COMPARE
  5178
        014044
                          042260
                                                     JSR
  5179
        014050
                 060000
                                                     60000
  5180
5181
        014052
                 000402
                                                     BR
                                                             65$
                                                                               :NO MORE ERRORS - EXIT
        014054
                 104016
                                                     ERROR
                                                             16
                                                                               :REPORT NEXT ERROR
  5182
5183
                 000770
                                                             64$
                                                                               :L00P
        014056
                                                     BR
                                            65$:
        014060
  5184
  5185
        014060
  5186
                                            ;;**********************************
                                                             WRITE DATA ADDRESS GREATER THAN 96K
  5187
                                            : * TEST 36
  5188
  5189
                                                     ISSUE A WRITE DATA OF 400 WORDS WITH ADDRESS = 577770.
  5190
                                                     MAKE SURE CORRECT DATA IS ON DISK.
  5191
  5192
                                                             THIS TEST IS ONLY EXECUTED IF MORE THAN 96K
                                                    NOTE:
  5193
                                                             OF MEMORY IS PRESENT.
  5194
  5195
                 000004
                                            TST36:
  5196
        014060
                                                    SCOPE
                                                                               :: DO 10. ITERATIONS
: CHECK IF > 96K MEMORY
  5197
        014062
                          000012 001262
                                                              #10. STIMES
                                                     MOV
                 123727
  5198
        014070
                          001326
                                   000003
                                                     CMPB
                                                             $MAMS1,#3
                 002016
032737
001011
  5199
        014076
                                                     BGF
                                                              3$
                                                                                : YES-SKIP
  5200
5201
        014100
                          000002 001664
                                                             #MEMSZB, OPTFLG
                                                                               :TEST IF REPORT FLAG SET
                                                     BIT
        014106
                                                                               :NO-SKIP
                                                     BNE
  5202
5203
5204
5205
5206
5207
5208
5209
5210
5211
                                                              .OPR011
        014110
                 104401
                          051573
                                                     TYPE
                                                                                "INSUFFICIENT MEMORY-DATA TRANSFET WITH
                 104401
                                                              . OPR014
        014114
                          051746
                                                     TYPE
                                                                               :ADDRESS >96K BYPASSED"
                 104401
052737
                          051752
        014120
                                                     TYPE
                                                              .OPR015
        014124
                          000002
                                   001664
                                                     BIS
                                                              #MEMSZB, OPTFLG : SET REPORT FLAG
        014132
                 000463
                                                     BR
                                                              6$
        014134
                 012737 014142 001110
                                           35:
                                                     MOV
                                                             #4$. $LPERR
                                                                               :SET LOCAL LOOP ON ERROR
        014142
  5212
5213
5214
5215
        014142
                 104416
                                                     TSSINIT
                                                                               : CLEAR SUBSYSTEM
                                                                               :BAD INIT ERROR
        014144
                 104003
                                                     ERROR
                                                     JSR R4, LRLOAD WRDATA! BA17
                 004437 035674
        014146
                 001123
        014152
                                                                               : WRITE DATA AND BA17
  5216
         014154
                                                     -400
                                                                               :400 WORDS FROM
         014156
                 177770
                                                                               : ACCROSS 96K BOUNDARY
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | | | |
|---|---|--|---|
| 5218 014160 022 5219 014161 000 5220 014162 000312 5221 014164 004437 042260 5222 014170 010013 5223 014172 005777 5224 014174 000400 | .BYTE | R4.GENCOM | :TO SECTOR 22 :TRACK 0 :CYL 312 :GENERATE DATA :PATTERN 13 MEM MAN WITH DEST. :RELOCATION ARGUMENT :400 WORDS |
| 5226 014176 104417 5227 014200 104430 5228 014202 104002 | TLOADRK TWAT96 ERROR | | :LOAD RK REGS ;WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5230 014204 104421 5231 014206 104004 | T CHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |
| 5219 014161 0000 5220 014162 000312 5221 014164 004437 042260 5222 014170 010013 5223 014172 005777 5224 014174 000400 5225 5226 014176 104417 5227 014200 104430 5228 014202 104002 5229 5230 014204 104421 5231 014206 104004 5232 5233 014210 004437 035674 5234 014214 000121 5235 014216 177400 5236 014220 070414 5237 014222 022 5238 014223 000 5241 014226 104417 5242 014230 104424 | JSR RDDATA -400 IBUFF .BYTE .BYTE .312 | | :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 22 :TRACK 0 :CYLINDER 312 |
| 5241 014226 104417 5242 014230 104424 5243 014232 104002 5244 | TLOADRK TWAT32 ERROR | | :LOAD RK REGS ;WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5245 014234 104421 5246 014236 104004 5247 | T CHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |
| 5248 014240 004437 042260 5249 014244 110000 5250 014246 005777 5251 014250 000400 | JSR 110000 5777 400 BR ERROR | R4.GENCOM | COMPARE DATA MEM MANAGEMENT WITH DESTINATION RELOCATION ARGUMENT 400 WORDS NO MISCOMPARES-BRANCH REPORT 1ST ERROR |
| 5252 014252 000413 5253 014254 104015 5254 5255 014256 013700 001634 5256 014262 005300 5257 014264 001406 5258 014266 004437 042260 5259 014272 050000 5260 014274 000402 5261 014276 104016 5262 014300 000770 | 64\$: MOV BEQ JSR 50000 BR ERROR BR | ERRLMT, RO RO 65\$ R4, GENCOM 65\$ 16 64\$ | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE NO MORE ERRORS - EXIT REPORT NEXT ERROR |
| 5263 014302 5264 | 65\$: | 043 | . LOUP |
| 5265 014302 5266 5267 | | | SS GREATER THAN 96K |
| 5269 5270 | ;* CHECK M | READ DATA OF 400 | WORDS WITH ADDRESS = 577770. |
| 5266 5267 5268 5269 5270 5271 5272 5273 | NOTE: | THIS TEST IS ONE OF MEMORY IS PRE | Y EXECUTED IF MORE THAN 96K |

CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 100 CZR6KG.P11 28-AUG-81 15:16 T37 READ DATA ADDRESS GREATER THAN 96K

| 1 | 5274 | | | | | :* | | | |
|---|--|--|--|------------------|--------|-----------------|---|---|--|
| | 275 276 277 278 279 280 | 014302 014304 014312 014320 014322 | 000004 012737 123727 002001 000462 | 000012 001326 | 001262 | †\$137: 2\$: | SCOPE MOV CMPB BGE BR | #10.,\$TIMES \$MAM\$1,#3 3\$ 6\$ | ::DO 10. ITERATIONS :CHECK IF >96K MEMORY :YES-SKIP |
| - | 282 | 014324 | 012737 | 014332 | 001110 | 3\$: | MOV | #4\$, \$LPERR | SET LOCAL LOOP ON ERROR |
| | 284 285 286 | 014332 014332 014334 | 104416 | | | 45: | ISSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| | 288 289 290 291 292 293 294 295 296 297 | 014342 014344 014346 014350 014351 014352 | 004437 000123 177400 072414 005 000 000312 004437 000014 000400 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 JSR 14 400 | R4, LRLOAD 5 0 R4, GENCOM | LOAD 'L' REGS :WRDATA :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 5 :TRACK 0 :CYLINDER 312 :GENERATE DATA :PATTERN 14 :400 WORDS |
| | 300 301 | 014364 014366 014370 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 5311 | 014372 014374 014376 014402 014404 014406 014410 014411 014412 | 104421 104004 004437 001121 177400 177770 005 000 000312 | 035674 | | | TCHKOP ERROR JSR RDDATA!E -400 177770 .BYTE .BYTE 312 | 4 : OR 5, 6, 7 R4, LRLOAD BA17 | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :LOAD 'L' REGS :READ DATA WITH BA17 SET :400 WORDS :ACCROSS 96K BOUNDARY :FROM SECTOR 5 :TRACK 0 :CYL 312 |
| | 5313 5314 5315 | 014414 014416 014420 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 5312 5313 5314 5315 5316 5317 5318 5321 5322 5323 5324 5326 5327 5328 5329 | 014422 014424 014426 014432 014434 014436 014440 014442 | 104421 104004 004437 120000 005777 000400 000413 104015 | 042260 | | | TCHKOP ERROR JSR 120000 5777 400 BR ERROR | 4 : OR 5, 6, 7 R4. GENCOM | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :COMPARE DATA :MEM MANAGEMENT WITH SOURCE :RELOCATION ARGUMENT :400 WORDS :NO MISCOMPARES-SKIP :REPORT FIRST ERROR |
| | 5326 5327 5328 5329 | 014444 014450 014452 014454 | 013700 005300 001406 004437 | 001634 | | 64\$: | MOV DEC BEQ JSR | ERRLMT,RO RO 65\$ R4,GENCOM | :GET ERROR LIMIT :DECREMENT COUNT :IF ZERO - EXIT :CONTINUE DATA COMPARE |
| | | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30 (1046) 137 | 28-AUG- READ DAT | -81 15:17 PAGE TA ADDRESS GREATE | 101 ER THAN 96K |
|--|--|--|---------------|--------|------------------|---|--|---|
| 5330 5331 5332 5333 5334 5335 5336 5337 5338 5339 | 014460 014462 014464 014466 014470 | 060000 000402 104016 000770 | | | 65\$: | 60000 BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 5336 5337 | 014470 | | | | 6\$: | | ***** | ******* |
| 5338 | | | | | :*TEST | 40 | PARTIAL SECTOR V | |
| 5340 5341 5342 5343 | | | | | * | HEAD O. | WRITE DATA OF 10 SECTOR O. MAKE LED CORRECTLY. | 03 WORDS TO CYLINDER 312, SURE THE SECTOR WAS |
| 5344 | 014470 014472 014500 014502 | 000004 012737 104416 104003 | 000012 | 001262 | TST40: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 5345 5346 5347 5348 5349 5350 5351 5352 5353 5354 5355 5357 | 014504 014510 014512 014514 014516 014517 014520 | 004437 000123 177675 072414 007 000 000312 | 035674 | | | JSR WRDATA -103 OBUFF .BYTE .BYTE 312 | R4,LRLOAD 7 | :LOAD 'L' REG :WRITE DATA :WORD COUNT PARTIAL SECTOR :BUFF ADDRESS :SECTOR 7 :TRACK 0 :CYLINDER 312 |
| 5358 5359 5360 | 014522 014526 014530 | 004437 000003 000400 | 042260 | | | JSR 3 400 | R4,GENCOM | GENERATE DATA PATTERN 3 400 WORDS |
| 5361 5362 5363 5364 5365 | 014532 014534 014536 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5366 | 014540 014542 | 104421 104004 | | | | T CHKOP ERROR | 4 : OR 5.6.7 | CHECK FOR ANY ERROR REPORT ALL ERROR |
| 5369 | 014544 | 004437 | 035674 | | | JSR | R4, LRLOAD | ;LOAD 'L' REGS |
| 5367 5368 5369 5370 5371 5372 5373 5374 5375 5376 5378 5379 5380 5381 5382 5383 | 014550 014552 014554 014556 014557 014560 | 000121 177400 070414 007 000 000312 | | | | RDDATA -400 IBUFF .BYTE .BYTE 312 | 7 0 | READ DATA ONE FULL SECTOR BUFF ADDRESS SECTOR 7 TRACK 0 CYLINDER 312 |
| 5378 5379 5380 | 014562 014566 014570 | 004437 002007 000400 | 042260 | | | JSR 2007 400 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 5382 5383 5384 5385 | 014572 014574 014576 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 140 | 28-AUG PARTIAL | -81 15:17 PAGE SECTOR WRITE DA | 102 ATA |
|--|--|--|------------------|--------|---|---|--|---|
| 5386 5387 | 014600 014602 | 104421 104004 | | | | TCHKOP | 4 : OR 5.6.7 | CHECK FOR ANY ERRORS |
| 5387 5388 5389 5390 5391 5392 5394 5395 5396 | 014604 014610 014614 014616 014620 | 012701 012700 005021 005300 001375 | 072622 000275 | | 1\$: | MOV MOV CLR DEC BNE | #0BUFF+206,R1 #275,R0 (R1)+ R0 1\$ | CLEAR THE LAST 205 WORDS OF THE OUTPUT BUFFER TO ZERO TO VERIFY THE PARTIAL SECTOR WRITE O FILLED THE SECTOR |
| 5395 5396 5397 5398 5399 | 014622 014626 014630 014632 014634 | 004437 100000 000400 000413 104015 | 042260 | | | JSR 100000 400 BR ERROR | R4, GENCOM 3\$ | COMPARE OBUFF & IBUFF. ALL 400 WORDS NO ERRORS-EXIT REPORT FIRST COMPARE ERROR |
| 5400 5401 5402 | 014636 014642 014644 | 013700 005300 001406 | 001634 | | 2\$: | MOV DEC BEQ | ERRLMT,RO RO 3\$ | GET ERROR LIMIT DECREMENT IT IF ZERO-EXIT |
| 5403 5404 5405 5406 5407 5408 | 014646 014652 014654 014656 014660 | 004437 040000 000402 104016 000770 | 042260 | | | JSR 40000 BR ERROR BR | R4, GENCOM 3\$ 16 2\$ | CONTINUE COMPARE NO MORE ERRORS-EXIT REPORT NEXT COMPARE ERROR LOOP |
| 5409 5410 | 014662 | | | | 3\$: | ****** | ************ | |
| 5411 | | | | | *TEST | 41 | PARTIAL SECTOR | READ DATA |
| 5412 5413 5414 5415 5416 5417 5418 | | | | | * | WRITE C KNOWN C 103 WOR MAKE SU TO MEMO | RE ONLY 103 WORD | ACK O, SECTOR ZERO WITH A ISSUE A READ DATA OF 312, TRACK O, SECTOR O. OS GET TRANSFERRED |
| 5419 5420 5421 5422 5423 | 014662 014664 014672 014674 | 000004 012737 104416 104003 | 000012 | 001262 | TST41: | SCOPE | #10\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 5425 5426 5427 5428 5429 | 014662 014664 014672 014674 014674 014702 014704 014706 014710 014711 014712 014714 014720 014722 014724 014726 014730 | 004437 000123 177400 072414 017 | 035674 | | | LIDDATA | R4.LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-400 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 17 ;TRACK 0 ;CYLINDER 312 ;GENERATE DATA |
| 5431 5432 5433 5434 | 014712 014714 014720 014722 | 000312 004437 000004 000400 | 042260 | | | 312 JSR 4 | R4,GENCOM | CYLINDER 312 GENERATE DATA PATTERN 4 :400 WORDS |
| 5436 5437 5438 | 014724 014726 014730 | 104417 104430 104002 | | | | | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5440 5441 | 014732 014734 | 104421 104004 | | | | | | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |

MACY11 30(1046) 28-AUG-81 15:17 PAGE 103

T41

PARTIAL SECTOR READ DATA

CZR6KGO RK6 FCTNL CTRL DIAG

CZR6KG.P11 28-AUG-81 15:16

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T42 | 28-AUG- WRITE DA | -81 15:17 PAGE ATA WITH NON-EXI | 104 STENT MEMORY |
|--|--|--|--|------------------|-----------------|---|---|--|
| 5498 5499 5500 | 015104 015105 015106 | 013 000 000312 | | | | BYTE BYTE 312 | 13 | :SECT 13 :TRACK 0 :CYLINDER 312 |
| 5502 5503 5504 5505 5506 5507 | 015110 015112 015114 015116 015120 015122 | 104417 104430 104002 104422 000000 000000 | | | | 0 | 2 | |
| 5500 5501 5502 5503 5504 5506 5506 5508 5510 5511 5512 5513 5514 5518 5518 5521 5521 5521 5522 5523 5526 5529 5530 | 015120 015122 015124 015126 015130 015136 015144 015150 015162 015166 015174 015204 015204 015214 015222 | 000040 104004 012737 012737 113700 042700 | 054151 050650 001541 177774 000003 | 001450 061072 | | BIC | #177774,R0 #3,R0 | TEST IF BOTH UPPER BUS BITS SET |
| 5516 5517 5518 | 015162 015166 015174 | 001406 010037 012737 104010 022737 | 001204 000003 | 001202 | | BEQ MOV MOV ERROR | 1\$ RO.\$REG11 #3.\$REG10 | ; YES - SKIP ; SET UP FOR ERROR REPORT |
| 5519 5520 5521 | 015176 015204 015206 | 022737 001412 012737 012737 013737 | 176002 054123 | 001544 | 1\$: | CMP BEQ MOV | #176002,T.BA 2\$ #EM11,EM10N | :YES - SKIP :SET UP MESSGAE |
| 5523 5524 5525 | 015222 015230 | 013737 | 176002 001544 | 001202 | | MOV MOV ERROR | #176002,\$REG10 T.BA,\$REG11 10 | STORE VALUE FOR REPORT |
| 5531 | 015232 015236 015240 015246 015252 015260 | 005737 001411 012737 005037 013737 104010 | 001542 054076 001202 001542 | 001450 001204 | 2\$: | TST BEQ MOV CLR MOV ERROR 1 | 3\$ #EM10.EM10N \$REG10 T.WC,\$REG11 | :TEST IF WORD COUNT CORRECT :YES - SKIP :SET UP MESSAGE |
| 5532 5533 5534 | 015262 | | | | 3\$: | | | |
| 5535 5536 | | | | | :***** *TEST | 43 .*** | ************************************** | NON-EXISTENT MEMORY |
| 5534 5535 5536 5537 5538 5539 5540 5541 | | | | | ;* ;* ;* | ISSUE A | READ DATA OF 1 RE NON-EXISTENT | WORD USING ADDRESS 776000. MEMORY SETS. |
| 5542 5543 5544 5545 | 015262 015264 015272 015274 | 000004 012737 104416 104003 | 000012 | 001262 | 15143: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES 3 | ;;DO 10. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 5546 5547 5548 5549 5550 5551 5552 5553 | 015276 015302 015304 015306 015310 015311 015312 | 004437 001521 177777 176000 013 000 000312 | 035674 | | | JSR BA16!BA -1 176000 .BYTE .BYTE 312 | R4.LRLOAD 17:RDDATA | :LOAD 'L' REG :BA16 & 17 WITH READ DATA :WORD COUNT OF 1 :BUFF ADDRESS=IO PAGE BASE :SECTOR 13 :TRACK 0 :CYL 312 |

| | RK6 FCT P11 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T43 | 28-AUG READ DA | -81 15:17 PAGE TA WITH NON-EXIS | 105 TENT MEMORY |
|--|--|--|--|--------------------------------------|-------------------------|---|--|--|
| 5554 5555 5556 5557 5558 5559 5560 | 015314 015316 015320 015322 015324 015326 | 104417 104430 104002 104422 000000 000000 | | | | 0 | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION WITH ERRORS |
| 5562 5563 5564 5565 | 015314 015316 015320 015322 015324 015326 015330 015332 015334 015342 015350 015360 015360 | 000040 104004 012737 012737 113700 042700 022700 | 054151 050724 001541 177774 000003 | 001450 061072 | | NEMERR ERROR MOV MOV MOVB BIC CMP | 4; OR 5,6,7 #EM11A,EM10N #OPER43,DF010A T.CS1+1,R0 #177774,R0 #3,R0 1\$ | ;NON-EXISTENT MEMORY ERROR ;REPORT ALL DISCREPANCIES ;SET MESSAGE ;SET SUPPORT MESSAGE ;GET UPPER CS1 ;CLEAR UNWANTED BITS ;TEST BOTH BUS 16 & 17 SET ;YES - SKIP |
| 5569 5570 5571 | 015364 015366 015374 015400 | 001406 012737 010037 104010 | 000003 001204 | 001202 | | BEQ MOV MOV ERROR | #3,\$REG10 RO,\$REG11 10 | SET VALUES FOR REPORT |
| 5567 5568 5569 5570 5571 5572 5573 5574 5575 5576 5577 | 015402 015410 015412 015420 015426 015434 | 022737 001412 012737 012737 013737 104010 | 176002 054123 176002 001544 | 001544 001450 001202 001204 | 1\$: | CMP BEQ MOV MOV MOV ERROR | #176002,T.BA 2\$ #EM11,EM10N #176002,\$REG10 T.BA,\$REG11 | :TEST IF BUS ADDRESS CORRECT :YES - SKIP :SET MESSAGE :SET VALUES FOR REPORT |
| 5579 5580 5581 5582 5583 5584 5585 | 015436 015442 015444 015452 015456 015464 | 005737 001411 012737 005037 013737 104010 | 001542 054076 001202 001542 | 001450 001204 | 2\$: | TST BEQ MOV CLR MOV ERROR | T.WC 3\$ #EM10,EM10N \$REG10 T.WC,\$REG11 | :TEST IF WORD COUNT CORRECT :YES - SKIP :SET MESSAGE :SET VALUES |
| 5586 5587 5588 | 015466 | | | | 3\$: | | | |
| 5589 5590 5591 | | | | | :***** :*TEST | ****** 44 | UNIBUS PARITY E | ************************************** |
| 5589 5590 5591 5592 5593 5594 5595 5596 5597 5598 5599 5600 | | | | | * * * * | PARITY. STARTIN THE LOC | IZE A MEMORY LOC ISSUE A WRITE D G AT A LOCATION ATION WITH BAD P IBUS PARITY ERRO | ATA OF 400 WORDS 112 WORDS BEFORE ARITY. MAKE SURE |
| 5598 5599 5600 5601 5602 5603 | | | | | ;* ;* ;* | NOTE: | THIS TEST IS ON MEMORY PARITY O BUFFER. IT WILL ON 'ECC' TYPE M | PTION EXISTS FOR NOT BE EXECUTED |
| 5603 5604 5605 | 015466 | 000004 | | | :* ::***** TST44: | ******** SCOPE | ****** | ****** |
| 5606 5607 5608 5609 | 015470 015476 015500 | 012737 104416 104003 | 000012 | 001262 | | MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |

| CZR6KGO | RK6 FCT | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 144 | 28-AUG- | -81 15:17 PAGE PARITY ERROR | 106 | |
|--|--|--|--|--|-----------------|---|---|--|--|
| 5610 5611 5612 5613 5614 5615 5616 | 015502 015510 015512 015520 015522 015526 015534 | 032737 001013 032737 001005 104401 052737 000137 | 000100 000004 051452 000004 016326 | 001664 | 25\$: | BIT BNE BIT BNE TYPE BIS JMP | 1\$ #MEMPYB,OPTFLG 25\$,OPR010 | :TEST IF PARITY OPTION PRESENT :YES-SKIP :TEST IF PARITY OPTION REPORTED :YES-SKIP TO EXIT :PRINT BYPASS MESSAGE :SET OPTION REPORTED BIT :SKIP TO EXIT | |
| 5612 5613 5613 5614 5617 5618 5619 5622 5622 5622 5622 5622 5622 5622 562 | 015540 015540 015544 015546 015550 015552 015553 015554 | 004437 000123 177400 072414 010 000 000312 | 035674 | | 1\$: | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4.LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-400 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 10 ;TRACK 0 ;CYLINDER 312 | |
| 5626 5627 5628 5629 | 015556 015564 015566 | 032737 001002 005077 | 002000 164100 | 001664 | | BIT BNE CLR | #CP1170,OPTFLG 3\$ aCSRPTR | :TEST IF 11/70 :YES - SKIP :CLEAR PARITY IE | |
| 5630 5631 5632 5633 | 015572 015576 015600 | 004437 000007 000400 | 042260 | | 3\$: | JSR 7 400 | R4,GENCOM | GENERATE DATA PATTERN 7 400 WORDS | |
| 5635 5636 5637 5638 | 015602 015606 015612 015614 | 012746 012746 000002 | 000340 015614 | | 10\$: | MOV MOV RTI | #PR7,-(SP) #10\$,-(SP) | :PUT PRIORITY 7 CN STACK :PUT ADDRESS ON STACK :SET PRI | |
| 5640 5641 5642 5643 5644 5645 | 015614 015622 015630 015632 015640 015646 | 012737 032737 001011 012777 012737 012777 | 100200 002000 000004 100200 000001 | 001664 | | MOV BIT BNE MOV MOV | #CP1170,OPTFLG 5\$ #BIT2.aCSRPTR | 24; SET WORD IN BUFFER ; TEST IF 11/70 ; YES - SKIP ; SET WRITE WRONG PARITY BIT 24; SET BAD PARITY IN MEMORY ; CLEAR CONTROL BIT, SET IE BIT | |
| 5646 5647 5648 5649 5650 5651 5652 5653 5655 5656 5657 5658 5659 5660 5661 | 015654 015660 015664 015666 015672 015674 015700 015706 015714 015722 015724 015732 015734 015750 015750 | 013746 012746 000002 013704 005000 012701 012777 012777 012737 104417 032737 001434 012737 012777 012777 | 001622 015666 001672 001662 070400 070410 016302 002000 000016 000000 000000 170000 | 163712 164002 001264 001664 177746 163740 163166 177750 | 5\$: 11\$: | MOV MOV RTI MOV CLR MOV MOV TLOADRK BIT BEQ MOV MOV MOV | RKPRI,-(SP) #11\$,-(SP) CSRPTR,R4 RO #INTSET,R1 #SPCHLR,@RKVEC #SPCPAR,@MMVECA #2\$,\$ESCAPE #CP1170,OPTFLG 45\$ #16,177746 #0,@KWLADD #0,@STKS #170000,177750 | SET OLD PRIORITY SET ADDRESS RESTORE PRI SET R4 WITH CSR POINTER SET R0 FOR COUNTER SET R1 FOR POINTER TO INTERRUPT FLAG SET UP INTERRUPT VECTORS FOR RK611 AND PARITY ERROR SET UP ESCAPE FOR ERROR LOAD RK REGS TEST IF 11/70 NO - SKIP SET TO DISABLE CACHE AND UNIBUS ERROR TURN OFF CLOCK INTERRUPTS TURN OFF KEYBOARD SET FOR ERROR FORCE | |
| 5664 5665 | 015764 | 105711 | | | 40\$: | TSTB | (R1) | :LOOP TO WAIT FOR INTERRUPT OR ABORT | |

| CZR6KG0 CZR6KG. |) RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 144 | | 5-81 15:17 PAGE PARITY ERROR | 107 |
|--|--|--|--|--|-------------------------|--|--|---|
| 5666 5667 5669 5670 5671 5672 5673 5674 | 015766 015770 015772 015774 015776 016000 016002 | 003005 005300 100774 000240 003372 000240 005014 | | | 43\$: | BGT DEC BMI NOP BGT NOP CLR | 43\$ R0 40\$ 40\$ (R4) | :WAIT. THE CODE BETWEEN THE STARS IS SET :SET UP SO ALL BYTES HAVE PARITY OF 1. :IF THIS CODE IS CHANGED, REMEMBER ALL :BYTES MUST HAVE AN EVEN NUMBER OF :BITS. :CLEAR ERROR FORCE |
| 5674 5675 5676 5677 5678 5679 5680 5681 5682 5683 5684 5685 | 016004 016010 016016 016024 016026 016030 016036 016040 016040 016050 | 005037 012777 012777 104430 000414 032737 001024 005077 005037 012777 | 177746 000100 000100 002000 163626 072640 000001 | 163672 163120 001664 163614 | 45\$: | CLR MOV MOV TWAT96 BR BIT BNE CLR CLR MOV BR | 177746 #BIT6, akwLADD #100, a\$TKS 46\$ #CP1170, OPTFLG 48\$ aCSRPTR OBUFF+224 #1, aCSRPTR 48\$ | :ENABLE CACHE :TURN ON CLOCK INTERRUPTS :TURN ON KEYBOARD INTERRUPTS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :TEST IF 11/70 :YES - SKIP :ELSE CLEAR CSR :CLEAR THE BAD PARITY WORD :SET PARITY DETECT AGAIN :SKIP |
| 5687 5688 5689 5690 5691 5692 5693 5694 5695 5696 5697 | 016060 016070 016074 016100 016106 016110 016110 016112 016114 016116 016120 | 032737 001007 005077 005037 012777 104002 104422 000000 000000 000100 104004 | 002000 163576 072640 000001 | 001664 163564 | 46\$: 47\$: 48\$: | BIT BNE CLR CLR MOV ERROR TCHKWE O UPERR ERROR | #CP1170,OPTFLG 47\$ aCSRPTR OBUFF+224 #1,aCSRPTR 2 | :TEST IF 11/70 :YES - SKIP :CLEAR CSR :CLEAR BAD PARITY WORD :SET UP PARITY DETECT AGAIN :REPORT TO SLOW ERROR :CHECK OPERATION WITH ERROR :UNIBUS PARITY ERROR :REPORT ALL DISCREPANCIES |
| 5699 5700 5701 5702 5703 5704 5705 5706 5707 5708 5709 | 016122 016126 016134 016142 016150 016152 016160 016166 016170 | 005037 012737 012737 023727 103010 012737 013737 104010 000413 | 001264 050777 054123 001544 072642 001544 | 061072 001450 072642 001202 001204 | | CLR MOV MOV CMP BHIS MOV MOV ERROR BR | 14\$ | CLEAR ESCAPE SET MESSAGES FOR REPORT CHECK IF BA IN RANGE NOT TO LOW - SKIP SET VALUES FOR REPORT |
| 5710 5711 5712 5713 5714 5715 | 016172 016200 016202 016210 016216 | 023727 101407 012737 012737 104010 | 001544 072646 001544 | 072646 001202 001204 | 14\$: | CMP BLOS MOV MOV ERROR | T.BA,#0BUFF+232 16\$ #0BUFF+232,\$REG1 #T.BA,\$REG11 | :CHECK IF BA IN RANGE :YES - SKIP 10 :SET VALUES |
| 5716 5717 5718 5719 5720 5721 | 016220 016226 016234 016236 016244 016252 | 012737 023727 103007 012737 013737 104010 | 054076 001542 177513 001542 | 001450 177513 001202 001204 | 16\$: | MOV CMP BHIS MOV MOV ERROR | #EM10.EM10N T.WC.#-265 20\$ #-265.\$REG10 T.WC.\$REG11 | :SET MESSAGE :CHECK IF WORD COUNT WITHIN RANGE :YES - SKIP :SET VALUES |

| CZR6 | KGO | RK6 FCT | NL CTRL 8-AUG-81 | | MACY11 | 30(1046) 144 | 28-AUG | -81 15:17 PAGE PARITY ERROR | 108 | |
|----------------------------|---|--|--|----------------------------|----------------------------|-----------------|------------------------------------|--|---|----------|
| 57 57 57 57 57 | 722 723 724 725 726 727 728 | 016254 016262 016264 016272 016300 | 023727 101407 012737 013737 104010 | 001542 177515 001542 | 177515 001202 001204 | 20\$: | CMP BLOS MOV MOV ERROR | T.WC.#-263 2\$ #-263,\$REG10 T.WC,\$REG11 | :STILL CHECKING IF WC :YES - SKIP :SET VALUES | IN RANGE |
| 57 | 29 | 016302 016302 | 005037 | 001264 | | 2\$: | CLR | \$ESCAPE | ;REV 006 | |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 144 | 28-AUG- | -81 15:17 PAGE PARITY ERROR | 109 |
|--|--|--|----------------------------|------------------|-----------------|--|----------------------------------|---|
| 5731 5732 5733 5734 5735 | 016306 016314 016320 016326 | 012777 004737 012777 | 034442 034522 000100 | 163304 162616 | 45: | MOV JSR MOV | PC.OPTIST | :RESET INT. VECTORS FOR RK06 :INSURE KEYBOARD IS ENABLED |
| 5734 5735 5736 5737 5738 5739 5740 | | | | | .SBTTL | ****** | PLE SECTOR OPERA | ****** |
| 5741 5742 5743 5744 5745 5746 | | | | | ** TEST ** | ISSUE A | WRITE DATA OF 10, SECTOR O. REAL | 000 WORDS TO CYLINDER 312, D DATA BACK ONE SECTOR |
| 5747 | 016326 016330 016336 016340 | 000004 012737 104416 104003 | 000012 | 001262 | | SCOPE MOV TSSINIT ERROR | | ;;DO 10. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 5749 5750 5751 5752 5753 5754 5755 5756 5757 5758 5759 | 016342 016346 016350 016352 016354 016355 016356 | 004437 000123 177000 072414 000 000 000312 | 035674 | | | JSR WRDATA -1000 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-1000 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 0 ;TRACK 0 ;CYLINDER 312 |
| 5760 5761 5762 5763 5764 | 016360 016364 016366 | 000015 | 042260 | | | JSR 15 1000 | R4, GENCOM | GENERATE DATA PATTERN 15 1000 WORDS |
| 5765 5766 | 016370 016372 016374 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 5769 5770 | 016376 016400 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7, | :CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 5772 5773 5774 | 016402 016406 016410 | 004437 002007 001000 | 042260 | | | JSR 2007 1000 | R4,GENCOM | :CLEAR IBUFF :TO ALL 1'S |
| 5767 5768 5769 5770 5771 5772 5773 5774 5775 5776 5777 5778 5778 5778 5780 5781 5782 5783 | 016412 016416 016420 016422 016424 016425 016426 | 004437 000121 177400 070414 000 000 000 | 035674 | | | JSR RDDATA -400 IBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 3:2 |
| 5784 5785 5786 | 016430 016432 016434 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

| |) RK6 FCT P11 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 145 | 28-AUG TWO SEC | -81 15:17 PAG TOR WRITE DATA | 9 E 110 (PART 1) |
|--|--|--|---------------|--------|-----------------|---|--|---|
| 5787 5788 5789 5790 | 016436 016440 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | ; CHECK OPERATION FOR ANY ERRORS , 10 : REPORT ALL ERRORS |
| 5791 5792 5793 | 016442 016446 016450 016452 016454 016455 016456 | 004437 000121 177400 071414 001 000 000312 | 035674 | | | JSR RDDATA -400 IBUFF+1 .BYTE .BYTE .BYTE | | :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF+1000 IS BUFF ADDRESS :SECTOR 1 :TRACK 0 :CYLINDER 312 |
| 5799 5800 5801 5802 | 016460 016462 016464 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 5803 5804 | 016466 016470 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS 10 REPORT ALL ERRORS |
| 5794 5795 5796 5797 5798 5800 5801 5802 5803 5804 5805 5806 5807 5810 5811 5812 5813 5814 5815 5816 5817 5818 | 016472 016476 016500 016502 016504 | 004437 100000 001000 000413 104015 | 042260 | | | JSR 100000 1000 BR ERROR | R4, GENCOM 2\$ 15 | COMPARE DATA 1000 WORDS NO MISCOMPARES-EXIT REPORT FIRST ERROR |
| 5812 5813 5814 5815 5816 | 016506 016512 016514 016516 016522 016524 016526 016530 | 005300 | 001634 | | 64\$: | MOV DEC BEQ JSR 40000 | R4, GENCUM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 5819 5820 | 016526 016530 016532 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 5821 5822 5823 | 016532 | | | | 2\$: | ****** | ***** | ******** |
| 5824 5825 5826 5827 5828 5829 5830 | | | | | | SEEK DI | WRITE DATA OF , SECTOR 23. R ME AND MAKE SUR D NOT TAKE PLACE | |
| 5831 5832 5833 5834 5835 | 016532 016534 016542 016544 | 000004 012737 104416 104003 | 000012 | 001262 | 15146: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 5836 5837 5838 5839 5840 5841 5842 | 016546 016552 016554 016560 016561 | 004437 000123 177000 072414 023 000 | 035674 | | | JSR WRDATA -1000 OBUFF .BYTE .BYTE | R4.LRLOAD | :LOAD "L" REGS :WRDATA :-1000 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 23 :TRACK 0 |

```
CZR6KG.P11 28-AUG-81 15:16
                                                    TWO SECTOR WRITE DATA (PART 2)
                                           146
  5843 016562 000312
                                                    312
                                                                              :CYLINDER 312
  5844
                 004437
  5845
        016564 016570
                                                    JSR
                                                             R4. GENCCM
                          042260
                                                                               GENERATE DATA
                                                    16
                                                                               : PATTERN 16
  5846
                                                    1000
  5847
        016572
                 001000
                                                                               :1000 WORDS
  5848
  5849
        016574
                                                    TLOADRK
                                                                               :LOAD RK REGS
                 104417
  5850
        016576
                                                    TWAT96
                                                                               :WAIT FOR INTERRUPT
                 104430
  5851
5852
5853
                                                    ERROR
                                                                               :TO SLOW/NOT COMPLETE ERROR
        016600
                 104002
        016602
                 104421
                                                    TCHKOP
                                                                               CHECK OPERATION FOR ANY ERRORS
                                                             4 ; OR 5, 6, 7, 10 ; REPORT ALL ERRORS
  5854
        016604
                 104004
                                                    ERROR
  5855
  5856
5857
                                                    IF THE TRACK ADDRESS AT THE END OF OPERATION IS IN ERROR
                                                    THE CONTROLLER DID A MID-TRANSFER SEEK AS THOUGH IT
  5858
                                                    WERE IN 24(8) SECTORS PER TRACK MODE.
  5859
  5860
                 004437
                          035674
                                                                               :LOAD 'L' REGS
        016606
                                                    JSR
                                                             R4.LRLOAD
  5861
5862
5863
                 000121
        016612
                                                    RDDATA
                                                                               :RDDATA
                 177400
                                                                               :-400 WORDS
                                                    -400
        016614
                                                                               : IBUFF IS BUFF ADDRESS
                 070414
                                                    IBUFF
        016616
                    023
                                                             23
  5864
        016620
                                                    .BYTE
                                                                               :SECTOR 23
                                                    BYTE
                                                             0
                                                                               :TRACK 0
  5865
        016621
                    000
        016622
  5866
                 000312
                                                                               :CYLINDER 312
  5867
  5868
                 004437
                          042260
                                                     JSR
        016624
                                                             R4. GENCOM
                                                                               :CLEAR IBUFF TO ALL ONES
        016630
                 002007
                                                    2007
  5869
  5870
        016632
                 001000
                                                    1000
  5871
  5872
5873
        016634
                 104417
                                                    TLOADRK
                                                                               :LOAD RK REGS
        016636
                 104424
                                                    TWAT32
                                                                               :WAIT FOR INTERRUPT
                                                                               : TO SLOW/NOT COMPLETE ERROR
  5874
        016640
                 104002
                                                    ERROR
  5875
  5876
                                                                               CHECK OPERATION FOR ANY ERRORS
        016642
                 104421
                                                    TCHKOP
                                                             4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
  5877
        016644
                 104004
                                                    ERROR
  5878
  5879
                 004437 035674
                                                                               :LOAD 'L' REGS
        016646
                                                    JSR
                                                             R4.LRLOAD
  5880
5881
5882
                 000121
        016652
                                                                               :RDDATA
                                                    RDDATA
        016654
                                                                               :-400 WORDS
                                                    -400
                                                                              :SECTOR 24 : IBUFF +1000 IS BUFF ADDRESS
                                                    IBUFF+1000
BYTE 24
BYTE 0
                 071414
        016656
  5883
        016660
                    024
  5884
5885
5886
5887
                     000
        016661
                                                     .BYTE
                                                                               : TRACK 0
                 000312
        016662
                                                    312
                                                                               :CYLINDER 312
        016664
                 104417
                                                    TLOADRK
                                                                               :LOAD RK REGS
  5888
        016666
                 104424
                                                    TWAT32
                                                                               : WAIT FOR INTERRUPT
  5889
        016670
                 104002
                                                    ERROR
                                                                               :TO SLOW/NOT COMPLETE ERROR
  5890
  5891
        016672
                 104421
                                                    TCHKOP
                                                                               CHECK OPERATION FOR ANY ERRORS
                                                             4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
  5892
        016674
                 104004
                                                    ERROR
  5893
  5894
        016676
                 004437 042260
                                                                               : COMPARE DATA
                                                             R4, GENCOM
  5895
        016702
                 100000
                                                    100000
  5896
        016704
                 001000
                                                    1000
                                                                               :1000 WORDS
                                                             1$
  5897
        016706
                 000413
                                                    BR
                                                                               :NO ERRORS-SKIP
       016710
  5898
                 104015
                                                    ERROR
                                                                               :REPORT FIRST ERROR
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 111

CZR6KGO RK6 FCTNL CTRL DIAG

```
013700
5900
       016712
                          001634
                                                                  ERRLMT . RO
                                                        MOV
                                                                                     :GET ERROR LIMIT
5901
       016716
                                              645:
                                                        DEC
                                                                  RO
                                                                                      :DECREMENT COUNT
       016720
016722
016726
016730
016732
016734
5902
5903
                 001406
                                                        BEQ
                                                                 65$
                                                                                      : IF ZERO - EXIT
                          042260
                                                                  R4, GENCOM
                                                                                     : CONTINUE DATA COMPARE
                                                        JSR
5904
                 040000
                                                        40000
5905
5906
5907
5908
                 000402
                                                        BR
                                                                 65$
                                                                                      :NO MORE ERRORS - EXIT
                 104016
                                                        ERROR
                                                                  16
                                                                                     :REPORT NEXT ERROR
                 000770
                                                                  64$
                                                        RR
                                                                                      :LOOP
       016736
                                              65$:
5909
       016736
                                              15:
5910
5911
                                              : * TEST 47
                                                                 TWO SECTOR WRITE DATA (PART 3)
5912
5913
                                                        ISSUE A WRITE DATA OF 401 WORDS TO CYLINDER 312.
5914
                                                        TRACK O, SECTOR 10. READ DATA BACK ONE SECTOR AT
5915
                                                        A TIME AND CHECK ZERO FILL OF SECOND SECTOR.
5916
5917
5918
                                              TST47:
       016736
                 000004
                                                        SCOPE
5919
                 012737
       016740
                          000012 001262
                                                        MOV
                                                                 #10. STIMES
                                                                                     :: DO 10. ITERATIONS
       016746 016750
5920
                 104416
                                                                                     : CLEAR SUBSYSTEM
                                                        TSSINIT
5921
                 104003
                                                        ERROR
                                                                 3
                                                                                     :BAD INIT ERROR
5922
5923
       016752
                 004437
                          035674
                                                                                     :LOAD 'L" REGS
                                                        JSR
                                                                 R4, LRLOAD
5924
5925
       016756
                 000123
                                                        WRDATA
                                                                                     : WRDATA
       016760
                 177377
                                                        -401
                                                                                     :-401 WORDS
5926
5927
5928
5929
5930
       016762
                 072414
                                                        OBUFF
                                                                                     OBUFF IS BUFF ADDRESS
       016764
                    010
                                                        .BYTE
                                                                  10
                                                                                     :SECTOR 10
       016765
                    000
                                                        BYTE
                                                                 0
                                                                                     : TRACK 0
                 000312
       016766
                                                                                     :CYLINDER 312
5931
       016770
                 004437 042260
                                                        JSR
                                                                                     :GENERATE DATA
                                                                 R4. GENCOM
5932
       016774
                 000002
                                                                                     :PATTERN 2
5933
       016776
                                                        1000
                 001000
                                                                                     :1000 WORDS
5934
5935
       017000
                104417
                                                        TLOADRK
                                                                                     :LOAD RK REGS
       017002
5936
                104430
                                                        TWAT96
                                                                                     :WAIT FOR INTERRUPT
5937
       017004
                 104002
                                                        ERROR
                                                                                     :TO SLOW/NOT COMPLETE ERROR
5938
5939
       017006
                                                                                    CHECK OPERATION FOR ANY ERRORS

10 :REPORT ALL ERRORS

OBUFF FOR EXPECTED ZEROS FROM ZERO FILL

GET STARTING ADDRESS TO BE CLEARED
                 104421
                                                        TCHKOP
5940
                                                        ERROR 4 : OR 5, 6, 7, CLEAR LAST 377 WORDS OF
                104004
5941
5942
5943
       017012
                 012700
                                                                 #OBUFF+1002,R0
#377,R1
                          073416
                                                        MOV
                          000377
                                                                                     : NUMBER OF WORDS
                                                        MOV
5944
5945
       017022
                 005020
                                                                                     : CLEAR WORD
                                              15:
                                                        CLR
                                                                  (R0) +
       017024
                 005301
                                                        DEC
                                                                 R1
                                                                                     :DEC COUNT
5946
5947
       017026
                 001375
                                                        BNE
                                                                                     :LOOP UNTIL COUNT ZERO
       017030
                 004437
                          042260
                                                        JSR
2007
                                                                 R4. GENCOM
                                                                                     CLEAR IBUFF TO ONES
5948
       017034
                 002007
       017036
                 001000
5949
                                                        1000
5950
5951
5952
5953
       017040 017044
                 004437
                          035674
                                                                 R4. LRLOAD
                                                        JSR
                                                                                     ; LOAD 'L' REGS
                 000121
                                                        RDDATA
                                                                                     :RDDATA
       017046
                                                        -400
                                                                                     :-400 WORDS
5954
       017050
                070414
                                                        IBUFF
                                                                                     : IBUFF IS BUFF ADDRESS
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 112

TWO SECTOR WRITE DATA (PART 2)

146

CZR6KGO RK6 FCTNL CTRL DIAG

CZR6KG.P11 28-AUG-81 15:16

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL | DIAG 15:16 | MACY11 | 30(1046) | 1WO SEC | -81 15:17 PAGÉ TOR WRITE DATA (F | 113 PART 3) |
|---|--|--|------------------|--------|---|--------------------------------------|--|---|
| 5955 5956 5957 | 017052 017053 017054 | 010 000 000312 | | | | .8YTE .8YTE 312 | 10 | :SECTOR 10 :TRACK 0 :CYLINDER 312 |
| 5959 5960 5961 | 017056 017060 017062 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5956 5957 5958 5959 5961 5965 5965 5965 5965 5965 5977 5978 5978 5978 5981 5988 5988 5988 5988 5988 5988 598 | 017064 017066 017070 017074 017076 017100 017102 017103 017104 | 104421 104004 004437 000121 177400 071414 011 000 000312 | 035674 | | | RDDATA -400 IBUFF+10 | R4, LRLUAD | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF+1000 IS BUFF ADDRESS :SECTOR 11 :TRACK 0 :CYLINDER 312 |
| 5972 5973 5974 5975 | 017106 017110 017112 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 5977 5978 5979 5980 5981 | 017114 017120 017122 017124 017126 | 004437 100000 001000 000413 104015 | 042260 | | | JSR 100000 1000 BR ERROR | R4.GENCOM 2\$ 15 | ;DATA COMPARE ;1000 WORDS ;NO ERROR-SKIP ;REPORT FIRST ERROR |
| 5982 5983 5984 5985 5986 5987 | 017130 017134 017136 017140 017144 | 005300 | 001634 042260 | | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 5988 5989 5990 5991 5992 | 017146 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 5993 5994 5995 | 017154 | | | | 2\$: :****** | ****** | ************************************** | K ON WRITE (PART 1) |
| 5996 5997 5998 5999 6000 6001 | | | | | * | TRACK O | . SECTOR 25. REA | 000 WORDS TO CYLINDER 312, AD DATA BACK ONE SECTOR A MID-TRANSFER SEEK |
| 6002 6003 6004 6005 6006 6007 | 017154 017156 017164 017166 | 000004 012737 104416 104003 | 000012 | 001262 | TST50: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 6007 6008 6009 6010 | 017170 017174 017176 | 004437 000123 177000 | 035674 | | | JSR WRDATA -1000 | R4,LRLOAD | :LOAD 'L' REGS :WRDATA :-1000 WORDS |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 114
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
                                              T50
                                                        MID-TRANSFER SEEK ON WRITE (PART 1)
                                                                                    :OBUFF IS BUFF ADDRESS :SECTOR 25
        017200
017202
017203
  6011
                  072414
                                                        OBUFF
                                                                 25
 6012
                      025
                                                        .BYTE
                                                        BYTE
                                                                                     :TRACK 0
                  000312
 6014
        017204
                                                                                     :CYLINDER 312
  6015
        017206
                                                        JSR
3
 6016
                  004437 042260
                                                                 R4, GENCOM
                                                                                     GENERATE DATA
                  000003
                                                                                     : PATTERN 3
  6017
         017214
                                                        1000
  6018
                  001000
                                                                                     :1000 WORDS
  6019
 6020
6021
6022
6023
        017216
017220
                                                                                     :LOAD RK REGS
                  104417
                                                        TLOADRK
                  104430
                                                        TWAT96
                                                                                     :WAIT FOR INTERRUPT
         017222
                  104002
                                                        ERROR
                                                                                     :TO SLOW/NOT COMPLETE ERROR
                                                        TCHKOP ; CHECK OPERATION FOR ANY ERRORS
ERROR 4 ; OR 5, 6, 7, 10 ; REPORT ALL ERRORS
A TRACK ERROR PRINTED OUT AT THE END OF THE OPERATION INDICATES A
 6024
        017224 017226
                  104421
                 104004
  6026
  6027
                                                        MID-TRANSFER HEAD SWITCH DID NOT OCCUR.
 6028
6029
6030
        017230
017234
017236
                  004437
                                                        JSR
                                                                 R4, GENCOM
                            042260
                                                        2007
                  001000
                                                        1000
 6031
 6032
                                                                                     ; LOAD 'L' REGS
         017240
                           035674
                                                        JSR
                                                                  R4, LRLOAD
                  004437
                                                                                     :RDDATA
         017244
                  000121
                                                        RDDATA
  6034
         017246
                  177400
                                                        -400
                                                                                     :-400 WORDS
  6035
         017250
                  070414
                                                        IBUFF
                                                                                     : IBUFF IS BUFF ADDRESS
  6036
         017252
                                                                 25
                      025
                                                                                     :SECTOR 25
                                                        .BYTE
         017253
                      000
                                                         BYTE
                                                                                     : TRACK 0
                                                        312
 6038
        017254
                  000312
                                                                                     :CYLINDER 312
  6040
         017256
                  104417
                                                        TLOADRK
                                                                                     ; LOAD RK REGS
  6041
6042
6043
         017260
                  104425
                                                        TWAT48
                                                                                     :WAIT FOR INTERRUPT
         017262
                  104002
                                                        ERROR
                                                                                     :TO SLOW/NOT COMPLETE ERROR
                                                                 4 :OR 5, 6, 7, 10 :REPORT ALL ERRORS
         017264 017266
  6044
                  104421
                                                        TCHKOP
  6045
                  104004
                                                        ERROR
  6046
         017270
017274
017276
017300
                  004437
000121
177400
  6048
                                                                                     :LOAD 'L' REGS
                            035674
                                                        JSR
                                                                  R4.LRLOAD
                                                                                     :RDDATA
                                                        RDDATA
                                                                                     :-400 WORDS
  6049
                                                        -400
  6050
                  071414
                                                        IBUFF + 1000
                                                                                              : IBUFF+1000 IS BUFF ADDRESS
                                                                                     : SECTOR O
  6051
         017302
                      000
                                                        .BYTE
                                                                 0
                                                                                     : TRACK 1
  6052
         017303
                      001
                                                         BYTE
  6053
         017304
                  000312
                                                        312
                                                                                     :CYLINDER 312
  6054
  6055
         017306
                                                                                     :LOAD RK REGS
                  104417
                                                        TLOADRK
  6056
6057
         017310
                  104425
                                                        TWAT48
                                                                                     :WAIT FOR INTERRUPT
         017312
                  104002
                                                        ERROR
                                                                                     :TO SLOW/NOT COMPLETE ERROR
  6058
  6059
         017314
                  104421
                                                        TCHKOP
                                                                                     CHECK OPERATION FOR ANY ERRORS
                                                                 4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
         017316
  6060
                  104004
                                                        ERROR
  6061
         017320
017324
017326
017330
017332
  6062
                  004437
                            042260
                                                                  R4. GENCOM
                                                                                     : COMPARE DATA
                  100000
                                                        100000
                  001000
                                                                                     :1000 WORDS
  6064
                                                        1000
  6065
                  000413
                                                                  15
                                                                                     :NO ERRORS-SKIP
                                                        BR
                  104015
                                                        ERROR
  6066
                                                                                     :REPORT FIRST ERROR
```

| CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 150 | 28-AUG MID-TRA | -81 15:17 PAGE NSFER SEEK ON WR | 115 |
|--|--|--|------------------|--------|-----------------|--|------------------------------------|---|
| 6067 6068 6069 6070 6071 | 017340 017342 017344 | 013700 005300 001406 004437 | 001634 042260 | | 64\$: | MOV DEC BEQ JSR | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6070 6071 6072 6073 6074 6075 6076 | 017350 017352 017354 017356 017360 | 040000 000402 104016 000770 | | | 65\$: | 40000 BR ERROR BR | 65\$ 16 64\$ | ;NO MORE ERRORS - EXIT :REPORT NEXT ERROR ;LOOP |
| 6078 6079 | 017360 | | | | 1\$: | ****** | **** | ****** |
| 6080 6081 | | | | | ;* | 51 | | EK ON WRITE (PART 2) |
| 6082 6083 6084 6085 6086 | | | | | ;* ;* ;* | TRACK 2 | . SECTOR 25. RE | 000 WORDS TO CYLINDER 312, AD DATA BACK ONE SECTOR A MID-TRANSFER SEEK |
| 6087 6088 6089 6090 6091 | 017360 017362 017370 017372 | 000004 012737 104416 104003 | 000012 | 001262 | TST51: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ;;DO 10. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 6092 6093 6094 6095 6096 6097 6098 6099 | 017374 017400 017402 017404 017406 017407 017410 | 004437 000123 177000 072414 025 002 000312 | 035674 | | | JSR WRDATA -1000 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-1000 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 25 ;TRACK 2 ;CYLINDER 312 |
| 6100 6101 6102 6103 | 017412 017416 017420 | 004437 000004 001000 | 042260 | | | JSR 1000 | R4,GENCOM | GENERATE DATA PATTERN 4 1000 WORDS |
| 6104 6105 6106 6107 6108 6109 | 017422 017424 017426 | 104417 104430 104002 | | | į | A CYLIN | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR ED AT THE END OF THE OPERATION INDICATES A |
| 6109 6110 6111 | 017430 017432 | 104421 104004 | | | <i>(</i> | TCHKOP ERROR | | CHECK OPERATION FOR ANY ERRORS 10 REPORT ALL ERRORS |
| 6112 6113 6114 6115 6116 | 017434 017440 017442 | 004437 002007 001000 | 042260 | | | JSR 2007 1000 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 6117 6118 6119 6120 6121 6122 | 017444 017450 017452 017454 017456 017457 | 004437 000121 177400 070414 025 002 | 035674 | | | JSR RDDATA -400 IBUFF .BYTE .BYTE | R4,LRLOAD | ;LOAD 'L' REGS ;RDDATA ;-400 WORDS ;IBUFF IS BUFF ADDRESS ;SECTOR 25 ;TRACK 2 |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T51 | 28-AUG | -81 15:17 NSFER SEEK | PAGE ON WR | 116 ITE (PART 2) |
|--|--|--|------------------|--------|-----------------|--|--------------------------------------|---------------|---|
| 6123 | 017460 | 000312 | | | | 312 | | | ;CYLINDER 312 |
| 6125 6126 6127 | 017462 017464 017466 | 104425 | | | | TLOADRK TWAT48 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6129 | 017470 017472 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5. | 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6124 6125 6126 6127 6128 6129 6131 6132 6133 6134 6135 6136 6137 6138 6139 | 017474 017500 017502 017504 017506 017507 017510 | 004437 000121 177400 071414 000 000 000313 | 035674 | | | JSR RDDATA -400 IBUFF+10 .BYTE .BYTE 313 | R4.LRLOAD | | ;LOAD 'L' REGS ;RDDATA ;-400 WORDS ;IBUFF+1000 IS BUFF ADDRESS ;SECTOR 0 ;TRACK 0 ;CYLINDER 313 |
| 6149 6141 6142 6143 | 017512 | | | | | TLOADRK TWAT48 ERROR | | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6144 | 017520 017522 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5. | 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6146 6147 6148 | 017524 | 004437 | 042260 | | | JSR 100000 | R4,GENCOM | | COMPARE DATA |
| 6148 6149 6150 6151 6152 6153 | 017530 017532 017534 017536 | 001000 000413 104015 | | | | 1000 BR ERROR | 1 \$ 15 | | :1000 WORDS :NO MISCOMPARES-SKIP :REPORT 1ST ERROR |
| 6153 6154 6155 6156 6157 | 017540 017544 017546 017550 017554 | 013700 005300 001406 004437 040000 | 091634 042260 | | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RO RO 65\$ R4,GENCOM | | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6158 6159 6160 6161 | 017556 017560 017562 017564 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6162 6163 6164 | 017564 | | | | 1\$: | | | | ****** |
| 6165 | | | | | *TEST | 52 | TWO SECTOR | READ | DATA (PART 1) |
| 6167 6168 6169 | | | | | * | | | | OO WORDS TO CYLINDER 312, FY THAT CORRECT DATA IS |
| 6170 6171 6172 6173 | | | | | * | NOTE: | | | DATA (PART 1) MUST BE THIS TEST. |
| 6174 6175 6176 6177 6178 | 017564 017566 017574 017576 | 000004 012737 104416 104003 | 000012 | 001262 | 15152: | SCOPE MOV TSSINIT ERROR | #10.,\$TIME | S | ;;DO 10. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |

| | RK6 FCT P11 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 30(1046) T52 | 28-AUG TWO SEC | -81 15:17 PAGE TOR READ DATA (P | 117 ART 1) |
|--|--|--|------------------|--------------------------|--|--|---|
| 6179 | | | | | : GENERA | TE SAME DATA AS | USED IN TWO SECTOR WRITE DATA (PART 1) |
| 6181 6182 6183 6184 6185 6186 | 017600 017604 017606 | 004437 000015 001000 | 042260 | • | GENERAT JSR 15 1000 | E SAME DATA AS U R4,GENCOM | SED IN TWO SECTOR WRITE DATA PART 1 :GENERATE DATA :PATTERN 15 :1000 WORDS |
| 6187 6188 6189 | 017610 017614 017616 | 004437 002007 001000 | 042260 | | JSR 2007 1000 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 6187 6188 6189 6190 6191 6192 6193 6194 6195 6196 6197 6198 | 017620 017624 017626 017630 017632 017633 017634 | 004437 000121 177000 070414 000 000 000312 | 035674 | | JSR RDDATA -1000 IBUFF .BYTE .BYTE 312 | R4,LRLOAD 0 | :LOAD 'L' REGS :RDDATA :-1000 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 6199 6200 6201 6202 6203 6204 6205 | 017636 017640 017642 | 104417 104430 104002 | | | TLOADRK TWAT96 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6203 6204 | 017644 017646 | 104421 104004 | | | TCHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6206 6207 | 017650 017654 | 004437 | 042260 | | JSR 100000 | R4,GENCOM | COMPARE DATA |
| 6208 6209 6210 | 017656 017660 017662 | 001000 000413 104015 | | | 1000 BR ERROR | 1 \$ 15 | ;1000 WORDS ;NO MISCOMPARES-SKIP |
| 6211 6212 6213 6214 6215 6216 | 017664 017670 017672 017674 017700 017702 | 013700 005300 001406 004437 040000 000402 | 001634 042260 | 64\$: | MOV DEC BEQ JSR 40000 BR | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE NO MORE ERRORS - EXIT |
| 6218 6219 6220 | 017704 017706 017710 | 104016 | | 65\$: | ERROR BR | 16 64\$ | REPORT NEXT ERROR |
| 6222 6223 6224 | 017710 | | | 1\$: ::**** :*TEST | ****** | ************************************** | ************************************** |
| 6215 6216 6217 6218 6219 6220 6221 6222 6223 6224 6225 6226 6227 6228 6229 6231 6232 6233 6234 | | | | * * | ISSUE A TRACK O READ AN | READ DATA OF 10 SECTOR 23. VE D A MID-TRANSFER | 00 WORDS TO CYLINDER 312, RIFY THAT CORRECT DATA IS SEEK DOES NOT OCCUR. |
| 6230 6231 6232 | | | | * * * | NOTE: | TWO SECTOR WRITE EXECUTED BEFORE | E DATA (PART 2) MUST BE THIS TEST. |
| 6233 6234 | 017710 | 000004 | | 15153: | SCOPE | ***** | ******** |

| CZR6KG0 CZR6KG.F | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 153 | 28-AUG- TWO SEC | -81 15:17 PAGE TOR READ DATA (P | 118 ART 2) |
|--|--|--|------------------|--------|-----------------|-----------------------------------|--|--|
| 6235 6236 6237 | 017712 017720 017722 | 012737 104416 104003 | 000012 | 001262 | | MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 6239 | | | | | | ; GENERA | TE SAME DATA AS | USED IN TWO SECTOR WRITE (PART 2) |
| 6236 6237 6238 6239 6240 6241 6242 6243 6244 | 017724 017730 017732 | 004437 000016 001000 | 042260 | | | JSR 16 1000 | R4,GENCOM | GENERATE DATA PATTERN 16 1000 WORDS |
| 6245 | 017734 017740 | 004437 | 042260 | | | JSR 2007 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 6246 6247 6248 6249 6250 6251 6253 6254 6255 6256 6257 6258 6259 6260 6261 6262 6263 | 017742 017744 017750 017752 017754 017756 017757 017760 | 002007 001000 004437 000121 177000 070414 023 000 000312 | 035674 | | | 1000 JSR | R4,LRLOAD | :LOAD 'L' REGS :RDDATA :-1000 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 23 :TRACK 0 :CYLINDER 312 |
| 6256 6257 6258 6258 | 017762 017764 017766 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW, NOT COMPLETE ERROR |
| 6260 6261 | 017770 017772 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6263 6264 | 017774 020000 | 004437 | 042260 | | | JSR 100000 | R4, GENCOM | COMPARE DATA |
| 6265 6266 6267 | 020002 020004 020006 | 001000 000413 104015 | | | | 1000 BR ERROR | 1 \$ 15 | :1000 WORDS :NO MISCOMPARES-SKIP :REPORT 1ST ERROR |
| 6268 6269 6270 6271 6272 6273 | 020010 020014 020016 020020 020024 | 013700 005300 001406 004437 040000 | 001634 042260 | | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6274 6275 6276 6277 | 020024 020026 020030 020032 020034 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6278 6279 6280 | 020034 | | | | 1\$: | ***** | | ******* |
| 6281 | | | | | *TEST | 54 | TWO SECTOR READ | |
| 6282 6283 6284 6285 6286 | | | | | * * * | TRACK O. | READ DATA OF 40, SECTOR 10. VECED IN MEMORY. | 1 WORDS TO CYLINDER 312, RIFY THAT ALL 401 WORDS |
| 6288 6288 6289 | | | | | ** | NOTE: | TWO SECTOR WRITE EXECUTED BEFORE | E DATA (PART 3) MUST BE THIS TEST. |
| 6290 | | | | | | ****** | ********* | ******* |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 154 | 28-AUG | -81 15:17 PAGE TOR READ DATA (A | 119 ART 3) |
|--|--|--------------------------------------|---------------|--------|---|---|--|---|
| 6291 6292 6293 6294 | 020034 020036 020044 020046 | 000004 012737 104416 104003 | 000012 | 001262 | 15154: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 6295 | | | | | : | GENERATI | E SAME DATA AS U | SED IN TWO SECTOR WRITE (PART 3) |
| 6298 6299 6300 | 020050 020054 020056 | 004437 000002 000401 | 042260 | | | JSR 2 401 | R4, GENCOM | GENERATE DATA PATTERN 2 401 WORDS |
| 6302 6303 6304 | 020060 020064 020066 | 004437 002007 001000 | 042260 | | | JSR 2007 1000 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 6291 6293 6293 6293 6294 6295 6296 6301 6302 6303 6304 6308 6307 6308 6311 6311 6311 6311 6311 6311 6312 6312 | 020070 020074 020076 020100 020102 020103 020104 | 010 | 035674 | | | JSR RDDATA -401 IBUFF .BYTE .BYTE 312 | 10 : | :LOAD 'L' REGS :RDDATA :-401 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 10 :IRACK 0 :CYLINDER 312 |
| 6314 6315 6316 | 020106 020110 020112 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6318 | 020114 020116 | 104421 104004 | | | | TCHKOP ERROR | | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6321 | 020120 020124 | 004437 | 042260 | | | JSR 100000 | R4, GENCOM | COMPARE DATA |
| 6323 6324 6325 | 020126 020130 020132 | 000401 | | | | 401 BR | 1 \$ 15 | :401 WORDS :NO MISCOMPARES-SKIP :PRINT FIRST ERROR |
| 6327 6328 | 020134 | 013700 005300 001406 | 001634 | | 64\$: | MOV DEC BEQ | ERRLMI,RO RO 65\$ | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT |
| 6330 | 020144 | 004437 | 042260 | | | JSR 40000 | R4.GENCOM | CONTINUE DATA COMPARE |
| 6326 6327 6328 6329 6330 6331 6332 6333 6335 6336 6337 6338 6339 | 020142 020144 020150 020152 020154 020156 | 000402 104016 000770 | | | | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6335 6336 | 020160 020160 | | | | 65 \$: | | | * |
| 6337 | | | | | :***** :*TEST | 55 | MID-TRANSFER SE | ************************************** |
| 6340 6341 6342 | | | | | * | ISSUE A TRACK O READ AN | READ DATA OF 10 SECTOR 25. VE D A MID-TRANSFER | 00 WORDS TO CYLINDER 312, RIFY THAT CORRECT DATA IS SEEK DOES OCCUR. |
| 6343 6344 6345 6346 | | | | | * | NOTE: | MID-TRANSFER SE EXECUTED BEFORE | EK ON WRITE (PART 1) MUST BE THIS TEST. |

```
6347
                                               TST55: SCOPE
6348
       020160
6349
       020162
                 012737
                                                                   #10.,$TIMES
                           000012 001262
                                                         MOV
                                                                                       :: DO 10. ITERATIONS
6350
                                                         TSSINIT
                                                                                       :CLEAR SUBSYSTEM
                 104416
6351
6352
6353
       020172
                 104003
                                                         ERROR
                                                                                       :BAD INIT ERROR
                                                         GENERATE SAME DATA AS USED IN MID TRANSFER SEEK ON WRITE (PART 1)
6354
6355
6356
6357
       020174
020200
020202
                 004437
                           042260
                                                         JSR
                                                                   R4. GENCOM
                                                                                       : GENERATE DATA
                 000003
                                                                                       : PATTERN 3
                                                         1000
                 001000
                                                                                       :1000 WORDS
6358
6359
6360
       020204
020210
020212
                 004437
                           042260
                                                         JSR
                                                                   R4. GENCOM
                                                                                       :CLEAR IBUFF TO ALL ONES
                 002007
                                                         2007
                                                         1000
6361
       020214
020220
020222
020224
020226
020227
6362
6363
                                                                                       :LOAD 'L' REGS
                           035674
                 004437
                                                         JSR
                                                                   R4.LRLOAD
                 000121
                                                                                       :RDDATA
                                                         RDDATA
6364
6365
                 177000
                                                         -1000
                                                                                       :-1000 WORDS
                 070414
                                                         IBUFF
                                                                                       : IBUFF IS BUFF ADDRESS
6366
6367
                     025
                                                                   25
                                                                                       SECTOR 25
                                                         .BYTE
                     000
                                                         .BYTE
                                                                                       :TRACK 0
                                                         312
6368
       020230
                 000312
                                                                                       :CYLINDER 312
6369
6370
6371
6372
6373
       020232
020234
020236
                 104417
                                                         TLOADRK
                                                                                       :LOAD RK REGS
                 104430
                                                         TWAT96
                                                                                       :WAIT FOR INTERRUPT
                 104002
                                                         ERROR
                                                                                       :TO SLOW/NOT COMPLETE ERROR
6374
                                                                   CHECK OPERATION FOR ANY ERRORS
4 :OR 5, 6, 7, 10 :REPORT ALL ERRORS
       020240
                 104421
                                                         TCHKOP
       020242
                 104004
                                                         ERROR
6376
       020244 020250
6377
                 004437
                           042260
                                                                   R4. GENCOM
                                                                                       : COMPARE DATA
6378
6379
6380
6381
6382
6383
                 100000
                                                         100000
       020252
020254
020256
                                                         1000
                 001000
                                                                                       :1000 WORDS
                 000413
                                                                   1$
                                                                                       :NO MISCOMPARES-SKIP
                                                         BR
                                                         ERROR
                                                                                       :PRINT FIRST ERROR
       020260
020264
                 013700 001634
                                                         MOV
                                                                   ERRLMT, RO
                                                                                       GET ERROR LIMIT
                 005300
                                               648:
                                                         DEC
                                                                   RO
                                                                                       :DECREMENT COUNT
6385
       020266
                 001406
                                                         BEQ
                                                                   65$
                                                                                       : IF ZERO - EXIT
6386
       020270
                 004437
                                                                   R4, GENCOM
                           042260
                                                                                       CONTINUE DATA COMPARE
                                                         JSR
6387
       020274
                 040000
                                                         40000
6388
6389
6390
6391
6392
       020276 020300
                                                                   65$
                 000402
                                                         BR
                                                                                       :NO MORE ERRORS - EXIT
                                                         ERROR
                 104016
                                                                   16
                                                                                       :REPORT NEXT ERROR
       020302
                 000770
                                                                   64$
                                                                                       :LOOP
                                               65$:
       020304
                                               15:
6393
6394
                                               : * TEST 56
                                                                   MID-TRANSFER SEEK ON READ (PART 2)
6395
                                                         ISSUE A READ DATA OF 1000 WORDS TO CYLINDER 312, TRACK 2, SECTOR 25. VERIFY THAT CORRECT DATA IS
6396
6397
6398
                                                         READ AND A MID-TRANSFER SEEK DOES OCCUR.
6399
6400
                                                                   MID-TRANSFER SEEK ON WRITE (PART 2) MUST BE
6401
                                                                   EXECUTED BEFORE THIS TEST.
6402
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 120

155

MID-TRANSFER SEEK ON READ (PART 1)

CZR6KGO RK6 FCTNL CTRL DIAG

28-AUG-81 15:16

CZR6KG.P11

020340 020344

020426 020430

020430 000004

020320 004437 042260 : GENERATE SAME DATA AS USED IN MID TRANSFER SEEK ON WRITE (PART 2)

JSR R4.GENCOM : GENERATE DATA
PATTERN 4

1000 WORDS

JSR R4.GENCOM ; CLEAR IBUFF TO ALL ONES

JSR R4,LRLOAD ;LOAD 'L' REGS
RDDATA ;RDDATA
-1000 ;-1000 WORDS
IBUFF ;IBUFF IS BUFF ADDRESS
.BYTE 25 ;SECTOR 25

BYTE 25 SECTOR 25
BYTE 2 TRACK 2
CYLINDER 312
TLOADRK SLOAD RK REGS

TLOADRK ;LOAD RK REGS
TWAT96 ;WAIT FOR INTERRUPT
ERROR 2 ;TO SLOW/NOT COMPLETE ERROR

TCHKOP : CHECK OPERATION FOR ANY ERRORS ERROR 4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS

JSR R4.GENCOM ; COMPARE DATA
100000
1000 :1000 WORDS
BR 1\$:NO MISCOMPARES-SKIP
ERROR 15 :REPORT FIRST ERROR

MOV ERRLMT, RO :GET ERROR LIMIT
DEC RO :DECREMENT COUNT
BEQ 65\$:IF ZERO - EXIT
JSR R4, GENCOM :CONTINUE DATA COMPARE

40000
BR 65\$;NO MORE ERRORS - EXIT
ERROR 16 ;REPORT NEXT ERROR
BR 64\$;LOOP

15:

:*TEST 57 CYLINDER ADDRESS OVERFLOW (PART 1)

ISSUE A READ DATA OF 400 WORDS TO CYLINDER 632, TRACK 2, SECTOR 25. MAKE SURE CYLINDER ADDRESS OVERFLOW ERROR DOES NOT OCCUR.
CYLINDER 1456 IS USED FOR THE RK07.

TST57: SCOPE

64\$:

65\$:

| CZR6KGO CZR6KG. | RK6 FCT | NL (TRL 18-AUG-81 | 15:16 | MACY11 | 30(1046) 157 | 28-AUG | -81 15:17 PAGE R ADDRESS OVERFL | 122 |
|--|--|--|------------------|--------|-----------------|-----------------------------|------------------------------------|--|
| 6459 6460 6461 6462 | 020432 020440 020442 | 012737 104416 104003 | 000012 | 001262 | | MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 6463 6464 6465 6466 6467 6468 6469 6470 | 020444 020452 020456 020460 020462 020464 020465 | 000121 177400 070414 025 002 | 036120 035674 | | | RDDATA | LSTCYL,18 R4,LRLOAD | |
| 6472 6473 6474 | | 104417 104434 104002 | | | | TLOADRK TWAT159 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6475 6476 6477 6478 6479 | 020476 020500 | 104004 | | | | ERROR | 4 : OR 5. 6. ?. | ; CHECK OPERATION FOR ANY ERRORS 10 ; REPORT ALL ERRORS ********************************** |
| 6480 6481 6482 6483 6484 6485 | | | | | .* | | | S OVERFLOW (PART 2) 1 WORDS TO CYLINDER 632, KE SURE CYLINDER ADDRESS UR. OR THE RK07. |
| 6486 6487 6488 6489 6490 6491 6492 6493 | 02051/ | 000004 012737 104416 104003 013737 004437 000121 177377 | | | is160: | | #10.,\$TIMES 3 LSTCYL,1\$ | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR :LOAD 'L' REGS :401 WORDS |
| 6495 6496 6497 6498 6499 | 020534 020536 020537 020540 | 070414 025 002 000000 | | | 1\$: | IBUFF .BYTE .BYTE | 25 | :IBUFF IS BUFF ADDR :SEC 25 :TRK 2 :CYL 632/1456 |
| 6500 6501 6502 6503 | 020542 020544 020546 | 104417 104434 104002 | | | | TLOADRK TWAT159 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6504 6505 6506 6507 6508 6509 | 020550 020552 020554 020556 | 104422 001000 000000 000000 | | | | TCHKWE COERR 0 | | :CHECK OPERATION WITH EXPECTED ERROR :CYLINDER OVERFLOW |
| 6511 | 020560 | 104004 | | | .SBTTL | ERROR **18 BI | 4: OR 5,6,7 T DATA TRANSFER | REPORT ANY DISCREPANCIES TESTS |
| 6512 6513 6514 | | | | | : TEST | 61 | FORMAT IN 24 SE | CTOR FORMAT |

| 6515 6516 6517 6518 6519 6520 | | | | | | FORMAT CYLINDER 312, TRACK O, AND TRACK 1 FOR 24 SECTOR FORMAT. VERIFY FORMAT AND THAT DATA LATE DID NOT OCCUR WITH WRITE HEADER ON IN READING DATA BUFFER AFTER READ HEADER. | | | | | |
|--|--|--|--|--|------|---|--|--|--|--|--|
| 6521 6522 6523 6524 6525 6526 | 020562 020564 020572 020600 020606 020610 | 000004 012737 012737 012737 005001 | 000012 000312 020610 | 001262 001676 001110 | 1\$: | SCOPE MOV MOV MOV CLR | #312,REFMT | ::DO 10. ITERATIONS :SET REFORMAT SWITCH :SET LOCAL LOOP ON ERROR :CLEAR R1 FOR TRACK COUNTER | | | |
| 6526 6527 6528 6529 6531 6533 6533 6533 6537 6538 6539 | 020610 020612 020614 020622 020630 020636 020644 020650 020656 | 104416 104003 012737 053737 013737 012737 110137 012737 012737 | 010127 001720 001626 000074 001607 072414 000312 | 001600 001600 001610 001602 001604 001614 | | TSSINIT ERROR MOV BIS MOV MOV MOVB MOV MOV | #WRHEAD!CFMT,L. DTYPE,L.CS1 DRVNUM_L_CS2 | CLEAR SUBSYSTEM BAD INIT ERROR CS1 :SET UP FOR WRITE HEADER 24(8) SECTOR MODE SET DRV TYP SET DRIVE NUMBER SET WORD COUNT LOAD TRACK ADDRESS CYLINDER ADDRESS | | | |
| 6538 6539 | 020664 020670 | 004437 001200 | 042260 | | | JSR 1200 | | GENERATE HEADER : INCLUDE BAD SECTOR BITS | | | |
| 6540 6541 6542 6543 | 020672 020674 020676 | 104417 104434 104002 | | | | TLOADRK TWAT159 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR | | | |
| 6544 6545 6546 | 020700 020702 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS | | | |
| 6547 6548 6549 | 020704 | 104415 | | | | SCOP1 | | ; LOCAL LOOP ON ERROR TO 1\$ | | | |
| 6550 6551 6552 6553 6554 | 020706 020710 020712 020714 020716 020724 | 005701 001002 005201 000735 012737 005001 | 020726 | 001110 | 2\$: | IST BNE INC BR MOV CLR | R1 2\$ R1 1\$ #3\$,\$LPERR | ;R1 POINTING TO TRACK O ;NO-SKIP ;BUMP TO TRACK 1 ;LOOP ;SET LOCAL LOOP ON ERROR ;CLEAR TRACK POINTER | | | |
| 6556 6557 6558 6559 6560 6561 6562 6563 | 020724 020726 020726 020730 020732 020740 020746 020752 | 104416 104003 012737 013737 110137 012737 | 010125 001626 001607 000312 | 001600 001610 001614 | 3\$: | TSSINIT ERROR MOV MOV MOVB MOV | 3 #RDHEAD!CFMT,L. DRVNUM,L.CS2 R1,L.DT #312,L.DCYL | CLEAR SUBSYSTEM BAD INIT ERROR CS1 :LOAD READ 24(8) SECTOR FORMAT LOAD DRIVE NUMBER LOAD TRACK LOAD CYLINDER | | | |
| 6564 6565 6566 6567 6568 6569 6570 | 020760 020764 020766 020770 020772 | 004437 104421 104004 104013 104002 | 036362 | | | JSR TCHKOP ERROR ERROR ERROR | R4, RDSTHD 4: OR 5.6.7 13 2 | GO READ STANDARD HEADER RETURN IF CERR W/O DATA LATE SET REPORT ALL OTHER ERRORS REPORT DATA LATE REPORT 'OPERATION TO SLOW' OR 'HEADER O NOT FOUND' MESSAGE | | | |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL I 8-AUG-81 | 15:16 | MACY11 | 30(1046) 161 | 28-AUG | -81 15:17 PAGE IN 24 SECTOR FOR | 124 |
|--|--|--|--------|--------|-----------------|---------------------------------------|--|---|
| 6571 6572 6573 6574 6575 6576 | 020774 020776 021002 021004 021006 | 104415 004437 101200 000413 104015 | 042260 | | | SCOP1 JSR 101200 BR ERROR | R4.GENCOM | :LOCAL LOOP TO 3\$ ON ERROR :GENERATE & COMPARE HEADERS :INCLUDING BAD SECTOR LISTS :NO MISCOMPARES-SKIP :REPORT FIRST MISCOMPARE |
| 6577 | 021010 021014 021016 021020 021024 | 013700 005300 001406 004437 040000 | 001634 | | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RG RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6582 6583 6584 6585 | 021014 021016 021020 021024 021026 021030 021032 021034 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6578 6579 6580 6581 6582 6583 6584 6585 6586 6587 6588 6589 6590 6591 6592 | 021034 021036 021040 021042 021044 | 104415 005701 001002 005201 000730 | | | 4\$: | SCOP1 TST BNE INC BR | R1 5\$ R1 3\$ | :LOCAL LOOP TO 3\$:POINTING TO TRACK 1 :NO-EXIT :BUMP TO TRACK 1 :LOOP |
| 6593 | 021046 | | | | 5\$: | ****** | | ****** |
| 6594 6595 6596 | | | | | *TEST | | | T DATA TRANSFER (PART 1) |
| 6598 6599 6600 | | | | | * | ISSUE A TO CYLIF AND MAKE | WRITE DATA OF 4 NDER 312, TRACK E SURE IT IS COR | 00 WORDS IN 24 SECTOR FORMAT 0. SECTOR 0. READ SECTOR BACK RECT. |
| 6601 6602 6603 | 021046 021050 | 000004 012737 | 000012 | 001262 | TST62: | SCOPE MOV | #10 \$TIMES | ;;DO 10. ITERATIONS |
| 6604 6605 6606 6507 | 021056 021064 021066 | 012737 104416 104003 | 000312 | 001676 | | MOV TSSINIT ERROR | #312 REFMT | SET REFORMAT SWITCH CLEAR SUBSYSTEM BAD INIT ERROR |
| 6608 6609 6610 | 021070 021074 021076 | 004437 000013 000400 | 042260 | | | JSR 13 400 | R4,GENCOM | GENERATE DATA PATTERN 13 :400 WORDS |
| 6611 6612 6613 6614 | 021100 021104 021106 | 004437 002007 000400 | 042260 | | | JSR 2007 400 | R4,GENCOM | CLEAR IBUFF TO ALL ONES |
| 6615 6616 6617 6618 | 021110 021114 021116 | 004437 010123 177400 | 035674 | | | JSR WRDATA! | R4, LRLOAD | :LOAD 'L' REGS :WRDATA!CFMT :-400 WORDS |
| 6617 6618 6619 6620 6621 6622 | 021114 021116 021120 021122 021123 021124 | 072414 000 000 000 000312 | | | | OBUFF BYTE BYTE 312 | 0 | OBUFF IS BUFF ADDRESS SECTOR 0 TRACK 0 CYLINDER 312 |
| 6621 6622 6623 6624 6625 6626 | 021126 021130 021132 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACV11 30(1046) 28-AUG-81 15:17 PAGE 125
CZR6KG.P11 28-AUG-81 15:16 T62 24 SECTOR FORMAT DATA TRANSFER (PART 1)
```

| 6627 6628 6629 | 021134 021136 | 104421 | | | | TCHKOP | 4 :0R 5 6 7 | ; CHECK OPERATION FOR ANY ERRORS , 10 ; REPORT ALL ERRORS |
|--|--|--|----------------------------|------------------|---|--|--|---|
| 6630 6631 6632 6633 6634 6635 6636 6637 6638 | 021140 021144 021146 021150 021152 021153 021154 | 004437 010121 177400 070414 000 000 000312 | 035674 | | | JSR RDDATA: 0 -400 IBUFF .BYTE .BYTE 312 | R4.LRLOAD | :LOAD 'L' REGS :RDDATA!CFMT :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 6639 6640 6641 6642 | 021156 021160 021162 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6644 | 021164 021166 | 104421 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7 | ; CHECK OPERATION FOR ANY ERRORS , 10 ; REPORT ALL ERRORS |
| 6645 6646 6647 | 021170 021174 | 004437 | 042260 | | | JSR 100000 | R4, GENCOM | COMPARE DATA |
| 6648 6649 6650 6651 | 021176 021200 021202 | 000400 000413 104015 | | | | 400 BR ERROR | 1 \$ 15 | :400 WORDS :NO MISCOMPARES-SKIP :REPORT 1ST ERROR |
| 6652 6653 6654 6655 6656 | 021204 021210 021212 021214 021220 | 013700 005300 001406 004437 040000 | 001634 | | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6657 6658 6659 6660 | 021222 021224 021226 021230 | 000402 104016 000770 | | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6661 6662 6563 | 021230 | | | | 1\$: | | | |
| 6664 6665 6666 6667 | | | | | : TEST | 63 | 24 SECTOR FORM | AT DATA TRANSFER (PART 2) |
| 6668 6669 6670 6671 6672 | | | | | * | TO CYLIN AND MAKE SEEK HAS | NDER 312, TRACK E SURE IT IS CO S TAKEN PLACE. | 1000 WORDS IN 24 SECTOR FURMAT O. SECTOR 23. READ SECTOR BACK RRECT. MAKE SURE THAT MID-TRANSFER |
| 6673 6674 6675 6676 6677 6678 | 021230 021232 021240 021246 021252 021254 | 000004 012737 012737 004737 104416 104003 | 000012 000312 034522 | 001262 001676 | TST63: | SCOPE MOV MOV JSR TSSINIT ERROR | #10.,\$TIMES #312,REFMT PC,OPITST | ;;DO 10. ITERATIONS ;SET REFORMAT SWITCH ;SET UP OPTIONS ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 6680 6681 6682 | 021256 021262 | 004437 000015 | 042260 | | | JSR 15 | R4.GENCOM | GENERATE DATA |
| | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 30(1046) 163 | 28-AUG 24 SECT | OR FORMAT DATA | 126 TRANSFER (PART 2) |
|--|--|--|---------------|------------------------|--|-----------------------------|---|
| 6683 6684 | 021264 | 001000 | | | 1000 | | :1000 WORDS |
| 6685 | | | | | JSR 2007 1000 | R4.GENCCM | |
| 6687 6688 6689 6690 6691 6693 6694 6695 | 021276 021302 021304 021306 021310 021311 021312 | 004437 010123 177000 072414 023 000 000312 | 035674 | | JSR WRDATA! -1000 OBUFF .BYTE .BYTE .BYTE 312 | R4, LRLOAD CFMT | :LOAD 'L' REGS :WRDATA!CFMT :-1000 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 23 :TRACK 0 :CYLINDER 312 |
| 6697 | 021314 021316 021320 | 104417 104430 104002 | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS ;WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6701 6702 6703 | 021322 021324 | 104004 | | | TCHKOP ERROR + | 4 ;OR 5, 6, 7, | :CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6698 6699 6700 6701 6702 6703 6704 6705 6706 6707 6708 6709 6710 6711 | 021326 021332 021334 021336 021340 021341 021342 | 004437 010121 177000 070414 023 000 000312 | 035674 | | JSR RDDATA! -1000 IBUFF .BYTE .BYTE 312 | R4.LRLOAD CFMT | :-1000 UCRDS |
| 6712 6713 | 021344 021346 021350 | 104417 104426 104002 | | | TLOADRK TWAT64 ERROR | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 6716 | 021352 021354 | 104421 104004 | | | TCHKOP ERROR | 4 :OR 5, 6, 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 6719 | 021356 021362 | 004437 | 042260 | | JSR 100000 | R4,GENCOM | COMPARE DATA |
| 6721 6722 6723 6724 | 021364 021366 021370 | 001000 000413 104015 | | | 1000 BR ERROR | 1 \$ 15 | ;1000 WORDS ;NO MISCOMPARES-SKIP ;REPORT FIRST ERROR |
| 6726 6727 6728 | 021372 021376 021400 021402 021406 | 013700 005300 001406 004437 040000 | 001634 | 64\$: | MOV DEC BEQ JSR 40000 | ERRLMT,RO RO 65\$ R4,GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| 6730 6731 6732 6733 | 021410 021412 021414 021416 | 000402 104016 000770 | | 65\$: | BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |
| 6735 | 021416 | | | 1\$: | | | |
| 6737 6738 | | | | .SBTTL | **SPECIA | AL DATA TRANSFER | TESTS |
| 5. 50 | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 164 | 28-AUG | -81 15:17 PAGE ECTOR DATA TRANSF | 127 FER AND BSE |
|--|--|--|------------------|------------------|-----------------|---|---|--|
| 6739 6740 | | | | | TEST | ******* | | TA TRANSFER AND BSE |
| 6741 6742 6743 6744 6745 | | | | | | FORMAT SECTOR TO CYLIFERROR SI | CYLINDER 312, TRA 1 MARKED BAD. IS NDER 312, TRACK (ETS AND RADA IS (RE IT IS CORPECT | ACK O IN 26 SECTOR FORMAT WITH SSUE A WRITE DATA OF 1000 WORDS D. SECTOR O. MAKE SURE BAD SECTOR CORRECT. READ SECTOR O AND |
| 6747 6748 6749 6750 6751 6752 | | | 3. | 7. | * | ISSUE A SECTOR (PREVIOUS | READ DATA OF 100 0. MAKE SURE BAI S SECTOR IS LOADE | OO WORDS TO CYLINDER 312, TRACK O, SECTOR ERROR SETS AND THE ED CORRECTLY INTO MEMORY. |
| 6753 6754 6755 6756 | 021420 021426 021434 | 000004 012737 012737 104416 104003 | | | TST64 . | SCOPE MOV MOV TSSINIT ERROR | #10.,\$TIMES #312,REFMT | ;;DO 10. ITERATIONS ;SET REFORMAT SWITCH ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 6761 6762 6763 6764 6765 | 021444 021446 021450 021452 | 004437 000127 177676 072414 000 000 000312 | 035674 | | | JSR WRHEAD -102 OBUFF .BYTE .BYTE .BYTE | R4.LRLOAD | ;LOAD 'L' REGS ;WRHEAD ;-102 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 0 ;TRACK 0 ;CYLINDER 312 |
| 6766 6767 6768 | 021456 021462 | 004437 | | | | JSR 600 | R4, GENCOM | |
| 6769 6770 6771 | 021464 | 042737 042737 | 040000 040000 | 072424 072426 | | BIC | #BIT14,0BUFF+10 #BIT14,0BUFF+12 | ; MARK SECTOR 1 BAD ; CORRECT HURC |
| 6772 6773 6774 6775 | | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 6776 6777 6778 6779 | 021506 021510 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 6780 6781 6782 6783 | 021512 021516 021520 | 004437 000016 001000 | 042260 | | | JSR 16 1000 | R4,GENCOM | GENERATE DATA PATTERN 16 1000 WORDS |
| 6784 6785 6786 | 021522 021526 021530 | 004437 002007 001000 | 042260 | | | JSR 2007 1000 | R4.GENCOM | CLEAR IBUFF TO ALL ONES |
| 6784 6785 6786 6787 6788 6789 6790 6791 6792 6793 6794 | 021532 021536 021540 021542 021544 021545 021546 | 004437 000123 177000 072414 000 000 000 | 035674 | | | JSR WRDATA -1000 OBUFF .BYTE .BYTE 312 | R4.LRLOAD 0 | :LOAD 'L' REGS :WRDATA :-1000 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) 164 | 28-AUG-81 15:17 MULTI-SECTOR DATA | K 10 PAGE 128 TRANSFER AND BSE |
|---|--------|-----------------|--------------------------------------|--------------------------------------|
| 4705 | | | | |

| | . 705 | | | | | | | | |
|-----|--|--|--|--|--|---|--|---|--|
| | 6795 6796 6797 6798 | 021550 021552 021554 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 6799 6800 | 021556 | 104422 | | | | TCHKWE | | CHECK OPERATION WITH EXPECTED ERR |
| | 6802 | 021560 | 000000 | | | | BSERR | | ;BAD SECTOR ERROR |
| *.4 | 6800 6801 6802 6803 6804 6805 6806 6807 6808 6809 6810 6811 6813 6814 6815 | 021564 021566 021570 021574 021600 021616 021616 021616 021624 021632 021670 021642 | 000000 104004 005037 004437 032737 001416 012737 013737 013737 012737 104010 000527 | 050072 037642 000020 054260 050046 050060 050557 | 050072 001450 001202 001204 061072 | | ERROR CLR JSR BIT BEQ MOV MOV MOV MOV ERROR BR | 4; OR 5,6,7 GRP4ER R4,CHKCTS #TRKERR,GRP4ER 1\$ #EM13,EM10N EXPTRK,\$REG10 REALTRK,\$REG11 #OPER37,DF010A 10 | :NO-SKIP :"TRACK ADDRESS INCORRECT" :EXPECTED VALUE |
| | 6816 | 021644 021652 | 032737 | 000040 | 050072 | 1\$: | BIT | #SECERR, GRP4ER | :SECTOR IN ERROR? |
| | 6821 | 021654 021662 021670 021676 021704 | 001422 012737 012737 013737 013737 104010 | 054310 050557 050044 050062 | 001450 061072 001202 001204 | | MOV MOV MOV ERROR | #EM14,EM10N #OPER37,DF010A EXPSEC,\$REG10 REALSEC,\$REG11 | :NO-SKIP :'SECTOR ADDRESS INCORRECT' :'AFTER WRITE DATA ABORTED WITH BSE' :EXPECTED VALUE :REAL VALUE |
| | 6823 | 021706 021710 021712 021720 | 000505 104415 012737 | 0?1720 | 001110 | 3\$: | SCOP1 MOV | 5\$ #3\$,\$LPERR | :EXIT :LOCAL LOOP TO BEGINNING OF TEST :SET LOCAL LOOP ON ERROR |
| | 6830 6831 | 021720 021722 021724 021730 021732 021734 021736 021737 021740 | 104416 104003 004437 000121 177400 070414 000 000 000 | 035674 | | ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | TSSINIT ERROR JSR RDDATA -400 IBUFF .BYTE .BYTE .BYTE 312 | 3 R4,LRLOAD | CLEAR SUBSYSTEM BAD INIT ERROR LOAD 'L' REGS RDDATA -400 WORDS IBUFF IS BUFF ADDRESS SECTOR 0 TRACK 0 CYLINDER 312 |
| | 6833 6834 6835 6836 6837 6838 6840 | 021742 021744 021746 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 6841 6842 6843 | 021750 021752 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| | 6844 | 021754 021760 | 004437 | 042260 | | | JSR 100000 | R4, GENCOM | COMPARE DATA |
| | 6845 6846 6847 6848 6849 | 021762 021764 021766 | 000400 000413 104015 | | | | 400 BR ERROR | 4 \$ 15 | :400 WORDS :NO MISCOMPARES-EXIT :REPORT FIRST ERROR |
| | 6850 | 021770 | 013700 | 001634 | | | MOV | ERRLMT, RO | GET ERROR LIMIT |
| | | | | | | | | | |

| SEQ | 0128 |
|-----|------|

| ZR6KG. 6851 6852 | 021774 | 8-AUG-81 005300 001406 | | 64\$: | DEC BEQ | R0 | :DECREMENT COUNT :IF ZERO - EXIT |
|--|--|--|------------------|----------------------|---|--|--|
| 6852 6853 6854 6855 6857 6858 6860 6861 6862 6863 | 021776 022000 022004 022006 022010 022012 022014 | 004437 040000 000402 104016 000770 | 042260 | 65\$: | JSR 40000 BR . ERROR BR | 65\$ 16 64\$ | CONTINUE DATA COMPARE ON MORE ERRORS - EXIT REPORT NEXT ERROR LOOP |
| 6860 6861 6862 | 022014 022020 022022 | 004437 002007 001000 | 042260 | 4\$: | JSR 2007 1000 | R4,GENCOM | CLEAR IBUFF |
| 6864 6865 6866 6867 6868 6869 6870 6871 | 022024 022030 022032 022034 022036 022037 022040 | 004437 000121 177000 070414 000 000 000 000312 | 035674 | | JSR RDDATA -1000 IBUFF .BYTE .BYTE .BYTE 312 | R4,LRLOAD 0 | :LOAD 'L' REGS :RDDATA :-1000 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 6873 | 022042 022044 022046 | 104417 104424 104002 | | | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW, NOT COMPLETE ERROR |
| 6874 6875 6876 6877 6878 6879 6880 | 022050 022052 022054 022056 022060 | 104422 000000 000100 000000 104004 | | | TCHKWE 0 BSERR 0 ERROR | 4; OR 5,6,7 | CHECK OPERATION WITH EXPECTED ERROR BAD SECTOR ERROR REPORT ALL DISCREPANCIES |
| 6881 6882 6883 6884 6885 6886 | 022062 022066 022070 022072 022074 | 004437 100000 000400 000413 104015 | 042260 | | JSR 100000 400 BR ERROR | R4,GENCOM 5\$ 15 | COMPARE DATA AGAIN :400 WORDS :NO MISCOMPARES :REPORT FIRST ERROR |
| 6885 6886 6887 6888 6889 6890 6891 6892 6893 6894 6895 6896 6897 6898 6899 | 022076 022102 022104 022106 022112 022114 022116 022120 | 013700 005300 001406 004437 040000 000402 104016 000770 | 001634 042260 | 66\$: | MOV DEC BEQ JSR 40000 BR ERROR BR | ERRLMT, RO RO 67\$ R4, GENCOM 67\$ 16 66\$ | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE NO MORE ERRORS - EXIT REPORT NEXT ERROR LOOP |
| 6896 6897 6898 6899 6900 6901 6902 6903 6904 6905 | 022122 022122 | | | 67\$: 5\$: **TES.T | ******* 65 FORMAT MAKE SUI | ************** FORMAT TEST CYLINDER 312. | TRACKS O AND 1 IN 26 SECTOR FORMAT. ET. READ SECTORS 0-25 AND MAKE |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 165 | 28-AUG- | -81 15:17 PAGE | 130 |
|--|--|--|--|--|-----------------|---|---|---|
| 6907 6908 6909 6910 | 022122 022124 022132 022134 | 000004 012737 005000 012737 | 000001 022142 | 001262 001110 | TST65: | SCOPE MOV CLR MOV | #1,\$TIMES RO #1\$,\$LPERR | ;;DO 1 ITERATION ;CLEAR TRACK COUNTER ;SET LOCAL LOOP |
| 6912 6913 6914 | 022142 022142 022144 | 104416 104003 | | | 1\$: | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| 6907 6908 6909 6911 6913 6914 6915 6916 6917 6918 6919 6921 6921 6921 6921 6921 6921 6921 | 022146 022154 022162 022170 022174 022202 022210 | 013737 012737 053737 110037 012737 012737 012737 | 001626 000127 001720 001607 072414 177676 000312 | 001610 001600 001600 001604 001602 001614 | | MOV MOV BIS MOVB MOV MOV MOV | DRVNUM,L.CS2 #WRHEAD,L.CS1 DTYPE,L.CS1 RO,L.DT #OBUFF,L.BA #-102,L.WC #312,L.DCYL | :LOAD DRIVE NUMBER :LOAD WRITE HEADER :SET DRV TYP :LOAD DESIRED TRACK FROM TRACK COUNTER :LOAD BUS ADDRESS : WORD COUNT : CYLINDER |
| 6924 6925 | 0222216 022222 | 004437 001200 | 042260 | | | JSR 1200 | R4,GENCOM | :BUILD HEADER :WITH BSE FLAGGED |
| 6927 6928 6929 | 022224 022226 022230 | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6931 6932 | 022232 022234 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 6934 | 022236 | 104415 | | | | SCOP1 | | ;LOCAL LOOP TO 1\$ |
| 6940 6941 | 022240 022242 022244 022246 022250 022252 | 005700 001002 005200 000735 005000 012737 | 022260 | 001110 | 2\$: | TST BNE INC BR CLR MOV | R0 2\$ R0 1\$ R0 #113\$,\$LPERR | :RO AT ZERO? :NO-EXIT :BUMP COUNTER :LOOP :CLEAR SECTOR COUNTER :SET LOCAL LOOP ON ERROR |
| 6943 6944 6945 | 022260 022260 022262 | 104416 104003 | | | 113\$: 3\$: | TSSINIT ERROR | | CLEAR SUBSYSTEM BAD INIT ERROR |
| 6942 6943 6944 6945 6946 6947 6949 6951 6952 6953 6955 6956 6957 6958 | 022260 022262 022264 022264 022270 022272 022274 022276 022277 022300 | 004437 000121 177400 070414 000 000 000312 | 035674 | | J | JSR RDDATA -400 IBUFF .BYTE .BYTE 312 | R4,LRLOAD | :LOAD 'L' REGS :RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 6955 | | 110037 | 001606 | | | MOVB | RO.L.DS | :LOAD SECTOR COUNTER INTO DESIRED SECTOR |
| 6957 6958 6959 | 022306 022310 022312 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 6960 6961 6962 | 022314 022316 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |

| CZR6KO | O RK6 FCT | NL CTRL | DIAG 15:16 | MACY11 | 30(1046) T65 | 28-AUG FORMAT | -81 15:17 F TEST | AGE | 131 |
|---|--|---|---------------|--------|-----------------|---|--|-------------|--|
| 6963 6964 6965 | 022320 | 104415 | | | | SCOP1 | | | ;LOCAL LOOP TO 3\$ ON ERROR |
| 6768 6968 6969 | 022322 022326 022330 | 022700 001402 005200 000754 | 000024 | | | CMP BEQ INC BR | #24.R0 4\$ R0 3\$ | | :LAST SECTOR READ? :YES-EXIT :BUMP SECTOR COUNTER :LOOP |
| 6971 | 022334 | 005037 | 001676 | | 4\$: | CLR | REFMT | | CLEAR REFORMAT SWITCH |
| 6973 | | | | | .SBTTL | **WRITE | CHECK TESTS | | |
| 6976 | | | | | ::**** *TEST | ******* 66 | | | 1 NO ERROR |
| 6978 6979 6980 6981 | | | | | * | WRITE C DO A WR ERROR O | YLINDER 312, ITE-CHECK OF CCURS. | TRAC 400 | NO ERROR CK O, SECTOR O WITH A KNOWN PATTERN. WORDS. MAKE SURE NO |
| 6982 6983 6984 6985 | 022340 022342 022350 022352 | 000004 012737 104416 104003 | 000012 | 001262 | TST66: | MOV | #10.,\$TIMES | **** | ;;DO 10. ITERATIONS ;CLEAR SUBSYSTEM ;BAD INI; ERROR |
| 6973 6973 6973 6973 6973 6973 6973 6983 6983 6983 6983 6983 6983 6993 699 | 022354 022360 022362 022364 022366 022367 022370 | 000123 177400 072414 000 000 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE 312 | R4.LRLOAD | | :LOAD 'L' REGS :WRDATA :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 6996 6997 6998 | 022372 022376 022400 | 004437 000002 000400 | 042260 | | | JSR 2 400 | R4,GENCOM | | GENERATE DATA PATTERN 2 400 WORDS |
| 6999 7000 7001 7002 7003 | 022402 022404 022406 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7004 7005 | 022410 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. | 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7006 7007 7008 7009 7010 7011 7012 7013 7014 | 022414 022420 022422 022424 022426 022427 022430 | 004437 000131 177400 072414 000 000 000 000312 | 035674 | | | JSR WRTCHK -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | | :LOAD 'L' REGS :WRTCHK :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 7015 7016 7017 7018 | 022432 022434 022436 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

| 7019 7020 7021 7022 7023 | 022440 022442 | 104421 104004 | • | | : *TEST | TCHKOP ERROR ******* | | ; CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS OR (PART 1) |
|--|--|---|--------|--------|---|--|--|--|
| 7025 7025 7026 7027 7028 | | | | | ** | DATA EX | YLINDER 312, TRA HECK CYLINDER 31 CEPT WORD 110 HA RATIONS: | CK O, SECTOR O WITH ALL ZEROES. 2. TRACK O, SECTOR O WITH SAME S ONE OF THE FOLLOWING |
| 7029 7030 7031 7032 7033 | í | | | | * | 000001 000002 000004 000010 | 000020 000400 000040 001000 000100 002000 000200 004000 | 020000 |
| 7034 7035 7036 7037 7038 | | | | | * | OF THE | RE WRITE CHECK E CONFIGURATIONS A D COUNT IS CORRE | RROR SET FOR EACH ND THAT, THE BUS ADDRESS CT. |
| 7039 7040 7041 7042 | 022444 022446 022454 | 000004 012737 012700 | 000012 | 001262 | 15167: | SCOPE MOV MOV | #10.,\$TIMES #BITO,RO | ;;DO 10. ITERATIONS ;SET LO ORDER BIT IN RO FOR ;CAUSING WRITE CHECK ERROR |
| 7043 7044 7045 7046 7047 | 022460 022462 022464 022470 022472 | 104416 104003 004437 000001 000400 | 042260 | 1 | | ISSINIT ERROR JSR 1 400 | 3 R4, GENCOM | CLEAR SUBSYSTEM BAD INIT ERROR GENERATE DATA, ALL 0'S |
| 7048 7049 7050 7051 7052 7053 7054 7055 | 022474 022500 022502 022504 022506 022507 022510 | 004437 000123 177400 072414 000 000 000 000312 | 035674 | | | JSR · WRDATA -400 OBUFF .BYTE .BYTE 312 | R4.LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-400 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR 0 ;TRACK 0 ;CYLINDER 312 |
| 7056 7057 7058 7059 7060 | 022512 022514 022516 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7061 7062 | 022520 022522 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7, | :CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7063 7064 7065 7066 7067 7068 7069 7070 7071 | 022524 022530 022532 022534 022536 022537 022540 | 004437 000131 177400 072414 000 000 000 000312 | 035674 | | | JSR WRICHK -400 OBUFF .BYTE .BYTE .BYTE 312 | R4,LRLOAD 0 0 . | :LOAD 'L' REGS ;WRTCHK :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER 312 |
| 7072 7073 7074 | 022542 022544 022546 | 104417 104424 104002 | * | | í | TLOADRK TWAT32 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 167 | 28-AUG WRITE C | -81 15:1 HECK ERRO | C 11 17 PAGE DR (PART | 133 1). |
|--|--|--|--|--|-----------------|--|--|---------------------------------|--|
| 7075 7076 7077 7078 | 022550 022552 | 104421 104004 | | | | ERROR | 4 ; OR 5 | 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |
| 7079 7080 7081 7082 7083 7084 7085 7086 7087 7088 7089 7090 7091 | 022554 022556 022564 022570 022572 022574 022600 022602 022604 022606 022607 022610 | 010037 104416 104003 004437 000131 | 022564 072634 035674 | | 1\$: | SCOP1 MOV MOV ISSINIT ERROR JSR WRICHK -400 OBUFF .BYTE .BYTE .BYTE | #1\$,\$LPE R0.OBUFF 3 R4,LRLOA | RR +220 | :LOCAL LOOP ON WRITE CHECK :SET LOCAL LOOP :CAUSE ERROR BIT IN BUFFER :CLEAR SUBSYSTEM :BAD INIT ERROR :LOAD 'L' REGS :WRICHK :-400 WGRDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 7092 7093 7094 7095 | 022612 022614 022616 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7096 | 022620 | 104422 | | | | TCHKWE | | | CHECK OPERATION WITH EXPECTED ERROR |
| 7098 7099 | 022622 022624 022626 | 000004 | | | | WCKERR 0 | | | ;WRITE CHECK ERROR |
| 7100 | 022630 | 104004 | | | | ERROR | 4: OR 5. | .6.7 | REPORT ALL DISCREPANCIES |
| 7102 7103 | 022632 | 104415 | | | | SCOP1 | | | ;LOCAL LOOP ON ERROR TO 1\$ |
| 7104 7105 7106 7107 7108 7109 7110 7111 7112 | | | | | | WCE OCC NPR CYC OCCURRE NPR CYC THE ACT | AND BE COURRED. IF LE, WC AND. IF WCE LE OF A DUAL WORD | DRRECT. IT OCCUR OCCURR OUBLE C | AND BUS ADDRESS CAN BE EITHER OF THREE THE DIFFERENCE IS CAUSED BY WHEN THE URRED ON THE FIRST WORD OF A DOUBLE LL BE TWO PAST WHERE THE ERROR ACTUALLY ED ON A SINGLE NPR CYCLE OR THE LAST YCLE, WC AND BA CONTENTS ARE ONE PAST HE ERROR WAS. IN SOME CASES, WC AND BA THE ERROR WAS AND STILL BE ACCEPTABLE. |
| 7113 7114 7115 7116 7117 7118 7119 7120 7121 7122 7123 | 022634 022642 022644 022646 022654 022662 022670 022676 | 023727 001416 101040 012737 012737 013737 012737 104010 | 001544 054123 072636 001544 050613 | 001450 001202 001204 061072 | | CMP BEQ BHI MOV MOV MOV MOV ERROR | 2\$ 6\$ #EM11,EM #OBUFF+2 I.BA,\$RE | 110N 222, \$ REG | :CHECK BA HALT AT PROPER PLACE :YES-SKIP :IF TO HI - SKIP :"INCORRECT BA" 10 :GOOD VALUE :BAD VALUE :'WRITE CHECK ABORTED WITH WCE" |
| 7123 7124 7125 7126 7127 7128 7129 7130 | 022700 022706 022710 022712 022720 022726 022734 022742 | 023727 001461 101037 012737 012737 012737 012737 013737 104010 | 001542 054076 050613 177511 001542 | 177511 001450 061072 001202 001204 | 2\$: | CMP BEQ BHI MOV MOV MOV MOV ERROR | T.WC,#-2 3\$ 7\$ #EM10,EM #OPER41, #-267,\$R T.WC,\$RE | 110N DF 010A PEG 10 | CHECK WORD COUNT AT CORRECT VALUE YES-SKIP IF HIGHER SKIP ''INCORRECT WC'' 'WRITE CHECK ABORTED WITH WCE'' GOOD VALUE ERROR VALUE |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 767 | 28-AUG- WRITE CH | 81 15:17 PAGE HECK ERROR (PART | 134 1) |
|--|--|--|--|--|---------------------------|--|--|--|
| 7131 | 022744 | 000442 | | | | BR | 3\$ | :EXIT (|
| 7132 7133 7134 7135 7136 7137 7138 7139 7140 | 022746 022754 022756 022764 022772 023000 023006 | 023727 101415 012737 012737 013737 012737 104010 | 001544 054123 072642 001544 050613 | 072642 001450 001202 001204 061072 | 6\$: | CMP BLOS MOV MOV MOV MOV ERROR | 7\$ #EM11,EM10N #OBUFF+226,\$REG1 T.BA,\$REG11 | :TEST IF BA AT H! SIDE :YES - SKIP :SET MESSAGE 0 :GOOD VALUE :ERROR VALUE :'WRITE CHECK ABORTED WITH WCE" |
| 7142 7143 7144 7145 7146 7147 | 023010 023016 023020 023026 023034 023042 023050 | 023727 101415 012737 012737 012737 012737 013737 104010 | 001542 054076 050613 177513 001542 | 177513 001450 061072 001202 001204 | 7\$: | CMP BLOS MOV MOV MOV MOV ERROR | 3\$ #EM10,EM10N #OPER41,DF010A | :TEST IF WORD COUNT AT HI SIDE :YES - SKIP :SET MESSAGE :'WC ABORTED WITH WCE'' :GOOD VALUE :ERROR VALUE |
| 7148 7149 7150 | 023052 | 104415 | | | 3\$: | SCOP1 | | ;LOCAL LOOP ON ERROR TO 1\$ |
| 7151 7152 7153 7154 7155 | 023054 023060 023062 023064 | 032700 001002 006300 000637 | 100000 | | | BIT BNE ASL BR | 4\$ | :BIT 15 SET? :YES-EXIT :SHIFT ERROR BIT :LOOP |
| 7156 7157 7158 7159 7160 7161 7162 7163 | 023066 | | | | 4\$: :****** :*TEST | WRITE CY IN ALL W SECTOR (| WRITE CHECK ERRO | CK O, SECTOR O WITH 17777 CK CYLINDER 312, TRACK O, DATA EXCEPT WORD 120 HAS |
| 7164 7165 7166 7167 7168 7169 | | | | | * | | 177757 177377 177737 176777 177677 175777 177577 173777 | |
| 7170 7171 7172 7173 | | | | | * * * | OF THE | RE WRITE CHECK ER CONFIGURATIONS AN COUNT IS CORRECT | RROR SET FOR EACH ND THAT THE BUS ADDRESS |
| 7174 7175 7176 7177 7178 | 023066 023070 023076 | 000004 012737 012700 | 000012 177776 | 001262 | †\$170: | SCOPE MOV MOV | #10.,\$TIMES #177776,RO | ;;DO 10. ITERATIONS ;LOAD RO FOR CAUSING WRITE CHECK ERROR |
| 7179 7180 7181 7182 7183 7184 7185 7186 | 023102 023104 023106 023112 023114 | 104416 104003 004437 000007 000400 | 042260 | | | TSSINIT ERROR JSR 7 400 | R4.GENCOM | CLEAR SUBSYSTEM BAD INIT ERROR GENERATE DATA ALL 1'S 400 WORDS |
| 7185 7186 | 023116 023122 | 004437 000123 | 035674 | | | JSR WRDATA | R4, LRLOAD | :LOAD 'L' REGS :WRDATA |

| CZR6KGO CZR6KG.F | RK6 FCTI | NL CTRL I 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 170 | 28-AUG- WRITE C | -81 15:17 HECK ERROR | E 11 PAGE (PART | 135 |
|--|--|---|---------------|--------|-----------------|---|-------------------------|-----------------------|--|
| 7188 7189 7190 7191 | 023124 023126 023130 023131 023132 | 177400 072414 000 000 000 000312 | | | | -400 OBUFF .BYTE .BYTE 312 | 0 | | :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 7194 7195 | 023134 023136 023140 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7198 | 023142 023144 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. | 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7201 7202 7203 | 023146 023152 023154 023156 023160 023161 023162 | 000131 177400 072414 000 000 | 035674 | | | JSR WRTCHK -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD 0 0 | | :LOAD 'L' REGS :WRTCHK :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 7208 7209 7210 | 023164 023166 023170 | | | | | TLOADRK TWAT32 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW, NOT COMPLETE ERROR |
| 7213 | 023172 023174 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, | 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7216 | 023176 023200 | | 023206 | 001110 | | SCOP1 MOV | #1\$,\$LPERF | OCAL | LOOP TO START OF TEST ;SET LOCAL LOOP |
| 7219 | 023212 | | 072634 | | 1\$: | MOV TSSINIT ERROR | RO.OBUFF+2 | 220 | ; PUT WORD IN OBUFF TO CAUSE WCE ; CLEAR SUBSYSTEM ; BAD INIT ERROR |
| 7221 7222 7223 7224 7225 7226 7227 7228 | 023214 023216 023222 023224 023226 023230 023231 023232 023234 023236 023240 023240 023246 023246 023250 023252 | 004437 000131 177400 072414 000 000 000 000312 | 035674 | | | JSR WRTCHK -400 OBUFF .BYTE .BYTE 312 | R4,LRLOAD | | :LOAD 'L' REGS :WRTCHK :-400 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 7230 7231 7232 | 023234 023236 023240 | 104417 104424 104002 | | | | TLOADRK TWAT32 ERROR | | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7234 7235 | 023242 023244 | 104422 | | | | TCHKWE 0 | | | CHECK OPERATION WITH EXPECTED ERROR |
| 7236 7237 7238 | 023246 023250 023252 | 000004 000000 104004 | | | | WCKERR 0 ERROR | 4: OR 5.6. | .7 | :WRITE CHECK ERROR :REPORT ALL DISCREPANCIES |
| 7239 7240 7241 | 023254 | | | | | SCOP1 | | | :LOCAL LOOP TO 1\$ |
| 7241 | | | | | • | NOTE: | THE WORD | COUNT | AND BUS ADDRESS CAN BE EITHER OF THREE |

CZ

| CZR6KG CZR6KG | | | NL CTRL 8-AUG-81 | | MACY11 | 30(1046) 170 | 28-AUG-81 15:17 PAGE 136 WRITE CHECK ERROR (PART 2) |
|--|--------------------------------------|----------------------|--|--------------------------------------|--------------------------------------|-----------------|---|
| 7243 7244 7245 7246 7247 7248 7249 7250 7251 | | | | | | | VALUES AND BE CORRECT. THE DIFFERENCE IS CAUSED BY WHEN THE WCE OCCURRED. IF IT OCCURRED ON THE FIRST WORD OF A DOUBLE NPR CYCLE, WC AND BA WILL BE TWO PAST WHERE THE ERROR ACTUALLY OCCURRED. IF WCE OCCURRED ON A SINGLE NPR CYCLE OR THE LAST NPR CYCLE OF A DOUBLE CYCLE, WC AND BA CONTENTS ARE ONE PAST THE ACTUAL WORD WHERE THE ERROR WAS. IN SOME CASES, WC AND BA CAN BE THREE PAST WHERE THE ERROR WAS AND STILL BE ACCEPTABLE. |
| 7252 7253 7254 7255 7256 7257 | 0232 0232 0232 0232 0232 | 64 66 70 76 | 023727 001416 101040 012737 012737 013737 | 001544 054123 072636 001544 | 072636 001450 001202 001204 | | CMP I.BA,#OBUFF+222 : CHECK BA HALT AT PROPER PLACE SEQ S:YES-SKIP BHI 6\$:IF TO HI - SKIP MOV #EM11,EM10N : 'INCORRECT BA'' MOV #OBUFF+222,\$REG10 : GOOD VALUE MOV T.BA,\$REG11 :BAD VALUE |

| P11 2 | 8-AUG-81 | 15:16 | | 170 | WRITE C | HECK ERROR (PART | 2) |
|--|---|--|--|---|--|---|---|
| 023312 023320 | 012737 104010 | 050613 | 061072 | | MOV ERROR | #OPER41,DF010A | "WRITE CHECK ABORTED WITH WCE" |
| 023322 023330 023332 023334 023342 023350 023356 | 023727 001461 101037 012737 012737 012737 012737 | 054076 050613 | 001450 061072 | 2\$: | CMP BEQ BHI MOV MOV MOV MOV | T.WC,#-267 3\$ 7\$ #EM10,EM10N #OPER41,DF010A #-267,\$REG10 T.WC,\$REG11 | :CHECK WORD COUNT AT CORRECT VALUE :YES-SKIP :IF HIGHER - SKIP :'INCORRECT WC'' :'WRITE CHECK ABORTED WITH WCE'' :GOOD VALUE :ERROR VALUE |
| 023364 | 104010 | | | | ERROR BR | 10 3\$ | ;EXIT |
| 023370 023376 023400 023406 023414 023422 023430 | 023727 101415 012737 012737 013737 012737 104010 | 001544 054123 072642 001544 050613 | 072642 001450 001202 001204 061072 | 6\$: | CMP BLOS MOV MOV MOV MOV ERROR | 7\$ #EM11,EM10N #OBUFF+226,\$REG1 T.BA,\$REG11 | :TEST IF BA AT HI SIDE :YES - SKIP :SET MESSAGE 10 :GOOD VALUE :ERROR VALUE :'WRITE CHECK ABORTED WITH WCE' |
| 023432 023440 023442 023450 023456 023464 023472 | 023727 101415 012737 012737 012737 013737 104010 | 001542 054076 050613 177513 001542 | 177513 001450 061072 001202 001204 | 7\$: | CMP BLOS MOV MOV MOV MOV ERROR | T.WC.#-265 3\$ #EM10.EM10N #OPER41.DF010A #-265.\$REG10 T.WC.\$REG11 | :TEST IF WORD COUNT AT HI SIDE :YES - SKIP :SET MESSAGE :'WC ABORTED WITH WCE'' :GOOD VALUE :ERROR VALUE |
| 023474 | 104415 | | | 3\$: | SCOP1 | | |
| 023476 023502 023504 023506 | 032700 001002 006300 000637 | 100000 | | | BIT BNE ASL BR | #BIT15,R0 4\$ R0 1\$ | :BIT 15 SET? (ALL PATTERNS TESTED) :YES-EXIT :SHIFT FOR NEXT TEST :LOOP |
| 023510 | | | | 45: | ****** | ***** | |
| | | | | *TEST | 71 | WRITE CHECK OF F | PARTIAL SECTOR |
| | | | | * | CONFIGURE 110 WORL DIFFEREN | RATIONS. ISSUE A DS MAKING SURE TH NT THAN DATA ON D | HE 111TH WORD IS DISK. MAKE SURE |
| 023510 023512 023520 023522 | 000004 012737 104416 104003 | 000012 | 001262 | 15171: | SCOPE MOV TSSINIT ERROR | #10.,\$TIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 023524 023530 023532 | 004437 000007 000400 | 042260 | | | JSR 7 400 | R4,GENCOM | GENERATE DATA ALL 1'S 400 WORDS |
| | 023312 023320 023320 0233330 0233334 0233364 0233366 0233366 0233366 0233400 0234400 0234400 0234400 0234400 0234400 0234400 023450 023450 023450 023450 023510 023510 | 023312 012737 023320 104010 023322 023727 023330 001461 023332 101037 023334 012737 023342 012737 023356 013737 023366 000442 023370 023727 023376 101415 023400 012737 023414 013737 023422 012737 023430 104010 023432 023727 023440 101415 023442 012737 023440 101415 023442 012737 023450 012737 023450 012737 023450 012737 023474 104010 023474 104415 023474 104415 023476 032700 023502 001002 023504 006300 023506 000637 023510 | 023312 012737 050613 023320 001461 023332 001461 023332 101037 023334 012737 054076 023342 012737 050613 023350 012737 050613 023356 013737 001542 023370 023727 001544 023376 101415 023400 012737 072642 023414 013737 050613 023422 012737 050613 023432 023727 001544 023422 012737 050613 023432 023727 001542 023440 013737 050613 023432 023727 001542 023440 012737 050613 023450 012737 050613 023450 012737 050613 023450 012737 050613 023450 012737 050613 023450 012737 050613 023474 104415 023476 032700 100000 023502 001002 023504 006300 023506 000637 023510 023521 004033 023524 004437 042260 023530 000007 | 023312 012737 050613 061072 023320 104010 023322 023727 001542 177511 023330 001461 023332 101037 023342 012737 054076 001450 023350 012737 050613 061072 023350 012737 050613 061072 023356 013737 001542 001204 023366 000442 023370 023727 001542 001204 023376 101415 023400 012737 054123 001450 023406 012737 072642 001202 023414 013737 001542 001204 023422 012737 050613 061072 023430 104010 023432 023727 001542 177513 023440 101415 023442 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023472 104010 023474 104415 023474 104415 023476 032700 100000 023506 000037 023510 023510 000004 023510 000004 023510 000004 023510 000004 023510 000004 023510 000004 023510 000007 | 023312 012737 050613 061072 023320 104010 023322 023727 001542 177511 2\$: 023330 001461 023332 101037 023334 012737 050613 061072 023350 012737 050613 061072 023356 013737 001542 001204 023366 000442 023370 023727 001544 072642 6\$: 023370 012737 072642 001204 023366 012737 072642 001202 023376 101415 023406 012737 072642 001202 023414 013737 001544 001204 023430 000000 023430 104010 023440 101415 023440 101415 023440 101415 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023450 012737 050613 061072 023506 000007 023506 000003 023506 0000037 023510 000004 023506 0000037 023510 000004 023510 000004 023510 000004 023510 000004 023522 104003 023524 004437 042260 023530 000007 | 023312 012737 050613 061072 | 023312 |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 138
CZR6KG.P11 28-AUG-81 15:16
                                         171
                                                           WRITE CHECK OF PARTIAL SECTOR
  7314 023534
7315 023540
                   004437
                             035674
                                                                                        :LOAD "L" REGS
                                                                     R4.LRLOAD
                   000123
                                                           WRDATA
                                                                                         : WRDATA
  7316
        023542
                                                           -400
                                                                                         :-400 WORDS
         023544
                   072414
                                                                                         OBUFF IS BUFF ADDRESS
                                                           OBUFF
         023546
  7318
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7330
                       000
                                                           .BYTE
                                                                     0
                                                                                         :SECTOR O
         023547
                                                                     Ŏ
                       000
                                                           BYTE
                                                                                         : TRACK O
         023550
                   000312
                                                                                         :CYLINDER 312
         023552
023554
023556
                   104417
                                                           TLOADRK
                                                                                         :LOAD RK REGS
                   104430
                                                           TWAT96
                                                                                        :WAIT FOR INTERRUPT
                   104002
                                                           ERROR
                                                                                        : TO SLOW/NOT COMPLETE ERROR
         023560
                   104421
                                                           TCHKOP
                                                                                         : CHECK OPERATION FOR ANY ERRORS
         023562
                  104004
                                                                    4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
                                                           ERROR
         023564 005037 072636
                                                           CIR
                                                                     OBUFF + 222
  7331
         023570
                   004437
                             035674
                                                                                        :LOAD 'L" REGS
                                                           JSR
                                                                     R4. LRLOAD
  7332
         023574
                   000131
                                                           WRTCHK
                                                                                         : WRTCHK
                   177670
 7333
7334
7335
7336
7336
7338
7339
7341
7342
7343
7344
7346
7348
7349
7350
         023576
                                                           -110
                                                                                         :-110 WORDS
        023600
023602
023603
                                                                                         OBUFF IS BUFF ADDRESS
                   072414
                                                           OBUFF
                      000
                                                           .BYTE
                                                                                         : SECTOR O
                                                                  0
                       000
                                                            BYTE
                                                                                         :TRACK 0
                                                           312
         023604
                   000312
                                                                                         :CYLINDER 312
                                                          TLOADRK
TWAT32
                                                                                :LOAD RK REGS
         023606
                  104417
         023610
                  104424
                                                                                        :WAIT FOR INTERRUPT
         023612
                                                           ERROR 2
                   104002
                                                                                        :TO SLOW/NOT COMPLETE ERROR
         023614
                   104421
                                                          . TCHKOP
                                                          :CHECK OPERATION FOR ANY ERRORS
ERROR 4 :OR 5, 6, 7, 10 :REPORT ALL ERRORS
         023616 104004
                                                 .SBITL **MAXIMUM DATA TRANSFER AND CONTROLLER TIME OUT
                                                 :*TEST 72 MAXIMUM CATA TRANSFER (PART 1)
  7351
                                                           IN THE FIRST PASS OF THE PROGRAM. THE HEADERS OF
  7352
                                                           THE FIRST 4 CYLINDERS ARE WRITTEN. THIS IS DONE TO
  7353
                                                           INSURE THE FORMAT IS CORRECT.
  7354
  7355
                                                           ZERO OUT THE FIRST 256 SECTORS OF THE DISK WITH
  7356
7357
7358
                                                          ONE SECTOR WRITES. ISSUE A SEEK TO CYLINDER O, TRACK O. ISSUE A WRITE DATA OF MAXIMUM DATA TRANSFER 200000 WORDS TO CYLINDER O, TRACK O, SECTOR O. MAKE SURE CONTROLLER TIME OUT IS NOT SET. CHECK CYLINDER ADDRESS,
  7359
  7360
                                                          DISK ADDRESS, BUS ADDRESS AND WORD COUNT. READ
  7361
7362
7363
                                                          EACH SECTOR TO MAKE SURE IT WAS WRITTEN CORRECTLY.
                                                          NOTE:
                                                                    THIS TEST IS EXECUTED ONLY IF NO BAD SECTORS ARE PRESENT IN THE FIRST 256 SECTORS ON THE PACK.
 7364
7365
7366
7367
                                                 : *
         023620
                  000004
                                                TST72: SCOPE
  7368
                             000002 001262
                                                                    #2.$TIMES :: DO 2 ITERATIONS
#FPFMT, OPTFLG :TEST IF FIRST PASS SWITCH SET
                                                                    #2.STIMES
                                                          MOV
         023630
                   032737
                             000400 001664
                                                          BIT
```

| CZR6KGO CZR6KG.F | RK6 FCT1 | NL CTRL [8-AUG-81 | 1AG 15:16 | MACY11 | 30(1046) 172 | 28-AUG | -81 15:17 PAGE DATA TRANSFER (F | 139 PART 1) |
|--|--|---|----------------------------|--------|-------------------------|--|---|--|
| 7370 | 023636 | 001043 | | | | BNE | 24\$ | :YES - SKIP FORMAT |
| 7372 | 023644 | 105037 005037 | 023664 | | | CLRB CLR | 21 \$ 22 \$ | CLEAR ADDRESS POINTERS |
| 7370 7371 7372 7373 7374 7375 7376 7376 7376 7381 7381 7381 7382 7381 7388 7388 7388 7388 7388 7389 7391 7395 7396 7396 7397 7398 7398 7398 7398 7398 7398 7398 | 023650 023654 023656 023660 023662 023663 023664 | 004437 000127 177676 072414 000 000 000 | 035674 | | 20\$: 21\$: 22\$: | JSR WRHEAD -102 OBUFF .BYTE .BYTE | R4.LRLOAD | :LOAD 'L' REGISTERS :WRITE HEADER :102 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK ADDRESS (VARIABLE) :CYLINDER 0 (VARIABLE) |
| 7383 7384 7385 | 023666 023672 | 004437 001200 | 042260 | | | JSR 1200 | R4,GENCOM | GO GENERATE HEADERS ; WITH BAD SECTOR ERRORS |
| 7386 7387 7388 | 023676 | 104417 104431 104002 | | | | TLOADRK TWAT112 ERROR | 2 | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 7390 7391 | 023702 023704 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 7393 7394 7395 7396 | 023706 023714 023716 023722 | 001403 | 023663 023663 | 000002 | | CMPB BEQ INCB BR | 21\$,#2 23\$ 21\$ 20\$ | :TEST IF LAST TRACK :YES - SKIP :ELSE BUMP TRACK :LOOP |
| 7398 7399 7400 7401 7402 7403 | 023724 023730 023736 023740 023744 | 023727 | 023663 023664 023664 | 000003 | 23\$: | CLRB CMP BEQ INC BR | 21\$ 22\$,#3 24\$ 22\$ 20\$ | CLEAR TRACK POINTER TEST IF LAST CYLINDER WRITTEN YES - SKIP ELSE BUMP CYLINDER LOOP |
| 7404 7405 7406 | 023754 | 013737 012703 | 023760 000400 | 001110 | 24 \$: | MOV MOV | 1\$,\$LPERR #400,R3 | SET LOCAL LOOP ON ERROR SET COUNT FOR SECTOR CLEARING |
| 7407 7408 7409 7410 7411 7412 7413 7414 7415 7416 | 023760 023762 023764 023770 | 104416 104003 004437 000123 177400 072414 000 000 000 | 035674 | | | TSSINIT ERROR JSR WRDATA -400 OBUFF .BYTE .BYTE | 3 R4,LRLOAD | CLEAR SUBSYSTEM BAD INIT ERROR LOAD 'L' REGS WRDATA -400 WORDS OBUFF IS BUFF ADDRESS SECTOR 0 TRACK 0 CYLINDER 0 |
| 7/.17 | 024002 024004 024006 | 104417 104434 104002 | | | | TLOADRK TWAT159 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7418 7419 7420 7421 7422 7423 7424 | 024010 024012 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7. | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7424 | | 104415 005303 | | | | SCOP1 DEC | R3 | :LOCAL LOOP ON ERROR TO 15 :DECREMENT COUNT |
| | | | | | | | | |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 140
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
                                                       MAXIMUM DATA TRANSFER (PART 1)
        024020
                  012762
                                    000004
  7426
                           072414
                                                                #OBUFF, RKBA(R2) ; SET BA
                                              2$:
                                                                DRVNUM, RK(S2(R2) ; SET DRIVE NUM
DTYPE HOLD
                                                       MOV
  7428
7429
7430
7431
7432
7433
        024034
                  005037
                           001662
                                                       CLR
                 013762
012737
053737
        024040
                           001626
                                     000010
                                                       MOV
                                                                                         SET DRIVE NUMBER
                                    036124
036124
        024046
                                                       MOV
        024054
                           001720
                                                       BIS
                                                                 DIYPE, HOLD
        024062
                  013762
                           036124
                                    000000
                                                       MOV
                                                                 HOLD RKCS1(R2) : DO WRITE DATA
  7434 7435
        024070
                  104425
                                                       TWAT48
                                                                                   :WAIT FOR INTERRUPT
        024072
                  104002
                                                       ERROR
                                                                                   :TO SLOW/NOT COMPLETE ERROR
  7436
7437
        024074
                  032762
                           000200
                                    000014
                                                       BIT
                                                                 #BSE . RKER (R2)
                                                                                   :BAD SECTOR ERROR?
  7438
7439
        024102
                  001415
                                                       BEQ
                                                                 3$
                                                                                   :NO-SKIP
        024104
                  032737
                                                                #BSERPT, OPTFLG
                                                                                   :TEST IF BSE TO MANY HAS BEEN REPORTED
                           000200
                                                       BIT
                                    001664
        024112
  7440
                  001007
                                                                                   : YES - SKIP
                                                       BNE
                                                                 5$
                 052737
012737
                           000200
052547
                                                                #BSERPT, OPTFLG
  7441
        024114
                                    001664
                                                                                   :SET FLAG
                                                       BIS
  7442
        024122
024130
                                    001360
                                                                #0PR017, EM1N
                                                                                   :SET MESSAGE
:'FIRST 256 SECTOR NOT BSE FREE'
                                                       MOV
                  104001
                                                       ERROR
                                                       JMP
  7444
        024132
                  000137
                           024466
                                              5$:
                                                                                    GO TO EXIT
                                                                 14$
  7445
                                                       CHECK FOR ANY OTHER ERRORS
                                              35:
  7446
        024136
                                                                4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
  7447
        024136
                  104421
                                                       TCHKOP
  7448
        024140
                 104004
                                                       ERROR
  7449
        024142
                 104415
                                                       SCOP1
                                                                                   :LOCAL LGOP TO 15: (RESTART SECTOR CLEAR)
  7450
7451
7452
7453
        024144
                  005303
                                                       DEC
                                                                                   : DECREMENT COUNT
        024146
                 001324
                                                       BNE
                                                                 2$
                                                                                   :LOOP IF NOT ZERO
 7454
7455
7456
7457
        024150
                  004437
                           035674
                                                                                   :LOAD 'L" REGS
                                                       JSR
                                                                R4.LRLOAD
                                                                                   :SEEK
:0 WORDS
:0 IS BUFF ADDRESS
        024154
                  000117
                                                       SEEK
                                                      0
        024156
                  000000
        024160
024162
024163
                                                       Ö
                  000000
  7458
                                                                                   :SECTOR 0
                     000
                                                       .BYTE
  7459
                     000
                                                                                   : TRACK O
                                                       .BYTE
  7460
        024164
                  000000
                                                                                   : CYLINDER O
  7461
  7462
7463
        024166
024170
                  104417
                                                       TLOADRK
                                                                                   :LOAD RK REGS
                  104423
                                                       TWAT16
                                                                                   : WAIT FOR INTERRUPT :
                                                                                   : TO SLOW/NOT COMPLETE ERROR
  7464
        024172
                  104002
                                                       ERROR
  7465
        024174
                  005037
                           001662
                                                       CLR
                                                                INTSET
                                                                                   :CLEAR FIRST INTERRUPT
        024200
                  104421
  7466
                                                       TCHKOP
                                                                                   CHECK OPERATION FOR ANY ERRORS
  7467
        024202
                  104004
                                                       ERROR
                                                                4 :OR 5. 6. 7
                                                                                   :REPORT ALL ERRORS
:WAIT FOR SECOND INTERRUPT
        024204
024206
024210
024214
024216
  7468
                  104427
                                                       TWAT80
  7469
7470
                  104002
                                                       ERROR
                                                                                   ; TO SLOW/NOT COMPLETE ERROR
                           042260
                  004437
                                                                 R4, GENCOM
                                                       JSR
                                                                                   :GENERATE DATA
  7471
                  004006
                                                       4006
                                                                                   : PATTERN 6, 1ST WORD REPEATED
  7472
7473
                  000400
                                                       400
                                                                                   :400 WORDS
        024220
024220
024222
  7474
                                             45:
                  104416
                                                                                   : CLEAR SUBSYSTEM
                                                       TSSINIT
  7476
                  104003
                                                                                   BAD INIT ERROR
                                                       ERROR
        024224
024230
024232
024234
  7477
                  004437
                           035674
                                                                R4, LRLOAD
                                                       JSR
  7478
                  000123
                                                       WRDATA
                                                                                   : WRDATA
  7479
                  000000
                                                       0
                                                                                   : 0 WORDS
  7480
                  072414
                                                       OBUFF
                                                                                   : OBUFF IS BUFF ADDRESS
        024236
                     000
                                                                0
                                                       .BYTE
                                                                                   : SECTOR O
```

| 14 | CHOKG. | , 11 | 28-AUG-81 | 15:10 | | 1/2 | MAXIMUM | DATA TRANSFER T | PART 1) |
|----|--|--|--|--|------------------|---|--|--|---|
| | 7483 | 024237 | 000000 | | | | OBYTE | 0 | :TRACK 0 :CYLINDER 0 |
| | 7484 7485 7486 | 024242 | 052737 | 000020 | 001610 | | BIS | #BAI,L.CS2 | |
| , | 7487 7488 7489 7490 | 024250 024252 024254 | 104437 | | | | TLOADRK TWAT8S ERROR | 2 | :LOAD RK REGS :WAIT FOR SECOND INTERRUPT :ELSE REPORT TO SLOW/NOT COMPLETE ERROR |
| | 7491 7492 7493 | 024256 024256 024260 | 104421 | | | 7\$: | TCHKOP ERROR | 4 ;OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| | 7495 7496 7497 7498 7499 7500 | 024262 024264 024270 024274 024300 024306 | 012703 005037 005037 013737 | 000400 024332 024334 024314 000020 | 001110 001610 | | SCOP1 MOV CLR CLR MOV BIC | #400,R3 10\$ 12\$ 8\$,\$LPERR #BAI,L.CS2 | :INTERNAL LOOP ON ERROR TO 4\$:SET COUNTER FOR READ-COMPARE LOOP :CLEAR SECTOR AND TRACK VALUES :CLEAR CYL VALUE :SET LOCAL LOOP ON ERROR :CLEAR BAI |
| | 7503 7504 7505 7506 | 024314 024314 024316 024320 024324 024326 024330 024332 024333 024333 | 004437 000121 177400 070414 000 000 | 035674 | | 8\$: 9\$: 10\$: 11\$: 12\$: | TSSINIT ERROR JSR RDDATA -400 IBUFF .BYTE .BYTE | 3 R4.LRLOAD | CLEAR SUBSYSTEM BAD INIT ERROR LOAD RK REGS READ DATA 400 WORDS INTO IBUFF SECTOR (VARIABLE) TRACK (VARIABLE) CYL (VARIABLE) |
| | 7513 7514 7515 7516 | 024336 024340 024342 | 104425 | | | | TLOADRK TWAT48 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 7517 | 024344 024346 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| | 7520 | 024350 | 104415 | | | | SCOP1 | | :LOCAL LOOP ON ERROR TO 8\$ |
| | 7522 | 024352 024356 | 004437 | 042260 | | | JSR 100000 | R4,GENCOM | COMPARE DATA |
| | 7524 7525 7526 7527 | 024360 024362 024364 | 000400 000413 104015 | | | | 400 BR ERROR | 13 \$ 15 | :400 WORDS :NO MISCOMPARE-EXIT LOOP :REPORT FIRST ERROR |
| | 7528 7529 7530 7531 | 024366 024372 024374 024376 | 013700 005300 001406 004437 | 001634 042260 | | 64\$: | MOV DEC BEQ JSR | ERRLMT, RO RO 65\$ R4, GENCOM | GET ERROR LIMIT DECREMENT COUNT IF ZERO - EXIT CONTINUE DATA COMPARE |
| | 7521 7522 7523 7524 7525 7526 7527 7528 7529 7530 7531 7532 7533 7534 7535 7536 7537 | 024402 024404 024406 024410 024412 | 000402 104016 | | | 65\$: | 40000 BR ERROR BR | 65\$ 16 64\$ | :NO MORE ERRORS - EXIT :REPORT NEXT ERROR :LOOP |

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 172 | 28-AUG-81 15:17 PAGE 142 MAXIMUM DATA TRANSFER (PART 1) | | | |
|--|--|--|--|--------|-------------------------|---|---|--|--|
| 7538 7539 | 024412 | 104415 | | | 13\$: | SCOP1 | | ;LOCAL LOOP TO 8\$ | |
| 7540 7541 7542 | 024414 | | | | | DEC BEQ. | R3 14\$ | :DEC READ LOOP COUNT :IF ZERO-EXIT | |
| 7543 7544 7545 7546 7547 7548 7549 7550 7551 7552 7553 | 024420 024424 024432 024434 024440 024444 024452 024454 024460 024464 | 105237 123727 001332 105037 105237 123727 001322 105037 005237 000715 | 024332 024332 024333 024333 024333 024333 | 000026 | | INCB CMPB BNE CLRB INCB CMPB BNE CLRB INC BR | 10\$,#26 9\$ 10\$,#26 10\$ 11\$,#3 9\$ 11\$,#3 | BUMP SECTOR ; FINISHED WITH TRACK? :NO-LOOP ; CLEAR SECTOR ; BUMP TRACK ; FINISHED WITH CYLINDER? ; NO-LOOP ; CLEAR TRACK ; BUMP CYL. ; LOOP | |
| 7554 7555 7556 | 024466 | | | | 145: | ****** | ***** | ******* | |
| 7557 | | | | | ;* | | MAXIMUM DATA TR | | |
| 7558 7559 7560 7561 7562 7563 7564 7565 7566 7567 7568 7569 7570 7571 | | | | | * * * * * * * * * * * * | 200000 ISSUE A 200000 OUT IS DISK AD SEEK TO OF 2000 NOTE: | WORD WRITE. SEE WRITE OF MAXIMU WORD WRITE. MAK NOT SET. CHECK DRESS, BUS ADDRE CYLINDER 632. 00 WORDS. MAKE THIS TEST IS EX IN THE FIRST 25 CYLINDER 1456 I | ORS OF THE DISK WITH K TO CYLINDER 632. M DATA TRANSFER E SURE CONTROLLER TIME CYLINDER ADDRESS SS AND WORD COUNT. ISSUE A WRITE CHECK SURE NO ERROR SETS. ECUTED ONLY IF NO BAD SECTORS ARE PRESENT 6 SECTORS ON THE PACK. S USED FOR RK07. | |
| 7572 | 024466 024470 024476 | 000004 012737 | 000002 | 001262 | ts173: | SCOPE | #2,\$TIMES | ::DO 2 ITERATIONS | |
| 7575 7576 7577 | 024476 024500 024502 024506 | 104416 104003 012700 005037 | 000620 072414 | | | TSSINIT ERROR MOV CLR | 3 #400.,R0 OBUFF | CLEAR SUBSYSTEM BAD INIT ERROR SET COUNT FOR INTERRUPT WAIT | |
| 7573 7574 7575 7576 7577 7578 7579 7580 7581 7582 7583 7584 7585 7586 7587 7588 7589 7590 7591 7592 | 024512 024516 024520 024522 024524 024525 024526 024530 024536 | 004437 000123 000000 072414 000 000 000 000000 052737 | 035674 | 001610 | | JSR WRDATA O OBUFF .BYTE .BYTE O BIS | R4,LRLOAD 0 0 #BAI,L.CS2 | LOAD 'L' REGS :WRDATA :0 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 0 :SET BAI | |
| 7587 7588 7589 7590 7591 | 024536 024540 024542 024544 | 104417 104434 000401 000403 | | | 1\$: | TLOADRK TWAT159 BR BR | 2\$ 3\$ | :LOAD RK REGS :WAIT FOR INTERRUPT :NO INTERRUPT-SKIP :INTERRUPT-SKIP | |
| 7592 7593 | 024546 024550 | 005300 001373 | | | 2\$: | DE C BNE | R0 1\$ | :DEC WAIT COUNTER :NO ZERO-LOOP | |

SEQ 0142

| | | | | MII | |
|--------|----------|--------------|-------|----------|--|
| MACY11 | 30(1046) | 28-AUG-81 | 15:17 | PAGE 143 | |
| | | MAXIMUM DATA | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 1 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 173 | 28-AUG | -81 15:17 PAGE DATA TRANSFER (F | 143 PART 2) |
|--|--|---|--------------------------------------|------------------|-----------------|--|--|--|
| 7594 7595 | 024552 | 104002 | | | | ERROR | 2 | :TO SLOW/NOT COMPLETE ERROR |
| 7596 7597 7598 | 024554 024562 | 032762 001415 | 000200 | 000014 | 3\$: | BIT BEQ | #BSE,RKER(R2) | :DID BSE SET :NO-SKIP |
| 7599 7600 7601 7602 7603 7604 7605 | 024564 024572 024574 024602 024610 024612 | 001007 052737 012737 104001 | 000200 000200 052547 025160 | 001664 001360 | | BIT BNE BIS MOV ERROR JMP | 12\$ | :TEST IF TO MANY BAD SECTORS REPORTED :YES - SKIP :SET FLAG :SET MESSAGE :'FIRST 256 SECTORS NOT BSE FREE'' :EXIT |
| 7606 7607 7608 7609 7610 7611 | 024616 024616 024620 024622 024630 | 104004 | 036120 036120 | | 4\$: | TCHKOP ERROR MOV MOV | 4 ;OR 5, 6, 7, LSTCYL,13\$ LSTCYL,14\$ | ; CHECK OPERATION FOR ANY ERRORS // 10 ; REPORT ALL ERRORS |
| 7612 7613 | 024636 024642 | 004437 | 035674 | | | JSR SEEK | R4,LRLOAD | :LOAD 'L' REGS |
| 7614 | 024644 024646 024650 024651 024652 | 000000 | | | 13\$: | 0 | 0 | :0 WORDS :0 IS BUFF ADDR :SEC 0 :TRK 0 :CYL 632/1456 |
| 7620 7621 7622 7623 7624 7625 7626 7627 | 024654 024656 024660 024662 | 104423 | 001662 | | | TLOADRK TWAT16 ERROR CLR | 2 INTSET | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR ;CLEAR INTERRUPT FLAG |
| 7625 7626 | 024666 024670 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 7628 7629 7630 | 024672 024674 | 104427 104002 | | | | TWAT80 ERROR | 2 | ; WAIT FOR 2ND INTERRUPT |
| 7631 7632 7633 | 024676 024700 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 7635 7636 7637 7638 7639 7640 | 024702 024706 024710 024712 024714 024715 024716 | 004437 000105 000000 000000 000 000 000 | 035674 | | | JSR CLEAR 0 0 .BYTE .BYTE | R4,LRLOAD 0 | ;LOAD 'L' REGS ;CLEAR ;O WORDS ;O IS BUFF ADDRESS ;SECTOR O ;TRACK O ;CYLINDER O |
| 7641 7642 7643 7644 7645 | 024720 024722 024724 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7646 7647 | 024726 024730 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5. 6. 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 7648 7649 | 024732 | 004437 | 035674 | | | JSR | R4.LRLOAD . | ;LOAD 'L' REGS |

SEQ 0143

| CZR6KGO CZR6KG. | RK6 FCT P11 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 173 | 28-AUG- MAXIMUM | N 11 -81 15:17 PAGE DATA TRANSFER (| 144 PART 2) |
|--|--|--|----------------------------|--------|-----------------|---|---|--|
| 7650 7651 7652 7653 7654 7655 7656 | 024740 024742 024744 024745 | 000123 000000 072414 000 000 000 | | | | WRDATA 0 OBUFF .BYTE .BYTE 0 | 0 | :WRDATA :0 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 0 |
| 7657 7658 7659 7660 | 024750 024756 024762 | 012737 012700 052737 | 135143 000621 000020 | | | MOV BIS | #135143,0BUFF #401.,R0 #BAI,L.CS2 | SET WORD FOR OUTPUT SET COUNT FOR INTERRUPT WAIT SET BUS ADDRESS INC INHIBIT |
| 7661 7662 7663 7664 7665 | 024770 | 104417 104434 000401 000403 | | | 5\$: | TLOADRK TWAT159 BR BR | 6\$ 7\$ | :LOAD RK REGS :WAIT FOR INTERRUPT :NO INTERRUPT-BRANCH :INTERRUPT-BRANCH |
| 7666 7667 7668 7669 | 025000 025002 025004 | 005300 001373 104002 | | | 6\$: | DEC BNE ERROR | R0 5\$ 2 | :DEC WAIT COUNT :LOOP IF NOT ZERO :TO SLOW/NOT COMPLETE ERROR |
| 7670 7671 7672 7673 | 025006 025006 025010 | 104421 104004 | | | 7\$: | TCHKOP ERROR | 4 :OR 5, 6, 7, | CHECK OPERATION FOR ANY ERRORS 10 : REPORT ALL ERRORS |
| 7674 7675 7676 7677 7678 7679 7680 7681 7682 7683 7684 7685 | 025030 025032 | 004437 000117 000000 000000 000 000 000 000 104417 104423 104002 005037 | 035674 | | 14\$: | JSR SEEK O O .BYTE .BYTE O TLOADRK TWAT16 ERROR CLR | 0 | :LOAD 'L' REGS :0 WORDS :0 IS BUFF ADDR :SEC 0 :TRK 0 :CYL 632/1456 :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CLEAR INTERRUPT FLAG |
| 7686 7687 7688 | 025042 025044 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 7689 7690 7691 7692 7693 | 025046 025050 025052 025054 | 104427 104002 104421 104004 | | | | TWAT80 ERROR TCHKOP ERROR | 2 4 ; OR 5, 6, 7 | :WAIT FOR SECOND INIT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 7693 7694 7695 7696 7697 7698 7699 7700 7701 | 025056 025062 025064 025066 025070 025071 025072 | 004437 000105 000000 000000 000 000 000 | 035674 | | | JSR CLEAR 0 0 .BYTE .BYTE | R4,LRLOAD 0 0 | :LOAD 'L' REGS :CLEAR :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 7702 7703 7704 7705 | 025074 025076 025100 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

| CZR6KGO CZR6KG.I | RK6 FCTI | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 173 | 28-AUG MAXIMUM | -81 15:17 PAGE DATA TRANSFER | 145 PART 2) |
|--|--|---|----------------------------|------------------|---------------------------|--|---------------------------------------|--|
| 7707 | | 104421 | | | | TCHKOP | 4 ;OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS ;REPORT ALL ERRORS |
| 7708 7709 7710 7711 7712 7713 7714 7715 7716 7717 7718 | 025112 025114 025116 025120 025121 | 004437 000131 000000 072414 000 000 000 052737 012700 | 035674 000020 000621 | | | OBUFF BYTE O BIS | | ; WRTCHK :0 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 0 |
| 7719 | | 104417 104434 000401 000403 | | | 8\$: | TLOADRK TWAT159 BR BR | 9\$ 10\$ | :LOAD RK REGS :WAIT FOR INTERRUPT :NO INTERRUPT-SKIP :INTERRUPT-SKIP |
| 7725 | 025146 025150 •025152 | 005300 001373 104002 | | | 9\$: | DEC BNE ERROR | R0 8\$ 2 | :DEC WAIT COUNT . :NOT ZERO-LOOP :TO SLOW/NOT COMPLETE ERROR |
| 7727 7728 7729 7730 7731 | | 104421 104004 | | | 10\$: | TCHKOP ERROR | 4 ;OR 5, 6, 7, | CHECK OFERATION FOR ANY ERRORS 10 :REPORT ALL ERRORS |
| 7732 7733 7734 7735 7736 7737 7738 7739 7740 7741 | 025160 | | | * | 11\$: :***** :*TEST | SEEK TO WAIT FO OF CYLI OUT SET | R SECOND INTERRUI NDER O, TRACK O. | ISSUE A RECALIBRATE AND DO NOT PT. NOW ISSUE A READ HEADER MAKE SURE CONTROLLER TIME |
| 7742 7743 7744 7745 7746 7747 | 025160 025162 025170 025172 025174 | 000004 012737 104416 104003 013737 | 000005 | 001262 025216 | 15174: | SCOPE MOV TSSINIT ERROR MOV | #5.,\$TIMES 3 LSTCYL,1\$ | ::DO 5. ITERATIONS :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 7748 7749 7750 7751 7752 7753 7754 7755 7756 | 025202 025206 025210 025212 025214 025215 025216 | 004437 000117 000000 000000 000 000 000 | 035674 | | 1\$: | JSR SEEK 0 0 .BYTE 0 | R4,LRLOAD 0 | :LOAD 'L' REGS :0 WORDS :0 IS BUFF ADDR :SEC 0 :TRK 0 :CYL 632/1456 |
| 7758 7759 7760 | 025220 ,025222 025224 025226 | 104417 104423 104002 104421 | | | | TLOADRK TWAT16 ERROR TCHKOP | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION FOR ANY ERRORS |
| | | | | | | | | |

| CZR6KGO CZR6KG.I | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACÝ11 30(1046) 174 | 28-AUG | -81 15:17 LER TIME OU | C 12 PAGE | 146 |
|------------------------------|--|---|------------------|------------------------|---|--------------------------------|--------------|--|
| 7762 7763 | 025230 | 104004 | | | ERROR | 4 :OR 5. | 6. 7 | REPORT ALL ERRORS |
| 7764 7765 7766 | 025232 025236 025240 025242 025244 | 104427 | 001662 | | CLR TWAT80 ERROR TCHKOP ERROR | INTSET 2 4 : OR 5. | | CLEAR INTERRUPT FLAG WAIT FOR SECOND INTERRUPT TO SLOW/NOT COMPLETE ERROR CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 7770 7771 7772 7773 | 025246 025252 025254 025256 025260 025261 025262 | 000105 000000 000000 000 | 035674 | | JSR CLEAR 0 0 .BYTE .BYTE | R4,LRLOAD | | :LOAD 'L' REGS :CLEAR :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 7778 7779 7780 7781 | 025264 025266 025270 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7782 7783 7784 | 025272 025274 | 104421 104004 | | | TCHKOP ERROR | 4 :OR 5. | 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 7785 | 025276 025302 025304 025306 025310 025311 025312 | 004437 000113 000000 000000 000 000 000 | 035674 | | JSR RECAL 0 0 .BYTE .BYTE | R4,LRLOAD 0 0 | | :LOAD 'L' REGS :RECAL :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 7793 7794 | 025314 025316 025320 | 104423 | | | TLOADRK TWAT16 ERROR | 2 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7797 | 025322 025326 025330 025332 025334 025335 025336 | 004437 000125 000000 000000 000 000 000 | 035674 | | JSR RDHEAD 0 0 .BYTE .BYTE | R4.LRLOAD | | :LOAD 'L' REGS :RDHEAD :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 7805 | 025340 025342 025344 | 104417 104436 104002 | | | TLOADRK TWAT2S ERROR | | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 7809 | 025346 025350 025352 025354 025356 025360 025362 025364 025370 | | 001662 000100 | 000000 | TCHKWE 0 0 CTOERR ERROR TSSINIT ERROR CLR MOV | 4: OR 5.6. 3 INTSET #IE.RKCS1 | 7 | CONTROLLER TIME OUT REPORT ANY DISCREPANCIES CLEAR SUBSYSTEM BAD INIT ERROR CLEAR INT FLAG SET INT ENABLE |

```
CZR6KG.P11 28-AUG-81 15:16
                                              174
                                                          CONTROLLER TIME OUT
                                                                                    :WAIT FOR SECOND INT
  7818 025376 104437
7819 025400 104002
                                                          TWAT85
                                                          FRROR 2
  7820
  7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
                                                .SBITL **ERRORS DURING DATA TRANSFER
                                                 ** TEST 75 LIMIT DETECT ON DATA TRANSFER
                                                          ISSUE A SUBSYSTEM CLEAR. ISSUE A RECALIBRATE. ISSUE A SEEK TO CYLINDER 2 WITH BAD PARITY. ISSUE A DRIVE
                                                          CLEAR. ISSUE A WRITE DATA OF 400 WORDS TO CYLINDER 1. TRACK O, HEAD O. SEEK INCOMPLETE BECAUSE OF OUTER
  7832
  7833
                                                          LIMIT SHOULD BE THE CNLY ERROR SET.
  7834
7835
7836
7837
         025402
                   000004
                                                 TST75: SCOPE
                            000003 001262
                                                                    #3., STIMES
                                                          MOV
                                                                                       :: DO 3. ITERATIONS
  7838
7839
         025412
                                                                                        : CLEAR SUBSYSTEM
                   104416
                                                          TSSINIT
                                                                  3
                   104003
                                                          ERROR
                                                                                       :BAD INIT ERROR
  7840
  7841
7842
7843
7844
7845
                                                                                        :LOAD 'L' REGS
         025416
                            035674
                                                          JSR
                   004437
                                                                    R4. LRLOAD
         025422
025424
025426
025430
025431
                                                                                       :RECAL
                   000113
                                                          RECAL
                                                                                       :0 WORDS
                   000000
                                                          0
                                                                                       :0 IS BUFF ADDRESS
                   000000
                                                          0
                                                          .BYTE
                       000
  7846
                                                          BYTE
                                                                                        : TRACK 0
                       000
  7847
         025432
                   000000
                                                                                        :CYLINDER 0
  7848
         025434 025436
  7849
                   104417
                                                          TLOADRK
                                                                                        :LOAD RK REGS
                   104423
                                                                                        : WAIT FOR INTERRUPT
  7850
                                                          TWAT16
         025440
  7851
                   104002
                                                          ERROR
                                                                                        : TO SLOW/NOT COMPLETE ERROR
  7852
7853
         025442
                   005037 001662
                                                          CLR
                                                                    INTSET
                                                                                        :CLEAR INTERRUPT FLAG
  7854
         025446
                   104437
                                                          TWAT85
                                                                                        :WAIT FOR SECOND INTERRUPT
  7855
         025450
                   104002
                                                          ERROR
  7856
7857
         025452 025454
                                                                                        CHECK OPERATION FOR ANY ERRORS
                   104421
                                                          TCHKOP
  7858
                   104004
                                                          ERROR
                                                                    4 :OR 5, 6, 7 :REPORT ALL ERRORS
  7859
         025456
                                                                                        :LOAD 'L" REGS
  7860
                   004437
                            035674
                                                                    R4.LRLOAD
                                                                                       SEEK
O WORDS
O IS BUFF ADDRESS
SECTOR O
         025462 025464
  7861
                   000117
                                                          SEEK
  7862
7863
                   000000
         025466
025470
025471
                                                          0
                   000000
  7864
                       000
                                                                    0
                                                          .BYTE
  7865
                       000
                                                           .BYTE
                                                                                        : TRACK 0
                   000002
         025472
  7866
                                                                                        :CYLINDER 2
         025474 025502
                                                                                        SET EVEN PARITY BIT
  7867
                             000020 001616
                                                          MOV
                                                                    #PAT.L.MR1
                                                                                        : LOAD RK REGS
  7868
                   104417
                                                          TLOADRK
                                                                                        : WAIT FOR INTERRUPT
         025504
                   104423
  7869
                                                          TWAT16
  7870
         025506
                   104002
                                                          ERROR
                                                                                        :TO SLOW/NOT COMPLETE ERROR
  7871
         025510 025512
                   104416
                                                          TSSINIT
                                                                                        : CLEAR SUBSYSTEM
                                                          ERPOR 3
                   104003
                                                                                       :BAD INIT ERROR
```

CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 147

| CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046 CZR6KG.P11 28-AUG-81 15:16 175 | E 12 5) 28-AUG-81 15:17 PAGE 148 LIMIT DETECT ON DATA TRANSFER |
|---|--|
|---|--|

| | 7874 | | | | | | | | |
|---|--|--|--|--------|--------|------|--|-----------------|--|
| | 7875 7876 7877 7878 7879 7880 7881 7882 7883 7884 7885 7886 | 025514 025520 025522 025524 025526 025527 025530 | 004437 000123 177400 072414 000 000 000001 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE | R4,LRLOAD | ;LOAD 'L' REGS ;WRDATA ;-400 WORDS ;OBUFF IS BUFF ADDRESS ;SECTOR O ;TRACK O ;CYLINDER 1 |
| | 7883 7884 7885 7886 | 025532 025534 025536 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 7887 7888 7889 7890 | 025540 025542 025544 025546 025550 | 104422 000002 000000 000000 104004 | | | | TCHKWE SKIERR O | 4 00 5 4 007 | CHECK OPERATION WITH ERROR |
| | 7891 7892 7893 | | 104004 | | | | ERROR | 4 :OR 5,6,OR7 | REPORT ALL DISCREPANCIES |
| | 7894 7895 | 025552 025554 | 104416 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| | 7896 7897 7898 7899 7900 7901 7902 7903 7904 7905 | 025556 025562 025564 025564 025566 025570 025571 025572 | 004437 000101 000000 000000 000 000 000 | 035674 | | 3\$: | JSR SELDRY 0 0 .BYTE .BYTE | R4,LRLOAD | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| | 7906 7907 7908 7909 7910 | 025574 025602 025604 025606 | 012737 104417 104423 104002 | 000001 | 001616 | | MOV TLOADRK TWAT16 ERROR | #1.L.MR1 | :SET TO GET STATUS PAIR 1 :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 7911 7912 7913 | 025610 025612 | 104421 104004 | | | | TCHKOP ERROR | 4 .: OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| | 7914 7915 7916 | 025614 025622 | 032737 001755 | 000040 | 001574 | | BIT BEQ | #S.HDHM, T.MR2 | :TEST IF HEADS HOME :NO - GET STATUS AGAIN |
| | 7917 7918 7919 | 025624 025626 | 104416 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| | 7920 | 025630 | 012762 | 000100 | 000000 | | MOV | #IE,RKCS1(R2) | :SET IE |
| | 7923 7924 | 025636 025642 025644 025646 | 005037 104437 000401 000404 | 001662 | | | CLR TWATES BR BR | INTSET | CLEAR INT FLAG WAIT FOR SECOND INTERRUPT |
| : | 7927 | 025650 | 012737 | 060404 | 001372 | 15: | MOV | #DH016.DH2N | "SUBSYSTEM CLEAR TO RESET LIMIT ERROR |
| | 7928 7929 | 025656 | 104002 | | | | ERROR | 2 | ALLOWING HEADS TO RELOAD" |
| | | | | | | | | | |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 149 CZR6KG.P11 28-AUG-81 15:16 T75 LIMIT DETECT ON DATA TRANSFER
```

| 025660 | | | | 2\$: | | | | | | | | |
|--|--|--|---|---|---|--|--|---|---|--|--|--|
| | | | | *TEST | * A READ DATA OF 400 WORDS ON CYLINDER O. TRACK O. SECTOR O. DURING READ ISSUE A | | | | | | | |
| 025660 025662 025670 025672 | 000004 012737 104416 104003 | 000012 | 001262 | 15176: | SCOPE MOV TSSINIT ERROR | #10., \$ TI | | :CLEAR SUBSYSTEM | | | | |
| 025674 025700 025702 025704 025706 025707 025710 | 004437 000121 177400 070414 000 000 000 | 035674 | | | JSR RDDATA -400 IBUFF .BYTE .BYTE | R4.LRLOA | | RDDATA :-400 WORDS :IBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 | | | | |
| 025712 | 104417 | | | | TLOADRK | | LOAD RK | REGS | | | | |
| 025714 | 012762 | 000001 | 000022 | | MOV | #1,RKSPA | R(R2) | ; WRITE SPARE REGISTER . | | | | |
| 025722 025724 | 104423 104002 | | | | TWAT16 ERROR | 2 | | | | | | |
| 025726 025730 025732 025734 025736 | 104422 000000 000000 000020 104004 | | | | TCHKWE 0 0 PGERR ERROR | 4 ;OR 5 | | :PHOG ERROR | 1 | | | |
| | | | | TEST | ISSUE A A WRITE CYLINDER ALL ZERO DURING N SURE PRO ISSUE A | DATA WORL R O, TRACI DS TO CYL WRITE ISSI DGRAMMING READ DATA | DS CONSI: K O, SEC INDER O, UE CONTRI ERROR I: A TO CYL | STING OF 177777 TO TOR O. NOW WRITE TRACK O. SECTOR O. OLLER CLEAR. MAKE S RESET. NOW INDER O. TRACK O. | | | | |
| 025740 025742 025750 025752 | 000004 012737 104416 104003 | 000012 | 001262 | 15177: | SCOPE MOV TSSINIT ERROR | #10.,\$TI | | CLEAR SUBSYSTEM | | | | |
| 025754 025760 | 004437 000001 | 042260 | | | JSR 1 | R4, GENCO | М | GENERATE DATA OF ALL ONES | | | | |
| | 025660 025662 025670 025672 025674 025706 025706 025707 025710 025712 025714 025722 025730 025730 025730 025730 025730 025730 025730 025730 025730 025730 025730 025730 | 025660 000004 025662 012737 025670 104416 025672 104003 025674 004437 025700 000121 025704 070414 025706 000 025707 000 025710 000000 025712 104417 025714 012762 025722 104423 025724 104002 025726 104423 025730 000000 025734 000000 025734 000000 025734 000000 025736 104404 | 025660 000004 025662 012737 000012 025672 104416 025672 104003 025674 004437 035674 025700 000121 025704 070414 025706 000 025707 000 025710 000000 025712 104417 025714 012762 000001 025722 104423 025724 104002 025730 000000 025732 000000 025732 000000 025732 000000 025734 000020 025736 104004 | 025660 000004 025662 012737 000012 001262 025672 104003 025674 004437 035674 025700 000121 025704 070414 025706 000 025707 000 025710 000000 025712 104417 025714 012762 000001 000022 025722 104423 025724 104002 025730 000000 025732 000000 025732 000000 025734 000000 025736 104004 | 025660 000004 025662 012737 000012 001262 025670 104416 025672 104003 025674 004437 035674 025700 000121 025704 070414 025706 000 025710 000000 025712 104417 025714 012762 000001 000022 025722 104423 025724 104002 025726 104422 025730 000000 025732 000000 025734 000000 025734 000000 025734 000000 025734 000000 025734 000000 025736 104404 025736 104404 025736 104404 025736 104404 | TEST 76 | TEST 76 | TEST 76 | | | | |

| CZR6KGC CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 177 | 28-AUG ECC HAR | -81 15:1 D | 7 PAGE | 150 | |
|--|--|--|---------------|--------|-----------------|--|----------------------------------|---------|---|--|
| 7986 7987 | 025762 | 000400 | | | | 400 | | | | |
| 7988 7989 7990 7991 7992 7993 7994 7995 | 025764 025770 025772 025774 025776 025777 026000 | 004437 000123 177400 072414 000 000 00000 | 035674 | | | JSR WRDATA -400 OBUFF .BYTE .BYTE | R4.LRLOA | D | :LOAD 'L' :WRDATA :-400 WORD :OBUFF IS :SECTOR O :TRACK O :CYLINDER | BUFF ADDRESS |
| 7996 7997 7998 7999 | 026002 026004 026006 | 104417 104430 104002 | | | | TLOADRK TWAT96 ERROR | 2 | | :LOAD RK R :WAIT FOR :TO SLOW/N | REGS INTERRUPT IOT COMPLETE ERROR |
| 8000 8001 | 026010 026012 | 104421 | | | | TCHKOP ERROR | 4 :OR 5 | . 6. 7. | CHECK OPE | RATION FOR ANY ERRORS ALL ERRORS |
| 8002 8003 8004 8005 | 026014 026020 026022 | 004437 000002 000400 | 042260 | | | JSR 2 400 | R4,GENCO | M | :GENERATE | DATA OF ZEROS |
| 8004 8005 8006 8007 8008 8009 8010 8011 -8012 8013 8014 | 026030 026032 026034 026036 026037 | 004437 000123 177630 072414 000 000 000000 | 035674 | | | JSR WRDATA -150 OBUFF .BYTE .BYTE | R4,LRLOA | D | :LOAD 'L' :WRDATA :-150 WORD :OBUFF IS :SECTOR O :TRACK O :CYLINDER | S BUFF ADDRESS |
| 8015 8016 | 026042 | 104417 | | | | TLOADRK | | | START OFE | RATION |
| 8017 8018 8019 | 026050 | 005737 001026 005762 001372 | 001662 | | 1\$: | TST BNE TST BNE | INTSET 2\$ RKWC(R2) 1\$ | | CHECK IF YES - MUC TEST IF N | INTERRUPT HAS OCCURRED H TO SOON. REPORT ERRUR PR'S DONE |
| 8022 | 026060 | 052762 | 100000 | 000000 | | 818 | #CCLR,RK | CS1(R2) | CLEAR CON | TROLLER (CROWBAR WRITE) |
| 8020 8021 8022 8023 8024 8025 8026 8027 8028 8029 8030 8031 8033 8034 8035 8036 8037 8038 8039 | 026066 026072 026074 026076 026100 026101 026102 | 004437 000121 177400 070414 000 000 000 | 035674 | | | JSR RDDATA -409 IBUFF .BYTE .BYTE | R4,LRLOA | | :LOAD 'L' :RDDATA :-400 WORD :IBUFF IS :SECTOR 0 :TRACK 0 :CYLINDER | S BUFF ADDRESS |
| 8032 8033 8034 8035 | 026104 026106 026110 | 104417 104425 104002 | | | | TLOADRK TWAT48 ERROR | | | :LOAD RK R :WAIT FOR :TO SLOW/N | EGS INTERRUPT OT COMPLETE ERROR |
| 8036 8037 8038 8039 8040 | 026112 026114 026116 026120 026122 | 104422 000000 000003 000000 104004 | | | | 0 | CHERR | | ;DATA CHEC | RATION WITH ERROR K AND ECC HARD |
| 8041 | | | | | | LANDA | 4 .UK 5, | 0,7 | ALPUNI AL | L DISCREPANCIES |

```
CZR6KGO RK6 FCTNL CTRL DIAG
                                     MACY11 30(1046) 28-AUG-81 15:17 PAGE .151
CZR6KG.P11
                                                       ECC HARD
               28-AUG-81 15:16
 8042
8043
8044
8045
       026124
026126
026126
026130
026132
                  000402
                                                                                    : SKIP TO EXIT
                                              28:
                                                                4 : OR 5, 6, 7, 10 : REPORT ALL ERRORS
                  104421
                                                        TCHKOP
                  104004
                                                       ERROR
 8046
8047
8048
8049
8050
8051
8052
8053
                                              35:
                                                                 DRIVE TIMING ERROR
                                                        ISSUE A SUBSYSTEM CLEAR. SEEK TO CYLINDER 632.
ISSUE A RECALIBRATE BUT DO NOT WAIT FOR SECOND INTERRUPT.
                                                        PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A READ HEADER
  8054
                                                       OF CYLINDER O. TRACK O. CLOCK THROUGH SEEK
  8055
                                                        AND DRIVE CLEAR MESSAGES. TURN OFF DIAGNOSTIC MODE.
  8056
8057
                                                       DRIVE TIMING ERROR SHOULD SET BECAUSE OF NO DATA
                                                        TRANSISTIONS ON DATA LINE.
  8058
                  000004
                                              TST100: SCOPE
  8059
         026132
        026134
                           000005 001262
  8060
                                                       MOV
                                                                 #5. . STIMES
                                                                                   :: DO 5. ITERATIONS
  8061
 8062
8063
         026142
                  104416
                                                       TSSINIT
                                                                                    : CLEAR SUBSYSTEM
         026144
                  104003
                                                                3
                                                       FRROR
                                                                                    :BAD INIT ERROR
  8064
                  004437
  8065
         026146
                           035674
                                                        JSR
                                                                 R4. LRLOAD
                                                                                    :LOAD 'L' REGS
        026152
026154
026156
026160
  8066
                                                        SEEK
                                                                                    : SEEK
                  000000
                                                       00
  8067
                                                                                    : 0 WORDS
  8068
                  000000
                                                                                    :0 IS BUFF ADDRESS
                     000
  8069
                                                        .BYTE
                                                                 00
                                                                                    : SECTOR O
  8070
         026161
                                                        .BYTE
                                                                                    : TRACK O
 8071
8072
8073
         026162
                  000632
                                                       632
                                                                                    :CYLINDER 632
        026164
                  104417
                                                       TLOADRK
                                                                                   : LOAD RK REGS
         026166
                  104423
  8074
                                                       TWAT16
                                                                                   : WAIT FOR INTERRUPT
  8075
         026170
                  104002
                                                       ERROR
                                                                                    : TO SLOW/NOT COMPLETE ERROR
         026172
                  005037
  8076
                           001662
                                                       CLR
                                                                 INTSET
                                                                                    :CLEAR INT FLAG
  8077
         026176
                                                       TWAT96
                  104430
                                                                                    :WAIT FOR SECOND INTERRUPT
  8078
         026200
                  104002
                                                       ERROR
                                                                                   : TO SLOW/NOT COMPLETE ERROR
  8079
  8080
        026202
                  004437
                           035674
                                                       JSR
                                                                                    :LOAD 'L' REGS
                                                                 R4. LRLOAD
        026206
  8081
                  000113
                                                       RECAL
                                                                                    : RECAL
                                                       0
  8082
        026210
                  000000
                                                                                   :0 WORDS
:0 IS BUFF ADDRESS
  8083
        026212
                  000000
        026214
  8084
                     000
                                                        .BYTE
                                                                 00
                                                                                    : SECTOR O
  8085
                     000
                                                       BYTE
                                                                                    : TRACK O
  8086
         026216
                  000000
                                                                                    : CYLINDER O
  8087
        026220
026222
026224
  8088
                  104417
                                                       TLOADRK
                                                                                   :LOAD RK REGS
                  104423
  8089
                                                       TWAT16
                                                                                   :WAIT FOR INTERRUPT
  8090
                                                       ERROR
                                                                                   : TO SLOW/NOT COMPLETE ERROR
  8091
        026226
026232
  8092
                  004437
                                                                 R4. LRLOAD
                           035674
                                                        JSR
                                                                                   :LOAD "L" REGS
  8093
                  000125
                                                       RDHEAD
                                                                                    : RDHEAD
        026234
  8094
                  000000
                                                                                   :0 WORDS
:0 IS BUFF ADDRESS
  8095
        026236
                  000000
        026240
  8096
                                                                00
                     000
                                                       .BYTE
                                                                                    SECTOR O
                     000
                                                       .BYTE
                                                                                    :TRACK O
```

| CZR6KGO CZR6KG. | RK6 FC1 | NL CTRL | DIAG 15:16 | MACY11 | 30(1046) 1100 | 28-AUG | -81 15:17 PAGE IMING ERROR | 152 |
|--|--|--|------------------|--------|---|---|--|---|
| 8098 8099 8100 | 026242 026244 026252 | 000000 012737 104417 | 000040 | 001616 | | 0 MOV TLOADRK | #DMD,L.MR1 | :CYLINDER O :SET DIAG MODE ;LOAD RK REGS |
| 8102 8103 | 026254 026260 | 004437 001062 | 036316 | | | JSR 1062 | R4,MCLOCK | CLOCK CONTROLLER THROUGH SEEK |
| 8105 | 026262 | 005062 | 000026 | | | CLR | RKMR1(R2) | RESET DIAG MODE, LET RD HDRS COMPLETE |
| 8108 8109 8110 8111 8112 | 026266 026270 026272 026274 026276 026300 026302 | 104424 104002 104422 010000 000000 000000 104004 | | | | TWAT32 ERROR TCHKWE DTERR 0 | | ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR ;CHECK OPERATION WITH EXP ERROR ;DRIVE TIMING ERROR |
| 8114 | 026302 | 104004 | | | 10. | ERRUR | 4 ; UK 5,0,7 | REPORT ALL DISCREPANCIES |
| 8116 8117 8118 8119 | 026304 026306 026310 026316 | 104416 104003 012762 005037 | 000100 001662 | 000000 | | TSSINIT ERROR MOV CLR | 3 #IE,RKCS1(R2) INTSET | CLEAR SUBSYSTEM BAD INIT ERROR SET INTERRUPT ENABLE CLEAR INT FLAG |
| 8121 8122 8123 | 026322 026324 | 104437 104002 | | | | TWAT8S ERROR | 2 | ; WAIT FOR INTERRUPT FOR END OF RECAL |
| 8124 8125 8126 8127 8128 8129 8130 8131 | 026304 026306 026310 026316 026316 026324 026324 026332 026334 026336 026340 026341 026342 | 004437 000105 000000 000000 000 000 000 | 035674 | | | CLEAR 0 0 .BYTE | | :LOAD 'L' REGS :CLEAR :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 8132 8133 | 026344 026346 026350 026352 026354 | 104417 104423 104002 104421 104004 | | | | FREDE | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 8138 8139 | | | | | .SBTTL | **ERROR | FORCING IN DRIVE | |
| 8140 | | | | | : TEST | 101 | INITIALIZE CLEAR | ING SACK |
| 8142 8143 8144 8145 8146 8147 8148 8149 8150 | | | | | * | ISSUE A DRIVE. DIAGNOST MESSAGE PHASE AD SURE UNI | SUBSYSTEM CLEAR. ISSUE A SUBSYSTE IC MODE. ISSUE ID = 3 AND DRIVE DRESS 6. TURN OF IT FIELD ERROR DO | SELECT AN AVAILABLE M CLEAR. PUT CONTROLLER IN A SELECT COMMAND WITH SELECTED = 0. CLOCK THROUGH OFF DIAGNOSTIC MODE. MAKE DES NOT SET. |
| 8151 8152 | 026356 026360 026366 | | 000012 | 001262 | TST101: | SCOPE | #10.,STIMES | ::DO 10. ITERATIONS :CLEAR SUBSYSTEM |

| (| ZR6KG0 ZR6KG.I | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 1101 | 28-AUG | -81 15:17 PAGE IZE CLEARING SACE | 153 |
|---|--|--|--------------------------------|---------------|--------|--|---|---|---|
| | 8154 8155 | 026370 | 104003 | | | | ERROR | 3 | ;BAD INIT ERROR |
| | 8156 8157 8158 8159 8160 8161 8162 8163 | 026372 026376 026400 026402 026404 026405 026406 | 000000 000000 000 | 035674 | | | JSR SELDRV 0 0 .BYTE .BYTE | R4, LRLOAD | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| | 8164 8165 8166 8167 8168 | 026410 026412 026414 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| | 8168 8169 8170 | 026416 026420 | 104421 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| | 8171 8172 8173 | 026422 026424 | 104416 | | | | | 3 | ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| | 8174 8175 8176 8177 8178 8179 8180 8181 8182 8183 | 026440 026441 026442 026444 | 000 000 000000 012737 | | | | JSR SELDRV 0 0 .BYTE .BYTE 0 MOV CLR | #3:DMD, L.MR1 | ;LOAD 'L' REGS ;SELDRV :0 WORDS ;O IS BUFF ADDRESS ;SECTOR 0 ;TRACK 0 ;CYLINDER 0 ;SET DIAG MODE AND MESSAGE PAIR 3 ;SELECT DRIVE 0 |
| | 8183 8184 8185 | 026456 | 104417 | | | | TLOADRK | | :LOAD RK REGS |
| | 8186 8187 8188 | 026460 026464 | 004437 001027 | 036316 | | | JSR 1027 | R4,MCLOCK | :CLOCK THROUGH PHASE ADDRESS 6 |
| | 8189 8190 | 026466 | 042762 | 000040 | 000026 | | BIC | #DMD,RKMR1(R2) | CLEAR MAINTENANCE MODE |
| | 8191 8192 8193 | 026474 026476 | 104424 104002 | | | | TWAT32 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE |
| | 8194 8195 8196 8197 8198 8199 8200 8201 8202 8203 8204 8205 | 026500 026502 | | | | ************************************** | ISSUE A OFFSET O MODE. TRACK O MESSAGES SHOULD | DRIVE OFF TRACK SUBSYSTEM CLEAR. OF +1200 MICRO-IN ISSUE A WRITE DAY SECTOR O. CLOC S. TURN OFF DIAC SET IN DRIVE. RE | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS ISSUE A RECALIBRATE. ISSUE NCHES. PUT CONTROLLER IN DIAGNOSTIC TA OF 1 WORD TO CYLINDER O, TK THROUGH SEEK AND DRIVE CLEAR GNOSTIC MODE. DRIVE OFF TRACK EPEAT FOR ALL AVAILIABLE DRIVES. |
| | 8206 8207 8208 8209 | 026504 026506 026514 | | 000005 | 001262 | TST102: | SCOPE | #5.,\$TIMES | ::DO 5. ITERATIONS :CLEAR SUBSYSTEM |

| CZ | R6KG0 R6KG.F | RK6 FCTM | NL CTRL E | 15:16 | MACY11 30(1046) T102 | DRIVE OF | -81 15:17 PAGE FF TRACK | 154 |
|----|--|--|---|--------|-------------------------|--|----------------------------|--|
| | 8210 | 026516 | 104003 | | | ERROR | 3 | ;BAD INIT ERROR |
| | 8213 8214 8215 8216 8217 | 026524 026526 | 000000 000000 000 | 035674 | | JSR RECAL 0 0 .BYTE .BYTE | R4.LRLOAD | :LOAD 'L' REGS :RECAL :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| | 8220 8221 8222 8223 | 026540 026542 | 104417 104423 104002 005037 | 001662 | | TLOADRK TWAT16 ERROR CLR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CLEAR INTERRUPT FLAG |
| | 8225 8226 | 026550 026552 | 104437 104002 | | | TWAT8S ERROR | 2 | ; WAIT FOR INTERRUPT #2 |
| | 8228 8229 8230 8231 8232 8233 8233 | 026560 026562 026564 026566 026567 | 004437 000105 000000 000000 000 000 000 | 035674 | | JSR CLEAR 0 0 .BYTE .BYTE | R4.LRLGAD | :LOAD 'L' REGS :CLEAR :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| | 8236 8237 8238 | 026572 026574 026576 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 8240 8241 | 026600 026602 | 104421 104004 | | | T CHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| | 8243 8244 8245 8246 8247 8248 8249 | 026610 026612 | 000000 000000 000 000 000 | 035674 | 001612 | O O BYTE | 0 | :LOAD 'L' REGS :OFFSET :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O :SET OFFSET AT +1200 |
| | 8252 8253 8254 | 026630 026632 026634 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| | 8256 8257 | 026636 026640 | 104421 104004 | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| | 8259 | 026642 | 005037 | 001662 | | CLR | INTSET | CLEAR INT FLAG |
| | 8257 8258 8259 8260 8261 8262 8263 8264 | 026646 026650 | 104424 104002 | | | TWAT32 ERROR | 2 | :WAIT FOR INT #2 |
| | 8264 8265 | 026652 026654 | 104421 104004 | | | T CHKOP ERROR | 4 :OR 5. 6. 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| | | | | | | | | |

| | | | DIAG 15:16 | MACY11 | 30(1046) 28-AUG- T102 DRIVE OF | -81 15:17 PAGE FF TRACK | 155 |
|---------|---|--|------------------|--------|--|------------------------------|---|
| 00000 | 26656 25662 26664 26666 26670 | 004437 000105 000000 000000 000 | 035674 | | CIFAR | R4,LRLOAD | :LOAD 'L' REGS :CLEAR :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O |
| 0 | 26671 26672 | 000000 | | | DBYTE | 0 | :TRACK 0 :CYLINDER 0 |
| 000 | 26674 26676 26700 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 00 | 26702 26704 | 104421 104004 | | | T CHKOP ERROR | 4 ;OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 0000000 | 26706 26712 26714 26716 26720 26721 | 004437 000105 000000 000000 0000 0000 0000 00 | 035674 | 7 | 23 -1 OBUFF .BYTE .BYTE | R4,LRLOAD | :LOAD 'L' REGS :WRITE DATA W/O INTERRUPT ENABLE :-1 WORDS :OBUFF IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 0 | 26724 | 012737 | 000040 | 001616 | MOV | #DMD,L.MR1 | SET DIAGNOSTIC MODE |
| 0 | 26732 | 104417 | | | TLOADRK | | |
| 0 | 26734 26740 | 004437 001064 | 036316 | | JSR 1064 | R4,MCLOCK | CLOCK THROUGH SEEK & DRIVE CLEAR |
| 000 | 26742 26746 26750 26756 26760 26762 | 005062 104426 012762 104423 000240 000240 | 000026 100000 | 000000 | CLR TWAT64 MOV TWAT16 NOP NOP | RKMR1(R2) #CCLR,RKCS1(R2) | :CLEAR DIAGNOSTIC MODE :WAIT FOR INTERRUPT :CLEAR CONTROLLER :STALL FOR 16 MS |
| 000000 | 26764 26770 26772 26774 26776 26777 27000 | 004437 000101 000000 000000 000 000 000 000 | | | JSR SELDRV 0 0 .BYTE .BYTE | R4,LRLOAD | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| | 27002 | 005037 | 001616 | | CLR | L.MR1 | RESET DIAG MODE |
| 0 | 27006 27010 27012 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 000 | 27014 27016 27020 27022 27022 | 104422 000400 000000 000000 104004 | | | TCHKWE DROTERR 0 0 ERROR | 4: OR 5.6.7 | :CHECK OPERATION WITH ERROR EXPECTE :DRIVE OFF TRACK :REPORT ANY DISCREPANCIES |

```
T103
                                                           FILE UNSAFE
CZR6KG.P11
                28-AUG-81 15:16
                                                 :*TEST 103
                                                                     FILE UNSAFE
  8322
8323
8324
8325
8326
8327
8328
8329
8330
8331
                                                           ISSUE A SUBSYSTEM CLEAR. ISSUE A RECLAIBRATE. ISSUE A READ HEAD OF CYLINDER O, TRACK O IN 24 SECTOR FORMAT. DO A SELECT COMMAND IN 26 SECTOR FORMAT. PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A WRITE HEADER TO CYLINDER O, TRACK O, ONE WORD IN 26 SECTOR FORMAT. CLOCK THROUGH SEEK AND DRIVE CLEAR MESSAGES.
                                                           SIMULATE INDEX PULSE. TURN OFF DIAGNOSTIC MODE. FILE
                                                           UNSAFE SHOULD SET BECAUSE OF ATTEMPTING TO WRITE
  8332
                                                           THROUGH SECTOR PULSE. REPEAT FOR ALL AVAILIABLE DRIVES.
  8333
  8334
                                                   8335
8336
8337
         027026
                   000004
                                                  TST103: SCOPE
                             000005 001262
177777 001676
                                      001262
                                                                                         :: DO 5. ITERATIONS
                                                                     #5.,$TIMES
                                                           MOV
         027036
                   012737
                                                           MOV
                                                                     #-1, REFMT
                                                                                         :SET REFORMAT SWITCH
  8338
         027044
                   104416
                                                           TSSINIT
                                                                                         : CLEAR SUBSYSTEM
  8339
                                                                     3
         027046
                   104003
                                                           ERROR
                                                                                         :BAD INIT ERROR
  8340
  8341
8342
8343
8344
8345
8346
8346
         027050 027054
                                                           JSR
                                                                                         :LOAD 'L' REGS
                   004437
                             035674
                                                                     R4, LRLOAD
                   000113
                                                           RECAL
                                                                                         :RECAL
         027056
                                                                                         : 0 WORDS
                   000000
                                                           0
         027060
027062
027063
                                                                                         :0 IS BUFF ADDRESS
                                                           0
                   000000
                                                                                         :SECTOR G
                                                            .BYTE
                                                                     0
                       000
                                                           BYTE
                       000
                                                                     0
                                                                                          :TRACK 0
         027064
                   000012
                                                                                         :CYLINDER 12
  8349
         027066
                   104417
                                                           TLOADRK
                                                                                         :LOAD RK REGS
  8350
         027070
                   104423
                                                           TWAT16
                                                                                         :WAIT FOR INTERRUPT
                                                           ERROR
         027072
  8351
                   104002
                                                                                         :TO SLOW/NOT COMPLETE ERROR
  8352
  8353
         027074 027076
                   104421
                                                           TCHKOP
                                                                                         : CHECK OPERATION FOR ANY ERRORS
  8354
                   104004
                                                                     4 : OR 5, 6, 7 : REPORT ALL ERRORS
                                                           ERROR
  8355
  8356
         027100
                   005037
                             001662
                                                           CLR
                                                                     INTSET
                                                                                         :CLEAR INT FLAG
  8357
         027104
                   104437
                                                           TWAT8S
                                                                                         :WAIT FOR SECOND INT
                   104002
  8358
         027106
                                                           ERROR
  8359
  8360
         027110
                                                           TCHKOP
                   104421
                                                                                         : CHECK OPERATION FOR ANY ERRORS
  8361
         027112
                   104004
                                                                     4 : OR 5, 6, 7 : REFORT ALL ERRORS
                                                           ERROR
  8362
8363
         027114 027120
                                                                                         :LOAD 'L' REGS
                   004437
                             035674
                                                            JSR
                                                                     R4, LRLOAD
                   000105
                                                                                         :CLEAR
  8364
                                                           CLEAR
  8365
         027122
                   000000
                                                           0
                                                                                         : 0 WORDS
                                                                                         :0 IS BUFF ADDRESS
  8366
         027124
                   000000
                                                           Ō
                                                                                         :SECTOR 0
  8367
         027126
                       000
                                                           .BYTE
                                                                     0
  8368
                       000
                                                            .BYTE
                                                                                         : TRACK 0
  8369
         027130
                   000012
                                                                                         :CYLINDER 12
  8370
  8371
8372
8373
         027132
027134
027136
                   104417
                                                           TLOADRK
                                                                                         :LOAD RK REGS
                   104423
                                                           TWAT16
                                                                                         :WAIT FOR INTERRUPT
                   104002
                                                           ERROR
                                                                                         :TO SLOW/NOT COMPLETE ERROR
  8374
  8375
         027140
                   104421
                                                           TCHKOP
                                                                                         CHECK OPERATION FOR ANY ERRORS
                                                                     4 ; OR 5, 6, 7 ; REPORT ALL ERRORS
  8376
          027142
                   104004
                                                           ERROR
  8377
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 156

CZR6KGO RK6 FCTNL CTRL DIAG

SEQ 0156

| MACY11 | | 28-AUG-81 | 15:17 | PAGE | |
|--------|------|-------------|-------|------|--|
| | T103 | FILE UNSAFE | | | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 30(1046) T103 | 28-AUG | -81 15:17 PAGE SAFE | 157 |
|--|--|--|---------------|-------------------------|---|---------------------------|--|
| 8378 8379 8380 | 027144 027150 027152 | 010125 | 035674 | | JSR RDHEAD! | R4,LRLOAD CFMT | :LOAD 'L' REGS :RDHEAD!CFMT :O WORDS |
| 8381 8382 8383 8384 | 027154 027156 027157 027160 | 000000 000 000 00012 | | | BYTE | 0 | :0 IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 12 |
| 8386 8387 8388 | 027162 027164 027166 | 104417 104424 104002 | | | TLOADRK TWAT32 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8390 8391 8392 | 027170 027172 | 104421 104004 | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 8379 8380 8381 8382 8383 8384 8385 8386 8387 8388 8389 8391 8391 8395 8396 8397 8398 8399 8399 | 027174 027200 027202 027204 027206 027207 027210 | 004437 000101 000000 000000 000 000 000 000012 | 035674 | | JSR SELDRV 0 0 .BYTE .BYTE | R4,LRLOAD 0 | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER 12 |
| 8401 8402 8403 8404 | 027212 027214 027216 | 104417 104423 104002 | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8405 8406 8407 8408 8409 8410 8411 8412 | 027220 027224 027226 027230 027232 027233 027234 027236 | 004437 000127 177777 072414 000 000 000012 012737 | | 001616 | JSR WRHEAD -1 OBUFF .BYTE .BYTE 12 MOV | R4,LRLOAD 0 0 #DMD,L.MR1 | :LOAD 'L' REGS :WRHEAD :-1 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :(YLINDER 12 ;SET DIAGNOSTIC-MODE |
| 8413 8414 8415 8416 | 027244 027246 027252 | 104417 004437 001064 | 036316 | | TLOADRK JSR 1064 | R4,MCLOCK | :LOAD RK REGS :CLOCK THROUGH SEEK AND DRIVE CLEAR |
| 8418 | 027254 | 052762 | 000200 | 000026 | BIS | #MIND, RKMR1(R2) | ; SET INDEX |
| 8416 8417 8418 8419 8420 8421 8422 8423 8424 | 027262 027266 | 004437 001001 | 036316 | | JSR 1001 | R4,MCLOCK | CLOCK INDEX |
| 8423 | 027270 | 042762 | 000200 | 000026 | BIC | #MIND, RKMR1(R2) | CLEAR INDEX |
| 8425 8426 8427 8428 8429 | 027276 027302 | 004437 001001 | 036316 | | JSR 1001 | R4,MCLOCK | CLOCK CLEAR |
| 8428 | 027304 | 005062 | 000026 | | CLR | RKMR1(R2) | CLEAR DIAGNOSTIC MODE |
| 8430 8431 8432 | 027310 027312 | 104426 104002 | | | TWAT64 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8433 | 027314 | 104421 | | | TCHKOP | | CHECK OPERATION FOR ANY ERRORS |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 1103 | FILE UN | -81 15:17 PAGE SAFE | 158 | |
|--|--|---|---------------|--------|------------------|---|------------------------|--|------------|
| 8434 | 027316 | 104004 | | | | ERROR | 4 ;OR 5, 6, 7, | 10 : REPORT ALL ERRORS | |
| 8434 8435 8436 8437 8438 8443 8441 8442 8443 | 027320 027324 027326 027330 027332 027333 027334 | 004437 000101 000000 000000 000 000 000 000012 | 035674 | | | JSR SELDRV 0 0 .BYTE .BYTE | R4,LRLOAD | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER 12 | |
| 8444 | 027336 | 005037 | 001616 | | | CLR . | L.MR1 | CLEAR DIAG MODE | |
| 8446 8447 8448 | 027342 027344 027346 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 . | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE E | RROR |
| 8446 8447 8448 8449 8451 8452 8453 8455 8456 8457 8458 | 027350 027352 027354 027356 027360 | 104422 040400 000000 000000 104004 | • | ę | | TCHKWE UNSERR!! 0 0 ERROR | DROTERR 4: OR 5,6,7 | :CHECK OPERATION WITH E :UNSAFE AND DRIVE OFF T :REPORT ANY DISCREPANCE | RACK |
| 8455 8456 8457 | 027362 027364 | 104416 104003 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INI; ERROR | |
| 8459 8460 8461 8462 8463 8464 8465 | 027366 027372 027374 027376 027400 027401 027402 | 004437 000101 000000 000000 000 000 000 000012 | 035674 | | | JSR SELDRV 0 0 .BYTE .BYTE 12 | R4, LRLOAD | :LOAD 'L' REGS :SELDRV :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O | |
| 8466 8467 8468 | 027404 | 012737 | 000001 | 001616 | | MOV | #1,L.MR1 | SET MESSAGE SELECT ONE | |
| 8469 8470 8471 8472 8473 | 027412 027412 027414 027416 | 104417 104423 104002 | | | 1\$: | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE E | RROR |
| 8474 8475 8476 | 027420 027422 | 104421 104004 | | , | | TCHKOP ERROR | 4 ,: OR 5, 6, 7 | :CHECK OPERATION FOR AN :REPORT ALL ERRORS | Y ERRORS . |
| 8477 8478 8479 | 027424 027432 | 032737 001767 | 000049 | 001574 | | BIT BEQ | #S.HDHM,T.MR2 1\$ | :TEST IF HEADS HOME | |
| 8480 8481 8482 | 027434 027436 | 104416 104003 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR | |
| 8474 8475 8476 8477 8478 8487 8481 8482 8483 8484 8485 8486 8487 8488 | 027440 027444 027446 | 005037 104434 000240 | 001662 | | | CLR TWAT159 NOP | INTSET | :CLEAR INT FLAG :WAIT FOR APPROX 160 MS :DON'T CARE ERROR RETUR | |
| 8487 8488 8489 | 027450 027452 | 104416 104003 | | | | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR | |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 159
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
                                             1103
                                                        FILE UNSAFE
  8490
         027454 012762 000100 000000
                                                         MOV
                                                                   #IE.RKCS1(R2) ; SET INTERRUPT ENABLE
  8491
 8492
8493
         027462
                  104437
                                                          TWAT85
                                                                                      :WAIT FOR SECOND INTERRUPT FROM HDS LOADED
         027464
                  104002
                                                         ERROR
 8494
8495
         027466 005037 001616
                                                         CLR
                                                                   L.MR1
                                                                                      : CLEAR MR1
 8496
8497
         027472 027476
                                                                                      ; LOAD 'L" REGS
                  004437
                            035674
                                                          JSR
                                                                   R4.LRLOAD
  8498
                  000105
                                                         CLEAR
                                                                                      :CLEAR
  8499
         027500
                  000000
                                                         0
                                                                                      : 0 WORDS
  8500
         027502
                                                         Ŏ
                  000000
                                                                                      :0 IS BUFF ADDRESS
         027504
  8501
                      000
                                                                                      :SECTOR O
                                                          .BYTE
 8502
8503
                      000
                                                         BYTE
                                                                                       :TRACK 0
         027506
                  000012
                                                                                      :CYLINDER 12
 8504
         027510
027512
 8505
                  104417
                                                                                      :LOAD RK REGS
;WAIT FOR INTERRUPT
                                                         TLOADRK
 8506
8507
                  104423
                                                         TWAT16
         027514
                  104002
                                                         ERROR
                                                                                      :TO SLOW/NOT COMPLETE ERROR
 8508
8509
         027516 027520
                                                                                      :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS
                  104421
                                                         TCHKOP
  8510
                  104004
                                                         ERROR
                                                                   4 : OR 5, 6, 7
  8511
 8512
8513
         027522 027526
                            042260
                                                        *JSR
                  004437
                                                                   R4.GENCOM
                                                                                      :BUILD HEADERS
                  001200
                                                         1200
 8514
        027530
027534
027536
 8515
                  004437
                            035674
                                                         JSR
                                                                                      :LOAD 'L' REGS
                                                                   R4. LRLOAD
 8516
8517
                                                         WRHEAD
                                                                                      : WRHEAD
                  177676
                                                         -102
                                                                                      :-102 WORDS
 8518
         027540
                  072414
                                                                                      OBUFF IS BUFF ADDRESS
                                                         OBUFF
         027542
027543
  8519
                      000
                                                                   0
                                                         .BYTE
                                                                                      :SECTOR O
  8520
                                                         BYTE
                      000
                                                                                      : TRACK O
 8521
8522
8523
         027544
                  000012
                                                                                      :CYLINDER 12
         027546
                  104417
                                                         TLOADRK
                                                                                      :LOAD RK REGS
 8524
8525
8526
8527
8528
         027550
                  104426
                                                         TWAT64
                                                                                      WAIT FOR INTERRUPT
         027552
                  104002
                                                         ERROR
                                                                                      :TO SLOW/NOT COMPLETE ERROR
         027554
                  104421
                                                         TCHKOP
                                                                                      CHECK OPERATION FOR ANY ERRORS
         027556
                  104004
                                                         ERROR 4 : OR 5, 6, 7 : REPORT ALL ERRORS
 8529
8530
8531
                                                         DUMMY TEST FOR PREVIOUS TEST EXIT
THIS TEST IS PRESENT TO MAKE $SW08TB TABLE HAVE AN ENTRY
WHICH RELATES TO 'NEWDRY'. THIS IS NECESSARY IF AN ERROR OCCURS
                                                : * TEST 104
  8532
  8533
  8534
                                                         IN THE PRECEEDING TEST AND THAT ERROR ABORTS THE TEST.
  8535
                                                         IF THIS TEST WERE NOT PRESENT, THE PROGRAM WOULD SKIP THE "NEWDRY" ROUTINE AND GO TO THE TEST FOLLOWING "NEWDRY".
 8536
8537
8538
8539
                                                         IN ADDITION, THE DRIVE IS CLEARED AND THE HEADS ARE ALLOWED
                                                         TO RELOAD. THIS MUST BE DONE TO PREVENT UNEXPECTED INTERRUPTS
  8540
                                                         FROM THE DRIVE COMING READY AT A LATER TIME.
  8541
 8542
8543
         027560
                                                TST104: SCOPE
         027562
                  012737
                            000001 001262
                                                                   #1,$TIMES
                                                         MOV
                                                                                      :: DO 1 ITERATION
 8544
         027570
                 104416
                                                                                      : CLEAR SUBSYSTEM
                                                         TSSINIT
```

| CZR6KGO CZR6KG. | RK6 FCTI | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T104 | 28-AUG | -81 15:17 PAGE EST FOR PREVIOUS | 160 TEST EXIT |
|--|--|--|--|--|------------------|---|---|---|
| 8546 | 027572 | | | | | ERROR | 3 | ;BAD INIT ERROR |
| 8547 85489 85551 85555 85555 85555 85555 85555 85555 85566 85566 85567 85577 85778 85778 | 027574 027602 027606 027614 027622 027630 027636 027640 027644 | 013762 005037 012737 053737 013762 032762 001004 005237 001371 104002 | 001626 036126 000001 001720 036124 000200 | 000010 036124 036124 000000 000012 | | CLR MOV BIS MOV BIT RNE INC | HOLD1 #1,HOLD | SELECT THE DRIVE TEST IF DRIVE READY BR IF YES ELSE TRY AGAIN |
| 8559 8560 8561 | 027650 027650 027652 | 104416 104003 | | | 2\$: | TSSINIT ERROR | | ;CLEAR SUBSYSTEM ;BAD INIT ERROR |
| 8563 8564 | 027654 027660 | 004437 001200 | 042260 | | | JSR 1200 | R4, GENCOM | GENERATE HEADERS FOR CYL 0 |
| 8566 8567 8568 8569 8570 8571 | 027662 027666 027670 027672 027674 027675 027676 | 004437 000127 177676 072414 000 000 000 | 035674 | | | JSR WRHEAD -102 OBUFF BYTE BYTE 0 | R4, LRLOAD | :LOAD 'L' REGS ;WRHEAD :-102 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 0 |
| 8574 8575 8576 | 027700 027702 027704 | 104417 104426 104002 | | | | TLOADRK TWAT64 | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 8579 8580 | 027710 | 104421 104004 005037 | 001676 | | .SBTTL | ERROR CLR | 4 : OR 5. 6. 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS CLEAR REFORMAT SWITCH |
| 8581 8582 8583 8584 8585 8586 | 027716 027720 027726 027734 | 000004 012737 032737 001026 | 000001 000200 | 001262 001630 | NEWDRV: | | #1,\$TIMES | |
| 8588 8589 8590 8591 8592 8593 | 027736 027742 027746 027754 027756 027764 027766 | 005237 006337 033737 001005 032737 001012 000763 | 001626 001630 001630 000400 | 001354 001630 | 1\$: | INC ASL BIT BNE BIT BNE BR | DRVNUM DRVBIT DRVBIT,\$DEVM 2\$ #BIT8,DRVBIT 3\$ 1\$ | BUMP TO NEXT SEQUENTIAL ADDRESS BUMP DRIVEBIT TO THAT POSITION IS THIS DRIVE TO BE TESTED? YES-EXIT ALL DRIVES TESTED? YES-EXIT ELSE CHECK NEXT DRIVE AVAILABLE |
| 8594 8595 8596 8597 8598 8599 8600 | 027770 027776 030002 030006 030012 030016 | 112737 013701 004737 000137 005037 005037 | 000004 001626 036150 004720 001630 001626 | 001102 | 2\$: 3\$: | MOVB MOV JSR JMP CLR CLR | #4,\$TSTNM DRVNUM,R1 PC,GTYP1 TSTLUP DRVBIT DRVNUM | :SET TEST NUMBER FOR REPORTS :GET DRV TYP FOR NEXT DRV TO IST . :GO TO TEST LOOP TO CHECK THIS DRIVE :CLEAR DRIVE BIT . :CLEAR DRIVE NUMBER |
| 8601 | | | | | | | | |

| | | | | TEST | 105 | RESET ATTENTION | S WITH UNIBUS INIT |
|--|--|--|--|---|--|---|--|
| | | | | | DO A RE ISSUE A | CALIBRATE ON ALL RESET. MAKE SU | AVAILIABLE DRIVES. RE ALL ATTENTION RESET. |
| 030040 030044 030046 030050 030052 030054 030056 030060 | 000004 012737 005000 012701 013703 104416 104003 030103 001006 006301 005200 032701 | 000012 000001 001354 | 001262 | TST105: | | | ::DO 10. ITERATIONS :CLEAR DRIVE POSITION COUNTER :PRESET BIT FOR POSITION 0 IN TESTING FOR AVAIL :GET DEVICE MAP :CLEAR SUBSYSTEM :BAD INIT ERROR :TEST IF THIS DRIVE AVAILABLE :YES-SKIP TO SEEK :SHIFT DRIVE SELECT BIT :BUMP DRIVE POSITION COUNTER :ALL DRIVE POSITIONS CHECKED :NO-LOOP :SKIP TO RESET |
| 030066 | 010037 | 001610 | | 2\$: | MOV | RO.L.CS2 | |
| 030100 | 012737 | 036134 | 001600 | | MOV | #RECAL,L.CS1 | ;LOAD RECALIBRATE |
| 030106 030110 030112 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | 2 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 030150 | 030104 | 091662 000764 000012 000016 001557 177400 | 001556 | 12\$: | CLR MOV MOV MOVB BIC BIT | INTSET #500.,R5 #12,RKCS1(R2) RKASOF(R2),T.ASO T.ASOF+1,R4 #177400,R4 R1,R4 | CLEAR INTERRUPT FLAG SET COUNT FOR 8 SECONDS RESET INTERRUPT ENABLE OF GET ATTENTION REGISTER ADJUST FOR CHECK OF ATTENTION CLEAR UNUSED BITS |
| 030154 030156 030160 030162 030164 | 104423 000240 000240 005305 001362 | | | | TWAT16 NOP NOP DEC BNE | R5 12\$ | :WAIT FOR 16 MS :DON'T CARE RETURNS :TATOL WAIT TIME IS 8 SECONDS :CHECK ATTENTION EACH 16 MS |
| 030166 030170 030170 030172 | 104002 104421 104004 | | | 10\$: | TCHKOP ERROR | | :REPORT IF NO ATTENTION IN 8 SEC :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 030174 030176 030200 | 000727 000005 004737 | 045220 | | 45: | BR RESET JSR | 3\$ PC,\$TKINT | :LOOP FOR NEXT DRIVE :UNIBUS RESET :RESET KEYBOARD INTERRUPT ENABLE |
| 030204 030210 | 012701 005301 | 000031 | | 5\$: | MOV DEC | #25.,R1 R1 | :DO A SHORT DELAY |
| | 030022 030024 030032 030034 030046 030050 030056 030056 030056 030066 030070 030074 030110 030110 030112 030112 030124 030124 030132 030144 030150 030150 030150 030164 030150 030162 030164 030170 030170 030172 | 030022 000004 030024 012737 030032 005000 030034 012701 030040 013703 030044 104416 030046 104003 030052 001006 030054 006301 030056 005200 030060 032701 030064 001771 030066 000443 030070 010037 030074 004737 030110 104423 030112 104002 030114 005037 030112 104002 030114 005037 030124 012762 030132 016237 030140 113704 030150 030104 030150 030104 030150 030104 030152 001006 030154 104423 030156 000240 030156 000240 030162 005305 030164 001362 030165 000240 030166 104002 | 030022 000004 030024 012737 000012 030032 005000 030034 012701 000001 030040 013703 001354 030046 104003 030052 001006 030054 006301 030056 005200 030060 032701 000400 030060 00443 030070 010037 001610 030074 004737 036134 030100 012737 000113 030114 005037 001662 030120 012705 000764 030124 012762 000012 030140 113704 001557 030140 113704 001557 030140 042704 177400 030150 030104 030152 016237 000016 030154 104423 030150 030104 030152 01006 030154 104423 030156 000240 030162 005305 030164 001362 030170 000240 030170 104421 030170 104421 030171 104004 030172 104004 030172 000005 030174 000727 030176 000005 030177 045220 030204 012701 000031 | 030022 000004 030024 012737 000012 001262 030034 012701 000001 030040 013703 001354 030046 104003 030050 030103 030052 001006 030054 006301 030066 0032701 000400 030066 000443 030070 010037 001610 030074 004737 036134 030100 012737 000113 001600 030114 005037 001662 030112 104002 030114 005037 00012 030112 104002 030114 012762 000764 030120 012705 000764 030120 012705 000764 030132 016237 000016 001556 030140 113704 001557 030140 113704 001557 030140 00240 030150 030104 030150 030104 030150 030106 030151 104423 030150 030104 030150 030104 030150 030104 030150 030104 030150 030106 030160 000240 030160 000240 030160 000240 030170 104421 030170 104421 030172 104004 030174 000727 030176 000005 030176 000005 030177 0045220 030204 012701 000031 | 03C022 000004 012737 000012 001262 030032 012701 000001 001354 030040 013703 001354 030052 001006 030054 006301 030056 005200 030064 004437 030066 000443 030074 004737 036134 001600 03014 00423 030112 00402 030140 012737 000113 001600 030140 012737 000113 001600 030140 012737 000113 001600 030140 012737 000113 001600 030140 012737 000113 001600 030140 012705 000764 030132 016237 00016 0001557 030140 013704 001557 030140 013704 001557 030140 013704 001557 030150 030164 042704 01557 030150 030164 042704 0001557 030150 030164 042704 01557 030150 030164 042704 0001557 030150 030164 042704 0001557 030150 030164 042704 030152 001006 030154 04423 030152 001006 030154 000240 030155 030164 001362 03016 | | 030022 000004 012737 000012 001262 |

| CZR6KGO | RK6 FCT | NL CTRL | DIAG | MACY11 | 30(1046) | 28-AUG | F 13 -81 15:17 PAGE TTENTIONS WITH U | 162 |
|--|--|--|--|------------------|--------------|--|--|--|
| 8658 8659 8660 | 030212 | | | | | BNE JSR | 5\$ PC.OPITST | |
| 8661 | 030220 | 104420 | | | | TGETRK | | GET RK611 REGS |
| 8662 8663 8664 8665 | 030222 | 105737 001407 | 001557 | | | TSTB BEG | | :ALL ATTENTION RESET? |
| 8666 8667 8668 | 030230 030236 030244 | 012737 012737 104012 | 056630 056754 | | | MOV MOV ERROR | #EMDA.EM12N #EMUR.DF011A 12 | "DRIVE ATT NOT RESET RESULT OF UNIBUS RESET" |
| 8669 8670 | 030246 | | | | 6\$: | | | |
| 8671 8672 8673 | | | | | *TEST | 106 | RESET ATTENTIONS | WITH SUBSYSTEM CLEAR |
| 8674 8675 8676 8677 | | | | | * | DO A REGISSUE A RESET. | CALIBRATE ON ALL SUBSYSTEM CLEAR. | AVAILABLE DRIVES. MAKE SURE ALL ATTENTIONS |
| 8678 8679 8680 8681 8682 8683 8684 8685 8686 8687 8688 8689 8690 8691 8692 8693 | 030246 030250 030256 030260 030264 030270 030274 030276 030300 030302 030304 030310 030312 | 000004 012737 005000 012701 013703 104416 104003 030103 001006 006301 005200 032701 001771 000443 | 000012 000001 001354 | | 1\$: 3\$: | SCOPE MOV CLR MOV MOV TSSINIT ERROR BIT BNE ASL INC BIT | #10.,\$TIMES R0 #1,R1 \$DEVM,R3 3 R1.R3 | ::DO 10. ITERATIONS :CLEAR DRIVE POSITION COUNTER :PRESET TO TEST POSITION 0 :CUT DEVICE MAP :CLEAR SUBSYSTEM :BAD INIT ERROR :THIS DRIVE AVAILABLE? :YES-SKIP TO SEEK :SHIFT TO NEXT DRIVE POSITION :DUMP POSITION COUNTER :ALL POSITIONS CHECKED :NO-LOOP :YES-SKIP TO CLEAR |
| 8694 8695 8696 8697 8698 8699 8700 | 030314 030320 030324 030332 030334 030336 | 010037 004737 012737 104417 104423 104002 | 001610 036134 000113 | 001600 | 2\$: | MOV JSR MOV TLOADRK TWAT16 ERROR | RO.L.CS2 PC.GTYPO #RECAL.L.CS1 | :LOAD DRIVE NUMBER :LOAD RECALIBRATE :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8701 8702 8703 8704 8705 | 030340 030344 030350 030356 030364 | 005037 012705 012762 016237 113704 | 001662 000764 000012 000016 001557 | 000000 001556 | 12\$: | CLR MOV MOV MOVB | INTSET #500.,R5 #12,RKCS1(R2) RKASOF(R2),T.ASO T.ASOF+1,R4 | CLEAR INT FLAG SET COUNT FOR 8 SECONDS RESET INTERRUPT ENABLE F GET ATTENTION REGISTER ADJUST FOR CHECK OF ATTENTION |

| CZ | R6KG0 | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 1106 | 28-AUG RESET A | G 13 G-81 15:17 PAGE TTENTIONS WITH S | 163 |
|----|--|--|--|--|------------------|---|--------------------------|---|--|
| | 8706 8707 8708 8709 | 030370 030374 030376 | 042704 030104 001006 | 177400 | | | BIC BIT BNE | #177400.R4 R1.R4 10\$ | :CLEAR UNUSED BITS :CHECK IF ATT SET FROM DRIVE RECAL ED :YES - SKIP |
| | 8710 8711 8712 8713 | 030400 030402 030404 030406 030410 | 104423 000240 000240 | | | | TWAT16 NOP NOP | | :WAIT FOR 16 MS :DON'T CARE RETURNS |
| | 8714 8715 8716 | 030412 | 001362 | | | | DEC RNE ERROR | R5 12\$ 2 | :TATOL WAIT TIME IS 8 SECONDS :CHECK ATTENTION EACH 16 MS :REPORT IF NO ATTENTION IN 8 SEC |
| | 8717 8718 8719 8720 | 030414 030414 030416 | 104421 | | | 10\$: | TCHKOP ERROR | 4 :OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| | 8721 | 030420 | 000727 | | | | BR | 3\$ | :LOOP FOR NEXT DRIVE |
| | 8708 8709 8710 8711 8712 8713 8714 8715 8716 8717 8718 8720 8721 8722 8723 8724 8725 8726 8727 8728 8729 8730 8731 8732 8733 | 030422 030430 030434 030436 | 012701 005301 | 000040 000031 | 000010 | 4\$: 5\$: | BIS MOV DEC BNE | #SCLR,RKCS2(R2) #25.,R1 R1 5\$ | :DO SUBSYSTEM CLEAR :DO A SHORT DELAY |
| | 8728 | 030440 | 104420 | | | | TGETRK | | GET RK611 REGS |
| | 8730 8731 8732 | 030442 030446 | 105737 001407 | 001557 | | | ISTB BEQ | T.ASOF+1 6\$ | :TEST ALL ATTENTION RESET |
| | 8733 8734 8735 8736 | 030450 030456 030464 | 012737 012737 104012 | 056630 057044 | 001470 061112 | | MOV MOV ERROR | #EMDA,EM12N #EMSCLR,DF011A 12 | "DRIVE ATT NOT RESET AS RESULT OF SUBSYSTEM CLEAR" |
| | 8737 8738 | 030466 | | | | 6\$: | ****** | • | ****** |
| | 8739 8740 | | | | | ; *TEST | 107 | | ION FROM OTHER DRIVE |
| | 8741 8742 8743 8744 8745 | | | | | * | IS SET. MAKE SUI | HER AVAILABLE DRI WAIT FOR SECOND | AVAILABLE DRIVE. DO A SELECT IVE. MAKE SURE STATUS VALID DINTERRUPT FROM RECALIBRATE REMAINS SET AND DRIVE STATUS |
| | 8745 8747 8748 | | | | | | REPEAT I | FOR ALL COMBINATI | IONS OF TWO AVAILLABLE DRIVES. |
| | 8749 8750 8751 8752 | | | | | :* | NOTE: | TWO DRIVES ARE A | |
| | 8753 8754 8755 8756 8757 8758 8759 8760 8761 | 030466 030470 030476 030502 030506 030512 030514 030520 | 000004 012737 013746 004437 022627 101007 005737 001002 | 000012 001354 036242 000001 001304 | 001262 | †\$1107: | | SDEVM,-(SP) R4,BIT(NT | ::DO 10. ITERATIONS :PUT DEVICE MAP ON STACK :COUNT NUMBER OF BITS(# OF DRIVES) :COMPARE TO 1 :SKIP IF MORE THAN 1 :CHECK IF PASS 0 :NO-SKIP |

| CZR6KGO CZR6KG. | RK6 FCT P11, 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 1107 | 28-AUG SVAL AN | -81 15:17 PAGE D ATTENTION FROM | 164 OTHER DRIVE |
|--|--|--|--|----------------------------|------------------|--|---|---|
| 8762 8763 | 030522 030526 | 104401 000137 | 052664 031772 | | 15: | TYPE | OPRO18 \$EOP | "OVERLAPPED OPERATION BYPASSED" GET OUT. |
| 8764 8765 8766 8767 8768 8769 8770 8771 8772 8773 | 030532 030540 030544 030546 030550 030554 030560 030566 | 012737 013705 005000 005001 012703 012704 012737 000503 | 177777 001354 000001 000001 030570 | 001224 | 28: | MOV CLR CLR MOV MOV MOV BR | #-1,\$TMP1 \$DEVM,R5 R0 R1 #1,R3 #1,R4 #3\$,\$LPERR 11\$ | SET LOOP CONTROL FLAG GET DEVICE MAP CLEAR FOR DRIVE #A CLEAR FOR DRIVE #B SET DRIVE POSITION A SET DRIVE POSITION B SET LOCAL LOOP ON ERROR GO SET UP POINTERS |
| 8774 8775 8776 | | 104416 104003 | | | 3\$: | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| 8777 8778 8779 8780 8781 | 030574 030600 030604 030610 | 010037 010037 004737 012737 | 001610 001626 036134 000113 | 001600 | | MOV MOV JSR | RO.L.CS2 RO.DRVNUM PC.GTYPO | :LOAD DRIVE A :LOAD FOR REPORT |
| 8781 8782 8783 8784 9785 8786 8787 8788 8789 | 030616 | 104417 104423 104002 104421 104004 | 000113 | 001600 | | MOV TLOADRK TWAT16 ERROR TCHKOP ERROR | #RÉCAL,L.CS1 2 4 :OR 5, 6, 7 | ;LOAD RECAL ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW, NOT COMPLETE ERROR ;CHECK OPERATION FOR ANY ERRORS ;REPORT ALL ERROPS |
| 8789 | 030630 | 005037 | 001662 | | | CLR | INTSET | CLEAR INT FLAG |
| 8792 8793 8794 | 030640 | 010137 010137 004737 012737 | 001626 | 001600 | | MOV MOV JSR MOV | R1.L.CS2 R1.DRVNUM PC.GTYP1 #SELDRV.L.CS1 | :LOAD DRIVE B :LOAD FOR REPORT :LOAD DRIVE SELECT |
| 8795 8796 8797 8798 | 030656 030660 030662 | 104417 104423 104002 | | | | TLOADRK TWAT16 | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 87 9 9 8800 8801 | 030664 030666 | 104421 104004 | | | | TCHKOP ERROR | 4 :OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS |
| 8801 8802 8803 8804 8805 8806 8807 | 030670 030676 030700 030706 030714 | 032737 001007 012737 012737 104011 | 100000 056444 050250 | 001552 001460 061112 | • | BIT BNE MOV MOV ERROR | #SVAL,T.DS 4\$ #EMSVAL,EM11N #OPEROO,DF011A | :CHECK IF STATUS VALID SET :YES - SKIP :"STATUS VALID NOT SET RESULT OF :DRIVE SELECT" |
| 8808 8809 8810 8811 8812 8813 | 030716 030722 030724 030726 | 005037 104436 000401 000406 | 001662 | | 4\$: | CLR TWAT2S BR BR | INTSET 44\$ 55\$ | :CLEAR INT FLAG :WAIT FOR SEEK COMPLETE INTERRUPT :NONE RECEIVED - SKIP : RECEIVED - SKIP |
| 8814 8815 8816 8817 | 030730 030734 030742 | 010037 012737 104002 | 001626 060501 | 001372 | 44\$: | MOV MOV ERROR | RO, DRVNUM #DH017, DH2N 2 | :SET DRIVE FOR REPORT :"COMMAND - SELECT AFTER RECAL" |

| .P11 . | TNL CTRL 28-AUG-81 | | MACTI | 1107 | | 6-81 15:17 PAGE ID ATTENTION FROM | |
|--|--|------------------|------------------|-------|---|---|---|
| 030744 030746 030754 | 104420 032737 001007 | 100000 | 001552 | 55\$: | TGETRK BIT BNE | #SVAL,T.DS | GET RK PEGS TEST IF SVAL STILL SET YES - SKIP |
| 030756 030764 030772 | 012737 012737 104014 | 056444 060524 | 001510 061112 | | MOV MOV ERROR | #EMSVAL,EM14N #DH018,DF011A | "STATUS VALID RESET RESULT OF RECAL COMPLETE ATTENTION AFTER SEL" |
| 030774 | 104415 | | | 5\$: | SCOP1 | | :LOCAL LOOP TO 3\$ |
| 030756 030764 030772 030774 | | | | | OF DRIV LOWEST B. THE THE LOW AS A. | NUMBER DRIVE AS SECOND PASS SWAN | ES THE TEST TO BE RUN ON EVERY COMBINATION OF FIRST PASS OF THE PROGRAM WILL USE THE A AND THE NEXT HIGHER NUMBER DRIVE AS PS DRIVE A & B. THE THIRD PASS USES AS B AND THE 3RD HIGHEST NUMBER DRIVE WAPS A & B AGAIN. THIS CONTINUES EEN TESTED WITH THE LOWEST NUMBER |
| | | | | | THE SEC | OND HIGHEST NUMB | ER DRIVE IS THEN USED AS A AND THE EY ARE SWAPPED ON THE NEXT PASS. |
| | | | | | THIS TE | | NUED UNTIL ALL COMBINATIONS ARE |
| 030776 031002 | 005237 001024 | 001224 | | 115: | INC | \$1MP1 16\$ | :INCREMENT PASS CONTROL :SKIP IF NOT ZERO :(IT WILL BE ZERO ON THE 1ST PASS) |
| 031004 031006 | 030305 001006 | | | 12\$: | BIT | R3, R5 13\$ | :TEST IF BIT POSITION FOR A AT AVAIL DE |
| 031010 03'012 031014 031020 031022 | 005200 006303 032703 001771 000464 | 000400 | | 225: | INC ASL BIT BEQ BR | R0 R3 #BIT8,R3 12\$ 50\$ | :BUMP RO (DRIVE A) :SHIFT DRIVE SELECT BIT ONE POSITION :IF BIT 8 IS SET, ALL DRIVES HAVE :BEEN CHECKED; IF NOT CHECK NEXT POSITION :DONE-EXIT |
| 031024 | 010001 | | | 13\$: | MOV MOV | RO.R1 R3.R4 | SET DRIVE B TO THE SAME AS A |
| 031030 031032 | 005201 | | | 14\$: | INC | R1 R4 | :BUMP R1 (DRIVE B) :SHIFT SELECTOR BIT ONE POSITION |
| 031014 031020 031022 031022 031024 031030 031032 031034 031036 031046 031046 031062 031064 031066 | 030405 001004 032704 001771 000452 | 000400 | | | BIT BNE BIT BEQ BR | R4,R5 15\$ #BIT8,R4 14\$ 50\$ | :IS THIS DRIVE AVAIL? :YES-SKIP :WERE ALL POSITIONS CHECKED? :NO-LOOP :DONE-EXIT |
| 031050 | 000137 | 030570 | | 15\$: | JMP | 3\$ | GO DO THE TEST ON THE DRIVE A & B |
| 031054 031062 | 032737 001410 | 000001 | 001224 | 16\$: | BIT | #BITO,\$TMF1 | : CONTAINED IN RO & R1 :IS PASS FLAGS ODD? :NO-SKIP |
| 031064 031066 031070 | 010046 010346 010403 | | | | MOV MOV | RO(SP) R3(SP) R4.R3 | SWAP RO & R1, R3 & R4 |

| CZ | R6KG0 R6KG. | RK6 FCT P11 2 | NL CTRL I 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) 1107 | 28-AL | UG-81 15:17 PAGE AND ATTENTION FROM | 166 OTHER DRIVE |
|----|--|--|--|----------------------------|--------|---|--|--|--|
| | 8874 8875 8876 8877 | 031072 031074 031076 031100 | 010100 012604 012601 000137 | 030570 | | | MOV MOV JMP | R1,R0 (SP)+,R4 (SP)+,R1 3\$ | REPEAT TEST ON THIS COMBO. |
| | 8879 8880 8881 8882 | 031104 031112 031114 031116 | 032737 001410 005200 006303 | 000002 | 001224 | 17\$: 18\$: | BIT BEG INC ASL BIT | #BIT1,\$TMP1 19\$ RO R3 R3,R5 | :TEST IF PASS FLAGS AT HALF MODULE 4? :NO-SKIP TO BUMP DRIVE B :BUMP DRIVE A :SHIFT DRIVE SELECT BIT |
| | 8883 8884 8885 8886 8887 | 031114 031116 031120 031122 031124 031130 031132 | 005200 006303 030305 001014 032703 001771 000412 | 000400 | | | BIT BNE BIT BEQ BR | R3,R5 20\$ #BIT8,R3 18\$ 21\$ | ;AVAILABLE? ;YES-SKIP ;ALL CHECKED? ;NO-SKIP ;GO TO NEXT PASS |
| | 8875 888778 888778 888778 888888 888888 888888 | 031134 031136 031140 031142 031144 031150 031152 | 001004 | 000400 | | 19\$: | INC ASL BIT BNE BIT BEQ BR | R4,R5 | ;BUMP DRIVE B ;SHIFT DRIVE SELECT BIT ;AVAILABLE? ;YES-SKIP ;ALL CHECKED? ;NO-LOOP ;YES-SKIP TO NEXT PASS |
| | 8897 | 031154 | 000137 | 030570 | | 20\$: | JMP | 3\$ | GO TEST THIS COMBO |
| | 8899 8900 8901 8902 8903 | 031162 | 010100 010403 005037 000137 | 001224 031010 | | 21\$: 23\$: 50\$: | MOV MOV CLR JMP | R1.R0 R4.R3 \$TMP1 22\$ | ;SET DRIVE O TO LOW POSITION THIS PASS ;SET SELECT BITS TO AGREE ;CLEAR PASS FLAGS ;GO SET UP A & B |
| | 8904 8905 | | | | | *TEST | 110 | OVERLAPPED OPERA | ATIONS |
| | 8906 8907 8908 8909 8910 8911 8912 | | | | | * | SEEK C DATA T AT THE | ON DRIVE A TO CYLIM TO CYLINDER 100, TR | H DRIVE A AND DRIVE B. ISSUE A NDER 1. IMMEDIATELY ISSUE A WRITE RACK O, HEAD O ON DRIVE B. TRANSFER NO ERRORS SHOULD ATTENTION SET. |
| | 8913 8914 | | | | | * | REPEAT | FOR ALL COMBINATI | ONS OF TWO DRIVES. |
| | 8915 8916 8917 8918 | | | | | * | NOTE: | TEST WILL NOT BE | |
| | 8919 8920 | 031174 031176 | 000004 012737 | 000005 | 001262 | 151110: | SCOPE MOV | #5.,\$TIMES | ;;DO 5. ITERATIONS |
| | 8921 8922 8923 8924 8925 | 031204 031212 031216 031220 | 012737 013705 005000 005001 | 177777 001354 | 001224 | 2\$: | MOV MOV CLR | #-1,\$TMP1 \$DEVM,R5 R0 R1 | :SET LOOP CONTROL FLAG :GET DEVICE MAP :CLEAR FOR DRIVE #A |
| | 8924 8925 8926 8927 8928 8928 | 031220 031222 031226 031232 031240 | 012703 012704 012737 000555 | 000001 000001 031242 | 001110 | | MOV MOV MOV BR | | CLEAR FOR DRIVE #B SET DRIVE POSITION A SET DRIVE POSITION B SET LOCAL LOOP ON ERROR GO SET UP POINTERS |

| | | K 13 | |
|--------|--|--------------------------|--|
| MACY11 | | 15:17 PAGE OPERATIONS | |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 18-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) T110 | 28-AUG- | -81 15:17 PAGE PED OPERATIONS | 167 |
|--|--|--|--|------------------|------------------|---|--|--|
| 8930 8931 8932 | 031242 031242 031244 | 104416 104003 | | | 3\$: | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 8934 8935 8936 8937 | 031252 | 010037 010037 004737 012737 | 036134 | 001600 | | MOV MOV JSR MOV | RO.DRVNUM RO.L.CS2 PC.GTYPO #RECAL.L.CS1 | STORE DRIVE FOR REPORT SETUP DRIVE A TO RECAL |
| 8931 8932 8933 8934 8935 8936 8937 8938 8939 8941 8942 8943 | 031270 031272 031274 031276 | 104417 104423 104002 005037 | 001662 | | | TLOADRK TWAT16 ERROR CLR | 2 INTSET | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CLEAR INTERRUPT FLAG |
| 8944 8945 | | 104437 104002 | | | | TWAT8S ERROR | 2 | :WAIT FOR SECOND INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8946 8947 8948 8949 8950 | 031306 031314 031316 031320 | 012737 104417 104423 104002 | 000105 | 001600 | 4\$: | TLOADRK | | :SET UP TO CLEAR DRIVE :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8948 8949 8950 8951 8952 3953 8954 8955 8956 8957 8958 8959 | 031314 031316 031320 031322 031322 031324 031336 031336 031342 031342 031352 | 104421 104004 032737 001372 010137 010137 004737 012737 | 001626 | | 43: | TCHKOP ERROR BIT BNE MOV MOV JSR MOV | 4 :OR 5, 6, 7 #DI.T.CS1 4\$ R1.DRVNUM R1.L.CS2 PC.GTYP1 #RECAL.L.CS1 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS :TEST IF DI STILL SET :YES - LOOP :STORE DRIVE FOR REPORT :SETUP DRIVE B TO RECAL |
| 8961 8962 8963 8964 8965 8966 8967 8968 | 031362 031364 031366 031372 031374 031404 031406 031410 | 104417 104423 104002 005037 104437 104002 012737 104417 104423 104002 | 001662 000105 | | | TWAT8S ERROR MOV TLOADRK TWAT16 | 2 INTSET 2 #CLEAR,L.CS1 | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR :CLEAR INTERRUPT FLAG :WAIT FOR SECOND INTERRUPT :TO SLOW/NOT COMPLETE ERROR :SET UP DRIVE CLEAR :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8972 8973 8974 8975 | 031412 031412 031414 031416 031424 | 104421 104004 032737 001372 | 040000 | 001540 | 5\$: | TCHKOP ERROR BIT BNE | 4 :OR 5, 6, 7 #DI.T.CS1 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS :TEST IF DI STILL SET :YES - LOOP |
| 8969 8970 8971 8972 8973 8974 8975 8976 8977 8978 8979 8980 8981 8982 8983 | 031426 031432 031436 031442 031450 | 010037 010037 004737 012737 012737 | 001626 001610 036134 000001 000117 | 001614 001600 | | MOV MOV JSR MOV MOV | RO.DRVNUM RO.L.CS2 PC.GTYPO #1.L.DCYL #SEEK,L.CS1 | STORE DRIVE FOR REPORT SETUP DRIVE A TO SEEK TO CYL 1 |
| 8982 8983 8984 8985 | 031456 031460 031462 | 104417 104423 104002 | | | | TLOADRK TWAT16 ERROR | | :LOAD RK REGS :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |

| CZROKGU | | 8-AUG-81 | 15:16 | | 1110 | | PED OPERATIONS | 108 |
|--|--|--|--|--------------------------------------|-------|---|--|---|
| 8986 8987 8988 8989 8990 8991 8992 8993 | 031464 031470 031474 031500 031506 031514 031522 | 010137 010137 004737 012737 012737 012737 012737 | 001626 001610 036150 000100 177400 072414 000123 | 001614 001602 001604 001600 | | MOV MOV JSR MOV MOV MOV MOV | R1,DRVNUM R1,L.CS2 PC,GTYP1 #100,L.DCYL #-400,L.WC #OBUFF,L.BA #WRDATA,L.CS1 | STORE DRIVE FOR REPORT SETUP DRIVE B TO WRITE DATA AT CYL 100 :400 WORDS |
| 8994 8995 | 031530 | 104417 | | | | TLOADRK | | ;LOAD RK REGS-DO WRITE |
| 8996 8997 8998 | 031532 031534 | 104427 104002 | | | | TWAT80 ERROR | 2 | :WAIT FOR INTERRUPT :TO SLOW/NOT COMPLETE ERROR |
| 8999 9000 9001 9002 | 031536 031540 | 104421 104004 | | | | TCHKOP ERROR | 4 ;OR 5, 6, 7 | :CHECK OPERATION FOR ANY ERRORS :REPORT ALL ERRORS |
| 9003 9004 9005 9006 9007 9008 | 031542 031546 031552 031554 031562 031570 | 010037 130337 001007 012737 012737 104011 | 001626 001557 056630 050362 | 001460 061112 | | MOV BITB BNE MOV MOV ERROR | RO.DRVNUM R3.T.ASOF+1 10\$ #EMDA.EM11N #EMSK.DF011A | STORE DRIVE FOR REPORT CHECK IF DRIVE ATTENTION IS DRIVE A YES-SKIP ''DRIVE ATTENTION NOT SET RESULT OF SEEK'' |
| 9009 9010 9011 | 031572 | 104415 | | | 10\$: | SCOP1 | | ;LOCAL LOOP TO 3\$ |
| 9012 9013 9014 9015 9016 9017 9018 9019 9020 | | | | | | OF DRIVI LOWEST I B. THE THE LOW! AS A. | ES AVAILABLE. TH NUMBER DRIVE AS A SECOND PASS SWAP EST NUMBER DRIVE THE FORTH PASS SI | ES THE TEST TO BE RUN ON EVERY COMBINATION HE FIRST PASS OF THE PROGRAM WILL USE THE A AND THE NEXT HIGHER NUMBER DRIVE AS PS DRIVE A & B. THE THIRD PASS USES AS B AND THE 3RD HIGHEST NUMBER DRIVE WAPS A & B AGAIN. THIS CONTINUES EEN TESTED WITH THE LOWEST NUMBER |
| 9021 9022 9023 | | | | | | THE SECO | OND HIGHEST NUMBE | ER DRIVE IS THEN USED AS A AND THE EY ARE SWAPPED ON THE NEXT PASS. |
| 9024 9025 | | | | | 1 | THIS TEC | | NUED UNTIL ALL COMBINATIONS ARE |
| 9027 9028 9029 | 031574 031600 | 005237 001024 | 001224 | | 11\$: | INC BNE | \$TMP1 16\$ | :INCREMENT PASS CONTROL :SKIP IF NOT ZERO :(IT WILL BE ZERO ON THE 1ST PASS) |
| 9031 9032 | 031602 031604 | 030305 001006 | | | 12\$: | BIT | R3.R5 13\$ | :TEST IF BIT POSITION FOR A AT AVAIL DRIVE :YES-SKIP |
| 9024 9025 9026 9027 9028 9029 9030 9031 9032 9033 9034 9035 9036 9037 9038 9039 | 031606 031610 031612 031616 031620 | 005200 006303 032703 001771 000464 | 000400 | | 22\$: | INC ASL BIT BEQ BR | R0 R3 #BIT8,R3 12\$ 50\$ | ;BUMP RO (DRIVE A) ;SHIFT DRIVE SELECT BIT ONE POSITION ;IF BIT 8 IS SET, ALL DRIVES HAVE ;BEEN CHECKED; IF NOT CHECK NEXT POSITION ;DONE-EXIT |
| 9040 9041 | 031622 031624 | 010001 010304 | | | 13\$: | MOV MOV | R0.R1 R3.R4 | SET DRIVE B TO THE SAME AS A |
| | | | | | | | | |

```
CZR6KGO RK6 FCTNL CTRL DIAG
                                 MACY11 30(1046) 28-AUG-81 15:17 PAGE 170
              28-AUG-81 15:16
                                         END OF PASS ROUTINE
CZR6KG-P11
        031772
031772
                                          SFOP:
                                                  SCOPE
 9099
                000004
                005037
                         001102
 9100
        031774
                                                  CLR
                                                           $TSTNM
                                                                           :: ZERO THE TEST NUMBER
                         001262
  9101
        032000
                005037
                                                           $TIMES
                                                                           :: ZERO THE NUMBER OF ITERATIONS
                                                  CLR
                005237
 9103
        032004
                                                                           :: INCREMENT THE PASS NUMBER
                                                  INC
                                                           $PASS
        032010
                         100000
                                001304
                                                           #100000, $PASS
                                                                           :: DON'T ALLOW A NEG. NUMBER
                                                  BIC
  9104
        032016
                005327
                                                           (PC)+
                                                                           ::L00P?
                                                  DEC
  9105
        032020
                                          SEOPCT: . WORD
                000001
 9106
        032022
                003063
                                                                           ::YES
                                                  BGT
                                                           $DOAGN
                                                           (PC)+,@(PC)+
                                                                           :: RESTORE COUNTER
        032024
                                                  MOV
  9108
        032026
                000001
                                          SENDCT: . WORD
                                                  SEOPCT
  9109
        032030
                032020
                                                          64$
 9110
        032032
                         032040
                                                                           :: TYPE ASCIZ STRING
                104401
                                                  TYPE
                                                          <12><15>/END PASS #/
        032036
  9111
                000407
                                                  BR
                                          ::65$:
  9112
                                                  .ASCIZ
  9113
        032056
                                          645:
        032056
                                                                           :: SAVE $PASS FOR TYPEOUT
                013746
 9114
                         001304
                                                           $PASS,-(SP)
                                                                           :: TYPE PASS NUMBER
  9115
 9116
        032062 032064
                                                  TYPDS
                104405
                                                                           :: GO TYPE--DECIMAL ASCII WITH SIGN
                                                          66$
                104401
                         032072
                                                  TYPE
                                                                           :: TYPE ASCIZ STRING
  9118
        032070
                000421
                                                  BR
                                                                            :: GET OVER THE ASCIZ
                                          ::67$:
  9119
                                                          / TOTAL ERRORS SINCE LAST REPORT /
                                                  .ASCIZ
  9120
        032134
  9121
        032134
                013746
                         001112
                                                  MOV
                                                           SERTTL, - (SP)
                                                                           :: SAVE SERTTL FOR TYPEOUT
                                                                           :: TOTAL NUMBER OF ERRORS
  9122
 9123
9124
9125
        032140
032142
032146
                                                                           :: GO TYPE--DECIMAL ASCII WITH SIGN
                                                  TYPDS
                104405
                104401
                                                  TYPE
                                                           .SCRLF
                         001273
                                                                           :: TYPE CARRIAGE RETURN, LINE FEED
                005037
                         001112
                                                  CLR
                                                           SERTTL
                                                                           :: CLEAR ERROR TOTAL
  9126
9127
        032152
                013700
                         000042
                                         $GET42: MOV
                                                           a#42.RO
                                                                           :: GET MONITOR ADDRESS
        032156
                001405
                                                  BEQ
                                                           $DOAGN
                                                                            ;;BRANCH IF NO MONITOR
  9128
        032160
                000005
                                                                           :: CLEAR THE WORLD
                                                  RESET
  9129
        032162
                                          SENDAD: JSR
                004710
                                                           PC, (RO)
                                                                           :: GO TO MONITOR
                                                                           :: SAVE ROOM
  9130
        032164
                000240
                                                  NOP
  9131
        032166
                000240
                                                  NOP
                                                                           ::FOR
  9132
        032170
                000240
                                                  NOP
                                                                           ::ACT11
 9133
        032172
                                          $DOAGN:
 9134
9135
        032172
                000137
                                                          a(PC)+
                                                                           :: RETURN
                032202
        032174
                                          $RTNAD: . WORD
                                                           TSTAPT
                            377
  9136
        032176
                                    000
                                          $ENULL: .BYTE
                                                           -1,-1,0
                                                                           :: NULL CHARACTER STRING
                032202
122737
  9137
                                                   EVEN
        032202
032210
032212
                                                          #APTENV, SENV
                                                                           ; RUNNING UNDER APT MODE ?
  9138
                         000001
                                 001316
                                          TSTAPT: CMPB
  9139
                001007
                                                  BNE
                                                           2$
                                                                           :BRANCH IF NOT
  9140
                023727
                                                                           : TWO PASS DONE ?
                         001304
                                 000002
                                                  CMP
                                                           $PASS,#2
  9141
        032220
                103403
                                                           2$
                                                                           :BRANCH IF NOT
                                                  BLO
        032222
032226
032230
                005237
 9142
9143
                                                                           :INCREMENT TEST NUMBER
                         001102
                                                           $TSTNM
                                                  INC
                                                                           ; WAITING LOOP FOR APT DUMP THE NEXT PROG
                                                  BR
                                                           1$
  9144
                000137
                         003150
                                                           NEWPAS
                                                  JMP
                                                                            REPEAT THE SAME TEST IF NOT UNDER APT
  9145
                                          .SBITL ROUTINE TO SIZE MEMORY
  9146
                                          9147
  9148
                                          : * CALL:
                                         :*
  9149
                                                  JSR
                                                          PC,$SIZE
  9150
                                                  RETURN
  9151
                                          ; *$LSTAD WILL CONTAIN:
  9152
                                                  WITH KT11 OPTION
                                                                         -- LAST VIRTUAL ADDRESS OF THE LAST BANK
```

WITHOUT KT11 OPTION

-- LAST ABSOLUTE ADDRESS OF AVAILABLE MEMORY

9153

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 171
CZR6KGO RK6 FCTNL CTRL DIAG
                                                                                   ROUTINE TO SIZE MEMORY
CZR6KG.P11
                             28-AUG-81 15:16
   9154
9155
                                                                                    :* $LSTBK WILL CONTAIN THE LAST BANK AS A SAF
                                                                                    : * $KT11 IS THE MEMORY MANAGEMENT KEY
   9156 9157
                                                                                    :*BITO7 = 0 DON'T USE MEMORY MANAGEMENT
                                                                                                    MUST BE SETUP BEFORE THE CALL
                                                                                   *BIT15 = 0 DON'T HAVE MEMORY MANAGEMENT OPTION
   9158
   9159
                                                                                                    DETERMINED BY ROUTINE
   9160
                032234
                                                                                                                     RO,-(SP)
                                                                                                                                                      :: SAVE RO ON THE STACK
:: SAVE R1 ON THE STACK
   9161
                                010046
                                                                                   $SIZE: MOV
                032236
                                                                                                                     R1,-(SP)
                                 010146
                                                                                                    MOV
    9162
                                                                                                                    R2,-(SP)
R3,-(SP)
A#114,-(SP)
A#116,-(SP)
#116,A#114
#RII,A#116
                                 010246
                                                                                                                                                      :: SAVE R2 ON THE STACK
    9163
                                                                                                    MOV
               032242
032244
032250
032254
                                                                                                                                                      SAVE R3 ON THE STACK
   9164
                                 010346
                                                                                                    MOV
    9165
                                 013746
                                                  000114
                                                                                                    MOV
                                                                                                                                                      :: SAVE MEMORY ERROR VECTOR PS & PC
                                013746
012737
012737
013746
                                                  000116
                                                                                                    MOV
    9166
                                                  000116
                                                                  000114
                                                                                                    MOV
   9167
                                                                                                                                                      :: IGNORE PARITY ERRORS WHILE SIZING
               032262
032270
032274
                                                                                                    MOV
                                                                  000116
    9168
                                                  200000
                                                                                                                     @#ERRVEC,-(SP) ;; SAVE PRESENT ERROR VECTOR PS & PC @#ERRVEC+2,-(SP)
                                                                                                    MOV
   9169
                                                  000004
    9170
                                 013746
                                                  000006
                                                                                                    MOV
                                                                                   MOV SP.RO :: SAVE THE STACK POINTER :: SET THE ERRYEC PS TO THE PRESENT PS
   9171
                032300
                                 010600
    9172
                                                                                                                    ;;PUSH OLD PSW AND PC ON STACK
(SP)+,@#ERRVEC+2 ;;SAVE THE PSW IN @#ERRVEC+2
#3776,R1 ;;SETUP ADDRESS
(PC)+ ;;USE MEMORY MANAGEMENT?
200 ;;SET TO USE MEMORY MANAGEMENT
   9173
                032302
                                                                                                    TRAP
                                 104400
                032304
                                 012637
   9174
                                                  000006
                                                                                                    MOV
   9175
                032310
                                 012701
                                                  003776
                                                                                                    MOV
   9176
                032314
                                 105727
                                                                                                    TSTB
                032316
032320
                                                                                   $KT11:
                                                                                                                   SCORE

#$KINEX.@#ERRVEC

#$KINEX.@#ERRVEC

#$1 FOR TIMEOUT

#$RO

#$1 FOR TIMEOUT

#$100000,$KIT11

#$1 FOR 'PAR' LOADING

#$1 FOR LOAD EIGHT 'PAR.'S' AND EIGHT 'PDR.'S'

#$1 LOAD EIGHT 'PAR.'S' AND EIGHT 'PDR.'S'

#$1 LOAD 'PAR'

#$200,(SP)

#$1 LOAD 'PAR'

#$200,(SP)

#$1 LOOP UNTIL ALL EIGHT ARE LOADED

#$1 FOR LOAD 'PAR'

#$200,(SP)

#$2 SETUP KIPAR FOR I/O

#$2 SETUP KIPAR FOR TESTING

#$2 SETUP KIPAR FOR TESTING
   9177
                                 000200
                                                                                                    . WORD
                                 100062
   9178
                                                                                                    BP
                                                  032460 177572
                                                                   000004
   9179
                032322
                                 012737
                                                                                                    MOV
   9180
                032330
                                 005737
                                                                                                    TST
    9181
                032334
                                 052737
                                                  100000
                                                                  032316
                                                                                                    BIS
                032342
                                 005046
    9182
                                                                                                    CLR
                                 012702
                                                  172340
    9183
                                                                                                    MOV
                032350
    9184
                                                                                                    MOV
                032354
                                                  077406 177740 18:
    9185
                                 012762
                                                                                                    MOV
                                011622
                032362
032364
    9186
9187
                                                                                                    MOV
                                 062716
077307
                                                  000200
                                                                                                    ADD
                032370
    9188
                                                                                                    SOB
                                 012742
005042
012737
    9189
                032372
                                                  177600
                                                                                                    MOV
    9190
                032376
                                                                                                    CLR
    9191
                032400
                                                  032416 000004
                                                                                                    MOV
                                                                                                                                                      :: ENABLE 22 BIT MODE
:: THIS PDP-11 HAS A SR3 REGISTER
    9192
                032406
                                 012737
                                                  000020
                                                                 172516
                                                                                                    MOV
                                                                                                                     #20,@#SR3
    9193
                032414
                                 000401
                                                                                                                     3$
                                                                                                    BR
                                                                                                                    (SP)+,(SP)+ ;;CLEAN OFF THE STACK--NO SR3

@#SR0 ;:TURN ON MEMORY MANAGEMENT

#$KTOUT,@#ERRVEC ;;SET FOR TIME OUT

@#143776 ;;TRAP ON NON-EX-MEM

#40,(R2) ;;MAKE A 1K STEP
                                022626
    9194
                032416.
                                                                                                    CMP
                032420
032424
032432
032436
    9195
                                                  177572
                                                                                   3$:
                                                                                                     INC
                                 012737
                                                 032450
143776
                                                                  000004
    9196
                                                                                                    MOV
    9197
                                 005737
                                                                                                     TST
                                 062712
023712
    9198
                                                  000040
                                                                                                    ADD
                                                  172356
    9199
                032442
                                                                                                                     a#KIPAR7, (R2)
                                                                                                                                                      ::LAST ONE?
                                                                                                    CMP
                                 101371
    9200
                032446
                                                                                                    BHI
                                                                                                                     4$
                                                                                                                                                      ::NO--TRY IT
                                                                                                                     (R2),R2
@#SR0
                                                                                                                                                      :: GET LAST BANK+1
    9201
                032450
                                 011202
                                                                                   SKTOUT: MOV
                                                                                                                                                       :: TURN OFF MEMORY MANAGEMENT
    9202
                032452
                                 005037
                                                  177572
                                                                                                    CLR
                                 000421
042737
012737
005002
                032456
    9203
                                                                                                                     SSIZEX
                                                                                                    BR
                                                                                                                    #100000, $KT11 ;; KT11 NON-EXISTENT
#$CROUT, @#ERRVEC ;; SET FOR TIMEOUT
R2 ;; SET UP BANK
    9204
9205
                                                                  032316
                                                                                   SKINEX: BIC
                032466
032474
                                                  032516
                                                                                   SCORE:
                                                                                                    MOV
    9206
                                                                                                    CLR
                                                                                                                     #4000.R1
#40.R2
                                                                                                                                                      :: INCREMENT BY 1K
                                 062701
062702
                032476
032502
    9207
                                                  004000
                                                                                                    ADD
                                                                                    15:
                                                                                                                                                       :: 1K STEP .
    9208
                                                  000040
                                                                                                                                                       :: TRAP ON TIME OUT
                                 005711
```

```
CZR6KGO RK6 FCTNL CTRL DIAG
                                        MACY11 30(1046) 28-AUG-81 15:17 PAGE 172
CZR6KG.P11 28-AUG-81 15:16
                                                   ROUTINE TO SIZE MEMORY
                    022701
  9210
         032510
                              177776
                                                                       #177776.R1
                                                                                            ::LAST ONE
  9211
         032514
                                                             BNE
                                                                       15
                                                                                            ::NO--TRY AGAIN
         032516
032522
032526
032530
  9212
                    162701
162702
                                                                       #4000,R1
#40,R2
                              004000
                                                   $CROUT: SUB
                                                                                           :: DROP BACK
                                                                       (SP)+, a#ERRVEC+2'; RESTORE ERROR VECTOR
                              000040
                                                   $SIZEX: SUB
  9214
                    010006
012637
                                                             MOV
                              000006
                                                             MOV
  9216
9217
         032534
                    012637
                              000004
                                                             MOV
         032540
                    012637
                              000116
                                                             MOV
                                                                       (SP)+,0#116
                                                                                            :: RESTORE MEMORY ERROP VECTOR
                              000114
                                                                       (SP)+, 0#114
R1,$LSTAD
  9218
         032544
                    012637
                                                             MOV
         032550
  9219
                    010137
                                                             MOV
                                                                                            :: LAST ADDRESS
         032554
                    010237
  9220
                              032574
                                                             MOV
                                                                                           :: LAST BANK
                                                                       R2, $LSTBK
                   012603
         032560
                                                             MOV
                                                                       (SP) + R3
                                                                                            :: RESTORE R3
         032562
                    012602
                                                                       (SP)+,R2
                                                           MOV
                                                                                           :: RESTORE R2
                   012601
012600
         032564
                                                                       (SP)+,R1
                                                             MOV
                                                                                            :: RESTORE R1
         032566
032570
032572
  9224
                                                             MOV
                                                                       (SP)+,R0
                                                                                            :: RESTORE RO
                    000207
                                                             RTS
                                                                       PC
  9226
                    000000
                                                  $LSTAD: . WORD
                                                                       0
                                                                                            :: CONTAINS THE LAST ADDRESS
  9227
9228
9229
9230
                                                  $LSTBK: .WORD O .SBTTL SCOPE HANDLER ROUTINE
         032574
                    000000
                                                                                           :: CONTAINS THE LAST BANK
                                                  **THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT :*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>) :*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08> :*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
  9231
  9233
9234
9235
9236
9237
                                                   : *SW14=1
                                                                       LOOP ON TEST
                                                   : *SW11=1
                                                                       INHIBIT ITERATIONS
                                                   : *SW09=1
                                                                       LOOP ON ERROR
  9238
                                                   : *SW08=1
                                                                       LOOP ON TEST IN SWR<7:0>
  9239
                                                   : *CALL
  9240
                                                             SCOPE
                                                                                 ::SCOPE=IOT
  9241
  9242
         032576
                                                  $SCOPE:
  9243
         032576
                  104407
                                                  CKSWR :: TEST FOR CHANGE IN SOFT-SWR :: GO TO ERROR ROUTINE IF RETURN PC LESS THAN 1002
  9244
9245
                                                   ::OTHERWISE CONTINUE
  9246
9247
9248
9249
9250
         032600
                             001002
                   021627
                                                             CMP
                                                                       (SP),#1002
                                                                                           :: UNEXPECTED TRAP OR INTERRRUPT
                                                                                           :: ARE TRAPPED HERE VIA TOT
         032604
                    101002
                                                                       1$
                                                             BHI
                                                                                           :: GO PRUCESS UNEXPECTED TRAP
         032606
                    000137
                              033614
                                                             JMP
                                                                       $ERROR
         032612
                   032777
                                                                                          ::LOOP ON PRESENT TEST?
::YES IF SW14=1
                              040000 146320 1$:
                                                                       #BIT14, aSWR
                                                             BIT
         032620
                   001131
                                                                       $OVER
                                                             BNE
  9251
9252
9253
9254
                                                   #####START OF CODE FOR THE XOR TESTER####
                                                                                          :: IF RUNNING ON THE 'XOR' TESTER CHANGE
:: THIS INSTRUCTION TO A 'NOP' (NOP=240)
:: SAVE THE CONTENTS OF THE ERROR VECTOR
:: SET FOR TIMEOUT
         032622
                   000416
                                                   $XTSTR: BR
                                                                       6$
         032624
                    013746
                              000004
                                                             MOV
                                                                       @#ERRVEC,-(SP)
                   012737
005737
012637
000500
022626
012637
                              032650
  9255
         032630
                                        000004
                                                                       #5$, a#ERRVEC
a#177060
                                                             MOV
         032636
032642
032646
032650
  9256
                                                                                            ;; TIME OUT ON XOR?
                                                             TST
  9257
9258
9259
                              000004
                                                             MOV
                                                                       (SP)+, a#ERRVEC
                                                                                           :: RESTORE THE ERROR VECTOR
                                                                                           .. GO TO THE NEXT TEST
                                                             BR
                                                                       $SVLAD
                                                                                            :: CLEAR THE STACK AFTER A TIME OUT
                                                             CMP
                                                 .58:
                                                                       (SP)+,(SP)+
         032652
  9260
                              000004
                                                             MOV
                                                                       (SP)+, @#ERRVEC :: RESTORE THE ERROR VECTOR
                                                  68: #####END OF CODE FOR THE XOR TESTER####
  9261
         032656
                    000440
  9262
         032660
                                                                       #B!T08, aSWR
  9263
         032660
                    032777
                              000400 146252
                                                            BIT
                                                                                          :: LOOP ON SPEC. TEST?
         032666
                    001421
  9264
                                                                                           :: BR IF NO
                                                             BEQ
         032670
                    005046
                                                                       -(SP)
                                                                                           :: CLEAR A TEMP. LOCATION
                                                             CLR
```

CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 173 CZR6KG.P11 28-AUG-81 15:16 SCOPE HANDLER ROUTINE

| | | 0 400 01 | | | | | 00.1.12 | |
|--|--|--|--|----------|----------|------------|--------------------------|---|
| 9266 | 032672 | 117716 | 146242 000110 001102 033122 001106 001103 | | | MOVB | aswR.(SP) | ::PICKUP THE DESIRED TEST NUMBER |
| | 032676 | 001414 | , 102 12 | | | BEQ | 8\$ | ;;BRANCH IF BAD TEST NUMBER IN SWR ;;CHECK THE NUMBER IN THE SWR ;;BRANCH IF TEST NUMBER IS OUT OF RANGE ;;UPDATE THE TEST NUMBER |
| 9267 9268 9269 9270 9271 9272 9273 9274 9275 | 032700 | 022716 | 000110 | | | CMP | #110,(SP) | ;; CHECK THE NUMBER IN THE SWR |
| 9269 | 032704 | 002411 | | | | BLT | 85 | ;;BRANCH IF TEST NUMBER IS OUT OF RANGE |
| 9270 | 032706 032712 | 011637 | 001102 | | | MOV | (SP), \$TSTNM | ;;UPDATE THE TEST NUMBER |
| 9271 | 032712 | 005316 | | | | DEC | (SP) (SP) | ::BACKUP BY ONE ::SCALE THE TEST NUMBER AS AN INDEX ::FORM THE ADDRESS OF TEST POINTER |
| 9272 | 032714 | 006316 | 077100 | | | ASL | (SP) | ;; SCALE THE TEST NUMBER AS AN INDEX |
| 92/3 | 032716 | 002/10 | 033122 | | | MOV | #\$5WU81BL,(5P) | CET LOOP ADDRESS OF TEST POINTER |
| 9275 | 032722 032726 | 000466 | 001100 | | | MUV | a(SP)+,\$LPADR \$OVER | ::SET LOOP ADDRESS TO DESIRED TEST ::GO LOOP ON THE TEST |
| 9276 | 032730 | 005726 | | | 84. | TST | (SP)+ | CLEAN THE BAD TEST NUMBER OFF OF THE STACK |
| 9277 | 032732 | 105737 | 001103 | | 28: | TSTB | SERFI G | :: HAS AN ERROR OCCURRED? |
| 9276 9277 9278 | 032736 | 001421 | 001.03 | | | BEQ | 3\$ | ;;GO LOOP ON THE TEST ;;CLEAN THE BAD TEST NUMBER OFF OF THE STACK ;;HAS AN ERROR OCCURRED? ;;BR IF NO |
| 9279 | 032740 | 123737 | 001115 | 001103 | | CMPB | SERMAX, SERFLG | :: MAX. ERRURS FUR THIS TEST ULLURRED! |
| 9280 | 032746 | 101015 | | | | BHI | 3\$ | ;;BR IF NO |
| 9281 | 032750 | 032777 | 001000 | 146162 | | BIT | 3\$ #BIT09, @SWR | ;;LOOP ON ERROR? |
| 9282 9283 | 032756 | 001404 013737 | 001110 | 001104 | 70 | BEQ | 4\$ | ;;BR IF NO |
| 9283 | 032760 | 013/3/ | 001110 | 001106 | 13: | MOV | \$LPERR, \$LPADR | :: SET LOOP ADDRESS TO LAST SCOPE |
| 9284 9285 | 032766 032770 | 000446 105037 | 001107 | | / . | BR | \$OVER | TEDO THE EDDOD ELAC |
| 9286 | 032774 | 005037 | 001262 | | 45. | CLRB | STIMES | CLEAR THE NUMBER OF ITERATIONS TO MAKE |
| 9287 | 033000 | 000415 | 001202 | | | BR | 15 | FSCAPE TO THE NEXT TEST |
| 9288 | 033002 | 032777 | 004000 | 146130 | 3\$: | BIT | #BIT11 aSWR | ::INHIBIT ITERATIONS? |
| 9289 | 033010 | 001011 | | | | BNE | 1\$ | ::BR IF YES |
| 9290 | 033012 | 001011 | 001304 | | | IST | \$PASS | ;; IF FIRST PASS OF PROGRAM |
| 9291 | 033016 | 001406 | | | | BEQ | 1\$ | ;; INHIBIT ITERATIONS |
| 9286 9287 9288 9289 9290 9291 9292 9293 9294 9295 9296 9297 9298 9299 9300 9301 | 033002 033010 033012 033016 033020 033024 033032 | 005237 023737 | 001104 | 001104 | | INC | \$ICNT | ::ZERO THE ERROR FLAG ::CLEAR THE NUMBER OF ITERATIONS TO MAKE ::ESCAPE TO THE NEXT TEST ::INHIBIT ITERATIONS? ::BR IF 'ES ::IF FIRST PASS OF PROGRAM :: INCREMENT ITERATION COUNT ::CHECK THE NUMBER OF ITERATIONS MADE ::BR IF MORE ITERATION REQUIRED ::REINITIALIZE THE ITERATION COUNTER ::SET NUMBER OF ITERATIONS TO DO ::COUNT TEST NUMBERS ::SET TEST NUMBERS ::SAVE SCOPE LOOP ADDRESS ::CLEAR THE ESCAPE FROM ERROR ADDRESS ::ONLY ALLOW ONE(1) ERROR ON NEXT TEST ::DISPLAY TEST NUMBER |
| 9293 | 033024 | 023/3/ | 001262 | 001104 | | CMP | \$11MES,\$1CN1 | ;; CHECK THE NUMBER OF ITERATIONS MADE |
| 9294 | 033034 | 002024 012737 013737 105237 113737 | | | | BGE | DUVER #1 CICNIT | DEINITIALIZE THE LIEDATION COUNTED |
| 9295 | 033034 | 013737 | 000001 033120 | 001104 | 15: | MOV MOV | CMYCHT CTIMES | SET NUMBER OF ITERATIONS TO DO |
| 9297 | 033042 | 105237 | 001102 | | \$SVLAD: | INCR | STSTAM | ·· COUNT TEST NUMBERS |
| 9298 | 033054 | 113737 | 001102 | 001302 | | MOVB | SISTNM STESTN | ::SET TEST NUMBER IN APT MAILBOX |
| 9299 | 033062 | 01165/ | 001106 | 001302 | | MOV | (SP), \$LPADR | ::SAVE SCOPE LOOP ADDRESS |
| 9300 | 033066 | 011637 | 001110 | | | MCV | (SP), \$LPERR | ::SAVE ERROR LOOP ADDRESS |
| 9301 | 033072 | 005037 | 001264 | | | CLR | \$ESCAPE | :: CLEAR THE ESCAPE FROM ERROR ADDRESS |
| 9302 | 033076 | 112737 | 000001 | CIIIIO | | MOVB | #1.SERMAX | ;;ONLY ALLOW ONE (1) ERROR ON NEXT TEST |
| 9303 | 033104 | 013777 | 001102 | 146030 . | SOVER: | MOV | SISINM, ODISPLAY | ;;DISPLAY TEST NUMBER |
| 9304 9305 | 033112 | 013716 | 001106 | | | MCV RTI | \$LPADR, (SP) | ::FUDGE RETURN ADDRESS ::FIXES PS |
| 9306 | 033120 | 003720 | | | SMXCNT: | | | :: MAX. NUMBER OF ITERATIONS |
| 9307 | 033122 | 003.20 | | | \$5W081B | | | ,, max. Nonsen of Tremations |
| 9308 | 033122 | 003164 | | | | . WORD | TST1+2 | ::STARTING ADDRESS OF TEST 1 |
| 9309 | 033124 | 003302 | | | | . WORD . | TST2+2 | ::STARTING ADDRESS OF TEST 2 |
| 9310 | 033126 | 003370 | | | | . WORD | 1513+2 | ::STARTING ADDRESS OF TEST 3 |
| 9311 | 033130 | 004620 | | | | . WORD | 1514+2 | ::STARTING ADDRESS OF TEST 4 |
| 9312 | 033132 | 004726 | | | | . WORD | ISI5+2 | ::STARTING ADDRESS OF TEST 5 |
| 9313 | 033134 | 005104 | | | | . WORD | 1516+2 | ::STARTING ADDRESS OF TEST 6 |
| 9314 9315 | 033136 | 005232 | | | | . WORD | TST7+2 | STARTING ADDRESS OF TEST 7 |
| 9316 | 033142 | 006262 | | | | .WORD | TST10+2 TST11+2 | ::STARTING ADDRESS OF TEST 10 ::STARTING ADDRESS OF TEST 11 |
| 9317 | 033144 | 006400 | | | | .WORD | 15112+2 | STARTING ADDRESS OF TEST 12 |
| 9318 | 033146 | 006516 | | | | WORD | TST13+2 | ::STARTING ADDRESS OF TEST 13 |
| 9319 | 033150 | 006760 | | | | .WORD | TST14+2 | ::STARTING ADDRESS OF TEST 14 |
| 9320 | 033152 | 007112 | | | | . WORD | TST15+2 | ::STARTING ADDRESS OF TEST 15 |
| 9321 | 033154 | 007322 | | | | . WORD | 15116+2 | ::STARTING ADDRESS OF TEST 16 |
| | | | | | | | | |

```
SCOPE HANDLER ROUTINE
CZR6KG.P11
                  28-AUG-81 15:16
          033156
                     007512
                                                                 . WORD
                                                                 . WORD
          033162
033164
033166
033170
033172
033174
033176
  9324
9325
9326
9327
9328
                     010514
                                                                . WORD
                                                                . WORD
                     011324
                                                                 . WORD
                                                                 . WORD
                     011666
                                                                 . WORD
                     012020
012176
012330
                                                                 . WORD
                                                                 . WORD
          033200
                                                                 . WORD
          033202
033204
033206
033210
033214
                     012624 013020
  9332
                                                                 . WORD
                                                                 . WORD
  9333
                                                                 . WORD
                     013254
  9334
                     013442
013674
014062
014304
014472
                                                                 . WORD
  9335
                                                                 .WORD
.WORD
.WORD
  9336
9337
  9338
          033216
                                                                 . WORD
  9339
          033220
                     014664
015060
015264
  9340
          033222
                                                                . WORD
  9341
          033224
                                                                 . WORD
  9342 9343
          033226
                                                                 . WORD
          033230
                     015470
                                                                 . WORD
          033234
033236
033240
033244
033246
                     016330
                                                                 . WORD
  9344
                     016534
                                                                . WORD
  9345
                     016740
017156
  9346
                                                                . WORD
  9347
                                                                . WORD
                                                                . WORD
  9348
                     017362
                                                                . WORD
                     017566
  9349
                                                                . WORD
  9350
                     017712
                                                                . WORD
          033250
  9351
                     020036
                                                                . WORD
  9352
          033252
                     020162
                                                                . WORD
  9353
          033254
                     020306
020432
                                                                . WORD
          033256
  9354
          033260
033262
                     020504
  9355
                                                                . WORD
  9356
9357
                     020564
                                                                . WORD
          033264
                     021050
                                                                . WORD
  9358
          033266
033270
                     021232
                                                                . WORD
  9359
                     021420
                                                                . WORD
                     022124
  9360
          033272
                                                                 . WORD
          033274
  9361
                                                                 . WORD
          033276
033300
033302
033304
033310
                     022446 023070
  9362
                                                                . WORD
  9363
                                                                . WORD
  9364
9365
                     023512
                                                                . WORD
                     023622
024470
025162
025404
                                                                . WORD
                                                                . WORD
  9366
                                                                . WORD
  9367
                                                                . WORD
          033312
  9368
                                                               . WORD
                     025662 025742
          033314
  9369
                                                                . WORD
          033316
   9370
                                                                . WORD
          033320
033322
  9371
                     026134
                                                                .WORD
.WORD
.WORD
                     026360
   9372
                     026506
027030
027562
030024
030250
          033324
   9373
          0333326
0333330
0333332
   9374
  9375
                                                                . WORD
  9376
                                                                . WORD
```

. WORD

MACY11 30(1046) 28-AUG-81 15:17 PAGE 174

CZR6KGO RK6 FCTNL CTRL DIAG

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 175
                                                                                            TST107+2
TST110+2
SEOP+2
ABTFAIL+2
::STARTING ADDRESS OF TEST 107
::STARTING ADDRESS OF TEST 110
:ADDRESS OF END OF PASS
ABORT FAILURE HANDLER
                                                                                  . WORD
           033336 030470
   9379 033340 031176
                                                                                  . WORD
                                                                                  . WORD
   9380
           033342 031774
   9381
9382
             033344 044172
                                                                                 . WORD
   9383
                                                                .SBITL APT COMMUNICATIONS ROUTINE
   9384
   9385
                                                                                                #1.$FFLG :: TO REPORT FATAL ERROR
#1.$MFLG :: TO TYPE A MESSAGE
$ATYC
             033346 112737 000001 033612 $ATY1: MOVB
033354 112737 000001 033610 $ATY3: MOVB
   9386
   9387
            033362
033364
033372
033372
                          000403
   9388
                                                                                   BR
                                                                                                #1, $FFLG :: TO ONLY REPORT FATAL ERROR
   9389
9390
                                        000001 033612 $ATY4: MOVB
                                                                     SATYC:
                                                                                           RO.-(SP) ::PUSH RO ON STACK
R1.-(SP) ::PUSH R1 ON STACK
SMFLG ::SHOULD TYPE A MESSAGE?
5$ ::IF NOT: BR
   9391
                           010046
                                                                                  MOV
                           010146
   9392
                                                                                  MOV
             033376
                                        033610
                                                                                 TSTB
                                                                                               $MFLG ;:SHOULD TYPE A MESSAGE?

$$ ;:IF NOT: BR

#APTENV,$ENV ;:OPERATING UNDER APT?

$$ ;:IF NOT: BR

#APTSPOOL,$ENVM ;:SHOULD SPOOL MESSAGES?

$$ ;:IF NOT: BR

$4(SP),RO ;:GET MESSAGE ADDR.

#2,4(SP) ;:BUMP RETURN ADDR.

$MSGTYPE ;:SEE IF DONE W/ LAST XMISSION?

$$ ;:IF NOT: WAIT

R0,$MSGAD ;:PUT ADDR IN MAILBOX

(R0)+ ;:FIND END OF MESSAGE
   9394
             033402
                           001450
                                                                                  BEQ
   9395
             033404
                           122737
                                        000001 001316
                                                                                 CMPB
             033412
                           001031
   9396
                                                                                  BNE
   9397
             033414
                           132737 000100 001317
                                                                                  BITB
             033422
   9398
                           001425
                                                                                  BEQ
                                        000004
000002
001276
            033424
   9399
                           017600
                                                                                  MOV
                           062766
005737
   9400
                                                                                  ADD
                                                                    15:
             033436
   9401
                                                                             TST
                           001375
                                                                                               1$
RO,$MSGAD
             033442
   9402
                                                                                  BNE
                           010037 001312
105720 2$:
   9403
             033444
                                                                                   MOV
   9404
             033450
                                                                                  TSTB
                                                                                                2$
   9405
             033452
                           001376
                                                                                   BNE
                                                                                                $MSGAD,RO
                                                                                                $MSGAD,RO ;:SUB START OF MESSAGE
RO ::GET MESSAGE LNGTH IN WORDS
RO,$MSGLGT ;:PUT LENGTH IN MAILBOX
#4,$MSGTYPE ;:TELL APT TO TAKE MSG.
   9406 9407
             033454
                           163700 001312
                                                                                  SUB
            033460
033462
033466
033474
                           006200
010037
012737
                                                                                  ASR
   9408
                                         001314
                                                                                  MOV
                                        000004 001276
   9409
                                                                                  MOV
                          000413
   9410
                                                                                   BR
                                                                                                5$
                                                                                               a4(SP),4$
#2,4(SP)
177776,-(SP)
                                                                                                                           ::PUT MSG ADDR IN JSR LINKAGE
::BUMP RETURN ADDRESS
::PUSH 177776 ON STACK
::CALL TYPE MACRO
                                        000004 033922 3$:
000002 000004
177776
   9411
             033476
                                                                                  MOV
   9412 9413
             033504
                           062766
                                                                                  ADD
                           013746 004737
                                       044202

4$:

5$:

10$:
             033512
                                                                                  MOV
                                                                              JSR
                                                                                                PC, STYPE
   9414
             033516
                                                                                 . WORD
   9415
             033522
                           000000
             033524
   9416
                                                                                              $FFLG ::SHOULD REPORT FATAL ERROR?

12$ ::IF NOT: BR

$ENV ::RUNNING UNDER APT?

12$ ::IF NOT: BR

$MSGTYPE ::FINISHED LAST MESSAGE?
   9417
             033524
                           105737
                                                                             TSTB
                                                                                 TSTB $FFLG ::SHOULD REPORT FATAL ERROR?
BEQ 12$ ::IF NOT: BR
TST $ENV ::RUNNING UNDER APT?
BEQ 12$ ::IF NOT: BR
TST $MSGTYPE ::FINISHED LAST MESSAGE?
BNE 11$ ::IF NOT: WAIT
MOV : 04(SP),$FATAL ::GET ERROR #
ADD #2.4(SP) ::BUMP RETURN ADDR.
INC $MSGTYPE ::TELL APT TO TAKE ERROR
CLRB $FFLG ::CLEAR EATAL FLAG
CLRB $MFLG ::CLEAR LOG FLAG
CLRB $MFLG ::CLEAR MESSAGE FLAG
MOV (SP)+.R1 ::POP STACK INTO R1
MOV (SP)+.R0 ::POP STACK INTO R0
RTS PC ::RETURN
             033530
   9418
                           001416
             033532
                           005737
   9419
             033536
   9420
                           001413
                                                     11$: TST
   9421
             033540
                           005737
                                         001276
                           001375
   9423
             033546
                           017637
                                         000004 001300
                           062766 000002
005237 001276
105037 033612
105037 033611
105037 033610
   9424 9425
             033554
                                         000002 000004
             033562
                                                                    12$: CLRB
             033566
033572
033576
   9426
9427
   9428
                                                                                MOV (SP)+,R1
MOV (SP)+,R0
RTS PC
.BYTE 0
.BYTE 0
   9429 9430
                           012601
             033602
             033604
                                                                                                                           ::RETURN
::MESSG. FLAG
::LOG FLAG
   9431
                           000207
             033606
                                                        SMFLG: BYTE
    9432
             033610
                                000
             033611
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 176
CZR6KGO RK6 FCTNL CTRL DIAG
               28-AUG-81 15:16
ZR6KG.P11
                                            APT COMMUNICATIONS ROUTINE
 9434
9435
9436
9437
        033612
                                            SFFLG: .BYTE
                                                                                 :: FATAL FLAG
                 033614
                                            APTSIZE=200
                 000001
                                            APTENV=001
 9438
9439
                 000100
                                            APTSPOOL=100
                 000040
                                            APTCSUP=040
 9440
                                            .SBITL ERROR HANDLER ROUTINE.
  9441
 9442
  9443
                                            ** THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
  9444
                                            ** SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
  9445
                                            : *AND GO TO TYPERR ON ERROR
 9446
                                            :*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW15=1 HALT ON ERROR
                                                              HALT ON ERROR
  9447
  9448
                                            : *SW13=1
                                                               INHIBIT ERROR TYPEOUTS
  9449
                                            : *SW10=1
                                                              BELL ON ERROR
 9450
                                            : *SW09=1
                                                              LOOP ON ERROR
 9451
                                            : * CALL
  9452
                                                     ERROR
                                                                       :: ERROR=EMT AND N=ERROR ITEM NUMBER
  9453
 9454
        033614
                                            SERROR:
                 104407
105237
001775
 9455
        033614
                                                     CKSWR
                                                                                :: TEST FOR CHANGE IN SOFT-SWR
        033616
 9456
                          001103
                                                              SERFLG
                                                     INCB
                                                                                :: SET THE ERROR FLAG
 9457 9458
        033622
                                                     BEQ
                                                              7$
                                                                                :: DON'T LET THE FLAG GO TO ZERO
        033624
                 013777
                          001102
                                  145310
                                                              $TSTNM. aDISPLAY :: DISPLAY TEST NUMBER AND ERROR FLAG
                                                     MOV
                 032777
 9459
        033632
                          002000
                                   145300
                                                     BIT
                                                              #BIT10, aSWR
                                                                                :: BELL ON ERROR?
 9460
        033640
                 001402
                                                              15
                                                     BEQ
                                                                                :: NO - SKIP
 9461
        033642
                 104401
                          001266
                                                     TYPE
                                                               . $BELL
                                                                                :: RING BELL
 9462
        033646
                 005237
                          001112
                                            15:
                                                     INC
                                                              SERTTL.
                                                                                :: COUNT THE NUMBER OF ERRORS
 9463
        033652
                 011637
                          001116
                                                     MOV
                                                              (SP) . SERRPC
                                                                                :: GET ADDRESS OF ERROR INSTRUCTION
                 162737
 9464
        033656
                          000002
                                   001116
                                                     SUB
                                                              #2.SERRPC
                 117737
 9465
        033664
                          145226
                                   001114
                                                     MOVB
                                                              a$ERRPC,$ITEMB
                                                                                :: STRIP AND SAVE THE ERROR ITEM CODE
 9466
        033672
                 032777
                          020000
                                   145240
                                                     BIT
                                                              #BIT13, aSWR
                                                                                :: SKIP TYPEOUT IF SET
 9467
        033700
                 001055
                                                     BNE
                                                              20$
                                                                                :: SKIP TYPEOUTS
 9468
        033702
                 021627
                          001002
                                                     CMP
                                                              (SP),#1002
                                                                                :: IF RETURN PC LESS THAN 1002
 9469
        033706
                 101046
                                                     BHI
                                                              12$
                                                                                 :: ERROR IS ILLEGAL TRAP
 9470
                                            :: PROCESS UNEXPECTED TRAP OR INTERRUPT
 9471
        033710
                 016637 162737
                          000004
                                   001116
                                                     MOV
                                                              4(SP), SERRPC
                                                                                :: GET PC AT TIME OF FALSE TRAP
                          000002
        033716
 9472
                                   001116
                                                     SUB
                                                              #2, SERRPC
                                                                                :: ADJUST PC
 9473
        033724
                 104401
                                                     TYPE
                                                               .10$
                                                                                :: TYPE HEADER
       033730
033734
033736
                 013746
 9474
                          001116
                                                     MOV
                                                              SERRP(,-(SP)
                                                                                :: SAVE SERRPC FOR TYPEOUT
 9475
                 104402
                                                     TYPOC
                                                                                :: GO TYPE--OCTAL ASCII(ALL DIGITS)
 9476
9477
                 104401
                          033776
                                                     TYPE
                                                               .11$
        033742
                 162716
                          000004
                                                     SUB
                                                              #4. (SP)
                                                                                :: GET FALSE TRAP VECTOR ADDR
 9478
        033746
                 011637
                          001116
                                                     MOV
                                                              (SP) , SERRPC
 9479
        033752
                 013746
                          001116
                                                     MOV
                                                              SERRPC .- (SP)
                                                                                :: SAVE SERRPC FOR TYPEOUT
        033756
 9480
                 104402
                                                     TYPOC
                                                                                :: GO TYPE--OCTAL ASCII(ALL DIGITS)
        033760
 9481
                 104401
                          001273
                                                     TYPE
                                                               SCRLF
 9482
        033764
                 022626
                                                     CMP
                                                              (SP)+,(SP)+
                                                                                :: POP FALSE TRAP VECTOR PC&ADDR
 9483
                 000422
050200
        033766
                                                     BR
                                                              20$
        033770
 9484
                                                              <200> 'PC= '
                          036503
                                   000040
                                           105:
                                                     . ASCIZ
 9485
                020040
042520
052040
047524
        033776
                          047125
                                   054105
                                           118:
                                                     .ASCIZ
                                                                UNEXPECTED TRAP TO "
 9486
        034004
                          052103
                                   042105
 9487
        034012
                          040522
                                   020120
        034020
 9488
                          000040
 9489
                                                     .EVEN
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 177
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
                                                ERROR HANDLER ROUTINE
        034024
034024
034030
  9400
                                                128:
  9491
                            034136
                   004737
                                                          JSR
                                                                   PC.TYPERR
                                                                                       :: GO TO USER ERROR ROUTINE
  9492
                   104401
                                                          TYPE
                                                                    .SCRLF
         034034
                                                20$:
  9494
         034034
                   122737
                            000001
                                      001316
                                                          CMPB
                                                                   #APTENV, SENV
                                                                                       ;; RUNNING IN APT MODE
                  001007
         034042
                                                                                       :: NO. SKIP APT ERROR REPORT
:: SET ITEM NUMBER AS ERROR NUMBER
                                                          BNE
                                                                   2$
                                                                   $ITEMB,21$
  9496
         034044
                            001114
                                      034056
                                                          MOVB
                  004737
000
000
000
000777
005777
100002
         034052
034056
034057
  9497
                            033364
                                                          JSR
                                                                   PC. SATY4
                                                                                       :: REPORT FATAL ERROR TO APT
  9498
                                                218:
                                                          .BYTE
  9499
                                                          .BYTE
         034060
034062
034066
  9500
                                                                                       :: APT ERROR LOOP
                                                225:
                                                          BR
                                                                   22$
  9501
9502
                                                                                       :: HALT ON ERROR
                            145052
                                                          TST
                                                                   DSWR
                                                                                       :: SKIP IF CONTINUE
                                                          BPL
         034070
  9503
                   000000
                                                                                       :: HALT ON ERROR!
                                                          HALT
  9504
9505
         034072
                  104407 032777
                                                          CKSWR
                                                                                       :: TEST FOR CHANGE IN SOFT-SWR
         034074
                            001000 145036
                                                                   #BITO9, aSWR
                                                          BIT
                                                                                       :: LOOP ON ERROR SWITCH SET?
  9506
         034102
                   001402
                                                                                       ::BR IF NO
::FUDGE RETURN FOR LOOPING
                                                                   45
                                                          BEQ
                                                                   SLPERR, (SP)
  9507
         034104
                   013716
                            001110
                                                          MOV
  9508
                   005737
         034110
                            001264
                                                          TST
                                                                   SESCAPE
                                                                                       :: CHECK FOR AN ESCAPE ADDRESS
  9509
         034114
                   001402
                                                          BEQ
                                                                   5$
                                                                                       :: BR IF NONE
  9510
         034116
                  013716
                            001264
                                                          MOV
                                                                   SESCAPE. (SP)
                                                                                       :: FUDGE RETURN ADDRESS FOR ESCAPE
        034122
  9511
 9512
9513
        034122 034130
                  022737 001001
                            032162 000042
                                                                   #$ENDAD . 0#42
                                                                                       :: ACT-11 AUTO-ACCEPT?
                                                                                       :: BRANCH IF NO
                                                          BNE
                                                                   6$
        034132
  9514
                  000000
                                                         HALT
                                                                                       ::YES
  9515
  9516
        034134
                  000002
                                                                                       :: RETURN
 9517
                                                .3BITL TYPE ERROR ROUTINE :*ENTRY JSR PC. TYPERR
  9518
  9519
 9520
9521
9522
9523
9524
9525
                                                : *RETURN RTS PC
                                                ** THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH :* ERROR IS TO BE REPORTED. IT THEN USES THE "ERROR TABLE" ($ERRIB)
                                                * *ENTRY TO DEFINE WHAT INFORMATION IS TO BE REPORTED CONCERNING
                                                : * THE ERROR.
  9526
                                                TYPERR: SAVREG
         034136
                 104413
  9528
                  113737
         034140
                            001102 001302
                                                         MOVB
                                                                   $TSTNM, $TESTN
                                                                                       GET TEST NUMBER FOR REPORT
                  042737
                            177400 001302
  9529
         034146
                                                         BIC
                                                                   #177400, STESTN ; CLEAR UNUSED BITS
  9530
         034154
                            001114
                                                         MOVB
                                                                   $ITEMB,RO
                                                                                       :ENTER ERROR NUMBER
  9531
         034160
                  042700
                            177400
                                                                   #177400,RO
                                                                                       CLEAR UNUSED BITS
                                                         BIC
 9532
9533
         034164
                  005300
                                                                                       FORM INDEX FOR ERROR TABLE
                                                         DEC
        034166
034170
                  006300
                                                          ASL
                                                                   RO
 9534
                  006300
                                                          ASL
 9535
         034172
                  006300
                                                          ASL
                                                                   #$ERRTB,R0
(R0)+,2$
 9536
                  062700
012037
         034174
                            001360
                                                                                       :FORM ADDRESS OF ERROR ENTRY :GET EM POINTER
                                               15:
                                                          ADD
  9537
         034200
                            034214
                                                          MOV
  9538
         034204
                  001404
                                                         BEQ
                                                                                       :BRANCH IF THERE ISN'T ONE
        034206
  9539
                   104401
                            001273
                                                                   .SCRLF
                                                                                       :TYPE CARRIAGE RETURN LINE FEED :TYPE ERROR MESSAGE (EM)
                                                          TYPE
  9540
         034212
                   104401
                                                          TYPE
        034214
034216
034222
034224
034230
  9541
                  000000
                                                          . WORD
                                                                                       EM POINTER GOES HERE
 9542
9543
                  012037
                            034232
                                                                   (RO)+,4$
                                                          MOV
                                                                                       GET DH POINTER
                  001404
                                                         BEQ
                                                                   5$
                                                                                       :BRANCH IF THERE ISN'T ONE
                                                                                       TYPE CR-LF
  9544
                   104401
                            001273
                                                          TYPE
                                                                   . SCALF
                   104401
                                                                                       : TYPE DATA HEADER
```

| CZR6K60 RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) | 28-AUG-81 15:17 PAGE | 178 |
|---|----------------------------------|--|---|
| 9546 034232 000000 9547 034234 012001 9548 034236 001445 9549 034240 005004 9550 034242 012000 9551 034244 012002 9552 034246 104401 001273 9553 034252 112003 9554 034254 105720 | 4\$: 5\$: | TYPE SCOLE | ; DH POINTER GOES HERE ; GET DT POINTER ; BRANCH IF THERE ARE NONE ; SET INDENT SWITCH ; GET DF POINTER ; STORE NUMBER OF DH'S |
| 9547 034234 012001 9548 034236 001445 9549 034240 005004 9550 034242 012000 9551 034244 012002 9552 034246 104401 001273 9553 034252 112003 9554 034254 105720 9555 034260 001416 9557 034262 005704 9558 034264 001004 9559 034266 013146 9560 034270 104402 9561 034272 005303 9562 034274 001403 9563 034276 104401 051053 9564 034302 000771 9565 034304 104401 001273 9566 034310 005710 9567 034312 001401 9568 034314 005104 9569 034316 005302 9570 034320 003414 9571 034322 012037 034342 9572 034326 001751 9573 034330 005704 9574 034332 001402 9575 034334 104401 051053 | 108:. | MOVB (RO)+,R3 TSTB (RO)+ TST R3 BEQ 14\$ TST R4 BNE 12\$ | GET & STORE NUMBER OF DATA WORDS BUMP PAST FORMAT WORD TEST IF ANY DATA FOR THIS HEADER NO - SKIP DATA PRINT CHECK FOR INDENT YES, GO INDENT PUT FIRST DATA WORD ON STACK |
| 9559 034266 013146 9560 034270 104402 9561 034272 005303 9562 034274 001403 | 118: | DEC R3 | PUT FIRST DATA WORD ON STACK TYPE IT MORE DATA WORDS NO-BRANCH |
| 9563 034276 104401 051053 | 125: | TYPE SPACE2 | : TYPE SEPARATORS |
| 9564 034302 000771 9565 034304 104401 001273 9566 034310 005710 9567 034312 001401 | 13\$: | TYPE ,\$CRLF IST (RO) BEQ 14\$ | :LOOP :TYPE <cr><lf> :CHECK IF NEXT HEADER AVAILABLE :NO, DO NOT CHANGE INDENT</lf></cr> |
| 9568 034314 005104 9569 034316 005302 | 14\$: | COM R4 DEC R2 | :CHANGE INDENT :MORE DH'S? |
| 9567 034312 001401 9568 034314 005104 9569 034316 005302 9570 034320 003414 9571 034322 012037 034342 9572 034326 001751 9573 034330 005704 | 15\$: | MOV (RO)+,18\$ BEQ 10\$ TST R4 | :MORE DH'S? :NO-BRANCH :GET NEXT DH POINTER :IF O GET DATA :INDENT? |
| 9574 034332 001402 9575 034334 104401 051053 9576 034340 104401 9577 034342 000000 9578 034344 104401 001273 | 17 \$: 18 \$: | TYPE ,SPACE2 | :NO, BRANCH :TYPE INDENT :TYPE DH :DH POINTER GOES HERE |
| 9579 034350 000740 9580 034352 104414 9581 034354 005237 001632 9582 034360 032777 010000 | 20 \$: | BR 10\$ RESREG INC ERRONT | GET DATA :INCREMENT THE ERROR COUNT |
| 9583 034366 001421 | | BEQ 25\$ | ; CHECK IF SWITCH 12 SET ; NO, RETURN |
| 9584 034370 022737 000024 9585 034376 103015 | 001632 | CMP #20., ERRCNT BHIS 25\$ | :CHECK IF ERROR THRESHOLD EXCEEDED :NO, RETURN |
| 9586 034400 104401 053317 9587 | | TYPE .ABORT | :TYPE 'PROGRAM ABORTED BECAUSE :ERROR THRESHOLD EXCEEDED' |
| 9588 034404 005737 000042 9589 034410 001407 | | TST 42 | CHECK IF CHAIN MODE |
| 9590 034412 012706 001100 9591 034416 012737 000001 9592 034424 000137 031772 | 032020 | MOV #STACK, SP MOV #1, \$EOPCT JMP \$EOP | :NO. HALT PROCESSOR :INITIALIZE STACK :FORCE END OF PROGRAM |
| 9593 034430 000000 9594 034432 000207 9595 9596 9597 9598 9599 | 22\$: 25\$: .SBTTL | THIS IS THE INDICATION T | ITERRUPT FLAG AND DOES AN RII. |
| 9600 034434 005237 001662 9601 034440 000002 | NEXINT: | INC INTSET | BUMP THE INTERRUPT COUNTER |

CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 179
CZR6KG.P11 28-AUG-81 15:16 NON-EXISTANT MEMORY AND INTERRUPT CHECK HANDLER

| | 9602 9603 9604 9605 9606 9607 9608 | | | | | SBTTL | MOST IN PROCESS PROGRAM | ING AS A RESULT (| RK611 ARE HANDLED BY THIS ROUTINE. ACTUAL OF THE INTERRUPT IS LEFT TO THE MAIN UST SETS A FLAG TO INDICATE THE |
|--|--|--|---|--|--|------------------|--|---|--|
| | 9609 9610 9611 | 034442 034444 034450 | 000240 005237 000002 | 001662 | | INTHLR: | NOP INC RII | INTSET | :BUMP THE INTERRUPT FLAG :RETURN. |
| 9613 9613 9614 9616 9616 9616 9616 9616 9616 9616 | 9613 9614 9615 | | | | | .SBTTL | MEMORY I | PARITY ERROR TRAF PARITY TRAPS WILL CLUDE THE PC AT | P HANDLER BE REPORTED BY THIS ROUTINE. THE REPORT TIME OF FAILURE AND ABORT THE PROGRAM. |
| | 9617 9618 9619 9620 9621 9622 9623 | 034452 034460 034462 034466 034470 034476 034502 | 032777 001003 104401 104402 012737 012706 000137 | 020000 053546 000001 001100 031772 | 032020 | PERHLR: | BIT BNE TYPE TYPOC MOV MOV JMP | #BIT13, aSWR 1\$.EM3 #1,\$EOPCT #STACK,SP \$EOP | :TEST IF INHIBIT REPORT :YES - SKIP :TYPE PARITY ERROR MESSAGE :AND PC VALUE :FORCE END OF PROGRAM :CLEAN OFF STACK |
| | 9625 9626 9627 | | | | | .SBTTL | THE LIN | | NDLER T HANDLER WILL INCREMENT THE LCLKTK R) EACH TIME AN INTERRUPT OCCURS. |
| | 9629 9630 9631 | 034506 034512 034520 | 005237 042777 000002 | 001674 000200 | 145170 | LCKHLR: | INC BIC RTI | #BIT7, @KWLADD | ; INCREMENT CLOCK TICK COUNTER ; CLEAR MONITOR BIT |
| | 9633 9633 9635 9635 9636 9637 9638 9643 9644 9644 9644 9644 9644 9644 9645 9651 9653 9654 | | 104413 013746 013746 012737 012737 005037 005737 000240 000240 000240 0012737 052737 052737 000507 | 000004 000006 034754 000340 001670 000100 170200 177770 | 000004 000006 001664 001664 001664 | SBITL OPTIST: | THIS ROLLINE CL | OCK ARE ON THE SY SE, AND THE APPRO | SETUP THE MEMORY PARITY OPTION AND THE YSTEM. FLAGS ARE SET IF PRESENT: CLEARED OPRIATE INTERRUPT VECTORS ARE SET UP. ;STORE OLD NEM CONTENTS ;DET INTERRUPT FOR NEM ;SET PRIORITY ;CLEAR PARITY WORD FLAGS ;CLEAR PARITY PRESENT FLAG ;TEST IF EITHER 11/70 OR 11/44 ;NOW SEE IF IT'S 11/70 ;SET POINTER FOR 11/70 ;SET 11/70 FLAG ;SET PARITY PRESENT FLAG ;GO TO VECTOR SETUP |
| | 9656 9657 | 034626 034632 | 013703 012704 | 001714 | | 3\$: | MOV MOV | MEMBAS,R3 #1,R4 | SET UP POINTER TO FIRST PARITY (SR :INIT MASK |
| | | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCT P11 2 | NL CTRL 8-AUG-81 | | MACY11 | 30(1046) OPTION | 28-AUG PRESENT | K 14 5-81 15:17 PAGE TEST AND SETUP | 180 |
|--|--|--|--|--------|-------------------------|--|--|--|
| 9658 9659 9660 9661 9662 9663 9664 | 034636 034642 034644 034650 034654 034656 | 012713 005713 052713 032713 001061 050437 | 000001 000002 000002 001670 | | 6\$: | MOV TST BIS BIT BNE BIS BIT | #1,(R3) (R3) #BIT1,(R3) #BIT1,(R3) 47\$ R4,MEMPAR #PARPRE,OPTFLG | :SET PARITY DETECT IN THAT CSR :IS THIS ECC MEMORY? :YES - EXIT :SET PARITY PRESENT BIT :WAS PARITY PRESENT SET BEFORE |
| 9665 9666 9667 9668 9669 9670 | 034662 034666 034672 034676 | 013700 012720 012710 012700 | 001716 034766 000340 072640 | | | BNE MOV MOV MOV | 10\$ MMVECA,RO #40\$,(RO)+ #PR7,(RO) #OBUFF+224,RO | :YES - SKIP :SET UP FOR PARITY TRAPS : TO 40\$:SET POINTER TO BUFFER WHERE BAD PARITY : IS USED IN THE TESTS |
| 9671 9672 9673 9674 9675 9676 9677 9678 | 034702 034706 034712 034716 034720 034726 034732 | 012713 012710 012713 005710 042737 012713 012710 | 000004 177777 000001 000100 000002 000000 | 001664 | • | MOV MOV TST BIC MOV MOV BIC | #BIT2,(R3) #-1,(R0) #1,(R3) (R0) #PARPRE,OPTFLG #2,(R3) #0,(R0) #7,(R3) | :SET TO WRITE WRONG PARITY :WRITE WORD BAD :SET TO DETECT PARITY ERROR :READ BAD WORD :REV 005 :TRUN OFF CZR ERROR ENABLE :CLEAR BAD PARITY :REV 006 |
| 9680 9681 9682 9683 9684 9685 9686 | 034736 034740 034744 034746 034750 034752 | 000442 062703 000241 006104 001332 000434 | 000002 | | 10\$: | MOV BR ADD CLC ROL BNE BR | #0 (R0) 35\$ #2,R3 R4 6\$ 35\$ | :REV 006 :REV 005 :BUMP TO NEXT CSR :SHIFT MASK :TEST IF ALL DONE :YES - SKIP |
| 9687 9688 9689 9690 | 034754 034756 034764 | 022626 012737 000720 | 035040 | 000004 | 20\$: | CMP MOV BR | (SP)+,(SP)+ #30\$,ERRVEC 3\$ | :CLEAR STACK :SET NEW NEM TRAP ADDRESS :GO TO CSR CHECKS |
| 9691 9692 9693 9694 9695 9696 | 034766 034770 034774 035002 035006 035012 035016 | 022626 010337 052737 012713 012710 012713 000412 | 001672 000100 000000 000000 000001 | 001664 | 40\$: | CMP MOV BIS MOV MOV MOV BR | (SP)+,(SP)+ R3,(SRPTR #PARPRE,OPTFLG #0,(R3) #0,(R0) #1,(R3) 35\$ | CLEAR STACK SET CSR POINTER FOR CSR TO BE USED SET PARITY PRESENT FLAG TURN OFF CSR ERROR ENABLE WRITE GOOD PARITY SET TO DETECT PARITY ERRORS EXIT |
| 9698 9699 9700 9701 9702 9703 9704 9705 9706 9707 9708 | 035020 035024 035032 035036 035040 035042 035044 035050 035054 | 012713 042737 005037 000402 022626 000736 013700 005737 001004 032737 | 000000 000100 001670 001716 001670 002000 | 001664 | 47\$: 30\$: 35\$: | MOV BIC CLR BR CMP BR MOV TST BNE BIT | #0,(R3) #PARPRE,OPTFLG MEMPAR 35\$ (SP)+,(SP)+ 10\$ MMVECA,RO MEMPAR 37\$ #CP1170,OPTFLG | CLEAR CSR FORGET THEM ALL FORGET THEM ALL EXIT CLEAR STACK GO CHECK NEXT CSR SET UP POINTER TO PARITY VECTOR TEST IF ANY PARITY PRESENT YES - SKIP TEST IF 11/70 |
| 9709 9710 9711 9712 9713 | 035064 035066 035072 035076 035100 | 001405 012720 012710 000403 012720 | 034452 000340 000116 | | 37\$: 39\$: | BEQ MOV MOV BR MOV | 39\$ #PERHLR,(R0)+ #PR7,(R0) 38\$ #116,(R0)+ | :NO - SKIP :SET UP PARITY VECTOR :SET PRIORITY :ELSE RESTORE TRAP CATCHER |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 181
CZR6KGO RK6 FCTNL LTRL DIAG
               28-AUG-81 15:16
                                             OPTION PRESENT TEST AND SETUP
CZR6KG-P11
        035104
                 005010
                                                               (RO)
                  012737
                                                                                 SET UP NEM VECTOR FOR LINE CLOCK TEST
  9715
        035106
                          034434
                                            38$:
                                                               #NEXINT, ERRVEC
                                    000004
                                                      MOV
                          001662
  9716
                  005037
        035114
                                                                                 :CLEAR INTERRUPT COUNTER
                                                      CLR
                                                               INTSET
                 013700
        035120
                                                      MOV
                                                               KWL VEC, RO
                                                                                 SET POINTER TO VECTOR
                 012720
                          034506
  9718
        035124
                                                      MOV
                                                               #LCKHLR, (RO)+
                                                                                 ; INSERT ADDRESS OF INTERRUPT HOLR
        035130
  9719
                  012710
                           000340
                                                      MOV
                                                               #PR7.(RO)
                                                                                 :INSERT PRIORITY
  9720
        035134
                 012777
                          000100
                                   144546
                                                      MOV
                                                               #BIT6. aKWLADD
                                                                                 :LOAD KW11-L FOR INTERRUPT ENABLE
  9721
        035142
                  000240
                                                      NOP
 9722
9723
9724
9725
                 000240
000240
005737
        035144
                                                      NOP
        035146
035150
035154
                                                      NOP
                                                                                 : TEST IN NEM ON KW11-P REFERENCE
                          001662
                                                      TST
                                                               INTSET
                 001003
                                                               45
                                                                                 :THIS BRANCH WILL BYPASS SET UP OF
  9726
9727
                                                                                 : CLOCK OPTION
        035156
                                                               #LCLKPR, OPTFLG
                           100000
                                   001664
                                                      BIS
                                                                                 :SET CLOCK PRESENT FLAG
  9728
        035164
                  012701
                          000006
                                                               #6.R1
                                             45:
                                                      MOV
                                                                                 :RESTORE OLD VECTOR
                           001662
  9729
        035170
                  005037
                                                      CLR
                                                               INTSET
                                                                                 :CLEAR INT FLAG
                                                               (SP)+,ERRVEC+2
  9730
                 012637
        035174
                           000006
                                                      MOV
  9731
        035200
                 012637
                          000004
                                                               (SP)+, ERRVEC
                                                      MOV
                 012746
        035204
  9732
                          000000
                                                      MOV
                                                               #PRO,-(SP)
                                                                                 :RESTORE PRIORITY TO 0
        035210
035214
  9733
                          035216
                                                      MOV
                                                               #12$,-(SP)
  9734
9735
                  000002
                                                      RTI
        035216
                                             12$:
  9736
        035216
                                                      RESREG
                  104414
  9737
        035220
                 000207
                                                      RIS
  9738
9739
  9740
                                             . SBITL
                                                      LOOP ON INTERNAL ERROR
  9741
                                                      THIS ROUTINE IS USED TO PROVIDE TIGHT SCOPE LOOPS. THE CALLER
                                             :*
  9742 9743
                                                      IS EXPECTED TO SET SLPERR TO THE START OF THE SCOPE LOOP
                                                      TO BE EXECUTED ON ERROR.
  9744
        035222
  9745
                 032777
                                  143710
                                             SCOP1$: BIT
                                                               #SW9, aSWR
                          001000
                                                                                 CHECK IF LOOP ON ERROR
  9746
                  001405
                                                               5$
                                                      BEQ
                                                                                 :NO. CONTINUE
  9747
        035232
                  105737
                                                      TSTB
                                                               $ERFLG
                           001103
                                                                                 : CHECK IF ERROR OCCURRED
  9748
        035236
                  001402
                                                      BEQ
                                                               5$
                                                               $LPERR, (SP)
  9749
        035240
                  013716
                          001110
                                                      MOV
                                                                                 :LOAD ERROR RETURN
  9750
        035244
                  000002
                                                                                 : RETURN
                                                      RTI
  9751
                                             . SBITL
                                                      LINE CLOCK CALIBRATE
  9752
9753
9754
9755
                                                      WAITS FOR A LINE CLOCK INTERRUPT TO CALIBRATE THE INTERRUPTS
                                                      TO A MEANINGFUL TIME VALUE. IN ADDITION IT PRESETS
                                                      THE TIMENT IF THERE IS NO LINE CLOCK. TIMENT IS USED IN THE
                                                      LINE CLOCK SIMULATOR.
  9756
9757
        035246 035252
                 005037
032737
                                                                                 CLEAR TICK COUNTER : TEST IF CLOCK PRESENT
                           001674
                                             CLKCAL: CLR
                                                               LCLKTK
  9758
                           100000
                                    001664
                                                      BIT
                                                               #LCLKPR, OPTFLG
                                                                                 :YES - SKIP
  9759
        035260
                  001004
                                                      BNE
                                                               1$
                 012737
000410
005737
        035262
035270
  9760
                                                               #16., TIMENT
                                                                                 ELSE PRESET TIMENT
                           000020
                                   001654
                                                      MOV
  9761
                                                      BR
                                                               2$
                                                                                 : AND EXIT
  9762
9763
        035272
035276
                                                                                 : TEST IF INTERRUPT HAS OCCURRED
                           001662
                                             15:
                                                      TST
                                                               INTSET
                  001005
                                                      BNE
                                                                                 : YES- ABORT CALIBRATION
                                                               2$
  9764
         035300
                  005737
                                                      TST
                                                                                 :WAIT FOR CLOCK TICK
                           001674
                                                               LCLKTK
                 001772
  9765
         035304
                                                      BEQ
                                                                                 :NOT YET - LOOP
                                                               15
        035306
                  005037
  9766
                           001674
                                                      CLR
                                                                                 :CLEAR TICK COUNT
                                                               LCLKTK
         035312
  9767
                  000207
                                                                        : RETURN
                                             2$:
                                                      RTS
  9768
  9769
                                             . SBITL
                                                    LINE CLOCK SIMULATION ROUTINE .
```

```
28-AUG-81 15:16
CZR6KG.P11
                                              LINE CLOCK SIMULATION ROUTINE
  9770
                                                        THIS ROUTINE IS USED TO SIMULATE THE LINE CLOCK. TO
                                                        DO THIS THE VALUE STORED IN MILCAT IS USED AS THE
  9772
9773
                                                        BASE AND REPRESENTS THE NUMBER OF TIMES A DECREMENT
                                                        AND BRANCH LOOP CAN BE DONE IN 1 MILLISECOND. THE TIMENT VALUE IS DECREMENTED AND IF IT REACHED 0 THE
  9774
  9775
                                                       LINE CLOCK TICK COUNTER IS BUMPED. THEN THE TIMENT IS RESET TO 16 (REPRESENTS 16 MILLISECONDS PER LINE CLOCK
  9776
                                                        TICK).
  9778
  9779
                                                        THUS THE ROUTINE RETURNS TO THE CALLER AFTER 1 MILLISECOND
  9780
                                                        AND BUMPS THE LINE CLOCK TICK COUNTER FOR EACH 16 CALLS.
  9781
  9782
  9783
         035314
                                              MYTIME: MOV
                  010046
                                                                 RO.-(SP)
                                                                                    : SAVE RO
                  013700
  9784
         035316
                            001652
                                                        MOV
                                                                 MILCNT, RO
                                                                                    :SET COUNT
                  005737
  9785
         035322
                           001662
                                              15:
                                                        TST
                                                                 INTSET
                                                                                    : TEST IF INTERRUPT SET
  9786
         035326
                  001012
                                                        BNE
                                                                 2$
                                                                                    : YES - SKIP
        035330
  9787
                  005300
001373
                                                        DEC
                                                                                    :DECREMENT COUNT TO ZERO
                                                                 RO
  9788
         035332
                                                        BNE
                                                                 1$
  9789
        035334
                  005337
                           001654
                                                                 TIMENT
                                                        DEC
                                                                                    :DECREMENT TIMENT
                                                                                    :IF NOT ZERO - EXIT
:ELSE BUMP TICK COUNTER
  9790
         035340
                  001005
                                                        BNE
                                                                 2$
  9791
         035342
                  005237
                            001674
                                                        INC
                                                                 LCLKTK
                                                                 #16. TIMENT
                  012737
  9792
         035346
                                                                                    :RESET TIME COUNT
                           000020
                                     001654
                                                        MOV
  9793
         035354
                                                        MOV
                                                                 (SP)+,R0
                                                                                    :RESTORE RO
  9794
         035356
                  000207
                                                        RIS
                                                                                    : RETURN
  9795
  9796
                                               . SBITL
                                                        WAIT FOR INTERRUPT ROUTINE
  9797
                                                        THE ROUTINE IS ENTERED BY ONE OF FOURTEEN TRAP CALLS. THE CALL
  9798
                                                        SPECIFIES HOW MANY TICKS OF THE LINE CLOCK ARE TO ELAPSE
  9799
                                                        WHILE WAITING FOR INTERRUPT. IF INTERRUPT DOES NOT OCCUR
  9800
                                                        IN THAT PERIOD OF TIME, AN ERROR MESSAGE IS PREPARED (BUT NOT PRINTED IN THE ROUTINE) AND THEN RETURNS TO THE
  9801
  9802
                                                        LOCATION FOLLOWING THE CALL. IF INTERRUPT OCCURS THE
  9803
                                                        RETURN IS BUMPED BY 2. NORMALLY AN ERROR CALL WILL
  9804
                                                        BE IN THE LOCATION AFTER THE CALL TO INTERRUPT WAIT.
  9805
        035360 035362
  9806
                  104413 012700
                                              IWAT8S: SAVREG
                                                                          ; ENTRY FOR 8 SECOND WAIT
  9807
                           000764
                                                                 #500.,RO
                                                        MOV
        035366
  9808
                  000463
                                                                 WATSRT
                                                        BR
  9809
        035370
                  104413
                                              IWAT1M:
                                                       SAVREG
                                                                           ENTRY FOR 1 MIN WAIT
  9810
                  012700
         035372
                           007246
                                                        MOV
                                                                 #3750.,RO
  9811
         035376
                  000457
                                                        BR
                                                                 WATSRT
  9812
9813
        035400
                  104413
                                              IWAT2S: SAVREG
                                                                 ENTRY FOR 2 SECOND WAIT
        035402
                  012700
                           000200
                                                        MOV
                                                                 #128.,R0
  9814
         035406
                  000453
                                                                 WATSRT
                                                        BR
  9815
         035410
                  104413
                                              IWATIS: SAVREG
                                                                                    ENTRY FOR 1 SECOND WAIT
  9816
                  012700
         035412
                                                                 #63.,R0
                           000077
                                                       MOV
 9817
9818
9819
         035416
                  000447
                                                        BR
                                                                 WATSRT
        035420
035422
035426
                  104413 012700
                                              IWAT159:
                                                                 SAVREG
                                                                                    ENTRY FOR 160 MS WAIT
                           000012
                                                                 #10.,R0
                                                        MOV
  9820
                  000443
                                                        BR
                                                                 WATSRT
  9821
         035430
                  104413
                                              IWAT144:
                                                                 SAVREG
                                                                                    ENTRY FOR 144 MS WAIT
  9822
9823
         035432
                  012700
                           000011
                                                        MOV
                                                                 #9. .RO
         035436
                  000437
                                                        BR
                                                                 WATSRT
         035440
                  104413
                                              IWAT128:
                                                                 SAVREG
                                                                                   :ENTRY FOR 128 MS WAIT
         035442
                  012700
                           000010
                                                        MOV
                                                                 #8. .RO
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 182

CZR6KGO RK6 FCTNL CTRL DIAG

```
MACY11 30(1046) 28-AUG-81 15:17
                                                                           PAGE 183
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11
               28-AUG-81 15:16
                                             WAIT FOR INTERRUPT ROUTINE
                                                               WATSRT
        035446
                 000433
  9827
        035450
                                             IWAT112:
                  104413
                                                               SAVREG
                                                                                 :ENTRY FOR 112 MS WAIT
                 012700
                                                               #7.RO
WATSRT
        035452
  9828
                           000007
                                                      MOV
  9829
9830
9831
                  000427
        035456
        035460
035462
                 104413 012700
                                             IWAT96: SAVREG
                                                                                 ENTRY FOR 96 MS WAIT
                           000006
                                                      MOV
                                                               #6.RO
        035466
035470
035472
  9832
9833
                  000423
                                                               WATSRT
                                                      RR
                  104413
                                             IWAT80: SAVREG
                                                                                 :ENTRY FOR 80 MS WAIT
  9834
                  012700
                           000005
                                                      MOV
                                                               #5.R0
  9835
        035476
                 000417
                                                               WATSRT
  9836
        035500
                  104413
                                             IWAT64: SAVREG
                                                                                 ENTRY FOR 64 MS WAIT
                                                               #4.RO
  9837
        035502
                  012700
                           000004
                                                      MOV
  9838
        035506
                  000413
                                                               WATSRT
                                                      BR
  9839
        035510
                                             IWAT48: SAVREG
                  104413
                                                                                 :ENTRY FOR 48 MS WAIT
                 012700
  9840
        035512
                           000003
                                                      MOV
                                                               #3.RO
  9841
        035516
                  000407
                                                               WATSRT
                                                      BR
  9842
9843
                 104413 012700
        035520
                                             IWAT32: SAVREG
                                                                                 ENTRY FOR 32 MS WAIT
        035522
                           000002
                                                      MOV
                                                               #2.R0
  9844
        035526
                  000403
                                                               WATSRT
                                                      BR
  9845
        035530
                  104413
                                                      SAVREG
                                             IWAT16:
                                                                                 :ENTRY FOR 16 MS WAIT
                 012700
012746
012746
  9846
        035532
                           000001
                                                      MOV
                                                               #1.R0
        035536
035542
                           000000
  9847
                                                               #PRO,-(SP)
                                             WATSRT: MOV
                                                                                 :LOAD PRIORITY O ON STACK
  9848
                                                      MOV
                                                               #5$,-(SP)
                                                                                 :LOAD ADDRESS
        035546
                  000002
  9849
                                                      RTI
  9850
        035550
035556
                 012737
004737
                                                               #16., TIMENT
  9851
                           000020
                                    001654
                                             5$:
                                                      MOV
                                                                                 ; PRESET TIME COUNTER
  9852
                           035246
                                                      JSR
                                                               PC, CLKCAL
                                                                                 GO CALIBRATE THE CLOCK
  9853
        035562
                  005737
                           001662
                                                      TST
                                                                                 : TEST IF INTERRUPT OCCURRED
                                             15:
                                                               INTSET
  9854
        035566
                 001036
                                                      BNE
                                                               3$
                                                                                  :YES - EXIT
  9855
        035570
                 032737
                                                               #LCLKPR, OPTFLG
                                                                                 : TEST IF KW11-L AVAILABLE
                           100000
                                    001664
                                                      BIT
        035576
  9856
                 001002
                                                      BNE
                                                                                 : YES - SKIP
  9857
                           035314
                                                                                 ELSE CALL SIMULATOR
        035600
                  004737
                                                               PC . MYTIME
                                                      JSR
  9858
        035604
                  023700
                                             2$:
                                                      CMP
                                                               LCLKTK, RO
                                                                                  : TEST IF ENOUGH TICKS COUNTED
  9859
        035610
                  103764
                                                      BLO
                                                                                  :NO - LOOP
  9860
        035612
                  104420
                                                      TGETRK
                                                                                 ELSE GET '611 REGS
                                                               T.CS1.R1
#177741.R1
  9861
        035614
                  013701
                                                                                 :PUT CS1 IN R1- STRIP ALL BUT
                           001540
                                                      MOV
  9862
9863
        035620
                  042701
                           177741
                                                                                 : COMMAND CODE: INDEX INTO TABLE
                                                      BIC
                                                               CMNDLB(R1), DH2N; AND SELECT HEADER TO IDENTIFY OPERATION
        035624
                  016137
                           050210
                                    001372
                                                      MOV
                                                                                 :MESSAGE (NO INTERRUPT OR INTERRUPT LATE)
        035632
                  012737
                           053616
                                    001370
  9864
                                                      MOV
                                                               #EM4,EM2N
        035640
                  013700
                           001302
                                                                                  GET NUMBER OF PRESENT TEST
  9865
                                                      MOV
                                                               STESTN, RO
        035644
  9866
                  006300
                                                                                  SHIFT FOR INDEX
                                                      ASL
                                                               RO
        035646
                 016037
162737
                                                               $SW08TB(RO), $ESCAPE : LOAD ESCAPE TO ABORT TESTS #2, $ESCAPE : BUT GO TO NEXT SCOPE CALL
  9867
                           033122
                                    001264
                                                      MOV
  9868
        035654
                                    001264
                                                      SUB
  9869
        035662
                  000402
                                                      BR
                                                               #2,(SP)
  9870
        035664
                  062716
                           000002
                                                      ADD
                                                                                 BUMP RETURN AROUND ERROR
  9871
                                                                                  : RESTORE REGS
        035670
                  104414
                                             45:
                                                      RESREG
  9872
        035672
                  000002
                                                                                  : RETURN
  9873
  9874
                                             . SBITL
                                                      "L" REGISTER LOADING ROUTINE
  9875
                                                      THE PARAMETERS FOLLOWING THE CALL ARE TRANSFERRED INTO
  9876
9877
                                                      THE "L" REGISTERS L.CS1-L.DCYL. L.MR1 IS NOT
                                                      LOADED IN THIS MANNER SINCE IT IS NOT COMMONLY LOADED
  9878
                                                      FOR AN OPERATION. L.CS2 IS LOADED FROM DRVNUM.
  9879
  9880
                                                      CALL:
                                                                        R4, LRLOAD
  9881
                                                               COMMAND
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 184
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG-P11
                                                     "L" REGISTER LOADING ROUTINE
                  28-AUG-81 15:16
  9882
9883
9884
9885
                                                                          WORD COUNT
                                                                          BUS ADDRESS
                                                                          .BYTE
                                                                                               SECTOR ADDRESS
                                                                          .BYTE
                                                                                               TRACK ADDRESS
  9886
                                                                         CYLINDER ADDRESS
  9887
         035674
035674
035676
035700
035704
  9888
                                                    LRLOAD:
  9889
9890
9891
9892
                                                                         RO,-(SP)
R1,-(SP)
#L.CS1,R1
                                                                                              :: PUSH RO ON STACK.
:: PUSH R1 ON STACK.
:GET ADDRESS OF L REGS
                    010046
                    010146
012701
012700
012421
005300
                               001600
                                                                                               : PRESET COUNT
                               000004
                                                               MOV
                                                                         #4.RO
  9893
          035710
                                                               MOV
                                                                          (R4)+,(R1)+
                                                                                               MOVE FIRST FOUR WORDS INTO "L" REGS
                                                    15:
  9894
          035712
                                                               DEC
                                                                       . RO
                                                                                               :CS1, WC. BA, DA
  9895
          035714
                    001375
                                                                       . 15
                                                               BNE
  9896
          035716
                    013721
                               001626
                                                               MOV
                                                                         DRVNUM, (R1)+
                                                                                              :LOAD DRIVE NUMBER
         035722
035724
035726
035730
                                                                                            BUMP PAST ASOF
  9897
                    005721
                                                               TST
                                                                          (R1) +
                    012411
012601
012600
  9898
                                                                         (R4)+,(R1)
(SP)+,R1
                                                               MOV
  9899
                                                                                            ::POP STACK INTO R1
::POP STACK INTO RO
                                                               MOV
 9900
9901
9902
9903
9904
9905
                                                                         (SP)+,R0
                                                               MOV
          035732
                    000204
                                                               RTS
                                                    .SBTTL LOAD RK611 FOR OPERATION
                                                               THE REGISTER SETUP STORAGE IS TRANSFERRED TO THE RK611 REGISTER. THIS IS A STRAIGHT TRANSFER WITH NO CHECKING OR MANIPULATION
                                                    :*
                                                               OF THE REGISTER CONTENTS. L.CS1 IS TRANSFERRED LAST AS IT SHOULD BE IF THE GO BIT IS SET.
  9906:
  9907
                                                                         INTSET
                                                                                              CLEAR INTERRUPT FLAG.
  9908
          035734
                    005037
                                                    LOADRK: CLR
                               001662
          035740
  9909
                    010046
                                                                         RO,-(SP)
                                                               MOV
         035742
035744
035750
035752
  9910
                    010146
                                                                         R1,-(SP)
                                                               MOV.
  9911
                    012700
                               001602
                                                               MOV:
                                                                         #L.WC.RO
                                                                                              GET ADDRESS OF SETUP STORAGE WC
  9912
9913
                    010201
                                                               MOV -
                                                                          R2,R1
                                                                                               GET BASE ADDRESS
                    062701
                               000002
                                                                                               :PUT R1 PAST RKCS1
                                                               ADD-
                                                                         #2,R1
                                                                         (RÓ)+,(R1)+
(RO)+,(R1)+
(RO)+,(R1)+
(RO)+,(R1)
                    012021
  9914
          035756
                                                               MOV.
                                                                                              :LOAD WORD COUNT
  9915
          035760
                                                                                               :LOAD BUS ADDRESS
                                                               MOV-
  9916
          035762
                    012021
                                                                                               :LOAD DISK ADDRESS
                                                               MOV -
                                                                                              :LOAD CS2
:BUMP R1 TO ASOF
  9917
          035764
                    012011
                                                               MOV
                                                                         #6.R1
                    062701
012021
012021
062701
  9918
          035766
                               000006
                                                               ADD -
  9919
          035772
                                                                          (R0)+,(R1)+
                                                                                               :LOAD OFFSET
                                                               MOV.
  9920
9921
9922
9923
          035774
                                                                                               :LOAD CYLINDER
;BUMP R1 TO MR1
                                                                          (RO)+,(R1)+
                                                               MOV .
          035776
                               000004
                                                                         #4.R1
                                                               ADD -
          036002
                                                                          (RO),(R1)
                    011011
                                                               MOV :
                                                                                               :LOAD MR1
                                                                                               :SEE IF TEST 7
:BR IF YES
          036004
                    123727
                               001102 000007
                                                               CMPB
                                                                         STSTNM,#7
                    001403
053737
013712
  9924
9925
          036012
                                                               BEQ
                                                                          1$
                                                                         DTYPE,L.CS1
L.CS1,(R2)
(SP)+,R1
                                                                                               :ELSE SET CORRECT DRIVE TYPE :LOAD CS1
          036014
                               001720
                                          001600
                                                               BIS
  9926
9927
          036022
                               001600
                                                               MOV
                    012601
          036026
                                                                                               :RESTORE REGISTER
                                                               MOV
  9928
          036030
                                                                          (SP)+,R0
                                                               MOV
  9929
9930
          036032
                    000002
                                                               RII
                                                                                               : RETURN
  9931
9932
9933
                                                    THIS ROUTINE LOADS CONSTANTS EITHER FOR THE RKO6 OR THE RKO7
          036034
036040
                    005737
                               001720
  9934
                                                    LDCON: TST
                                                                         DTYPE
                                                                                               :SEE IF RKO6
  9935
                                                               BEQ
                                                                          1$
                                                                                               :BR IF YES
                                                                         #1456.LSTCYL
#1000.TSTCYL
  9936
          036042
                    012737
                               001456
                                         036120
                                                               MOV
                                                                                               :ELSE LOAD RKO7 CONSTANTS
          036050
                    012737
                               001000
                                         036122
                                                               MOV
                                                                                               :MAY NOT BE NEEDED
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 185
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
 9938
        036056
                  005037
                                                                HOLD2
#DTYE, HOLD3
                           036130
                                                       CLR
                           000040
                                    036132
                                                       MOV
  9940
         036070
                  000207
                                                       RTS
  9941
                           000632
036122
002000
036132
  9942
                  012737
005037
012737
         036072
                                    036120 15:
                                                       MOV
                                                                #632, LSTCYL
                                                                                   : RKO6 CONSTANTS
         036100
                                                       CLR
                                                                TSTCYL
                                                                                   :MAY NOT BE NEEDED
  9944
        036104
                                    036130
                                                                HCDT HOLLZ
                                                       MOV
  9945
        036112
                  005037
                                                       CLR
 9946
9947
9948
9949
        036116
                  000207
                                                       RIS
        036120
036122
                  000000
                                              LSTCYL: 0
                                                                                  :FOR 120,57,60 MAY NOT BE NEEDED :FOR 173,105
                  000000
                                              TSTCYL: 0
  9950
        036124
                                              HOLD:
                  000000
  9951 036126
                                              HOLD1: 0
                  000000
  9952: 036130
9953: 036132
                  000000
                                              HOLD2: 0
                                                                                  .; FOR 17
                  000000
                                              HOLD3: 0
                                                                                   :FOR T12
  9954 :
  9955
 9956
9957
                                              THESE ROUTINES LOAD THE CORRECT DRIVE TYPE INTO DTYPE
        036134
036136
036144
  9958
                                              GTYPO: ASL
                  006300
  9959
                  016037
                           001722 001720
                                                                TYPTBL (RO) , DTYPE
                                                       MOV
  9960
                  006200
                                                       ASR
        036746
 9961
                 000207
                                                       RIS
  9962
 9963
        036150
                  006301
                                              GTYP1: ASL
 9964
        036152
                  016137
                           001722 001720
                                                       MOV
                                                                TYPTBL (R1) , DTYPE
                 006201
 9965
        036160
                                                       ASR
 9966
9967
        036162
                                                       RIS
                                                                PC
 9968
 9969
9970
9971
                                              .SBITL STORE RK611 REGISTERS
                                                       ALL THE RK611 REGISTERS ARE STORED IN THE TEST TABLE T
                                             ;*
                                             :*
                                                       WITH THE EXCEPTION OF THE DATA BUFFER WHICH IS NOT STORED IN
  9972
                                                       THIS ROUTINE.
  9973
 9974
                 010046
         036164
                                                                RO,-(SP)
R1,-(SP)
                                              GETRK:
                                                       MOV
                                                                                   :STORE REGISTERS TO BE USED
  9975
        036166
                                                       MOV
  9976
        036170
                  010346
                                                       MOV
                                                                R3,-(SP)
                 012700
010201
012703
012120
  9977
        036172
                                                                                   :SET POINTER TO TEST TABLE :SET POINTER TO RK611 BASE
                           001540
                                                                #T.CS1,RO
                                                       MOV
        036176
036200
036204
036206
036210
  9978
                                                       MOV
                                                                R2.R1
  9979
                           000012
                                                       MOV
                                                                #10.,R3
                                                                                   SET COUNT FOR 1ST 10 REGS
 9980
9981
9982
                                              18:
                                                       MOV
                                                                (R1)+,(R0)+
                                                                                   :STORE RKCS1 THROUGH RKSPAR
                  005303
                                                       DEC
                                                                R3
                  001375
                                                                1$
                                                       BNE
  9983
        036212
                  062701
                           000002
                                                                #2.R1
                                                       ADD
                                                                                   ; BUMP POINTER PAST RKDB
  9984
        036216
                  005720
                                                       TST
                                                                (R0) +
                                                                                   BUMP POINTER PAST T. RKDB
  9985
        036220
                  012703
                           000004
                                                                #4.R34
                                                                                   SET COUNT FOR LAST 5 REGS
                                                       MOV
                                                                (R1)+,(R0)+
  9986
        036224
                  012120
                                              28:
                                                       MOV
                                                                                   :STORE RKMR1 THROUTH RKMR3
  9987
        036226
                  005303
                                                       DEC
  9988
        036230
                  001375
                                                       BNE
  9989
        036232
                  012603
                                                       MOV
                                                                (SP)+,R3
                                                                                   : RESTORE REGISTERS
  9990
        036234
                  012601
                                                       MOV
                                                                (SP)+,R1
        036236
  9991
                 012600
                                                       MOV
                                                                (SP) + , RO
  9992
        036240
                  000002
                                                                                   : RETURN
                                                       RII
  9993
                                              SBITL BIT COUNTER IN A WORD
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 186
CZR6KG.P11 , 28-AUG-81 15:16 STORE RK611 REGISTERS

9994 :* THE WORD WHOSE BITS MUST BE COUNTED
```

```
THE WORD WHOSE BITS MUST BE COUNTED IS PLACED ON THE STACK
 9995
                                                        BY THE CALLING ROUTINE. THE NUMBER OF BITS FOUND IN THE WORD
 9996
                                                        ARE PASSED BACK ON THE STACK.
 9997
 9998
       036242
036250
                           000002 001256 BITCHT: MOV
                 016637
                                                                 2(SP) . $TMP16
                                                                                     GET WORD WHOSE BITS ARE TO BE COUNTED
                                                                                    STORE R3
CLEAR STMP16 FOR COUNTING
                 010346
                                                                 R3,-(SP)
                                                        MOV
10000
       036252
                  005037
                           001260
                                                                 STMP17
                                                        CLR
                                                                                    SET A SHIFT COUNTER
10001
        036256
                 012703
                           000021
                                                                 #17.,R3
                                                        MOV
10002
        036262
                 000241
                                                        CLC
                                                             $1MP16
3$
R3
        036264
036270
036272
036274
10003
                  006037
                           001256
                                              18:
                                                        ROR
                                                                                     : ROTATE WORD.
                 103407
005303
10004
                                                                                    : WAS BIT SHIFTED OUT A 1?
                                                        BCS
10005
                                              28:
                                                        DEC
                                                                                    :NO - DEC COUNT
                                                                                    :LOOP IF NOT ZERO
10006
                 001373
                                                        BNE
                                                             (SP)+,R3
$TMP17,2(SP)
R4
$TMP17
                                                                 1$
                 012603 013766
10007
        036276
                                                       MOV
                                                                                    RESTORE R3
                                                       MOV
10008
        036300
                           001260 000002
                                                                                    PUT COUNT OF BITS ON STACK
                                                                                    RETURN
10009
        036306
                 000204
                                                        RIS
10010 036310
                 005237
                                                       INC
                                                                                    : BUMP COUNT
                           001260
10011 036314
                 000766
                                                        BR
                                                                                    :L00P.
10012
10013
                                              .SBITL MAINTENANCE CLOCK ROUTINE
10014
                                                        THE PARAMETERS PASSED TO THIS ROUTINE ARE LOCATED IN THE
10015
                                                       ADDRESS OFTER THE CALL. THE FIRST BYTE CANTAINS THE NUMBER OF PHASES ADDRESSES THE CALLING ROUTINE WANTS THE CONTROLLER
10016
10017
                                                       CLOCKED THROUGH AND THE SECOND BITE CONTAINS THE NUMBER OF
10018
                                                        CLOCK TRANSITIONS (PARTIAL PHASES) TO BE DONE.
10019
10020 036316
                                              MCLOCK:
10021
10022
10023
10024
                                                                 R0,-(SP)
R1,-(SP)
(R4)+,R0
(R4)+,R1
        036316
                 010046
                                                        MOV
                                                                                    :: PUSH RO ON STACK
                                                                                    :: PUSH R1 ON STACK
       036320 010146
036322 112400
                                                        MOV
                                                                                    GET NUMBER OF CONTROLLER PHASE ADDRESSES
                                                        MOVB
       036324
                 112401
                                                        MOVB
                                                                                    GET PARTIAL PHASE ADDRESS COUNT
10025
10026
10027
10028
10029
       036326
036330
                 006300
                                                        ASL
                                                                                    MULTIPLY PHASE ADDRESS COUNT BY 4
                                                       ASL RO
ADD R1,RO
BIS #MCLK,RKMR1(R2);SET CLOCK
RIS #MCLK,RKMR1(R2);CLEAR MCLK
                 006300
                                                                                    :ADD IN PARTIALS
        036332
                 060100
                 052762
042762
005300
        036334
                           000400 000026 15:
                                                     / BIS
10030
                           000400 000026
        036342
                                                                 #MCLK, RKMR1(R2) : CLEAR MCLK
                                                                RO :DECREMENT COUNT

1$ :LOOP IF NOT ZERO

(SP)+,R1 ::POP STACK INTO R1

(SP)+,RO ::POP STACK INTO RO
10031
        036350
                                                        DEC
10032
10033
        036352
                 001370
                                                        BNE
        036354
                 012601
                                                       MOV
10034
       036356
                 012600
                                                       MOV
10035
       036360
                 000204
                                                        RIS
10036
                                              .SBITL READ AND SORT HEADERS
10037
                                                       THE HEADERS IN THE CYLINDER AND TRACK SPECIFIED BY THE FIELDS IN THE 'L' REGISTERS ARE READ AND STORED IN
10038
10039
                                                        ASSCENDING ORDER. CONTROLLER ERRORS ARE CHECKED IN THE
10040
                                                       READ HEADER OPERATION AND DATA LATE IS CHECKED AFTER
10041
                                                       EACH READ OF THE DATA BUFFER.
10042
                                                                          ; OR 5, 6, 7 : RETURN POINT IF CERR IN READ HDR
10043
                                                       CALL:
                                                                 JSR
10044
                                                                 TCHKOP
10045
                                                                 ERROR
10046
                                                                 ERROR
10047
                                                                                           . : RETURN IF TO SLOW OR
                                                                 ERROR
10048
                                                                                              : IF HDR O NOT FOUND
10049
```

| | CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) READ AN | 28-AUG D SORT H | -81 15:17 PAGE EADERS | 187 |
|---|---|--|--|--|----------------------------|--------------------------|---|---|---|
| | 10050 10051 10052 10053 10054 10055 10056 | 036362 036364 036372 036374 036400 036404 036412 036414 | 104413 032737 001402 005077 012700 032737 001402 012700 | 100000 143310 000026 010000 | 001664 | RDSTHD: 20\$: 1\$: | SAVREG BIT BEQ CLR MOV BIT BEQ MOV | 20\$ | THITCONING |
| | 10057 10058 10059 10060 10061 10062 10063 10064 10065 10066 | 036420 036424 036426 036430 036432 036436 036444 | 012701 010005 010104 010203 062703 013762 013762 013762 | 070414 000024 001626 001614 001606 | 000010 000020 000006 | 18: | MOV MOV MOV ADD MOV MOV MOV | #IBUFF,R1 RO.R5 R1,R4 R2,R3 #RKDB,R3 DRVNUM,RKCS2(R2 L.DCYL,RKDCYL(R. L.DA,RKDA(R2) | :PRESET FOR 26 SECTOR FORMAT :IS 24 SECTOR MODE SET? :NO - SKIP :ELSE CHANGE TO 24 SECTOR MODE :SET POINTER TO INPUT BUFFER :SAVE NUMBER OF SECTORS :SAVE IBUFF ADDRESS :SET UP POINTER TO RKDB) ;LOAD DRIVE NUM 2) ;LOAD CYLINDER NUM :LOAD TRACK AND SECTOR |
| | 10067 | 036460 036466 036472 036476 036504 | 012737 005037 005037 053737 | 000020 | 001654 | 2\$: | MOV CLR CLR B!S MOV | #16., TIMENT INTSET LCLKTK DTYPE, L.CS1 L.CS1, RKCS1(R2) | SET TIME COUNTER CLEAR INTERRUPT ELAG CLEAR TICK COUNTER SET DRV TYP LOAD COMMAND |
| | 10068 10069 10070 10071 10072 10073 10074 10075 10076 10077 | 036516 | 005737 001020 004737 005737 001770 | 001662 035314 001674 | | 3\$: | TST BNE JSR TST BEQ | INTSET 4\$ PC.MYTIME LCLKTK 3\$ | :TEST IF INT OCCURRED :YES - SKIP :WAIT 1 MS :HAVE WE WAITED 16 MS? :NO - LOOP ON WAIT |
| | 10079 10080 10081 10082 10083 10084 | 036532 036540 036542 036550 036556 | | | | | | #6,6(SP) #EM4,EM2N #OPER24,DH2N 10\$ | SET RETURN FOR TO SLOW GET RK REGS LOAD MESSAGE 'TO SLOW/NOT COMPLETE' LOAD COMMAND 'READ HEADER' FOR REPORT SKIP |
| • | 10085 10086 10087 | 036560 036564 | 005762 100474 | 000000 | | 4\$: | TST BMI | RKCS1(R2) 11\$ | :TEST FOR CONTROLLER ERROR :YES - SKIP |
| • | 10088 | 036566 036570 036572 | 011324 011324 011324 | | | | MOV MOV MOV | (R3),(R4)+ (R3),(R4)+ (R3),(R4)+ | STORE HEADERS |
| | 10092 | 036574 036600 | 005762 100443 | 000010 | | | TST BMI | RKCS2(R2) 8\$ | : TEST IF DATA LATE : YES - SKIP |
| | 10095 | 036602 036604 | 005300 001325 | | | | DEC BNE | RO 2\$ | ; DEC SECTOR COUNT ; IF NOT ZERO - LOOP |
| | 10091 10092 10093 10094 10095 10096 10097 10098 10099 10100 10101 10102 10103 10104 10105 | 036606 036614 036616 036624 036632 036634 036636 036640 | 032737 001403 012777 032761 001413 012124 012124 | 100000 000100 000037 | 001664 143064 000002 | 5\$: | BIT BEQ MOV BIT BEQ MOV MOV | #LCLKPR,OPTFLG 5\$ #BIT6, akwLADD #37,2(R1) 6\$ (R1) + (R4) + (R1) + (R4) + (R1) + (R4) + | :TEST IF CLOCK PRESENT :NO - SKIP :SET INTERRUPT ENABLE :HEADER AT TOP OF BUFF=HEAD 0? :YES - SKIP :ELSE MOV THIS HEADER TO BOTTOM |

| CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) READ AN | 28-AUG D SORT H | -81 15:17 PAGE EADERS | 188 |
|--|--|--|--|--|-----------------------|---|---|---|
| 10106 10107 10108 10109 10110 10111 10112 | 036642 036644 036646 036654 036660 | 005305 001367 012737 005037 000421 | 056366 001372 | 001370 | | DEC BNE MOV CLR BR | R5 5\$ #EM56,EM2N DH2N 9\$ | :TEST FO INSURE HEAD O IS FOUND :IF ALL HEADERS NOT CHECKED - LOOP :ELSE 'HEADER O NOT FOUND' MESSAGE :SKIP |
| 10113 10114 10115 10116 10117 10118 10119 10120 10121 10122 10123 10124 | 036662 036666 036670 036672 036674 036676 | 012700 012120 012120 012120 020004 001373 | 070414 | | 6\$: 7\$: | MOV MOV MOV CMP BNE | #IBUFF,R0 (R1)+,(R0)+ (R1)+,(R0)+ (R1)+,(R0)+ R0,R4 7\$ | GET TOP OF IBUFF MOVE HEADERS SO THEY START AT TOP OF IBUFF ALL HEADERS MOVED? NO - LOOP |
| 10119 10120 10121 | 036700 036706 | 062766 000423 | 000010 | 000006 | | ADD BR | #10,6(SP) 11\$ | ; SET UP FOR GOOD RETURN |
| 10122 10123 10124 10125 10126 10127 10128 10129 10130 | 036710 036716 036724 036732 036734 036740 036742 036750 | 012737 012737 062766 104420 013700 006300 016037 162737 | 054631 056777 000004 001302 033122 000002 | 001500 061112 000006 001264 001264 | 8\$: 9\$: 10\$: | MOV MOV ADD TGETRK MOV ASL MOV SUB | #EMDLT.EM13N #EMRDB.DF011A #4.6(SP) \$TESTN.RO RO \$SW08TB(RO).\$ESO #2.\$ESCAPE | ; DATA LATE SET RESULT OF READ DB" ; SET ERROR RETURN ; GET RK REGS ; GET TEST NUMBER ; SHIFT FOR INDEX CAPE ; SET ESCAPE ; TO NEXT SCOPE CALL |
| 11113/ | 036756 036760 | 104414 | | | 115: | RESREG RTS | R4 | |
| 10133 10134 10135 10136 10137 10138 10139 10140 | | | | 1 | SBTTL | THIS ROUGH THEN IF | VE STATUS UTINE GETS ALL THESE SREG17. THESE ERROR OCCURS WHI | HE DRIVE STATUS AND PLACES IT IN \$REG10 REGISTORS ARE FIRST CLEARED TO ALL ONES AND ILE GETTING STATUS, THE 1'S ARE LEFT |
| 10141 10142 10143 | | | | | *CALL: | JSR BR BR | R4, GETDRS ERROR PROCESSING NO ERROR PROCESS | |
| 10144 10145 10146 10147 10148 10149 10150 | 036762 036764 036772 036776 037002 037006 | 104413 012762 012700 012701 012720 005301 | 100000 001202 000010 177777 | 000000 | GETDRS: | SAVREG MOV MOV MOV MOV DEC | #\$REG10,R0 #8.,R1 #177777,(R0)+ R1 | CLEAR ANY OLD ERRORS LAYING AROUND PRESET ALL STATUS STORAGE TO ALL ONES |
| 10151 10152 10153 10154 | 037010 037012 037016 037022 | 001374 012700 012701 005037 | 001206 000001 001230 | | | BNE MOV CLR | 1\$ #\$REG12,RO #1,R1 \$TMP3 | :SET POINTER TOREG12 FOR A01 & B01 :PRESET FOR PAIR ONE. :CLEAR ERROR SWITCH |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 189
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11
                28-AUG-81 15:16
                                                GET DRIVE STATUS
                  013762
                                                                   L.CS2, RKCS2(R2) :LOAD DRIVE #
R1, RKMR1(R2) :LOAD MR1
        037026
                            001610
                                      000010
                                               25:
                  010162
012762
012703
005303
                            000026
000001
000050
10156
         037034
                                                          MOV
                                                                   #BITO, RKCS1(R2) : DO SELECT
#40. R3 : WAIT FOR A FEW MICRO RECORDS TO
         037040
                                      000000
                                                          MOV
 10158
         037046
                                                          MOV
                                                35:
                                                         DEC
                                                                                       :BIT SELECT FINISH
         037054
 10160
                   001376
                                                         BNE
         037056
                   032762
 10161
                            100000
                                      000000
                                                         BIT
                                                                   #CERR, RKCS1(R2) ; ANY ERROR SET AS A RESULT OF SELECT?
         037064
037066
037074
037076
10162
10163
10164
10165
                   001415
                                                         BEQ
                                                                   45
                                                                                       :NO - SKIP
                  032762
                            024000
                                      000000
                                                         RIT
                                                                   #CTO!SPAR, RKCS1(R2) ; CHECK IF TIMEOUT OR PARITY ERROR
                                                                                      : YES - SKIP
                                                         BNE
                                                                   #37400 ,RKCS2(R2) :TEST FOR ERRORS:
                  032762
                            037400
                                      000010
                                                         BIT
10166
                                                                                          NED!UPE!MDS!UFE!NEM!PGE
         037104
037106
037114
                                                                                      :NO - SKIP
                                                         BEQ
10168
                  012737
                                      001230
                                                                   #1.$TMP3
                            000001
                                                         MOV
                                                                                       :SET ERROR FLAG
 10169
                  022020
                                                                   (RO)+,(RO)+
                                                         CMP
                                                                                      BUMP TO LET THAT PAIR STAY ALL 1'S.
 10170
         037116
                  000404
                                                                                       : SKIP
                  016220
016220
012762
                                                                   RKMR2(R2),(R0)+ :STORE A WORD
RKMR3(R2),(R0)+ :STORE B WORD
 10171
         037120
                            000034
                                                48:
                                                         MOV
10172
         037124
                            000036
                                                         MOV
         037130
                                      000000
                            100000
                                                         MOV
                                                                   #CCLR, RKCS1(R2); CLEAR ANY OLD ERROR IN CONTROLLER
 10174
         037136
                  005701
                                                         TST
                                                                                       : IS R1 A O (LAST TRANSFER, PAIR O)
 10175
         037140
                  001410
                                                         BEQ
                                                                   6$
                                                                                       : YES - SKIP
        037142
                                                                                      :ELSE BUMP TO NEXT PAIR :PAIR 3 JUST STORED?
 10176
                  005201
                                                         INC
10177
         037144
                  022701
                                                                   #4,R1
                            000004
                                                         CMP
                                                                                      :NO - SKIP

:ELSE SET TO PAIR O

:PRESET POINTER FOR PAIR O
 10178
         037150
                  001326
                                                         BNF
                                                                   2$
 10179
         037152
                   005001
                                                         CLR
 10180
         037154
                  012700
                            001202
                                                                   #$REG10,RO
                                                         MOV
 10181
         037160
                  000722
                                                         BR
                                                                                       GO GET THEM
         037162
 10182
                   104414
                                                         RESREG
                                                                                      :EXIT HERE
 10183
         037164
                  005737
                            001230
                                                                   $TMP3
                                                         TST
                                                                                      :ANY ERROR IN STATUS GETTING
         037170
10184
                  001001
                                                         BNE
                                                                   7$
                                                                                      : YES - SKIP
         037172
 10185
                   005724
                                                                   (R4) +
                                                                                      ELSE BUMP PART ERROR
                                                         TST
         037174
 10186
                  000204
                                                75:
                                                                                       : RETURN
10187
10188
                                                .SBITL
                                                         SUBSYSTEM INITIALIZE AND INITIALIZE STATE TEST
10189
                                                         THE SUBSYSTEM IS INITIALIZED WITH A SUBSYSTEM CLEAR
10190
                                                         COMMAND. CERR AND DI ARE MONITORED FOR A SHORT
 10191
                                                         PERIOD OF TIME DURING WHICH THEY SHOULD BOTH RESET.
 10192
10193
                                                         IF THEY DO RESET, READY IS TESTED TO INSURE IF SETS.
10194
10195
                                                         IF ANY OF THESE THREE CONDITIONS ARE NOT MET AN APPROPRIATE
10196
                                                         ERROR MESSAGE IS PREPARED AND REPORTED WHEN THE ROUTINE
10197
                                                         RETURN TO THE CALL. IF EVERY THING IS GOOD, THE RETURN
10198
                                                         SKIPS OVER THE ERROR CALL AND TEST ABORT.
 10199
 10200
                                                         THE USUAL CALL TO THIS ROUTINE WILL BE FOLLOWED BY AN ERROR MESSAGE AND BRANCH TO END OF TEST. THIS
 10201
 10202
                                                         IS DONE BECAUSE FAILURE TO INITIALIZE CORRECTLY IS FATAL TO
 10203
                                                         THE TEST.
10204
10205
10206
10207
10208
10209
10210
         037176
                                               SSINIT:
         037176
                                                                  RO.-(SP)
R1.-(SP)
                  010046
                                                                                      :: PUSH RO ON STACK
                                                         MOV
        037200
037202
037206
037212
                  010146
012701
012700
012720
                                                                                      :: PUSH R1 ON STACK
                                                         MOV
                            000007
                                                                  #7,R1
                                                         MOV
                            001600
                                                         MOV
                                                                   #L.($1,R0
                                                                                      :GET ADDRESS OF "L" REGS
                            000100
                                                         MOV
                                                                   #100,(RO)+
                                                                                      :PRESET CS1 INTR ENABLE
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 190
CZR6KGO RK6 FCTNL CTRL DIAG
                                                  SUBSYSTEM INITIALIZE AND INITIALIZE STATE TEST
CZR6KG.P11
                 28-AUG-81 15:16
         037216
037220
037222
                                                                       (R0) +
                    005020
                                                                                           :CLEAR THE NEXT
10212
10213
10214
10215
10216
10217
10218
10219
10221
10222
10223
10224
10225
10226
10227
10228
10227
10233
10233
10233
10233
10233
                    005301
                                                                       R1
                                                             DEC
                                                                                           : COUNT 0?
                    001375
                                                             BNE
                                                                       7$
                                                                                            :NO - LOOP
         037224
037232
037240
037246
037254
                   012762
012737
016237
032737
001433
                                                                      #SCLR, RKCS2(R2)
#10., $TMP0
RKCS1(R2), T.CS1
#CERR:DI, T.CS1
                                        000010
001222
001540
001540
                              000040
000012
000000
                                                             MOV
                                                                                           : CLEAR SUBSYSTEM
                                                                                           SET A COUNTER
                                                             MOV
                                                             MOV
                                                  15:
                                                                                           :GET CS1
                              140000
                                                            BIT
                                                                                           :TEST IF ERROR OR DI SET
                                                             BEQ
                                                                                           :NO - SKIP TO READY TEST
                    005337
                              001222
                                                                       $TMP0
                                                             DEC
                                                                                           :ELSE DECREMENT COUNTER
         037262
                    001366
                                                             BNE
                                                                       15
                                                                                           : AND LOOP
         037264
037272
037274
                    032737
                              100000
                                        001540
                                                             BIT
                                                                       #CERR, T. CS1
                                                                                           : TEST - IS IT CERR STILL SET
                    001404
                                                             BEQ
                                                                       3$
                                                                                           :NO - SKIP TO DI MESSAGE
                    012737
                                                                       #EM5, EM3N
                              053711
                                        001400
                                                             MOV
                                                                                           :MESSAGE (SUBSYS CLR NOT RESET ERROR)
         037302
                    000403
                                                             BR
                                                                       45
                   012737
         037304
                              053755
                                        001400
                                                             MOV
                                                                       #EM6, EM3N
                                                                                           :MESSAGE (SUBSYS CLEAR NOT RESET DI)
         037312
                                                             TGETRK
                    104420
                                                  45:
                   013700
         037314
                              001302
                                                            MOV
                                                                       STESTN.RO
                                                                                           GET PRESENT TEST NUMBER
         037320
037322
037330
                    006300
                                                                                            SHIFT FOR INDEX
                                                             ASL
                                                                       RO
                                                                      $SWO8TBL(RO), $ESCAPE ; LOAD ESCAPE TO ABORT TEST #2, $ESCAPE ; SET TO NEXT SCOPE CALL
                             033122
                    016037
                                        001264
                                                             MOV
                    162737
                                       001264
                                                             SUB
         037336
037340
                   012601
                                                             MOV
                                                                       (SP)+,R1
                                                                                           :: POP STACK INTO R1
                    012600
                                                                       (SP)+,R0
                                                                                           :: POP STACK INTO RO
                                                            MOV
         037342
                   000414 032737
                                                            BR
                                                                       6$
                                                                                           :DSKIP TO EXIT
                              000200
                                       001540
                                                            BIT
                                                                       #RDY, T. CS1
                                                                                           : TEST READY SET
         037352
                    001004
                                                            BNF
                                                                       5$
                                                                                           :YES - GOOD EXIT
10236
10237
10238
10239
10240
10241
10242
10243
10244
10246
10247
10248
10253
10253
10253
10253
10253
10256
10257
10260
10261
10262
10263
         037354
                    012737
                              054034
                                        201400
                                                            MOV
                                                                       #EM7, EM3N
                                                                                           :MESSAGE (SUBSYS CLR NOT SET READY)
                   000753
         037362
                                                            BR
                                                                       45
                   012601
012600
         037364
                                                                       (SP)+,R1
                                                  55:
                                                            MOV
                                                                                           :RESTORE REGS
         037366
037370
                                                                       (SP)+.RO
                                                            MOV
                    062716
                              000002
                                                            ADD
                                                                       #2.(SP)
                                                                                           : GOOD RETURN
         037374
                    000002
                                                            RII
                                                  63:
                                                  . SETTL
                                                            WORD COUNT AT END OF OPERATION CHECK
                                                             THIS ROUTINE COMPARES THE CONTENTS OF THE TEST STORAGE FOR
                                                  :*
                                                             THE WORD COUNT AGAINST THE SUPPLIED VALUE. IF UNEQUAL, THE
                                                            ERROR FLAG (WCERR) IS SET IN GROUP 4 ERROR FLAGS (GRP4ER)
                                                  : * CALL: JSR
                                                                       R4. CHKWC
                                                             . WORD
                                                                                           : EXPECTED WC VALUE
         037376 012437 050034
                                                  CHKWC:
                                                            MOV
                                                                       (R4)+,EXPWC
                                                                                           :STORE EXPECTED VALUE
         037402
                   023737
                             050034
                                        001542
                                                            CMP
                                                                      EXPWC.T.WC
                                                                                           : COMPARE
                   001406
052737
013737
         037410
                                                            BEQ
                                                                                            EQUAL - SKIP
                                                                       1$
         037412
                              000001
                                        050072
                                                                      #WCERR, GRP4ER
                                                            BIS
                                                                                         SET ERROR FLAG
                              001542
                                        050050
                                                            MOV
                                                                                           STORE REAL WORD COUNT
                                                                       T.WC, REALWC
         037426
                   000204
                                                  15:
                                                            RTS
                                                                                           : RETURN.
                                                  . SBTTL
                                                            BUS ADDRESS AT END OF OPERATION CHECK
                                                            THIS ROUTINE COMPUTES THE EXPECTED BUS ADDRESS AT THE END OF
                                                            A TRANSFER BY USING THE INITIAL BUS ADDRESS, ADDING IN THE
                                                            INITIAL WORD COUNT, AND SUBTRACTING ANY RESIDUAL WORD COUNT.
                                                            IF THIS COMPUTED BA DOES NOT EQUAL THE CONTENTS OF RKBA
 10264
                                                            AN ERROR FLAG (BAERR) IS SET IN GROUP 4 ERROR FIELD (GRP4ER)
 10265
 10266
                                                            IF BUS ADDRESS INCREMENT INHIBIT WAS SET, THE EXPECTED BUS
```

| 10267 | | | | | :*CALL: | ADDRESS JSR | IS THE STARTING | BUS ADDRESS. |
|---|--|--|--|------------------|--------------------------|--|---|---|
| 10270 10271 10272 10273 10274 10275 10276 10277 10278 10279 | 037430 037432 037434 037436 037444 037454 037456 037462 037462 037470 | 010046 010146 010346 032737 001404 013737 000441 013700 005400 113703 042703 | 000020 001604 001602 001601 177774 | 001610 050040 | CHKBA: | MOV MOV BIT BEQ MOV BR MOV NEG MOVB BIC | RO,-(SP) R1,-(SP) R3,-(SP) #BAI,L.CS2 4\$ L.BA,EXPBA 3\$ L.WC,RO RO L.CS1+1,R3 #177774,R3 | :TEST IF BAI SET :NO - SKIP :STORE EXPECTED BA (SAME AS STARTING BA) :GET INITIAL WORD COUNT :GET BA16 & BA17 :CLEAR UNWANTED BITS |
| 10268 10270 10271 10273 10273 10273 10273 10273 10273 10273 10273 10273 10273 10273 10283 10283 10283 10283 10283 10293 10293 10293 10293 10293 10293 10293 10293 10303 10303 10303 10313 | 037474 037476 037500 037504 037506 037510 037512 037514 037516 037522 037530 037530 037530 037534 037536 037540 037540 037540 037564 037564 037564 037564 037564 037602 037632 037636 037636 037636 037636 | 005700 001003 062703 000407 005700 100001 005203 006300 005503 013701 001411 005401 005701 100001 005303 010037 010037 010037 020037 010037 | 000002 001604 001542 050036 050040 001544 000004 001541 177774 050036 000002 050052 | 050072 050054 | 6\$: 5\$: 7\$: 2\$: 8\$: | TST BADD BAST BADD BADD BADD BADD BADD BADD BADD BAD | R0 6\$ #2,R3 9\$ R0 5\$ R3 R0 L.BA,R0 R3 T.WC,R1 1\$ R1 R1 R1 R1 R3 R3,EXPUBA R0,EXPBA R0,EXPBA R0,EXPBA R0,EXPBA R0,EXPBA R0,EXPBA R0,EXPBA R1,RC R3,EXPUBA R3,EXPUBA R4 R5,REALBA T.CS1+1,R3 #177774,R3 R3,EXPUBA 8\$ #UBAERR,GRP4ER R3,REALUB (SP)+,R3 (SP)+,R1 (SP)+,R0 R4 | :TEST IF INITIAL WORD COUNT O :NO - SKIP :ADD 2 TO BA16,17 (65K WORD XFER) :SKIP :TEST IF INITIAL WC BIT 15 SET :NO - SKIP :BUMP BA16,17 (32K WORD XFER) :SHIFT WORD COUNT TO MAKE MEM ADD (NT :ADD IN START BUFFER ADD :IF CARRY - ADD INTO BA16,17 :GET END OF OPERATION WORD COUNT :BRANCH IF ZERO :TEST END OPERATION WC BIT 15 SET :NO - SKIP :DEC BA 16,17 (32K WC LEFT) :SHIFT WC TO MAKE MEM ADD (NT :SUB FROM COMPUTED BUS ADDRESS :SUB CARRY FROM BA16,17 :STORE EXPECTED UPPER BA BITS :EQUAL TO COMPUTED? :YES - SKIP :ELSE SET BAERR FLAG :STORE REAL BUS ADDRESS :GET REAL UPPER BA :CLEAR UNWANTED BITS :CHECK IF EQUAL :YES - SKIP :ELSE SET UBA ERROR :STORE REAL UPPER BA |
| 10318 10319 10320 10321 10322 | | | | | SBTTL | THIS RO ARE COR OPERATI | UTINE CHECKS THA RECT FOR ANY SIZ ON. THE CONTENT | EST AT END OF OPERATION T THE CONTENTS OF THE RKDCYL AND RKDA E DATA TRANSFER AT THE END OF THE S OF THE LOAD REGISTER STORAGE ARE INITIAL VALUES TO MAKE THE |

```
CZR6KGO RK6 FCTNL CTRL DIAG
                                       MACY11 30(1046) 28-AUG-81 15:17 PAGE 192
                                                 CYLINDER, TRACK, SECTOR TEST AT END OF OPERATION
CZR6KG.P11
                 28-AUG-81 15:16
 10323
                                                           NECESSARY CALCULATION.
10325
10326
10327
10328
10329
                                                           ALL THREE VALUES ARE GENERATED AND STORED IN EXPECTED VALUES
                                                           STORAGE EXPCYL, EXPTRK, EXPSEC. ALL 3 ARE CHECKED AND
                                                           IF ONE OR MORE ARE WRONG, THE CORRESPONDING BIT IN THE ERROR FLAGS FIELD (GRP4ER) IS SET.
10330
                                                 : * CALL: JSR
                                                                     R4.CHKCTS
10332
         037642
                   104413
                                                 CHKCTS: SAVREG
10333
         037644
                   013700
                             001602
                                                                     L.WC.RO
                                                           MOV
                                                                                         GET SPECIFIED WORD COUNT
         037650
037652
10334
10335
10336
10337
10338
10339
10341
10342
10343
10344
10345
10346
10347
10348
10349
                   005400
                                                           NEG
                                                                                         :NEGATE IT
                                                                     T.WC.R1
                             001542
                                                           MOV
                                                                                         GET END OF OPERATION WORD COUNT
         037656
                   001401
                                                           BEQ
                                                                  . 10$
                                                                                         : IF ZERO - SKIP
         037660
                   005401
                                                                     R1
                                                           NEG
                                                                                         : NEGATE IT
         037662
                   160100
                                                                                         COMPUTE ACTUAL WORDS TRANSFERRED
                                                 10$:
                                                           SUB
                                                                     R1, R0
         037664
                   005001
                                                           CLR
                                                                     R1
                                                                                         : CLEAR R1 FOR COUNTING
                                                          THE FOLLOWING CODE DETERMINES HOW MAY SECTORS OF DATA HAS BEEN TRANSFERRED IN THE OPERATION. ONCE IT HAS COMPUTED THAT, THE
                                                           END OF OPERATION VALUES FOR THE CYLINDER, TRACK, AND SECTOR
                                                           IS CALCULATED.
        037666 037672
                   022700
                             000400
                                                           CMP
                                                                     #400,R0
                                                           BGT
                                                                     2$
         037674
                   005201
                                                           INC
         037676
                   162700
                            000400
                                                           SUB
                                                                     #400.RO
         037702
                   000771
                                                           BR
                                                                     15
         037704
                   005700
                                                                     RO
                                                           TST
10350
        037706
                   001401
                                                                     3$
                                                           BEQ
10351
         037710
                   005201
                                                           INC
10351
10352
10353
10354
10355
10356
10357
                                                           AT THIS POINT R1 HAS A COUNT OF THE
                                                           NUMBER OF FULL SECTOR TRANSFER + 1 IF A
                                                           PARTIAL SECTOR WAS TRANSFERRED.
                  012703
032737
         037712
                             000026
                                                           MOV
                                                                    #26.R3
        037716
037724
037726
                             010000
                                      001600
                                                           BIT
                                                                    #CFMT, L.CS1
                  001402 012703
                                                          BEQ
                                                                     45
                             000024
                                                          MOV
                                                                    #24.R3
10359
                                                          R3 HAS BEEN SET UP WTH THE NUMBER
10360
10361
10362
10363
10364
10365
10366
10367
10368
10369
10370
10371
10372
10373
                                                          OF SECTORS IN A TRACK FOR THE FORMAT USED
        037732
037740
037744
                  013737
                             001614
                                      050042
                                                          MOV
                                                                    L.DCYL, EXPCYL GET STARTING VALUES FOR CYLINDER
                             001607
                                                                    L.DT.R4
#177400,R4
                                                          MOVB
                                                                                        : TRACK
                  042704
                            177400
                                                          BIC
        037750
                            001606
                                                                    L.DS.R5
#177400.R5
                                                          MOVB
                                                                                        : SECTOR
        037754
                   042705
                            177400
                                                          BIC
        037760
                   005301
                                                          DEC
                                                                    R1
                                                                                        :ADJUST COUNT FOR ZERO DETECT
        037762
                   005205
                                                58:
                                                           INC
                                                                    R5
                                                                                        BUMP SECTOR COUNT
        037764
                   020503
                                                           CMP
                                                                    R5.R3
                                                                                        ;DID THIS MAKE SECTOR COUTN > 1 TRACK?
        037766
                   001010
                                                          BNE
                                                                    6$
                                                                                        :NO - SKIP
        037770
                   005005
                                                                    R5
                                                           CLR
                                                                                        ELSE CLEAR SECTOR COUNT
                  005204
022704
        037772
                                                           INC
                                                                                        BUMP TRACK COUNT
        037774
                            000003
                                                          CMP
                                                                    #3.R4
                                                                                        :DID THIS MAKE TRK COUNT > 1 CYLINDER?
        040000
                   001003
                                                          BNE
                                                                    6$
                                                                                        :NO - SKIP
10374
        040002
                   005004
                                                          CLR
                                                                                        ; ELSE CLEAR TRACK COUNT
                  005237
005301
001363
10375
        040004
                            050042
                                                                    EXPCYL
                                                           INC
                                                                                        BUMP CYLINDER COUNT
10376
10377
        040010
                                                          DEC
                                                                    R1
                                                                                        : DEC COUNT
        040012
                                                          BNE
                                                                                        : IF ZERO - EXIT
10378
                  010437
                            050046
                                                                    R4.EXPTRK
                                                                                        STORE EXPECTED TRACK
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 193
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG-P11
                                               CYLINDER. TRACK SECTOR TEST AT END OF OPERATION
                28-AUG-81 15:16
                  010537
                                                                                      :STORE EXPECTED SECTOR (CYL ALREADY SLOW)
 10379
                                                                   R5.EXPSEC
         040020
                            050044
         040024
 10380
                                      050042
                                                         CMP
                                                                   T.DCYL, EXPCYL
                                                                                      :TEST IF CYLINDER OK
                            001560
                                                                                      : YES - SKIP
 10381
                  001403
                                                         BEQ
                                                                   75
                                                                  #CYLERR, GRP4ER
                                                                                      :NO - SET ERROR FLAG
10382
10383
                  052737
         040034
                            000010
                                      050072
                                                         BIS
         040042
                            001547
                                                         CMPB
                                                                   R4.T.DA+1
                  001403
052737
120537
001403
052737
012700
013720
013720
013720
113710
10384
10385
10386
10387
10388
10389
10390
         040046
                                                         BEQ
                                                                                      : YES - SKIP
         040050
                                                                   #TRKERR, GRP4ER
                                                                                      :NO - SET ERROR FLAG
                            000020
                                      050072
                                                         BIS
                                                                                      TEST SECTOR COUNT OK
         040056
                            001546
                                                         CMPB
                                                                   R5.T.DA
                                                                   9$
         040062
                                                         REQ
                                                                                      : YES - SKIP
                                                                  #SECERR GRP4ER
#REALWC RO
         040064
                            000040
050050
                                     050072
                                                                                      :USE SET ERROR FLAG
                                                         BIS
                                                         MOV
                                                                  T.WC,(RO)+
T.BA,(RO)+
         040076
                            001542
                                                         MOV
                                                                                      STORE REAL WORD COUNT
 10391
         040102
                            001544
                                                         MOV
                                                                                      STORE REAL BUS ADDRESS
10392
                                                                  T.DCYL, (RO)+
T.DA+1, (RO)
         040106
                            001560
                                                         MOV
                                                                                      STORE REAL CYLINDER ADDRESS
         040112
                            001547
                                                         MOVB
                                                                                      :STORE REAL TRACK ADDRESS
 10394
         040116
                  005720
                                                                   (R0) +
                                                         TST
 10395
         040120 040124
                  113710
                            001546
                                                         MOVB
                                                                   T.DA. (RU)
                                                                                      :STORE REAL SECTOR ADDRESS
10396
10397
10398
10399
                  104414
                                                         RESREG
         040126
                  000204
                                                         RTS
                                               .SBTTL
                                                         OPERATION CHECK ROUTINE
 10400
                                                         THIS IS WHERE ALL HARDWARE ERROR INDICATORS AND SOME SOFTWARE
                                                         ERRORS ARE CHECKED. THE GENERAL PROCEDURE FLOW IS AS FOLLOWS: THE ROUTINE IS CALLED WITH A TRAF (TCHKOP). THE LOCATION
 10401
 10402
                                                         FOLLOWING THE TRAP CALL WILL HAVE AN ERROR TRAP WHICH THE ROUTINE WILL BYPASS IF NO ERROR IS FOUND. IF AN
 10403
10404
10405
10406
10407
                                                         ERROR IS DETECTED, THE ERROR TRAP CALL IS MODIFIED
                                                         BY THIS ROUTINE SUCH THAT THE ERROR TABLE ITEM WILL
                                                         BE THE PROPER ITEM FOR THE FORMAT REQUIRED BY THIS
 10408
                                                         ERROR. THE ERROR TRAP WILL BE MADE EITHER ERROR 4,5,
 10409
                                                         7. OR 10. REFER TO THE ERROR ITEM TABLE FOR A DESCRIPTION
                                                         OF THE FORMAT AND WHICH ERRORS ARE DISPLAYED IN WHAT
 10410
 10411
                                                         FORMAT.
10412
         040130
                  104413
                                               CHKWE: SAVREG
         040132
                                                                   (SP),R0
 10414
                  011600
                                                                                      GET POINTER TO ERROR WORDS
                                                         MOV
10415
                  012037
                            001242
                                                                   (RO)+,$TMP10
                                                                                      STORE EXPECTED ERROR GROUP
                                                         MOV
 10416
         040140
                            001244
                                                                   (RO)+,$TMP11
                                                         MOV
                                                                                      STORE EXPECTED ERROR GROUP
 10417
         040144
                  012037
                            001246
                                                                   (RO)+,$TMP12
                                                                                      STORE EXPECTED ERROR GROUP 3
                                                         VOM
                                                                  RO, (SP)
 10418
         040150
                  010016
                                                                                      STORE RETURN
                                                         MOV
 10419
         040152
                  012737
                            177777 001250
                                                         MOV
                                                                   #-1,$TMP13
                                                                                      :SET FLAG - EXPECTED ERROR
10420
10421
10422
10423
10424
10425
10426
10427
10428
10429
10430
                   000403
         040160
                                                         BR
                                                                   CHKST
         040162
                                               CHKOP:
                                                         SAVREG
         040164
                   005037
                            001250
                                                                   $TMP13
                                                                                      :RESET EXPECTED ERROR FLAG
                                                         CLR
         040170 040172
                  104420 005037
                                               CHKST: TGETRK
                                                                                      GET 611 REGS IO TRAP
                                                                   GRP1ER
                            050064
                                                         CLR
                                                                                      : CLEAR ERROR FLAGS
         040176
                   005037
                            050066
                                                         CLR
                                                                   GRP2ER
         040202
                   005037
                            050070
                                                                   GRP3ER
                                                         CLR
         040206
                   005037
                            050072
                                                                   GRP4ER
                                                         CLR
                   005037
         040212
                            050206
                                                                   GPSUMF
                                                         CLR
                                                                                      : CLEAR SUMMARY FLAGS
10431
10432
10433
10434
                   032737
         040216
                                      001540
                            024000
                                                         BIT
                                                                  #CS1ERBIT, T. CS1 : TEST IF ERROR SET IN CS1
         040224
040226
040234
                   001111
                                                         BNE
                                                                                      : YES - SKIP
                                                                  #CSZERBIT, T. CSZ : TEST IF ERROR SET IN CSZ
                   032737
                            177400
                                      001550
                                                         BIT
                   001105
                                                         BNE
                                                                                      : YES - SKIP
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 194
CZR6KGO RK6 FCTNL CTRL DIAG
                                                    OPERATION CHECK ROUTINE
CZR6KG.P11
                  28-AUG-81 15:16
                                                                                              :TEST IF ERROR SET IN DS
                    032737
                                         001552
 10435
          040236
                               000070
                                                                         #DSERBIT, T.DS
10436
10437
10438
10439
                    001101
                                                                                               : YES - SKIP
          040244
                                                               BNE
                                                                         4$
          040246
                                                                         T.ER
                                                                                               :TEST IF ERROR SET IN ER
                    005737
                               001554
                                                               TST
                    001076
                                                               BNE
                                                                         45
                                                                                               : YES - SKIP
          040254
                    032737
                                                                         #CERR, T. CS1
                                                                                               : COMBINED ERROR SET?
                               100000
                                         001540
                                                               BIT
                    001405
052737
000137
                                                                         9$ :NO - SKIP
#CERNER, GRP1ER :SET ERROR FLAG IN GROUP 1
         040262
040264
040272
 10440
                                                               BEQ
10441
10442
10443
                               100000
                                                               BIS
                                         050064
                               041022
                                                                                               :SKIP
                                                               CODE TO CHECK WORD COUNT, BUFFER ADDRESS, CYLINDER, TRACK, AND SECTOR AT THE END OF THE OPERATION. THIS IS DONE ONLY
 10444
 10445
 10446
                                                               IF CERR NOT SET BY THE OPERATION.
 10447
 10448
                                                               ALL OF THE ABOVE CONDITIONS ARE CHECKED AND A BIT SET FOR
                                                               EACH CHECK THAT FAILS. HOWEVER, ONLY ONE ERROR IS REPORTED.
 10449
 10450
                                                               THE ORDER OF PRIORITY FOR REPORTING THE ERROR IS THE ORDER
 10451
                                                               LISTED ABOVE.
10452
10453
10454
10455
         040276 040302
                    005737
                               001250
                                                                         STMP13
                                                                                              : TEST IF ERROR EXPECTED
                                                               TST
                                                                         62$
                    001402
                                                                                               :NO - SKIP
                                                               BEQ
          040304
                                                                                               : YES - JUMP
                    000137
                                                               JMP
                                                                         25$
                               041022
10456
10457
10458
10459
10460
                    013700
042700
022700
002445
022700
003042
004437
                                                                         T.CS1.RO
#177741.RO
          040310
                               001540
                                                    62$:
                                                                                               :GET CS1
                                                               MOV
          040314
                               177741
                                                               BIC
                                                                                               : CHECK IF OPERATION IS READ DATA.
          040320
                                                                                               : WRITE DATA, OR WRITE CHECK. IF
                               000020
                                                               CMP
                                                                         #20.R0
         040324
040326
040332
                                                                         3$
                                                                                               :NOT, SKIP ALL CHECKING IN GROUP
                                                               BLT
                                                                         #30,R0
                               000030
                                                               CMP
10461
10462
10463
                                                                         3$
                                                               BGT
         040334
                               037376
                                                               JSR
                                                                         R4. CHKWC
                                                                                               CHECK WORD COUNT
          040340
                    000000
                                                               . WORD
                                                                                               :EXPECTED WORD COUNT
 10464
          040342
                    004437
                               037430
                                                               JSR
                                                                         R4, CHKBA
                                                                                               CHECK BUS ADDRESSS
 10465
          040346
                    004437
                               037642
                                                                                               CHECK CYL, TRACK, & SECTOR
                                                               JSR
                                                                         R4, CHKCTS
                    005737
                                                                                               ; ANY GROUP 4 ERRORS?
 10466
          040352
                               050072
                                                               TST
                                                                         GRP4ER
 10467
          040356
                    001430
                                                                                               :NO - SKIP
                                                               BEQ
 10468
          040360
                    016037
                                                                         CMNDLB(RO), DF010A ; LOAD ADDRESS OF COMMAND MESSAGE
                               050210
                                         061072
                                                               MOV
10469
10470
10471
10472
10473
          040366
                                                                                              ; PUT GROUP 4 ERROR FLAG IN RO
                    013700
                               050072
                                                               MOV
                                                                         GRP4ER, RO
          040372
                    005001
                                                                                               CLEAR R1 FOR INDEX COUNTER
                                                               CLR
          040374
                    006200
103402
                                                                                               :SHIFT FLAGS - FIRST ONE ON RIGHT IS ERROR TO :BE REPORTED, REST ARE IGNORED
                                                    15:
                                                               ASR
          040376
                                                                         2$
                                                               BCS
                                                                        (RO) + ; WHEN AN ERROR BIT IS FOUND,

1$ ; GET THE ERROR MESSAGE ASSOCIATED

GRP4MS(RO), EM10N; WITH IT AND SET ERROR TABLE ITEM TO

EXPWC(RO), $REG10; POINT TO THE MESSAGE. LOAD REG10 & 11

REALWC(RO), $REG11; WITH EXPECTED & IS VALUES

: RESTORE REGISTER

#10 a(SP)
          040400
                    005720
                                                               TST
 10474
          040402
                    000774
          040404
                    016037
                               050074
                                         001450
                                                               MOV
10475
10476
10477
10478
10479
10480
10481
10482
10483
                    016037
                               050034
                                         001202
          040412
                                                               MOV
                    016037
          040420
                               050050
                                         001204
                                                               MOV
          040426
040430
040436
                    104414 012776
                                                               RESREG
                               000010
                                         000000
                                                                         #10,a(SP)
                                                                                               MAKE THE ERROR CALL POINT TO THE
                                                               MOV
                    000002
                                                               RTI
                                                                                               :RIGHT TABLE ENTRY & RETURN.
          040440
                    104414 062716
          040440
                                                               RESREG
          040442
                               000002
                                                               ADD
                                                                         #2,(SP)
                                                                                               :BUMP RETURN PAST ERROR
 10484
                    000002
          040446
                                                                                               : RETURN
 10485
 10486
                                                               THE FOLLOWING CODE BUILDS THE GROUP 1.2. & 3 ERROR WORDS.
 10487
 10488
10489
                    012700
                                                                                               :SET UP GENERAL REGISTER AS POINTER :CS1
          040450
                               050064
                                                                         #GRP1ER,RO
          040454
                               001540
                                                                         #T. (S1, R1
                                                               MOV
          040460
                    012703
                                                                         #T. CS2. R3
 10490
                               001550
                                                                                               : CS2
                                                               MOV
```

| CZR6KGO CZR6KG. | | NL CTRL 8-AUG-81 | | MACY11 | | 28-AUG | -81 15:17 PAGE ROUTINE M 15 | | 5 |
|--|--|--|--------------------------------------|--------|-----------------|--|--|--|---|
| 10491 | 040464 040470 | 012704 012705 | 001552 001554 | | | MOV MOV | #T.DS.R4 ' #T.ER.R5 | :DS :AND ER | 1 |
| 10493 | 040474 | 051510 | | | | BIS | (R5),(R0) | SET ALL BITS IN GRP1ER THAT | |
| 10495 | 040476 | 042710 | 120701 | | | BIC | #ILF!ECH!BSE!HV | CORRESPOND TO ERROR BITS IN RKER C!OPI!DCK, (RO); CLEAR ALL THAT DON'T BELONG GRP1 | |
| 10497 10498 10499 10500 | 040502 040506 040510 | 032711 001402 052710 | 020000 000001 | | | BIT BEQ BIS | #SPAR,(R1) 5\$ #SPARERR,(R0) | :TEST IF SPAR SET :NO - SKIP :SET SPAR ERROR FLAG | |
| 10501 10502 10503 10504 10505 | 040514 040520 040522 | 032714 001402 052710 | 000010 000100 | | 5\$: | BIT BEQ BIS | #ACLO,(R4) 6\$ #ACLOERR,(R0) | :TEST ACLO SET :NO - SKIP :SET ACLO ERROR FLAG | |
| 10506 10507 10508 | 040526 040532 040534 | 032714 001402 052710 | 000020 | | 6\$: | BIT BEQ BIS | #SPDLSS,(R4) 7\$ #SPDERR,(R0) | :TEST SPEED LOSS SET :NO - SKIP :SET SPEED LOSS ERROR FLAG | |
| 10509 10510 10511 10512 10513 | 040540 040544 040546 | 032714 001402 052710 | 000040 000400 | | 7\$: | BIT BEQ BIS | #DROT,(R4) 8\$ #DROTERR,(R0) | :TEST IF DROT SET :NO - SKIP :SET DROT ERROR FLAG | |
| 10513 10514 10515 10516 10517 | 040552 040556 040560 | 032711 001002 032710 | 100000 020000 | | 8\$: | BIT BNE BIT | #CERR,(R1) 10\$ #NCERWE,(R0) | :TEST CERR ITSELF SET :YES - SKIP :SET NO CERR WITH ERROR FLAG | |
| 10518 | 040564 | 012700 | 050066 | | 10\$: | MOV | #GRP2ER,RO | SET POINTER TO GROUP 2 ERROR FLAGS | |
| 10519 10520 10521 10522 | 040570 040574 040576 | 032715 001402 052710 | 000100 000001 | | | BIT BEQ BIS | #ECH, (R5) 11\$ #ECHERR, (R0) | :TEST IF ECH SET :NO - SKIP :SET ECH FLAG | |
| 10523 10524 10525 10526 | 040602 040606 040610 | 032715 001402 052710 | 100000 | | 11\$: | BIT BEQ BIS | #DCK,(R5) 12\$ #DCKERR,(R0) | :TEST DCK SET :NO - SKIP :SET DCK ERROR FLAG. | |
| 10524 10525 10526 10527 10528 10529 10530 10531 10532 10533 10534 10535 10536 10537 10538 10539 10540 10541 10542 10543 | 040614 040620 040622 040626 040632 040634 | 032713 001402 052710 032713 001402 052710 | 040000 000004 100000 000010 | | 12\$: 120\$: | BIT BEQ BIS BIT BEQ BIS | #WCE,(R3) 120\$ #WCKERR,(R0) #DLT,(R3) 13\$ #DLTERR,(R0) | :TEST WRITE CHECK ERROR :NO - SKIP :SET WCE BIT :TEST DATA LATE :NO - SKIP :SET DLT ERROR FLAG | |
| 10535 10536 10537 | 040640 040644 040646 | 032715 001402 052710 | 020000 000020 | | 13\$: | BIT BEQ BIS | #OPI,(R5) 14\$ #OPIERR,(R0) | :TEST OPI SET :NO - SKIP :SET OPI ERROR FLAG | |
| 10539 10540 10541 | 040652 040656 040660 | 032715 001402 052710 | 000400 000040 | | 14\$: | BIT BEQ BIS | #HVRC,(R5) 16\$ #HVRCERR,(R0) | :TEST HVRC SET :NO - SKIP :SET HVRC FLAG | |
| 10542 10543 10544 10545 10546 | 040664 040670 040672 | 032715 001402 052710 | 000200 | | 16\$: | BIT BEQ BIS | #BSE,(R5) 17\$ #BSERR,(R0) | :TEST BSE ERROR FLAG :NO - SKIP :SET BSE FLAG | |

| CZR6KGO CZR6KG. | RK6 FCT P11 2 | CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | | | -81 15:17 PAGE ROUTINE | 196 |
|--|--|--|----------------------------|--------|-------|---|--|---|
| 10547 10548 | 040676 | 012700 | 050070 | | 17\$: | MOV | #GRP3ER,RO | SET POINTER TO GROUP 3 FLAGS |
| 10549 10550 10551 10552 10553 | 040702 040706 040710 | 032713 001402 052710 | 010000 000001 | | | BIT BEQ BIS | #NED,(R3) 18\$ #NEDERR,(R0) | :TEST NED SET ;NO - SKIP ;SET NED FLAG |
| 10553 10554 10555 10556 | 040714 040720 040722 | 032711 001402 052710 | 004000 000002 | | 18\$: | BIT BEQ BIS | #CTO,(R1, 19\$ #CTOERR,(R0) | ;TEST CTO SET ;NO - SKIP ;SET CTO FLAG |
| 10556 10557 10558 10559 10560 | 040726 040732 040734 | 032713 001402 052710 | 000400 000004 | | 19\$: | BIT BEQ BIS | #UFE,(R3) 20\$ #UFERR,(R0) | :TEST UFE SET :NO - SKIP :SET UFE FLAG |
| 10561 10562 10563 | 040740 040744 040746 | 032713 001402 052710 | 001000 000010 | | 20\$: | BIT BEQ BIS | #MDS,(R3) 21\$ #MDSERR,(R0) | ;TEST MDS SET ;NO - SKIP ;SET MDE FLAG |
| 10564 10565 10566 10567 | 040752 040756 040760 | 032713 001402 052710 | 002000 000020 | | 21\$: | BIT BEQ BIS | #PGE,(R3) 22\$ #PGERR,(R0) | :TEST PGE SET :NO - SKIP :SET PGE FLAG |
| 10568 10569 10570 10571 | 040764 040770 040772 | 032713 001402 052710 | 004000 000040 | | 22\$: | BIT BEQ BIS | #NEM, (R3) 23\$ #NEMERR, (R0) | :TEST NEM SET :NO - SKIP :SET NEM FLAG |
| 10572 10573 10574 10575 | 040776 041002 041004 | 032713 001402 052710 | 020000 000100 | | 23\$: | BIT BEQ BIS | #UPE,(R3) 24\$ #UPERR,(R0) | : TEST UPE SET :NO - SKIP : SET UPE FLAG |
| 10576 10577 10578 10579 | 041010 041014 041016 | 032715 001402 052710 | 000001 000200 | | 24\$: | BIT BEQ BIS | #ILF,(R5) 25\$ #ILFERR,(R0) | :TEST ILF SET :NO - SKIP :SET ILF FLAG. |
| 10580 10581 10582 10583 10584 10585 10586 10587 10588 10589 10590 10591 | | | | | | THE FLA AN ERRO TEMP11, THE ERR THE CON OCCURRE & 12 AR | G IN \$TMP13 INDI R WAS EXPECTED A & TEMP12 SPECIF ORS FOUND AND ST TENTS OF GRP1,2, D BUT WERE NOT E E MODIFIED TO IN BOTH CONDITIONS | XECUTED ONLY IF ERRORS WERE EXPECTED. CATES IF ND THE CONTENTS OF TMP10, Y WHICH ERRORS. THESE ARE COMPARED AGAINST ORED IN GRP1ER, GRP2ER, AND GRP3ER. & 3 ARE MODIFIED TO INDICATE ERRORS THAT XPECTED. THE CONTENTS OF \$TMP10,11, DICATE EXPECTED ERRORS THAT DID NOT CAN EXIST AT THE SAME TIME AND MUST |
| 10592 10593 10594 10595 10596 | 041022 041026 041030 041034 | 005737 001423 012704 012705 | 001250 050064 001242 | | 25\$: | TST BEQ MOV MOV | \$TMP13 110\$ #GRP1ER,R4 #\$TMP10,R5 | :CHECK IF AN ERROR WAS EXPECTED :NO - SKIP :GET ADDRESS OF ERROR :GET ADDRESS OF EXPECTED ERRORS |
| 10597 10598 10599 10600 10601 10602 | 041040 041042 041044 041046 041050 041052 | 011500 011401 020001 001003 005000 005001 | | | 26\$: | MOV MOV CMP BNE CLR | (R5).R0 (R4).R1 R0.R1 27\$ R0 | :GET EXPECTED ERROR :GET GROUP ERROR FLAGS :ARE THEY EQUAL? :NO - SKIP :CLEAR EXPECTED ED :CLEAR OCCURED |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 197
CZR6KG.P11 28-AUG-81 15:16
                                                          OPERATION CHECK ROUTINE
                                                                                  28$
 10603 041054 000403
                                                                      BR
 10604
10605
10606
10607
10608
10609
                                                                                                        :STORE EXPECTED ERRORS :RESET EXPECTED THAT OCCURRED
                                                          27$:
                                                                                 RO,R3
           041056
                       010003
           041060
041062
041064
                                                                                 R1.R0
R3.R1
                       040100
                                                                      BIC
                                                                                                      RESET OCCURRED THAT EXPECTED
                       040301
                                                                      BIC
                                                                                 RO. (R5)+
                                                                                                        STORE EXPECTED THAT DID NOT OCCUR
                                                          28$:
                       0.10025
                                                                      MOV
                                                                                 R1,(R4)+
           041066 041070
                       010124
                                                                      MOV
10610
10612
10613
10614
10615
10616
                                   001250
                                                                                 #$TMP13,R5
                                                                                                        :ALL GROUPS CHECKED.
                       022705
                                                                      CMP
          041074
                       001361
                                                                      BNE
                                                                                 26$
                                                                                                        :NO - LOOP
                                                                      THE FOLLOWING CODE:
                                                                     A. DETERMINES WHICH FORMAT IS TO BE USED

B. LOADS THE ADDRESSES OF THE ASCIZ TEXT INTO THE SELECTED ERROR TABLE ITEM AND FORMAT FIELD

C. COUNTS THE NUMBER OF ERRORS THAT MUST BE REPORTED
  10617
  10618
                                                                      D. GETS DRIVE STATUS IF GROUP 1 ERROR.
  10619
 10620
10621
10622
10623
                                                                      THE DECISION OF WHICH ERROR IS TO BE USED
                                                                     IS BASED ON THE ERROR GROUP (OR GROUPS) THAT HAVE FLAGS SET. IF ANY BIT IS SET IN GROUP 1.2. OR 3. GROUP 1 FORMAT (ERROR 4 OR 5) WILL BE USED; ANY SET IN GROUP 2 OR 3. GROUP 2 (ERROR 6) WILL BE USED; AND A
  10624
                                                                      FLAG SET IN GROUP 3 ONLY, GROUP 3 (ERROR 7) IS USED.
  10626
  10627
                                                                      THE FORMAT TO BE USED IN THE CONTROLLING FACTOR IN HOW THE
 10628
10629
10630
10631
10632
10633
                                                                      ERROR TRAP IS CHANGED IN THE MAIN CALL. IF GROUP 1 FORMAT IS
                                                                     USED THE ERROR TRAP WILL BE CHANGED TO ERROR 4 OR 5 (DEPENDING ON AVAILABILITY OF DRIVE STATUS), GROUP 2 FORMAT WILL BE ERROR 6, AND GROUP 3 WILL BE ERROR 7. ONLY THE LOW ORDER BYTE OF THE ERROR TRAP WILL BE ALTERED. THE SP WILL BE POINTING TO THE LOCATION THAT CONTAINS THE ERROR CALL TRAP.
  10634
  10635
                                                                      IF THE STATUS IS READ FROM THE DRIVE WITH NO PROBLEM,
  10636
10637
                                                                      ERROR 4 IS USED. IF ANY ERROR IS ENCOUNTERED READING STATUS. ERROR 5 IS USED. ERROR 5 INCLUDES A WARNING MESSAGE.
 10638
10639
10640
10641
10642
10643
           041076
                     005004
                                                          110$:
                                                                                                         :CLEAR COUNTERS
           041100
                                                                                  R5
                       005005
                                                                      CLR
                      012700
012701
012703
012710
012711
013746
                                  001224
001226
050205
                                                                      MOV
                                                                                                         :LOAD POINTERS FOR TEMPORARY STORAGE OF ADDRESS
                                                                                 #$TMP1,R0
           041102
                                                                                 #$TMP2,R1
            041106
                                                                                                         ; WHERE ASCIZ ADDRESSES GO
                                                                      MOV
                                                                                 #GPSUMF, R3
#DF007A, (R0)
                                                                                                         POINTERS TO GROUP SUMMARY FLAGS
            041112
                                                                      MOV
  10644
                                   061052
                                                                      MOV
                                                                                                         PRESET FOR GRP3 ERR MESSAGE BUILD
            041116
            041122
                                   001442
                                                                      MOV
                                                                                  #DH7N, (R1)
  10646
            041126 041132
                                   050070
                                                                                  GRP3ER, - (SP)
                                                                                                         :GET GROUP 3 ERRORS, PUT ON STACK
                                                                      MOV
                                                                                                         GO COUNT NUMBER AT ERRORS
                                                                                 R4.BITCNT
(SP)
                       004437
                                                                      JSR
                                   036242
  10648
10649
10650
10651
10652
10653
            041136
                       005716
                                                                                                         :ANY ERRORS?
                                                                      TST
                                                                                                        :NO - SKIP
:ADD IN ERROR TOTAL
:SET BIT TO INDICATE GROUP 3 ERROR
            041140
                       001403
                                                                                  29$
                                                                      BEQ
                                                                                 (SP), R5
#GRP3ST, (R3)
            041142
                       061605
052713
                                                                      ADD
                                   000004
                                                                      BIS
            041144
            041150 041152
                     005726
                                                          29$:
                                                                                  (SP)+
                                                                      TST
                                                                                                         CLEAR OFF STACK
  10654
                                   001250
                                                                      TST
                                                                                  STMP13
                                                                                                         :ERROR EXPECTED
  10655
            041156
                       001412
                                                                      BEQ
                                                                                  31$
                                                                                                         :NO - SKIP
  10656
                                                                                  $TMP12,-(SP)
                                                                                                         PUT GROUP 3 NOT RECEIVED ERRORS ON STACK
            041160
                       013746
                                   001246
                                                                      MOV
  10657
                       004437
                                                                                  R4, BITCHT
                                                                                                         COUNT NUMBER OF ERRORS.
            041164
                                   036242
                                                                      JSR
            041170
                                                                                                         :WERE THERE ANY
                       005716
```

| CZR6KGO CZR6KG.P | RK6 FCT! | NL CTRL [B-AUG-81 | 1AG 15:16 | MACY11 | 30(1046) OPERATIO | 28-AUG | -81 15:17 PAGE ROUTINE | 198 |
|----------------------------------|--|--|----------------------------|--------|----------------------|--------------------------|--|---|
| 10660 | 041172 041174 041200 | 001403 052713 061604 | 000040 | | | BEQ BIS ADD | 30\$ #GP3NR,(R3) (SP),R4 | :NO - SKIP :SET GROUP 3 NOT RECEIVED ERROR FLAG :ADD COUNT TO TOTAL THESE |
| 10664 10665 | 041202 041204 041210 041214 | 005726 013746 004437 005716 | 050066 036242 | | 30\$: 31\$: | TST MOV JSR TST | (SP)+ GRP2ER,-(SP) R4,BITCNT (SP) | CLEAR OFF STACK GET GROUP 2 ERRORS FOR COUNTING COUNT BITS ANY SET? |
| 10668 | 041214 041216 041220 041224 041226 041232 | 001407 052713 061605 012710 012711 | 000002 | | | BEQ BIS ADD MOV | 32\$ #GRP2ST,(R3) (SP),R5 #DF006A,(R0) | :NO - SKIP :SET FLAG FOR GROUP 2 ERRORS :ADD INTO TOTAL :STORE ADDRESS FOR BUILDING REPORT |
| 10672 10673 10674 | 041236 041240 | 005726 | 001432 | | 32\$: | TST | #DH6N,(R1) (SP)+ \$TMP13 | CLEAR OFF STACK * CANY EXPECTED ERRORS |
| 10675 10676 | 041244 041246 041252 041256 | 001416 013746 004437 005716 | 001244 036242 | | | BEQ MOV JSR TST | 34\$ \$TMP11,-(SP) R4,BITCNT (SP) | :NO - SKIP :GET GROUP 2 NOT RECEIVED ERRORS :COUNT NUMBER OF BITS :ANY SET? |
| 10679 10680 10681 10682 | 041260 041262 041266 041270 | 001407 052713 061604 012710 | 000020 061026 | | | BEQ BIS ADD MOV | 33\$ #GP2NR,(R3) | :NO - SKIP :SET FLAG FOR GROUP 2 NOT RECEIVED :ADD INTO TOTAL :STORE ADDRESS FOR BUILDING REPORT |
| 10683 10684 10685 | 041274 | 012711 005726 013746 | 050064 | | 33\$: 34\$: | MOV TST MOV | #DH6N, (R1) (SP)+ GRP1ER,-(SP) | CLEAR OFF STACK GET GROUP 1 ERROR FLAGS |
| 10687 10688 10689 10690 | 041306 041312 041314 041316 | 004437 005 716 001407 052713 | 036242 | | | JSR TST BEQ BIS | R4,BITCNT (SP) 35\$ #GRP1SI,(R3) | COUNT THE NUMBER OF BITS . ANY SET? NO - SKIP SET FLAG FOR GROUP 1 ERRORS SET |
| 10691 10692 10693 | 041322 041324 041330 041334 | 061605 012710 012711 005726 | 060742 001412 | | 35\$: | ADD MOV MOV TST | (SP),R5 #DF004A,(R0) #DH4N,(R1) (SP)+ | :ADD INTO TOTAL :LOAD ADDRESS FOR BUILDING REPORT :CLEAR OFF STACK |
| 10695 10696 10697 | 041336 041342 041344 041350 | 005737 001416 013746 004437 | 001250 001242 036242 | | •• | TST BEQ MOV JSR | \$TMP13 60\$ \$TMP10,-(SP) R4,BITCNT | ;ANY EXPECTED ERRORS? ;NO - SKIP ;GET GROUP 1 NO RECEIVED ERROR ;COUNT # OF BITS |
| 10699 10700 10701 | 041354 041356 041360 041364 | 005716 001407 052713 061604 | 000010 | | | TST BEQ BIS ADD | (SP) 36\$ #GP1NR,(R3) (SP),R4 | :ANY SET? :NO - SKIP :SET FLAG FOR GROUP 1 NOT RECEIVED :ADD INTO TOTAL |
| 10703 10704 10705 | 041366 041372 041376 041400 | 012710 012711 005726 032713 | 060742 001412 000011 | | 36\$: 60\$: | MOV MOV TST BIT | #DF004A,(R0) #DH4N,(R1) (SP)+ | ; CLEAR OFF STACK. (3) ; ANY GROUP 1 ERROR |
| 10707 10708 10709 | 041404 041406 041412 041416 | 001414 042713 004437 000401 | 040000 | | | BEQ BIC JSR BR | 52\$ #DR'STER, (R3) R4, GETDRS 51\$ | ;NO - SKIP |
| 10711 10712 10713 | 041420 041422 041426 041432 | 000406 012710 012711 052713 | 060772 001422 040000 | | 51\$: | BR MOV MOV BIS | 52\$ #DF005A,(R0) #DH5N,(R1) #DRSTER,(R3) | :NO ERROR RETURN :CHANGE TO FORMAT 5 - STORE ADDRESS :FOR BUILDING REPORT :SET DRIVE STATUS ERROR |

```
10715 041436
                                               52$:
10716
                                                         THE ERRORS ARE COUNTED, FLAGS SET TO INDICATE WHICH ERRORS ARE TO BE REPORTED, AND THE ERROR FORMAT HAS BEEN SELECTED.
10718
10719
10720
10721
10722
10723
                                                         THE FOLLOWING CODE WILL TYPE ALL THE ERRORS, LOAD THE
                                                         PROPER HEADER MESSAGE ADDRESS IN THE ERROR ITEM TABLE
                                                         AND LOAD THE PROPER HEADER MESSAGE ADDRESS IN THE PROPER
                                                         DF TABLE.
10724
                                                         AT THIS TIME
10725
                                                              R5 CONTAINS EITHER THE NUMBER OF ERRORS THAT OCCURRED BUT WERE
10726
                                                                   NOT EXPECTED OR
10727
                                                                   THE NUMBER OF ERRORS THE OCCURRED IF NONE WERE EXPECTED
10728
10729
10730
                                                              R4 CONTAINS THE NUMBER OF ERRORS THAT WERE EXPECTED BUT
                                                                   DID NOT OCCUR.
                                                              $TMP10 CONTAINS GROUP 1 ERRORS THAT WERE EXPECTED BUT DID NOT OCCUR
$TMP11 CONTAINS GROUP 2 ERRORS THAT WERE EXPECTED BUT DID NOT OCCUR
$TMP12 CONTAINS GROUP 3 ERRORS THAT WERE EXPECTED BUT DID NOT OCCUR
10731
10732
                                                             GRP1ER CONTAINS GROUP 1 ERRORS THAT OCCURRED OR OCCURRED AND WERE NOT EXPECT GRP2ER CONTAINS GROUP 2 ERRORS THAT OCCURRED OR OCCURRED AND WERE NOT EXPECT GRP3ER CONTAINS GROUP 3 ERRORS THAT OCCURRED OR OCCURRED AND WERE NOT EXPECT
10733
10734
10735
10736
                                                         (R1) = #$TMP2 CONTAINS THE ADDRESS OF THE HEADER MESSAGE ADDRESS IN
10737
                                                                   DF THAT MUST BE ALTERED TO IDENTIFY THE OPERATION
10738
                                                         (RO) = #$TMP1 CONTAINS THE ADDRESS OF THE HEADER MESSAGE ADDRESS IN
10739
                                                                   THE ERROR ITEM TABLE THAT MUST BE ALTERED TO PROVIDE A
10740
                                                                   PROPER MESSAGE TO REPORT.
                                                         (R3) = #GRSUMF CONTAIN FLAGS TO INDICATE WHICH OF THE GROUP
10742
                                                                   ERROR FLAG FIELDS HAVE ERROR BITS STORED.
        041436
                  032777
                           020000 137474
                                                                   #SW13, aSWR
                                                                                      : IS REPORT INHIBITED?
10744
        041444
                  001402
                                                                   37$
                                                         BEQ
                                                                                      :NO - SKIP
10745
        041446
                  000137
                            042034
                                                         JMP
                                                                   49$
                                                                                      :ELSE EXIT
10746
        041452
                  005737
                            001250
                                               37$:
                                                         TST
                                                                   $TMP13
                                                                                      ; WERE ERRORS EXPECTED?
10747
        041456
                  001004
                                                         BNE
                                                                   38$
                                                                                      : YES - SKIP
10748
10749
                                                         IF NO ERRORS WERE EXPECTED, $TMP10,11, &12 ARE NOT MEANINGFUL
10750
10751
        041460
                  012771
                           057745
                                     000000
                                                         MOV
                                                                   #DH007,a(R1)
                                                                                      :HEADER = ERROR IN OPERATION
10752
        041466
                  000411
                                                         BR
                                                                   39$
10753
10754
10755
10756
10757
10758
        041470
                  012771
                            057566
                                     000000
                                               38$:
                                                                   #DH005,a(R1)
                                                         MOV
                                                                                      :PRESET HDRMSG = EXPECTED NOT SET
        041476
                  032713
                            000070
                                                                   #GP1NR!GP2NR!GP3NR, (R3) ; ANY NOT RECEIVED ERRORS?
                                                         BIT
        041502
                  001003
                                                                   39$
                                                                                      : YES - SKIP
                                                         BNE
                  012771
                                                                  #DH006,a(R1)
        041504
                            057663
                                     000000
                                                         MOV
                                                                                      SET MESSAGE TO UNEXPECTED ERROR SET
                  013701
                            001540
        041512
                                               39$:
                                                                                      GET CS1
                                                         MOV
                                                                   T.CS1,R1
        041516
                  042701
                            177741
                                                                  #177741,R1
                                                         BIC
                                                                                      CLEAR ALL BUT COMMAND
10759
10760
                            050210
        041522 016170
                                     000000
                                                         MOV
                                                                   CMNDLB(R1), a(R0) ; MOVE ADDRESS OF COMMAND MESSAGE
10761
                                                                                      : INTO REPORT
10762
        041530 041534
                 032713
                                                                   #GRP1ST!GRP2ST!GRP3ST, (R3); ANY GPR ERRORS?
                            000007
                                                         BIT
10763
                                                                                      :NO - SKIP GPR REPORT
                                                         BEQ
                                                                   46$
10764
10765
                                                         PRINT ALL THE ERRORS CONTAINED IN THE GPR1.2.3ER (UNEXPECTED ERRORS)
10766
10767
        041536
                  013701
                            050070
                                                                   GRP3ER.R1
                                                                                      GET GROUP 3 ERROR FLAGS
        041542
10768
                  012700
                            050110
                                                                  #GRP3MS,RO
                                                                                      ; SET POINTER TO GRP3 ERROR MESSAGES
                                                         MOV
        041546
                  005037
10769
                            001252
                                                         CLR
                                                                  STMP14
                                                                                      : CLEAR GROUP PRINTING INDICATOR
        041552
                  012737
                                     001254
                            000021
                                                                  #17.,$TMP15
                                               405:
                                                         MOV
                                                                                      :PRESET SHIFT COUNT
```

MACY11 30(1046) 28-AUG-81 15:17 PAGE 199

OPERATION CHECK ROUTINE

CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16

| | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30 (1046) OPERATI | 28-AUG | -81 15:17 PAGE ROUTINE | 200 |
|---|--|--|--|--------|----------------------|---|--|--|
| 10771 10772 10773 10774 10775 10776 10777 | 041560 041562 041564 041566 041572 041576 041600 | 000241 006001 103406 062700 005337 001371 000411 | 000002 001254 | | 41\$: 141\$: | CLC ROR BCS ADD DEC BNE BR | R1 42\$ #2,R0 \$1MP15 41\$ 44\$ | CLEAR CARRY ROTATE ERROR FLAGS WAS BIT SHIFTED OUT SET? NO - BUMP POINTER DEC SHIFT COUNT LOOP IF SHIFT NOT ZERO |
| 10778 10779 10780 10781 10782 10783 10784 10785 | 041602 041606 041612 041614 041616 041620 041622 | 011037 104401 104401 000000 005305 001362 000427 | 041614 001273 | | 42\$: 43\$: | MOV TYPE TYPE .WORD DEC BNE BR | (RO) .43\$,\$CRLF R5 141\$ 46\$ | GET ERROR MESSAGE ADDRESS FROM TABLE TYPE CRLF TYPE ERROR MESSAGE MESSAGE ADDRESS GOES HERE DECEREMENT TOTAL ERROR COUNT. LOOP IF ZERO ELSE EXIT GPR ERROR PRINT LOOP |
| 10786 10787 10788 10789 10790 10791 10792 10793 10794 10795 10796 10797 10798 10799 | 041624 041626 041630 041634 041636 041642 041646 041652 041654 041662 041664 041670 041674 041674 | 005713 100455 005737 001007 013701 012700 005237 000737 022737 001407 013701 012700 005237 000724 | 001252 050066 050130 001252 000002 050064 050146 001252 | 001252 | 44\$: | TST BMI TST BNE MOV INC BR CMP BEQ MOV INC BR | (R3) 47\$ \$TMP14 45\$ GRP2ER,R1 #GRP2MS,R0 \$TMP14 40\$ #2,\$TMP14 46\$ GRP1ER,R1 #GRP1MS,R0 \$TMP14 40\$ | :TEST GPSUMF FLAG FOR PRINTING ERROR NOT RECEIVED :YES - SKIP :PRINTING GROUP 3? :NO -SKIP :ELSE SET TO GROUP 2, GET GRP2ER :& SET POINTER TO GROUP 2 ERROR MESSAGE TABLE :BUMP TO INDICATE PRINTING GROUP 2 :GO RESTART PRINT LOOP :PRINTING GROUP 1? :YES - EXIT GPR ERROR PRINT LOOP. :ELSE SET TO GROUP 1, GET GROUP 1 ERROR :SET POINTER TO GROUP 1 ERROR MESSAGE TABLE :BUMP TO INDICATE PRINTING GROUP 1 :RESTART PRINT LOOP. |
| 10800 10801 10802 10803 | 041702 041706 | 005737 001452 | 091250 | | 46\$: | TST BEQ | \$TMP13 : | :EXPECTING ERRORS? :NO - SKIP |
| 10804 | | | | | : | PRINT A | LL ERRORS CONTAI | INED IN \$TMP10, 11, 12(NOT RECEIVED ERRORS) |
| 10806 10807 10808 10809 10810 10811 10813 10813 10814 10815 10816 10817 10818 10819 10820 10821 10823 10823 10824 10825 10826 | 041712 041714 041720 041722 041726 041730 041734 041740 041750 041754 041760 041762 041762 041770 041774 042000 042004 042006 | 005713 100423 032713 001445 032713 001404 104401 104401 052737 010405 013701 012700 000672 005737 001007 013701 012700 005237 000662 022737 001407 | 000070 000007 001273 057663 100000 001246 050110 001252 001244 050130 001252 | 050206 | 146\$: 47\$: | BIT BEQ BIT BEQ TYPE TYPE BIS MOV MOV MOV BR TST BNOV MOV INC BR CMP BEQ | 49\$ | :TEST IF PRINTING NOT RECEIVED ERRORS :YES - SKIP P3NR, (R3): ANY NOT RECEIVED ERRORS :NO - SKIP GRP3ST, (R3): ANY NOT RECEIVED ERRORS? :NO - SKIP LABEL FOR UNEXPECTED ERRORS :TYPE (RLF :TYPE HEADER FOR PREVIOUS ERRORS :SET PRINTING NOT RECEIVED ERRORS SWITCH :MOVE TOTAL ERRORS TO R5 :GET GRP3 NOT RECEIVED ERRORS :SET POINTER TO GROUP 3 MESSAGES :GO START PRINT LOOP :PRINTING GROUP 3? :NO - SKIP :ELSE SETUP TO PRINT GROUP 2 - GET ERRORS :& SET POINTER TO GROUP 2 MESSAGE TABLE :BUMP TO INDICATE GROUP 2 PRINTING :GO START PRINT LOOP :PRINTING GROUP 1? :YES - EXIT LOOP |

| CZR6KGO CZR6KG.I | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) OPERATI | 28-AUG ON CHECK | -81 15:17 PAGE ROUTINE | | |
|---|--|--|--------------------------------------|--------|---------------------|---|--|---|---|
| 10827 10828 10829 10830 | 042016 042022 042026 042032 | 013701 012700 005237 000647 | 001242 050146 001252 | | | MOV MOV INC BR | \$TMP10,R1 #GRP1MS,R0 \$TMP14 40\$ | :SET POINTER TO GROUP 1 MESSAGE :TABLE AND GET GROUP 1 ERRORS. :BUMP TO INDICATE GROUP 1 PRINTING :START LOOP AGAIN. | |
| 10831 10832 10833 | 042034 | 032713 | 000077 | | 49\$: | BIT | #77,(R3) | : TEST IF ANY ERRORS TO BE REPORTED : GRP:ST:GRP2ST:GRP3ST | |
| 10834 10835 10836 10837 10838 10839 | 042040 042042 042044 042050 | 001004 104414 062716 000002 | 000002 | | | BNE RESREG ADD RTI | 61\$ #2,(SP) | : GP1NR!GP2NR'GP3NR :YES - SKIP :ELSE EXIT :BUMP FOR GOOD RETURN | |
| 10839 10840 10841 10842 10843 10844 10845 | 042052 042060 042064 042066 | 112776 032713 001403 112776 | 000007 000022 000006 | 000000 | 61\$: | MOVB BIT BEQ MOVB | #GRP2ST!GP2NR,() 50\$ | ;PRESET FOR GROUP 3 ERROR RETURN. R3);ANY GROUP 2 ERRORS? ;NO - SKIP ;ELSE SET FOR GROUP 2 ERROR RETURN | |
| 10844 10845 10846 10847 10848 10849 10850 10851 | 042074 042100 042102 042110 042114 042116 | 032713 001411 112776 032713 001403 112776 | 000011 000004 040000 000005 | 000000 | 50\$: | BIT BEQ MOVB BIT BEQ MOVB | 53\$ #4.a(SP) | R3) ;ANY GROUP 1 ERRORS? ;NO - SKIP ;ELSE SET FOR GROUP 1 ERROR RETURN. ;CHECK IF ERROR GETTING DRIVE STATUS ;NO - SKIP ;ELSE CHANGE RETURN FORM GROUP 1 | |
| 10851 10852 10853 10854 10855 10856 10857 10858 10859 10860 | 042124 042130 042132 042136 042140 042146 042154 042156 | 005737 001011 013700 006300 016037 162737 104414 000002 | 001264 001302 033122 090002 | 001264 | 54\$: | ASL MOV SUB RESREG RTI | STESTN,RO RO \$SW08TB(RO),\$ES | :ABORT TO PRESENT TEST AFTER CAPE :ERROR IS REPORTED :BUT GO TO NEXT SCOPE STATEMENT :RETURN | |
| 10861 10862 10863 10864 10865 10866 10867 10868 10869 10870 10871 | | | | | SBITL | BAD SEC THE FIE CALL IS THAT HA L.DCYL THAT IS IS PLAC IS PLAC | TOR CHECK LD WHOSE ADDRESS CHECKED TO SEE VE THE CYLINDER AND L.DT. IF A SI BAD FOR THAT CYLINDER ED ON THE STACK. | IS IN THE LOCATION AFTER THE IF ANY SECTORS ARE LISTED THEREIN AND TRACK ADDRESS SPECIFIED IN ECTOR IS FOUND IN THIS FIELD LINDER AND TRACK, THE SECTOR NUMBER THE TOTAL NUMBER OF BAD SECTORS AFTER THE ENTIRE | • |
| 10872 10873 10874 | | | | | | CALL: | | CK LD TO BE SEARCHED> | |
| 10875 10876 10877 10878 10879 10880 10881 | 042160 042164 042170 042172 042176 042200 | 012637 010437 011404 005037 005714 100417 | 001236 001240 001234 | | BDSRCK: | MOV MOV CLR TST BMI | (SP)+,\$TMP6 R4,\$TMP7 (R4),R4 \$TMP5 (R4) | STORE OLD R4 CONTENTS GET RETURN ADDRESS GET POINTER TO FIELD TO BE CHECKED CLEAR A COUNTER TEST IF FIELD HAS NO (OR NO MORE)ENTRIES YES - EXIT | |
| 10882 | 042202 | 023724 | 001614 | | | CMP | L.DCYL. (R4)+ | IS THIS ENTRY FOR THIS CYLINDER? | |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 202
CZR6KG.P11 28-AUG-81 15:16
                                                          BAD SECTOR CHECK
10883 042206 001012
10884 042210 005204
10885 042212 123714
10886 042216 001005
                                                                                                           :NO - SKIP
                       005204
                                                                                                           BUMP TO TRACK
                                                                       INC
                                                                                   L.DT.(R4)
2$
-(SP)
                                                                                                           : IS ENTRY FOR THIS TRACK?
                                   001607
                                                                       CMPB
                                                                       BNE
                                                                                                           :NO - SKIP
                                                                                                           CLEAR STACK LOCATION
 10887
10888
           042220
                       005046
                                                                       CLR
           042222
042224
042230
                                                                                   -(R4),(SP)
$TMP5
                                                                                                           :PUT SECTOR NUMBER ON STACK :BUMP COUNTER -
                       114416 005237
                                                                       MOVB
 10889
                                   001234
                                                                       INC
 10890
                                                                                   3$
                                                                                                           :BRANCH
                       000401
                                                                       BR
 10891
           042232
042234
042236
                       005304
 10892
                                                           2$:
                                                                       DEC
                                                                                   R4
                                                                                                           : DECREMENT POINTER TO WORD ALIGN
 10893
10894
                                                                                                           BUMP TO NEXT ENTRY
                                                                       TST
                                                                                   (R4) +
                       000757
                                                                       BR
                                                                                   1$
 10895
           042240
042244
042250
042254
                                                                                   $TMP5,-(SP)
$TMP6,-(SP)
$TMP7,R4
 10896
10897
                      013746
                                  001234
                                                                                                          :PUT COUNT ON STACK :PUT OLD R4 CONTENTS BACK ON STACK
                                                           48:
                                                                       MOV
                                                                       MOV
                     013704
 10898
                                   001240
                                                                       MOV
                                                                                                           SET UP RETURN
 10899
                       005724
                                                                       TST
                                                                                   (R4) +
                                                                                                           BUMP PAST PARAMETER
 10900
           042256
                       000204
                                                                       RTS
                                                                                   R4
                                                                                                           :RETURN
 10901
 10902
                                                           SBITL DATA GENERATION AND COMPARE ROUTINE

CALLS: JSR R4.GENCOM
 10903
10904
 10905
                                                                                   CONTROL WORD
 10906
 10907
                                                                                               R4.GENCOM
                                                                                   CONTROL WORD
 10908
 10909
                                                                                   LENGTH
 10910
 10911
                                                                                               R4, GENCOM
 10912
                                                                                   CONTROL WORD
                                                                                   RELOCATION CONSTANT
 10914
                                                                                   LENGTH
 10915
 10916
                                                                 RETURN:
 10917
                                                                       R4 IS ADJUSTED IN THE CODE FOR THE FOLLOWING RETURNS:
 10918
                                                                       THE FIRST CALL RETURNS TO THE LOCATION FOLLOWING THE
 10919
                                                                       CONTROL WORD. THIS IS UNCONDITIONAL.
 10920
                                                                       THE SECOND CALL RETURNS TO THE LOCATION FOLLOWING THE LENGTH IF THE OPERATION REQUIRES DATA COMPARE AND DATA MISCOMPARED.
 10921
 10922
10923
10924
                                                                       IF DATA IS, TO BE GENERATED ONLY OR NO DATA COMPARE
                                                                       ERRORS OCCURRED, THE RETURN IS TO LENGTH +4.
 10925
10926
10927
                                                                       THE THIRD CALL IS IDENTICAL TO THE SECOND.
 10928
                                                                 DEFINITION OF CONTROL WORD:
                                                                      BIT 15 - DO COMPARE OPERATION OF IBUFF (SOURCE) TO OBUFF
(DESTINATION). EXPECTED VALUES ARE IN OBUFF (DESTINATION.

BIT 14 - RESUME COMPARE OPERATION FROM POINT LEFT BY LAST COMPARE.

BIT 13 - INVOKE MEMORY MANAGEMENT FOR SOURCE (IBUFF).

BIT 12 - INVOKE MEMORY MANAGEMENT FOR DESTINATION (OBUFF).

BIT 11 - REPEAT FIRST WORD OF SELECTED PATTERN THROUGHOUT OBUFF.

BIT 10 - CLEAR IBUFF TO PATTERN SELECTED.
 10929
 10930
 10931
 10932
 10933
 10934
 10935
                                                                       BIT 9 - BUILD HEADERS, CONSIDERING BS FILES
BIT 8 - BUILD HEADERS, ALL SECTORS INDICATE GOOD SECTORS.
BIT 7 - HEADER OPERATION SPECIFIED (EITHER COMPARE OR BUILD).
 10936
 10937
 10938
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 203
CZR6KG.P11 28-AUG-81 15:16 DATA GENERATION AND COMPARE ROUTINE
```

BIT 6 TO 0 - PATTERN SELECT FIELD, OCTAL ENCODED. O INDICATES NO DATA GENERATION, 1 IS ALL ZEROS, AND 7 IS ALL ONES. 10940 10941 OTHER PATTERNS PROVIDED ARE PATTERNS 2-6, 8-16. : * 10942 10943 EXPLANATION OF CALLS: THE CALL WITH CONTROL WORD THE ONLY PARAMETER IS USED FOR BUILDING OR COMPARING HEADERS OR RESUMING A COMPARE OPERATION. 10944 10945 10946 10947 THE CALL WITH CONTROL WORD AND LENGTH AS PARAMETERS IS USED 10948 FOR DATA GENERATION OR COMPARE AND FOR IBUFF INITALIZATION. 10949 THE CALL WITH CONTROL WORD, RELOCATION CONSTANT, AND LENGTH IS USED FOR DATA GENERATION OR COMPARE WITH MEMORY MANAGEMENT. 10950 10951 10952 10953 10954 DESCRIPTION: 10955 THIS ROUTINE IS MULTI-PURPOSE AND WILL PERFORM THE FOLLOWING:

A. BUILD HEADERS, EITHER 20 OR 22 SECTORS/TRACK MODE. THE
ROUTINE WILL BUILD THE HEADERS AS ALL GOOD SECTORS (BIT 8)
OR TAKE THE BAD SECTOR FILES (HARDWARE OR SOFTWARE) FOR
EITHER FORMAT) INTO ACCOUNT AND BUILD THE HEADERS WITH THE
SECTORS MARKED BAD IF ANY SECTORS FOR THE CYLINDER - TRACK 10956 10957 10958 10959 10960 ARE LISTED THEREIN (BIT 9). 10962 10963 10964 COMPARE THE CONTENTS OF IBUFF AND OBUFF (BIT 15). THE CONTENTS OF THE BUFFER MAY BE HEADERS OR DATA. A 10965 10966 HEADER COMPARE OPERATION MAY BE SPECIFIED (BIT 7) WHICH WILL CAUSE THE COMPARE TO BE LIMITED TO 74(8) OR 102(8) WORDS OF HEADERS. THE LENGTH DEPENDS ON THE FORMAT BIT THAT WAS LAST SPECIFIED IN L.CS1. THE HEADERS 10967 10968 10969 MAY BE BUILT BEFORE THE COMPARE AS PART OF THE OPERATION (BIT 15 AND BIT 8 OR 9). DATA CAN ALSO BE 10970 10971 10972 GENERATED BEFORE THE COMPARE (NON-ZERO BITS 6-0). 10973 RESUME COMPARE OPERATION. IF A COMPARE OPERATION DETECTS A MISCOMPARE, THE ROUTINE RETURNS TO CALLER BUT STORES PARAMETERS SUCH THAT THE COMPARE CAN BE RESUMED. THIS IS DONE BY CALLING GENCOM WITH BIT 14 SET IN THE CONTROL WORD. 10974 10975 10976 10977 10978 10979 10980 D. DATA GENERATION OR COMPARE USING MEMORY MANAGEMENT. 10981 MEMORY MANAGEMENT CAN BE INVOKED FOR EITHER 10982 SOURCE OR DESTINATION BUT NOT FOR BOTH. IN THIS 10983 MANNER, DATA GENERATION CAN BE MADE TO 10984 PLACE DATA ANYWHERE IN AVAILABLE MEMORY. LIKEWISE 10985 DATA COMPARE WILL COMPARE THE CONTENTS OF IBUFF TO 10986 ANY AREA OF AVAILABLE MEMORY. 10987 042260 042260 010046 10988 GENCOM: 10989 :: PUSH RO ON STACK MOV RO,-(SP) :: PUSH R1 ON STACK 10990 042262 010146 R1,-(SP) MOV :: PUSH R3 ON STACK 010346 10991 042264 R3,-(SP) MOV R5.-(SP) (R4)+.R0 :: PUSH R5 ON STACK :GET PARAMETER WORD 042266 10992 010546 MOV 10993 012400 MOV 012737 10994 042272 056312 001520 MOV #EM54 . EM15N PRESET FOR HEADER COMPARE ERROR

| 0 | ZR6KGO ZR6KG.I | RK6 FCT1 P11 28 | NL CTRL I 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) DATA GE | 28-AUG- NERATION | -81 15:17 PAGE AND COMPARE ROU | 204 TINE |
|---|---|--|--|--|--------------------------------------|---------------------|--|--|---|
| | 10995 10996 10997 10998 | 042300 042304 042306 042314 042320 | 032700 001005 012737 000137 | 000200 056341 043046 | 001520 | 18\$: | BNE MOV JMP | #BIT7,R0 18\$ #EM55,EM15N 17\$ | :HEADER OPERATION SPECIFIED? :YES - SKIP :CHANGE FOR DATA COMPARE ERROR :ELSE JUMP TO DATA ROUTINE |
| | 11005 | 042320 042322 042326 042330 042334 | 010446 032700 001002 000137 113701 013703 012705 | 001400 042630 001607 001614 000005 | | 19\$: | MOV BIT BNE JMP MOVB MOV MOV | R4,-(SP) #BIT8:BIT9,R0 19\$ 11\$ L.DT,R1 L.DCYL,R3 #5,R5 | ;;PUSH R4 ON STACK ;MUST HEADERS BE BUILT? ;YES - SKIP ;ELSE JUMP TO HEADER COMPARE ;START HEADER BUILD ROUTINE ;GET TRACK AND CYL ;SET COUNT TO SHIFT TRACK FOR HDR WORD |
| | 11006 11007 11008 11009 11010 11011 | 042350 | 006301 005305 001375 | 000(0) | | 1\$: | ASL DEC BNE | R1 R5 1\$ | :SHIFT TRACK :DECREMENT TRACK :LOOP UNTIL COUNT O |
| | 11012 11013 11014 11015 11016 | 042362 | 012704 032737 001404 012704 052701 | 000026 010000 000024 001000 | 001600 | | MOV BIT BEQ MOV BIS | #26,R4 #CFMT,L.CS1 2\$ #24,R4 #BIT9,R1 | :PRESET FOR 26 SECTOR MODE :IS IT 24 SECTOR MODE? :NO - SKIP :CHANGE COUNT FOR 24 SECTOR MODE :SET 24 SECTOR MODE BIT IN WRD 2 OF HDR |
| | 11012 11013 11014 11015 11016 11017 11018 11019 11020 11021 11022 11023 11024 11025 11026 | 042422 | 052701 012705 010325 010125 010337 010115 040137 040315 053725 | 140000 072414 001224 001224 001224 | | 2\$: 3\$: | BIS MOV MOV MOV MOV BIC BIC BIS | #BIT15!BIT14,R1 #OBUFF,R5 R3.(R5)+ R1.(R5)+ R3.\$TMP1 R1.(R5) R1.\$TMP1 R3.(R5) \$TMP1,(R5)+ | SET BS BITS TO INDICATE GOOD SECTOR SET POINTER TO ADDRESS WHERE HEADERS GO INSERT CYLINDER INSERT TRACK AND SECTOR CALCULATE HVRC WORD: COMPLETE HVRC WORD INSERTION |
| | 11027 11028 11029 11030 11031 11032 11033 | 042436 042440 042442 042444 | 005304 001402 005201 000762 | | | | DEC BEQ INC BR | R4 4\$ R1 3\$ | :DECREMENT HEADER COUNT :DONE? - YES. SKIP :BUMP SECTOR :LOOP |
| | 11032 11033 11034 11035 11036 11037 11038 | 042446 042452 042454 042456 042460 | 032700 001003 005700 100464 000534 | 001000 | | 4\$: 10\$: | BIT BNE IST BMI BR | #BIT9,R0 5\$ R0 11\$ | :MUST HEADERS BE CORRECTED FOR TABLE ENTRIES? :YES - SKIP :IS THIS A COMPARE OPERATION? :YES-GO DO HDR COMPARE :ELSE GET OUT |
| | 11038 11040 11041 11042 11043 11044 | 042462 042470 042476 042504 042506 | 013737 012737 032737 001403 013737 | 001640 100000 010000 001636 | 042520 001224 001600 042520 | 5\$: | MOV MOV BIT BEQ MOV | BSF26P.6\$ #BIT15,\$TMP1 #CFMT,L.CS1 8\$ BSF24P.6\$ | :PRESET FOR BS FACTORY LIST :SET BIT TO BE RESET IN BAD HEADER :IS THIS 26 SECTOR MODE? :YES - SKIP :ELSE CHANGE FOR 24 SECTOR MODE |
| | 11045 11046 11047 11048 | 042514 042520 042522 042524 | 004437 000000 012605 001417 | 042160 | | 8\$: 6\$: | JSR .WORD MOV BEQ | R4.BDSRCK 0 (SP)+.R5 9\$ | GO CHECK FOR BAD SECTOR THIS ADDRESS POINTER TO FILE TO BE CHECKED GOES HERE GET # OF BAD SECTORS THIS PACK ADDRESS SKIP IF ZERO |
| | 11049 | 042526 | 011601 | | | 7\$: | MOV | (SP),R1 | GET 1ST BAD SECTOR NUMBER |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) DATA GI | 28-AUG | -81 15:17 PAGE AND COMPARE ROUT | 205 INE |
|---|----------------------------|---|---|---|
| 11051 042530 006301 11052 042532 006301 11053 042534 061601 11054 042536 062601 11055 042540 062701 000002 11056 042544 043761 001224 11057 042552 043761 001224 11058 042560 005305 11059 042562 001361 | 072414 072416 | ASL ASL ADD ADD BIC BIC DEC BNE | R1 (SP),R1 (SP)+,R1 #2,R1 \$TMP1,OBUFF(R1) \$TMP1,OBUFF+2(R1) R5 7\$ | :MULTIPLY SECTOR NUMBER BY 6 TO :LOACATE SECTOR TO BE MARKED BAD :ADD 2 FOR 2ND WORD THAT SECTOR : CLEAR BIT FOR BAD SECTOR IN HDR) : CORRECT THE HVRC BIT :DECREMENT BAD SECTOR COUNT :LOOP IF NOT ZERO |
| 11060 11061 042564 032737 100000 11062 042572 001730 11063 042574 012737 040000 11064 042602 013737 001644 11065 042610 032737 010000 11066 042616 001736 11067 042620 013737 001642 11068 042626 000732 11069 | 001224 042520 001600 | BIT BEQ MOV MOV BIT BEQ MOV BR | #BIT15,\$TMP1 10\$ #BIT14,\$TMP1 BSS26P,6\$ #CFMT,L.CS1 8\$ BSS24P,6\$ 8\$ | ;WERE WE DOING BS FACTORY LIST? ;NO - GO CHECK IF COMPARE MUST BE DONE ;ELSE SET BIT TO BE RESET IN BAD HDR ;PRESET POINTER FOR 26 SECTOR MODE ;TEST IF WE ARE DOING 26 SECTOR MODE ;YES - SKIP TO START CHECK ;CHANGE POINTER TOR 24 SECTOR MODE ;SKIP TO START CHECK |
| 11070 11071 042630 012701 000102 11072 042634 032737 010000 11073 042642 001402 11074 042644 012701 000074 11075 11076 042650 012704 070414 | 001600 | START OF MOV BIT BEQ MOV | F COMPARE #102.R1 #CFMT.L.CS1 12\$ #74.R1 | :PRESET FOR 102 WORDS OF HEADER :CHECK IF 26 SECTOR MODE :YES - SKIP :CHANGE TO 74 WORDS OF HEADER |
| 11075 11076 042650 012704 070414 11077 042654 012705 072414 11078 042660 005003 11079 042662 032700 040000 11080 042666 001412 11081 042670 013705 091700 11082 042674 013704 001702 11083 042700 013703 001704 11084 042704 013701 001706 11085 042710 005701 11086 042712 001417 | 12\$: | MOV MOV CLR BIT BEQ MOV MOV MOV TST BEQ | #IBUFF,R4 #OBUFF,R5 R3 #BIT14,R0 13\$ DESHLD,R5 SRCHLD,R4 WRDNUM,R3 WRDCNT,R1 R1 50\$ | SET START OF HEADERS TO BE COMPARED SET START OF GOOD HEADERS CLEAR COUNTER IS THIS A CONTINUATION OF EARLIER COMPARE NO - SKIP GET VALUES WHERE PREVIOUS CHECK STOPPED DESTINATION AND SOURCE WORD NUMBER IN ERROR WORD COUNT LEFT IN COMPARE TEST IF WORD COUNT LEFT = 0 YES - EXIT |
| 11088 042714 032700 030000 11089 042720 001402 11090 042722 005237 177572 11091 042726 022425 11092 042730 001012 11093 042732 005203 11094 042734 005301 11095 042736 001373 11096 042740 032700 030000 11097 042744 001402 11098 042746 005337 177572 | 25\$: | BIT BEQ INC CMP BNE INC DEC BNE BIT BEQ DEC | 25\$ a#SR0 (R4)+,(R5)+ 14\$ R3 R1 25\$ | :MEM MANAGE REQUIRED? :NO - SKIP :TURN IT ON :COMPARE THE WORDS :SKIP IF NOT EQUAL :BUMP WORD NUMBER IN ERROR :DEC WORD COUNT LEFT IN COMPARE :LOOP IF NOT ZERO :MEM MANAGE IN USE? :NO - SKIP :TURN IT OFF |
| 11099 042752 11100 042752 012604 11101 042754 000427 11102 | 50\$: | MOV BR | (SP)+,R4 16\$ | ::POP STACK INTO R4 |
| 11103 11104 11105 042756 010537 001700 11106 042762 010437 001702 | 148: | MOV MOV | R5.DESHLD R4.SRCHLD | RAMETER STORAGE FOR CONTINUATION STORE DESTINATION SOURCE |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 206
CZREKGO RKE FCTNL CTRL DIAG
CZR6KG.P11
                28-AUG-81 15:16
                                                DATA GENERATION AND COMPARE ROUTINE
         042766
042772
042776
043002
                   014537
014437
010337
                                                                                        :LOAD GOOD WORD FOR REPORT
                             001202
                                                                    -(R5), $REG10
-(R4), $REG11
 11107
 11108
                                                           MOV
                                                                                                 BAD WORD
                                                                    R3.$REG12
 11109
                             001206
                                                           MOV
                                                                                                 WORD NUMBER
                                                                                        :DEC COUNT LEFTFOR CONTINUATION
 11110
                   005301
                                                           DEC
         043004
 11111
                   005203
                                                                                        BUMP BAD WORD NUMBER
                                                           INC
 11112
         043006
                   010137
                             001706
                                                           MOV
                                                                    R1.WRDCNT
                                                                                        :STORE COUNT LEFT
         043012
043016
043022
043024
                             001704
                                                                    R3.WRDNUM
#BIT12:BIT13,R0
                   010337
                                                           MOV
                                                                                                 WORD NUM IN ERROR
                   032700
 11114
                             030000
                                                                                        :MEM MANAGE IS USE?
                                                           BIT
 11115
                                                                                        :NO - SKIP
:TURN IT OFF
                                                           REQ
                                                                    15$
                   005337
 11116
                             177572
                                                                    a#SRO
                                                           DEC
         043030
043030
043032
11118
11119
                                                15$:
                                                                    (SP)+,R4
                                                                                        :: POP STACK INTO R4
: ERROR RETURN
                   012604
                                                           MOV
11120
11121
11122
11123
11124
11125
11126
11127
11128
11129
                   005724
                                                                    (R4) +
                                                           TST
         043034
                                                 168:
                                                                                        :: POP STACK INTO R5
                                                                     (SP)+,R5
                   012605
                                                           MOV
                                                                                        :: POP STACK INTO R3
                   012603
                                                                    (SP)+,R3
         043036
                                                           MOV
                                                                                        :: POP STACK INTO RT
         043040
043042
043044
                                                                    (SP)+,R1
                                                          MOV
                                                                    (SP)+,R0
                                                                                        :: POP STACK INTO RO
                   012600
                                                           MOV
                                                         · RTS
                   000204
                                                          DATA PATTERN PROCESSING ROUTINE
11130
11131
11132
11133
11134
11135
11136
11137
11138
         043046
043052
043054
043056
                   032700
                                                 175:
                                                                    #BIT14,RO
                             040000
                                                                                        : CONTINUE WITH COMPARE?
                                                           BIT
                   001402
                                                                    29$
                                                                                        :NO - SKIP
                                                           BEQ
                                                                    R4,-(SP)
28$
                                                                                        STORE RETURN
                   010446
                                                           MOV
                   000704
                                                           BR
                                                                                        : GO CONTINUE COMPARE
         043060
043064
043070
                  012705
012703
032700
                                                                    #OBUFF,R5
#IBUFF,R3
                             072414
                                                 298:
                                                           MOV
                                                                                        GET DESTINATION
                                                                                        GET SOURCE
                                                           MOV
                             030000
                                                                    #BIT12:BIT13,RO ;USE MEM MANAGE?
                                                           BIT .
 11139
         043074
                   001412
                                                                    21$
                                                                                        :NO - SKIP
                                                           BEQ
 11140
 11141
         043076
                             172354
                                                                    (R4)+,@#KIPAR6
#BIT12,R0
                   012437
                                                           MOV
                                                                                        :LOAD PAR FOR RELOCATION
11142
         043102
                   032700
                                                                                        : RELOCATE SOURCE?
                             010000
                                                           BIT
         043106
                   001403
                                                          BEQ
                                                                    20$
                                                                                        :NO - SKIP
11144
         043110
                   012705
                             140070
                                                                    #140070,R5
                                                                                        :SET DESTINATION TO USE PAR6 + OFFSET
                                                           MOV
                   000402
         043114
                                                           BR
                                                                    21$
                                                                                        :SKIP
                                                                    #140070,R3
                                                                                        :SET SOURCE TO USE PAR6 + OFFSET
 11146
         043116
                             140070
                                                 20$:
                                                           MOV
 11147
         043122 043124
                                                                                        :STORE COUNT
:STORE RETURN
 11148
                   012401
                                                 215:
                                                           MOV
                                                                    (R4) + .R1
 11149
                   010446
                                                           MOV
                                                                    R4,-(SP)
 11150
                                                                    R3,R4
                                                                                        :PUT IN IBUFF POINTER
:CLEAR R3 FOR WORD NUMBER COUNTER
         043126
                   010304
                                                           MOV
         043130
                   005003
                                                           CLR
 11152
                                                                    #77,R0
         043132
                   032700
                             000077
                                                           BIT
                                                                                        :ANY DATA PATTERN SPECIFIED?
         043136
                   001666
                                                                    13$
                                                           BEQ
                                                                                        :NO - GO DO COMPARE
11154
                                                           START OF GENERATION ROUTINE
 11156
11157
         043140
                   010537
                             001700
                                                                                        :STORE PARAMETERS FOR COMPARE
                                                           MOV
                                                                    R5, DESHLD
 11158
         043144
                   010437
                             001702
                                                           MOV
                                                                    R4, SRCHLD
 11159
         043150
                   010337
                             001704
                                                           MOV
                                                                    R3, WRDNUM
         043154
 11160
                   010137
                             001706
                                                           MOV
                                                                    R1. WRDCNT
 11161
 11162
                                                           CODE TO GENERATE DATA PATTERN IN AREA POINTED TO BY R5.
```

CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 207 CZR6KG.P11 28-AUG-81 15:16 DATA GENERATION AND COMPARE ROUTINE

11163 11164 11165 11166 043160 032700 030000 11167 043164 001402 MEMORY MANAGEMENT WILL BE TURNED ON BUT RELOCATION WILL NOT OCCUR UNLESS REQUIRED BY SWITCHES

BIT #BIT12:BIT13,RO : MEMORY MANAGEMENT REQUIRED? : NO - SKIP

. .

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG-81 15:17 PAGE DATA GENERATION AND COMPARE ROUT | 208 INF |
|--|---|---|
| 11168 043166 005237 177572 11169 043172 032700 002000 11170 043176 001403 11171 043200 010446 11172 043202 010504 11173 043204 012605 | INC @#SRO 33\$: BIT #BIT10,RO BEQ 32\$ MOV R4,-(SP) MOV R5,R4 MOV (SP)+,R5 | :TURN IT ON :GENERATE PATTERN IN IBUFF? :NO - SKIP :ELSE SWAP R4 AND R5 |
| 11174 11175 043206 122700 000001 11176 043212 001004 11177 043214 005025 11178 043216 005301 11179 043220 001375 11180 043222 000550 11181 11182 043224 122700 000007 11183 043230 001005 11184 043232 012725 177777 11185 043236 005301 11186 043240 001374 11187 043242 000540 11188 | 32\$: CMPB #1,R0 BNE 55\$ 30\$: CLR (R5)+ DEC R1 BNE 30\$ BR 22\$ | ;PATTERN 1 (ALL ZEROS.? ;NO - SKIP ;CLEAR WORD IN BUFF ;DEC WORD COUNT ;LOOP UNTIL WORD COUNT ZERO ;EXIT BUILD |
| 11182 043224 122700 000007 11183 043230 001005 11184 043232 012725 177777 11185 043236 005301 11186 043240 001374 11187 043242 000540 | 55\$: CMPB #7,R0 BNE 56\$ 31\$: MOV #-1,(R5)+ DEC R1 BNE 31\$ BR 22\$ | ;PATTERN 7 (ALL ONES)? ;NO - SKIP ;LOAD WORD IN BUFF ;DEC WORD COUNT ;LOOP UNTIL WORD COUNT ZERO ;EXIT BUILD |
| 11189 043244 122700 000002 11190 043250 001003 11191 043252 012703 047234 11192 043256 000504 11193 | 56\$: CMPB #2,R0 BNE 57\$ MOV #PATO2,R3 BR 70\$ | ;PATTERN 2 SET UP |
| 11194 043260 122700 000003 11195 043264 001003 11196 043266 012703 047274 11197 043272 000476 | 57\$: CMPB #3,R0 BNE 58\$ MOV #PATO3,R3 BR 70\$ | ;PATTERN 3 SET UP |
| 11198 11199 043274 122700 000004 11200 043300 001003 11201 043302 012703 047334 11202 043306 000470 | 58\$: CMPB #4,R0 BNE 59\$ MOV #PATO4,R3 BR 70\$ | ;PATTERN 4 SET UP |
| 11204 043310 122700 000005 11205 043314 001003 11206 043316 012703 047374 11207 043322 000462 | 59\$: CMPB #5,R0 BNE 60\$ MOV #PATO5,R3 BR 70\$ | ;PATTERN 5 SET UP |
| 11209 043324 122700 000006 11210 043330 001003 11211 043332 012703 047434 11212 043336 000454 | 60\$: CMPB #6,R0 BNE 61\$ MOV #PATO6,R3 BR 70\$ | ;PATTERN 6 SET UP |
| 11214 043340 122700 000010 11215 043344 001003 11216 043346 012703 047474 11217 043352 000446 | 61\$: CMPB #10,R0 BNE 62\$ MOV #PAT10,R3 BR 70\$ | ;PATTERN 10 SET UP |
| 11201 043302 012703 047334 11202 043306 000470 11203 11204 043310 122700 000005 11205 043314 001003 11206 043316 012703 047374 11207 043322 000462 11208 11209 043324 122700 000006 11210 043330 001003 11211 043332 012703 047434 11212 043336 000454 11213 11214 043340 122700 000010 11215 043344 001003 11216 043346 012703 047474 11217 043352 000446 11218 11219 043354 122700 000011 11220 043360 001003 11221 043362 012703 047534 11222 043366 000440 11223 | 62\$: CMPB #11,R0 BNE 63\$ MOV #PAT11,R3 BR 70\$ | ;PATTERN 11 SET UP |

| CZR6KGO RK6 FCTNL CTRL DIAG | MACY11 30(1046) 28-AUG- | -81 15:17 PAGE | 209 |
|--|---------------------------------------|---|---|
| CZR6KG.P11 28-AUG-81 15:16 | DATA GENERATION | AND COMPARE ROUT | INE |
| 11224 043370 122700 000012 | 63\$: CMPB | #12,R0 | ;PATTERN 12 SET UP |
| 11225 043374 001003 | BNE | 64\$ | |
| 11226 043376 012703 047574 | MOV | #PAT12,R3 | |
| 11227 043402 000432 | BR | 70\$ | |
| 11229 043404 122700 000013 | 64\$: CMPB | #13,R0 | ;PATTERN 13 SET UP |
| 11230 043410 001003 | BNE | 65\$ | |
| 11231 043412 012703 047634 | MOV | #PAT13,R3 | |
| 11232 043416 000424 | BR | 70\$ | |
| 11234 043420 122700 000014 | 65\$: CMPB | #14,R0 | ; PATTERN 14 SET UP |
| 11235 043424 001003 | BNE | 66\$ | |
| 11236 043426 012703 047674 | MOV | #PAT14,R3 | |
| 11237 043432 000416 | BR | 70\$ | |
| 11239 043434 122700 000015 | 66\$: CMPB | #15,R0 | ;PATTERN 15 SET UP |
| 11240 043440 001003 | BNE | 67\$ | |
| 11241 043442 012703 047734 | MOV | #PAT15,R3 | |
| 11242 043446 000410 | BR | 70\$ | |
| 11244 043450 122700 000016 | 67\$: CMPB | #16,R0 | ;PATTERN 16 SET UP |
| 11245 043454 001003 | BNE | 68\$ | |
| 11246 043456 012703 047774 | MOV | #PAT16,R3 | |
| 11247 043462 000402 | BR | 70\$ | |
| 11249 043464 012703 047774 | 68\$: MOV | #PAT16,R3 | ;SET UP FOR 16 |
| 11224 043370 122700 000012 11225 043374 001003 11226 043376 012703 047574 11227 043402 000432 11228 11229 043404 122700 000013 11230 043410 001003 11231 043412 012703 047634 11232 043416 000424 11233 11234 043420 122700 000014 11235 043424 001003 11236 043426 012703 047674 11237 043432 000416 11238 11239 043434 122700 000015 11240 043440 001003 11241 043442 012703 047734 11242 043446 000410 11243 11244 043450 122700 000016 11245 043454 001003 11246 043456 012703 047774 11247 043462 000402 11248 11249 043464 012703 047774 11250 11251 043470 032700 004000 11252 043474 001020 11253 043476 010466 11255 043502 012700 000020 11256 043506 010504 | 70\$: BIT | #BIT11,R0 | ;FIRST WORD REPEAT? |
| | BNE | 73\$ | ;YES - SKIP |
| | MOV | R4(SP) | ;STORE R4 |
| | MOV | R0(SP) | ;STORE R0 |
| | MOV | #16.,R0 | ;PRESET COUNT FOR PATTERN LENGT'! |
| | MOV | R5,R4 | ;STORE START OF BUFF |
| 11257 11258 043510 012325 11259 043512 005301 11260 043514 001405 11261 043516 005300 11262 043520 001373 11263 11264 043522 012425 | 71\$: MOV DEC BEQ DEC BNE | (R3)+,(R5)+ R1 74\$ R0 71\$ | ;MOV WORD TO BUFF ;DEC WORD COUNT ;EXIT IF ZERO ;DEC PAT LENGTH COUNT ;LOOP IF NOT ZERO |
| 11265 063526 005301 | 72\$: MOV | (R4)+,(R5)+ | ;REPEAT PATTERN IN BUFFER |
| | DEC | R1 | ;DEC WORD COUNT |
| | BNE | 72\$ | ;LOOP UNTIL WORD COUNT ZERO |
| 11266 043526 001375 11267 11268 043530 012600 11269 043532 012604 11270 043534 000403 11271 | 74\$: MOV MOV BR | (SP)+,R0 (SP)+,R4 22\$ | RESTORE RO RESTORE R4 EXIT BUILD |
| 11272 043536 011325 11273 043540 005301 11274 043542 001375 11275 | 73\$: MOV DEC BNE | (R3),(R5)+ R1 73\$ | ;MOV THE SAME WORD INTO BUFFER ;DEC WORD COUNT ;LOOP UNTIL ZERO |
| 11276 043544 032700 030000 | 22\$: BIT | #BIT12:BIT13,R0 | :MEMORY MANAGEMENT REQUIRED? |
| 11277 043550 001402 | BEQ | 34\$ | :NO - SKIP |
| 11278 043552 005337 177572 | DEC | a#SR0 | :TURN OFF MEM MANAGEMENT |
| 11279 043556 005700 | 34\$: TST | R0 | :IS COMPARE REQUIRED? |
| 11217 043330 003100 | 540. 131 | "" | , 10 CONTANT REMOTRED. |

| CZR6KGO CZR6KG.P | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) DATA GE | 28-AUG | -81 15:17 PAGE AND COMPARE ROU | 210 TINE |
|---|--|--|--|--|----------------------|--|--|--|
| 11280 11281 11282 11283 | 043560 043562 043566 043572 043576 | 100012 013705 013704 013703 | 001700 001702 001704 | | | BPL MOV MOV | 23\$ DESHLD,R5 SRCHLD,R4 WRDNUM,R3 | :NO - SKIP :RESTORE COMPARE PARAMETERS |
| 11284 11285 | 043602 | 013701 000137 | 001706 042714 | | 276 | MOV JMP | WRDCNT,R1 13\$ | GO START COMPARE |
| 11286 11287 11288 | 043606 043606 043610 | 012604 000137 | 043034 | | 23\$: | MOV JMP | (SP)+,R4 16\$ | ::POP STACK INTO R4 :GO TO EXIT |
| 11281 11282 11283 11284 11285 11286 11287 11288 11290 11291 11292 11293 11294 11295 11296 11297 11298 11299 11299 | | | | | SBTTL | PHASE LI | OCK LOOP CLOCK A UTINE IS ENTERED FIRST RUNS TEST | DJUSTMENT ROUNTINE VIA A START AT LOCATION 220(8). THE 1, 2, AND 3 TO SET UP THE INTERNAL HEN JUMPS TO THE CLOCK ADJUST ROUTINE. FIRST AVAILABLE DRIVE AND SETS AND BIT IN MR1. INSTRUCTIONS ON WHERE TO |
| 11299 | | | | | ;* ;* | THIS RO | UTINE WILL LOOP | UNTIL THE PROCESSOR IS HALTED. |
| 11301 11302 | 043614 | 104401 | 052752 | | ADJCLK: | TYPE | | ; TYPE ADJUSTMENT INSTRUCTIONS |
| 11304 11305 11306 11307 11308 11309 | 043620 043626 043634 043642 043650 043652 043660 043662 | 012762 013762 012762 032762 001774 032737 001402 005077 | 000040 001626 000001 000200 100000 136022 | 000010 000010 000000 000000 001664 | 5\$: | MOV MOV BIT BEQ BIT BEQ CLR | DRVNUM, RKCS2(R2 #1, RKCS1(R2) #RDY, RKCS1(R2) 5\$ | ; CLEAR SUBSYSTEM ; SELECT DRIVE ; WAIT FOR READY ; TEST IF CLOCK PRESENT ; NO - SKIP ; CLEAR INTERRUPT ENABLE |
| 11312 11313 11314 11315 11316 11317 11318 11319 | 043666 043674 043700 043702 043704 043712 043716 043720 043722 | 012762 012701 005301 001376 012762 012701 005301 001376 000761 | 000040 000014 000000 000014 | 000026 | 1\$: 2\$: 3\$: | MOV MOV DEC BNE MOV MOV DEC BNE BR | #DMD.RKMR1(R2) #12.,R1 R1 2\$ #0,RKMR1(R2) #12.,R1 R1 3\$ | SET DIAG MODE SET A COUNT DEC COUNT LOOP UNTIL ZERO CLEAR MR1 SET COUNT DEC COUNT LOOP UNTIL ZERO RESTART LOOP |
| 11320 11321 11322 11323 11324 11325 11326 11327 11328 11329 11330 11331 11332 11333 11334 11335 | | | | | SBTTL | THIS RO SUBSYST NECESSA IS CONT | EM IS CLEARED, T RY, CERTAIN CYLI | WHEN A CONTROL C IS TYPED. THE THE DRIVE IS RECALIBRATED, AND, IF NDERS ARE REFORMATED. THE REFORMATTING CATION REFMT WHICH CONTAINS THE ADDRESS |
| 11329 | 043724 | 012737 | 000111 | 001302 | CTRHLT: | MOV | #\$TN, \$TESTN | SET UP FOR HALT FAIL |
| 11331 | 043732 043734 | 104416 104003 | | | | TSSINIT ERROR | 3 | CLEAR SUBSYSTEM BAD INIT ERROR |
| 11334 | 043736 043742 | 113700 042700 | 001102 177400 | | | MOVB | \$TSTNM, RO #177400, RO | GET CURRENT TEST NUMBER CLEAR UNUSED BITS |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG CONTROLLED HALT | -81 15:17 PAGE SUBROUTINE | 211 |
|---|--|-------------------------------------|--|
| 11336 043746 022700 000003 11337 043752 001464 11338 043754 004437 035674 11339 043760 000113 11340 043762 000000 11341 043764 000000 11342 043766 000 11343 043767 000 11344 043770 000000 11345 11346 043772 104417 11347 043774 104423 11348 043776 104002 11351 044002 104004 11352 11353 044004 005037 001662 11354 044010 104437 11355 044012 104002 11356 11357 044014 104421 11358 044016 104004 11359 11360 044020 104416 11361 044022 104003 11362 11363 044024 005737 001676 11364 044030 001435 11365 044032 104401 053115 11366 11367 044036 004437 035674 11368 044042 000127 | CMP BEQ JSR RECAL 0 0 .BYTE .BYTE | #3,R0 PROGEND R4,LRLOAD | :TEST IF TEST NUMBER 3 :GO TO HALT PROG :LOAD 'L' REGS :RECAL :O WORDS :O IS BUFF ADDRESS :SECTOR O :TRACK O :CYLINDER O |
| 11346 043772 104417 11347 043774 104423 11348 043776 104002 | TLOADRK TWAT16 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 11350 044000 104421 11351 044002 104004 | T CHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 11353 044004 005037 001662 11354 044010 104437 11355 044012 104002 | CLR TWAT8S ERROR | INTSET 2 | CLEAR INTERRUPT FLAG ;WAIT FOR SECOND INTERRUPT |
| 11357 044014 104421 11358 044016 104004 | T CHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 11360 044020 104416 11361 044022 104003 | TSSINIT ERROR | 3 | :CLEAR SUBSYSTEM :BAD INIT ERROR |
| 11363 044024 005737 001676 11364 044030 001435 11365 044032 104401 053115 | TST BEQ TYPE | REFMT PROGEND OPRO20 | :TEST IF REFORMAT REQUIRED :NO - GO TO HALT :TYPE MESSAGE |
| 11369 044044 177676 11370 044046 072414 11371 044050 000 | JSR WRHEAD -102 OBUFF .BYTE .BYTE .312 | R4.LRLOAD | :LOAD 'L' REGS :WRHEAD :-102 WORDS :OBUFF IS BUFF ADDRESS :SECTOR 0 :TRACK 0 :CYLINDER 312 |
| 11372 044051 000 11373 044052 000312 11374 11375 044054 005737 001676 11376 044060 100002 11377 044062 005037 001614 11378 044066 004437 042260 11379 044072 001200 11380 11381 044074 104417 11382 044076 104434 11383 044100 104002 11384 11385 044102 104421 11386 044104 104004 11387 11388 044106 122737 000002 | TST BPL CLR 5\$: JSR 1200 | REFMT 5\$ L.DCYL R4,GENCOM | :TEST IF CYL 0 :NO - SKIP :ELSE LOAD FOR CYL 0 :GENERATE HEADERS |
| 11381 044074 104417 11382 044076 104434 11383 044100 104002 | TLOADRK TWAT159 ERROR | | ;LOAD RK REGS ;WAIT FOR INTERRUPT ;TO SLOW/NOT COMPLETE ERROR |
| 11385 044102 104421 11386 044104 104004 | T CHKOP ERROR | 4 ;OR 5, 6, 7 | CHECK OPERATION FOR ANY ERRORS REPORT ALL ERRORS |
| 11388 044106 122737 000002 11389 044114 001403 11390 044116 105237 001607 11391 044122 000761 | 001607 CMPB BEQ INCB BR | #2.L.DT PROGEND L.DT 5\$ | :TEST IF TRACK 2 FORMATTED :YES - SKIP :ELSE BUMP TRACK :DO NEXT TRACK |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 212
CZR6KGO RK6 FCTNL CTRL DIAG
                                                CONTROLLED HALT SUBROUTINE
CZR6KG.P11 28-AUG-81 15:16
                                                                   TYPE ,OPRO21 ;TYPE HALT MESSAGE
 11392
                  104401
012706
105037
005037
005737
 11393
         044124 044130
                                                PROGEND:
                            053211
11394
11395
11396
11397
11398
11399
                            001100
                                                         MOV
         044134
                            001103
                                                          CLRB
                                                                   SERFLG
                                                                                       :CLEAR ERROR FLAG
                                                                                      CLEAR ESCAPE
TEST IF MONITOR PRESENT
                                                                   SESCAPE.
         044140
                            001264
                                                          CLR
         044144
                            000042
                                                         TST
                                                                   a#42
         044150
044152
044156
                                                                   10$
                                                                                       :NO - SKIP
                   001404
                                                         BEQ
                   005037
                                                                                      SET FOR END OF PROGRAM
                                                                   SEOPCT
                            032020
                                                          CLR
 11400
                            031772
                                                          IMP
                                                                   $EOP
                                                                                       :GO TO END OF PASS
 11401
11402
11403
11404
11405
11406
         044162
                   000000
                                                10$:
                                                          HALT
                                                                                       :HALT PROGRAM
         044164
                   000137
                            001776
                                                          JMP
                                                                   START1
                                                                                       :GO TO RESTART IF CONTINUE
                                                .SBTTL
                                                         HALT FAIL ROUTINE
                                                         THIS ROUTINE IS ENTERED IF A HARDWARE ERROR IS DETECTED WHEN THE CARTRIDGE IS BEING REFORMATTED PRIOR TO HALT.
                                                :*
 11407
         044170
                                                ABTFAIL:
 11408
                   000240
                                                                   NOP
                                                                   ,OPRO22
PROGEND
                                                         TYPE
 11409
                   104401
                            053252
                                                                                       :TYPE HALT FAIL MESSAGE
 11410
         044176
                   000137
                                                          JMP
                                                                                       :GO STOP PROGRAM
                            044124
                                                .SBITL TYPE ROUTINE
 11411
11412
                                                ;;**********************
                                                **ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A O BYTE.
 11414
                                                ** THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 11415
                                                                   $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 11416
                                                :*NOTE2:
                                                                   $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 11417
                                                :*NOTE3:
                                                                   $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
 11418
 11419
                                                : *CALL:
 11420
11421
11422
11423
11424
11425
11426
11427
11428
                                                :*1) USING A TRAP INSTRUCTION
                                                         TYPE
                                                                    MESADR
                                                                                      :: MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
                                                : * OR
                                                          TYPE
                                                :*
                                                          MESADR
                                                :*
                                                :*
                                                STYPE: ISTB
         044202
                   105737
                            001157
                                                                   $TPFLG
                                                                                      :: IS THERE A TERMINAL?
         044206
044210
044212
044214
                                                                                      :: BR IF YES
 11429
11430
                   100002
                                                          BPL
                                                                                       : ; HALT HERE IF NO TERMINAL
                   000000
                                                          HALT
                                                                                      ::LEAVE
 11431
                   000430
                                                          BR
 11432
11433
11434
11435
                                                                                       :: SAVE RO
                   010046
                                                          MOV
                                                                   RO,-(SP)
                                                15:
                                                                                       :: GET ADDRESS OF ASCIZ STRING
:: RUNNING IN APT MODE
                                                                   a2(SP),R0
                   017600
         044216
                             000002
                                                          MOV
         044222
                   122737
                            000001
                                      001316
                                                          CMPB
                                                                   #APTENV, SENV
                                                                   62$ :: NO.GO CHECK FOR APT CONSOLE #APTSPOOL, SENVM :: SPOOL MESSAGE TO APT
         044230
                   001011
                                                          BNE
 11436
11437
         044232
                   132737
                             000100 001317
                                                          BITB
                                                                                      ::NO.GO CHECK FOR CONSOLE
::SETUP MESSAGE ADDRESS FOR APT
::SPOOL MESSAGE TO APT
         044240
                   001405
                                                          BEQ
                                                                   62$
         044242
044246
044252
044254
 11438
11439
                   010037
                                                                   RO,61$
                            044252
                                                          MOV
                   004737
                                                                   PC.$ATY3
                                                          JSR
                                                                   0 :: MESSAGE ADDRESS
#APTCSUP, SENVM :: APT CONSOLE SUPPRESSED
60$ :: YES, SKIP TYPE OUT
                   000000
132737
 11440
                                                61$:
                                                          . WORD
                             000040 001317
 11441
                                                62$:
                                                          BITB
 11442
11443
         044262
                   001003
                                                          BNE
                                                                                       :: PUSH CHARACTER TO BE TYPED ONTO STACK
         044264
                   112046
                                                2$:
                                                          MOVB
                                                                    (R0)+,-(SP)
                                                                                       .. BR IF IT ISN'T THE TERMINATOR
         044266
044270
044272
 11444
                   001005
                                                          BNE
                                                                   4$
                                                                                       : IF TERMINATOR POP IT OFF THE STACK
                   005726
                                                                    (SP)+
 11445
                                                          TST
                                                                                       :: RESTORE RO
 11446
                                                                    (SP)+,R0
                   012600
                                                60$:
                                                          MOV
                                                                   #2, (SP)
 11447
                   062716
                            000002
                                                                                       :: ADJUST RETURN PC
                                                35:
                                                          ADD
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) | 28-AUG-81 15:17 PAG | É 213 | | | |
|---|---------------------------|--|---|--|--|--|
| 11448 044300 000002 11449 044302 122716 000011 11450 044306 001430 11451 044310 122716 000200 11452 044314 001006 | | RTI CMPB #HT,(SP) BEQ 8\$ CMPB #CRLF,(SP) BNE 5\$ | ::RETURN ::BRANCH IF <ht> ::BRANCH IF NOT <crlf></crlf></ht> | | | |
| 11449 044302 122716 000011 11450 044306 001430 11451 044310 122716 000200 11452 044314 001006 11453 044316 005726 11454 044320 104401 11455 044322 001273 11456 044324 105037 044532 11457 044330 000755 11458 044332 004737 044414 11459 044336 123726 001156 11460 044342 001350 11461 044344 013746 001154 11462 11463 044354 002770 11465 044356 004737 044414 11466 044362 105337 044532 | | TST (SP)+ TYPE \$CRLF (LRB \$CHARCNT BR 2\$ | CET MEYT CHADACTED | | | |
| 11458 044332 004737 044414 11459 044336 123726 001156 11460 044342 001350 11461 044344 013746 001154 11462 | | JSR PC,\$TYPEC CMPB \$FILL(,(SP)+ BNE 2\$ MOV \$NULL,-(SP) | ::GO TYPE THIS CHARACTER ::IS IT TIME FOR FILLER CHARS.? ::IF NO GO GET NEXT CHAR. ::GET # OF FILLER CHARS. NEEDED ::AND THE NULL CHAR. | | | |
| 11463 044350 105366 000001 11464 044354 002770 11465 044356 004737 044414 11466 044362 105337 044532 11467 044366 000770 | | DECB 1(SP) BLT 6\$ JSR PC,\$TYPEC DECB \$CHARCNT BR 7\$ | ,, GO TIPE A NOLL | | | |
| 11467 044366 000770 11468 11469 | ;HORIZONTAL TAB PROCESSOR | | | | | |
| 11470 11471 044370 112716 000040 11472 044374 004737 044414 11473 044400 132737 000007 11474 044406 001372 11475 044410 005726 11476 044412 000724 11477 044414 11478 044414 105777 134524 11479 044420 100022 11480 044422 017746 134520 11481 044426 042716 177600 | 8\$: 9\$: 9\$: | TST (SP)+ BR 2\$ | ::REPLACE TAB WITH SPACE ::TYPE A SPACE ::BRANCH IF NOT AT ::TAB STOP ::POP SPACE OFF STACK ::GET NEXT CHARACTER | | | |
| 11478 044414 105777 134524 11479 044420 100022 11480 044422 017746 134520 11481 044426 042716 177600 11482 044432 122716 000023 11483 044436 001012 11484 044440 | | TSTB | ::CHAR IN KYBD BUFFER? ::BR IF NOT ::GET CHAR ::STRIP EXTRANEOUS BITS ::WAS CHAR XOFF :BR IF NOT | | | |
| 11485 044440 105777 134500 11486 044444 100375 11487 044446 117716 134474 11488 044452 042716 177600 11489 044456 122716 000021 11490 044462 001366 11491 044464 | 102\$: | TSTB | ::WAIT FOR CHAR ::GET CHAR ::STRIP IT ::WAS IT XON? :BR IF NOT | | | |
| 11492 044464 005726 11493 044466 | 10\$: | TST (SP)+ | ::FIX STACK | | | |
| 11494 044466 105777 134456 11495 044472 100375 | | TSTB a\$TPS BPL 10\$ | :: WAIT UNTIL PRINTER IS READY | | | |
| 11496 044474 116677 000002 11497 044502 122766 000015 11498 044510 001003 11499 044512 105037 044532 | 134450 000002 | MOVB 2(SP), a\$TPB CMPB #CR,2(SP) BNE 1\$ CLRB \$CHARCNT | ::LOAD CHAR TO BE TYPED INTO DATA REG. ::IS CHARACTER A CARRIAGE RETURN? ::BRANCH IF NO ::YESCLEAR CHARACTER COUNT | | | |
| 11500 044516 000406 11501 044520 122766 000012 11502 044526 001402 11503 044530 105227 | 000002 1\$: | BR STYPEX CMPB #LF,2(SP) BEQ STYPEX INCB (PC)+ | ::EXIT ::IS CHARACTER A LINE FEED? ::BRANCH IF YES ::COUNT THE CHARACTER | | | |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 214
                     28-AUG-81 15:16
CZR6KG.P11
                                                           TYPE ROUTINE
 11504 044532 000000
11505 044534 000207
                                                            $CHARCNT:.WORD
                                                                                    0
                                                                                                           :: CHARACTER COUNT STORAGE
                                                            STYPEX: RTS
11506
 11507
                                                            .SBITL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
 11508
 11509
 11510
                                                            * THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
                                                            **SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE **NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
 11511
 11512
                                                            **BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
                                                            *REPLACED WITH SPACES.
 11514
 11515
                                                            : *CALL:
                                                            ;*
 11516
                                                                        MOV
                                                                                                       :: PUT THE BINARY NUMBER ON THE STACK :: GO TO THE ROUTINE
                                                                                    NUM, - (SP)
                                                                        TYPDS
 11518
 11519
           044536
                                                           $TYPDS:
 11520
11521
11522
11523
                                                                                    RO,-(SP)
R1,-(SP)
                                                                                                        :: PUSH RO ON STACK
           044536
                        010046
           044540
                                                                                                           :: PUSH R1 ON STACK
                        010146
                                                                        MOV
                                                                                                           ::PUSH R2 ON STACK
::PUSH R3 ON STACK
::PUSH R5 ON STACK
::SET BLANK SWITCH AND SIGN
                                                                                    R2.-(SP)
           044542
                        010246
                                                                        MOV
            044544
                        010346
                                                                        MOV
                                                                                    R3,-(SP)
11524
11525
11526
11527
11528
11529
11530
11531
                                                                                    R5,-(SP)
#20200,-(SP)
20(SP),R5
1$
R5
            044546
                        010546
                                                                        MOV
            044550
                        012746
                                    020200
                                                                        MOV
            044554
                        016605
                                    000020
                                                                                                            :: GET THE INPUT NUMBER
                                                                        MOV
                                                                                                            ... BR IF INPUT IS POS.
            044560
                        100004
                                                                        BPL
                                                                                                            ::MAKE THE BINARY NUMBER POS.
::MAKE THE ASC!! NUMBER NEG.
::ZERO THE CONSTANTS INDEX
::SETUP THE OUTPUT POINTER
::SET THE FIRST CHARACTER TO A BLANK
                        005405
112766
005000
012703
112723
            044562
                                                                        NEG
                                                                                    #'-,1(SP)
RO
           044564 044572
                                   000055 000001
                                                                        MOVB
                                                                        CLR
                                                                                    #$DBLK,R3
#',(R3)+
R2
            044574
                                    044752
                                                                        MOV
 11532
11533
            044600
                                    000040
                                                                        MOVB
                                                                                                            :: CLEAR THE BCD NUMBER
            044604
                        005002
                                                            25:
                                                                        CLR
 11534
11535
11536
11537
11538
11539
                                                                                    SDTBL (RO),R1
            044606
044612
                        016001
                                   044742
                                                                                                             :: GET THE CONSTANT
                                                                        MOV
                        160105
                                                            3$:
                                                                        SUB
                                                                                    R1,R5
                                                                                                             ;; FORM THIS BCD DIGIT
                        002402
005202
                                                                                                            :: BR IF DONE
            044614
                                                                                    4$
R2
                                                                        BLT
            044616
                                                                        INC
                                                                                                            :: INCREASE THE BCD DIGIT BY 1
           044620
044622
044624
                        000774
                                                                                     3$
                                                                        BR
                                                                                    R1,R5
R2
5$
                        060105
                                                                        ADD
                                                                                                            :: ADD BACK THE CONSTANT
 11540
11541
11542
11543
                        005702
                                                                        TST
                                                                                                            :: CHECK IF BCD DIGIT=0
                                                                                                            ::FALL THROUGH IF 0
::STILL DOING LEADING 0'S?
::BR IF YES
            044626
                        001002
                                                                        BNE
                                                                                    (SP)
            044630
                        105716
                                                                        TSTB
            044632
                        100407
                                                                                    7$
                                                                        BMI
                                                                                    (SP)
 11544
11545
11546
11547
11548
11549
11550
11551
11552
11553
11554
11555
                        106316
                                                                                                            ::MSD?
            044634
                                                                        ASLB
                                                                                   (SP)
6$ ;:MSD?
1(SP),-1(R3) ;:YES--SET THE SIGN
#'O.R2 ;:MAKE THE BCD DIGIT ASCII
#',R2 ;:MAKE IT A SPACE IF NOT ALREADY A DIGIT
R2,(R3)+ ;:PUT THIS CHARACTER IN THE OUTPUT BUFFER
(R0)+ ;:JUST INCREMENTING
R0,#10 ;:CHECK THE TABLE INDEX
2$ ;:GO DO THE NEXT DIGIT
8$ ;:GO TO EXIT
R5,R2 ;:GET THE LSD
            044636
                        103003
                                                                        BCC
                        116663
052702
052702
110223
                                    000001 177777
            044640
                                                                        MOVB
            044646
                                    000060
                                                                        BIS
            044652
                                    000040
                                                                        BIS
            044656
                                                                        MOVB
                        005720
            044660
                                                                        TST
                        020027
            044662
                                    000010
                                                                        CMP
                        002746
003002
010502
                                                                                    2$ ::GO DO THE NEXT DIGIT

8$ ::GO TO EXIT

R5.R2 ::GET THE LSD

6$ ::GO CHANGE TO ASCII

(SP)+ ::WAS THE LSD THE FIRST NON-ZERO?

9$ ::BR IF NO
            044666
                                                                        BLT
           044670
                                                                        BGT
           044672
                                                                        MOV
                        000764
                                                                        BR
 11556
11557
                        105726
            044676
                                                                        TSTB
            044700
                        100003
                                                                        BPL
                                                                                    -1(SP),-2(R3)
(R3)
                                                                                                            ::YES--SET THE SIGN FOR TYPING
::SET THE TERMINATOR
 11558
            044702
                        116663
                                   177777 177776
                                                                        MOVB
                        105013
 11559
            044710
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 215
CZR6KGO RK6 FCTNL CTRL DIAG
              28-AUG-81 15:16
                                            CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
CZR6KG_P11
                 012605
012603
012602
012601
                                                                                :: POP STACK INTO R5
                                                              (SP)+,R5
 11560 044712
                                                                               :: POP STACK INTO R3
        044714
                                                              (SP)+,R3
 11561
                                                     MOV
                                                                               :: POP STACK INTO R2
                                                              (SP)+,R2
11562
11563
        044716
                                                     MOV
                                                                               :: POP STACK INTO RT
        044720
044722
                                                              (SP)+,R1
                                                     MOV
                                                                               :: POP STACK INTO RO
                                                              (SP)+,R0
11564
11565
                 012600
                                                     MOV
                                                              SDBLK
2(SP),4(SP)
                                                                                :: NOW TYPE THE NUMBER
        044724
                 104401
                          044752
                                                     TYPE
 11566
                 016666
                          000002 000004
                                                     MOV
                                                                                :: ADJUST THE STACK
 11567
        044736
                 012616
                                                     MOV
                                                              (SP)+, (SP)
                 000002
 11568
        044740
                                                     RII
                                                                                :: RETURN TO USER
                 023420
001750
                                            SDTBL:
                                                     10000.
 11569
        044742
 11570
        044744
                                                     1000.
11571
11572
11573
        044746
                 000144
                                                     100.
                                                     10.
        044752
                                            $DBLK:
                                                     .BLKW
                 000004
                                            .SBITL BINARY TO OCTAL (ASCII) AND TYPE
 11574
 11575
 11576
                                            ** THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
 11577
 11578
                                            ; *OCTAL (ASCII) NUMBER AND TYPE IT.
                                            :*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
 11579
 11580
                                            : *CALL:
 11581
                                                     MOV
                                                              NUM, - (SP)
                                                                                :: NUMBER TO BE TYPED
11582
11583
11584
                                                                                :: CALL FOR TYPEOUT
                                                     TYPOS
                                                     .BYTE
                                                                                :: N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
                                                                                ::M=1 OR 0
                                                     .BYTE
                                                                                        ::1=TYPE LEADING ZEROS
 11585
11586
11587
                                                                                         :: 0=SUPPRESS LEADING ZEROS
 11588
                                            **STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
                                            :*$TYPOS OR $TYPOC
 11589
 11590
                                            : * CALL:
 11591
                                            **
                                                     MOV
                                                              NUM, - (SP)
                                                                                :: NUMBER TO BE TYPED
 11592
                                                     TYPON
                                                                                :: CALL FOR TYPEOUT
 11593
                                            ** TYPOC --- ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
 11594
 11595
                                            : *CALL:
 11596
                                                     MOV
                                                                                :: NUMBER TO BE TYPED
                                            :*
                                                              NUM, -(SP)
 11597
                                                     TYPOC
                                                                                :: CALL FOR TYPEOUT
 11598
                                                              a(SP),-(SP)
1(SP),$0FILL
                                                                                ::PICKUP THE MODE
 11599
        044762
                 017646
                          000000
                                            $TYPOS: MOV
 11600
        044766
                 116637
                          000001
                                   045205
                                                     MOVB
                                                                                :: LOAD ZERO FILL SWITCH
                 112637
        044774
                          045207
                                                              (SP)+, SOMODE+1
                                                                                :: NUMBER OF DIGITS TO TYPE
 11601
                                                     MOVB
                 062716
                                                              #2.(SP)
                                                                                :: ADJUST RETURN ADDRESS
 11602 '045000
                          000002
                                                     ADD
 11603
                 000406
        045004
                                                              STYPON
                                                     BR
                 112737
112737
112737
                                                                               ::SET THE ZERO FILL SWITCH ::SET FOR SIX(6) DIGITS
                                   045205
045207
 11604
        045006
                                           STYPOC: MOVB
                          000001
                                                              #1,$0FILL
                                                              #6,$0MODE+1
 11605
                          000006
        045014
                                                     MOVB
                                   045204
                                            $TYPON: MOVB
 11606
        045022
                                                              #5,$OCNT
                                                                                :: SET THE ITERATION COUNT
                                                                                :: SAVE R3
 11607
        045030
                 010346
                                                     MOV
                                                              R3,-(SP)
                                                              R4,-(SP)
                                                                                ::SAVE R4
 11608
        045032
                 010446
                                                     MOV
 11609
        045034
                 010546
                                                              R5.-(SP)
                                                     MOV
        045036
                 113704
                          045207
                                                              $OMODE+1,R4
 11610
                                                     MOVB
                                                                                :: GET THE NUMBER OF DIGITS TO TYPE
         045042
                 005404
 11611
                                                     NEG
                                                              R4
 11612
11613
                 062704
        045044
                                                                                :: SUBTRACT IT FOR MAX. ALLOWED
                          000006
                                                     ADD
                                                              #6.R4
                                                                               SAVE IT FOR USE
                          045206
                                                              R4, $3MODE
$0FILL, R4
                 110437
         045050
                                                     MOVB
         045054
                 113704
 11614
                                                     MOVB
                                                                                :: PICKUP THE INPUT NUMBER
                                                              12(SP), R5
 11615
        045060
                 016605
                          000012
                                                     MOV
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) |) 28-AUG-81 15:17 PAGE PUT ROUTINE | 217 |
|--|---|---|--|
| 11672 045232 013737 045212 11673 045240 012737 045270 11674 045246 012737 000200 11675 045254 005777 133666 11676 045260 012777 000100 11677 045266 000207 11678 11679 | 000060 000062 | MOV \$TKQIN,\$TKQOUT MOV #\$TKSRV,@#TKVEC MOV #200,@#TKVEC+2 TST @\$TKB MOV #100,@\$TKS RTS PC | ::QUEUE INTO THE INPUT & OUTPUT POINTERS. ::INITIALIZE THE KEYBOARD VECTOR ::'BR'' LEVEL 4 ::CLEAR DONE FLAG ::ENABLE TTY KEYBOARD INTERRUPT ::RETURN TO CALLER |
| 11679 11680 11681 11682 11683 11684 11685 | ;*THIS ;*BY RE ;*IT IN ;*IF TH | N THE QUEUE. HE CHARACTER IS A "CONTRO | TITY KEYBOARD INTERRUPT THE INPUT BUFFER AND PUTTING OL-C'' (^C) \$TKINT IS CALLED AND THE ''CONTROL-C'' RESTART ADDRESS (CTRHLT) |
| 11686 045270 117746 133652 11687 045274 042716 177600 11688 045300 042716 177600 11689 045304 021627 000021 11690 045310 001002 11691 045312 005726 11692 045314 000002 | | : MOVB | ::PICKUP THE CHARACTER ::STRIP THE JUNK ::STRIP THE JUNK ::IS IT A RANDOM XON? ::BRANCH IF NO ::CLEAN RANDOM XON OFF STACK ::RETURN |
| 11694 045316 021627 000003 11695 045322 001007 11696 045324 104401 046422 11697 045330 004737 045220 11698 045334 005726 11699 045336 000137 043724 11700 045342 021627 000007 | | CMP (SP),#3 BNE 1\$ TYPE ,\$CNTLC JSR PC,\$TKINT TST (SP)+ JMP CTRHLT CMP (SP),#7 BNE 2\$ CMP #SWREG,SWR | ::IS IT A CONTROL C? ::BRANCH IF NO ::TYPE A CONTROL-C (^C) ::INIT THE KEYBOARD ::CLEAN UP STACK ::CONTROL C RESTART ::IS IT A CONTROL G? ::BRANCH IF NO ::IS SOFT-SWR SELECTED? |
| 11703 045356 001500 11704 11705 045360 11706 045360 022737 000001 | 045210 | CMP #1,\$TKCNT BNE 3\$ TYPE ,\$BELL TST (SP)+ BR 5\$ | ::GO TO SWR CHANGE ::IS THE QUEUE FULL? ::BRANCH IF NO ::RING THE TTY BELL ::CLEAN CHARACTER OFF OF STACK ::EXIT |
| 11713 045406 005077 133532 11714 045412 005726 11715 045414 105777 133524 11716 045420 100375 11717 045422 117746 133520 11718 045426 042716 177600 | 31\$: | CMP (SP),#23 BNE 32\$ CLR a\$TKS TST (SP)+ TSTB a\$TKS BPL 31\$ MOVB a\$TKB,-(SP) BIC #^C177,(SP) CMP (SP)+,#21 | ::IS IT A CONTROL-S? ::BRANCH IF NO ::DISABLE TTY KEYBOARD INTERRUPTS ::CLEAN CHAR OFF STACK ::WAIT FOR A CHAR ::LOOP UNTIL ITS THERE ::GET THE CHARACTER ::MAKE IT 7-BIT ASCII ::IS IT A CONTROL-Q? ::BRANCH IF NO ::REENABLE TTY KEYBOARD INTERRUPTS |
| 11719 045432 022627 000021 11720 045436 001366 11721 045440 012777 000100 11722 045446 000002 11723 045450 005237 045210 11724 045454 021627 000140 11725 045460 002405 11726 045462 021627 000175 11727 045466 003002 | 32\$: | BNE 31\$ MOV #100,a\$TKS RTI INC \$TKCNT CMP (SP),#140 BLT 4\$ CMP (SP),#175 BGT 4\$ | ::BRANCH IF NO ::REENABLE TTY KEYBOARD INTERRUPTS ::RETURN ::COUNT THIS CHARACTER ::IS IT UPPER CASE? ::BRANCH IF YES ::IS IT A SPECIAL CHAR? ::BRANCH IF YES |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 218
CZR6KGO RK6 FCTNL CTRL DIAG
                    28-AUG-81 15:16
                                                         TTY INPUT ROUTINE
CZR6KG-P11
                      042716
112677
005237
023727
 11728
11729
11730
                                  000040
177512
045212
                                                                                                        ;; MAKE IT UPPER CASE
           045470
                                                                                 #40,(SP)
(SP)+,@$TKQIN
                                                                     BIC
                                                         45:
                                                                                                        :: AND PUT IT IN QUEUE
                                                                     MOVB
           045500
045504
045512
045514
                                                                                 $TKQIN :: UPDATE THE POINTER
$TKQIN, #$TKQEND :: GO OFF THE END?
                                                                     INC
11731
11732
11733
11734
11735
11736
11737
11738
11739
                                  045212
                                              045217
                                                                     CMP
                                                                                 5$ :: BRANCH IF NO #STKQSRT, STKQIN :: RESET THE POINTER
                       001003
                                                                     BNE
                       012737
                                  045216
                                             045212
                                                                     MOV
           045522
                       000002
                                                          5$:
                                                                     RII
                                                                                                        :: RETURN
                                                         **SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
**ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
**SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
**CALL WHEN OPERATING IN TTY INTERRUPT MODE.
 11740
           045524 022737
045532 001124
                                                                                                        :: IS THE SOFT-SWR SELECTED
 11741
                                                         SCKSWR: CMP
                                                                                 #SWREG, SWR
                                  000176 001140
                                                                                                        :: EXIT IF NOT
 11742
11743
                      001124
                                                                                 15$
                                                                     BNE
                                                                                                        :: IS A CHAR WAITING?
           045534
                                  133404
                                                                     TSTB
                                                                                 a$TKS
                                                                                                        :: IF NOT, EXIT
 11744
           045540
                      100121
                                                                                 15$
                                                                     BPL
 11744
11745
11746
11747
11748
11749
11750
11751
11752
                                                                                a$TKB,-(SP)
#^C177,(SP)
(SP),#7
                       117746
                                                                                                        ::YES
           045542
                                  133400
177600
                                                                     MOVB
          045546
045552
045556
                      042716
021627
                                                                     BIC
                                                                                                        :: MAKE IT 7-BIT ASCII
                                  000007
                                                                     CMP
                                                                                                        :: IS IT A CONTROL-G?
                                                                                                        :: IF NOT, PUT IT IN THE TTY QUEUE
                      001300
                                                                     BNE
                                                                                                        :: AND EXIT
                                                         ;*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
;*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
;*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
6$: CMPB $AUTOB,#1 ;;ARE WE RUNNING IN AUTO-MODE?
BEQ 2$ ;;BRANCH IF YES
 11754
 11755
11756
11757
11758
11759
          045560 123727
045566 001674
045570 005726
045572 004737
045576 005077
                                  001134 000001
                                                                                 2$
(SP)+
                                                                                                        :: CLEAR CONTROL-G OFF STACK
                                                                     TST
                                  045220
                                                                                                        ::FLUSH THE TTY INPUT QUEUE
                                                                                 PC, STKINT
                                                                     JSR
                                                                                                        ::DISABLE TTY KEYBOARD INTERRUPTS
                                                                                 a$TKS
                                                                     CLR
                                                                                                        :: SET INTERRUPT MODE INDICATOR
 11760
           045602
                       112737
                                  000001 001135
                                                                     MOVB
                                                                                 #1.SINTAG
 11761
                                                                                 .SCNTLG
                                                                                                        :: ECHO THE CONTROL-G (^G)
 11762
           045610
                       104401
                                  046434
                                                                                                        :: TYPE CURRENT CONTENTS
 11763
           045614
                       104401
                                  046441
                                                          $GTSWR: TYPE
                                                                                  .SMSWR
 11764
11765
11766
11767
11768
                                                                                                        :: SAVE SWREG FOR TYPEOUT
           045620
                      013746
                                  000176
                                                                                 SWREG, - (SP)
                                                                     MOV
           045624
045626
045632
                                                                                                        :: GO TYPE--OCTAL ASCII(ALL DIGITS)
                       104402
                                                                     TYPOC
                       104401
                                                                                 . SMNEW
                                                                                                        : : PROMPT FOR NEW SWR
                                  046452
                                                                     TYPE
                      005046
                                                          19$:
                                                                                                        :: CLEAR COUNTER
                                                                     CLR
                                                                                 -(SP)
           045634
045636
045642
                      005046
105777
                                                                                                        ;; THE NEW SWR
                                                                     CLR
                                                                                 -(SP)
 11769
                                                                                                        :: CHAR THERE?
                                  133302
                                                          7$:
                                                                     TSTB
                                                                                 asTKS
 11770
                       100375
                                                                                 7$
                                                                     BPL
                                                                                                        :: IF NOT TRY AGAIN
 11771
 11772
11773
                       117746
                                  133276
177600
                                                                                 @$TKB,-(SP)
#^C177,(SP)
                                                                                                        ::PICK UP CHAR
           045644
                                                                     MOVB
           045650
                       042716
                                                                                                        :: MAKE IT 7-BIT ASCII
                                                                     BIC
 11774
           045654
                      021627 001015
                                                                                                        :: IS IT A CONTROL-C?
                                                                                 (SP),#3
                                  000003
                                                                     CMP
                                                                                                        :: BRANCH IF NOT
 11776
11777
                                                                     BNE
                                                                                                        ::YES, ECHO CONTROL-C (^C)
                      104401
062706
123727
           045662
                                                                     TYPE
                                                                                 ,SCNTLC
                                  046422
 11778
           045666
                                  000006
                                                                     ADD
                                                                                 #6,SP
           045672
045700
045702
                                                                                 $INTAG,#1
 11779
                                                                                                        ; : REENABLE TTY KEYBOARD INTERRUPTS?
                                  001135
                                              000001
                                                                     CMPB
                                                                                                        :: BRANCH IF NO
 11780
                       001003
                                                                     BNE
                                                                                 8$
                                                                                 #100, @$TKS
 11781
                       012777
                                                                                                        :: ALLOW TTY KEYBOARD INTERRUPTS
                                   000100
                                              133234
                                                                     MOV
 11782
           045710
                       000137
                                  043724
                                                                     JMP
                                                                                 CTRHLT
                                                                                                        :: CONTROL-C RESTART
 11783
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046 TTY IN | 28-AUG-81 15:17 PUT ROUTINE | M 1 PAGE 219 |
|--|--------------------------|---|--|
| 11786 045720 001005 11787 045722 104401 046427 11788 045726 062706 000006 | 9\$: 20\$: | CMP (SP),#25 BNE 10\$ TYPE ,\$CNTLU ADD #6,SP | ;;IGNORE PREVIOUS INPUT |
| 11789 045732 000737 11790 11791 11792 045734 021627 000015 11793 045740 001022 | | BK 173 | ;;LET'S TRY IT AGAIN |
| 11794 045742 005766 000004 11795 045746 001403 11796 045750 016677 000002 11797 045756 062706 000006 11798 045762 104401 001273 11799 045766 123727 001135 11800 045774 001003 11801 045776 012777 000100 | 133162 | TST 4(SP) BEQ 11\$ MOV 2(SP), aSWR ADD #6,SP TYPE ,\$CRLF | ;; IS IT A <cr>? ;; BRANCH IF NO ;; YES, IS IT THE FIRST CHAR? ;; BRANCH IF YES ;; SAVE NEW SWR ;; CLEAR UP STACK ;; ECHO <cr> AND <lf> ;; RE-ENABLE TTY KBD INTERRUPTS? ;; BRANCH IF NOT ;; RE-ENABLE TTY KBD INTERRUPTS ;; RE-ENABLE TTY KBD INTERRUPTS ;; RETURN</lf></cr></cr> |
| 1100/ 040004 00000/ | 133140 | CMPB \$INTAG,#1 BNE 15\$ MOV #100,@\$TKS RTI | ;;RE-ENABLE TTY KBD INTERRUPTS? ;;BRANCH IF NOT ;;RE-ENABLE TTY KBD INTERRUPTS ;;RETURN |
| 11803 046006 004737 044414 11804 046012 021627 000060 11805 046016 002420 11806 046020 021627 000067 11807 046024 003015 11808 046026 042726 000060 | | JSR PC,\$TYPEC CMP (SP),#60 BLT 18\$ CMP (SP),#67 BGT 18\$ BIC #60,(SP)+ | ::RETURN ::ECHO CHAR ::CHAR < 0? ::BRANCH IF YES' ::CHAR > 7? ::BRANCH IF YES |
| 11808 046026 042726 000060 11809 046032 005766 000002 11810 046036 001403 11811 046040 006316 11812 046042 006316 | | REQ 17\$ | 113 INTO THE LING! CHAN |
| 11813 046044 006316 11814 046046 005266 070002 11815 046052 056616 177776 11816 046056 000667 11817 046060 104401 001272 | | ASL (SP) INC 2(SP) BIS -2(SP),(SP) BR 7\$ TYPE ,\$QUES | ;; ROOM FOR NEW ONE. ;;KEEP COUNT OF CHAR ;;SET IN NEW CHAR ;;GET THE NEXT ONE ;;TYPE ? <cr><lf></lf></cr> |
| 11818 046064 000720 11819 11820 11821 11822 11823 | .DSABL | BR 20\$ LSB | ;;SIMULATE CONTROL-U |
| 11823 | :*THIS | | SINGLE CHARACTER FROM THE TTY |
| 11825 11826 11827 11828 | * * | RDCHR RETURN HERE | ::GET A CHARACTER FROM THE QUEUE ::CHARACTER IS ON THE STACK ::WITH PARITY BIT STRIPPED OFF |
| 11824 11825 11826 11827 11828 11829 11830 046066 011646 11831 046070 016666 000004 11832 046076 005066 000004 11833 046102 005046 11834 046104 012746 046112 11835 046110 000002 | 000002 \$RDCHR | MOV 4(SP),2(SP) CLR 4(SP) CLR -(SP) | ::PUSH DOWN THE PC AND ::THE PS ::GET READY FOR A CHARACTER ::PUT NEW PS ON STACK ::PUT NEW PC ON STACK |
| 11834 046104 012746 046112 11835 046110 000002 11836 046112 | 64\$: | MOV #64\$,-(SP) | ;: PUT NEW PC ON STACK ;: POP NEW PC AND PS |
| 11837 046112 005737 045210 11838 046116 001775 | 15: | TST STKCNT BEQ 1\$ | ;;WAIT ON A CHARACTER |
| 11839 046120 005337 045210 | | DEC STKCNT | ;;DECREMENT THE COUNTER |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | TTY INP | 28-AUG-81 15:17 PAGE UT ROUTINE | |
|---|---|--|--|
| | 045217 | MOVB a\$TKQOUT,4(SP) INC \$TKQOUT CMP \$TKQOUT,#\$TKQEND BNE 2\$ MOV #\$TKQSRT,\$TKQOUT RTI ********************************** | ;;GET ONE CHARACTER ;;UPDATE THE POINTER ;;DID IT GO OFF OF THE END? ;;BRANCH IF NO ;;RESET THE POINTER ;;RETURN ING FROM THE TIY |
| 11848 11849 11850 11851 | ;*CALL: ;* ;* | ROUTINE WILL INPUT A STRI | ::INPUT A STRING FROM THE TTY ::ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK ::TERMINATOR WILL BE A BYTE CF ALL 0'S |
| 11853 046156 010346 11854 046160 005046 11855 046162 012703 046412 11856 046166 022703 046422 11857 046172 101456 11858 046174 104410 11859 046176 112613 11860 046200 122713 000177 11861 046204 001022 11862 046206 005716 11863 046210 001007 11864 046212 112737 000134 11865 046220 104401 046410 11867 046230 005303 11868 046232 020327 046412 11869 046236 103434 11870 046240 111337 046410 11871 046244 104401 046410 11872 046250 000746 11873 046252 005716 11874 046254 001406 11875 046256 112737 000134 11876 046264 104401 046410 11877 046270 005016 11878 046272 122713 000025 11879 046276 001003 11880 046300 104401 046427 11881 046304 000726 11882 046306 122713 000022 11883 046312 001011 11884 046314 105013 11885 046316 104401 001273 11886 046322 104401 046412 11887 046326 000717 11888 046330 104401 001272 | \$RDLIN: 1\$: 2\$: 10\$: 046410 6\$: | MOV | ::TERMINATOR WILL BE A BYTE CF ALL O'S ::SAVE R3 ::CLEAR THE RUBOUT KEY ::GET ADDRESS ::BUFFER FULL? ::BR IF YES ::GO READ ONE CHARACTER FROM THE TTY ::GET CHARACTER ::IS IT A RUBOUT ::BR IF NO :IS THIS THE FIRST RUBOUT? ::BR IF NO :TYPE A BACK SLASH ::SET THE RUBOUT KEY ::BACKUP BY ONE ::STACK EMPTY? ::BR IF YES ::SETUP TO TYPEOUT THE DELETED CHAR. ::GO TYPE ::GO READ ANOTHER CHAR. ::RUBOUT KEY SET? ::BR IF NO :TYPE A BACK SLASH ::CLEAR THE RUBOUT KEY ::BR IF NO :TYPE A CONTROL 'U' ::GO START OVER ::S CHARACTER A ''AR'? ::BRANCH IF NO :CLEAR THE CHARACTER :TYPE A 'CR' & 'LF' :TYPE THE INPUT STRING ::GO PICKUP ANOTHER CHACTER :TYPE A 'CR' & 'LF' :TYPE THE INPUT STRING ::GO PICKUP ANOTHER CHACTER :TYPE A 'CR' & 'LF' :CLEAR THE BUFFER AND LOOP |
| 11889 046334 000712 11890 046336 111337 046410 11891 046342 104401 046410 11892 046346 122723 000015 11893 046352 001305 11894 046354 105063 177777 11895 046360 104401 001274 | 3\$: | MOVB (R3),9\$ TYPE ,9\$ CMPB #15,(R3)+ | ::CLEAR THE BUFFER AND LOOP ::ECHO THE CHARACTER ::CHECK FOR RETURN ::LOOP IF NOT RETURN ::CLEAR RETURN (THE 15) ::TYPE A LINE FEED |

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 221 CZR6KG.P11 28-AUG-81 15:16
                                                                                          :: CLEAN RUBOUT KEY FROM THE STACK
          046364
                    005726
                                                                      (SP)+
                                                                      (SP)+,R3
 11897
          046366
                    012603
                                                                                         ;; RESTORE R3
                                                           MOV
                                                                     (SP),-(SP)
4(SP),2(SP)
#$TTYIN,4(SP)
                                                                                        :: ADJUST THE STACK AND PUT ADDRESS OF THE
 11898
11899
          046370
                    011646
                                                           MOV
          046372
                    016666
                                                                                         :: FIRST ASCII CHARACTER ON IT
                              000004 000002
                                                           MOV
                                               11900
          046400
                              046412
                                       000004
 11901
                    000002
          046406
11902
11903
11904
11905
11906
11907
                                           9$: .BYTE 0
.BYTE 0
$TTYIN: .BLKB 8.
000 $CNTLC: .ASCIZ /^C/<15><12>
          046410
          046411
                       000
         046412
046422
046427
046434
                    000010
                             005015
006525
005015
                   041536
                                        000012
                                       000
                    043536
 11908
                       015
                              051412
          046441
          046446
 11909
                    036440
                              000040
                   020040
 11910
         046452
                                                 $MNEW: .ASCIZ / NEW = /
                              042516 020127
 11911
         046460
                                 000
 11912
                                                  .EVEN
                    046464
                                                  .SBTTL READ AN OCTAL NUMBER FROM THE TTY
 11914
 11915
 11916
                                                  :*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
 11917
                                                  : * CHANGE IT TO BINARY.
                                                 **THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL

**OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED

**FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST

**THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
 11918
 11919
 11920
 11921
11922
11923
11924
11925
                                                  : * CALL:
                                                  :*
                                                           RDOCT
                                                           RDOCT ;: READ AN OCTAL NUMBER RETURN HERE :: LOW ORDER BITS ARE ON TOP OF THE STACK
                                                                                          :: HIGH ORDER BITS ARE IN $HIOCT
 11926
 11927
                                                                     (SP),-(SP)
4(SP),2(SP)
                                                                                         :: PROVIDE SPACE FOR THE
          046464 011646
                                                  $RDOCT: MOV
                                                                                      :: INPUT NUMBER
 11928
                    016666 000004 000002
          046466
                                                           MOV
                                                                     RO,-(SP)
 11929
         046474
                    010046
                                                                                         :: PUSH RO ON STACK
                                                           MOV
 11930
         046476
                    010146
                                                            MOV
                                                                      R1,-(SP)
                                                                                          ;; PUSH R1 ON STACK
 11931
11932
11933
11934
11935
         046500
                    010246
                                                                      R2,-(SP)
                                                                                          :: PUSH R2 ON STACK
                                                            MOV
          046502
                    104411
                                                                                          :: READ AN ASCIZ LINE
                                                            RDLIN
                                                                                         GET ADDRESS OF 1ST CHARACTER
AND SAVE IT
CLEAR DATA WORD
          046504
                    012600
                                                                      (SP)+,R0
                                                            MOV
          046506
                    010037
                                                                      RO.5$
                              046612
                                                            MOV
          046512
                    005001
                                                                      R1
                                                            CLR
 11936
11937
          046514
                    005002
                                                            CLR
                    112046
          046516
                                                  2$:
                                                            MOVB
                                                                      (R0)+,-(SP)
                                                                                          :: PICKUP THIS CHARACTER
 11938
11939
                    001420
          046520
                                                                                         :: IF ZERO GET OUT
:: MAKE SURE THIS CHARACTER
                                                            BEQ
         046522
046526
046530
                   122716
003026
122716
002423
                                                                      #'0,(SP)
                              000060
                                                            CMPB
 11940
11941
11942
11943
                                                                      4$
#'7,(SP)
                                                                                          :: IS AN OCTAL DIGIT
                                                            BGT
                              000067
                                                            CMPB
         046534
                                                            BLT
                                                                      4$
                    006301
          046536
                                                            ASL
                                                                      R1
                                                                                          ::*2
 11944
          046540
                    006102
                                                            ROL
 11945
                    006301
          046542
                                                            ASL
 11946
11947
                    006102
          046544
                                                            ROL
          046546
                    006301
                                                            ASL
                                                                                          ::*8
 11948
         046550
                    006102
                                                            ROL
                   042716 062601
 11949
                            177770
                                                                     #*(7,(SP)
          046552
                                                           BIC
                                                                                          ::STRIP THE ASCII JUNK
         046556
 11950
                                                                                         :: ADD IN THIS DIGIT
                                                                      (SP)+,R1
                                                           ADD
         046560
                    000756
 11951
                                                                                          ::LOOP
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 222
CZR6KGO RK6 FCTNL CTRL DIAG
                                                READ AN OCTAL NUMBER FROM THE TTY
CZR6KG.P11 28-AUG-81 15:16
                                                                                        :: CLEAN TERMINATOR FROM STACK
                                                                    (SP)+
         046562
                   005726
 11953
                                                                    R1,12(SP)
                   010166
         046564
                             000012
                                                          MOV
                                                                                        :: SAVE THE RESULT
11954
11955
11956
11957
11958
11959
                   010237
012602
012601
012600
         046570
046574
                             046622
                                                                    R2.SHIOCT
                                                          MOV
                                                                                       ::POP STACK INTO R2
::POP STACK INTO R1
                                                                    (SP)+,R2
                                                          MOV
                                                                    (SP)+,R1
         046576
                                                          MOV
                                                                                       :: POP STACK INTO RO
                                                                    (SP)+,RO
                                                          MOV
         046600
                                                                                        :: RETURN
                   000002
005726
         046602
                                                          RTI
                                                                                       :: CLEAN PARTIAL FROM STACK
                                                                    (SP)+
         046604
                                                45:
                                                          IST
                                                                                       SET A TERMINATOR :: TYPE UP THRU THE BAD CHAR.
                                                                    (RO)
 11960
         046606
                   105010
                                                          CLRB
 11961
         046610
                   104401
                                                          TYPE
                                                          .WORD
 11962
         046612
                   000000
                                               5$:
                                                                    0
                                                                   SQUES
15
0
                                                                                       ::'?' 'CR' & 'LF''
                   104401 001272
000730
         046614
 11964
         046620
046622
                                                          BR
                                                SHIDCT: . WORD
 11965
                                                                                        ::HIGH ORDER BITS GO HERE
                   000000
11966
11967
11968
11969
                                                .SBITL SAVE AND RESTORE RO-R5 ROUTINES
                                                 ::***********************************
                                                 : *SAVE RO-R5
 11970
                                                 : * CALL:
 11971
 11972
                                                 *UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
 11973
 11974
                                                 : *TOP---(+16)
 11975
                                                 : + +2---(+18)
 11976
                                                 : * +4---R5
                                                 : * +6---R4
 11978
11979
                                                 : * +8---R3
                                                 : *+10---R2
                                                 : *+12---R1
 11980
                                                : *+14---RO
 11981
 11982
 11983
                                                $SAVREG:
         046624
                                                                    RO,-(SP)
R1,-(SP)
R2,-(SP)
R3,-(SP)
                                                                                        :: PUSH RO ON STACK
         046624
 11984
                   010046
                                                                                        :: PUSH R1 ON STACK
 11985
         046626
                   010146
                                                          MOV
                                                                                        :: PUSH R2 ON STACK
 11986
         046630
                   010246
                                                          MOV
 11987
                                                                                        ;; PUSH R3 ON STACK
         046632
                   010346
 11988
11989
11990
11921
                                                                                       :: PUSH R4 ON STACK
                                                                    R4.-(SP)
         046634
                   010446
                                                          MOV
                                                                                        :: PUSH R5 ON STACK
         046636
                   010546
                                                          MOV
                                                                    R5,-(SP)
                                                                    22(SP),-(SP)
22(SP),-(SP)
                                                                                        SAVE PS OF MAIN FLOW
                             000022
         046640
                   016646
                                                          MOV
                             000022
         046644
                   016646
                                                          MOV
                                                                    22(SP),-(SP)
 11992
                                                                                        :: SAVE PS OF CALL
         046650
                   016646
                             000022
                                                          MOV
 11993
                   016646
                             000022
                                                                    22(SP),-(SP)
                                                                                        :: SAVE PC OF CALL
         046654
                                                          MOV
 11994
                   000002
         046660
 11995
 11996
11997
                                                 :*RESTORE RO-R5
                                                 : * CALL:
 11998
                                                          RESREG
                                                 . *
 11999
12000
12001
         046662
                                                 $RESREG:
                                                                    (SP)+,22(SP)
(SP)+,22(SP)
(SP)+,22(SP)
(SP)+,22(SP)
(SP)+,R5
                   012666
012666
012666
012666
012605
                            000022
000022
000022
                                                                                        :: RESTORE PC OF CALL
:: RESTORE PS OF CALL
         046666
046672
046676
                                                          MOV
                                                                                        RESTORE PC OF MAIN FLOW
 12002
12003
12004
                                                          MOV
                                                                                        : RESTORE PS OF MAIN FLOW
                             000022
                                                          MOV
                                                                                        :: POP STACK INTO R5
:: POP STACK INTO R4
         046702
                                                          MOV
                                                                    (SP)+,R4
(SP)+,R3
(SP)+,R2
 12005
                   012604
         046704
                                                          MOV
                                                                                        :: POP STACK INTO R3
 12006
                   012603
         046706
                                                          MOV
                                                                                        :: POP STACK INTO R2
 12007
         046710
                   012602
                                                          MOV
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 223 CZR6KG.P11 28-AUG-81 15:16 SAVE AND RESTORE RO-R5 ROUTINES
                                                                                MOV RTI
.SBTTL POWER DOWN AND UP ROUTINES
   12008 046712 012601
12009 046714 012600
                                                                                                                                                (SP)+,R1 ::POP STACK INTO R1
(SP)+,RO ::POP STACK INTO RO
   12010
                     046716 000002
  12011
12012
12013
12014
                                                                                                           POWER DOWN ROUTINE
                     046720 012737 047060 000024 $PWRDN: MOV 046726 012737 000340 000026 MOV
  12015
12016
12017
12018
12019
12020
12021
12023
12023
12025
12026
12027
12028
12028
12031
12033
12033
12033
12033
12033
12033
12033
12044
12045
12046
12047
12047
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
12048
                                                                                                                                                    #$ILLUP, @#PWRVEC :: SET FOR FAST UP
#340, @#PWRVEC+2 :: PRIO: 7
                                                                                                                                                    RO,-(SP)
                    046734
046736
                                                                                                                               MOV
                                                                                                                                                                                        ::PUSH RO ON STACK
::PUSH R1 ON STACK
                                          010046
                                                                                                                                                    R1,-(SP)
                                          010146
                                                                                                                       MOV
                                                                                                        MOV
MOV
MOV
MOV
MOV
MOV
MOV
HAL T
                                                                                                                                                                                            ::PUSH R2 ON STACK
::PUSH R3 ON STACK
::PUSH R4 ON STACK
::PUSH R5 ON STACK
                                                                                                                                                    R2.-(SP)
R3.-(SP)
                     046740
                                          010246
                    046742
                                          010446
                                                                                                                                                    R4,-(SP)
                     046746
                                          010546
                                                                                                                                                    R5,-(SP)
                                                                                                                                                                                               :: PUSH DSWR ON STACK
                                                                                                                                                   aswr,-(SP) ;; PUSH aswr on ST
SP,$SAVR6 ;; SAVE SP
#$PWRUP, a#PWRVEC ;; SET UP VECTOR
                                          017746
010637
012737
                                                               132164 047064
                     046754
                                                               046772 000024
                     046760
                     046766
                                          000000
                                          000776
                                                                                                                                                                                               :: HANG UP
                    ; POWER UP ROUTINE

046772 012737 047060 000024 $PWRUP: MOV #$ILLUP, @#PWRVEC ;; SET FOR FAST DOWN
047000 013706 047064 MOV $SAVR6, SP ;; GET SP
047010 005237 047064 CLR $SAVR6 ;; WAIT LOOP FOR THE TTY
047010 005237 047064 1$: INC $SAVR6 ;; WAIT FOR THE INC
047014 001375 BNE 1$ ;; OF WORD
047016 012677 132116 MOV (SP) + @SWR ;; POP STACK INTO @SWR
                                                                                  BNE
MOV
MOV
MOV
                                                                                                                                                     (SP)+, aswr
(SP)+, R5 :: POP STACK INTO ASWR
:: POP STACK INTO R5
                                          012677 132116
                     047016
                    047022
047024
047026
047030
                                          012605
                                                                                                                                                                                              ::POP STACK INTO R4
::POP STACK INTO R3
                                                                                                                                                     (SP)+,R4
                                          012604
                                          012603
                                                                                                                                                     (SP)+,R3
                                                                                                                                                                                               ::POP STACK INTO RE
                                                                                                                                                     (SP)+,R2
(SP)+,R1
                                          012602
                                                                                                                            MOV
                                                                                                                                                   (SP)+,R1 ;:POP STACK INTO R1
(SP)+,R0 ;:POP STACK INTO R0

#$PWRDN,@#PWRVEC ::SET UP THE POWER DOWN VECTOR
#340,@#PWRVEC+2 ;:PRIO:7
                     047032
047034
                                          012601
                                                                                                                            MOV
                                          012600
012737
012737
                                                                                                                            MOV
                                                               046720 000024
000340 000026
                     047036
                                                                                                                            MOV
                     047044
                                                                                                                               MOV
                                                                                                                                                                    REPORT THE POWER FAILURE
                                          104401
047066
000002
                     047052
                                                                                                                               TYPE
                                                                                                      $PWRMG: .WORD
                                                                                                                                                   $POWER
                     047054
                                                                                                                                                                                               :: POWER FAIL MESSAGE POINTER
                     047056
                                                                                                                               RII
                     047060
                                           000000
                                                                                                                                                                                               :: THE POWER UP SEQUENCE WAS STARTED
                                                                                                         $ILLUP: HALT
                                                                                                                                                                                              .: BEFORE THE POWER DOWN WAS COMPLETE
                                                                                                         $SAVR6: 0
                     047062
                                           000776
                                                               047520 042527 $POWER: .ASCIZ <15><12>'POWER'
                     047064
                                           000000
                     047066 047074
                                           005015
                                          000122
                                                                                                           .SBITL TRAP DECODER
  12055
12056
12057
12058
12059
                                                                                                         **THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION :*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
                                                                                                        ; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
    12060
                                                                                                         : *GO TO THAT ROUTINE.
   12061
                                                                                  $TRAP: MOV
                                                                                                                                                    RO,-(SP) :: SAVE RO
2(SP), RO :: GET TRAP ADDRESS
   12062
                     047076 010046
                      047100 016600 000002
   12063
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 224 CZR6KG.P11 28-AUG-81 15:16 TRAP DECODER
                                                                         005740 TST
111000 MOVB
006300 ASL
016000 047132 MOV
RTS
                                                                                                                                                                                                                                                                              -(RO)
(RO),RO
(RO),RO
(CO),RO

        12064 047104 005740
       12065 047106
12066 047110
    12066
12067
12068
12069
12070
12071
12072
12073
12074
12075
12076
12077
12078
12079
12080
12081
                                       047112
                                       047116 000200
                                                                                                                                                               :: THIS IS USE TO HANDLE THE "GETPRI" MACRO
                                     .SBITL TRAP TABLE
                                                                                                                                                                                         **THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED **BY THE 'TRAP' INSTRUCTION.
       12082
                                                                                                                                                                                                                                         ROUTINE
                                                                                                                    $TRPAD: .WORD $TRAP2

$TYPE ;: CALL=TYPE

$TYPOC ;: CALL=TYPOC

$TYPOS ;: CALL=TYPOS

$TYPON ;: CALL=TYPON

$TYPDS ;: CALL=TYPOS
       12083
                                                                                                                                                                                                                                         -----
     12083
12084
12085
12086
12087
12088
12089
12090
12091
12092
12093
12094
                                      047132 047120
047134 044202
047136 045006
047140 044762
                                                                                                                                                                                                                                                                                                                                                             TRAP+1(104401) TTY TYPEOUT ROUTINE
                                                                                                                                                                                                                                                                                                                                                                                                                                         TYPE OCTAL NUMBER (WITH LEADING ZEROS)
TYPE OCTAL NUMBER (NO LEADING ZEROS)
TYPE OCTAL NUMBER (AS PER LAST (ALL)
TYPE DECIMAL NUMBER (WITH SIGN)
                                                                                                                                                                                                                                                                                                                                                             TRAP+2(104402)
TRAP+3(164403)
                                      047142
                                                                                                                                                                                                                                                                                                                                                             TRAP+4(104404)
TRAP+5(104405)
                                                                               045022
                                                                               044536
                                      047146 045614
                                                                                                                                                                                                                                       $GTSWR :: CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
                                                                                                                                                                                                                                   $CKSWR ;;CALL=CKSWR TRAP+6(104406) GET SOFT-SWR SETTING

$CKSWR ;;CALL=RDCHR TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR SEDIN ;CALL=RDLIN TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY TRAP+13(104413) SAVE RO-R5 ROUTINE TRAP+13(104413) SAVE RO-R5 ROUTINE TRAP+14(104414) RESTORE RO-R5 ROUTINE TRAP+15(104415) INTERNAL LOOP ON ERROR SINIT ;CALL=TSSINIT RAP+16(104416) INITIAL IZE SUBSYSTEM TRAP+16(104416) INITIAL IZE SUBSYSTEM TRAP+16(104416) INITIAL IZE SUBSYSTEM TRAP+20(104420) GET RK611 REGISTERS TRAP+20(104420) GET RK611 REGISTERS TRAP+21(104421) CHECK OPERATION FOR ANY ERRORS TRAP+23(104423) WAIT 16 MS IWAT32 ;CALL=TWAT34 TRAP+25(104424) WAIT 32 MS IWAT48 ;CALL=TWAT48 TRAP+25(104425) WAIT 48 MS IWAT64 ;CALL=TWAT64 TRAP+25(104426) WAIT 64 MS IWAT64 ;CALL=TWAT64 TRAP+25(104427) WAIT 80 MS IWAT96 ;CALL=TWAT64 TRAP+25(104426) WAIT 64 MS IWAT12 ;CALL=TWAT16 TRAP+30(104431) WAIT 112 MS IWAT12 ;CALL=TWAT18 TRAP+31(104431) WAIT 128 MS IWAT144 ;CALL=TWAT18 TRAP+35(104432) WAIT 16 MS IWAT19 ;CALL=TWAT18 TRAP+35(104435) WAIT 16 MS IWAT18 ;CALL=TWAT18 TRAP+35(104436) WAIT 16 MS IWAT18 ;CALL=TWAT18 TRAP+35(104437) WAIT 178 MS IWAT18 ;CALL=TWAT18 TRAP+35(104437) WAIT 160 MS IWAT18 ;CALL=TWAT18 TRAP+35(104437) WAIT 160 MS IWAT18 ;CALL=TWAT18 TRAP+35(104437) WAIT 160 MS IWAT18 ;CALL=TWAT18 TRAP+35(104437) WAIT FOR 1 SECOND IWAT18 ;CALL=TWAT18 TRAP+36(104436) WAIT FOR 2 SECONDS IWAT8 ;CALL=TWAT8 TRAP+36(104436) WAIT FOR 3 SECONDS IWAT8 ;CALL=TWAT8 TRAP+36(104437) WAIT FOR 8 SECONDS IWAT8 ;CALL=TWAT18 TRAP+37(104447) WAIT FOR 8 SECONDS IWAT8 ;CALL=TWAT18 TRAP+37(104437) WAIT FOR 8 SECONDS IWAT8 ;CALL=TWAT18 TRAP+37(104447) WAIT FOR 8 SECONDS IWAT18 ;CALL=TWAT18 TRAP+37(104447) WAIT FOR 8 SECONDS IWAT18 ;CALL=TWAT18 TRAP+37(104447) WAIT FOR 1 MIN
                                     047150
047152
047154
                                                                            045524
                                                                              046066
       12095
                                                                               046156
      12096
12097
12098
12099
12100
12101
12102
12103
12104
12105
12106
12107
12108
12109
12110
12111
12111
12111
                                       047156
                                                                              046464
                                       047160
                                                                              046624
                                     047162
047164
                                                                             046662
                                                                             037176
                                     047166
047170
                                                                               035734
                                       047172
                                                                              036164
                                        047174
                                                                               040162
                                                                              040130
035530
                                        047176
                                        047200
                                        047202
                                                                               035520
                                      047204
047206
047210
047212
047214
047216
047220
                                                                               035510
                                                                               035500
                                                                             035470
035460
035450
                                                                             035440
                                                                             035430
                                       047222
                                                                               035420
                                                                                                                                       IWAT1S
IWAT2S
IWAT8S
IWAT1M
$TERM=.-$TRPAD
       12115
                                       047224
                                                                               035410
      12116 047226
12117 047230
12118 047232
12119
                                                                               035400
                                                                             035360
                                       047232 035370
                                                                              000102
```

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 225
DATA PATTERNS
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
                                                                                                                                                                                                               .SBTTL DATA PATTERNS
   12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
12121
                                                                                                                                                                                                              :DATA PATTERN 1
                                                                                                                                                                                                                                                       PATTERN IS ALL ZEROS
                                                                                                                                                                                                               :DATA PATTERN 2
                                                                                                                                                                                                                                                       HI-LO FREQ. MIX
                                      047234
047234
047236
047240
047242
047244
047246
047250
                                                                                                                                                                                               e PATO2:
                                                                                 177777
177777
177777
052525
052525
052525
177777
                                                                                                                                                                                                                                                         177777
                                                                                                                                                                                                                                                       177777
                                                                                                                                                                                                                                                       052525
052525
052525
                                        047252
                                                                                  177777
                                                                                                                                                                                                                                                        177777
                                                                                 052525
052525
177777
052525
177252
177252
177252
                                                                                                                                                                                                                                                       052525
052525
177777
052525
177252
177252
                                        047254
                                      047256
047260
047262
047264
047266
047270
047272
                                                                                                                                                                                                                                                       172765
172765
                                                                                 172765
                                                                                                                                                                                                              : DATA PATERN 3
                                                                                                                                                                                                                                                       HI FREQ. PHASE MIX
                                      047274
047274
047276
047300
047302
                                                                                                                                                                                                               PATO3:
                                                                                  000000
                                                                                                                                                                                                                                                        000000
                                                                                  000000
                                                                                                                                                                                                                                                        000000
                                                                                  000000
177777
                                                                                                                                                                                                                                                        000000
                                                                                                                                                                                                                                                        177777
                                        047304
                                                                                   177777
                                                                                                                                                                                                                                                        177777
                                        047306
                                                                                  177777
                                                                                                                                                                                                                                                        177777
                                         047310
                                                                                   000000
                                                                                                                                                                                                                                                        000000
                                                                                  000000
177777
                                        047312
                                                                                                                                                                                                                                                       000000
177777
                                        047314
                                        047316
047320
                                                                                   177777
                                                                                                                                                                                                                                                         177777
                                                                                   000000
                                                                                                                                                                                                                                                         000000
                                        047322
                                                                                                                                                                                                                                                         177777
                                                                                   000000
177777
                                                                                                                                                                                                                                                       000000
                                       047326
047330
047332
                                                                                  000000
177777
                                                                                                                                                                                                                                                       000000
                                                                                                                                                                                                               : DATA PATTERN 4
                                                                                                                                                                                                                                                       LO FREQ. PHASE MIX
                                       047334
047334
047336
047340
047342
047344
                                                                                                                                                                                                               PATO4:
                                                                                 052525
052525
052525
125252
125252
125252
052525
052525
125252
                                                                                                                                                                                                                                                       052525
052525
052525
125252
                                         047346
                                         047350
                                         047352
047354
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 226 CZR6KG.P11 28-AUG-81 15:16 DATA PATTERNS
                                    125252
052525
125252
052525
125252
052525
125252
 12176 047356
12177 047360
12178 047362
12179 047364
12180 047370
12182 047372
12183
12184
12185 047374
12188 047376
12189 047400
12190 047402
12191 047404
12192 047406
12193 047410
12194 047412
12195 047414
12196 047416
12197 047420
12198 047422
12199 047424
12200 047422
12201 047430
12202 047432
12203
12204
12205 047434
12208 047436
12209 0474460
12210 047446
12211 047446
12212 047466
12213 047450
12214 047452
12215 047456
12217 047460
12218 047452
12218 047462
12219 047466
12221 047466
12221 047466
12222 047472
12223
12224
12225
12226
12227
                                                                                                  : DATA PATTERN 5
                                                                                                                     MAX PRECOMP. PHASE MIX
                                                                                                 PAT05:
                                      133333
                                                                                                                     133333
                                       066666
                                                                                                                     066666
                                       155555
                                                                                                                     155555
                                       155555
                                                                                                                     155555
                                       133333
                                                                                                                     133333
                                       066666
                                                                                                                     066666
                                       066666
155555
                                                                                                                     066666
                                       155555
                                                                                                                      155555
                                       133333
                                                                                                                      133333
                                      133333
                                       133333
                                     133333
133333
133333
                                                                                                                     133333
133333
                                                                                                 : DATA PATTERN 6
                                                                                                                     ROTATING BOUNDARY PULSE PRECOMP.
                                                                                                  PATO6:
                                                                                                                     121105
150442
                                      121105
                                      150442
                                      064221
132110
055044
                                                                                                                     064221
                                                                                                                     132110
                                                                                                                     055044
                                      026422
013211
105504
                                                                                                                      105504
                                      042642
021321
110550
                                                                                                                     110550
                                      044264
022132
011055
                                                                                                                     044264
022132
011055
                                       104426
042213
                                                                                                                     104426 042213
                                                                                                  : DATA PATTERN 7
                                                                                                                    FIELD OF ALL ONES
                                                                                                  : DATA PATTERN 10
  12228
12229
12230
12231
                                                                                                                     ROTATING CELL PULSE PRECOMP.
                   047474
047474
047476
                                                                                                  PAT10:
                                       026455
                                                                                                                     026455
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 227 CZR6KG.P11 28-AUG-81 15:16 DATA PATTERNS
                                                                                                                                                                                                                      045513
122645
151322
                                                                      045513
122645
151322
                                   047500
    12232
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
12233
                                  047504
047506
047510
047512
047514
047516
047520
047522
                                                                      064551
132264
055132
026455
113226
045513
                                                                                                                                                                                                                       113226
                                                                       122645
151322
                                                                                                                                                                                                                       122645
151322
                                 047524
047526
047530
047532
                                                                      064551
132264
055132
                                                                                                                                                                                                                      064551
                                                                                                                                                                                                                       055132
                                                                                                                                                                                  :DATA PATTERN 11
                                                                                                                                                                                                                       SHIFTED 1 IN A FIELD OF ZEROS
                                  047534
047534
047536
                                                                                                                                                                                  PAT11:
                                                                        000001
                                                                                                                                                                                                                        000001
                                                                        000002
                                                                                                                                                                                                                        000002
                                   047540
                                                                        000004
                                                                                                                                                                                                                        000004
                                  047542
047544
047546
047550
047552
047554
                                                                       000004
000010
000020
000040
000100
000200
                                                                                                                                                                                                                        000010
                                                                                                                                                                                                                        000020
                                                                                                                                                                                                                        000040
                                                                                                                                                                                                                       000100
                                                                        000400
                                                                                                                                                                                                                        000400
                                                                        001000
                                    047556
                                                                                                                                                                                                                       001000
                                    047560
                                                                        002000
                                                                                                                                                                                                                       002000
                                    047562
                                                                        004000
                                                                                                                                                                                                                        004000
                                    047564
                                                                        010000
                                                                                                                                                                                                                       010000
                                    047566
                                                                        020000
                                                                                                                                                                                                                        020000
                                    047570
                                                                        040000
                                                                                                                                                                                                                        040000
                                    047572
                                                                        100000
                                                                                                                                                                                                                        100000
                                                                                                                                                                                   :DATA PATTERN 12
                                                                                                                                                                                                                        SHIFTED O IN A FIELD OF ONES
                                   047574
047574
047576
                                                                                                                                                                                   PAT12:
                                                                                                                                                                                                                       177776
177775
                                                                        177776
                                                                        177775
                                   047600
047602
047604
047606
047610
047612
                                                                        177773
                                                                                                                                                                                                                        177773
                                                                                                                                                                                                                       177767
177757
                                                                        177767
                                                                        177757
                                                                                                                                                                                                                      177737
177677
177577
                                                                        177737
                                                                        177677
177577
                                                                                                                                                                                                                      177377
176777
175777
                                                                        177377
176777
                                     047616
                                    047620
047622
047624
047626
                                                                        175777
                                                                        173777
                                                                                                                                                                                                                        173777
                                                                        167777
                                                                                                                                                                                                                        167777
                                                                        157777
                                                                                                                                                                                                                        157777
     12284
12285
12286
12287
                                     047630
                                                                        137777
                                                                                                                                                                                                                        137777
                                     047632
                                                                        077777
                                                                                                                                                                                                                        077777
                                                                                                                                                                                   :DATA PATTERN 13
```

```
CZR6KGO RK6 FCTNL CTRL DIAG MACY11 30(1046) 28-AUG-81 15:17 PAGE 228 CZR6KG.P11 28-AUG-81 15:16 DATA PATTERNS
12288
12289 047634
12291 047636
12292 047640
12293 047642
12294 047644
12295 047650
12297 047652
12298 047654
12299 047656
12301 047662
12302 047664
12303 047666
12304 047670
12305 047672
12308
12309 047674
12311 047676
12312 047700
12313 047702
12313 047702
12314 047704
12315 047700
12317 047712
12318 047716
12319 047716
12319 047716
12320 047720
12321 047720
12321 047720
12321 047722
12322 047724
12323 047730
12323 047736
12324 047730
12325 047730
12327
12328
12329 047734
12331 047736
12332 047746
12333 047742
12333 047744
12335 047756
12337 047756
12337 047756
12338 047766
12340 047760
12341 04762
12342 047764
12333 047766
                                                                                                                                                                                                 ALTERNATING 0-1
                                                                                                                                                                PAT13:
                                                                                                                                                                 : DATA PATTERN 14
: ALTERNATING 1-0
                             047674
047674 125252
047676 125252
047700 125252
047702 125252
047704 125252
047706 125252
047710 125252
047712 125252
047714 125252
047716 125252
047720 125252
047720 125252
047724 125252
047726 125252
047730 125252
                                                                                                                                                                 PAT14:
                                                                                                                                                                                                125252
125252
125252
                                                                                                                                                                 :DATA PATTERN 15
                                                                                                                                                                                                 SHIFTING ZEROS AND ONES
                                                                                                                                                                PAT15:
                                                              000001
000003
000007
                                                                                                                                                                                                000001
000003
000007
                                                                 000017
                                                                                                                                                                                                 000017
                                                                 000037
                                                                                                                                                                                                  000037
                                                                 000077
                                                                                                                                                                                                  000077
                                                                000177
000377
000777
                                                                                                                                                                                                  000177
                                                                 001777
                                                                 003777
007777
                                                                 017777
                                                                                                                                                                                                  017777
                                                                 037777
```

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL DIAG 8-AUG-81 15:16 | MACY11 | 30(1046) DATA PA | 28-AUG-81 | 15:17 | PAGE | 229 | |
|--|--|--|--------|---------------------|--|----------|------|-----|--|
| 12344 | 047770 047772 | 077777 177777 | | | 077777 1777?7 | | | | |
| 12346 12347 12348 12349 12350 12351 12352 12353 12354 12355 12356 12357 12361 12362 12363 12364 12365 12366 | 047774 047774 047776 050000 050002 050004 050010 050012 050014 050016 050020 050022 050024 050026 050030 050032 | 072307 135143 156461 167230 073514 035646 016723 107351 143564 061672 030735 114356 046167 123073 151453 164616 | | :DATA PATTO: | 072307 135143 156461 167230 073514 035646 016723 107351 143564 061672 030735 114356 046167 123073 151453 164616 | ROTATING | | | |
| | | | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG-81 15:17 PAGE 230 FIELDS AND VARIABLES FOR OPERATION CHECKING | |
|---|--|----|
| 12367 12368 024000 12369 177400 12370 | SBTTL FIELDS AND VARIABLES FOR OPERATION CHECKING CS1ERBIT=24000 ;CS1 ERROR BITS SPAR & CTO CS2ERBIT=17740 ;CS2 ERROR BITS DLT, WCE, UPE, NED, NEM | |
| 12372 12373 12373 | DSERBIT=70 ;PGE,MOS,UFE; DS ERROR BITS; SPDLSS,DROT,ACLO | |
| 12375 050034 000000 12376 050036 000000 12377 050040 000000 12378 050042 000000 12379 050044 000000 12380 050046 000000 | EXPWC: .WORD 0 ;EXPECTED WORD COUNT (GIVEN) EXPUBA: .WORD 0 ;EXPECTED UPPER BA (COMPUTED) EXPBA: .WORD 0 ;EXPECTED BUS ADDRESS (COMPUTED) EXPCYL: .WORD 0 ;EXPECTED CYLINDER (COMPUTED) EXPSEC: .WORD 0 ;EXPECTED SECTOR (COMPUTED) EXPTRK: .WORD 0 ;EXPECTED TRACK (COMPUTED) | |
| 12382 050050 000000 12383 050052 000000 12384 050054 000000 12385 050056 000000 12386 050060 000000 12387 050062 000000 | REALWC: .WORD 0 ; WORD COUNT AT END OF OPERATION REALUB: .WORD 0 ; REAL UPPER BA REALBA: .WORD 0 ; BUS ADDRESS REALCY: .WORD 0 ; CYLINDER REALTRK: .WORD 0 ; TRACK REALSEC: .WORD 0 ; SECTOR | |
| 12369 12370 12371 12372 12373 12374 12375 12376 12377 050034 000000 12377 050040 000000 12378 050042 000000 12380 050046 000000 12381 12382 050050 000000 12383 050052 000000 12384 050054 000000 12385 050056 000000 12387 050062 000000 12388 12389 050064 000000 12388 12389 050064 000000 12390 12391 12392 000004 12395 0000000 12397 0000000 12399 12398 000000 12399 12399 12399 12399 12399 12399 12399 12399 12399 12400 12399 12400 12401 12402 12403 12404 12405 12406 | GRP1ER: .WORD 0 SPARERR=BIT0 SKIERR BIT1 NXFERR BIT2 DRPARERR=BIT3 FMTERR BIT5 ACLOERR=BIT6 SPERR BIT7 DROTERR=BIT8 COERR BIT9 IDAERR BIT10 WLERR BIT11 DTERR BIT11 DTERR BIT12 DRIVE TYPE FROR COERR BIT10 WLERR BIT10 WLERR BIT10 WLERR BIT11 DTERR BIT11 DTERR BIT12 NOR CERR WITH ERROR SPEROR COERR BIT11 DTERR BIT11 DTERR BIT12 NOR CERR WITH ERROR SPEROR COERR BIT11 DTERR BIT11 CERR BIT11 DRIVE UNSAFE ERROR CERROR SET ERROR CERROR SET ERROR | RR |
| 12407 050066 000000 12408 000001 12409 000002 12410 000004 12411 000010 12412 000020 12413 000040 12414 000100 | GRP2ER: .WORD 0 ECHERR= BITO :ECC HARD ERROR DCKERR= BIT1 :DATA CHECK ERROR WCKERR= BIT2 :WRITE CHECK ERROR DLTERR= BIT3 :DATA LATE ERROR OPIERR= BIT4 :OPERATION INCOMPLETE ERROR HVRCERR=BIT5 :HEADER VRC ERROR BSERR= BIT6 :BAD SECTOR ERROR | |
| 12416 050070 000000 12417 000001 12418 000002 12419 000004 12420 000010 12421 000020 12422 000040 | GRP3ER: .WORD 0 NEDERR= BITO ;NON-EXISTANT DRIVE ERROR CTOERR= BIT1 ;CONTROLLER TIME OUT ERROR UFERR= BIT2 ;UNIT FIELD ERROR MDSERR= BIT3 ;MULTIPLE DRIVE SELECT ERROR PGERR= BIT4 ;PROGRAMMING ERROR NEMERR= BIT5 ;NON-EXISTANT MEMORY ERROR | |

| And in company of the control of | CZR6KGO CZR6KG. | RK6 FCT | NL CTRL DIAG 8-AUG-81 15:16 | MACY11 | 30(1046) FIELDS | 28-AUG- | -81 15:17 PAGE ABLES FOR OPERATE | 231 ON CHECKING |
|--|---|--|--|--------|--------------------|--|--|---|
| | 12423 | | 000100 000200 | | | UPERR= ILFERR= | BIT6 BIT7 | ;UNIBUS PARITY ERROR ;ILLEGAL FUNCTION ERROR. |
| | 12425 12426 12427 12428 12429 12430 12431 12432 | 050072 | 000000 000001 000002 000004 000010 000020 000040 | | GRP4ER: | .WORD WCERR= UBAERR= BAERR= CYLERR= TRKERR= SECERR= | 0 BITO BIT1 | GROUP 4 ERROR FIELD WORD COUNT ERROR FLAG UPPER BA ERROR BUS ADDRESS ERROR FLAG CYL ADDRESS ERROR FLAG TRACK ADDRESS ERROR FLAG SECTOR ADDRESS ERROR FLAG |
| THE RESIDENCE OF PERSONS ASSESSED IN TAXABLE | 12434 12435 12436 12437 12438 12439 | 050074 050076 050100 050102 050104 050106 | 054076 054151 054123 054225 054260 054310 | | GRP4MS: | .WORD .WORD .WORD .WORD .WORD | EM10 EM11A EM11 EM12 EM13 EM14 | |
| the second secon | 12425 12425 12425 12427 12428 12430 12433 12433 12433 12433 12433 12443 12443 12444 12444 12445 12445 12445 12453 12453 12454 | 050110 050112 050114 050116 050120 050122 050124 050126 | 054342 054365 054410 054431 054456 054500 054524 054550 | | GRP3MS: | .WORD .WORD .WORD .WORD .WORD .WORD .WORD | EM15 EM16 EM17 EM18 EM19 EM20 EM21 EM22 | |
| | 12455 | 050130 050132 050134 050136 050140 050142 050144 | 054571 054602 054615 054631 054643 054670 054703 | | GRP2MS: | .WORD .WORD .WORD .WORD .WORD .WORD | EM23 EM24 EM25 EM26 EM27 EM28 EM29 | |
| | 12456 12457 12458 12459 12460 12461 12462 12463 12464 12465 12466 12467 12470 12471 12472 12473 12474 12475 12476 12477 | 050146 050150 050152 050154 050156 050160 050162 050164 050170 050172 050174 050176 050200 050202 050204 | 054724 054777 055017 055055 055123 055140 055161 055170 055213 055233 055233 055233 055337 055330 055333 | | GRP1MS: | .WORD .WORD .WORD .WORD .WORD .WORD .WORD .WORD .WORD .WORD .WORD .WORD | EM30 EM31 EM32 EM33 EM34 EM35 EM36 EM37 EM38 EM39 EM40 EM41 EM42 EM43 EM45 | |
| | 12475 12476 12477 12478 | 050206 | 000000 000001 000002 000004 | | GPSUMF: | .WORD GRP1ST= GRP2ST= GRP3ST= | 0 BIT0 BIT1 BIT2 | GROUP ERROR SUMMARY FLAGS GROUP 1 ERROR SET GROUP 2 ERROR SET GROUP 3 ERROR SET |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 232
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11
                                                      FIELDS AND VARIABLES FOR OPERATION CHECKING
                   28-AUG-81 15:16
 12479
12480
12481
12482
12483
12484
12485
12486
12487
12488
                                                                 GP1NR= BIT3
                                                                                                  :GROUP 1 ERROR NOT RECEIVED
                      000010
                                                                                                  GROUP 2 ERROR NOT RECEIVED
                                                                                                  ; GROUP
                      000020
                                                                 GP2NR= BIT4
                                                                 GP3NR= BIT5
                      000040
                                                                 DRSTER= BIT14
                                                                                                  ERROR IN GETTING DRIVE STATUS FLAG.
                      040000
                                                                 REPNR= BIT15
                                                                                                  :REPORTING NOT RECEIVED SWITCH
                      100000
                                                      .SBTTL
                                                                 TABLE OF OPERATION MESSAGE ADDRESS
                                                                 THIS TABLE CONTAINS THE ADDRESS OF ASCIZ FIELDS THAT ARE
                                                      ;*
                                                                 USED IN REPORTING TO IDENTIFY THE OPERATION BEING PERFORMED.
          050210
050212
050214
                     050250
050265
050276
 12489
12490
12491
12492
12493
12494
12495
12496
12497
12500
12501
12502
12503
12504
12505
12506
12507
12508
12510
12511
12512
12513
12514
12515
12516
12517
                                                      CMNDLB: . WORD
                                                                            OPER00
                                                                                                  :ADDRESS OF SELECT MESSAGE
                                                                            OPERO2
OPERO4
OPERO6
                                                                 . WORD
                                                                                                                   PACK ACK
                                                                                                                   DRIVE CLEAR
                                                                  . WORD
          050216
050220
050222
                     050312
                                                                  . WORD
                                                                                                                   UNLOAD
                                                                                                                   START SPINDLE
                     050321
                                                                  . WORD
                                                                            OPER10
                     050337
                                                                            OPER12
                                                                                                                   RECALIBRATE
                                                                  . WORD
          050224
                     050353
                                                                            OPER14
                                                                                                                   OFFSET
                                                                 . WORD
          050226
                                                                            OPER16
                     050362
                                                                 . WORD
                                                                                                                   SEEK
          050230
                                                                 . WORD
                                                                            OPER20
                     050367
                                                                                                                   READ DATA
          050232
                                                                 . WORD
                                                                            OPER22
                     050401
                                                                                                                   WRITE DATA
          050234
                                                                            OPER24
                     050414
                                                                 . WORD
                                                                                                                   READ HEADER
          050236
                                                                 . WORD
                                                                            OPER26
                     050431
                                                                                                                   WRITE HEADER
                                                                            OPER30
          050240
                                                                                                                   WRITE CHECK
                     050447
                                                                 . WORD
          050242
050244
                                                                            OPER32
                                                                                                   :ILLEGAL OPERATION 33
                     050463
                                                                  . WORD
                     050507
                                                                            OPER34
                                                                  . WORD
          050246
                     050533
                                                                  . WORD
                                                                            OPER36
                                                       SBTTL OPERATION MESSAGES
          050250
050256
050264
050265
050272
050276
                     051104
                                053111
                                           020105
                                                      OPEROO: .ASCIZ /DRIVE SELECT/
                     042523
                                042514
                                           052103
                          000
                                041501
000113
053111
                                           020113 OPER02: .ASCIZ /PACK ACK/
                     041501 051104
                                           020105
000122
                                                      OPERO4: .ASCIZ /DRIVE CLEAR/
                     046103
047125
                                 040505
          050304
          050312
                                 047514
                                           042101
                                                      OPERO6: .ASCIZ /UNLOAD/
          050320
                          000
                                040524
044520
                                           052122
042116
          050321
                                                      OPER10: .ASCIZ /START SPINDLE/
          050326
050334
                     051440
 12518
                      042514
                                    000
 12519
12520
12521
12522
12523
12524
12525
12526
12527
12528
12529
12530
12531
12532
12533
          050337
                          122
                                 041505
                                           046101
                                                      OPER12: .ASCIZ /RECALIBRATE/
          050344
050352
050353
                      041111
                                 040522
                                           042524
                          000
                          117
                                           042523
                                 043106
                                                      OPER14: .ASCIZ /OFFSET/
                     000124
042523
122
          050360
                                045505
040505
040524
044522
052101
042101
042504
          050362
                                                      OPER16: .ASCIZ /SEEK/
                                           020104
           050367
                                                      OPER20: .ASCIZ
                                                                            /READ DATA/
                                           000
042524
000101
           050374
                      040504
           050401
                                                      OPER22: .ASCIZ /WRITE DATA/
                     042040
042522
040505
           050406
          050414
050422
050430
050431
050436
                                           044040
                                                      OPER24: .ASCIZ /READ HEADERS/
                                            051522
                          000
                                 044522 040505
                                           042524
042504
                                                      OPER26: .ASCIZ /WRITE HEADERS/
                     044040
           050444
                                     000
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG OPERATION MESSA | -81 15:17 PAGE 233 GES |
|---|--|---|
| 12535 050447 127 044522 12536 050454 041440 042510 | 042524 OPER30: .ASCIZ 045503 | /WRITE CHECK/ |
| 12537 050462 000 12538 050463 111 046114 12539 050470 046101 043040 12540 050476 052103 047511 12541 050504 031463 000 | 043505 OPER32: .ASCIZ 047125 020116 | /ILLEGAL FUNCTION 33/ |
| 12541 050504 031463 000 12542 050507 111 046114 12543 050514 046101 043040 12544 050522 052103 047511 12545 050530 032463 000 | 043505 OPER34: .ASCIZ 047125 020116 | /ILLEGAL FUNCTION 35/ |
| 12545 050530 032463 000 12546 050533 111 046114 12547 050540 046101 043040 12548 050546 052103 047511 | 043505 OPER36: .ASCIZ 047125 020116 | /ILLEGAL FUNCTION 37/ |
| 12546 050533 111 046114 12547 050540 046101 043040 12548 050546 052103 047511 12549 050554 033463 000 12550 050557 127 044522 12551 050564 042040 052101 12552 050572 041101 051117 12553 050600 020104 044527 12554 050606 041040 042523 | 042524 OPER37: .ASCIZ 020101 042524 044124 000 | /WRITE DATA ABORTED WITH BSE/ |
| 12555 050613 12556 050613 127 044522 12557 050620 041440 042510 12558 050626 040440 047502 12559 050634 042105 053440 | 042524 OPER41: .ASCIZ | /WRITE CHECK ABORTED WITH WCE/ |
| | 052122 052111 000105 020105 040440 042105 020110 054105 052116 051117 | /WRITE DATA ABORTED WITH NON-EXISTANT MEMORY/ |
| 12569 050724 042522 042101 12570 050732 052101 020101 12571 050740 051117 042524 12572 050746 044527 044124 12573 050754 047117 042455 12574 050762 052123 047101 12575 050770 042515 047515 | 042040 OPER43: .ASCIZ 041101 020104 047040 044530 020124 054522 | /READ DATA ABORTED WITH NON-EXISTANT MEMORY/ |
| 12569 050724 042522 042101 12570 050732 052101 020101 12571 050740 051117 042524 12572 050746 044527 044124 12573 050754 047117 042455 12574 050762 052123 047101 12575 050770 042515 047515 12576 050776 000 12577 050777 127 044522 12578 051004 042040 052101 12579 051012 041101 051117 12580 051020 020104 044527 12581 051026 052440 044516 12582 051034 020123 040520 12583 051042 054524 042440 12584 051050 051117 000 | 042524 OPER44: .ASCIZ 020101 042524 044124 052502 044522 051122 | /WRITE DATA ABORTED WITH UNIBUS PARITY ERROR/ |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 234
CZR6KGO RK6 FCTNL CTRL DIAG
                                                        ASCII MESSAGES
CZR6KG.P11 28-AUG-81 15:16
                                                         .SBTTL ASCII MESSAGES
 12587
                                 000040
 12588
                                                        SPACE2: .ASCIZ / /
OPRO01: .ASCIZ <15><12>/RK611 BUS ADDRESS ( /
          051053
12589
12590
12591
12592
12593
12594
12595
12596
12597
12598
12599
12600
12601
12602
12603
12604
12605
           051056
                      005015
                      020061
042101
020123
                                 052502
051104
          051064
051072
                                             020123
                                             051505
                                 020050
           051100
                                                 000
                          040
                                             020075
                                  020051
                                                        OPR002: .ASCIZ / ) = /
           051105
           051112
                                             030461
047524
051104
           051113
                                  033113
                                                        OPROO3: .ASCIZ /RK611 VECTOR ADDRESS ( /
                      053040
           051120
                                  041505
           051126
051134
                                  042101
                      051505
                                  020123
                                             020050
          051142
051143
051150
                                 033113
044522
020131
                           122
                                             030461
                                                         OPROO4: .ASCIZ /RK611 PRIORITY ( /
                                             051117
                      050040
                      052111
                                             020050
           051156
           051164
                                             043125
047105
           051165
                           111
                                  051516
                                                       OPROOS: .ASCIZ /INSUFFICIENT MEMORY. PROGRAM ABORTING./<15><12>
                                  044503
042515
020056
           051172
                      044506
                      020124
054522
043517
 12606
           051200
                                             047515
 12607
           051206
                                             051120
                                 040522
051117
 12608
           051214
                                             020115
 12609
           051222
                                             044524
                      041101
          051230
 12610
                      043516 006456
                                             000012
 12611
12612
12613
12614
12615
12616
          051236
                                                         OPR006:
                                                                    .ASCII <15><12>/TO BYPASS TESTING DRIVE O, PLACE IT OFF-LINE/
                                                                    .ASCIZ <15><12>/TO TEST DRIVE O, REPLACE PROGRAM PACK WITH SCRATCH PACK/
          051236
051236
051244
051252
051260
                                                         OPRC07:
                                 044103
054040
040520
                                                                    .ASCII <CR><LF>/CHANGE XXDP PACK/
                      005015
                                             047101
                      042507
020120
005015
                                             042130
045503
 12617
12618
12619
12620
12621
12623
12623
12624
12625
12626
12627
12628
12629
12630
12631
12632
12633
12634
12635
                                  046103
047514
                                              040505
                                                                    .ASCIZ <CR><LF>/CLEAR LOC 40, RESTART PROGRAM/
           051266
051274
                       020122
                                              020103
                      030064
                                  051054
                                              051505
                      040524
           051302
                                  052122
                                             050040
                                  051107
           051310
                                             046501
           051316
                           000
                                                        : .ASCII <15><12>/DRIVE O WILL NOT BE TESTED. TO TEST DRIVE 0./<15><12>
: .ASCIZ /RESTART AT 214 AND MOUNT SCRATCH PACK AS DIRECTED./
OPROO8: .ASCIZ <15><12>/NO DRIVES AVAILABLE FOR TESTING. PROGRAM ABORTED/
           051317
051324
051332
                                             020117 051505
                                  047012
053111
                           015
                       051104
                                  040526
042514
052040
043516
                       040440
                                             046111
                                             043040
051505
           051340
                       041101
           051346
051354
                      051117
                                              020056
                       044524
                       051120
                                  043517
           051362
                                              040522
           051370
                       020115
                                              051117
                                  041101
                       042524
           051376
                                  000104
                                  044124
046114
020107
                       005015
                                             020105
053517
           051402
                                                        OPROO9: .ASCIZ <15><12>/THE FOLLOWING DRIVES WILL BE TESTED/<15><12>
 12636
12637
           051410
                       047506
                                             051104
           051416
                       047111
                       053111
                                  051505
                                             053440
 12638
           051424
           051432
                                             042502
 12639
                                  020114
                       046111
                       052040
                                  051505
 12640
           051440
 12641
           051446
                       006504
                                  000012
```

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AU ASCII MESSAGES | G-81 15:17 PAGE 235 |
|---|---|--|
| 12642 051452 005015 047516 12643 051460 051101 052111 12644 051466 050117 044524 12645 051474 043040 051117 12646 051502 046505 051117 12647 051510 051101 040505 12648 051516 020116 051525 | 020131 047117 046440 020131 044440 | <15><12>/NO PARITY OPTION FOR MEMORY AREA IN USE/<15><12> |
| 12647 051510 051101 040505 12648 051516 020116 051525 12649 051524 012 12650 051525 055 052440 12651 051532 052502 020123 12652 051540 044522 054524 12653 051546 051122 051117 12654 051554 051505 020124 12655 051562 040520 051523 12656 051570 005015 000 12657 051573 015 046412 12658 051600 051117 020131 | 044516 .ASCIZ 040520 042440 052040 054502 042105 | /- UNIBUS PARITY ERROR TEST BYPASSED/<15><12> |
| 12660 051614 046040 051101 12661 051622 042440 047516 12662 051630 020110 047506 12663 051636 052502 020123 12664 051644 051104 051505 12665 051652 044502 051524 12666 051660 020066 020046 12667 051666 052040 051505 | 020122 042101 020123 030440 033461 | <15><12>/MEMORY SIZE NOT LARGE ENOUGH FOR BUS ADDRESS BITS 16 & 17 TESTS |
| 12668 051674 005015 12669 051676 046101 020114 12670 051704 040524 054040 12671 051712 020122 042524 12672 051720 020123 044527 12673 051726 040440 042104 | 042506 052123 044124 | /ALL DATA XFER TESTS WITH ADDR >/ |
| 12674 051734 000076 12675 051736 031063 000113 12676 051742 032066 000113 12677 051746 033071 000113 12678 051752 041040 050131 12679 051760 042523 006504 12680 051766 005015 020012 12681 051774 020040 020040 12682 052002 020052 040503 12683 052010 047511 020116 | OPRO13: .ASCIZ OPRO14: .ASCIZ OPRO15: .ASCIZ 000012 | /64K/ /96K/ |
| 12684 052016 006452 005012 12685 052022 044124 051511 12686 052030 047522 051107 12687 052036 051440 047510 12688 052044 020104 042502 12689 052052 046101 042524 12690 052060 054502 052040 12691 052066 047111 020107 | 025052 050040 .ASCII 046501 046125 044040 020104 050131 041536 | /THIS PROGRAM SHOULD BE HALTED BY TYPING *C./<15><12> |
| 12692 052074 006456 012 12693 052077 111 020106 12694 052104 052114 042105 12695 052112 044523 043516 12696 052120 042510 044040 12697 052126 020124 042513 | 040510 .ASCII 052440 052040 046101 | /IF HALTED USING THE HALT KEY, THE STATE OF THE DRIVE/<15><12> |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG-81 15:17 PAGE 236 ASCII MESSAGES |
|--|---|
| 12698 052134 052040 042510 12699 052142 040524 042524 12700 052150 020106 044124 12701 052156 051104 053111 | 051440 047440 020105 006505 |
| 12702 052164 012 12703 052165 117 020122 12704 052172 052122 044522 12705 052200 020105 040503 12706 052206 052117 041040 12707 052214 051120 042105 12708 052222 042524 027104 | 040503 .ASCII /OR CARTRIDGE CANNOT BE PREDICTED./<15><12><12> 043504 047116 020105 041511 005015 |
| 12699 052142 040524 042524 12700 052150 020106 044124 12701 052156 051104 053111 12702 052164 012 12703 052165 117 020122 12704 052172 052122 044522 12705 052200 020105 040503 12706 052206 052117 041040 12707 052214 051120 042105 12708 052222 042524 027104 12709 052230 012 12710 052231 101 046114 12711 052236 044522 042526 12712 052244 047524 041040 12713 052252 042524 052123 12714 052260 046440 051525 12715 052266 042502 047440 12716 052274 044514 042516 12717 052302 012 12718 052303 122 040505 12719 052310 020054 047101 12720 052316 051127 052111 12721 052324 047514 045503 12722 052332 051505 052105 12723 052340 012 12724 052341 101 054516 12727 052362 042524 020104 12728 052354 052117 052040 12727 052362 042502 052040 12728 052370 042524 020104 12729 052376 052123 041040 | 042040 .ASCII /ALL DRIVES TO BE TESTED MUST BE ON-LINE,/<15><12> 020123 020105 042105 020124 026516 006454 |
| 12717 052302 012 12718 052303 122 040505 12719 052310 020054 047101 12720 052316 051127 052111 12721 052324 047514 045503 12722 052332 051505 052105 | 054504 .ASCII /READY, AND WRITE LOCK RESET./<15><12> 020104 020105 051040 006456 |
| 12730 052404 043117 026506 | 042040 .ASCII /ANY DRIVE NOT TO BE TESTED MUST BE OFF-LINE./<15><12><12> 047040 020117 051505 052515 020105 044514 005012 |
| 12731 052412 042516 006456 12732 052420 047516 042524 12733 052426 047062 020104 12734 052434 020104 052523 12735 052442 050505 042525 12736 052450 050040 051501 12737 052456 052522 020116 12738 052464 042515 044440 | 020072 .ASCII /NOTE: 2ND AND SUBSEQUENT PASS RUN TIME IS/<15><12> 047101 051502 052116 020123 044524 006523 |
| 12732 052420 047516 042524 12733 052426 047062 020104 12734 052434 020104 052523 12735 052442 050505 042525 12736 052450 050040 051501 12737 052456 052522 020116 12738 052464 042515 044440 12739 052472 012 12740 052473 040 020040 12741 052500 040440 050120 12742 052506 020130 020062 12743 052514 020116 030063 12744 052522 041505 043040 12745 052530 042440 041501 12746 052536 051104 053111 12747 052544 005015 000 12748 052536 051104 053111 12749 052554 052123 031040 12750 052562 051440 041505 12751 052570 051522 047040 12752 052576 041040 042523 12753 052604 051122 051117 | 020040 .ASCIZ / APPROX 2 MIN 30 SEC FOR EACH DRIVE./<15><12> 047522 044515 051440 051117 020110 027105 |
| 12747 052544 005015 000 12748 052547 015 043012 12749 052554 052123 031040 12750 052562 051440 041505 12751 052570 051522 047040 12752 052576 041040 042523 12753 052604 051122 051117 | 051111 OPR017: .ASCII <15><12>/FIRST 256 SECTORS NOT BSE ERROR FREE./ 033065 047524 052117 042440 043040 |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG-81 15:17 PAGE 237 ASCII MESSAGES SEQ 0236 |
|---|--|
| 12754 052612 042522 027105 12755 052616 040515 044530 12756 052624 020115 040504 12757 052632 052040 040522 12758 052640 042506 020122 12759 052646 052123 041040 12760 052654 051501 042523 | 052515 .ASC!Z /MAXIMUM DATA TRANSFER TEST BYPASSED/<15><12> 040524 051516 042524 050131 006504 |
| 12761 052662 000012 12762 052664 020040 020040 12763 052672 047412 046116 12764 052700 020061 051104 12765 052706 027105 047440 12766 052714 046122 050101 12767 052722 020104 050117 12768 052730 052101 047511 12769 052736 041040 050131 | 006440 OPR018: .ASCIZ / /<15><12>/ONLY 1 DRIVE. OVERLAPPED OPERATIONS BYPASSED/<15><12> 020131 053111 042526 042520 051105 051516 051501 |
| 12754 052612 042522 027105 12755 052616 040515 044530 12756 052624 020115 040504 12757 052632 052040 040522 12758 052640 042506 020122 12759 052646 052123 041040 12760 052654 051501 042523 12761 052662 000012 12763 052664 020040 020040 12763 052672 047412 046116 12764 052700 020061 051104 12765 052706 027105 047440 12766 052714 046122 050101 12767 052722 020104 050117 12768 052730 052101 047511 12769 052736 041040 050131 12770 052744 042523 006504 12771 052752 005015 041523 12772 052760 035105 041440 12773 052766 024040 051124 12774 052774 026051 042440 12775 053002 034055 020073 12776 053010 026062 042440 12777 053016 031055 024040 12778 053024 041440 052517 12779 053032 026105 027040 12780 053040 041457 024515 12781 053044 005015 042101 12782 053052 052123 051040 12783 053060 043040 051117 12784 053066 047117 052123 12785 053074 020124 042514 12785 053074 020124 042514 | 000012 050117 OPR019: .ASCII <15><12>@SCOPE: CH1 (TRIG), E53-8; CH2, E49-2 (AC COUPLE, .2V/CM)@ 030510 043511 031465 044103 034464 041501 046120 053062 |
| 12781 053044 005015 042101 12782 053052 052123 051040 12783 053060 043040 051117 12784 053066 047117 052123 12785 053074 020124 042514 12786 053102 020114 047117 12787 053110 031110 005015 | 052512 .ASCIZ <15><12>/ADJUST R72 FOR CONSTANT LEVEL ON CH2/<15><12> 031067 041440 047101 042526 041440 000 |
| 12788 053115 015 050012 12789 053122 051107 046501 12790 053130 046101 020124 12791 053136 042116 047111 12792 053144 020055 040503 12793 053152 044522 043504 12794 053160 047506 046522 12795 053166 041040 044505 | 047522 OPR020: .ASCIZ <15><12>/PROGRAM HALT PENDING - CARTRIDGE FORMAT BEING CORRECTED/<15><12 044040 042520 020107 052122 020105 052101 043516 042522 005015 |
| 12796 053174 041440 051117 12797 053202 052103 042105 12798 053210 000 12799 053211 015 025012 12800 053216 025052 020040 12801 053224 043517 040522 12802 053232 040510 052114 12803 053240 020040 025052 12804 053246 006452 000012 12805 053252 040503 052122 12806 053260 043504 020105 12807 053266 046522 052101 12808 053274 051117 042522 | 025052 |
| 12800 053216 025052 020040 12801 053224 043517 040522 12802 053232 040510 052114 12803 053240 020040 025052 12804 053246 006452 000012 12805 053252 040503 052122 12806 053260 043504 020105 12807 053266 046522 052101 12808 053274 051117 042522 12809 053302 047511 020116 | 044522 OPR022: .ASCIZ /CARTRIDGE FORMAT CORRECTION FAILED/<15><12> 047506 041440 052103 040506 |

| | CZR6KGO RK6 FCT CZR6KG.P11 2 | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) ASCII M | 28-AUG | | SE |
|--|---|---|--|--|---------------------|--------------------|---|----|
| | 12810 053310 | 046111 | 042105 | 005015 | | | | |
| | 12810 053310 12811 053316 12812 053317 12813 053324 12814 053332 12815 053340 12816 053346 12817 053354 12818 053362 12819 053370 12820 053376 12821 053404 12822 12823 12824 053405 12825 053412 12826 053420 12827 053426 12828 053442 12829 053442 12830 053450 12831 053456 12832 053464 12833 053465 12834 053472 12836 053506 12837 053514 12838 053522 12839 053530 12840 053536 | 000 015 051107 047502 020107 051525 047522 042522 020104 042105 000 | 050012 046501 052122 042502 020105 020122 044123 054105 042105 | 047522 040440 047111 040503 051105 044124 046117 042503 005015 | ABORT: | .ASCIZ | <15><12>/PROGRAM ABORTING BECAUSE ERROR THRESHOLD EXCEEDED/<15><12> | |
| the special property of the contract of the co | 12823 12824 053405 12825 053412 12826 053420 12827 053426 12828 053434 12829 053442 12830 053450 12831 053456 | 106 047055 044530 020124 054522 045522 040502 042104 000 | 052101 047117 052123 042515 040440 030466 042523 042522 | 046101 042440 047101 047515 020124 020061 040440 051523 | .SBTTL EM1: | ERROR ME .ASCIZ | SSAGES /FATAL-NON EXISTANT MEMORY AT RK611 BASE ADDRESS/ | |
| THE RESERVE ASSESSMENT ASSESSMENT OF THE PERSON OF THE PER | 12829 053442 12830 053450 12831 053456 12832 053464 12833 053465 12834 053472 12835 053500 12836 053506 12837 053514 12838 053522 12839 053530 12840 053536 12841 053544 | 106 053455 051040 040440 020105 047516 051525 042524 000124 | 052101 044522 040505 042116 044504 020124 020105 051122 | 046101 042524 054504 044440 020104 040503 047111 050125 | EM2: | .ASCIZ | /FATAL-WRITE READY AND IE DID NOT CAUSE INTERRUPT/ | |
| | 12843 053554 | 040506 040520 042440 052040 050040 042440 036440 | 1 11 11 11 124 1 1 | 026514 054524 051117 027120 052101 051117 | EM3: | .ASCIZ | /FATAL-PARITY ERROR TRAP. PC AT ERROR = / | |
| A STATE OF THE PROPERTY OF THE | 12849 053616 12850 053624 12851 053632 12852 053640 12853 053646 | 054105 042105 051105 042040 052117 051125 040527 042524 046515 040527 | 042520 044440 052522 042111 047440 047440 | 052103 052116 052120 047040 041503 020122 040514 047503 020104 | EM4: | .ASCIZ | /EXPECTED INTERRUPT DID NOT OCCUR OR WAS LATE. COMMAND WAS:/ | |
| The same of the sa | 12855 053662 12856 053670 12857 053676 12858 053704 12859 053711 12860 053716 12861 053724 12862 053732 12863 053740 12864 053746 12865 053754 | 123 052123 042514 042111 051040 042440 000 | 020056 047101 035123 041125 046505 051101 047040 051505 051122 | 000 054523 041440 042040 052117 052105 051117 | EM5: | .ASCIZ | /SUBSYSTEM CLEAR DID NOT RESET ERROR/ | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(10 ERRO | 46) 28-AUG- | -81 15:17 PAGE 239 |
|--|--|-------------|--|
| 12866 053755 123 041125 12867 053762 052123 046505 12868 053770 042514 051101 12869 053776 042111 047040 12870 054004 051040 051505 12871 054012 042040 053105 12872 054020 020105 047111 12873 054026 051122 050125 12874 054034 052523 051502 12875 054042 042524 020115 12876 054050 040505 020122 12877 054056 020104 047516 12878 054064 042523 020124 12879 054072 042101 000131 12880 054076 047527 042122 12881 054104 052517 052116 12882 054112 041516 051117 12883 054120 052103 000 12884 054123 102 051525 12885 054130 042104 042522 12886 054136 044440 041516 12887 054144 042522 052103 12888 054151 125 050120 12889 054164 042104 042522 12891 054172 041040 051525 12890 054164 042104 042522 12891 054172 041040 052111 12892 054200 047111 047503 12893 054206 041505 020124 12894 054214 030501 026066 12895 054222 024467 000 12896 054225 103 046131 12897 054232 042504 020122 12898 054240 051104 051505 12899 054246 047111 047503 | 054523 EM6: 041440 042040 052117 052105 041511 042524 000124 051531 EM7: 046103 044504 | | /SUBSYSTEM CLEAR DID NOT RESET DEVICE INTERRUPT/ |
| 12876 054050 040505 020122 12877 054056 020104 047516 12878 054064 042523 020124 12879 054072 042101 000131 12880 054076 047527 042122 12881 054104 052517 052116 12882 054112 041516 051117 | 020124 042522 041440 EM10 044440 042522 | : .ASCIZ | /WORD COUNT INCORRECT/ |
| 12881 054104 052517 052116 12882 054112 041516 051117 12883 054120 052103 000 12884 054123 102 051525 12885 054130 042104 042522 12886 054136 044440 041516 12887 054144 042522 052103 12888 054151 125 050120 12889 054156 041040 051525 | 040440 EM11 051523 051117 | : .ASCIZ | /BUS ADDRESS INCORRECT/ |
| 12887 054144 042522 052103 12888 054151 125 050120 12889 054156 041040 051525 12890 054164 042104 042522 12891 054172 041040 052111 12892 054200 047111 047503 12893 054206 041505 020124 12894 054214 030501 026066 12895 054222 024467 000 | 000 051105 EM11 040440 051523 020123 051122 041050 030440 | A: .ASCIZ | /UPPER BUS ADDRESS BITS INCORRECT (BA16, 17)/ |
| 12892 054200 047111 047503 12893 054206 041505 020124 12894 054214 030501 026066 12895 054222 024467 000 12896 054225 103 046131 12897 054232 042504 020122 12898 054240 051104 051505 12899 054246 047111 047503 | 047111 EM12 042101 020123 051122 | : .ASCIZ | /CYLINDER ADDRESS INCORRECT/ |
| 12900 054254 041505 000124 12901 054260 051124 041501 12902 054266 042101 051104 12903 054274 020123 047111 12904 054302 051122 041505 12905 054310 042523 052103 12906 054316 040440 042104 | 020113 EM13 | : .ASCIZ | /TRACK ADDRESS INCORRECT/ |
| 12900 054254 041505 000124 12901 054260 051124 041501 12902 054266 042101 051104 12903 054274 020123 047111 12904 054302 051122 041505 12905 054310 042523 052103 12906 054316 040440 042104 12907 054324 051523 044440 12908 054332 051117 042522 12909 054340 000056 12910 054342 047516 026516 12911 054350 051511 040524 12912 054356 042040 044522 12913 054364 000 12914 054365 103 047117 12915 054372 046117 042514 12916 054400 044524 042515 12917 054406 000124 12918 054410 047125 052111 12919 054416 042511 042114 12920 054424 051122 051117 12921 054431 115 046125 | 047503 000124 051117 EM14 042522 041516 052103 | : .ASCIZ | /SECTOR ADDRESS INCORRECT./ |
| 12910 054342 047516 026516 12911 054350 051511 040524 12912 054356 042040 044522 | 054105 EM15 052116 042526 | : .ASCIZ | /NON-EXISTANT DRIVE/ |
| 12913 054364 000 12914 054365 103 047117 12915 054372 046117 042514 12916 054400 044524 042515 | 051124 EM16 020122 052517 | : .ASCIZ | /CONTPOLLER TIMEOUT/ |
| 12917 054406 000124 12918 054410 047125 052111 12919 054416 042511 042114 12920 054424 051122 051117 | 043040 EM17 042440 000 | : .ASCIZ | /UNIT FIELD ERROR/ |
| 12920 054424 051122 051117 12921 054431 115 046125 | 050111 EM18 | : .ASCIZ | /MULIPLE DRIVE SELECT/ |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) ERROR M | 28-AUG ESSAGES | -81 15:17 PAGE 240 |
|--|--|---------------------|-------------------|--|
| 12922 054436 042514 042040 12923 054444 042526 051440 12924 054452 041505 000124 | 044522 046105 | | | |
| 12924 054452 041505 000124 12925 054456 051120 043517 12926 054464 046515 047111 12927 054472 051105 047522 | 040522 | EM19: | .ASCIZ | /PROGRAMMING ERROR/ |
| 12928 054500 047516 026516 | 000122 054105 052116 051117 | EM20: | .ASCIZ | /NON-EXISTANT MEMORY/ |
| 12930 054514 046440 046505 12931 054522 000131 12932 054524 047125 041111 12933 054532 050040 051101 12934 054540 020131 051105 12935 054546 000122 | 051525 052111 047522 | EM21: | .ASCIZ | /UNIBUS PARITY ERROR/ |
| 12935 054546 000122 12936 054550 046111 042514 12937 054556 020114 052506 12938 054564 044524 047117 | 040507 041516 000 | EM22: | .ASCIZ | /ILLEGAL FUNCTION/ |
| 12938 054564 044524 047117 12939 054571 105 041503 12940 054576 051101 000104 | 044040 | EM23: | .ASCIZ | /ECC HARD/ |
| 12941 054602 040504 040524 12942 054610 042510 045503 | 041440 | EM24: | .ASCIZ | /DATA CHECK/ |
| 12943 054615 127 044522 12944 054622 041440 042510 12945 054630 000 | 042524 045503 | EM25: | .ASCIZ | /WRITE CHECK/ |
| 12946 054631 104 052101 12947 054636 040514 042524 | 020101 | EM26: | .ASCIZ | /DATA LATE/ |
| 12942 054610 042510 045503 12943 054615 127 044522 12944 054622 041440 042510 12945 054630 000 12946 054631 104 052101 12947 054636 040514 042524 12948 054643 117 042520 12949 054650 044524 047117 12950 054656 041516 046517 12951 054664 052105 000105 12952 054670 042510 042101 12953 054676 053040 041522 12954 054703 102 042101 12955 056710 041505 067524 | 040522 044440 046120 | EM27: | .ASCIZ | /OPERATION INCOMPLETE/ |
| 12952 054670 042510 042101 12953 054676 053040 041522 | 051105 | EM28: | .ASCIZ | /HEADER VRC/ |
| 12954 054703 102 042101 12955 054710 041505 047524 12956 054716 051105 047522 | 051440 020122 000122 | EM29: | .ASCIZ | /BAD SECTOR ERROR/ |
| 12957 054724 047503 052116 12958 054732 046114 051105 12959 054740 052105 041505 12960 054746 020104 051104 12961 054754 020105 052502 12962 054762 040520 044522 12963 054770 042440 051122 | 047522 042040 042524 053111 020123 054524 051117 | EM30: | .ASCIZ | /CONTROLLER DETECTED DRIVE BUS PARITY ERROR/ |
| 12964 054776 000 12965 054777 123 042505 12966 055004 047111 047503 12967 055012 042514 042524 | 020113 050115 | EM31: | .ASCIZ | /SEEK INCOMPLETE/ |
| 12967 055012 042514 042524 12968 055017 116 047117 12969 055024 042530 052503 12970 055032 046102 020105 12971 055040 053111 020105 12972 055046 041516 044524 12973 055054 000 | 000 042455 040524 051104 052506 047117 | EM32: | .ASCIZ | /NON-EXECUTABLE DRIVE FUNCTION/ |
| 12973 055054 000 12974 055055 104 044522 12975 055062 042040 052105 12976 055070 042524 020104 12977 055076 053111 020105 | 042526 041505 051104 052502 | EM33: | .ASCIZ | /DRIVE DETECTED DRIVE BUS PARITY ERROR/ |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-A ERROR MESSAGE | UG-81 15:17 PAGE 241 |
|--|--|--|
| 12978 055104 020123 040520 12979 055112 054524 042440 12980 055120 051117 000 | 044522 051122 | |
| 12980 055120 051117 000 12981 055123 106 051117 12982 055130 020124 051105 12983 055136 000122 12984 055140 051104 053111 | 040515 EM34: .ASCI | Z /FORMAT ERROR/ |
| 12984 055140 051104 053111 12985 055146 054524 042520 12986 055154 051122 051117 12987 055161 101 026103 | 020105 EM35: .ASCI 042440 000 | Z /DRIVE TYPE ERROR/ |
| 12987 055161 101 026103 | 047514 EM36: .ASCI | Z /AC LOW/ |
| 12987 055161 101 026103 12988 055166 000127 12989 055170 050123 047111 12990 055176 020105 050123 12991 055204 020104 047514 | 046104 EM37: .ASCI 042505 051523 | Z /SPINDLE SPEED LOSS/ |
| 12992 055212 000 12993 055213 104 044522 12994 055220 047440 043106 | 052040 | Z /DRIVE OFF TRACK/ |
| 12994 055220 047440 043106 12995 055226 040522 045503 12996 055233 103 046131 12997 055240 042504 020122 12998 055246 051105 046106 | 000 047111 EM39: .ASCI 053117 053517 | Z /CYLINDER OVERFLOW/ |
| 12978 055104 020123 040520 12979 055112 054524 042440 12980 055120 051117 000 12981 055123 106 051117 12982 055130 020124 051105 12983 055136 000122 12984 055140 051104 053111 12985 055146 054524 042520 12986 055154 051122 05117 12987 055161 101 026103 12988 055166 000127 12989 055170 050123 047111 12999 055176 020105 050123 12991 055204 020104 047514 12992 055212 000 047440 043106 12993 055233 104 044522 12994 055226 040522 04503 12996 055233 103 046131 12997 | 043505 EM40: .ASCI 051511 045503 042522 | Z /ILLEGAL DISK PACK ADDRESS/ |
| 13004 055304 051523 000 13005 055307 127 044522 13006 055314 046040 041517 13007 055322 051105 047522 13008 055330 051104 053111 | 020113 | Z /WRITE LOCK ERROR/ |
| 13006 055314 046040 041517 13007 055322 051105 047522 13008 055330 051104 053111 13009 055336 044524 044515 13010 055344 042440 051122 13011 055352 000 | 000122 020105 EM42: .ASCI 043516 051117 | Z /DRIVE TIMING ERROR/ |
| 13012 055353 116 020117 13013 055360 051122 053440 13014 055366 020110 047523 13015 055374 047440 044124 13016 055402 042440 051122 13017 055410 051440 052105 13018 055415 104 044522 13019 055422 052440 051516 13020 055430 000105 13021 055432 042503 051122 13022 055440 052105 041040 13023 055446 047040 020117 13024 055454 042510 020122 13025 055462 047522 020122 | 052111 042515 051105 051117 | Z /NO CERR WITH SOME OTHER ERROR SET/ |
| 13018 055415 104 044522 13019 055422 052440 051516 13020 055430 000105 | 000 042526 EM44: .ASCI 043101 | Z /DRIVE UNSAFE/ |
| 13012 055353 116 020117 13013 055360 051122 053440 13014 055366 020110 047523 13015 055374 047440 044124 13016 055402 042440 051122 13017 055410 051440 052105 13018 055415 104 044522 13019 055422 052440 051516 13020 055430 000105 13021 055432 042503 051122 13022 055440 052105 041040 13023 055446 047040 020117 13024 055454 042510 020122 13025 055462 047522 020122 13026 055470 000124 13027 13028 055472 053126 042040 13029 055500 047040 052117 13030 055506 052105 053440 13031 055514 020110 040520 13032 055522 040440 045503 13033 055527 123 040524 | 051440 EM45: .ASCI 052125 052117 051105 042523 | Z /CERR SET BUT NO OTHER ERROR SET/ |
| 13028 055472 053126 042040 13029 055500 047040 052117 13030 055506 052105 053440 13031 055514 020110 040520 13032 055522 040440 045503 13033 055527 123 040524 | 051440 052111 045503 | Z /VV DID NOT SET WITH PACK ACK/ |
| 13033 055527 123 040524 | 000 052524 EM47: .ASCI | Z /STATUS VALID SET ON SELECT TO NON-EXISTANT DRIVE/ |

SEQ 0241

| | MACY11 30(1046) 28-AUG-81 15:17 PAGE 242 ERROR MESSAGES |
|--|---|
| 13034 055534 020123 040526 13035 055542 020104 042523 13036 055550 047117 051440 13037 055556 041505 020124 13038 055564 047040 047117 13039 055572 044530 052123 13040 055600 020124 051104 13041 055606 000105 13042 055610 052123 052101 13043 055616 053040 046101 13044 055624 051040 051505 13045 055632 047440 020116 | 044514 020124 046105 047524 042455 047101 053111 |
| 13042 055610 052123 052101 13043 055616 053040 046101 13044 055624 051040 051505 13045 055632 047440 020116 13046 055640 042514 052103 13047 055646 020117 054105 13048 055654 040524 052116 13049 055662 044522 042526 13050 055667 123 040524 | 051525 EM48: .ASCIZ /STATUS VALID RESET ON SELECT TO EXISTANT DRIVE/ 042111 052105 042523 052040 051511 042040 |
| 13048 055654 040524 052116 13049 055662 044522 042526 13050 055667 123 040524 13051 055674 020123 040526 13052 055702 020104 047516 13053 055710 042522 042523 13054 055716 047117 042040 13055 055724 042526 051040 13056 055732 040505 042523 | 000 052524 EM49: .ASCIZ /STATUS VALID NOT RESET ON DRIVE RELEASE/ 044514 020124 020124 044522 046105 000 |
| 13057 055737 105 050130 13058 055744 042524 020104 13059 055752 020104 047111 13060 055760 051122 050125 13061 055766 044504 020104 13062 055774 020124 041517 13063 056002 020122 051117 13064 056010 051501 046040 13065 056016 027105 041440 13066 056024 040515 042116 | 041505 EM50: .ASCIZ /EXPECTED 2ND INTERRUPT DID NOT OCCUR OR WAS LATE. COMMAND WAS:/ 047062 042524 020124 047516 052503 053440 052101 046517 053440 |
| 13067 056032 051501 000072 13068 056036 040503 047116 13069 056044 051040 040505 13070 056052 040502 020104 13071 056060 052103 051117 13072 056066 046111 006505 13073 056073 124 051505 13074 056100 043516 040440 | 052117 EM51: .ASCII /CANNOT READ BAD SECTOR FILE/<15><12> 020104 042523 043040 012 |
| 13070 056052 040502 020104 13071 056060 052103 051117 13072 056066 046111 006505 13073 056073 124 051505 13074 056100 043516 040440 13075 056106 052122 042105 13076 056114 020116 044124 13077 056122 042040 044522 | 044524 .ASCIZ .ZIESTING ABORTED ON THIS DRIVE/ 047502 047440 051511 042526 |
| 13077 056122 042040 044522 13078 056130 000 13079 056131 101 044514 13080 056136 042515 052116 13081 056144 041501 020113 13082 056152 052040 044510 13083 056160 051104 053111 13084 056166 005015 | 047107 EM52: .ASCII /ALIGNMENT PACK ON THIS DRIVE./<15><12> 050040 047117 020123 027105 |
| 13085 056170 042524 052123 13086 056176 020107 041101 13087 056204 042524 020104 13088 056212 052040 044510 13089 056220 051104 053111 | 047111 .ASCIZ /TESTING ABORTED ON THIS DRIVE./ 051117 047117 020123 027105 |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) ERROR M | 28-AUG MESSAGES | -81 15:17 PAGE 243 |
|---|--|--------------------|--|
| 13090 056226 000 13091 056227 124 020117 13092 056234 054516 041040 13093 056242 051440 041505 13094 056250 051522 020056 13095 056256 052123 047111 13096 056264 041101 051117 13097 056272 020104 047117 13098 056300 044510 020123 13099 056306 053111 000105 13100 056312 042510 042101 13101 056320 053440 051117 13102 056326 044515 041523 13103 056334 040520 042522 13104 056341 104 052101 13105 056364 047527 042122 13106 056354 051511 047503 13107 056362 051101 000105 13108 13109 056366 040503 047116 13110 056374 043040 047111 13111 056402 042510 042101 13112 056410 030040 044440 13113 056416 042522 042101 13114 056424 042116 051440 13115 056432 020124 042510 13116 056440 051105 000123 13117 056444 052123 052101 13118 056452 053040 046101 13119 056460 000 13120 056461 123 046105 13119 056466 020124 044527 13122 056474 047040 047117 13123 056502 051105 020117 | 040515 EM53: 042101 047524 042524 020107 042524 052040 051104 | .ASC!Z | /TO MANY BAD SECTORS. TESTING ABORTED ON THIS DRIVE/ |
| 13100 056312 042510 042101 13101 056320 053440 051117 13102 056326 044515 041523 | 051105 EM54: 020104 046517 | .ASCIZ | /HEADER WORD MISCOMPARE/ |
| 13104 056341 104 052101 13105 056346 047527 042122 13106 056354 051511 047503 13107 056362 051101 000105 | 000 020101 EM55: 046440 050115 | .ASCIZ | /DATA WORD MISCOMPARE/ |
| 13108 13109 056366 040503 047116 13110 056374 043040 047111 13111 056402 042510 042101 13112 056410 030040 044440 13113 056416 042522 042101 13114 056424 042116 051440 13115 056432 020124 042510 13116 056440 051105 000123 13117 056444 052123 052101 | 052117 EM56: 020104 051105 020116 040440 051117 042101 | .ASCIZ | /CANNOT FIND HEADER O IN READ AND SORT HEADERS/ |
| 13115 056432 020124 042510 13116 056440 051105 000123 13117 056444 052123 052101 13118 056452 053040 046101 | 051525 EMSVAL: | .ASCIZ | /STATUS VALID/ |
| 13119 056460 000 13120 056461 123 046105 13121 056466 020124 044527 13122 056474 047040 047117 13123 056502 051105 020117 13124 056510 052101 051525 | 044124 055055 052123 | : .ASCIZ | /SELECT WITH NON-ZERO STATUS PAIR/ |
| 13124 056510 052101 051525 13125 056516 044501 000122 13126 056522 051127 052111 13127 056530 020107 047503 13128 056536 047101 020104 13129 056544 052101 051525 13130 056552 043505 051511 13131 056560 020122 000062 13132 056564 051104 053111 13134 056572 047111 042524 13135 056600 050125 000124 13136 055055 13137 056604 051104 053111 13138 056612 052123 052101 13139 056620 041440 040510 13140 056626 000105 13141 056630 051104 053111 13142 056636 052101 042524 13143 056644 047511 000116 13144 056650 047503 052116 13145 056656 046114 051105 | 047111 EMWCS2: 046515 052123 051040 042524 | : .ASCIZ | /WRITING COMMAND STATUS REGISTER 2/ |
| 13132 13133 056564 051104 053111 13134 056572 047111 042524 13135 056600 050125 000124 | 020105 EMDI: | | DRIVE TYPE ERROR |
| 13136 13137 056604 051104 053111 13138 056612 052123 052101 13139 056620 041440 040510 13140 056626 000105 13141 056630 051104 053111 13142 056636 052101 042524 | FMDPAR: | EM33 .ASCIZ | /DRIVE STATUS CHANGE/ |
| 13141 056630 051104 053111 13142 056636 052101 042524 | 020105 EMDA: 052116 | .ASCIZ | /DRIVE ATTENTION/ |
| 13141 056630 051104 053111 13142 056636 052101 042524 13143 056644 047511 000116 13144 056650 047503 052116 13145 056656 046114 051105 | 047522 EMCCLR | : .ASCIZ | /CONTROLLER CLEAR/ |

THATT

GGG

0000000000

| CZR6KGO CZR6KG.F | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) ERROR MI | 28-AUG | 5-81 15:17 PAGE 244 | |
|---|--|--|--|--|----------------------|------------------|---|----|
| 13146 13147 13148 | 056664 | 042514 050250 050276 | 051101 | 000 | EMSELD= EMDCLR= | OPEROO OPERO4 | ;DRIVE SELECT ;DRIVE CLEAR | * |
| 13150 13151 13152 | 056671 056676 056704 | 123 020104 051122 | 041505 047111 050125 | 047117 042524 000124 | EMZINT: | .ASCIZ | SECOND INTERRUPT/ | |
| 13154 13155 | 056720 056726 | 042523 | 042523 | 043114 | EMSKSF: | .ASCIZ | /SEEK TO SELF/ | |
| 13156 13157 13158 13159 | 056727 056734 056742 | 050362 125 041505 047111 050125 | 042516 042524 042524 | 050130 020104 051122 | EMUXIT: | .ASCIZ | /UNEXPECTED INTERRUPT/ | |
| 13161 13162 | 056754 056762 | 047125 | 041111 051505 | 051525 052105 | EMUR: | .ASCIZ | /UNIBUS RESET/ | |
| 13164 13165 | 056771 | 122 000 | 051505 | 052105 | EMRSET: | .ASCIZ | /RESET/ | |
| 13166 13167 13168 13169 | 056777 057004 057012 | 054631 122 043516 020101 | 040505 042040 052502 | 044504 052101 043106 | EMDLT= EMRDB: | -ASCIZ | ;DRIVE SELECT ;DRIVE CLEAR ;DRIVE CLEAR ;RECALIBRATE /SECOND INTERRUPT/ /SEEK TO SELF/ /UNEXPECTED INTERRUPT/ /UNIBUS RESET/ /RESET/ /READING DATA BUFFER/ /CONTROLLER ERROR/ /SUBSYSTEM CLEAR/ /MULTIPLE INTERRUPTS/ /BAD SECTORS ON PACK IN AREAS USED BY TEST (CYL 312(8))/<15><12 | |
| 13171 | 057023 057030 | 103 046117 | 047117 | 051124 020122 | EMCERR: | .ASCIZ | /CONTROLLER ERROR/ | |
| 13174 | 057044 057052 | 052523 | 051502 020115 | 051531 046103 | EMSCLR: | .ASCIZ | /SUBSYSTEM CLEAR/ | |
| 13177 13178 13179 13180 | 057064 057064 057072 057100 | 052515 042514 051105 000123 | 052114 044440 052522 | 050111 052116 052120 | EMMI: | .ASCIZ | /MULTIPLE INTERRUPTS/ | |
| 13180 13181 13182 13183 13184 13185 13186 13189 13190 13191 13192 13193 13194 13195 13197 13198 13197 13198 13199 13200 13201 | 057100 057106 057110 057116 057124 057132 057140 057146 057154 057162 057170 057170 057206 057214 057222 057230 | 040502 052103 047117 020113 042522 042523 052040 041450 031061 005015 042524 020107 042524 052040 | 020104 051117 050040 047111 051501 020104 051505 046131 034050 | 042523 020123 041501 040440 052440 054502 020124 031440 024451 | DRVABT: | .ASCII | /BAD SECTORS ON PACK IN AREAS USED BY TEST (CYL 312(8))/<15><12 | ?> |
| 13191 13192 13193 13194 13195 | 057200 057206 057214 057222 057230 | 042524 020107 042524 052040 051104 | 052123 041101 020104 044510 053111 | 047111 051117 047117 020123 000105 | | .ASCIZ | /TESTING ABORTED ON THIS DRIVE/ | |
| 13197 13198 13199 13200 13201 | 057236 057244 057252 057260 | 051524 020115 041520 053111 | 020124 051105 020040 000105 | 052516 020122 051104 | .SBTTL DH001: | DATA HE | ADERS FOR ERROR REPORTS /TST NUM ERR PC DRIVE/ | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) DATA HE | 28-AUG-81 ADERS FOR ER | 15:17 PAGE RROR REPORTS | 245 | | | |
|---|--|---------------------------|----------------------------|----------------|-------------|------------|-------------|
| 13202 057264 051524 020124 13203 057272 020115 051105 13204 057300 041520 020040 13205 057306 053111 000105 13206 057312 045522 051503 13207 057320 020040 045522 | 052516 DH002A: 020122 051104 | .ASCIZ /TS | ST NUM ERR PC | DRIVE/ | | | |
| 13202 057264 051524 020124 13203 057272 020115 051105 13204 057300 041520 020040 13205 057306 053111 000105 13206 057312 045522 051503 13207 057320 020040 045522 13208 057326 020062 020040 13209 057334 051504 020040 13210 057342 045522 051105 13211 057350 020040 045522 13212 057356 043117 020040 13213 057364 041504 046131 13214 057372 045522 040504 13215 057377 122 041113 13216 057404 020040 051040 13217 057412 000103 13218 057414 030101 020060 13219 057422 020040 030102 13220 057430 020040 020040 13221 057436 020061 020040 13222 057444 030102 020061 13223 057452 020040 030101 | 020061 DH002B: 051503 045522 020040 020040 051501 045522 020040 000 | .ASCIZ /RK | CCS1 RKCS2 | RKDS RKER | R RKASOF | RKDCYL RI | KDA/ |
| 13215 057377 122 041113 13216 057404 020040 051040 13217 057412 000103 | 020101 DH002C: | .ASCIZ /RK | KBA RKWC/ | | | | |
| 13218 057414 030101 020060 13219 057422 020040 030102 13220 057430 020040 020040 13221 057436 020061 020040 13222 057444 030102 020061 13223 057452 020040 030101 13224 057460 020040 020040 13225 057466 020062 020040 13226 057474 030101 020063 13227 057502 020040 030102 | 020040 DH002D: 020060 030101 020040 020040 020062 030102 020040 020040 020040 | .ASCIZ /AC | 00 B00 | A01 B01 | A02 | B02 A | 03 B03/ |
| 13227 057502 020040 030102 13228 057510 045522 051503 13229 057516 020040 045522 13230 057524 020062 020040 13231 057532 051504 020040 13232 057540 045522 051105 13233 057546 020040 045522 13234 057554 043117 020040 13235 057562 051115 000061 | 020061 DH003B: 051503 045522 020040 020040 051501 045522 | .ASCIZ /RM | KCS1 RKCS2 | RKDS RKE | R RKASOF | RKMR1/ | |
| 13236 057566 044124 020105 13237 057574 053117 020105 13238 057602 020105 054105 13239 057610 052103 042105 13240 057616 051122 051117 13241 057624 044124 052101 13242 057632 042111 047040 13243 057640 051440 052105 13244 057646 020116 050117 | 041101 DH005: 051101 042520 042440 020123 042040 052117 044440 051105 035116 | | HE ABOVE ARE E | | RS THAT DID | NOT SET IN | OPERATION:/ |
| 13246 057662 000 13247 057663 124 042510 13248 057670 047502 042526 13249 057676 042522 052440 13250 057704 050130 041505 13251 057712 020104 051105 13252 057720 051522 051440 13253 057726 044440 020116 13254 057734 051105 052101 13255 057742 035116 000 | 040440 042516 042524 047522 052105 050117 047511 | .ASCIZ /T | HE ABOVE ARE U | INEXPECTED ERF | RORS SET IN | OPERATION: | |
| 13255 057742 035116 000 13256 057745 124 042510 13257 057752 047502 042526 | 040440 DH007: | .ASCIZ /TH | HE ABOVE ARE E | RRORS SET IN | OPERATION: | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | | | | MACY11 30(1046) 28-AUG-81 15:17 PAGE 247 DATA HEADERS FOR ERROR REPORTS | | | | | | |
|---|--|--|---|---|--|--|---|--|--|--|
| 13314 13315 13316 13317 13318 | 060442 060450 060456 060464 060472 | 044514 046101 043516 051504 042522 | 044515 047514 044040 052040 047514 | 020124 044527 040505 020117 042101 | • | | | | | |
| 13320 13321 13322 | 060500 060501 060506 060514 | 000 123 020124 020122 | 046105 043101 042522 | 041505 042524 040503 | DH017: | .ASCIZ | /SELECT AFTER RECAL/ | | | |
| 13314 13315 13316 13317 13318 13319 13320 13321 13322 13322 13322 13322 13332 13333 13333 13333 13333 13333 13333 13334 13334 13334 13334 13334 13334 13334 13334 13334 13334 | 060522 060524 060532 060540 060546 060554 060562 | 000114 042522 047503 042524 020116 020122 052103 | 040503 050115 040440 043101 042523 000 | 020114 042514 052124 042524 042514 | DH018: | .ASCIZ | /RECAL COMPLETE ATTN AFTER SELECT/ | | | |
| 13330 | | | | | .SBTTL | | BLES FOR ERROR REPORTS | | | |
| 13332 13333 13334 | 060566 060574 | 060566 001302 001540 001554 001302 | 001116 001550 001556 | 001626 001552 | DT003: | .WORD | \$TESTN, \$ERRPC, DRVNUM, T. CS1, T. CS2, T. DS, T. ER, T. ASOF, T. MR1 | | | |
| 13336 13337 13338 13339 13340 | 060602 060610 060616 060616 060616 060616 | 001302 | 001116 | 001566 001626 | DT001: DT002: DT004: DT005: DT006: DT007: | .WORD | \$TESTN, \$ERRPC, DRVNUM | | | |
| 13342 13343 13344 | 060616 060624 060632 | 001302 001540 001554 | 001116 001550 001556 | 001626 001552 | DT010: | .WORD | \$TESTN, \$ERRPC, DRVNUM T.CS1, T.CS2, T.DS, T.ER, T.ASUF | | | |
| 13346 13347 | 060636 060642 060646 060654 | 001560 001544 001202 001210 | 001546 001542 001204 001212 001220 | 001206 001214 | | .WORD .WORD .WORD | T.DCYL,T.DA T.BA,T.WC \$REG10,\$REG11,\$REG12,\$REG13,\$REG14,\$REG15,\$REG16,\$REG17 | | | |
| 13350 13351 13352 | 060662 060666 060674 | 001216 001302 001202 | 001216 001204 | 001626 001206 | DT015: DT015A: .SBTTL | | \$TESTN,\$ERRPC,DRVNUM \$REG10,\$REG11,\$REG12 DRMATS FOR ERROR REPORTS | | | |
| 13353 13354 | 060702 060704 | 000001 | 000 | | DF001: | .WORD | 13.0 | | | |
| 13348 13349 13350 13351 13352 13353 13354 13355 13356 13357 13360 13361 13362 13363 13364 13365 13366 13367 13368 13368 | 060706 060710 060712 060714 060716 060720 060722 060724 | 000004 000 057264 003 057312 007 057377 002 | 000 000 000 | | DF002: | .WORD .BYTE .WORD .BYTE .WORD .BYTE .WORD .BYTE | 4 0.0 DH002A 3.0 DH002B 7.0 DH002C 2.0 | | | |
| 13365 13366 13367 13368 13369 | 060726 060730 060732 060734 | 000002 003 057510 006 | 000 | | DF003: | .WORD .BYTE .WORD .BYTE | 2 3.0 DH003B 6.0 | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 30(1046) 28-AUG-81 15:17 PAGE 248 DATA FORMATS FOR ERROR REPORTS |
|---|--|
| 13370 13371 060736 000006 13372 060740 000 000 13373 060742 000000 13374 060744 000 000 13375 060746 057264 13376 060750 003 000 13377 060752 057312 13378 060754 007 000 13379 060756 057377 13380 060760 002 000 13381 060762 057414 13382 060764 010 000 | DF004: .WORD 6 .BYTE 0.0 DF004A: .WORD 0 .BYTE 0.0 .WORD DH002A .BYTE 3.0 .WORD DH002B .BYTE 7.0 .WORD DH002C .BYTE 2.0 .WORD DH002D .BYTE 10.0 |
| 13370 13371 060736 000006 13372 060740 000 000 13373 060742 000000 13374 060744 000 000 13375 060746 057264 13376 060750 003 000 13377 060752 057312 13378 060754 007 000 13379 060756 057377 13380 060760 002 000 13381 060762 057414 13382 060764 010 000 13383 060770 000 000 13385 060770 000 000 13386 060772 000000 13387 060774 000 000 13388 060776 057264 13389 061000 003 000 13390 061002 057312 13391 061004 007 13392 061006 057377 13393 061010 002 13394 061012 057414 13395 061014 010 000 13396 061016 060014 13397 061020 000 13398 13399 061022 000005 13398 13399 061022 000005 13398 | DF005: .WORD 7 .BYTE 0.0 DF005A: .WORD 0 .BYTE 0.0 .WORD DH002A .BYTE 3.0 .WORD DH002B .BYTE 7.0 .WORD DH002C .BYTE 2.0 .WORD DH002D .BYTE 10.0 .WORD DH005A .BYTE 0.0 |
| 13399 061022 000005 13400 061024 000 000 13401 061026 000000 13402 061030 000 000 13403 061032 057264 13404 061034 003 000 13405 061036 057312 13406 061040 007 000 13407 061042 057377 13408 061044 002 000 | DF006: .WORD 5 .BYTE 0.0 DF006A: .WORD 0 .BYTE 0.0 .WORD DH002A .BYTE 3.0 .WORD DH002B .BYTE 7.0 .WORD DH002C .BYTE 2.0 |
| 13410 061046 000004 13411 061050 000 000 13412 061052 000000 13413 061054 000 000 13414 061056 057264 13415 061060 003 000 13416 061062 057510 13417 061064 006 000 | DF007: .WORD 4 .BYTE 0.0 DF007A: .WORD 0 .BYTE 0.0 .WORD DH002A .BYTE 3.0 .WORD DH003B .BYTE 6.0 |
| 13418 13419 061066 000004 13420 061070 000 000 13421 061072 000000 13422 061074 000 000 13423 061076 057264 13424 061100 003 000 13425 061102 060140 | DF010: .WORD 4 .BYTE 0.0 DF010A: .WORD 0 .BYTE 0.0 .WORD DH002A .BYTE 3.0 .WORD DH010A |

| | CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 30(1046) DATA FOR | 28-AUG | -81 15:17 PAGE R ERROR REPORTS | 249 |
|---|---|--------------------------------------|--|---------------|-----------------------------|---------------------------------|-----------------------------------|--|
| | 13426 | 061104 | 002 | 000 | | .BYTE | 2.0 | |
| | 13428 13429 13430 | 061106 061110 061112 | 000004 000 000000 | 000 | DF011: | .WORD .BYTE .WORD | 0.0 | |
| | 13431 | 061114 | 000 | 000 | or or in. | .BYTE | 0.0 DH002A | |
| | 13433 | 061120 | 003 | 000 | | .BYTE | 3.0 DH003B | |
| | 13435 | 061122 061124 | 057510 000006 | 000000 | | .WORD | 6.0 | |
| | 13427 13428 13429 13430 13431 13433 13433 13435 13436 13443 13444 13445 13446 | 061130 061132 061134 | 000002 003 060353 | 000 | DF015: | .WORD .BYTE .WORD | 2 3.0 DH015 | |
| | 13440 | 061136 | 003 | 000 | | .BYTE | 3.0 | |
| - | 13442 | 061140 061142 | 000001 003 | 000 | DF016: | .WORD .BYTE | 13.0 | |
| | 13445 13446 13447 | 061144 061270 | 000052 000052 070376 | | BS26: BS24: | .BLKW .BLKW .=70376 | 52 52 | |
| | 13447 13448 13449 13450 13451 13452 13453 13454 13455 | 070376 070400 070402 070406 | 000240 005014 005237 000240 000002 | 001662 | SPCHLR: SPCPAR: | NOP CLR INC NOP RTI | (R4) INTSET | CLEAR MEM MAINT REG COUNT THE INTERRUPT RETURN |
| | 13453 13454 13455 13456 | 070410 070412 070414 072414 | 00002 000240 001000 001000 000001 | | IBUFF: OBUFF: .END | NOP .BLKW .BLKW | 1000 1000 | , RETORN |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) 28-AUG-81 15:17 PAGE 251 CROSS REFERENCE TABLE USER SYMBOLS |
|---|--|---|
| ABASE = 177440 1963# ABORT 053317 9586 ABTFAI 044170 9381 ACDW1 = 000000 2285 ACDW2 = 000000 2285 ACLO = 000010 2058# | 2285 12812# 11408# 2328 | 2326 |
| ACDW2 = 000000 2285 ACLO = 000010 2058# ACLOER= 000100 10504 ACPUOP= 000000 2285 ADDW0 = 000000 2285 ADDW1 = 000000 2285 ADDW11 = 000000 2285 ADDW12 = 000000 2285 ADDW13 = 000000 2285 ADDW14 = 000000 2285 ADDW15 = 000000 2285 ADDW2 = 000000 2285 ADDW3 = 000000 2285 ADDW3 = 000000 2285 ADDW4 = 000000 2285 ADDW5 = 000000 2285 ADDW5 = 000000 2285 ADDW6 = 000000 2285 | 10502 12396# 2300 | |
| ACLOER= 000100 ACPUOP= 000000 ACPUOP= 000000 ACPUOP= 000000 ADDW1 = 000000 ADDW1 = 000000 ADDW11 = 000000 ADDW11 = 000000 ADDW12 = 000000 ADDW13 = 000000 ADDW14 = 000000 ADDW15 = 000000 ADDW2 = 000000 ADDW3 = 000000 ADDW3 = 000000 ADDW4 = 000000 ADDW4 = 000000 ADDW4 = 000000 ADDW6 = 000000 ADDW7 = 00000000 ADDW7 = 000000 ADDW7 = 0000000 ADDW7 = 000000 ADDW7 = 0000000 ADDW7 = 000000 ADDW7 = 0000000 ADDW7 = 00000000000000000000000000000000000 | 2291 2327 11301# 2298 2313 2317 2317 2318 2318 2318 2318 2318 2318 2319 2319 2319 2319 2319 2319 2319 2319 | 9437# 9494 11434 1:436 |
| APTSPO= 000100 9397 ASWREG= 000000 2285 ATESTN= 000000 2285 AUNIT = 000000 2285 AUSWR = 000000 2285 AVECT1= 000210 1961# | 2298 2289 2292 2299 2285 | 2324 |

| CZR6KGO RK6 F CZR6KG.P11 | CTNL CTRL DIAG 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15 | 17 PAGE | 252 YMBOLS | | | | | | SEQ |
|--|---|--|---------------------------------|-------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|----------------|----------------|----------------|
| AVECT2= 00000 BAERR = 00000 BAI = 00000 BA16 = 00040 BA17 = 00100 | 10305 2021# 2006# 2007# | 2325 12429# 4835 5069 5215 | 7485 5155 5306 | 7500 5495 5495 | 7586 5548 5548 | 7659 | 7716 | 10273 | | | | | |
| BDSRCK 04216 BITCNT 03624 BITO = 00000 | 2 8756 | 11045 9998# 2003 7041 | 10647 2036 8868 | 10657 2055 9052 | 10665 2697 10157 | 10677 3057 12390 | 10687 3089 12408 | 10698 3693 12417 | 3932 12427 | 4438 12476 | 4626 | 4628 | 4630 |
| BIT00 = 00000 BIT01 = 00000 BIT02 = 00000 BIT03 = 00000 BIT04 = 00000 BIT05 = 00000 BIT06 = 00010 BIT07 = 00020 BIT08 = 00040 BIT09 = 00100 | 1 1901# 1900# 1900# 1899# 0 1898# 0 1896# 180 1895# 0 1894# 1893# | 1911 1910 1909 1908 1907 1906 1905 1904 1903 1902 | 9263 9281 | 9505 | | | | | 9660 | 9661 | 12391 | 12409 | 12418 |
| BIT1 = 00000 | 12428 | 2037 12477 | 2698 | 3693 | 3934 | 4684 | 8879 | 9063 | | | | | |
| BIT10 = 00200 BIT11 = 00400 | 00 1890# | 2008 | 2027 2028 | 2046 2047 | 2079 2064 | 2093 2080 | 2106 2094 | 2120 2107 | 2134 2121 | 2704 2135 | 9459 2705 | 11169 9288 | 12400 11251 |
| BIT12 = 01000 | 12401 | 2011 | 2029 | 2048 | 2081 | 2095 | 2108 | 2122 | 2136 | 11088 | 11096 | 11114 | 11138 |
| BIT13 = 02000 | 11142 | 11166 | 11276 2030 11138 | 12402 | 2065 | 2082 | 2096 | 2109 | 2123 | 2137 | 9466 | 9617 | 11088 |
| BIT14 = 04000 | 11096 | 11114 2013 | 2031 | 11166 | 11276 2066 | 12403 2083 | 2097 | 2110 | 2124 | 2138 | 4366 | 4367 | 6770 |
| BIT15 = 1000 | 6771 1886# | 9249 | 11018 2015 | 11063 | 11079 2051 | 11131 2067 | 12404 2084 | 12482 2143 | 2706 | 4363 | 4364 | 4516 | 7151 |
| BIT2 = 0000 | 7289 1909# | 11018 2038 | 11040 2057 | 11061 2699 | 12405 5643 | 12483 9671 | 12392 | 12410 | 12419 | 12429 | 12478 | | |
| BIT3 = 0000 BIT4 = 0000 BIT5 = 0000 | 20 1907# 0 1906# | 2020 2021 2022 | 2039 2040 2041 | 2058 2059 2060 | 2700 2073 2074 | 12393 2114 2088 | 12411 2128 2101 | 12420 3175 2115 | 12430 12394 2129 | 12479 12412 3175 | 12421 12395 | 12431 12413 | 12480 12422 |
| BIT6 = 00010 | 12432 1905# | 12481 2004 12396 | 2023 | 2042 | 2061 | 2075 | 2089 | 2102 | 2116 | 2130 | 2701 | 5676 | 9720 |
| BIT7 = 00020 | | 2005 | 12414 2024 9630 | 12423 | 2062 | 2076 | 2090 | 2103 | 2117 | 2131 | 2702 | 2824 | 3044 |
| BIT8 = 0004 | 3471 | 8584 2006 8591 | 2025 8620 | 10995 2044 8690 | 12397 2063 8852 | 12424 2077 8862 | 2091 8885 | 2104 8893 | 2118 9036 | 2132 9046 | 2703 9069 | 3137 9077 | 3215 11001 |
| BIT9 = 0010 | 12398 1902# 11001 | 2007 | 2026 | 2045 | 2078 | 2092 | 2105 | 2119 | 2133 | 4568 | 4569 | 4623 | 4624 |
| BPTVEC= 0000 BSE = 00020 BSERPT= 00020 BSERR = 00010 BSF24P 0016 | 14 1918# 200 2043# 200 2702# 200 6802 36 2679# | 7437 7439 6878 4158 | 7596 7441 10545 11043 | 10496 7599 12414# | 10543 7601 | | | | | | | | |
| BSERR = 00016 BSF24P 0016 BSF26P 00166 BSS24P 00166 BSS26P 00166 BS24 0612 BS24CT 00166 | 2 2683# 2685# 20 2679 | 4060 4164* 4149* 4194 4169* | 11039 4198 4190 13446# | 11067 11064 | | | | | | | | | |

| | | | | | | G 4 | | | | | | | |
|--|---|--|---------------------------------|---------------------------------|-----------------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|--------------------------|--------------------------|----------------|
| | CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE | 253 YMBOLS | | | | | | SEQ 0251 |
| Section of the section of the section of | BS26 061144 2681 BS26CT 001646 2687# CCLR = 100000 2015# CDT = 002000 2008# | 4172 4156* 3505 3078 | 13445# 3559 3147 | 8022 9944 | 8298 | 10146 | 10173 | | | | | | |
| | CERNER= 100000 10441 CERR = 100000 2014# CFMT = 010000 2011# | 12405# 3071 6530 | 3121 6559 | 4281 6617 | 10161 6632 | 10217 6690 | 10221 6705 | 10439 8379 | 10514 10055 | 10356 | 11013 | 11041 | 11065 |
| to the second se | CHKBA 037430 10270# CHKCTS 037642 6806 CHKOP 040162 10422# CHKST 040170 10420 CHKWC 037376 10251# CHKWE 040130 10413# | 10464 10332# 12103 10425# 10462 12104 | 10465 | | | | | | | | | | |
| | CKSWR = 104407 9243 CLEAR = 000105 1988# CLKCAL 035246 9757# CMNDLB 050210 9863 | 9455 3593 9852 10468 | 9504 7635 10760 | 12093# 7695 12489# | 7771 | 8125 | 8229 | 8268 | 8364 | 8498 | 8947 | 8967 | |
| | COE = 001000 2045# COERR = 001000 6505 CP1170= 002000 2704# CR = 000015 1826# CRLF = 000200 1827# CSRPTR 001672 2710# | 12399# 5627 11497 2823 5629* | 5641 11507 11451 5643* | 5657 12615 11507 5645* | 5680 12618 5650 | 5687 5682* | 9652 5684* | 9708 5689* | 5691* | 9651* | 9692* | | |
| | CS1ERB= 024000 10431 CS2ERB= 177400 10433 CTO = 004000 2009# CTOERR= 000002 7812 CTRHLT 043724 2953 CYLERR= 000010 10382 | 12368# 12369# 10163 10555 2982 12430# | 10553 12418# 3159 | 11329# | 11699 | 11782 | | | | | | | |
| | DCK = 100000 2051# DCKERR= 000002 8038 DDISP = 177570 1833# DDT = 000400 2063# | 10496 10526 2232 | 10524 12409# 2787 | | | | | | | | | | |
| | DESHLD 001700 2717# DF 001 060702 2379 DF 002 060706 2394 DF 003 060726 2405 | 11081 13353# 13356# 13366# | 11105* | 11157* | 11281 | | | | | | | | |
| - | DF 004 060736 2486 DF 004A 060742 10692 DF 005 060766 2500 DF 005A 060772 10712 DF 006 061022 2525 DF 006A 061026 10670 | 13371# 10703 13384# 13386# 13399# | 13373# | | | | | | | | | | |
| - | DF007 061046 2551 DF007A 061052 10644 DF010 061066 2574 | 10682 13410# 13412# 13419# | 13401# | | | | | | | | | | |
| - | DF010A 061072 5511* 10468* | 5564* 13421# | 5701* | 6812* | 6819* | 7120* | 7127* | 7138* | 7144* | 7258* | 7265* | 7276* | 7282* |
| the second of the second of | DF011 061106 2588 DF011A 061112 3246* 3544* 3855* | 2597 3333* 3550* 3875* | 2606 3349* 3556* 3882* | 2614 3384* 3578* 4277* | 13428# 3395* 3584* 4284* | 3431* 3610* 8667* | 3482* 3616* 8734* | 3487* 3746* 8806* | 3493* 3761* 8823* | 3499* 3768* 9007* | 3515* 3785* 10124* | 3521* 3814* 13430# | 3538* 3826* |
| Name and Address of the Owner, where | DF 015 061130 2626 DF 016 061140 2634 DH 001 057236 2377 | 13437# 13442# 13198# | | | | | | | | | | | |

| | CZR6KGO CZR6KG.I | RK6 FCTNL CTRL P11 28-AUG-8 | DIAG 1 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE | 254 YMBOLS | | | | | | SEQ 025 |
|---|---|--------------------------------------|---|--|-----------------------------------|-------------------------|-------------------------|--------------|---------------|---------------|---------------|--------------|--------------|--------------|---------------|
| Of the second or second or second | DH002B DH002C DH002D | 057264 057312 057377 057414 | 2403 13206# 13215# 13218# | 2624 13360 13362 13381 13368 | 13202# 13377 13379 13394 | 13358 13390 13392 | 13375 13405 13407 | 13388 | 13403 | 13414 | 13423 | 13432 | | | |
| - | DH002C DH002D DH003B DH005 DH005A | 057510 057566 | 13228# | 13368 13236# | 13416 | 13434 | | | | | | | | | |
| Construction of the last | DH005A DH006 | 060014 057663 | 13215# 13218# 13228# 10753 13263# 10756 | 13396 10813 | 13247# | | | | | | | | | | |
| - | DH006 DH007 DH010 | 057745 060077 | 10751 2572 13278# | 13256# 13272# | | | | | | | | | | | |
| | DH010A DH010B | 060140 060153 | 13280# | 13425 | | | | | | | | | | | |
| - | DH011 DH012 DH013 | 060223 060252 060303 | 2586 2595 | 13287# 13291# 13296# | | | | | | | | | | | |
| - | DH014 DH015 | 060326 060353 | 2604 2612 13304# | 13300# | | | | | | | | | | | |
| - | DH016 DH017 | 060404 060501 | 7027 | 13309# | | | | | | | | | | | |
| | DH018 DH2N | 060524 001372 | 8823 2392# | 13324# 7927* | 8815* | 9863* | 10082* | 10110* | | | | | | | |
| - | DH4N DH5N | 001412 001422 | 2484# | 10693 10713 | 10704 | | | | | | | | | | |
| - | DH6N DH7N DI = | 001432 001442 040000 | 2392# 2484# 2498# 2523# 2549# 2013# 2013# 2032# 10533 | 10671 | 10683 | 75/1 | 7501 | 7417 | 7011 | 7053 | 7070 | 905/ | 907/ | 10217 | |
| - | DISPLA | 001142 | 2232# | 3484 2787* 2795 | 3518 2795* | 3541 9303* | 3581 9458* | 3613 | 3811 | 3852 | 3879 | 8954 | 8974 | 10217 | |
| - | DLT = DLTERR= | 000174 100000 000010 | 2032# | 4274 | 10531 | | | | | | | | | | |
| - | DMD = DRA = | 000040 000001 | 2055# | 3646 | 3654 | 3693 | 3702 | 8099 | 8181 | 8189 | 8289 | 8412 | 11312 | | |
| - | DRDY = DROT = | 000200 000040 | 2062# 2060# 8317 | 3093 10510 | 3098 | 3123 | 8553 | | | | | | | | |
| - | DROTER= | 000010 | 2039# | 8451 | 10512 | 12398# | | | | | | | | | |
| | DRPARE= DRSTER= DRVABT | 040000 040000 057110 | 3466 10708 4202 | 12393# 10714 13181# | 10848 | 12482# | | | | | | | | | |
| - | DRVBIT DRVDRP DRVMSK= | 001630 001666 | 2675# 2708# 2019# | 3184* 2911* | 3250 3057* | 3252* 3089* | 4091 3127* | 4092 3186 | 4141 3217 | 4142 4092* | 8584 4142* | 8588* | 8589 | 8591 | 8599* |
| - | DRVNUM | 001626 | 2674# 3735 | 3193* 3801 | 3258* 3843 | 3259 3907 | 3280 3924 | 3320 3970 | 3370 3987 | 3387 6532 | 3413 6560 | 3457 6916 | 3473 7429 | 3635 8548 | 3683 8587* |
| - | | | 8596 13333 2705# | 8600* 13336 | 8779* 13342 | 8792* 13350 | 8814* | 8934* | 8956* | 8977* | 8987* | 9003* | 9896 | 10063 | 11304 |
| Contramos of the | | 040000 | 2066# | 2912 3243 | 3048 3490 | 3153 3547 | 3171 3765 | | | | | | | | |
| - | | 177570 010000 | 10435 1832# 2048# | 12372# | 2786 | | | | | | | | | | |
| CONTRACTOR OF STREET, | DIERR = | 010000 000040 | 8110 2041# 12395# | 12402# 3075 | 3144 | 9939 | | | | | | | | | |
| 101-140-140-140-140-140-140-140-140-140- | DTYPE | 001720 | 2726# 9934 | 3032* 9959* | 3078* 9964* | 3105* | 3132 | 3139* | 3147* | 3989 | 6531 | 6918 | 7431 | 8551 | 9925 |
| 1 | | | | | | | | | | | | | | | |

| CZR6KGO CZR6KG. | RK6 FCTNL CTRL P11 28-AUG-8 | DIAG 1 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15:1 TABLE | 17 PAGE USER S | 255 YMBOLS | | | | | | SEQ 0 |
|---|--|--|--|---------------------------------|------------------------|------------------------|------------------------|-------------------------|----------------|-----------------|-------|-------|-------|--------|
| DT001 DT002 DT003 DT004 DT005 DT006 DT007 DT010 DT015 DT015A | 060610 060616 060566 060616 060616 060616 060616 060616 060666 | 2378 2393 2404 2485 2499 2524 2550 2587 2573 2633 | 13336# 13337# 13338# 13339# 13340# 13341# 2596 2625 13351# | 2605 13350# | 2613 | 13342# | | | | | | | | |
| ECCW = | 020000 | 2697# | 3058 | 3088 | 3100 | 3107 | | | | | | | | |
| ECH = ECHERR= EMCCLR | 000100 000001 056650 | 2633 2697# 2082# 2042# 8038 3515 4283 3481 | 10496 10522 3521 | 10520 12408# 13144# | | | | | | | | | | |
| EMCERR EMDA | 057023 056630 | 4283 3481 | 3521 13171# 3514 | 3537 | 3577 | 3609 | 8666 | 8733 | 9006 | 13141# | | | | |
| EMDI | 050276 056564 | 3486 | 3616 3520 10123 | 13148# 3543 | 3583 | 3615 | 3813 | 3854 | 3881 | 13133# | | | | |
| EMDPAR= EMDSC EMDTPE= | | 4276 3482 3245 3431 | 3487 3492 13132# | 13166# 3493 3549 | 3499 3767 | 3538 13137# | 3544 | 3550 | 3556 | 13136# | | | | |
| EMMI EMNZPR | 057064 056461 | 3825 3349 | 13177# 3578 | 3584 | 13120# | | | | | | | | | |
| EMRCAL= EMRDB EMRSET | 056777 056771 | 3746 4277 3875 | 13149# 4284 3882 | 10124 13164# 13174# | 13167# | | | | | | | | | |
| EMSCLR EMSELD= | 057044 050250 | 3246 3333 | 4284 3882 8734 3384 | 13174# 3785 | 13147# | | | | | | | | | |
| EM2 VAL | 057044 050250 050362 056712 056444 000030 056754 056727 | 9007 3814 3332 1921# 8667 3874 | 13156# 3826 3348 2770* 13161# 13157# | 3855 3383 2771* | 13153# 3394 | 3430 | 3498 | 3555 | 3745 | 3760 | 3784 | 8805 | 8822 | 13117# |
| EMWCS2 EM1 | 056522 053405 001360 | 3395 2951 | 13126# 2980 2951* | 12824# | | | | | | | | | | |
| EM1N EM10 | 054076 | 2376# 5528 | 2951* 5582 | 2980* 5716 | 4089* 7126 | 4100* 7143 | 4110* 7264 5575* | 4117* 7281 | 4126* 12434 | 4139* | 4202* | 7442* | 7602* | 712/ |
| EM10N | 001450 | 2571# 7135* | 5582 5510* 7143* | 5521* 7255* | 5528* 7264* 7117 | 5563* 7273* 7135 | 7281* 7255 | 5582* 10475* 7273 | 5702* 12436 | 5716* 12884# | 6809* | 6818* | 7117* | 7126* |
| EM11 EM11A EM11N | 054123 054151 001460 | 5521 5510 2585# 3767* | 5575 5563 3332* 3784* 12896# 3245* | 5702 12435 3383* 3813* | 12888# 3430* | 3481* | 3486* | 3492* | 3498* | 3537* | 3543* | 3549* | 3555* | 3745* |
| | 054225 | 3767* 12437 | 3784* 12896# | 3813* | 3854* | 8805* | 9006* | 3472 | 3470 | 373. | 3343 | 3347 | 3,,,, | 3.43 |
| EM12 EM12N EM13 | 001470 | 12437 2594# 4276* | 3245* 6809 3825* | 3348* 12438 | 3394* 12901# | 3609* | 3615* | 3760* | 3881* | 8666* | 8733* | | | |
| EM13 EM13N EM14 EM14N | 054260 001500 054310 | 4276* 2603# 6818 2611# | 12439 | 12438 3874* 12905# | 4283* | 10123* | | | | | | | | |
| EM14N EM15 EM15N | 001510 054342 | 12441 | 3514* 12910# 10994* | 3520* | 3583* | 8822* | | | | | | | | |
| EM15N EM16 EM17 | 001520 054365 054410 | 2623# 12442 12443 | 12914# 12918# | 10997* | | | | | | | | | | |

| CZR6KGC CZR6KG. | RK6 FCTNL CTRL P11 28-AUG-8 | DIAG 1 15:16 | MACY11 | 30(1046) CROSS F | 28-AUC | -81 15: TABLE - | 17 PAGE - USER S | 256 YMBOLS | | | | | | SEQ 02 |
|--|--|---|---|----------------------|--------------|--------------------|---------------------|---------------|--------------|--------------|--------------|--------------|--------------|--------------|
| EM18 EM19 EM2 EM2INT EM20 EM21 EM22- EM23 EM24 EM25 EM26 EM27 EM28 EM29 | 054431 054456 053465 056671 001370 054500 054524 054550 054571 054602 054615 054643 054643 054643 054670 054703 054777 055017 055017 055161 055161 055170 055213 055233 | 12444 12445 12833# 3761 2391# 12446 12447 12448 12450 12451 12453 12454 12455 12456 9619 2402# 12458 12459 | 12921# 12925# 3768 3754* 12928# 12932# 12936# 12939# | 13150# 9864* | 10081* | 10109* | | | | | | | | |
| EM24 EM25 EM26 EM27 EM28 EM29 | 054602 054615 054631 054643 054670 054703 | 12451 12452 12453 12454 12455 12456 | 3768 3754* 12938# 12936# 12936# 12943# 12948# 12948# 12952# 12954# 12965# 12965# 12984# 12984# 12984# 12989# 12989# 12989# 12989# | 13166 | | | | | | | | | | |
| EM3 EM3N EM30 EM31 EM32 | 053546 001400 054724 054777 055017 | 12460 | 12842# 3211* 12957# 12965# 12968# | 3225* | 3239* | 3300* | 10223* | 10225* | 10236* | | | | | |
| EM3 EM3N EM30 EM31 EM32 EM33 EM34 EM35 EM36 EM36 EM37 EM38 EM39 | 055123 055140 055161 055170 055213 | 12461 12462 12463 12464 12465 12466 | 12974# 12981# 12984# 12987# 12989# 12993# | 13136 13132 | | | | | | | | | | |
| EM39 EM4 EM40 EM41 EM42 EM43 EM44 EM45 EM46 EM47 EM48 | 053616 001410 055255 055307 055330 055353 | 12466 12467 9864 2483# 12468 12469 12470 12471 12472 12473 3239 3211 3225 | 12996# 10081 3577* 13000# 13005# 13012# | 12849# | | | | | | | | | | |
| EM49 | 055432 055472 055527 055610 055667 053711 001420 055737 | 12472 12473 3239 3211 3225 3300 10223 2497# 3754 4089 4126 4139 | 13050# 12859# 13057# 4100 | 4110 | 4117 | 13068# | | | | | | | | |
| EM5 EM5N EM50 EM51 EM52 EM53 EM54 EM55 EM56 | 056036 056131 056227 056312 056341 056366 053755 | 4126 4139 10994 10997 10109 10225 2522# 10236 2548# 2678# 5900 6888 | 13079# 13091# 13100# 13104# 13109# 12866# | 4.10 | 4111 | , 30004 | | | | | | | | |
| EM6N EM7 EM7N | 001430 054034 001440 | 10236 | 12874# | | | | | | | | | | | |
| ERRCNT ERRLMT | 001632 001634 | 2676# 2678# 5900 6888 | 9581* 4306 5983 7528 | 9584 4802 6068 | 4875 6153 | 4956 6212 | 5025 6269 | 5106 6327 | 5175 6383 | 5255 6439 | 5326 6577 | 5400 6652 | 5471 6725 | 5812 6850 |

| SEQ 0256 | |
|------------------------|--|
| | |
| 7465* 8483* 9785 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

8

\$

| CZR6KGO RK6 F CZR6KG.P11 | CTNL CTRL DIAG 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE | 258 YMBOLS | | | | | | SEQ 02 | 2 |
|--|--|--|---|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|---|
| IDAE = 00200 IDAERR= 00200 IE = 00010 ILF = 00000 ILFERR= 00020 INTHLR 03444 | 3938 2004# 2036# 2036# 2036# | 3946 2970 10496 12424# 3041 | 4007 3868 10577 5731 | 12400# 7817 9609# | 7920 | 8118 | 8490 | | | | | | | |
| INTR = 00036 | 52 2693# -7623* 8632* 9853 1919# | 2944* 7684* 8701* 9908* 2768* | 2949 7764* 8789* 10068* 2769* | 2969* 7816* 8809* 10073 | 2974 7853* 8942* 11353* | 3741* 7922* 8964* 13450* | 3823 8017 9600* | 3859* 8076* 9610* | 3914× 8119* 9716* | 3977* 8223* 9724 | 5652 8259* 9729* | 7428* 8356* 9762 | 7465* 8483* 9785 | |
| IR = 00010 IWAT1M 0353 IWAT1S 0354 IWAT11 0354 IWAT12 0354 IWAT14 0354 IWAT15 0354 IWAT16 0355 IWAT2S 0356 IWAT32 0355 IWAT48 0355 IWAT64 0355 | 70 9809# 90 9815# 90 9824# 90 9821# 90 9818# 90 9812# 90 9839# | 12118 12115 12111 12112 12113 12114 12105 12116 12106 12107 12108 12117 12109 12110 | | | | | | | | | | | | |
| IWAT8S 03536 IWAT80 03546 IWAT96 03546 KIPAR0= 17236 KIPAR1= 17236 KIPAR3= 17236 | 70 9833# 9830# 1952# 1953# 1954# 1955# | 12117 12109 12110 9151 | 9183 | | | | | | | | | | | |
| KIPAR4= 1723 KIPAR5= 1723 KIPAR6= 1723 KIPAR7= 1723 KIPDR0= 1723 KIPDR1= 1723 KIPDR2= 1723 KIPDR3= 1723 KIPDR4= 1723 KIPDR6= 1723 KIPDR6= 1723 | 1957# 1958# 1959# 1941# 1942# 1943# 10 1945# 12 1946# | 11141* 9199 | | | | | | | | | | | | |
| KIPDR7= 1723 | 16 1948# 10 2721# 12 2722# | 5660* 9717 | 5676* | 9630* | 9720* | 10053* | 10100* | 11310* | | | | | | |
| KWLADD 0017 KWLVEC 0017 LCKHLR 0345 LCLKPR= 1000 LCLKTK 0016 LDCON 0360 | 9629# 00 2706# 74 2712# | 9718 9727 3863* 9934# 11501 | 9758 3865 | 9855 9629* | 10051 9757* | 10098 9764 | 11308 9766* | 9791* | 9858 | 10069* | 10076 | | | |
| LF = 0000 | 12 1825# 34 9908# | 11501 | | 12615 | 12618 | | | | | | | | | |
| LOADRK 0357 LRLOAD 0356 | 34 3304 12 1825# 9908# 4067 4672 5137 5753 6117 | 12101 4225 4698 5154 5776 6132 | 4253 4733 5214 5791 6191 | 4350 4762 5233 5837 6248 | 4378 4781 5288 5860 6306 | 4426 4827 5305 5879 6362 | 4459 4847 5350 5923 6418 | 4505 4914 5369 5951 6464 | 4525 4938 5425 5965 6492 | 4557 4989 5443 6008 6616 | 4578 5006 5494 6032 6631 | 4611 5068 5547 6047 6689 | 4639 5086 5619 6093 6704 | |

| CZR6KG0 CZR6KG. | RK6 FCTNL CTRL DI P11 28-AUG-81 1 | IAG 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG EFERENCE | -81 15: TABLE - | M 4 17 PAGE - USER S | 259 | | | | | | SEQ 0257 |
|--|--------------------------------------|--|--|--|--|--|--|---|---|---|---------------------------------------|---------------------------------------|---------------------------------------|----------------------------------|
| LSTCYL | 036120 | 6759 7314 7709 8065 8363 4065 | 6788 7331 7749 8080 8378 6463 | 6829 7375 7770 8092 8393 6491 | 6864 7409 7785 8124 8405 7609 | 6947 7454 7797 8156 8436 7610 | 6988 7477 7841 8174 8459 7747 | 7007 7505 7860 8212 8497 9936* | 7049 7579 7875 8228 8515 9942* | 7064 7612 7898 8243 8566 9948# | 7084 7634 7946 8267 9888# | 7185 7649 7988 8282 11338 | 7200 7674 8007 8303 11367 | 7222 7694 8024 8341 |
| L.ASOF L.BA L.CS1 | 001612 001604 001600 | 2658# 2656# 3559* 6530* 8981* | 8250* 6535* 3063* 3565* 6531* 8993* | 6920* 3114* 3593* 6559* 9891 | 8992* 3195* 3636* 6917* 9925* | 10275 3228* 3684* 6918* 9926 | 10290 3281* 3736* 3626* 10055 | 3321* 3772* 8696* 10070* | 3371* 3802* 8781* 10071 | 3414* 3844* 8794* 10209 | 3415* 3906* 8937* 10279 | 3458* 3925* 8947* 10356 | 3505* 3969* 8959* 11013 | 3524* 3988* 8967* 11041 |
| L.CS2 | 001610 | 11065 2662# 3694* 7500* | 11072 3061* 3735* 7586* 10273 | 3113* 3801* 7659* | 3192* 3843* 7716* | 3280* 3907* 8182* | 3290* 3924* 8624* | 3320* 3970* 8694* | 3370* 3987* 8778* | 3413* 4835* 8791* | 3457* 6532* 8935* | 3635* 6560* 8957* | 3645* 6916* 8978* | 3683* 7485* 8988* |
| L.DCYL | 001606 001614 | 2659# | 10065 | 6536* | 6562* | 6922* | 8980* | 8990* | 10064 | 10361 | 10882 | 11005 | 11377* | |
| L.DS L.DT L.MR1 | 001606 001607 001616 001602 | 2660# 2661# 2665# 8289* 2657# | 6955* 3926* 3322* 8310* 6533* | 10364 4317 3336* 8412* 6921* | 6534* 3459* 8444* 8991* | 6561* 3503* 8467* 9911 | 6919* 3567* 8495* 10277 | 10362 3591* 10333 | 10885 3646* | 11004 3693* | 11388 7867* | 11390* 7906* | 8099* | 8181* |
| MCLK = MCLOCK MDS = MDSERR= | 000400 036316 001000 | 2077# 3650 2026# | 10029 3698 10561 12420# | 10030 8102 | 8186 | 8293 | 8415 | 8420 | 8425 | 10020# | | | | |
| MEMBAS MEMPAR | 001714 001670 | 2723# | 9656 9643* | 9663* | 9701* | 9706 | | | | | | | | |
| MEMPYB= MEMSZB= MERD = MESMSK= | 000004 000002 001000 000017 | 2698# 2698# 2078# 2071# | 5612 4901 | 5615 4906 | 5049 | 5055 | 5200 | 5206 | | | | | | |
| MEWD = | 001652 | 2079# 2689# 2076# | 9784 8418 | 8423 | | | | | | | | | | |
| MIND = MMVEC = MMVECA | 000250 001716 | 2689# 2076# 1930# 2724# 2075# | 5654* | 9666 | 9705 | | | | | | | | | |
| MSP = | 000100 035314 017760 | 2075# 3864 2146# | 9783# | 9857 | 10075 | | | | | | | | | |
| M.CDIF= M.DRV = M.HEAD= M.ID = M.PAR = | 017760 000007 007000 000003 | 2145# 2142# 2149# 2144# 2143# 2148# | | | | | | | | | | | | |
| NCERWE= NED = NEDERR= | 010000 000001 1 | 2147# 10516 2029# 10551 | 12403# 3073 12417# 10569 | 3142 | 10549 | | | | | | | | | |
| NEMERR= NEWDRV NEWPAS | | 2028# 5508 4093 2921# | 10569 5561 4143 9144 | 10571 8582# | 12422# | | | | | | | | | |

.

| CZR6KGO RK6 FCTNL CT CZR6KG.P11 28-AUG | TRL DIAG G-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG EFERENCE | -81 15: TABLE - | 17 PAGE | 260 YMBOLS | | | | | | SEQ 0258 |
|--|---|--|--|---|--|---|---|---|---|--|---|---|--|
| NEXINT 034434 NXF = 000004 | 2941 2038# | 9600# | 9715 | | | | | | | | | | ė. |
| NXFERR= 000004 OBUFF 072414 | 12392# 4228 4581 5140 5710 6771* 7188 7426 8569 1992# 2057# | 4353 4614 5291 5712 6791 7203 7480 8992 8244 | 4362 4622 5353 5756 6920 7218* 7577* 9669 | 4381 4642 5389 5840 6991 7225 7582 11019 | 4429 4675 5428 5926 7010 7252 7652 11056* | 4437 4683 5460 5942 7052 7256 7657* 11057* | 4462 4701 5622 6011 7067 7271 7712 11077 | 4508 4736 5640* 6096 7081* 7274 7878 11136 | 4516* 4765 5644* 6535 7087 7317 7991 11370 | 4528 4830 5683* 6619 7114 7329* 8010 13455# | 4560 4856 5690* 6692 7118 7334 8285 | 4568* 4857 5703 6762 7133 7378 8408 | 4569* 4992 5705 6770* 7136 7412 8518 |
| OFST = 000004 OPEROO 050250 | 2057# 8806 | 12489 | 12507# | 13147 | | | | | | | | | |
| OPER04 050276 OPER06 050312 | 12491 12492 | 12512# 12514# | 13148 | | | | | | | | | | |
| OPER10 050321 OPER12 050337 OPER14 050353 | 12493 12494 12495 | 12516# 12519# 12522# | 13149 | | | | | | | | | | |
| OPER16 050362 OPER20 050367 | 12496 12497 | 12524# | 13156 | | | | | | | | | | |
| OFFSET= 000115 OFST = 000004 OPER00 050250 OPER02 050265 OPER04 050276 OPER06 050312 OPER10 050321 OPER12 050337 OPER14 050353 OPER16 050362 OPER20 050367 OPER22 050401 OPER24 050414 OPER26 050431 OPER30 050447 OPER30 050447 OPER30 050463 OPER34 050507 OPER36 050533 OPER37 050557 OPER40 050613 OPER41 050613 | 8806 12490 12491 12492 12493 12494 12495 12496 12497 12498 10082 12500 12501 12502 12503 12504 | 12489 12510# 12514# 12516# 12516# 12522# 12522# 12525# 12535# 12535# 12538# 12542# | 12529# | | | | | | | | | | |
| OPER36 050533 OPER37 050557 | 12504 6812 12555# | 12546# 6819 | 12550# | | | | | | | | | | |
| OPER42 050650 | 7120 5511 | 7127 12561# | 7138 | 7144 | 7258 | 7265 | 7276 | 7282 | 12556# | | | | |
| OPER43 050724 OPER44 050777 OPI = 020000 OPIERR= 000020 | 5564 5701 2049# 10537 2864 2867 | 12569# 12577# 10496 12412# | 10535 | | | | | | | | | | |
| OPRO01 051056 OPRO02 051105 OPRO03 051113 OPRO04 051143 OPRO05 051165 | 2867 2874 2886 2886 2829 | 2878 12595# 12600# 12604# | 2895 | 12593# | | | | | | | | | |
| OPROVI 051056 OPROVI 051056 OPROVI 051105 OPROVI 051113 OPROVI 051143 OPROVI 051143 OPROVI 051165 OPROVI 051236 OPROVI 051236 OPROVI 051236 OPROVI 051402 OPROVI 051452 OPROVI 051573 OPROVI 051736 OPROVI 051746 OPROVI 051752 | 2874 2886 2829 3060 2840 3158 3163 | 12589# 2878 12595# 12600# 12604# 12611# 3056 12626# 12635# 12642# 5052 12675# 12676# 12677# 5054 | 3087 | 12614# | 13 | | | | | | | | |
| | 5614 4904 4905 5053 5204 4907 2859 7442 | 12642# 5052 12675# 12676# | 5203 | 12657# | | | | | | | | | |
| OPR016 051766 OPR017 052547 | 4907 2859 7442 | 5054 12680# 7602 12762# 12771# | 5205 12748# | 12678# | | | | | | | | | |
| OPR018 052664 OPR019 052752 | 8762 11301 | 12771# | | | | | | | | | | | |

E 00

| Special activities - contra | CZR6KGO RK6 FCTNL CZR6KG.P11 28-A | CTRL DIAG NUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE - USER S | 261 | | | | | | SEQ O | 25 |
|--|--|---|---|--|--|-------------------------------|---------------------------------|-------------------------|------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|----|
| the same of the same blist will be a second to the same of the sam | OPRO20 053115 OPRO21 053211 OPRO22 053252 OPTFLG 001664 | 11365 11393 11409 2695# 5049 7439 9855 2913 | 12788# 12799# 12805# 2857 5055* 7441* 10051 3869 | 2860* 5200 7599 10098 5732 | 2912* 5206* 7601* 11308 6677 | 3048 5610 9644* 8659 | 3058* 5612 9652* 9638# | 3088* 5615* 9653* | 3100* 5627 9675* | 3107 5641 9693* | 3153 5657 9700* | 3171* 5680 9708 | 4901 5687 9727* | 4906* 7369 9758 | |
| SECTION AND PROPERTY AND PROPERTY OF SECTION AND PERSONS ASSESSED FOR THE PERSONS ASSESSED FOR THE PERSONS ASSESSED. | OR = 000200 PACK = 000103 PARM 001752 PARPRE= 000100 PAT = 000020 PAT02 047234 PAT03 047274 PAT04 047334 PAT05 047374 PAT06 047434 PAT10 047474 PAT11 047534 | 2024# 1987# 2179 2701# 2073# 11191 11196 11201 11206 11211 11216 11221 11226 11231 | 3228 2745# 5610 3459 12126# 12166# 12186# 12206# 12229# 12269# 12289# 12309# | 9644 7867 | 9653 | 9675 | 9693 | 9700 | | | | | | | |
| Secure of the second section of the second section of the second section of the second section of | PAT12 047574 PAT13 047634 PAT14 047674 PAT15 047734 PAT16 047774 PCA = 004000 PCD = 010000 | 11246 2080# 2081# | 11249 | 12349# | | | • | | | | | | | | |
| | PERHLR 034452 PGE = 002000 PGERR = 000020 PIP = 020000 PIRQ = 177772 | 9617# 2027# 7964 2065# 1831# | 9710 10565 10567 | 12421# | | | | | | | | | | | |
| | PIRQVE = 000240 PROGEN 044124 PRO = 000000 PR1 = 000040 PR2 = 000100 PR3 = 000140 PR4 = 000200 | 1925# 11337 1848# 1849# 1850# 1851# 1852# | 11364 2921 | 11389 3036 | 11393# 9732 | 11410 9847 | | | | | | | | | |
| - | PR5 = 000240 PR6 = 000300 | 1853# 1854# | 1962 | | | | | | | | | | | | |
| - | PR7 = 000340 PS = 177776 | 1855# 1828# 1829# | 2754 1829 | 2942 | 3042 | 5635 | 9642 | 9668 | 9711 | 9719 | | | | | |
| - | PSW = 177776 PWRVEC= 000024 RDCHR = 104410 | 1829# 1920# 11858 | 2774* 12094# | 2775* | 12015* | 12016* | 12025* | 12031* | 12043* | 12044* | | | | | |
| | RDDATA= 000121 | 1994# 5777 6363 | 4068 5792 6419 | 4782 5861 6465 | 4848 5880 6493 | 4939 5952 6632 | 5007 5966 6705 | 5087 6033 6830 | 5155 6048 6865 | 5234 6118 6948 | 5306 6133 7506 | 5371 6192 7947 | 5444 6249 8025 | 5548 6307 | |
| | RDGATE = 100000 RDHEAD = 000125 RDLIN = 104411 RDOCT = 104412 RDSTHD 036362 RDY = 000200 REALBA 050054 | 2084# 1996# 11932 2868 4294 2005# 10306* | 4254 12095# 2879 6564 2970 12384# | 6559 2896 10050# 10234 | 7798 12096# 11306 | 8093 | 8379 | | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG EFERENCE | -81 15: TABLE - | 17 PAGE USER S | 262 YMBOLS | | | | | | SEQ 0 |
|--|---|--|----------------------------------|--------------------------|-------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|-----------------|-----------------|
| REALCY 050056 12385# REALSE 050062 6821 REALTR 050060 6811 REALUB 050052 10312* REALWC 050050 10256* RECAL = 000113 1991# REFMT 001676 2713# 6676* | 12387# 12386# 12383# 10389 3736 11339 2759* 6755* | 10477 3906 4219* 6971* | 12382# 3969 4346* 8337* | 7786 4422* 8580* | 7842 4501* 11363 | 8081 4553* 11375 | 8213 4607* | 8342 4667× | 8626 4726* | 8696 4810* | 8781 6524* | 8937 6604* |
| REPNR = 100000 10814 RESREG= 104414 9580 RESTRT 001762 2177 RESVEC= 000010 1915# | 12483# 9736 2748# | 9871 | 10132 | 10182 | 10396 | 10478 | 10482 | 10836 | 10858 | 12098# | | |
| RKASOF = 000016 1974# RKBA = 000004 1969# RKCS1 = 000000 1967# RKCS2 = 000010 1971# RKDA = 000006 1970# RKDB = 000024 1976# RKDCYL = 000020 1975# RKDS = 000012 1972# RKECPS = 000030 1980# | 8635 7426* 2945* 10071* 2967* 10065* 4251 10064* 8553 | 8704 2970* 10085 3387* 10062 | 3868* 10146* 7429* | 7432* 10157* 8548* | 7817* 10161 8723* | 7920* 10163 10063* | 8022* 10173* 10092 | 8118* 10216 10155* | 8298* 11305* 10165 | 8490* 11306 10214* | 8552* 11303* | 8634* 11304* |
| RKECPT = 000032 1981# RKER = 000014 1973# RKMR1 = 000026 1977# | 7437 3654* | 7596 3702* | 8105* | 8189* | 8296* | 8418* | 8423* | 8428* | 10029* | .10030* | 10156* | 11312* |
| RKMR2 = 000034 1978# RKMR3 = 000036 1979# RKPRI 001622 2669# RKSPAR= 000022 1982# RKVEC 001620 2668# RKWC = 000002 1968# | 10171 10172 2918* 7956* 2916* 7427* 3290 | 5647 3040 8019 3645 | 5653* | 5731* | | | | | | | | |
| SAVREG= 104413 9527 9839 | 9638 9842 8723 | 9806 9845 | 9809 10050 | 9812 10145 | 9815 10332 | 9818 10413 | 9821 10422 | 9824 12097# | 9827 | 9830 | 9833 | 9836 |
| 6824 7538 | 3950 6934 8826 | 10214 4080 6964 9010 | 11303 4247 7079 12099# | 4279 7102 | 4286 7149 | 4315 7215 | 4399 7240 | 4480 7287 | 4932 7424 | 6548 7449 | 6571 7495 | 6587 7520 |
| SECERR= 000040 6816 SEEK = 000117 1993# SELDRV= 000101 1986# 3772 | 12099 10388 3802 3063 7899 | 12432# 3844 3114 8157 | 3925 3195 8175 | 3988 3281 8304 | 7455 3321 8394 | 7613 3371 8437 | 7675 3414 8460 | 7750 3458 8794 | 7861 3524 | 8066 3565 | 8981 3636 | 3684 |
| SETCLK 001742 2181 SKI = 000002 2037# SKIERR= 000002 3946 SPACE2 051053 3178 SPAR = 020000 2012# SPARER= 000001 3466 SPCHLR 070400 5653 SPCPAR 070410 5654 | 7888 9563 10163 10500 13449# 13452# | 12391# 9575 10498 12390# | 12588# | | | | | | | | | |
| SPDERR= 000200 10508 SPDLSS= 000020 2059# SRCHLD 001702 2718# | 12397# 10506 11082 | 11106* | 11158* | 11282 | | | | | | | | |

| CZR6KGO CZR6KG.I | P11 28-AUG-81 | 15:16 | | 30(1046) CROSS R | 28-AUC EFERENCE | -81 15: TABLE - | 17 PAGE | 263 YMBOLS | | | | |
|--|--|--|--|-----------------------|--------------------|--------------------|---------------|---------------|--------|--------|--------|-------|
| SRTFLG SRTINS= | 001624 000010 | 2670# | 2742* 2857 | 2745* 2860 | 2748* | 2751* | 2862 | 3054 | 3262 | | | |
| SRTSPL= SRO = SR1 = SR2 = | 177572 | 1990# 1934# 1935# 1936# | 9180 | 9195* | 9202* | 11090* | 11098* | 11116* | 11168* | 11278* | | |
| SR3 = SSINIT STACK = START | 177574 177576 172516 037176 001100 001772 001776 177774 | 1936# 1937# 10205# 1819# 2170 2743 | 9192* 12100 2753 2176 2746 | 2766 2751# 2749 | 2936 2752# | 9590 11403 | 9622 | 11394 | | | | |
| STKLMT= | 177774 100000 | 1830# | 3209 | 3223 | 3298 | 3329 | 3345 | 3380 | 3391 | 3427 | 3496 | 3553 |
| SWR | 001140 | 3782 2231# | 8803 2764 | 8819 2786* | 2788 | 2794* | 2801* | 2815 | 9249 | 9263 | 9266 | 9281 |
| WREG - | 000176 000001 | 9466 2174# 1883# | 9501 2794 | 9505 2815 | 9582 11702 | 9617 11741 | 9745 11764 | 10743 | 11702 | 11741 | 11796* | 12023 |
| SW00 = SW01 = SW02 = SW03 = SW04 = SW05 = SW06 = SW07 = SW09 = | 000001 000002 000004 000010 000020 000040 000100 000200 000400 001000 000002 | 1883# 1873# 1872# 1871# 1870# 1869# 1868# 1866# 1865# 1864# 1882# 1863# | 1883 1882 1881 1880 1879 1878 1877 1876 1875 1874 | | | | | | | | | |
| SW10 = SW11 = SW12 = SW13 = SW14 = SW15 = | 002000 004000 010000 020000 040000 100000 000004 | 1862# 1861# 1860# 1859# 1858# 1881# | 9582 10743 | | | | | | | | | |
| SW4 = SW5 = SW6 = SW7 = SW8 = S.ACLO = S.BRHM = S.BRKE = S.DOOR = S.DOOR = S.DROT = S | 000020 000040 000100 000200 000400 001000 000100 000100 000400 000400 000200 000200 000200 040000 040000 040000 040000 040000 | 1880# 1879# 1878# 1876# 1876# 1875# 2102# 2116# 2134# 2117# 2088# 2109# 2097# 2097# 2103# 2120# | 9745 | | | | | | | | | |

SEQ 0261

12036*

| | CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE - USER S | 264 | | | | | | SEQ |
|-------------------|--|--|--|---|---|---|--|--|--|--|--|--|--|
| | S.HDFL= 000200 2131# S.HDHM= 000040 2115# S.ICYL= 000040 2104# S.ILF = 000400 2137# S.LOAD= 010000 2132# S.MHD = 000400 2132# S.MHD = 000400 2136# S.OFF = 002000 2093# S.PAR = 001000 2105# S.PIP = 020000 2096# S.PLO = 004000 2135# S.REV = 004000 2121# S.RTZ = 020000 2123# S.SECT= 000020 2123# S.SECT= 000000 2128# S.SYI = 002000 2106# S.SPIN= 010000 2108# S.SPIN= 010000 2119# S.TYPE= 000400 2119# S.UNLD= 040000 2119# S.UNLD= 040000 2110# S.WCLK= 000100 2089# S.WCLK= 000100 2130# S.WCLK= 000040 2130# S.WGAT= 000100 2130# S.WGAT= 004000 2107# S.WRL = 004000 2094# | 7914 | 8477 | | | | | | | | | | |
| | S.XDOK= 000020 S.XERR= 001000 2133# TBITVE= 000014 1916# TCHKOP= 104421 3084 3690 4636 5097 5803 6260 6931 7466 7767 8353 8952 | 3150 3778 4695 5152 5853 6318 6961 7492 7782 8360 8972 3421 5505 | 3220 3829 4709 5166 5876 6374 7004 7517 7857 8375 9000 3465 5558 | 3234 4078 4748 5230 5891 6430 7019 7607 7911 8390 11350 3530 | 3287 4244 4778 5245 5939 6476 7061 7625 8000 8433 11357 3659 | 3296 4269 4793 5303 5963 6545 7076 7631 8044 8474 11385 3709 | 3326 4295 4844 5317 6024 6565 7197 7646 8135 8509 12103# 3937 | 3342 4373 4867 5366 6044 6628 7212 7671 8168 8527 | 3377 4406 4930 5386 6059 6643 7326 7686 8194 8578 | 3509 4452 4948 5440 6110 6701 7343 7691 8240 8649 | 3572 4486 5004 5457 6129 6716 7390 7706 8256 8718 | 3599 4522 5017 5769 6144 6777 7421 7729 8264 8786 | 3642 4575 5080 5788 6203 6841 7447 7761 8279 8800 |
| | TCHKWE = 104422 3203 4651 8109 TGETRK = 104420 3070 | 8316 8316 | 5558 8450 3389 | 5694 12104# | 6504 | 6800 | 6876 | 7096 | 7234 | 7809 | 7887 | 7961 | 8036 |
| The second second | TIMENT 001654 2690# | 8316 3120 10080 9760* 11673* | 10126 9789* | 3606 10226 9792* | 3742 10425 9851* | 3757 12102# 10067* | 3809 | 3850 | 3878 | 4273 | 8661 | 8728 | 8818 |
| | TKVEC = 000060 TLOADR = 104417 3065 3561 3972 4632 5076 5555 6639 | 11673* 3115 3568 4002 4647 5093 5656 6105 6697 | 11674* 3197 3595 4075 4691 5148 5765 6712 | 3229 3638 4240 4705 5162 5784 6140 6773 | 3283 3648 4265 4744 5226 5799 6199 6796 | 3292 3686 4369 4774 5241 5849 6256 6837 | 3323 3696 4386 4789 5299 5872 6314 6872 | 3338 3738 4449 4840 5313 5887 6370 6927 | 3373 3774 4467 4863 5362 5935 6426 6957 | 3417 3804 4518 4926 5382 5959 6472 7000 | 3461 3846 4533 4945 5436 5973 6500 7015 | 3506 3909 4571 5000 5454 6020 6541 7057 | 3526 3928 4586 5014 5502 6040 6624 7072 |

| CZR6KGO CZR6KG. | RK6 FCTNL CTRL P11 28-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG EFERENCE | -81 15: TABLE - | 17 PAGE | 265 YMBOLS | | | | | |
|--|--|---|--|--|--|--|--|--|---|---|--|--|--|
| | 000044 | 7092 7642 7954 8275 8628 | 7193 7661 7996 8291 8697 | 7208 7681 8015 8312 8783 | 7230 7702 8032 8349 8796 | 7322 7719 8073 8371 8939 | 7339 7757 8088 8386 8948 | 7386 7778 8100 8401 8961 | 7417 7793 8132 8414 8968 | 7462 7805 8164 8446 8983 | 7487 7849 8184 8470 8995 | 7513 7868 8220 8505 11346 | 7587 7883 8236 8523 11381 |
| TRAPVE= TRKERR= | 000064 000034 000020 | 1924# 1922# 6807 | 2772* 10385 | 2773* 12431# | | | | | | | | | |
| | 000014 104416 | 1917# 3033 3798 423 5285 6293 6985 7872 8487 9135 | 3080 3840 4456 5347 6350 7043 7893 8545 9138# | 3110 3903 4502 5422 6406 7082 7917 8560 | 3189 3921 4554 5491 6460 7179 7943 8614 | 3277 3966 4608 5544 6489 7219 7981 8684 | 3317 3984 4669 5607 6528 7307 8062 8775 | 3367 4062 4727 5750 6557 7407 8116 8931 | 3410 4222 4824 5834 6605 7475 8153 11331 | 3454 4238 4911 5920 6678 7503 8171 11360 | 3632 4263 4987 6005 6756 7574 8209 12100# | 3665 4292 5061 6090 6827 7745 8338 | 3680 4347 5135 6177 6913 7814 8456 |
| TSTCYL TSTLUP TST10 TST100 TST100 TST101 TST102 TST103 TST104 TST105 TST106 | 036122 004720 003162 005334 026132 026356 026504 027026 027560 030022 030246 030466 006260 031174 006376 006514 006756 007110 007320 007510 | 9937* 3304# 2934# 8059# 8151# 8207# 8207# 8542# 8609# 8679# 8673# 3678# 3678# 3678# 3678# 3838# 3899# | 9943* 8598 9308 9315 9372 9373 9374 9376 9377 9376 9377 9318 9319 9320 9321 | 9949# | | | | | | | | | |
| IST11 IST110 IST12 IST13 IST14 IST15 IST16 IST17 IST20 IST21 IST22 IST22 IST24 IST25 IST26 IST27 IST26 IST27 IST30 IST31 IST31 IST32 IST31 IST32 IST33 IST34 IST35 IST36 IST36 IST36 IST37 | 007510 003300 007644 010512 01;110 011322 011540 011664 012016 012174 003366 012326 012622 013016 013252 013440 013672 014060 | 3964# 2965# 3994 4217# 4344# 4499# 4551# 4605# 4665# 4896# 4896# 4896# 5126# 5126# | 9322 9309 4038# 9324 9325 9327 9328 93329 93310 93331 93333 93334 93337 93337 9338 | 9323 | | | | | | | | | |

SEQ 0263

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUC | -81 15: TABLE - | 17 PAGE - USER S | 266 YMBOLS | | | | | | SEQ |
|---|--|--|---|--|--|--|--|---|--|--------------------------------------|--------------------------------------|--------------------------------------|
| TST4 004616 TST40 014470 TST41 014662 TST42 015056 TST43 015262 TST44 015466 TST45 016326 TST45 016326 TST46 016532 TST47 016736 TST50 017154 TST50 017154 TST51 017360 TST52 017564 TST53 017710 6234# TST55 020160 TST55 020160 TST56 020304 TST57 020430 TST61 020562 TST61 020562 TST62 021046 TST65 022122 TST64 021416 TST65 022122 TST66 022340 TST66 022340 TST67 022444 TST70 023066 TST71 023510 TST71 023510 TST72 023620 TST73 024466 TST73 024466 TST74 025160 TST75 025402 TST75 025600 TST77 07979# TST77 07979# TST77 025740 TST77 TST77 TST77 TWAT1M= 104431 TWAT1S= 104435 TWAT1S= 104435 TWAT1S= 104435 TWAT1S= 104435 TWAT1S= 104435 | 9311 93340 933445 933445 933445 933445 933455 933555 93355 93355 9335 933 | 4370 | 4450 | 4519 | 4572 | 4633 | 4692 | 4745 | 4775 | 6774 | 6928 | 7387 |
| TWAT12= 104432 12112# TWAT14= 104433 12113# TWAT15= 104434 6473 TWAT16= 104423 3067 3596 4003 7908 8372 8962 | 6501 3117 3639 4266 7958 8402 8969 | 6542 3198 3656 7463 8074 8447 8984 | 7418 3231 3687 7621 8089 8471 11347 | 7588 3284 3704 7643 8133 8506 12105# | 7662 3293 3739 7682 8165 8629 | 7720 3324 3775 7703 8221 8641 | 8484 3339 3805 7758 8237 8698 | 11382 3374 3847 7779 8253 8710 | 12114# 3418 3871 7794 8276 8784 | 3462 3911 7850 8299 8797 | 3527 3929 7869 8313 8940 | 3569 3974 7884 8350 8949 |
| TWAT2S= 104436 7806 TWAT32= 104424 4387 5455 7073 TWAT48= 104425 4587 | 8810 4468 5785 7093 4648 | 12116# 4534 5800 7209 6041 | 4706 5873 7231 6056 | 4790 5888 7340 6126 | 4864 5960 8107 6141 | 4946 5974 8191 7434 | 5015 6640 8261 7514 | 5094 6797 8387 8033 | 5163 6838 12106# 12107# | 5242 6873 | 5314 6958 | 5383 7016 |
| TWAT64= 104426 6713 TWAT8S= 104437 3750 | 8297 3916 | 8430 3979 | 6056 8524 7488 | 6126 8575 7818 | 12108# 7854 | 7923 | 8121 | 8225 | 8357 | 8492 | 8944 | 8965 |

| | CZR6KGO CZR6KG. | RK6 FCTNL CT P11 28-AUC | TRL DIAG G-81 15:16 | MACY11 | 30(1046) CROSS R | | -81 15: TABLE - | 17 PAGE | 267 | | | | | | SEQ | 0 |
|--|---|--|---|---|--|--|--|--|--|--|--|---|---|---|---|---|
| - | TWAT96= | 104427 | 11354 7468 4841 5850 7194 | 12117# 7628 4927 5936 7323 | 7689 5001 6021 7997 | 7765 5077 6106 8077 | 8997 5149 6200 12110# | 12109# 5227 6257 | 5300 6315 | 5363 6371 | 5437 6427 | 5503 6625 | 5556 6698 | 5678 7001 | 5766 7058 | |
| Control of the Contro | TYPE = | 104405 | 9116 2809 3158 5614 9545 11301 11787 11963 | 9123 2829 3163 8762 9552 11365 11798 12045 | 12089# 2840 3176 9110 9563 11393 11817 12085# | 2859 3178 9117 9565 11409 11865 | 2864 4904 9124 9575 11454 11871 | 2867 4905 9461 9576 11565 11876 | 2874 4907 9473 9578 11634 11880 | 2878 5052 9476 9586 11696 11885 | 2886 5053 9481 9619 11708 11886 | 2895 5054 9492 10779 11762 11888 | 3056 5203 9539 10780 11763 11891 | 3060 5204 9540 10812 11766 11895 | 3087 5205 9544 10813 11777 11961 | |
| - | TYPON = | 034136 104402 104404 | 9491 2866 12088# | 9527# 2877 | 2894 | 9475 | 9480 | 9560 | 9620 | 11765 | 12086# | | | | | |
| | TYPOS = TYPTBL T.ASOF | 001722 001556 | 12087# 2727# 2645# 13333 | 3132* 3479 13343 | 9959 3512 | 9964 3535 | 3575 | 3607 | 8635* | 8636 | 8663 | 8704* | 8705 | 8730 | 9004 | |
| - | T.BA | 001544 | 2640# 7252 | 5519 | 5523 7271 | 5573 7275 | 5577 10303 | 5703 10306 | 5706 10391 | 5710 13346 | 5713 | 7114 | 7119 | 7133 | 7137 | |
| - | T.CS1 | 001540 | 2638# 5565 | 7257 3071 8954 | 3121 8974 | 3484 9861 | 3518 9977 | 3541 10216* | 3581 10217 | 3613 | 3811 10234 | 3852 10307 | 3879 10431 | 4281 10439 | 5512 10456 | |
| - | T.CS2 T.DA | 001550 001546 | 10489 2642# 2641# | 10757 3073 10383 | 13333 3142 10386 | 13343 4274 10393 | 10433 10395 | 10490 13345 | 13333 | 13343 | | | | | | |
| | T.DB T.DCYL T.DS | 001564 001560 001552 | 2648# 2646# 2643# 3391 10491 | 10380 3093 3427 13333 | 10392 3098 3490 13343 | 13345 3123 3496 | 3125 3547 | 3209 3553 | 3223 3743 | 3237 3758 | 3243 3765 | 3298 3782 | 3329 8803 | 3345 8819 | 3380 10435 | |
| | T.ECPS T.ECPT T.ER T.MR1 T.MR2 T.MR3 | 001570 001572 001554 001566 001574 001576 | 2650# 2651# 2644# 2649# 2652# 2653# 2647# | 3075 13333 7914 | 3144 8477 | 10437 | 10492 | 13333 | 13343 | | | | | | | |
| - | T.SPAR T.WC | 001562 001542 000002 | 2647# 2639# 7261 10311 | 5526 7267 12428# | 5530 7279 | 5580 7284 | 5584 10253 | 5717 10256 | 5720 10292 | 5723 10335 | 5726 10390 | 7123 13346 | 7129 | 7141 | 7146 | |
| | UFERR = UNLOAD= | 000400 000004 000107 | 2025# 3662 1989# | 10557 3712 | 10559 | 12419# | | | | | | | | | | |
| The residence of the second se | UNS = UNSERR= UPE = UPERR = | 040000 040000 020000 000100 0035536 | 2050# 8451 2030# 5697 2061# 9808 9847# | 12404# 10573 10575 3237 9811 | 12423# 9814 | 9817 | 9820 | 9823 | 9826 | 9829 | 9832 | 9835 | 9838 | 9841 | 9844 | |
| And in comments of the particles | WCERR = WCKERR= | 040000 000001 000004 004000 | 2031# 10255 7098 2047# | 10528 12427# 7236 | 10530 | 12410# | | | | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30 (1046) CROSS R | | | 17 PAGE | | | | | | | SEQ 0266 |
|--|--|--|--|---|--|---|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| WLERR = 004000 12401# WRDATA= 000123 1995# 5215 6789 | 4379 5289 6989 | 4460 5351 7050 | 4526 5426 7186 | 4579 5495 7315 | 4640 5620 7410 | 4699 5754 7430 | 4763 5838 7478 | 4828 5924 7580 | 4915 6009 7650 | 4990 6094 7876 | 5069 6617 7989 | 5138 6590 8008 |
| WRDCNT 001706 2720# WRDNUM 001704 2719# WRHEAD= 000127 1997# 8406 | 11084 11083 4226 8516 | 11112* 11113* 4351 8567 | 11160* 11159* 4427 11368 | 11284 11283 4506 | 4558 | 4612 | 4673 | 4734 | 6530 | 6760 | 6917 | 7376 |
| WRL = 004000 2064# WRTCHK= 000131 1998# | 3125 7008 | 7065 | 7085 | 7201 | 7223 | 7332 | 7710 | | | | | |
| WRTGAT= 040000 2083# \$APTHD 000224 2191 \$ASTAT= ****** U 9417 \$ATYC 033372 9388 | 2197# 9432 9390# | | | | | | | | | | | |
| \$ATY1 033346 9386# \$ATY3 033354 9387# \$ATY4 033364 9389# \$AUTOB 001134 2228# \$BASE 001352 2326# \$BDADR 001122 2223# \$BDDAT 001126 2225# | 11439 9497 2819* 2865 | 11755 2873* | 11912 2919 | 2943 | | | | | | | | |
| \$BELL 001266 2277# | 9461 | 9517 | 11708 | 11905 | | | | | | | | |
| \$CDW1 001356 2328# \$CHARC 044532 11456* \$CKSWR 045524 11741# | 11466* 12093 | 11473 | 11499* | 11504# | | | | | | | | |
| \$CMTAG 001100 2211# \$CM1 = 000020 2243# | 2761 2244# | 2762 2245# 2253# | 2770 2246# | 2776 2247# | 2777 2248# | 2778 2249# | 2250# | 2251# | 2252# | 2253# | 2254# | 2255# |
| \$CM2 = 000040 2256# 2256# | 2257# 2244# 2257# | 2258# 2245# 2258# | 2259# 2246# 2259# | 2247# | 2248# | 2249# | 2250# | 2251# | 2252# | 2253# | 2254# | 2255# |
| \$CM3 = 000020 2241# \$CM4 = 000020 2259# 2272# | 2243 2260# 2273# 11777 | | 2262# 2275# | 2263# | 2264# | 2265# | 2266# | 2267# | 2268# | 2269# | 2270# | 2271# |
| \$CNTLC 046422 11696 \$CNTLG 046434 11762 \$CNTLU 046427 11787 \$CORE 032466 9178 \$CPUOP 001324 2300# | 11907# 11880 9205# | 11905# | | | | | | | | | | |
| \$CRLF 001273 2279# 11507 \$CROUT 032516 9205 \$DBLK 044752 11531 | 9124 11798 9212# 11565 | 9481 11885 11573# | 9492 11905 | 9517 11966 | 9539 | 9544 | 9552 | 9565 | 9578 | 10779 | 10812 | 11455 |
| \$DEVCT 001306 2291# \$DEVM 001354 2327# \$DOAGN 032172 9106 \$DTBL 044742 11534 \$ENDAD 032162 2807 \$ENDCT 032026 2776 | 3043 9127 11569# 9129# 9108# | 4091* 9133# 9512 | 4141* | 8589 | 8613 | 8683 | 8755 | 8766 | 8923 | | | |
| \$ENULL 032176 9136# \$ENV 001316 2296# \$ENVM 001317 2297# \$EOP 031772 2831 \$EOPCT 032020 2776* \$ERFLG 001103 2214# \$ERMAX 001115 2220# | 2813 2799 8763 2830* 2976 2779* | 9138 2824 9098# 9105# 4082 9279 | 9395 3044 9380 9109 4121* 9302* | 9419 9397 9592 9591* 9233 9307 | 9494 11436 9623 9621* 9277 | 11434 11441 11400 11399* 9279 | 9285* | 9307 | 9456* | 9517 | 9747 | 11395• |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE - USER S | 269 YMBOLS | | | | | | SEQ 0267 |
|--|------------------------------------|---------------------------------|----------------------------------|---------------------------------|--------------------------------|--------------------------------|----------------|-----------------|-----------------|-----------------|----------------|----------------|
| \$ERROR 033614 2770 \$ERRPC 001116 22214 | 9248 9463* | 9454# 9464* | 9465 | 9471+ | 9472* | 9474 | 9478* | 9479 | 9517 | 13333 | 13336 | 13342 |
| \$ERRPC 001116 22214 13350 \$ERRTB 001360 23454 \$ERTTL 001112 22184 \$ESCAP 001264 22764 9517 | 9536 9121 2778* 9867* | 9125* 2920* 9868* | 9462* 3064* 10129* | 9517 3102* 10130* | 3185* 10229* | 3257* 10230* | 5655* 10852 | 5700* 10856* | 5730* 10857* | 9301* 11396* | 9508 | 9510 |
| \$ETABL 001316 \$ETEND 001360 2203 \$FATAL 001300 22884 \$FFLG 033612 93864 \$FILLC 001156 22394 \$FILLS 001155 22384 \$GDADR 001120 22224 | 2329# | 9417 11507 | 9426* | 9434# | | | | | | | | |
| \$GTSWR 045614 117634 \$HD = 000000 1804 | 12091 | | | | | | | | | | | |
| \$HIBTS 000224 21984 \$HIOCT 046622 119544 \$ICNT 001104 22154 \$ILLUP 047060 12015 \$INTAG 001135 22294 \$ITEMB 001114 22194 | 11965# 9292* 12031 11760* | 9293 12048# | 9295* | 9306 | | | | | | | | |
| SKINEX 032400 9179 | 9204# | 11779 | 11799 9517 | 11912 9530 | | | | | | | | |
| \$KTOUT 032450 9196 \$KT11 032316 2847 \$LF 001274 22804 \$LFLG 033611 9427 | 9201# 9177# 9517 9433# | 9181* 11507 | 9204* 11895 | 11905 | 11966 | | | | | | | |
| \$LPADR 001106 22164 \$LPERR 001110 22174 5058 | 2780* 2781* 5132* | 9274* 3919* 5209* 9283 | 9283* 3982* 5282* 9300* | 9299* 4061* 6525* 9306 | 9304 4235* 6554* 9507 | 9306 4249* 6825* 9749 | 4289* 6910* | 4375* 6941* | 4455* 7080* | 4773* 7216* | 4909* 7404* | 4984* 7499* |
| \$LSTAD 032572 2845 \$LSTBK 032574 2827 \$MADR1 001330 23134 \$MADR2 001334 23174 \$MADR3 001340 23204 | 9219* 2843 2856* | 9226# 9220* | 9227# | 7500 | 7501 | ,,,, | | | | | | |
| \$LSTAD 032572 2845 \$LSTBK 032574 2827 \$MADR1 001330 23134 \$MADR2 001334 23174 \$MADR3 001340 23204 \$MADR4 001344 23234 \$MAIL 001276 2199 \$MAMS1 001326 23074 \$MAMS2 001332 23154 \$MAMS3 001336 23184 \$MAMS4 001342 23214 \$MBADR 000226 21994 | 2203 2855* | 2286# 4898 | 2798 4979 | 2813 5047 | 9298 5128 | 9494 5198 | 11434 5278 | | | | | |
| \$MAMS4 001342 23214 \$MBADR 000226 21994 \$MFLG 033610 93874 \$MNEW 046452 11766 \$MSGAD 001312 22934 | 9393 11910# 9403* | 9428* 9406. | 9432# | | | | | | | | | |
| \$MFLG 033610 93879 \$MNEW 046452 11766 \$MSGAD 001312 22934 \$MSGLG 001314 22944 \$MSGTY 001276 22874 \$MSWR 046441 11763 \$MTYP1 001327 23084 \$MTYP2 001333 23164 \$MTYP3 001337 23194 \$MTYP4 001343 23224 \$MXCNT 033120 9296 | 9408* 9401 11908# 2854* | 9409* | 9421 | 9425* | | | | | | | | |
| \$MTYP3 001337 23194 \$MTYP4 001343 23224 \$MXCNT 033120 9296 | 9306# | | | | | | | | | | | |

| CZR6KGO RK6 FCTNL CTRL DI CZR6KG.P11 28-AUG-81 1 | AG 5:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE - USER S | 270 YMBOLS | | | | | | SEQ 0268 |
|--|--|--|---|---|--|---|--|---|--|---|--|---|--|
| | 2237# 2927# 3403 3889# 4492 4967# 5412 5994# 6395 6899# 7557 | 11461 2929 3434# 3891 4543# 4969 5482# 5996 6449# 6901 7733# 8198 | 11507 2958# 3436 3955# 4545 5035# 5484 6079# 6451 6975# 7735 8321# | 2960 3620# 3957 4595# 5037 5535# 6081 6478# 6977 7826# 8323 | 2988# 3622 4014# 4597 5116# 5537 6164# 6480 7021# 7828 8530# | 2990 3667# 4016 4656# 5118 5589# 6166 6513# 7023 7933# 8532 | 3268# 3669 4208# 4658 5186# 5591 6223# 6515 7157# 7935 8602# | 3270 3717# 4210 4715# 5188 5740# 6225 6594# 7159 7968# 8604 | 3305# 3719 4328# 4717 5266# 5742 6280# 6596 7295# 7970 8671# | 3307 3788# 4330 4812# 5268 5823# 6282 6665# 7297 8049# 8673 | 3357# 3790 4410# 4814 5337# 5825 6337# 6667 7348# 8051 8738# | 3359 3831# 4412 4886# 5339 5910# 6339 6739# 7350 8140# 8740 | 3401# 3833 4490# 4888 5410# 5912 6393# 6741 7555# 8142 8904# |
| \$0CNT 045204 1 \$0MODE 045206 1 | 8906 1606* 1601* 9250 2290# 2201# | 11635* 11605* 9275 2798* | 11648# 11610 9284 2910* | 11613* 9294 3046 | 11624* 9303# 8759 | 11650# 9102* | 9103* | 9114 | 9136 | 9140 | 9290 | 9307 | |
| \$POWER 047066 1 \$PWRDN 046720 | 2046 | 12051# 12015# | 12043 | | | | | | | | | | |
| \$PWRMG 047054 1 \$PWRUP 046772 1 \$QUES 001272 \$RDCHR 046066 1 \$RDDEC= ****** U | 2046# 2025 2278# 1830# 2097 1853# 1927# | 12031# 9517 12094 | 11507 | 11817 | 11888 | 11905 | 11963 | 11966 | | | | | |
| \$REGAD 001160 \$REGO 001162 \$REG1 001164 | 1853# 1927# 1846# 2241# 2243# 2244# 2251# | 12095 12096 | 5522* | 5529* | 5569* | 5576* | 5583* | 5705* | 5712* | 5719* | 5725* | 6810* | 6820* |
| 1 | 7118* 3351 | 7128* | 7136* | 7145* | 7256* | 7266* | 7274* | 7283* | 10147 | 10180 | 10476* | 11107* | 13347 |
| \$REG12 001206 \$PEG13 001210 | 2252# 7119* 2253# 2254# 2255# | 5516* 7129* 10152 13347 13347 13347 13347 | 5523* 7137* 11109* | 5530* 7146* 13347 | 5570* 7257* 13351 | 5577* 7267* | 5584* 7275* | 5706* 7284* | 5713* 10477* | 5720* 11108* | 5726* 13347 | 6811* 13351 | 6821* |
| SRTNAD 032174 | 2253# 2254# 2255# 2256# 2257# 2258# 2245# 2246# 2246# 2248# 2249# 2250# 1999# 9135# | 13347 13347 13347 | | | | | | | | | | | |
| \$R2A = ****** U 1 \$SAVRF 046624 1 | 2099 1983# | 12097 12032 | 12033* | 12034* | 12050# | | | | | | | | |
| \$SCOPE 032576 \$SETUP= 000137 | 2024* 2768 2740# 9243 | 9242# 2767 9455 | 2768 9504 | 2770 9512 | 2772 | 2774 11705 | 2776 11706 | 2777 11736 | 2778 11912 | 2780 | 2807 | 2810 | 9100 |

. .

| CZR6KGO CZR6KG.P | RK6 FCTNL CTRL 211 28-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE | 271 YMBOLS | | | • | | | SEQ 0 |
|--|--|--|---|--|--|--|---|--|--|--|--|--|--|--|
| \$SIZE \$SIZEX \$STUP = | 032234 032522 177777 | 2826 9203 2740# | 9161# 9213# | | | | | | | | | | | |
| \$SVLAD \$SWR = | 033050 167400 | 9258 1793# 2777 3679 4666 5606 6523 7942 9128 9278 9459 2298# | 9297# 1804 2778 3731 4725 5749 6603 7980 9134 9279 9466 | 1808 2780 3797 4822 5833 6675 8060 9136 9286 9501 | 1809 2781 3839 4897 5919 6754 8152 9287 9505 | 1810 2935 3900 4978 6004 6908 8208 9235 9288 9517 | 1811 2966 3965 5046 6089 6984 8336 9236 9300 12047 | 1812 3031 4039 5127 6176 7040 8543 9237 9303 | 1813 3276 4218 5197 6235 7176 8610 9238 9306 | 1814 3316 4345 5277 6292 7306 8680 9244 9446 | 1815 3366 4421 5346 6349 7368 8754 9261 9447 | 2275 3409 4500 5421 6405 7573 8920 9263 9448 | 2276 3453 4552 5490 6459 7744 9095 9264 9449 | 2277 3631 4606 5543 6488 7836 9101 9277 9450 |
| \$SWRMK= \$SWO8T | 033122 | 1815 9273 12119# | 2801 1816 9307# | 9238 9867 | 9239 10129 | 9267 10229 | 10856 | | | | | | | |
| STERM = STESTN STIMES | 000102 001302 001262 | 12119# 2289# 2275# 3797* 4822* 5833* 6675* 8060* 9296* | 9298* 2777* 3839* 4897* 5919* 6754* 8152* | 9528* 2935* 3900* 4978* 6004* 6908* 8208* | 9529* 2966* 3965* 5046* 6089* 6984* 8336* | 9865 3031* 4039* 5127* 6176* 7040* 8543* | 10127 3276* 4218* 5197* 6235* 7176* 8583* | 10227 3316* 4345* 5277* 6292* 7306* 8610* | 10854 3366* 4421* 5346* 6349* 736* 8680* | 11329* 3409* 4500* 5421* 6405* 7573* 8754* | 13333 3453* 4552* 5490* 6459* 7744* 8920* | 13336 3631* 4606* 5543* 6488* 7836* 9101* | 13342 3679* 4666* 5606* 6523* 7942* 9286* | 13350 3731* 4725* 5749* 6603* 7980* 9293 |
| STKB STKCNT STKINT | 001146 045210 045220 045217 | 2234# 11655# 2758 11659# | 9306 11480 11670* 3861 11731 | 11487 11706 8654 | 11507 11723* 11670# | 11654 11837 11697 | 11675 11839* 11758 | 11686 | 11717 | 11745 | 11772 | | • | |
| STKQIN STKQOU | 045217 045212 045214 045216 | 11656# 11657# 11658# | 11671* 11672* 11671 | 11842 11672 11840 11733 | 11729* 11841* 11844 | 11730* 11842 | 11731 11844* | 11733* | | | | | | |
| \$TKS | 001144 | 2233# | 11769 | 5677* 11781* | 5733* 11801* | 11478 | 11485 | 11507 | 11654 | 11676* | 11713* | 11715 | 11721* | 11743 |
| STKSRV STMPO | 045270 001222 | 11673 2259# 2906* | 11686# 2869* 2907* | 2871 2909 | 2873 10215* | 2880* 10219* | 2882 | 2885 | 2897* | 2899 | 2901 | 2903* | 2904* | 2905* |
| STMP1 STMP10 STMP11 | 001224 001242 001244 | 2260# 11024* 2267# 2268# | 11686# 2869* 2907* 8765* 11026 10415* | 8843* 11040* 10595 10676 | 8868 11056 10697 10821 | 8879 11057 10827 | 8901* 11061 | 8922* 11063* | 9027* | 9052 | 9063 | 9085* | 10641 | 11022* |
| \$TMP12 \$TMP13 \$TMP14 \$TMP15 \$TMP16 \$TMP17 | 001244 001250 001252 001254 001256 001260 001226 001230 001232 001234 001236 001240 000111 | 11759* 11673 2259# 2906* 2260# 11024* 2267# 2277# 2277# 2273# 2274# 2263# 2264# 2266# 1794# | 10416* 10417* 10419* 10769* 10770* 9998* 10000* 10642 | 10656 10423* 10788 10775* 10003* | 10816 10453 10792* | 10592 10794 | 10610 10798* | 10654 10819 | 10674 10823* | 10695 10825 | 10746 10829* | 10801 | | |
| \$TMP2 \$TMP3 \$TMP4 \$TMP5 \$TMP6 \$TMP7 | 001226 001230 001232 001234 | 2262# 2263# 2264# | 10642 10154* 3062* 10879* 10876* 3183* | 10168* 3091 10889* | 10183 3095* 10896 | | | | | | | | | |
| \$TMP7 \$TM = | 001240 000111 | 2266# 1794# 3366# | 3183* 1804 3401 | 10168* 3091 10889* 10897 3253* 2927 3409# | 3258 2935# 3434 | 10877* 2958 3453# | 10898 2966# 3620 | 2988 3631# | 3031# 3667 | 3268 3679# | 3276# 3717 | 3305 3731# | 3316# 3788 | 3357 3797# |

| CZR6KGO RK6 FCTNL CTRL DIAG CZR6KG.P11 28-AUG-81 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG EFERENCE | -81 15: TABLE - | M 5 17 PAGE - USER S | 272 YMBOLS | | | | | | SEQ 0270 |
|---|---|---|---|--|--|--|---|--|---|--|---|--|
| \$TPB 001152 2236# \$TPFLG 001157 2240# \$TRAP 047076 2772 | 3839# 4490 4897# 5410 5919# 6393 6754# 7555 8152# 8904 11496* 11428 11494 12062# | 3889 4500# 4967 5421# 5994 6405# 6899 7573# 8196 8920# 11507 11507 | 3900# 4543 4978# 5482 6004# 6449 6908# 7733 8208# 9268 | 3955 4552# 5035 5490# 6079 6459# 6975 7744# 8321 9308 | 3965# 4595 5046# 5535 6089# 6478 6984# 7826 8336# 11329 | 4014 4606# 5116 5543# 6164 6488# 7021 7836# 8530 | 4039# 4656 5127# 5589 6176# 6513 7040# 7933 8543# | 4208 4666# 5186 5606# 6223 6523# 7157 7942# 8602 | 4218# 4715 5197# 5740 6235# 6594 7176# 7968 8610# | 4328 4725# 5266 5749# 6280 6603# 7295 7980# 8671 | 4345# 4812 5277# 5823 6292# 6665 7306# 8049 8680# | 4410 4822# 5337 5833# 6337 6675# 7348 8060# 8738 |
| \$TRAP2 047120 12073# \$TRP = 000041 12077# 12098# 12111# \$TRPAD 047132 12067 | 12084 12086# 12099# 12112# 12084# | 12087# 12100# 12113# 12119 | 12088# 12101# 12114# | 12089# 12102# 12115# | 12090# 12103# 12116# | 12091 12104# 12117# | 12092# 12105# 12118# | 12093 12106# 12119# | 12094# 12107# | 12095# 12108# | 12096# 12109# | 12097# 12110# |
| \$TSTM 000230 2200# \$TSTNM 001102 2213# | 8595* | 9100* | 9142* | 9233 | 9270* | 9297* | 9298 | 9303 | 9307 | 9458 | 9517 | 9528 |
| \$TTYIN 046412 11855 | 11334 11856 | 11868 | 11886 | 11900 | 11904# | | | | | | | |
| \$TYPBN= ****** U 12090 \$TYPDS 044536 11519# \$TYPE 044202 9414 \$TYPEC 044414 11458 \$TYPEX 044534 11500 \$TYPOC 045006 11604# \$TYPON 045022 11603 \$TYPOS 044762 11599# \$UNIT 001310 2292# \$UNITM 000234 2202# | 12089 11428# 11465 11502 12086 11606# 12087 | 12077 11472 11505# 12088 | 12085 11477# | 11803 | | | | | | | | |
| \$USWR 001322 2299# \$VECT1 001346 2324# | 2875 | 2884* | 2885* | 2888 | 2908* | 2909* | 2914 | 2918 | | | | |
| \$USWR 001322 2299# \$VECT1 001346 2324# \$VECT2 001350 2325# \$XOFF = 000023 11482 \$XON = 000021 11489 \$XTSTR 032622 9252# \$\$GET4= 000000 9128# \$\$SW08= 000111 9307# | 11507 11507 | 11689 | | | | | | | | | | |
| 9333# 9346# 9359# 9372# \$0FILL 045205 11600* | 9308 9321# 9334# 9347# 9360# 9373# 11604* 9244 2168 | 9309# 9322# 9335# 9348# 9361# 9374# 11614 | 9310# 9323# 9336# 9349# 9362# 9375# 11649# | 9311# 9324# 9337# 9350# 9363# 9376# | 9312# 9325# 9338# 9351# 9364# 9377# | 9313# 9326# 9339# 9352# 9365# 9378# | 9314# 9327# 9340# 9353# 9366# 9379# | 9315# 9328# 9341# 9354# 9367# 9380# | 9316# 9329# 9342# 9355# 9368# | 9317# 9330# 9343# 9356# 9369# | 9318# 9331# 9344# 9357# 9370# | 9319# 9332# 9345# 9358# 9371# |
| \$40CAT 000000 2167# = 074414 2152# 2780 11659 13454# .\$ASTA= ****** U 9387 .\$X = 000224 2187# | 9244 2168 2781 11660# 13455# 9390 2192 | 9468 2172# 9113# 11904# | 2178# 9136 11905 | 2180# 9137# 11912# | 2187 9306 11966 | 2188# 9307 12027 | 2190# 9435# 12049 | 2192# 9517 12119 | 2210# 11507 13332# | 2281 11573# 13445# | 2691# 11654 13446# | 2765 11658# 13447# |

| CZR6KGO CZR6KG. | RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | | 28-AUG | | 17 PAGE | 274 NAMES | | | | | | SEQ |
|--------------------------------------|--|--|---|---|--|---|--|--|--|--|--|--|---|---|--|
| COMMEN ENDCOM ERROR | 1# 1820# 1826 33483 35705 3880 435705 3880 435705 3880 435705 46965 5173 5406 6145 5173 6629 6726 6726 77268 | 1926# 1926# 1926# 2932 3338853 33885 3388 3388 33885 33885 33885 33885 33885 33885 33885 33885 33885 3388 36 | 2981 3983 3373 3897 3897 3897 3897 3897 3897 | 30340 | 30475 30475 30475 305777 305777 305777 305 | 30278 30278 30278 30278 302777 302777 302777 302777 302777 302777 302777 302777 3027 | 302855 302855 302855 302855 30285 30285 30295 30 | 3111 3233333333333333333333333333333333 | 3118 3118 3118 3118 3118 3118 3118 3118 | 3151 3157 3157 3157 3157 3157 3157 3157 | 3190 3190 3190 3190 3190 3190 3190 3190 | 3199 3199 3199 3199 3199 3199 3199 3199 | 3207 3325 33455 336806 4304 4655 53158 5408 4304 4655 53158 561275 564483 72322 74275 76915 76915 774275 77 | 3212 3327 3463 3570 36815 36815 4503 45003 45003 45003 45003 45003 45003 4606 5603 5603 5603 5603 5603 5603 5603 5 | 3221 3334 3469 3573 3627 3627 3627 3627 3627 3627 3627 36 |
| ESCAPE GETPRI GETSWR INITSS | 1# 1# 1# 2736# 5750 6678 7745 | 8985 1926# 1926# 1926# 4237 5834 6756 7814 | 8998 9173 2810# 4262 5920 6826 7838 8545 4847 5879 | 9001 4291 6005 6912 7872 | 9008 4824 6090 6943 7893 8614 4989 | 4910 6177 | | | 5134 6350 7179 8062 11331 5288 6047 | 5211 6406 7219 8115 11360 5425 | 5284 6460 7307 8153 | 5422 6489 7406 8171 | 5491 6527 7474 8209 | 5544 6556 7502 8338 | 5607 6605 7574 8456 |
| LOADLS | 8480 2738# 5837 6362 7084 7785 8174 8566 | 8487 4827 5860 6418 7185 7797 8212 11338 | 8545 4847 5879 6616 7200 7841 8228 11367 | 4291 6005 6912 7872 8559 4938 5923 6631 7222 7860 8243 | 8614 4989 5951 6689 7314 7875 8267 | 6985 7917 8684 5086 5965 6704 7331 7897 8303 | 4986 6236 7043 7943 8774 5137 6008 6759 7409 7946 8341 | 5060 6293 7082 7981 8930 5233 6032 6788 7454 7988 8363 | 11331 5288 6047 6829 7477 8007 8378 | 11360 5425 6093 6864 7579 8024 8393 | 5443 6117 6946 7634 8065 8405 | 5618 6132 6988 7649 8080 8436 | 5753 6191 7007 7694 8092 8459 | 5776 6248 7049 7709 8124 8497 | 5791 6306 7064 7770 8156 8515 |

| CZR6KGC CZR6KG. |) RK6 FCT | NL CTRL 8-AUG-81 | DIAG 15:16 | MACY11 | 30(1046) CROSS R | 28-AUG | -81 15: TABLE - | 17 PAGE | 275 NAMES | | | | | | SEQ | 0 |
|---------------------------------|---|---|---|---|---|---|---|---|---|--|---|--|---|--|---|---|
| MSG | 2927# 3436 4014# 4658 5266# 5825 6393# 6901 7825# 8532 | 2929 3620# 4016 4715# 5268 5910# 6395 6975# 7828 8602# | 2958# 3622 4208# 4717 5337# 5912 6449# 6977 7933# 8604 | 2960 3667# 4210 4812# 5339 5994# 6451 7021# 7935 8671# | 2987# 3669 4328# 4814 5410# 5996 6478# 7023 7967# 8673 | 2990 3717# 4330 4886# 5412 6079# 6480 7157# 7970 8738# | 3268# 3719 4410# 4888 5482# 6081 6513# 7159 8048# 8740 | 3270 3788# 4412 4967# 5484 6164# 6515 7295# 8051 8904# | 3305# 3790 4490# 4969 5535# 6166 6594# 7297 8140# 8906 | 3307 3831# 4492 5035# 5537 6223# 6596 7348# 8142 | 3357# 3833 4543# 5037 5589# 6225 6665# 7350 8196# | 3359 3889# 4545 5116# 5591 6280# 6667 7555# 8198 | 3401# 3891 4595# 5118 5740# 6282 6739# 7557 8321# | 3403 3955# 4597 5186# 5742 6337# 6741 7733# 8323 | 3434# 3957 4656# 5188 5823# 6339 6899# 7735 8530# | |
| MULT | 1# 1# 3889 5116 6280 7555 | 1926# 1926# 3955 5186 6337 7733 | 2927 4014 5266 6393 7826 | 2958 4208 5337 6449 7933 | 2988 4328 5410 6478 7968 | 3268 4410 5482 6513 8049 | 3305 4490 5535 6594 8140 | 3357 4543 5589 6665 8196 | 3401 4595 5740 6739 8321 | 3434 4656 5823 6899 8530 | 3620 4715 5910 6975 8602 | 3667 4812 5994 7021 8671 | 3717 4886 6079 7157 8738 | 3788 4967 6164 7295 | 3831 5035 6223 7348 | |
| ОРСНК | 2740# 5440 6144 6961 7606 8043 8527 | 4844 5457 6203 7004 7625 8135 8578 | 4867 5769 6260 7019 7631 8168 8648 | 4930 5788 6318 7061 7646 8194 8717 | 4948 5803 6374 7076 7670 8240 8786 | 5004 5853 6430 7197 7686 8256 8800 | 5017 5876 6476 7212 7691 8264 8951 | 5080 5891 6545 7326 7706 8279 8971 | 5097 5939 6628 7343 7728 8353 9000 | 8530 5152 5963 6643 7390 7761 8360 11350 | 8602 5166 6024 6701 7421 7767 8375 11357 | 5230 6044 6716 7446 7782 8390 11385 | 5245 6059 6777 7466 7857 8433 | 8904 5303 6110 6841 7491 7911 8474 | 5317 6129 6931 7517 8000 8509 | |
| POP | 12037 | 1926# 1926# | 9429 9390 | 9430 9392 | 9899 9413 | 10033 9888 | 10231 | 11099 | 11118 | 11122 | 11286 11519 | 11560 11929 | 11955 | 12004 | 12036 12023 | |
| REPORT | 2737# | 1926# | 4956 | 5025 | 5106 | 5175 | 5255 | 5326 | 5471 | 5812 | 5900 | 5983 | 6068 | 6153 | 6212 | |
| RKLOAD | 6269 2739# 5436 6055 6773 7339 7883 8386 8983 | 6327 4840 5454 6105 6796 7386 7907 8401 11346 | 6383 4863 5502 6125 6837 7417 7996 8446 11381 | 6439 4926 5555 6140 6872 7462 8032 8469 | 6577 4945 5765 6199 6927 7513 8073 8505 | 6652 5000 5784 6256 6957 7620 8088 8523 | 6725 5014 5799 6314 7000 7642 8132 8574 | 6850 5076 5849 6370 7015 7681 8164 8628 | 6888 5093 5872 6426 7057 7702 8220 8697 | 7528 5148 5887 6472 7072 7757 8236 8783 | 5162 5935 6500 7092 7778 8252 8796 | 5226 5959 6624 7193 7793 8275 8939 | 5241 5973 6639 7208 7805 8312 8948 | 5299 6020 6697 7230 7849 8349 8961 | 5313 6040 6712 7322 7868 8371 8968 | |
| SCOPE | 1821# 3964 5196 6348 7743 | 2934 4038 5276 6404 7835 | 2965 4217 5345 6458 7941 | 3030 4344 5420 6487 7979 | 3275 4420 5489 6522 8059 | 3315 4499 5542 6602 8151 | 3365 4551 5605 6674 8207 | 3408 4605 5748 6753 8335 | 3452 4665 5832 6907 8542 | 3630 4724 5918 6983 8582 | 3678 4821 6003 7039 8609 | 3730 4896 6088 7175 8679 | 3796 4977 6175 7305 8753 | 3838 5045 6234 7367 8919 | 3899 5126 6291 7572 9099 | |
| SETTRA | 1# 12077# 12102 12117 | 1926# 12086 12103 12118 | 11833 12087 12104 | 12088 12105 | 12089 12106 | 12091 12107 | 12093 12108 | 12094 12109 | 12095 12110 | 12096 12111 | 12097 12112 | 12098 12113 | 12099 12114 | 12100 12115 | 12101 12116 | |
| SETUP SKIP SLASH SPACE | 1# 1# 1# 1926# | 1926# 1926# 1926# | 2760 | | | | | | | | | | | | | |
| STARS | 3274 3788 4419 4967 5488 | 1926# 3305 3795 4490 4976 5535 | 2184 3314 3831 4498 5035 5541 | 2186 3357 3837 4543 5044 5589 | 2193 3364 3889 4550 5116 5604 | 2206 3401 3898 4595 5125 5740 | 2281 3407 3955 4604 5186 5747 | 2284 3434 3963 4656 5195 5823 | 2927 3451 4014 4664 5266 5831 | 2933 3620 4037 4715 5275 5910 | 2958 3629 4208 4723 5337 5917 | 2964 3667 4216 4812 5344 5994 | 2988 3677 4328 4820 5410 6002 | 3029 3717 4343 4886 5419 6079 | 3268 3729 4410 4895 5482 6087 | |

| CZR6KGO CZR6KG. | RK6 FCT P11 2 | NL CTRL | DIAG 15:16 | MACY11 | 30(1046 CROSS |) 28-AU | G-81 15 E TABLE | :17 PAG | 6 E 276 NAMES | | | | | | SEQ | 0273 |
|--|---|--|--|--|--|--|--|--|--|--|--|--|--|--|--|------|
| SWRSU TRMTRP | 6164 6521 7295 8058 8904 11413 1# 12077# | 6174 6594 7304 8140 8918 11509 1926# 12119 | 6223 6601 7348 8150 9091 11576 2782# | 6233 6665 7366 8196 9147 11653 | 6280 6673 7555 8206 9230 11736 | 6290 6739 7571 8321 9385 11751 | 6337 6752 7733 8334 9442 11822 | 6347 6899 7742 8530 9517 11846 | 6393 6906 7826 8541 9526 11915 | 6403 6975 7834 8602 9633 11968 | 6449 6982 7933 8608 9739 12013 | 6457 7021 7940 8671 10861 12029 | 6478 7038 7968 8678 10874 12056 | 6486 7157 7978 8738 10902 | 6513 7174 8049 8752 11290 | |
| TYPBIN TYPDEC TYPNAM TYPNUM | 1# 1# 1# | 1926# 1926# 1793# 1926# | 9114 1926# | 9121 2803 | | | | | | | | | | | | |
| TYPOCS TYPOCT TYPTXT \$\$CMRE | 1# | 1926# 1926# 1926# 2243 | 2865 9110 2244 | 9474 9117 2245 | 9479 2246 | 11764 2247 | 2248 | 2249 | 2250 | 2251 | 2252 | 2253 | 2254 | 2255 | 2256 | |
| \$\$CMTM | 2204# 2257 2204# 2273 | 2258 2259 2274 | 2260 | 2261 | 2262 | 2263 | 2264 | 2265 | 2266 | 2267 | 2268 | 2269 | 2270 | 2271 | 2272 | |
| \$\$ESCA \$\$NEWT | 1# 1# 3889 5116 6280 7555 12077# 12102 | 1926# 1926# 3955 5186 6337 7733 12086 12103 | 2927 4014 5266 6393 7826 12087 12104 | 2958 4208 5337 6449 7933 12088 12105 | 2988 4328 5410 6478 7968 12089 12106 | 3268 4410 5482 6513 8049 12091 12107 | 3305 4490 5535 6594 8140 12093 12108 | 3357 4543 5589 6665 8196 12094 12109 | 3401 4595 5740 6739 8321 12095 12110 | 3434 4656 5823 6899 8530 12096 12111 | 3620 4715 5910 6975 8602 12097 12112 | 3667 4812 5994 7021 8671 12098 12113 | 3717 4886 6079 7157 8738 12099 12114 | 3788 4967 6164 7295 8904 12100 12115 | 3831 5035 6223 7348 12101 12116 | |
| \$\$SETM \$\$SKIP .EQUAT .HEADE .KI11 .SETUP .SWRHI .SWRLO .\$ACT1 | 12117 2798# 1# 1# 1# 1# 1793# 1# 1# | 12118 1926# 1793# 1793# 1793# 1793# 1816# 1793# | 1816 1795 1926 2740 1804 | | | | | | | | | | | | | |
| .\$APTH .\$APTY | 1# | 2282# 1793# 1793# | 2182 9383 | | | | | | | | | | | | | |
| SACTI SAPTB SAPTH SAPTY SASTA SCATC SCMTA SDB2D SDB20 | 1# 1# 1# 1# | 1793# | 2204 | | | | | | | | | | | | | |
| .\$DIV .\$EOP .\$ERRO .\$ERRT | 1# 1# 1# | 1793# 1793# 1793# | 9089 9440 | | | | | | | | | | | | | |
| .\$MULT .\$POWE .\$RAND | 1# | 1793# | 12011 | | | | | | | | | | | | | |
| .\$RDDE .\$RDOC .\$READ .\$R2AZ | 1# | 1793# 1793# | 11913 11651 | | | | | | | | | | | | | |

```
MACY11 30(1046) 28-AUG-81 15:17 PAGE 277
CROSS REFERENCE TABLE -- MACRO NAMES
CZR6KGO RK6 FCTNL CTRL DIAG
CZR6KG.P11 28-AUG-81 15:16
 .$SAVE
                              1793# 11966
.$SB2D
.$SB2O
.$SCOP
.$SIZE
.$SUPR
.$TRAP
.$TYPB
                      1#
                      1#
                              1793#
1793#
                                             9228
9145
                      1#
                      1#
                      1#
                              1793# 12054
                      1#
                              1793# 11507
1793# 11411
1793# 11574
1793# 2150
.STYPD
                      1#
                      1#
                     1#
.$TYPO
.$40CA
.1170
```

. ABS. 074414 000

ERRORS DETECTED: 0

CZR6KG,CZR6KG.LST/SOL/CRF/NL:TOC=CZR6KG.SML,CZR6KG.P11 RUN-TIME: 35 44 3 SECONDS RUN-TIME RATIO: 130/82=1.5 CORE USED: 38K (76 PAGES)