

The Basics of Serial Data Compliance and Validation Measurements





Table of Contents

Introduction: A Definition of Serial Compliance and Validation	3
A Transition In Progress: From Parallel To Serial Data Architectures	3
Building A Framework of Standards	3
Understanding Serial Architectures — The Common Threads	4
High Signaling Frequencies and Data Rates	4
Differential Signaling	4
A "Stack" Architecture	5
Packetized Data	6
Characteristics of the Physical Layer	6
Physical Layer Compliance Testing: An Analog View Of A Digital World	7
Differing Standards, Common Compliance Measurements	8
Amplitude Measurements	8
Timing Measurements	8
Jitter Measurements	9
Mask Testing of Eye Diagrams	9
Measurements on Optical Signals	11
Overview of Serial Measurement Solutions	12
Real-time Oscilloscopes	13
Sampling Oscilloscopes	13
Logic Analyzers	13
Signal Sources	13
Analog Compliance Measurement Considerations: Probing	14
Connecting to the Serial Device Under Test	14
Compliance Measurement Considerations: Acquisition	16
Acquisition System Performance Drives Measurement Accuracy	16
Evaluating the Acquisition System's Analog Performance	17
Evaluating Digital Performance	17
Compliance Measurement Considerations: Analysis	18
Getting a Handle on all that Data	19
Thinking Beyond Compliance Testing	19
A Digital Tool for Digital Tasks	19
Probing Means Making the Right Connections	20
Acquiring the Signal: from Packet to Parallel	20
Triggering is the Key to Efficiency in Troubleshooting	22
New Synchronization Modes Stay in Step with Serial Requirements	22
Analyzing the Results	23
Summary	24

Introduction: A Definition of Serial Compliance and Validation

In the computing and communications industries, a degree of standardization at the system, subsystem, and component levels is the foundation that technology builds upon. Examples of standardization range from LVDS signaling to the PCI Express serial bus designed to replace current PCI technology. Standards pervade semiconductor architectures, network protocols, and software components. And for every standard, there must be some means of certification, some way to prove that new products are in *compliance* with the standard.

Serial data architectures, and the standards that support them, are the next frontier in digital design. Industry committees announce new serial standards or refinements at almost every major industry event. Inevitably, the emerging standards call for certification procedures involving electronic test and measurement equipment: oscilloscopes, logic analyzers, signal sources, and more. There is an urgent need for expert, efficient solutions that can speed the process—still unfamiliar to many designers—of serial compliance and validation measurement.

This primer deals with the challenges of serial device compliance testing, validation, and troubleshooting. The discussion in the ensuing pages covers basic principles, measurement requirements, and tools for troubleshooting, all in the context of the latest serial transmission technologies. The primer is designed to help you understand the common aspects of serial data transmission; to explain the analog and digital measurement requirements that apply to these emerging serial techniques, and to provide an overview of the test and measurement solutions that support both compliance tests and troubleshooting work.

A Transition In Progress: From Parallel To Serial Data Architectures

Parallel data transmission architectures dominate digital systems, but there is change in the wind. Parallel constructs are nearing their practical bandwidth limits, and there is a tremendous need for an order-of-magnitude increase in data throughput.

In recent years there has been a major industry push toward serial data transmission technologies to address this need. But the change will not occur overnight. Currently we are in the midst of a transition, and both architectures are alive and well. There is at least one more generation of parallel technology to come, a fact implied by some of the latest specifications. The PCI-SIG, for example, has defined both PCI-X 2.0 (parallel) and PCI Express (serial) formats. But serial data architecture is virtually certain to prevail as data rates continue to escalate. It provides some key benefits over parallel data transfer:

- Higher bandwidth per pin
- Scalable performance through the use of aggregated lanes
- Lower overhead and latency (maximizes payload efficiency)

It all adds up to a wide range of measurement needs. Design and validation engineers, accustomed to working on parallel buses, will need to perform system-level testing and debug on serial technologies as well.

Building A Framework of Standards

The key to the success of any emerging standard is a systematic plan to address specifications, testing, and compliance requirements. Typically such plans are developed by industry working groups. Companies with an interest in supporting a new proposal work cooperatively to develop and stabilize standards and define qualification criteria. Interoperability does not occur in a vacuum, and the only way for a company to keep pace with emerging standards is to participate in the committees and working groups that develop them. Standards typically include measurement requirements and in many cases, specific test equipment recommendations as well. Tests are usually performed at “plug fests” where prospective vendors gather to evaluate their products for interoperability and compliance with the standard.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

InfiniBand and PCI Express are two 2.5 Gb/s standards. InfiniBand has found its niche in high-performance computing, while PCI Express is growing fast in its inclusion in product roadmaps. Other examples of serial data specifications with data rates ranging from 1 Gb/s to 3.2 Gb/s include:

- Serial ATA
- IEEE 1394B (Firewire)
- FibreChannel
- 1 GbE Serial (1000Base-CX)
- 10 GbE XAUI
- 10 GFC XAUI
- RapidIO
- And others still emerging

Understanding Serial Architectures—The Common Threads

As summarized earlier, there are numerous serial technologies evolving now, and more to come. While each of these protocols has its own unique qualities, most of them share some fundamental characteristics, particularly in the areas of bandwidth, signaling, protocol architecture and data formatting.

High Signaling Frequencies and Data Rates

Serial data signaling is achieved by embedding the clock and data in the same transmission media. The SerDes (Serial Deserializer) found in all links is responsible for Serializing the data when transmitted, and deserializing it when received. By embedding the clock in the data bit stream, less pins are used to achieve the same data transfer rate and many traditional testing concerns, such as setup and hold time and clock-data jitter are avoided. However, the clock and data still need to be recovered by a receiver in a serial data serdes. Thus excessive jitter can cause the receiver not to recover the clock correctly and cause bit errors.

Data rates are bumping up against the “ceiling” of what conventional wisdom says is possible in a copper transmission line with 2.5 Gb/s to 3.2 Gb/s being the “sweet spot” of standards that are in development today. However, as more is learned about signal integrity at these rates, standards groups are in early stages of pushing these rates up to 4-6 Gb/s. Because non return to zero (NRZ) signaling is used, the fundamental signaling frequency is one half the data rate. For instance, the minimum data period (logic “1” or “0” in a 2.5 Gb/s) has a data period of 400 ps (1.25 GHz fundamental frequency). At these frequencies, risetimes between 50-100 ps are not uncommon. In some standards, more bandwidth is achieved by using multiple lanes of serial data transmission. The following table demonstrates how multiple lane architectures are used to facilitate higher data throughput.

Serial Bus Standard	Bit Rate	Maximum Raw Data Rate
PCI Express	2.5 Gb/s	Up to 80 Gb/s (32X)
Infiniband	2.5 Gb/s	Up to 30 Gb/s (12X)
10 GbE XAUI	3.125 Gb/s	12.5 Gb/s (4X)
FibreChannel 2X	2.125 Gb/s	2.125 Gb/s (1X)
Serial ATA II	3.0 Gb/s	3.0 Gb/s (1X)

8B/10B encoding is another common denominator of these specifications. Data is transferred over a single differential pair. The clock is embedded in the data bit stream. As 10 bits of data arrives at the pins of the receiver, it is de-serialized by the receiver device. The result of this function is an 8bit data word that can be used as data. Signal rate, number of lanes deployed, and encoding provide the maximum data transfer rate for a serial standard.

Differential Signaling

Differential signaling is not new. But it is turning out to be the best solution for transmitting the sensitive high-speed signals used in today’s serial protocols. Fast serial buses often rely on very low-voltage signals simply because it takes less time to change states over the span of a few hundred millivolts, for example, than it takes to make a full 1-volt transition. This has led to the widespread adoption of environments such as LVDS and has created a need for a transmission medium that protects signals from noise and losses. The differential transmission approach is the answer to this challenge.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 1. Single-ended and differential signals; the differential environment uses two complementary paths.

Differential transmission delivers the signal along two “balanced” paths. Figure 1 contrasts differential transmission with the single-ended technique. In the differential system, the two sides of the path are exact complements of one another; that is, a signal level of +1 volt on one side is mirrored by its -1 volt complement on the other. The two signals are “swinging” in opposite directions at all times. If an unwanted external noise component couples into the line, it does not share this complementary characteristic; instead, it tends to induce the same signal into both lines. This is known as a common-mode signal, and it is automatically rejected at the receiving end of the circuit, theoretically leaving only the valid signal. The extent of this rejection, or attenuation, of the unwanted signal is known as the common mode rejection ratio.

Differential signaling has long been the mode of choice for long, “box-to-box” interconnects, but with the advent of high-speed serial architectures, differential techniques are the best way to ensure reliable data transmission over any distance—even at the chip-to-chip level.




Figure 2. Layers of a serial data link.

A “Stack” Architecture

Within most serial standards the architecture is viewed as a “stack of layers,” as shown in Figure 2. Layers communicate with each other while at the same time buffering each other’s operations from adjacent levels.

The stack includes the physical layer in which electronic signals pass through transmission media; a logical layer in which these signals are interpreted as meaningful data; a transaction layer, and more. Each layer has its own applicable standards and compliance procedures.

Figure 2 shows the physical layer (PHY) partitioning of a serial data link. The PHY provides isolation from the higher layers of the protocol stack, and encompasses two layers: logical and electrical. The Electrical section of the PHY handles the high speed serial packet exchange and power management mechanisms. The Logical layer of the PHY handles reset, initialization, encoding, and decoding. Both the electrical and logical sub-blocks also may incorporate standard-specific features.

Each of the two blocks composing the PHY has unique test requirements. Analog waveform characteristics such as jitter are a priority when making electrical interface measurements. In the logical layer, digital packets must be interpreted, embedded clocks extracted, and so forth.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 3. Serial PHY link implementation.

Figure 3 shows a typical physical layer link interface of a serial bus implementation. This layout is typical of a 4X PCI Express link and others. Each lane of the link consists of two differential channels, one transmit and one receive.

Packetized Data

Serial bus data is packetized, and the packets contain contributions from several layers. Figure 4 shows an example of this concept.

- The logical sub-block of the PHY adds framing to signal the beginning and end of each packet. The sub-block is responsible for symbol transmission and alignment
- The data link layer provides error checking and re-try services. Packets include ACK (Acknowledge), power management information, and more.
- The transaction layer handles initialization, instruction generation and processing, and flow control.

Characteristics of the Physical Layer

The physical layer is the carrier of the packetized differential signals just described. From the functional perspective, the physical layer mechanics—circuit board traces, connectors, and cables—are simply a path for data expressed in the form of binary signals. These binary signals are the subject of your physical layer measurements for debug, validation, and compliance tests with an oscilloscope.

In a copper physical layer (PHY) specification, several different bus configurations can be defined. Figures 5, 6, and 7 depict three typical mechanical environments for a serial physical media dependent (PMD) interface. Every individual lane of the PHY consists of transmit and receive differential pairs. The transmit pair and its transmission medium are often called a channel. Within a channel, signals may traverse three basic types of copper paths:




Figure 4. The layers of a serial data packet.




Figure 5. Chip-to-chip lane.




Figure 6. Connector part of the lane.

Chip-to-chip

► **Figure 5.** A chip-to-chip lane normally resides on an etched circuit board (ECB), which serves as the transmission medium. A typical application would be a PCI Express bus on a motherboard, where large amounts of data need to be transmitted from one device to another.

Card to card

► **Figure 6.** When a connector is part of the lane, as in an edge card application, the specification may require AC coupling capacitors on the transmit or receive side of the link. This eliminates potential common-mode bias mismatches between transmit and receive devices. Low-cost links may employ long runs on FR4 board and inexpensive connectors, both of which can add jitter, crosstalk, and potential imbalances due to layout.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 7. Cable connection part of the lane.

Card to Cable

► **Figure 7.** Introducing a cable connection into the lane adds yet another source of loss and jitter. Cable-connected serial links are prevalent in server applications such as InfiniBand; in storage applications such as Serial ATA and FibreChannel; and in peripheral applications such as 1394B.

A cabled system as in Figure 7 includes contributions from the maximum potential number of vendors. Compliance and interoperability testing are key to the success of any product in which many independently-developed elements must function together flawlessly. This is especially true in the early stages of a standard's lifecycle, when details are still in flux and interpretations may vary.

All standards address the important issue of transmit and receive loss budgets. They also define compliance test points at which system-level testing must be performed. Essentially, compliance points are those at which system components (usually from different vendors) need to interoperate. Figure 8 summarizes some typical interoperability points in a complete system made up of interconnected elements. These are shown as test points because they are specifically called out in the standard as the probing attachment points for test instrumentation.




Figure 8. Common interoperability test points in a serial system.




Figure 9. The compliance procedure.

Physical Layer Compliance Testing: An Analog View Of A Digital World

All of today's serial architectures operate in the digital realm. But much of the compliance testing task consists of analog measurements. Why? Isn't this all about digital data?

The answer is a qualified "yes." There are important exceptions. Digital signals exist in a world of distributed capacitance, noise, power supply variations, crosstalk, and other imperfections. Each of these phenomena detracts from "ideal" digital signals, sometimes to the point of compromising their ability to carry data. As a result, serial bus specifications set limits on signal distortions and degradation. The device under test must meet these limits in order to be considered "in compliance." Test conditions and test points are explained in detail in the standard, sometimes to the extent of recommending specific test equipment including the particular make and model. Figure 9 summarizes a typical compliance test process, in this case applicable to the InfiniBand and PCI Express standards but very similar to the other leading standards.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

Differing Standards, Common Compliance Measurements

Serial standards normally include amplitude, timing, jitter, and eye diagram measurements within their compliance testing specifications. Automated measurement/analysis tools are commonly used to speed the selection and application of these tests. Naturally, standards differ from one to the next, and not all measurements are required for compliance with every standard.

The following list encapsulates some of the key measurements commonly required at plug-fests (to prove compliance and interoperability) and ultimately, in certified compliance verification procedures.

Amplitude Measurements

Does the signal achieve the voltage levels and stability to reliably pass through the transmission medium and communicate a proper “one” or “zero” to the receiving circuit? These tests ensure that the signal has enough amplitude tolerance to do its job under worst case conditions.

- **Differential Voltage** – every specification will have a peak-to-peak differential voltage specification. This is the fundamental specification to guarantee that transceiver is transmitting the correct voltage levels. The minimum transmitter differential voltage is specified such that a stated minimum differential voltage will arrive at the receiver under worst-case media conditions (maximum loss). This ensures proper data transfer.
- **De-Emphasis** – de-emphasis is the ratio of the amplitude of the second and subsequent bits after a “transition bit” to the amplitude of the “transition bit.” Other terms for de-emphasis are pre-emphasis and equalization. De-emphasis is used in serial data transmission systems to compensate for the frequency characteristics of “lossy” media such as the low-cost FR4 boards and connectors used in desktop computers. By making the transition bit higher in amplitude than the subsequent bits, the signal will arrive at the receiver pins with an “open eye.”
- **Common Mode Voltage Measurements (AC, DC)** – common mode imbalance and noise on the transmitter can create undesirable effects in the differential signal. It is often useful to break apart the differential signal into its single-ended components to troubleshoot such issues. This technique also pinpoints crosstalk and noise effects that may be coupling into one side of the differential pair and not the other.

- **Waveform Eye Height** – eye height is the data eye opening in the amplitude domain. It provides a very valuable measurement, because it represents the actual sample point of the receiver circuit. It is measured at the .5 Unit Interval (UI) point, where the UI timing reference is defined by the recovered clock. For more details about eye diagrams see the Eye Diagram later in this document.

Timing Measurements

Is the signal free from timing variations, and are its transitions fast enough to preserve the critical data values the signal is meant to deliver? These tests, which require uncompromised performance on the part of the measurement toolset, detect aberrations and signal degradation that arise from distributed capacitance, crosstalk, and more.

- **Unit Interval and Bit Rate** – variations in the embedded clock frequency can be measured by looking at the mean measurement of the embedded clock over a large number of consecutive cycles. In some standards, if the mean measurement is more than 100 parts per million (PPM) away from the specified value, then the DUT fails.
- **Rise/Fall Time** – some standards have not included rise time as part of the compliance test series simply because of the risetime measurement errors introduced by the probe/instrument combination. However, by applying the “square root of the sum of the squares” formula to the measured value, it is possible to determine whether the driver is approaching a rise/fall time failure. Risetimes that are too fast can cause EMI issues, while those that are too slow rise can cause data errors.
- **Waveform Eye Width** – waveform masks can be confusing when used to validate transmitter compliance. Section 6 of the Serial ATA specification says that the statistical certainty achieved by capturing a waveform and comparing it to a mask cannot guarantee compliance to the required 10^{-12} BER ($\pm 7 \sigma$). This is due to the number of actual edges that can be captured in a reasonable amount of time.

However, the waveform eye width is a good check for the health of the signal. It can serve as a simple “plugfest friendly” test as long as a statistical certainty (number of edges) is specified along with it.

Waveform eye width should not to be confused with jitter eye width, which does provide statistical certainty down to 10^{-12} BER levels.




Figure 10. “Bathtub curve,” or Cumulative Distribution Function.

Jitter Measurements

Jitter measurements have been a topic of extensive discussion in industry working groups in recent years. Jitter is so important, in fact, that specialized analysis tools exist to help designers penetrate this difficult problem.

Time interval error (TIE) is the basis for many jitter measurements. TIE is the difference between the recovered clock (the jitter timing reference) and the actual waveform edge. Performing histogram and spectrum analysis on a TIE waveform provides the basis for advanced jitter measurements.

At the time of this writing there are few consistent measurement methods, aside from eye diagrams, among standards. In FibreChannel, InfiniBand, and XAUI, methods have been developed by the T11.2 jitter working group.

“Methodologies for Jitter Specification” (MJS) published in 1999 defines total jitter as “the sum of random and deterministic jitter components”. More recently, this work has been updated by the T11.2 in the form of “Methodologies for Jitter and Signal Quality Specification” (MJSQ). The relationship to Total Jitter (TJ), Jitter Eye Opening (at 10^{-12} BER), and Unit Interval is as follows:

$$\text{Total Jitter} + \text{Jitter Eye Opening} = 1 \text{ Unit Interval}$$

Total jitter is defined by establishing a jitter timing reference defined by a “Golden PLL” model for clock recovery from the serial bit stream. The Golden PLL loop bandwidth is defined by $f_c/1667$,

where f_c is the bit rate. From the jitter timing reference, a Cumulative Distribution Function (CDF), also known as a “bathtub curve” (Figure 10) is established, showing where the eye opening at 10^{-12} BER occurs. Traditionally these measurements have been cumbersome to make with a BERT scan or Time Interval Analyzer (TIA) instrumentation. There are automated software toolsets available for performing these measurements with a real-time oscilloscope and for separating Random and Deterministic Jitter (Rj/Dj).

Standards such as Serial ATA and PCI Express agree that the total jitter is the sum of random and deterministic components. However, various models for clock recovery exist. These standards call for the clock to be recovered from a set number of consecutive bits in the serial bit stream. These jitter methods are used because there is recognition that different forms of clock recovery such as oversampling or phase interpolation can be implemented.

Figures 11 and 12 show two different jitter measurement methods used on the same 2.5 Gb/s signal. In Figure 11, the Total Jitter and Deterministic Jitter is shown (as specified in InfiniBand). Total Jitter is determined using the bath tub curve method. In this case, the Jitter Eye opening is .583 UI and the Total Jitter is .417 UI at 10^{-12} BER. Figure 12 shows the “250 Cycle Jitter” test specified in PCI Express. Median to Max outlier is determined by the median of the TIE histogram to the maximum outlier on the histogram. In this case, 44.87 ps measured over any 250 consecutive bits. These are just two of several possible methods.

Mask Testing of Eye Diagrams

The “eye diagram”—an oscilloscope display that results from the overlap of a series of data waveforms—is an important tool for establishing the quality of serial signals. To produce an eye diagram, it is necessary to trigger the oscilloscope synchronously to the data stream and connect the input channel to the data stream carrying random or pseudorandom bits.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 11. Total Jitter and Deterministic Jitter measurement determined using InfiniBand compliance methodology.




Figure 12. Results of a 250-cycle jitter test performed by following PCI Express compliance methodology.

A synchronous clock signal, the data itself or the clock recovered from the data (if the oscilloscope has a clock recovery circuit) triggers the oscilloscope. In one captured screen, all possible signal transitions of the signal are displayed: positive-going, negative-going, leading, and trailing. This single display provides information about the eye opening, noise, jitter, rise and fall times, and amplitude. The display can be used for qualitative analysis, while the




Figure 13. Eye pattern mask.




Figure 14. Eye pattern display.

embedded statistical database of the oscilloscope can be used to make quantitative measurements.

Rather than extracting numeric information on the signal characteristics, the two-dimensional shape can easily be compared to a group of violation zones called a mask. Figure 13 depicts a mask as outlined in a typical standards document.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 15.

Masks are defined by and for each standard group. Comparing the shape of an eye to a mask is a quick, efficient method of ensuring that the transmitter source signal will not cause excessive degradation of the receiver performance. Figure 14 shows an actual eye diagram as captured on a real-time oscilloscope display. Note that the boundaries of this image, which passes the compliance test, are within the ranges expressed in Figure 13.

Measurements on Optical Signals

Many serial data standards such as InfiniBand, FibreChannel, and 1394B have both copper and optical PMD variants.

Examples of commonly used optical measurement are AOP (Average Optical Power) and ER (Extinction Ratio). Somewhat less known is the OMA – Optical Modulation Amplitude. OMA is growing in popularity due to its use in the FC (Fibre Channel) and 10 GbE (IEEE 802.3ae, 10 Gb/s Ethernet) standards, which are by far the fastest growing segments of the very high-speed optical market.

► ER

A very common optical measurement is the Extinction Ratio – ER. Here is the definition of ER:

$$ER_{dB} = 10 * \log_{10} \left(\frac{High}{Low} \right)$$




Figure 16. Measuring OMA on a square-wave: Figure above shows the standard-prescribed way of measuring the OMA.

The 'High' and what is 'Low' changed somewhat over the years, today these are the mean values in the aperture which for the NRZ eye is a horizontal region horizontally centered between the eye crossing, with width of 20% of the UI.

Figure 15 is an example of the measurement on an oscilloscope screen.

Basic issue of the ER measurement is that the 'Low' level greatly influences the measurement; it's typically necessary to run 'Dark Level Compensation' to obtain a reliable result.

► OMA

Here is a definition of OMA with some comments on its use, with the 10 Gb/s standards being measured on a sampling oscilloscope (aka CSA – Communications Signal Analyzer).

Performance of the optical link is related to transmitted power of High and Low signal level, which therefore need to be measured. Instead of measuring these directly, telecommunication standards typically specified ER (Extinction Ratio) and AOP (Average Optical Power).

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 17.

10 GbE specification uses OMA (Optical Modulation Amplitude) instead of the ER + AOP pair. This change doesn't remove the references to ER completely, so both OMA and ER have to be measured. AOP remains only in non-signaling related specifications (e.g. safety).

The equation is simply:

OMA = High – Low [W,W,W]; or, in it's perhaps more common usage in dBm units:

$$OMA_{dBm} = 10 \log \left(\frac{High - Low}{1mW} \right)$$

Referring back to Figure 16, note that the n (in the "n*UI" expressions at the top of the picture) differs from standard to standard; for example for 10 GbE it is allowed to be anywhere between 4 and 11. For the sake of comparable results, we recommend to use the lowest allowed value (e.g. $n = 4$ for 10 GbE).

Practical measurement is shown in Figure 17.




Figure 18.

The measurement on a square wave is specified because it's perceived to be more repeatable than a measurement on the eye diagram; however, but it cannot be performed on live data, or a PRBS. For this reason another definition is also used.

► Measuring OMA on an eye diagram — Figure 18 gives an example of this measurement, also note the ISI [Inter-Symbol Interference] present in the eye diagram, somewhat common to today's low-cost transmitters. In some cases standards this eye diagram based method is the only one used for OMA; on the other hand, in the case of 10 GbE the standard only allows this method for approximating OMA and the square-wave method is the only binding one for conformance verification.

While ER and AOP will remain the preferred way to specify longer haul links, OMA is used more and more frequently due to the growing number of shorter reach standards like 10 GbE and 10GBFC.

Overview of Serial Compliance Measurement Solutions

At this point, it should be clear that serial compliance measurements require the resources of high-performance measurement instruments. Four classes of instrumentation are most often used for compliance testing as well as design verification and debug tasks.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

Real-time Oscilloscopes

The tool of choice for measuring the electrical portion of the PHY is a high-performance real-time (RT) oscilloscope. State-of-the-art digital storage oscilloscopes (DSO) and digital phosphor oscilloscopes (DPO) can capture continuous, contiguous data in the multi-gigabit range with very good signal integrity. Many current-generation instruments include Digital Signal Processing (DSP) software algorithms that can recover the embedded clock from a serial data bit stream acquired with a single trigger event. This eliminates trigger jitter from subsequent analysis steps. Some real-time oscilloscopes offer both Real-Time (RT) and Equivalent Time (ET) Eye reading techniques using hardware clock recovery, each of which has their advantages.

Once a clock is recovered from a serial bit stream, the oscilloscope can create an eye diagram and a frequency spectrum of the Time Interval Error (TIE). The TIE can be analyzed to separate random and deterministic jitter, an analysis that also provides an estimate for total jitter at the 10^{-12} bit error rate (BER).

Aside from combining the functions of several instruments into one, the RT oscilloscope has other advantages: probing flexibility, rich display, triggering capabilities, and more. The RT oscilloscope makes an ideal platform for serial data validation, debug, and compliance testing.

Sampling Oscilloscopes

The only oscilloscopes available for looking at very high-speed analog signal integrity are high-speed sampling oscilloscopes. With a maximum bandwidth of 70+ GHz, these instruments are capable of analyzing optical and electrical signals at 40 Gb/s and beyond. Sampling oscilloscopes capture waveforms in “Equivalent Time” (ET), constructing a composite image from samples accumulated over numerous repetitive cycles. Waveform eye diagrams created by sampling oscilloscopes provide a good view of optical and electrical signal characteristics. An extensive library of built-in measurements makes this the ideal tool for characterization and compliance testing of very high-speed components, transceivers, and transmission systems.

Logic Analyzers

The preferred tool for measuring the formatted serial data (as opposed to individual pulse characteristics) is the logic analyzer. Unlike both RT and ET oscilloscopes, logic analyzers capture binary data and express it in terms of clocks, cycles, and edge transitions. The purpose of the logic analyzer is to simplify acquisition and analysis of the purely digital aspects of the serial transmission. To carry out its serial bus debug mission, it must deliver features consistent with the needs of high-speed buses: high sample rate, deep memory, flexible triggering and synchronization, and more. And like the oscilloscope, it must offer low-impact probing tools.

Signal Sources

Good high-speed engineering practices include exercising designs under “real-world” conditions. The right tool for mimicking these conditions as closely as possible is a programmable signal source. Generating test signals at today’s data rates requires high-speed Data Timing Generators (DTG) and Arbitrary Waveform Generators (AWG). Without these instruments there would be no way to test and validate new physical layer designs. Many signal sources can replay signals that have been captured with an oscilloscope. The signals can act as a reference signal or may be modified to stress the device under test.

Data Timing Generators are especially useful for generating multiple streams of channels of parallel data—up to 96 channels in today’s most advanced instruments. These tools deliver 3.3 Gb/s data rates, sufficient to cover most of today’s standards. At the same time these advanced instruments provide a host of signal manipulation features including independent level, rise/fall and jitter controls.

High-speed digital signals inevitably have analog attributes. Arbitrary Waveform Generators can provide stimulus signals with analog content (usually deliberate impairments) on a bus channel. Capable of delivering any type or shape of waveform, AWGs are universally applied in design and manufacturing. Current AWGs have sample rates exceeding 4 GS/s (2 GHz bandwidth), equivalent to a 4 Gb/s data rate.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

Of these four tools, the real-time oscilloscope has become the workhorse of compliance testing. It also serves as a debug troubleshooting platform, where it is assisted by the logic analyzer. Recent advances in both measurement performance and integrated analysis capability have made the RT oscilloscope the choice of standards groups, product developers, and compliance certification providers.

Analog Compliance Measurement Considerations: Probing

Every serial measurement, whether for compliance testing, validation, or troubleshooting purposes, consists of probing the device, acquiring the signal data, and analyzing the captured information. Selecting the right tools, and applying them correctly, is the way to ensure fast, accurate results. The balance of this document will deal with the measurement needs of today's high-speed serial devices.

Connecting to the Serial Device Under Test

Measurements begin with a connection to the device under test. In the case of serial bus architectures, the question arises: what is the mechanical interface of the lane to be tested? This is a question usually answered in the mechanical portion of the standard, sometimes called the physical media dependent (PMD) specification. There are diverse configurations, each with its own unique characteristics.

The mechanical interface has a profound impact on probing for both electrical and logical testing. The probe may need to match tiny physical features, while delivering high-speed differential signals intact to the measurement instrument. Alternatively, the probe may need to adapt to prototype fixturing such as test points fitted with SMA connectors.

There are four approaches to the probing challenge. Remember, the signals in most serial architectures are transmitted differentially, so all of the solutions explained here are meant to connect differentially.




Figure 19. Pseudo-differential probing connection to a serial device.

► Pseudo-Differentially Connected Movable Probes — Compliance measurements usually have specified test points, but troubleshooting work may require probing circuit points anywhere on a device's circuit board. This makes it necessary to probe individual circuit traces and pins with moveable manual probes. Both pseudo-differential and true differential probing solutions are available. Both configurations have their strengths.

Two single-ended active probes, one on each side of the differential signal, can be used for pseudo-differential measurements. Figure 19 shows a Chip-Chip application example. Two channels of the oscilloscope capture two channels of data, which are subsequently processed as one signal.

Because the single-ended probe can capture both AC and DC components of the signal, it is the best tool for looking at common-mode effects on a differential link. While the link's receiver sees only the differential swing from the transmitter, variations in the common-mode voltage can cause undesirable amplitude variations in alternating cycles.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 20. Asymmetrical signal captured using pseudo-differential probing.

Figure 20 shows an example of asymmetrical signals captured by a pseudo-differential probing setup. Most serial standards have a specification for maximum common-mode AC voltage (V_{CM}) and also stipulate an acceptable range for common mode DC voltage. Max and Min measurements can be made on the V_{CM} waveform to determine if a device is within specification. Similarly, the oscilloscope calculates the differential voltage V_{DIFF} by subtracting one channel's value from the other. The math waveform represents the signal the receiver actually sees. Eye diagram, amplitude, and jitter and timing measurements are made on this math waveform.

Because the two sides of the waveform enter two separate oscilloscope input channels in pseudo-differential probing, the inputs must be deskewed before making any measurements.

- True Differential Movable Probes — a true differential active probe is optimized as a low-loss, high-fidelity path for differential signals. Figure 21 shows such a probe capturing the receive side of a connector-based Card-Card serial link.

Unlike the pseudo-differential connection, this probe requires only one oscilloscope channel and makes the subsequent math steps unnecessary. This offers, among other advantages, the ability to use the multiple channels of the oscilloscope to capture multiple lanes simultaneously at the highest sample rates (up to 20 GS/s). It is




Figure 21. A true differential probing setup.




Figure 22. The waveform resulting from a true differential acquisition (as seen at the oscilloscope input).

also useful for debugging of multiple high-speed test points.

Figure 22 shows the waveform from the differential probe. The differential probe requires only one channel of the oscilloscope and does not need deskewing.

It is important to note that any probe will impose some loading to the Device Under Test (DUT). Every probe has its own circuit model whose impedance can change with increasing frequency. This can affect the behavior of the observed circuit and influence the measurement, factors that must be considered when evaluating results.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 23. An SMA true differential probing connection.

When designing “Chip-Chip” interfaces it is important to design test pads into the design of the board, and to consider the mechanical requirements of the intended probes. Probing pads should be placed as close as possible to the receiver termination resistors to avoid signal distortions due to reflections.

- SMA Pseudo-Differentially Connected Probes — many compliance test fixtures and prototype circuits are fitted with SMA high-frequency connectors for external test instrumentation. Under these conditions, the SMA pseudo-differential approach is a practical solution. Here the output of the transmitter connects directly to two inputs of the oscilloscope, each of which has an input impedance of $50\ \Omega$. SMA adapters provide the necessary mechanical termination on the front panel of the oscilloscopes.

As explained earlier, this pseudo-differential technique consumes two channels of the oscilloscope, and probe deskewing is critical.

- SMA True Differential Probes — a new class of oscilloscope probes has emerged to implement component-level transmitter testing of devices with integral SMA fixturing: the high-performance SMA-terminated differential probe.

The SMA input differential probe is also ideal for compliance tests where interoperability points are defined at the “Card-Card” or “Card-Cable” interface. A $100\ \Omega$ matched termination network properly terminates both legs of the differential signal to any user-provided common mode voltage. The voltage may be at ground potential or a termination voltage appropriate to the logic family being tested.

The common mode connector can also be left open if the transmitter will drive a $100\ \Omega$ differential load. Figure 23 illustrates a true differential SMA probe attached to a Card-Card interface and fixture.

Compliance Measurement Considerations: Acquisition

System Performance Drives Measurement Accuracy

The pairing of oscilloscopes and their probes must be considered as a system when choosing solutions for critical high-speed measurements. The instrument’s performance becomes part of the measurement. The analog acquisition characteristics of the system as well as its digitizing specifications all play a role in delivering meaningful measurement results.

With real-time oscilloscopes taking on increasing responsibility in compliance testing, it is important to choose a solution that preserves the signal for analysis steps such as eye diagram and amplitude measurements. Following is a summary of some key characteristics that play a role in this.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

Evaluating The Acquisition System's Analog Performance

- Bandwidth (BW) — A good rule of thumb for selecting oscilloscope bandwidth is outlined in the Fibre Channel Physical Interface specification (FC-P1): "For rise time measurements the oscilloscope and probe combination should have a bandwidth of 1.8 times the bit rate."

Following this guideline, measurements on a 2.5 Gb/s standard call for an analog bandwidth of at least 4.5 GHz. This allows the first harmonic (1.25 GHz) and the third harmonic (3.75 GHz) to be passed with some margin.

The term "bandwidth" denotes the frequency range that the oscilloscope's input circuit (vertical amplifier) will admit, within certain tolerances. The instrument's sample rate (see below) is usually optimized to handle this same range.

- Risetime (tr) – Risetime measurements on digital devices are part of most validation and compliance tests, so the system rise time of the test equipment is critical. In effect, the measured risetime includes the contribution of the instrument's own risetime. The following equation shows the typical relationship between displayed risetime, system rise time, and the actual rise time of the device under test:

$$tr(\text{displayed}) \approx \sqrt{[tr(\text{meas. system})^2 + tr(\text{signal})^2]}$$

At this writing, not all oscilloscope vendors provide guaranteed rise time specifications for its oscilloscopes and probes. In most standards, the risetime specifications describe the time it takes to traverse from 20% to 80% of the voltage swing. Obviously there is an advantage to knowing the actual risetime the probe provides, the better to calculate its impact on the measurement.

For example, a probe with a 20% to 80% risetime specification of 65 ps, when applied to a signal with a true risetime of 75 ps, would produce a measured result of 99 ps. This is an unavoidable measurement artifact.

If even the best available real-time oscilloscopes add measurement errors in rise time why not use a higher bandwidth sampling oscilloscope for validation and compliance?

Certainly this is an alternative but sometimes it is important to provide a single connection point to the DUT in order to maintain signal integrity. Sampling oscilloscopes require the signal go through a power splitter in order to get one copy of the signal into the input channel and one to the clock recovery or trigger module. RT oscilloscopes do not have this requirement. More importantly, the reason real-time oscilloscopes are desired is because the jitter measurement techniques that have been adopted by several industry groups can be performed by real-time oscilloscopes, making it the preferred platform in many cases.

Evaluating Digital Performance

- Sample Rate (SR) – The sample rate required to accurately reconstruct an analog signal is defined by the Nyquist sampling theorem. This states that a sample rate at least two times greater than the frequency content of the input signal is required to capture enough data to accurately reconstruct the waveform. Therefore an instrument with 6 GHz input bandwidth must have sample rate of at least 12 GS/s. The 20 GS/s sample rate of state of the art oscilloscopes meet this requirement.
- Record Length (RL) – The record length required for serial data testing is typically determined by the chosen jitter measurement technique. For example both PCI Express and InfiniBand are 2.5 Gb/s standards. PCI Express is intended to be primarily a Chip-Chip or Card-Card applications. Acquisition for jitter compliance requires 3500 consecutive cycles (1.4 usec) of real time data at full sample rate.

For standards that are intended for cabled or "Cabinet-Cabinet" interfaces, such as InfiniBand, different methods are used to determine jitter compliance. Here the jitter methodology is borrowed from Fibre Channel and the methodology used for measurement requires that a repeating jitter pattern be transmitted from the device under test. The record length required to perform the jitter measurements is dictated by how many bits are in the jitter compliance pattern.

- Interpolation – For signals with fast rise times (like the 50-100 ps rise-times in serial data links), $\sin(x)/x$ interpolation of the sampled data provides accurate amplitude-based measurements and eye diagrams. An interpolation factor of greater than 3X (on 20 GS/s sampled data) is adequate for such measurements.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 24. Real-time eye diagram displayed with post-processing techniques.



Figure 25. The user interface window of a serial analysis tool running on a real-time oscilloscope.

For jitter measurements in which a reference level is taken at the switching threshold or “zero level” of the differential signal, interpolation typically has negligible effect on the results.

Some real time oscilloscopes provide $\sin(x)/x$ interpolation as part of the acquisition path; it is the default means of interpolation. This provides accurate results without slowing down the waveform and measurement throughput.

Compliance Measurement Considerations: Analysis

Jitter tests and eye diagram measurements are among the most complex procedures that an oscilloscope can perform. Both require statistical analysis of vast amounts of data. And both are key elements of serial compliance testing.

Eye diagrams have been the province of sampling oscilloscopes for years. The sampling methodology provides accurate measurements with a very low jitter noise factor (JNF). However, the requirement

for a stable, uninterrupted signal makes the sampling instrument impractical when performing industry standard jitter measurements. Such techniques require continuous (contiguous) data to perform the analysis. Sampling oscilloscopes do not provide continuous data. More recently, some real-time oscilloscopes have incorporated clock recovery circuits based on a PLL based clock recovery circuit. They perform eye diagram tests using random Equivalent Time sampling. This technique is similar to that used in sampling oscilloscopes and require repetitive trigger events to build an eye diagram and is susceptible to trigger jitter.

Fortunately, some real-time oscilloscopes offer another means of eye rendering. They rely on the single-trigger nature of real-time acquisition, capturing a contiguous series of complete waveform cycles as they occur after the trigger event. The embedded clock is recovered in software after the acquisition, and the actual waveform edges are “redrawn” using the recovered clock as the reference. Figure 24 is an eye diagram derived with this methodology.

There are several advantages to this approach. It provides a JNF as low as 700 fs on certain real-time oscilloscope models, making it the equal of sampling oscilloscopes in terms of eye diagram precision. And because the clock is recovered using software DSP, clock recovery is not limited to a single algorithm. The software-based

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 26. A jitter trend analysis. The real-time waveform is shown in blue, and the jitter trend in red.

package provides an interface for changing the method by which the clock is recovered, a valuable asset in a world of constantly evolving standards. Real-time clock recovery and eye rendering also provides a means for separating transition bits from non-transition bits and performing separate mask testing operations on each type of bit as is required for PCI Express. Figure 27 shows the separation of Transition and Non-Transition bits from the eye diagram shown in Figure 24.

It is often necessary to more deeply analyze the data in the context of the compliance measurements. For example, an eye diagram test may fail because the embedded clock signal has too much modulation. The eye diagram shows only violations to the mask, but a TIE waveform trend or frequency spectrum can reveal further clues. Other built-in oscilloscope tools such as cursor measurements and zoom controls can aid the in-depth analysis.

Getting a Handle on all that Data

Eye diagrams and jitter measurements in particular produce a volume of data that would be difficult to manage without the help of automated analysis tools. Figure 25 shows the user interface of an integrated analysis package running on a real-time oscilloscope. Key measurements such as rise and fall time can be set up with just one on-screen “button.” The acquisition window presents the raw serial waveform.




Figure 27. Serial compliance summary screen showing the eye pattern mandated by the standard as well as quantitative results in tabular form.

But Figures 26 and 27 bring out the true benefit of the analysis package. In Figure 26 the automated tools work on the waveform from Figure 27 to produce an information-rich jitter trend analysis.

Thinking Beyond Compliance Testing

A Digital Tool for Digital Tasks

Physical layer compliance tests are often the climax of a long and arduous product development process. But there are other concerns before and after compliance. After all, the device has to pass not only pulses but also valid binary data. In our discussion so far, nothing has proven the device’s ability to deliver the correct information at the data and protocol levels. Debugging, troubleshooting, and design validation at these levels are as much a part of the project as is preparation for compliance tests.

That means it is time for the logic analyzer to step in and acquire and interpret the data as a whole, rather than individual pulse features. In the logic analyzer’s digital environment, captured data creates a timing diagram of the bus activity. Serial data is fanned out to parallel form and stored in the instrument’s memory. With appropriate decoding tools, this recorded data can even be disassembled to help engineers confirm that higher-level programmatic instructions are being carried out correctly.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer

While this document deals mainly with analog compliance test challenges and solutions, it is worthwhile to review the logic analyzer systems that supplement real-time and sampling oscilloscopes for serial measurements.

Probing Means Making the Right Connections

All measurements start with probing, and preserving signal fidelity is just as much a concern here as it was with the analog acquisition. Earlier we discussed the practice of fixturing prototype devices with SMA connectors to deliver maximum signal fidelity to an oscilloscope. Logic analyzers have their own answer to this approach, with the same signal fidelity objectives in mind.

At frequencies of 2.5 Gb/s and higher, it is not enough to simply clip on a common logic analyzer probe. Flying leads and micrograbbers will introduce ground loops and other unpredictable analog effects. Even routing signals to pin headers will impact low-voltage, high-frequency serial signals. They simply will not tolerate the electrical stub or the loss contributed by a connector.

Instead, a probing method must be considered during board layout. The preferred method for serial signals such as PCI Express is to route the traces to a landing pad. Unlike a connector-based access point, a landing pad has almost no impact on the signal when probe is not in use. Of course, a landing pad requires a matching pattern on the logic analyzer probe.

Clearly the goal is to minimize the loading effect of the probe. But any probe will contribute to the signal loss budget. High-speed signals are sensitive to the impedance of the probe, particularly its capacitive load. As the bandwidth of a signal increases, so does the effect of the probe capacitance. The “ideal” probe for serial bus acquisition has:

- High analog bandwidth
- High impedance
- Low capacitance
- Minimal stub




Figure 28. An active logic analyzer probe with landing pads.

In practice these requirements necessitate an active probe with buffering components as close to the landing pad as possible, as shown in Figure 28.

The probe in Figure 28 is designed specifically for PCI Express applications but there are similar “connectorless” solutions available for general high-speed probing. These are suitable for serial technologies such as HyperTransport, assuming the device under test is designed with matching landing pads for the probe.

A second type of probe plugs into an edge connector on the DUT and passes the signals to a logic analyzer as well as the next element in the DUT’s system.

Acquiring the Signal: from Packet to Parallel

Serial signals deliver deep packets of data that are a few bits wide; parallel signals appear in the form of “words” that are one bit deep but many bits wide. A logic analyzer is an innately parallel architecture, with many channels (bits) accepting data simultaneously. But thanks to special processor- and bus-support packages, logic analyzers can acquire and analyze serial data just as readily as parallel data. The hallmark of a state-of-the-art logic analyzer is the breadth of its processor and bus support packages.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 29. In this example, the logical view descrambles, deskews, and decodes the data, and sets the bits to the correct polarity. The results are displayed as a stream of hexadecimal data.




Figure 30. Multi-channel eye diagram tool.

Figure 29 shows how the logic analyzer displays breaks apart serial data and displays it in the logical and electrical sub-block formats.

The electrical view shows waveform data, but it is neither decoded nor descrambled, and its polarity appears in the inverse. This view does, however, show the time alignment of every change in the data values in all four lanes.

The steady increase in digital bus data rates is accompanied by an equivalent decrease in timing margins and data-valid windows. Designers need tools that can help them capture and analyze data eye diagrams on many channels, quickly and unobtrusively. Given these eye diagrams, the engineer measures vertical and horizontal histograms, 4-point and 6-point mask testing, slope, eye-limit, statistical measurements and more. Figure 30 is a screen from a measurement package that carries out these functions. Data may be viewed as a bus form, or as a single channel, or as a bus form with individual channels highlighted to quickly identify the source of elusive problems.




Figure 31. Automated deskewing tool counteracts skew in the measurement system when acquiring high-speed data.

At higher speeds, channel-to-channel skew can make it difficult to acquire valid data. The solution to this problem is a measurement tool that automates adjustment of setup/hold windows to remove skew from the measurement system, allowing valid data to be captured. Figure 31 depicts such a tool. In addition to this key automated feature, the tool allows users to verify their settings using a programmable margin value to test for corner cases of data valid windows on the bus.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 32. A logic analyzer trigger template.

These tools are important part of the troubleshooting process. They make it possible to spot errors and begin the process of tracing backward toward the causes. Some logic analyzers can interface directly to an oscilloscope as well, displaying the oscilloscope's waveform view in perfect time correlation with the logical or electrical displays. This simplifies troubleshooting of problems that arise from signal integrity defects, for example.

Triggering is the Key to Efficiency in Troubleshooting

One of the defining features of any logic analyzer is the flexibility of its triggering system. When coupled with a support package designed for a particular serial standard (such as RapidIO or PCI Express), the logic analyzer delivers advanced triggering capabilities to easily isolate and capture specified transactions.

Debug work proceeds quickly when the logic analyzer permits triggering (at speed) on transactions or other packet elements such as control symbols. Some instruments even include triggering templates such as the one shown in Figure 32. These are presets (factory-provided or user-customized) that allow the user to fill in a "form" to specify events of interest. The template fields can be optimized for the unique requirements of each serial protocol.




Figure 33. Source-synchronous clocking setup screen.

New Synchronization Modes Stay in Step with Serial Requirements

High-speed synchronous data transfers are becoming ever more common in emerging computing, networking, and communications environments, including serial data architectures. Synchronous buses are those that send data multiple times per cycle using a diverse array of clocking schemes. Digital architects have devised a number of innovative clocking approaches, including "double-pumped," "quad-pumped," and "source-synchronous."

Perhaps the most innovative of these is the source-synchronous clocking architecture. In a typical source-synchronous transaction, the transmitting device sends a strobe and multiple data bits in each cycle. The receiving device uses this strobe to latch the data, and then resynchronizes the data to the master or common clock.

The Basics Of Serial Data Compliance and Validation Measurements

► Primer




Figure 34. Cycle-by-cycle analysis of RapidIO bus activity.

In a HyperTransport link, for example, commands, addresses, and data transfers are source-synchronous as well as “double-pumped.” Packet transfers take place on both the rising and falling edges of the clock signal, yielding a data rate twice that of the clock frequency.

Complex synchronous clocking schemes that deliver multiple bits in every cycle can only continue to grow in popularity, as developers strive for ever-higher bandwidths in their digital systems. Logic analyzers must keep pace with this trend. Today, some instruments offer simplified control of synchronous acquisition, again using setup steps involving self-explanatory templates such as the one shown in Figure 33.

Analyzing the Results

With the acquisition completed, the stored data must be decoded into meaningful results and displayed in an appropriate manner. Bus support packages include sophisticated software tools to disassemble, decode, and display the captured data in a packet-style view using its listing window, as illustrated in Figure 34. This is an acquisition from a RapidIO bus.

The display includes three elements: a packet/control symbol summary, detailed decoding of the fields of a packet/control symbol, and the raw data. Color-coding differentiates the text in each of these three elements and distinguishes control symbols from packets in the packet/control symbol summary. Color also differentiates the transaction and operation levels of request and response packets in the details column.


Equipped with an optimized support package, the logic analyzer delivers advanced disassembly features, such as deep capture of onboard processor activity correlated to transmit and receive ports and deep synchronous display of these ports. The disassembler provides control symbol decoding and display of individual fields in the physical layer; packet decoding and display of individual fields for physical, transport and logical protocol layers; and simultaneous decoding of both transmit and receive data ports.

Summary

Serial buses, components, and transmission elements are here to stay, and are destined to grow in importance as technology markets continue to demand ever-accelerating data rates. Design and validation engineers have a new and perhaps unfamiliar discipline—serial compliance measurement—to learn even as they confront aggressive development schedules and fast-changing standards.

Fortunately, industry working groups and standards committees have formed around each of the many serial standards, stabilizing the technologies and disseminating information about design, architecture, and compliance requirements.

At the same time, a new generation of measurement tools, ranging from real-time oscilloscopes to logic analyzers and signal sources, has emerged to help engineers deal with serial measurement challenges. These solutions deliver the performance to capture, display, and analyze the most complex serial signals. Thanks to these innovative, automated tools, engineers can perform serial compliance and validation tests with the same ease and accuracy as any other measurement.



TDSRT-EYE™

TDSRT-EYE Serial Data Compliance and Analysis Software takes the guesswork out of compliance testing by providing a complete solution from probe tip to compliance report for emerging copper serial data standards.



P7350 and P7350SMA Differential Probes

The P7350 and P7350SMA are your high bandwidth differential probing solutions for analog validation and compliance testing, whether probing at the circuit board or using SMA connection. All the TekConnect.

Contact Tektronix:

ASEAN / Australasia / Pakistan (65) 6356 3900

Austria +43 2236 8092 262

Belgium +32 (2) 715 89 70

Brazil & South America 55 (11) 3741-8360

Canada 1 (800) 661-5625

Central Europe & Greece +43 2236 8092 301

Denmark +45 44 850 700

Finland +358 (9) 4783 400

France & North Africa +33 (0) 1 69 86 80 34

Germany +49 (221) 94 77 400

Hong Kong (852) 2585-6688

India (91) 80-2275577

Italy +39 (02) 25086 1

Japan 81 (3) 3448-3010

Mexico, Central America & Caribbean 52 (55) 56666-333

The Netherlands +31 (0) 23 569 5555

Norway +47 22 07 07 00

People's Republic of China 86 (10) 6235 1230

Poland +48 (0) 22 521 53 40

Republic of Korea 82 (2) 528-5299

Russia, CIS & The Baltics +358 (9) 4783 400

South Africa +27 11 254 8360

Spain +34 (91) 372 6055

Sweden +46 8 477 6503/4

Taiwan 886 (2) 2722-9622

United Kingdom & Eire +44 (0) 1344 392400

USA 1 (800) 426-2200

USA (Export Sales) 1 (503) 627-1916

For other areas contact Tektronix, Inc. at: 1 (503) 627-7111

Updated 20 September 2002



For Further Information

Tektronix maintains a comprehensive, constantly expanding collection of application notes, technical briefs and other resources to help engineers working on the cutting edge of technology. Please visit www.tektronix.com



Copyright © 2003, Tektronix, Inc. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks or registered trademarks of their respective companies.

06/03 MD/SFI

55W-16736-0