


**RF PCB Toolbox™**

User's Guide



**MATLAB®**

R2021b



## How to Contact MathWorks



Latest news: [www.mathworks.com](http://www.mathworks.com)  
Sales and services: [www.mathworks.com/sales\\_and\\_services](http://www.mathworks.com/sales_and_services)  
User community: [www.mathworks.com/matlabcentral](http://www.mathworks.com/matlabcentral)  
Technical support: [www.mathworks.com/support/contact\\_us](http://www.mathworks.com/support/contact_us)



Phone: 508-647-7000



The MathWorks, Inc.  
1 Apple Hill Drive  
Natick, MA 01760-2098

*RF PCB Toolbox™ User's Guide*

© COPYRIGHT 2021 by The MathWorks, Inc.

The software described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from The MathWorks, Inc.

FEDERAL ACQUISITION: This provision applies to all acquisitions of the Program and Documentation by, for, or through the federal government of the United States. By accepting delivery of the Program or Documentation, the government hereby agrees that this software or documentation qualifies as commercial computer software or commercial computer software documentation as such terms are used or defined in FAR 12.212, DFARS Part 227.72, and DFARS 252.227-7014. Accordingly, the terms and conditions of this Agreement and only those rights specified in this Agreement, shall pertain to and govern the use, modification, reproduction, release, performance, display, and disclosure of the Program and Documentation by the federal government (or other entity acquiring for or through the federal government) and shall supersede any conflicting contractual terms or conditions. If this License fails to meet the government's needs or is inconsistent in any respect with federal procurement law, the government agrees to return the Program and Documentation, unused, to The MathWorks, Inc.

### Trademarks

MATLAB and Simulink are registered trademarks of The MathWorks, Inc. See [www.mathworks.com/trademarks](http://www.mathworks.com/trademarks) for a list of additional trademarks. Other product or brand names may be trademarks or registered trademarks of their respective holders.

### Patents

MathWorks products are protected by one or more U.S. patents. Please see [www.mathworks.com/patents](http://www.mathworks.com/patents) for more information.

### Revision History

September 2021	Online only	New for Version 1.0 (R2021b)
----------------	-------------	------------------------------

<b>Stepped Impedance Maximally Flat Low-Pass Filter for Microwave Applications</b> .....	<b>1-2</b>
<b>Characterization and Modeling of On-Chip Square Spiral Inductor for Si RFIC Application</b> .....	<b>1-8</b>
<b>Bandstop and Bandpass Filters with Open Microstrip Line Stubs using Behavioral and EM Simulation</b> .....	<b>1-14</b>
<b>Design of Dual-Fed Square Microstrip Patch Antenna for Bluetooth Low Energy Applications</b> .....	<b>1-22</b>
<b>Create and Analyse Dual Characteristics of Complementary Split Ring Resonators from Gerber Files</b> .....	<b>1-37</b>
<b>Prototype, Design, and Analysis of SIW based Microstrip Tapered Transmission Line</b> .....	<b>1-44</b>
<b>Model and Analyze Microstrip Interdigital Capacitor as Bandpass filter</b> .....	<b>1-50</b>
<b>Introduction to Passive Planar Spiral Inductors</b> .....	<b>1-55</b>
<b>Design and Analysis of Hairpin Micro-Strip Line Bandpass Filter</b> .....	<b>1-66</b>
<b>Analyzing Crosstalk Between PCB Traces</b> .....	<b>1-77</b>
<b>Create and Analyze PCB Interconnects using Custom Traces</b> .....	<b>1-88</b>
<b>Analyzing High Frequency Currents and Techniques for Routing PCB Traces</b> .....	<b>1-99</b>
<b>Introduction to Equal and Unequal Split Wilkinson Power Splitter</b> ...	<b>1-106</b>
<b>Introduction to 4-Port Couplers</b> .....	<b>1-123</b>
<b>Design Two-Stage Low Noise Amplifier Using Microstrip Transmission Line Matching Network</b> .....	<b>1-143</b>
<b>Design and Analyze Compact UWB Low Pass Filter Using pcbComponent</b> .....	<b>1-158</b>
<b>Design and Analyze Band Stop Filter using pcbComponent</b> .....	<b>1-171</b>

<b>Design and Analyze High Pass Filter using pcbComponent .....</b>	<b>1-182</b>
<b>Design of Quarter-Wave Transformer for Impedance Matching Applications .....</b>	<b>1-194</b>

## **Computational Techniques**

# 2

<b>Method of Moments Solver for Metal and Dielectric Structures .....</b>	<b>2-2</b>
MoM Formulation .....	2-2
Neighbor Region .....	2-6
Singularity Extraction .....	2-7

# RF PCB Examples

---

- “Stepped Impedance Maximally Flat Low-Pass Filter for Microwave Applications ” on page 1-2
- “Characterization and Modeling of On-Chip Square Spiral Inductor for Si RFIC Application” on page 1-8
- “Bandstop and Bandpass Filters with Open Microstrip Line Stubs using Behavioral and EM Simulation” on page 1-14
- “Design of Dual-Fed Square Microstrip Patch Antenna for Bluetooth Low Energy Applications” on page 1-22
- “Create and Analyse Dual Characteristics of Complementary Split Ring Resonators from Gerber Files” on page 1-37
- “Prototype, Design, and Analysis of SIW based Microstrip Tapered Transmission Line” on page 1-44
- “Model and Analyze Microstrip Interdigital Capacitor as Bandpass filter” on page 1-50
- “Introduction to Passive Planar Spiral Inductors ” on page 1-55
- “Design and Analysis of Hairpin Micro-Strip Line Bandpass Filter” on page 1-66
- “Analyzing Crosstalk Between PCB Traces” on page 1-77
- “Create and Analyze PCB Interconnects using Custom Traces” on page 1-88
- “Analyzing High Frequency Currents and Techniques for Routing PCB Traces” on page 1-99
- “Introduction to Equal and Unequal Split Wilkinson Power Splitter” on page 1-106
- “Introduction to 4-Port Couplers” on page 1-123
- “Design Two-Stage Low Noise Amplifier Using Microstrip Transmission Line Matching Network” on page 1-143
- “Design and Analyze Compact UWB Low Pass Filter Using pcbComponent” on page 1-158
- “Design and Analyze Band Stop Filter using pcbComponent” on page 1-171
- “Design and Analyze High Pass Filter using pcbComponent” on page 1-182
- “Design of Quarter-Wave Transformer for Impedance Matching Applications” on page 1-194

## Stepped Impedance Maximally Flat Low-Pass Filter for Microwave Applications

This example shows you how to design a stepped impedance low pass filter for X-band applications.

Microstrip filter plays an important role in microwave applications. Almost all communication systems contain an RF front end which performs signal processing using RF filters. Microwave low pass filters attenuate the unwanted signals above the cut-off frequency. These filters have very low insertion loss and are easy to fabricate in compact sizes.

The stepped impedance low-pass microstrip filters is a cascaded structure of alternating high and low impedance transmission lines. These lines act as semi-lumped elements as they are much shorter than the associated guided wavelength. The high-impedance lines act as series inductors and the low-impedance lines act as shunt capacitors. Therefore, this filter structure is directly realizing the L-C ladder type (LC- $\Pi$ ) of low-pass filters.

Here the stepped impedance low-pass filter and the lumped element model is analyzed for a cut off frequency of 9 GHz. The results of lumped element model and the simulation model are compared and validated [1].

### Design Stepped Impedance Low-Pass Filter


Design a stepped impedance low-pass filter at 9 GHz on an aluminium substrate and visualize it.

```
freq = 9e9;  
sub = dielectric("Name",{ 'Fr4' }, "EpsilonR", 9.6, "LossTangent", 0, "Thickness", 1.6e-3);  
obj = filterStepImpedanceLowPass;  
obj.FilterOrder = 7;  
obj.Substrate = sub;  
d = design(obj, freq, 'Z0', 50, 'HighZ', 120, 'LowZ', 20);  
figure; show(d);
```



Model the 7th order maximally flat low-pass filter at 9 GHz using the `rffilter` object from RF Toolbox. Analyze its s-parameter behavior with input and output impedance at 50 ohm.

```
Lpfilter = rffilter('FilterType','Butterworth','ResponseType','LowPass', ...
    'Implementation','LC_pi','FilterOrder',obj.FilterOrder,'PassbandFrequency',freq,
    'PassbandAttenuation',3.0103,'Zin',50,'Zout',50,'Name','Filter');
spar = sparameters(Lpfilter,linspace(0.1e9,12e9,51));
figure; rfplot(spar);
```




It is clear from the scattering parameters that the cut-off frequency is at 9 GHz and the stop band attenuation is more than 20dB using the lumped element model.

#### Analyze Using Simulation Model

Analyze the simulation model for its s-parameter behavior at 50 ohm reference impedance.

```
s11 = sparameters(d,linspace(0.1e9,12e9,51));
figure; rfplot(s11)
ylim([-50,0]);
```






The scattering parameters obtained from the filter layout realization using simulation model are more accurate because the coupling effect between microstrip line sections are considered along with the losses. The s-parameters plot shows that the cut-off frequency is reduced to 5.8 GHz. This reduction is due to two reasons. One is the coupling effect between each section and the second is the design method for modeling the filter which uses the analytical equations where those effects are not considered. Hence, the design will give approximate results, and you should optimize the length and width of the High and Low impedance lines to shift the cut-off frequency to the desired value.


Use the current function to plot the current distribution on the surface of the stepped impedance low-pass filter below the cut off frequency and view its mesh.

```
figure;
current(d,3e9,'scale','log10');
```



```
figure;  
mesh(d);
```

NumTriangles : 198  
 NumTetrahedra : 420  
 NumBasis : 846  
 MaxEdgeLength : 0.00267  
 MeshMode : auto



Designing the stepped impedance low-pass filter at S-band and below will exhibit less shift in frequency nearly about 0.5 GHz when compared with the shift in design at high frequencies.

### Conclusion

The stepped impedance low-pass filter is designed and analyzed using the design function at 9 GHz cut off frequency. The design is compared with both lumped model and the simulation model to understand the difference in shift in the frequency. It is seen that the shift in the frequency for simulation model is about 2.9 GHz which is due to coupling effect. Hence, the design parameters of the stepped impedance low-pass filter should be optimized to achieve the desired cut-off frequency.

### Reference

1. Salama, Y Battah, A Abuelhaja, 'Stepped Impedance 7th order Maximally Flat Low-Pass Filter Using Microstrip Line for X-Band Applications', *Journal of Physics: Conference Series (ICERIA)*.
2. Sheetal.Mitra, 'Stepped Impedance Microstrip Low-Pass Filter Implementation for S-band Application', *International Journal of Latest Trends in Engineering and Technology (IJLTET)*, Vol. 5, Issue 3, May 2015.

## Characterization and Modeling of On-Chip Square Spiral Inductor for Si RFIC Application

This example shows how to model a square spiral inductor for Si (silicon) RFIC application.

The Silicon substrate is chosen for its low cost of Si IC fabrication over GaAs IC fabrication. The potential for integration with baseband circuits makes Si the process of choice in many RFIC applications.

The RF planar inductors play a vital role in wireless communication to meet the desired requirements like low supply voltage, low cost, low power dissipation, low noise, high frequency of operation, and low distortion.

The square spiral inductors are the most common in Si RF IC's. Design the square spiral inductor over the Si substrate and the SiO<sub>2</sub> insulator at 3 GHz.


### Define Parameters

```
N = 7;
ID = 81e-6;
W = 6e-6;
S = 4e-6;
% Height from the ground plane to the spiral
H = 303e-6;
GL = 230e-6;
GW = 230e-6;
```

### Create Planer Square Spiral Inductor on Si and Sio2 Substrate


Model the 7 turn square spiral inductor using the defined parameters in microstrip line form on Silicon and Sio<sub>2</sub> substrate

```
Ind = spiralInductor;
Ind.NumTurns = N;
Ind.InnerDiameter = ID;
Ind.Width = W;
Ind.Spacing = S;
Ind.Height = H;
Ind.GroundPlaneLength = GL;
Ind.GroundPlaneWidth = GW;
d = dielectric('Name',{'Silicon','sio2'},'EpsilonR',[11.9,4.1],'LossTangent',[0.005,0],'Thickness');
Ind.Substrate = d;
figure; show(Ind);
```



Use the `sparameters` function to compute the s-parameters and plot it.


```
spar = sparameters(Ind,linspace(1e9,5e9,21));  
figure; rfplot(spar);
```



The s-parameters plot shows that after 430 MHz the S11 and S22 monotonically increases towards 0 dB. S12 and S21 decreases showing that energy is stored in inductor and not radiated. The behavior of S11 and S21 satisfies the law of conservation of energy.


Use the inductance function to calculate the measure of inductance of the square spiral inductor at 3 GHz.

```
figure; inductance(Ind,linspace(1e9,5e9,21));
```



It is observed from the plot that the inductance of the spiral inductor increases with increase in frequency. Based on analyzing the quality or Q- factor the peak in Q will be the design frequency of the inductor [2]. According to the reference the design frequency is around 3 GHz and the calculated inductance of the spiral is around 11.09 nH which is suitable for RFIC application.


```
figure;  
mesh(Ind, 'View', 'Metal');
```



Use the current function to plot the current distribution on the surface of the square spiral Inductor.

```
figure;
current(Ind,3e9,'scale','log10');
```





## Reference



- 1 Beerasha R Sa, A M Khanb, Manjunatha Reddy H Vc , " The Design and EM-Simulation of Square Spiral Inductor Using SimpleEquations", *Materials Today: Proceedings* 5 (2018) 10875-10882.
- 2 Tuan Huu Bui, "Design and Optimization of a 10 nH Square-Spiral Inductor for Si RF Ics", University of North Carolina at Charlotte, October, 1999.

## Bandstop and Bandpass Filters with Open Microstrip Line Stubs using Behavioral and EM Simulation

This example shows different ways to create microstrip Line Bandpass and Bandstop filters using open circuit stub.

The `pcbElement` object is used to convert the RF PCB catalog into a circuit element and a Tee shaped circuit is built. The circuit is analysed using the behavioral model and EM simulation. The `traceTee` shape in RF PCB Toolbox is used and converted into a PCB component and analysed. The PCB is analysed using EM Simulation and the results are compared with the circuit counterpart.

The dimensions of the microstrip line and the stub in the figure are taken from the reference. The left image shows the circuit representation with the port numbers and the right side image shows the `traceTee` structure with same dimensions.



### Circuit Element with Behavioral Model for Microstrip Line

Create a `circuit` object and three `microstripLine` objects to build the circuit as shown in the figure. Update the value of `EpsilonR` and `Height` to 2.33 and 1.57 mm respectively.

```
tic
ckt = circuit;
c1 = microstripLine('Length',46e-3,'Width',4.6e-3);
c1.Substrate.EpsilonR = 2.33;
c1.Height = 1.57e-3;
c2 = microstripLine('Length',46e-3,'Width',4.6e-3);
c2.Substrate.EpsilonR = 2.33;
c2.Height = 1.57e-3;
c3 = microstripLine('Length',18.4e-3,'Width',4.6e-3);
c3.Substrate.EpsilonR = 2.33;
c3.Height = 1.57e-3;
```

Use the `pcbElement` object to convert the microstrip lines to circuit objects and set the `Behavioral` flag to `true` so that the computation will be done using the analytical equations. In the circuit model, the microstrip discontinuities are not modelled, hence the results might be slightly different than EM analysis.


```
p = pcbElement(c1,'Behavioral',true);
p1 = pcbElement(c2,'Behavioral',true);
p2 = pcbElement(c3,'Behavioral',true);
```

Use the `add` function to form the circuit and use the ports numbers as shown in the circuit above. Use port numbers 1 and 2 for the first microstrip line and connect another microstrip line from ports 2 to 3 which forms a series connection. Connect the third microstrip line from the port 2 to 4 which forms a tee network.

```
add(ckt,[1 2 0 0],p);
add(ckt,[2 3 0 0],p1);
add(ckt,[2 4 0 0],p2);
setports(ckt,[1 0],[3 0]);
```

Use the `sparameters` function to calculate the s-parameters for the circuit and plot it using the `rfplot` function.

```
S = sparameters(ckt,linspace(1e9,10e9,21));
figure,rfplot(S);
```



### Circuit Element with EM simulation for Microstrip Line

Use the `pcbElement` object to convert the microstrip lines to circuit objects and set the `Behavioral` flag to `false` so that the computation will be done using EM Simulation.

```

ckt1 = circuit;
p = pcbElement(c1, 'Behavioral', false);
p1 = pcbElement(c2, 'Behavioral', false);
p2 = pcbElement(c3, 'Behavioral', false);

```

Use the `add` function to form the circuit and use the ports numbers as shown in the circuit above. Use port numbers 1 and 2 for the first microstrip line and connect another microstrip line from ports 2 to 3 which forms a series connection. Connect the third microstrip line from the port 2 to 4 which forms a tee network.

```

add(ckt1, [1 2 0 0], p);
add(ckt1, [2 3 0 0], p1);
add(ckt1, [2 4 0 0], p2);
setports(ckt1, [1 0], [3 0]);


```

Use the `sparameters` function to calculate the s-parameters for the circuit and plot it using the `rfplot` function. Each microstripLine section is solved using the EM solver and the s-parameters calculated are combined to give the combined response of the circuit.

```

S = sparameters(ckt1, linspace(1e9, 10e9, 21));
figure;
rfplot(S);


```



### Creating PCB Stack of traceTee Shape with EM Simulation


Use the `traceTee` shape to create the open circuit stub and use the dimensions as shown in the figure above and visualize it.

```
obj = traceTee;  
obj.Length = [92e-3 18.4e-3];  
obj.Width = [4.6e-3 4.6e-3];  
figure;  
show(obj);
```



Use the `pcbComponent` to convert the shape into a PCB stack. The `pcbComponent` creates the PCB stack up for traceTee shape and assigns the `FeedLocations` at the three open ends of the shape. Assign the dielectric and groundplane to the `Layers` property of the `pcbComponent`. Also assign the `BoardShape` to the groundplane. In the current design, the stub is required as open circuit, hence delete the feed at the third location.


```
pcb = pcbComponent(obj);
gnd = traceRectangular('Length',92e-3,'Width',90e-3);
d = dielectric('EpsilonR',2.33);
pcb.BoardThickness = 1.57e-3;
pcb.Layers{2} = d;
pcb.Layers{3} = gnd;
pcb.BoardShape = gnd;
pcb.FeedLocations(3,:)=[];
figure;
show(pcb);
```



Use the mesh function to manually mesh the structure and set the MaxEdgeLength to 10 mm.

```
figure, mesh(pcb, 'MaxEdgeLength', 10e-3);
```


```
NumTriangles : 415  
NumTetrahedra : 1134  
NumBasis : -  
MaxEdgeLength : 0.01  
MeshMode : manual
```



Use the `sparameters` function to calculate the s-parameters of the structure and plot it using `rfplot` function.

```
S1 = sparameters(pcb,linspace(1e9,8e9,35));  
figure;  
rfplot(S1);
```





### Design at Specific Frequency

The resonance of the Bandstop filter depends on the stub length which needs to be quarter wavelength at the resonant frequency. In the above example the stub is quarter wavelength at 2.9 GHz and hence resonance is observed at that frequency. If the resonance is expected at any other frequency then the stub length needs to be quarter wavelength at that frequency.


### References

- 1 Alexander B. Yakovlev, Ahmed I. Khalil , Efficient MOM-based generalized scattering matrix method for the integrated circuit and multilayered structures in waveguide

## Design of Dual-Fed Square Microstrip Patch Antenna for Bluetooth Low Energy Applications

This example shows how to use the `pcbComponent` and `pcbcascade` functionality of RF PCB Toolbox™ to design and analyze the dual-fed square microstrip patch antenna for Bluetooth Low Energy (BLE) applications.

You can use different feed arrangements to achieve circular and elliptical polarization or by using two orthogonal modes excited with a 90 degree phase difference between them. The two orthogonal modes can be accomplished by adjusting the physical dimensions of the patch and using either single or multiple feeds. For a square patch element, the easiest way to excite for circular polarization is to feed the element at two adjacent edges, to excite the two orthogonal modes as shown in the figure. For a quadrature phase difference, feed the element with a 90 degree power divider or a 90 degree hybrid as shown in the figure below.




### Create Variables

```
Centerfreq = 2.4e9;
freq       = linspace(2e9,3e9,41);
```

### Design of Branchline Coupler

Use the `design` function on the `couplerBranchline` object to create a branchline coupler at the desired frequency and visualize it. The default substrate for branchline coupler is Teflon.

```
coupler = design(couplerBranchline,Centerfreq);
figure;
show(coupler);
```




### Create Variables for Square Patch and the Connecting Feed Lines

The `patchLength` variable creates a square patch. The `feedLineWidth` and `feedLineLength` variables create the feed lines to the antenna. The `portSpacing` matches the gap between the feed lines to that of the output ports of the branchline coupler. The `patchLength` and `feedLineLength` are close to half wavelength at design frequency.

```
patchLength = 41.9e-3;
feedLineLength = 65.7e-3;
feedLineWidth = 3e-3;
portSpacing = coupler.ShuntArmLength/2+coupler.PortLineWidth/2;
```


Use the `traceRectangular` object to create a square patch with side length as `patchLength`. Use the `rotateZ` function to rotate the shape by 45 degrees and visualize it.

```
patch = traceRectangular('Length',patchLength,'Width',patchLength);
patch = rotateZ(patch,45);
figure;
show(patch);
```




Use the `traceRectangular` object to create two feed lines with same length, width, and equal spacing on either side of the X-axis. Perform a Boolean add operation for the shapes `patch`, `feedLine1` and `feedLine2` and visualize it.

```
feedLine1 = traceRectangular('Length', feedLineLength, 'Width', feedLineWidth, 'Center', [-feedLineLength, feedLineLength]);
feedLine2 = traceRectangular('Length', feedLineLength, 'Width', feedLineWidth, 'Center', [-feedLineLength, feedLineLength]);
antShape = patch+ feedLine1+ feedLine2;
figure;
show(antShape);
```



Translate the shape along the X-axis such that the feedlines are aligning at  $x = 0$ .

```
translate(antShape, [feedLineLength, 0, 0]);
```




Define the substrate parameters and create a dielectric object. Create a groundplane using the `antenna.Rectangle` object and use `pcbStack` to create a PCB antenna. Assign the dielectric and ground plane to the `Layers` property on `pcbStack`. Assign the `FeedLocations` to the edge of the feedline and set the `BoardThickness` to `Height` on the `pcbStack` and visualize the antenna.

```
EpsilonR    = coupler.Substrate.EpsilonR;    % Dielectric EpsilonR
Height      = coupler.Height;                % Height of the Substrate
LossTangent = coupler.Substrate.LossTangent; % Loss Tangent of the Substate
```


```
d1 = dielectric('Name',{'Teflon'},'EpsilonR',EpsilonR,'LossTangent',LossTangent,'Thickness',Height);
Gnd = antenna.Rectangle('Length',120e-3,'Width',80e-3,'Center',[120e-3/2,0]);
```

```
ant = pcbStack;
ant.Layers = {antShape,d1,Gnd};
ant.BoardShape = Gnd;
ant.FeedLocations = [0 portSpacing 1 3;0,-portSpacing 1 3];
ant.BoardThickness = Height;
figure;
show(ant);
```



Use the impedance function to plot the impedance of the antenna from 2.2 GHz to 2.6 GHz

```
figure;
impedance(ant, linspace(2.2e9, 2.6e9, 31));
```



The result shows that the impedance of the patch is around 400 ohms at 2.4 GHz. In order to match the impedance of the patch with the 50 ohm line, connect a quarter wavelength transformer at the end of the feedline to transform the impedance to 50 ohm. The impedance of the quarterwave transformer is the geometric mean of the impedances to be matched. Hence the geometric mean of 50 ohm and 400 ohm value comes out to be 141 ohms.


Use the `microstripLine` design to calculate the width of the line with a Z0 of 141 ohm.

```
line = microstripLine;
line.Height = coupler.Height;
line = design(line,Centerfreq,"LineLength",0.25,"Z0",141);
```


Use the `traceRectangular` object to create two quarter wave transformer lines with same length, width, and equal spacing on either side of the X-axis. Perform a Boolean add operation for the shapes `Line1` and `Line2` and visualize it.

```
Line1 = traceRectangular('Length',line.Length,'Width',line.Width,'Center',[line.Length/2,por
Line2 = traceRectangular('Length',line.Length,'Width',line.Width,'Center',[line.Length/2,-por
translate(antShape,[line.Length,0,0]);
```





```
antShape = antShape + Line1+ Line2;  
show(antShape);
```




Define the substrate parameters and create a dielectric to use in the PCB stack of the antenna. Create a groundplane using the `antenna.Rectangle` shape.

Use the `pcbStack` to create a PCB antenna and assign the dielectric and ground plane to the `Layers` property on `pcbStack`. Assign the `FeedLocations` to the edge of the feedline and set the `BoardThickness` to `Height` on the `pcbStack` and visualize the antenna. The below code performs these operations and creates the PCB antenna.


```
EpsilonR      = coupler.Substrate.EpsilonR;    % Dielectric EpsilonR
Height        = coupler.Height;                % Height of the Substrate
LossTangent   = coupler.Substrate.LossTangent; % Loss Tangent of the Substrate
```

```
d1 = dielectric('Name',{'Teflon'}, 'EpsilonR',EpsilonR, 'LossTangent',LossTangent, 'Thickness',Height);
Gnd = antenna.Rectangle('Length',120e-3, 'Width',80e-3, 'Center',[120e-3/2,0]);
ant = pcbStack;
ant.Layers = {antShape,d1,Gnd};
ant.BoardShape = Gnd;
ant.FeedLocations = [0 portSpacing 1 3;0,-portSpacing 1 3];
ant.BoardThickness = Height;
figure,show(ant);
```




Use the `pcbCascade` object to join the coupler and the patch antenna. To obtain the circular polarization, connect the isolated port on the branchline coupler to a matched load of 50 ohm. The isolated port feed location in `FeedLocations` property of the `pcbStack` is copied into the `ViaLocations`. The feed location on the isolated port is deleted. The `lumpedElement` object is used to create an impedance of 50 ohms and the location of the Lumped Element is given at the `ViaLocations`. Assign this `lumpedElement` to the `Load` property on the `pcbStack` and visualize the antenna. The below code performs these operations.

```
pcbAntenna = pcbCascade(coupler, ant);
pcbAntenna.ViaLocations = pcbAntenna.FeedLocations(2,:);
pcbAntenna.ViaDiameter = pcbAntenna.FeedDiameter;
pcbAntenna.FeedLocations(2,:) = [];
r = lumpedElement;
r.Impedance = 50;
r.Location = [pcbAntenna.ViaLocations(1:2), pcbAntenna.BoardThickness];
pcbAntenna.Load = r;
figure;
show(pcbAntenna);
```



Use the `sparameters` function to calculate the s-parameters of the antenna and plot the result using the `rfplot` function.


```
spar = sparameters(pcbAntenna, freq);  
figure;  
rfplot(spar);
```



The result shows that the antenna is a good match from 2 GHz to 3 GHz.

Use the pattern function to plot the 3D radiation pattern of the antenna.


```
figure;  
pattern(pcbAntenna,Centerfreq);
```



The antenna has a gain of around 7 dBi at the design frequency.

Use the `axialRatio` function to plot the axial ratio of the antenna at 2.45 GHz. Use the axial ratio to determine the polarization of the antenna. For the circular polarization, the axial ratio must be less than 3 dB.


```
figure;
axialRatio(pcbAntenna,Centerfreq,90,0:5:180);
title('Axial Ratio for Azimuth = 90 Plane');
```



The result shows that the axial ratio is below 3 dB for all the elevation angles and hence the antenna exhibits a circular polarization. In the orthogonal plane when azimuth angle is 0 degrees, the circular polarization is obtained between the elevation angles of 60 to 90 degrees.

Use the `axialRatio` function to plot the axial ratio of the antenna with frequency.

```
figure;  
axialRatio(pcbAntenna, freq, 0, 90);  
title('Axial Ratio with Frequency');
```



The axial ratio with frequency shows that the antenna exhibits circular polarization around 2.4 GHz.

**References**

[1] Balanis, C.A. "Antenna Theory. Analysis and Design", p. 860, Wiley, New York, 3rd Edition, 2005.



# Create and Analyse Dual Characteristics of Complementary Split Ring Resonators from Gerber Files

This example shows how to create a complementary split ring resonator (CSRR) from Gerber files and subsequently analyze the model. The Gerber file format is used in printed circuit board (PCB) manufacturing and is available in two formats: RS-274D, which was the initial release standard, and RS-274X, which is the newer extended Gerber format. The RF-PCB Toolbox™ supports the newer RS-274X format both to generate Gerber files from a PCB model and also to create the PCB model from a set of Gerber files.

The CSRRs have been proposed for the synthesis of metamaterials. The basic unit cell that exhibits negative permittivity is imported using the gerber files in the first section, which shows band stop response at 0.9 GHz, and later the left handed (LH) behaviour of the metamaterial is achieved which exhibits pass band at the same frequency by creating the slit on the top layer of the transmission line and the same is analyzed [1].

This example shows how to model the above described PCB structure from the gerber file.

## Introduction

A set of Gerber files includes information about layer geometry, layer mask, solder paste usage on the layers, drill file and so on. To create a PCB model out of these files, you need layer files that specify the PCB geometry, and if available a drill file to specify any plated through-hole (PTH) vias. The geometry of the layers is specified through either a top and a bottom layer file, with extensions .gtl and .gbl, or a Gerber file, with the extension .gbr. The RF-PCB Toolbox supports the Excellon format to specify drill information with file extensions .txt or .drl.

The complimentary metamaterial resonator structure contains three layers on which the top layer is the transmission line in microstrip form and the bottom layer is the CSRR. The CSRR model is created from the gerber file in first section. Later, a gap capacitor is introduced by modifying the top layer of CSRR in second section and further, their behaviours are analyzed in the third section .

## Import Top and Bottom layer from the Gerber file

The first step is to import a top-layer and bottom-layer Gerber file from the workspace using the gerberRead function. This will create a PCBReader object. The PCBReader object provides access to the stack up that holds the information of the metal and dielectric layers and also any drill files that describe a PTH via from one metal layer to another if available.

The CSRR model imported using StackUp method contains three layers corresponding to the model of CSRR and returns the model with additional two layers of air dielectric as the first and last layer by default.


Import the top and bottom layers from the gerber file by passing .gtl and .gbl file as inputs to the function gerberRead and use stack up method to create the layers.

```
P1 = gerberRead('CSRRW05lit.gtl','CSRRW05lit.gbl');
P1.StackUp;
```



Pass the created PCB reader object as input to pcbComponent and clean up the layer vertices by rounding it off upto some tolerance. Here 6 is picked as the tolerance as the layer dimensions are in mm units. Later, view the top and bottom layer of the structure to measure its feed width and board dimensions.

The imported PCBReader object contains five layers, Where, layer2 and layer4 holds the top and bottom layer of the CSRR structure.

```
pb = pcbComponent(P1);  
  
pb.Layers{2}.Vertices = round(pb.Layers{2}.Vertices,6);  
pb.Layers{4}.Vertices = round(pb.Layers{4}.Vertices,6);  
  
% Visualize the top and bottom layer of the PCB structure  
figure; show(pb.Layers{2});
```



```
figure; show(pb.Layers{4});
```



The pointers are placed to measure the dimensions of Feed Width and the board shape as shown above. It is observed that, the Feed Width is 1.15 mm and ground plane length and width are 16 mm each.

Next step is to modify the layers of pcb object. Set the PCB Board dimensions, feed diameter and feed location from the measured values accordingly and visualize the PCB model.

```
%Define substrate
h = 1.27e-3;
sub = dielectric('Name',{'Alumina'},'EpsilonR',10.2,'LossTangent',0.0023,'Thickness',h);


% Define Board thickness
pb.BoardThickness = h;

% Define pcb Layers
pb.Layers = {pb.Layers{2},sub,pb.Layers{4}};

% Define Board Shape
gndL = 16e-3;
gndW = 16e-3;
gnd = antenna.Rectangle('Length',gndL,'Width',gndW);
pb.BoardShape = gnd;

% Define Feed Diameter and set Feed location from the measured values
Fw = 1.15e-3;
pb.FeedDiameter = Fw/2;
pb.FeedLocations = [-gndL/2,0,1,3;gndL/2,0,1,3];

% Visualize pcb Component (pb)
figure; show(pb)
```




### Create Slit model of CSRR

Create the slit complimentary split ring resonator by introducing the slit in the microstrip line which exhibits gap capacitor due to which the structure can show its characteristics as LH Metamaterial.

Modify the top layer from the pcbComponent object (pb) by introducing the slit in the top layer of CSSR structure and visualize it.

```
pbs = copy(pb);
g = 0.15e-3;
W = 3.85e-3;
% Create the rectangle to introduce the gap
trace = traceRectangular('Length',g,'Width',W,'Center',[0,0]);
toplayer = pbs.Layers{1};
% Subtract the rectangle from the top layer
slit = toplayer-trace;
% Reassign the top layer
pbs.Layers{1} = slit;
% Visualize pcb Component (pbs)
figure; show(pbs)
```




### Analyze the above CSRR model with and without the slit

The CSRR model shown without slit (pb) and With slit (pbs) on the top layer is analysed in the frequency range of 0.1 GHz to 2 GHz using the sparameters method to compute the transmission coefficient and is plotted using the rfplot method.

```

% Analyse sparameters of CSRR without slit
spar = sparameters(pb,linspace(0.1e9,2e9,51));
figure; rfplot(spar,2,1);
% Analyse sparameters of CSRR with slit
spar = sparameters(pbs,linspace(0.1e9,2e9,31));
hold on; rfplot(spar,2,1)
title('Transmission Co-efficient of CSRR models');
legend('S21 without slit','S21 with slit');

```



It is observed from the above graph that the transmission coefficient S21 for the CSRR metamaterial of negative permittivity lines exhibits the band stop response at resonant frequency of 0.9 GHz, and the Left handed behaviour which is achieved by introducing gap capacitors in microstrip line exhibits the band pass response at the same frequency.

### Conclusion

The microstrip lines loaded with CSRRs has been analyzed in two different forms on the same substrate and is observed that they exhibit stop and pass band at same desired frequency.

The `gerberRead` function is used to import the gerber files of CSRR. One can create, a `PCBReader` object, and subsequently use that object to generate the PCB model using a `pcbComponent` object.

## Reference

- 1 Jordi Bonache, Marta Gil, Ignacio Gil, Joan García, and Ferran Martín, "On the Electrical Characteristics of Complementary Metamaterial Resonators," *IEEE MICROWAVE AND WIRELESS COMPONENTS LETTERS*, VOL. 16, NO. 10, OCTOBER 2006.

## Prototype, Design, and Analysis of SIW based Microstrip Tapered Transmission Line


This example shows how to design and analyze a Substrate Integrated Waveguide (SIW) microstrip transmission line using Gerber files.

High performance microwave components can be designed using a novel approach called the Substrate Integrated Waveguide (SIW) technology. This approach combines the advantages of planar technology, such as low fabrication costs, with the low loss inherent to the waveguide solution.

This SIW tapered transmission line model is intended to operate in the microwave frequency range of 10GHz to 15 GHz [1].

### Define Parameters

Below is the schematic diagram of SIW based microstrip tapered transmission line model.



```

L = 40.016e-3;
Wt = 3.81e-3;
W = 12e-3;
PW = 2.46e-3;
L1 = 2.1e-3;
PL = 6e-3;
gndW = W;
gndL = L+(2*L1)+(2*PL);
% define substrate
h = 0.8e-3;
sub = dielectric('Name',{'duriod'},'EpsilonR',2.2,'LossTangent',0,'Thickness',h);

```

### Create and Analyze SIW Based Tapered Transmission Line

Use the defined parameters to create the microstrip transmission line. A tapered section is used to match the impedance between a 50  $\Omega$  microstrip line in which quasi-TEM and TE<sub>10</sub> mode are the dominant mode and their electric current distributions are approximate in the profile of the structure are shown.

Create the model using pcbComponent object and visualize it using show function.

```

% Create the tapered planar microstrip line trace
trace1 = traceRectangular('Length',L,'Width',W);
v = [-L/2, Wt/2, 0; -(L/2+L1), PW/2, 0; -(L/2+L1), -PW/2, 0; -L/2, -Wt/2, 0];
trace2 = antenna.Polygon('Vertices',v);

```



```

trace3 = antenna.Polygon('Vertices',-v);
Port1 = traceRectangular('Length',PL,'Width',PW,'Center',[-gndL/2+PL/2+1e-12,0]);
Port2 = traceRectangular('Length',PL,'Width',PW,'Center',[gndL/2-PL/2-1e-12,0]);
Mtrace = trace1+trace2+trace3+Port1+Port2;
    
```

In order to build the PCB model, use pcbComponent object. Mtrace created above will be the top layer on the rectangular SIW.


```

p = pcbComponent;
p.BoardThickness = h;
gnd = traceRectangular('Length',gndL,'Width',gndW,'Center',[0,0]);
p.BoardShape = gnd;
p.Layers = {Mtrace,sub,gnd};
    
```

Define feed and via locations. The FeedLocations and ViaLocations are the property with an array of four elements, in which the 1st and 2nd elements define the x and y co-ordinates, 3rd and 4th elements define the layers of connection.


```

% Define Feed location
p.FeedDiameter = PW/2;
p.FeedLocations = [-gndL/2,0,1,3;gndL/2,0,1,3];
p.ViaDiameter = 1e-3/2;
% Define Via location
offset = 0.5e-3;
viax = -L/2+offset;
viay = -W/2+offset;
for i=1:40
    viaSp = 0.5e-3;
    ViapointX(i) = viax + (i-1)*(viaSp)+(i-1)*(p.ViaDiameter);
    ViapointY(i) = viay;
    layer1(i) = 1;
    layer2(i) = 3;
    Viapoint1 = [ViapointX' ViapointY' layer1' layer2'];
end
for i=1:40
    viaSp = 0.5e-3;
    ViapointX1(i) = viax + (i-1)*(viaSp)+(i-1)*(p.ViaDiameter);
    ViapointY1(i) = -viay;
    layer11(i) = 1;
    layer21(i) = 3;
    Viapoint2 = [ViapointX1' ViapointY1' layer11' layer21'];
end
p.ViaLocations = [Viapoint1;Viapoint2];
figure; show(p);
    
```



Use the `sparameters` function to compute the s-parameters in the frequency range of 10 - 15 GHz and plot it.

```
freq = linspace(10e9,15e9,31);  
spar = sparameters(p,freq);  
figure; rfplot(spar,2,1);  
hold on; rfplot(spar,1,1);  
axis tight;
```



It is observed from the plot that the reflection coefficient S11 is less than -15 dB over the frequency band and the transmission coefficient S21 is around -0.3 dB to -0.7 dB across the entire band.

### Prototype the model using Gerber files

Gerber files are open ASCII vector format files that contain information on each physical board layer of the PCB design. Circuit board objects, like copper traces, vias, pads, solder mask and silkscreen images, are all represented by series of coordinates. These files are used by PCB manufacturers to translate the details of the design into the physical properties of the PCB.

To generate these files, two additional pieces of information is required apart from the PCB design. The first is the type of connector to be used and the second is the PCB manufacturing service/viewer service. The type of RF connector determines the pad layouts on the PCB. The RF PCB Toolbox™ provides a catalog of PCB services and RF connectors. The PCB services catalog supports, configuring the Gerber file generation process for manufacturing as well as for online viewer-only.

### Generation of Gerber files

Gerber files contains the collection of files that describe a Printed Circuit Board (PCB) . Each file describes a specific aspect of the PCB design. For example, .gtl and .gbl files contains the information about the metal regions corresponding to the signal and ground that are filled with copper traces. Similarly, .gts and .gbs files holds the information about the solder mask, which is applied to protect and insulate the metal regions. Design information is encoded into the silkscreen layer designated by .gto and .gbo files.

To understand the generation process for these files, use a PCB manufacturing service with an online viewer and render the design.

### Online viewer for Gerber files

The PCB services catalog contains different manufacturing services type which can be accessed using the object `PCBServices`. In this example, `MayhewWriter` is used to configure the Gerber file generation process and view them using the Mayhewlabs free online 3D Gerber viewer. Select an SMA edge connector from the available catalog and modify it accordingly. The PCB model, PCB services, and the RF PCB connector are used to create a `PCBWriter`.

```
s = PCBServices.MayhewWriter;
s.Filename = 'SIWMicrostripLine';
%
PW = PCBWriter(p,s);
PW.UseDefaultConnector = 0;
```

Using the above created `PCBWriter`, execute the `gerberWrite` command to generate the Gerber files for the SIW Model.

```
gerberWrite(PW)
```

The collection of files are generated and placed in a folder with the same name as assigned in the `Filename` property of the particular PCB services. This folder is located in the current working directory. The files in the folder are shown in the image below.

Name	Date modified	Type	Size
SIWMicrostripLine.dri	5/10/2021 4:12 PM	DRI File	1 KB
SIWMicrostripLine.gbl	5/10/2021 4:12 PM	GBL File	1 KB
SIWMicrostripLine.gbo	5/10/2021 4:12 PM	GBO File	138 KB
SIWMicrostripLine.gbs	5/10/2021 4:12 PM	GBS File	1 KB
SIWMicrostripLine.gpi	5/10/2021 4:12 PM	GPI File	1 KB
SIWMicrostripLine.gtl	5/10/2021 4:12 PM	GTL File	1 KB
SIWMicrostripLine.gto	5/10/2021 4:12 PM	GTO File	301 KB
SIWMicrostripLine.gts	5/10/2021 4:12 PM	GTS File	1 KB
SIWMicrostripLine.ipc	5/10/2021 4:12 PM	IPC File	1 KB
SIWMicrostripLine_1-3	5/10/2021 4:12 PM	Text Document	2 KB

If the file name is not specified then the folder name and the files in the folder are named as "untitled".

Running the above example automatically opens up the Mayhew Labs PCB manufacturing service in the default internet browser. Further to view the 3D PCB model drag and drop the gerber files as shown below.


## Step 2:

Select the layers corresponding to the gerber files

SIWMicrostripLine.gts	Top solder mask	▼
SIWMicrostripLine.ipc	No layer	▼
SIWMicrostripLine_1-3.txt	Drill	▼
SIWMicrostripLine.dri	No layer	▼
SIWMicrostripLine.gbl	Bottom copper	▼
SIWMicrostripLine.gbo	Bottom silk-screen	▼
SIWMicrostripLine.gbs	Bottom solder mask	▼
SIWMicrostripLine.gpi	No layer	▼
SIWMicrostripLine.gtl	Top copper	▼
SIWMicrostripLine.gto	Top silk-screen	▼

Done

Click on Done to view the proposed PCB design as shown below.



## Reference

- 1 Bouchra Rahal, *et.al*, "SUBSTRATE INTEGRATED WAVEGUIDE POWER DIVIDER, CIRCULATOR AND COUPLER IN [10-15] GHZ BAND", *International Journal of Information Sciences and Techniques*, DOI:10.5121/ijist.2014.4201, March, 2015.


## Model and Analyze Microstrip Interdigital Capacitor as Bandpass filter

The interdigital capacitor (IDC) is a multi-finger periodic structure and are frequently used in microstrip microwave integrated circuits for RF or microwave development. The interdigital capacitors use the capacitance that occurs across a narrow gap between conducting fingers. They are optimized based on applications.

This example shows the analysis of interdigital capacitor that shows band pass response in the frequency range of 3.5 GHz to 3.9 GHz. The capacitance is calculated in the desired range with and without de-embedding the effect of microstrip feeder line.


Create an interdigital capacitor and visualize it.

```
obj = interdigitalCapacitor;  
figure; show(obj);
```



Use the `sparameters` function to compute the s-parameters and plot it using the `rfplot` function from RF Toolbox to understand the behavior of the designed capacitor.

```
freq = linspace(2e9,8e9,51);  
spar = sparameters(obj,freq);  
figure; rfplot(spar);
```




The s-parameters plot shows that the insertion loss is minimal in the frequency range of 3.5 GHz to 3.9 GHz which exhibits band pass like behavior. The capacitor exhibits low attenuation in this frequency range.

These kinds of capacitor are used in RF couple or DC blocks where the capacitor should have minimal attenuation and reflection when the signal goes through them.

Analyze the measure of capacitor without deembedding the feeder line effect using the capacitance function from 3.5 GHz to 3.9 GHz. Use the mesh function to manually mesh the structure.


```
figure; mesh(obj, 'MaxEdgeLength', 0.0017)
```

NumTriangles : 778  
NumTetrahedra : 1584  
NumBasis : -  
MaxEdgeLength : 0.0017  
MeshMode : manual




```
freq = linspace(3.5e9,3.9e9,21);  
figure;capacitance(obj,freq,'DeEmbed',0)
```





It is observed that there is a sudden spurious spike at 3.82 GHz which is due to the effect of feeder line. Further to eliminate that effect the DeEmbed option in the capacitance method has to be enabled.

```
figure;capacitance(obj,freq,'DeEmbed',1)
```



Hence, by de-embedding the effect of feeder line it subtracts the additional phase that is added due to the feed line. The capacitance of the capacitor is around 1 pF to 1.5 pF in the frequency range of 3.5 to 3.9 GHz.

The capacitance of the capacitor can be analyzed over the desired frequency range using different options such as de-embed the effect of feeder line and include the effect of parasitics by enabling the the options in capacitance method.

### Reference

- 1 *NIHAD DIB, QIU ZHANG, ULRICH ROHDE, "NEW CAD MODEL OF THE MICROSTRIP INTERDIGITAL CAPACITOR"*, Active and Passive Electronic Components, Vol. 27, December, 2004

## Introduction to Passive Planar Spiral Inductors

This example shows you how to design, visualize, and analyze different types of spiral inductors.

The modern wireless communication system requires low cost, small size, and higher efficiency circuits design. The circuit need considerable amount of passive (inductor and capacitor) components for designing RF components like power amplifier, oscillators, microwave switches, combiners, and splitters circuits.

In radio frequency integrated circuits (RFIC) the spiral inductors dominates overall circuit performance and it is frequently used as a passive component in modern RFIC's design technology.


Here the passive planar spiral inductor is modeled and analysed. This example shows the analyses of different types of spiral inductors.

### Model Spiral Inductor


The passive spiral inductor can be realized in different structure like square, circular, hexagonal, and octagonal with multiturns. The multi-turn inductors are used for higher inductance value design.

The spiral Inductor is a two port multiturn planar inductor with multiple dielectric layers. A turn in the spiral inductor is the length of a complete 360-degree revolution.

*Square spiralInductor*




*Circular spiralInductor*



*Hexagonal spiralInductor*




*Octagonal spiralInductor*



The width and spacing of the strips in the spiral inductor are uniform throughout. You can feed the inductor in such a way that the inner end is routed out from the layer below the inductor by a via hole or the input port and the outer end or output port is extended to the end of the board at the same layer .

The figure shown below consists of four spiral inductors along with their physical parameters to model spiral inductors




### Planar Spiral Inductor in Embedded Microstrip Form with Homogeneous Substrate

Create and analyze a multiturn spiral inductor with different configurations like square, circular, hexagonal, and octagonal by changing the property `SpiralShape`. Calculate the measure of inductance at 600 MHz.

#### Square Spiral Inductor


Create and analyze a multiturn square spiral inductor.

```
Ind = spiralInductor('SpiralShape','square');  
figure; show(Ind);
```



Use the `sparameters` function to compute the s-parameters and plot it using the `rfplot` function.

```
spar = sparameters(Ind,linspace(300e6,800e6,21));  
figure;  
rfplot(spar);
```




The s-parameters plot shows that after 430 MHz the S<sub>11</sub>/S<sub>22</sub> is monotonically increasing towards 0 dB and S<sub>12</sub>/S<sub>21</sub> is decreasing accordingly. This plot tells that the energy is stored in inductor and not radiated. The behavior of S<sub>11</sub> and S<sub>21</sub> satisfies the law of conservation of energy.

Use the inductance function to plot the measure of inductance of the square spiral inductor at 600 MHz and view the mesh.

```
Ls = inductance(Ind,600e6)
```

```
Ls = 4.3114e-08
```


```
figure; mesh(Ind,'View','Metal');
```



### Circular Spiral Inductor

Create and analyze multiturn circular spiral inductor.

```
Ind = spiralInductor('SpiralShape', 'circle');  
figure; show(Ind);
```



Use the inductance function to calculate the measure of inductance of the circular spiral inductor at 600 MHz.

```
Lc = inductance(Ind,600e6)
```


```
Lc = 3.8296e-08
```

### Octagonal Spiral Inductor

Create and analyze a multiturn octagonal spiral inductor.


```
Ind = spiralInductor('SpiralShape','Octagon');  
figure; show(Ind);
```





Use the current function to plot the current distribution on the surface of the octagonal spiral Inductor.

```
figure;  
current(Ind,600e6,'scale','log10');
```



Use the inductance function to plot the measure of inductance of the octagonal spiral inductor at 600 MHz.


```
Lo = inductance(Ind,600e6)
```

```
Lo = 3.7167e-08
```

### Hexagonal spiral Inductor

Create and analyze multiturn hexagonal spiral inductor.

```
Ind = spiralInductor('SpiralShape','Hexagon');  
figure; show(Ind);
```




Use the inductance function to calculate the measure of inductance of the hexagonal spiral inductor at 600 MHz.

```
Lh = inductance(Ind,600e6)
```

```
Lh = 3.6280e-08
```

Use the charge function to plot the charge distribution on the surface of the octagonal spiral Inductor.

```
figure;  
charge(Ind,600e6,'scale','log10');
```



The Magnitude of inductance for the different configurations of the four turn spiral inductors are shown in the table below. It is observed that the inductance of the square spiral inductor is more when compared to the rest of the spiral shapes.

Sl.no	Spiral Shape	Inductance (nH)
1	Square	43.11
2	Circle	38.29
3	Octagon	37.67
4	Hexagon	36.28

The magnitude of the inductance increases as the length of the inductor and area increases. It is evident from the figures shown for the four configurations of spiral inductors, that the inductance of spiral inductors increases with the increase in trace length and area of the inductors such that: Square > Circular > Octagonal > Hexagonal. The circular and square structures are most popular of the spiral inductors because of less complex analytical design and ease of fabrication. However, other polygonal spirals have also been used in circuit design. Some designers prefer polygons with more than four sides to improve performance of quality factor of the spiral inductors.

## Reference

- 1 *Sunderarajan S. Mohan, Maria del Mar Hershenson, Stephen P. Boyd, and Thomas H. Lee, "Simple Accurate Expressions for Planar Spiral Inductances," IEEE Journal Of Solid-State Circuits, Vol. 34, No. 10, pp. 1419-1424, October 1999.*

## Design and Analysis of Hairpin Micro-Strip Line Bandpass Filter

This example shows how to design and analyze Hairpin filter in RF PCB Toolbox™.

Most wireless applications require high quality, low cost, and compact sized RF or microwave filters. Planar filters can be used to fulfil this purpose. Among planar filters hairpin filters are available in reduced size as compared to parallel coupled line structures. These hairpin filters may conceptually be obtained by folding the resonators of parallel-coupled half-wavelength resonator filters. The Hairpin filters are widely used as bandpass filters in transmitters and receivers at various frequencies.


### Create Variables

```
N = 3;  
Ripple = 0.1;  
BandWidth = 20;  
Z0 = 50;  
f = linspace(1.5e9,2.5e9,51);  
EpsilonR = 6.15;  
Height = 1.27e-3;
```

### Tapped-Input Hairpin Filter


Use the `filterHairpin` object to create the hairpin filter and visualize it.

```
filter = filterHairpin;  
figure;  
show(filter);  
view(-37,30);
```



Use the design function to design a 3rd order hairpin filter with a RippleFactor of 0.1 dB and 20% fractional bandwidth and visualize it.


```
filter.FilterOrder = N;
filter.Height = Height;
filter.Substrate.EpsilonR = EpsilonR;
filter = design(filter,2e9,'FBW',BandWidth,'RippleFactor',Ripple);
figure;
show(filter);
view(-37,35);
```



Use the `sparameters` function to calculate the s-parameters for the hairpin filter and plot it using `rfplot` function.

```
spar = sparameters(filter,f);  
figure;  
rfplot(spar);
```






The result shows that the filter resonates close to the design frequency of 2 GHz. The design function uses analytical equations and the spacing between the resonators is generally calculated using the practical approach. Hence the design function sets the spacing to 0.5 mm between all the resonators. To get the accurate results, the spacing between the resonators needs to be adjusted. Increase the bandwidth of the filter by reducing the spacing between the resonators.

Set the Spacing between the resonators to 0.05 mm.

```
filter.Spacing = [0.05e-3 0.05e-3];
```

Use the `sparameters` function to calculate the s-parameters for the hairpin filter and plot it using `rfplot` function.

```
spar = sparameters(filter,f);
figure;
rfplot(spar);
```




### Shifting Resonators and Feed Lines

You can also shift the resonators and the feeds using the `ResonatorOffset` and `FeedOffset` properties of `filterHairpin`.

Change the `ResonatorOffset` and `FeedOffset` and visualize it.

```
filter.ResonatorOffset = [0e-3 3e-3 5e-3];  
filter.FeedOffset(2) = filter.FeedOffset(2) + 5e-3;  
figure;  
show(filter);  
view(-37,37);
```




### Comparing Results with the Paper

Change the dimensions of the filter as given in [1]. Change the spacing on the filterHairpin and set the spacing to 0.4 mm and set the length of the U-Shaped resonator to 2 mm.

```


filter.ResonatorOffset = [0e-3 0e-3 0e-3];
filter.Resonator(1).Length(1) = 20.4e-3;
filter.Resonator(1).Length(2) = 2e-3;
filter.Resonator(1).Length(3) = 20.4e-3;
filter.Spacing = [0.4e-3 0.4e-3];
filter.PortLineWidth = 1.85e-3;
filter.FeedOffset = [-4.565e-3 -4.565e-3];
figure;
show(filter);
view(-37,29);

```




Use the `sparameters` function to calculate the s-parameters for the hairpin filter and plot it using `rfplot` function.

```
spar = sparameters(filter,f);  
figure;  
rfplot(spar);  
title('S-Paramters for the Hairpin Filter');
```



Plot the absolute values of S21 over the frequency range using `rfplot` function.


```
figure;  
rfplot(spar,2,1,'abs');  
title('Magnitude - S21');
```



### Coupled-Input Hairpin Filter


Use the `filterHairpin` object to create the hairpin filter. Change the `FeedType` property to `Coupled` to create the hairpin filter with a coupled Input.

```
filterC = filterHairpin;  
filterC.FeedType = 'Coupled';  
filterC.FeedOffset = [0 0];  
figure;  
show(filterC);  
view(-37,35);
```



Use the `sparameters` function to calculate the s-parameters for the hairpin filter and plot it using `rfplot` function. The frequency range for the simulation is taken as 1.5 GHz to 2.5 GHz with 301 points. As this below simulation takes more time to run, load the sparameters from the s2p file and then plot the S-Parameters.

```
sparC = sparameters('sparams.s2p');  
figure;  
rfplot(sparC);
```



The result shows narrow band resonances at 1.7 GHz, 1.85 GHz, and 2 GHz. For this type of Input, the ResonatorOffset and FeedOffset can also be used to create different types of Hairpin Filters.

### References

- 1 Nikunj Parikh , Pragma Katore , Ketan Kathal , Nandini Patel , Gaurav Chaitanya, Design and Analysis of Hairpin Micro-Strip Line Band Pass Filter.



## Analyzing Crosstalk Between PCB Traces


This example shows how to create a pair of close traces using `traceLine` object and performs analysis on those traces to calculate the amount of unwanted coupling to the passive trace.

### Create traces

```

trace1 = traceLine;
trace1.Length = [10 5*sqrt(2) 10 5*sqrt(2) 10]*1e-3;
trace1.Angle = [0 45 0 -45 0];
trace1.Width = 3e-3;
trace1.Corner = "Miter";
trace2 = copy(trace1);
trace2.Length = [11 6*sqrt(2) 6 6*sqrt(2) 11]*1e-3;
trace2 = translate(trace2, [0, -5e-3, 0]);
trace = trace1 + trace2 ;
figure;
show(trace);

```




### Create PCB Component

Use the `pcbComponent` to create the PCB stack for the shape. For creating a PCB stack, the trace created above is used as a top layer. The middle layer is a dielectric and the bottom layer is a ground plane. Use the `dielectric` object to create the Teflon dielectric. Use `traceRectangular` object to create a rectangular ground plane. Assign the trace, dielectric(d), and groundplane to the `Layers` property of the `pcbComponent`. Assign the `FeedLocations` at the ends of the trace and visualize it.

```

pcb = pcbComponent;
d = dielectric('Teflon');
groundplane = traceRectangular('Length', 40e-3, 'Width', 40e-3, 'Center', [40e-3/2, 0]);
pcb.Layers = {trace,d,groundplane};
pcb.FeedLocations = [0,0,1,3;40e-3,0,1,3;40e-3,-5e-3,1,3;0e-3,-5e-3,1,3];
pcb.BoardShape = groundplane;
pcb.FeedDiameter = trace1.Width/2;
figure;
show(pcb);

```




Use current function to plot the current distribution on the trace

```


figure;
current(pcb,1e9,'scale','log');

```




Use the layout function to show the layout of the pcbComponent.

```
figure;  
layout(pcb);
```



Use `sparameters` function to calculate the leakage power from Trace 1 to Trace 2.

```
spar = sparameters(pcb,linspace(0.1e9,10e9,51));
figure;
rfplot(spar,2,1);
hold on
rfplot(spar,3,1);
rfplot(spar,4,1);
```




The S<sub>31</sub> shows the power coupled from the top trace to the bottom trace. This is the unwanted coupling from the top line to the bottom line and must be reduced. To reduce the coupling, increase the spacing between the traces.

### Increase the Spacing Between Traces

```

tracel = traceline;
tracel.Length = [10 5*sqrt(2) 10 5*sqrt(2) 10]*1e-3;
tracel.Angle = [0 45 0 -45 0];
tracel.Width = 3e-3;
tracel.Corner = "Sharp";
trace2 = copy(tracel);
trace2.Length = [11 6*sqrt(2) 6 6*sqrt(2) 11]*1e-3;
trace2 = translate(trace2, [0, -10e-3, 0]);
trace = tracel + trace2 ;
figure;
show(trace);


```



### Create PCB Component


Update the properties of the created earlier and visualize it.

```
groundplane = traceRectangular('Length', 40e-3, 'Width', 40e-3, 'Center', [40e-3/2, 0]);  
pcb.Layers = {trace, d, groundplane};  
pcb.FeedLocations = [0, 0, 1, 3; 40e-3, 0, 1, 3; 40e-3, -10e-3, 1, 3; 0e-3, -10e-3, 1, 3];  
figure;  
show(pcb);
```



Use current function to plot the current distribution on the trace.


```
figure;  
current(pcb,1e9,'scale','log');
```



Use the layout function to show the layout of the pcbComponent.


```
figure;  
layout(pcb);
```





Use `sparameters` function to calculate the leakage power from Trace 1 to Trace 2.

```
spar = sparameters(pcb,linspace(0.1e9,10e9,101));
figure;
rfplot(spar,2,1);
hold on
rfplot(spar,3,1);
rfplot(spar,4,1);
```




When the spacing between the traces is doubled to 10 mm, the coupling also reduces by around 10 dB and reaches to less than -25 dB.

### Plot the Crosstalk Induced Voltage

Define a pulse signal with rise time and fall time and use the `timeresp` function to plot the output signal at port 2 for the input pulse signal.

```
sampleTime = 1e-9;
t = (0:999)*sampleTime;
input = [0.05*(0:20)'; ones(1,78)'; 0.05*(20:-1:0)'; zeros(1,80)'];
input = repmat(input,5,1);
fit = rationalfit(spar);
output = timeresp(fit(3,1),input,sampleTime);
figure;
yyaxis left;
plot(t,input);
yyaxis right;
plot(t,output);
title('Crosstalk between the Traces');
xlabel('Time (sec)');
ylabel('Voltage (volts)');
legend('Vinput', 'Output', 'Location', 'SouthWest');
```



The output signal magnitude is around 0.1 mV as seen from the result.

### References

- 1) <https://incompliancemag.com/article/visualizing-crosstalk-in-pcbs/>
- 2) Basic Principles of Signal Integrity, Altera

## Create and Analyze PCB Interconnects using Custom Traces

This example shows how to use the custom traces `traceLine` and `tracePoint` in RF PCB Toolbox and create PCB traces with different shapes and orientations. The `traceLine` uses the lengths and angles properties to create a trace and the `tracePoint` uses points to create the trace. For both the traces, corner property can be set to `Sharp`, `Miter`, and `Smooth` to create specific corners at all the bends.

### Line Trace

Use the `traceLine` object to create a line trace. Observe that the `traceLine` has `Length`, `Angle`, `Width`, and `Corner` as properties. The line trace is a combination of all the rectangles which are created based on the `Length`, `Angle`, and the `Corner` property is used to specify the type of corner at each bend. You can specify the corners as `sharp`, `miter`, or `smooth`. By default the `Corner` property is set to `Sharp`.


```
trace = traceLine

trace =
  traceLine with properties:

    Name: 'mytraceLine'
  StartPoint: [0 0]
    Length: [0.0200 0.0200 0.0200 0.0150]
    Width: 0.0050
    Angle: [90 0 -90 45]
    Corner: "Sharp"
```


Visualize the `traceLine` using the `show` function.

```
figure;
show(trace);
```



Change the Length and Angle property on the traceLine and set the Corner to smooth.

```
trace.Length = [10 5*sqrt(2) 10 5*sqrt(2) 10]*1e-3;  
trace.Angle = [0 45 0 -45 0];  
trace.Width = 3e-3;  
trace.Corner = "smooth";  
figure;  
show(trace);
```




The output shows that the trace is created using the angle specified for each corresponding length input. The corners are specified as smooth and hence it creates curved edges.

### Extend the Line Trace

Add a 15 mm line perpendicular to the earlier trace. So add 15 mm to the Length property and 90 deg to the Angle property of the trace and set the corner to Miter .

```
trace.Length = [10 5*sqrt(2) 10 5*sqrt(2) 10 15]*1e-3;  
trace.Angle = [0 45 0 -45 0 90];  
trace.Width = 3e-3;  
trace.Corner = "Miter";  
figure;  
show(trace);
```




The output shows that the trace is created using the angle specified for each corresponding length input. The corners are specified as Miter and hence it creates mitered edges. Observe that the ends of the trace are at [0,0] and [40,15] mm where the feed points are assigned in the next section.

### Create PCB Component

Use the `pcbComponent` to create the PCB stack for the shape. For creating a PCB stack, use the trace created as the top layer. The middle layer is a dielectric and the bottom layer is ground plane. Use the `dielectric` object to create the FR4 dielectric. Use `traceRectangular` object to create a rectangular ground plane. Assign the `trace`, `dielectric(d)`, and `groundplane` to the `Layers` property on the `pcbComponent`. Assign the `FeedLocations` at the ends of the trace and visualize it.


```
pcb = pcbComponent;
d = dielectric('FR4');
groundplane = traceRectangular('Length', 60e-3, 'Width', 30e-3, 'Center', [60e-3/2, 0]);
pcb.Layers = {trace, d, groundplane};
pcb.BoardShape = groundplane;
pcb.FeedDiameter = trace.Width/2;
pcb.FeedLocations = [0, 0, 1, 3; 40e-3, 15e-3, 1, 3];
figure;
show(pcb);
```



Use `sparameters` to calculate the s-parameters of the trace and plot it using `rfplot` function.

```
spar = sparameters(pcb,linspace(1e9,5e9,51));  
figure;  
rfplot(spar);
```






### Point Trace

Use the tracePoint object to create a Point trace. Observe that the tracePoint has TracePoints, Width, and Corner as properties. Based on the Points, the tracePoint creates the trace and the Corner property is used to specify the type of corner at each bend i.e. you can specify either sharp, miter or smooth. Change the TracePoints and set the corner property to Miter


```
trace = tracePoint;
trace.TracePoints = [0 0;5 0;10 5;15 5;20 0;25 0]*1e-3;
trace.Corner = "Miter";
figure;
show(trace);
```



### Extend the trace

Add an additional L-Shaped trace to the earlier trace so that the feed points are aligned to the same edge. Add two points in the TracePoints property as shown below. Set the Corner to Miter.


```
trace.TracePoints = [0 0;5 0;10 5;15 5;20 0;25 0;25 15;0 15]*1e-3;  
trace.Corner = "Miter";  
figure;  
show(trace);
```



### Create PCB Component


Use the `pcbComponent` to create the PCB stack for the shape. For creating a PCB stack, use the trace created as a top layer. The middle layer is a dielectric and the bottom layer is ground plane. Use the `dielectric` object to create the FR4 dielectric. Use `traceRectangular` object to create a rectangular ground plane. Assign the trace, dielectric(d) and `groundplane` to the `Layers` property on the `pcbComponent`. Assign the `FeedLocations` at the ends of the trace and visualize it.

```
pcb = pcbComponent;
d = dielectric('FR4');
groundplane = traceRectangular('Length', 40e-3, 'Width', 40e-3, 'Center', [40e-3/2, 0]);
pcb.Layers = {trace, d, groundplane};
pcb.FeedLocations = [0, 0, 1, 3; 0e-3, 15e-3, 1, 3];
pcb.BoardShape = groundplane;
pcb.FeedDiameter = trace.Width/2;
figure;
show(pcb);
```




Use current function to plot the current distribution on the trace

```
figure;  
current(pcb,1e9);
```



Use charge function to plot the charge on the trace

```
figure;  
charge(pcb,1e9);
```




## Analyzing High Frequency Currents and Techniques for Routing PCB Traces

This example shows how to use the RF PCB Toolbox to analyze the surface currents on the trace and focuses on the routing discipline that needs to be followed while designing the Mixed Signal PCB layout.

### Build Trace

To analyze the currents on the trace, build a trace using `traceLine` object and visualize it.

```
trace = traceLine;
trace.StartPoint = [0 -20e-3];
trace.Length = [10 5*sqrt(2) 10 5*sqrt(2) 20 40 50]*1e-3;
trace.Angle = [0 45 0 -45 0 90 180];
trace.Width = 3e-3;
trace.Corner = "Sharp";
figure;
show(trace)
```




### Create PCB Component of Trace

Use the `pcbComponent` object to create the PCB stack up for the trace. Use the `dielectric` object function and create a teflon dielectric. Use the `traceRectangular` object to create the ground plane for the PCB. Assign the trace, dielectric, and the groundplane to the `Layers` property of the `pcbComponent`. Visualize the PCB stack using the `show` function.

```

pcb = pcbComponent;
d = dielectric('Teflon');
groundplane = traceRectangular('Length', 60e-3, 'Width', 100e-3, 'Center', [60e-3/2,0]);
pcb.Layers = {trace,d,groundplane};
pcb.FeedLocations = [0e-3, -20e-3, 1, 3; 0e-3, 20e-3, 1, 3];
pcb.BoardShape = groundplane;
pcb.FeedDiameter = trace.Width/2;
pcb.ViaDiameter = trace.Width/2;
figure;
show(pcb);

```



### Surface Currents on PCB Trace and Ground Plane

Electromagnetic simulations for signals of different frequencies are shown here to visualize the paths in which the currents flow. The forward signal currents for each case are constrained to the trace. However, the return ground currents can flow anywhere on the ground plane.


Use the `current` function to plot the current distribution at 100 MHz.

```

figure;
current(pcb,0.1e9,'scale','log');
title('Current at 100 MHz');

```






The figure shows that there is a red line between the two feed locations i.e, Source and Load, which means the current on the ground plane chooses the path of least resistance and returns directly from the source to the load. A small amount of the ground current flows along the signal path (light red), while even smaller amounts flow in between these two paths as indicated by the blue color of much of the plane.

As the frequency increases, the return currents on the ground plane flow exactly beneath the trace.

Use the current function to plot the current distribution at 500 MHz.


```
figure;
current(pcb,0.5e9,'scale','log');
title('Current at 500 MHz');
```



This figure shows that the return current on the ground plane flows only along the trace and doesn't flow between the source and load. As the frequency increases, the return currents on the ground plane flow exactly beneath the trace and this fact can be seen in the subsequent figures.

Use the `current` function to plot the current distribution at 2 GHz.

```
figure;  
current(pcb,2e9,'scale','log');  
title('Current at 2 GHz');
```



This results shows that the high frequency current on the ground plane flows beneath the trace and the routing of the PCB traces on the board becomes very critical and must be followed carefully to avoid cross talk with other traces.


### Routing with Gap in Ground Plane

For mixed signal PCB layout, separate the ground plane into analog ground and digital ground to reduce the interference between these traces. But splitting the ground plane and not following the routing discipline causes severe problems in the mixed signal PCB design. To understand this, use the same trace created in the above section but with a slit in the ground plane

Use the `pcbComponent` object to build the PCB Stack of the trace. Use `traceRectangular` to build two rectangular traces and subtract these traces from the ground plane to create the slit in the ground plane and visualise it.

```
pcb = pcbComponent;
d = dielectric('Teflon');
groundplane1 = traceRectangular('Length', 60e-3, 'Width', 100e-3, 'Center', [60e-3/2, 0]);
slit1 = traceRectangular('Length', 1e-3, 'Width', 48e-3, 'Center', [20e-3, 27e-3]);
slit2 = traceRectangular('Length', 1e-3, 'Width', 50e-3, 'Center', [20e-3, -27e-3]);
groundplane = groundplane1 - slit1 - slit2;
pcb.Layers = {trace, d, groundplane};
pcb.FeedLocations = [0e-3, -20e-3, 1, 3; 0e-3, 20e-3, 1, 3];
pcb.BoardShape = groundplane1;
pcb.FeedDiameter = trace.Width/2;
pcb.ViaDiameter = trace.Width/2;
```


```
figure;
show(pcb);
```



The slit in the ground plane is such that the trace above crosses the slit perpendicularly as shown in the figure.

Use the `current` function to plot the current distribution at 5 GHz. As there is a slit in the ground plane the currents cannot return directly beneath the trace and takes a longer route to return through the small joint where both the ground planes are attached.

```
figure;
current(pcb,5e9,'scale','log');
title('Current at 5 GHz with Slit Ground Plane');
```



The result shows that the return currents take a longer route and might interfere with the components placed in that area and introduce noise at that component. So even if the ground is separated as an analog and digital ground, the routing of the traces is very important to design a PCB with less crosstalk and noise.

### References

- 1 Mark Fortunato, Successful PCB Grounding with Mixed-Signal Chips - Follow the Path of Least Impedance
- 2 Henry W. Ott, Partitioning and Layout of a Mixed-Signal PCB.

## Introduction to Equal and Unequal Split Wilkinson Power Splitter


This example shows you how to design, analyze, and compare an equal and unequal Wilkinson splitter.

A Wilkinson power splitter is a device that is matched at all ports. This splitter is lossless when excited at the input port and the output ports are isolated. You can also make this splitter to perform arbitrary power division which is the unequal Wilkinson splitter.

### Equal Split Wilkinson with Rectangular Shape

Use the `wilkinsonSplitter` object to create an equal split Wilkinson splitter. For this case the reference impedance is 50 Ohms. The split lines have an impedance of 70.7 ohms and the Isolation Resistor between the two output ports is 100 Ohms. The split lines have the same width and have a length equal to a quarter wavelength. The port lines have an impedance of 50 Ohms.


```
splitter = wilkinsonSplitter;
figure;
show(splitter);
```



The `Shape` property on the `wilkinsonSplitter` is used to create the geometry with rectangular bends or circular rings. The default `Shape` property is `Rectangular` which creates split lines with rectangular bends.

Use the `sparameters` function to compute the S-parameters and plot it using the `rfplot` function.


```
spar = sparameters(splitter,linspace(1e9,5e9,31));
figure;
rfplot(spar);
```



The result shows an S<sub>11</sub> value of -25 dB at 1.8 GHz. The S<sub>21</sub> and S<sub>31</sub> are overlapping each other with a value of -3.1 dB. This overlap indicates an equal power division to the output ports. The Isolation is also higher than -25 dB at 1.8 GHz. The output ports are matched over the entire simulated frequency range and S<sub>22</sub> and S<sub>33</sub> value is higher than -25 dB at 1.8 GHz.

Use the design method to design Wilkinson splitter at 2 GHz and visualize it.


```
splitter = design(splitter,2e9);
figure;
show(splitter);
```



Compute and plot the S-parameters of the 2 GHz splitter.

```
spar = sparameters(splitter, linspace(1e9, 3e9, 31));  
figure;  
rfplot(spar);
```






The result shows an S<sub>11</sub> value of -30 dB close to the design frequency of 2 GHz. The S<sub>21</sub> and S<sub>31</sub> overlaps each other indicating an equal power division to output ports. The isolation is also higher than -30 dB at the design frequency. The output ports are matched over the entire simulated frequency range and the S<sub>22</sub> and S<sub>33</sub> value is higher than -20 dB at the design frequency.

Use the current function to plot the current distribution on the surface of the Wilkinson power splitter.


```
figure;
current(splitter,2e9);
```



### Equal Split wilkinson with Circular Shape

Use the Shape property of the Wilkinson to change the splitter shape to Circular.


```
splitter.Shape = 'Circular';  
figure;  
show(splitter);
```



For a reference impedance of 50 Ohms, the input PortLine and two output PortLines have an impedances of 50 ohms. Both the SplitLines have the same width and the same impedance of 70.7 ohms. The resistance between the two lines is represented by the 100 ohm load. Since the Shape property is Circular, the SplitLines are created using an annular ring.

Compute and plot the S-parameters of the splitter.


```
spar = sparameters(splitter, linspace(1e9, 5e9, 31));
figure;
rfplot(spar);
```



The result shows an S<sub>11</sub> value of -25 dB at 2 GHz. The S<sub>21</sub> and S<sub>31</sub> overlap each other with a value of -3.1 dB at the resonant frequency. This indicates an equal power division to output ports. The Isolation is also better than -25 dB at 1.8 GHz. The output ports are matched over the entire simulated frequency range and the S<sub>22</sub> and S<sub>33</sub> value is higher than -25 dB at 1.8 GHz.


Design the Wilkinson splitter at 4 GHz.

```
splitter = design(splitter,4e9);
figure;
show(splitter);
```



Compute and plot the S-parameters.


```
spar = sparameters(splitter, linspace(3e9, 5e9, 31));  
figure;  
rfplot(spar);
```



The result shows an S<sub>11</sub> value of -20 dB close to the design frequency of 4 GHz. The S<sub>21</sub> and S<sub>31</sub> overlap on each other indicating an equal power division to output ports. The Isolation is also better than -20 dB at the design frequency. The output ports are matched over the entire simulated frequency range and the S<sub>22</sub> and S<sub>33</sub> value is -20 dB at the design frequency.

Compute and plot the current distribution on the surface of the splitter.

```
figure;
current(splitter,4e9);
```




### Design and Analysis of the Unequal Split wilkinson Power Splitter

The unequal Wilkinson splitter divides the power unequally to the output ports. Because of the unequal division, the impedance of both the arms of the power splitter and width of the split lines are different. Two more microstrip lines are used to match the split lines to the reference impedance. Both the SplitLine and the MatchLine are quarter wavelength long.

Use the wilkinsonSplitterUnequal object to create a Wilkinson splitter and use the show function to visualize it.


```
splitter = wilkinsonSplitterUnequal;
figure;
show(splitter);
```



Design the Wilkinson splitter at 2 GHz and specify the power ratio between the ports as 2.


```
splitter = design(splitter,2e9,'PowerRatio',2);  
figure;  
show(splitter);
```





Compute and plot the S-parameters.


```
spar = sparameters(splitter, linspace(1e9, 3e9, 31));  
figure;  
rfplot(spar);
```



The result shows an S<sub>11</sub> value higher than -30 dB close to the design frequency of 2 GHz. The S<sub>21</sub> value is close to the expected value of -1.76 dB and S<sub>31</sub> value is close to the expected value of -4.77 dB. These values indicate an unequal division to output ports. The Isolation is also higher than -30 dB at the design frequency. The output ports are matched over the entire simulated frequency range and S<sub>22</sub> and S<sub>33</sub> value is better than -20 dB at the design frequency.


Compute and plot the current distribution on the surface of the Wilkinson power splitter.

```
figure;
current(splitter,2e9);
```




Change the PowerRatio to 4 in the design method.

```
splitter = design(splitter,2.5e9,'PowerRatio',4);  
figure;  
show(splitter);
```



Computer and plot the S-parameters.


```
spar = sparameters(splitter, linspace(1e9, 4e9, 31));  
figure;  
rfplot(spar);
```



The result shows an  $S_{11}$  value higher than -30 dB close to the design frequency of 2.5 GHz. The  $S_{21}$  value is close to the expected value of -0.97 dB and  $S_{31}$  value is close to the expected value of -6.99 dB. These values indicate an unequal division to output ports with the power ratio of 4. The Isolation is also higher than -20 dB at the design frequency. The output ports are matched over the entire simulated frequency range and  $S_{22}$  and  $S_{33}$  value is better than -15 dB at the design frequency.

Compute and plot current distribution on the surface of the Wilkinson power splitter.

```
figure;
current(splitter,2.5e9);
```




## Introduction to 4-Port Couplers

This example shows how to design and analyze 4-Port Couplers.

4-Port couplers have a through port, coupled port, and an isolated port. For the equal split couplers, power is evenly split between the through port and the coupled port and the ideal coupling factor is 3 dB. No power is coupled to the isolated port. In this example, you will design and analyze a Branchline coupler and Ratrace coupler.


### Design and Analyze the Branchline Coupler

The Branchline coupler is a 3-dB coupler and divides power equally between the through and coupled arms. It is also called Quadrature Hybrid because of the 90 degree phase difference in the outputs from the through and coupler arms. With all ports matched, power entering port 1 is evenly divided between ports 2 and 4, with a 90 degree phase shift between the outputs. No power is coupled to the Port 3 (the isolated port).



Use the object `couplerBranchline` to create a Branchline coupler and visualize it.

```
coupler = couplerBranchline;
figure;
show(coupler);
```




The `Height` property controls the substrate thickness for the RF PCB Catalog elements. Changing the `Height` property changes the substrate thickness.

Change the `Height` property of the Branchline coupler to 0.508 mm . Use the `design` function to design the Branchline coupler at 3 GHz and visualize it.


```
coupler.Height = 0.508e-3;  
coupler = design(coupler,3e9);  
figure;  
show(coupler);
```





Use the `sparameters` function to calculate the S-Parameters and plot it using the `rfplot` function.


```
spar = sparameters(coupler, linspace(1e9, 5e9, 31));  
figure;  
rfplot(spar);
```



As there are 16 curves in the result, let us analyze the result in three different parts.

#### Plot Return Loss Values at All Ports

```
figure;
rfplot(spar,1,1);
hold on;
rfplot(spar,2,2);
hold on;
rfplot(spar,3,3);
hold on;
rfplot(spar,4,4);
hold off;
```




The result shows that all the ports are a good match at 3 GHz and the value of S<sub>11</sub>, S<sub>22</sub>, S<sub>33</sub>, and S<sub>44</sub> is close to -30 dB.

### Plot S-Parameters When Input is Applied at Port 1

Analyze the values of S<sub>21</sub>, S<sub>31</sub>, and S<sub>41</sub> to understand the behavior of Branchline coupler when input is applied to port 1.


```
figure;
rfplot(spar,2,1);
hold on;
rfplot(spar,3,1);
hold on;
rfplot(spar,4,1);
hold off;
```



The result shows that the power is equally divided between Port 2 and Port 4. Port 3 is isolated.

Plot the phase of the S<sub>21</sub> and S<sub>41</sub> to understand the phase different between the output ports.

```
figure,rfplot(spar,2,1,'angle');  
hold on  
rfplot(spar,4,1,'angle');  
hold off;
```




The result shows that the phase difference between the output ports is close to 90 degrees at the design frequency. Hence, the outputs at Port 2 and Port 4 is out of phase by 90 degrees when the input is applied to Port 1.

### Plot S-Parameters When Input is Applied at Port 3

Analyze the values of S13, S23, and S43 to understand the behavior of Branchline coupler when input is applied to Port 3.


```
figure;
rfplot(spar,2,3);
hold on;
rfplot(spar,4,3);
hold on;
rfplot(spar,1,3);
hold off;
```



The result shows that the power is equally divided to Port 2 and Port 4. Port 1 is isolated.

Plot the phase of the S<sub>23</sub> and S<sub>43</sub> to understand the phase different between the output ports.


```
figure,  
rfplot(spar,2,3,'angle');  
hold on  
rfplot(spar,4,3,'angle');  
hold off;
```



The result shows that the phase difference between the output ports is close to 90 degrees at the design frequency of 3 GHz. Hence, when the input is applied to Port 3, the output at Port 2 and Port 4 is out of phase by 90 degree.

Use the current method to visualize the current distribution on the Branchline coupler


```
figure;  
current(coupler,3e9);
```



### Design and Analyze Ratrace Coupler


The Ratrace Coupler is a 4-port coupler and is also called a 180 deg ring hybrid as the output ports exhibit a phase shift of 180 deg. With reference to the 180 deg hybrid shown below, a signal applied at Port 3 will be evenly split into two in-phase components at Ports 2 and 4. Port 1 is isolated. If the input is applied at Port 1, signal is equally split into two components with a 180 deg phase difference at Ports 2 and 4. Port 3 is isolated. When operated as a combiner, with input signals applied at Ports 2 and 4, the sum of the inputs forms at Port 3, while the difference forms at Port 1. Hence Port 3 and 1 are referred to as the sum and difference ports respectively.






Use the `couplerRatrace` object to create a Ratrace coupler and visualize it.

```
coupler = couplerRatrace;  
figure;  
show(coupler);
```




Change the Height property for the Ratrace coupler. Use the design function to design the Ratrace coupler at 3 GHz and visualize it.

```
coupler.Height = 0.762e-3;  
coupler = design(coupler,3e9);  
figure;  
show(coupler);
```



Use the `sparameters` function to calculate the S-Parameters for the Ratrace coupler and plot it using the `rfplot` function.


```
spar = sparameters(coupler, linspace(1e9, 5e9, 31));  
figure;  
rfplot(spar);
```



As there are 16 curves in the result, let us analyze the result in three different parts.

#### Plot Return Loss Values at All Ports

```
figure;
rfplot(spar,1,1);
hold on;
rfplot(spar,2,2);
hold on;
rfplot(spar,3,3);
hold on;
rfplot(spar,4,4);
hold off;
```




The result shows that all the ports are a good match at 3 GHz and the values of S<sub>11</sub>, S<sub>22</sub>, S<sub>33</sub>, and S<sub>44</sub> is higher than -30 dB.

### Plot S-Parameters When Input is Applied at Port 1

Analyze the values of S<sub>21</sub>, S<sub>31</sub>, and S<sub>41</sub> to understand the behavior of Ratrace coupler when input is applied to port 1.


```
figure;
rfplot(spar,2,1);
hold on;
rfplot(spar,3,1);
hold on;
rfplot(spar,4,1);
hold off;
```



The result shows that the power is equally divided between Port 2 and Port 4. Port 3 is isolated when the input is applied to Port 1.

Plot the phase of S<sub>21</sub> and S<sub>41</sub> to understand the phase difference between the output ports.

```
figure,rfplot(spar,2,1,'angle');  
hold on  
rfplot(spar,4,1,'angle');  
hold off;
```




The result shows that the phase difference between the output ports is close to 180 degrees at the design frequency. Hence, when the input is applied at Port 1, the output at Port 2 and Port 4 is out of phase by 180 degrees.

### Plot S-Parameters When Input is Applied at Port 3

Analyze the values of  $S_{23}$ ,  $S_{43}$ , and  $S_{13}$  to understand the behavior of Ratrace coupler when input is applied to Port 3.

```
figure;
rfplot(spar,2,3);
hold on;
rfplot(spar,4,3);
hold on;
rfplot(spar,1,3);
hold off;
```




The result shows that the power is equally divided between Port 2 and Port 4. Port 1 is isolated when the input is applied to Port 3.

Plot the phase of the S<sub>23</sub> and S<sub>43</sub> to understand the phase difference between the output ports.

```
figure,rfplot(spar,2,3,'angle');  
hold on  
rfplot(spar,4,3,'angle');  
hold off;
```






The result shows that the phase difference between the output ports is close to 0 degrees at the design frequency of 3 GHz. Hence, when the input is applied at Port 3, the output at Port 2 and Port 4 is in phase.

Use the current method to visualize the current distribution on the Ratrace coupler

```
figure;  
current(coupler,3e9);
```




## Design Two-Stage Low Noise Amplifier Using Microstrip Transmission Line Matching Network

This example shows how to use the RF PCB Toolbox™ shapes and the `pcbComponent` object functionality to design a two-stage low noise amplifier (LNA) for a wireless local area network (WLAN) with an input and output matching network (MNW) to maximize the power delivered to the 50 ohm load.

Designing an input and output MNW is an important part of an amplifier design. The amplifier in this example has high gain and low noise. This example uses the `traceTee` RF PCB shape to create the input and output matching network.

The diagram shows the matching network topology used for both the input and output matching networks. The lengths and widths given in the paper[1] are for the lines TL2 and TL1 for Input MNW and TL3 and TL4 for the output MNW. Additional Port lines will be added as shown in the figure which will have same length as the series transmission lines (TL2 and TL3) so that we can connect the ports and analyze the structure. As the MNW forms the tee shape at both input and output, you can use the `traceTee` shape for creating the MNWs.



### Define Microstrip Transmission Line Parameters

The microstrip transmission line parameters are chosen as follows.

Physical Height of conductor or dielectric thickness — 1.524 mm

Relative permittivity of dielectric — 3.48

Loss angle tangent of dielectric — 0.0037

Physical thickness of microstrip transmission line — 3.5 um

### Create the Variables

The variables below are for creating the input and output MNWs. The `Length_Line1` and `Length_Line2` store the length of the series matching line and the length of the portline. The paper

gives the TL2 as 14.7 mm and hence the portline at input also is taken as 14.7 mm. Hence the Length\_Line1 becomes 29.4 mm. At the output MNW, the line TL3 is 22.5 mm and hence the portline at the output is also 22.5 mm. Hence Length\_Line2 becomes 45 mm. The stub lengths Length\_Stub1 and Length\_Stub2 are also taken from the paper[1].

```
Length_Line1 = 29.4e-3; % Length of the Input Matching Network  
Length_Stub1 = 8.9e-3; % Length of the Stub
```

```
Length_Line2 = 45e-3; % Length of the Output Matching Network  
Length_Stub2 = 5.66e-3; % Length of the Stub  
Width_Line = 3.5e-3; % Width of the line
```

```
EpsilonR = 3.48; % Dielectric EpsilonR  
Height = 1.524e-3; % Height of the Substrate  
LossTangent = 0.0037; % Loss Tangent of the Substrate
```

```
fmin = 2e9;  
fmax = 3e9;  
points = 50;  
freq = linspace(fmin, fmax, points);
```


Use the nport function from RF Toolbox to read the sparameters of the amplifier from an s2p file for the amplifier and store it in the variables Amp1 and Amp2.

```
Amp1 = nport('f551432p.s2p');  
Amp2 = nport('f551432p.s2p');
```


### **Design Input Matching Network Using tracetee shape**

The input matching network consists of one shunt stub and one series microstrip transmission line. The dimensions of the series transmission line is Length\_Line1 and the length of the stub is Length\_Stub1. The width of the lines is Width\_Line.

```
InputMatching = traceTee('Length',[Length_Line1 Length_Stub1], 'Width',[Width_Line Width_Line]);  
show(InputMatching);
```



```
Gnd1 = antenna.Rectangle('Length',Length_Line1,'Width',30e-3);  
show(Gnd1);
```




The output figures show the tee shaped matching network and the ground plane for creating the PCB stack.


### Design Output Matching Network Using traceTee shape

The output matching network also consists of one shunt stub and one series microstrip transmission line. The dimensions of the series transmission line is `Length_Line2` and the length of the stub is `Length_Stub2`. The width of the lines is `Width_Line`.

```
OutputMatching = traceTee('Length',[Length_Line2 Length_Stub2], 'Width',[Width_Line Width_Line]);  
figure;  
show(OutputMatching);
```



```
Gnd2 = antenna.Rectangle('Length',Length_Line2,'Width',30e-3);  
figure;  
show(Gnd2);
```



The output figures show the tee shaped matching network and the ground plane for creating the PCB stack up.


### **Create pcbComponent for Input and Output Matching Networks**

The `pcbComponent` method creates the PCB stack for any of the RF PCB shapes and it assigns the layers for dielectric, ground plane and feeds at the open ends of the shape.

Use the `pcbComponent` method to create the PCB stack of the `InputMatching` `traceTee` shape. Use the `show` method to visualize the PCB stack up of the `traceTee`. Notice that the `pcbComponent` method assigns the `InputMatching` shape, dielectric, ground plane to `Layers` property of `pcbComponent` and assigns `FeedLocations` at three open ends of the shape.


```
InputMatchingNw = pcbComponent(InputMatching);  
figure;  
show(InputMatchingNw);
```





The output shows the top and the bottom metal with the dielectric in the middle and ports at all the open ends of the shape. However the stub needs to be an open circuit. For this you can remove the feed at the third port, increase the ground plane width and change the dielectric values as per the paper[1] using the below code.


```
d=dielectric('Name',{'Teflon'},'EpsilonR',EpsilonR,'LossTangent',LossTangent,'Thickness',Height)
InputMatchingNw.Layers(2:3) = {d,Gnd1};
InputMatchingNw.BoardShape = Gnd1;
InputMatchingNw.FeedLocations(3,:) = [];
InputMatchingNw.BoardThickness = Height;
figure;
show(InputMatchingNw);
```



Observe the changes in the PCB stack up after removal of the feed and increasing the ground plane width.

Use the `sparameters` function to calculate the s-parameters of the input matching network.


```
s_in=sparameters(InputMatchingNw,freq);
figure;
rfplot(s_in);
```



```
rfwrite(s_in, 's_in.s2p');
```


Perform the same steps for the output matching network and build the required PCB stack.

```
OutputMatchingNw = pcbComponent(OutputMatching);
OutputMatchingNw.Layers(2:3) = {d Gnd2};
OutputMatchingNw.BoardShape = Gnd2;
OutputMatchingNw.FeedLocations(3,:) = [];
OutputMatchingNw.BoardThickness = Height;
figure;
show(OutputMatchingNw);
```



The output shows the top and the bottom metal with dielectric in the middle layer. Use the `sparameters` function to calculate the s-parameters of the output matching network.

```
s_out=sparameters(OutputMatchingNw,freq);  
figure;  
rfplot(s_out);
```



```
rfwrite(s_out, 's_out.s2p');
```


Use `nport` function from RF Toolbox to import the s-parameter files for the input and output matching networks.

```
IMNW = nport('s_in.s2p');
OMNW = nport('s_out.s2p');
```

### Cascaded Amplifier S-Parameters

Use the `circuit` function to cascade the two amplifiers and use the `sparameters` function to calculate the s-parameters and plot it using the `rfplot` method.

```
casamp = circuit([Amp2, clone(Amp2)], 'amplifiers');
S2 = sparameters(casamp, freq);
figure;
rfplot(S2);
```




The plot shows that the S<sub>21</sub> is around 35 dB but the S<sub>11</sub> and S<sub>22</sub> values are around -5 dB mark which is not sufficient as the expected values are -10 dB. So the MNWs that are designed will improve the S<sub>11</sub> and S<sub>22</sub> values.

### Cascade Input and Output Matching Networks with Two Amplifiers

Use the `circuit` function to cascade the Input and output matching networks' s-parameters and the two amplifiers and plot the s-parameters. The S<sub>11</sub> and S<sub>22</sub> are below -10 dB indicating a proper matching at the input and output ports of the amplifier.

```
casamp1 = circuit([IMNW ,clone(Amp1),clone(Amp2), OMNW], 'amplifiersWithMatching');
S3 = sparameters(casamp1,freq);
figure;
rfplot(S3);
```




The plot shows that the S<sub>11</sub> and S<sub>22</sub> are below -10 dB and hence the reflected power is reduced at Port1 and Port2.

### Compare Input Reflection Coefficients of Two-Stage LNA

To verify the simultaneous conjugate match at the input of the amplifier, plot the input reflection coefficients in dB for the amplifier circuit with and without a matching network. Plot the s-parameters with and without the matching networks over the frequency range of 2 - 3 GHz.

```
figure;
rfplot(S2,1,1);
hold on;
rfplot(S3,1,1);
legend('|S11| of Two-Stage LNA Without MNW', '|S11| of Two-Stage LNA with MNW');
title('Input Reflection Coefficients of Two-Stage LNA');
grid on;
```




The input return loss for the two-stage LNA with the input MNW is around -12 dB.

### Compare Output Reflection Coefficients of Two-Stage LNA

To verify the simultaneous conjugate match at the output of the amplifier, plot output reflection coefficients in dB for both the two-stage LNA with and without a MNW.

```
figure;
rfplot(S2,2,2);
hold on;
rfplot(S3,2,2);
legend('|S22| of Without MNW','|S22| of With MNW');
title('Output Reflection Coefficients of Two-Stage LNA');
grid on;
```





The calculated output return loss for the two-stage LNA with the output MNW is around -10 dB.

This matching network design can be used for matching any input impedance and convert that impedance to 50 ohm so that you get good matching at input and output.

### Reference

- [1] Maruddani, B, M Ma'sum, E Sandi, Y Taryana, T Daniati, and W Dara. "Design of Two Stage Low Noise Amplifier at 2.4 - 2.5 GHz Frequency Using Microstrip Line Matching Network Method." *Journal of Physics: Conference Series* 1402 (December 2019): 044031.


## Design and Analyze Compact UWB Low Pass Filter Using pcbComponent

This example shows how to design and analyze a compact low pass ultra-wide band (UWB) filter based on a U-shaped complementary split ring resonator using the pcbComponent object. The filter is designed to have very low insertion loss over a wide band of frequency from low 0.1 GHz to 10.8 GHz. The design of the filter is taken from the reference [1].

### Design and Analyze UWB Low Pass Filter

This compact filter design employs U-shaped complementary split ring resonator (U-CSRR). U-CSRR is a uniplanar configuration of complementary split ring resonator (CSRR) as described in [1]. This structure has an advantage of simpler fabrication as it is formed on the top metal layer. The U-CSRR is formed using two concentric split square rings of outer length  $L_1$ , inner length  $L_2$  as shown in Figure (a) below. This U-CSRR element is created on top metal layer of hosting transmission line. The equivalent circuit of the single U-CSRR cell shown in Figure (b) is represented by a parallel resonant circuit with inductance  $L_c$  and capacitance  $C_c$ . The inductance  $L_R$  and capacitance  $C_R$  represent the inductance and capacitance of the host transmission. The U-CSRR particle is electrically coupled to the host transmission line.

The equivalent circuit of the U-CSRR particle suggests that at low frequency, the impedance of the parallel tank circuit is small and the circuit has a passband characteristics. Figure (a) shows the schematic diagram of such a filter employing two U-CSRR cells in microstrip [1] representing various feature dimensions. As in [1], the choice of two U-CSRR particles in filter design is to have a compact size and ensure high attenuation in stop band.



Use the traceRectangular object to create feeding transmission line ZA and rectangular unit cell Cell\_A. Perform the Boolean add operation for the microstrip shapes ZA, Cell\_A and create LeftSection.

```
% Set variables for ground plane
gndL = 18e-3;
gndW = 7e-3;

% Set variables for feeding transmission line
ZA_Width = 4e-3;
```

```

ZA_Length = 4e-3;

% Define unit cell length
Cell_Length = 5e-3;

% Create feeding microstrip line
ZA = traceRectangular("Length",ZA_Length,"Width",ZA_Width,...
    "Center",[-ZA_Length/2-Cell_Length 0]);

% Create rectangular unit cell
Cell_A = traceRectangular("Length",Cell_Length,"Width",Cell_Length,...
    "Center",[-Cell_Length/2 0]);

% Join feeding line and rectangular unit cell
LeftSection = ZA + Cell_A;

```

Use traceLine object to create shapes s1, s2, s3, s4. Use traceRectangular object to create shape s5.

Subtract shapes s1,s2,s3,s4, and s5 from LeftSection. This operation creates various slots seen on U-CSRR particle. Visualize LeftSection using the show function.

```

% Create shapes for various slots
s1 = traceLine('StartPoint',[-Cell_Length/2-0.2e-3 -1.9e-3],...
    'Angle',[-180 -270 0], 'Length',[1.75e-3 3.8e-3 1.75e-3], 'Width',0.2e-3);

s2 = traceLine('StartPoint',[-Cell_Length/2+0.2e-3 -1.9e-3],...
    'Angle',[0 90 180], 'Length',[1.75e-3 3.8e-3 1.75e-3], 'Width',0.2e-3);


s3 = traceLine('StartPoint',[-Cell_Length/2-1.2e-3 -0.2e-3],...
    'Angle',[-90 0 90], 'Length',[0.8e-3 2.4e-3 0.8e-3], 'Width',0.2e-3);

s4 = traceLine('StartPoint',[-Cell_Length/2-1.2e-3 0.2e-3],...
    'Angle',[90 0 -90], 'Length',[0.8e-3 2.4e-3 0.8e-3], 'Width',0.2e-3);

s5 = traceRectangular("Length",0.2e-3,"Width",1.8e-3,...
    "Center",[-Cell_Length/2 0]);


% Create slots of U-CSRR on hosted microstrip line
LeftSection = LeftSection -s1 -s2 -s3 -s4 -s5;
figure;
show(LeftSection);

```




Use the `copy`, `rotateZ`, and `rotateX` methods on the `LeftSection` object to create a `RightSection`. This creates right portion of filter having another U-CSRR hosted transmission line. Visualize `RightSection` using `show` function.

```
RightSection = copy(LeftSection);
RightSection = rotateZ(RightSection,180);
RightSection = rotateX(RightSection,180);
figure;
show(RightSection);
```



Perform the Boolean add operation for the shapes LeftSection, RightSection to create a filter. Visualize the filter.

```
filter = LeftSection + RightSection;  
show(filter);
```



Define the substrate parameters and create a dielectric to use in the `pcbComponent` of the designed filter. Create a groundplane using the `traceRectangular` shape. Use the `pcbComponent` to create a filter PCB. Assign the dielectric and ground plane to the `Layers` property on `pcbComponent`. Assign the `FeedLocations` to the edge of the feed ports. Set the `BoardThickness` to 1.52 mm on the `pcbComponent` and visualize the filter. The below code performs these operations and creates the filter PCB.

```
% Define Substrate and its thickness
substrate = dielectric("R04730JXR");
substrate.Thickness = 1.52e-3;

% Define bottom ground plane
ground = traceRectangular("Length",gndL,"Width",gndW,...
    "Center",[0,0]);
```


Use `pcbComponent` to create a filter pcb.

```
pcb = pcbComponent;
pcb.BoardShape = ground;
pcb.BoardThickness = 1.52e-3;
```

```

pcb.Layers = {filter, substrate, ground};
pcb.FeedDiameter = ZA_Width/2;
pcb.FeedLocations = [-gndL/2 0 1 3; gndL/2 0 1 3];
figure;
show(pcb);

```




Use the mesh function to have fine meshing and set `MaxEdgeLength` to 1mm.

```

figure;
mesh(pcb, 'MaxEdgeLength', 1e-3)

```


```
NumTriangles : 1716  
NumTetrahedra : 3270  
NumBasis : -  
MaxEdgeLength : 0.001  
MeshMode : manual
```



Use the `sparameters` function to calculate the S-parameters for the low pass filter and plot it using the `rfplot` function.

```
spar = sparameters(pcb,linspace(0.1e9,15e9,30));  
figure;  
rfplot(spar);
```






As there are four curves in the result, let us analyze the results.

### Plot S-Parameters

Analyze the values of  $S_{12}$ , and  $S_{11}$  to understand the behavior of low pass filter.


```
figure;
rfplot(spar,1,1);
hold on;
rfplot(spar,1,2);
hold on;
```




The result shows that the filter has  $S_{21}$  values close to 0 dB and  $S_{11}$  values less than -15 dB between wide band of frequencies  $f_1 = 0.1$  GHz and  $f_2 = 10.0$  GHz. The designed filter therefore has ultra-wide passband response. For frequencies greater than 10.8 GHz,  $S_{21}$  values are less than -10 dB indicating stopband response.

Use the charge function to visualize the charge distribution on the metal surface and dielectric of low pass filter.

```
figure;
charge(pcb,5e9);
```




```
figure;  
charge(pcb,5e9,'dielectric');
```




Use the current function to visualize the current distribution on the metal surface and volume polarization currents on dielectric of low pass filter.

```
figure;  
current(pcb,5e9);
```



```
figure;  
current(pcb,5e9,'dielectric');
```



### References

- [1] Abdalla, M. A., G. Arafa, and M. Saad, "Compact UWB LPF based on uni-planar metamaterial complementary split ring resonator," Proceedings of 10th International Congress on Advanced Electromagnetic Materials in Microwaves and Optics (METAMATERIALS), 10-12, Chania, Greece, Sep. 2016




```

Z1_Length = 0.3e-3;
Z1_Width = 15.15e-3;
Z12_Length = 14.05e-3;
Z12_Width = 0.45e-3;
Z2_Length = 2.3e-3;
Z2_Width = 14.85e-3;
gndL = 45e-3;
gndW = 30e-3;

ZA = traceRectangular("Length",ZA_Length+Z1_Length/2,"Width",ZA_Width,...
    "Center",[-gndL/2+ZA_Length/2+Z1_Length/4 0]);
Z1 = traceRectangular("Length",Z1_Length,"Width",Z1_Width+ZA_Width/2,...
    "Center",[-gndL/2+ZA_Length+Z1_Length/2 (Z1_Width/2+ZA_Width/4)]);
Z12 = traceRectangular("Length",Z12_Length+Z1_Length,"Width",Z12_Width,...
    "Center",[-gndL/2+ZA_Length+Z1_Length/2+Z12_Length/2 0]);
LeftSection = ZA+Z1+Z12;
figure;
show(LeftSection);

```




Use the copy, rotateZ and rotateX functions on LeftSection object to create a RightSection. Visualize the RightSection object.

```

RightSection = copy(LeftSection);
RightSection = rotateZ(RightSection,180);
RightSection = rotateX(RightSection,180);
figure;
show(RightSection);


```





Perform a Boolean add operation for the shapes `LeftSection` and `RightSection` to create a `combineSection` object. Use the `traceRectangular` object to create centerArm `Z2`. Perform a Boolean add operation for the shapes `combineSection`, `Z2`, and create a `filter` object. Visualize the `filter` object.

```
combineSection = LeftSection + RightSection;  
Z2 = traceRectangular("Length",Z2_Length,"Width",Z2_Width,...  
    "Center",[0 -Z12_Width/2+Z2_Width/2]);  
filter = combineSection + Z2;  
show(filter);
```



Define the substrate parameters and create a dielectric to use in the `pcbComponent` of the designed filter. Create a groundplane using the `traceRectangular` shape.


```
substrate = dielectric("EpsilonR",6.15,"LossTangent",0.0027,...
    "Name","custom","Thickness",1.27e-3);

ground = traceRectangular("Length",gndL,"Width",gndW,...
    "Center",[0,6e-3]);
```

### Create PCB Filter Using `pcbComponent`

Use the `pcbComponent` to create a filter PCB. Assign the dielectric and ground plane to the `Layers` property of the `pcbComponent`. Assign the `FeedLocations` to the edge of the feed ports. Set the `BoardThickness` to 1.27 mm on the `pcbComponent` and visualize the filter.


```
pcb = pcbComponent;
pcb.BoardShape = ground;
pcb.BoardThickness = 1.27e-3;
pcb.Layers = {filter,substrate,ground};
pcb.FeedDiameter = ZA_Width/2;
pcb.FeedLocations = [-gndL/2 0 1 3;gndL/2 0 1 3];
figure;
show(pcb);
```



### Plot and Analyze the S-Parameters

Use the `sparameters` function to calculate the s-parameters for the band stop filter and plot it using the `rfplot` function.


```
spar = sparameters(pcb,linspace(0.1e9,6e9,50));  
figure;  
rfplot(spar);
```



As there are four curves in the result, let us analyze the results.

Analyze the values of  $S_{12}$ , and  $S_{11}$  to understand the behavior of band stop filter.

```
figure;  
rfplot(spar,1,1);  
hold on;  
rfplot(spar,1,2);  
hold on;
```




The result shows that the filter has center frequency  $f_0 = 2.5$  GHz for the band-edge frequencies  $f_1 = 1.75$  GHz and  $f_2 = 3.4$  GHz. The  $S_{11}$  values are close to 0 dB and  $S_{12}$  values are less than -10 dB between frequencies  $f_1 = 1.75$  GHz and  $f_2 = 3.4$  GHz. The designed filter therefore has stopband response.


### Visualize Charge and Current Distribution

Use the charge function to visualize the charge distribution on the metal surface and dielectric of band stop filter.

```
figure;
charge(pcb,2.4e9);
```




```
figure;  
charge(pcb,2.4e9,'dielectric');
```




Use the current function to visualize the current distribution on the metal surface and the volume polarization currents on dielectric of band stop filter

```
figure;  
current(pcb,2.4e9);
```



```
figure;  
current(pcb,2.4e9,'dielectric');
```





## References


- [1] Jia-Sheng Hong "Microstrip Filters for RF/Microwave Applications", p. 184, John Wiley & Sons, 2nd Edition, 2011.

## Design and Analyze High Pass Filter using pcbComponent

This example shows how to design and analyze high pass filter. A microstrip high pass filter is designed based on a three-pole ( $n = 3$ ) Chebyshev high pass prototype with 0.1 dB passband ripple and cut-off frequency  $f_c = 1.5$  GHz.


### Design and Analyze High Pass Filter

The element values of the corresponding low pass Chebyshev prototype are  $g_0 = g_4 = 1.0$ ,  $g_1 = g_3 = 1.0316$ , and  $g_2 = 1.1474$ . Using the design equations given in reference [1] for  $n = 3$  and  $Z_0 = 50$  ohm terminations, we can obtain quasi-lumped circuit elements values as  $C_1 = C_3 = 2.0571$  pF,  $L_2 = 4.6236$  nH. A schematic diagram of such a high pass filter taken from reference [1] representing various feature dimensions is shown below. It is seen here that the series capacitors  $C_1$  and  $C_3$  are realized by identical interdigital capacitors, while the shunt inductor  $L_2$  is realized by a short-circuited stub. A commercial substrate (RT/D 5880) having a relative dielectric constant of 2.2 and thickness of 1.57 mm is chosen for this microstrip filter realization. The dimensions of the interdigital capacitors, such as the finger length, width, spacing between fingers, and number of the fingers are given in the reference [1].




Use the `interdigitalCapacitor` object and change its properties as per given values in reference [1] to create interdigitated fingers. Visualize created object using `show`

```
idc = interdigitalCapacitor;
idc.NumFingers = 10;
idc.FingerLength = 10e-3;
idc.FingerWidth = 0.3e-3;
idc.FingerSpacing = 0.2e-3;
idc.FingerEdgeGap = 0.2e-3;
idc.GroundPlaneWidth = 5e-3;
idc.TerminalStripWidth = 0.1e-3;
idc.PortLineLength = 0.1e-3;
idc.PortLineWidth = 4.8e-3;
figure;
show(idc);
```




Use the `pcbComponent` on `idc` object to create a capacitor `cap1`. Visualize `cap1` using `show`

```
pcb = pcbComponent(idc);
cap1 = pcb.Layers{1};
figure;
show(cap1);
```



Use the `copy`, `rotateZ`, `rotateX` and `translate` operation methods on capacitor `cap1` object to create capacitor `cap2`. Visualize `cap2` using `show`


```
cap2 = copy(cap1);  
cap2 = rotateZ(cap2,180);  
cap2 = rotateX(cap2,180);  
cap2 = translate(cap2,[-6.2e-3 0 0]);  
cap1 = translate(cap1,[6.2e-3 0 0]);  
figure;  
show(cap2);
```



Use the `traceRectangular` object to create both feeding ports `port1`, `port2` and short circuited stub `centerArm`. Perform a Boolean add operation for the shapes `port1`, `cap2`, `centerArm`, `cap1` and `port2` to create `filter`. Visualize `filter` using `show`

```
portW = 4.9e-3;
portL = 3.6e-3;
centerL = 2e-3;
centerW = 9.9e-3;
port1 = traceRectangular("Length",portL,"Width",portW,"Center",[-11.4e-3-portL/2 -0.05e-3]);
port2 = traceRectangular("Length",portL,"Width",portW,"Center",[11.4e-3+portL/2 -0.05e-3]);

centerArm = traceRectangular("Length",centerL,"Width",centerW,"Center",[0 -2.55e-3]);
filter = port1 + cap2 + centerArm + cap1 + port2;
figure;
show(filter);
```




Define the substrate parameters and create a dielectric to use in the `pcbComponent` of the designed filter. Create a groundplane using the `traceRectangular` shape.

Use the `pcbComponent` to create a filter PCB. Assign the dielectric and ground plane to the `Layers` property on `pcbComponent`. Assign the `FeedLocations` to the edge of the feed ports. Assign `ViaLocations` at the edge of stub centerArm. Set the `BoardThickness` to 1.57 mm on the `pcbComponent` and visualize the filter. The below code performs these operations and creates the filter `pcb` object.


```
substrate = dielectric("EpsilonR",2.2,"LossTangent",0.0009,...
    "Name","custom","Thickness",1.57e-3);
gndL = 30e-3;
gndW = 25e-3;
ground = traceRectangular("Length",gndL,"Width",gndW,...
    "Center",[0,-4e-3]);

pcb = pcbComponent;
pcb.BoardShape = ground;
pcb.BoardThickness = 1.57e-3;
pcb.Layers = {filter,substrate,ground};
pcb.FeedDiameter = portW/2;
pcb.FeedLocations = [-gndL/2 0 1 3;gndL/2 0 1 3];
pcb.ViaDiameter = centerL;
pcb.ViaLocations = [0 -6.5e-3 1 3];
figure;
show(pcb);
```



Use the `sparameters` method to calculate the S-parameters for the band stop filter and plot it using the `rfplot` function.

```
spar = sparameters(pcb,linspace(0.1e9,3.5e9,40));  
figure;  
rfplot(spar);
```




As there are four curves in the result, let us analyze the results.

### Plot S-Parameters

Analyze the values of  $S_{11}$ , and  $S_{12}$  to understand the behavior of high pass filter.

```
figure;  
rfplot(spar,1,1);  
hold on;  
rfplot(spar,1,2);  
hold on;
```







The result shows that the filter has -3 dB cut-off frequency  $f_c = 1.8$  GHz . The  $S_{12}$  values are greater than -3 dB and  $S_{11}$  values are less than -10 dB above -3 dB cut-off frequency 1.8 GHz. The designed filter therefore has high pass response and em simulated results matches closely with reference. The 0.3 GHz shift in -3 dB cut-off frequency is observed.

Use the charge method to visualize the charge distribution on the metal surface and dielectric of high pass filter

```
figure;
charge(pcb, 3e9);
```




```
figure;  
charge(pcb,3e9,'dielectric');
```




Use the current method to visualize the current distribution on the metal surface and volume polarization currents on dielectric of high pass filter

```
figure;  
current(pcb, 3e9);
```



```
figure;  
current(pcb,3e9,'dielectric');
```




## References

- [1] Jia-Sheng Hong "Microstrip Filters for RF/Microwave Applications", p. 184, John Wiley & Sons, 2nd Edition, 2011.

## Design of Quarter-Wave Transformer for Impedance Matching Applications

This example shows how to design the Quarter-wave transformer for impedance matching applications by using the `pcbComponent`, `microstripLine`, and `traceRectangular` object in the RF PCB Toolbox.

Quarter-wave transformer is a simple and useful circuit for matching the real impedance of a terminating load ( $Z_L$ ) to the characteristic impedance of the feeding transmission line ( $Z_0$ ) as depicted in the given figure. The characteristic impedance of the quarter-wave transformer is calculated as  $Z_1 = \sqrt{Z_0 Z_L}$  [1]. This example is to design a single section quarter-wave transformer to match the  $100\ \Omega$  load to a  $50\ \Omega$  transmission line at an operating frequency of 2 GHz. The calculated characteristic impedance of the quarter-wave transformer  $Z_1$  is  $70.71\ \Omega$ .



### Design of Single Section Quarter-Wave Transformer

Use the `design` function on the `microstripLine` object to create the  $50\ \Omega$  input transmission line and  $70.71\ \Omega$  quarter-wave transformer's Length and Width dimension for the operating frequency of 2 GHz. The default substrate for `microstripLine` is Teflon with thickness of 1.6 mm.

```
freq = 2e9;
m50 = design(microstripLine, freq, Z0=50, LineLength=0.05); % input transmission line
m70 = design(microstripLine, freq, Z0=70.71, LineLength=0.25); % section 1
```

Use the `traceRectangular` object to create the groundplane, input transmission line, and quarter-wave transmission line shapes.

```
% ground plane dimension
gndL = 2*m50.Length+m70.Length;
gndW = 5*m50.Width;


ground = traceRectangular("Length", gndL, "Width", gndW);
% input transmission line
Z0 = traceRectangular("Length", m50.Length, "Width", m50.Width, ...
    "Center", [-gndL/2+m50.Length/2 0]);
% First section Quarter-wave transformer
Z1 = traceRectangular("Length", m70.Length, "Width", m70.Width, "Center", ...
```

```
[-gndL/2+m50.Length+m70.Length/2 0]);
```

```
qline = Z0 + Z1;
```


Use the `pcbComponent` to create the quarter-wave transformer and use the `lumpedElement` for the terminating load of  $100\ \Omega$  and place it at the end of the quarter-wave transformer and use a via to connect the load to ground.

```
pcb =pcbComponent;
pcb.BoardShape = ground;
pcb.BoardThickness = m50.Height;
pcb.Layers = {qline,m50.Substrate,ground};
pcb.FeedDiameter = m50.Width/2;
pcb.FeedLocations = [-gndL/2 0 1 3];
pcb.ViaLocations = [-gndL/2+m50.Length+m70.Length,0,1,3];
pcb.ViaDiameter = m70.Width/2;
% Load
ZL = lumpedElement;
ZL.Impedance = 100;
ZL.Location = [-gndL/2+m50.Length+m70.Length,0,pcb.BoardThickness];
pcb.Load = ZL;
% show the single section quarter-wave transformer
figure;show(pcb)
```



Use the `sparameters` function to calculate the S parameters and plot it using the `rfplot` function.

```
sparams = sparameters(pcb,linspace(100e6,8e9,51));
figure; rfplot(sparams)
```



It is observed from the  $S_{11}$  values that the impedance is perfectly matched at the desired frequency of 2 GHz where the value of magnitude is less than  $-22$  dB with the bandwidth of 2800 MHz. Matching also occurs at frequencies where the  $Z_1$  has a length of  $(2n + 1)^{\lambda_0}/4$ ,  $n = 0, 1, 2, 3, \dots$

### Design of Multisection Quarter-Wave Transformer

In general, the single section transformer may be sufficient for narrow band impedance match. This transformer can be extended to multisection in a methodical manner to yield optimum matching characteristics over a wider bandwidth [1]. The following example is for the design of three section Chebyshev matching transformer to match a  $100\ \Omega$  load to a  $50\ \Omega$  with ripple level = 0.05. Each section's characteristic impedances are computed using the formulas given in [1] and the values are  $Z_1 = 57.5\ \Omega$ ,  $Z_2 = 70.7\ \Omega$  and  $Z_3 = 87\ \Omega$ . The three section Chebyshev matching transformer is designed by using same steps described in the design of single section quarter-wave transformer.

```
m50 = design(microstripLine,freq,"Z0",50,"LineLength",0.05); % input transmission line
m57 = design(microstripLine,freq,"Z0",57.5,"LineLength",0.25); % section 1
m70 = design(microstripLine,freq,"Z0",70.7,"LineLength",0.25); % section 2
m87 = design(microstripLine,freq,"Z0",87,"LineLength",0.25); % section 3
% ground plane dimension
gndL = 2*m50.Length+m57.Length+m70.Length+m87.Length;
gndW = 5*m50.Width;

ground = traceRectangular("Length",gndL,"Width",gndW);
% inpt transmission line
Z0 = traceRectangular("Length",m50.Length,"Width",m50.Width,...
    "Center",[-gndL/2+m50.Length/2 0]);
```




```


% First section Quarter-wave transformer
Z1 = traceRectangular("Length",m57.Length,"Width",m57.Width,"Center",...
    [-gndL/2+m50.Length+m57.Length/2 0]);
% Second section Quarter-wave transformer
Z2 = traceRectangular("Length",m70.Length,"Width",m70.Width,"Center",...
    [-gndL/2+m50.Length+m57.Length+m70.Length/2 0]);
% Third section Quarter-wave transformer
Z3 = traceRectangular("Length",m87.Length,"Width",m87.Width,"Center",...
    [-gndL/2+m50.Length+m57.Length+m70.Length+m87.Length/2 0]);

qline = Z0+Z1+Z2+Z3;
% create pcbComponent
pcb = pcbComponent;
pcb.BoardShape = ground;
pcb.BoardThickness = m50.Height;
pcb.Layers = {qline,m50.Substrate,ground};
pcb.FeedDiameter = m50.Width/2;
pcb.FeedLocations = [-gndL/2 0 1 3];
pcb.ViaLocations = [-gndL/2+m50.Length+m57.Length+m70.Length+m87.Length,0,1,3];
pcb.ViaDiameter = m87.Width/2;
% Load
ZL = lumpedElement;
ZL.Impedance = 100;
ZL.Location = [-gndL/2+m50.Length+m57.Length+m70.Length+m87.Length,0,pcb.BoardThickness];
pcb.Load = ZL;
% show the three section quarter-wave transformer
figure;show(pcb)

```




```
% Analysis  
sparams3 = sparameters(pcb,linspace(100e6,8e9,51));  
figure; rfplot(sparams3)
```



### Comparison of S parameters

```
figure; rfplot(sparams,'-.')  
hold on  
rfplot(sparams3)  
legend('dB(S_{11}) for N=1','dB(S_{11}) for N=3','Location','northeast')
```



From the comparison the s-parameters plot for single section and three section quarter-wave transformers designed at 2 GHz, it is observed that the bandwidth achieved for three section quarter-wave transformer is 7750 MHz with improved impedance matching characteristics. Therefore, it is evident that wider bandwidth is achieved for quarter-wave transformers with multiple sections.

### References

- [1] David M. Pozar, Microwave Engineering, pp. 246-261, 4<sup>th</sup> Edition, John Wiley & Sons, 2012.



# Computational Techniques

---

## Method of Moments Solver for Metal and Dielectric Structures

### In this section...

“MoM Formulation” on page 2-2

“Neighbor Region” on page 2-6

“Singularity Extraction” on page 2-7

Method of Moments computation technique for metal and dielectrics in a PCB.

A PCB consists of a metal part and a dielectric part. The first step in the computational solution of electromagnetic problems is to discretize Maxwell's equations. The process results in this matrix-vector system:

$$V = ZI$$

- $V$  – Applied voltage vector. This signal can be voltage or power applied to the antenna or an incident signal falling at the input port of the PCB component.
- $I$  – Current vector that represents current on the PCB component surface.
- $Z$  – Interaction matrix or impedance matrix that relates  $V$  to  $I$ . For calculating the interaction matrix, the effect of metal and dielectric parts of the PCB antenna are taken separately.



RF PCB Toolbox™ uses method of moments (MoM) to calculate the interaction matrix and solve system equations.

### MoM Formulation

The MoM formulation is split into three parts.

#### Discretization of Metals and Dielectrics


Discretization enables the formulation from the continuous domain to the discrete domain. This step is called *meshing*. In the MoM formulation, the metal surface of the PCB is meshed into triangles and the dielectric volume is meshed into tetrahedrons.



## Basis Functions

### Metals

To calculate the surface currents on the PCB, first define basis functions. RF PCB Toolbox uses Rao-Wilton-Glisson (RWG) [2] basis functions. The arrows show the direction of current flow.



The basis function includes a pair of adjacent (not necessarily coplanar) triangles and resembles a small spatial dipole with linear current distribution. Each triangle is associated with a positive or negative charge.

For any two triangle patches,  $t_n^+$  and  $t_n^-$ , having areas  $A_n^+$  and  $A_n^-$ , and sharing common edge  $l_n$ , the basis function is

$$\vec{f}_n(\vec{r}) = \begin{cases} \frac{l_n}{2A_n^+} \vec{\rho}_n^{+S}, & \vec{r} \in t_n^+ \\ \frac{l_n}{2A_n^-} \vec{\rho}_n^{-S}, & \vec{r} \in t_n^- \end{cases}$$

- $\vec{\rho}_n^+ = \vec{r} - \vec{r}_n^+$  — Vector drawn from the free vertex of triangle  $t_n^+$  to observation point  $\vec{r}$
- $\vec{\rho}_n^- = \vec{r}_n^- - \vec{r}$  — Vector drawn from the observation point to the free vertex of the triangle  $t_n^-$

and


$$\nabla \cdot \vec{f}_n(\vec{r}) = \begin{cases} \frac{l_n}{A_n^+}, & \vec{r} \in t_n^+ \\ -\frac{l_n}{A_n^-}, & \vec{r} \in t_n^- \end{cases}$$

The basis function is zero outside the two adjacent triangles  $t_n^+$  and  $t_n^-$ . The RWG vector basis function is linear and has no flux (no normal component) through its boundary.

**Dielectrics**

Basis functions are used to represent unknown quantities. In the case of a PCB component, the unknown quantities are the surface current on the metal structure and flux density due to dielectric volume. RF PCB Toolbox uses Rao-Wilton-Glisson (RWG) [2] basis functions.

For the dielectric volume, RF PCB Toolbox uses a zeroth order edge basis function to model the flux density.



The figure shows an edge-based basis function. The vector variation is perpendicular to the base edge AB (or  $\bar{l}$ ). The vector of the edge CD (or  $\bar{p}$ ) defines the basis function. Within a tetrahedron, the basis function is a constant field given by

$$\vec{f} = c\vec{p}$$


- $c$  - normalization coefficient.
- $p$  - vector of the edge defining the basis function.

**Interaction Matrix**

**Metals**

The interaction matrix is a complex dense symmetric matrix. It is a square  $N$ -by- $N$  matrix, where  $N$  is the number of basis functions, that is, the number of interior edges in the structure. A typical interaction matrix for a structure with 256 basis functions is shown:





To fill out the interaction matrix, calculate the free-space Green's function between all basis functions on the PCB surface. The final interaction matrix equations are:

$$Z_{mn} = \left( \frac{j\omega\mu}{4\pi} \right) \int_S \int_S \vec{f}_m(\vec{r}) \cdot \vec{f}_n(\vec{r}') g d\vec{r}' d\vec{r} - \left( \frac{j}{4\pi\omega\epsilon} \right) \int_S \int_S (\nabla \cdot \vec{f}_m) (\nabla \cdot \vec{f}_n) g d\vec{r}' d\vec{r}$$

where

- $g(\vec{r}, \vec{r}') = \frac{\exp(-jk|\vec{r} - \vec{r}'|)}{|\vec{r} - \vec{r}'|}$  – Free-space Green's function

To calculate the interaction matrix, excite the PCB by a voltage of 1 V at the input port. So the voltage vector has zero values everywhere except at the feeding edge. Solve the system of equations to calculate the unknown currents. Once you determine the unknown currents, you can calculate the field and surface properties of the PCB.

### Dielectrics

The interaction matrix is a complex dense symmetric matrix. To fill out the interaction matrix, calculate the free-space Green's function between all the basis functions on the PCB surface. The final interaction matrix equations are:

- $Z_{MM}$  - metal to metal interaction. For a pure metal structure, you only calculate this symmetric square matrix.

$$Z_{mn}^{MM} = \left( \frac{j\omega\mu}{4\pi} \right) \int_S \int_S \vec{f}_m^M(\vec{r}) \cdot \vec{f}_n^M(\vec{r}') g d\vec{r} d\vec{r}' - \left( \frac{j}{4\pi\omega\epsilon} \right) \int_S \int_S \left( \nabla \cdot \vec{f}_m^M \right) \left( \nabla \cdot \vec{f}_n^M \right) g d\vec{r} d\vec{r}'$$

- $Z_{DD}$  - dielectric to dielectric interaction. For pure dielectric structures, you only calculate this symmetric square matrix.

$$\begin{aligned} \widehat{Z}_{mn}^{DD} &= \sum_{p=1}^P \sum_{p'=1}^P \frac{K_p}{\widehat{\epsilon}_p} \int_{V_D} \vec{f}_{mp}(\vec{r}) \cdot \vec{f}_{np'}(\vec{r}') d\vec{r} \\ &- \frac{\omega^2 \mu_0}{4\pi} \sum_{p=1}^P \sum_{p'=1}^P K_p K_{p'} \int_{V_D} \int_{V_{D'}} g(\vec{r}, \vec{r}') \vec{f}_{mp}(\vec{r}) \cdot \vec{f}_{np'}(\vec{r}') d\vec{r} d\vec{r}' \\ &- \frac{1}{4\pi\epsilon_0} \sum_{q=1}^Q \sum_{q'=1}^Q \widehat{K}_q \widehat{K}_{q'} \int_{\Omega_q} \int_{\Omega_{q'}} g(\vec{r}, \vec{r}') f_{\perp mq}(\vec{r}) f_{\perp nq'}(\vec{r}') d_s d_{s'} \quad m, n = 1, \dots, N \end{aligned}$$

- $Z_{MD}$  and  $Z_{DM}$  - These matrices calculate the interaction between metal and dielectric. This matrix is not a symmetrical square matrix.

$$\begin{aligned} Z_{mn}^{MD} &= - \frac{\omega^2 \mu_0}{4\pi} \sum_{p=1}^2 \sum_{p'=1}^P K_p \int_t \int_{V_{D'}} \vec{f}_n^M(\vec{r}) \cdot \vec{f}_{mp'}(\vec{r}') g(\vec{r}, \vec{r}') d\vec{r}' d_s \\ &- \frac{1}{4\pi\epsilon_0} \sum_{p=1}^2 \sum_{q=1}^Q \widehat{K}_q \int_{t_D} \int_{\Omega_{q'}} (\nabla_s \cdot \vec{f}_n^M(\vec{r})) f_{\perp mq'}(\vec{r}') g(\vec{r}, \vec{r}') d_{\Omega} d_{s'} \\ &m = 1, \dots, N_D; n = 1, \dots, N_M \end{aligned}$$

$$\begin{aligned} Z_{mn}^{DM} &= - \frac{j\omega\mu_0}{4\pi} \sum_{p=1}^2 \sum_{p'=1}^P K_{p'} \int_{V_D} \int_{S_{D'}} \vec{f}_{np'}(\vec{r}) \cdot \vec{f}_m^M(\vec{r}') g(\vec{r}, \vec{r}') d_s d\vec{r}' \\ &+ \frac{1}{4\pi\epsilon_0\omega} \sum_{p=1}^2 \sum_{q=1}^Q \widehat{K}_q \int_{\Omega_q} \int_{S_{D'}} f_{\perp nq}(\vec{r}) \cdot (\nabla_s \cdot \vec{f}_m^M(\vec{r}')) g(\vec{r}, \vec{r}') d_s d_{\Omega} \\ &m = 1, \dots, N_D; n = 1, \dots, N_M \end{aligned}$$


where

- $g(\vec{r}, \vec{r}') = \frac{\exp(-jkR)}{R}$ ,  $R = |\vec{r} - \vec{r}'|$  is the free space Green's function.
- $K = \frac{\widehat{\epsilon}^{\pm} - \epsilon_0}{\widehat{\epsilon}^{\pm}}$  is the complex dielectric constant within every tetrahedron.
- $\widehat{K}_q = K_+ - K_-$  is the differential contrast on every face of the tetrahedron.

For a composite metal structure, you must calculate all four matrices.

## Neighbor Region

From the interaction matrix plot, you observe that the matrix is diagonally dominant. As you move further away from the diagonal, the magnitude of the terms decreases. This behavior is same as the Green's function behavior. The Green's function decreases as the distance between  $r$  and  $r'$  increases. Therefore, it is important to calculate the region on the diagonal and close to the diagonal accurately.



This region on and around the diagonal is called *neighbor region*. The neighbor region is defined within a sphere of radius  $R$ , where  $R$  is in terms of triangle size. The size of a triangle is the maximum distance from the center of the triangle to any of its vertices. By default,  $R$  is twice the size of the triangle. For better accuracy, a higher-order integration scheme is used to calculate the integrals. The figure shows a typical interaction matrix for a metal structure  $Z_{MM}$  with 256 basis functions.

The dielectric interaction matrix is also diagonally dominant. As you move further away from the diagonal, the magnitude of the terms decreases. This behavior is same as the Green's function behavior. The Green's function decreases as the distance between  $r$  and  $r'$  increases. Therefore, it is important to calculate the region on the diagonal and close to the diagonal accurately. For a dielectric the *neighbor region* is based on the average size of the tetrahedron.

## Singularity Extraction

Along the diagonal,  $r$  and  $r'$  are equal and defines Green's function becomes singular. To remove the singularity, extraction is performed on these terms.

$$\int_{t_p} \int_{t_q} (\vec{\rho}_i \cdot \vec{\rho}'_j) g(\vec{r}, \vec{r}') ds' ds = \int_{t_p} \int_{t_q} \frac{(\vec{\rho}_i \cdot \vec{\rho}'_j)}{|\vec{r} - \vec{r}'|} ds' ds + \int_{t_p} \int_{t_q} \frac{(\exp(-jk|\vec{r} - \vec{r}'|) - 1)(\vec{\rho}_i \cdot \vec{\rho}'_j)}{|\vec{r} - \vec{r}'|} ds' ds$$

$$\int_{t_p} \int_{t_q} g(\vec{r}, \vec{r}') ds' ds = \int_{t_p} \int_{t_q} \frac{1}{|\vec{r} - \vec{r}'|} ds' ds + \int_{t_p} \int_{t_q} \frac{(\exp(-jk|\vec{r} - \vec{r}'|) - 1)}{|\vec{r} - \vec{r}'|} ds' ds$$

The two integrals on the right-hand side of the equations, called potential or static integrals are found using analytical results [3].

The equations for the singularity extraction of the  $Z_{DD}$  matrix are:

$$\int_{V_D} \int_{V_{D'}} g(\vec{r}, \vec{r}') d\vec{r} d\vec{r}' = \int_{V_D} \int_{V_q} \frac{1}{|\vec{r} - \vec{r}'|} d\vec{r} d\vec{r}' + \int_{V_D} \int_{V_q} \frac{(\exp(-jk|\vec{r} - \vec{r}'|) - 1)}{|\vec{r} - \vec{r}'|} d\vec{r} d\vec{r}'$$

$$\int_{\Omega_q} \int_{\Omega_{q'}} g(\vec{r}, \vec{r}') d\Omega d\Omega' = \int_{\Omega_D} \int_{\Omega_q} \frac{1}{|\vec{r} - \vec{r}'|} d\Omega d\Omega' + \int_{S_D} \int_{S_q} \frac{(\exp(-jk|\vec{r} - \vec{r}'|) - 1)}{|\vec{r} - \vec{r}'|} d\Omega d\Omega'$$

## References

- [1] Harrington, R. F. *Field Computation by Moment Methods*. New York: Macmillan, 1968.
- [2] Rao, S. M., D. R. Wilton, and A. W. Glisson. "Electromagnetic scattering by surfaces of arbitrary shape." *IEEE. Trans. Antennas and Propagation*, Vol. AP-30, No. 3, May 1982, pp. 409-418.
- [3] Wilton, D. R., S. M. Rao, A. W. Glisson, D. H. Schaubert, O. M. Al-Bundak. and C. M. Butler. "Potential Integrals for uniform and linear source distribution on polygonal and polyhedral domains." *IEEE. Trans. Antennas and Propagation*. Vol. AP-30, No. 3, May 1984, pp. 276-281.