## *General Description*

The MAX5060/MAX5061 pulse-width modulation (PWM) DC-DC controllers provide high-output-current capability in a compact package with a minimum number of external components. These devices utilize an average-current-mode control that enables optimal use of low RDS(ON) MOSFETs, eliminating the need for external heatsinks even when delivering high output currents.

Differential sensing (MAX5060) enables accurate control of the output voltage, while adaptive voltage positioning provides optimum transient response. An internal regulator enables operation with 4.75V to 5.5V or 7V to 28V input voltage ranges. The high switching frequency, up to 1.5MHz, allows the use of low-output inductor values and input capacitor values. This accommodates the use of PC-board-embedded planar magnetics.

The MAX5060 features a clock output with 180° phase delay to control a second out-of-phase converter for lower capacitor ripple currents. The MAX5060 also limits the reverse current if the bus voltage becomes higher than the regulated output voltage. The MAX5060 is specifically designed to limit current sinking when multiple power-supply modules are paralleled. The MAX5060/MAX5061 offer an adjustable 0.6V to 5.5V output voltage. The MAX5060 offers an overvoltage protection, power-good signal, and an output enable function.

The MAX5060/MAX5061 operate over the automotive temperature range (-40°C to +125°C). The MAX5060 is available in a 28-pin thin QFN package while the MAX5061 is available in a 16-pin TSSOP package.

## *Applications*

Servers and Workstations

Point-of-Load Telecom DC-DC Regulators

Networking Systems

RAID Systems

High-End Desktop Computers

## **Selector Guide**



## **MAXIM**

## *Features*

- ♦ **4.75V to 5.5V or 7V to 28V Input Voltage Range**
- ♦ **Adjustable Output Voltage from 0.6V to 5.5V**
- ♦ **Up to 30A Output Current**
- ♦ **Can Parallel Outputs For Higher Output Current**
- ♦ **Programmable Adaptive Output Voltage Positioning**
- ♦ **True-Differential Remote Output Sensing (MAX5060)**
- ♦ **Average-Current-Mode Control**
	- **Superior Current Sharing Between Paralleled Modules**
	- **Accurate Current Limit Eliminates MOSFET and Inductor Derating**
- ♦ **Limits Reverse Current Sinking in Paralleled Modules (MAX5060)**
- ♦ **Programmable Switching Frequency from 125kHz to 1.5MHz**
- ♦ **Integrated 4A Gate Drivers**
- ♦ **Clock Output for 180° Out-of-Phase Operation (MAX5060)**
- ♦ **Voltage Signal Proportional to Output Current for Load Monitoring (MAX5060)**
- ♦ **Output Overvoltage Crowbar Protection (MAX5060)**
- ♦ **Programmable Hiccup Current-Limit Threshold and Response Time**
- ♦ **Overtemperature Thermal Shutdown**

## *Ordering Information*



\**EP = Exposed pad.*

*Pin Configurations appear at end of data sheet.*

**\_** *Maxim Integrated Products* **1**

*For pricing, delivery, and ordering information, please contact Maxim/Dallas Direct! at 1-888-629-4642, or visit Maxim's website at www.maxim-ic.com.*

## **ABSOLUTE MAXIMUM RATINGS**





\**Per JEDEC 51 standard.*

*Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.*

## **ELECTRICAL CHARACTERISTICS**

(V<sub>CC</sub> = 5V, V<sub>DD</sub> = V<sub>CC</sub> (MAX5060 only), T<sub>A</sub> = T<sub>J</sub> = T<sub>MIN</sub> to T<sub>MAX</sub>, unless otherwise noted. Typical specifications are at T<sub>A</sub> = +25°C.) (Note 1)



**MAXIM** 

## **ELECTRICAL CHARACTERISTICS (continued)**

(V<sub>CC</sub> = 5V, V<sub>DD</sub> = V<sub>CC</sub> (MAX5060 only), T<sub>A</sub> = T<sub>J</sub> = T<sub>MIN</sub> to T<sub>MAX</sub>, unless otherwise noted. Typical specifications are at T<sub>A</sub> = +25°C.) (Note 1)



## **ELECTRICAL CHARACTERISTICS (continued)**

(V<sub>CC</sub> = 5V, V<sub>DD</sub> = V<sub>CC</sub> (MAX5060 only),  $T_A = T_J = T_{MIN}$  to  $T_{MAX}$ , unless otherwise noted. Typical specifications are at  $T_A = +25^{\circ}$ C.) (Note 1)





## **ELECTRICAL CHARACTERISTICS (continued)**

(V<sub>CC</sub> = 5V, V<sub>DD</sub> = V<sub>CC</sub> (MAX5060 only), T<sub>A</sub> = T<sub>J</sub> = T<sub>MIN</sub> to T<sub>MAX</sub>, unless otherwise noted. Typical specifications are at T<sub>A</sub> = +25°C.) (Note 1)



**Note 1:** Specifications at T<sub>A</sub> = +25°C are 100% tested. Specifications over the temperature range are guaranteed by design. **Note 2:** Does not include an error due to finite error amplifier gain (see the *Voltage-Error Amplifier* section).

 $(T_A = +25^{\circ}C,$  Figures 1 and 2, unless otherwise noted.)



## *Typical Operating Characteristics*

**6 \_**

## *Typical Operating Characteristics (continued)*

 $(T_A = +25^{\circ}C,$  Figures 1 and 2, unless otherwise noted.)







*MAX5060/MAX5061*

MAX5060/MAX5061





**DRIVER FALL TIME vs. DRIVER LOAD CAPACITANCE**









**HIGH-SIDE DRIVER (DH) FALL TIME**  $C<sub>LOAD</sub> = 22nF$  $V_{IN} = 12V$ 



**LOW-SIDE DRIVER (DL) SINK AND SOURCE CURRENT** 







ノハノメレル

# *MAX5060/MAX5061* MAX5060/MAX5061



 $(T_A = +25^{\circ}C,$  Figures 1 and 2, unless otherwise noted.)





*Typical Operating Characteristics (continued)*



2ms/div



**LOAD-TRANSIENT RESPONSE** 







**8 \_**



200µs/div

**MAXIM** 

2ms/div

## *Typical Operating Characteristics (continued)*

 $(T_A = +25^{\circ}C,$  Figures 1 and 2, unless otherwise noted.)



1µs/div

# MAX5060/MAX5061 *MAX5060/MAX5061*

**MAXM** 

## *Pin Description*



## *Pin Description (continued)*



*Typical Application Circuit*



*Figure 1. Typical Application Circuit, VIN = 12V (MAX5060)*

*MAX5060/MAX5061*

MAX5060/MAX5061

## *Typical Application Circuit (continued)*



*Figure 2. Typical Application Circuit, VIN = +12V (MAX5061)*

*Block Diagram*



*Figure 3. Functional Diagram (MAX5060)*

**MAXM** 

*MAX5060/MAX5061*

**MAX5060/MAX5061** 

## *Block Diagram (continued)*



*Figure 4. Functional Diagram (MAX5061)*

*MAX5060/MAX5061*

**MAX5060/MAX5061** 

## *Detailed Description*

The MAX5060/MAX5061 are high-performance averagecurrent-mode PWM controllers. The average-currentmode control technique offers inherently stable operation, reduces component derating and size by accurately controlling the inductor current. This also improves the current-sharing accuracy when paralleling multiple converters. The devices achieve high efficiency, at high current (up to 30A) with a minimum number of external components. The high- and low-side drivers source and sink up to 4A for lower switching frequencies while driving high-gate-charge MOSFETs.

The MAX5060's CLKOUT output is 180° out-of-phase with respect to the high-side driver. The CLKOUT drives a second MAX5060 or a MAX5061 regulator out-ofphase, reducing the input capacitor ripple current and increasing the load current capacity. The paralleling capability of the MAX5060/MAX5061 improves design flexibility in applications requiring upgrades (higher load).

The MAX5060/MAX5061 consist of an inner averagecurrent-loop controlled by an outer-voltage-loop voltageerror amplifier (VEA). The combined action of the inner current loop and outer voltage loop corrects the output voltage errors by adjusting the inductor current. The inductor current is sensed across a current-sense resistor. The differential amplifier (MAX5060) senses the output right at the load for true-differential output voltage sensing. The sensed voltage is compared against internal 0.6V reference at the error-amplifier input. The output voltage can be set from 0.6V to 5.5V ( $IN \ge 7V$ ) using a resistor-divider at SENSE+ and SENSE-.

#### *IN, VCC, and VDD*

The MAX5060/MAX5061 accept a 4.75V to 5.5V or 7V to 28V input voltage range. All internal control circuitry operates from an internally regulated nominal voltage of 5V (VCC). For input voltages of 7V or greater, the internal VCC regulator steps the voltage down to 5V. The V<sub>CC</sub> output voltage is a regulated 5V output capable of sourcing up to 60mA. Bypass the V<sub>CC</sub> to SGND with 4.7µF and 0.1µF low-ESR ceramic capacitors for high-frequency noise rejection and stable operation. The MAX5060 uses V<sub>DD</sub> to power the low-side and high-side drivers, while the MAX5061 uses the V<sub>CC</sub> to power internal circuitry as well as the low- and highside driver supply. In the case of the MAX5061, use one or more 0.1µF low-ESR ceramic capacitors between V<sub>CC</sub> and PGND to reject the noise spikes due to high-current driver switching.

The TQFN-28 and TSSOP-16 are thermally enhanced packages and can dissipate up to 2.7W and 1.7W, respectively. The high-power packages allow the high-frequency, high-current buck converter to operate from a 12V or 24V bus. Calculate power dissipation in the MAX5060/MAX5061 as a product of the input voltage and the total V<sub>CC</sub> regulator output current (I<sub>CC</sub>). I<sub>CC</sub> includes quiescent current (I<sub>Q</sub>) and gate-drive current (IDD):

$$
P_D = V_{IN} \times I_{CC}
$$

$$
I_{\rm CC} = I_{\rm Q} + [f_{\rm SW} \times (Q_{\rm G1} + Q_{\rm G2})]
$$

where Q<sub>G1</sub> and Q<sub>G2</sub> are the total gate charge of the low-side and high-side external MOSFETs at  $VGATE =$  $5V$ ,  $I_Q$  is 3.5mA (typ), and fsw is the switching frequency of the converter.

#### *Undervoltage Lockout (UVLO)*

The MAX5060/MAX5061 include an undervoltage lockout with hysteresis and a power-on-reset circuit for converter turn-on and monotonic rise of the output voltage. The UVLO rising threshold is internally set at 4.35V with a 200mV hysteresis. Hysteresis at UVLO eliminates chattering during startup.

Most of the internal circuitry, including the oscillator, turns on when the input voltage reaches 4V. The MAX5060/MAX5061 draw up to 3.5mA of current before the input voltage reaches the UVLO threshold.

#### *Soft-Start*

The MAX5060/MAX5061 has an internal digital soft-start for a monotonic, glitch-free rise of output voltage. Softstart is achieved by the controlled rise of error amplifier dominant input in steps using a 5-bit counter and a 5-bit DAC. The soft-start DAC generates a linear ramp from 0 to 0.7V. This voltage is applied to the error amplifier at a third (noninverting) input. As long as the soft-start voltage is lower than the reference voltage, the system will converge to that lower reference value. Once the softstart DAC output reaches 0.6V, the reference takes over and the DAC output continues to climb to 0.7V assuring that it is out of the way of the reference voltage.

#### *Internal Oscillator*

The internal oscillator generates a clock with the frequency proportional to the inverse of RT. The oscillator frequency is adjustable from 125kHz to 1.5MHz with better than 8% accuracy using a single resistor connected from RT/SYNC to SGND (MAX5060) and from RT/SYNC/EN to SGND (MAX5061). The frequency accuracy avoids the over-design, size, and cost of passive filter components like inductors and capacitors. Use the following equation to calculate the oscillator frequency:

for  $120k\Omega \leq R_T \leq 500k\Omega$ :

$$
R_T = \frac{6.25 \times 10^{10}}{f_{SW}}
$$

for  $40k\Omega \leq R_T \leq 120k\Omega$ :

$$
R_T = \frac{6.40 \times 10^{10}}{f_{SW}}
$$
 Figures 1 and 2).

The oscillator also generates a 2VP-P voltage-ramp signal for the PWM comparator and a 180° out-of-phase clock signal for CLKOUT (MAX5060) to drive a second DC-DC converter out-of-phase.

#### *Synchronization*

The MAX5060/MAX5061 can be easily synchronized by connecting an external clock to RT/SYNC (MAX5060) or RT/SYNC/EN (MAX5061). If an external clock is present, then the internal oscillator is disabled and the external clock is used to run the MAX5060/MAX5061. If the external clock is removed, the absence of clock for 32µs is detected and the circuit starts switching from the internal oscillator. Pulling RT/SYNC on the MAX5060 or RT/SYNC/EN on the MAX5061 to ground for at least 50µs disables the converter.

Use an open-collector transistor to synchronize the MAX5060/MAX5061 with the external system clock (see



*Figure 5. MAX5060 Control Loop*

### *Control Loop*

The MAX5060/MAX5061 use an average-current-mode control scheme to regulate the output voltage (Figure 5). The main control loop consists of an inner current loop and an outer voltage loop. The inner loop controls the output current (IPHASE), while the outer loop controls the output voltage. The inner current loop absorbs the inductor pole reducing the order of the outer voltage loop to that of a single-pole system.

The current loop consists of a current-sense resistor (RSENSE), a current-sense amplifier (CA), a currenterror amplifier (CEA), an oscillator providing the carrier ramp, and a PWM comparator (CPWM) (Figure 6). The precision CA amplifies the sense voltage across RS by a factor of 34.5. The inverting input to the CEA senses the CA output. The CEA output is the difference between the voltage-error-amplifier output (EAOUT) and the amplified voltage from the CA. The RC compensation networks connected to CLP provide external frequency compensation for the CEA. The start of every

clock cycle enables the high-side drivers and initiates a PWM ON cycle. Comparator CPWM compares the output voltage from the CEA with a 0 to 2V ramp from the oscillator. The PWM ON cycle terminates when the ramp voltage exceeds the error voltage.

The MAX5060 outer voltage control loop consists of the differential amplifier (DIFF AMP), reference voltage, and VEA. The unity-gain differential amplifier provides truedifferential remote sensing of the output voltage. The differential amplifier output connects to the inverting input (EAN) of the VEA. For MAX5061, the DIFF AMP is bypassed and the inverting input is available to the pin for direct feedback. The noninverting input of the VEA is internally connected to an internal precision reference voltage. The MAX5060/MAX5061 reference voltage is set to 0.6V. The VEA controls the inner current loop (*Figure* 4). Use a resistive feedback network to set the VEA gain as required by the adaptive voltage-positioning circuit (see the *Adaptive Voltage Positioning* section).



*Figure 6. Phase Circuit*

#### *Current-Sense Amplifier*

The differential current-sense amplifier (CA) provides a DC gain of 34.5. The maximum input offset voltage of the current-sense amplifier is 1mV and the commonmode voltage range is 0 to 5.5V ( $IN = 7V$  to 28V). The current-sense amplifier senses the voltage across a current-sense resistor. The maximum common-mode voltage is 3.6V when  $V_{IN} = 5V$ . The common-mode voltage range determines the maximum output voltage of the buck converter.

#### *Peak-Current Comparator*

The peak-current comparator provides a path for fast cycle-by-cycle current limit during extreme fault conditions such as an output inductor malfunction (Figure 5). Note the average current-limit threshold of 26.9mV still limits the output current during short-circuit conditions. To prevent inductor saturation, select an output inductor with a saturation current specification greater than the average current limit. Proper inductor selection ensures that only the extreme conditions trip peak-current comparator, such as a broken output inductor. The 60mV threshold for triggering the peak-current limit is twice the full-scale average current-limit voltage threshold. The peak-current comparator has only a 260ns delay.

#### *Current-Error Amplifier*

The MAX5060/MAX5061 has a transconductance current-error amplifier (CEA) with a typical  $g_m$  of 550 $\mu$ S and 320µA output sink- and source-current capability. The current-error amplifier output CLP, serves as the inverting input to the PWM comparator. CLP is externally accessible to provide frequency compensation for the inner current loops (Figure 5). Compensate (CEA) so the inductor current down slope, which becomes the up slope to the inverting input of the PWM comparator, is less than the slope of the internally generated voltage ramp (see the *Compensation* section).

#### *PWM Comparator and R-S Flip-Flop*

The PWM comparator (CPWM) sets the duty cycle for each cycle by comparing the output of the current-error amplifier to a 2VP-P ramp. At the start of each clock cycle, an R-S flip-flop resets and the high-side driver (DH) turns on. The comparator sets the flip-flop as soon as the ramp voltage exceeds the CLP voltage, thus terminating the ON cycle (Figure 5).

#### *Differential Amplifier (MAX5060)*

The differential amplifier (DIFF AMP) facilitates outputvoltage remote sensing at the load (Figure 5). It provides true-differential output voltage sensing while rejecting the common-mode voltage errors due to highcurrent ground paths. Sensing the output voltage directly at the load provides accurate load voltage sensing in high-current environments. The VEA provides the difference between the differential amplifier output (DIFF) and the desired output voltage. The differential amplifier has a bandwidth of 3MHz. The difference between SENSE+ and SENSE- is regulated to 0.6V for the MAX5060. Connect SENSE+ to the center of the resistive divider from the output to SENSE-. Connect SENSE- to PGND near the load.

#### *Voltage-Error Amplifier*

The VEA sets the gain of the voltage control loop. The VEA determines the error between the differential amplifier output and the internal reference voltage.

The VEA output clamps to 930mV relative to the internally generated common-mode voltage (V<sub>CM</sub>, 0.6V), thus limiting the maximum output current. The maximum average current-limit threshold is equal to the maximum clamp voltage of the VEA divided by the gain (34.5) of the current-sense amplifier. This results in accurate settings for the average maximum current for each phase. Set the VEA gain using RF and RIN (see Figures 1 and 2) for the amount of output voltage positioning required within the rated current range as discussed in the *Adaptive Voltage Positioning* section. The finite gain of the VEA introduces an error in the output voltage setting. Use the following equation to calculate the output voltage at no load condition.

$$
V_{\text{OUT(NL)}} = \left(1 + \frac{R_{\text{IN}}}{R_{\text{F}}}\right) \times \left(\frac{R_{\text{H}} + R_{\text{L}}}{R_{\text{L}}}\right) \times V_{\text{REF}}
$$

where  $R_H$  and  $R_L$  are the feedback resistor network (see the *Typical Application Circuits*) and VREF = 0.6V.

#### *Adaptive Voltage Positioning*

Powering new-generation processors requires new techniques to reduce cost, size, and power dissipation. Voltage positioning reduces the total number of output capacitors to meet a given transient response requirement. Setting the no-load output voltage slightly higher than the output voltage during nominally loaded conditions allows a larger downward-voltage excursion when the output current suddenly increases. Regulating at a lower output voltage under a heavy load allows a larger upward-voltage excursion when the output current suddenly decreases. Allowing a larger voltage-step excursion reduces the required number of output capacitors or allows for the use of higher ESR capacitors.

Voltage positioning may require the output to regulate away from a center value. Define the center value as the voltage where the output drops  $(\Delta V)$ OUT $/2$ ) at one half the maximum output current (Figure 7).

Set the voltage-positioning window  $(\Delta V)$ UT) using the resistive feedback of the voltage-error amplifier (VEA). Use the following equations to calculate the voltagepositioning window (Figure 5):

$$
\Delta V_{OUT} = \frac{I_{OUT} \times R_{IN}}{G_C \times R_F} \times \frac{R_H + R_L}{R_L}
$$

$$
G_C = \frac{0.0289}{R_S}
$$

RIN and RF are the input and feedback resistors of VEA.  $G_C$  is the current-loop transconductance and  $R_S$ is the current-sense resistor.

#### *MOSFET Gate Drivers (DH\_, DL\_)*

The high-side (DH) and low-side (DL) drivers drive the gates of external n-channel MOSFETs (Figures 1 and 2). The drivers' 4A peak sink- and source-current capability provides ample drive for the fast rise and fall times of the switching MOSFETs. Faster rise and fall times result in reduced cross-conduction losses. For modern CPU voltage-regulating module applications, where the duty cycle is less than 50%, choose high-side MOSFETs (Q1)



*Figure 7. Defining the Voltage-Positioning Window*

with a moderate R<sub>DS(ON)</sub> and a very low gate charge. Choose low-side MOSFETs  $(Q2)$  with very low RDS(ON) and moderate gate charge. Size the high-side and lowside MOSFETs to handle the peak and RMS currents during overload conditions.

The driver block also includes a logic circuit that provides an adaptive nonoverlap time to prevent shoot-through currents during transition. The typical nonoverlap time is 35ns between the high-side and low-side MOSFETs.

#### *BST*

The MAX5060 uses  $V_{DD}$  to power the low- and high-side MOSFET drivers. The low- and high-side drivers in the MAX5061 are powered from  $V_{CC}$ . The high-side driver derives its power through a bootstrap capacitor and V<sub>DD</sub> supplies power internally to the low-side driver. Connect a 0.47µF low-ESR ceramic capacitor between BST and LX. Connect a Schottky rectifier from BST to V<sub>DD</sub> on the MAX5060, or to  $V_{CC}$  on the MAX5061. Reduce the PC board area formed by the boost capacitor and rectifier.

*MAX5060/MAX5061*

MAX5060/MAX506

#### *Protection*

The MAX5060 includes a power-good generator (PGOOD) for undervoltage protection (UVP), and a reverse current-limit protection; the MAX5060/MAX5061 include a hiccup current-limit protection to prevent damage to the powered electronic circuits. Additionally, the MAX5060 includes output overvoltage protection (OVP).

#### *PGOOD Generator (MAX5060)*

A PGOOD comparator compares the differential amplifier output (DIFF) against 0.90 times the set output voltage for undervoltage monitoring (see Figure 8). Use a 10kΩ pullup resistor from PGOOD to a voltage source less than or equal to V<sub>CC</sub>.

#### *Current Limit*

The VEA output is clamped to 930mV with respect to the common-mode voltage (V<sub>CM</sub>). Average current-mode control has the ability to limit the average current sourced by the converter during a fault condition. When a fault condition occurs, the VEA output clamps to 930mV with respect to the common-mode voltage (0.6V) to limit the maximum current sourced by the converter to  $I_{LIMIT}$  = 26.9mV/RS.

The hiccup current limit overrides the average current limit. The MAX5060/MAX5061 include hiccup currentlimit protection to reduce the power dissipation during a fault condition. The hiccup current-limit circuit derives inductor current information from the output of the current amplifier. This signal is compared against one half of VCLAMP(EA). With no resistor connected from the LIM pin to ground, the hiccup current limit is set at 90% of the full-load average current limit. Use REXT to increase the hiccup current limit from 90% to 100% of the fullload average limit (see Figures 1 and 2). The hiccup current limit can be disabled by connecting LIM to SGND. In this case, the circuit will follow the average current-limit action during overload conditions.

An internal clamp limits the continuous reverse current the buck converter sinks when a higher voltage is applied at the output. The reverse current limit translated at the current-amplifier input is -2.3mV (typ). The maximum reverse current the converter sinks depends on the current-sense resistor. Normally it is about 10% of the full load current.

#### *Overvoltage Protection (OVP) (MAX5060)*

The OVP comparator compares the OVI input to the overvoltage threshold. The overvoltage threshold is typically +12.7% above the internal 0.6V reference voltage. A detected overvoltage event latches the comparator output

forcing the power stage into the OVP state. In the OVP state, the high-side MOSFET turns off and the low-side MOSFET latches on. Connect DIFF to OVI for differential output sensing and overvoltage protection. Alternately, use a separate sensing network from VOUT to SGND. Connect OVI to the center tap of a resistor-divider from VOUT to SGND. In this case, the center tap is compared against 1.276V. Add an RC delay to reduce the sensitivity of the overvoltage circuit and avoid nuisance tripping of the converter (Figure 9). Disable the overvoltage function by connecting OVI to SGND.



*Figure 8. PGOOD Generator*



*Figure 9. Overvoltage Protection Input Delay*

*MAX5060/MAX5061* MAX5060/MAX5061

*MAX5060/MAX5061* MAX5060/MAX506

#### *Parallel Operation*

For applications requiring large output current, parallel two or more MAX5060s (multiphase operation) to increase the available output current. The paralleled converters operate at the same switching frequency but different phases keep the input capacitor ripple RMS currents to a minimum. The MAX5060 provides the clock output (CLKOUT), which is 180° out-of-phase with respect to DH. For the MAX5061, the out-of-phase clock can be easily generated using a simple inverter and driving it from the LX node. Use CLKOUT to drive the second DC-DC converter to double the effective switching frequency and reduce the input capacitor ripple current (see Figure 10).

To drive multiple converters out-of-phase, use a delay circuit to set 90° of phase shift (4 paralleled converters), or 60° of phase shift (6 converters in parallel). Designate one converter as master and the remaining converters as slaves. Connect the master and slave controllers in a daisy-chain configuration as shown in Figure 11. Choose the appropriate phase shift for minimum ripple currents at the input and output capacitors. The master controller senses the output differential voltage through SENSE+ and SENSE- and generates the DIFF voltage. Disable the voltage sensing of the slaved controllers by leaving DIFF unconnected (floating). Figure 11 shows a typical application circuit using four MAX5060s. This circuit provides two phases at a 12V input voltage and a 0.6V to 5V output voltage range.



*Figure 10. Parallel Configuration of MAX5060*

/VI /I X I /VI



*Figure 11. Parallel Configuration of Multiple MAX5060s*

*MAX5060/MAX5061*

MAX5060/MAX5061

# MAX5060/MAX5061 *MAX5060/MAX5061*

### *Applications Information*

#### *Inductor Selection*

The switching frequency, peak inductor current, and allowable ripple at the output determine the value and size of the inductor. Selecting higher switching frequencies reduces the inductance requirement, but at the cost of lower efficiency. The charge/discharge cycle of the gate and drain capacitances in the switching MOSFETs create switching losses. The situation worsens at higher input voltages, since switching losses are proportional to the square of the input voltage. The MAX5060 can operate up to 1.5MHz, however for  $V_{IN}$  > +12V, use lower switching frequencies to limit the switching losses.

Use the following equation to determine the minimum inductance value:

$$
L_{MIN} = \frac{(V_{INMAX} - V_{OUT}) \times V_{OUT}}{V_{INMAX} \times f_{SW} \times \Delta I_{L}}
$$

Choose ∆IL equal to approximately 40% of the output current. Since ∆IL affects the output-ripple voltage, the inductance value may need minor adjustment after choosing the output capacitors. Higher values reduce the output ripple, but at the cost of degraded transient response. Lower values have higher output ripple but better transient response. Also, lower inductor values correspond to smaller magnetics.

Choose inductors from the standard high-current, surfacemount inductor series available from various manufacturers. Particular applications may require custommade inductors. Use high-frequency core material for custom inductors. High ∆IL causes large peak-to-peak flux excursion, which increases the core losses at higher frequencies. The high-frequency operation coupled with high ∆I<sub>L</sub> reduces the required minimum inductance and even makes the use of planar inductors possible. The advantages of using planar magnetics include low-profile design, excellent current-sharing between modules due to the tight control of parasitics, and low cost.

For example, calculate the minimum inductance at VIN(MAX) = 13.2V, VOUT = 1.8V,  $\Delta I_L$  = 8A, and fsw = 330kHz:

$$
L_{MIN} = \frac{(13.2 - 1.8) \times 1.8}{13.2 \times 330k \times 8} = 0.6 \mu H
$$

The average-current-mode control feature of the MAX5060/MAX5061 limits the maximum peak inductor current and prevents the inductor from saturating. Choose an inductor with a saturating current greater than the worst-case peak inductor current. The hiccup current-limit circuit is masked during startup to avoid unintentional hiccup when large output capacitors are used.

Use the following equation to determine the worst-case inductor current:

$$
L_{\text{LPEAK}} = \frac{V_{\text{CL}}}{R_{\text{S}}} + \frac{\Delta I_{\text{L}}}{2}
$$

where R<sub>S</sub> is the sense resistor and  $V_{\text{CL}} = 0.0282V$ .

#### *Switching MOSFETs*

When choosing a MOSFET for voltage regulators, consider the total gate charge, R<sub>DS(ON)</sub>, power dissipation, and package thermal impedance. The product of the MOSFET gate charge and on-resistance is a figure of merit, with a lower number signifying better performance. Choose MOSFETs optimized for high-frequency switching applications.

The average current from the MAX5060/MAX5061 gatedrive output is proportional to the total capacitance it drives at DH and DL. The power dissipated in the MAX5060/MAX5061 is proportional to the input voltage and the average drive current. See the *IN, VCC, and VDD* section to determine the maximum total gate charge allowed from the combined driver outputs.

The gate charge and drain capacitance  $(CV^2)$  loss, the cross-conduction loss in the upper MOSFET due to finite rise/fall time, and the I2R loss due to RMS current in the MOSFET RDS(ON) account for the total losses in the MOSFET. Estimate the power loss (PD<sub>MOS</sub>) caused by the high-side and low-side MOSFETs using the following equations:

$$
PD_{MOS-HI} = (Q_G \times V_{DD} \times f_{SW}) +
$$

$$
\left(\frac{V_{IN} \times I_{OUT} \times (t_R + t_F) \times f_{SW}}{4}\right) + (1.4R_{DS(ON)} \times I^2 RMS-HI)
$$

where  $Q_G$ , R<sub>DS(ON)</sub>, t<sub>R</sub>, and t<sub>F</sub> are the upper-switching MOSFET's total gate charge, on-resistance at +25°C, rise time, and fall time, respectively.

$$
I_{RMS-HI} = \sqrt{(1^2DC + 1^2PK + I_{DC} \times I_{PK}) \times \frac{D}{3}}
$$

where  $D = V_{\text{OUT}}/V_{\text{IN}}$ ,  $I_{\text{DC}} = (I_{\text{OUT}} - \Delta I_{\text{L}}/2)$  and  $I_{\text{PK}} =$  $(IOUT + \Delta I_L/2).$ 

$$
PD_{MOS-LO} = (Q_G \times V_{DD} \times f_{SW}) +
$$
\n
$$
\left(\frac{2 \times C_{OSS} \times V_{IN}^{2} \times f_{SW}}{3}\right) + \left(1.4R_{DS(ON)} \times I^{2}RMS - LO\right)
$$
\n
$$
I_{RMS-LO} = \sqrt{\left(I^{2}DC + I^{2}PK + I_{DC} \times I_{PK}\right) \times \frac{(1-D)}{3}}
$$

where  $C<sub>OSS</sub>$  is the MOSFET drain-to-source capacitance.

For example, from the typical specifications in the *Applications Information* section with  $V_{\text{OUT}} = 1.8V$ , the high-side and low-side MOSFET RMS currents are 7.8A and 18.5A, respectively for 20A. Ensure that the thermal impedance of the MOSFET package keeps the junction temperature at least +25°C below the absolute maximum rating. Use the following equation to calculate maximum junction temperature:

$$
T_J = (PD_{MOS} \times \theta_{JA}) + T_A
$$

where  $\theta$ JA and  $T_A$  are the junction-to-ambient thermal impedance and ambient temperature, respectively.

#### *Input Capacitors*

The discontinuous input-current waveform of the buck converter causes large ripple currents in the input capacitor. The switching frequency, peak inductor current, and the allowable peak-to-peak voltage ripple reflected back to the source dictate the capacitance requirement. Increasing switching frequency or paralleling multiple outof-phase converters lowers the peak-to-average current ratio, yielding a lower input capacitance requirement for the same load current.

The input ripple is comprised of ∆VQ (caused by the capacitor discharge) and ∆V<sub>ESR</sub> (caused by the ESR of the capacitor). Use low-ESR ceramic capacitors with high-ripple-current capability at the input. Assume the contributions from the ESR and capacitor discharge are equal to 30% and 70%, respectively. Calculate the input capacitance and ESR required for a specified ripple using the following equation:

$$
ESR_{IN} = \frac{(\Delta V_{ESR})}{(\text{I}_{OUT} + \frac{\Delta I_L}{2})}
$$

$$
C_{IN} = \frac{\text{I}_{OUT} \times D(1-D)}{\Delta V_Q \times f_{SW}}
$$

where  $I_{\text{OUT}}$  is the output current of the converter.

For example, at  $V_{\text{OUT}} = 1.8V$ , the ESR and input capacitance are calculated for the input peak-to-peak ripple of 100mV or less yielding an ESR and capacitance value of 1.25mΩ and 110µF.

#### *Output Capacitors*

The worst-case peak-to-peak and capacitor RMS ripple current, the allowable peak-to-peak output ripple voltage, and the maximum deviation of the output voltage during step loads determine the capacitance and the ESR requirements for the output capacitors.

In buck converter design, the output-current waveform is continuous and this reduces peak-to-peak ripple current in the output capacitor equal to the inductor ripple current. Calculate the capacitance, the ESR of the output capacitor, and the RMS ripple current rating of the output capacitor based on the following equations.

$$
ESR_{OUT} = \frac{\Delta V_{OESR}}{\Delta I_L}
$$

$$
C_{OUT} = \frac{\Delta I_L}{8 \times \Delta V_{OO} \times f_{SW}}
$$

where ∆V<sub>OESR</sub> and ∆V<sub>OQ</sub> are the output-ripple contributions due to ESR and the discharge of output capacitor, respectively.

In the dynamic load environment, the allowable deviation of output voltage during the fast transient load dictates the output capacitance and ESR. The output capacitors supply the load step until the controller responds with a greater duty cycle. The response time (tRESPONSE) depends on the closed-loop bandwidth of the converter. The resistive drop across the capacitor ESR and capacitor discharge causes a voltage drop during a step load. Use a combination of SP polymer and ceramic capacitors for better transient load and ripple/noise performance.

Keep the maximum output voltage deviation less than or equal to the adaptive voltage-positioning window (∆VOUT). Assume 50% contribution each from the output capacitance discharge and the ESR drop. Use the following equations to calculate the required ESR and capacitance value:

$$
ESR_{OUT} = \frac{\Delta V_{ESR}}{I_{STEP}}
$$

$$
C_{OUT} = \frac{I_{STEP} \times I_{RESPONSE}}{\Delta V_Q}
$$

where ISTEP is the load step and tRESPONSE is the response time of the controller. Controller response time depends on the control-loop bandwidth.

#### *Current Limit*

In addition to the average current limit, the MAX5060/MAX5061 also have hiccup current limit. The hiccup current limit is set to 10% below the average current limit to ensure that the circuit goes in hiccup mode during continuous output short circuit. Connecting a resistor from LIM to ground increases the hiccup current limit, while shorting LIM to ground disables the hiccup current-limit circuit.

#### *Average Current Limit*

The average-current-mode control technique of the MAX5060/MAX5061 accurately limits the maximum output current. The MAX5060/MAX5061 sense the voltage across the sense resistor and limit the peak inductor current (IL-PK) accordingly. The ON cycle terminates when the current-sense voltage reaches 25.5mV (min). Use the following equation to calculate the maximum current-sense resistor value:

$$
R_{\rm S} = \frac{0.0255}{I_{\rm OUT}}
$$
  
PD<sub>R</sub> =  $\frac{0.75 \times 10^{-3}}{R_{\rm S}}$ 

where PD<sub>R</sub> is the power dissipation in the sense resistors. Select a 5% lower value of R<sub>S</sub> to compensate for any parasitics associated with the PC board. Also, select a non-inductive resistor with the appropriate power rating.

#### *Hiccup Current Limit*

The hiccup current-limit value is always 10% lower than the average current-limit threshold, when LIM is left unconnected. Connect a resistor from LIM to SGND to increase the hiccup current-limit value from 90% to

100% of the average current-limit value. The average current-limit architecture accurately limits the average output current to its current-limit threshold. If the hiccup current limit is programmed to be equal or above the average current-limit value, the output current will not reach the point where the hiccup current limit can trigger. Program the hiccup current limit at least 5% below the average current limit to ensure that the hiccup current-limit circuit triggers during overload. See the Hiccup Current Limit vs. REXT graph in the *Typical Operating Characteristics*.

#### *Reverse Current Limit (MAX5060)*

The MAX5060 limits the reverse current in case VBUS is higher than the preset output voltage. Calculate the maximum reverse current based on V<sub>CLR</sub>, the reversecurrent-limit threshold and the current-sense resistor.

$$
I_{REVERSE} = \frac{V_{CLR}}{R_S}
$$

where IREVERSE is the total reverse current sink into the converter and  $V_{\text{Cl}}$   $R = 2.3$ mV (typ).

#### *Compensation*

The main control loop consists of an inner current loop and an outer voltage loop. The MAX5060/MAX5061 use an average current-mode control scheme to regulate the output voltage (Figure 5). IPHASE is the inner average current loop. The VEA output provides the controlling voltage for this current source. The inner current loop absorbs the inductor pole reducing the order of the outer voltage loop to that of a single-pole system.

A resistive feedback network around the VEA provides the best possible response, since there are no capacitors to charge and discharge during large-signal excursions.  $R_F$  and  $R_{IN}$  determine the VEA gain. Use the following equation to calculate the value of RF:

$$
R_F = \frac{I_{OUT} \times R_{IN}}{G_C \times \Delta V_{OUT}}
$$

$$
G_C = \frac{0.0289}{R_S}
$$

where  $G_C$  is the current-loop transconductance and Rs is the value of the sense resistor.

When designing the current-control loop ensure that the inductor downslope (when it becomes an upslope at the CEA output) does not exceed the ramp slope. This is a necessary condition to avoid sub-harmonic oscillations similar to those in peak current-mode control with insufficient slope compensation.



Use the following equation to calculate the resistor RCF:

$$
R_{\text{CF}} \leq \frac{2 \times f_{SW} \times L \times 10^2}{V_{\text{OUT}} \times R_S}
$$

C<sub>CF</sub> provides a low-frequency pole while R<sub>CF</sub> provides a midband zero. Place a zero  $(f_Z)$  to obtain a phase bump at the crossover frequency. Place a high-frequency pole (fp) at least a decade away from the crossover frequency to reduce the influence of the switching noise and achieve maximum phase margin.

Use the following equations to calculate CCF and CCFF:

$$
C_{\text{CF}} = \frac{1}{2 \times \pi \times f_Z \times R_{\text{CF}}}
$$

$$
C_{\text{CFF}} = \frac{1}{2 \times \pi \times f_P \times R_{\text{CF}}}
$$

#### *Power Dissipation*

The TQFN-28 and TSSOP-16 are thermally enhanced packages and can dissipate about 2.7W and 1.7W, respectively. The high-power packages make the highfrequency, high-current buck converter possible to operate from a 12V or 24V bus. Calculate power dissipation in the MAX5060/MAX5061 as a product of the input voltage and the total  $V_{CC}$  regulator output current  $(ICC)$ . ICC includes quiescent current  $(I<sub>O</sub>)$  and gatedrive current (IDD):

 $P_D = V_{IN} \times I_{CC}$ 

$$
ICC = IQ + [fSW \times (QG1 + QG2)]
$$

where Q<sub>G1</sub> and Q<sub>G2</sub> are the total gate charge of the low-side and high-side external MOSFETs at  $V<sub>GATE</sub>$  = 5V,  $I_Q$  is estimated from the Supply Current ( $I_Q$ ) vs. Frequency graph in the *Typical Operating Characteristics*, and fsw is the switching frequency of the converter.

Use the following equation to calculate the maximum power dissipation (PDMAX) in the chip at a given ambient temperature (TA) :

#### MAX5060:

PDMAX = 34.5 x (150 - TA)..............mW

$$
\mathsf{MAX5061:}\newline
$$

$$
P_{DMAX} = 21.3 \times (150 - T_A) \dots \dots \dots \dots mW
$$

#### *PC Board Layout*

*MAX5060/MAX5061*

MAX5060/MAX5061

Use the following guidelines to layout the switching voltage regulator.

- 1) Place the IN, V<sub>CC</sub>, and V<sub>DD</sub> bypass capacitors close to the MAX5060/MAX5061.
- 2) Minimize the area and length of the high-current loops from the input capacitor, upper switching MOSFET, inductor, and output capacitor back to the input capacitor negative terminal.
- 3) Keep short the current loop formed by the lower switching MOSFET, inductor, and output capacitor.
- 4) Place the Schottky diodes close to the lower MOSFETs and on the same side of the PC board.
- 5) Keep the SGND and PGND isolated and connect them at one single point close to the negative terminal of the input filter capacitor.
- 6) Run the current-sense lines CSP and CSN very close to each other to minimize the loop area. Similarly, run the remote voltage sense lines SENSE+ and SENSE- close to each other. Do not cross these critical signal lines through power circuitry. Sense the current right at the pads of the current-sense resistors.
- 7) Avoid long traces between the V<sub>DD</sub> (MAX5060)/V<sub>CC</sub> (MAX5061) bypass capacitors, driver output of the MAX5060/MAX5061, MOSFET gates, and PGND. Minimize the loop formed by the V<sub>CC</sub> bypass capacitors, bootstrap diode, bootstrap capacitor, MAX5060/MAX5061, and upper MOSFET gate.
- 8) Place the bank of output capacitors close to the load.
- 9) Distribute the power components evenly across the board for proper heat dissipation.
- 10) Provide enough copper area at and around the switching MOSFETs, inductor, and sense resistors to aid in thermal dissipation.
- 11) Use 4oz copper to keep the trace inductance and resistance to a minimum. Thin copper PC boards can compromise efficiency since high currents are involved in the application. Also, thicker copper conducts heat more effectively, thereby reducing thermal impedance.



*Chip Information*

**MAXM** 

TRANSISTOR COUNT: 5654 PROCESS: BiCMOS

**28 \_**

## *Package Information*

(The package drawing(s) in this data sheet may not reflect the most current specifications. For the latest package outline information go to **www.maxim-ic.com/packages**.)



## *Package Information (continued)*

(The package drawing(s) in this data sheet may not reflect the most current specifications. For the latest package outline information go to **www.maxim-ic.com/packages**.)



**MAXM** 

## *Package Information (continued)*

(The package drawing(s) in this data sheet may not reflect the most current specifications. For the latest package outline information go to **www.maxim-ic.com/packages**.)



*MAX5060/MAX5061* MAX5060/MAX5061

*Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.*

#### *Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600 \_* **31**

© 2005 Maxim Integrated Products Printed USA **MAXIM** is a registered trademark of Maxim Integrated Products, Inc.