# Contents

Introduction	1
High Pass Filter (resistor modification)	1
Important Note	1
Installation	2
Dimensions	3
Power Requirements	3
Mains Supply (rack units) DC Power Supply Indicators (rack units)	4 4
Phantom Power	4
Output Level Control	4
Connector Details	5
Amplifier Controls	6
1073 Module 1084 Module	6 7
Specifications	8
1073 and 1084 Modules	8
Recall Sheets	9
1073 - Vertical Module 1073 - Horizontal Module 1084 - Vertical Module 1084 - Horizontal Module	9 10 11 12
Service Information	13
Schematic Drawing Index - 1073/1084 Racks Schematic Drawing Index - 1073 Module Schematic Drawing Index - 1084 Module	13 13 14

## Introduction

These 45 series modules are the same as the original designs, and contain all of the original components.

### **1073 Channel Amplifiers**

These very popular sounding mic pre's are considered by many to capture the very essence of the Neve sound. In manufacture since the early 1970s, the Class A design offers 3 bands of EQ with one fixed high frequency and a high pass filter.

### **1084 Channel Amplifiers**


Based on the same technology as the 1073s, the 1084s again deliver the unique sound and quality of Neve. However, the 1084s offer additional features, including 3 switchable EQ bands with cut and boost, a high Q for presence and low pass/high pass filters.

# **High Pass Filter (resistor modification)**

### **Important Note**

The high pass filter in both the 1073 & 1084 modules is a passive design and as such must be correctly terminated to achieve a maximally flat response.

In order to achieve this there is a 5k1 resistor fitted inside the module on the back connector between pin E (0v) and pin K (fader send) see diagram below:



In situations where the **fader connection is not used** (most Neve 45 series consoles except BCM10's) then the resistor remains in place.

In situations where the **fader connection is used** (BCM10's and AMS Neve 1073/1084 racks) then the 5k1 resistor should be disconnected and replaced with a fader or potentiometer whose value is 4k7 / 5k ohms.

Failure to do so will result in incorrect levels and uneven frequency response.

### Installation

The 1073s and 1084s are available as stand-alone modules, or in a choice of two housings.

The 3U rack houses two modules mounted horizontally in a 19" rack-mounting unit.

The 5U rack houses eight modules mounted vertically in a 19" rack-mounting unit.

Both have rear panels with XLRs for transformer balanced I/O.

The 3U rack rear panel has a fused, voltage selector IEC mains input connector. The 5U rack has a free standing AC supply with a fused, voltage selector IEC mains input connector and connects to the rack via a connector and a 1.5 meter cable.

Modules of any combination can be fitted into a rack unit.

**Example: 5U Rack fitted with1084 modules** 

# **Additional Information**

\*Rack Mount Instructions \*

A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

B) Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.

C) Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

D) Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

E) Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

Recommended Tma =  $50 \deg C$ 

Mains Voltage Adjustment

- 1.) Switch off unit.
- 2.) Remove fuse.

3.) Turn inner barrel with screwdriver or coin until correct voltage figure is under the white arrow on the housing.

4.) Replace fuse.

## **Dimensions**

Stand-alone Modules	Width mm (inches)	Height mm (inches)	Depth mm (inches)	Approx. Weight kg (lbs)	
1073 Module	45 (1.8)	222 (8.75)	254 (10)	2.5 (5.5)	
1084 Module	45 (1.8)	222 (8.75)	254 (10)	2.5 (5.5)	

19" Rack Mounting		Depth mm (inches)	Height mm (inches)	Approx. Weight kg (lbs)
2 Module Version	3	405 (16)	133 (5.25)	11 (24.2) *
8 Module Version	5	405 (16)	222 (8.75)	30 (66) *

\* Fully populated rack

# **Power Requirements**

Rack Units	3U	5U
Rated Voltage	100-230V AC	100-230V AC
Rated Frequency	50-60 Hz	50-60Hz
Rated Current	0.5A Max	0.8A Max
Primary Protection Fuse:		
Operating Voltage	100-230V AC	100-230V AC
Fuse Rating and Type	T0.5A H 250V 20mm x 5mm CERAMIC	T1A H 250V 20mm x 5mm CERAMIC
Location	IEC Mains connector	IEC Mains connector
Secondary Protection Fuse:		
Output Voltage		24V DC
Fuse Rating and Type		T 2.0A L 250V 20mm x 5mm GLASS
Location		F1
Output Voltage		48V DC
Fuse Rating and Type		T 250mA L 250V 20mm x 5mm GLASS
Location		F2

Modules	Power
1073 Module	106mA $\pm 10\text{mA}$ at 24V DC. Negative Earth
1084 Module	106mA $\pm 10\text{mA}$ at 24V DC. Negative Earth

### Mains Supply (rack units)

The 3U rack has a fused, voltage selector IEC mains input connector.

The 5U rack has a free standing AC supply with a fused, voltage selector IEC mains input connector and connects to the rack via a connector and a 1.5 meter cable.

The mains switch on the rear panel of the 3U rack unit is non-illuminating.

The CH (chassis) and OV are linked internally.

### **DC Power Supply Indicators (rack units)**

The red LED on the front panel of both 3U and 5U rack units indicates +24V power healthy when illuminated.

The green LED on the front panel of both 3U and 5U rack units indicates  $\pm 48V$  power healthy when illuminated.

### **Phantom Power**


Phantom power can be supplied to each module by pressing the phantom power switch on the front panel of the 3U or 5U rack. The LED in the switch will illuminate confirming that phantom power is supplied.


# **Output Level Control**

Each channel has an independent Output Level Control. The control is post-input, post-EQ and pre-output. This control can reduce the level at the output.

When the Output Control is fully clockwise the output gain is unity. The output is 20dB down with the control in the mid-position.

# **Connector Details**






# **Amplifier Controls**

### 1073 Module

EQL PHASE





## 1084 Module

•

40 MIC +

+ 7.2• 4.8 KHz

2 3.2 +

60 0 0 50 40 -20 -10 -0 +10 +10	High Frequency:	Smooth +/-16dB shelving wit selectable frequencies of 10kHz, 12kHz and 16kHz.
	Low Frequency:	Smooth +/-16dB shelving with selectable frequencies of 35Hz, 60Hz, 110Hz & 220Hz.
	Mid Frequency:	Smooth +/-12dB or +/-18dB peaking with switchable 'High Q', selectable centre frequencies of 0.36kHz, 0.7kHz, 1.6kHz, 3.2kHz, 4.8kHz & 7.2kHz.
4.8 0.35 Hz 3.2 1.6 0.7 0	High Pass Filter:	18dB per octave slope, switchable between 45Hz, 70Hz, 160Hz & 360Hz.
220 110 6 360 6 360 6	Low Pass Filter:	18dB per octave slope, switchable between 6kHz, 8kHz, 10kHz, 14kHz, & 18kHz.
10 • • • 10 70 • • • 14	EQL Button:	Switches the equaliser in or out of circuit.
EQL PHASE	Phase Button:	Gives 180° Phase change at Balanced Output.
• • •		




# **Specifications**

### 1073 and 1084 Modules


Microphone Input:	Input Impedance 300 $\Omega$ or 1200 $\Omega$ , gain +80db to +20dB in 5dB steps.
Line Input:	Input Impedance 10,000Ω bridging, gain +20dB to -10dB in 5dB steps. Both inputs are transformer balanced and earth free.
Output:	Maximum output is >+26dBu into 600Ω. Output impedance is 75Ω @1kHz. Output is transfomer balanced and earth free.
Distortion:	Not more than 0.07% from 50Hz to 10kHz at $+20$ dBu output (80kHz bandwidth) into 600 $\Omega$ .
Frequency Response:	+/-0.5dB 20Hz to 20kHz, -3dB at 40kHz Eq Out.
Noise:	Not more than -83dBu at all Line gain settings Eq In/Out (22Hz to 22kHz bandwidth). EIN better than -125dBu @ 60dB gain.

# **Recall Sheets**


### 1073 - Vertical Module




### 1073 - Horizontal Module



### 1084 - Vertical Module



### 1084 - Horizontal Module



# **Service Information**

# Schematic Drawing Index - 1073/1084 Racks


3U Horizontal Rack (AM5028)	AM5028 Assembly Drawing AM5028 Wiring Diagram
5U Vertical Rack (AM5033)	AM5033 Assembly Drawing AM5033 Wiring Diagram

# Schematic Drawing Index - 1073 Module

1073 Channel Amplifier (PL31073-C)	E10006 Block Diagram EH10023 Circuit Diagram
High Pass Filter (PL10182/C)	PL10182/C Assembly Drawing D/10019C Circuit Diagram
HF/LF EQ Frequency (PL10205)	PL10205 Assembly Drawing D/10042 Circuit Diagram
Presence Frequency (PL10211)	BA211 Assembly Drawing D/10048 Circuit Diagram
Mic Line Output (PL10283AV)	PL10283 Assembly Drawing EX10283 Circuit Diagram
Mic Amp/EQ Amp (PL10284)	PL10284 Assembly Drawing EX10284 Circuit Diagram
Sensitivity Switch (PL20033)	EK20033 Wiring Diagram
Low Frequency Switch (PL20065)	EK20065 Wiring Diagram
HP Filter Switch (PL20066)	EK20066 Wiring Diagram
Presence Switch (PL20105)	EK20105 Wiring Diagram

# Schematic Drawing Index - 1084 Module

1084 Channel Amplifier (PL31084-C)	EB20039 Block Diagram EH10036 Circuit Diagram
High Pass Filter (PL10182/A)	PL10182/A Assembly Drawing D/10019A Circuit Diagram
Low Pass Filter (PL10194/A)	PL10194/A Assembly Drawing D10031/A Circuit Diagram
HF/LF EQ Frequency (PL10205)	See 1073 drawing section
Presence Frequency (PL10211/A)	PL10211/A Assembly Drawing D/10048/A Circuit Diagram
Mic Line Output (PL10283AV)	See 1073 drawing section
Mic Amp/EQ Amp (PL10284)	See 1073 drawing section
Sensitivity Switch (PL20033)	See 1073 drawing section
Low Frequency Switch (PL20065)	See 1073 drawing section
Presence Switch (PL20105)	See 1073 drawing section
High Frequency Switch (PL20106)	EK20106 Wiring Diagram
HP/LP Filter Switch (PL20107)	EK20107 Wiring Diagram






# Title:1073/1084 Vertical Rack Wiring

## Schedule Nr: AM5033

Issue: 5

	CABLE		FROM	:-			ROUTIN	NG	TO:-		
Code	Туре	Colour	Pin	Connector	Location	Signal	Length	Comment	Pin	Connector	Location
310-166	32/0.2	Green/Yellow	Е	420-618 Housing	R/P				Tag	4mm Binding post	R/P
310-219	32/0.2	Black	А	420-353 Contacts					4	J1 24VAC	SZN825B084
310-218	32/0.2	Red	В						3	24VAC	
310-084	32/0.2	Orange	С						2	48VAC	
WR13011	32/0.2	Yellow	D						1	48VAC	
310-166	32/0.2	Green/Yellow		330-069	Mid Rail					330-069	Backpanel
WR13010	32/0.2	Blue	2	J2 0V24	SZN825B084				Tag	Solder	0V Distribution
310-218	32/0.2	Red	1	J2 +24V	SZN825B084				Tag	Solder	+24V
											Distribution
WR13010	32/0.2	Blue	Tag	Solder	0V Distribution				Chassis	330-069	Top mid rail
310-031	7/0.2	Orange	1	420-691 Housing	SYN824C128				2&3	Via 6K8 res's	Mic In Ch 1
310-031	7/0.2	Orange	9	420-612 Contacts	(Ch1&2)				2&3	Via 6K8 res's	Mic In Ch 2
310-031	7/0.2	Orange	1	420-691 Housing	SYN824C128				2&3	Via 6K8 res's	Mic In Ch 3
310-031	7/0.2	Orange	9	420-612 Contacts	(Ch3&4)				2&3	Via 6K8 res's	Mic In Ch 4
310-031	7/0.2	Orange	1	420-691 Housing	SYN824C128				2&3	Via 6K8 res's	Mic In Ch 5
310-031	7/0.2	Orange	9	420-612 Contacts	(Ch5&6)				2&3	Via 6K8 res's	Mic In Ch 6
310-031	7/0.2	Orange	1	420-691 Housing	SYN824B128				2&3	Via 6K8 res's	Mic In Ch 7
310-031	7/0.2	Orange	9	420-612 Contacts	(Ch7&8)				2&3	Via 6K8 res's	Mic In Ch 8
Insert conta	cts into all the	unused positions of	on the 420-	691 housings to impro-	ve retention force						
								Fit heatsink	1	LM317T	Side plate
								washer & bush	2	SZN825B084 U3	
								use H/S grease	3		

13 February, 2008






# Title: 1073/1084 Horizontal Rack

## Schedule Nr: AM5028

Issue:	1	
13346.		


	CABL	E	FROM:	-			ROUTIN	G	TO:-		
Code	Туре	Colour	Pin	Connector	Location	Signal	Length	Comment	Pin	Connector	Location
310-183	24/0.2	Green/Yellow	Е	330-071	IEC				Stud	330-454	Safety Earth
310-183	24/0.2	Green/Yellow		330-069	Chassis				Stud	330-454	Safety Earth
310-047	16/0.2	Brown	L	330-071	IEC			Sleeve with	1A	330-071	Switch
310-052	16/0.2	Blue	Ν	330-071	IEC			WA12005	2A	330-071	Switch
		Yellow			TF14021				1	CN20013	Switch
		Yellow			TF14021				Centre	Solder	TF19201
310-052	16/0.2	Blue	1(1of2)	Solder	TF19201				2	330-071	Switch
		Black			TF14021				1(2of2)	Solder	TF19201
		Brown			TF14021				3	Solder	TF19201
		Green			TF14021				2	Solder	TF19201
		Blue			TF14021				4(1of3)	Solder	TF19201
310-046	16/0.2	Black	4(2of3)	Solder	TF19201				4(2of3)	Solder	TF19201
		Red			TF14021				4(3of3)	Solder	TF19201
		Orange			TF14021				6	Solder	TF19201
		Violet			TF14021				5	Solder	TF19201
		Grey			TF14021				7	Solder	TF19201
		White			TF14021				3	J1 (25VAC)	SZN825A084
		White			TF14021				4	J1 (25VAC)	
310-052	16/0.2	Blue	2		SZN825A084				Bolt	330-069	Chassis
310-031	7/0.2	Orange	1	420-691 Housing	CN2				2+3	solder via 6K8 Res's	Mic In Ch1 XLR
310-031	7/0.2	Orange	9	420-612 Contacts	SYN824B12 8				2+3	solder via 6K8 Res's	Mic In Ch2 XLR


3 August, 2004



## EH 10023

Repert Neve & Company Ltd. own the copyright of this drawing which is not to be copyright of this drawing which is not to be copyright and the part is within a copyright and the permission






:


1 1		1	100
PF	D38000/LS	23.09.03	1
NAME	MOD. No.	DATE	ISS.


THIRD ANGLE PROJECTION	AMS NEVE PLC. owns the copyright to this drawing. It must not be copied in whole or in part, used for manuta- cture or otherwise disclosed without prior written consent of the company.	TITLE:	HIGH PAS	SS FILTE	R PCB ASSEMBLY		MIS EVE
	C AMS NEVE PLC.	DRAWN	APP'D	DATE	AMS NEVE PLC. BILLINGTON ROAD,	DRG No.	SHT
DRAWN TO B.S.308	SCALE 1:1	PF	DRA	22 00 02	BURNLEY LANCS BRIT SUB ENGLAND		C 1

182 cad



$\bigotimes$	The Neve Group of Companies	This drawing is the property of this company and			DATE	21/10/70 🍕
TITLE	B182 c&D	may not be reproduced or disclosed to a third party without the permission of this company.	A 19/7/71	10.299_0	DRAWING NUMBER	D/10,019 c & D







D/10,042


B 205

	<u> </u>		L2							
		B	LZ							
			C9			ĩ				
			]							
			L1							
							PF	D38000/LS	23.09.03	1
				1. 64	2.1.5		NAME	MOD. No.	DATE	ISS.
THIRD ANGLE PRO	JECTION	E PLC, owns the copyrigh awing. It must not be cc or in part, used for mar otherwise disclosed witho ten consent of the comp even pro-	ht TITLE: opied nufa- put aany.	PRESENC	E FREQU	ENCY PCB ASSEMBLY			AMS NEVI	2
DRAWN TO B.		EVE PLC.	DRAWN	APP'D	DATE	AMS NEVE PLC. BILLINGT	ON ROAD,	DRG N	lo.	SHT
		SCALE 1:1	1 PF	JAA	23.09.03	BURNLEY, LANCS, BB11 5UB, I	ENGLAND.	DI 10'	011	1



4 13-6-7	5-11241 g	r.					1	10 A. A. A.			T				1
$\bigotimes$	The	Neve	Group	of	Companies	This drawi	ng is the	e property of	this company a	and C	16/11/71	10,364	DATE	21/12/70	ß
TITLE	BA211								osed to a third this company.	5			DRÁWING NUMBER		8






BA283 AM & AV TITLE

This drawing is the property of this company and may not be reproduced or disclosed to a third party without the permission of this company.


B 7/6/72 10518 10518 N.T. DRAWING EX/10 283 NUMPED




i


			1.1.1.1.1.1	
	PF	D38000/LS	23.09.03	1
	NAME	MOD. No.	DATE	ISS.
-		0		1000


THIRD ANGLE PROJECTION	AMS NEVE PLC. owns the copyright to this drawing. It must not be copied in whole or in part, used for manufa- cture or otherwise disclosed without prior written consent of the company.	TITLE: 1	MIC AMF	P/EQ AMF	Y X 2 PCB ASSEMBLY	NAME		AMIS	S E
DRAWN TO B.S.308	© AMS NEVE PLC.	DRAWN	APP'D	DATE	AMS NEVE PLC. BILLINGTO			o	SHT
	SCALE 1:1	PF	DRA	23.09.03	BURNLEY. LANCS. BB11 5UB. E TEL. (01282) 457011 FAX. (0128	NGLAND. 2) 417282.	PI 102	84	1




EK 20033	Rupert Nave & Company Ltd. own the copyright of this drawing which is not to be copied, reproduced or disclosed, in part or whole, to a third party without written permission.	
WRJ51ep 3 TLACT	FF -50 -40 -30 -20 OFF +10 0 -10	-20
IL (m) 18 S2a   S5/M 4   W R 753 bro 4   Bh38k Br.W 6		0 0 0 A GN T2 TAMT
BASSE FIN H BASSE FIN H BASSE FIN H		Talin Io
BR438 fin H GM WR751 m Br439 fie P		270 - 430 - 2K2
WR75100 S2b BRASPS THU 6 GN		6 6 6 B
	120 330 330	
WR-75 16-0 BPJ283 (Find 7		· · 2_ 0 · 0
22 20 18 1 anl <sup>83</sup>	6 14 12 10 8 6 4	2 1 23
C WIRES 3 SOM LONG	2 1 ISSUE_ FIRST USED ON MATL 19-3-74. 19-10-73 DATE DRN. A.H.L FINISH	TOL. UNLESS OTHERWISE STATED
NB! SWITCH STOPPED DOWN TO 22 WAY	10878 CHANGE TRACED GT TITLE SENSITIVITY SWITCH NOTE Nº CHECKED AHL, FOR THE 1073 CHANNEL AMPLIFIER	DRG. Nº EK20033
4 12K WAS 1K5 24-6-76 5 3 27-6-74 10907	And CHECKED Rubert Neve & Company I to	1072 614-2









EB 20039



TITLE






٠.


11;

12.112


								·					-	-			-
					2									-	-		+
	12.03			.,									T	N D.	secrejes 1	07.04.25	T
LOUR	QUANTITY	STOCK CODE	DESCRIPTION		COMMENT			Hard Contactioners		-	1.11		NA	ME	MOD. No.	DATE	IS
							AMS NEVE PLC. ow to this drawing. It mu in whole or in part, un cture or otherwise dis prior written consent	sed for manufa- sed sed without	HIG-		ASS F	FILTER P	CR			AMS	E
					39.6	DRAWN TO B.S.308	C AMS NEVE PLC.		DRAWN			AMS NEVE PLC.	BILLINGTON	ROAD,	DRG N	io.	SHT
3.00					1		2.2.1.1	SCALE				BURNLEY, LANCS, 88 TEL. (01282) 457011 F			PL 10182	LA	




B194/A



	The Neve Group of Companies	This drawing is the property of this company and	DATE
TITLE	B194/A - COMPONENT LAYOUT	may not be reproduced or disclosed to a third party without the permission of this company.	DRAWING NUMBER





BA211/A

