

This microfiche card contains a grid of frames. The left side of the card is filled with a grid of frames, each containing data. The data is organized into columns and rows, with some frames containing headers and footers. The right side of the card is mostly blank, with a few faint markings and a small white mark at the bottom center.

1 .REPT 0

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

IDENTIFICATION

PRODUCT CODE: AC-8850E-MC
PRODUCT NAME: CZKMAE0 MOS/CORE 0-124K EXER
DATE CREATED: AUG, 1978
MAINTAINER: DIAGNOSTIC GROUP

COPYRIGHT (C) 1975,1976,1977,1978
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

		CONTENTS

50		
51		
52		
53		
54	1.0	ABSTRACT
55	1.1	GETTING STARTED
56		
57	2.0	REQUIREMENTS
58	2.1	EQUIPMENT
59	2.2	STORAGE
60		
61	3.0	LOADING PROCEDURE
62		
63	4.0	STARTING PROCEDURE
64	4.1	SWITCH SETTINGS
65	4.2	CONTROL-C OPTION
66	4.3	STARTING ADDRESS =200
67		RESTART ADDRESS =250
68	4.4	PROGRAM AND/OR OPERATOR ACTION
69	4.5	LONG GALLOP OPTION
70		
71	5.0	PROGRAM HALTS (NORMAL + ERROR)
72		
73	6.0	ERRORS
74	6.1	ERROR MESSAGE FORMAT.
75	6.2	ERROR DICTIONARY
76	6.3	ERROR HISTORY
77	6.4	ERROR RECOVERY
78		
79	7.0	RESTRICTIONS
80		
81	8.0	MISCELLANEOUS
82	8.1	ADDRESS/BANK RANGES IN OCTAL AND DECIMAL
83	8.2	EXECUTION TIME
84	8.3	PASS COUNT AND TEST NO. LOCATIONS
85	8.4	STACK POINTER
86	8.6	POWER FAIL
87		
88	9.0	PROGRAM DESCRIPTION
89	9.1	NARRATIVE FLOW CHART
90	9.2	TEST TITLES
91		TEST 0: TEST FOR PROPER BANK SELECTION
92		TEST 1: CHECK DATI/DATO LINES
93		TEST 2: TEST MEMORY FOR HOLDING DATA AND BYTE SELECTION
94		TEST 3: DUAL ADDRESS TEST A
95		TEST 4: DUAL ADDRESS TEST B
96		TEST 5: MARCHING 1'S AND 0'S
97		TEST 6: CELLS' VOLATILITY TEST
98		TEST 7: SHIFTING DIAGONAL
99		TEST 10: READ RECOVERY GALLOPING TEST THROUGH EVERY 64TH CELL
100		TEST 11: READ RECOVERY LONG GALLOPING/FAST GALLOPING TEST
101		TEST 12: WORST CASE TESTING FOR CORE MEMORY
102		TEST 13: WRITE RECOVERY TEST
103		
104	10.0	RXDP & ACT11 & APT OPERATION

105 [1.0] ABSTRACT

106
107 THIS DIAGNOSTIC WILL TEST 0 - 124K OF MOS OR CORE MEMORY
108 ON ANY PDP-11 FAMILY COMPUTER. SOME TESTS ARE WORST CASE
109 FOR MOS AND SOME FOR CORE, BUT ALL TESTS ARE ALWAYS RUN.
110 THE TESTS OCCUPIES LESS THAN 2K OF MEMORY SO IT CAN BE
111 USED TO TEST A SYSTEM WITH ONLY 4K OF MEMORY. IF ONLY 4K
112 EXISTS, HOWEVER, THE ABSOLUTE LOADER IS NOT SAVED.

113
114 THIS PROGRAM CAN BE RUN UNDER XXDP, APT AND ACT MONITORS.
115 ON PROCESSORS WITH NO HARDWARE SWITCH REGISTER, SOFTWARE
116 SWITCH REGISTER = LOCATION 176.

117
118 [1.1] GETTING STARTED

119
120 IF NO HARDWARE SWITCH REGISTER SET LOCATION 176 TO OBTAIN SWITCH
121 OPTIONS.

122
123 TO START:

124 -----

- 125
126 A. SET SWITCH REGISTER = 00000
127 B. START AT 200.
128 C. THE MEMORY LIMITS WILL BE PRINTED.
129 D. SEE SECTION 4.4 FOR REST OF PRINTOUTS EXPECTED.
130 E. 'END PASS #01' WILL BE TYPED LAST, AND THE TEST WILL
131 RESTART.
132 F. TO HALT THE TEST, TYPE CONTROL-C, THIS WILL INSURE THE
133 PROGRAM IS RELOCATED BACK TO LOWER MEMORY.
134 BE PATIENT, THE CONTROL-C IS ONLY RECOGNIZED AT THE END
135 OF THE CURRENT SUBTEST.
136 G. IF AN UNEXPECTED HALT OCCURS SEE SECTION 6.0. IF AN
137 ERROR # IS TYPED SEE SECTION 6.2.

138
139 !CAUTION! BEFORE 'DIGGING' INTO THE LISTING READ
140 SECTION 9.

141
142 SWITCH SETTING SUMMARY (SEE SECTION 4.1 FOR DETAILS)

143 -----

144
145 BIT15(100000) HALT ON ERROR
146 BIT14(040000) LOOP IN SUBTEST DEFINED BY BITS <3:0>
147 BIT13(020000) INHIBIT ERROR PRINTOUTS
148 BIT12(010000) ENABLE TESTING ABOVE 28K (MEMORY MANAGEMENT)
149 BIT11(004000) ENABLE PARITY TESTING
150 BIT10(002000) HALT AFTER EACH SUBTEST
151 BIT09(001000) INHIBIT PROGRAM RELOCATION
152 BIT08(000400) TYPE FIRST FAILING BIT ERROR PER 4K.
153 BIT07(000200) ENABLE LONG GALLOPING TEST
154 BIT06(000100) INHIBIT MEMORY SIZING
155 BIT05(000040) INHIBIT 'END PASS #XX' PRINTOUTS
156 BIT04(000020) INHIBIT PRINTOUTS
157 BIT03-BIT00 BEGINNING TEST NUMBER.
158
159
160

161 [2.0] REQUIREMENTS

162

163 [2.1] EQUIPMENT

164

165 STANDARD 11 FAMILY COMPUTER WITH A CONSOLE OUTPUT DEVICE
166 AND FROM 4K TO 124K OF MEMORY. PROGRAM WILL ALSO RUN ON THE
167 TIM PROCESSOR AND ON 30K LSI SYSTEMS.

168

169

170

171 [2.2] STORAGE

172

173 PROGRAM STORAGE - 0000 - 7744. PROGRAM EXPANDS FOR ERROR
174 HISTORY AND TO SAVE ABSOLUTE LOADER OR XXDP CHAIN MONITOR.
175 (SEE SECTION 9. FOR DETAILS)

176

177

178

179 [3.0] LOADING PROCEDURE

180

181 USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED TAPES.

182

183

184

185 [4.0] STARTING PROCEDURE

186

187 [4.1] SWITCH SETTINGS

188

189 SOFTWARE SWITCH REGISTER = LOCATION 176

190

191 BIT15(100000) HALT ON ERROR

192

193 BIT14(040000) LOOP ON TEST DEFINED BY SWITCH REGISTER BITS <3:0>

194 BIT13(020000) INHIBIT ERROR PRINTOUTS

195 BIT12(010000) ENABLE MEMORY MANAGEMENT (TESTING ABOVE 28K)

196

197 BIT11(004000) ENABLE PARITY MODULES.

198 !'PARITY' WILL BE TYPED

199 BIT10(002000) HALT AFTER EACH SUBTEST

200 !PRESS CONTINUE TO DO NEXT SUBTEST

201 BIT09(001000) INHIBIT PROGRAM RELOCATION

202 !IF SET LOCATIONS 430-7776 WILL NOT BE

203 !TESTED.

204

205 BIT08(000400) TYPE FIRST FAILING BIT IN EACH 4K BANK ONLY.

206 !THE TOTAL ERROR COUNT (UP TO 377) WILL

207 !BE SAVED IN THE ERROR HISTORY.

208 BIT07(000200) ENABLE LONG GALLOPING TEST.

209 !'GLP' WILL BE TYPED.

210 !CAUTION! INCREASES TEST TIME BY FACTOR OF 25.

211 BIT06(000100) INHIBIT MEMORY SIZING.

212 !THE MEMORY LIMITS MUST BE SETUP IN THE FOLLOWING LOCATIONS:

213 (VALUES TO TEST 0-8K ARE SHOWN)

214 (LOWTWO=LOCATION 324)

215

216 LOWTWO: 0

;STORE BITS 17:16 OF LOW TEST ADDRESS

```
217          LOWADD: 0          ;STORE REST OF LOW TEST ADDRESS
218          ;DO NOT ATTEMPT TO SET THE LOWER LIMIT
219          ;AT OR ABOVE 160000 ON A 30K LSI SYSTEM.
220          ;THE PROGRAM WILL ASSUME MEMORY MANAGEMENT
221          ;MUST BE USED.
222          HIGHTWO: 0          ;STORE BITS 17:16 OF HIGH TEST ADDRESS
223          HIGHADD: 37776      ;STORE REST OF HIGH TEST ADDRESS
224
225          BIT05(000040)      INHIBIT 'END PASS #XX' PRINTOUTS
226
227          BIT04(000020)      A. INHIBIT ERROR HISTORY PRINTOUTS. THE
228          ;ERROR HISTORY CAN STILL BE OBTAINED
229          ;BY TYPING CONTROL-C.
230          ;B. INHIBIT PRINTOUTS 'PARITY','GLP','TST13 BNK XX'.
231
232          BIT03-BIT00        NUMBER OF TEST (0-13) TO RUN FIRST.
233          ;!NORMALLY USED WITH BIT14 (LOOP ON TEST)
234
235
236
237 [4.2] CONTROL-C OPTION
238
239          CONTROL C [^C]     AFTER COMPLETION OF THE CURRENT TEST.
240          ;THE ERROR HISTORY (SEE SEC. 6.3) WILL BE
241          ;TYPED. THE PROGRAM WILL HALT IN LOWER MEMORY.
242          ;PRESSING CONTINUE WILL RESTART THE DIAGNOSTIC.
243
244 [4.3] STARTING ADDRESS= 200
245          ;RESTART ADDRESS = 250 OR 200
246
247          ;RESTART AT 200 CLEARS PASS COUNT ($PASS) AND PRINTS 'CZKMAE' TITLE.
248
249
250
251
252
253 [4.4] PROGRAM AND/OR OPERATOR ACTION
254
255          1) LOAD PROGRAM INTO MEMORY USING ABSOLUTE LOADER.
256          2) SET OPTIONS (SEE SEC. 4.1)
257          3) START THE PROGRAM AT 200
258          4) THE FOLLOWING IS AN EXAMPLE WITH EXPLANATIONS
259          ;OF THE PRINTOUTS EXPECTED.
260
261          'XXXXX-YYYYY'      ;ADDRESSES OF TEST BOUNDARIES.
262
263          'PARITY'           ;IF PARITY OPTION SELECTED
264
265          'GLP'              ;IF LONG GALLOPING OPTION SELECTED.
266          ;PRINTED AS TST11 IS ENTERED.
267
268          'TST13 BNK 00'      ;ENTERING BANK 00 IN TEST 13.
269          'TST13 BNK 01'      ;AND BANK 1...
270          ETC...             ;UNTIL ALL BANKS (UP TO 7) HAVE BEEN TESTED.
271          'RELOC'            ;THE DIAGNOSTIC RELOCATES TO HIGHEST
272          ;LOCATIONS UNDER TEST AND RUNS TST0-TST13 AGAIN.
```

273 'TST13 BNK 00' ;TESTING BANK 00 IN TEST 13 (RELOCATED STATE.)
 274 ;NOTE-ONLY BANK 00 IS TESTED IN THE RELOCATED STATE.
 275
 276 'END PASS #XX' ;WHERE 'XX' IS THE PASS NO.
 277
 278
 279 ADDITIONAL PRINTOUTS
 280 'NO PAR' ;PRINTED IF PARITY SELECTED BUT NOT AVAILABLE.
 281
 282 'NO MNG' ;PRINTED IF SWR BIT 12 IS SET AND NO MEMORY
 283 ;MANAGEMENT AVAILABLE.
 284
 285
 286

4.5 LONG GALLOP OPTION

NORMAL WORST CASE SR SETTING = 0000. FOR LONG GALLOP
 SR = 200. LONG GALLOP OPTION SHOULD ONLY BE USED IF AN
 MOS MEMORY PROBLEM IS SUSPECTED AND NO OTHER SUBTESTS
 WILL FAIL. THE TEST TIME IS INCREASED 25 TIMES.

[5.0] PROGRAM HALTS (NORMAL+ ERROR)

THIS IS A LIST OF EXPECTED HALTS. IF THE TEST HALTS
 IN A LOCATION NOT IN THIS LIST AND IT IS LESS THAN 776, IT
 MAY BE DUE TO A DEVICE INTERRUPTING.
 NOTE THE HALT AT END OF SUBTEST AND HALT ON ERROR HALT LOCATIONS
 MAY BE RELOCATED. THE ACTUAL LOCATIONS THEY ARE IN CAN BE FOUND
 BY SUBTRACTING 500 FROM THE HALT PC AND ADDING THIS DIFFERENCE TO THE
 CONTENTS OF SAVR6 [LOC. 350].

PC	REASON	RECOVERY
---	-----	-----
112	TRAP TO LOC. 4	EXAMINE R6, IT CONTAINS THE POINTER TO THE PC WHERE THE TRAP OCCURRED.
146	POWER FAIL	POWER UP WILL RECOVER IF IN CORE MEMORY.
1672	HALT AT END OF TEST SWITCH SET.	PRESS CONTINUE TO GO TO NEXT SUBTEST.
6144	HALT ON ERROR SWITCH SET.	PRESS CONTINUE.
6230	CONTROL-C TYPED OR FATAL ERROR OCCURRED	PRESS CONTINUE TO RE- START TEST.

[6.0] ERRORS

328

329 [6.1] ERROR MESSAGE FORMAT

330
331 THE ERROR PRINTOUT CONSISTS OF 6 OCTAL WORDS IN THE FOLLOWING
332 FORMAT:

333
334 'LOCATION GOOD BAD PC ERROR PASFLG'

335
336
337 ''ADR ERR'' WILL BE PRINTED PRIOR IF AN ADDRESSING ERROR IS SUSPECTED.
338 ''PAR ERR'' WILL BE PRINTED PRIOR IF A PARITY ERROR TRAP OCCURRED
339 !CAUTION! IF PARITY ERROR THE GOOD DATA PRINTOUT IS THE
340 PARITY MODULE UNIBUS ADDRESS THAT FAILED.

341
342
343 WHERE:

344
345 LOCATION= FAILING MEMORY LOCATION
346 GOOD = GOOD DATA [DATA THAT WAS EXPECTED]
347 BAD = BAD DATA [DATA THAT WAS FOUND]
348 PC = PROGRAM COUNTER AT ERROR CALL.
349 ERROR = FAILING ERROR NO. (SEE SEC 6.2 - ERROR DICTIONARY)
350 PASFLG = CONTENTS OF LOCATION PASFLG. THIS MAY NOT BE RELEVANT.
351 (SEE SEC. 6.2-ERROR DICTIONARY)

352
353
354 !THE TEST WILL CONTINUE AFTER THE ERROR PRINTOUT.
355 !'NO MNG'' WILL BE TYPED IF TESTING ABOVE 28K SELECTED AND NO MEMORY
356 !MANAGEMENT IS FOUND.

357
358 !'NO PAR'' WILL BE TYPED IF PARITY OPTION SELECTED
359 !AND NO PARITY MODULES WERE FOUND.

360
361 (FATAL ERRORS)

362
363 'ERROR #XXXXXX'' WILL BE TYPED WHERE 'XXXXXX'' IS
364 THE ERROR NUMBER. THE DIAGNOSTIC WILL USUALLY HALT ON THIS TYPE
365 OF ERROR. SEE SEC. 6.2 -ERROR DICTIONARY - FOR DESCRIPTIONS
366 OF THE ERROR.

367
368
369
370 (APT MODE ERRORS)

371
372 ALL ERRORS ARE TREATED AS FATAL UNDER APT. WHEN AN
373 ERROR OCCURS UNDER APT A '1' IS STORED IN LOCATION
374 \$MSGTY AND THE PROGRAM HALTS AT FATHLT.

375
376 \$FATAL CONTAINS THE ERROR NO. IN THE LOW BYTE AND
377 THE FAILING BANK NO. UNDER TEST IN THE HIGH BYTE.

378
379
380
381
382 [6.2] ERROR DICTIONARY

383
384 THIS IS A LIST OF ERROR NUMBERS PRINTED AND POSSIBLE


```
385 CAUSES FOR THE ERROR.  
386 THE ROUTINE NAME WHERE THE ERROR CALL ORIGINATED IS GIVEN IN  
387 BRACKETS.  
388 NOTE- 'BAKPAT' REFERS TO THE BACKGROUND PATTERN WRITTEN INTO MEMORY  
389 FOR VARIOUS TESTS. IF PARITY SELECTED IT HAS A VALUE = 376 ,ELSE=377  
390 'SWAPPED BAKPAT' = 77000 IF PARITY SELECTED, ELSE=77400  
391  
392 .ENDR  
393  
394  
395 ;ERROR # 0 ;[BUSER] BUS ERROR TRAP TO LOC. 4 OCCURRED  
396 ; THIS ERROR IS NOT PRINTED AND IS FOR 'APT' USE.  
397  
398 ;ERROR # 1 ;[TSTTRP]FATAL DATA ERROR  
399 ;LOCATIONS 0000-430 FAILED 1'S + 0'S TEST.  
400 ;R0 = GOOD DATA  
401 ;R1 = ADDRESS OF FAILING LOCATION.  
402  
403 ;ERROR # 2 ;[CAPTSIZ] APT FATAL ERROR  
404 ;APT MEMORY TABLES NOT SETUP CORRECTLY.  
405 ;CHECK LOCATIONS $MAMS1 [430] TO $MADR4[446]  
406 ;, FOR CORRECT MEMORY SIZE DATA.  
407  
408 ;ERROR # 3 ;[TSTSIZ] OPERATOR FATAL ERROR  
409 ;SELECTED MEMORY SIZE GREATER THAN 28K, BUT  
410 ;SR BIT12 (10000) NOT SET.  
411 ;SET BIT12 AND RESTART AT 200.  
412  
413 ;ERROR # 4 ;[TSTSIZ] OPERATOR FATAL ERROR  
414 ;LOWEST SELECTED TEST LIMIT IS HIGHER THAN  
415 ;HIGHEST TEST LIMIT. SET LOCATIONS 'LOWTWO'[322]  
416 ;TO 'HIGHADD' [330] CORRECTLY AND RESTART  
417 ;AT 200.  
418  
419 ;ERROR # 5 ;[TSTO] TEST SEQUENCE ERROR  
420 ;TSTO HAS BEEN ENTERED OUT OF SEQUENCE  
421 ;TESTN SHOULD = 00  
422 ;THE DIAGNOSTIC HAS BEEN CORRUPTED.  
423 ;IF POSSIBLE SELECT ANOTHER 4K BANK  
424 ;BANK 0 AND RERUN THE TEST ON THE FAILING MEMORY.  
425  
426 ;ERROR # 6 ;[TSTO] DUAL ADDRESSING ERROR  
427 ;FOR THIS ERROR THE GOOD DATA PRINTED IS AN  
428 ;ADDRESS. THIS IS THE ADDRESS SELECTED WHEN  
429 ;THE SAME DATA WAS WRITTEN INTO THE FAILING  
430 ;LOCATION. CHECK BANK SELECT CIRCUITRY  
431  
432 ;ERROR # 7 ;[TSTO] ADDRESS AND DATA ERROR  
433 ;IDENTICAL TO PREVIOUS ERROR EXCEPT THE DATA  
434 ;WRITTEN INTO THE FAILING LOCATION WAS IN  
435 ;ERROR ALSO.  
436  
437 ;ERROR # 10 ;[TSTO] DATA ERROR  
438 ;IF BAD DATA = 0000 COULD BE AN ADDRESSING  
439 ;ERROR , ELSE COMPARE GOOD AND BAD DATA FOR FAILING BITS.  
440
```

```
441 ;ERROR # 11      :[TST0] ADDRESSING ERROR
442                  :THE FAILING ADDRESS RESPONDED BUT IS NON-
443                  :EXISTENT. MAY BE A DUAL ADDRESSING PROBLEM.
444
445 ;ERROR # 12      :[TST1] TEST SEQUENCE ERROR
446                  :$TEST [404] SHOULD = 01
447                  :   THE DIAGNOSTIC HAS BEEN CORRUPTED.
448
449 ;ERROR # 13      :[TST1] DATA ERROR
450                  :COMPARE GOOD AND BAD PRINTED DATA, FAILING
451                  :DATA BITS MAY SHORTED OR SWAPPED.
452
453 ;ERROR # 14      :[TST2] TEST SEQUENCE ERROR
454                  :$TESTN [404] SHOULD = 02
455                  :   THE DIAGNOSTIC HAS BEEN CORRUPTED.
456
457 ;ERROR # 15      :[TST2] ADDRESS OR DATA ERROR
458                  :IF 'ADR ERR' NOT PRINTED THEN THE BYTE SELECT
459                  :CIRCUITRY PROBABLY FAILED.
460
461 ;ERROR # 16      :[TST3] TEST SEQUENCE ERROR
462                  :$TESTN [404] SHOULD = 03
463                  :   THE DIAGNOSTIC HAS BEEN CORRUPTED.
464
465 ;ERROR # 17      :[TST3] DUAL ADDRESSING ERROR
466                  :DUAL ADDRESSING PROBLEM FOR BITS THAT DIFFER
467                  :IN GOOD AND BAD DATA PRINTOUT.
468
469 ;ERROR # 20      :[TST3] DUAL ADDRESSING ERROR
470                  :FOR THIS ERROR THE DATA PRINTED IS AN ADDRESS.
471                  :THIS IS THE ADDRESS THAT WAS SELECTED WHEN THE
472                  :SAME DATA WAS WRITTEN INTO THE FAILING LOCATION.
473
474 ;ERROR # 21      :[TST3] DUAL ADDRESSING ERROR
475                  :SAME AS ERROR #20 EXCEPT DIFFERENT DATA
476                  :(SWAPPED BAKPAT) WAS WRITTEN.
477
478 ;ERROR # 22      :[TST4] TEST SEQUENCE ERROR
479                  :$TESTN [404] SHOULD = 04.
480                  :   THE DIAGNOSTIC HAS BEEN CORRUPTED.
481
482 ;ERROR # 23      :[TST4] DUAL ADDRESSING ERROR
483                  :IF PASFLG = 0 THEN THE FAILING LOCATION
484                  :AND FAILING DATA ARE DUAL ADDRESSES.
485
486 ;ERROR # 24      :[TST5] TEST SEQUENCE ERROR
487                  :$TESTN [404] SHOULD = 05
488                  : THE DIAGNOSTIC HAS BEEN CORRUPTED.
489
490 ;ERROR # 25      :[TST5] DATA ERROR
491                  :DATA WRITE OR READ ERROR.
492 ;ERROR # 26      :[TST5] MARCHING 1'S AND 0'S DATA ERROR
493                  :IF PASFLG=0 FAILED MARCHING 1'S + 0'S IN
494                  :   MAX TO MIN DIRECTION.
495                  :IF PASFLG=1 FAILED MARCHING 1'S + 0'S IN
496                  :   MIN TO MAX DIRECTION
```

```
497          :IF PASFLG=3 FAILED MARCHING 0'S + 1'S IN
498          :          MAX TO MIN DIRECTION.
499          :
500 ;ERROR # 27 :[TST5] MARCHING 1'S AND 0'S DATA ERROR
501          :IDENTICAL TO PREVIOUS ERROR EXCEPT THE DATA IS
502          :CHECKED IMMEDIATELY AFTER BEING WRITTEN.
503          :
504 ;ERROR # 30 :[TST6] TEST SEQUENCE ERROR
505          :$TESTN SHOULD = 06
506          :THE DIAGNOSTIC HAS BEEN CORRUPTED.
507          :
508 ;ERROR # 31 :[TST6] VOLATILITY/REFRESH TEST ERROR
509          :IF PASFLG=0 BAKPAT WRITE OR READ ERROR.
510          :IF PASFLG=1 THE FAILING LOCATION CHANGED WHILE
511          :          ANOTHER LOCATIONS WAS WRITTEN FOR
512          :          2 MS. THE OTHER LOCATION IS SAVED
513          :          IN SAVLOC [352]
514          :IF PASFLG=2 SWAPPED BAKPAT (77400 OR 77000)
515          :          WRITE OR READ ERROR.
516          :IF PASFLG=3 SAME AS IF PASFLG=2 EXCEPT
517          :          THE DATA IS SWAPPED BAKPAT.
518          :
519 ;ERROR # 32 :[TST7] TEST SEQUENCE ERROR
520          :$TESTN SHOULD = 07
521          :THE DIAGNOSTIC HAS BEEN CORRUPTED.
522          :
523 ;ERROR # 33 :[TST7] SHIFTING DIAGONAL DATA ERROR
524          :IF PASFLG=0 BAKPAT WRITE OR READ ERROR.
525          :IF PASFLG=1 BAKPAT READ CHECK ERROR
526          :IF PASFLG= GREATER THAN 1 BUT EVEN VALUE THEN:
527          :          THE FAILING LOCATION COULD NOT BE WRITTEN INTO.
528          :IF PASFLG= GREATER THAN 1 BUT ODD VALUE THEN:
529          :          THE FAILING LOCATION WAS WRITTEN CORRECTLY
530          :          BUT LOST THE DATA.
531          :
532 ;ERROR # 34 :[TST10] TEST SEQUENCE ERROR
533          :$TESTN SHOULD = 10
534          :          THE DIAGNOSTIC HAS BEEN CORRUPTED.
535          :
536 ;ERROR # 35 :[TST10] BAKPAT DATA ERROR
537          :BAKPAT WRITE OR READ ERROR INTO THE FAILING LOCATION.
538          :
539 ;ERROR # 36 :[TST10] READ RECOVERY DATA ERROR
540          :          THIS ERROR CAN BE REPORTED BY TST10 AND TST11.
541          :          (THEY SHARE CODE). SEE $TESTN [404] FOR WHICH TEST FAILED.
542          :FOR BOTH TESTS COMPARE THE GOOD AND BAD DATA AT THE FAILING
543          :LOCATION TO SEE WHICH BITS FAILED.
544          :
545 ;ERROR # 37 :[TST10] READ RECOVERY DATA ERROR
546          :IDENTICAL TO THE PREVIOUS ERROR EXCEPT SWAPPED BAKPAT IS
547          :USED AS WRITE AND READ DATA.
548          :
549 ;ERROR # 40 :[TST11] TEST SEQUENCE ERROR
550          :$TESTN SHOULD = 11
551          :          THE DIAGNOSTIC HAS BEEN CORRUPTED.
552          :
```

```
553 ;ERROR # 41 ;[TST12] TEST SEQUENCE ERROR
554 ;$TESTN SHOULD = 12
555 ; THE DIAGNOSTIC HAS BEEN CORRUPTED.
556
557 ;ERROR # 42 ;[TST12] WORST CASE CORE TEST DATA ERROR
558 ;IF PASFLG=1 COMPARE GOOD AND BAD DATA FOR FAILING BITS.
559 ;IF PASFLG=2 THE FAILING LOCATION WAS WRITTEN AND READ
560 ; WITH GOOD DATA,BUT FAILED READ CHECK
561 ; READING IN THE MIN. TO MAX DIRECTION.
562 ;IF PASFLG=3 SAME CONDITIONS AS PASFLG=2 EXCEPT FAILED
563 ; DOING THE READ CHECK FROM MAX TO MIN DIRECTION.
564
565 ;ERROR # 43 ;[TST12] WORST CASE CORE TEST DATA ERROR
566 ; IDENTICAL TO PREVIOUS ERROR EXCEPT THE DATA WRITTEN
567 ;AND READ IS COMPLEMENTED.
568
569 ;ERROR # 44 ;[TST13] TEST SEQUENCE ERROR
570 ;$TESTN SHOOULD = 13
571 ; THE DIAGNOSTIC HAS BEEN CORRUPTED.
572
573 ;ERROR # 45 ;[TST13] WRITE RECOVERY TEST DATA ERROR
574 ;IF PASFLG=0 COMPARE GOOD AND BAD DATA FOR FAILING BITS.
575 ;IF PASFLG=77400 DATA ERROR FOUND WHILE DOING A SECOND READ CHECK.
576 ;IF PASFLG=77402 DATA ERROR FOUND IN FAILING LOCATION AFTER
577 ; SMALL TEST PROGRAM RUN IN FAILING BANK.
578 ;ERROR # 46 ;[TST13] WRITE RECOVERY TEST DATA ERROR
579 ; DATA ERROR FOUNDJUST BEFORE THE SMALL TEST
580 ;WAS TO BE RUN IN THE FAILING BANK. TO AVOID 'BLOWING' UP
581 ;WHEN THE SMALL TEST IS RUN TST13 IS ABORTED.
582
583 ;ERROR # 47 ;[TST13] WRITE RECOVERY TEST DATA ERROR
584 ; IDENTICAL TO ERROR #XXX EXCEPT THE DATA WRITTEN
585 ;AND READ IS DIFFERENT.(177667).
586 ;177667 IS THE COMPLEMENT OF 'JMP (R0)'' (110) WHICH IS
587 ;THE ESCAPE FROM THE SMALL TEST PROGRAM RUN IN THE BANK
588 ;UNDER TEST.
589
590 ;ERROR # 50 ;[PARERR] PARITY TRAP ERROR
591 ; PARITY TRAP TO 114 OCCURRED.
592 ;FOR THIS ERROR PRINTOUT THE 'GOOD DATA' IS ACTUALLY
593 ;THE FAILING PARITY MODULE UNIBUS ADDRESS.
594 ; SAVLOC [352] CONTAINS THE PC WHERE THE TRAP OCCURRED.
595
596 ;ERROR # 51 ;[PARITY] PARITY TRAP FATAL ERROR
597 ; A PARITY TRAP TO 114 OCCURRED, BUT NO PARITY MODULES COULD BE FOUND
598 ;WITH AN ERROR BIT (BIT15) SET.
599
600 ;ERROR # 52 ;[NOMM] OPERATOR FATAL ERROR
601 ; TESTING ABOVE 28K WAS SELECTED, BUT NO MEMORY MANAGEMENT
602 ;OPTION WAS FOUND.
603 ; RESET SWITCH OPTIONS AND RESTART AT 200.
604
605 ;ERROR # 53 ;[PARITY] OPERATOR FATAL ERROR
606 ; PARITY TESTING WAS SELECTED BUT NO PARITY MODULES
607 ;WERE FOUND.
608 ; RESET SWITCH OPTIONS AND START AT 200.
```

609
610 .REPT 0

611
612
613 [6.3] ERROR HISTORY

614
615 LOCATIONS IN MEMORY ARE SET ASIDE TO COLLECT A HISTORY
616 OF THE FAILING BITS IN A PARTICULAR MEMORY BANK. THIS
617 DATA IS COLLECTED FOR EVERY ERROR REGARDLESS OF SWITCH
618 SETTINGS.

619
620 NORMALLY THE DATA IS OUTPUT AT THE END OF TESTING, BUT
621 IF CONTROL-C IS TYPED IT IS OUTPUT AT THE END OF THE
622 CURRENT TEST.

623
624 THE ERROR HISTORY IS INTENDED TO HIGHLIGHT IF THE ERRORS
625 ARE DUE TO 1 BIT FAILING OR ONLY ADDRESS ERRORS.

626
627
628
629 ERROR HISTORY FORMAT:

630
631
632 ERROR BANK COUNT
633 -----

634
635
636 WHERE:

637
638 ERROR = BIT THAT FAILED [NUMBER OF THE FAILING BIT IN DECIMAL I.E.
639 0-15 WILL BE TYPED OUT OR THE WORDS 'ADR ERR' OR 'PAR ERR' WILL
640 BE TYPED OUT IF ADDRESS ERROR OR PARITY ERROR WAS SEEN
641 IN THE SPECIFIC BANK OF MEMORY
642 BANK = 4K MEMORY BANK IN WHICH THIS FAILURE WAS SEEN
643 A 0 FOR 0 TO 4K, A 1 FOR 4 TO 8K AND SO ON
644 COUNT = NUMBER OF TIMES THIS MEMORY BANK FAILED.
645 (377 IS MAXIMUM FAILURE COUNT RECORDED.)

646 [6.4] ERROR RECOVERY

647
648 IF THE PROGRAM IS HALTED AFTER REPORTING AN ERROR IT CAN EITHER
649 BE CONTINUED OR RESTARTED AT 200 OR 250 (SEE SEC 4.2). HOWEVER FOR
650 CPU'S THAT DESTROY CONTENTS OF REGISTERS AFTER COMING TO A HALT
651 THE PROGRAM SHOULD ONLY BE RESTARTED.

652
653 [7.0] RESTRICTIONS

654
655 MEMORY UNDER TEST SHOULD BE CONTIGUOUS. FOR SYSTEMS HAVING NON-
656 CONTIGUOUS MEMORY THE MEMORY BOUNDARIES SHOULD BE DEFINED BY THE
657 OPERATOR. (CONTIGUOUS MEMORY IS DEFINED AS A MEMORY THAT CAN BE
658 BOTH READ AND WRITTEN IN CONSECUTIVE LOCATIONS.)

659
660
661
662
663 [8.0] MISCELLANEOUS

665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720

[8.1] ADDRESS/BANK RANGES IN OCTAL AND DECIMAL

THIS REFERENCE TABLE CROSS REFERENCES THE MEMORY BANK NO.S,
 THE RANGE AND THE PAR USED WHEN MEMORY MANAGEMENT IS ENABLED.
 IT IS ALSO USEFUL TO SHOW STARTING ADDRESSES IN A PAR-
 TICULAR 4K BANK.

BANK NO.	DECIMAL RANGE	OCTAL RANGE	[PAGE ADDRESS REGISTER] USED/CONTENT	UNIBUS ADDRESS
0	0 - 4K	000000-017776	0 0000	772340
1	4K - 8K	020000-037776	NOT USED	
2	8K-12K	040000-057776	NOT USED	
3	12K-16K	060000-077776	NOT USED	
4	16K-20K	100000-117776	NOT USED	
5	20K-24K	120000-137776	NOT USED	
6	24K-28K	140000-157776	NOT USED	
7	28K-32K	160000-177776	NOT USED ON 30K (LSI-11) SYSTEMS	
			1 1600	772342
8	32K-36K	200000-217776	2 2000	772344
9	36K-40K	220000-237776	3 2200	772346
10	40K-44K	240000-257776	4 2400	772350
11	44K-48K	260000-277776	5 2600	772352
12	48K-52K	300000-317776	6 3000	772354
13	52K-56K	320000-337776	1 3200	
14	56K-60K	340000-357776	2 3400	
15	60K-64K	360000-377776	3 3600	
16	64K-68K	400000-417776	4 4000	
17	68K-72K	420000-437776	5 4200	
18	72K-76K	440000-457776	6 4400	
19	76K-80K	460000-477776	1 4600	
20	80K-84K	500000-517776	2 5000	
21	84K-88K	520000-537776	3 5200	
22	88K-92K	540000-557776	4 5400	
23	92K-96K	560000-577776	5 5600	
24	96K-100K	600000-617776	6 6000	
25	100K-104K	620000-637776	1 6200	
26	104K-108K	640000-657776	2 6400	
27	108K-112K	660000-677776	3 6600	
28	112K-116K	700000-717776	4 7000	
29	116K-120K	720000-737776	5 7200	
30	120K-124K	740000-757776	6 7400	
31	124K-128K	760000-777776	7 7600	772354

NOTES:

1. THE PAR (PAGE ADDRESS REGISTER) CONTENTS ARE SHOWN IN A TEST THAT SELF SIZES.
 IF THE LIMITS OF TESTING ARE SET BY THE OPERATOR AND
 IF THE BANK IS ABOVE 28K PAR NO. 1 WILL BE SET TO THE

721 BEGINNING PAGE. FOR EXAMPLE IF THE TESTING WAS TO
722 BEGIN WITH BANK 8 PAR NO. 1 WOULD EQUAL 2000, PAR 2
723 WOULD EQUAL 2200 ETC.
724
725

726
727 [8.2] EXECUTION TIME
728
729 HERE ARE SOME TYPICAL EXECUTION TIMES.
730
731 LSI-11 AND 4K:= 100 SECS.
732 LSI-11 AND 8K:= 5 MINUTES.
733

734
735 [8.2] PASS COUNT AND TEST NO. LOCATIONS
736
737 \$PASS [406] = PASS COUNT - CLEARED BY START AT 200.
738
739 \$TESTN [404] = CURRENT TEST NO. AND RELOCATION, PARITY FLAGS.
740
741 WHERE:
742 LOW BYTE = TEST NO.
743 IF BIT15 = 1 TEST IS RELOCATED
744 IF BIT13 = 1 PARITY UNDER TEST.
745

746
747 [8.4] STACK POINTER
748
749 THE STACK STARTS AT 500 WHEN THE PROGRAM IS NOT RELOCATED.
750 SAVR6[350] CONTAINS THE STACK STARTING VALUE WHEN THE DIAGNOSTIC
751 IS RELOCATED.
752 SAVR6 ALSO CONTAINS THE STARTING ADDRESS OF THE PROGRAM WHEN
753 IT IS RELOCATED.
754

755 [8.5] POWER FAIL
756
757 THE DIAGNOSTIC CAN BE POWER FAILED WITH NO ERRORS. TO USE,
758 START THE TEST AS USUAL AND POWER DOWN THEN UP AT ANY TIME.
759 THE PROGRAM SHOULD TYPE 'P' AND CONTINUE TO RUN FROM TEST 0
760 IN THE SAME STATE [I.E. STATE OF RELOCATION] AS IT WAS BEFORE
761 THE POWER WAS INTERRUPTED, HOWEVER IF THE DIAGNOSTIC WAS IN
762 A MEMORY THAT CAN NOT HOLD DATA WITH THE POWER DOWN THEN THE
763 PROGRAM WILL NOT RECOVER FROM POWER FAIL.
764

765
766 [9.0] PROGRAM DESCRIPTION
767

768
769 [9.1] NARRATIVE FLOW CHART
770
771 THE TEST IS LOADED INTO LOCATIONS 0000 - 7744 BUT
772 EXPANDS DEPENDING ON HOW MUCH MEMORY IS UNDER TEST.
773 SEE STEP 6. BELOW FOR A DETAILED EXPLANATION.
774

775
776 THE FOLLOWING NARRATIVE FLOW CHART DESCRIBES MAJOR

777 PROGRAM OPERATION. FOR THE PERSON WHO NEEDS DETAIL THE
778 TAG ASSOCIATED WITH THE OPERATION IS GIVEN IN BRACKETS.

779
780 FOR THIS DISCUSSION SWITCH SETTINGS ARE IGNORED AND EVERYTHING IS
781 ASSUMED ENABLED.

- 782
783 1. [START] PRINT "CZKMAE" TITLE
784
785 2. [TSTPP] SAVE DATA FROM LOCATIONS 0-376
786 INTO 7744-10314.
787
788 3. [TSTRP] TEST LOCATIONS 0-376 BY WRITING AND
789 READING 1'S AND 0'S. NOTE THIS IS THE ONLY
790 EXPLICIT TESTING OF THESE LOCATIONS.
791
792 4. [SLFSIZ] SIZE MEMORY BY WRITING INTO SUCCEEDING
793 MEMORY LOCATIONS UNTIL TIMEOUT TRAP TO 4 OCCURS,
794 OR 30K BOUNDARY REACHED.
795 ENABLE MEMORY MANAGEMENT AND SIZE MEMORY ABOVE
796 28K.
797
798 5. [TYPsiz] TYPE MEMORY TEST LIMITS.
799
800 6. [SETSTK] SPACE IS SAVED AT THE END OF THE TEST
801 FOR AN ERROR HISTORY. FOR EACH 4K BANK 18 BYTES ARE SAVED
802 IN THE FOLLOWING FORMAT:

803
804 !ADR ERR!PAR ERR!
805 !BIT14 !BIT15 !
806 !BIT12 !BIT13 !
807 !BIT10 !BIT11 !
808 !BIT08 !BIT09 !
809 !BIT06 !BIT07 !
810 !BIT04 !BIT05 !
811 !BIT02 !BIT03 !
812 !BIT00 !BIT01 !
813

814 IF GREATER THAN 4K UNDER TEST THE ABSOLUTE LOADER
815 (300 ADDRESSES) IS APPENDED. IF GREATER THAN 4K
816 AND UNDER XXDP CHAIN MODE 5674 (OCTAL) ADDRESSES
817 ARE APPENDED TO THE TEST. THIS SAVES THE XXDP
818 MONITOR, AND ALLOWS THE LOCATIONS OCCUPIED BY XXDP
819 TO BE TESTED.

- 820
821 7. [CLRMEM] CALL "PARITY" ROUTINE AND IF SELECTED,
822 ENABLE ALL PARITY MODULES. "PARMAP" [LOC. 352]
823 CONTAINS A MAP OF PARITY MODULES FOUND. IF
824 MODULE 172336 BIT 15 IS SET, IF #172334 FOUND BIT 14
825 IS SET ETC..
826
827 8. [CLRMEM] CLEAR MEMORY CURRENTLY UNDER TEST
828
829 9. [CONT] DISPATCH TO TST0
830
831 10. [TST0] EXECUTE TEST 0. SEE SECTION 10 FOR TEST
832 DESCRIPTIONS.

833
834 11. [TSTSCP] COMES HERE AFTER EACH TEST AND IF
835 CNTRL-C TYPED THEN GO TO ERROR HISTORY PRINTOUT.
836 IF SR=2000 THEN HALT
837 IF SR=40000 THEN LOOP ON TEST DEFINED BY <3:0>
838 ELSE CONTINUE TO NEXT TEST.
839
840 12. [TST1-TST12] EXECUTE TST1-TST12 EACH TIME
841 GOING TO STEP 9.
842
843 13. [TST13] TEST 13 IS DIFFERENT FROM TESTS 0-12,
844 BECAUSE IT IS A SMALL PROGRAM ACTUALLY RUNNING
845 IN THE MEMORY UNDER TEST. BEFORE THIS SMALL
846 PROGRAM IS STARTED 'TST13 BNK XX' IS TYPED.
847 THIS IS DONE IN CASE THE PROGRAM FAILS. THE
848 USER CAN THEN AT LEAST TELL WHICH BANK OF MEMORY
849 FAILED.
850
851 14. [RELOC] THE PROGRAM RELOCATES TO HIGH MEMORY
852 TO TEST THE LOCATIONS IT OCCUPIES. (430-ENDPRG).
853 WHERE 'ENDPRG' IS THE CONTENTS OF ENDSTK[306].
854 I.E THE LAST PROGRAM ADDRESS. NOTE 'RELOC' IS
855 PRINTED JUST PRIOR TO THE ACTUAL RELOCATION.
856
857 15. TESTS 0-13 ARE RUN AS DESCRIBED ABOVE EXCEPT
858 ONLY BANK 0 LOCATIONS 430-ENDPRG ARE TESTED.
859
860 16. [RELOER] RELOCATE THE PROGRAM BACK TO LOWER
861 MEMORY.
862
863 17. [LOWER] IF CONTROL-C TYPED GO PRINT ERROR
864 HISTORY.
865
866 18. [TSTMM] IF MEMORY MANAGEMENT SELECTED AND AVAILABLE,
867 RUN TESTS 0-13 ON THE FIRST 24K SLICE ABOVE 28K.
868
869 19. [CONTMM] CALL 'UPMM' TO UPDATE MEMORY MANAGEMENT
870 PAR REGISTERS TO POINT TO THE NEXT 24K SLICE OF
871 UPPER MEMORY.
872
873 20. [MAXADR] REPEAT STEPS 18 + 19 UNTIL ALL
874 MEMORY ABOVE 28K IS TESTED.
875
876 21. [ENDPAS] PRINT ERROR HISTORY OF FAILING BITS
877
878 22. [\$EOP] DISABLE PARITY MODULES.
879 PRINT 'END PASS #XX'
880
881
882 [9.2] TEST TITLES
883
884 SEE THE TEST HEADINGS IN THE LISTING FOR DETAILS ON EACH TEST.
885
886 TEST 0: TEST FOR PROPER BANK SELECTION
887 TEST 1: CHECK DATI/DATO LINES
888

889 TEST 2: TEST MEMORY FOR HOLDING DATA AND BYTE SELECTION
 890 TEST 3: DUAL ADDRESS TEST A
 891 TEST 4: DUAL ADDRESS TEST B
 892 TEST 5: MARCHING 1'S AND 0'S
 893 TEST 6: CELLS' VOLATILITY TEST
 894 TEST 7: SHIFTING DIAGONAL
 895 TEST 10: READ RECOVERY GALLOPING TEST THROUGH EVERY 64TH CELL
 896 TEST 11: READ RECOVERY LONG GALLOPING/FAST GALLOPING TEST
 897 TEST 12: WORST CASE TESTING FOR CORE MEMORY
 898 TEST 13: WRITE RECOVERY TEST
 899

900
 901 [10.0] RXDP & ACT11 & APT OPERATION
 902

903 RXDP CHAIN MODE
 904 -----
 905

906 OPERATION IS IDENTICAL TO STAND ALONE EXCEPT:
 907

- 908 1. NO 'CZKMAE' TITLE IS PRINTED.
- 909 2. NO TEST 13 PRINTOUTS SUCH AS 'TST13 BNK 00'.
- 910 3. THE PROGRAM ALWAYS HALTS ON ERROR.
- 911 4. AT THE END OF TEST (\$ENDAD) CONTROL IS RETURNED TO
- 912 THE RXDP CHAIN MONITOR VIA LOCATION 42.

913
 914 ACT11
 915 -----
 916

917 OPERATION IS IDENTICAL TO STAND ALONE EXCEPT:
 918

- 919 1. NO PRINTOUTS EXCEPT ERROR PRINTOUTS.
- 920 2. THE PROGRAM ALWAYS HALTS ON ERROR.
- 921 3. AT THE END OF TEST (\$ENDAD) CONTROL IS RETURNED TO
- 922 THE ACT11 MONITOR VIA LOCATION 42.

923
 924 APT
 925 ----
 926

927 OPERATION IS SIMILAR TO STAND ALONE EXCEPT:
 928

- 929 1. THE SOFTWARE SWITCH REGISTER BECOMES LOCATION 422 (\$SWREG).
- 930 2. AUTO SIZING CAN BE INHIBITED BY SETTING BIT 7 OF BYTE
- 931 LOCATION 421 (\$ENVM).
- 932 3. ALL PRINTOUTS CAN BE INHIBITED BY SETTING BIT 5 OF
- 933 BYTE LOCATION 421 (\$ENVM).
- 934 4. ALL ERRORS CAUSE LOCATION 400 (\$MSGTY) TO BE SET =
- 935 0001 AND THE PROGRAM HALTS AT LOCATION 6214 (FATHLT).
- 936 LOCATION 402 (\$FATAL) CONTAINS THE ERROR NO. IN THE
- 937 LOW BYTE AND THE FAILING MEMORY BANK NO. IN THE HIGH
- 938 BYTE.

939
 940 APT MANAGER INFORMATION
 941

942 THE FOLLOWING IS AN EXAMPLE SCRIPT TO TEST A 4K MEMORY.
 943 IT IS RECOMMENDED THAT DIFFERENT SCRIPTS BE USED FOR
 944 DIFFERENT MEMORY SIZES TO SAVE AUTO SIZING TIME.

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 18
CZKMAE.MAC 18-SEP-78 11:54

SEQ 0018

```
945
946 THE EXAMPLE ASSUMES YOU ARE LOGGED INTO THE APT MONITOR.
947
948 READY
949
950 RUN APPLU
951 APT 11 PAPER TAPE PROGRAM LOAD UTILITY
952
953
954 COMMAND: ED
955 PROGRAM NAME TO EDIT: EXAMPL
956 DO YOU WANT TO LOAD A NEW REV OF THE PROGRAM(Y/N)? N
957 FIRST PASS RUN TIME IN SECONDS <110>:
958 LONGEST TEST TIME IN SECONDS <10>:
959 ADDITIONAL RUN TIME IN SECONDS <0>:
960 WHICH ETABLE DO YOU WISH TO EDIT? A
961 SOFTWARE ENVIRONMENT<000>: 1
962 ENVIRONMENTAL MODE<000>: 240
963 SWITCH 1 <000000>:
964 SWITCH 2 <000000>:
965 CPU OPTIONS<0000>:
966 MEMORY TYPE 1 <000>:
967 MAXIMUM ADDRESS<00000000>:
968 MEMORY TYPE 2 <000>:
969 MAXIMUM ADDRESS<00000000>:
970 MEMORY TYPE 3 <000>:
971 MAXIMUM ADDRESS<00000000>:
972 MEMORY TYPE 4 <000>: 1
973 MAXIMUM ADDRESS<00000000>: 17776
974 WHICH ETABLE DO YOU WISH TO EDIT?
975 COMMAND: OFF
976
977
978 .ENDR
```

```

979 .ENABL ABS
980 .NLIST MD,MC,CND
981 .LIST ME,BIN,SEQ,LOC
982 .TITLE CZKMA
983 .*COPYRIGHT (C) AUGUST 1977
984 .*DIGITAL EQUIPMENT CORP.
985 .*MAYNARD, MASS. 01754
986 .*
987 .*PROGRAM BY PERVEZ ZAKI
988 .*
989 .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
990 .*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
991 .*
992 160000 $SWR=160000 ;;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
993
994
995
996
997 ;;TRAP CATCHER OF .+2 AND HALT FOR 0-776 LOCATIONS
998
999
1000
1001
1002 000240 SCOPE =NOP
1003
1004 000042 .=42
1005 000042 000000 .WORD 0 ;FOR ACT/XXDP
1006
1007 .SBTTL ACT11 HOOKS
1008
1009 ;;*****
1010 ;HOOKS REQUIRED BY ACT11
1011 000044 $SVPC=. ;SAVE PC
1012 000046 .=46
1013 000046 000156 $ENDAD ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
1014 000052 .=52
1015 000052 040000 .WORD 40000 ;;2)SET LOC.52 TO 40000
1016 000044 .=$SVPC ;; RESTORE PC
1017
1018 000070 .=70
1019 000070 012737 000136 000024 PWRDN: MOV #PWRUP,@#24
1020 000076 000000 HALT
1021

```

1022
1023
1024 000104
1025
1026 000104 005237 000400
1027 000110 000000
1028 000112 000000
1029
1030
1031 000120
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045 000120 010401
1046 000122 013700 000316
1047 000126 010021
1048 000130 020105
1049 000132 103775
1050 000134 000207
1051
1052
1053 000136 013706 000350
1054 000142 012700 006102
1055 000146 060600
1056
1057 000150 004710
1058 000152 000120
1059
1060
1061 000154 000411
1062
1063
1064 000156 004710
1065 000160 000240
1066 000162 000240
1067 000164 000240
1068 000166 000430
1069
1070
1071 000176 000176 000000
1072
1073
1074
1075
1076
1077

.=104
: GET HERE IF AN ILLEGAL TRAP TO LOC. 4 OCCURRED.
BUSER: INC @#\$MSGTY ; TELL APT FATAL ERROR#000
HALT ; *ERROR* TRAP TO LOC. 4 OCCURRED.
HALT ; IN CASE CONTINUE PRESSED.
:114 AND 116 ARE RESERVED FOR PARITY TRAP VECTORS. SETUP IN
:ROUTINE 'BEGIN'.
.=120

;* WRITE MEMORY BACKGROUND
:-----
: THIS ROUTINE IS USED TO WRITE THE MEMORY BACKGROUND TO
: THE VALUE STORED AT LOCATION BAKPAT. THE ROUTINE ASSUMES
: THAT R4 IS POINTING TO THE LOWEST LOCATION AND R5 TO THE
: HIGHEST LOCATION TO BE WRITTEN. THE PROGRAM LEAVES THE
: SUBROUTINE WITH R0 CONTAINING THE CONTENTS OF BAKPAT.
:*

WRTMEM: MOV R4,R1 ;SET R1 TO LOWEST LOCATION UNDER TEST
MOV @#BAKPAT,R0 ;LOAD R0 WITH THE CONTENTS OF LOCATION BAKPAT
2\$: MOV R0,(R1)+ ;STARTING FROM THE LOWEST LOCATION WRITE THE
CMP R1,R5 ;MEMORY TO BACK GROUND PATTERN
BLO 2\$
RTS PC ;RETURN FROM THE SUBROUTINE

PWRUP: MOV @#SAVR6,SP ;RESTORE STACK POINTER
MOV #PNTMES-BEGIN,R0
ADD SP,R0 ;GET THE INDIRECT ADDRESS OF LOCATION TPCRLF
;RELATIVE TO LOCATION OF DIAGNOSTIC IN THE CORE
JSR PC,(R0) ;GO TO THE TYPE ROUTINE AND TYPE CR, LF AND A 'P'
.ASCIZ /P/
.EVEN

;* SERVICE XXDP/ACT11
\$ENDAD: JSR PC,(R0) ;RETURN TO ACT11/XXDP MONITOR
NOP ;IF QUICK VERIFY=RESET ELSE NOP
NOP ;IF QUICK VERIFY=CLR #-1 ELSE INC #0
NOP ;IF QUICK VERIFY=BR .-4 ELSE NOP
BR RESTRT ;REPEAT TEST UNDER ACT11/XXDP

.=176
SWREG: .WORD 0

:SBTTL START AND RESTART ROUTINES
: RESTART AT 200 TO CLEAR APT TABLES
:*****

START AND RESTART ROUTINES

```

1078 000200 013706 000350      START:  MOV    @#SAVR6,SP      ;SETUP STACK POINTER.
1079 000204 012703 000412      MOV    #SUNIT,R3          ;CLEAR THE APT MAILBOX FROM $MAIL TO $DEVCT
1080 000210 005043              1$:   CLR    -(R3)           ;CLEAR A MAILBOX LOCATION
1081 000212 022703 000400      CMP    #SMAIL,R3         ;DONE?
1082 000216 001374              BNE    1$                ;BRANCH IF NO
1083 000220 105737 000042      TSTB  @#42               ;ACT11 MODE?
1084 000224 001011              BNE    RESTR             ;BRANCH IF YES
1085 000226 105737 000405      TSTB  @#$TESTN+1        ;ARE WE RELOCATED?
1086 000232 100406              BMI    RESTR             ;BR IF YES- SINCE TPCRLF IS RELOCATED ALSO-
1087 000234 004767 006334      JSR   PC,TPCRLF         ;PRINT TITLE
1088 000240 055103 046513 042501 .ASCIZ /CZKMAE0/
1089 000246 000060

```

```

1090                                .EVEN
1091
1092 000250 012704 007744      RESTR: MOV    #ENDPRG,R4    ;LOAD R4 WITH THE ADDRESS OF THE END OF THE PROGRAM
1093 000254 012703 000346      MOV    #SAVR5,R3         ;CAUSE R3 TO POINT TO THE LOCATION SAVR5
1094 000260 012305              MOV    (R3)+,R5         ;RESTORE R5
1095 000262 012306              MOV    (R3)+,SP        ;AND RESTORE R6 JUST IN CASE IT IS A RESTART
1096 000264 010600              MOV    SP,R0           ;PLACE THE STARTING ADDRESS OF THE TEST IN R0
1097 000266 012746 000340      MOV    #340,-(SP)       ;SET HIGH PRIORITY FOR RTI
1098 000272 010046              MOV    R0,-(SP)
1099 000274 000002              RTI
1100                                ;GO TO 'START'-MAY BE RELOCATED.
1101                                ;IF RELOCATED SEE LOCATION SAVR6 FOR START.

```

```

1102
1103
1104
1105
1106
1107
1108
1109      .SBTTL  APT PARAMETER BLOCK

```

```

1110      ;*****
1111      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
1112      ;*****
1113      ;*****
1114      .SX=      ;;SAVE CURRENT LOCATION
1115      =24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
1116 000024 200    ;;FOR APT START UP
1117      =44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
1118 000044 $APTHDR ;;POINT TO APT HEADER BLOCK
1119      =.SX     ;;RESET LOCATION COUNTER
1120      ;*****
1121      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
1122      ;INTERFACE SPEC.
1123
1124 $APTHD:
1125 000276 $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
1126 000300 $MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
1127 000302 $TSTM: .WORD 800.  ;;RUN TIM OF LONGEST TEST
1128 000304 $PASTM: .WORD 1200. ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
1129 000306 $UNITM: .WORD      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
1130 000310      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

```

1131
1132
1133      REL=$TESTN+1      ;IT WILL BE 0 IF THE PROGRAM IS IN THE LOWER

```



```

1190 000330 000000 HIGHTWO: 0 ;HOLDS BITS 17:16 OF HIGH TEST ADDRESS
1191 000332 037776 HIGHADD: 37776 ;HOLDS BITS 15:0 OF HIGH TEST ADDRESS
1192 ;:*****
1193
1194 000334 000000 $HIMAX: 0 ;HOLDS BITS 17:16 OF MAXIMUM AVAILABLE MEMORY
1195 000336 017776 $MAXM: 17776 ;HOLDS BITS 15:0 OF MAXIMUM AVAILABLE MEMORY
1196
1197 000340 000000 MAXMEM: .WORD ;MAXIMUM CURRENT VIRTUAL MEMORY UNDER TEST
1198
1199 000342 000000 SAVMAX: .WORD
1200 000344 000000 SAVR4: .WORD
1201 000346 000000 SAVR5: .WORD
1202
1203 ;* SAVR6 POINTS TO WHERE THE PROGRAM STARTS EVEN WHEN RELOCATED.
1204 000350 000500 SAVR6: .WORD BEGIN ;CONTAINS START ADDRESS WHEN RELOCATED ALSO.
1205 000352 000000 PARMAP: 0 ;MAP OF PARITY MODULES UNDER TEST.
1206 000354 000000 SAVLOC: 0 ;TEST 6 STORES ERROR INFO HERE
1207 000356 000000 PARSP: 0 ;SAVE SP DURING PARITY ERROR TRAP.
1208 000360 000000 PARPS: 0 ;SAVE PSW DURING PARITY ERROR TRAP.
1209 ;NOTE-PARSP +PARPS ARE NEEDED SINCE THERE IS
1210 ;IS NOT ENOUGH ROOM ON THE STACK (500-452) AND
1211 ;SO THE STACK MUST BE RESET IN THE PARERR ROUTINE.
1212 ;IN THIS CRUDE FASHION.
1213
1214
1215 ;*364-400 IS USED AS A STACK AREA BY ERRCHK ROUTINE FOR ERROR HISTORY PRINTOUT

```


1216 000400
1217
1218
1219
1220
1221 000400
1222 000400 000000
1223 000402 000000
1224 000404 000000
1225 000406 000000
1226 000410 000000
1227 000412 000000
1228 000414 000000
1229 000416 000000
1230 000420
1231 000420 000
1232 000421 000
1233 000422 000000
1234 000424 000000
1235 000426 000000
1236
1237
1238
1239
1240
1241
1242 000430 000
1243 000431 000
1244
1245
1246
1247
1248 000432 000000
1249
1250 000434 000
1251 000435 000
1252 000436 000000
1253 000440 000
1254 000441 000
1255 000442 000000
1256 000444 000
1257 000445 000
1258 000446 000000
1259 000450
1260
1261
1262
1263

```
      .=400  
      .SBTTL  APT MAILBOX-ETABLE  
  
      ::*****  
      .EVEN  
      $MAIL:      ::APT MAILBOX  
      $MSGTY: .WORD  AMSGTY  ::MESSAGE TYPE CODE  
      $FATAL: .WORD  AFATAL  ::FATAL ERROR NUMBER  
      $TESTN: .WORD  ATESTN  ::TEST NUMBER  
      $PASS:  .WORD  APASS   ::PASS COUNT  
      $DEVCT: .WORD  ADEVCT  ::DEVICE COUNT  
      $UNIT:  .WORD  AUNIT   ::I/O UNIT NUMBER  
      $MSGAD: .WORD  AMSGAD  ::MESSAGE ADDRESS  
      $MSGLG: .WORD  AMSGLG  ::MESSAGE LENGTH  
      $ETABLE:   ::APT ENVIRONMENT TABLE  
      $ENV:    .BYTE  AENV    ::ENVIRONMENT BYTE  
      $ENVM:  .BYTE  AENVM   ::ENVIRONMENT MODE BITS  
      $SWREG: .WORD  ASWREG  ::APT SWITCH REGISTER  
      $USWR:  .WORD  AUSWR   ::USER SWITCHES  
      $CPUOP: .WORD  ACPUOP  ::CPU TYPE,OPTIONS  
      ::*  
      ::*          BITS 15-11=CPU TYPE  
      ::*          11/04=01,11/05=02,11/20=03,11/40=04,11/45=05  
      ::*          11/70=06,PDQ=07,Q=10  
      ::*  
      ::*          BIT 10=REAL TIME CLOCK  
      ::*          BIT 9=FLOATING POINT PROCESSOR  
      ::*          BIT 8=MEMORY MANAGEMENT  
      $MAMS1: .BYTE  AMAMS1  ::HIGH ADDRESS,M.S. BYTE  
      $MTYP1: .BYTE  AMTYP1  ::MEM. TYPE,BLK#1  
      ::*  
      ::*          MEM.TYPE BYTE  -- (HIGH BYTE)  
      ::*          900 NSEC CORE=001  
      ::*          300 NSEC BIPOLAR=002  
      ::*          500 NSEC MOS=003  
      $MADR1: .WORD  AMADR1  ::HIGH ADDRESS,BLK#1  
      ::*          MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE  
      $MAMS2: .BYTE  AMAMS2  ::HIGH ADDRESS,M.S. BYTE  
      $MTYP2: .BYTE  AMTYP2  ::MEM. TYPE,BLK#2  
      $MADR2: .WORD  AMADR2  ::MEM.LAST ADDRESS,BLK#2  
      $MAMS3: .BYTE  AMAMS3  ::HIGH ADDRESS,M.S.BYTE  
      $MTYP3: .BYTE  AMTYP3  ::MEM. TYPE,BLK#3  
      $MADR3: .WORD  AMADR3  ::MEM.LAST ADDRESS,BLK#3  
      $MAMS4: .BYTE  AMAMS4  ::HIGH ADDRESS,M.S.BYTE  
      $MTYP4: .BYTE  AMTYP4  ::MEM. TYPE,BLK#4  
      $MADR4: .WORD  AMADR4  ::MEM.LAST ADDRESS,BLK#4  
      $ETEND:  
      .MEXIT  
  
      ::*****  
      .SBTTL  BEGIN OF AREA TESTED (+20) WHEN PROGRAM RELOCATES.
```

```

1264
1265 000450 177570      ;:*****
SWR: 177570 ;CHANGES TO SWREG IF NO HARDWARE SWITCH REGISTER
1266
1267 000500 000500      BEGIN:   .=500
1268 000500 010706      MOV     PC,SP           ;SET UP STACK POINTER TO EQUAL BEGIN ADDRESS
1269
1270 000502 005746      TST     -(SP)
1271 000504 010637 000350  MOV     SP,@#SAVR6     ;SAVE SP FOR FUTURE USE
1272 000510 012737 000070 000024  MOV     #PWRDN,@#24   ;PREPARE FOR ANY FUTURE POWER DOWN
1273 000516 005037 000300      CLR     @#$PRERR
1274 000522 005037 000314      CLR     @#TYPCNT
1275 000526 012700 000114      MOV     #114,R0       ;PREPARE TO SETUP PARITY TRAP VECTOR
1276 000532 012710 005474      MOV     #PARERR-,-6,(R0)
1277 000536 060720      ADD     PC,(R0)+      ;TO PARERR
1278 000540 012710 000340      MOV     #340,(R0)    ;AND PSW OF 340
1279 000544 105737 000405      TSTB   @#REL         ;IS THIS CODE RELOCATED?
1280 000550 100002      BPL     ONEPAS       ;BRANCH IF NO
1281 000552 000167 000572      JMP     TSTREL       ;THIS CODE IS RELOCATED SO GET TEST SIZE.
1282
1283 000556 005737 000406      ONEPAS: TST     @#$PASS   ;IS THIS THE FIRST PASS?
1284 000562 001402      BEQ     TSTRP        ;BRANCH IF YES (TEST TRAP CATCHER ADDRESSES)
1285 000564 000167 000406      JMP     SETSTK       ;GET THE TEST SIZE
1286 000570 012704 007744      TSTRP: MOV     #ENDPRG ,R4 ;LOAD R4 WITH THE ADDRESS OF THE END OF THE PROGRAM
1287 000574 012700 000377      MOV     #377,R0
1288 000600 010037 000316      MOV     R0,@#BAKPAT
1289 000604 005001      CLR     R1
1290 000606 012124      2$:    MOV     (R1)+,(R4)+ ;SAVE FROM 0000 TO BEGIN-30 AT END OF PROGRAM FOR NOW
1291 000610 020127 000400      CMP     R1,#$MAIL
1292 000614 103774      BLO     2$
1293 000616 005741      3$:    TST     -(R1)       ;PREPARE TO TEST THE TRAP VECTORS
1294 000620 010011      4$:    MOV     R0,(R1)     ;CHECK THE TRAP VECTORS FOR THE CAPABILITY
1295                                     ;OF HOLDING 0'S & 1'S
1296 000622 020011      CMP     R0,(R1)     ;IS THE DATA OK?
1297 000624 001403      BEQ     6$          ;BRANCH IF YES
1298
1299 000626 004767 005322      JSR     PC,FATERR    ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1300 000632 000001      1      ;*****ERROR NUMBER 1*****
1301
1302 000634 000300      6$:    SWAB   R0
1303 000636 001370      BNE     4$
1304 000640 005701      TST     R1           ;IF WE HAVE NOT REACHED THE LOWEST MEMORY LOCATION
1305 000642 001365      BNE     3$          ;THEN REPEAT FROM 3$
1306 000644 012701 000400      MOV     #$MAIL,R1
1307 000650 014441      8$:    MOV     -(R4),-(R1) ;RESTORE TRAP CATCHER ETC.
1308 000652 005701      TST     R1
1309 000654 001375      BNE     8$
1310 000656 012700 000006      SETSWR: MOV     #6,R0
1311 000662 012710 000340      MOV     #340,(R0)   ;SET UP TIME OUT TRAP PSW
1312 000666 012740 000700      MOV     #4$,-(R0)  ;AND THE RETURN ADDRESS
1313 000672 005777 177552      2$:    TST     @#SWR    ;DOES THE SWITCH REGISTER POINTED BY SWR EXIST ?
1314 000676 000404      BR     5$          ;BRANCH IF YES
1315 000700 022626      4$:    CMP     (SP)+,(SP)+ ;RESTORE THE STACK POINTER
1316 000702 012737 000176 000450      MOV     #SWREG,@#SWR ;AND PLACE THE ADDRESS OF THE SWITCH REGISTER
1317                                     ;DESIGNED FOR THE COMPUTERS NOT HAVING HARDWARE
1318                                     ;SWITCH REGISTER AND RUNNING STAND ALONE
1319 000710 105737 000420      5$:    TSTB   @#$ENV    ;RUNNING UNDER APT?

```

```

1320 000714 001403          BEQ      APTSIZ      ;BRANCH IF NO
1321 000716 012737 000422 000450      MOV      #$$SWREG,@#SWR ;SET SWR EQUAL TO APT SWITCH REGISTER.
1322
1323
1324
1325
1326          ;APTSIZ- THIS ROUTINE WILL SEARCH THE APT MEMORY ETABLE AND WHEN
1327          ;A NON ZERO TYPE IS FOUND WILL SETUP TO TEST TO GIVEN HIGH ADDRESS.
1328          ; IF APT DEFINES SIZE THE LOW TEST ADDRESS MUST=00000.(DUE TO ETABLE FORMAT)
1329          ;FLOW:
1330          ; IF BLOCK 4 (OR 3,2,1) TYPE NON ZERO THEN GET APT HIGH ADDRESS AND EXIT.
1331          ; ELSE SEND ERROR #3
1332          ;NOTE; THE MEMORY TYPE IS IGNORED SINCE ALL TESTS ARE RUN REGARDLESS OF MEMORY TYPE.
1333
1334 000724 012703 000340      APTSIZ: MOV      #MAXMEM,R3      ;POINT R3 TO MAXMEM.
1335 000730 013737 000330 000334      MOV      @#HIGHTWO,@#$HIMAX      ;IN CASE NO SELF SIZING DONE.
1336 000736 013737 000332 000336      MOV      @#HIGHADD,@#$MAXM      ;IN CASE NO SELF SIZING DONE.
1337 000744 105737 000421      TSTB    @#$ENVM      ;DOES APT ALLOW SELF SIZING?
1338 000750 100021          BPL      TRYSR      ;BRANCH IF YES
1339
1340 000752 012701 000451          MOV      #SMTYP4+4,R1      ;POINT R1 TO BLOCK TYPE 4(+4)
1341 000756 162701 000004      1$:     SUB      #4,R1      ;POINT R1 TO NEXT BLOCK TYPE.
1342 000762 105711          TSTB    (R1)      ;IS THE BLOCK TYPE NON ZERO?
1343 000764 001006          BNE      2$      ;BRANCH IF YES (MEMORY EXISTS)
1344 000766 020127 000431      CMP      R1,#SMTYP1      ;ALL APT BLOCK TYPES BEEN CHECKED?
1345 000772 101371          BHI      1$      ;BRANCH IF NO
1346
1347 000774 004767 005154          JSR      PC,FATERR      ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1348 001000 000002          2       ;*****ERROR NUMBER 2*****
1349
1350 001002 004767 006316      2$:     JSR      PC,GETADR      ;GO SET MAXIMUM APT ADDRESS INTO $MAXM + $HIMAX
1351 001006 004767 006312      JSR      PC,GETADR      ;GO SET MAXIMUM APT ADDRESS INTO HIGHADD+HIGHTWO
1352 001012 000453      BRTPSZ: BR      TYPsiz      ; TYPE THE SIZE OF MEMORY UNDER TEST
1353
1354 001014 032777 000100 177426      TRYSR:  BIT      #100,@SWR      ;USER DEFINED MEMORY TEST BOUNDARIES??
1355 001022 001047          BNE      TYPsiz      ;BRANCH IF YES (DON'T SIZE MEMORY)
1356
1357
1358
1359
1360
1361 001024 010401          SLFSIZ: MOV      R4,R1      ;SETUP R1 AND R4 TO THE LOWEST ADDRESS OF MEMORY
1362 001026 012710 001050      MOV      #4$,(R0)      ;SET UP RETURN ADDRESS FROM TIME OUT TRAP TO 4$
1363 001032 011111      2$:     MOV      (R1),(R1)      ;WRITE A MEMORY LOCATION INTO ITSELF AND TRAP IF NXM
1364 001034 062701 000002      ADD      #2,R1      ;ADD 2 TO THE ADDRESS POINTER
1365 001040 022701 170000      CMP      #170000,R1      ;CHECK IF BEYOND 30K MEMORY BOUNDARY
1366 001044 101372          BHI      2$      ;KEEP ON SIZING UP THE MEMORY UNTIL NXM TRAP
1367          ;(TIME OUT TRAP) IS ENCOUNTERED
1368 001046 000401          BR      5$      ;OR 30K BOUNDARY REACHED
1369
1370 001050 022626      4$:     CMP      (SP)+,(SP)+      ;RESTORE THE STACK POINTER
1371 001052 004767 005776      5$:     JSR      PC,MEMMNG      ; SERVICE MEMORY MANAGEMENT IF IT IS AVAILABLE
1372          ;AND IF IT HAS TO BE TESTED
1373 001056 105737 000276          TSTB    @#MMAVA      ;SEE IF MEMORY MANAGEMENT HAS TO BE TESTED
1374 001062 001416          BEQ      12$      ;IF NO MEM. MANG. THEN GO TO 12$
1375 001064 012710 001076      6$:     MOV      #8$,(R0)      ;SET UP THE RETURN ADDRESS FROM TRAP TO 8$
    
```

```

1376 001070 012701 020000      MOV      #20000,R1      ;BEGIN CHECKING MEMORY ABOVE 28K
1377 001074 000756              BR        2$
1378 001076 022626      8$:    CMP      (SP)+,(SP)+  ;RESTORE STACK POINTER
1379 001100 022701 160000      CMP      #160000,R1    ;IF R1 DID NOT READ ALL THE LOCATIONS POINTED BY
1380                                ;PAGE ADDRESS REGISTER 6 THEN IT HAS REACHED THE
1381                                ;MAXIMUM AVAILABLE MEMORY
1382 001104 001005              BNE      12$           ;IN WHICH CASE GO TO 12$
1383 001106 013702 172352      MOV      @#172352,R2   ;PREPARE TO UPDATE MEMORY MANAGEMENT REGISTERS
1384 001112 004767 005742      JSR      PC,MMREG     ;OTHERWISE GO TO UPDATE MEM. MANG. REGISTERS
1385 001116 000762              BR        6$
1386 001120 024341      12$:   CMP      -(R3),-(R1)  ;CAUSE R3 TO POINT TO LOCATION $MAXM AND R1
1387                                ;TO THE MAXIMUM AVAILABLE MEMORY
1388 001122 004767 006106      JSR      PC,PUTADR    ;GO TO THE SUBROUTINE TO PLACE THE ADDRESS IN R1
1389                                ;AT LOCATIONS $MAXM AND $HIMAX
1390 001126 024343              CMP      -(R3),-(R3)  ;MAKE R3 POINT TO HIGHADD
1391 001130 004767 006100      JSR      PC,PUTADR    ;PLACE THE ADDRESS IN R1 AT LOCATIONS HIGHADD
1392                                ;AND HIGHTWO
1393 001134 005743              TST      -(R3)
1394 001136 005043              CLR      -(R3)        ;CLEAR THE LOCATION LOWADD
1395 001140 005043              CLR      -(R3)        ;AND LOWTWO
1396 001142 012720 000104      TYPsiz: MOV     #BUSER,(R0)+ ;SET UP VECTOR FOR ANY FUTURE TRAP
1397 001146 010403              MOV      R4,R3        ;SET R3 TO POINT TO THE LOWEST AVAILABLE MEMORY
1398                                ;LOCATION
1399 001150 012701 000324      MOV      #LOWTWO,R1   ;
1400 001154 004767 005402      JSR      PC,PCRLF     ;TYPE CR/LF
1401 001160 004767 005550      JSR      PC,OCTTYP    ;TYPE LOW TEST ADDRESSE (LOWTWO+LOWADD)
1402 001164 004767 005304      TYPMEM: JSR     PC,$TYPE ; TYPE '-'
1403 001170 000055              .ASCIZ  /-/
1404                                .EVEN
1405 001172 004767 005536      JSR      PC,OCTTYP    ;TYPE HIGHEST TEST ADDRESS (HIGHTWO+HIGHADD)
1406 001176 012703 000330      SETSTK: MOV     #HIGHTWO,R3 ;MAKE R3 POINT TO THE HIGH ORDER BITS OF TOP ADDRESS
1407 001202 004767 006132      JSR      PC,$GTSIZ   ; GET THE BITS 13-17 OF THE TOP ADDRESS
1408                                ;PLACED IN BITS 0-4 OF R2
1409 001206 010401              MOV      R4,R1        ;SET R1 TO LOWEST TEST ADDRESS
1410
1411 001210 062704 000022      4$:    ADD      #18.,R4   ;APPEND THE ERROR STACK FOR THE MEMORY UNDER
1412                                ;TEST TO THE END OF THE PROGRAM
1413 001214 005302              DEC      R2
1414 001216 002374              BGE      4$
1415 001220 022737 167776 000336  CMP      #167776,@#$MAXM ;CHECK IF THIS IS A 30K SYSTEM
1416 001226 001002              BNE      5$           ;BRANCH IF NOT
1417 001230 062704 000022      ADD      #18.,R4     ;SAVE ANOTHER BANKS WORTH OF ERROR STACK
1418 001234 010437 000310      5$:    MOV      R4,@#ENDSTK ;SAVE THE ADDRESS OF THE END OF THE ERROR STACK
1419 001240 005021      6$:    CLR      (R1)+      ;CLEAR THE ERROR STACK
1420 001242 020104              CMP      R1,R4
1421 001244 101775              BLOS    6$
1422 001246 012737 157776 000340  MOV      #157776,@#MAXMEM ;SET MAXMEM TO MAXIMUM VIRTUAL ADDRESS
1423 001254 005723              TST      (R3)+        ;TESTING MEMORY MANAGEMENT?
1424 001256 001005              BNE      SAVLDR       ;BRANCH IF YES (GO SAVE LOADERS AT TOP OF VIRTUAL MEMORY)
1425 001260 021327 170000      CMP      (R3),#170000 ;IS THE VIRTUAL ADDRESS ABOVE 167776?
1426 001264 103002              BHIS    SAVLDR       ;BRANCH IF YES (GO SAVE LOADERS)
1427 001266 011363 000002      MOV      (R3),2(R3)  ;OTHERWISE MAKE THE CONTENTS OF LOCATION MAXMEM
1428                                ;EQUAL TO THE MAXIMUM AVAILABLE MEMORY
1429                                ;AND FALL INTO SAVE LOADERS.
1430
1431 001272 004767 006114      SAVLDR: JSR     PC,CLRMM ; DISABLE THE MEMORY MANAGEMENT UNIT

```

```

1432 001276 005723          TST      (R3)+      ;MAKE R3 TO POINT TO THE LOCATION MAXMEM
1433 001300 011305          MOV      (R3),R5    ;R5 CONTAINS THE ADDRESS OF MAXIMUM AVAILABLE MEM.
1434
1435          ;IF ONLY 4K BEING TESTED DON'T SAVE LOADERS
1436
1437 001302 020527 017776    CMP      R5,#17776  ;ONLY TESTING 4K MAX?
1438 001306 103416          BLO     4$          ;BRANCH IF YES (DON'T SAVE LOADERS)
1439
1440 001310 162705 000276    3$:     SUB      #276,R5  ;PREPARE TO SAVE 300 BYTES OF THE LOADERS
1441 001314 005737 000042    TST     @#42        ;IS THE PROGRAM RUNNING UNDER ACT OR XXDP ?
1442 001320 001406          BEQ     2$          ;IF NOT THEN GO TO 2$
1443 001322 023737 000042 000046    CMP     @#42,@#46  ;ARE WE RUNNING UNDER XXDP CHAIN MODE?
1444 001330 001402          BEQ     2$          ;BRANCH IF NO
1445 001332 162705 005674    SUB     #<1502.*2>,R5 ;SAVE 1500. WORDS FOR XXDP CHAIN MODE
1446 001336 012524          2$:     MOV     (R5)+,(R4)+ ;SAVE LOADER
1447 001340 020513          CMP     R5,(R3)
1448 001342 101775          BLOS   2$
1449 001344 012323          4$:     MOV     (R3)+,(R3)+ ;SAVE THE CONTENTS OF LOCATION MAXMEM IN SAVMAX
1450 001346 010423          MOV     R4,(R3)+  ;AND THE CONTENTS OF R4 AT SAVR4
1451
1452 001350 010537 000346    TSTREL: MOV    R5,@#SAVR5 ;SAVE HIGHEST VIRTUAL ADDRESS+2
1453 001354 004767 006032    TSTSIZ: JSR   PC,CLRMM  ;GO TO DISABLE MEMORY MANAGEMENT UNIT
1454 001360 005745          TST     -(R5)       ;SET R5 BACK TO HIGHEST VIRTUAL ADDRESS
1455 001362 012703 000324    1$:     MOV     #LOWTWO,R3 ;PREPARE TO LOAD R4 AND R5 WITH THE MEMORY BOUNDRIES
1456 001366 005723          TST     (R3)+      ;IF THE BITS 16,17 OF THE LOWEST LOCATION UNDER
1457          ;TEST ARE NON ZERO
1458 001370 001003          BNE     2$          ;THEN GO TO 2$
1459 001372 021327 157776    CMP     (R3),#157776 ;IF THE LOWEST LOCATION UNDER TEST IS HIGHER THAN
1460          ;157776 THEN GO TO TEST MEMORY MANAGEMENT
1461 001376 103411          BLO     4$
1462 001400 032777 010000 177042 2$:     BIT     #10000,@SWR  ;IS MEMORY MANAGEMENT SELECTED?
1463 001406 001003          BNE     3$          ;YES ALL IS WELL
1464 001410 004767 004540    JSR     PC,FATERR  ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1465 001414 000003          3       ;*****ERROR NUMBER 3*****
1466
1467 001416 000167 003514    3$:     JMP     TSTMM
1468 001422 020423          4$:     CMP     R4,(R3)+ ;GO TO TEST MEMORY MANAGEMENT
1469          ;COMPARE TOP OF PROGRAM (WITH SAVED LOADERS) TO
1470          ;LOWEST LOCATION UNDER TEST
1471 001424 103002          BHIS   6$
1472 001426 016304 177776    MOV     -2(R3),R4  ;ADJUST R4 TO POINT TO THE LOWEST LOCATION UNDER TEST
1473 001432 005723          6$:     TST     (R3)+  ;IF BITS 16-17 OF HIGHEST LOCATION TO BE TESTED
1474 001434 001003          BNE     8$          ;ARE NON ZERO THEN GO TO 8$
1475 001436 021305          CMP     (R3),R5    ;OTHERWISE SEE IF THE HIGHEST LOCATION TO BE
1476          ;TESTED IS HIGHER THAN HIGHEST VIRTUAL ADDRESS
1477 001440 101001          BHI     8$          ;IF SO THEN GO TO 8$
1478 001442 011305          MOV     (R3),R5    ;MODIFY R5
1479 001444 105737 000405    8$:     TSTB   @#REL     ;ARE WE RELOCATED.?
1480 001450 100014          BPL     10$        ;BRANCH IF NO
1481 001452 013704 000322    MOV     @#RELBOT,R4 ;SET BOTTOM TEST ADDRESS WHEN RELOCATED.
1482 001456 020527 017776    CMP     R5,#17776  ;ARE WE RELOCATED IN BANK 0?
1483 001462 103402          BLO     9$          ;BRANCH IF YES
1484 001464 012705 017776    MOV     #17776,R5  ;ELSE SET HIGH MEMORY UNDER TEST=4K
1485
1486 001470 020405          9$:     CMP     R4,R5  ;IS LOW LIMIT LOWER THAN HIGH LIMIT?
1487 001472 103403          BLO     10$        ;BRANCH IF YES

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 29

BEGIN OF AREA TESTED (+20) WHEN PROGRAM RELOCATES.

SEQ 0029

```

1488 001474 004767 004454          JSR    PC,FATERR      ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1489 001500 000004                   4          ;*****ERROR NUMBER 4*****
1490
1491 001502 012703 000342          10$:    MOV    #SAVMAX,R3
1492 001506 011343                   MOV    (R3),-(R3)    ;RESTORE THE CONTENTS OF MAXMEM
1493 001510 062713 000002          MEMTST: ADD   #2,(R3) ;MAKE THE CONTENTS OF MAXMEM = MAXIMUM AVAILABLE
1494                                     ;MEMORY +2
1495 001514 005725                   TST    (R5)+        ;AND SET R5=MAX MEMORY+2
1496
1497                                     ;CLEAR MEMORY UNDER TEST
1498
1499 001516 010500          CLRMEM: MOV    R5,R0      ;MOVE HIGH ADDRESS TO R0
1500 001520 005040          2$:    CLR    -(R0)      ;BEGIN CLEARING THE MEMORY FROM THE TOP
1501 001522 020004                   CMP    R0,R4        ;UNTIL THE BOTTOM IS REACHED
1502 001524 101375                   BHI    2$
1503 001526 012702 000001          MOV    #1,R2        ;SET R2 TO ENABLE PARITY MODULE CODE.
1504 001532 004767 005754          JSR    PC,PARITY    ;ENABLE PARITY IF WANTED AND AVAILABLE.
1505 001536 012702 000316          MOV    #BAKPAT,R2
1506 001542 012212          MOV    (R2)+,(R2)  ;WRITE SWAPPED BAKPAT IN LOCATION SWAPAT
1507 001544 000312          SWAB  (R2)
1508 001546 017702 176676          MOV    @SWR,R2     ;LOAD R2 WITH THE OPTIONS STORED AT $SWREG
1509 001552 042702 177760          BIC    #177760,R2 ;ONLY LEAVE THE LOWER 4 BITS OF $SWREG IN R2 TO GO TO
1510                                     ;THE TEST # SPECIFIED [DEFAULT IS TEST#0]
1511
1512
1513
1514                                     ;ENTER HERE FROM TSTSCP ROUTINE AT END OF SUBTEST
1515
1516 001556 005037 000306          CONT:  CLR    @#PASFLG ;INIT SUBTEST PASS FLAG.
1517 001562 110237 000404          MOV    R2,@#$TESTN  ;SET UP $TESTN WITH THE TEST NUMBER GOING
1518                                     ;TO BE EXECUTED
1519 001566 010401          LOOP:  MOV    R4,R1   ;LOAD R1 WITH THE LOWEST LOCATION UNDER TEST
1520 001570 010400          MOV    R4,R0       ;PLACE THE ADDRESS OF THE LOWEST LOCATION UNDER
1521                                     ;TEST IN R0
1522 001572 010403          MOV    R4,R3       ;AND IN R3
1523 001574 006302          ASL    R2
1524 001576 060702          ADD    PC,R2
1525 001600 066207 000004          ADD    TBL-,(R2),PC ;GO TO THE TEST #
1526                                     ;STORED IN BITS 0-3 OF SWITCH REGISTER
1527
1528
1529 001604 000102          TBL:   TST0-TBL    ;RELATIVE ADDRESS OF TEST # 0
1530 001606 000340          TST1-TBL    ;RELATIVE ADDRESS OF TEST # 1
1531 001610 000440          TST2-TBL    ;RELATIVE ADDRESS OF TEST # 2
1532 001612 000550          TST3-TBL    ;RELATIVE ADDRESS OF TEST # 3
1533 001614 001016          TST4-TBL    ;RELATIVE ADDRESS OF TEST # 4
1534 001616 001126          TST5-TBL    ;RELATIVE ADDRESS OF TEST # 5
1535 001620 001274          TST6-TBL    ;RELATIVE ADDRESS OF TEST # 6
1536 001622 001430          TST7-TBL    ;RELATIVE ADDRESS OF TEST # 7
1537 001624 001654          TST10-TBL   ;RELATIVE ADDRESS OF TEST # 10
1538 001626 002204          TST11-TBL   ;RELATIVE ADDRESS OF TEST # 11
1539 001630 002256          TST12-TBL   ;RELATIVE ADDRESS OF TEST # 12
1540 001632 002530          TST13-TBL   ;RELATIVE ADDRESS OF TEST # 13
1541 001634 003160          RELOC-TBL   ;RELATIVE ADDRESS OF ROUTINE 'RELOC'
1542
1543

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 30
CZKMAE.MAC 18-SEP-78 11:54

BEGIN OF AREA TESTED (+20) WHEN PROGRAM RELOCATES.

SEQ 0030

1544
1545
1546

;R5 IS POINTING TO THE TOP OF THE MEMORY TO BE TESTED+2
;R4 & R0 ARE POINTING TO THE LOWEST ADDRESS OF MEMORY TO BE TESTED

```

1547          ;*      SCOPE ROUTINE
1548          ;*      -----
1549          ;*
1550          ;*
1551          ;*      PROGRAM COMES TO THIS ROUTINE AFTER COMPLETION OF EACH TEST AND
1552          ;*      IF CNTRL-C TYPED GOTO ERROR HISTORY TYPE ROUTINE.
1553          ;*      IF SR= 2000 (BIT10) THEN HALT
1554          ;*      IF SR= 40000 (BIT14) THEN LOOP ON TEST DEFINED BY SR BITS<3:0>
1555          ;*      ELSE CONTINUE TO NEXT TEST.
1556          ;*
1557          ;*
1558          ;*
1559 001636 105737 000420      TSTSCP: TSTB  @#$ENV      ;ARE WE RUNNING UNDER APT?
1560 001642 001002          BNE      CNTSCP      ;IF SO THEN GO TO CNTSCP
1561 001644 004767 006022      JSR      PC,CHECKC ;TEST FOR CONTROL-C AND IF TYPED GO
1562          ;PRINT ERROR HISTORY AND HALT AT FATHLT.
1563 001650 113702 000404      CNTSCP: MOVB  @#$TESTN,R2 ;PLACE THE TEST NUMBER IN THE LOWER BYTE OF R2
1564          ;SINCE THERE ARE LESS THAN 377 TESTS UPPER BYTE
1565          ;OF R2 WILL BE 0
1566 001654 005237 000410          INC      @#$DEVCT ;TELL APT WE ARE STILL RUNNING OKAY
1567 001660 032777 002000 176562      BIT      #2000,@SWR ;IS THE PROGRAM GOING TO HALT AFTER EACH TEST?
1568 001666 001401          BEQ      TSTGO      ;IF NOT THEN GO TO 2$
1569 001670 000000          SWHALT: HALT ;HALT AT END OF TEST SWITCH SET.
1570          ;*
1571 001672 032777 040000 176550      TSTGO: BIT      #40000,@SWR ;IS THE PROGRAM GOING TO LOOP ON TEST
1572 001700 001332          BNE      LOOP      ;IF SO THEN GO TO THE STARTING OF THE SAME TEST
1573 001702 105202          INCB     R2
1574 001704 000724          BR      CONT      ;GO TO CONT AND CONTINUE EXECUTING THE NEXT TEST
  
```



```

1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587 001706 105737 000404
1588 001712 001403
1589 001714 004767 004234
1590 001720 000005
1591
1592 001722 012703 177777
1593 001726 010401
1594 001730 010310
1595 001732 020001
1596 001734 001417
1597 001736 005711
1598 001740 001430
1599 001742 020311
1600
1601
1602 001744 001004
1603 001746 012767 000006 000042
1604
1605 001754 000403
1606 001756
1607 001756 012767 000007 000032
1608
1609 001764 010046
1610 001766 105237 000301
1611 001772 000407
1612 001774 020311
1613 001776 001411
1614 002000 012767 000010 000010
1615
1616 002006 010046
1617 002010 010300
1618 002012 004767 003600
1619 002016 000000
1620 002020 012600
1621
1622 002022 013706 000350
1623 002026 062701 020000
1624
1625
1626 002032 020105
1627
1628 002034 103736
1629
1630 002036 105737 000421

```

```

*****
*TEST 0 TEST FOR PROPER BANK SELECTION
*(1) THIS TEST ASSUMES THAT THE MEMORY IS IN A STATE
* OF ALL 0'S AND R0 HAS THE ADDRESS OF THE LOWEST
* LOCATION UNDER TEST
*(2) IT CHECKS FOR PROPER BANK SELECTION BY WRITING
* 1'S IN A LOCATION AND CHECKING FOR 0'S IN THE SAME
* LOCATIONS OF OTHER 4K BANKS OF THE MEMORY
* [I.E. LOCATIONS LIKE 7766 AND 27766 ETC.]
*(3) THIS TEST ALSO CHECKS TO SEE THAT NONE OF THE NON EXIST-
* ING BANK RESPOND WHEN THEY ARE ADDRESSED
*****
TSTO: TSTB @#TESTN ;CHECK FOR PROPER TEST SEQUENCE
      BEQ .+10
      JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
      5 ;*****ERROR NUMBER 5*****
      MOV #177777,R3
1$: MOV R4,R1 ;R1 = ADDRESS OF LOWEST LOCATION OF MEMORY UNDER TEST
    MOV R3,(R0) ;SET ALL THE BITS AT (R0)
2$: CMP R0,R1 ;IS R0 POINTING TO THE SAME MEMORY LOCATION AS R1
    BEQ 4$ ;IN WHICH CASE CHECK FOR ALL 1'S AT (R1)
    TST (R1) ;OTHERWISE CHECK (R1) FOR ALL 0'S
    BEQ 5$
    CMP R3,(R1) ;IF R1 IS NOT EQUAL TO R0 AND (R1)
                ;DOES NOT CONTAIN ALL 0'S THEN
                ;CHECK TO SEE IF (R0) = (R1)
    BNE 3$
    MOV #6,12$ ;*ERROR* SETUP ERROR NO. IN 12$
                ;*****ERROR NUMBER #6*****
    BR 10$
3$: MOV #7,12$ ;*ERROR* SETUP ERROR NO. IN 12$
                ;*****ERROR NUMBER #7*****
10$: MOV R0,-(SP) ;SAVE R0 ON STACK
     INCB @#ADERR ;AN ADDRESSING ERROR IS SUSPECTED
     BR 11$
4$: CMP R3,(R1) ;CHECK (R1) FOR ALL 1'S
    BEQ 5$
    MOV #10,12$ ;*ERROR* SETUP ERROR NO. IN 12$
                ;*****ERROR NUMBER #10*****
    MOV R0,-(SP) ;SAVE R0 ON STACK
    MOV R3,R0
11$: JSR PC,ERROR ;GO TO THE ERROR SUBROUTINE
12$: .WORD ;ERROR NUMBER TO BE REPORTED WILL BE PLACED HERE
     MOV (SP)+,R0 ;RESTORE R0
5$: MOV @#SAVR6,SP ;RESTORE THE STACK POINTER
    ADD #20000,R1 ;CAUSE R1 TO POINT TO THE SAME CHIP
                ;LOCATION IN THE NEXT 4K BANK OF MEMORY
                ;BY ADDING 1 TO THE 14TH BIT OF ADDRESS IN R1
    CMP R1,R5 ;COMPARE R1 WITH THE HIGHEST MEMORY
                ;LOCATION WHICH IS STORED IN R5
    BLO 2$ ;IF R1 LESS THAN R5 THEN REPEAT THE TEST FROM 2$
    TSTB @#ENVM ;HAS APT INHIBITED SIZING?

```

```

1631 002042 100432          BMI      8$          ;BRANCH IF YES (DON'T TEST NON-EXISTENT MEMORY)
1632 002044 032777 000100 176376 BIT      #100,@SWR      ;HAS USER INHIBITED SIZING?
1633 002052 001026          BNE      8$          ;BRANCH IF YES (DON'T TEST NON-EXISTENT MEMORY)
1634
1635 002054 020127 157776          CMP      R1,#157776    ;SEE IF R1 HAS CROSSED 28K BOUNDRY OF VIRTUAL ADDRESS
1636 002060 101016          BHI      6$          ;IN WHICH CASE GO TO 6$
1637                                ;SHOULD BE LEFT AS IS FOR 30K SYSTEMS (WHICH USE 16K CHI
1638 002062 020137 000340          CMP      R1,@#MAXMEM  ;IS R1 LOWER THAN THE MAXIMUM AVAILABLE
1639                                ;MEMORY ?
1640 002066 103755          BLO      5$          ;IF SO THEN GO TO 5$
1641 002070 012702 000006          MOV      #6,R2        ;MAKE R2 POINT TO TRAP VECTOR+2 FOR NXM
1642 002074 012712 000340          MOV      #340,(R2)    ;SET PSW TO 340
1643 002100 012742 177714          MOV      #5$-,-6,-(R2) ;SET UP RETURN ADDRESS FROM TRAP TO 5$
1644 002104 060712          ADD      PC,(R2)
1645 002106 011111          MOV      (R1),(R1)    ;TRY TO WRITE TO NON-EXISTENT MEMORY (SHOULD TRAP)
1646 002110 004767 004040          JSR      PC,FATERR    ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1647 002114 000011          11                  ;*****ERROR NUMBER 11*****
1648
1649
1650 002116 012702 000004          6$: MOV      #4,R2
1651 002122 012722 000006          MOV      #6,(R2)+    ;RESTORE TRAP VECTOR
1652 002126 005012          CLR      (R2)
1653 002130 005010          8$: CLR      (R0)
1654
1655 002132 062700 020000          ADD      #20000,R0   ;CAUSE R0 TO POINT TO THE SAME CHIP
1656                                ;LOCATION IN THE NEXT 4K MEMORY BANK
1657                                ;BY ADDING 1 TO THE 14TH BIT OF ADDRESS IN R0
1658 002136 020005          CMP      R0,R5       ;COMPARE R0 WITH THE HIGHEST MEMORY
1659                                ;LOCATION WHICH IS STORED IN R5.
1660 002140 103672          BLO      1$          ;IF R0 LESS THEN REPEAT THE TEST
1661 002142 000635          ENDO: BR      TSTSCP
1662
1663

```

```

1664
1665
1666
1667
1668
1669 002144 122737 000001 000404 TST1:  CMPB  #1,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
1670
1671
1672 002152 001403 BEQ  .+10
1673 002154 004767 003774 JSR  PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1674 002160 000012 12 ;*****ERROR NUMBER 12*****
1675
1676 002162 012700 000001 1$:  MOV  #1,R0
1677 002166 010002 MOV  R0,R2 ;SET R2=1
1678 002170 010011 2$:  MOV  R0,(R1) ;MOV 1 AT LOCATION (R1)
1679 002172 020011 3$:  CMP  R0,(R1) ;COMPARE R1 WITH THE CONTENTS OF LOCATION (R1)
1680 002174 001403 BEQ  4$
1681 002176 004767 003414 JSR  PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
1682 002202 000013 13 ;*****ERROR NUMBER 13*****
1683
1684
1685 002204 005702 4$:  TST  R2 ;ARE WE SHIFTING A 0 IN DATA DIRECTION?
1686 002206 001406 BEQ  5$ ;IF SO THEN GO TO 5$
1687 002210 006300 ASL  R0 ;SHIFT THE 1 BROUGHT IN AT 1$ IN
1688 ;DATA DIRECTION
1689 002212 103366 BCC  2$ ;IF THE 1 HAS NOT BEEN SHIFTED THRU
1690 ;THE 16 DATA BITS THEN REPEAT FROM 2$
1691 002214 005002 CLR  R2 ;INITIATE SHIFTING OF 0 IN DATA DIRECTION
1692 002216 012700 177776 MOV  #177776,R0
1693 002222 000762 BR   2$
1694
1695 002224 000261 5$:  SEC  ;SET C BIT
1696 002226 006100 ROL  R0 ;SHIFT A 0 16 TIMES IN DATA DIRECTION
1697 002230 103757 BCS  2$ ;IF THE 0 HAS NOT BEEN SHIFTED THRU
1698 ;THE 16 DATA BITS THEN REPEAT FROM 2$
1699 002232 002701 020000 ADD  #20000,R1 ;OTHERWISE GO TO THE NEXT BANK OF
1700 ;4K MEMORY AND REPEAT THE TEST
1701 002236 020105 CMP  R1,R5
1702 002240 103750 BLO  1$
1703 002242 000737 END1: BR   ENDO
1704

```

```

1705      ;*****
1706      ;*TEST 2      TEST MEMORY FOR HOLDING DATA AND BYTE SELECTION
1707      ;*(1)      THIS TEST CHECKS THE MEMORY FOR THE CAPABILITY
1708      ;*          OF HOLDING 1'S AND 0'S BY WRITING A BACKGROUND
1709      ;*          OF BAKPAT AND READING IT
1710      ;*(2)      MEMORY IS WRITTEN USING A BYTE AT A TIME
1711      ;*(3)      STEPS 1 & 2 ARE REPEATED WITH A SWAPPED BACKGROUND PATTERN
1712      ;*****
1713 002244 122737 000002 000404 TST2:  CMPB    #2,@#STESTN    ;CHECK FOR PROPER TEST SEQUENCE
1714
1715 002252 001403          BEQ     .+10
1716 002254 004767 003674      JSR     PC,SEQERR    ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1717 002260 000014          BIC     #14          ;*****ERROR NUMBER 14*****
1718
1719 002262 013700 000316      1$:    MOV     @#BAKPAT,R0
1720 002266 110021          MOVVB  R0,(R1)+
1721 002270 113721 000317      MOVVB @#BAKPAT+1,(R1)+;WRITE THE MEMORY WITH THE WORD STORED IN BAKPAT
1722 002274 020105          CMP    R1,R5
1723 002276 103771          BLO   1$
1724
1725 002300 020041          2$:    CMP    R0,-(R1)    ;TEST THE MEMORY TO SEE IF IT CONTAINS
1726                          ;THE WORD STORED IN BAKPAT
1727 002302 001416          BEQ   8$
1728 002304 062701 000002      ADD   #2,R1
1729 002310 123741 000317      CMPB  @#BAKPAT+1,-(R1);CHECK FOR BYTE SELECTION PROBLEM
1730 002314 001402          BEQ   4$
1731 002316 120041          CMPB  R0,-(R1)    ;AGAIN CHECK FOR BYTE SELECTION PROBLEM
1732 002320 001002          BNE   6$
1733 002322 105237 000301      4$:    INCB  @#$ADERR    ;PREPARE TO INFORM THAT IT IS ADDRESSING ERROR
1734 002326 042701 000001      6$:    BIC   #1,R1      ;MAKE THE ADDRESS IN R1 EVEN
1735 002332 004767 003260      JSR   PC,ERROR    ;*ERROR* REPORT ERROR MESSAGE
1736 002336 000015          BIC   #15         ;*****ERROR NUMBER 15*****
1737
1738 002340 020104          8$:    CMP   R1,R4      ;KEEP ON TESTING THE MEMORY UNTIL
1739 002342 101356          BHI   2$          ;R1 EQUALS THE LOWEST ADDRESS
1740 002344 000337 000316      SWAB  @#BAKPAT    ;CHANGE THE DATA PATTERN
1741 002350 001744          BEQ   1$          ;IF THE DATA PATTERN DOES NOT HAVE LOW
1742                          ; BYTE =0 THEN FALL THRU
1743 002352 000733      END2: BR     END1
1744
1745                          ;THE TEST LEAVES BAKPAT LOCATION THE SAME AS IT WAS IN THE BEGINNING
1746

```

```
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758 002354 122737 000003 000404
1759 002362 001403
1760 002364 004767 003564
1761 002370 000016
1762
1763 002372 005003
1764 002374 004737 000120
1765
1766 002400 005002
1767 002402 050302
1768 002404 020204
1769 002406 103465
1770 002410 020205
1771 002412 103077
1772 002414 000312
1773
1774 002416 005001
1775 002420 050301
1776 002422 020104
1777 002424 103445
1778 002426 020105
1779 002430 103053
1780 002432 020102
1781 002434 001431
1782 002436 020011
1783
1784 002440 001437
1785 002442 012767 000017 000032
1786
1787 002450 010046
1788 002452 000316
1789 002454 022611
1790
1791 002456 001003
1792
1793
1794
1795 002460 012767 000020 000014
1796
1797 002466 105237 000301
1798 002472 010046
1799 002474 010200
1800 002476 004767 003114
1801 002502 000000
1802 002504 012600

*****
*TEST 3 DUAL ADDRESS TEST A
*****
*(1) THIS TEST CHECKS FOR DUAL ADDRESSING PROBLEMS BY WRITING A
* BACK GROUND OF BAKPAT.
*(2) STARTING FROM THE LOWEST LOCATION IN THE BANK THE TEST WRITES A
* LOCATION WITH SWAPPED BAKPAT
*(3) READS THE MEMORY FOR PROPER CONTENTS
*(4) SHIFTS A 1 ALONG THE ADDRESS DIRECTION AND REPEATS STEPS 1-3
*(5) REPEATS STEP 1-4 FOR EACH 4K BANK
*****
TST3: CMPB #3,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
      BEQ .+10
      JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
      16 ;*****ERROR NUMBER 16*****
      CLR R3
      JSR PC,@#WRTMEM ; WRITE MEMORY WITH THE BACKGROUND STORED
      ;AT LOCATION BAKPAT
      CLR R2
      BIS R3,R2 ;MAKE R2 POINT TO THE MEMORY BANK POINTED BY R3
      CMP R2,R4 ;IF R2 IS LESS THAN R4
      BLO 16$ ;THEN DO NOTHING
      CMP R2,R5 ;IF R2 IS HIGHER THAN THE HIGHEST LOCATION TO BE
      BHIS 20$ ;TESTED THEN EXIT THE TEST
      SWAB (R2) ;OTHERWISE WRITE THE COMPLEMENT OF BAKPAT IN
      ;THE LOCATION POINTED BY R2
      CLR R1
      BIS R3,R1
      CMP R1,R4 ;IF R1 IS POINTING TO A LOCATION LOWER THAN R4
      BLO 12$ ;THEN GO TO 12$
      CMP R1,R5
      BHIS 15$
      CMP R1,R2 ;CHECK THE MEMORY FOR CORRECT DATA
      BEQ 10$ ;IF R1 IS NOT = TO R2 THEN (R1) SHOULD HAVE
      CMP R0,(R1) ;THE SAME WORD AS BAKPAT
      ;IN WHICH CASE GO BACK TO 12$
      BEQ 12$ ;*ERROR* SETUP ERROR NO. IN 22$
      MOV #17,22$ ;*****ERROR NUMBER #17*****
      ;PLACE R0 ON THE STACK
      MOV R0,-(SP)
      SWAB (SP)
      CMP (SP)+,(R1) ;IF (R1) IS NOT = R0 THEN SEE IF IT IS SAME
      ;AS A SWAPPED R0
      BNE 9$ ;IF NOT THEN A SUSPECTED DUAL ADDRESSING PROBLEM
      ;FOR THE BITS THAT ARE DIFFERENT IN R0 AND (R1)
      ;OTHERWISE THERE IS DUAL ADDRESSING FOR THE
      ;ENTIRE WORD
      MOV #20,22$ ;*ERROR* SETUP ERROR NO. IN 22$
      ;*****ERROR NUMBER #20*****
      INCB @#SADERR ;ADDRESSING PROBLEM IS DETECTED
      MOV R0,-(SP) ;SAVE R0
      MOV R2,R0 ;SET R0=GOOD ADDRESS FOR ERROR REPORT
      JSR PC,ERROR ;GO TO THE ERROR SUBROUTINE
      .WORD ;ERROR NUMBER TO BE REPORTED WILL BE PLACED HERE
      MOV (SP)+,R0 ;RESTORE R0
```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 37
 CZKMAE.MAC 18-SEP-78 11:54 T3 DUAL ADDRESS TEST A

SEQ 0037

1803	002506	010011			MOV	R0,(R1)	:RESTORE (R1)
1804	002510	020037	000316		CMP	R0,@#BAKPAT	:IF THE CONTROL CAME HERE FROM 15\$-2 THEN
1805	002514	001411			BEQ	12\$	
1806	002516	000407			BR	11\$:RETURN TO 11\$
1807	002520	000300		10\$:	SWAB	R0	:MAKE R0 SAME AS SWAPPED BAKPAT
1808	002522	020011			CMP	R0,(R1)	:IF R1 = R2 THEN (R1) SHOULD CONTAIN A WORD
1809							:EQUAL TO SWAPPED R0
1810	002524	001404			BEQ	11\$:IN WHICH CASE GO BACK TO 11\$
1811	002526	012767	000021 177746		MOV	#21,22\$:*ERROR* SETUP ERROR NO. IN 22\$
1812							:*****ERROR NUMBER #21*****
1813	002534	000745			BR	8\$:AND GO TO 8\$
1814	002536	000300		11\$:	SWAB	R0	:RESTORE R0 TO BAKPAT
1815	002540	040301		12\$:	BIC	R3,R1	:TAKE OUT THE BANK ADDRESS FROM THE ADDRESS IN R1
1816	002542	005701			TST	R1	:IF R1 IS 0 THEN PLACE A 1 IN R1
1817	002544	001001			BNE	13\$:OTHERWISE GO TO 13\$
1818	002546	005201			INC	R1	
1819	002550	006101		13\$:	ROL	R1	
1820	002552	020127	020000		CMP	R1,#20000	:IF R1 IS LESS THAN A 4K BOUNDRY
1821	002556	103720			BLO	7\$:THEN REPEAT FROM 7\$
1822	002560	000312		15\$:	SWAB	(R2)	:RESTORE (R2) TO BAKPAT
1823	002562	040302		16\$:	BIC	R3,R2	:TAKE OUT THE BANK ADDRESS FROM THE ADDRESS
1824							:STORED IN R2
1825	002564	005702			TST	R2	:IF R2 = 0 THEN MOVE A 1 TO R2
1826	002566	001001			BNE	18\$:OTHERWISE GO TO 18\$
1827	002570	005202			INC	R2	
1828	002572	006102		18\$:	ROL	R2	:SHIFT A ONE IN THE ADDRESS WORD
1829	002574	020227	020000		CMP	R2,#20000	:IS THE ADDRESS IN R2 MORE THAN THE BOUNDRY
1830							:OF 4K
1831	002600	103700			BLO	6\$:IF NOT THEN GO TO 6\$
1832	002602	060203			ADD	R2,R3	:OTHERWISE MAKE R3 POINT TO THE NEXT 4K BANK
1833	002604	020337	000340		CMP	R3,@#MAXMEM	:IF R3 IS POINTING TO A BANK THAT IS LOWER
1834							:THAN MAXMEM
1835	002610	103673			BLO	4\$:THEN REPEAT FROM 4\$
1836	002612	000337	000316	20\$:	SWAB	@#BAKPAT	
1837	002616	001656			BEQ	TST3	:REPEAT THE TEST WITH SWAPPED BAKPAT ONLY IF
1838							:THE LOWER BYTE OF BAKPAT IS 0
1839	002620	000654		END3:	BR	END2	

```

1840
1841
1842
1843
1844
1845
1846 002622 122737 000004 000404 TST4:  CMPB  #4,@#STESTN  ;CHECK FOR PROPER TEST SEQUENCE
1847 002630 001403          BEQ    .+10
1848 002632 004767 003316          JSR    PC,SEQERR  ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1849 002636 000022          22          ;*****ERROR NUMBER 22*****
1850
1851 002640 005003          CLR    R3
1852 002642 010100          1$:  MOV    R1,R0
1853 002644 005703          TST   R3          ;IF R3 IS NOT 0 THEN STORE THE ADDRESS
1854 002646 001401          BEQ   R3          ;IN THE LOCATION
1855 002650 005100          COM   R0          ;OTHERWISE STORE COMPLEMENT
1856 002652 010021          2$:  MOV    R0,(R1)+ ;OF THE ADDRESS
1857 002654 020105          CMP   R1,R5      ;UNTIL THE HIGHEST MEMORY LOCATION IS REACHED
1858 002656 103771          BLO   1$
1859
1860 002660 020041          3$:  CMP   R0,-(R1)  ;CHECK THE LOCATION FOR THE CORRECT CONTENTS
1861 002662 001405          BEQ   4$
1862 002664 105237 000301          INCB  @#SADERR   ;THIS IS PROBABLY ADDRESS PROBLEM RATHER THAN
1863                                ;BIT PROBLEM
1864 002670 004767 002722          JSR   PC,ERROR  ;*ERROR* REPORT ERROR MESSAGE
1865 002674 000023          23          ;*****ERROR NUMBER 23*****
1866
1867 002676 010100          4$:  MOV    R1,R0
1868 002700 162700 000002          SUB   #2,R0      ;CHECK THAT THE ADDRESS IS STORED AT
1869 002704 005703          TST   R3          ;LOCATION IF R3 IS NOT 0
1870 002706 001401          BEQ   5$          ;OTHERWISE CHECK FOR
1871 002710 005100          COM   R0          ;ADDRESS COMPLEMENT
1872 002712 020104          5$:  CMP   R1,R4
1873 002714 101361          BHI   3$
1874 002716 112737 000001 000306          MOVB  #1,@#PASFLG ;SET PASFLG FOR ERROR REPORT.
1875 002724 005103          COM   R3          ;COMPLEMENT THE CONTENTS OF R3
1876 002726 001345          BNE   1$          ;REPEAT TST3 IF R3, IS NON 0, ENABLING ADDRESS
1877                                ;COMPLEMENT TO BE WRITTEN AND READ, OTHERWISE FALL THRU
1878 002730 000733          END4: BR    END3
1879

```

```

1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894 002732 122737 000005 000404 T5: *****
1895
1896 002740 001403 BEQ .+10
1897 002742 004767 003206 JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
1898 002746 000024 24 ;*****ERROR NUMBER 24*****
1899
1900 002750 004737 000120 1$: JSR PC,@#WRTMEM ;GO TO WRITE THE MEMORY WITH A BACKGROUND OF THE
1901 ;WORD STORED IN BAKPAT
1902 002754 020041 2$: CMP R0,-(R1) ;READ THE CONTENTS OF LOCATION POINTED BY R1
1903 002756 001403 BEQ 3$ ;TO SEE IF IT HAS THE SAME VALUE AS R0
1904 002760 004767 002632 JSR PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
1905 002764 000025 25 ;*****ERROR NUMBER 25*****
1906
1907 002766 000300 3$: SWAB R0
1908 002770 010011 MOV R0,(R1) ;SWAP THE BYTES AT (R1)
1909 002772 021100 CMP (R1),R0 ;READ (R1) FOR CORRECT VALUE
1910 002774 001403 BEQ 4$
1911 002776 004767 002614 JSR PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
1912 003002 000026 26 ;*****ERROR NUMBER 26*****
1913
1914
1915 003004 000300 4$: SWAB R0 ;SWAP THE BYTES OF THE REGISTER
1916 ;CONTAINING BACKGROUND PATTERN
1917 003006 001023 BNE 9$ ;IF THE LOWER BYTE OF THE REGISTER
1918 ;IS NOT 0 THEN THE PROGRAM IS READING
1919 ;THE MEMORY TO CONTAIN A BACK GROUND OF
1920
1921 ;BAKPAT AND WRITING THE SWAPPED WORD
1922
1923 ;IN WHICH CASE GO TO 9$
1924
1925 003010 005703 5$: TST R3 ;R3 WAS 0 WHEN THE PROGRAM ENTERED
1926 ;THIS TEST, AND IT IS NOT ALTERED UNTIL PASFLG=3
1927 ;IF R3 EQUAL 0 THEN THE PROGRAM IS
1928 ;READING/WRITING MIN. TO MAX. OTHERWISE
1929 ;IT IS GOING IN MAX. TO MIN. DIRECTION
1930 003012 001023 BNE 10$ ;IF R3 IS NOT CLEAR THEN GO TO 10$
1931 003014 062701 000002 6$: ADD #2,R1 ;OTHERWISE ADD 2 TO THE CONTENTS OF R1
1932 003020 020105 CMP R1,R5 ;COMPARE R1 WITH THE MAX. MEMORY LOCATION TO
1933 ;BE TESTED
1934 003022 103006 BHS 8$ ;IF R1>R5 THEN GO TO 8$ OTHERWISE
1935 003024 020011 7$: CMP R0,(R1) ;READ (R1) FOR THE CORRECT DATA
  
```


1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020

```

*****
;*TEST 6      CELLS' VOLATILITY TEST
;*(1) THIS TEST WRITES THE MEMORY WITH A BACK GROUND OF BAKPAT
;*(2) WITH PASFLG=0 THE TEST READS THE MEMORY FOR BAKPAT
;*(3) AND THEN INCREMENTS PASFLG
;*(4) IT THEN READS/SWAPS BYTES/Writes A LOCATION X FOR
;*(5) OVER 2 MSEC AND THEN READS THE MEMORY FOR BAKPAT
;*(6) REPEATS STEP 3 WITH X=X+4K UNTIL END OF MEMORY IS ENCOUNTERED
;*(7) IT THEN INCREMENTS PASFLG AND WRITES THE MEMORY TO
;*(8) BAKPAT AND WITH PASFLG=2 IT READS MEMORY FOR ALL
;*(9) SWAPPED BAKPAT AFTER WHICH PASFLG IS INCREMENTED TO 3
;*(10) REPEATS STEPS 3 AND 4 READING THE MEMORY FOR SWAPPED
;*(11) BAKPAT INSTEAD OF BAKPAT.
*****

003100 122737 000006 000404  TST6:  CMPB  #6,@#STESTN  ;CHECK FOR PROPER TEST SEQUENCE

003106 001403          BEQ    .+10
003110 004767 003040  JSR    PC,SEQERR  ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
003114 000030          JSR    30          ;*****ERROR NUMBER 30*****

003116 004737 000120  RPT6:  JSR    PC,@#WRTMEM  ;GO TO WRITE THE MEMORY WITH A BACKGROUND OF THE
                                ;WORD STORED AT LOCATION BAKPAT

003122 005037 000306  1$:   CLR    @#PASFLG
003126 010403          2$:   MOV    R4,R3      ;SET R3
003130 010401          3$:   MOV    R4,R1      ;AND R1 TO THE STARTING ADDRESS OF MEMORY UNDER TEST
003132 020011          3$:   CMP    R0,(R1)    ;CHECK (R1) FOR CORRECT DATA
003134 001403          BEQ    4$
003136 004767 002454  JSR    PC,ERROR    ;*ERROR* REPORT ERROR MESSAGE
003142 000031          JSR    31          ;*****ERROR NUMBER 31*****

003144 062701 000002  4$:   ADD    #2,R1      ;INCREMENT R1 BY 2
003150 020105          CMP    R1,R5      ;SEE IF R1 HAS REACHED THE MAX. OF MEMORY
003152 103767          BLO    3$
003154 132737 000001 000306  BITB  #1,@#PASFLG  ;CHECK TO SEE IF PASFLG=0 OR 2
003162 001002          BNE    5$
003164 105237 000306  INCB  @#PASFLG    ;IN WHICH CASE INCREMENT PASFLG COUNTER BY 1

003170 020305          5$:   CMP    R3,R5      ;SEE IF R3 HAS REACHED THE MAX. OF THE MEMORY
003172 103012          BHIS  7$
003174 012702 037776  MOV    #37776,R2   ;WRITE INTO 1 LOC FOR >2MS (ABOUT 100MS)
003200 000313          6$:   SWAB  (R3)
003202 005302          DEC    R2
003204 001375          BNE    6$
003206 010337 000354  MOV    R3,@#SAVLOC ;SAVE LOCATION WRITTEN FOR 2MS FOR ERROR REPORT.
003212 062703 020000  ADD    #20000,R3  ;BY ADDING 1 TO THE 14TH ADDRESS BIT CAUSE
                                ;R3 TO POINT TO A LOCATION IN THE NEXT
                                ;4K BANK OF MEMORY

003216 000744          BR     2$
003220 105237 000306  7$:   INCB  @#PASFLG  ;MAKE PASFLG=2
003224 000337 000316  SWAB  @#BAKPAT    ;IF BAKPAT IS NOT BEING SWAPPED FOR THE 2ND
003230 001732          BEQ    RPT6      ;THEN GO BACK TO THE LOCATION RPT6
003232 000721          END6: BR     END5
    
```

```

2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032 003234 122737 000007 000404
2033
2034 003242 001403
2035 003244 004767 002704
2036 003250 000032
2037
2038 003252 005037 000306
2039 003256 010337 000304
2040
2041 003262 010302
2042 003264 052702 017777
2043 003270 005202
2044 003272 001402
2045 003274 020502
2046 003276 103001
2047 003300 010502
2048
2049 003302 010337 000302
2050
2051 003306 013701 000304
2052
2053 003312 013700 000316
2054 003316 020103
2055 003320 001010
2056 003322 062703 000002
2057 003326 032703 000176
2058 003332 001402
2059 003334 062703 000200
2060 003340 000300
2061 003342 132737 000001 000306
2062
2063
2064 003350 001001
2065 003352 010011
2066
2067 003354 020011
2068
2069 003356 001403
2070 003360 004767 002232
2071 003364 000033
2072
2073 003366 062701 000002
2074 003372 020102
2075 003374 103746
2076 003376 005237 000410

:*****
:*TEST 7 SHIFTING DIAGONAL
:
:*(1) THIS TEST WRITES THE MEMORY WITH A BACKGROUND OF BAKPAT
:*(2) IT WRITES A DIAGONAL OF SWAPPED BAKPAT THROUGH EACH MEMORY BANK
:*(3) READS THE MEMORY FOR CORRECT DATA
:*(4) SHIFTS THE DIAGONAL AND REPEATS STEP 3 UNTIL THE
: DIAGONAL HAS BEEN SHIFTED 64 TIMES
:*(5) WRITES A BACKGROUND OF SWAPPED BAKPAT, A DIAGONAL OF
: BAKPAT AND REPEATS FROM STEP 3
:*****
TST7: CMPB #7,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
      BEQ .+10
      JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
      32 ;*****ERROR NUMBER 32*****
2$: CLR @#PASFLG
   MOV R3,@#LOWBNK ;LOWBNK CONTAINS ADDRESS OF THE LOWEST LOCATION
   ;IN THE 4K BANK THAT CAN BE TESTED
   MOV R3,R2
   BIS #17777,R2 ;R2 CONTAINS THE ADDRESS OF THE TOP OF THE BANK
   INC R2 ;ADD 1 TO POINT IT TO NEXT BANK
   BEQ 3$ ;BRANCH IF ZERO (IT MUST BE A 30K SYSTEM)
   CMP R5,R2
   BHIS 4$ ;IF R2 IS GREATER THAN R5 THEN GO TO 4$
   MOV R5,R2 ;NOW R2 CONTAINS THE ADDRESS OF THE HIGHEST LOCATION
   ;THAT CAN BE TESTED
4$: MOV R3,@#STRTDI ;LOAD STRTDI WITH THE STARTING ADDRESS OF THE
   ;DIAGONAL
   MOV @#LOWBNK,R1 ;R1 IS NOW POINTING TO THE LOWEST LOCATION IN THE 4K
   ;BANK
6$: MOV @#BAKPAT,R0 ;STORE THE CONTENTS OF BAKPAT IN R0
   CMP R1,R3 ;IS R1 POINTING TO A LOCATION IN THE DIAGONAL ?
   BNE 10$ ;IF NOT THEN GO TO 10$
   ADD #2,R3 ;THE FOLLOWING CODE IS USED TO PLACE THE
   BIT #176,R3 ;ADDRESS OF THE NEXT LOCATION IN THE DIAGONAL
   BEQ 8$ ;IN R3
   ADD #200,R3
8$: SWAB R0 ;DIAGONAL WILL CONTAIN SWAPPED BACKGROUND PATTERN
10$: BITB #1,@#PASFLG ;CONTENTS OF LOCATION PASFLG WILL BE EVEN IF THE
   ;MEMORY IS BEING WRITTEN AND IT WILL BE ODD
   ;IF IT IS ONLY BEING READ
   BNE 12$ ;IF IT IS BEING READ ONLY THEN GO TO 12$
   MOV R0,(R1) ;OTHERWISE WRITE THE MEMORY WITH THE CONTENTS
   ;OF R0
12$: CMP R0,(R1) ;CHECK THE LOCATION POINTED BY R1 TO CONTAIN
   ;PROPER DATA
   BEQ 14$ ;IF IT IS OK THEN GO TO 14$
   JSR PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
   33 ;*****ERROR NUMBER 33*****
14$: ADD #2,R1 ;CAUSE R1 TO POINT TO THE NEXT MEMORY LOCATION
   CMP R1,R2 ;IS IT THE END OF THE BANK ?
   BLO 6$ ;IF NOT THEN GO TO 6$
16$: INC @#$DEVCT ;TELL APT WE ARE STILL RUNNING OKAY
  
```

2077	003402	105237	000306		INCB	@#PASFLG
2078	003406	013703	000302		MOV	@#STRDI,R3
2079	003412	132737	000001	000306	BITB	#1,@#PASFLG
2080	003420	001330			BNE	4\$
2081	003422	005723			TST	(R3)+
2082	003424	020302			CMP	R3,R2
2083	003426	103003			BHIS	18\$
2084	003430	105737	000306		TSTB	@#PASFLG
2085	003434	100322			BPL	4\$
2086	003436	013703	000304	18\$:	MOV	@#LOWBNK,R3
2087						
2088	003442	000337	000316		SWAB	@#BAKPAT
2089	003446	001715			BEQ	4\$
2090						
2091	003450	010203			MOV	R2,R3
2092						
2093	003452	020205			CMP	R2,R5
2094						
2095	003454	103676			BLO	2\$
2096	003456	000665		END7:	BR	END6

;LOAD R3 WITH THE STARTING ADDRESS OF THE DIAGONAL
;HAS THE READ OF THE MEMORY BEEN DONE ?
;IF NOT THEN GO TO 4\$
;ADD 2 TO THE STARTING ADDRESS OF THE DIAGONAL
;AND UNLESS THE END OF THE BANK IS REACHED
;
;OR THE DIAGONAL HAS BEEN ROTATED 64 TIMES
;REPEAT FROM 4\$
;MAKE R3 POINT TO THE LOWEST LOCATION IN THE
;IN THE BANK UNDER TEST

;AND IF THE TEST HAS NOT BEEN PERFORMED WITH THE
;SWAPPED BACK GROUND PATTERN THEN GO TO 4\$
;MAKE THE PRESENT HIGH BOUNDRY AS THE NEXT
;LOW BOUNDRY
;UNLESS THE PRESENT HIGH BOUNDRY IS ALSO THE
;HIGH BOUNDRY FOR THE MEMORY UNDER TEST

```

2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152

```

```

:*****
;*TEST 10      READ RECOVERY GALLOPING TEST/EVERY 64TH CELL
                ;*(1)  THIS TEST WRITES THE MEMORY WITH A BACK GROUND PATTERN
                ;*      STORED AT LOCATION BAKPAT
                ;*(2)  TEST BEGINS AT LOWEST LOCATION BEING TESTED
                ;*      (LETS NAME IT 'A')
                ;*(3)  LETS NAME THE 1ST LOCATION IN THE ROW/COLUMN UNDER TEST AS 'B'.
                ;*(4)  SWAPS BYTES FOR LOCATION 'A'.
                ;*(5)  READS 'A', READS 'B'
                ;*(6)  'B' = 'B'+200 (MAKES 'B'=64TH CELL I.E. 200TH OCTAL
                ;*      LOCATION FROM THE PRESENT LOCATION OF 'B')
                ;*(7)  REPEATS STEPS 5 AND 6 UNTIL 'B' IS GREATER THAN THE
                ;*      END OF THE 4K BANK OF THE MEMORY IN WHICH 'A' IS RESIDING
                ;*(8)  A = A+2
                ;*(9)  REPEATS STEPS 3-8 UNTILL 'A' REACHES THE END OF THE BANK
                ;*(10) GOES TO THE NEXT 4K BANK OF MEMORY AND REPEATS STEPS
                ;*      3-9 UNTIL THE END OF THE MEMORY
                ;*(11) AFTER EXECUTING THE TEST BYTES ARE SWAPPED AT
                ;*      LOCATION BAKPAT AND STEPS 1-10 ARE REPEATED
                ;*(12) IN THIS TEST R0 IS POINTING TO LOCATION 'A', R1 TO
                ;*      LOCATION 'B', R2 TO THE END OF THE 4K BANK IN WHICH THE
                ;*      TEST IS TAKING PLACE AND R3 TO THE LOWEST LOCATION IN THE
                ;*      COLUMN/ROW CONTAINING 'A' AND 'B'
                ;*(13) MOST OF THE CODE USED BY THIS TEST IS ALSO USED BY TEST 11

```

```

2124 003460 122737 000010 000404 TST10: CMPB    #10,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
2125
2126 003466 001403          BEQ      .+10
2127 003470 004767 002460     JSR      PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
2128 003474 000034          34 ;*****ERROR NUMBER 34*****
2129
2130 003476 010402          MOV      R4,R2 ;SET R2 TO THE LOWEST MEMORY UNDER TEST
2131 003500 052702 017776     RPT10: BIS      #17776,R2 ;MAKE R2 POINT TO THE HIGHEST LOCATION IN THE 4K
2132 ;BANK FOR WHICH GALLOPING WILL BE PERFORMED
2133 003504 062702 000002     GALLOP: ADD     #2,R2 ;INCREMENT R2 BY 2
2134 003510 001402          BEQ      1$ ;BR IF IT WENT TO 0 (IT MUST BE A 30K SYSTEM)
2135 003512 020205          CMP      R2,R5 ;IF THE HIGH BOUNDRY OF THE TEST IS HIGHER THAN
2136 003514 101401          BLOS    2$ ;THE MAXIMUM ALLOWED ADDRESS THEN ADJUST R2
2137 003516 010502          1$: MOV      R5,R2
2138 003520 005046          2$: CLR      -(SP)
2139 003522 010200          MOV      R2,R0
2140 003524 013740 000316     4$: MOV      @#BAKPAT,-(R0) ;WRITE THE MEMORY UNDER TEST WITH A BACKGROUND OF
2141 ;BAKPAT
2142 003530 020003          CMP      R0,R3
2143 003532 101374          BHI     4$
2144 003534 010301          6$: MOV      R3,R1 ;R3 AND R1 ARE POINTING TO THE LOWEST LOCATION THAT
2145 ;CAN BE TESTED IN THIS BLOCK
2146 003536 023710 000316     CMP      @#BAKPAT,(R0) ;BEFORE STARTING THE GALLOPING TEST FOR LOCATION
2147 ;(R0) CHECK IT
2148 003542 001410          BEQ      8$ ;CONTINUE IF OK
2149 003544 010001          MOV      R0,R1 ;OTHERWISE PREPARE TO REPORT THE ERROR
2150 003546 013700 000316     MOV      @#BAKPAT,R0
2151 003552 004767 002040     JSR      PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
2152 003556 000035          35 ;*****ERROR NUMBER 35*****

```



```

2209 003762 020205          CMP      R2,R5
2210 003764 001410          BEQ      END10          ;IF PREVIOUS HIGH BOUNDRY WAS THE END OF THE
2211                                     ;TEST BOUNDRY THEN EXIT THE TEST
2212 003766 032702 017776    BIT      #17776,R2      ;WAS IT A 4K BOUNDRY ?
2213 003772 001025          BNE      RPT11          ;IF NOT THEN WE WERE PERFORMING TEST 11 WITH LONG
2214                                     ;GALLOPING TEST DISABLED
2215 003774 122737 000011 000404  CMPB    #11,@#STESTN    ;IF IT IS TEST # 11 THEN GO TO REPEAT TEST 11
2216 004002 001421          BEQ      RPT11
2217 004004 000635          BR       RPT10          ;OTHERWISE REPEAT TEST 10
2218 004006 000623          END10: BR      END7
2219
2220
2221

```

```
2222 ::*****  
2223 :*TEST 11 READ RECOVERY LONG GALLOPING/FAST GALLOPING TEST  
2224  
2225 :*(1) THIS TEST WRITES MEMORY WITH BAKPAT  
2226 :*(2) THE TEST BEGINS AT THE LOWEST LOCATION BEING TESTED  
2227 :* (LETS NAME IT 'B')  
2228 :*(3) 'A' 'B' [MOVE THE ADDRESS OF 'B' TO THE POINTER FOR LOCATION 'A']  
2229 :*(4) SWAPS BYTES FOR LOCATION 'A'  
2230 :*(5) READS 'A', READS 'B'  
2231 :*(6) 'B'='B'+2  
2232 :*(7) IF GALLOPING OPTION BIT AT $SWREG IS HIGH THEN STEPS 4 AND 5  
2233 :* ARE REPEATED UNTIL 'B' REACHES THE HIGHEST MEMORY LOCATION  
2234 :* OF THE 4K BANK IN WHICH 'A' IS RESIDING, THEN 'A' IS  
2235 :* DECREMENTED BY 2 AND AFTER MAKING 'B' TO POINT TO THE LOWEST  
2236 :* LOCATION OF THE 4K MEMORY BANK CONTAINING 'A' STEPS 3,4,5 AND  
2237 :* 6 ARE REPEATED UNTIL 'A' EQUALS THE END OF THE ENTIRE MEMORY  
2238 :*(8) IF GALLOPING OPTION BIT IS NOT HIGH THEN STEPS 4 AND 5 ARE  
2239 :* REPEATED UNTIL 'B' IS POINTING TO A CELL IN THE NEXT COLUMN  
2240 :* IF SEQUENTIAL CELLS LIE ALONG THE ROW, OR THE NEXT ROW  
2241 :* IF SEQUENTIAL CELLS LIE ALONG THE COLUMN, AT WHICH TIME  
2242 :* STEPS 2,3,4,5 AND 7 ARE REPEATED UNTIL THE END OF THE MEMORY  
2243 :*(9) TEST IS REPEATED FOR THE OPPOSITE BACKGROUND DATA  
2244 :*(10) IN THIS TEST R0 POINTS TO LOCATION 'A', R1 TO LOCATION  
2245 :* 'B', R2 TO THE HIGHEST LOCATION AND R3 TO THE LOWEST  
2246 :* LOCATION IN A 64/4K CELL BOUNDRY  
2247 :*(11) MOST OF THE CODE USED BY TEST 10 IS ALSO USED BY THIS TEST  
2248  
2249
```

```
2250 004010 122737 000011 000404 TST11: CMPB #11,@$TESTN ;CHECK FOR PROPER TEST SEQUENCE  
2251  
2252 004016 001403 BEQ .+10  
2253 004020 004767 002130 JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT  
2254 004024 000040 40 ;*****ERROR NUMBER 40*****  
2255  
2256 004026 010402 MOV R4,R2 ;MAKE R2 TO POINT TO THE LOWEST LOCATION  
2257 ;UNDER TEST  
2258 004030 105777 174414 TSTB @SWR ;LONG GALLOP ENABLED?  
2259 004034 100004 BPL RPT11 ;BRANCH IF NO  
2260 004036 004767 002540 JSR PC,PNTMES ;TYPE 'GLP'  
2261 004042 046107 000120 .ASCIZ /GLP/  
2262 004046 105777 174376 RPT11: TSTB @SWR ;LONG GALLOPING ENABLED?  
2263 004052 100612 BMI RPT10 ;BRANCH IF YES  
2264 ;TO RPT10  
2265 004054 052702 000176 BIS #176,R2 ;OTHERWISE SET THE LOW ORDER BITS OF THE ADDRESS  
2266 ;TO GET THE HIGH BOUNDRY  
2267  
2268 004060 000611 BR GALLOP ; PERFORM GALLOPING TEST
```



```

2269      ;*****
2270      ;*TEST 12      WORST CASE TESTING FOR CORE MEMORY
2271      ;*(1)        STARTING FROM THE LOWEST LOCATION UNDER TEST THE MEMORY
2272      ;*           IS WRITTEN WITH A BACKGROUND OF BAKPAT, HOWEVER LOCATIONS
2273      ;*           HAVING ADDRESS SUCH THAT EXCLUSIVE OR OF ADDRESS BITS 1 &
2274      ;*           8 = 1 ARE WRITTEN TO A VALUE OF SWAPPED BAKPAT
2275      ;*(2)        STARTING FROM THE LOWEST LOCATION THE MEMORY IS CHECKED
2276      ;*           TO CONTAIN THE CORRECT DATA AS EXPLAINED IN STEPS 3 & 4,
2277      ;*           UNTILL THE HIGHEST LOCATION UNDER TEST IS REACHED
2278      ;*(3)        READ EACH LOCATION FOR THE CORRECT CONTENT
2279      ;*(4)        COMPLEMENT THE LOCATION AND READ IT; COMPLEMENT THE LOCATION
2280      ;*           BACK TO ITS ORIGINAL VALUE AND READ IT AGAIN
2281      ;*(5)        STARTING FROM THE HIGHEST LOCATION UNDER TEST REPEAT STEPS
2282      ;*           3 & 4 UNTIL THE LOWEST LOCATION UNDER TEST IS REACHED
2283      ;*(6)        REPEAT STEPS 1-5, HOWEVER THIS TIME LOCATIONS WITH XOR
2284      ;*           OF ADDRESS BITS 8 & 13 =1 ARE WRITTEN TO SWAPPED BAKPAT
2285      ;*(7)        REPEAT STEPS 1-5, HOWEVER THIS TIME LOCATIONS WITH XOR
2286      ;*           OF ADDRESS BITS 3 & 9 =1 ARE WRITTEN TO SWAPPED BAKPAT
2287      ;*(8)        REPEAT STEPS 1-7 WITH A BACKGROUND OF SWAPPED BAKPAT AND
2288      ;*           THE LOCATIONS TO BE WRITTEN TO SWAPPED BAKPAT WRITTEN TO
2289      ;*           BAKPAT.
2290      ;*****
2291 004062 122737 000012 000404 1ST12: CMPB  #12,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
2292 004070 001403          BEQ    .+10
2293 004072 004767 002056          JSR    PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
2294 004076 000041          41     ;*****ERROR NUMBER 41*****
2295
2296
2297 004100 012702 000002          MOV    #2,R2 ;PREPARE TO TAKE THE EXCLUSIVE OR OF ADDRESS BITS 1
2298 004104 012703 000400          MOV    #400,R3 ;AND 8
2299 004110 112737 000001 000306 1$:  MOVB  #1,@#PASFLG ;INITIALIZE THE COUNTER FOR THE SUBTEST
2300 004116 010401          2$:  MOV    R4,R1 ;PLACE THE STARTING ADDRESS OF MEMORY UNDER
2301                                     ;TEST IN R1
2302 004120 013700 000316          4$:  MOV    @#BAKPAT,R0
2303 004124 030201          BIT    R2,R1 ;CHECK TO SEE IF ADDRESS BIT STORED IN R2 IS SET
2304 004126 001004          BNE   8$ ;IF IT IS SET THEN GO TO 8$
2305 004130 030301          BIT    R3,R1 ;CHECK TO SEE IF ADDRESS BIT POINTED BY R3 IS SET
2306 004132 001404          BEQ   12$ ;IF IT IS NOT SET THEN GO TO 12$
2307 004134 005100          6$:  COM    R0 ;COME HERE ONLY IF EXCLUSIVE OR OF ADDRESS BITS
2308                                     ;POINTED BY R2 & POINTED BY R3 = 1 IN WHICH
2309                                     ;CASE PREPARE TO WRITE THE LOCATION
2310                                     ;WITH A COMPLEMENT OF LOCATIONS NOT MEETING
2311                                     ;THIS CONDITION
2312 004136 000402          BR    12$
2313 004140 030301          8$:  BIT    R3,R1 ;COME HERE IF ADDRESS BIT POINTED BY R2 IS 1 AND
2314                                     ;CHECK ADDRESS BIT POINTED BY R3
2315 004142 001774          BEQ   6$ ;IF ADDRESS BIT POINTED BY R3 IS 0 THEN GO TO 6$
2316 004144 132737 000002 000306 12$: BITB  #2,@#PASFLG ;IS IT 2ND OR 3RD PASS OF THE SUBTEST ?
2317 004152 001001          BNE   14$ ;IF SO THEN READ THE MEMORY

```

```

2318 004154 010011          MOV    R0,(R1)      ;OTHERWISE WRITE THE MEMORY BFORE READING IT
2319 004156 020011          CMP    R0,(R1)      ;READ THE MEMORY FOR CORRECT CONTENTS
2320 004160 001403          BEQ   16$
2321 004162 004767 001430    JSR   PC,ERROR      ;*ERROR* REPORT ERROR MESSAGE
2322 004166 000042          42                ;*****ERROR NUMBER 42*****
2323
2324 004170 012746 000002    16$:  MOV    #2,-(SP)
2325 004174 005100          18$:  COM    R0
2326 004176 005111          COM    (R1)
2327 004200 020011          CMP    R0,(R1)      ;READ THE MEMORY AGAIN
2328 004202 001404          BEQ   19$
2329 004204 004767 001406    JSR   PC,ERROR      ;*ERROR* REPORT ERROR MESSAGE
2330 004210 000043          43                ;*****ERROR NUMBER 43*****
2331
2332 004212 010011          MOV    R0,(R1)      ;RESTORE THE LOCATION (R1)
2333 004214 005316          19$:  DEC    (SP)
2334 004216 001366          BNE   18$           ;EXECUTE THE CODE FROM 18$ TWICE
2335 004220 005726          TST   (SP)+        ;RESTORE THE STACK POINTER
2336 004222 122737 000003 000306  CMPB  #3,@#PASFLG  ;IS IT THE 3RD PASS OF THE SUBTEST ?
2337 004230 001412          BEQ   20$           ;IF SO THEN GO TO 20$
2338 004232 062701 000002    ADD   #2,R1        ;IN FIRST 2 PASSES THE PROGRAM PROCEEDS IN
2339                                     ;MIN. TO MAX. DIRECTION
2340 004236 020105          CMP   R1,R5        ;HAVE WE REACHED THE MAX. ADDRESS UNDER TEST ?
2341 004240 103727          BLO   4$           ;IF NOT THEN REPEAT FROM 4$
2342 004242 105237 000306    INCB  @#PASFLG
2343 004246 122737 000002 000306  CMPB  #2,@#PASFLG  ;IF IT IS THE 2ND PASS OF THE SUBTEST
2344 004254 001720          BEQ   2$           ;THEN REPEAT FROM 2$
2345 004256 162701 000002    20$:  SUB   #2,R1        ;OTHERWISE EXECUTE THE TEST IN MAX. TO MIN.
2346                                     ;DIRECTION
2347 004262 020104          CMP   R1,R4        ;HAVE WE REACHED THE MIN. ADDRESS UNDER TEST ?
2348 004264 103315          BHIS  4$           ;IF NOT THEN REPEAT FROM 4$
2349 004266 012702 020000    MOV   #20000,R2    ;PREPARE TO CHECK THE MEMORY WITH THE XOR OF
2350                                     ;ADDRESS BITS 8 AND 13
2351 004272 105237 000307          INCB  @#PASFLG+1   ;THE SUB TEST HAS CHECKED THE XOR ONE KIND
2352 004276 123727 000307 000002  CMPB  @#PASFLG+1,#2 ;HAS TWO XOR COMBINATIONS BEEN CHECKED ?
2353 004304 103701          BLO   1$           ;IF NOT THEN GO TO 1$
2354 004306 101004          BHI   22$          ;IF ALL THREE HAVE BEEN CHECKED THEN GO TO 22$
2355 004310 012702 000010    MOV   #10,R2       ;IF IT IS THE 2ND XOR COMBINATION THEN CHECK
2356 004314 006303          ASL   R3           ;FOR ADDRESS BITS 3 & 8
2357 004316 000674          BR    1$
2358 004320 005137 000316          22$:  COM   @#BAKPAT    ;IF THE TEST WAS NOT PERFORMED WITH THE SWAPPED
2359 004324 105737 000316          TSTB  @#BAKPAT
2360 004330 001654          BEQ   TST12
2361 004332 000625          END12: BR    END10

```

```

2362 .....
2363 *TEST 13 WRITE RECOVERY TEST
2364 * THIS TEST DIFFERS FROM 0-12 IN THAT IT CONSISTS OF A SMALL TEST PROGRAM
2365 * ACTUALLY RUNNING IN THE 4K BANK UNDER TEST.
2366 * THE PROGRAM IS SELF MODIFYING AND MAY BE DIFFICULT TO DEBUG.
2367 * TO AID IN THE DEBUG, BEFORE A A BANK IS ENTERED 'TST13 BANK XX'
2368 * IS TYPED. THIS WILL ALLOW THE USER TO AT LEAST SEE WHICH MEMORY
2369 * BANK FAILED.
2370 * THE TEST CONSISTS OF 1/2 OF THE BANK STORED WITH 'MOV R2,-(PC)''
2371 * AND THE OTHER 1/2 CONTAINING '177667'. '177667' IS THE COMPLEMENT
2372 * OF 'JMP (R0)'' INSTRUCTION.
2373 * R2 CONTAINS 'COM -(R1)'' INSTRUCTION ON ENTRY TO THE BANK AND R1 CONTAINS
2374 * THE HIGHEST TEST ADDRESS IN THAT BANK. THE HIGHEST TEST ADDRESS IS
2375 * USUALLY ON 4K BOUNDARIES. WHEN TESTING BANK 0 RELOCATED, HOWEVER
2376 * R1 CONTAINS THE FIRST FREE TEST ADDRESS BELOW THE DIAGNOSTIC.
2377 * IF YOU UNDERSTAND THIS SO FAR THE REST IS EASY.
2378 * THE TEST EXECUTION IS AS FOLLOWS:
2379 * 1. THE 'MOV R2,-(PC)'' INSTRUCTION EXECUTES STORING
2380 * THE CONTENTS OF R2 IN THE ADDRESS IT VACATED (DUE TO -(PC).
2381 * 2. SINCE R2 CONTAINS A 'COM -(R1)'' INSTRUCTION IT COMPLEMENTS
2382 * THE HIGHEST ADDRESS UNDER TEST. THIS ADDRESS CONTAINED
2383 * '177667' SO AFTER THE COM -(R1) IT EQUALS 110
2384 * CLEVERLY THIS IS THE 'JMP (R0)'' INSTRUCTION.
2385 * 3. THIS SEQUENCE CONTINUES UNTIL THE 'MOV R2,-(PC) INSTRUCTIONS
2386 * REACH THE MIDDLE OF THE TEST BANK. THEN THE 'JMP (R0)'' INSTRUCTION IS
2387 * AND EXECUTED. R0 CONTAINED THE RETURN ADDRESS BACK
2388 * TO TEST 13.
2389 * 4. THESE STEPS ARE REPEATED FOR EACH BANK UNDER TEST.
2390 .....
2391 .....
2392 004334 122737 000013 000404 TST13: CMPB #13,@#STESTN ;CHECK FOR PROPER TEST SEQUENCE
2393 004342 001403 BEQ .+10
2394 004344 004767 001604 JSR PC,SEQERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
2395 004350 000044 44 ;*****ERROR NUMBER 44*****
2396 .....
2397 004352 012702 010247 1$: MOV #10247,R2 ;PLACE THE OP CODE OF INSTRUCTION MOV R2,-(PC)
2398 ;IN R2.
2399 004356 012700 177667 MOV #177667,R0 ;PLACE THE COMPLEMENT OF THE INSTRUCTION
2400 ;JMP (R0) IN R0
2401 ;INSURE LOWEST TEST ADDRESS TO END OF 4K SEGMENT IS MULTIPLE OF 2
2402 ;SINCE THE TEST STORES 'MOV R2,-(PC) IN 1/2 AND 177667 IN THE OTHER 1/2
2403 .....
2404 004362 010546 2$: MOV R5,-(SP) ;SAVE R5
2405 004364 010446 MOV R4,-(SP) ;STORE LOWEST ADDRESS ON STACK
2406 004366 000241 29$: CLC
2407 004370 006005 ROR R5 ;MAKE POSITIVE BYTE COUNT OF HIGH ADDRESS
2408 004372 006004 ROR R4 ;DO SAME FOR LOWEST ADDRESS
2409 004374 160405 SUB R4,R5 ;GET DIFFERENCE OF LOWEST ADDRESS AND HIGHEST
2410 004376 006005 ROR R5 ;IF DIFFERENCE IS ODD THEN R4 IS AT LOWEST ADDRESS
2411 004400 103002 BCC 30$ ;BRANCH IF R4 IS AT LOWEST TEST ADDRESS.
2412 004402 062716 000002 ADD #2,(SP) ;INCREASE LOWEST TEST ADDRESS BY 2
2413 004406 012604 30$: MOV (SP)+,R4 ;RESTORE R4 (POSSIBLY INCREASED BY 2 FROM ENTRY)
2414 004410 012605 MOV (SP)+,R5 ;RESTORE HIGHEST TEST ADDRESS
2415 004412 010403 MOV R4,R3 ;PLACE THE LOWEST LOCATION UNDER TEST
2416 ;IN R3
2417 004414 000406 BR 28$ ;LEAVE LOW BITS OF R3 ALONE FIRST TIME IN CASE BANK 0
    
```

```

2418 004416 042703 017776      3$:  BIC      #17776,R3      ;CAUSE R3 TO POINT TO THE LOWEST LOCATION
2419                                ;IN THE 4K BANK UNDER TEST
2420 004422 001507              BEQ      14$              ;IF ADDRESS WENT TO 0, IT MUST BE A 30K SYSTEM
2421 004424 105737 000405      TSTB    @#REL            ;ARE WE RELOCATED?
2422 004430 100504              BMI      14$              ;BRANCH IF YES-TEST BANK0 ONLY-
2423 004432 020305      28$:  CMP      R3,R5              ;IF R3 IS HIGHER THAN THE HIGHEST LOCATION
2424 004434 103102              BHIS    14$              ;UNDER TEST THEN EXIT
2425                                ;IF R5 LESS THAN 20000 THEN WE ARE TESTING BANK0 RELOCATED IN BANK0
2426 004436 020527 020000      CMP      R5,#20000        ;IS HIGHEST TEST ADDRESS BELOW 4K?
2427 004442 103002              BHIS    31$              ;BRANCH IF NO
2428 004444 010501              MOV     R5,R1              ;SET R1 TO HIGHEST TEST ADDRESS IN BANK0
2429 004446 000407              BR      32$
2430
2431 004450 010301      31$:  MOV     R3,R1              ;SET R1 TO LOWEST CURRENT TEST ADDRESS
2432 004452 052701 017777      BIS     #17777,R1          ;SET LOW ORDER ADDRESS BITS
2433 004456 005201              INC     R1                  ;CAUSE R1 TO POINT TO THE HIGHEST LOCATION+2
2434                                ;OF THE 4K BANK BEING POINTED BY R3
2435 004460 001402              BEQ     32$              ;BRANCH IF R1 WENT TO 0 (WHICH MIGHT
2436                                ;HAVE HAPPENED IF TESTING A 30K LSI SYSTEM)
2437 004462 020105              CMP     R1,R5              ;COMPARE R1 TO HIGHEST ADDRESS UNDER TEST
2438 004464 101401              BLOS   33$              ;BRANCH IF WITHIN RANGE
2439 004466 010501      32$:  MOV     R5,R1              ;SET R1 TO THE MAXIMUM AVAILABLE MEMORY
2440
2441 004470 132737 000001 000306 33$:  BITB    #1,@#PASFLG        ;IS THE LOWEST BIT OF LOCATION PASFLG
2442 004476 001101              BNE    16$              ;SET? IN WHICH CASE BACK GROUND HAS
2443                                ;ALREADY BEEN WRITTEN AND WRITE RECOVERY
2444                                ;TEST IS BEING PERFORMED
2445
2446 004500 020304      4$:  CMP     R3,R4              ;OTHERWISE WRITE THE BACKGROUND
2447 004502 103430              BLO    8$                ;DEFINED AT STEP 3.
2448 004504 105737 000307      TSTB    @#PASFLG+1        ;IS THE TEST JUST DOING READ, I.E.
2449 004510 001002              BNE    6$                ;IS THE PASFLG+1 LOCATION NON ZERO? IF SO
2450                                ;THEN GO TO 6$
2451 004512 012713 010247      MOV     #10247,(R3)        ;WRITE THE LOCATION WITH THE OP CODE FOR MOV R2,-(PC)
2452 004516 020213      6$:  CMP     R2,(R3)          ;READ (R3) TO CONTAIN CORRECT DATA
2453 004520 001421              BEQ     8$
2454 004522 010046              MOV     R0,-(SP)          ;SAVE R0
2455 004524 010146              MOV     R1,-(SP)          ;AND R1 ON THE STACK
2456 004526 010301              MOV     R3,R1
2457 004530 010200              MOV     R2,R0              ;SET R0= GOOD DATA FOR ERROR PRINTOUT
2458 004532 004767 001060      JSR     PC,ERROR          ;*ERROR* REPORT ERROR MESSAGE
2459 004536 000045              45                          ;*****ERROR NUMBER 45*****
2460
2461 004540 012601              MOV     (SP)+,R1          ;RESTORE R1
2462 004542 012600              MOV     (SP)+,R0          ;AND R0
2463 004544 105737 000306      TSTB    @#PASFLG          ;IF PASFLG IS 0 AND THE MEMORY DOES NOT HAVE
2464                                ;THE PROPER DATA THEN WE DON'T WANT TO GO AND
2465                                ;EXECUTE THE INSTRUCTIONS STORED IN MEMORY UNDER
2466                                ;TEST
2467 004550 001005              BNE    8$                ;BRANCH IF PASFLG NOT =0
2468
2469 004552 010200              MOV     R2,R0              ;SAVE FOR ERROR REPORT
2470 004554 004767 001036      JSR     PC,ERROR          ;*ERROR* REPORT ERROR MESSAGE
2471 004560 000046              46                          ;*****ERROR NUMBER 46*****
2472
2473 004562 000663              BR      END12              ;ABORT TST 13.
  
```

```

2474
2475 004564 062703 000002      8$:  ADD    #2,R3      ;INCREMENT R3 BY 2
2476 004570 162701 000002      SUB    #2,R1      ;DECREMENT R1 BY 2
2477 004574 020105                CMP    R1,R5      ;WRITE THE BACKGROUND DEFINED AT STEP 4.
2478 004576 103014                BHIS   12$
2479 004600 020103                CMP    R1,R3      ;HAS STORING THE 177667 REACHED WHERE 'MOV R2,-(PC) IS?
2480 004602 103405                BLO   10$         ;BRANCH IF YES DON'T DESTROY THE MOV R2,-(PC) IS.
2481 004604 105737 000307      TSTB  @#PASFLG+1 ;IS THE THE READ ONLY CHECK PASS?
2482 004610 001002                BNE   10$         ;BRANCH IF YES
2483 004612 012711 177667      MOV    #177667,(R1);WRITE THE LOCATION WITH THE COMPLEMENT OF THE
2484                                     ;OP CODE JMP (R0)
2485 004616 020011      10$:  CMP    R0,(R1)    ;READ R1 TO CONTAIN CORRECT DATA
2486 004620 001403                BEQ   12$
2487 004622 004767 000770      JSR   PC,ERROR    ;*ERROR* REPORT ERROR MESSAGE
2488 004626 000047                47          ;*****ERROR NUMBER 47*****
2489
2490 004630 020301      12$:  CMP    R3,R1    ;IF WE HAVE NOT REACHED THE MIDDLE OF 4K BANK
2491 004632 103722                BLO   4$         ;THEN REPEAT FROM 4$
2492
2493                                     ;RETURN HERE AFTER PROGRAM RUN IN BANK UNDER TEST
2494
2495 004634 062703 020000      13$:  ADD    #20000,R3 ;OTHERWISE GO TO THE NEXT 4K BANK
2496 004640 000666                BR    3$
2497
2498 004642 122737 000001 000306 14$:  CMPB  #1,@#PASFLG ;THE PROGRAM CONTROL COMES HERE AS FOLLOWS
2499                                     ;1-PASFLG=0, PROGRAM HAS JUST COMPLETED A
2500                                     ;WRITE/READ CYCLE FOR THE BACK GROUND
2501                                     ;AND WANTS TO BEGIN THE WRITE RECOVERY TEST
2502 004650 001440                BEQ   24$         ;2-PASFLG=1, PROGRAM HAS JUST COMPLETED
2503                                     ;THE WRITE RECOVERY TEST AND WANTS TO
2504                                     ;READ MEMORY FOR CORRECT DATA
2505 004652 103627                BLO   END12      ;3-PASFLG=2, PROGRAM HAS CORRECTLY READ THE
2506                                     ;MEMORY AND WANTS TO GO THE NEXT TEST.
2507
2508 004654 105137 000307      COMB  @#PASFLG+1 ;ENTER HERE WITH PASFLG=0, ON THE FIRST ENTRY
2509                                     ;ENABLE READ ONLY FOR THE MEMORY AND ON THE SECOND
2510                                     ;ENTRY DISABLE READ ONLY
2511
2512 004660 001240                BNE   2$
2513 004662 012702 005141      MOV    #5141,R2   ;PLACE THE OP CODE FOR INSTRUCTION COM -(R1)
2514 004666 012700 177740      MOV    #13$,-6,R0;IN R2
2515 004672 060700                ADD    PC,R0      ;PLACE THE RETURN ADDRESS IN R0 AS 13$
2516                                     ;THUS WHEN THE READ RECOVERY TEST REACHES
2517                                     ;THE MIDDLE OF THE 4K MEMORY THEN THE
2518                                     ;INSTRUCTION EXECUTED WILL BE JMP (R0)
2519 004674 105237 000306      15$:  INCB  @#PASFLG   ;BRANCHING THE PROGRAM TO 13$
2520 004700 000630                BR    2$         ;INCREMENT PASFLG BY 1.
2521
2522 004702 032777 000020 173540 16$:  BIT    #20,@SWR   ;HAS THE PRINTOUTS BEEN SUPRESSED ?
2523 004710 001017                BNE   18$         ;IF SO THEN GO TO 18$
2524 004712 105737 000042      TSTB  @#42        ;IS THE PROGRAM RUNNING UNDER ACT?
2525 004716 001014                BNE   18$         ;BRANCH IF YES
2526 004720 004767 001656      JSR   PC,PNTMES   ;TYPE THE BANK UNDER TEST
2527 004724 051524 030524 020063 .ASCIZ /TST13 BANK/
2528 004732 040502 045516      000
2529 004740                .EVEN
  
```

```
2530 004740 004767 002466 JSR PC,GETBNK ;GET BANK NO. UNDER TEST INTO DECWRD FOR PRINT.  
2531 004744 004767 001660 JSR PC,$TPDEC ;TYPE BANK NO. UNDER TEST  
2532  
2533 004750 000113 18$: JMP (R3) ;BEGIN EXECUTING MOV R2,-(PC) ,COM -(R1) SEQUENCE IN TES  
2534  
2535  
2536 004752 105137 000307 24$: COMB @#PASFLG+1  
2537 004756 012700 000110 MOV #110,R0 ;PLACE THE OP CODE FOR JMP (R0) IN R0  
2538 004762 000744 BR 15$ ; READ THE MEMORY FOR CORRECT DATA AFTER  
2539 ;INCREMMENTING PASFLG TO 2  
2540  
2541 ;TST13 EXITS VIA END12.  
2542
```

```

2543 004764 012737 000377 000316 RELOC: MOV #377,@#BAKPAT
2544 004772 105737 000276 TSTB @#MMVA; ;IS THE MEMORY MANAGEMENT BEING TESTED ?
2545 004776 001065 BNE CONTMM ;IF SO THEN GO TO CONTMM AND CONTINUE TESTING
2546 ;MEMORY MANAGEMENT
2547 005000 032777 001000 173442 BIT #1000,@SWR ;RELOCATION WANTED?
2548 005006 001046 BNE CKDONE ;BRANCH IF NO
2549 005010 105737 000405 TSTB @#REL ;IF THE PROGRAM HAS ALREADY BEEN RELOCATED THEN ALSO
2550 005014 100420 BMI RELOER ; PLACE THE PROGRAM BACK IN LOWER CORE
2551 005016 112737 000200 000405 MOVB #200,@#REL ;OTHERWISE PREPARE TO RELOCATE
2552
2553 ;RELOCATE THE DIAGNOSTIC TO HIGHEST AVAILABLE MEMORY
2554
2555
2556 005024 004767 001552 JSR PC,PNTMES ;TYPE 'RELOC'
2557 005030 042522 047514 000103 .ASCIZ /RELOC/
2558 .EVEN
2559 005036 013705 000340 MOV @#MAXMEM,R5 ;PREPARE TO LOAD THE PROGRAM IN THE HIGHEST
2560 ;AVAILABLE MEMORY
2561 005042 014445 2$: MOV -(R4),-(R5) ;RELOCATE THE PROGRAM
2562 005044 020427 000430 CMP R4,#BEGIN-50 ;NEITHER RELOCATE NOR TEST LOCATIONS LOWER THAN BEGIN-50
2563 005050 101374 BHI 2$
2564 005052 000165 000050 JMP 50(R5)
2565
2566 ;*RELOCATE THE DIAGNOSTIC BACK TO LOWER MEMORY
2567
2568
2569 005056 013705 000346 RELOER: MOV @#SAVR5,R5 ;RESTORE R5
2570 005062 105737 000405 TSTB @#REL ;IS DIAGNOSTIC IN RELOCATED STATE?
2571 005066 100016 BPL CKDONE ;BRANCH IF NO
2572
2573 005070 012704 000430 2$: MOV #BEGIN-50,R4 ;PREPARE TO RELOCATE THE PROGRAM TO LOWER CORE
2574 005074 012524 MOV (R5)+,(R4)+
2575 005076 020537 000340 CMP R5,@#MAXMEM
2576 005102 103774 BLO 2$
2577 005104 105037 000405 CLRB @#REL
2578 005110 010537 000346 MOV R5,@#SAVR5 ;SAVE R5
2579 005114 012706 000500 MOV #BEGIN,SP ;RESET STACK TO LOWER MEMORY
2580 005120 010637 000350 MOV SP,@#SAVR6 ;'BEGIN' USES THIS TO RESET THE STACK.
2581 005124 000137 005130 CKDONE: JMP @#LOWER ;TRANSFER THE PROGRAM CONTROL TO THE LOWER CORE
2582
2583
2584
2585 005130 105737 000315 LOWER: TSTB @#SAVKBB ;HERE DUE TO ^C TYPED?
2586 005134 001073 BNE $TPSTK ;BRANCH IF YES (TYPE ERROR STACK)
2587 005136 004767 001712 TSTMM: JSR PC,MEMMNG ; SET THE REGISTERS IF THE MEMORY MANAGEMENT
2588 ;IS AVAILABLE
2589 005142 105737 000276 TSTB @#MMVA ;IS MEM. MANAG. AVAILABLE ?
2590 005146 001462 BEQ ENDPAS ;BRANCH IF NO
2591 005150 000402 BR $CNTMM ;BEGIN TESTING ABOVE 28K
2592 005152 004767 002050 CONTMM: JSR PC,UPMM ;GO TO UPDATE MEM. MANAG. REGISTERS
2593 005156 012703 000324 $CNTMM: MOV #LOWTWO,R3 ;MAKE R3 POINT TO THE LOCATION LOWTWO
2594 005162 004767 002154 JSR PC,GETSIZ ; LOAD BITS 6-10 OF R2 WITH THE BITS 13-17
2595 ;OF THE LOWEST ADDRESS UNDER TEST
2596 005166 012704 020000 MOV #20000,R4 ;MAKE R4 POINT TO THE LOWEST LOCATION IN THE BANK
2597 ;POINTED BY PAGE ADDRESS REGISTER 1 (PAR1)
2598 005172 020237 172342 CMP R2,@#172342 ;IS THE CONTENT OF R2 LOWER THAN THE CONTENT OF

```



```

2642                                     ;* TYPE ROUTINE FOR ERROR STACK
2643                                     ;* -----
2644                                     ;*
2645                                     ;*
2646                                     ;* THIS ROUTINE IS USED TO DETERMINE IF TYPE OUT OF THE ERROR STACK
2647                                     ;* FOR ONLY THE FAILING BITS IS REQUIRED OR NOT
2648
2649
2650 005314 032777 000020 173126 ENDPAS: BIT #20,@SWR ;ARE WE GOING TO TYPE THE ERROR STACK AND END OF PASS?
2651 005322 001055 BNE $EOP ;IF NOT THEN GO TO $EOP
2652 005324 012746 177777 $TPSTK: MOV #-1,-(SP) ;THE PROGRAM HAS REACHED THE END AND ERROR
2653 ;STACK AND END OF PASS WILL BE TYPED OUT
2654 005330 012701 007744 MOV #ENDPRG,R1 ;PLACE THE STARTING ADDRESS OF THE ERROR STACK
2655 ;FOR 0 TO 4K MEMORY IN R1
2656 005334 012703 000376 TYPSTK: MOV #376,R3
2657 005340 005216 INC (SP) ;IF WE HAVE GONE THRU THE ENTIRE
2658 005342 020137 000310 CMP R1,@#ENDSTK ;HAS THE END OF THE ERROR STACK BEEN REACHED ?
2659 005346 103043 BHIS $EOP ;THEN GO TO TYPE END OF PASS
2660 005350 112702 000022 RETSTK: MOVB #18.,R2
2661 005354 105302 RETSTK: DECB R2 ;IF ALL 16 BITS OF THIS BANK HAVE BEEN CHECKED.
2662 005356 002766 BLT TYPSTK ;BEEN CHECKED FOR ERROR THEN SEE IF THERE
2663 ;IS ANY MORE 4K MEMORY BANK
2664 005360 105721 TSTB (R1)+ ;OTHERWISE CHECK THE BYTE STORED AT (R1)
2665 005362 001774 BEQ RETSTK ;IF IT IS 0 WE WILL NOT TYPE IT
2666 005364 020227 000020 CMP R2,#16. ;IS THE POINTER POINTING TO ERROR STACK BYTE
2667 ;MEANT FOR COLLECTING ADDRESS FAILURES FOR
2668 ;THE SPECIFIC MEMORY BANK
2669 005370 103404 BLO 2$ ;IF NOT THEN GO TO TYPE BIT NUMBER
2670 005372 101026 BHI PARFL ;IF IT IS POINTING TO THE STACK LOCATION INTENDED
2671 ;TO COLLECT PARITY FAILURES THEN GO TO PARFL
2672 005374 004767 001010 JSR PC,TPADER ;OTHERWISE TYPE 'ADDRESS ERROR'
2673 005400 000404 BR FAILNM
2674 005402 010237 000312 2$: MOV R2,@#DECWRD ;PREPARE TO TYPE THE NUMBER OF THE FAILING BIT
2675 ;IN DECIMAL
2676 005406 004767 001212 JSR PC,TYPDEC ;GO TO TYPE THE BIT NUMBER IN DECIMAL
2677 005412 011637 000312 FAILNM: MOV (SP),@#DECWRD ;PREPARE TO TYPE THE PAGE NUMBER
2678 005416 004767 001206 JSR PC,$TPDEC ;IN DECIMAL
2679 005422 005043 CLR -(R3)
2680 005424 114113 MOVB -(R1),(R3) ;PREPARE TO PRINTOUT THE NUMBER OF TIMES THIS
2681 ;FAILURE OCCURED
2682 005426 105021 CLR (R1)+ ;CLEAR THE ERROR STACK
2683 005430 005043 CLR -(R3)
2684 005432 105237 000314 INCB @#TYPCNT ;ENABLE THE TYPE OUT OF 1 WORDS
2685 005436 004767 001326 JSR PC,RPTOCT ;TYPE THE 4K BANK AND THE NUMBER OF TIMES
2686 ;THIS FAILURE WAS SEEN
2687 005442 012703 000376 MOV #376,R3 ;RESET SCRATCH STACK FOR EACH BIT PRINTED.
2688 005446 000742 BR RETSTK
2689 005450 004767 000760 PARFL: JSR PC,TPPRER ;TYPE 'PAR ERR'
2690 005454 000756 BR FAILNM
  
```

```

2691
2692
2693          ;* END OF PASS
2694          ;* -----
2695          ;*
2696          ;* TYPE 'END PASS' AND DISABLE PARITY.
2697          ;* ALSO SERVICE ACT11.
2698          ;* AND EVERY CONSECUTIVE PASSES UNLESS BIT 4 OF $SWREG IS HIGH
2699          ;*
2700
2701
2702 005456 005002          $EOP: CLR R2          ;SET R2= PARITY MODULE DISABLE CODE
2703 005460 004767 002026 JSR PC,PARITY      ;GO DISABLE PARITY MODULES IF SELECTED.
2704 005464 105737 000315 TSTB @#SAVKBB      ;CONTROL-C TYPED?
2705 005470 001046          BNE CTLC          ;BRANCH IF YES-RESTORE LOADERS AND HALT-
2706 005472 005237 000406 INC @#$PASS        ;INCREMENT PASS COUNT
2707 005476 032777 000040 172744 BIT #4,@$SWR      ;'END PASS #XX' PRINTOUT WANTED?
2708 005504 001015          BNE ACT11          ;BRANCH IF NO
2709 005506 004767 001062 TYPEOP: JSR PC,TPCRLF ; TYPE CR, LF, AND 'END PASS #'
2710 005512 047105 020104 040520 .ASCIZ /END PASS #/
2711 005520 051523 021440 000 .EVEN
2712 005526 005526          MOV @#$PASS,@#DECWRD ;GET PASS COUNT
2713 005526 013737 000406 000312 JSR PC,$TPDEC      ;TYPE IT
2714 005534 004767 001070 ACT11: MOV @#42,R0 ;GET THE MONITOR ADDRESS
2715 005540 013700 000042 BEQ $DOAGN         ;IF NONE
2716 005544 001405          JSR PC,RLODER        ;RESTORE XXDP MONITOR
2717 005546 004767 000012 RESET              ;RETURN TO ACT11 MONITOR.
2718 005552 000005
2719
2720
2721          ;* SERVICE XXDP/ACT11
2722 005554 000137 000156 JMP @#$ENDAD       ;JUMP TO ACT SERVICE
2723
2724 005560 000137 000250 $DOAGN: JMP @#RESTRT ;REPEAT TEST IF NOT UNDER ACT11/XXDP
2725
2726 005564 004767 001622 RLODER: JSR PC,CLRMM ;STOP MEMORY MANAGEMENT SO CAN RESTORE LOADERS
2727 005570 013704 000344 MOV @#SAVR4,R4     ;RESTORE R4 WITH SAVR4
2728 005574 014445 4$: MOV -(R4),-(R5) ;RESTORE LOADERS
2729 005576 020437 000310 CMP R4,@#ENDSTK
2730 005602 101374 BHI 4$
2731 005604 000207 RTS PC              ;RETURN FROM RLODER CALL
2732
2733          ;CONTROL C HANDLER
2734
2735 005606 004767 177752 CTLC: JSR PC,RLODER ;RESTORE ABS LOADER
2736 005612 000167 000402 JMP APTHLT         ;IF NOT APT HALT AT FATHLT
2737
2738

```

```

2739          ;* ERROR HANDLING ROUTINE
2740          ;* -----
2741          ;*
2742          ;* PROGRAM COMES HERE EACH TIME AN ERROR IS ENCOUNTERED THIS
2743          ;* ROUTINE TYPES OUT THE ERROR MESSAGE IN THE FORMAT GIVEN EARLIER
2744          ;*
2745
2746 005616 017637 000000 000402 ERROR: MOV @ (SP), @#$FATAL ;LOAD THE LOCATION $FATAL WITH THE ERROR NUMBER
2747 005624 010346 1$: MOV R3, -(SP) ;SAVE R3
2748 005626 010046 MOV R0, -(SP) ;AND R0 ON THE STACK
2749
2750          ;SETUP BANK NO. IN FATAL FOR APT
2751
2752 005630 010103 MOV R1, R3 ;GET VIRTUAL ADDRESS UNDER TEST FOR GETBNK
2753 005632 004767 001574 JSR PC, GETBNK ;GET BANK NO. UNDER TEST INTO PBNK
2754 005636 013703 000312 MOV @#PBNK, R3 ;GET BANK UNDER TEST
2755 005642 110337 000403 MOV R3, @#$FATAL+1 ;STORE FAILING BANK NO. FOR APT
2756
2757          ;
2758
2759 005646 010346 MOV R3, -(SP) ;TEMPORARILY STORE R3
2760 005650 012703 000376 MOV #376, R3 ;MAKE R3 AS THE STACK POINTER
2761 005654 013743 000306 MOV @#PASFLG, -(R3) ;OUTPUT THE WORD STORED AT
2762 005660 005043 2$: CLR -(R3)
2763 005662 113713 000402 MOV @#$FATAL, (R3) ;PUT ERROR NO. ON ERROR STACK
2764 005666 016643 000006 MOV 6(SP), -(R3) ;PLACE THE RETURN PC AT (R3)
2765 005672 011143 MOV (R1), -(R3) ;PLACE BAD DATA,
2766 005674 010043 MOV R0, -(R3) ;AND GOOD DATA ON THE STACK
2767 005676 005043 CLR -(R3)
2768 005700 016313 000004 MOV 4(R3), (R3) ;TAKE THE
2769 005704 040013 BIC R0, (R3) ;EXCLUSIVE OR OF GOOD AND BAD DATA
2770 005706 046300 000004 BIC 4(R3), R0 ;TO FIND THE BITS THAT FAILED
2771 005712 050013 BIS R0, (R3) ;AND PLACE IT ON THE STACK
2772 005714 012700 002000 MOV #ENDPRG-.-24., R0 ;THIS CODE BRINGS THE RELATIVE ADDRESS
2773 005720 060700 ADD PC, R0 ;OF THE STARTING OF THE ERROR STACK
2774 005722 062700 000022 6$: ADD #18., R0 ;FOR THE SPECIFIC 4K BANK
2775 005726 005316 DEC (SP)
2776 005730 002374 BGE 6$
2777 005732 005726 TST (SP)+ ;RESTORE THE STACK POINTER
2778
2779 005734 105037 000277 ERR TYP: CLR @#TYPENB ;DISABLE ANY TYPE OUT
2780 005740 105737 000300 1$: TST @#$SPRERR ;IF THIS IS PARITY PROBLEM
2781 005744 001007 BNE 3$ ;THEN GO TO 3$
2782 005746 105720 TST (R0)+ ;OTHERWISE INCREMENT THE ERROR STACK POINTER BY 1
2783 005750 105737 000301 TST @#$ADERR ;IF THIS IS ADDRESSING PROBLEM
2784 005754 001003 BNE 3$ ;THEN GO TO 3$
2785 005756 105720 TST (R0)+ ;INCREMENT THE POINTER R0 BY 1
2786 005760 005713 2$: TST (R3) ;IS BIT 15 OF (R3) SET?
2787 005762 100015 BPL 4$ ;IF NOT THEN GO TO 4$
2788 005764 122710 000377 3$: CMPB #377, (R0) ;OTHERWISE SEE IF THIS ERROR HAS OCCURED 377 TIMES
2789 005770 001401 BEQ 5$ ;IF SO DON'T BUMP ERROR COUNT
2790 005772 105210 INCB (R0) ;INCREMENT THE ERROR COUNTER BY 1
2791 005774 122710 000001 5$: CMPB #1, (R0) ;MORE THAN 1 ERROR OCCURRED ON THIS BIT?
2792 006000 001404 BEQ 7$ ;BRANCH IF NO
2793 006002 032777 000400 172440 BIT #400, @SWR ;STOP ERROR PRINTOUT AFTER 1 WANTED?
2794 006010 001002 BNE 4$ ;BRANCH IF YES (DON'T TYPE ERROR)

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 59
 CZKMAE.MAC 18-SEP-78 11:54 ERROR HANDLING ROUTINE

SEQ 0059

```

2795 006012 105237 000277      7$: INCB @#TYPENB ;ENABLE THE TYPE OUT ROUTINE
2796 006016 105737 000300      4$: TSTB @#$PRERR ;PARITY ERROR?
2797 006022 001403              BEQ 9$ ;BRANCH IF NO
2798 006024 004767 000404      JSR PC,TPPRER ;ELSE TYPE 'PAR ERR'
2799 006030 000411              BR 8$ ;AND DON'T TEST INDIVIDUAL BIT FAILURES.
2800 006032 105737 000301      9$: TSTB @#$ADERR ;ADDRESS ERROR?
2801 006036 001403              BEQ 6$ ;BRANCH IF NO
2802 006040 004767 000344      JSR PC,TPADERR ;PRINT 'ADR ERR'
2803 006044 000403              BR 8$
2804 006046 105720              6$: TSTB (R0)+ ;POINT TO NEXT ENTRY IN ERROR STACK
2805 006050 006313              ASL (R3) ;IS THERE STILL AN ERROR BIT SET IN ERROR.
2806 006052 001342              BNE 2$ ;BR IF YES - KEEP FILLING ERROR STACK
2807 006054 112737 000006 000314 8$: MOVB #6,@#TYPCNT ;TELL TYPOCT TO TYPE 6 WORDS OF ERROR STACK.
2808                                     ;THE STACK POINTED BY R3
2809 006062 004767 001146      JSR PC,PUTADR ;GO TO THE SUBROUTINE TO PLACE THE ADDRESS IN R1
2810                                     ;AT LOCATIONS (R3) AND (R3-2)
2811 006066 004767 000620      JSR PC,TYPERR ;TYPE ERROR STACK (7 WORDS)
2812
2813 006072 005037 000300      10$: CLR @#$PRERR ;CLEAR ADDRESS/PARITY ERROR FLAGS
2814 006076 012600              MOV (SP)+,R0 ;RESTORE R0
2815 006100 012603              MOV (SP)+,R3 ;AND R3
2816 006102 105737 000420      FNDERR: TSTB @#$ENV ;ARE WE RUNNING UNDER APT?
2817 006106 001404              BEQ 2$ ;IF NOT THEN TEST FOR HALT
2818 006110 012737 000001 000400 MOV #1,@#$MSGTY ;OTHERWISE INFORM THE APT
2819 006116 000443              BR FATHLT ;GOTO FATHLT AND WAIT FOR APT.
2820
2821 006120 010246              2$: MOV R2,-(SP) ;SAVE R2 TEMP
2822 006122 005777 172322      TST @SWR ;DOES THE OPERATOR REQUIRE THE PROGRAM TO HALT
2823                                     ;ON ERROR
2824 006126 100405              BMI 4$ ;IF SO THEN HALT ON ERROR
2825 ;CHECK FOR CONTROL-C KEY
2826
2827 006130 004767 001536      JSR PC,CHECKC ;IF CONTROL-C TYPED THEN PRINT ERROR HISTORY
2828                                     ;AND HALT AT FATHLT.
2829 006134 105737 000042      7$: TSTB @#42 ;ARE WE RUNNING UNDER ACT?
2830 006140 001401              BEQ 6$ ;BRANCH IF NO
2831
2832 006142 000000              4$: HALT ;PROGRAM HAS HALTED ON ERROR, R1 IS POINTING
2833                                     ;TO A LOCATION WHICH SHOULD HAVE CONTAINED
2834                                     ;THE WORD STORED IN R0
2835 006144 012602              6$: MOV (SP)+,R2 ;RESTORE R2
2836 006146 062716 000002      ADD #2,(SP) ;RESTORE THE RETURN ADDRESS
2837 006152 000207              RTS PC ;RETURN FROM THE SUBROUTINE
2838
2839
2840
2841 006154              FATERR:
2842 006154 004767 000414 020122 SEQERR: JSR PC,TPCRLF ;TYPE 'ERROR #'
2843 006160 051105 047522      .ASCIZ /ERROR #/
2844 006166 000043              .EVEN
2845
2846
2847 006170 017637 000000 000402 MOV @ (SP),@#$FATAL ;LOAD THE LOCATION $FATAL WITH THE ERROR NUMBER
2848 006176 105237 000314      INCB @#TYPCNT ;TELL $TPNUM TO TYPE 1 WORD
2849 006202 012703 000376      MOV #376,R3 ;$TPNUM USES R3 AS STACK
2850 006206 013743 000402      MOV @#$FATAL,-(R3) ;PUT ERROR NO. ON STACK

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 60
 CZKMAE.MAC 18-SEP-78 11:54 ERROR HANDLING ROUTINE

SEQ 0060

```

2851 006212 005743          TST      -(R3)          ;$TPNUM REQUIRES THIS
2852 006214 004767 000560   JSR      PC,FAT:P      ;TYPE ERROR NO.
2853 006220 105737 000420   APTHLT: TSTB @#$ENV ;RUNNING UNDER APT?
2854 006224 001326          BNE      FNDERR        ;BRANCH IF YES
2855 006226 000000          FATHLT: HALT          ;FATAL ERROR OR ^C HALT.
2856 006230 000137 000250   JMP      @#RESTRT      ;RESTART TST BUT DON'T CLEAR PASS COUNT
2857                                     ;IN CASE ^C RESTART.
2858
2859
2860                                     ;PARERR
2861                                     ; PARITY TRAP HANDLER
2862                                     ; COME HERE FROM A TRAP TO 114.
2863                                     ; THIS ROUTINE SEARCHES THE AVAILABLE PARITY MODULES AND IF ONE
2864                                     ; HAS A PARITY ERROR BIT SET THE GET THE PARITY ERROR ADDRESS
2865                                     ; AND CALL THE 'ERROR' ROUTINE TO PRINT ERROR MESSAGE.
2866                                     ; IF NO PARITY ERROR BITS CAN BE FOUND A FATAL ERROR IS DONE.
2867
2868                                     ; REGISTER US AGE.
2869                                     ; R0= HOLDS PARITY MODULE ADDRESSES
2870                                     ; R1= GETS ERROR ADDRESS FOR 'ERROR' CALL.
2871
2872 006234 012637 000356   PARERR: MOV      (SP)+,@#PARSP ;SET PARSP TO RETURN ADDRESS
2873 006240 011637 000360   MOV      (SP),@#PARPS ;SAVE PSW FOR RETURN
2874 006244 013706 000350   MOV      @#SAVR6,SP ;AND RESET THE SP SINCE NOT ENOUGH STACK ROOM
2875                                     ; TO COMPLETE THE ERROR SERVICE ROUTINE.
2876 006250 010067 000130   MOV      R0,SAVR0 ;SAVE R0 DURING PARITY SERVICE
2877 006254 010167 000126   MOV      R1,SAVR1 ;SAVE R1 DURING PARITY SERVICE
2878 006260 013701 000352   MOV      @#PARMAP,R1 ;GET PARITY AVAILABLE MAP
2879 006264 012700 172100   MOV      #172100,R0 ;R0= FIRST PARITY ADDRESS.
2880
2881                                     TST      R1          ;ANY PARITY MODULES AVAILABLE?
2882 006272 001441          BEQ      4$          ;BR IF NO -FATAL ERROR-
2883 006274 006001          1$: ROR      R1          ;SHIFT PARITY MAP BIT INTO C BIT.
2884 006276 103005          BCC      2$          ;BRANCH IF THIS PARITY MODULE NOT AVAILABLE.
2885 006300 005710          TST      (R0)        ;PARITY MODULE ERROR BIT SET?
2886 006302 100406          BMI      3$          ;BRANCH IF YES -CALL 'ERROR' ROUTINE
2887 006304 020027 172136   CMP      R0,#172136 ;DONE ALL PARITY MODULES?
2888 006310 002032          BGE      4$          ;BR IF YES- GO TO FATAL ERROR CALL-
2889 006312 062700 000002   2$: ADD      #2,R0 ;POINT TO NEXT PARITY ADDRESS
2890 006316 000766          BR       1$          ;AND KEEP TRYING
2891 006320 042710 100000   3$: BIC      #100000,(R0) ;CLEAR PARITY ERROR BIT.
2892 006324 011001          MOV      (R0),R1 ;GET PARITY MODULE CSR
2893 006326 006101          ROL      R1          ;SHIFT ERROR ADDRESS BITS 11-5 INTO 15-9
2894 006330 006101          ROL      R1
2895 006332 006101          ROL      R1
2896 006334 006101          ROL      R1
2897 006336 042701 000777   BIC      #777,R1 ;SAVE ERROR ADDRESS ONLY
2898 006342 105237 000300   INCB    @#$PRERR ;TELL 'ERROR' PARITY ERROR CALL.
2899 006346 004767 177244   JSR      PC,ERROR ;*ERROR* REPORT ERROR MESSAGE
2900 006352 000050          50          ;*****ERROR NUMBER 50*****
2901
2902 006354 016700 000024   MOV      SAVR0,R0 ;RESTORE R0
2903 006360 016701 000022   MOV      SAVR1,R1 ;RESTORE R1
2904 006364 013746 000360   MOV      @#PARPS,-(SP) ;SET RETURN PSW ON STACK
2905 006370 013746 000356   MOV      @#PARSP,-(SP) ;AND SET RETURN ADDRESS ON STACK
2906 006374 000002          RTI          ;RETURN TO TEST WHERE PARITY TRAP OCCURRED.

```

```

2907
2908
2909 006376
2910 006376 004767 177552
2911 006402 000051
2912
2913
2914
2915
2916 006404 000000
2917 006406 000000
2918
2919
2920 006410 105737 000277
2921 006414 001406
2922 006416 004767 000160
2923 006422 042101 020122 051105
2924 006430 000122
2925
2926 006432 000207
2927
2928 006434 105737 000277
2929 006440 001406
2930 006442 004767 000134
2931 006446 040520 020122 051105
2932 006454 000122
2933
2934 006456 000207

;COME HERE IF NO PARITY ERROR FLAG FOUND SET
4$:
      JSR      PC,FATERR      ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
      51                ;*****ERROR NUMBER 51*****

;R0+R1 ARE SAVED HERE FOR PARITY TRAP DUE TO INSUFFICIENT
;STACK SPACE BETWEEN 500-450.
SAVR0: 0                ;SAVE R0 DURING PARITY TRAP SERVICE
SAVR1: 0                ;SAVE R1 DURING PARITY TRAP SERVICE

TPADER: TSTB @#TYPENB      ;TYPE ERROR?
        BEQ  1$           ;BRANCH IF NO
        JSR  PC,PNTMES     ; TYPE CR, LF AND 'ADR ER'
        .ASCIZ /ADR ERR/

        .EVEN
1$:     RTS      PC

TPPRER: TSTB @#TYPENB      ;ERROR PRINTOUTS ALLOWED?
        BEQ  1$           ;BRANCH IF NO
        JSR  PC,PNTMES     ;GO TO TYPE CR, LF AND 'PAR ERR'
        .ASCIZ /PAR ERR/

        .EVEN
1$:     RTS      PC

```

```

2935
2936
2937          ;* TYPE OUT ROUTINE
2938          ;* -----
2939          ;*
2940          ;* THIS ROUTINE IS USED BY THE PROGRAM TO TYPE OUT ANY CHARACTER
2941          ;*
2942
2943 006460 010146 NOTYP: MOV R1,-(SP)
2944 006462 016601 000002 MOV 2(SP),R1
2945 006466 105721 4$: TSTB (R1)+ ;IF THIS TYPE OUT HAS BEEN SUPRESSED THEN
2946 006470 001376 BNE 4$ ;PREPARE TO RETURN
2947 006472 000412 BR RETTYP
2948 006474 010146 $TYPE: MOV R1,-(SP) ;SAVE R1
2949 006476 010046 MOV R0,-(SP) ;AND R0 ON THE STACK
2950 006500 016601 000004 MOV 4(SP),R1 ;PLACE THE ADDRESS OF MESSAGE TO BE TYPED IN R1
2951 006504 112100 2$: MOVB (R1)+,R0 ;PLACE THE BYTE TO BE TYPED IN R0
2952 006506 001403 BEQ 4$ ;IF IT IS END OF MESSAGE THEN GO TO 4$
2953 006510 004767 000022 JSR PC,$TPCHR ;OTHERWISE GO TO TYPE THE CONTENTS OF R0
2954 006514 000773 BR 2$
2955 006516 012600 4$: MOV (SP)+,R0 ;RESTORE R0
2956 006520 005201 RETTYP: INC R1 ;CAUSE R1 TO
2957 006522 042701 000001 BIC #1,R1 ;POINT TO EVEN ADDRESS
2958 006526 010166 000002 MOV R1,2(SP) ;MODIFY THE RETURN ADDRESS
2959 006532 012601 MOV (SP)+,R1 ;RESTORE R1
2960 006534 000416 BR EXTYP ;AND RETURN VIA RTS PC
2961
2962 006536 132737 000040 000421 $TPCHR: BITB #40,@#$ENVM ;HAVE TYPE OUTS BEEN DISABLED?
2963 006544 001005 BNE 4$ ;IF SO THEN RETURN FROM THE SUBROUTINE
2964 006546 105737 177564 2$: TSTB @#$STPS ;WAIT HERE
2965 006552 100375 BPL 2$ ;UNTIL THE PRINTER IS READY
2966 006554 110037 177566 MOVB R0,@#$TPB ;LOAD DATA TO BE TYPED INTO DATA REG.
2967 006560 000404 4$: BR EXTYP ;RETURN
2968
2969 006562 004767 177706 PCRLF: JSR PC,$TYPE
2970 006566 005015 000 .ASCIZ <15><12> ;CR/LF
2971 006572 006572 .EVEN
2972 006572 000207 EXTYP: RTS PC ;RETURN
2973
2974 006574 004767 177762 TPCRLF: JSR PC,PCRLF ;TYPE CR/LF
2975 006600 000735 BR $TYPE ;NOW GO TO TYPE THE REST OF THE MESSAGE
2976
2977
2978 006602 032777 000020 171640 PNTMES: BIT #20,@$SWR ;PRINTOUTS ALLOWED?
2979 006610 001323 BNE NOTYP ;BRANCH IF NO
2980 006612 123737 000042 000046 CMPB @#42,@#46 ;RUNNING UNDER ACT 11?
2981 006620 001717 BEQ NOTYP ;BRANCH IF YES -NOT PRINTOUT-
2982 006622 000764 BR TPCRLF ;SEND CR/LF AND TYPE MESSAGE.
    
```



```

3011
3012
3013          :* OCTAL TYPE OUT ROUTINE
3014          :* -----
3015          :*
3016          :* THIS ROUTINE IS USED TO TYPE OUT THE OCTAL VALUES
3017          :* CONTROL SHOULD COME TO THIS ROUTINE WITH R3 POINTING TO
3018          :* THE LOW ORDER BITS (I.E. BITS 0-15) OF THE ADDRESS TO
3019          :* BE TYPED WHERE AS R3-2 SHOULD CONTAIN THE HIGH ORDER BITS
3020          :* (I.E. BITS 16 & 17). CONTENTS OF LOCATION R3-1 AND R0 ARE
3021          :* DESTROYED BY THIS SUBROUTINE
3022          :* BYTE TYPCNT SHOULD BE SET TO THE NUMBER OF WORDS THAT HAVE
3023          :* TO BE TYPED.
3024          :*
3025
3026 006712 032777 020000 171530 TYPERR: BIT #20000,@SWR ;ERROR PRINTOUT WANTED?
3027 006720 001054 BNE OCTXT ;BRANCH IF NO
3028 006722 004767 177634 JSR PC,PCRLF ;TYPE CR/LF
3029 006726 004767 000012 JSR PC,TYPCT ;TYPE OCTAL NO.
3030 006732 000447 BR OCTXT ;RETURN VIA RTS PC
3031 006734 012123 OCTTYP: MOV (R1)+,(R3)+ ;PLACE THE HIGH ORDER BITS AT LOCATION POINTED
3032 ;BY R3
3033 006736 012113 MOV (R1)+,(R3) ;AND NOW PLACE THE LOW ORDER BITS
3034 006740 105237 000314 INCB @#TYPCNT ;ENABLE THE TYPE OUT OF ONE OCTAL WORD
3035 006744 052743 000004 TYPOCT: BIS #4,-(R3)
3036 006750 106113 2$: ROLB (R3)
3037 006752 103376 BCC 2$
3038 006754 005000 CLR R0
3039 006756 106113 ROLB (R3) ;GET BITS 17 & 16 INTO R0
3040 006760 006100 ROL R0
3041 006762 106113 ROLB (R3)
3042 006764 006100 ROL R0
3043 006766 000405 BR $TPNUM
3044 006770 004767 177500 RPTOCT: JSR PC,$TYPE ; TYPE 3 SPACES
3045 006774 020040 .ASCIZ / /
3046 .EVEN
3047 007000 005000 FATYP: CLR R0
3048 007002 012723 000006 $TPNUM: MOV #6,(R3)+ ;ENABLE THE TYPE OUT OF 6 OCTAL DIGITS
3049 007006 000241 4$: CLC
3050 007010 006113 ROL (R3)
3051 007012 006100 ROL R0 ;PLACE THE CARRY FROM (R3) IN R0
3052 007014 052700 000060 BIS #60,R0 ;OR THE CONTENTS OF R0 WITH AN ASCII 0
3053 007020 004767 177512 JSR PC,$TPCHR ; TYPE THE OCTAL NUMBER STORED IN R0
3054 007024 005000 CLR R0
3055 007026 006113 ROL (R3)
3056 007030 006100 ROL R0 ;PLACE THE CARRY FROM (R3) IN R0
3057 007032 006113 ROL (R3)
3058 007034 006100 ROL R0 ;PLACE THE CARRY FROM (R3) IN R0
3059 007036 105363 177776 DECB -2(R3) ;IF WE HAVEN'T TYPED THE 6 OCTAL DIGITS
3060 007042 001361 BNE 4$ ;THEN REPEAT FROM 4$
3061 007044 105337 000314 DECB @#TYPCNT ;IF ALL THE WORDS REQUIRED HAVE NOT BEEN
3062 007050 001347 BNE RPTOCT ;TYPED THEN REPEAT FROM RPTOCT
3063 007052 000207 OCTXT: RTS PC

```

```

3064
3065
3066
3067
3068
3069
3070
3071
3072
3073 007054 012702 001400 MEMMNG: MOV #1400,R2
3074 007060 105037 000276 MMREG: CLR @#MMAVA ;CLEAR THE BYTE THAT IS SUPPOSED TO INDICATE
3075 ;THAT MEM. MANAG. IS AVAILABLE FOR TESTING
3076 007064 032777 010000 171356 BIT #10000,@SWR ;HAS THE OPERATOR ASKED TO CHECK MEMORY MANAG. ?
3077 007072 001441 BEQ RETMM ;IF NOT THEN RETURN FROM THE SUBROUTINE
3078 007074 012700 000004 MOV #4,R0 ;PREPARE TO SETUP TIME OUT VECTOR
3079 007100 012720 007200 MOV #NOMM,(R0)+ ;RETURN ADDRESS TO NOMM
3080 007104 012710 000340 MOV #340,(R0) ;AND WITH A PSW OF 340
3081 007110 005037 177572 CLR @#SRO ;TRY TO REACH MEM. MANAG. SRO
3082 007114 105237 000276 INCB @#MMAVA ;IF IT IS AVAILABLE THEN SET MEM. MANAG. AVAILABLE
3083 ;BYTE
3084 007120 012701 172340 MOV #172340,R1 ;R1 IS POINTING TO PAR0
3085 007124 005021 CLR (R1)+ ;PAR0 WILL POINT TO BANK 0
3086 007126 062702 000200 2$: ADD #200,R2
3087 007132 010221 MOV R2,(R1)+ ;SETUP PAR1-PAR6
3088 007134 020127 172356 CMP R1,#172356
3089 007140 103772 BLO 2$
3090 007142 012711 007600 MOV #7600,(R1) ;PAR7 IS POINTING TO THE I/O PAGE
3091 007146 012701 172300 MOV #172300,R1
3092 007152 012721 077406 4$: MOV #77406,(R1)+ ;SETUP PDR0-PDR7
3093 007156 020127 172316 CMP R1,#172316
3094 007162 101773 BLOS 4$
3095 007164 005237 177572 INC @#SRO ;ENABLE MEM. MANAG.
3096 007170 005010 $RETMM: CLR (R0) ;RESTORE TIME OUT TRAP VECTOR FOR ANY FUTURE TRAP
3097 007172 012740 000104 MOV #BUSER,-(R0)
3098 007176 000207 RETMM: RTS PC
3099
3100 007200 022626 NOMM: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
3101 007202 004767 177366 JSR PC,TPCRLF ;TYPE 'NO MEMORY MANAGEMENT MESSAGE
3102 007206 047516 046440 043516 .ASCIZ /NO MNG/
3103 007214 000 .EVEN
3104 007216 004767 176732 JSR PC,FATERR ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
3105 007216 004767 176732 JSR PC,FATERR ;*****ERROR NUMBER 52*****
3106 007222 000052 52
3107
3108 007224 000761 BR $RETMM ; RESTORE TIME OUT TRAP VECTOR
3109
3110 007226 013702 172354 UPMM: MOV @#172354,R2 ;PREPARE TO UPDATE MEMORY MANAG. REGISTERS
3111 007232 000712 BR MMREG
    
```

```

3112
3113          ;* 18 BIT ADDRESS GENERATOR
3114          ;* -----
3115          ;*
3116          ;* THIS SUBROUTINE IS USED TO PLACE THE ADDRESS STORED IN R1
3117          ;* IN THE LOCATION POINTED BY R3. THE ADDRESS IN R1 IS CONVERTED
3118          ;* TO AN 18 BIT ADDRESS ONLY IF MEM. MANAG. IS AVAILABLE IN WHICH
3119          ;* CASE THE HIGH ORDER BITS OF THE ADDRESS ARE PLACED IN LOCATION
3120          ;* POINTED BY R3-2
3121          ;*
3122          ;*
3123 007234 005063 177776          PUTADR: CLR      -2(R3)
3124 007240 010113                MOV      R1,(R3)          ;PLACE THE ADDRESS STORED IN R1 IN LOCATION (R3)
3125 007242 105737 000276        TSTB    @#MMAVA          ;IS THE MEM. MANAG. AVAILABLE ?
3126 007246 001425                BEQ     6$              ;IF NOT THEN RETURN FROM THE SUBROUTINE
3127 007250 010146                MOV     R1,-(SP)        ;SAVE R1
3128 007252 042701 017777        BIC     #17777,R1      ;CLEAR BITS 0-12 OF THE ADDRESS IN R1
3129 007256 040113                BIC     R1,(R3)        ;LEAVE BITS 0-12 OF THE ADDRESS IN (R3)
3130 007260 052701 004000        BIS     #4000,R1      ;PREPARE TO SHIFT R1 BY 12 PLACES
3131 007264 006001                2$:    ROR     R1
3132 007266 103376                BCC     2$              ;GET THE NUMBER OF PAR IN R1
3133 007270 062701 172340        ADD     #172340,R1     ;GET THE ADDRESS OF PAR IN R1
3134 007274 011101                MOV     (R1),R1        ;LOAD R1 WITH THE CONTENTS OF PAR
3135 007276 052701 010000        BIS     #10000,R1
3136 007302 006101                4$:    ROL     R1
3137 007304 103376                BCC     4$              ;PLACE THE ADDRESS BITS 13-17 IN BITS 11-15 OF R1
3138 007306 006101                ROL     R1
3139 007310 006143                ROL     -(R3)          ;PLACE BIT 17 IN LOCATION POINTED BY R3-2
3140 007312 006101                ROL     R1
3141 007314 006123                ROL     (R3)+          ;PLACE BIT 16 OF THE ADDRESS
3142 007316 050113                BIS     R1,(R3)        ;PLACE BITS 13-15 OF THE ADDRESS IN LOCATION (R3)
3143 007320 012601                MOV     (SP)+,R1      ;RESTORE R1
3144 007322 000207                6$:    RTS     PC          ;RETURN FROM THE SUBROUTINE
3145
3146          ;* GET ADDRESS FROM THE APT MAILBOX
3147          ;* -----
3148          ;*
3149          ;* THIS SUBROUTINE IS USED TO GET ADDRESS FROM APT MAILBOX AND
3150          ;* PLACE IT IN THE LOCATION USED BY THE PROGRAM TO DEFINE THE
3151          ;* MEMORY BOUNDRIES.
3152          ;* PROGRAM CONTROL SHOULD COME TO THIS SUBROUTINE WITH R1 POINT-
3153          ;* ING TO THE MEMORY TYPE IN THE APT MAILBOX AND R3 POINTING TO
3154          ;* THE LOCATION+2 WHERE THE LOW ORDER BITS OF THE ADDRESS HAVE
3155          ;* TO BE PLACED
3156          ;*
3157          ;*
3158 007324 016143 000001          GETADR: MOV     1(R1),-(R3) ;PLACE THE LOW ORDER BITS OF THE ADDRESS
3159 007330 005043                CLR     -(R3)          ;CLEAR THE LOCATION WHERE THE HIGH ORDER BITS
3160                                ;HAVE TO BE PLACED
3161 007332 116113 177777        MOVB   -1(R1),(R3)    ;PLACE BITS 16 & 17
3162 007336 000207                2$:    RTS     PC          ;RETURN FROM THE SUBROUTINE

```

```

3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173 007340 005046          $GTSIZ: CLR      -(SP)          ;PREPARE TO PLACE ADDRESS BITS 13-17 IN BITS
3174                                     ;0-4 OF R2
3175
3176 007342 012301          GETSIZ: MOV      (R3)+,R1
3177 007344 011302          MOV      (R3),R2          ;LOAD R2 WITH THE LOW ORDER BITS OF THE ADDRESS
3178 007346 042702 017777          BIC      #17777,R2        ;CLEAR ADDRESS BITS 0-12
3179 007352 052702 000040          2$:     BIS      #40,R2
3180 007356 006001          4$:     ROR      R1
3181 007360 006002          ROR      R2          ;ROTATE R1 AND R2 7 TIMES
3182 007362 103375          BCC      4$
3183 007364 005716          TST      (SP)          ;IF RETURN PC IS ZERO THEN IT MUST BE THE
3184 007366 001004          BNE      6$          ;FLAG THAT WAS SET AT $GTSIZ
3185 007370 005726          TST      (SP)+          ;POP THE FLAG OFF STACK
3186 007372 052702 000100          BIS      #100,R2        ;KEEP ROTATING
3187 007376 000767          BR       4$
3188 007400 012301          6$:     MOV      (R3)+,R1          ;PLACE THE LOW ORDER ADDRESS BITS IN R1
3189 007402 012700 160000          MOV      #160000,R0
3190 007406 040001          BIC      R0,R1          ;LEAVE BITS 0-12 OF THE ADDRESS IN R1
3191 007410 000207          RTS      PC          ;RETURN FROM THE SUBRORNE
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201 007412 105737 000276          CLRMM: TSTB     @#MMAVA          ;WAS THE MEMORY MANAGEMENT ENABLED ?
3202 007416 001404          BEQ      1$          ;IF NOT THEN GO TO 1$
3203 007420 005037 177572          CLR      @#SRO          ;DISABLE THE MEMORY MANAGEMENT
3204 007424 105037 000276          CLRB     @#MMAVA          ;AND DO NOT ATTEMPT TO TEST MEM. MANAG.
3205 007430 000207          1$:     RTS      PC          ;RETURN FROM THE SUBROUTINE
3206
3207
3208
3209
3210
3211
3212
3213
3214
3215 007432 010046          ;* GET BANK NO. UNDER TEST
3216 007434 010346          ;   CALLED BY ERRYP AND TST13 TO GET BANK NO. UNDER TEST INTO PBNK.
3217 007436 042703 017777          ;REGISTERS
3218 007442 052703 010000          ;R0=POINTER TO PAR UNDER TEST
3219                                     ;R3=VIRTUAL ADDRESS ON ENTRY
3220                                     ;R0+R3 ARE RESTORED ON EXIT.
3221
3222
3223
3224
3225
3226
3227
3228
3229
3230
3231
3232
3233
3234
3235
3236
3237
3238
3239
3240
3241
3242
3243
3244
3245
3246
3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319
3320
3321
3322
3323
3324
3325
3326
3327
3328
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468
3469
3470
3471
3472
3473
3474
3475
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549
3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3699
3700
3701
3702
3703
3704
3705
3706
3707
3708
3709
3710
3711
3712
3713
3714
3715
3716
3717
3718
3719
3720
3721
3722
3723
3724
3725
3726
3727
3728
3729
3730
3731
3732
3733
3734
3735
3736
3737
3738
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750
3751
3752
3753
3754
3755
3756
3757
3758
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807
3808
3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3840
3841
3842
3843
3844
3845
3846
3847
3848
3849
3850
3851
3852
3853
3854
3855
3856
3857
3858
3859
3860
3861
3862
3863
3864
3865
3866
3867
3868
3869
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887
3888
3889
3890
3891
3892
3893
3894
3895
3896
3897
3898
3899
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3915
3916
3917
3918
3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936
3937
3938
3939
3940
3941
3942
3943
3944
3945
3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000

```

```

3219 007446 000241          CLC
3220 007450 006003          1$: ROR      R3          ;SHIFT A BANK BIT
3221 007452 103376          BCC      1$          ;UNTIL IN BITS <2:0> OF R3
3222 007454 105737 000276   TSTB    @#MMAVA      ;MEMORY MANAGEMENT UNDER TEST?
3223 007460 001407          BEQ      2$          ;NO EXIT
3224
3225          ;GET PAR ADDRESS AND PHYSICAL BANK NO.
3226 007462 006303          ASL      R3          ;MAKE R3 PAR ADDRESS OFFSET.
3227 007464 062703 172340   ADD     #172340,R3   ;MAKE FULL PAR ADDRESS.
3228 007470 011300          MOV     (R3),R0      ;GET PAR CONTENTS
3229 007472 006300          ASL     R0
3230 007474 000300          SWAB    R0          ;SHIFT BANK BITS TO BITS <7:0>
3231 007476 110003          MOVVB   R0,R3       ;SET R3 TO PHYSICAL BANK NO.
3232 007500 010337 000312   2$: MOV   R3,@#PBK   ;STORE PHYSICAL BANK NO.
3233 007504 012603          MOV     (SP)+,R3    ;RESTORE R3
3234 007506 012600          MOV     (SP)+,R0    ;RESTORE R0
3235 007510 000207          RTS     PC          ;RETURN TO CALLER
3236
3237
3238
3239          ; PARITY ENABLE/DISABLE ROUTINE
3240
3241          ;
3242          ; THIS ROUTINE ENABLES OR DISABLES PARITY MODULES AND PRINTS ASSOCIATED MEESSAGES.
3243          ; IF PARITY AVAILABLE THEN BIT13 OF 'REL' IS SET AND 'PAR'ITY IS PRINTED.
3244          ; ALSO THE BACKGROUND TEST PATTERN (LOC. BAKPAT) IS SET=376
3245          ;
3246          ; REGISTER USAGE.
3247          ; R0= POINTS TO BUS TIMEOUT TRAP VECTOR (LOC. 4)
3248          ; R1= HOLDS PARITY MODULE UNIBUS ADDRESS.
3249          ; R2= ON ENTRY HOLDS ENABLE/DISABLE CODE .
3250          ; IF R2=0 THEN DISABLE
3251          ; IF R2=1 THEN ENABLE
3252          ; R3= SCRATCH TO SETUP LOC. PARMAP WITH A MAP OF PARITY MODULES PRESENT.
3253          ; CALL IS
3254          ; MOV     #1,R2 ;ENABLE CODE
3255          ; JSR     PC,PARITY
3256
3257
3258 007512 032777 004000 170730 PARITY: BIT   #4000,@SWR   ;PARITY TEST WANTED?
3259 007520 001460          BEQ     6$          ;BRANCH IF NO
3260
3261 007522 012700 000004          MOV     #4,R0      ;POINT R0 TO BUS TIMEOUT ADDRESS.
3262 007526 012710 000122          MOV     #5$-,-6,(R0) ;SET RETURN FROM TIMEOUT TRAP TO 5$
3263 007532 060710          ADD     PC,(R0)    ;IN THE CURRENT BANK.
3264 007534 005037 000352          1$: CLR     @#PARMAP ;CLEAR PARITY MAP HOLDER.
3265 007540 012701 172140          MOV     #172140,R1 ;SET R1 TO LAST PARITY MODULE ADDRESS+2
3266 007544 012703 100000          MOV     #100000,R3 ;SET R3 TO PARMAP AVAILABLE CODE BEGIN.
3267 007550 010241          2$: MOV     R2,-(R1) ;ENABLE A PARITY MODULE+TRAP IF NOT AVAILABLE.
3268 007552 050337 000352          BIS     R3,@#PARMAP ;NO TRAP TO 5$, SO SET PARITY AVAILABLE.
3269 007556 000241          CLC
3270 007560 006003          3$: ROR     R3          ;SETUP NEXT PARMAP BIT
3271 007562 103372          BCC     2$          ;BRANCH IF NOT DONE ALL PARITY ADDRESSES.
3272 007564 012710 000104          MOV     #BUSER,(R0) ;RESET BUS TIMEOUT TRAP VECTOR
3273 007570 005702          TST     R2          ;IS THIS A DISABLE CALL?
3274 007572 001433          BEQ     6$          ;BRANCH IF YES (EXIT)

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 69
 CZKMAE.MAC 18-SEP-78 11:54

SUBROUTINE TO DISABLE MEMORY MANAGEMENT

SEQ 0069

```

3275 007574 005737 000352      TST    @#PARMAP      ;WERE ANY PARITY MODULES FOUND?
3276 007600 001011              BNE    4$            ;BRANCH IF YES
3277 007602 004767 176766      JSR    PC,TPCRLF    ;PRINT 'NO PAR'
3278 007606 047516 050040 051101 .ASCIZ /NO PAR/
3279 007614      000
3280 007616 007616              .EVEN
3281 007616 004767 176332      JSR    PC,FATERR    ;*ERROR* REPORT ERROR MESSAGE AND HALT AT FATHLT
3282 007622 000053              53                  ;*****ERROR NUMBER 53*****
3283
3284
3285 007624 152737 000040 000405 4$: BISB   #40,@#REL    ;SET PARITY UNDER TEST FLAG
3286 007632 012737 000376 000316      MOV    #376,@#BAKPAT ;SET BACKGROUND PATTERN TO
3287                                ;WORST CASE PARITY CODE.
3288 007640 004767 176730      JSR    PC,TPCRLF    ;PRINT 'TST PARITY'
3289 007644 040520 044522 054524 .ASCIZ /PARITY/
3290 007652      000
3291 007654 007654              .EVEN
3292 007654 000405              BR     EXITC        ;AND EXIT VIA RTS PC
3293
3294                                ;GET HERE IF PARITY ADDRESS TIMED OUT TO LOC. 4
3295

```

CZKMA MACY11 30A(1052) 18-SEP-78 11:56 PAGE 70
 CZKMAE.MAC 18-SEP-78 11:54

SUBROUTINE TO DISABLE MEMORY MANAGEMENT

SEQ 0070

```

3296 007656 022626      5$:   CMP      (SP)+,(SP)+   ;RESET STACK FROM TRAP
3297 007660 000737      BR      3$           ;KEEP TRYING PARITY ADDRESSES.
3298
3299 007662 142737 000040 000405 6$:   BICB      #40,@#REL   ;CLEAR PARITY TESTING FLAG
3300 007670
3301 007670 000207      7$:   RTS      PC           ;RETURN TO CALLER
3302
3303
3304
3305
3306
3307      :CHECKC
3308      :      THIS ROUTINE CHECKS IF CONTROL-C WAS TYPED AT THE END OF EACH
3309      :      TEST OR IN THE ERROR TYPE ROUTINE.
3310      :      IF CONTROL-C TYPED THE PROGRAM IS RETURNED TO LOWER MEMORY IF IT WAS
3311      :      RELOCATED AND THE ERROR HISTORY IS PRINTED OUT.
3312      :      FINALLY IT HALTS AT FATHLT.
3313 007672 105037 000315 CHECKC: CLR      @#SAVKBB   ;INIT CONTROL-C FLAG.
3314 007676 105737 177560      TSTB      @#TKS         ;ANY CHAR. TYPED?
3315 007702 100372      BPL      EXITC         ;BR IF NO-EXIT VIA RTS PC-
3316 007704 113702 177562      MOV      @#$KBB,R2    ;GET THE CHAR TYPED.
3317 007710 042702 000200      BIC      #200,R2     ;CLEAR THE PARITY BIT.
3318 007714 122702 000003      CMP      #3,R2       ;IS IT CONTROL-C?
3319 007720 001363      BNE      EXITC         ;BRANCH IF NO -EXIT VIA RTS PC-
3320 007722 110237 000315      MOV      R2,@#SAVKBB  ;ELSE STORE THE CHAR. FOR USE AS A FLAG.
3321 007726 004767 176642      JSR      PC,TPCRLF    ;PRINT '^C'
3322 007732 041536      .ASCIZ  /^C/
3323 007736 007736      .EVEN
3324 007736 000167 175114      JMP      RELOER       ;GO RETURN PROGRAM TO LOWER CORE IF RELOCATED.
3325
3326      .=7744
3327 007744 000000      ENDPRG: 0
3328
3329
3330
3331
3332      000001      .END

```

```

;THIS BEGINS THE STORAGE FOR THE ERROR HISTORY
;STACK.FOR EACH 4K BANK 18. BYTES ARE SAVED.
;ALSO THE ABSOLUTE LOADER AND XXDP CODE IS SAVED
;AFTER THE ERROR STACK.
;FOR 4K MEMORY SIZE THEN PROGRAM=7744+22=7776

```


\$FATAL	000402	1223#	2746*	2755*	2763	2847*	2850										
\$GTSIZ	007340	1407	3173#														
\$HD =	000002	992															
\$HIBTS	000276	1125#															
\$HIMAX	000334	1194#	1335*														
\$KBB =	177562	1176#	3316														
\$MADR1	000432	1248#															
\$MADR2	000436	1252#															
\$MADR3	000442	1255#															
\$MADR4	000446	1258#															
\$MAIL	000400	1081	1126	1130	1221#	1291	1306										
\$MAMS1	000430	1242#															
\$MAMS2	000434	1250#															
\$MAMS3	000440	1253#															
\$MAMS4	000444	1256#															
\$MAXM	000336	1195#	1336*	1415													
\$MBADR	000300	1126#															
\$MSGAD	000414	1228#															
\$MSGLG	000416	1229#															
\$MSGTY	000400	1026*	1222#	2818*													
\$MTYP1	000431	1243#	1344														
\$MTYP2	000435	1251#															
\$MTYP3	000441	1254#															
\$MTYP4	000445	1257#	1340														
\$NWTST=	000001	1575#	1577	1664#	1666	1705#	1707	1747#	1749	1840#	1842	1880#	1882	1966#			
		1968	2021#	2023	2097#	2099	2222#	2224	2269#	2271	2362#	2364					
		1225#	1283	2706*	2713												
\$PASS	000406	1128#															
\$PASTM	000304	1146#	1149	1273*	2780	2796	2813*	2898*									
\$PRERR	000300	3096#	3108														
\$RETMM	007170	1011#	1016														
\$SVPC =	000044	992#	1001#	1588	1670	1714	1759	1847	1895	1983	2033	2125	2251	2292			
\$SWR =	000000	2393															
\$SWREG	000422	1233#	1321														
\$TESTN	000404	1085	1133	1224#	1517*	1563	1587	1669	1713	1758	1846	1894	1982	2032			
		2124	2182	2190	2215	2250	2291	2392									
\$TN =	000014	982#	992	1575	1588#	1664	1670#	1705	1714#	1747	1759#	1840	1847#	1880			
		1895#	1966	1983#	2021	2033#	2097	2125#	2222	2251#	2269	2292#	2362	2393#			
\$TPB =	177566	1178#	2966*														
\$TPCHR	006536	2953	2962#	3053													
\$TPDEC	006630	2531	2678	2714	2993#												
\$TPNUM	007002	3043	3048#														
\$TPS =	177564	1177#	2964														
\$TPSTK	005324	2586	2652#														
\$STSM	000302	1127#															
\$TYPE	006474	1402	2948#	2969	2975	3006	3044										
\$UNIT	000412	1079	1227#														
\$UNITM	000306	1129#															
\$USWR	000424	1234#															
\$Z =	000362	1213#															
\$ZZ =	007742	3326#															
\$SM =	000200	2487#															
.	= 007746	999#	1004#	1011	1012#	1014#	1016#	1018#	1024#	1031#	1070#	1114	1115#	1117#			
		1119#	1137#	1141#	1145#	1149#	1153#	1155#	1157#	1162#	1164#	1167#	1213	1216#			
		1267#	1276	1525	1588	1643	1672	1715	1759	1847	1896	1985	2034	2126			
		2252	2292	2393	2514	2529#	2712#	2772	2971#	3104#	3262	3280#	3291#	3323#			

.SX = 000276 3326#
 1114# 1119

CROSS REFERENCE TABLE -- MACRO NAMES

ERRLST	393#	395	398	403	408	413	419	426	432	437	441	445	449	453	457
	461	465	469	474	478	482	486	490	492	500	504	508	519	523	532
	536	539	545	549	553	557	565	569	573	578	583	590	596	600	605
MSG	1575#	1577	1664#	1666	1705#	1707	1747#	1749	1840#	1842	1880#	1882	1966#	1968	2021#
	2023	2097#	2099	2222#	2224	2269#	2271	2362#	2364						
NEWST	982#	1575	1664	1705	1747	1840	1880	1966	2021	2097	2222	2269	2362		
PLCERR	997#	1603	1606	1614	1785	1795	1811								
STARS	982#	1009	1074	1077	1111	1113	1120	1185	1192	1219	1262	1264	1575	1586	1664
	1668	1705	1712	1747	1757	1840	1845	1880	1893	1966	1981	2021	2031	2097	2123
	2222	2249	2269	2290	2362	2391									
\$ERRNM	997#	1681	1735	1864	1904	1911	1938	1996	2070	2151	2167	2176	2321	2329	2458
	2470	2487	2899												
\$FATAL	394#	395	398	403	408	413	419	426	432	437	441	445	449	453	457
	461	465	469	474	478	482	486	490	492	500	504	508	519	523	532
	536	539	545	549	553	557	565	569	573	578	583	590	596	600	605
\$FTERR	997#	1299	1347	1464	1488	1646	2909	3105	3281						
\$SQERR	997#	1589	1673	1716	1760	1848	1897	1986	2035	2127	2253	2293	2394		
\$\$NEWT	982#	1575	1664	1705	1747	1840	1880	1966	2021	2097	2222	2269	2362		
.HEADE	982#														
.\$ACT1	982#	1007													
.\$APT8	982#	1217													
.\$APTH	982#	1109													

. ABS. 007746 000

ERRORS DETECTED: 0

CZKMAE,CZKMAE.SEQ/CRF/SOL/NL:TOC=CZKMAE.MAC
RUN-TIME: 8 9 .6 SECONDS
RUN-TIME RATIO: 74/19=3.8
CORE USED: 11K (21 PAGES)