

Pin No.	In/Out	Port Name	Function																																				
85	I	NORM/SERV/T2/TEST	Normal/Service/Test2/Test mode selection. <table><tr><th>INPUT VOLTAGE</th><th>MODE</th></tr><tr><td>More than 4.0V</td><td>Normal</td></tr><tr><td>2.5V - 4.0V</td><td>Service</td></tr><tr><td>1.0V - 2.5V</td><td>Test 2</td></tr><tr><td>Less than 1.0V</td><td>Test</td></tr></table>	INPUT VOLTAGE	MODE	More than 4.0V	Normal	2.5V - 4.0V	Service	1.0V - 2.5V	Test 2	Less than 1.0V	Test																										
INPUT VOLTAGE	MODE																																						
More than 4.0V	Normal																																						
2.5V - 4.0V	Service																																						
1.0V - 2.5V	Test 2																																						
Less than 1.0V	Test																																						
86	I	T-PHOT	This port receives less than 2.4V when Take-up photo sensor detects the tape beginning.																																				
87	I	S-PHOT	This port receives less than 2.4V when Supply photo sensor detects the tape end.																																				
88	I	T.S.CURVE	Tuner S curve input.																																				
89	I	TRACKING ENVE	Playback envelope input for auto tracking adjustment.																																				
90	I	POS SW1	Mechanism position detection input. <table><tr><th>P.SW 3</th><th>P.SW 2</th><th>P.SW 1</th><th>Position(Mode) Name</th></tr><tr><td>0</td><td>0</td><td>0</td><td>EJECT</td></tr><tr><td>0</td><td>0</td><td>1</td><td>CASSETTE DOWN</td></tr><tr><td>0</td><td>1</td><td>0</td><td>REV,REV SLOW</td></tr><tr><td>0</td><td>1</td><td>1</td><td>MID(LOADING/UNLOADING)</td></tr><tr><td>1</td><td>0</td><td>0</td><td>PLAY/REC,STILL/PAUSE,CUE,FWD SLOW,STOP3*1</td></tr><tr><td>1</td><td>0</td><td>1</td><td>STOP</td></tr><tr><td>1</td><td>1</td><td>0</td><td>FF/REW</td></tr><tr><td>1</td><td>1</td><td>1</td><td>INTERMEDIATE</td></tr></table>	P.SW 3	P.SW 2	P.SW 1	Position(Mode) Name	0	0	0	EJECT	0	0	1	CASSETTE DOWN	0	1	0	REV,REV SLOW	0	1	1	MID(LOADING/UNLOADING)	1	0	0	PLAY/REC,STILL/PAUSE,CUE,FWD SLOW,STOP3*1	1	0	1	STOP	1	1	0	FF/REW	1	1	1	INTERMEDIATE
P.SW 3	P.SW 2	P.SW 1	Position(Mode) Name																																				
0	0	0	EJECT																																				
0	0	1	CASSETTE DOWN																																				
0	1	0	REV,REV SLOW																																				
0	1	1	MID(LOADING/UNLOADING)																																				
1	0	0	PLAY/REC,STILL/PAUSE,CUE,FWD SLOW,STOP3*1																																				
1	0	1	STOP																																				
1	1	0	FF/REW																																				
1	1	1	INTERMEDIATE																																				
91	I	POS SW2																																					
92	I	POS SW3																																					
(*1) The Pinch Roller is on the Capstan motor shaft.																																							
93	I	S.TAB(L)	This port receives low while the cassette tape with safety tab is inserted.																																				
94	I	N.C.	Not used																																				
95	O	POWER SAVE(H)	FIP on/off control during power off. FIP off:High FIP on:Low																																				
96	O	POWER OFF(H)	Power on/off control.																																				
97	O	SLOW MODE (H)	Not Used																																				
98	O	ROTARY SW	Rotary switching signal output.																																				
99	O	H.A.SW	Head amp switching signal output. 1. 4 Head model LP/EP:High SP:Low 2. 2 Head model Low																																				
100	I	ENVE SELECT	This port receives the playback envelope signal level to select the video head in special playback mode.																																				