

SHARP®

POCKET COMPUTER

MODEL
PC-1246S
PC-1248

OPERATION MANUAL



$$c = \sqrt{a^2 + b^2} + 2abc \cos \theta$$

150:END
160:PRINT "OK"
170:END



TABLE OF CONTENTS

	Page
INTRODUCTORY NOTE	4
CHAPTER 1. HOW TO USE THIS MANUAL	5
CHAPTER 2. INTRODUCTION TO THE COMPUTER	7
Description of System	7
Description of Keys	8
Description of Display	11
RESET Button	12
Cell Replacement	14
CHAPTER 3. USING THE COMPUTER AS A CALCULATOR	17
Start Up	17
Shut Down	17
Auto Off	17
Some Helpful Hints	18
Key operation	19
Simple Calculations	19
Recalling Entries	20
Errors	24
Serial Calculations	24
Negative Numbers	26
Compound Calculations and Parentheses	26
Using Variables in Calculations	27
Chained Calculations	29
Now It's Your Turn	29
CHAPTER 4. CONCEPTS AND TERMS OF BASIC	30
Numeric Constants	30
Scientific Notation	30
Limits	31
Hexadecimal Numbers	32
String Constants	32
Variables	33
Simple Numeric Variables	33
Simple String Variables	33
Numeric Array Variables	33
String Array Variables	34
Preallocated Variables	34
Expressions	35
Numeric Operators	36
String Expressions	36

Table of Contents

	Page
Relational Expressions	37
Logical Expressions	38
Parentheses and Operator Precedence	40
Calculator Mode	40
Functions	40
CHAPTER 5. PROGRAMMING THE COMPUTER	42
Programs	42
BASIC Statements	42
Line Numbers	42
BASIC Verbs	42
BASIC Commands	43
Modes	43
Beginning to Program on the Computer	44
Example 1 — Entering and Running a Program	44
Example 2 — Editing a Program	45
Example 3 — Using Variables in Programming	47
Example 4 — More Complex Programming	49
Storing Programs in the Memory	50
CHAPTER 6. SHORTCUTS	52
The DEF Key and Labelled Programs	52
CHAPTER 7. USING THE OPTIONS	53
USING THE CE-125 PRINTER/MICROCASSETTE RECORDER	54
Using the Printer	54
Using the Microcassette Recorder	55
Using an External Tape Playback Unit	57
Care and Maintenance	58
Errors	58
Examples	58
USING THE PRINTER/CASSETTE INTERFACE	61
Using the Printer	61
Using the Cassette Interface	63
Operating the Cassette Interface and Recorder	65
Tape Notes	68

	Page
CHAPTER 8. BASIC REFERENCE	69
Commands	72
Verbs	85
Functions	129
Pseudovariables	129
Numeric Functions	130
String Functions	135
CHAPTER 9. TROUBLESHOOTING	137
Machine Operation	137
BASIC Debugging	138
CHAPTER 10. MAINTENANCE OF THE COMPUTER	139
APPENDICES	
Appendix A: Error Messages	140
Appendix B: ASCII Character Code Chart	142
Appendix C: Formatting Output	144
Appendix D: Expression Evaluation and Operator Priority	147
Appendix E: Using Programs Written on Other PC Models	150
Appendix F: Numeric Precision on the Computer	157
Appendix G: Specifications	159
PROGRAM EXAMPLES	161
INDEX	206

INTRODUCTORY NOTE

Welcome to the world of **SHARP** owners!

Few industries in the world today can match the rapid growth and technological advances being made in the field of personal computing. Computers which just a short time ago would have filled a huge room, required a Ph.D. to program, and cost thousands of dollars, now fit in the palm of your hand, are easily programmed, and cost so little that they are within the reach of nearly everyone.

Your new **SHARP COMPUTER** was designed to bring you all of the latest state of the art features of this computing revolution. As one of the most sophisticated hand held computers in the world today it incorporates many advanced capabilities:

- * **MEMORY SAFE GUARD** — the **computer** remembers stored programs and variables even when you turn it off.
- * Battery powered operation for true portability.
- * **AUTO POWER OFF** function which conserves the batteries by turning the power off if no activity takes place within a specified time limit.
- * Programmable functions which allow the **computer** to be used as a "smart" calculator.
- * An expanded version of **BASIC** which provides formatted output, two-dimensional arrays, variable length strings, program chaining and many other advanced features.
- * An optional printer/microcassette recorder (Model CE-125) for long term storage and hard copy printout of programs and data.

Congratulations on entering an exciting and enjoyable new world. We are sure that you will find this purchase one of the wisest you have ever made. The **SHARP computer** is a powerful tool, designed to meet your specific mathematical, scientific, engineering, business and personal computing needs. With the **SHARP computer** you can begin **NOW** providing the solutions you'll need tomorrow!

CHAPTER 1

HOW TO USE THIS MANUAL

This manual is designed to introduce you to the capabilities and features of your **computer** and to serve as a valuable reference tool. Whether you are a "first time user" or an "old hand" with computers, you should acquaint yourself with the **computer** by reading and working through Chapters 2 through 6.

- * Chapter 2 describes the physical features of the **computer**.
- * Chapter 3 demonstrates the use of the **computer** as a calculator.
- * Chapter 4 defines some terms and concepts which are essential for BASIC programming, and tells you about the special considerations of these concepts on the **computer**.
- * Chapter 5 introduces you to BASIC programming on the **computer**, showing you how to enter, correct, and run programs.
- * Chapter 6 discusses some shortcuts that make using your new computer easier and more enjoyable.

Experienced BASIC programmers may then read through Chapter 8 to learn the specific features of BASIC as implemented on the **computer**. Since every dialect of BASIC is somewhat different, read through this material at least once before starting serious programming.

Chapter 8 is a reference section covering all the verbs, commands, and functions of BASIC arranged in convenient alphabetical groupings.

If you have never programmed in BASIC before, we suggest that you buy a separate book on beginning BASIC programming or attend a BASIC class, before trying to work through these chapters. This manual is not intended to teach you how to program.

The remainder of the manual consists of:

- * Chapter 7 — Basic information on the optional **CE-125** Printer/Micro-cassette Recorder and **CE-123P/CE-126P** Printer/Cassette Interface.
- * Chapter 9 — A troubleshooting guide to help you solve some operating and programming problems.

How to Use This Manual

- * Chapter 10 — The care and maintenance of your new computer.


Detailed Appendices, at the end of the manual, provide you with useful charts, comparisons, and special discussions concerning the use and operation of the computer.

Note: Unless otherwise specified, the text material applies to both models.


Using the Hard Cover

When the computer is not being used, mount the hard cover over the keyboard of the computer.

- When the computer is not in use.



- When the computer is in use.




CHAPTER 2 INTRODUCTION TO THE COMPUTER

Description of System

The SHARP computer system consists of:

- * 54-character keyboard.
- * 16-character display.
- * Powerful BASIC in 17.4KB ROM.
- * 4-bit CMOS processor.
- * 2KB RAM (PC-1246S), 8KB RAM (PC-1248)
- * Option: CE-124 Cassette Interface
CE-125 Printer/Microcassette Recorder.
CE-123P Printer/Cassette Interface.
CE-126P Printer/Cassette Interface.



To familiarize you with the placement and functions of parts of the **computer** keyboard, we will now study each section of the keyboard. For now just locate the keys and read the description of each. In Chapter 3 we will begin using your new machine.


DIFFERENCES BETWEEN THE PC-1246S AND THE PC-1248

The fundamental functions of the PC-1246S and the PC-1248 are exactly the same, except for the following:

Model	Program/data area capacity	BEEP function
PC-1246S	1278 Bytes	No
PC-1248	7422 Bytes	Yes

NOTE: No tone is generated by the PC-1246S.


Description of Keys



- BRK ON** Power on/BReAK key. Press this key to turn the power on. Pressing this key after an AUTO OFF turns the computer back on. Also press this key to temporarily interrupt a program which is being executed.
- OFF** Power off key. Press this power key to turn the power off.
- SHIFT** SHIFT key. Press this key before pressing any key which has a character above it and the character above is displayed. (Note: Not used to capitalize letters as all alphabet keys on the computer are in the upper case).
- ▼** Down arrow key. Press this key to display the next program line.
- ▲** Up arrow key. Press this key to display the previous program line.
- <DEL** Backspace key. This key allows you to move the cursor to the left without erasing previously typed characters. Pressing **SHIFT** before pressing this key will DElete whatever character the cursor is "on top of".
- INS** Forward key. This key allows you to move the cursor to the right without erasing previously typed characters. Pressing **SHIFT** before pressing this key makes a space directly before the character the cursor is "on top of". You can then INSert a new character into this space.

MODE Mode selection key. When you use the **computer**, check the display for the operational mode it is in (RUN or PROgram) by the indicator on the lower left of the display. Press **MODE** to change the selection from RUN to PRO or from PRO to RUN.

DEF DEFInable key. This is a special key used to execute BASIC programs.



A ~ **Z** Alphabet keys. You are probably familiar with these keys from the standard typewriter keyboard. On the **computer** display the characters always appear in the upper case.


= Equals key. On the **computer** this key is **not** used to indicate the end of a calculation; in BASIC programming this symbol has a special function.

SPC SPaCe key. Pressing this key advances the cursor leaving a blank space. Pressing **SPC** while the cursor is positioned over a character, erases that character.

P↔NP
ENTER ENTER key. When you type this key, whatever you previously typed is "entered" into the computer's memory. This key is similar to the Carriage Return key on a typewriter. You must press **ENTER** before the **computer** will act on alphanumeric input from the keyboard. Pressing **SHIFT** before pressing this key will cause the **computer** to switch on and off the printing of calculations on the **CE-125**, **CE-123P** or **CE-126P**.

! " #
\$ % &
? : ,
; ,
These symbols are found above the top row of alphabet keys. Pressing **SHIFT** and then the alphabet key under the character desired displays these symbols.

INPUT
[]
IF
[]
}
CLOAD
[]
Preset command and statement keys. Pressing **SHIFT** and then the alphabet (including equals and space) key under the command or statement desired enters the designated command or statement to the **computer**.



0 ~ **9** • Number keys. The layout of these keys is similar to that found on the standard calculator.

(**1** Number key. Pressing **SHIFT** and then this key produces a left parenthesis.

) **2** Number key. Pressing **SHIFT** and then this key produces a right parenthesis.

CA
CL Clear key. Pressing **CL** erases the characters you have just typed in and "releases" errors. Pressing **SHIFT** before pressing this key activates the **CA** (reset) function. **CA** clears the display and resets the computer.

/ Division key. Press this key to include the division operator in calculations. Pressing **SHIFT** and then this key will display the "power" symbol, indicating that a number is to be raised to a specific power.


<
***** Multiplication key. Press this key to include the multiplication operator in calculations. Pressing **SHIFT** and then this key displays the "less than" character.

>
- Subtraction key. Press this key to include the subtraction operator in calculations. Pressing **SHIFT** and then this key displays the "greater than" character.

Exp
+ Addition key. Press this key to include the addition operator in calculations. Pressing **SHIFT** and then this key displays the exponentiation character used in scientific notation.


π **√** **@** These three characters are found above the zero, decimal point and 3 keys. They are displayed by pressing **SHIFT** and then the character under the symbol desired.


Description of Display





The liquid crystal display of the **SHARP computer** shows up to 16 characters at one time. Although you may input up to 80 characters including **ENTER** in one line, only the first 16 characters are displayed. To review the remaining characters in a line, move the cursor to the far right and the display will 'scroll' – that is as characters drop off the left, new characters appear on the right.

The display consists of:

 The prompt. This symbol appears when the computer is awaiting input. As you type, the prompt disappears and is replaced by the cursor.

 The cursor. This symbol (the underline) tells you the location of the next character to be typed in. As you begin typing the cursor replaces the prompt. The cursor is also used to position the computer over certain characters when using the **INSert** and **DELete** functions.


 **RUN** RUN indicator. This indicator tells you the operational mode of the **computer** is in the RUN mode.

 **PRO** **PRO**gram indicator. This indicator tells you the operational mode of the **computer** is in the programming mode.

BUSY Program execution indicator. When the **computer** is executing a program this indicator is lit (except when characters are displayed). The **computer** will not undergo **AUTO OFF** while the **BUSY** indicator is on. **BUSY** disappears from the display when execution is completed.

P Printer indicator. This indicator appears whenever you elect the print option when using the **computer** as a calculator.

DEF Definable mode indicator. This symbol lights up whenever you press the **DEF** key.

 **DEG RAD GRAD** Angular measurement indicator. This indicator displays the current unit of angles for the input of trigonometric functions. Depending on the mode in use the indicator will appear on **DEG** (degrees), **RAD** (radians), or **GRAD** (gradients).

SHIFT Shift key indicator. This indicator lights up when the **SHIFT** key has been depressed. Remember, the **SHIFT** key must be released before depressing any other key.

Introduction to the computer


E Error indicator. Whenever an error is encountered this indicator is displayed. When an error occurs, reset with the **CL** key.

RESET Button

The RESET button is used to reset the computer when CLeAr or CA is not sufficient to correct the problem.

To reset the **COMPUTER**, press **ON** and press down the RESET button for about 1 second.

Note: When the RESET button is released, "BUSY" will appear on the display while the computer is being reset. The reset operation is not performed while the RESET button is held down.




Press the RESET button with any pointed object such as a ball-point pen. Do not use easily broken points such as mechanical pencils or the tips of needles.

If you get no response from any key even when the above operation is performed, press the RESET button and do the following:

- 1 Set the computer to the **PRO**gram mode with the **MODE** key.
- 2 Enter **NEW0** and press **ENTER**.

This operation clears all the contents reserved in the computer. Please re-enter the program.



Contrast Control

Turn the control in the direction of the arrow to darken the display, and turn it in the opposite direction to lighten the display.
Adjust the control so that the display is easy to see.

Cell Replacement

When used without peripherals, this computer draws power from the cells inside it. When connected to the CE-125 or CE-126P, the computer can also be supplied from the CE-125 or CE-126P if it has enough power voltage and the cell power decreases. This minimizes the power consumption of the cell.


When to Replace the Cells

If the display becomes dim and difficult to read even when the contrast is at the maximum setting, the cells have become low and should be replaced.


Note: The data and programs stored in the computer will be lost when the cells are removed. Store any data or programs you wish to keep in an optional peripheral device such as the CE-124, CE-125, CE-126P or CE-123P, or a data recorder (CE-152).

Follow the procedure below to insert or replace cells.


1. Press the **OFF** key.
2. Remove the cell compartment lid.



3. While holding down the stopper, move the cell cover in the direction indicated by the arrow in the figure and remove it.




4. Take out the old cells and insert two new cells. Wipe them clean and make sure their positive and negative marks match similar marks in the cell compartment.




5. Attach the cell cover by reversing step 4.
6. Attach the cell compartment lid.

Introduction to the computer

7. Press the **ON** key and the reset button to initialize the computer.



8. Set the PRO mode (program mode) by pressing the **MODE** key, then enter **NEW0** and press the **ENTER** key.
Check to make sure the prompt symbol (**>**) is displayed.



If it is not displayed, remove the cells and reinsert them according to the procedure above.

NOTE:

- Keeping a dead cell in the computer may result in damage to the computer from solvent leakage of the cell. Remove a dead cell promptly.
- The cells in the computer when you bought it were installed at the factory, so they may not provide you with a full service life (estimated at 120 hours).

CAUTION: Keep cell out of reach of children.

CHAPTER 3

USING THE COMPUTER AS A CALCULATOR

Now that you are familiar with the layout and components of the **SHARP computer**, we will begin investigating the exciting capabilities of your new computer.

Because the **computer** allows you the full range of calculating functions, plus the increased power of BASIC programming abilities (useful in more complex calculations), it is commonly referred to as a "smart" calculator. That, of course, makes you a "smart" user!

(Before using the **computer**, be sure that the batteries are correctly installed.)

Start Up

To turn on the **computer**, press **ON**. Display the mode indicator (**■**) on the label RUN by pressing the **MODE** key. For use as a calculator, the **computer** must be in the RUN mode. When the machine is ON the prompt (>) will appear on the display.

Shut Down

To turn off the **computer**, press **OFF**.

When you turn off the computer, you clear (erase) the display. However, the **computer** does remember all programs and reserved contents. All of these contents are still in effect when the **computer** is turned back on.

When the BEEP instruction (**PC-1248** only) or CLOAD command is executed, stop the execution by pressing **BRK** and press OFF.

Auto Off



In order to save battery wear, the **computer** automatically powers down when no keys have been pressed for about 11 minutes. (Note: The **computer** will not AUTO OFF while you are executing a program.)

To restart the computer after an AUTO OFF, press the **BRK ON** key. All settings will be exactly as they were when the AUTO OFF occurred.

Some Helpful Hints

Until you are used to your new **computer**, you are bound to make mistakes while entering data. Later we will discuss some simple ways to correct these mistakes. For now, if you get an Error Message, press CLEAR and retype the entry. If the computer "hangs up" — you cannot get it to respond at all — press the RESET button (See Chapter 2).

The PROMPT (>) tells you that the **computer** is awaiting input. As you enter data the prompt disappears and the CURSOR (_) moves to the right indicating the next available location in the display.

The right  and left  arrows move the cursor within a line.


ENTER informs the **computer** that you are finished entering data and signals the computer to perform the indicated operations. **YOU MUST PRESS ENTER AT THE END OF EACH LINE OF INPUT OR YOUR CALCULATIONS WILL NOT BE ACTED UPON BY THE COMPUTER.**

When performing numeric calculations input appears on the left of the screen; the results appear on the right of the display.

When using the **SHIFT** key in conjunction with another key (to access square root for example) press **SHIFT**, release the **SHIFT**, then press the other key. **SHIFT** is active for only one key at a time.

Do not use dollar signs or commas when entering calculations into the **computer**. These characters have special meaning in the BASIC programming language.

In this manual we use 0 to indicate zero, so that you can distinguish between the number (0) and the letter (O).

To help get you started entering data correctly, we will show each keystroke necessary to type in the example calculations. When **SHIFT** is used, we will indicate the desired character in the following keystroke. For example pressing **SHIFT** and **1** will produce the (character. These keystrokes are written **SHIFT** .

Be sure to enter CLEAR after each calculation (unless you are performing serial calculations). CLEAR erases the display and resets the error condition. It does not erase anything stored in the computer's memory.

Key operation

Now let's operate the keys. Set the **computer** to the RUN mode and press the following keys while watching the display:

(Example)

PRINT Z	USING X	GOSUB C	→ Z X C _
(1) 2	√ .	→ Z X C 1 2 . 3 _
CA CL			→ >
INPUT A	RUN =	4	+ 5 _
			↑ Cursor

If you press an alphabet or number key, the item denoted on the key will be entered. When you wish to enter the character or symbol denoted above each key, press **SHIFT** before operating the key.

(Example)

↓ Clears the display.

CA CL	SHIFT	PRINT Z	→ P R I N T _
SHIFT	W	SHIFT	1
SHIFT	.	SHIFT	√
			→ P R I N T " (√ _

The **SHIFT** key is used to enter the characters or symbols labeled in brown above each key that has two functions. If you repeatedly press the **SHIFT** key, the **SHIFT** symbol in the top right of the display will go on and off. The **SHIFT** symbol indicates that the **SHIFT** key is activated and the characters labeled in brown can be entered.

Simple Calculations

The **computer** performs calculations with ten-digit precision. Set the **computer** to the RUN mode. Now try these simple arithmetic examples. Remember to **CL**ear between calculations.

Using the Computer as a Calculator

Input

5 0 + 5 0 ENTER

1 0 0 - 5 0 ENTER

6 0 * 1 0 ENTER

3 0 0 / 5 ENTER

1 0 SHIFT ^ 2 ENTER

2 * SHIFT π ENTER

SHIFT $\sqrt{\quad}$ 6 4 ENTER

Display

100.

50.

600.

60.

100.

6.283185307

8.

Recalling Entries

Even after the **computer** has displayed the results of your calculation, you can re-display your last entry. To recall, use the left \leftarrow and right \rightarrow arrows.

The left arrow \leftarrow recalls the expression with the cursor positioned after the **last** character.

The right arrow \rightarrow recalls the expression with the cursor positioned "on top of" the **first** character.

Remember that the left and right arrows are also used to position the cursor along a line. The right and left arrows are very helpful in editing (or modifying) entries without having to retype the entire expression.

You will become familiar with the use of the right and left arrows in the following examples. Now, take the role of the manager and perform the calculations as we discuss them.

As the head of personnel in a large marketing division, you are responsible for planning the annual sales meeting. You expect 300 people to attend the three day conference. For part of this time, the sales force will meet in small groups. You believe that groups of six would be a good size. How many groups would this be?

Input

3 0 0 / 6 ENTER

Display

50.

On second thought you decide that groups containing an odd number of participants might be more effective. Recall your last entry using the \leftarrow arrow.

Input

\leftarrow

Display

300/6_

To calculate the new number of groups you must replace the six with an odd number. Five seems to make more sense than seven. Because you recalled using the \leftarrow arrow, the cursor is positioned at the end of the display. Use the \leftarrow to move the cursor one space to the left.

Input

\leftarrow

Display

300/6

Notice that after you move the cursor it becomes a flashing block \blacksquare . Whenever you position the cursor "on top of" an existing character, it will be displayed as the flashing cursor.

Type in a 5 to replace the 6. One caution in replacing characters — once you type a new character over an existing character, the original is gone forever! You cannot recall an expression that has been typed over.

Input

5

ENTER

Display

300/5_

60.

Sixty seems like a reasonable number of groups, so you decide that each small group will consist of five participants.

Recall is also useful to verify your last entry, especially when your results do not seem to make sense. For instance, suppose you had performed this calculation:

Input

3 0 / 5 ENTER

Display

6.

Using the Computer as a Calculator

Even a tired, overworked manager like you realizes that 6 does not seem to be a reasonable result when you are dealing with hundreds of people! Recall your entry using the \rightarrow .

Input

\rightarrow

Display

30/5

Because you recalled using the \rightarrow , the flashing cursor is now positioned over the first character in the display. To correct this entry you wish to insert another zero. Using the \rightarrow , move the cursor until it is positioned over the zero. When making an INSert, you position the flashing cursor over the character before which you wish to make the insertion.

Input

\rightarrow

Display

30/5

Use the INSert key to make space for the needed character.

Input

SHIFT INS

Display

30/5

Pressing INSert moves all the characters one space to the right, and inserts a bracketed open slot. The flashing cursor is now positioned over this open space, indicating the location of the next typed input. Type in your zero. Once the entry is corrected, display your new result.

Input

0

ENTER

Display

300/5

60.

On the other hand, suppose that you had entered this calculation:

Input

3 0 0 / 5 ENTER

Display

600.

The results seem much too large. If you only have 300 people attending the meeting, how could you have 600 "small groups"? Recall your entry using the $\left[\right] >$.

Input

$\left[\right] >$

Display

3 0 0 0 / 5

The flashing cursor is now positioned over the first character in the display. To correct this entry eliminate one of the zeros. Using the $\left[\right] >$ move the cursor to the first zero (or any zero). When deleting a character, you position the cursor "on top of" the character to be deleted.

Input

$\left[\right] >$

Display

3 0 0 0 / 5

Now use the DELEte key to get rid of one of the zeros.

Input

$\left[\right] \text{SHIFT} \left[\right] \text{DEL}$

Display

3 0 0 / 5

Pressing DELEte causes all the characters to shift one space to the left. It deletes the character it is "on top of" and the space the character occupies. The flashing cursor stays in the same position indicating the next location for input. Since you have no other changes to make, complete the calculation.

Input

$\left[\right] \text{ENTER}$

Display

6 0 .

(Note: Pressing the SPaCe key, when it is positioned over a character, replaces the character leaving a blank space. DELEte eliminates the character and the space it occupied.)

Errors

Recalling your last entry is essential when you get the dreaded ERROR message. Let us imagine that, unintentionally, you typed this entry into the computer:

Input

3 0 0 / / 5 ENTER

Display

ERROR 1

Naturally you are surprised when this message appears! ERROR 1 is simply the computer's way of saying, "I don't know what you want me to do here". To find out what the problem is, recall your entry using either the < or > key.

Input

< (or >)

Display

3 0 0 / / 5

Whether you use the < or > key, the flashing cursor indicates the point at which the computer got confused. And no wonder, you have too many operators! To correct this error use the DELete key.

Input

SHIFT DEL ENTER

Display

60.

If, upon recalling your entry after an ERROR 1, you find that you have omitted a character, use the INSert sequence to correct it.

When using the computer as a calculator, the majority of the errors you encounter will be ERROR 1 (an error in syntax). For a complete listing of error messages, see APPENDIX A.

Serial Calculations

The computer allows you to use the results of one calculation as part of the following calculation.

Part of your responsibility in planning this conference is to draw up a detailed budget for approval. You know that your total budget is \$150.00 for each attendant. Figure your total budget:

Input

3 0 0 * 1 5 0 ENTER

Display

45000.

Of this amount you plan to use 15% for the final night's awards presentation. When performing serial calculations it is not necessary to retype your previous results, but DO NOT CLear between entries. What is the awards budget?

Input

* . 1 5

Display

45000. * . 15 _

Notice that as you type in the second calculation (* . 15), the computer automatically displays the result of your first calculation at the left of the screen and includes it in the new calculation. In serial calculations the entry must begin with an operator. As always, you end the entry with **ENTER**:

NOTE: The $\frac{\%}{\square}$ key cannot be used in the calculation. The $\frac{\%}{\square}$ key should be used as a character only.

Example: 45000 * 15 **SHIFT** $\frac{\%}{\square}$ **ENTER** → ERROR 1

Input

ENTER

Display

6750.

Continue allocating your budget. The hotel will cater your dinner for \$4000:

Input

- 4 0 0 0

Display

6750. -4000 _

ENTER

2750.

Decorations will be \$1225:

Input

- 1 2 2 5 **ENTER**

Display

1525.

Finally, you must allocate \$2200 for the speaker and entertainment:

Input

- 2 2 0 0 **ENTER**

Display

-675.

Obviously, you will have to change either your plans or your allocation of resources!

Negative Numbers

Since you want the awards dinner to be really special, you decide to stay with the planned agenda and spend the additional money. However, you wonder what percentage of the total budget will be used up by this item. First, change the sign of the remaining sum:

Input

***** **-** **1**

ENTER

Display

675.*-1

675.

Now you add this result to your original presentation budget:

Input

+ **6** **7** **5** **0** **ENTER**

Display

7425.

Dividing by 45000 gives you the percentage of the total budget this new figure represents:

Input

/ **4** **5** **0** **0** **0** **ENTER**

Display

0.165

Fine, you decide to allocate 16.5% to the awards presentation.

Compound Calculations and Parentheses

In performing the above calculations, you could have combined several of these operations into one step. For instance, you might have typed both these operations on one line:

$$675 + 6750 / 45000$$

Compound calculations, however, must be entered very carefully:

$675 + 6750 / 45000$ might be interpreted as

$$\frac{675 + 6750}{45000}$$

or

$$675 + \frac{6750}{45000}$$

When performing compound calculations, the **computer** has specific rules of expression evaluation and operator priority (see APPENDIX D). Be sure you get the calculation you want by using parentheses to clarify your expressions:

$$(675+6750) / 45000 \quad \text{or} \quad 675+(6750 / 45000)$$

To illustrate the difference that the placement of parentheses can make, try these two examples:

Input

SHIFT (6 7 5 + 6
7 5 0 SHIFT) / 4
5 0 0 0 ENTER

6 7 5 + SHIFT (6
7 5 0 / 4 5 0 0
0 SHIFT) ENTER

Display

0.165

675.15

Using Variables in Calculations

The **computer** can store up to 26 simple numeric **variables** under the alphabetic characters A to Z. If you are unfamiliar with the concept of variables, they are more fully explained in Chapter 4. You designate variables with an Assignment Statement:

$$\begin{aligned} A &= 5 \\ B &= -2 \end{aligned}$$

You can also assign the value of one variable (right) to another variable (left):

$$\begin{aligned} C &= A + 3 \\ D &= E \end{aligned}$$

A variable may be used in place of a number in any calculation.

Now that you have planned your awards dinner, you need to complete arrangements for your conference. You wish to allocate the rest of your budget by percentages also. First you must find out how much money is still available. Assign a variable (R) to be the amount left from the total:

Using the Computer as a Calculator

Input	Display
$R = 45000 - 7425$	$R = 45000 - 7425$
$ENTER$	$37575.$

As you press $ENTER$ the computer performs the calculation and displays the new value of R. You can display the current value of any variable by entering the alphabetic character it is stored under:

Input	Display
R $ENTER$	$37575.$

You can then perform calculations using your variable. The value of (R) will not change until you assign it a new value.

You wish to allocate 60% of the remaining money to room rental:

Input	Display
$R * .60$	$R * .60$
$ENTER$	$22545.$

Similarly, you want to allocate 25% of your remaining budget to conduct management training seminars:

Input	Display
$R * .25$ $ENTER$	9393.75

Variables will retain their assigned values even if the machine is turned OFF or undergoes an AUTO OFF. Variables are lost only when:

- * You assign a new value to the same variable.
You type in NEW $ENTER$ or NEW 0 $ENTER$.
- * You type in CLEAR $ENTER$ (not the CLEAr key).
- * The batteries are changed.

There are certain limitations on the assignment of variables, and certain programming procedures which cause them to be changed. See Chapter 4 for a discussion of assignment. See Chapter 5 for a discussion of the use of variables in programming.

Chained Calculations

In addition to combining several operators in one calculation, the **computer** also allows you to perform several calculations one after the other — without having to press **ENTER** before moving on. You must separate the equations with commas. Only the result of the **final** calculation is displayed. (Remember too, that the maximum line length accepted by the computer is 80 characters including **ENTER**.)

You wonder how much money would have been available for rooms if you had kept to your original allocation of 15% for the awards dinner:

Input

R = . 8 5 * 4 5
 , R * . 6
 =

Display

. 8 5 * 4 5 0 0 0 , R * . 6 0 —

Although the computer performs all the calculations in the chain, it displays only the final result:

Input

ENTER

Display

2 2 9 5 0 .

To find the value of R used in this calculation, enter R:

Input

R ENTER

Display

3 8 2 5 0 .

Now It's Your Turn

This concludes our discussion of using the **computer** as a calculator. Undoubtedly, as you become more familiar with your **computer's** capabilities and special features, you will find many new and useful applications for this "smart" calculator.

But calculating is only one of the many potential uses of the **computer**. In the next chapter we will examine the concepts and terms of the BASIC language, as it is used by the **computer**. Then you can begin to create your own, unique, problem-solving programs.

CHAPTER 4 CONCEPTS AND TERMS OF BASIC

In this chapter we will examine some concepts and terms of the BASIC language. Because the **computer** uses many features of BASIC when used as a calculator, some of these concepts are also useful for advanced calculator functions.

Numeric Constants

In Chapter 3 you entered simple numbers for use in calculations, without worrying about the different ways that numbers can be represented, or the range of numbers that the **SHARP computer** can process. Some of you, however, may need or desire to know more about how the **computer** uses numbers.

The **SHARP computer** recognizes three different ways to represent numbers:

- * Decimals.
- * Exponential or scientific notation.
- * Hexadecimal numbers.

Decimal numbers are familiar to most of you. Scientific notation and hexadecimal numbers may require some explanation.

Scientific Notation

People who need to deal with very large and very small numbers often use a special format called exponential or **scientific notation**. In scientific notation a number is broken down into two parts.

The first part consists of a regular decimal number between 1 and 10. The second part represents how large or small the number is in powers of 10.

As you know, the first number to the left of the decimal point in a regular decimal number shows the number of 1's, the second shows the number of 10's, the third the number of 100's, and the fourth the number of 1000's. These are simply increasing powers of 10:

$$10^0 = 1, 10^1 = 10, 10^2 = 100, 10^3 = 1000, \text{ etc.}$$

Scientific notation breaks down a decimal number into two parts: the first part shows what the numbers are, the second part shows how far a number is to the left, or right, of the decimal point. For example:

Hexadecimal Numbers

The decimal system is only one of many different systems to represent numbers. Another which has become quite important when using computers is the hexadecimal system. The hexadecimal system is based on 16 instead of 10. To write hexadecimal numbers you use the familiar 0 ~ 9 and 6 more "digits": A, B, C, D, E, and F. These correspond to 10, 11, 12, 13, 14, and 15. When you want the **computer** to treat a number as hexadecimal put an ampersand '&' character in front of the numeral:

```
&A    = 10
&10   = 16
&100  = 256
&FFFF = 65535
```

Those with some computer background may notice that the last number (65535) is the same as the largest number in the special group of limits discussed in the last paragraph. Hexadecimal notation is never required in using the **computer**, but there are special applications where it is convenient.

String Constants

In addition to numbers, there many ways that the **SHARP computer** uses letters and special symbols. These letters, numbers, and special symbols are called characters. These characters are available on the **computer**:

```
1 2 3 4 5 6 7 8 9 0
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
! " # $ % & ( ) * + , - . / : ; < = > ? @ √ π ^ E
```

In BASIC, a collection of characters is called a **string**. In order for the **computer** to tell the difference between a string and other parts of a program, such as verbs or variable names, you must enclose the characters of the string in quotation marks ("").

The following are examples of string constants:

```
"HELLO"
"GOODBYE"
"SHARP"
```

The following are **not** valid string constants:

```
"COMPUTER"      No ending quote
"ISN'T"         Quote can't be used within a string
```

Variables

In addition to constants, whose values do not change during a program, BASIC has **variables**, whose values can change. Variables are names used to designate locations where information is stored. These variables are like the letters used in algebraic equations. Just as there are numeric and string constants, there are numeric and string variables.

Simple Numeric Variables

You have already used **simple numeric variables** when working with the **computer** as a calculator in Chapter 3. Simple numeric variables are used to store a single number and are designated by a single letter (A – Z):

```
A = 5
C = 12.345
```

Simple numeric variables may take the same range of values as numeric constants.

Simple String Variables

String variables are used to hold strings (a collection of characters). They are named by a single letter followed by a dollar sign:

```
A$ = "ABCD"
C$ = "HELLO!"
```

NOTE: Strings must be put between
the quotation marks.

A string variable may be from 0 to 7 characters long. If you try to store more than 7 characters in a string variable, only the first 7 will be saved. When a string variable is empty, or its length is zero, it is called NUL or the NUL string.

Numeric Array Variables

For some purposes it is useful to deal with numbers as an organized group, such as a list of scores or a tax table. In BASIC these groups are called **arrays**. An array can be either **one-dimensional**, like a list, or **two-dimensional**, like a table. Array names are designated in the same manner as simple variable names, except that they are followed by parentheses. The elements of an array are referred to by a number inside the parentheses; when the array is two dimensional there must be two numbers separated by a comma:

```
A(5)    The fifth element of a one-dimensional array A
B(3,2)  The element in the third row and second column of a two dimensional B array
```

Concepts and Terms of BASIC

Arrays are created using the DIM verb or command. To create an array you give its name and its size:

`DIM X(5)` creates an array with six entries, numbered 0 through 5.
`DIM Y(32)` creates an array with 33 entries, numbered 0 through 32.

Note that `DIM X(5)` actually creates an array with six entries:

`X(0) X(1) X(2) X(3) X(4) X(5)`

Similarly, `DIM Y(2, 2)` creates an extra 0 row and a extra 0 column:

`Y(0, 0) Y(0, 1) Y(0, 2)`
`Y(1, 0) Y(1, 1) Y(1, 2)`
`Y(2, 0) Y(2, 1) Y(2, 2)`

This extra element, or row and column, is often used by programmers to hold partial products during computations. For example, you might total the elements of the X array by summing them into `X(0)`.

The form and use of the DIM verb is covered in detail in Chapter 8.

Note: The A array **does not** have the extra 0 element and does not need to be DIMensioned (see section below on Preallocated Variables).

String Array Variables

String array variables have the same relationship to numeric array variables as simple string variables have to simple numeric variables, — their names are the same except for the addition of a dollar sign:

`CS(5)` The fifth string element in the array CS

With string arrays the length of each string will be 16 characters unless you specifically choose a different length in the DIM statement:

`DIM X$(12) * 8` DIMensions a string array with 13 elements, each a string 8 characters long.

Chapter 8 details the use of the DIM statement.

Preallocated Variables

Some of the variables which you will use most frequently have already been allocated space in the computer's memory. Twenty-six locations are reserved for numeric variables A — Z, string variables A\$ — Z\$, numeric array A(26), OR string array A\$(26). The locations are assigned as follows:

<u>Loc.</u>	<u>Num. Var.</u>	<u>Str. Var.</u>	<u>Num. Arr. Var.</u>	<u>Str. Arr. Var.</u>
1	A	A\$	A(1)	A\$(1)
2	B	B\$	A(2)	A\$(2)
3	C	C\$	A(3)	A\$(3)
4	D	D\$	A(4)	A\$(4)
⋮	⋮	⋮	⋮	⋮
23	W	W\$	A(23)	A\$(23)
24	X	X\$	A(24)	A\$(24)
25	Y	Y\$	A(25)	A\$(25)
26	Z	Z\$	A(26)	A\$(26)

NOTE: There are only twenty-six locations and you must be careful not to use the same location in two different ways.

If you use location 24 to store a numeric value in X and then try to print X\$, you will get an ERROR 9. Similarly, if you store a number in A(24) and then store another number in X you will over-write the first number, but you will not get an error message.

The A() and A\$() arrays are different from all other arrays – they don't have a zero element. It is possible to use DIM to make A() or A\$() larger than 26, but if you do, the first 26 elements will use the reserved locations while the elements from 26 on will be stored in a different part of the memory. The only way that you will notice this, however, is that these 26 special locations are not cleared when you RUN a program. All other array variables are cleared with each new RUN. By using good programming practice and always initializing your variables to the desired value, you will avoid any possible confusion.

If DIM is used to allocate the A() or A\$() arrays larger than 26 elements, there are certain special conditions in which an error can cause the part of the array from A(27) or A\$(27) on to become inaccessible. If this occurs, it is necessary to re-dimension the array.

Expressions

An **expression** is some combination of variables, constants, and operators which can be evaluated to a single value. The calculations which you entered in Chapter 3 were examples of expressions. Expressions are an intrinsic part of BASIC programs. For example, an expression might be a formula that computes an answer to some equation, a test to determine the relationship between two quantities, or a means to format a set of strings.

Numeric Operators

The **computer** has five **numeric operators**. These are the arithmetic operators which you used when exploring the use of the **computer** as a calculator in Chapter 3:

- + Addition
- Subtraction
- * Multiplication
- / Division
- ^ Power

A **numeric expression** is constructed in the same way that you entered compound calculator operations. Numeric expressions can contain any meaningful combination of numeric constants, numeric variables, and these numeric operators:

$$(A * B) ^ 2$$
$$A(2, 3) + A(3, 4) + 5.0 - C$$
$$(A/B) * (C+D)$$

In certain circumstances the multiplication operator can be implied:

- 2A is the same as 2 * A
- 7C is the same as 7 * C
- ABC is the same as A * B * C

As you can see from the last example, there is a possibility that implied multiplication could be confused with other BASIC words, so don't use this form unless the context is very clear.

String Expressions

String expressions are similar to numeric expressions except that there is only one string operator — concatenation (+). This is the same symbol used for plus. When used with a pair of strings, the + attaches the second string to the end of the first string and makes one longer string. You should take care in making more complex string concatenations and other string operations because the work space used by the **computer** for string calculations is limited to only 79 characters.

NOTE: String quantities and numeric quantities cannot be combined in the same expression unless one uses one of the functions which convert a string value into a numeric value or vice versa:

"15" + 10 is illegal
 "15" + "10" is "1510", not "25"

Relational Expressions

A **relational expression** compares two expressions and determines whether the stated relationship is True or False. The relational operators are:

> Greater Than
 >= Greater Than or Equal To
 = Equals
 <> Not Equal To
 <= Less Than or Equal To
 < Less Than

The following are valid relational expressions:

A < B
 C(1, 2) >= 5
 D(3) <> 8

If A was equal to 10, B equal to 12, C(1, 2) equal to 6, and D(3) equal to 9, all of these relational expressions would be True.

Character strings can also be compared in relational expressions. The two strings are compared character by character according to their ASCII value starting at the first character (see Appendix B for ASCII values). If one string is shorter than the other, a \emptyset or NUL will be used for any missing positions. All of the following relational expressions are True:

"ABCDEF" = "ABCDEF"
 "ABCDEF" <> "ABCDE"
 "ABCDEF" > "ABCDE"

Relational expressions evaluate to either True or False. The **computer** represents True by a 1; False is represented by a \emptyset . In any logical test an expression which evaluates to 1 or more will be regarded as True while one which evaluates to \emptyset or less will be considered False. Good programming practice, however, dictates the use of an explicit relational expression instead of relying on this coincidence.

Logical Expressions

Logical expressions are relational expressions which use the operators AND, OR, and NOT. AND and OR are used to connect two relational expressions; the value of the combined expression is shown in the following tables:

A AND B

		Value of A	
		True	False
Value of B	True	True	False
	False	False	False

A OR B

		Value of A	
		True	False
Value of B	True	True	True
	False	True	False

(Note: Value of A and B must be 0 or 1)

- Decimal numbers can be expressed in the binary notation of 16 bits as follows:

DECIMAL NOTATION	BINARY NOTATION OF 16-BIT
32767	0111111111111111
3	0000000000000011
2	0000000000000010
1	0000000000000001
0	0000000000000000
-1	1111111111111111
-2	1111111111111110
-3	1111111111111101
-32768	1000000000000000

The negative (NOT) of a binary number 0000000000000001 is taken as follows:

NOT 0000000000000001
 (Negative) → 1111111111111110

Thus, 1 is inverted to 0, and 0 to 1 for each bit, which is called "to take negative (NOT)."

Then, the following will result when 1 and NOT 1 are added together:

$$\begin{array}{r}
 0000000000000001 \quad (1) \\
 +) \quad 1111111111111110 \quad (\text{NOT } 1) \\
 \hline
 1111111111111111 \quad (-1)
 \end{array}$$

Thus, all bits become 1. According to the above number list, the bits become -1 in decimal notation, that is $1 + \text{NOT } 1 = -1$.

The relationship between numerical value X and its negative (NOT X) is:

$$X + \text{NOT } X = -1$$

This results in an equation of NOT $X = -X - 1$

$$\text{i.e. NOT } X = -(X + 1)$$

From the equation the following are found to result.

$$\text{NOT } 0 = -1$$

$$\text{NOT } -1 = 0$$

$$\text{NOT } -2 = 1$$

More than two relational expressions can be combined with these operators. You should take care to use parentheses to make the intended comparison clear.

$$(A < 9) \text{ AND } (B > 5)$$

$$(A >= 10) \text{ AND NOT } (A > 20)$$

$$(C = 5) \text{ OR } (C = 6) \text{ OR } (C = 7)$$

The **computer** implements logical operators as "bitwise" logical functions on 16 bit quantities. (See note on relational expressions and True and False). In normal operations this is not significant because the simple 1 and 0 (True and False) which result from a relational expression uses only a single bit. If you apply a logical operator to a value other than 0 or 1, it works on each bit independently. For example if A is 17, and B is 22, (A OR B) is 23:

$$17 \text{ in binary notation is } 10001$$

$$22 \text{ in binary notation is } 10110$$

$$17 \text{ OR } 22 \text{ is } 10111 \quad (1 \text{ if } 1 \text{ in either number, otherwise } 0)$$

$$10111 \text{ is } 23 \text{ in decimal.}$$

If you are a proficient programmer, there are certain applications where this type of operation can be very useful. Beginning programmers should stick to clear, simple True or False relational expressions.

Parentheses and Operator Precedence

When evaluating complex expressions the computer follows a predefined set of priorities which determine the sequence in which operators are evaluated. This can be quite significant:

$5 + 2 * 3$ could be

$$5 + 2 = 7$$

$$7 * 3 = 21$$

or

$$2 * 3 = 6$$

$$6 + 5 = 11$$

The exact rules of "operator precedence" are given in Appendix D.

To avoid having to remember all these rules and to make your program clearer, always use parentheses to determine the sequence of evaluation. The above example is clarified by writing either:

$$(5 + 2) * 3$$

or

$$5 + (2 * 3)$$

Calculator Mode

In general, any of the above expressions can be used in the calculator mode as well as when programming a BASIC statement. In the RUN mode an expression is computed and displayed immediately. For example:

Input

$(5 > 3) \text{ AND } (2 < 6)$

Display

1.

The 1 means that the expression is True.

Functions

Functions are special components of the BASIC language which take one value and transform it into another value. Functions act like variables whose value is determined by the value of other variables or expressions. ABS is a function which produces the absolute value of its argument:

ABS (-5) is 5

ABS (6) is 6

LOG is a function which computes the log to the base 10 of its argument.

LOG (100) is 2
 LOG (1000) is 3

A function can be used any place that a variable can be used. Many functions do not require the use of parentheses:

LOG 100 is the same as LOG (100)

You must use parentheses for functions which have more than one argument. Using parentheses always makes programs clearer.

See Chapter 8 for a complete list of functions available on the computer.

CHAPTER 5

PROGRAMMING THE COMPUTER

In the previous chapter we examined some of the concepts and terms of the BASIC programming language. In this chapter you will use these elements to create programs on the **computer**. Let us reiterate however, this is **not** a manual on how to program in BASIC. What this chapter will do is familiarize you with the use of BASIC on your **computer**.

Programs

A **program** consists of a set of instructions to the computer. Remember the **computer** is only a machine. It will perform the exact operations that you specify. You, the programmer, are responsible for issuing the correct instructions.

BASIC Statements

The **computer** interprets instructions according to a predetermined format. This format is called a **statement**. You always enter BASIC statements in the same pattern. Statements must start with a line number:

```
10: INPUT A
20: PRINT A * A
30: END
```

Line Numbers

Each line of a program must have a unique line number — any integer between 1 and 999. Line numbers are the reference for the computer. They tell the **computer** the order in which to perform the program. You need not enter lines in sequential order (although if you are a beginning programmer, it is probably less confusing for you to do so). The computer always begins execution with the lowest line number and moves sequentially through the lines of a program in ascending order.

When programming it is wise to allow increments in your line numbering (10, 20, 30, . . . 10, 30, 50, etc). This enables you to insert additional lines if necessary. **CAUTION: Do not use the same line numbers in different programs.** If you use the same line number, the oldest line with that number is deleted when you enter the new line.

BASIC Verbs

All BASIC statements must contain **verbs**. Verbs tell the computer what action to perform. A verb is always contained within a program, and as such is not acted upon immediately.

```

10: INPUT A
20: PRINT A * A
30: END

```

Some statements require or allow an **operand**:

```

10: INPUT A
20: PRINT A * A
30: END

```

Operands provide information to the computer telling it what data the verb will act upon. Some verbs require operands, with other verbs they are optional. Certain verbs do not allow operands. (See Chapter 8 for a complete listing of BASIC verbs and their use on the **computer**).

BASIC Commands

Commands are instructions to the computer which are entered outside of a program. Commands instruct the computer to perform some action with your program or to set modes which effect how your programs are executed.

Unlike verbs, commands have immediate effects — as soon as you complete entering the command (by pressing the **ENTER** key), the command will be executed. Commands **are not** preceded by a line number:

```

RUN
NEW
RADIAN

```

Some verbs may also be used as commands. (See Chapter 8 for a complete listing of BASIC commands and their use on the **computer**).

Modes

You will remember that when using the **computer** as a calculator, it is set in the RUN mode.

The RUN mode is also used to execute the programs you create.

The PROgram mode is used to enter and edit your programs.

Beginning to Program on the Computer

After all your practice in using the **computer** as a calculator you are probably quite at home with the keyboard. From now on, when we show an entry, we will **not** show every keystroke. Remember to use **SHIFT** to access characters above the keys and **END EVERY LINE BY PRESSING THE ENTER KEY**.

Now you are ready to program! Set the computer to the **PROgram** mode and enter this command:

<u>Input</u>	<u>Display</u>
NEW	>

The **NEW** command clears the **computer's** memory of all existing programs and data. The prompt appears after you press **ENTER**, indicating that the computer is awaiting input.

Example 1 — Entering and Running a Program

Make sure the **computer** is in the **PRO** mode and enter the following program:

<u>Input</u>	<u>Display</u>
10 PRINT "HELLO"	10: PRINT "HELLO"

Notice that when you push **ENTER** the **computer** displays your input, automatically inserting a colon (:) between the line number and the verb. Verify that the statement is in the correct format.

Now change the mode to **RUN** by pressing the **MODE** key:

<u>Input</u>	<u>Display</u>
RUN	HELLO

Since this is the only line of the program, the computer will stop executing at this point. Press **ENTER** to get out of the program and reenter **RUN** if you wish to execute the program again.

Example 2 – Editing a Program

Suppose you wanted to change the message that your program was displaying, that is you wanted to edit your program. With a single line program you could just retype the entry, but as you develop more complex programs editing becomes a very important component of your programming. Let's edit the program you have just written.

Are you still in the RUN mode? If so return to the PROgram mode.

You need to recall your program in order to edit it. Use the Up Arrow (^) to recall your program. If your program was completely executed, the (^) will recall the last line of the program. If there was an error in the program, or if you used the BREAK (BRK) key to stop execution, the (^) will recall the line in which the error or BREAK occurred. To make changes in your program use the (^) to move up in your program (recall the previous line) and the (v) to move down in your program (display the next line). If held down the (^) and the (v) will scroll vertically, that is they will display each line moving up or down in your program.

You will remember that to move the cursor within a line you use the > (right arrow) and < (left arrow). Using the > position the cursor over the first character you wish to change:

Input

^

Display

10: PRINT "HELLO"

<<<<<

10 PRINT "HELLO"

Notice that the cursor is now in the flashing block form indicating that it is "on top of" an existing character. Type in:

Input

GOOD"!_

Display

10 "GOOD"!_

Don't forget to press **ENTER** at the end of the line. Change to the RUN mode.

Input

RUN

Display

ERROR 1 IN 10^E

This is a new kind of error message. Not only is the error type identified (our old friend the syntax error) but the line number in which the error occurs is also indicated.

Change back to the PROgram mode. You must be in the PROgram mode to make changes in a program. Using \uparrow , recall the last line of your program.

Input

Display

\uparrow

10: PRINT "GOOD" !

The flashing cursor is positioned over the problem area. In Chapter 4 you learned that when entering string constants in BASIC all characters must be contained within quotation marks. Use the DElete key to eliminate the "!"

Input

Display

DEL

10 PRINT "GOOD" _

Now let's put the ! in the correct location. When editing programs, DElete and INsert are used in exactly the same way as they are in editing calculations (See Chapter 3). Using the \leftarrow position the cursor on top of the character which will be the first character following the insertion.

Input

Display

\leftarrow

10 PRINT "GOOD"

Press the INsert key. A \square will indicate the spot where the new data will be entered:

Input

Display

INS

10 PRINT "GOOD" \square

Type in the !. The display looks like this:

Input

Display

!

10 PRINT "GOOD!"

Remember to press **ENTER** so the correction will be entered into the program.

NOTE: If you wish to DELeTe an entire line from your program just type in the line number and the original line will be eliminated.

Example 3 — Using Variables in Programming

If you are unfamiliar with the use of numeric and string variables in BASIC, reread these sections in Chapter 4.

Using variables in programming allows much more sophisticated use of the **computer's** computing abilities.

Remember, you assign simple numeric variables using any letter from A to Z:

```
A = 5
```

To assign string variables you also use a letter, followed by a dollar sign. **Do not use the same letter in designating a numeric and a string variable.** You cannot designate A and A\$ in the same program.

Remember that simple string variables cannot exceed 7 characters in length:

```
A$ = "TOTAL"
```

The values assigned to a variable can change during the execution of a program, taking on the values typed in or computed during the program. One way to assign a variable is to use the INPUT verb. In the following program the value of A\$ will change in response to the data typed in answering the inquiry "WORD?". Enter this program:

```
10 INPUT "WORD?"; A$
20 B = LEN (A$)
30 PRINT "WORD_IS_"; B; " _LTRS"
40 END
```

↑ _____ means space

Before you RUN the program notice several new features. Line 30 of this program exceeds the 16 character maximum of the **computer's** display. When a line is longer than 16 characters (up to the 79 character maximum), **computer** moves the characters to the left as the 16 character maximum is exceeded. This does not destroy the previous input. This move to the left is referred to as horizontal scrolling.

The second new element in this program is the use of the END statement to signal the completion of a program. END tells the computer that the program is completed. It is always good programming practice to use an END statement.

As your programs get more complex you may wish to review them before you begin execution. To look at your program, use the LIST command. LIST, which can only be used in the PROgram mode, displays programs beginning with the lowest line number.



Try listing this program:

Input

LIST

Display

10: INPUT "WORD?"

Use the  and  arrows to move through your program until you have reviewed the entire program. To review a line which contains more than 16 characters move the cursor to the extreme right of the display and the additional characters will appear on the screen. After checking your program, run it:

Input

RUN

HELP

ENTER

Display

WORD? _

WORD IS 4. LTRS

>

This is the end of your program. Of course you may begin it again by entering RUN. However, this program would be a bit more entertaining if it presented more than one opportunity for input. We will now modify the program so it will keep running without entering RUN after each answer.

Return to the PRO mode and use the up or down arrows (or LIST) to reach line 40.

You may type 40 to Delete the entire line or use the > to position the cursor over the E in End. Change line 40 so that it reads:

40: GOTO 10

Now RUN the modified program.

The GOTO statement causes the program to loop (keep repeating the same operation). Since you put no limit on the loop it will keep going forever (an "infinite" loop). To stop this program hit the BREAK (**BRK**) key.

When you have stopped a program using the **BRK** key, you can restart it using the **CONT** command. **CONT** stands for **CONTInue**. With the **CONT** command the program will restart on the line which was being executed when the **BRK** key was pressed.

Example 4 — More Complex Programming

The following program computes N Factorial (N!). The program begins with 1 and computes N! up to the limit which you enter. Enter this program.

```
100 F=1: WAIT 128
```

```
110 INPUT "LIMIT? "; L
```

```
120 FOR N=1 TO L
```

```
130 F=F*N
```

```
140 PRINT N, F
```

```
150 NEXT N
```

```
160 END
```

Several new features are contained in this program. The **WAIT** verb in line 100 controls the length of time that displays are held before the program continues. The numbers and their factorials are displayed as they are computed. The time they appear on the display is set by the **WAIT** statement to approximately 2 seconds, instead of waiting for you to press **ENTER**.

Also in line 100, notice that there are two statements on the same line separated by a colon (:). You may put as many statements as you wish on one line, separating each by a colon, up to the 80 character maximum including **ENTER**. Multiple statement lines can make a program hard to read and modify, however, so it is good programming practice to use them only where the statements are very simple or there is some special reason to want the statements on one line.

Also in this program we have used the **FOR** verb in line 120 and the **NEXT** verb in line 150 to create a loop. In Example 3 you created an "infinite" loop which kept repeating the statements inside the loop until you pressed the **BRK** key. With this **FOR/NEXT** loop the computer adds 1 to N each time execution reaches the **NEXT** verb. It then tests to see if N is larger than the limit L. If N is less than or equal to L, execution returns to the top of the loop and the statements are executed again. If N is greater than L, execution continues with line 160 and the program stops.

Programming the Computer

You may use any numeric variable in a FOR/NEXT loop. You also do not have to start counting at 1 and you can add any amount at each step. See Chapter 8 for details.

We have labelled this program with line numbers starting with 100. Labelling programs with different line numbers allows you to have several programs in memory at one time. To RUN this program instead of the one at line 10 enter:

```
RUN 100
```

In addition to executing different programs by giving their starting line number, you can give programs a letter name and start them with the DEF key (see Chapter 6).

You will notice that while the program is running, the BUSY indicator is lit at those times that there is nothing on the display. RUN the program a few more times and try setting N at several different values.

Storing Programs in the Memory

Programs remain in memory when the computer is turned off or it undergoes an AUTO OFF. Even if you use the **BRK**, **CLear** or **CA** keys, the programs will remain.

Programs are lost from memory when you perform the following actions:

- * You enter **NEW** or **NEW 0** before beginning programming.
- * You create a new program using the **SAME LINE NUMBERS** as a program already in memory.
- * You change the batteries.

This brief introduction to programming on the **computer** should serve to illustrate the exciting programming possibilities of your new computer.

The following tables show the number of bytes used to define each variable and the number used by each program statement.

Variable	Variable name	Data
Numeric array variable	6 bytes	8 bytes
String array variable	6 bytes	Specified number of bytes*

* For example, if DIM Z\$(2, 3) * 10 is specified, 12 variables, each capable of storing 10 characters, are reserved. This requires 6 bytes (variable name) + 10 bytes (number of characters) x 12 = 126 bytes.

Element	Line number	Statement & function	Others
Number of bytes used	2 bytes	1 byte	1 byte

Remaining Number of Bytes and Number of Usable Variables

The number of remaining bytes in the program/data area can be determined by operating:

MEM

To determine the number of numeric variables which can be reserved by the DIM statement use the following formula:

$$(MEM - 6) / 8 \quad \text{ENTER}$$

↑ When calculating the number of string variables, replace this "8" with the necessary number of characters.

CHAPTER 6 SHORTCUTS

The **computer** includes several features which make programming more convenient by reducing the number of keystrokes required to enter repetitive material.

One such feature is in the availability of abbreviations for verbs and commands (See Chapter 8)

This chapter discusses the additional feature which can eliminate unnecessary typing — the DEF key.

The DEF Key and Labelled Programs

Often you will want to store several different programs in the **computer's** memory at one time. (Remember that each must have unique line numbers). Normally, to start a program with a RUN or GOTO command, you need to remember the beginning line number of each program (see Chapter 8). But, there is an easier way! You can label each program with a letter and execute the program using only two keystrokes. This is how to label a program and execute it using DEF:

Note: Put a label on the first line of each program that you want to reference. The label consists of a single character in quotes, followed by a colon:

```
10: "A": PRINT "FIRST"
20: END
80: "B": PRINT "SECOND"
90: END
```

Any one of the following characters can be used: A, S, D, F, G, H, J, K, L, =, Z, X, C, V, B, N, M, and SPC. Notice that these are the keys in the last two rows of the alphabetic portion of the keyboard.

Note: To execute the program, instead of typing RUN 80 or GOTO 10, you need only press the **DEF** key and then the letter used as a label. In the above example, pressing **DEF** and then 'B' would cause 'SECOND' to appear on the display.

When DEF is used to execute a program, variables and mode settings are affected in the same way as when GOTO is used. See Chapter 8 for details.

CHAPTER 7

USING THE OPTIONS

The following optional peripheral equipment can be used with the computer.

CE-125	Printer/microcassette recorder
CE-123P	Printer/cassette interface
CE-126P	Printer/cassette interface
CE-152	Cassette recorder (CE-123P, CE-126P or CE-124 is required)
CE-124	Cassette interface (CE-152 can be used)

Note: When using the CE-126P optional printer, be aware that the character code 39 (&27) for the **computer** (displayed characters) and for the printer (printer characters) are different characters.

Example: PRO mode
 10 B\$=CHR\$ 39
 20 PRINT B\$
 30 LPRINT B\$
 RUN mode

RUN

—

← Content of the character code in the pocket computer is displayed.

← Content of the character code in the CE-126P, a space, is printed. In this example, the paper is fed by one line.

USING THE CE-125 PRINTER/ MICROCASSETTE RECORDER

The CE-125 Printer/Microcassette Recorder allows you to add a printer and microcassette recorder to your computer.

The CE-125 features:

- * 24 character wide thermal printer with approximately 48 line per minute print speed.
- * Convenient paper feed and tear bar.
- * Simultaneous printing of calculations as desired.
- * Easy control of display or printer output in BASIC.
- * Complete built-in microcassette playback/recorder unit including fast forward and tape counter.
- * Manual and program control of recorder for storing programs and data.
- * Filenames and passwords on tape for control and security.
- * Jack for external playback unit.
- * Built-in rechargeable Ni-Cad batteries for portability.
- * Recharger (EA-23E) supplied.
- * Automatic Stop Function of Microcassette when the end of tape is reached. (PLAY and RECORD modes only)

Using the Printer

If you are using the computer as a calculator, you may use the CE-125 to simultaneously print your calculations. This is easily accomplished by pressing the **SHIFT** key and then the **ENTER** key (P ↔ NP) while in the RUN mode. The printer indicator "P" will light up on the display. After this, when you press **ENTER** at the end of a calculation, the contents of the display will be printed on one line and the results will be printed on the next. For example:

Input

300 / 50

Paper

300 / 50

6.

You may print output on the printer from within BASIC programs by using the LPRINT statement (see Chapter 8 for details). LPRINT can be used in the same form as the PRINT statement. The difference is that if you PRINT something to the display which is longer than 16 characters, there is no way for you to see the extra characters. With the LPRINT verb, the extra characters will be printed on a second and possibly a third line as is required.

Programs which have been written with PRINT can be converted to work with the printer by including a PRINT=LPRINT statement in the program (see Chapter 8 for details). All PRINT statements following this statement will act as if they were LPRINT statements. PRINT=PRINT will reset this condition to its normal state. This structure may also be included in a program in an IF statement allowing a choice of output at the time the program is used.

You may also list your programs on the printer with the LLIST command (see Chapter 8 for details). If used without line numbers LLIST will list all program lines currently in memory in their numerical order by line number. A line number range may also be given with LLIST to limit the lines which will be printed. When program lines are longer than 24 characters, two or more lines may be used to print one program line. The second and succeeding lines will be indented four characters so that the line number will clearly identify each separate program line.

Caution:

- If an error (ERROR code 8) occurs due to a paper misfeed, tear off the paper tape, and pull the remaining part of the paper tape completely out of the printer. Then press the **CL** key to clear the error condition.
- When the printer/recorder is exposed to strong external electrical noise, it may print numbers at random. If this happens, depress the **BRK** key to stop the printing, then press the **CL** key.

Pressing the **CL** key will return the printer to its normal condition.


When the printer causes a paper misfeed or is exposed to strong external electrical noise while printing, it may not operate normally and only the symbol "BUSY" will be displayed. If this happens, depress the **BRK** key to stop the printing. (Release the paper misfeed.) Press the **CL** key.

- When the CE-125 is not in use, turn off the printer switch to save the battery life.
- Even while printing under the LPRINT command, the entry can be executed when an INPUT, INKEY\$ or PRINT command is performed. In this case, however, the printer will stop if the **CL** key is pressed. Therefore, only press the **CL** key upon completion of printing.

Using the Microcassette Recorder

LOADING THE CASSETTE TAPE

1. Depress the STOP/EJECT (■) button to open the cassette compartment lid.
2. Load the cassette tape into the compartment so that the title ("A" or "B") of the tape track to be used is facing upwards. The open edge of the cassette should be facing forward.
3. Press the cassette compartment lid down.



UNLOADING THE CASSETTE TAPE

1. Depress the STOP/EJECT (■) button to open the cassette compartment lid and remove the tape.
2. Press the cassette compartment lid down.

Note: In the PLAY mode press the STOP/EJECT (■) button once to stop the tape movement. Press it again to eject the tape.

Use the manual controls for positioning the tape. Set the 'REMOTE' switch to OFF. In this position you may use the fast forward (FF), and rewind (REW) buttons in combination with the tape counter to position the tape as desired. To return control of the cassette unit to the computer, set the REMOTE switch to the ON position.

The facilities which are available with your cassette include:

- CSAVE Saves the contents of program or reserve memory on tape.
- CLOAD Retrieves a program or reserve memory from tape.
- CLOAD? Compares the program on tape with the contents of memory to insure that you have a good copy.
- MERGE Combines a program on tape with one already in memory.
- PRINT# Saves the contents of variables on tape.
- INPUT# Retrieves the contents of variables from tape.
- CHAIN Starts execution of a program which has been stored on tape.

Programs may be assigned filenames which will be stored on the tape. This allows the unambiguous storage of many programs on one tape. Programs can then be retrieved by name and the tape will be searched to find the appropriate file. If programs have been password protected in memory, they cannot be stored on tape, but a password can be assigned at the time that unprotected programs are CSAVEd. Such password protected programs can be used by other persons, but they will not be able to LIST or modify the programs in any way.

See Chapter 8 for details on all these verbs and commands.

When a program or data is recorded on tape it will be preceded by a high pitched tone of approximately 7 seconds (PC-1248 only). This tone serves to advance the tape past any leader and to identify the beginning of each program or set of data.


When searching for a filename, the tape can read only in a forward direction. This search is relatively slow, so it is sometimes preferable to keep track of program locations by using the tape counter. The tape can then be manually positioned using fast forward, reverse, and play, to the leader tone area of the correct program before the retrieval is started. While scanning the tape you will be able to hear the high tones which begin each program. In between these high tones will be a mixed high and low tone sound which indicates programs or data.

Note: No tone is generated by the PC-1246S.

Using an External Tape Playback Unit

The **CE-125** also provides a jack to connect an external tape playback unit. The external playback unit can only be used for **reading** from tape, i.e. **CLOAD**, **MERGE**, and **INPUT#**. The main purpose of this jack is to load tapes created on some other **SHARP** computer.

Use the supplied cassette cable to connect the **CE-125** and an external tape playback unit.



When the external tape unit is connected, it automatically takes the place of the internal microcassette for the appropriate commands and may be used in the same way.

- To transfer program and data from the tape of the external playback unit, use the tape recorder with which the tape was prerecorded. Other tape recorders may not work.

Care and Maintenance

- * Be sure that the power is OFF on both units when connecting or disconnecting the CE-125 and the computer.
- * The printer should be operated on a level surface.
- * The CE-125 should be kept away from extreme temperatures, moisture, dust, and loud noises.
- * Use a soft, dry cloth to clean the CE-125. DO NOT use solvent or a wet cloth.
- * Keep foreign objects out of the CE-125.
- * Clean tape heads periodically with any standard head cleaning kit.

Errors

If the batteries become low, or if the CE-125 is subjected to strong noise, the unit may cease to function and the computer may "hang up". This can also occur if the units are connected and the power of the CE-125 is not turned on when a LPRINT or LLIST command is used. In some cases ERROR 8 may be displayed on the computer.

The CLear key usually clears this condition, but in some cases the RESET may be required. Be sure to restore adequate power to the CE-125 before attempting to use it again.

Examples

The procedures for computer and microcassette recorder operation

1. Saving

- (1) Turn off the REMOTE switch.
- (2) Put a tape into the tape compartment.
(Tape winding can be available by manual operation.)
- (3) Turn on the REMOTE switch.
- (4) Depress the **RECORD** (●) button.
- (5) With the same command which saves your program you must give the program a "filename". This is for reference purposes. Your filename can not be longer than 7 characters. To save the program with a filename type:

CSAVE **SHIFT** " PRO-1 **SHIFT** "

Your program will be saved with the name "PRO-1". You can assign any name you desire, whatever is easiest for you to keep trace of. Also, note that there is a 7 character length limit for your filename. If the name is

longer than 7 characters, the excess is ignored. A good practice is to maintain a program log, which includes the program name, starting and stopping location on tape (use the counter numbers), and a brief description of what the program does.

Press the **ENTER** key. At this time you should hear a shrill buzzing sound (PC-1248 only), and the tape should be turning. Also the "BUSY" indicator should light up. This tells you that the computer is "busy" transferring your program from memory to the tape. If this does not happen, start again from the beginning of the section.

Once the computer arrives at the end of the program, the "BUSY" indicator light will go off, the recorder will stop, and the "prompt" will re-appear on the display. In order to insure that this has in fact been accomplished we can read it back into memory from the tape as explained in the next section.

Note: When saving a program on the used tape, erase the portion (approx. 5 counter numbers) before writing and execute the recording command.

(Make sure that the previous program is completely erased without any portion remaining.)

2. Collating the Computer and Tape Contents

Now that your program is saved on tape, you will no doubt want to see if it is really there. To do this is relatively simple; use the CLOAD? command.

- (1) Turn off the REMOTE switch to clear remote control functions.
- (2) Rewind the tape to the place at which you started, again using the number counter.
- (3) Turn on the REMOTE switch to set remote control functions.
- (4) Depress the **PLAY (◀)** button.
- (5) To collate the program with a filename type:

CLOAD **SHIFT** ? **SHIFT** " PRO-1 **SHIFT** "

Press the **ENTER** key.

During the collation, the mark "*" is shown at the right most digit of the display. The mark "*" will disappear when the collation is completed. While a file name is being retrieved, no "*" mark will be displayed as the collation is not started yet. This is the same for the MERGE, CHAIN, CLOAD, and INPUT# commands. (If no file name has been specified, this will occur during reading of the first program.)

Note 1) If the specified file name is not found, the computer will continue to retrieve the file name even after the tape stops. In such a case, press **BRK** to stop retrieval. This is the same for the MERGE, CHAIN, CLOAD, and INPUT# commands.

Using the Options

The computer compares the CSAVEd program with the one in its memory. If all went well, it will display the "prompt" and end its check. If all did not go well, an error message will be displayed, usually ERROR 8. This tells you that the program on tape is somehow different from the program in SHARP's memory. Erase that portion of tape and start again.

3. Transfer from Tape

- (1) Turn off the REMOTE switch.
- (2) Rewind the tape to the place at which you started, again using the number counter.
- (3) Stop rewinding.
- (4) Turn the REMOTE switch back ON.
- (5) Press the PLAY (◀) button.
- (6) Type:

CLOAD SHIFT "PRO-1" SHIFT "

and press the ENTER key.

(Remember "PRO-1" is the filename we have given to your program. If you saved the program under another name you must use that name instead of PRO-1)

- (7) The mark "*" appears while loading the designated CSAVEd program from the tape to the computer's memory.
(If no file name has been specified, this will occur during reading of the first program.)
The mark "*" disappears when the load is performed completely.
- (8) The cassette retains a copy of the program, so you can CLOAD the same program over and over again.
While loading, if an error message ERROR 8 is displayed, start again from the above step (1).

USING THE PRINTER/CASSETTE INTERFACE

The optional CE-123P/CE-126P Printer/Cassette Interface allows you to add a printer and to connect a cassette recorder to your computer.

The Printer/Cassette Interface features:

- * 24 character wide thermal printer.
- * Convenient paper feed and tear bar.
- * Simultaneous printing of calculations as desired.
- * Easy control of display or printer output in BASIC.
- * Built-in cassette interface with remote function.
- * Manual and program control of recorder for storing programs, data.
- * Dry battery operation for portability.

For connecting the **computer** to the Printer/Cassette Interface, refer to the instruction manual which is supplied with the Printer/Cassette Interface.

Using the Printer

If you are using the **computer** for manual calculation, you may use the Printer/Cassette Interface to simultaneously print your calculations.

This is easily accomplished by pressing the **SHIFT** key and then the **ENTER** key (P ↔ NP) while in the RUN mode.

The printer indicator (P) will appear in the upper left area of the display. After this, when you press the **ENTER** at the end of a calculation, the contents of the display will be printed on one line and the results will be printed on the next. For example:

Input

300/50 **ENTER**

Paper

300/50

6.

Using the Options

You may print output on the printer from within BASIC programs by using the LPRINT statement (see Chapter 8 for details). LPRINT can be used in the same form as the PRINT statement. The difference is that if you PRINT something to the display which is longer than 16 characters, there is no way for you to see the extra characters. With the LPRINT verb, the extra characters will be printed on a second and possibly a third line as is required.

Programs which have been written with PRINT can be converted to work with the printer by including a PRINT = LPRINT statement in the program (see Chapter 8 for details). All PRINT statements following this statement will act as if they were LPRINT statements. PRINT = PRINT will reset this condition to its normal state. This structure may also be included in a program in an IF statement allowing a choice of output at the time the program is used.

You may also list your programs on the printer with the LLIST command (see Chapter 8 for details). If used without line numbers LLIST will list all program lines currently in memory in their numerical order by line number. A line number range may also be given with LLIST to limit the lines which will be printed. When program lines are longer than 24 characters, two or more lines may be used to print one program line. The second and succeeding line will be indented four characters so that the line number will clearly identify each separate program line.

Caution:

- In case an error (ERROR code 8) occurs due to a paper misfeed, tear off the paper tape, and pull the remaining part of the paper tape completely out of the printer. Then press the **[CL]** key to clear the error condition.
- When the printer is exposed to strong external electrical noise, it may print numbers at random. If this happens, depress the **[BRK]** key to stop the printing. Turn the Printer/Cassette Interface power off and on, and then press the **[CL]** key. Pressing the **[CL]** key will return the printer to its normal condition.

When the printer causes a paper misfeed or is exposed to strong external electrical noise while printing, it may not operate normally and only the symbol "BUSY" will be displayed. If this happens, depress the **[BRK]** key to stop printing. (Release the paper misfeed.) Turn the Printer/Cassette Interface power off and on, and then press the **[CL]** key.

- When the Printer/Cassette Interface is not in use, turn off the printer switch to save the battery life.

Using the Cassette Interface

Using this cassette interface will allow you to store programs and data from the computer onto cassette tape (of course you'll also need a cassette recorder such as we sell for this computer system: model **CE-152**). Once on tape, you can load these programs and data back into the computer with a simple procedure.

Connecting the Printer/Cassette Interface to a Tape Recorder

Only three connections are necessary:

1. Connect red plug into the MICrophone jack on the cassette recorder.
2. Connect gray plug into the EARphone jack on the cassette recorder.
3. Connect the black plug into the REMote jack on the cassette recorder.

Cassette Tape Recorder

We recommend that you use the optional cassette tape recorder **CE-152** for your computer system. The **CE-152** is designed to match the **computer** records, programs and data via the Printer/Cassette Interface. Any recorded program can be retrieved and reloaded into the **computer**.

The following is a description of the minimum tape recorder specifications necessary for interfacing with the Printer/Cassette Interface:

Item	Requirements
1. Recorder Type	Any tape recorder, standard cassette or micro-cassette recorder, may be used in accordance with the requirements outlined below.
2. Input Jack	The recorder should have a mini-jack input labeled "MIC". Never use the "AUX" jack.
3. Input Impedance	The input jack should be a low impedance input (200 ~ 1,000 OHM.)
4. Minimum Input Level	Below 3 mV or -50 dB.
5. Output jack	Should be a minijack labeled: "EXT. (EXternal speaker)", "MONITOR", "EAR (EARphone)" or equivalent.
6. Output impedance	Should be below 10 OHM.
7. Output level	Should be above 1V (practical maximum output above 100 mW)
8. Distortion	Should be within 15% within a range of 2 KHz through 4 kHz.
9. Wow and Flutter	0.3% maximum (W.R.M.S.)
10. Other	Recorder motor should not fluctuate in speed.

* In case the miniplug provided with the Printer/Cassette Interface is not compatible with the input/output jacks of your tape recorder, special line conversion plugs are available on the market.

Note: Some tape recorders may not perform properly due to different specifications. Additionally tape recorders having distortion, increased noise, and power deterioration after long years of use may not show satisfactory results owing to change in their electrical characteristics.

Operating the Cassette Interface and Recorder

Recording (saving) onto magnetic tape

See Tape Notes.

1. Turn off the REMOTE switch on the Printer/Cassette Interface.
2. Enter a program or data into the Computer.
3. Load tape into the tape recorder.

Determine the position on the tape where you want to record the program.

 - When using a tape, be sure the tape moves past the clear leader (non-magnetic mylar material).
 - When using a tape already partially recorded, search for a location where no recording exists.
4. Connect the Interface's red plug to the tape recorder's MIC jack and the black plug to the REM jack.
5. Turn on the REMOTE switch.
6. Simultaneously press record and play buttons on the tape recorder (to put it in record mode).
7. Enter recording instructions (CSAVE statement, PRINT # statement), and press the **ENTER** key for execution.

First set the unit to "RUN" or "PRO" mode. Next push the following keys:

C **S** **A** **V** **E** **SHIFT** **"** file name **SHIFT** **"** **ENTER** .

(To write the contents of data memory onto tape, push as follows:

P **R** **I** **N** **T** **SHIFT** **#** **ENTER** .)

E.g., **C** **S** **A** **V** **E** **SHIFT** **"** **A** **A** **SHIFT** **"** **ENTER**

When you press the **ENTER** key, tape motion will begin, leaving about an 8-second non-signal blank. (On the PC-1248 only, a beep tone is recorded.) After that, the file name and its contents are recorded.

8. When the recording is complete, the PROMPT symbol (>) will be displayed and the tape recorder will automatically stop. The program is now saved on tape. (The program also remains in the computer's memory.)
When data are to be automatically recorded by program execution (PRINT # statement, not manual operation), set up steps 1 thru 6 before executing the program.

To aid you in locating programs on tapes, use the tape counter on the recorder.

Collating the Computer and Tape Contents

See tape Notes.

After loading or transferring a program to or from tape, you can verify that the program on tape and program in the Computer are identical (and thus be sure that everything is OK before continuing your programming or execution of programs).

1. Turn off the REMOTE switch.
2. With cassette in the recorder, operate the tape motion controls to position tape at the point just before the appropriate file name to be checked.
3. Connect gray plug to EARphone and black plug to REMote jacks.
4. Turn on the REMOTE switch.
5. Press PLAY button of recorder.
6. Input a CLOAD? statement and start execution with **ENTER** key. Do this as follows: Set unit to "RUN" or "PRO" mode. Enter the following key sequence —

The file name which you used previously.

C **L** **O** **A** **D** **SHIFT** **?** **SHIFT** **"** **A** **A** **SHIFT** **"** **ENTER**

The Computer will automatically search for the specified file name and will compare the contents on tape with the contents in memory.

During the collation, the mark "*" is shown at the right most digit of the display. The mark "*" will disappear when the collation is completed. While a file name is being retrieved, no "*" mark will be displayed as the collation is not started yet.

(If no file name has been specified, this will occur during reading of the first program.)

If the programs are verified as being identical, a PROMPT symbol (>) will be displayed on the Computer.

If the programs differ, execution will be interrupted and an Error code 8 will be displayed. If this occurs, try again.

Loading from a magnetic tape

See Tape Notes.

To load, transfer, or read out programs and data from magnetic tape into the Computer, use the following procedure.

1. Turn off the REMOTE switch.
2. Load tape in the tape recorder. Position tape just before the portion to be read out.
3. Connect the gray plug to the EAR jack on the tape recorder, and the black plug to the REM jack.
[In using a tape recorder having no REM terminal, press the PAUSE button to make a temporary stop.]
4. Turn on the REMOTE switch.
5. Push the PLAY button on the tape recorder (to put unit in playback mode).

Set the VOLUME control to middle or maximum.

If the tape recorder does not function properly when the volume is set to maximum, turn the volume down and try again.

Set Tone to maximum treble.

6. Input transfer instructions (CLOAD statement, INPUT # statement), and press **ENTER** key for execution.

Put the unit into "RUN" mode. Then push the following keys: **C L O**
A D **SHIFT** **"** file name **SHIFT** **"** **ENTER** .

(To load the contents of the data memory, push as follows: **I N P U**
T **SHIFT** **#** **ENTER** .)

E.g., **C L O A D** **SHIFT** **"** **A A** **SHIFT** **"** **ENTER**

The specified file name will be automatically searched for and its contents will be transferred into the Computer.

The mark "*" appears while loading the designated CSAVED program from the tape to the computer's memory.

The mark "*" disappears when the load is performed completely.

7. When the program has been transferred the computer will automatically stop the tape motion and display the PROMPT (>) symbol.
To transfer data (INPUT # statement) in the course of a program, set up steps 1 thru 5 prior to executing the program.

Using the Options

- Notes:**
- If an error occurs (error code "8" is displayed), start over from the beginning. If the error continues, adjust volume up or down slightly.
 - If the error code is not displayed but tape motion continues (while the Computer displays the symbol "BUSY"), transferring is improper. Press **BRK** key (to "break") to stop the tape. Repeat steps.
 - If the error remains or the tape continues to run after several attempts to correct the problem, try cleaning and demagnetizing the Recorder's tape head.

Tape notes

- 1) For any transfer or collation, uses the tape recorder that was used for recording. If the tape recorder for transfer or collation is different from that used for recording, transfer or collation may not be possible.
- 2) Always uses only the highest quality tape for programs and data storage (economy grade audio type tape may not provide the proper characteristics for digital recordings).
- 3) Keep the tape heads and tape handling parts clean — use a cassette cleaner tape to keep everything clean.
- 4) Volume setting — set to middle or maximum level.
Volume level can be very important when reading in data from the recorder; make slight adjustments as required to obtain error-free data transfer. A slight adjustment either up or down may result in perfect recordings every time.
- 5) Be sure all connections between the computer and cassette interface are secure. And be sure the connections between interface and recorder are secure and dirt-free.
- 6) If problems occur when using AC power for the Printer/Cassette Interface and/or the recorder, use battery power instead (sometimes the AC power connection also adds some "hum" to the signal which upsets proper digital recordings).
 - To connect the AC adaptor to the Printer/Cassette Interface, turn the Printer/Cassette Interface power off and then connect the adaptor to the Printer/Cassette Interface.
- 7) Tone control — set to maximum treble.
- 8) When recording programs or data on the used tape, erase the portion before writing and execute the recording command. (Make sure that the previous program is completely erased without any portion remaining.)

CHAPTER 8

BASIC REFERENCE

The following chapter is divided into three sections:

- Commands:** Instructions which are used outside a program to change the working environment, perform utilities, or control programs.
- Verbs:** Action words used in programs to construct BASIC statements.
- Functions:** Special operators used in BASIC programs to change one variable into another.

Commands and verbs are arranged alphabetically. Each entry is on a separate page for easy reference. The contents of each section is shown in the tables below so that you can quickly identify the category to which an operator belongs. Functions are grouped according to four categories and arranged alphabetically within category.

Commands

Program Control

CONT
GOTO*
NEW
NEW Ø
RUN

Cassette Control

CLOAD
CLOAD?
CSAVE
INPUT #*
MERGE
PRINT #*

Debugging

LIST
LLIST
TROFF*
TRON*

Variables Control

CLEAR
DIM*

Angle Mode Control

DEGREE*
GRAD*
RADIAN*

Other

BEEP* (Only PC-1248)
PASS*
RANDOM*
USING*
WAIT*

*These commands are also BASIC verbs. Their effect as commands is identical to their effect as verbs so they are not described in the command reference section. See the verb reference section for more information.

Verbs

Control and Branching

CHAIN
END
FOR ... TO ... STEP
GOSUB
GOTO
IF ... THEN
NEXT
ON ... GOSUB
ON ... GOTO
RETURN
STOP

Assignment and Declaration

CLEAR
DIM
LET

Input and Output

AREAD
CSAVE
DATA
INPUT
INPUT #
LPRINT
PAUSE
PRINT
PRINT #
USING
READ
RESTORE
WAIT

Other

BEEP (Only PC-1248)
DEGREE
GRAD
RADIAN
RANDOM
REM
TROFF
TRON

FunctionsPseudovariables

INKEY\$
MEM
PI

String Functions

ASC
CHR\$
LEFT\$
LEN
MID\$
RIGHT\$
STR\$
VAL

Numeric Functions

ABS
ACS
ASN
ATN
COS
DEG
DMS
EXP
INT
LOG
LN
RND
SGN
SIN
SQR
TAN

COMMANDS

- 1 CLOAD
- 2 CLOAD "filename"

Abbreviations: CLO., CLOA.

See also: CLOAD?, CSAVE, MERGE, PASS

Purpose

The CLOAD command is used to load a program saved on cassette tape.

Use

The first form of the CLOAD command clears the memory of existing programs and loads the first program stored on the tape, starting at the current position.

The second form of the CLOAD command clears the memory, searches the tape for the program whose name is given by "filename", and loads the program.

If the computer is in PROgram or RUN mode, program memory is loaded from the tape.

Examples

CLOAD Loads the first program from the tape.

CLOAD "PRO3" Searches the tape for the program named 'PRO3' and loads it.

Notes:

1. If the designated file name is not retrieved, the computer will continue to search the file name even after the tape reaches the end. In this case, stop the retrieval function by pressing the **BRK** key. This applies to MERGE, CHAIN, CLOAD? and INPUT# commands to be described later.
2. If an error occurs during CLOAD or CHAIN command (to be described later) execution, the program stored in the computer will be invalid.

1 CLOAD?

2 CLOAD? "filename"

Abbreviations: CLO.?, CLOA.?

See also: CLOAD, CSAVE, MERGE, PASS

Purpose

The CLOAD? command is used to compare a program saved on cassette tape with one stored in memory.

Use

The first form of the CLOAD? command compares the program stored in memory with the first program stored on the tape, starting at the current position.

The second form of the CLOAD? command searches the tape for the program whose name is given by "filename" and then compares it to the program stored in memory.

Examples

CLOAD?

Compares the first program from the tape with the one in memory.

CLOAD? "PRO3"

Searches the tape for the program named 'PRO3' and compares it to the one stored in memory.

1 CONT

Abbreviations: C., CO., CON.

See also: RUN, STOP verb

Purpose

The CONT command is used to continue a program which has been temporarily halted.

Use

When the STOP verb is used to halt a program during execution, the program can be continued by entering CONT in response to the prompt.

When a program is halted using the **BRK** key, the program can be continued by entering CONT in response to the prompt.

Examples

CONT Continues an interrupted program execution.

- 1 CSAVE
- 2 CSAVE "filename"
- 3 CSAVE , "password"
- 4 CSAVE "filename", "password"

Abbreviations: CS., CSA., CSAV.

See also: CLOAD, CLOAD?, MERGE, PASS

Purpose

The CSAVE command is used to save a program to cassette tape.

Use

The first form of the CSAVE command writes all of the programs in memory on to the cassette tape without a specified file name.

The second form of the CSAVE command writes all of the programs in memory on to the cassette tape and assigns the indicated file name.

The third form of the CSAVE command writes all of the programs in memory on to the cassette tape without a specified file name and assigns the indicated password. Programs saved with a password may be loaded by anyone, but only someone who knows the password can list or modify the programs. (See discussion under PASS command).

The fourth form of the CSAVE command writes all of the programs in memory on to the cassette tape and assigns them the indicated file name and password.

If the computer is in PROgram or RUN mode, program memory is loaded to the tape.

Examples

CSAVE "PRO3", "SECRET" Saves the programs now in memory on to the tape under the name 'PRO3', protected with the password 'SECRET'.

Commands

GOTO

1 **GOTO** expression

Abbreviations: G., GO., GOT.

See also: RUN

Purpose

The GOTO command is used to start execution of a program.

Use

The GOTO command can be used in place of the RUN command to start program execution at the line number specified by the expression.

GOTO differs from RUN in five respects:

- 1) The value of the interval for WAIT is not reset.
- 2) The display format established by USING statements is not cleared.
- 3) Variables and arrays are preserved.
- 4) PRINT = LPRINT status is not reset.
- 5) The pointer for READ is not reset.

Execution of a program with GOTO is identical to execution with the **DEF** key.

Examples

GOTO 100

Begins execution of the program at line 100.

1 LIST

2 LIST expression

Abbreviations: L., LI., LIS.

See also: LLIST

Purpose

The LIST command is used to display a program.

Use

The LIST command may only be used in the PROgram mode. The first form of the LIST command displays the statement with the lowest line number.

The second form displays the statement with the nearest line number greater than the value of the expression. The Up Arrow and Down Arrow keys may then be used to examine the program.

Examples

LIST 100

Displays line number 100.

Commands:
LLIST

- 1 **LLIST**
- 2 **LLIST** expression 1 , expression 2

Abbreviations: LL., LLI., LLIS.

See also: LIST

Purpose

The LLIST command is used for printing a program on the printer.

Use

The LLIST command may only be used in the PROgram mode.

The first form prints all of the programs in memory.

The second form prints the statements from the line number with the nearest line equal to or greater than the value of expression 1 to the nearest line equal to or greater than the value of expression 2. There must be at least two lines between the two numbers.

Examples

LLIST 100, 200 Lists the statements between line numbers 100 and 200.

- 1 MERGE
- 2 MERGE "filename"

Abbreviations: MER., MERG.

See also: CLOAD, CLOAD?, CSAVE, PASS verb

Purpose

The MERGE command is used to load a program saved on cassette tape and merge it with programs existing in memory.

Use

The first form of the MERGE command loads the first program stored on the tape starting at the current position and merges it with programs already in memory.

The second form of the MERGE command searches the tape for the program whose name is given by "filename", and merges it with the programs already in memory.

Programs with overlapping line numbers are treated as one program after merging.

If the program in memory is password protected, another password protected program cannot be merged with it. If the program on cassette is not password protected, it becomes protected by the password of the program in memory when merged.

If the program in memory is not password protected, it becomes protected by the password of the program on the cassette when merged.

Examples

MERGE

Merges the first program from the tape.

MERGE "PRO3"

Searches the tape for the program named 'PRO3' and merges it.

Note: For example, let's assume the computer memory contains the following program:

```
10: PRINT "DEPRECIATION"  
20: INPUT "METHOD: " ; A
```

Commands
MERGE:

At this point you remember that you have a similar program portion on tape under the filename "DEP1". You will, of course, want to see if this program has sections useful in the program you are currently constructing. The first step is to find the tape with "DEP1" on it. Cue the tape to the place at which "DEP1" starts.

Now type: MERGE "DEP1" and press **ENTER**.

The computer will now load "DEP1" into memory IN ADDITION to the above program. After "DEP1" is loaded, you might find something in memory similar to this:

```
10: PRINT "DEPRECIATION"  
20: INPUT "METHOD: " ; A  
10: "DEP1" : REM >> SECOND MODULE <<  
20: PRINT "INTEREST CHARGES"  
30: INPUT "AMT. BORROWED: " ; B  
:  
(etc)
```

Note that unlike the CLOAD command, the new program DID NOT replace the existing one and that some line numbers have been duplicated. Also note that a "label" was used on the first line of the merged module. This allows "LINKING" of the modules together (See LINKING MERGED MODULES — on the next page). It is important that you review the following information before proceeding with any further editing or programing:

IMPORTANT NOTES:

Once a MERGE is performed, no INSERTIONS, DELETIONS, or CHANGES are allowed to previously existing program lines.

Example:

```
10 "A" REM THIS IS EXISTING PROGRAM  
20 FOR T = 1 TO 100  
30 LPRINT T  
40 NEXT T  
:  
(etc)
```

BEFORE doing a MERGE of the next program, make any necessary changes to this program.

Then MERGE the next program: MERGE "PROG2" (example)

```
10 "B" REM THIS IS MERGED PROGRAM
20 INPUT "ENTER DEPRECIATION: " ; D
30 INPUT "NUMBER OF YEARS: " ; Y
40 etc.
```

Now you may make changes to the above program since it was the last MERGED portion.

LINKING MERGED MODULES (programs) TOGETHER

Since the processor executes your program lines in logical sequence, it will stop when it encounters a break in the sequence in line numbering, i.e. if line numbers 10, 20, 30 are followed by duplicate line numbers in a second module, the following techniques are valid: GOTO "B" GOSUB "B", IF. . . THEN "B" (B is used for example only, you can use any label.)

Commands
NEW

- 1 NEW
 - 2 NEW 0
- Abbreviations: none.

Purpose

The NEW command is used to clear an existing program.

Use

The NEW command may only be used in the PROgram mode.

The first form of the NEW command clears all programs and data which are currently in memory. (The programs with password cannot be cleared.)

The second form of the NEW command clears all programs and data which are currently in memory. Note that the programs with password can be cleared.

The NEW command is not defined in the RUN mode and will result in an ERROR 9.

Examples

NEW Clears program or data.

1 PASS "character string"

Abbreviations: PA., PAS.

See also: CSAVE, CLOAD

Purpose

The PASS command is used to set and cancel passwords.

Use

Passwords are used to protect programs from inspection or modification by other users. A password consists of a character string which is **no more than seven characters long**. The seven characters must be alphabetic or one of the following special symbols: ! # \$ % & () * + - / , . : ; < = > ? @ $\sqrt{\quad}$ π ^

Once a PASS command has been given the programs in memory are protected. A password protected program cannot be examined or modified in memory. It cannot be output to tape or listed with LIST or LLIST, nor is it possible to add or delete program lines. If several programs are in memory and PASS is entered, all programs in memory are protected. If a non-password protected program is merged with a protected program, the merged program is protected. The way to remove this protection is to execute another PASS command with the same password, or execute NEW \emptyset in PROgram mode.

Examples

PASS "SECRET" Establishes the password 'SECRET' for all programs in memory.

Commands RUN

- 1 RUN
- 2 RUN line number

Abbreviations: R., RU.

See also: GOTO

Purpose

The RUN command is used to execute a program in memory.

Use

The first form of the RUN command executes a program beginning with the lowest numbered statement in memory.

The second form of the RUN command executes a program beginning with the specified line number.

RUN differs from GOTO in five respects:

- 1) The value of the interval for WAIT is reset.
- 2) The display format established by USING statements is cleared.
- 3) Variables and arrays other than the fixed variables are cleared.
- 4) PRINT = PRINT status is set.
- 5) The pointer for READ is reset to the beginning DATA statement.

Execution of a program with GOTO is identical to execution with the DEF key. In all three forms of program execution FOR/NEXT and GOSUB nesting is cleared.

Examples

RUN 100

Executes the program which begins at line number 100.

VERBS

1 AREAD variable name

Abbreviations: A., AR., ARE., AREA.

See also: INPUT verb and discussion of the use of the DEF key in Chapter 6

Purpose

The AREAD verb is used to read in a single value to a program which is started using the **DEF** key.

Use

When a program is labelled with a letter, so that it can be started using the **DEF** key, the AREAD verb can be used to enter a single starting value without the use of the INPUT verb. The AREAD verb must appear on the first line of the program following the label. If it appears elsewhere in the program, it will be ignored. Either a numeric or string variable may be used, but only one can be used per program.

To use the AREAD verb type the desired value in the RUN mode, press the **DEF** key, followed by the letter which identifies the program. If a string variable is being used, it is not necessary to enclose the entered string in quotes.

Examples

```
10 "X": AREAD N
20 PRINT N ^ 2
30 END
```

Entering "7 **DEF** X" will produce a display of "49".

Notes:

1. When the display indicates PROMPT (">") at the start of program execution, the designated variable is cleared.
2. When the contents of the display have been displayed by a PRINT verb just prior to the start of program execution, the following is stored:

Verbs BEEP

- When the display indicates PRINT numeric expression, numeric expression or PRINT "String", "String", the contents on the right of the display are stored.

Example: When the program below is executed;

```
10 "A" : PRINT "ABC", "DEFG"  
20 "S" : A READ A$ : PRINT A$  
RUN mode
```

DEF [A] →

ABC

DEFG

DEF [S] →

DEFG

- When the display indicates PRINT Numeric expression; Numeric expression..., the contents displayed first (on the extreme left) are stored.
- When the display indicates PRINT "String"; "String"; "String"..., the "String" designated last are stored.

1 BEEP expression

Abbreviations: B., BE., BEE.

(PC-1246S has no
BEEP function.)

Purpose

The BEEP verb is used to produce an audible tone.

Use

The BEEP verb causes the PC-1248 to emit one or more audible tones at 4 kHz. The number of beeps is determined by the expression, which must be numeric. The expression is evaluated, but only the integer part is used to determine the number of beeps.

BEEP may also be used as a command using numeric literals and predefined variables. In this case the beeps occur immediately after the **ENTER** key is pressed.

Examples

10 A = 5 : A\$ = "g"

20 BEEP 3

Produces 3 beeps.

30 BEEP A

Produces 5 beeps.

40 BEEP (A+4)/2

Produces 4 beeps.

50 BEEP A\$

This is illegal and will produce an ERROR 9 message.

60 BEEP -4

Produces no beeps, but does not produce an error message.

- 1 CHAIN
- 2 CHAIN expression
- 3 CHAIN "filename"
- 4 CHAIN "filename", expression

Abbreviations: CH., CHA., CHAI.

See also: CLOAD, CSAVE, and RUN

Purpose

The CHAIN verb is used to start execution of a program which has been stored on cassette tape.

Use

To use the CHAIN verb one or more programs must be stored on a cassette. Then, when the CHAIN verb is encountered in a running program, a program is loaded from the cassette and executed.

The first form of CHAIN loads the first program stored on the tape and begins execution with the lowest line number in the program. The effect is the same as having entered CLOAD and RUN when in the RUN mode.

The second form of CHAIN loads the first program stored on the tape and begins execution with the line number specified by the expression.

The third form of CHAIN searches the tape for the program whose name is indicated by "filename", loads the program, and begins execution with the lowest line number.

The fourth form of CHAIN will search the tape for the program whose name is indicated by filename, load the program, and begin execution with the line number indicated by the expression.

Examples

10 CHAIN


Loads the first program from the tape and begins execution with the lowest line number.

20 CHAIN "PRO-2", 480

Searches the tape for a program named PRO-2, loads it, and begins execution with line number 480.

**Verbs
CHAIN**

For example, let's assume you have three program sections named PRO-1, PRO-2, PRO-3. Each of these sections ends with a CHAIN statement.



During execution, when the computer encounters the CHAIN statement, the next section is called into memory and executed. In this manner, all of the sections are eventually run.

1 CLEAR

Abbreviations: CL., CLE., CLEA.

See also: DIM

Purpose

The CLEAR verb is used to erase all variables which have been used in the program and to reset all preallocated variables to zero or NULL.

Use

The CLEAR verb recovers space which is being used to store variables. This might be done when the variables used in the first part of a program are not required in the second part and available space is limited. CLEAR may also be used at the beginning of a program when several programs are resident in memory and you want to clear out the space used by execution of prior programs.

CLEAR does not free up the space used by the variables A – Z, A\$ – Z\$, or A(1) – A(26) since they are permanently assigned (see Chapter 4). CLEAR does reset numeric variables to zero and string variables to NULL.

Examples

```
1Ø A = 5 : DIM C(5)  
2Ø CLEAR
```

Frees up the space assigned to C() and resets A to zero.

1 DEGREE

Abbreviations: DE., DEG., DEGR., DEGREE.

See also: GRAD and RADIAN

Purpose

The DEGREE verb is used to change the form of angular values to decimal degrees.

Use

The computer has three forms for representing angular values — decimal degrees, radians and gradient. These forms are used in specifying the arguments to the SIN, COS, and TAN functions and in returning the results from the ASN, ACS, and ATN functions.

The DEGREE function changes the form for all angular values to decimal degree from until a GRAD or RADIAN verb is used. The DMS and DEG functions can be used to convert decimal degrees to degree, minute, second form and vice versa.

Examples

10 DEGREE

20 X = ASN 1

X now has a value of 90, i.e. 90 degrees, the Arcsine of 1.

1 DATA expression list

Where: expression list is: expression
or: expression , expression list

Abbreviations: DA., DAT.

See also: READ, RESTORE

Purpose

The DATA verb is used to provide values for use by the READ verb.

Use

When assigning initial values to an array, it is convenient to list the values in a DATA statement and use a READ statement in a FOR . . . NEXT loop to load the values into the array. When the first READ is executed, the first value in the first DATA statement is returned. Succeeding READs use succeeding values in the sequential order in which they appear in the program, regardless of how many values are listed in each DATA statement or how many DATA statements are used.

DATA statements have no effect if encountered in the course of regular execution of the program, so they can be inserted wherever it seems appropriate. Many programmers like to include them immediately following the READ which uses them. If desired, the values in a DATA statement can be read a second time by using the RESTORE statement.

Examples

10 DIM B(10)

Sets up an array.

20 FOR I = 1 TO 10

30 READ B(I)

Loads the values from the DATA statement into B()
B(1) will be 1, B(2) will be 2, B(3) will be 3, etc.

40 NEXT I

50 DATA 1, 2, 3, 4, 5, 6

70 DATA 7, 8, 9, 10

1 DIM dim list

- Where: dim list is: dimension spec, dim list
- and: dimension spec. is: dimension spec., dim list
or: numeric dim spec.
or: string dim spec.
- and: numeric dim spec is: numeric name (size)
- and: string dim spec is: string name (dims)
or: string name (dims) * len
- and: numeric name is: valid numeric variable name
- and: string name is: valid string variable name
- and: dims is: size
or: size, size
- and: size is: number of elements
- and: len is: length of each string in a string array

Abbreviations: D., DI.

Purpose

The DIM verb is used to reserve space for numeric and string array variables.

Use

Except for A(1) ~ A(26) and A\$(1) ~ A\$(26), which are predefined (see Chapter 4), a DIM verb must be used to reserve space for any array variable. An array variable and a simple variable may have the same name. A string array and a numeric array may have the same name except for the dollar sign.

The maximum number of dimensions in any array is two; the maximum size of any one dimension is 255. In addition to the number of elements specified in the dimension statement, one additional "zeroeth" element is reserved. For example, DIM B(3) reserves B(0), B(1), B(2), and B(3). In two dimensional arrays there is an extra "zeroeth" row and column.

In string arrays one specifies the size of each string element in addition to the number of elements. For example, DIM B\$(3)*12 reserves space for 4 strings which are each a maximum of 12 characters long. If the length is not specified each string can contain a maximum of 16 characters.

When a numeric array is dimensioned, all values are initially set to zero; in a string array the values are set to NUL.

A() and A\$() may be dimensioned to sizes larger than 26 with the DIM statement. In this case, part of the array is in the preallocated memory and part is in program memory. See Chapter 4.

Examples


- 10 DIM B(10) Reserves space for a numeric array with 11 elements.
- 20 DIM C\$(4,4)*10 Reserves space for a two dimensional string array with 5 rows and 5 columns; each string will be a maximum of 10 characters.

NOTE:

The **computer** makes it possible to use an expression as the suffix of two-dimensional string array variables.

For the second suffix, however, do not use an array variable. However, arrays, such as A(30) can be used with this.

Example 1: B (A*B, C (0)) = 10. Not usable



Example 2: B (C (0), 5) = 10. Usable

Example 3: B (4, A(30)) = 10. Usable

In Example 1, therefore, C (0) can be used when replaced by A(30), or if required, A(30) = C (0) is placed before it.

Verbs END

1 END

Abbreviations: E., EN.

Purpose

The END verb is used to signal the end of a program.

Use

When multiple programs are loaded into memory at the same time a mark must be included to indicate where each program ends so that execution does not continue from one program to another. This is done by including an END verb as the last statement in the program.

Examples

```
10 PRINT "HELLO"  
20 END  
30 PRINT "GOODBYE"  
40 END
```

With these programs in memory a 'RUN 10' prints 'HELLO', but not 'GOODBYE'. 'RUN 30' prints 'GOODBYE'.


```

1 FOR numeric variable = expression 1 TO expression 2
2 FOR numeric variable = expression 1 TO expression 2
   STEP expression 3

```

Abbreviations: F. and FO.; STE.

See also: NEXT

Purpose

The FOR verb is used in combination with the NEXT verb to repeat a series of operations a specified number of times.

Use

The FOR and the NEXT verbs are used in pairs to enclose a group of statements which are to be repeated. The first time this group of statements is executed the loop variable (the variable named immediately following the FOR) has the value of expression 1.

When execution reaches the NEXT verb this value is tested against expression 2. If the value of the loop variable is less than expression 2, the loop variable is increased by the step size and the enclosed group of statements is executed again, starting with the statement following the FOR. In the first form the step size is 1; in the second form the step size is given by expression 3. If the value of the loop variable is greater than or equal to expression 2, execution continues with the statement which immediately follows the NEXT. Because the comparison is made at the end, the statements within a FOR/NEXT pair are always executed at least once.

Expression 1 may have any value in the numeric range. When expression 1 and expression 2 are compared, only the integer part is used in the expression 2. Expression 2 and expression 3 must be an integer in the range of -32768 to 32767 ; Expression 3 may not be zero. Expression 1, expression 2 and expression 3 can also be specified in negative.

The loop variable may be used within the group of statements, for example as an index to an array, but care should be taken in changing the value of the loop variable.

Programs should be written so that they never jump from outside a FOR/NEXT pair to a statement within a FOR/NEXT pair. Similarly, programs must never leave a FOR/NEXT pair by jumping out. Always exit a FOR/NEXT loop via the NEXT statement. To do this, set the loop variable to a value higher than expression 2.

Verbs FOR

The group of statements enclosed by a FOR/NEXT pair can include another pair of FOR/NEXT statements which use a different loop variable as long as the enclosed pair is completely enclosed; i.e., if a FOR statement is included in the group, the matching NEXT must also be included. FOR/NEXT pairs may be "nested" up to five levels deep.

Examples

```
10 FOR I = 1 TO 5  
20 PRINT I  
30 NEXT I
```

This group of statements prints the numbers 1, 2, 3, 4, 5.

```
40 FOR N = 10 TO 0 STEP -1  
50 PRINT N  
60 NEXT N
```

This group of statements counts down 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0.

```
70 FOR N = 1 TO 10  
80 X = 1  
90 FOR F = 1 TO N  
100 X = X * F  
110 NEXT F  
120 PRINT X  
130 NEXT N
```

This group of statements computes and prints N factorial for the numbers from 1 to 10.

1 **GOSUB** expression

Abbreviations: GOS., GOSU.

See also: GOTO, ON . . . GOSUB, ON . . . GOTO, RETURN

Purpose

The GOSUB verb is used to execute a BASIC subroutine.

Use

When you wish to execute the same group of statements several times in the course of a program or use a previously written set of statements in several programs, it is convenient to use the BASIC capability for subroutines using the GOSUB and RETURN verbs.

The group of statements is included in the program at some location where they are not reached in the normal sequence of execution. A frequent location is following the END statement which marks the end of the main program. At those locations in the main body of the program — where subroutines are to be executed, include a GOSUB statement with an expression which indicates the starting line number of the subroutine. The last line of the subroutine must be a RETURN. When GOSUB is executed, the **computer** transfers control to the indicated line number and processes the statements until a RETURN is reached. Control is then transferred back to the statement following the GOSUB.

A subroutine may include a GOSUB. Subroutines may be “nested” in this fashion up to 10 levels deep.

The expression in a GOSUB statement may not include a comma, e.g., 'A(1, 2)' cannot be used. Since there is an ON . . . GOSUB structure for choosing different subroutines at given locations in the program, the expression usually consists of just the desired line number. When a numeric expression is used it must evaluate to a valid line number, i.e., 1 to 999, or an ERROR 4 will occur.

Examples

```
10 GOSUB 100
20 END
100 PRINT "HELLO"
110 RETURN
```

When this program is run it prints the word 'HELLO' one time.

1 GOTO expression

Abbreviations: G., GO., GOT.

See also: GOSUB; ON ... GOSUB; ON ... GOTO;

Purpose

The GOTO verb is used to transfer control to a specified line number.

Use

The GOTO verb transfers control from one location in a BASIC program to another location. Unlike the GOSUB verb, GOTO does not "remember" the location from which the transfer occurred.

The expression in a GOTO statement may not include a comma, e.g., 'A(1, 2)' cannot be used. Since there is an ON ... GOTO structure for choosing different destinations at given locations in the program, the expression usually consists of just the desired line number. When a numeric expression is used, it must evaluate to a valid line number, i.e., 1 to 999, or an ERROR 4 will occur.

Well designed programs usually flow simply from beginning to end, except for sub-routines executed during the program. Therefore, the principal use of the GOTO verb is as a part of an IF ... THEN statement.

Examples

```
10 INPUT A$
20 IF A$ = "Y" THEN GOTO 50
30 PRINT "NO"
40 GOTO 60
50 PRINT "YES"
60 END
```

This program prints 'YES' if a 'Y' is entered and prints 'NO' if anything else is entered.

1 GRAD

Abbreviations: GR., GRA.

See also: DEGREE and RADIAN

Purpose

The GRAD verb is used to change the form of angular values to gradient form.

Use

The **computer** has three forms for representing angular values — decimal degrees, radians, and gradient. These forms are used in specifying the arguments to the SIN, COS, and TAN functions and in returning the results from the ASN, ACS, and ATN functions.

The GRAD function changes the form for all angular values to gradient form until a DEGREE or RADIAN verb is used. Gradient form represents angular measurement in terms of percent gradient, i.e., a 45° angle is a 50^g gradient.

Examples

10 GRAD

20 X = ASN 1

X now has a value of 100, i.e., a 100^g gradient, the Arcsine of 1.

Verbs IF...THEN

- 1 IF condition THEN statement
- 2 IF condition statement

Abbreviations: none for IF, T., TH., THE.

Purpose

The IF... THEN verb pair is used to execute or not execute a statement depending on conditions at the time the program is run.

Use

In the normal running of a BASIC program, statements are executed in the sequence in which they occur. The IF... THEN verb pair allows decisions to be made during execution so that a given statement is executed only when desired. When the condition part of the IF statement is true, the statement is executed; when it is False, the statement is skipped.

The condition part of the IF statement can be any relational expression as described in Chapter 4. It is also possible to use a numeric expression as a condition, although the intent of the statement will be less clear. Any expression which evaluates to zero or a negative number is considered False; any which evaluates to a positive number is considered True.

The statement which follows the THEN may be any BASIC statement, including another IF... THEN. If it is a LET statement, the LET verb itself must appear.

The two forms of the IF statement are identical in action, but the first form is clearer.

Examples

```
10 INPUT "CONTINUE? "; A$
20 IF A$ = "YES" THEN GOTO 10
30 IF A$ = "NO" THEN GOTO 60
40 PRINT "YES OR NO, PLEASE"
50 GOTO 10
60 END
```

This program continues to ask 'CONTINUE?' as long as 'YES' is entered; it stops if 'NO' is entered, and complains otherwise.

1 INPUT input listWhere: input listand: input groupand: var listand: promptis: input groupor: input group , input listis: var listor: prompt , var listor: prompt ; var listis: variableor: variable , var list

is: any string constant

Abbreviations: I., IN., INP., INPU.

See also: INPUT #, READ

Purpose

The INPUT verb is used to enter one or more values from the keyboard.

Use

When you want to enter different values each time a program is run, use the INPUT verb to enter these values from the keyboard.

In its simplest form the INPUT statement does not include a prompt string, instead a question mark is displayed on the left edge of the display. A value is then entered, followed by the **ENTER** key. This value is assigned to the first variable in the list. If other variables are included in the same INPUT statement, this process is repeated until the list is exhausted.

If a prompt is included in the INPUT statement, the process is exactly the same except that, instead of the question mark, the prompt string is displayed at the left edge of the display. If the prompt string is followed by a semicolon, the cursor is positioned immediately following the prompt. If the prompt is followed by a comma, the prompt is displayed, then when a key is pressed the display is cleared and the first character of the input is displayed at the left edge.

When a prompt is specified and there is more than one variable in the list following it, the second and succeeding variables are prompted with the question mark. If a second prompt is included in the list, it is displayed for the variable which immediately follows it.

Verbs
INPUT

If the **ENTER** key is pressed and no input is provided, the variable retains the value it had before the INPUT statement.

Examples

- 10 INPUT A
Clears the display and puts a question mark at the left edge.
- 20 INPUT "A = "; A
Displays 'A =' and waits for input data.
- 30 INPUT "A = ", A
Displays 'A ='.
When data is input 'A =' disappears and the data is displayed starting at left edge.
- 40 INPUT "X = ? "; X, "Y = ? "; Y
Displays 'X = ?' and waits for first input.
After **ENTER** is pressed, display is cleared and 'Y = ?' is displayed at left edge.

- 1 INPUT #
- 2 INPUT # "filename"
- 3 INPUT # var list
- 4 INPUT # "filename"; var list

Where: var list

is: variable

or: variable , var list

Abbreviations: I. #, IN. #, INP. #, INPU. #

See also: INPUT, PRINT #, READ

Purpose

The INPUT # verb is used to enter values from the cassette tape.

Use

PRINT # saves the values of variables on tape. They can then be read back into the same or another program using the INPUT # verb.

With the first form, the values are sequentially read from the tape and assigned to the 26 preallocated storage locations (fixed variables) and A() variables, (A(27) ~). The transfer continues until the values recorded on tape run out or the computer memory is filled to its capacity.

With the second form, the tape is searched for the indicated filename and the variables are loaded as in the first form.

With the third form, if the variable list includes a fixed variable, values are sequentially read from the tape and assigned to the preallocated storage locations, starting at the specified variable.

With the fourth form, the tape is searched for the indicated filename and the variables are loaded as in the third form.

There is a special variable form which may be used in the variable list. It looks like an array variable except that an asterisk is enclosed in the parentheses, e.g., B(*) or F\$(*). This form causes all values of the indicated variable to be restored from the tape; i.e., B (*) restores B (0), B (1), B (2), . . . etc., for as many values as were originally stored. You may not read a single element of an array.

Examples

- 1) 20 INPUT # A
- 2) 20 INPUT # A(3)
- 3) 20 INPUT # "FIL2"; A\$
- 4) 20 INPUT # "FIL3"; G (*)

Reads values from the current position of the tape.

Reads values from the current position of the tape and assigns the values to the variables A(3) ~ A(26) (or C ~ Z) and A(27) ~.

Searches the tape for the file 'FIL2' and reads in values.

Searches the tape for the file 'FIL3' and reads in as many values of G () as are available.

NOTES:

1. When the prerecorded data on tape is transferred to a variable, the data and variable should be coincident in shape (numerical or string variable), size and length. An error (ERROR 8) will result unless they are coincident in size and length. No error will occur when they are not coincident only in shape. In this case, however, the transfer of incorrect data may result when the numerical data is transferred to a string variable or the string data to a numerical variable. Therefore, the data and variable should also be coincident in shape.
2. The data transfer to variables in the fixed variables and/or in the shape of A () terminates when the prerecorded data on tape is out or when the computer memory is filled to capacity.

- 1 LET variable = expression
- 2 variable = expression

Abbreviations: LE.

Purpose

The LET verb is used to assign a value to a variable.

Use

The LET verb assigns the value of the expression to the designated variable. The type of the expression must match that of the variable, i.e. only numeric expressions can be assigned to numeric variables and only string expressions can be assigned to string variables. In order to convert from one type to the other, one of the explicit type conversion functions, STR\$ or VAL, must be used.

The LET verb may be omitted in all LET statements except those which appear in the THEN clause of an IF ... THEN statement. In this one case the LET verb must be used.

Examples

10 I = 10

20 A = 5*I

30 X\$ = STR\$(A)

40 IF I >= 10 THEN LET Y\$ = X\$ + ".00"

Assigns the value 10 to I.

Assigns the value 50 to A.

Assigns the value '50' to X\$.

Assigns the value '50.00' to Y\$.

- 1 LPRINT print expr
- 2 LPRINT print expr , print expr
- 3 LPRINT print list

Where: print list

is: print expr

and: print expr

or: print expr ; print list

is: expression

or: USING clause; expression

The USING clause is described separately under USING

Abbreviations: LP, LPR, LPR!, LPR!.

See also: PAUSE, PRINT, USING, and WAIT

Purpose

The LPRINT verb is used to print information on the printer.

Use

The LPRINT verb is used to print prompting information, results of calculations, etc. The first form of the LPRINT statement prints a single value. If the expression is numeric, the value will be printed at the far right edge of the paper. If it is a string expression, the print is made starting at the far left.

With the second form of the LPRINT statement the paper is divided into two 12 character halves and the two values are printed in each half according to the same rules as above.

With the third form the print always starts at the left edge and each value is printed immediately following the previous value from left to right with no intervening space.

It is possible to cause PRINT statements to work as LPRINT statements. See the PRINT verb for details.

If an LPRINT statement contains more than 24 characters, the first 24 are printed on one line, the next 24 on the next line, and so forth.

Unlike PRINT, there is no halt or wait after execution of an LPRINT statement.

Examples

```
10 A=10: B=20: X$ = "ABCDEF"  
20 LPRINT A  
30 LPRINT X$  
40 LPRINT A, B  
50 LPRINT A; B; X$
```

Paper

```
ABCDEF 10.  
10.20.ABCDEF 10. 20.
```

Verbs
NEXT...

1 **NEXT** numeric variable

Abbreviations: N., NE., NEX.

See also: FOR

Purpose

The **NEXT** verb is used to mark the end of a group of statements which are being repeated in a FOR/NEXT loop.

Use

The use of the **NEXT** verb is described under FOR. The numeric variable in a **NEXT** statement must match the numeric variable in the corresponding FOR.

Examples

```
10 FOR I = 1 TO 10  
20 PRINT I  
30 NEXT I
```

Print the numbers from 1 to 10.

1 ON expression **GOSUB** expression list

Where: expression list is: expression
or: expression , expression list

Abbreviations: O. ; GOS., GOSU.

See also: GOSUB, GOTO, ON ... GOTO

Purpose

The ON ... GOSUB verb is used to execute one of a set of subroutines depending on the value of a control expression.

Use

When the ON ... GOSUB verb is executed the expression between ON and GOSUB is evaluated and reduced to an integer. If the value of the integer is 1, the first subroutine in the list is executed as in a normal GOSUB. If the expression is 2, the second subroutine in the list is executed, and so forth. After the RETURN from the subroutine execution proceeds with the statement which follows the ON ... GOSUB.

If the expression is zero, negative, or larger than the number of subroutines provided in the list, no subroutine is executed and execution proceeds with the next line of the program.

NOTE: Commas may not be used in the expressions following the GOSUB. The computer cannot distinguish between commas in expressions and commas between expressions.

Examples

```
10 INPUT A
20 ON A GOSUB 100,200,300
30 END
100 PRINT "FIRST"
110 RETURN
200 PRINT "SECOND"
210 RETURN
300 PRINT "THIRD"
310 RETURN
```

An input of 1 prints "FIRST"; 2 prints "SECOND"; 3 prints "THIRD". Any other input does not produce any print.

1 ON expression GOTO expression list

Where: expression list is: expression
or: expression, expression list

Abbreviations: O., G., GO., GOT.

See also: GOSUB, GOTO, ON...GOSUB

Purpose

The ON...GOTO verb is used to transfer control to one of a set of locations depending on the value of a control expression.

Use

When the ON...GOTO verb is executed the expression between ON and GOTO is evaluated and reduced to an integer. If the value of the integer is 1, control is transferred to the first location in the list. If the expression is 2, control is transferred to the second location in the list, and so forth.

If the expression is zero, negative, or larger than the number of locations provided in the list, execution proceeds with the next line of the program.

NOTE: Commas may not be used in the expressions following the GOTO. The computer cannot distinguish between commas in expressions and commas between expressions.

Examples

```
10 INPUT A
20 ON A GOTO 100,200,300
30 GOTO 900
100 PRINT "FIRST"
110 GOTO 900
200 PRINT "SECOND"
210 GOTO 900
300 PRINT "THIRD"
310 GOTO 900
900 END
```

An input of 1 prints 'FIRST'; 2 prints 'SECOND'; 3 prints 'THIRD'. Any other input does not produce any print.

- 1 PAUSE print expr
- 2 PAUSE print expr , print expr
- 3 PAUSE print list

Where: print list is: print expr
 or: print expr ; print list
 and: print expr is: expression
 or: USING clause ; expression

The USING clause is described separately under USING

Abbreviations: PAU., PAUS.

See also: LPRINT, PRINT, USING, and WAIT

Purpose

The PAUSE verb is used to print information on the display for a short period.

Use

The PAUSE verb is used to display prompting information, results of calculations, etc. The operation of PAUSE is identical to PRINT except that after PAUSE the computer waits for a short preset interval of about .85 seconds and then continues execution of the program without waiting for the ENTER key or the WAIT interval.

The first form of the PAUSE statement displays a single value. If the expression is numeric, the value is printed at the far right end of the display. If it is a string expression, the display is made starting at the far left.

With the second form of the PAUSE statement the display is divided into two 8 character halves. The two values are displayed in each half according to the same rules as above.

With the third form the display starts at the left edge and each value is displayed immediately following the previous value from left to right with no intervening space.

PAUSE statements are not affected by the PRINT = LPRINT statement (see PRINT).

While it is possible to write PAUSE statements which would display more than 16 characters only the left-most 16 appear in the display. There is no way to see the other characters.

Verbs
PAUSE

Examples

10 A = 10 : B = 20 : X\$ = "ABCDEF"

20 PAUSE A

30 PAUSE X\$

40 PAUSE A, B

50 PAUSE A; B; X\$

Display

	10.
ABCDEF	
10.	20.
10.20.ABCDEF	

- 1 **PRINT** print expr
- 2 **PRINT** print expr , print expr
- 3 **PRINT** print list
- 4 **PRINT** = **LPRINT**
- 5 **PRINT** = **PRINT**

Where: print list is: print expr
 or: print expr ; print list
 and: print expr is: expression
 or: USING clause ; expression

The USING clause is described separately under **USING**

Abbreviations: P., PR., PRI., PRIN.

See also: **LPRINT**, **PAUSE**, **USING**, and **WAIT**

Purpose

The **PRINT** verb is used to print information on the display or on the printer.

Use

The **PRINT** verb is used to display prompting information, results of calculations, etc. The first form of the **PRINT** statement displays a single value. If the expression is numeric, the value is printed at the far right end of the display. If it is a string expression, the display is made starting at the far left.

With the second form of the **PRINT** statement the display is divided into two 8 character halves and the two values are displayed in each half according to the same rules as above.

With the third form the display starts at the left edge and each value is displayed immediately following the previous value from left to right with no intervening space.

The fourth and fifth forms of the **PRINT** statement do no printing. The fourth form causes all **PRINT** statements which follow it in the program to be treated as if they were **LPRINT** statements. The fifth form resets this condition so that the **PRINT** statements will again work with the display.

While it is possible to write **PRINT** statements which would display more than

Verbs
PRINT

16 characters, only the left-most 16 appear in the display. There is no way to see the other characters.

Examples

- 10 A = 10 : B = 20 : X\$ = "ABCDEF"
- 20 PRINT A
- 30 PRINT X\$
- 40 PRINT A, B
- 50 PRINT A; B; X\$

Display

10.
ABCDEF
10. 20.
10.20. ABCDEF

- 1 PRINT #
- 2 PRINT # "filename"
- 3 PRINT # "var list"
- 4 PRINT # "filename" ; var list

Where: var list is: variable
or: variable , var list

Abbreviations: P. #, PR. #, PRI. #, PRIN. #

See also: INPUT #, PRINT, READ

Purpose

The PRINT # verb is used to save values on the cassette tape.

Use

Using PRINT # the values of variables can be saved on tape. These can then be read back into the same or another program using the INPUT # verb.

With the first form, the values of the 26 preallocated variables (variables A ~ Z and A\$ ~ Z\$), A() and A\$() variables are stored on the tape.

Note: Variables A ~ Z and A(1) ~ A(26) are the same.

With the second form, the values are saved on the tape as in the first form under the designated filename.

With the third form, if the variable list includes a fixed variable, the values of the fixed variables starting from the specified variable are saved on tape.

With the fourth form, the values are saved on the tape as in the third form under the designated filename.

There is a special variable form which may be used in the variable list. It looks like an array variable except that an asterisk is enclosed in the parentheses, e.g., B(*) or F\$(*). This form causes all values of the indicated variable to be saved on the tape, i.e., B(*) saves B(0), B(1), B(2), . . . etc., for as many values as are in the array. You may not save a single element of an array.

Verbs
PRINT #

Examples

- 1) 10 PRINT # A
- 2) 10 PRINT # "FIL2"; A\$
- 3) 10 PRINT # "FIL3"; G(*)

Saves values on the tape at the current position.

Saves values on the tape under the filename 'FIL2'.

Saves values of G () on the tape under the filename 'FIL3'.

Note:

A variable above A(27) or a dimensional variable must be secured into the program/data area before the PRINT # command is executed. If the variable is not designated before the PRINT # command, an error (ERROR 3) will result.

1 RADIANT

Abbreviations: RAD., RADI., RADIA.

See also: DEGREE and GRAD

Purpose

The RADIANT verb is used to change the form of angular values to radian form.

Use

The **computer** has three forms for representing angular values — decimal degrees, radians, and gradient. These forms are used in specifying the arguments to the SIN, COS, and TAN functions and in returning the results from the ASN, ACS, and ATN functions.

The RADIANT function changes the form for all angular values to radian form until a DEGREE or GRAD verb is used. Radian form represents angles in terms of the length of the arc with respect to a radius, i.e., 360° is 2 PI radians since the circumference of a circle is 2 PI times the radius.

Examples

10 RADIANT

20 X = ASN 1

X now has a value of 1.570796327 or PI/2, the Arcsine of 1

1 RANDOM

Abbreviations: RA., RAN., RAND., RANDO., etc.

Purpose

The RANDOM verb is used to reset the seed for random number generation.

Use

When random numbers are generated using the RND function, the **computer** begins with a predetermined "seed" or starting number. The RANDOM verb resets this seed to a new randomly determined value.

The starting seed will be the same each time the **computer** is turned on, so the sequence of random numbers generated with RND is the same each time, unless the seed is changed. This is very convenient during the development of a program because it means that the behavior of the program should be the same each time it is run even though it includes a RND function. When you want the numbers to be truly random, the RANDOM statement can be used to make the seed itself random.

Examples

```
10 RANDOM  
20 X = RND 10
```

When run from line 20, the value of X is based on the standard seed. When run from line 10, a new seed is used.

1 READ variable listWhere: variable listis: variableor: variable , variable list

Abbreviations: REA.

See also: DATA, RESTORE

Purpose

The READ verb is used to read values from a DATA statement and assign them to variables.

Use

When assigning initial values to an array, it is convenient to list the values in a DATA statement and use a READ statement in a FOR . . . NEXT loop to load the values into the array. When the first READ is executed, the first value in the first DATA statement is returned. Succeeding READs use succeeding values in the sequential order in which they appear in the program, regardless of how many values are listed in each DATA statement or how many DATA statements are used.

If desired, the values in a DATA statement can be read a second time by using the RESTORE statement.

Examples

```

10 DIM B(10)
20 FOR I = 1 TO 10
30 READ B(I)
40 NEXT I
50 DATA 1, 2, 3, 4, 5, 6
60 DATA 7, 8, 9, 10

```

Sets up an array

Loads the values from the DATA statement into
B () — B (1) is 1, B (2) is 2, B (3) is 3, etc.

Verbs
REM

1 REM remark

Abbreviations: none

Purpose

The REM verb is used to include comments in a program.

Use

Often it is useful to include explanatory comments in a program. These can provide titles, names of authors, dates of last modification, usage notes, reminders about algorithms used, etc. These comments are included by means of the REM statement.

The REM statement has no effect on the program execution and can be included anywhere in the program. Everything following the REM verb in that line is treated as a comment, so the REM verb must be the last statement in a line when multiple statement lines are used.

Examples

```
10 REM THIS LINE HAS NO EFFECT
```

1 RESTORE

2 RESTORE expression

Abbreviations: RES., REST., RESTO., RESTOR.

See also: DATA, READ

Purpose

The RESTORE verb is used to reread values in a DATA statement or to change the order in which these values are read.

Use

In the regular use of the READ verb the **computer** begins reading with the first value in a DATA statement and proceeds sequentially through the remaining values. The first form of the RESTORE statement resets the pointer to the first value of the first DATA statement, so that it can be read again. The second form of the RESTORE statement resets the pointer to the first value of the first DATA statement whose line number is greater than the value of the expression.

Examples

10 DIM B(10)

Sets up an array

20 FOR I = 1 TO 10

30 READ B(I)

Assigns the value 10 to each of the elements of B().

40 RESTORE

50 NEXT I

60 DATA 10

Note: The RESTORE verb must be written at the beginning of the line (just after the line number). It cannot be used with a colon (:) following another statement.

Verbs
RETURN

1 RETURN

Abbreviations: RE., RET., RETU., RETURN.

See also: GOSUB, ON . . . GOSUB

Purpose

The RETURN verb is used at the end of a subroutine to return control to the statement following the originating GOSUB.

Use

A subroutine may have more than one RETURN statement, but the first one executed terminates the execution of the subroutine. The next statement executed will be the one following the GOSUB or ON . . . GOSUB which calls the subroutine. If a RETURN is executed without a GOSUB, an Error 5 will occur.

Examples

```
10 GOSUB 100  
20 END  
100 PRINT "HELLO"  
110 RETURN
```

When run this program prints the word "HELLO" once.

1 STOP

Abbreviations: S., ST., STO.

See also: END; CONT command

Purpose

The STOP verb is used to halt execution of a program for diagnostic purposes.

Use

When the STOP verb is encountered in program execution, the **computer** execution halts and a message is displayed such as 'BREAK IN 200' where 200 is the number of the line containing the STOP. STOP is used during the development of a program to check the flow of the program or examine the state of variables. Execution may be restarted using the CONT command.

Examples

10 STOP

Causes "BREAK IN 10" to appear in the display.

Verbs
TROFF

1 TROFF

Abbreviations : TROF.

See also: TRON

NOTE :

TRON (Trace On) and TROFF (Trace Off) are used to control the execution of a program. When TRON is executed, the program execution is traced. When TROFF is executed, the program execution is not traced.

Purpose

The TROFF verb is used to cancel the trace mode.

Use

Execution of the TROFF verb restores normal execution of the program.

Examples

```
10 TRON
20 FOR I = 1 TO 3
30 NEXT I
40 TROFF
```

When run, this program displays the line numbers 10, 20, 30, 30, 30 and 40 as the is pressed. By pressing the , you can review the line.

1 TRON

Abbreviations : TR., TRO.

See also: TROFF

Purpose



The TRON verb is used to initiate the trace mode.

Use

The trace mode provides assistance in debugging programs. When the trace mode is on, the line number of each statement is displayed **after** each statement is executed. The **computer** then halts and waits for the Down Arrow key to be pressed before moving on to the next statement. The Up Arrow key may be pressed to see the statement which has just been executed. The trace mode continues until a TROFF verb is executed.

Examples

```
10 TRON
20 FOR I = 1 TO 3
30 NEXT I
40 TROFF
```

When run, this program displays the line numbers 10, 20, 30, 30, 30 and 40 as the  is pressed. By pressing the , you can review the line.

Verbs USING

- 1 USING
- 2 USING "editing specification"
- 3 USING character variable

Abbreviations: U., US., USI., USIN.

See also: LPRINT, PAUSE, PRINT

Further guide to the use of USING is provided in Appendix C

Purpose

The USING verb is used to control the format of displayed or printed output.

Use

The USING verb can be used by itself or as a clause within a LPRINT, PAUSE, or PRINT statement. The USING verb establishes a specified format for output which is used for all output which follows until changed by another USING verb.

The editing specification of the USING verb consists of a quoted string composed of some combination of the following editing characters:

- # Right justified numeric field character
 - Decimal point.
- ^ Used to indicate that numbers should be displayed in scientific notation.
- & Left justified alphanumeric field.

For example, "####" is an editing specification for a right justified numeric field with room for 3 digits and the sign. In numeric fields, a location must be included for the sign, even if it will always be positive.

Editing specifications may include more than one field. For example "####&&&&" could be used to print a numeric and a character field next to each other.

If the editing specification is missing, as in the first form, special formatting is turned off and the built-in display rules pertain.

Examples

Display

- 10 A = 125 : X\$ = "ABCDEF"
- 20 PRINT USING "##.## ^"; A
- 30 PRINT USING "&&&&&&"; X\$
- 40 PRINT USING "####&&"; A; X\$

1. 25E 02
ABCDEF
125 ABC

- Notes:
1. When the total number of digits specified with USING exceeds 16 for "PRINT expression", ERROR 7 results.
 2. When the number of digits for the integer part (sign and decimal point included) exceeds 8 while using the fixed decimal point system for "PRINT expression , expression", ERROR 7 results.
When the character string of the expression in the form of "PRINT expression , expression" exceeds 8 columns, the excess part is not displayed.
 3. When the display contents of the form "PRINT expression ; expression" exceeds 16 columns, the excess part is not displayed.

Verbs WAIT

- 1 WAIT
- 2 WAIT expression

Abbreviations: W., WA., WAI.

See also: PAUSE, PRINT

Purpose

The WAIT verb is used to control the length of time that displayed information is shown before program execution continues.

Use

In normal execution the **computer** halts execution after a PRINT command until the **ENTER** key is pressed. The WAIT command causes the **computer** to display for a specified interval and then proceed automatically (similar to the PAUSE verb). The expression which follows the WAIT verb determines the length of the interval. The interval may be set to any value from 0 to 65535. Each increment is about one sixty-fourth of a second. WAIT 0 is too fast to be read reasonably; WAIT 65535 is about 17 minutes. WAIT with no following expression resets the **computer** to the original condition of waiting until the **ENTER** key is pressed.

Examples

10 WAIT 64

Causes PRINT to wait about 1 second.

FUNCTIONS

Pseudovariables

Pseudovariables are a group of functions which take no argument and are used like simple variables wherever required.

1 INKEY\$

INKEY\$ is a string pseudovariable which gives to the specified variable the value of the key pressed while the INKEY\$ function is executed. INKEY\$ is used to respond to the pressing of individual keys without waiting for the **ENTER** key to end the input. The computer just keeps "circling" until it receives a message from the key board.

```
10: A$ = INKEY$
20: B = ASC A$
30: IF B = 0 THEN GOTO 10
40: PRINT B
```

Note: **ENTER**, **SHIFT**, **DEF**, **^**, **v**, **>**, **<**, **MODE**, and **CL** all have a value of NULL.

1 MEM

MEM is a numeric pseudovariable which has the value of the number of characters of program memory remaining. The available program memory will be the total memory less the space consumed by programs and array variables. MEM may also be used as a command.

1 PI

PI is a numeric pseudovariable which has the value of PI. It is identical to the use of the special PI character (π) on the keyboard. Like other numbers the value of PI is kept to 10 digit accuracy (3.141592654).

Numeric Functions

Numeric functions are a group of mathematical operations which take a single numeric value and return a numeric value. They include trigonometric functions, logarithmic functions, and functions which operate on the integer and sign parts of a number. Many dialects of BASIC require that the argument to a function be enclosed in parentheses. The computer does not require these parentheses, except when it is necessary to indicate what part of a more complex expression is to be included in the argument.

LOG 100 + 100 will be interpreted as:

(LOG 100) + 100 not LOG (100 + 100).

1 ABS numeric expression

ABS is a numeric function which returns the absolute value of the numeric argument. The absolute value is the value of a number without regard to its sign. ABS -10 is 10.

1 ACS numeric expression

ACS is a numeric function which returns the arccosine of the numeric argument. The arccosine is the angle whose cosine is equal to the expression. The value returned depends on whether the computer is in decimal degree, radian, or gradient mode for angles. ACS .5 is 60 in the decimal degree mode.

1 ASN numeric expression

ASN is a numeric function which returns the arcsine of the numeric argument. The arcsine is the angle whose sine is equal to the expression. The value returned depends on whether the computer is in decimal degree, radian, or gradient mode for angles. ASN .5 is 30 in the decimal degree mode.

1 **ATN** numeric expression

ATN is a numeric function which returns the arctangent of the numeric argument. The arctangent is the angle whose tangent is equal to the expression. The value returned depends on whether the **computer** is in decimal degree, radian, or gradient mode for angles. ATN 1. is 45 in the decimal degree mode.

1 **COS** numeric expression

COS is a numeric function which returns the cosine of the angle argument. The value returned depends on whether the **computer** is in decimal degree, radian, or gradient mode for angles. COS 60 is .5 in the decimal degree mode.

1 **DEG** numeric expression

The DEG function converts an angle argument in DMS (Degree, Minute, Second) format to DEG (Decimal Degree) form. In DMS format the integer portion of the number represents the degrees, the first and second digits of the decimal represent the minutes, the third and fourth digits of the decimal represent the seconds, and any further digits represent decimal seconds. For example, $55^{\circ} 10' 44.5''$ is represented as 55.10445. In DEG format the integer portion is degrees and the decimal portion is decimal degrees. DEG 55.10445 is 55.17902778.

1 **DMS** numeric expression

DMS is a numeric function which converts an angle argument in DEG format to DMS format (see DEG). DMS 55.17902778 is 55.10445.

Functions
Numeric Functions

1 EXP numeric expression

EXP is a numeric function which returns the value of e (2.718281828 — the base of the natural logarithms) raised to the value of the numeric argument. EXP 1 is 2.718281828.

1 INT numeric expression

INT is a numeric function which returns the integer part of its numeric argument. INT PI is 3.

1 LOG numeric expression

LOG is a numeric function which returns the logarithm to the base 10 of its numeric argument. LOG 100 is 2.

1 LN numeric expression

LN is a numeric function which returns the logarithm to the base e (2.718281828) of its numeric argument. LN 100 is 4.605170186.

1 **RND** numeric expression

RND is a numeric function which generates random numbers. If the value of the argument is less than one but greater than or equal to zero, the random number is less than one and greater than or equal to zero. If the argument is an integer greater than or equal to 1, the result is a random number greater than or equal to 1 and less than or equal to the argument. If the argument is greater than or equal to 1 and not an integer, the result is a random number greater than or equal to 1 and less than or equal to the smallest integer which is larger than the argument: (In this case, the generation of the random number changes depending on the value of the decimal portion of the argument.):

<u>Argument</u>	----- Result -----	
	<u>Lower Bound</u>	<u>Upper Bound</u>
.5	$0 <$	< 1
2	1	2
2.5	1	3

The same sequence of random numbers is normally generated because the same "seed" is used each time the **computer** is turned on. To randomize the seed, see the RANDOM verb.

1 **SGN** numeric expression

SGN is a numeric function which returns a value based on the sign of the argument. If the argument is positive, the result is 1; if the argument is zero, the result is 0; if the argument is negative, the result is -1. SGN -5 is -1.

1 **SIN** numeric expression

SIN is a numeric function which returns the sine of the angle argument. The value returned depends on whether the **computer** is in decimal degree, radian, or gradient mode for angles. SIN 30 is .5.

1 **SQR** numeric expression

SQR is a numeric function which returns the square root of its argument. It is identical to the use of the special square root symbol ($\sqrt{\quad}$) on the keyboard. SQR 4 is 2.

1 **TAN** numeric expression

TAN is a numeric function which returns the tangent of its angle argument. The value returned depends on whether the **computer** is in decimal degree, radian, or gradient mode for angles. TAN 45 is 1.

String Functions

String functions are a group of operations used for manipulating strings. Some take a string argument and return a numeric value. Some take a string argument and return a string. Some take a numeric value and return a string. Some take a string argument and one or two numeric arguments and return a string. Many dialects of BASIC require the argument of a function to be enclosed in parentheses. The **computer** does not require these parentheses, except when it is necessary to indicate what part of a more complex expression is to be included in the argument. String functions with two or three arguments all require the parentheses.

1 **ASC** string expression

ASC is a string function which returns the numeric ASCII code value of the first character in its argument. The chart of ASCII codes and their relationship to characters is given in Appendix B. ASC "A" is 65.

1 **CHR\$** numeric expression

CHR\$ is a string function which returns the character which corresponds to the numeric ASCII code of its argument. The chart of ASCII codes and their relationship to characters is given in Appendix B. CHR\$ 65 is "A".

1 **LEFT\$** (string expression, numeric expression)

LEFT\$ is a string function which returns the leftmost part of the string first argument. The number of characters returned is determined by the numeric expression. LEFT\$ ("ABCDEF", 2) is "AB".

1 **LEN** string expression

LEN is a string function which returns the length of the string argument. LEN "ABCDEF" is 6.

Functions
String Functions

1 MID\$ (string expression , num. exp. 1, num. exp. 2)

MID\$ is a string function which returns a middle portion of the string first argument. The first numeric argument indicates the first character position to be included in the result. The second numeric argument indicates the number of characters that are to be included. MID\$ ("ABCDEF", 2, 3) is "BCD".

1 RIGHT\$ (string expression , numeric expression)

RIGHT\$ is a string function which returns the rightmost part of the string first argument. The number of characters returned is determined by the numeric argument. RIGHT\$ ("ABCDEF", 3) is "DEF".

1 STR\$ numeric expression

STR\$ is a string function which returns a string which is the character representation of its numeric argument. It is the reverse of VAL. STR\$ 1.59 is '1.59'.

1 VAL string expression

VAL is a string function which returns the numeric value of its string argument. It is the reverse of STR\$. The VAL of a non-number is zero. VAL "1.59" is 1.59.

Note: The character-string convertible by VAL function to a numerical value consists of numerals (0 to 9), symbols (+ and -) and a symbol (E) indicating an exponential portion. No other characters and symbols are included. If a character-string includes other characters and symbols, any character-string on the right of that character-string will be ignored. If included in a character-string, a space is usually regarded as non-existing. If, however, a space is included in the portion (on the right of E) corresponding to an exponential part, any character-string on the right of the space will be ignored.

CHAPTER 9 TROUBLESHOOTING

This chapter provides you with some hints on what to do when your **SHARP computer** does not do what you expect it to do. It is divided into two parts — the first part deals with general machine operation and the second with BASIC programming. For each problem there are a series of suggestions provided. You should try each of these, one at a time, until you have fixed the problem.

Machine Operation

If:

You turn on the machine but there is nothing on the display

There is a display, but no response to keystrokes

You have typed in a calculation or answer and get no response

You are running a BASIC program and it displays something, and stops

You enter a calculation and it is displayed in BASIC statement format (colon after the first number)

You get no response from any keys.

Then You Should:

1. Press **BRK ON** to see if AUTO POWER OFF has been activated or press **OFF**.
 2. Replace the batteries.
-
1. Press **CL** to clear.
 2. Press **CA** (**SHIFT** **CL**) to clear.
 3. Press **OFF** and **ON** again.
 4. Press the RESET button.
-
1. Press **ENTER**.
-
1. Press **ENTER**.
-
1. Change the mode from the PROgram into the RUN for calculations.
-
1. Press the RESET button.
 2. If you get no response from any key even when the above operation is performed, enter NEW 0 **ENTER** . (at PRO mode) This will clear the program, data and all reserved contents.

BASIC Debugging

When entering a new BASIC program, it is usual for it **not** to work the first time. Even if you are simply keying in a program that you know is correct, such as those provided in this manual, it is usual to make at least one typing error. If it is a new program of any length, it will probably contain at least one logic error as well. Following are some general hints on how to find and correct your errors.

You run your program and get an error message:

1. Go back to the PROGRAM mode and use the or the keys to recall the line with the error. The cursor will be positioned at the place in the line where the **computer** got confused.
2. If you can't find an obvious error in the way in which the line is written, the problem may lie with the values which are being used. For example, CHR\$(A) will produce an error if A has a value of 1 because CHR\$(1) is an illegal character. Check the values of the variables in either the RUN or the PROGRAM mode by typing in the name of the variable followed by .

You RUN the program and don't get an error message, but it doesn't do what you expect.

3. Check through the program line by line using LIST and the and keys to see if you have entered the program correctly. It is surprising how many errors can be fixed by just taking another look at the program.
4. Think about each line as you go through the program as if you were the computer. Take sample values and try to apply the operation in each line to see if you get the result that you expected.
5. Insert one or more extra PRINT statements in your program to display key values and key locations. Use these to isolate the parts of the program that are working correctly and the location of the error. This approach is also useful for determining which parts of a program have been executed. You can also use STOP to temporarily halt execution at critical points so that several variables can be examined.
6. Use TRON and TROFF, either as commands or directly within the program to trace the flow of the program through individual lines. Stop to examine the contents of critical variables at crucial points. This is a very slow way to find a problem, but sometimes it is also the only way.

CHAPTER 10 MAINTENANCE OF THE COMPUTER

To insure trouble-free operation of your **SHARP** computer, we recommend the following:

- * Always handle the computer carefully as the liquid crystal display is made of glass.
- * Keep the computer in an area free from extreme temperature changes, moisture, or dust. During warm weather, vehicles left in direct sunlight are subject to high temperature build up. Prolonged exposure to high temperature may cause damage to your computer.
- * Use only a soft, dry cloth to clean the computer. Do not use solvents, water, or wet cloths.
- * To avoid battery leakage, remove the batteries when the computer will not be in use for an extended period of time.
- * If service should be required on this equipment, use only a **SHARP** servicing dealer, a **SHARP** approved service facility or **SHARP** repair service where available.
- * If the computer is subjected to strong static electricity or external noise, it may "hang up" (all keys become inoperative). If this occurs, press the **RESET** button while holding down any key. (See Troubleshooting).
- * Keep this manual for further reference.

(NOTE: For maintenance of the **CE-125** please see Chapter 7.)

APPENDIX A ERROR MESSAGES

There are nine different error codes built into the **computer**. The following table will explain these codes.

Error Number	Meaning
1	Syntax error. <ul style="list-style-type: none">This means that the computer can't understand what you have entered. Check for things such as semicolons on the ends of PRINT statements, misspelled words, and incorrect usages. $3 * / 2$
2	Calculation error. <p>Here you have probably done one of three things:</p> <ol style="list-style-type: none">Tried to use too large a number. Calculation results are greater than 9.999999999E 99.Tried to divide by zero. $5 / 0$An illogical calculation has been attempted. $LN - 30 \quad \text{or} \quad ASN 1.5$
3	DIMension error/Augument error. <ul style="list-style-type: none">Array variable already exists. Array specified without first dimensioning it. Array subscript exceeds size of array specified in DIM statement. $DIM B(256)$Illegal function argument. This means that you have tried to make the computer do something that it just can't handle. An example is specifying a top limit for a FOR . . . NEXT loop that is greater than 32767. The reason for the error in this case is that the top limit for a FOR . . . NEXT loop is stored in just two bytes. The maximum, positive, signed integer value that two bytes can hold is 32767. $10 \text{ FOR } A = 1 \text{ TO } 32768$

- 4 Line Number error.
Here you have probably done one of two things:
1. Tried to use an unexsisting line number by the GOTO, GOSUB, RUN, LIST or THEN etc.
 2. Tried to use too large a line number. The maximum line number is 999.
- 5 Nesting error.
Subroutine nesting exceeds 10 levels.
FOR loop nesting exceeds 5 levels.
RETURN verb without a GOSUB, NEXT verb without a FOR, or READ verb without a DATA.
Buffer space exceeded.
- 6 Memory Overflow.
Generally this error happens when you've tried to DIMension an array that is too big for memory. This can also happen when a program becomes too large.
- 7 PRINT USING error.
This means that you have put an illegal format specifier into a USING statement.
- 8 I/O device error.
This error can happen only when you have the optional printer and/or cassette recorder connected to the **computer**. It means that there is a problem with communication between the I/O device and the **computer**.
- 9 Other errors.
This code will be displayed whenever the computer has a problem that isn't covered by one of the other eight error codes. One of the most common causes for this error is trying to access data in a variable in one fashion (e.g. A\$) while the data was originally stored in the variable in another fashion (e.g. A).

APPENDIX B ASCII CHARACTER CODE CHART

The following chart shows the conversion values for use with CHR\$ and ASC. The column shows the first hex character or the first four binary bits, the row shows the second hex character or the second binary bits. The upper left corner of each box contains the decimal number for the character. The lower right shows the character. If no character is shown then it is an illegal character on the computer. For example, the character 'A' is a decimal 65 or a hex 41 or a binary 01000001.

ASCII Character Code Chart

First 4 bits

The computer does not recognize codes in the shaded area. If you enter a code number in the shaded area, an error will result.

Hex Binary	0	1	2	3	4	5	6	7
	0000	0001	0010	0011	0100	0101	0110	0111
0 0000	0 NUL	16	32 SPACE	48 0	64 @	80 P	96 E	112
1 0001	1	17	33 !	49 1	65 A	81 Q	97	113
2 0010	2	18	34 "	50 2	66 B	82 R	98	114
3 0011	3	19	35 #	51 3	67 C	83 S	99	115
4 0100	4	20	36 \$	52 4	68 D	84 T	100	116
5 0101	5	21	37 %	53 5	69 E	85 U	101	117
6 0110	6	22	38 &	54 6	70 F	86 V	102	118
7 0111	7	23	39 □	55 7	71 G	87 W	103	119
8 1000	8	24	40 (56 8	72 H	88 X	104	120
9 1001	9	25	41)	57 9	73 I	89 Y	105	121
A 1010	10	26	42 *	58 :	74 J	90 Z	106	122
B 1011	11	27	43 +	59 ;	75 K	91 √	107	123
C 1100	12	28	44 ,	60 <	76 L	92	108	124
D 1101	13	29	45 -	61 =	77 M	93 π	109	125
E 1110	14	30	46 .	62 >	78 N	94 ^	110	126
F 1111	15	31	47 /	63 ?	79 O	95 -	111	127

Second 4 Bits

APPENDIX C FORMATTING OUTPUT

It is sometimes important or useful to control the format as well as the content of output. The **computer** controls display formats with the **USING** verb. This verb allows you to specify:

- * The number of digits
- * The location of the decimal point
- * Scientific notation format
- * The number of string characters

These different formats are specified with an "output mask". This mask may be a string constant or a string variable:

10: USING "####"

20: M\$ = "&&&&&&"

30: USING M\$

When the **USING** verb is used with no mask, all special formatting is cancelled.

40: USING

A **USING** verb may also be used within a **PRINT** statement:

50: PRINT USING M\$, N

Wherever a **USING** verb is used, it will control the format of all output until a new **USING** verb is encountered.

Numeric Masks

A numeric **USING** mask may only be used to display numeric values, i.e., numeric constants or numeric variables. If a string constant or variable is displayed while a numeric **USING** mask is in effect, the mask will be ignored. A value which is to be displayed must always fit within the space provided by the mask. The mask must reserve space for the sign character, even when the number will always be positive. Thus a mask which shows four display positions may only be used to display numbers with three digits.

Specifying Number of Digits

The desired number of digits is specified using the '#' character. Each '#' in the mask reserves space for one digit. The display or print always contains as many characters as are designated in the mask. The number appears to the far right of this field; the remaining positions to the left are filled with spaces. Positive numbers therefore always have at least one space at the left of the field. Since the computer maintains a maximum of 10 significant digits, no more than 11 '#' characters should be used in a numeric mask.

NOTE: In all examples in this appendix the beginning and end of the displayed field will be marked with a 'I' character to show the size of the field.

<u>Statement</u>	<u>Display</u>
10: USING "####"	(Set the computer to the RUN position, type RUN, and press <input type="button" value="ENTER"/> .)
20: PRINT 25	25
30: PRINT -350	-350
40: PRINT 1000	ERROR 7 IN 40

Notice that the last statement produced an error because 5 positions (4 digits and a sign space) were required, but only 4 were provided in the mask.

Specifying a Decimal Point

A decimal point character, '.', may be included in a numeric mask to indicate the desired location of the decimal point. If the mask provides fewer significant decimal digits than are required for the value to be displayed, the remaining positions to the right will be filled with zeros. If there are more significant decimal digits in the value than in the mask, the extra digits will be truncated (not rounded):

<u>Statement</u>	<u>Display</u>
10: USING "####.##"	
20: PRINT 25	25.00
30: PRINT -350.5	-350.50
40: PRINT 2.547	2.54

Specifying Scientific Notation

A '^' character may be included in the mask to indicate that the number is to be displayed in scientific notation. The '#' and '.' characters are used in the mask to specify the format of the "characteristic" portion of the number, i.e., the part which is displayed to the left of the E. Two '#' characters should always be used to the left of the decimal point to provide for the sign character and one integer digit. The decimal point may be included, but is not required. Up to 9 '#' characters may appear to the right of the decimal point. Following the characteristic portion, the exponentiation character, E, will be displayed followed by one position for the sign and two positions for the exponent. Thus, the smallest scientific notation field would be provided by a mask of "##^" which would print numbers of the form ' 2 E 99'. The largest scientific notation field would be "##.#####^" which would print numbers such as '-1.234567890 E -12'.

<u>Statement</u>	<u>Display</u>
10: USING "###.##^"	
20: PRINT 2.00	2. 00 E 00
30: PRINT -365.278	-3. 65 E 02

Specifying Alphanumeric Masks

String constants and variables are displayed using the '&' character. Each '&' indicates one character in the field to be displayed. The string will be positioned at the left end of this field. If the string is shorter than the field, the remaining spaces to the right will be filled with spaces. If the string is longer than the field, the string will be truncated to the length of the field.

<u>Statement</u>	<u>Display</u>
10: USING "&&&&&&"	
20: PRINT "ABC"	A B C
30: PRINT "ABCDEFGHI"	A B C D E F

Mixed Masks

In most applications a USING mask will contain either all numeric or all string formatting characters. Both may be included in one USING mask, however, for certain purposes. In such cases, each switch from numeric to string formatting characters or vice versa marks the boundary for a different value. Thus, a mask of "#####&&&&" is a specification for displaying two separate values — a numeric value which is allocated 5 positions and a string value which is allocated 4 positions:

<u>Statement</u>	<u>Display</u>
10: PRINT USING "###.##&&"; 25; "CR"	25. 00CR
20: PRINT -5.789; "DB"	-5. 78DB

Remember: Once specified, a USING format is used for all output which follows until cancelled or changed by another USING verb.

APPENDIX D EXPRESSION EVALUATION AND OPERATOR PRIORITY

When the **SHARP computer** is given a complex expression, it evaluates the parts of the expression in a sequence which is determined by the priority of the individual parts of the expression. If you enter the expression:

$$100 / 5 + 45$$

as either a calculation or as a part of a program, the **computer** does not know whether you meant:

$$\frac{100}{5 + 45} = 2 \quad \text{or} \quad \frac{100}{5} + 45 = 65$$

Since the **computer** must have some way to decide between these options, it uses its rules of operator priority. Because division has a higher "priority" than addition (see the next page), it will choose to do the division first and then the addition, i.e., it will choose the second option and return a value of 65 for the expression.

Operator Priority

Operators on the SHARP computer are evaluated with the following priorities from highest to lowest:

1. Parentheses
2. Variables and Pseudovariables
3. Exponentiation (\wedge), when preceded by a multiplication which omits the operator
4. Multiplication which omits the operator
5. Functions
6. Exponentiation (\wedge)
7. Unary minus, negative sign ($-$)
8. Multiplication and division ($*$, $/$)
9. Addition and subtraction ($+$, $-$)
10. Relational operators ($<$, $<=$, $=$, $<>$, $>=$, $>$)
11. Logical operators (AND, OR)

The fourth item refers to usage such as $2A$ or $5C(2)$ in which a multiplication operator is implied, but not shown. The third refers to the combination of this with exponentiation, such as $3A^3$ or $5D^1.5$. In these combined cases the exponentiation will be done first and the multiplication second.

When there are two or more operators at the same priority level the expression will be evaluated from left to right. (The exponentiation will be evaluated from right to left). Note that with $A+B-C$, for example, the answer is the same whether the addition or the subtraction is done first.

When an expression contains multiple nested parentheses, the innermost set is evaluated first and evaluation then proceeds outward.

Sample Evaluation

Starting with the expression:

$$((3+5-2)*6+2) / 10^{\text{LOG } 100}$$

The **computer** would first evaluate the innermost set of parentheses. Since '+' and '-' are at the same level it would move from left to right and would do the addition first:

$$((8-2)*6+2) / 10^{\text{LOG } 100}$$

Then it would do subtraction:

$$((6)*6+2) / 10^{\text{LOG } 100}$$

or:

$$(6*6+2) / 10^{\text{LOG } 100}$$

In the next set of parentheses it would do the multiplication first:

$$(36+2) / 10^{\text{LOG } 100}$$

And then the addition:

$$(38) / 10^{\text{LOG } 100}$$

or:

$$38 / 10^{\text{LOG } 100}$$

Now that the parentheses are cleared, the LOG function has the highest priority so it is done next:

$$38 / 10^2$$

The exponentiation is done next:

$$38 / 100$$

And last of all the division is performed:

$$0.38$$

This is the value of the expression.

APPENDIX E USING PROGRAMS WRITTEN ON OTHER PC MODELS

The SHARP computers, the PC-1211, the PC-1245, the PC-1246, the PC-1246S, the PC-1247, the PC-1248, the PC-1251, and the PC-1500 have many features in common, but there are some significant differences. Sometimes the same features are present, yet act in a slightly different fashion. In order to facilitate the use of programs on different models the following comparison charts are provided.

Verbs and Commands

In the following chart the symbol:

- M indicates that the feature can only be used in manual execution, i.e., as a command;
- P indicates that the feature can only be used within a program;
- B indicates that the feature can be used in both contexts.

When no symbol is shown, the feature is not available on that machine

	PC-1211	PC-1245, PC-1246 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
AREAD	P	P	P	See Note 1
ARUN			P	
BEEP	P	B	B	PC-1500 has tone and duration
CHAIN	P	P	P	
CLEAR	B	B	B	PC-1246/PC-1246S have no BEEP function
CLOAD	M	M	M	
CLOAD?	M	M	M	
CLS			B	
COLOR			B	
CONT	M	M	M	
CSAVE	M	B	B	
CSIZE			B	
CURSOR			B	
DEGREE	B	B	B	
DATA		P	P	

Verbs and Commands (continued)

	PC-1211	PC-1245, PC-1248 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
DEBUG	M			
DIM		B	B	
END	P	P	P	
FOR ... TO ... STEP	P	P	P	
GOSUB	P	P	P	
GOTO	P	B	B	
GCURSOR			B	
GPRINT			B	
GRAD	B	B	B	
GRAPH			B	
IF ... THEN	P	P	P	
INPUT	P	P	P	
INPUT #	B	B	B	
LET	P	P	P	
LF			B	
LINE			B	
LIST	M	M	M	
LLIST		M	M	PC-1211 can emulate with LIST
LOCK			B	
LPRINT		P	B	See Note 2
MERGE	M	M	M	
NEW	M	M	M	
NEXT	P	P	P	
ON ... ERROR			P	
ON ... GOSUB		P	P	
ON ... GOTO		P	P	
PAUSE	P	P	P	
PASS		M		
PRINT	P	P	B	See Note 2
PRINT #	B	B	B	
RADIAN	B	B	B	
RANDOM		B	B	
READ		P	P	
REM	P	P	P	

Pseudovariables

In this and the following charts the features are simply marked with a 'Y' when the machine has the feature.

	PC-1211	PC-1245, PC-1246 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
INKEY\$		Y	Y	PC-1211 has only π
MEM	Y	Y	Y	
PI or π	Y	Y	Y	
TIME			Y	

Numeric Functions

	PC-1211	PC-1245, PC-1246 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
ABS	Y	Y	Y	PC-1211 has only $\sqrt{\quad}$
ACS	Y	Y	Y	
ASN	Y	Y	Y	
ATN	Y	Y	Y	
COS	Y	Y	Y	
DEG	Y	Y	Y	
DMS	Y	Y	Y	
EXP	Y	Y	Y	
INT	Y	Y	Y	
LOG	Y	Y	Y	
LN	Y	Y	Y	
NOT		Y	Y	
POINT			Y	
RND		Y	Y	
SGN	Y	Y	Y	
SIN	Y	Y	Y	
SQR or $\sqrt{\quad}$	Y	Y	Y	
STATUS			Y	
TAN	Y	Y	Y	

APPENDIX E
Feature Comparison

String Functions

	PC-1211	PC-1245, PC-1246 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
ASC		Y	Y	
CHR\$		Y	Y	
LEFT\$		Y	Y	
LEN		Y	Y	
MID\$		Y	Y	
RIGHT\$		Y	Y	
STR\$		Y	Y	
VAL		Y	Y	

Operators

	PC-1211	PC-1245, PC-1246 PC-1246S, PC-1247 PC-1248, PC-1251	PC-1500	Comments
^	Y	Y	Y	
*, /, +, -	Y	Y	Y	
>, >=, =, <>, <=, <	Y	Y	Y	
AND, OR,		Y	Y	
&		Y	Y	

Precaution for using programs developed for the PC-1251

Although the BASIC statements of the PC-1246S/1248 are identical to those of the PC-1251, the number of display columns differ. As a result, when programs created for the PC-1251 are executed on the PC-1246S/1248, problems may occur in the statements related to the display such as "PRINT", "PAUSE", "INPUT", etc. Therefore in these instances, the programs must be modified.

1. When the total number of columns exceed 16 with a USING format in the PRINT expression, ERROR 7 results.

Example: 10: USING "#####.#####"
17 columns or more

20: PRINT A

Note: When the total number of columns specified in the integer part exceed 11 including the sign digit, the excess part is ignored and the integer part is regarded as 11 digits in the **computer**.

Examples:

1) 10: USING "#####."
This format does not cause an error.

2) 10: USING "#####.####"
This format also does not cause an error.

Integer part: 11 digits, Decimal point: 1 digit and Decimal part: 4 digits

Total: 16 digits (less than 17 digits)

3) 10: USING "#####.#####"
This format causes ERROR 7.

(Total number of digit is greater than 16.)

- Change the USING format to within 16 columns.

2. When the integer part exceeds 8 columns with a USING format in the PRINT expression, expression, ERROR 7 results.

Example: 10: USING "#####.##"
9 columns or more

20: PRINT A, B

- Change the USING format to within 8 columns.

APPENDIX E
Feature Comparison

3. When a message of the form INPUT ""; A exceeds 15 columns, the first part of the message is not displayed.
 - Shorten the message.
4. When the display contents of the form PRINT expression ; expression ; expression, exceeds 16 columns, when the character string of the expression in the form of PRINT expression ; expression exceeds 8 columns, or when a message of the form INPUT ""; A exceeds 16 columns, the excess part is not displayed.
 - Rewrite so that the message or results fit.
5. The **PC-1246S** has no BEEP function. No sound will be generated by programs using the BEEP command, although this does not cause an error.

Precaution for using programs developed for the PC-1245

1. The program/data area of the **PC-1246S** (1278 Bytes) is smaller than that of the **PC-1245** (1486 Bytes).
Note that the program written on the **PC-1245** whose capacity exceeds that of the **PC-1246S** cannot be used on the **PC-1246S**.
2. The **PC-1246S** has no BEEP function. No sound will be generated by programs using the BEEP command, although this does not cause an error.

APPENDIX F NUMERIC PRECISION ON THE COMPUTER

Accuracy in Computations

While the **computer** displays the results of calculations to an accuracy of 10 digits, 12 digits are used internally in calculations to provide additional accuracy. For example: $5/9$ yields $5.55555555555E-01$

internally which is rounded to the 10th digit and displayed externally as
 $5.55555556E-01$

Similarly,

$$5/9 * 9 \text{ yields } 4.99999999999E 00$$

internally and when this is rounded to 10 digits externally, the display will show
 5.

The function employs an approximation algorithm.

For example:

$$\text{SIN } 30 \text{ yields } 5.00000000001E-01$$

internally and when this is rounded to 10 digits externally, the display will show
 0.5

This is very significant in the logical expression.

Since the internal value is used in the logical expression,

$$\text{SIN } 30 = 0.5$$

will be taken as False (0).

Therefore, if you use a logical expression in an IF statement, first enter the result into a variable and then compare. The rounding occurs when the value is assigned to a variable.

```

10: INPUT A
20: B = SIN A
30: IF B = 0.5 THEN...
    :
```

APPENDIX F
Numeric Precision

Special Limits

In addition to the general limits described above and in Chapter 4, certain functions of the computer have their own special limits. These are shown in the chart below.

Functions	Dynamic range
$y \wedge x$ (y^x)	$-1 \times 10^{100} < x \log y < 100$ $\left(\begin{array}{l} y=0, x \leq 0: \text{ERROR 2} \\ y=0, x > 0: 0 \\ y < 0, x \neq \text{integer: ERROR 2} \end{array} \right)$ (Ex: $0 \wedge 0$ ENTER → ERROR 2 $0 \wedge 5$ ENTER → 0 $(-4) \wedge 0.5$ ENTER → ERROR 2) The value of Y can be negative only if X is an integer.
SIN x COS x TAN x	DEG: $ x < 1 \times 10^{10}$ RAD: $ x < \frac{\pi}{180} \times 10^{10}$ GRAD: $ x < \frac{10}{9} \times 10^{10}$ In TAN x, however, the following cases are excluded. DEG: $ x = 90 (2n-1)$ RAD: $ x = \frac{\pi}{2} (2n-1)$ GRAD: $ x = 100 (2n-1)$ (n: integer)
ASN x (SIN ⁻¹ x) ACS x (COS ⁻¹ x)	$-1 \leq x \leq 1$
ATN x (TAN ⁻¹ x)	$ x < 1 \times 10^{100}$
LN x LOG x	$1 \times 10^{-99} \leq x < 1 \times 10^{100}$
EXP x	$-1 \times 10^{100} < x \leq 230.2585092$
\sqrt{x}	$0 \leq x < 1 \times 10^{100}$

Functions other than those shown above can be calculated only when x stays within the following range.

$$1 \times 10^{-99} \leq |x| < 1 \times 10^{100} \text{ and } 0$$

As a rule, the error of functional calculations is less than ± 1 at the lowest digit of a displayed numerical value (at the lowest digit of mantissa in the case of scientific notation system) within the above calculation range.

APPENDIX G SPECIFICATIONS

Model:	PC-1246S/PC-1248 Pocket Computer	
Processor:	4 bit CMOS CPU	
Programming Language:	BASIC	
Memory Capacity:	System ROM:	About 17.4 K Bytes
	RAM	
	System	About 500 Bytes
	User	
	Fixed Memory Area (A ~ Z, A\$ ~ Z\$)	208 Bytes
	Program/Data Area	1278 Bytes (PC-1246S), 7422 Bytes (PC-1248)
Stack:	Sub-routine: 10 stacks	Function: 16 stacks
	FOR-NEXT: 5 stacks	Data: 8 stacks
Operators:	Addition, subtraction, multiplication, division, exponentiation, trigonometric and inverse trigonometric functions, logarithmic and exponential functions, angle conversion, square root, sign, absolute, integer, relational operators, logical operators.	
Numeric Precision:	10 digits (mantissa) + 2 digits (exponent).	
Editing Features:	Cursor left and right, line up and down, character insert, character delete.	
Memory Protection:	CMOS Battery backup.	
Display:	16 character liquid crystal display with 5 x 7 dot characters.	
Keys:	54 keys: Alphabetic, numeric, special symbols, and functions. Numeric pad. User defined keys.	
Power Supply:	6.0V DC Lithium cells.	
	Type: CR-2032	
Power Consumption:	6.0V DC @ 0.05W	
	Cells are sufficient for approximately 120 hours of continuous operation in normal circumstances. (Based on 10 minutes of operation or program execution and 50 minutes of display per hour at a temperature of 20°C)	
	<ul style="list-style-type: none"> • The operation time varies slightly depending on usage and the type of battery used. 	

APPENDIX G
Specifications

Operating Temperature: 0°C ~ 40°C (32°F ~ 104°F).
Dimensions: 135(W) x 70(D) x 11(H) mm.
5-5/16"(W) x 2-3/4"(D) x 7/16"(H)
Weight: Approximately 85g (0.19 lb) (with cells)
Accessories: Hard cover, two lithium cells (built-in), and operation manual

Program Examples

Probably you have acquired knowledge on a number of program commands as you have progressed up to this page. It is necessary, however, to generate actual programs by yourself in addition to those given in the instruction manual, so that you can generate programs freely using BASIC language. Like driving a car or playing tennis that can be improved by actual practice, you can improve your programming only by generating as many programs as possible regardless of your skill. It is also important for you to refer to programs generated by others. For your reference, the following pages contain a variety of programs using BASIC commands.

(Sharp Corporation and/or its subsidiaries assume no responsibilities or obligations to any losses or damages that could arise through the use of the software programs employed in this instruction manual.)

Notes on the use of the PC-1246S

The PC-1246S has no BEEP function. No sound will be generated by programs using the BEEP command, although this does not cause an error.

Notes on the use of the CE-125

When the computer is used while connected to printer/microcassette recorder CE-125, the microcassette tape supplied with the CE-125 cannot be used as is. The 20 programs recorded on this tape were developed for the PC-1251. The program contents as well as program lists for 9 of these programs are given in the PC-1251 Instruction Manual and those for the remaining 11 are given in the CE-125 Instruction Manual. The contents of the program in the Program Examples are identical to the programs given in the PC-1251 Instruction Manual. However, after reading a program from the microcassette tape mentioned above, it can be used if certain portions of the program list are modified. **In the Program Examples, the portions which differ from the program lists recorded on the tape are underlined.**

Further, when reading a program given in the CE-125 Instruction Manual from the tape, the portions to be modified are summarized at the end of the Program Examples and can be used for reference.

CONTENTS

(program title)	(page)
● NEWTON'S METHOD FOR FINDING ROOTS OF EQUATIONS	163
● AVERAGE, VARIANCE, AND STANDARD DEVIATION	167
● INTERSECTION BETWEEN CIRCLES AND STRAIGHT LINES	172
● NUMBER OF DAYS CALCULATION	177
● TYRING PRACTICE	181
● SOFTLANDING GAME	185
● MEMORY CHECKER	189
● BUGHUNT	194
● DOUBLE ROTATION	199
● Modification Summary of the CE-125 Program Examples	203

Showing the bytes used in each program

The number of bytes used in each program is shown at the end of each program listing.

The way to find this out is as follows:

RUN mode

1) CLEAR

2) 1278 — MEM → number of bytes. (PC-1246S)

7422 — MEM → number of bytes. (PC-1248)

Program Title: **NEWTON'S METHOD FOR FINDING ROOTS OF EQUATIONS**

OVERVIEW (mathematical)

Finding the roots of equations is usually troublesome, but by using Newton's Method the approximate roots of equations can be found.

When 1 root is found, depending on the interval width, by using Newton's Method the starting point automatically changes.

CONTENTS

$$X_{n+1} = X_n - \frac{f(X_n)}{f'(X_n)}$$

If the absolute value of the distance between X_n and X_{n+1} is less than 10^{-8} , X_n is considered a root and is displayed. Here the first derivative is defined in the following way:


$$f'(X) = \frac{f(X+h) - f(X)}{h} \quad (h \text{ is the minute interval})$$

Change E-8 in line 340 to change the value for 10^{-8} .

INSTRUCTIONS

INPUT

- Starting point
- Minute interval
- Interval



OUTPUTS

Root value (by pressing the **ENTER** key, the next interval's root is found)

EXAMPLE

$x^3 - 2x^2 - x + 2 = 0$ (the roots are $-1, 1, 2$)

- starting point = 0
- minute interval = 10^{-4}
- interval = 0.5

The above values are used in the calculation.

The functions are to be written into lines after 500 as subroutines.

How to type in the example:



1. Go into PRO mode by operating the mode change key.
2. $500B = ((X-2) * X-1) * X+2$ [ENTER]
- 510 RETURN [ENTER] That is all that had to be done.

Note: This program adopts the basic algorithm of the Newton method. Multiplied root may be obtained, but it occurs that one part of the root is not displayed.

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	[DEF] [A]	STARTING POINT = _	Waiting for starting point input
2	0 [ENTER]	MINUTE INTV. = _	Waiting for minute interval input
3	0.0001 [ENTER]	INTERVAL = _	Waiting for interval width input
4	0.5 [ENTER]		2. Display of roots
5	[ENTER]		1. By repeatedly pressing the [ENTER] key the roots of the function are found.
6	[ENTER]		-1.
7	[ENTER]		1.
8	[ENTER]		-1.
9	[ENTER]		-1.
10	[ENTER]		-1.
11	[ENTER]		2.
	⋮	⋮	
	⋮	⋮	
	⋮	⋮	

FLOWCHART



PROGRAM LIST

```

10:"A": INPUT "STARTING
    POINT=";A
20:INPUT "MINUTE INTV.="
    ";A
30:INPUT "INTERVAL=";W
40:G=V:F=V:Z=0
50:IF Z=0 GOTO 70
60:G=G-W:C=G;GOTO 80
70:C=G:Z=1
80:GOSUB 300
90:F=F+W:C=F
100:GOSUB 300
110:GOTO 50
120:END
300:X=C:GOSUB 500
310:Y=B:X=A+C
320:GOSUB 500
330:D=C:C=D-A*Y/(B-Y)
340:IF ABS(D-C)>=E-8
    GOTO 300
350:BEEP 3: PRINT C
360:RETURN
500:B=((X-2)*X-1)*X+2
510:RETURN
    
```

255

MEMORY CONTENTS

A	Minute interval
B	$f(x)$
C	X_0
D	$f(x+h)$
E	
F	✓
G	✓
H	
I	
J	
K	
L	
M	
N	
O	
P	
Q	
R	
S	
T	
U	
V	Starting point
W	Interval
X	x
Y	$f(x)$
Z	Initial flag

Program Title: **AVERAGE, VARIANCE AND STANDARD DEVIATION**

OVERVIEW

If the data are input, the total sum, average, variance, and standard deviation will be calculated for you. Revision of input data as well as data with weights is possible.

CONTENTS

Total sum $\Sigma x_i \cdot f_i$

Standard deviation $\sigma = \sqrt{\sigma^2}$

Average $\bar{x} = \frac{\Sigma x_i \cdot f_i}{\Sigma f_i}$

Variance $\sigma^2 = \frac{\Sigma (x_i - \bar{x})^2 f_i}{\Sigma f_i - 1}$

Number of data entries (up to 50)

(when there are no weights $f_i = 1$)

INSTRUCTIONS

1. At **DEF** **A**, select whether or not there are any weights, then input the data.
2. **DEF** **B** is used to find any revision positions in the data. **DEF** **C** is used to revise the data.
3. The total sum, average, variance, and standard deviation will be calculated with **DEF** **D**.

EXAMPLE

x_i	14.1	14.2	14.3	14.4	14.5
f_i	8	19	23	15	10

(data with weights)

KEY OPERATION SEQUENCE






Step No.	Key Input	Display	Remarks
1	DEF A	NO. OF DATA = _	Waiting for number of data input
2	5 ENTER	WEIGHTS YES = 1/NO = 2? _	Waiting for the selection of weights/no weights.
3	1 ENTER	X (1) = ?	
4	14.1 ENTER	F (1) = ?	
5	8 ENTER	X (2) = ? : :	
12	14.5 ENTER	F (5) = ?	
13	10 ENTER	>	End of the process

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF B	X (1) = 14.1	
2	ENTER	F (1) = 8	
3	ENTER	X (2) = 14.1	DEF C is used to input the revised values when data errors are found
4	DEF C	X (2) =	
		REVISION VALUE = _	Revised value is input
5	14.2 ENTER	F (2) = 19	
	ENTER		
		⋮	
		⋮	
1	DEF D	TOTAL SUM	
2	ENTER	1072.5	
3	ENTER	MEAN VALUE	
4	ENTER	14.3	
5	ENTER	VARIANCE	
6	ENTER	1.432432432E-02	
7	ENTER	STD. DEV.	Display of standard deviation
8	ENTER	1.196842683E-01	
9	ENTER	>	Processing finished

FLOWCHART

STATISTICS WITH MICRO 17.10



PROGRAM LIST

```

10: "A": CLEAR : WAIT 0
20: INPUT "NO. OF DATA="
   IP
30: WAIT 60: PRINT "WEIG
   HTS": INPUT "YES=1/N
   0=2 ? "A: WAIT
40: IF A=2 DIM X(P-1):
   GOTO 70
50: IF A=1 DIM X(P-1):F(
   P-1): GOTO 70
60: GOTO 30
70: FOR I=0 TO P-1
80: B$="X(" + STR$(I+1)+
   ")="
85: PAUSE B$: INPUT X(I)
   : GOTO 100
90: GOTO 85
100: IF A=2 GOTO 150
120: B$="F(" + STR$(I+1)+
   ")="
130: PAUSE B$: INPUT F(I)
   : GOTO 150
140: GOTO 130
150: NEXT I: END
200: "B": WAIT : I=0
210: B$="X(" + STR$(I+1)+
   ")=": J=1: PRINT B$: X
   (I)
230: IF A=1 LET B$="F(" +
   STR$(I+1)+")=":
   PRINT B$: F(I): J=2
240: I=I+1
250: IF I=P END
255: GOTO 210
260: "C": PAUSE B$: IF
   LEFT$(B$,1)="X"
   INPUT "REVISION VALU
   E=": X(I): GOTO 290
270: IF LEFT$(B$,1)="F"
   INPUT "REVISION VALU
   E=": F(I): GOTO 290
280: GOTO 250
290: IF J=1 GOTO 230
291: GOTO 210
300: "D": N=0: T=0: S=0: FOR
   I=0 TO P-1: X=X(I)
305: F=1: IF A=1 LET F=F(
   I)
310: N=N+F: T=T+F*X: S=S+F*
   X*X: NEXT I
400: WAIT : X=T/N: Q=(S-N*X
   *X)/(N-1): S=SQ:
   PRINT "TOTAL SUM":
   PRINT I: PRINT "MEAN
   VALUE": PRINT X

```

```

410: PRINT "VARIANCE":
   PRINT Q: PRINT "STD.
   DEV.": PRINT S: END

```

649

MEMORY CONTENTS

A	✓
B\$	✓
C	
D	
E	
F	✓
G	
H	
I	✓
J	Flag
K	
L	
M	
N	✓
O	
P	Data number
Q	Variance
R	
S	Standard deviation
T	Total sum
U	
V	
W	
X	Average
Y	
Z	
X (P-1)	Data
F (P-1)	Data

Program Title: **INTERSECTION BETWEEN CIRCLES AND STRAIGHT LINES**

OVERVIEW


The points of intersection between circles and straight lines in the X-Y plane are found.

CONTENTS

The 2 points of intersection between a circle and a straight line are P and Q.

(Note) The angles are in degrees, minutes, and seconds and are to be input in the following way:

123.1423 = 123 degrees 14 minutes 23 seconds.




INSTRUCTIONS

1. If the straight line is determined by 2 points, **DEF** **A** is used.
If the line is determined by 1 point and 1 direction angle, **DEF** **B** is used.
2. After the data are input, the results are displayed.

EXAMPLE

$X_1 = -50$
 $Y_1 = 0$
 $X_2 = 50$ $X_P = 0$
 $Y_2 = 100$ $Y_P = 50$
 $X_0 = 50$ $X_Q = 50$
 $Y_0 = 50$ $Y_Q = 100$
 $R = 50$
 $\alpha = 45^\circ$



(Note) The coordinate values are accurate up to 5 decimal places.



KEY OPERATION SEQUENCE
(when 2 points on the line are known)

Step No.	Key Input	Display	Remarks
1	DEF A	X0 = _	
2	50 ENTER	Y0 = _	
3	50 ENTER	R = _	
4	50 ENTER	X1 = _	
5	-50 ENTER	Y1 = _	
6	0 ENTER	X2 = _	
7	50 ENTER	Y2 = _	
8	100 ENTER	P-X 0.0000	(x_p, y_p)
9	ENTER	P-Y 49.9999	
10	ENTER	Q-X 50.0000	(x_q, y_q)
11	ENTER	Q-Y 100.0000	
12	ENTER	>	END

(when 1 point on the line and 1 direction angle are known)

Step No.	Key Input	Display	Remarks
1	DEF B	$X0 = _$	
2	50 ENTER	$Y0 = _$	
3	50 ENTER	$R = _$	
4	50 ENTER	$X1 = _$	
5	-50 ENTER	$Y1 = _$	
6	0 ENTER	$A = _$	
7	45 ENTER	P-X 0.0000	(x_p, y_p)
8	ENTER	P-Y 49.9999	
9	ENTER	Q-X 50.0000	(x_q, y_q)
10	ENTER	Q-Y 100.0000	
11	ENTER	>	END

FLOWCHART



PROGRAM LIST

MEMORY CONTENTS

TRANFORMER

```

10:"A":J=0: GOTO 30
20:"B":J=1
30:DEGREE : INPUT "X0="
  "A,"Y0=";"B,"R=";"C
40:INPUT "X1=";"D,"Y1="
  "E
50:IF J<>0 INPUT "A=";
  H:H= DEG H: GOTO 90
60:INPUT "X2=";"I;"B;"Y2="
  "G
70:X=F-D:Y=G-E: GOSUB 5
  00
80:H=X
90:X=A-D:Y=B-E: GOSUB 5
  00
100:K=W* SIN(X/H)
110:L= ACS (K/C)
120:M=H-90-L:N=H-90+L
130:GOSUB 600
140:PRINT USING "#####.
  ####";"P-X";Q: PRINT
  "P-Y";P
150:M=N: GOSUB 600
160:PRINT "Q-X";Q: PRINT
  "Q-Y";P
170:END
500:W=√(X*X+Y*Y)
510:X= ACS (X/W): IF Y<0
  LET X=360-X
520:RETURN
600:Q=A+C* COS M:P=B+C*
  SIN M: RETURN
351
  
```

A	X ₀
B	Y ₀
C	R
D	X ₁
E	Y ₁
F	X ₂
G	Y ₂
H	✓
I	
J	✓
K	h
L	α
M	QP
N	QQ
O	XP, XQ
P	YP, YQ
Q	
R	
S	
T	
U	
V	
W	L
X	ΔX, θ
Y	ΔY
Z	

Program Title: NUMBER OF DAYS CALCULATION

OVERVIEW

How many days has it been since you were born?

This program is convenient for answering such questions. By setting a certain day, this program will output the number of days that have passed since that day.

CONTENTS

[Instructions]

BASE YEAR
MONTH
DAY
TARGET YEAR
MONTH
DAY

To end the program, type in in place of the year.

[Example]

from 1976 year 10 month 5 day
to 1982 year 6 month 4 day : 2068 days
to 1985 year 1 month 1 day : 3010 days



Note: Number of days calculated by this program doesn't include the base day. If you want the number that includes the base day, please change the program as follows:

```
140:WAIT : USING : PRINT  
"DAYS=",X+1
```

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF A	START YEAR =	
2	1976 ENTER	MONTH =	Base date 1976 year 10 month 5 day input
3	10 ENTER	DAY =	
4	5 ENTER	END YEAR =	
5	1982 ENTER	MONTH =	Target date 1982 year 6 month 4 day input
6	6 ENTER	DAY =	
7	4 ENTER	DAYS = 2068	
8	ENTER	END YEAR =	
9	1985 ENTER	MONTH =	Target date 1985 year 1 month 1 day input
10	1 ENTER	DAY =	
11	1 ENTER	DAYS = 3010	
12	ENTER	END YEAR =	
13	DEF Z	>	

FLOWCHART



PROGRAM LIST

MEMORY CONTENTS

```

10:"A"
20:INPUT "START YEAR=";
R,"MONTH=";S,"DAY=";
T
30:INPUT "END YEAR=";F,
"MONTH=";V,"DAY=";W
50:H=R
60:G=S:I=T
70:GOSUB 500
80:J=I
100:H=F
110:G=V:I=W
120:GOSUB 500
130:X=I-J
140:WAIT : USING : PRINT
"DAYS=";X
150:GOTO 30
500:IF G-3>=0 LET G=G+1:
GOTO 520
510:G=G+13:H=H-1
520:I=INT (365.25*H)+
INT (30.6*G)+I
530:I=I-INT (H/100)+
INT (H/400)-306-122:
RETURN
600:"Z": END
    
```

270

A	
B	
C	
D	
E	
F	Year (after calculation)
G	✓
H	✓
I	✓
J	✓
K	
L	
M	
N	
O	
P	
Q	
R	Start year
S	Month of base date
T	Day of base date
U	
V	Month of target date
W	Day of target date
X	Number of days
Y	
Z	

OVERVIEW

Quick key operation!

How fast and accurate is your typing?

If you practice with this program, it will make programming much easier for you. Improve your skill!

CONTENTS (such as calculation contents)

The number of characters (4 ~ 6) is randomly chosen.

The character arrangement (A ~ Z) is done randomly.

The allotted time depends on the number of characters and the grade level.

3 is the shortest time allotment while 1 is the longest.

INSTRUCTIONS

After the buzzer sounds 4 to 6 characters will be displayed. You are to type in the same characters within the allotted time.

If they are all correct, you get 10 points.

If more than half are correct, you get 5 points.

After the allotted time is over, the next problem is displayed. The allotted time depends on the grade, which has three levels (1, 2, 3).

3 is the shortest time allotment while 1 is the longest.


Point competition is done within the same grade category.

There are 10 problems, making the maximum score 100 points.

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF Z	GRADE (1, 2, 3)?	Grade input to play in
2	1 ENTER	A Z B D C	1st question and answer
3	A	A Z B D C A	1st question answered
4	Z	A Z B D C A Z	2nd question
	⋮		
		YOUR - SCORE = 80	After the 10 questions are answered the score is displayed.
		YOUR SCORE BEST	If your score is higher than the high score the guidance is displayed.
		>	
1	DEF A	HIGH - SCORE = 80	When you want to play in the same grade
		B W V S	
2	B	B W V S B	
	⋮		
	⋮	YOUR - SCORE = 60	
		>	

FLOWCHART



PROGRAM LIST

001010000011

```

10:"Z": CLEAR : DIM B$(
5),C$(5): RANDOM
15:INPUT "GRADE(1,2,3)?
":L: WAIT 0
17:IF (L=1)+(L=2)+(L=3)
<>1 THEN 15
18:GOTO 30
20:"A": WAIT 0:P=0:
PAUSE "HIGH-SCORE=":
X
30:FOR S=1 TO 10
40:B= RND 4+2:Y$="":R=
INT (B/2)
50:FOR C=0 TO B-1:C$(C)
=" "
60:D= RND 26:B$(C)=
CHR$(D+64):Y$=Y$+
CHR$(D+64): NEXT C
:A$=""
70:BEEP 3:E=0: WAIT 30:
USING "#####"
80:FOR W=1 TO B*10/L:
PRINT Y$:A$: IF E=B
LET W=B*20/L: GOTO 1
00
85:C$(E)= INKEY$ : IF C
$(E)=" THEN 100
87:A$=A$+C$(E)
90:E=E+1
100:NEXT W:Q=0
110:FOR W=0 TO B-1: IF B
$(W)=C$(W) LET Q=Q+1
120:NEXT W: IF Q<=R THEN
150
130:IF Q=B LET P=P+10:
GOTO 150
140:P=P+5
150:NEXT S: USING : BEEP
3: PAUSE "YOUR-SCORE
=":P

```

```

160:IF P>X LET X=P: WAIT
100: PRINT "YOUR SCO
RE BEST"

```

170:END

467

MEMORY CONTENTS

A\$	✓
B	✓
C	Loop counter
D	✓
E	✓
F	
G	
H	
I	
J	
K	
L	Grade
M	
N	
O	
P	Score
Q	✓
R	✓
S	Loop counter
T	
U	
V	
W	Loop counter
X	High score
Y\$	
Z	
B\$(5)	✓
C\$(5)	✓

OVERVIEW

This game involves landing a rocket, with only a limited amount of fuel, as softly as possible. The rocket is in free fall. The engine is used to slow down the free falling rocket. If ignition takes place too soon or too much fuel is used, then the rocket is thrust back out into space and becomes dust around the planet. If all the fuel is burned up, the rocket hits the planet and blows up. The aim is to land the rocket as softly as possible by controlling the engines while watching how much fuel is burned.

CONTENTS

Gravity is set to be $5 \text{ m}/(\text{unit time})^2$.

If 5 units of fuel per a unit time are burnt, then gravity is offset.

Equations

$$H = H_0 + V_0 t + \frac{1}{2} a t^2$$

$$V = V_0 + a t$$

$$V^2 = V_0^2 + 2aH$$

$$H_0 = 500, V_0 = -50, F_0 = 200$$

H : height

V : speed

a : gravitational
acceleration

t : time

H_0 : initial height

V_0 : initial speed

F_0 : initial fuel

F : fuel burned

The initial height, initial fuel level, and the wait time is stored in line 30 as data. By changing these values the above variables can be changed.


INSTRUCTIONS

1. The program is started by pressing **DEF** **A** . Press **0** ~ **9** keys to adjust the amount of fuel used to land the rocket.

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF A	***START***	
2	Keys 0 ~ 9 designate fuel burned in unit time	500 450 200 0	Height, speed, fuel left and fuel burnt in unit time are displayed.
	9	452 46 191 9	
	⋮	⋮	⋮
	⋮	Repeat	⋮
	⋮	⋮	⋮
	(If successful)	SUCCESS!!	
		FUEL LEFT: F = 15	
	(If failed)	GOOD BYE!!	
		REPLAY (Y/N)?	Wait for input on whether you wish to play again
	Y		Play again
	N	>	End

FLOWCHART



PROGRAM LIST

```

10:"A": WAIT 50: CLEAR
   : USING :S=-50:A=0:D
   $=" "
20:BEEP 3: PRINT " ***
   START ***"
30:DATA "TIME=",50,"FUE
   L=",200,"HEIGHT=",50
   0
40:RESTORE
50:READ B$,W,B$,F,B$,H
60:WAIT W
70:PRINT USING "####":H
   :S:F:C
80:IF F<=0 GOTO 170
90:BEEP 1:D$= INKEY$
100:IF D$=" " LET C=A:
   GOTO 130
110:C= VAL D$
120:A=C
130:IF C>F LET C=F
140:F=F-C:X=C-5:H=H+S+X/
   2:S=S+X
150:IF H>0 GOTO 70
160:IF (< ABS H<5)+(< ABS
   S<5)=2 BEEP 5: PRINT
   "SUCCESS!!": GOTO 18
   0
170:BEEP 3: PRINT "GOOD
   BYE!!": GOTO 190
180:WAIT 150: PRINT
   USING "####": "FUEL L
   EFT:F=":F
190:WAIT 50: PRINT "REPL
   AY (Y/N) ?":Z$=
   INKEY$
200:IF (Z$="Y")+ (Z$="N")
   <>1 GOTO 190
210:IF Z$="Y" GOTO 10
220:END

```

413

MEMORY CONTENTS

A	✓
B\$	✓
C	Fuel burned
D\$	Fuel burned
E	
F	Initial fuel level, fuel left
G	
H	Initial height, height
I	
J	
K	
L	
M	
N	
O	
P	
Q	
R	
S	Speed
T	
U	
V	
W	Wait time
X	✓
Y	
Z\$	✓


Program Title: MEMORY CHECKER

OVERVIEW

A line of 12 characters will be displayed on the screen for approx. 5 seconds. Your memory will be tested by how well you input the above line after it has disappeared.

CONTENTS

The following type of line will be displayed for approx. 5 seconds. There are 2 characters and 2 numbers in each set.



The 3 sets shown above are to be memorized and then input as answers.

The computer will then analyze your answers and place you in one of the possible 7 categories.


Each set is split into 2 parts of former 2 and latter 2 characters, giving a total of 6 points when all the answers are correct.

Points	Evaluation Message
0	IDIOT
1	BAD
2	AVERAGE
3	OK
4	GOOD !
5	* INTELLIGENT *
6	**GENIUS**

KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF A	MEMORY CHECK	Title
2		**XX **XX **XX	Display of problem line (5 sec.) * . . character X . . number
3		ANS. = _	Waiting for the input of set 1
4	(Example) AB12 ENTER	ANS. = _	Waiting for the input of set 2
5	**XX ENTER	ANS. = _	Waiting for the input of set 3
6	**XX ENTER	**XX **XX **XX	Display of the input.
7		**XX **XX **XX	Display of the problem line (1.5 sec.)
8		**XX **XX **XX	Redisplay of the input
9		IDIOT	
		BAD	
		AVERAGE	
		OK	display of category
		GOOD!	
		* INTELLIGENT *	
		GENIUS	
10		REPLAY (Y/N) ?	Player input request
11	Y or N ENTER		If Y, go to step 2
		>	If N, END

FLOWCHART



PROGRAM LIST

TIAA HOWO 11

```

10: "A": USING : WAIT 20
   0: PRINT "MEMORY CHE
   CK": CLEAR : RANDOM
20: DIM G$(6)*1, N$(10)*1
   , V$(3)*2, X$(3)*4, Z$(
   3)*2, Y$(3)*4
30: FOR I=1 TO 9: N$(I)=
   STR$ I: NEXT I: N$(10
   )="0"
50: FOR I=1 TO 6
60: J= RND 26: J=J+64
70: G$(I)= CHR$( J):
   NEXT I
80: FOR I=1 TO 3
90: Y$(I)=" "
100: FOR J=1 TO 2: K= RND
   9
110: Y$(I)=Y$(I)+N$(K):
   NEXT J
120: J=(I-1)*2+1
130: A$(I)=G$(J)+G$(J+1)
140: H$=Y$(I): A$(I+3)=
   RIGHT$(H$,2): NEXT
   I
150: GOSUB 500
160: FOR I=1 TO 3
170: INPUT "  ANS. = "; X$(
   I): X$(I)= LEFT$(X$(
   I),4)
180: Z$(I)= LEFT$(X$(I),
   2)
190: V$(I)= RIGHT$(X$(I)
   ,2): NEXT I
200: GOSUB 520: GOSUB 500
   : GOSUB 520
210: N=0
220: FOR I=1 TO 3
230: IF A$(I)=Z$(I) LET N
   =N+1
240: IF A$(I+3)=V$(I) LET
   N=N+1
250: NEXT I
260: N=N+1
270: WAIT 150: ON N GOTO
   300,310,320,330,340,
   350,360
300: BEEP 1: PRINT "  SIDI
   OT": GOTO 370
310: BEEP 1: PRINT "  BAD
   ": GOTO 370
320: BEEP 2: PRINT "  OAVE
   (RAGE": GOTO 370
330: BEEP 2: PRINT "  OK
   ": GOTO 370
340: BEEP 3: PRINT "  GO
   ODI": GOTO 370
350: BEEP 4: PRINT "  * INT
   ELLIGENT.*": GOTO 37
   0
360: BEEP 5: PRINT "  *GEN
   IUS**"
370: W$="": BEEP 1: INPUT
   "  REPLAY (Y/N)?": W$
380: IF W$="N" THEN 600
390: IF W$="Y" THEN 50
395: GOTO 370
400: GOTO 370
500: WAIT 300: BEEP 2:
   PRINT A$(1);A$(4);"
   ";A$(2);A$(5);"  ";
   A$(3);A$(6)
510: RETURN
520: WAIT 80: BEEP 1:
   PRINT USING "#####"
   ;X$(1);X$(2);X$(3)
525: USING
530: RETURN
600: END

```

838

MEMORY CONTENTS

A\$	
B\$	
C\$	} 2 columns of characters
D\$	
E\$	
F\$	
G	
H\$	✓
I	Index
J	Random number generation
K	Random number generation
L	Random number generation
M	
N	Counter
O	
P	
Q	
R	
S	
T	
U	
V	
W\$	input for REPLAY
X	
Y	
Z	
G\$(6)*1	Characters (1 ~ 6)
N\$(10)*1	Number table (1 ~ 10)
V\$(3)*2	2 columns after answering (1 ~ 3)
X\$(3)*4	Work (1 ~ 3)
Y\$(3)*4	Work (1 ~ 3)
Z\$(3)*2	2 columns before answering (1 ~ 3)

- Each time the man moves the display changes

Bug is caught

HIT! HIT!

BANG! BANG!

SCORE t

ENERGY e

Concerning the BEEP sound (Note: No beep occurs with the PC-1246.)

- ★ Hint: When the distance is 1 the BEEP goes off 3 times


2 " 2
3 " 1

- ★ If the distance is greater than 3 no BEEP is given.
- ★ When the bug is caught, the BEEP goes off 5 times.



KEY OPERATION SEQUENCE

Step No.	Key Input	Display	Remarks
1	DEF A	**BUGHUNT GAME**	
		(0, 0) D = 5 E = 100	
2	8	(0, 1) D = 4 E = 99	
3	6	(1, 1) D = 2 E = 98	2 BEEPs
4	8	HIT! HIT!	5 BEEPs
5		BANG! BANG!	
6		SCORE 1	
7		ENERGY 108	

FLOWCHART



Copyright © 1984 by The McGraw-Hill Companies, Inc. All rights reserved. Printed in the United States of America. This book is printed on acid-free paper.



PROGRAM LIST

```

10:"A": RANDOM : WAIT 2
50: PRINT "**BUGHUNT
   GAME**": BEEP 3
20:X=0:Y=0:E=100:F=100:
   T=0:S=0
30:A= RND 9:B= RND 9
40:L= ABS (X-A)+ ABS (Y
   -B)
50:IF X=A AND Y=B GOTO
   400
100:IF L=1 BEEP 3
110:IF L=2 BEEP 2
120:IF L=3 BEEP 1
130:WAIT 50: PRINT "(%:
   STR$(X);",": STR$(
   Y);" ) D=": STR$(L):
   " E=": STR$(E)
150:S=S+1:E=F- INT (S/2)
153:IF E<=0 THEN 500
155:G$= INKEY$ : IF G$="
   " GOTO 130
157:BEEP 1
160:IF G$="2" LET Y=Y-1:
   GOTO 210
170:IF G$="4" LET X=X-1:
   GOTO 210
180:IF G$="6" LET X=X+1:
   GOTO 210
190:IF G$="8" LET Y=Y+1:
   GOTO 210
200:GOTO 150
210:IF X<0 LET X=0: GOTO
   150
220:IF Y<0 LET Y=0: GOTO
   150
230:IF X>9 LET X=9: GOTO
   150
240:IF Y>9 LET Y=9: GOTO
   150
250:IF X=A AND Y=B GOTO
   400
260:E=F- INT (S/2)
270:IF E<=0 GOTO 500
280:R= RND 5

```

```

290:IF R=1 LET B=B-1:
   GOTO 340
300:IF R=2 LET A=A-1:
   GOTO 340
310:IF R=3 LET A=A+1:
   GOTO 340
320:IF R=4 LET B=B+1:
   GOTO 340
340:IF A<0 OR A>9 GOTO 3
   70
350:IF B<0 OR B>9 GOTO 3
   70
360:GOTO 40
370:BEEP 4: PAUSE "*** W
   ARP ***": GOTO 30
400:PAUSE "HIT! HIT!"
410:BEEP 5
420:PAUSE "BANG! BANG!"
430:T=T+1:C= RND 3*5:F=F
   +C
435:E=F- INT (S/2)
440:WAIT 100: PRINT "SCO
   RE ":T: PRINT "ENERG
   Y ":E
450:GOTO 30
500:WAIT 100: PRINT "SCO
   RE ": STR$(T): WAIT
   : PRINT " *GAME OVER
   !!*"
510:END

```

729

MEMORY CONTENTS

FILE MANIPULATION

A	Position of bug X coordinate
B	Position of bug Y coordinate
C	Amount of energy added
D	
E	Remaining energy
F	Energy level
G\$	Key read in
H	
I	
J	
K	
L	Distance between bug and man
M	
N	
O	
P	
Q	
R	Size of bug movement
S	Time spent
T	Score
U	
V	
W	
X	Man position X coordinate
Y	Man position Y coordinate
Z	

Program Title: DOUBLE ROTATION

OVERVIEW

Quickly put in order A, B, C

This is a game that arranges randomly placed characters (A — J) in alphabetical order. When the letters are arranged in the right order, a score is displayed. The trick is to attack from the best place.

The sooner the characters are arranged, the better.


It is fun to race with 2 or 3 of your friends.

INSTRUCTIONS

1. After the program is initiated, by pressing **DEF** **A** , "DOUBLE ROTATION" is displayed. A random sequence of characters (A — J) is then displayed.
2. The space in between the characters is taken as the break points (1 — 9) where the numbers are placed. Inputting a break number causes the characters on each side of the breakpoint to be rotated by moving them to the far ends of the row.
3. After the characters have been placed in order, the number of moves required is displayed as the score. The lower the score the better.

EXAMPLE

In (1) 4 is input, "F" and "I" move to each side changing the configuration to (2). If 1 is now input, the "E" moves to the far right but "F" stays in its place because it is already in the far left position, becoming configuration (3).



KEY OPERATION SEQUENCE


Step No.	Key Input	Display	Remarks
1	DEF A	DOUBLE ROTATION A ~ J	
2	1 ~ 9	⋮ Repeated input	Random sequence display Numbers between 1 and 9 are selected and input
		⋮	
		ABCDEFGHIJ	
		GAME END	
		YOUR SCORE 35	
		>	
			Does player want to play using the same beginning random characters?
1	DEF B	A ~ J	
		Same as DEF A in succession	

If the 2 lines are changed as below, then the game is easier to play and key can be used.

180: C = VAL DS: IF DS = "0" GOTO 210

240: IF C <= 1 GOTO 260

FLOWCHART



PROGRAM LIST

```

10:"A": CLEAR : WAIT 50
   : RANDOM : DIM B$(4)
20:PAUSE "DOUBLE ROTATI
   ON"
30:B$(0)="ABCDEFGHJIJ"
40:B$(1)=""
50:A=0
60:FOR I=1 TO 10
70:R= RND 10
80:S=2^(R-1)
85:B=S AND A
90:IF B<>0 GOTO 70
100:A=A OR S
110:B$(1)=B$(1)+ MID$( B
   $(0),R,1): NEXT I
120:B$(2)=B$(1)
130:N=0
150:BEEP 1
170:D$="": PRINT B$(2):D
   $= INKEY$
180:C= VAL D$
190:IF C=0 GOTO 170
210:B$(3)= LEFT$( B$(2),
   C)
220:B$(4)= RIGHT$( B$(2)
   ,10-C)
240:IF C=1 GOTO 260
250:B$(3)= RIGHT$( B$(3)
   ,1)+ LEFT$( B$(3),C-
   1)
260:IF C=9 GOTO 280
270:B$(4)= RIGHT$( B$(4)
   ,9-C)+ LEFT$( B$(4),
   1)
280:B$(2)=B$(3)+B$(4)
290:N=N+1
300:IF B$(2)<>B$(0) GOTO
   150
310:BEEP 5: PAUSE "GAME
   END"
320:WAIT 200: PRINT
   USING "####";"YOUR S
   CORE":N
330:END
400:"B": WAIT 50: GOTO 1
   20

```

MEMORY CONTENTS

A	✓
B	✓
C	✓
D\$	Input key
E	
F	
G	
H	
I	✓
J	
K	
L	
M	
N	Score
O	
P	
Q	
R	Random numbers
S	✓
T	
U	
V	
W	
X	
Y	
Z	
B\$(4)	Character sequences

Modification Summary of the CE-125 Program Examples

Program
Title

MATRIX PRODUCT

(The PC-1246S cannot use this program due to the shortage of memory capacity.)

- KEY OPERATION SEQUENCE

REVISION POSITION = _ ⇒ REV. POSITION = _
ALL DATA PRINT? (Y/N) _ ⇒ ALL PRINT (Y/N) _

- Change 2 step of the program list as follows:

```
160:"B":B$(0)="": INPUT
    "REV. POSITION=";B$(
    0);Z= LEN B$(0):
    GOTO 170
```

```
250:INPUT "ALL PRINT(Y/N
    )";G$
```

Program
Title

NUMERICAL INTEGRATION USING SIMPSON'S RULE

- KEY OPERATION SEQUENCE

F(X): INPUT = 1/CAL. = 2? _ ⇒ INP. = 1/CAL. = 2? _
ALL DATA PRINT? (Y/N) _ ⇒ ALL PRINT (Y/N) _

- Change 2 steps of the program list as follows:

```
10:"A": CLEAR : WAIT 0:
    INPUT "INP.=1/CAL.=2
    ?";Q: GOTO 16
```

```
140:INPUT "ALL PRINT(Y/N
    )";W$
```

Program Title **CORRELATION COEFFICIENT AND LINEAR REGRESSION**

KEY OPERATION SEQUENCE

REVISION POSITION = _

⇒ REV. POSITION = _

ALL DATA PRINT? (Y/N) _

⇒ ALL PRINT (Y/N) _

- Change 2 step of the program list as follows:

```
500: "B": B$(0)=": INPUT
      "REV. POSITION="; B$(
      0)
```

```
500: 560: 0#=#": INPUT "ALL PR
      INT(Y/N)" : 0#
```

Program Title **HISTOGRAM**

INSTRUCTIONS

"OVER-DELETED CHECK"

⇒ "OVER-DELETED!!"

- Change 3 steps of the program list as follows:

```
20: PRINT "RANGE A=<DATA
      =<B": INPUT "A="; A, "
      B="; B
```

```
250: IF D(N)-1<0 BEEP 2:
      WAIT : PRINT "OVER-D
      ELETED !!"
```

```
30: INPUT "SCALE UNIT SI
      ZE="; D
```

Program Title **CROSS-FOOTING**

(The PC-1246S cannot use this program due to the shortage of memory capacity.)

KEY OPERATION SEQUENCE

REVISION POSITION = _

⇒ REV. POSITION = _

DATA IN = 1/OUT = 2? _

⇒ DATA IN = 1/OUT = 2 _

- Change 2 steps of the program list as follows:

```
130: INPUT "REV. POSITION
      =" ; C# : Z = LEN C# : X# =
      RIGHT$ (C#, Z-2) : Y =
      VAL X# : GOTO 145
```

```
530: INPUT "DATA IN=1/OUT
      =" ; K : IF (K=1)+(K=2
      )=1 GOTO 550
```

Program
Title

SORTING

- KEY OPERATION SEQUENCE

CHARACTER = 1/NUMBER = 2? -

⇒

CHAR. = 1/NUM. = 2? -

INCREASE = 1/DECREASE = 2? -

⇒

INC. = 1/DEC. = 2? -

- Change 2 steps of the program list as follows:

```
10: "A": CLEAR : INPUT "  
CHAR.=1/NUM.=2?" ; M
```

```
30: INPUT "INC.=1/DEC.=2  
?" ; I
```

Program
Title

THE LOAN LIMIT, CALCULATION OF THE NUMBER OF INSTALLMENTS

- KEY OPERATION SEQUENCE

NO. OF INSTALLMENT = _

⇒

NO. OF INST. = _

INSTALLMENT AMOUNT = _

⇒

INST. AMT. = _

- Change 3 steps of the program list as follows:

```
20: INPUT "NO. OF INST. =  
" ; A
```

```
400: INPUT "INST. AMT. = "  
B
```

```
210: INPUT "LOAN SIZE LIM  
IT = " ; D
```

Program
Title

BIORHYTHM (SEMI-GRAPHIC)

- KEY OPERATION SEQUENCE

DATE OF BIRTH: YEAR = _

⇒

BIRTH: YEAR = _


- Change one step of the program list as follows:

```
30: INPUT "BIRTH: YEAR = "  
; U$, "MONTH = " ; V, "DAY = "  
; W
```

INDEX

&	32	CLOAD	72
*	36	CLOAD?	73
+	36	CLear key	10
-	36	CONT	74
/	36	COS	131
^	36	CSAVE	75
√	134	Cursor	11
<	37	Cassette	54
◀	20	Commands	43, 72
<=	37	Compatibility	150
<>	37	Constants	30, 32
=	37	DATA	91
>	37	DEF key	52
▶	20	DEG	131
>=	37	DEGREE	90
π	129	DELeTe key	23
↑	138	DIM	92
↓	138	DMS	120
ABS	130	Debugging	138
ACS	130	Display	11
AND	38	END	94
AREAD	85	ENTER key	9, 18
ASC	135	EXP	132
ASCII	142	Editing calculations	20
ASN	130	Editing programs	45
ATN	131	Error Messages	140
Arrays	33	Exponentiation	132
Auto off (Auto Power Off)	17	Expressions	35
BEEP	86	FOR...TO...STEP	95
Batteries, PC-1246S/1248	14	Formatting output	144
Busy	11	Functions	40, 129
CA key	10	GOSUB	97
CE-125	53	GOTO	76, 98
CE-126P	61	GRAD	99
CHAIN	87	Hexadecimal	32
CHR\$	135	IF...THEN	100
CLEAR	89	INKEY\$	129

INPUT	101	PROgram mode	43
INPUT #	103	Parentheses	40
INSert key	46	Preallocated variables	34
INT	132	Priority	147
LEFT\$	135	Program	42
LEN	135	Pseudovariables	129
LET	105	RADIAN	117
LIST	77	RANDOM	118
LLIST	78	READ	119
LN	132	REM	120
LOG	132	RESET	12
LPRINT	106	RESTORE	121
Labelled programs	52	RETURN	122
Limits of numbers	31	RIGHT\$	136
Line numbers	42	RND	133
Logical expressions	38	RUN	84
Loops	48	RUN mode	43
MEM	129	Range of numbers	31
MERGE	79	Relational expressions	37
MID\$	136	SGN	133
Maintenance	139	SHIFT key	18, 19
Masks	144	SIN	133
Memory Protection	50	SQR	134
NEW	82	STOP	123
NEXT	108	STR\$	136
NOT	38	Scientific notation	30
Numeric expressions	36	Square root	134
Numeric variables	33	Statements	42
ON (Start up)	17	String expressions	36
ON ... GOSUB	109	String variables	33
ON ... GOTO	110	Subroutines	97
OR	38	TAN	134
Operator precedence	40	TROFF	124
Operator priority	147	TRON	125
Operators	36	Tape, external	64
P ↔ NP	61	Tape	68
PASS	83	Troubleshooting	137
PAUSE	111	USING	126
PI	129	VAL	136
PRINT	113	Variables	33
PRINT #	115	Verbs	42, 85



SHARP CORPORATION
OSAKA, JAPAN

1986 © SHARP CORPORATION
PRINTED IN JAPAN/IMPRIME AU JAPON
6F2.9T(TINSE1086ECZZ)