

MTX100B
Declassification and Security
Instructions

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Contacting Tektronix

Tektronix, Inc.
14200 SW Karl Braun Drive
P.O. Box 500
Beaverton, OR 97077
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit www.tektronix.com to find contacts in your area.

Table of Contents

Preface	iii
Clear and Sanitize Procedures.....	1
Memory Devices.....	1
Data Export Devices.....	3

Table of Contents

Preface

This document helps customers with data security concerns to sanitize or remove memory devices from the MTX100B MPEG Recorder & Player.

These products have data storage (memory) devices and data output devices (USB ports). These instructions tell how to clear or sanitize the memory devices and disable the data output devices.

Products The following Tektronix products are covered by this document:

- MTX100B MPEG Recorder & Player
- MTX100B Option 01 (ASI Interface)
- MTX100B Option 02 (Universal Parallel/Serial Interface)
- MTX100B Option 05 (IEEE 1394/ASI Interface)
- MTX100B Option 07 (SMPTE310M/ASI/PSI Interface)

Related Documents

The *MTX100B MPEG Recorder and Player Service Manual*, Tektronix part number 077-0191-xx, is available on the Tektronix Web site, at www.tektronix.com/manuals

Terms The following terms may be used in this document:

- **Clear.** This removes data on media/memory before reusing it in a secured area. All reusable memory is cleared to deny access to previously stored information by standard means of access.
- **Erase.** This is equivalent to clear.
- **Media storage/data export device.** Any of several devices that can be used to store or export data from the instrument, such as a USB port.
- **Nonvolatile memory.** Data is retained when the instrument is powered off.
- **Power off.** Some instruments have a “Standby” mode, in which power is still supplied to the instrument. For the purpose of clearing data, putting the instrument in Standby mode does not qualify as powering off. For these products, you will need to either press a rear-panel OFF switch or remove the power source from the instrument.
- **Remove.** This is a physical means to clear the data by removing the memory device from the instrument. Instructions are available in the product Service Manual.
- **Sanitize.** This eradicates the data from media/memory so that the data cannot be recovered by other means or technology. This is typically used when the device will be moved (temporarily or permanently) from a secured area to a non-secured area.
- **Scrub.** This is equivalent to sanitize.
- **User-modifiable.** The user can write to the memory device during normal instrument operation, using the instrument interface or remote control.
- **Volatile memory.** Data is lost when the instrument is powered off.

Clear and Sanitize Procedures

Memory Devices

The following tables list the volatile and nonvolatile memory devices in the standard instrument and listed options. Detailed procedures to clear or sanitize these devices, if any, are shown following each table.

Table 1: Volatile memory devices

Type and minimum size	Function	User modifiable	Data input method	Location	To clear	To sanitize
SDRAM 64 MB	Mega FIFO	No	Written by processor system	A12 Main board	None	Remove the power source from the instrument for at least 20 seconds
DDRAM 1 GB	Processor system memory	No	Written by processor system	CPU Processor module	None	Remove the power source from the instrument for at least 20 seconds
SRAM	Cache RAM	No	Written by processor system	CPU Processor module	None	Remove the power source from the instrument for at least 20 seconds

Table 2: Nonvolatile memory devices

Type and minimum size	Function	User modifiable	Data input method	Location	To clear	To sanitize
Serial Flash	Holds FPGA PCI configuration	No	Factory configuration	A100 ASI Interface module (Option 01)	None	None
Serial Flash	Holds FPGA PCI configuration	No	Factory configuration	A110 Universal Parallel/Serial Interface module (Option 02)	None	None
Serial Flash	Holds FPGA PCI configuration	No	Factory configuration	A140 IEEE 1394/ASI Interface module (Option 05)	None	None
Serial Flash	Holds FPGA PCI configuration	No	Factory configuration	A170 SMPTE310M/ASI/PSI Interface Module (Option 07)	None	None
EEPROM	Holds installed options	No	Factory configuration	Main board A12	None	None
EEPROM	Holds FPGA image	No	Factory configuration	Main board A12	None	None

Table 2: Nonvolatile memory devices (cont.)

Type and minimum size	Function	User modifiable	Data input method	Location	To clear	To sanitize
Flash	BIOS	No	Factory configuration	CPU Processor module	None	None
Fixed IDE Hard Drive	Holds operating system and application software. Holds user storables data such as test streams and measurement results.	Yes	Firmware operations, user input	Mounted on chassis	Erase the hard drive with commercial erasure software. Reinstall Microsoft Windows and the instrument software using the supplied recovery discs.	Remove the hard drive from the instrument. Store the removed hard drive in a secure area or destroy it.

Data Export Devices

The following table lists the data export devices in the standard instrument and listed options. Detailed procedures to disable these devices, if any, are shown following the table.

Table 3: Data export devices

Type and minimum size	Function	User modifiable	Data input method	Location	To disable
LAN Ethernet connector	Data transfer	N/A	N/A	CPU Processor module	N/A
USB port	USB devices can be used to store user-storable data such as transport streams, measurement results, and instrument settings	Yes	User Writable	Instrument front panel	Remove all USB memory devices. USB devices can be reformatted, stored in a secure area, or destroyed.