

NS-AP480

HOME CINEMA SPEAKER PACKAGE

Main, Center and Surround Speaker

The Yamaha Commitment:

Audio and visual media, when skillfully integrated, have an enormous potential to excite us, to touch our innermost feelings, and to broadly stimulate our imaginations. Yamaha's unvarying commitment is to create A/V components that make the entertainment experience more dynamic and meaningful, to not only give you pleasure, but to expand and enrich your life.

Out of the hundreds of loudspeaker manufacturers, Yamaha is the only one that also makes musical instruments. YAMAHA audio components and speakers can be found in the homes and recording studios of audiophiles and industry professionals alike. No other company is as intimately involved with the production and reproduction of fine music.

KEY FEATURES OF THE NS-AP480 SPEAKER PACKAGE ARE:

- A/V magnetically shielded.
- Developed to give high performance on all channels.
- 2 way acoustic suspension design.
- Ideal for Dolby DIGITAL or DTS surround systems and other high quality home theater applications.
- Utilized as a main speaker, center channel speaker, and surround speaker.
- Fully voice matched system.
- Can be used on shelf, stand or wall mounted.

Owner's Manual

CONTENTS

Consumer Precautions
Connections to the Amplifier or Receiver
Using with Yamaha Active Servo Processing Subwoofers
Setting up the Speakers
Speaker Placement
Specifications

IMPORTANT:

Please record the serial number of your loudspeakers in the space below.

Model: NS-AP480

Serial No.

The serial number is located on the rear of each unit. Retain this Owner's Manual in a safe place for future reference.

CONSUMER PRECAUTIONS

Read these precautions carefully before operating your NS-AP480 speakers.

- Since these speakers can be wall mounted, it is essential that they are firmly secured. Be sure to consult a reliable source about the best type of hanger for your particular wall's construction. Secure installation is the purchaser's responsibility.
- Do not attach them to thin plywood or soft wall surface materials as the screws may tear
 free, causing the speakers to fall and be damaged, or result in personal injury.
- Do not fasten the speakers to walls with nails, adhesives, or other unsafe hardware. Longterm use and vibrations may cause them to pull free.
- Do not place the speakers where they are liable to be knocked over or struck by falling objects. Stable placement will also ensure better sound performance.
- · Placing the speakers on the same stand or shelf as the turntable can result in feedback.
- This speaker features a magnetically shielded design, but there is still a chance that
 placing it too close to a TV set might impair picture color. Should this happen, move the
 speaker away from the TV set.
- Never touch the woofer or tweeter units with your hands or expose them to excessive physical shock. If they are dented or bent, the sound will be distorted.
- Lower the power amplifier/receiver volume control before changing input sources. Never change input sources (for example, FM to CD) at high listening levels. Always turn the receiver / amplifier unit off when installing or removing input cables.
- Anytime you note distortion, reduce the volume control on your power amplifier/receiver
 to a lower setting. Never allow your power amplifier to be driven into "clipping".
- Do not attempt to clean the speakers with chemical solvents as this might damage the finish to clean. wipe with a dry, soft cloth.
- To prevent the enclosure from warping or discoloring, do not place the speakers where they will be exposed to direct sunlight or excessive humidity.

CONNECTIONS TO THE AMPLIFIER OR RECEIVER

To assure low distortion on program peaks, your amplifier or receiver should be capable of delivering at least 10 watts RMS (continuous sine-wave power) per channel. This speaker can be used safely with amplifiers rated at up to 30 watts RMS per channel.


Amplifiers rated at higher than 30 watts RMS (continuous sine-wave power) per channel may be used with care

CONNECTIONS

- Check to make sure that the power has been turned off before making connections.
- Connect the (+) terminals on both amplifier and Speaker Connect the (-) terminals on both amplifier and Speaker.
- Reversing polarity (+/-) will result in unnatural sound reproduction.

PROCEDURE

- 1. Loosen the speaker terminals by turning the knobs counterclockwise.
- 2. Insert the lead portions of the speaker cable into the terminal holes.
- 3. Tighten the speaker terminals by turning the knobs clockwise.
- 4. Lightly pull the speaker cable to make sure connections are secure.



USING WITH YAMAHA ACTIVE SERVO PROCESSING SUBWOOFERS


This YAMAHA speaker is designed to give excellent balanced sound performance on all channels of a Dolby DIGITAL or DTS surround system, Since surround systems often contain a lot of very low frequency sounds, we suggest using these speakers in conjunction with one or more powered subwoofers to get the maximum performance from your sound system.

Please refer to your subwoofer owner's manual for proper connection instructions

1

SETTING UP THE SPEAKERS

Mounting the main speakers




Main speakers can be positioned horizontally or vertically

Please note: Logo can rotate.

Mounting the center speaker

Place the center speaker on top of the TV, on the floor under the TV or inside the TV rack so that it is stable.

When placing the speaker on top of the TV, put the provided Velcro at two points on both the bottom of the speaker and on top of the TV to prevent the speaker from falling




Notes

- Do not place the speaker on top of the TV whose area is smaller than the bottom area of the speaker. The speaker may fall and might cause personal injury.
- Though this speaker is a magnetically shielded type, there may be some influence on a TV picture depending on the type of TV or the placement of the speaker. In such a case, place the speaker apart from TV so that there is no influence on TV picture.


Mounting the rear speaker

Please place rubber pads as shown in the diagram prior to mounting the speakers on the wall.



Fasten screws into a firm wall or wall support as shown in the figure, and hang the holes of the mounting bracket on the protruding screws.

★Make sure that the screws are securely caught by the narrow sections of the "key hole" opening.



WARNING

- Each speaker weighs 3.74 lbs (1.7 kg). Do not mount them on thin plywood or a wall with soft surface material. If mounted, the screws may come out of the flimsy surface and the speakers may fall. This damages the speakers or causes personal injury.
- Do not install the speakers to a wall with nails, adhesives, or any other unstable hardware. Long-term use and vibrations may cause them to fall.
- To avoid accidents resulting from tripping over loose speaker cords, fix them to the wall.
- Secure installation is the purchaser's responsibility.

YAMAHA ELECTRONICS CORPORATION, USA

6660 ORANGETHORPE AVENUE, BUENA PARK, CALIFORNIA 90620•MAILING ADDRESS: P.O. BOX 6660, BUENA PARK, CALIFORNIA 90622

Yamaha Loudspeakers are designed and manufactured to provide a high level of trouble-free performance. Yamaha Electronics Corporation, USA, is proud of the experienced craftsmanship that goes into each and every Yamaha Loudspeaker. Yamaha sells its Loudspeakers only through a network of high quality, specially authorized dealers and is pleased to offer the following Limited Warranty, which applies only to products purchased from our Electronics Corporation, USA, service department if you have any questions authorized dealers. We suggest that you read the Limited Warranty thoroughly, and invite you to contact your authorized Yamaha dealer or the Yamaha

MITE **NS-AP480** U LOUDSPEAKERS ス RA

Duration of Warranty

This Speaker System is covered by this warranty for a period of two (2) years beginning from the date of first consumer purchase

What is Covered and What is Not Covered?

This warranty covers all defects in materials or workmanship in this product, but DOES NOT COVER the following: (1) Damage, deterioration or malfunction resulting from:

- a. Accident, negligence, misuse, abuse, improper installation or operation or failure to follow instructions contained in your Owner's manual. b. Any shipment of the product. (Claims must be presented to the carrier.)
- c. Repair or attempted repair by anyone other than Yamaha or an authorized Yamaha Preferred Customer Service Center

- (2) Any unit which has been altered or on which the serial number has been defaced, modified or removed.(3) Normal wear and any periodic maintenance.(4) Any unit which has not been purchased from an authorized YAMAHA dealer in the U.S.A. If you are uncertain as to whether a dealer has been authorized by YAMAHA, please contact YAMAHA's Service Department.
- (5) Any unit used for industrial or commercial purposes

Who may enforce the warranty:

This warranty is enforceable only by the original purchaser

What we will pay for and what you must pay for:

YAMAHA will repair or replace units covered by this warranty, without charge to the consumer for labor or materials. YOU ARE RESPONSIBLE FOR ANY INSTALLATION OR REMOVAL CHARGES AND FOR ANY INITIAL SHIPPING CHARGES. If the Components must be shipped for warranty service. However, we will pay the return shipping charges to any destination within the U.S.A.if the repairs are covered by the warranty.

How you can get Warranty Service:

- YAMAHA Speaker Systems requiring service must be delivered to any authorized YAMAHA Service Center within the fifty states of the U.S.A., the District of Columbia or Puerto Rico. Warranty service is not available at any other location or outside the U.S.A.
 Units shipped for service should be packed securely and must be accompanied by a detailed explanation of the problem(s) requiring service And Bill of Sale as proof of Warranty coverage.
 Warranty registration is not required for Warranty coverage.

Limitation of Implied Warranties:

ANY IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS WARRANTY.

Exclusion of Damages

BECAUSE OF PRODUCT DEFECTS. YAMAHA'S LIABILITY, FOR ANY DEFECTIVE PRODUCT, IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT, AT OUR OPTION. YAMAHA SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OR DAMAGES OF ANY OTHER KIND OR CHARACTER

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

For the nearest authorized YAMAHA Preferred Customer Service Center please call:

1-800-4-YAMAHA

Should you have any questions about service received or if you need assistance in locating an authorized Yamaha Service Center, please contact:



SERVICE DEPARTMENT

YAMAHA ELECTRONICS CORPORATION, USA

6660 ORANGETHORPE AVE , BUENA PARK ,CA 90620 • MAIL ADDRESS: P.O.BOX 6660, BUENA PARK,CA 90622


YAMAHA Website Address-http://www.yamaha.com Phone: (714)522-9105
YAMAHA products are backed by a nationwide network of high quality YAMAHA authorized Service Centers, providing prompt courteous and professional service.

P/N 430018 Printed ⊒. China

SPEAKER PLACEMENT

This speaker is designed to be used as a main, center, surround or effects speaker:

- Main speaker placement should be separated by a distance of 6-10ft. If they are placed too close together, there will be a reduction in the stereo effect.
 Conversely, If palced too far apart, the so called "middle-omission" effect will occur and the vocal center fill will be lost. Height of the speaker should be at least at ear level.
- Center channel speakers should be placed centered above or below the TV.
- Surround speakers should ideally be placed behind the listening area. At least as far apart as the main speakers and up to 2 additional feet apart per side. The height of the speaker should be at a minimum of ear level or preferably somewhat higher.



SPECIFICATIONS

Model NS-AP480

Type 2-way Bass Retlex

Speaker: Woofer Dual 3" High Compliance Pulp Cone and Rubber surround

Speaker:Tweeter 1/2" balanced dome

Frequency Range 110Hz~30KHz (-10dB)

Impedance6 ohmsNominal Input35wMaximum Input110wSensitivity (dB/2.83v. 1m)88dBCrossover Frequency6,500Hz

Dimension (HxWxD) $10\frac{5}{8}$ "x4"x4 $\frac{7}{8}$ " (270×100×122mm)

Weight 3.74lbs (1.7kg)

Finish Black Magnetic Shielding Yes

Accessories 100"Bulk Speaker Wire

5/8 "x 2/8" Rubber pad 16pcs

1"x4"Velcro 2pcs

^{*} Specifications subject to change without notice due to product improvements.