


# Deep Learning HDL Toolbox™

## Reference



# MATLAB®

R2021b

 MathWorks®

# How to Contact MathWorks



Latest news: [www.mathworks.com](http://www.mathworks.com)  
Sales and services: [www.mathworks.com/sales\\_and\\_services](http://www.mathworks.com/sales_and_services)  
User community: [www.mathworks.com/matlabcentral](http://www.mathworks.com/matlabcentral)  
Technical support: [www.mathworks.com/support/contact\\_us](http://www.mathworks.com/support/contact_us)  
Phone: 508-647-7000



The MathWorks, Inc.  
1 Apple Hill Drive  
Natick, MA 01760-2098

*Deep Learning HDL Toolbox™ Reference*

© COPYRIGHT 2020–2021 by The MathWorks, Inc.

The software described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from The MathWorks, Inc.

**FEDERAL ACQUISITION:** This provision applies to all acquisitions of the Program and Documentation by, for, or through the federal government of the United States. By accepting delivery of the Program or Documentation, the government hereby agrees that this software or documentation qualifies as commercial computer software or commercial computer software documentation as such terms are used or defined in FAR 12.212, DFARS Part 227.72, and DFARS 252.227-7014. Accordingly, the terms and conditions of this Agreement and only those rights specified in this Agreement, shall pertain to and govern the use, modification, reproduction, release, performance, display, and disclosure of the Program and Documentation by the federal government (or other entity acquiring for or through the federal government) and shall supersede any conflicting contractual terms or conditions. If this License fails to meet the government's needs or is inconsistent in any respect with federal procurement law, the government agrees to return the Program and Documentation, unused, to The MathWorks, Inc.

## Trademarks

MATLAB and Simulink are registered trademarks of The MathWorks, Inc. See [www.mathworks.com/trademarks](http://www.mathworks.com/trademarks) for a list of additional trademarks. Other product or brand names may be trademarks or registered trademarks of their respective holders.

## Patents

MathWorks products are protected by one or more U.S. patents. Please see [www.mathworks.com/patents](http://www.mathworks.com/patents) for more information.

## Revision History

September 2020	Online only	New for Version 1.0 (R2020b)
March 2021	Online only	Revised for Version 1.1 (R2021a)
September 2021	Online only	Revised for Version 1.2 (R2021b)

## **Functions —**

**1**

---



# Functions —

---

# dlhdl.Workflow class

**Package:** `dlhdl`

Configure deployment workflow for deep learning neural network

## Description

Use the `dlhdl.Workflow` object to set options for compiling and deploying your deep learning network to a target FPGA. You create an object of the `dlhdl.Workflow` class for the specified deep learning network and FPGA bitstream. Use the object to:

- Compile the deep learning network.
- Estimate the speed and throughput of your network on the specified FPGA device.
- Compile and deploy the neural network onto the FPGA.
- Predict the class of input images.
- Profile the results for the specified network and the FPGA.

## Creation

`hw = dlhdl.Workflow('Network', Network, 'Bitstream', Bitstream)` creates a workflow configuration object with a network object and bitstream to deploy your custom pretrained deep learning network object.

`hw = dlhdl.Workflow('Ntwork', Network, 'Bitstream', Bitstream, Name, Value)` creates a workflow configuration object with a network object and bitstream to deploy your custom pretrained deep learning network object, with additional options specified by one or more name-value pair arguments.

### Input Arguments

#### **Bitstream — Name of the FPGA bitstream**

`" "` (default) | character vector

Name of the FPGA bitstream, specified as a character vector. Make sure that the bitstream name matches the data type and the FPGA board that you are targeting. For a list of provided bitstream names, see “Use Deep Learning on FPGA Bitstreams”.

**Example:** `'Bitstream', 'arria10soc_single'` specifies that you want to deploy the trained network with `single` data types to an Arria10 SoC board.

#### **Network — Network object**

`SeriesNetwork` object | `DAGNetwork` object | `yolov2objectDetector` object | `dlquantizer` object

Name of the deep learning network object.

**Example:** `'network'`, `net` creates a workflow object for the saved pretrained network `net`. To specify `net`, you can import any of the existing supported pretrained networks or use transfer learning to adapt the network to your issue. See “Supported Pretrained Networks”.

```
net = resnet18;
hW = dlhdl.Workflow('Network', net, 'Bitstream', 'zcu102_single');
```

**Example:** 'network', `dlquantizeObj` creates a workflow object for the quantized network object `dlquantizeObj`. To specify `dlquantizeObj`, you can import any of the supported existing pretrained networks and create an object by using the `dlquantizer` class. For information on supported networks, see “Supported Pretrained Networks”.

```
net = resnet18;
dlquant0bj = dlquantizer(net, 'ExecutionEnvironment', 'FPGA');
dlquant0bj.calibrate(imdsTrain);
hW = dlhdl.Workflow('Network', dlquant0bj, 'Bitstream', 'zcu102_int8');
```

## Properties

**'Target' — `dlhdl.Target` object to deploy network and bitstream to the target device**  
`hTarget`

Target object specified as `dlhdl.Target` object

Example: 'Target', `hTarget`

```
hTarget = dlhdl.Target('Intel', 'Interface', 'JTAG')
hW = dlhdl.Workflow('network', snet, 'Bitstream', 'arrial0soc_single', 'Target', hTarget);
```

## Methods

### Public Methods

activations	Retrieve intermediate layer results for deployed deep learning network
compile	Compile workflow object
deploy	Deploy the specified neural network to the target FPGA board
getBuildInfo	Retrieve bitstream resource utilization
predict	Run inference on deployed network and profile speed of neural network deployed on specified target device

## Examples

### Create Workflow Object by using Property Name Value Pairs

```
snet = vgg19;
hW = dlhdl.Workflow('Network', snet, 'Bitstream', 'arrial0soc_single', 'Target', hTarget);
```

### Create Workflow Object with Quantized Network Object

```
snet = getLogoNetwork;
dlquant0bj = dlquantizer(snet, 'ExecutionEnvironment', 'FPGA');
Image = imageDatastore('heineken.png', 'Labels', 'Heineken');
dlquant0bj.calibrate(Image);
hTarget = dlhdl.Target('Xilinx', 'Interface', 'Ethernet');
hW = dlhdl.Workflow('Network', dlquant0bj, 'Bitstream', 'zcu102_int8', 'Target', hTarget);
```

## See Also

### Objects

`dlhdl.Target` | `dlquantizer` | `dlquantizationOptions`

**Topics**

“Prototype Deep Learning Networks on FPGA and SoCs Workflow”  
“Quantization of Deep Neural Networks”

**Introduced in R2020b**

# activations

**Class:** dlhdl.Workflow

**Package:** dlhdl

Retrieve intermediate layer results for deployed deep learning network

## Syntax

```
act = activations(image,layername)
act = activations(imIn,layername, Name,Value)
```

## Description

`act = activations(image,layername)` returns intermediate layer activation data results for the image data in `imIn`, and the name of the layer specified in `layername`. The result size depends on the output size of the layer. The layer output size can be retrieved by using `analyzeNetwork`.

`act = activations(imIn,layername, Name,Value)` returns intermediate layer activation data results for the image data in `imIn`, and the name of the layer specified in `layername`, with additional options specified by one or more `Name,Value` pair arguments. The result size depends on the output size of the layer. The layer output size can be retrieved by using `analyzeNetwork`.

## Input Arguments

### **image — Input image**

`m`-by-`n`-by-`k` numeric array

Input image, specified as a `m`-by-`n`-by-`k` numeric array. `m`, `n`, and `k` must match the dimensions of the deep learning network input image layer. For example, for the LogoNet network, resize the input images to a 227-by-227-by-3 array.

Data Types: `single`

### **layername — Name of layer in deployed deep learning network**

`"` (default) | character vector

Name of the layer in the deployed deep learning network whose results are retrieved for the image specified in `imIn`.

The layer has to be of the type `Convolution`, `Fully Connected`, `Max Pooling`, `ReLU`, or `Dropout`. `Convolution` and `Fully Connected` layers are allowed as long as they are not followed by a `ReLU` layer.

Example: `'maxpool_3'`

## Name-Value Pair Arguments

Specify optional comma-separated pairs of `Name,Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1,Value1,...,NameN,ValueN`.

**Profiler — Flag that returns profiling results**

'off' (default) | 'on'

Flag to return profiling results for the deep learning network deployed to the target board.

Example: 'Profiler', 'on'

**Output Arguments****act — Intermediate layer activation data**

array of single

Intermediate layer activation data, returned as an array of singles. The array size depends on the layer output size. For example, for the ResNet-18 network pool1 layer, the size of the returned result array is 56-by-56-by-64.

**Examples****Visualize Activations of a Deep Learning Network by Using LogoNet**

This example shows how to feed an image to a convolutional neural network and display the activations of the different layers of the network. Examine the activations and discover which features the network learns by comparing areas of activation to the original image. Channels in earlier layers learn simple features like color and edges, while channels in the deeper layers learn complex features. Identifying features in this way can help you understand what the network has learned.

**Logo Recognition Network**

Logos assist in brand identification and recognition. Many companies incorporate their logos in advertising, documentation materials, and promotions. The logo recognition network (LogoNet) was developed in MATLAB® and can recognize 32 logos under various lighting conditions and camera motions. Because this network focuses only on recognition, you can use it in applications where localization is not required.

**Prerequisites**

- Arria10 SoC development kit
- Deep Learning HDL Toolbox™ Support Package for Intel FPGA and SoC
- Deep Learning Toolbox™
- Deep Learning HDL Toolbox™
- Computer Vision Toolbox™

**Load Pretrained Series Network**

To load the pretrained series network LogoNet, enter:

```
snet = getLogoNetwork();
```

**Create Target Object**

Create a target object that has a custom name for your target device and an interface to connect your target device to the host computer. Interface options are JTAG and Ethernet. To use JTAG, install

Intel™ Quartus™ Prime Standard Edition 18.1. Set up the path to your installed Intel Quartus Prime executable if it is not already set up. For example, to set the toolpath, enter:

```
% hdlsetupToolPath('ToolName', 'Altera Quartus II', 'ToolPath', 'C:\altera\18.1\quartus\bin64');
```

To create the target object, enter:

```
hTarget = dlhdl.Target('Intel', 'Interface', 'JTAG');
```

### Create Workflow Object

Create an object of the `dlhdl.Workflow` class. When you create the object, specify the network and the bitstream name. Specify the saved pretrained LogoNet neural network, `snet`, as the network.

Make sure that the bitstream name matches the data type and the FPGA board that you are targeting. In this example, the target FPGA board is the Intel Arria10 SOC board. The bitstream uses a single data type.

```
hw = dlhdl.Workflow('network', snet, 'Bitstream', 'arria10soc_single', 'Target', hTarget);
```

Read and show an image. Save its size for future use.

```
im = imread('ferrari.jpg');
imshow(im)
```



```
imgSize = size(im);
imgSize = imgSize(1:2);
```

### View Network Architecture

Analyze the network to see which layers you can view. The convolutional layers perform convolutions by using learnable parameters. The network learns to identify useful features, often including one feature per channel. The first convolutional layer has 64 channels.

```
analyzeNetwork(snet)
```

The Image Input layer specifies the input size. Before passing the image through the network, you can resize it. The network can also process larger images.. If you feed the network larger images, the activations also become larger. Because the network is trained on images of size 227-by-227, it is not trained to recognize larger objects or features.

### Show Activations of First Maxpool Layer

Investigate features by observing which areas in the maxpool layers activate on an image and comparing that image to the corresponding areas in the original images. Each layer of a convolutional neural network consists of many 2-D arrays called *channels*. Pass the image through the network and examine the output activations of the `maxpool_1` layer.

```
act1 = hw.activations(single(im), 'maxpool_1', 'Profiler', 'on');



| offset_name             | offset_address  | allocated_space   |
|-------------------------|-----------------|-------------------|
| "InputDataOffset"       | "0x0000000000"  | "24.0 MB"         |
| "OutputResultOffset"    | "0x0180000000"  | "136.0 MB"        |
| "SystemBufferOffset"    | "0x0a00000000"  | "64.0 MB"         |
| "InstructionDataOffset" | "0x0e00000000"  | "8.0 MB"          |
| "ConvWeightDataOffset"  | "0x0e80000000"  | "4.0 MB"          |
| "EndOffset"             | "0x0ec00000000" | "Total: 236.0 MB" |



### Programming FPGA Bitstream using JTAG...
### Programming the FPGA bitstream has been completed successfully.

### Finished writing input activations.
### Running single input activations.
```

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total
Network	10182024	0.06788	1	10182024
conv_module	10182024	0.06788		
conv_1	7088885	0.04726		
maxpool_1	3093166	0.02062		


\* The clock frequency of the DL processor is: 150MHz

The activations are returned as a 3-D array, with the third dimension indexing the channel on the `maxpool_1` layer. To show these activations using the `imtile` function, reshape the array to 4-D. The third dimension in the input to `imtile` represents the image color. Set the third dimension to have size 1 because the activations do not have color. The fourth dimension indexes the channel.

```
sz = size(act1);
act1 = reshape(act1,[sz(1) sz(2) 1 sz(3)]);
```

Display the activations. Each activation can take any value, so normalize the output using the `mat2gray`. All activations are scaled so that the minimum activation is 0 and the maximum activation is 1. Display the 96 images on an 12-by-8 grid, one for each channel in the layer.

```
I = imtile(mat2gray(act1), 'GridSize',[12 8]);
imshow(I)
```



### Investigate Activations in Specific Channels

Each tile in the activations grid is the output of a channel in the `maxpool_1` layer. White pixels represent strong positive activations and black pixels represent strong negative activations. A channel that is mostly gray does not activate as strongly on the input image. The position of a pixel in the activation of a channel corresponds to the same position in the original image. A white pixel at a location in a channel indicates that the channel is strongly activated at that position.

Resize the activations in channel 33 to be the same size as the original image and display the activations.

```
act1ch33 = act1(:,:, :, 22);
act1ch33 = mat2gray(act1ch33);
act1ch33 = imresize(act1ch33, imgSize);

I = imtile({im, act1ch33});
imshow(I)
```



### Find Strongest Activation Channel

Find interesting channels by programmatically investigating channels with large activations. Find the channel that has the largest activation by using the `max` function, resize the channel output, and display the activations.

```
[maxValue, maxValueIndex] = max(max(max(act1)));
act1chMax = act1(:,:, :, maxValueIndex);
act1chMax = mat2gray(act1chMax);
act1chMax = imresize(act1chMax, imgSize);

I = imtile({im, act1chMax});
imshow(I)
```



Compare the strongest activation channel image to the original image. This channel activates on edges. It activates positively on light left/dark right edges and negatively on dark left/light right edges.

## See Also

[compile](#) | [deploy](#) | [getBuildInfo](#) | [predict](#)

**Introduced in R2020b**

# compile

**Class:** dlhdl.Workflow

**Package:** dlhdl

Compile workflow object

## Syntax

```
compile  
compile(Name,Value)
```

## Description

`compile` compiles the `dlhdl.Workflow` object and generates the parameters for deploying the network on the target device.

`compile(Name,Value)` compiles the `dlhdl.Workflow` object and generates the parameters for deploying the network on the target device, with additional options specified by one or more `Name,Value` pair arguments.

The function returns two matrices. One matrix describes the layers of the network. The **Conv Controller (Scheduling)** and the **FC Controller (Scheduling)** modules in the deep learning processor IP use this matrix to schedule the convolution and fully connected layer operations. The second matrix contains the weights, biases, and inputs of the neural network. This information is loaded onto the DDR memory and used by the **Generic Convolution Processor** and the **Generic FC Processor** in the deep learning processor.

## Input Arguments

### Name-Value Pair Arguments

Specify optional comma-separated pairs of `Name,Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1,Value1,...,NameN,ValueN`.

#### **InputFrameNumberLimit — Maximum input frame number limit** integer

Parameter to specify maximum input frame number limit to calculate DDR memory access allocation.

Example: '`InputFrameNumberLimit`',30

## Examples

### Compile the `dlhdl.Workflow` object

Compile the `dlhdl.Workflow` object, for deployment to the Intel® Arria® 10 SoC development kit that has single data types.

Create a `dlhdl.Workflow` object and then use the `compile` function to deploy the pretrained network to the target hardware.

```
snet = vgg19;
hT = dlhdl.Target('Intel');
hW = dlhdl.Workflow('network', snet, 'Bitstream', 'arrial0soc_single','Target',hT);
hW.compile
```

Once the code is executed the result is:

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"24.0 MB"
"OutputResultOffset"	"0x01800000"	"4.0 MB"
"SystemBufferOffset"	"0x01c00000"	"52.0 MB"
"InstructionDataOffset"	"0x05000000"	"20.0 MB"
"ConvWeightDataOffset"	"0x06400000"	"276.0 MB"
"FCWeightDataOffset"	"0x17800000"	"472.0 MB"
"EndOffset"	"0x35000000"	"Total: 848.0 MB"

```
ans =
struct with fields:
    Operators: [1x1 struct]
    LayerConfigs: [1x1 struct]
    NetConfigs: [1x1 struct]
```

## Generate DDR Memory Offsets Based On Number of Input Frames

- 1 Create a `dlhdl.Workflow` object and then use the `compile` function with optional argument of `InputFrameNumberLimit` to deploy the pretrained network to the target hardware.

```
snet = alexnet;
hT = dlhdl.Target('Xilinx');
hW = dlhdl.Workflow('network', snet, 'Bitstream', 'zcul02_single','Target',hT);
hW.compile('InputFrameNumberLimit',30);
```

- 2 The result of the code execution is:

```
### Compiling network for Deep Learning FPGA prototyping ...
### Targeting FPGA bitstream zcul02_single ...
### The network includes the following layers:

 1  'data'      Image Input          227x227x3 images with 'zerocenter' normalization
 2  'conv1'     Convolution        96 11x11x3 convolutions with stride [4 4] and padding [0 0 0 0]
 3  'relu1'     ReLU              ReLU
 4  'norm1'    Cross Channel Normalization cross channel normalization with 5 channels per element
 5  'pool1'     Max Pooling       3x3 max pooling with stride [2 2] and padding [0 0 0 0]
 6  'conv2'     Grouped Convolution 2 groups of 128 5x5x48 convolutions with stride [1 1] and padding [0 0 0 0]
 7  'relu2'     ReLU              ReLU
 8  'norm2'    Cross Channel Normalization cross channel normalization with 5 channels per element
 9  'pool2'     Max Pooling       3x3 max pooling with stride [2 2] and padding [0 0 0 0]
10  'conv3'     Convolution        384 3x3x256 convolutions with stride [1 1] and padding [1 1 1]
11  'relu3'     ReLU              ReLU
12  'conv4'     Grouped Convolution 2 groups of 192 3x3x192 convolutions with stride [1 1] and padding [0 0 0 0]
13  'relu4'     ReLU              ReLU
14  'conv5'     Grouped Convolution 2 groups of 128 3x3x192 convolutions with stride [1 1] and padding [0 0 0 0]
15  'relu5'     ReLU              ReLU
16  'pool5'     Max Pooling       3x3 max pooling with stride [2 2] and padding [0 0 0 0]
17  'fc6'       Fully Connected   4096 fully connected layer
18  'relu6'     ReLU              ReLU
```

```

19  'drop6'    Dropout          50% dropout
20  'fc7'      Fully Connected 4096 fully connected layer
21  'relu7'    ReLU             ReLU
22  'drop7'    Dropout          50% dropout
23  'fc8'      Fully Connected 1000 fully connected layer
24  'prob'     Softmax          softmax
25  'output'   Classification Output crossentropyex with 'tench' and 999 other classes

3 Memory Regions created.

Skipping: data
Compiling leg: conv1>>pool5 ...
Compiling leg: conv1>>pool5 ... complete.
Compiling leg: fc6>>fc8 ...
Compiling leg: fc6>>fc8 ... complete.
Skipping: prob
Skipping: output
Creating Schedule...
.....
Creating Schedule...complete.
Creating Status Table...
.....
Creating Status Table...complete.
Emitting Schedule...
.....
Emitting Schedule...complete.
Emitting Status Table...
.....
Emitting Status Table...complete.

### Allocating external memory buffers:



| offset_name             | offset_address | allocated_space   |
|-------------------------|----------------|-------------------|
| "InputDataOffset"       | "0x00000000"   | "24.0 MB"         |
| "OutputResultOffset"    | "0x01800000"   | "4.0 MB"          |
| "SchedulerDataOffset"   | "0x01c00000"   | "4.0 MB"          |
| "SystemBufferOffset"    | "0x02000000"   | "28.0 MB"         |
| "InstructionDataOffset" | "0x03c00000"   | "4.0 MB"          |
| "ConvWeightDataOffset"  | "0x04000000"   | "16.0 MB"         |
| "FCWeightDataOffset"    | "0x05000000"   | "224.0 MB"        |
| "EndOffset"             | "0x13000000"   | "Total: 304.0 MB" |



### Network compilation complete.

```

## Compile dagnet network object

- Create a `dlhdl.Workflow` object with `resnet18` as the network for deployment to a Xilinx® Zynq® UltraScale+™ MPSoC ZCU102 board which uses `single` data types.

```

snet = resnet18;
hTarget = dlhdl.Target('Xilinx');
hW = dlhdl.Workflow('N',snet,'B','zcu102_single','T',hTarget);

```

- Call the `compile` function on `hW`

```
hW.compile
```

Calling the `compile` function, returns:

```

### Compiling network for Deep Learning FPGA prototyping ...
### Targeting FPGA bitstream zcu102_single ...
### The network includes the following layers:

```

```

1  'data'           Image Input
2  'conv1'          Convolution

```

```

224x224x3 images with 'zsobel' normalization
64 7x7x3 convolutions with stride [2 2] and p

```

```

3  'bn_conv1'           Batch Normalization
4  'conv1_relu'         ReLU
5  'pool1'              Max Pooling
6  'res2a_branch2a'    Convolution
7  'bn2a_branch2a'     Batch Normalization
8  'res2a_branch2a_relu' ReLU
9  'res2a_branch2b'    Convolution
10 'bn2a_branch2b'     Batch Normalization
11 'res2a'               Addition
12 'res2a_relu'          ReLU
13 'res2b_branch2a'    Convolution
14 'bn2b_branch2a'     Batch Normalization
15 'res2b_branch2a_relu' ReLU
16 'res2b_branch2b'    Convolution
17 'bn2b_branch2b'     Batch Normalization
18 'res2b'               Addition
19 'res2b_relu'          ReLU
20 'res3a_branch2a'    Convolution
21 'bn3a_branch2a'     Batch Normalization
22 'res3a_branch2a_relu' ReLU
23 'res3a_branch2b'    Convolution
24 'bn3a_branch2b'     Batch Normalization
25 'res3a'               Addition
26 'res3a_relu'          ReLU
27 'res3a_branch1'    Convolution
28 'bn3a_branch1'     Batch Normalization
29 'res3b_branch2a'    Convolution
30 'bn3b_branch2a'     Batch Normalization
31 'res3b_branch2a_relu' ReLU
32 'res3b_branch2b'    Convolution
33 'bn3b_branch2b'     Batch Normalization
34 'res3b'               Addition
35 'res3b_relu'          ReLU
36 'res4a_branch2a'    Convolution
37 'bn4a_branch2a'     Batch Normalization
38 'res4a_branch2a_relu' ReLU
39 'res4a_branch2b'    Convolution
40 'bn4a_branch2b'     Batch Normalization
41 'res4a'               Addition
42 'res4a_relu'          ReLU
43 'res4a_branch1'    Convolution
44 'bn4a_branch1'     Batch Normalization
45 'res4b_branch2a'    Convolution
46 'bn4b_branch2a'     Batch Normalization
47 'res4b_branch2a_relu' ReLU
48 'res4b_branch2b'    Convolution
49 'bn4b_branch2b'     Batch Normalization
50 'res4b'               Addition
51 'res4b_relu'          ReLU
52 'res5a_branch2a'    Convolution
53 'bn5a_branch2a'     Batch Normalization
54 'res5a_branch2a_relu' ReLU
55 'res5a_branch2b'    Convolution
56 'bn5a_branch2b'     Batch Normalization
57 'res5a'               Addition
58 'res5a_relu'          ReLU
59 'res5a_branch1'    Convolution
60 'bn5a_branch1'     Batch Normalization
61 'res5b_branch2a'    Convolution
62 'bn5b_branch2a'     Batch Normalization
63 'res5b_branch2a_relu' ReLU
64 'res5b_branch2b'    Convolution
65 'bn5b_branch2b'     Batch Normalization
66 'res5b'               Addition
67 'res5b_relu'          ReLU
68 'pool5'              Global Average Pooling
69 'fc1000'             Fully Connected
70 'prob'                Softmax
71 'ClassificationLayer_predictions' Classification Output

```

### Optimizing series network: Fused 'nnet.cnn.layer.BatchNormLayer' into 'nnet.cnn.layer.Convolution2DLayer'  
5 Memory Regions created.

```

Skipping: data
Compiling leg: conv1>>pool1 ...
Compiling leg: conv1>>pool1 ... complete.
Compiling leg: res2a_branch2a>>res2a_branch2b ...
Compiling leg: res2a_branch2a>>res2a_branch2b ... complete.
Compiling leg: res2b_branch2a>>res2b_branch2b ...
Compiling leg: res2b_branch2a>>res2b_branch2b ... complete.
Compiling leg: res3a_branch2a>>res3a_branch2b ...
Compiling leg: res3a_branch2a>>res3a_branch2b ... complete.
Compiling leg: res3a_branch1 ...
Compiling leg: res3a_branch1 ... complete.
Compiling leg: res3b_branch2a>>res3b_branch2b ...
Compiling leg: res3b_branch2a>>res3b_branch2b ... complete.
Compiling leg: res4a_branch2a>>res4a_branch2b ...
Compiling leg: res4a_branch2a>>res4a_branch2b ... complete.
Compiling leg: res4a_branch1 ...
Compiling leg: res4a_branch1 ... complete.
Compiling leg: res4b_branch2a>>res4b_branch2b ...
Compiling leg: res4b_branch2a>>res4b_branch2b ... complete.
Compiling leg: res5a_branch2a>>res5a_branch2b ...
Compiling leg: res5a_branch2a>>res5a_branch2b ... complete.
Compiling leg: res5a_branch1 ...
Compiling leg: res5a_branch1 ... complete.
Compiling leg: res5b_branch2a>>res5b_branch2b ...
Compiling leg: res5b_branch2a>>res5b_branch2b ... complete.
Compiling leg: pool5 ...
Compiling leg: pool5 ... complete.
Compiling leg: fc1000 ...
Compiling leg: fc1000 ... complete.
Skipping: prob
Skipping: ClassificationLayer_predictions
Creating Schedule...
.....
Creating Schedule...complete.
Creating Status Table...
.....
Creating Status Table...complete.
Emitting Schedule...
.....
Emitting Schedule...complete.
Emitting Status Table...
.....
Emitting Status Table...complete.

### Allocating external memory buffers:



| offset_name             | offset_address | allocated_space   |
|-------------------------|----------------|-------------------|
| "InputDataOffset"       | "0x00000000"   | "24.0 MB"         |
| "OutputResultOffset"    | "0x01800000"   | "4.0 MB"          |
| "SchedulerDataOffset"   | "0x01c00000"   | "4.0 MB"          |
| "SystemBufferOffset"    | "0x02000000"   | "28.0 MB"         |
| "InstructionDataOffset" | "0x03c00000"   | "4.0 MB"          |
| "ConvWeightDataOffset"  | "0x04000000"   | "52.0 MB"         |
| "FCWeightDataOffset"    | "0x07400000"   | "4.0 MB"          |
| "EndOffset"             | "0x07800000"   | "Total: 120.0 MB" |



### Network compilation complete.

ans =
struct with fields:
    weights: [1x1 struct]
    instructions: [1x1 struct]
        registers: [1x1 struct]
    syncInstructions: [1x1 struct]

```

**See Also**

`deploy` | `getBuildInfo` | `predict`

**Topics**

“Use the Compiler Output for System Integration”

**Introduced in R2020b**

# deploy

**Class:** dlhdl.Workflow

**Package:** dlhdl

Deploy the specified neural network to the target FPGA board

## Syntax

`deploy`

## Description

`deploy` programs the specified target board with the bitstream and deploys the deep learning network on it.

## Examples

### Deploy LogoNet to Intel Arria 10 SoC Development Kit

Deploy VGG-19 to the Intel Arria 10 SoC development kit that has `single` data types.

The `deploy` function starts programming the FPGA device, displays progress messages, and the time it takes to deploy the network.

```

1 snet = vgg19;
    hTarget = dlhdl.Target('Intel');
    hw = dlhdl.Workflow('Network', snet, 'Bitstream', 'arria10soc_single','Target',hTarget);
    hw.deploy
2 ### Programming FPGA bitstream using JTAG ...
### Programming FPGA bitstream has completed successfully.



| offset_name             | offset_address | allocated_space   |
|-------------------------|----------------|-------------------|
| "InputDataOffset"       | "0x00000000"   | "24.0 MB"         |
| "OutputResultOffset"    | "0x01800000"   | "4.0 MB"          |
| "SystemBufferOffset"    | "0x01c00000"   | "52.0 MB"         |
| "InstructionDataOffset" | "0x05000000"   | "20.0 MB"         |
| "ConvWeightDataOffset"  | "0x06400000"   | "276.0 MB"        |
| "FCWeightDataOffset"    | "0x17800000"   | "472.0 MB"        |
| "EndOffset"             | "0x35000000"   | "Total: 848.0 MB" |



### Loading weights to FC Processor.
### 4% finished, current time is 14-Jun-2020 18:31:07.
### 8% finished, current time is 14-Jun-2020 18:31:32.
### 12% finished, current time is 14-Jun-2020 18:31:58.
### 16% finished, current time is 14-Jun-2020 18:32:23.
### 20% finished, current time is 14-Jun-2020 18:32:48.
### 24% finished, current time is 14-Jun-2020 18:33:13.
### 28% finished, current time is 14-Jun-2020 18:33:39.
### 32% finished, current time is 14-Jun-2020 18:34:04.
### 36% finished, current time is 14-Jun-2020 18:34:30.
### 40% finished, current time is 14-Jun-2020 18:34:56.
### 44% finished, current time is 14-Jun-2020 18:35:21.
### 48% finished, current time is 14-Jun-2020 18:35:46.
### 52% finished, current time is 14-Jun-2020 18:36:11.
```

```
### 56% finished, current time is 14-Jun-2020 18:36:36.
### 60% finished, current time is 14-Jun-2020 18:37:02.
### 64% finished, current time is 14-Jun-2020 18:37:27.
### 68% finished, current time is 14-Jun-2020 18:37:52.
### 72% finished, current time is 14-Jun-2020 18:38:17.
### 76% finished, current time is 14-Jun-2020 18:38:43.
### 80% finished, current time is 14-Jun-2020 18:39:08.
### 84% finished, current time is 14-Jun-2020 18:39:33.
### 88% finished, current time is 14-Jun-2020 18:39:58.
### 92% finished, current time is 14-Jun-2020 18:40:23.
### 96% finished, current time is 14-Jun-2020 18:40:48.
### FC Weights loaded. Current time is 14-Jun-2020 18:41:06
```

## Deploy Quantized LogoNet to Xilinx ZCU102 Development Kit

- 1 Create a file in your current working directory called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork
    data = getLogoData;
    net = data.convnet;
end

function data = getLogoData
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

- 2 Create an image datastore and split 70 percent of the images into a training data set and 30 percent of the images into a validation data set.

```
curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir);
unzip('logos_dataset.zip');
imds = imageDatastore('logos_dataset', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[imdsTrain,imdsValidation] = splitEachLabel(imds,0.7,'randomized');
```

- 3 Create a `dlhdl.Workflow` object which has quantized LogoNet as the network argument, `zcu102_int8` as the bitstream, and `hTarget` as the target argument.

To quantize the network, you need the products listed under FPGA in “Quantization Workflow Prerequisites”.

```
% Save the pretrained SeriesNetwork object
snet = getLogoNetwork;

% Create a Target object and define the interface to the target board
hTarget = dlhdl.Target('Xilinx','Interface','Ethernet');

% Create a Quantized Network Object
dlquantObj = dlquantizer(snet,'ExecutionEnvironment','FPGA');
dlquantObj.calibrate(imdsTrain);

% Create a workflow object for the SeriesNetwork and using the FPGABitstream
hw = dlhdl.Workflow('Network', dlquantObj, 'Bitstream', 'zcu102_int8','Target',hTarget);
```

- 4 Deploy the `dlhdl.Workflow` object to your target FPGA board by using the `deploy` method.

```
% Deploy the workflow object
hw.deploy;
```

- 5 When you call the `deploy` method, the method returns:

```
### Programming FPGA Bitstream using Ethernet...
Downloading target FPGA device configuration over Ethernet to SD card ...
```

```
# Copied /tmp/hdlcoder_rd to /mnt/hdlcoder_rd
# Copying Bitstream hdlcoder_system.bit to /mnt/hdlcoder_rd
# Set Bitstream to hdlcoder_rd/hdlcoder_system.bit
# Copying Devicetree devicetree_dlhdl.dtb to /mnt/hdlcoder_rd
# Set Devicetree to hdlcoder_rd/devicetree_dlhdl.dtb
# Set up boot for Reference Design: 'AXI-Stream DDR Memory Access : 3-AXIM'
```

Downloading target FPGA device configuration over Ethernet to SD card done. The system will now reboot for persistent memory.

```
System is rebooting . . . .
### Programming the FPGA bitstream has been completed successfully.
```

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```
### Loading weights to FC Processor.
### FC Weights loaded. Current time is 12-Jun-2020 13:17:56
```

## See Also

`compile` | `getBuildInfo` | `predict` | `dlquantizer` | `dlquantizationOptions` | `calibrate` | `validate`

**Introduced in R2020b**

# getBuildInfo

**Class:** dlhdl.Workflow

**Package:** dlhdl

Retrieve bitstream resource utilization

## Syntax

```
area = getBuildInfo
```

## Description

area = getBuildInfo returns a structure containing the bitstream resource utilization.

## Output Arguments

**area — Bitstream resource utilization structure**

Bitstream resource utilization returned as a structure.

- The **Block Memory Bits** utilization is available for Intel bitstreams only.
- The resource utilization results of Intel bitstreams show the **Block RAM** utilization as 100%. To analyze bitstream resource utilization, refer to the **Block Memory Bits** utilization instead.

## Examples

### Retrieve arria10soc\_singleBitstream Resource Utilization

- 1 Create a file in your current working folder called `getLogoNetwork.m`. In the file, enter:

```
function net = getLogoNetwork
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
    net = data.convnet;
end
```

- 2 Create a `dlhdl.Workflow` object that has `LogoNet` as the `Network` argument and `arria10soc_single` as the `Bitstream` argument.

```
snet = getLogoNetwork;
hW = dlhdl.Workflow('Network',snet,'Bitstream','arria10soc_single');
```

- 3 Call `getBuildInfo` argument to retrieve the `arria10soc_single` resource utilization. Store the resource utilization in `area`.

```
area = hW.getBuildInfo
```

Deep Learning Processor Bitstream Build Info

Resource	Utilized	Total	Percentage
----------	----------	-------	------------

LUTs (CLB/ALM)*	93578	251680	37.18
DSPs	278	1687	16.48
Block RAM	2131	2131	100.00
Block Memory Bits	23211920	43642880	53.19
* LUT count represents Configurable Logic Block(CLB) utilization in Xilinx devices and Adaptive Logic Module (ALM) utilization in Zynq devices.			

```
area =
```

```
    struct with fields:
```

```
        LUT: [93578 251680]
        BlockMemoryBits: [23211920 43642880]
            BlockRAM: [2131 2131]
            DSP: [278 1687]
```

## See Also

[compile](#) | [deploy](#) | [predict](#)

**Introduced in R2021a**

# **predict**

**Class:** `dlhdl.Workflow`

**Package:** `dlhdl`

Run inference on deployed network and profile speed of neural network deployed on specified target device

## **Syntax**

```
predict(image)
predict(image, Name, Value)
```

## **Description**

`predict(image)` predicts responses for the image data in `imds` by using the deep learning network that you specified in the `dlhdl.Workflow` class for deployment on the specified target board and returns the results.

`predict(image, Name, Value)` predicts responses for the image data in `imds` by using the deep learning network that you specified by using the `dlhdl.Workflow` class for deployment on the specified target boards and returns the results, with one or more arguments specified by optional name-value pair arguments.

## **Input Arguments**

### **image — Input image**

*m*-by-*n*-by-*k* numeric array

Input image, specified as a *m*-by-*n*-by-*k* numeric array. *m*, *n*, and *k* must match the dimensions of the deep learning network input image layer. For example, for the LogoNet network, resize the input images to a 227-by-227-by-3 array.

Data Types: `single`

### **Name-Value Pair Arguments**

Specify optional comma-separated pairs of `Name,Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1,Value1,...,NameN,ValueN`.

Example:

### **Profile — Flag that returns profiling results**

`'off'` (default) | `'on'`

Flag to return profiling results, for the deep learning network deployed to the target board.

Example: `'Profile', 'On'`

## **Examples**

## Predict Outcome and Profile Results

- Create a `dlhdl.Workflow` object that has VGG-19 as the network argument, `arrial0soc_single` as the bitstream argument, and `hTarget` as the target argument.

```
% Save the pretrained SeriesNetwork object
snet = vgg19;

% Create a Target object and define the interface to the target board
hTarget = dlhdl.Target('Intel');

% Create a workflow object for the SeriesNetwork and using the FPFA bitstream
hw = dlhdl.Workflow('Network', snet, 'Bitstream', 'arrial0soc_single','Target',hTarget);
```

- Load your input image and resize the input image to match the image input layer size for the VGG-19 network.

```
% Load input images and resize them according to the network specifications
image = imread('zebra.jpeg');
inputImg = imresize(image, [224, 224]);
imshow(inputImg);
imIn = single(inputImg);
```

- Deploy the `dlhdl.Workflow` object to your target FPGA board by using the `deploy` method. Retrieve the VGG-19 network prediction result for your input image from the FPGA board by using the `predict` method.

```
% Deploy the workflow object
hw.deploy;
% Predict the outcome and optionally profile the results to measure performance.
[prediction, speed] = hw.predict(imIn,'Profile','on');
[val, idx] = max(prediction);
snet.Layers(end).ClassNames{idx}
```

## Obtain Prediction Results for Quantized LogoNet Network

This example shows how to use the `predict` method to retrieve the prediction results for an input image from a deployed quantized LogoNet network.

- Create a file in your current working folder called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork
    data = getLogoData;
    net = data.convnet;
end

function data = getLogoData
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

- Create an image datastore and split 70 percent of the images into a training data set and 30 percent of the images into a validation data set.

```
curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir);
unzip('logos_dataset.zip');
imds = imageDatastore('Logos_dataset', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[imdsTrain,imdsValidation] = splitEachLabel(imds,0.7,'randomized');
```

- Create a `dlhdl.Workflow` object which has quantized LogoNet as the network argument, `zcu102_int8` as the bitstream, and `hTarget` as the target argument.

To quantize the network, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

```
% Save the pretrained SeriesNetwork object
snet = getLogoNetwork;

% Create a Target object and define the interface to the target board
hTarget = dlhdl.Target('Xilinx','Interface','Ethernet');

% Create a Quantized Network Object
dlquantObj = dlquantizer(snet,'ExecutionEnvironment','FPGA');
dlquantObj.calibrate(imdsTrain);

% Create a workflow object for the SeriesNetwork and using the FPFA bitstream
hw = dlhdl.Workflow('Network', dlquantObj, 'Bitsream', 'zcu102_int8','Target',hTarget);
```

- 4** Retrieve a random image from `logos_dataset`.

```
index = randperm(numel(imdsValidation.Files),1)
imIn = readimage(imdsValidation,index)
inputImg = imresize(imIn, [227 227]);
```

- 5** Deploy the `dlhdl.Workflow` object to your target FPGA board by using the `deploy` method. Retrieve the prediction for the image by using the `predict` method.

```
% Deploy the workflow object
hw.deploy;
% Predict the outcome and optionally profile the results to measure performance.
[prediction, speed] = hw.predict(single(inputImg),'Profile','on');
[val, idx] = max(prediction);
snet.Layers(end).ClassNames{idx}
```

## See Also

`compile` | `deploy` | `getBuildInfo` | `dlquantizer` | `dlquantizationOptions` | `calibrate` | `validate`

## Topics

“Profile Inference Run”  
“Profile Network for Performance Improvement”

## Introduced in R2020b

# dlhdl.Target class

**Package:** dlhdl

Configure interface to target board for workflow deployment

## Description

Use the `dlhdl.Target` object to create the interface to deploy the `dlhdl.Workflow` object to your target hardware.

## Creation

`hTarget = dlhdl.Target(Vendor)` creates a target object that you pass on to `dlhdl.Workflow` to deploy your deep learning network to your target device.

`hTarget = dlhdl.Target(Vendor,Name,Value)` creates a target object that you pass on to `dlhdl.Workflow`, with additional properties specified by one or more `Name,Value` pair arguments.

### Input Arguments

#### **Vendor — Target board vendor name**

'Xilinx' (default) | 'Intel' | "Xilinx" | "Intel"

Target device vendor name, specified as a character vector or string.

Example: 'Xilinx' or "Xilinx"

## Properties

Specify optional comma-separated pairs of `Name,Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1,Value1,...,NameN,ValueN`.

#### **Interface — Interface to connect to the target board**

'JTAG' (default) | 'Ethernet'

Name of the interface specified as a character vector.

Example: 'Interface', 'JTAG' creates a target configuration object with 'JTAG' as the interface to the target device.

#### **IPAddress — IP address for the target device with Ethernet interface**

'' (default)

IP address for the target device with the Ethernet interface specified as a character vector.

Example: 'IPAddress', '192.168.1.101' creates a target configuration object with '192.168.1.101' as the target device IP address.

#### **Username — SSH user name**

'root' (default)

SSH user name specified as a character vector.

Example: 'Username', 'root' creates a target configuration object with 'root' as the SSH user name.

#### **Password — SSH password**

'root' | 'cyclonevsoc'

Password of the root user specified as a character vector. Use 'root' on the Xilinx SoC boards and 'cyclonevsoc' on the Intel SoC boards.

Example: 'Password', 'root' creates a target configuration object with 'root' as the SSH password for Xilinx SoC boards.

Example: 'Password', 'cyclonevsoc' creates a target configuration object with 'cyclonevsoc' as the SSH password for Intel SoC boards.

#### **Port — SSH connection port number**

22 (default)

SSH port number specified as an integer.

Example: 'Port', 22 creates a target configuration object with 22 as the SSH port number.

## **Methods**

### **Public Methods**

release	Release the connection to the target device
validateConnection	Validate SSH connection and deployed bitstream

## **Examples**

### **Create Target Object That Has a JTAG interface**

```
hTarget = dlhdl.Target('Xilinx','Interface','JTAG')
hTarget =
```

Target with properties:

```
Vendor: 'Xilinx'
Interface: JTAG
```

### **Create Target Object That Has an Ethernet Interface and Set IP Address**

```
hTarget = dlhdl.Target('Xilinx','Interface','Ethernet','IPAddress','192.168.1.101')
hTarget =
```

Target with properties:

```
Vendor: 'Xilinx'
Interface: Ethernet
IPAddress: '192.168.1.101'
Username: 'root'
Port: 22
```

## See Also

### Functions

`release | validateConnection`

### Objects

`dlhdl.Workflow`

**Introduced in R2020b**

# release

**Class:** dlhdl.Target

**Package:** dlhdl

Release the connection to the target device

## Syntax

```
release
```

## Description

release releases the connection to the target board.

## Examples

### Release Connection to Target Device

- 1 Create a dlhdl.Target object that has an Ethernet interface and SSH connection.

```
hTarget = dlhdl.Target('Xilinx','Interface','Ethernet','IPAddress','192.168.1.101');
```

- 2 Create a dlhdl.Workflow object and deploy the object to the target board.

```
snet = alexnet;
hW = dlhdl.Workflow('Network',snet,'BitstreamName','zcu102_single', 'Target', hTarget);
hW.deploy;
```

- 3 Obtain a prediction.

Use this image to run the code:



```
% Load input images and resize them according to the network specifications
image = imread('zebra.jpeg');
inputImg = imresize(image, [227, 227]);
imshow(inputImg);
% Predict the outcome and optionally profile the results to measure performance.
[prediction, speed] = hW.predict(single(inputImg), 'Profile', 'on' );
```

- 4 Release the connection.

```
hTarget.release;
```

**See Also**

[validateConnection](#)

**Introduced in R2020b**

# validateConnection

**Class:** dlhdl.Target

**Package:** dlhdl

Validate SSH connection and deployed bitstream

## Syntax

```
validateConnection
```

## Description

**validateConnection:**

- 1 First validates the SSH connection for an Ethernet interface. This step is skipped for a JTAG interface.
- 2 Validates the connection for a deployed bitstream.

## Examples

### Validate dlhdl.Target Object that has a JTAG Interface

Validate deployed bitstream and SSH connection to the target device.

- 1 Create a dlhdl.Target object with a JTAG interface.

```
hTarget = dlhdl.Target('Intel','Interface','JTAG');
```

- 2 Create a dlhdl.Workflow object and deploy the object to the target board.

```
snet = vgg19;
hw = dlhdl.Workflow('Network',snet,'BitstreamName','arrial0soc_single', 'Target', hTarget);
hw.deploy;
```

- 3 Validate the connection and bitstream.

```
hTarget.validateConnection
### Validating connection to bitstream over JTAG interface
### Bitstream connection over JTAG interface successful
```

### Validate dlhdl.Target Object that has an Ethernet Interface

Validate deployed bitstream and SSH connection to the target device.

- 1 Create a dlhdl.Target object that has an Ethernet interface.

```
hTarget = dlhdl.Target('Xilinx','Interface','Ethernet','IPAddress','10.10.10.14');
```

- 2 Create a dlhdl.Workflow object and deploy the object to the target board.

```
snet = alexnet;
hw = dlhdl.Workflow('Network',snet,'Bitstream','zcu102_single', 'Target', hTarget);
hw.deploy;
```

- 3** Validate the connection and bitstream.

```
hTarget.validateConnection
### Validating connection to target over SSH
### SSH connection successful
### Validating connection to bitstream over Ethernet interface
### Bitstream connection over Ethernet interface successful
```

**See Also**

[release](#)

**Introduced in R2020b**

# dlhdl.ProcessorConfig class

**Package:** dlhdl

Configure custom deep learning processor

## Description

Use the `dlhdl.ProcessorConfig` class to configure a custom processor, which is then passed on to the `dlhdl.buildProcessor` class to generate a custom deep learning processor.

## Creation

The `dlhdl.ProcessorConfig` class creates a custom processor configuration object that you can use to specify the processor parameters. The processor parameters are then used by the `dlhdl.buildProcessor` class to build and generate code for your custom deep learning processor.

`dlhdl.ProcessorConfig(Name,Value)` creates a custom processor configuration object, with additional options specified by one or more name-value arguments.

## Properties

### System Level Properties

#### SynthesisTool — Synthesis tool name

'Xilinx Vivado' (default) | 'Altera Quartus II' | 'Xilinx ISE' | character vector

Synthesis tool name, specified as a character vector.

Example: `Xilinx Vivado`

#### SynthesisToolChipFamily — Synthesis tool chip family name

'Zynq Ultrascale+' (default) | 'Artix7' | 'Kintex7' | 'Kintex Ultrascale+' | 'Spartan7' | 'Virtex7' | 'Virtex Ultrascale+' | 'Zynq' | 'Arria 10' | 'Arria V GZ' | 'Cyclone 10 GX' | 'Stratix 10' | 'Stratix V' | character vector

Specify the target device chip family name as a character vector

Example: `'Zynq'`

#### TargetFrequency — Target frequency in MHz

200 (default) | integer

Specify the target board frequency in MHz.

Example: `220`

#### TargetPlatform — Name of the target board

'Xilinx Zynq Ultrascale+ MPSoC ZCU 102 Evaluation Kit' (default) | 'Generic Deep Learning Processor' | 'Altera Arria 10 SoC development kit' | 'Xilinx Zynq ZC706 evaluation kit' | character vector

Specify the name of the target board as a character vector.

Example: 'Xilinx Zynq ZC706 evaluation kit'

**Bitstream — Name of the bitstream**

'arria10soc\_single' | 'arria10soc\_int8' | 'zc706\_single' | 'zc706\_int8' | 'zcu102\_single' | 'zcu102\_int8'

Specify the name of the bitstream whose processor configuration must be retrieved as a character vector.

Example: 'Bitstream','zcu102\_single'

**Top Level Properties****RunTimeControl — Deep learning processor IP core mode setting**

'register' (default) | 'port' | character vector

Deep learning processor IP core mode, specified as a character vector. To use multiframe mode set RunTimeControl to 'register'. To use streaming mode, set the RunTimeControl to 'port'.

Example: 'register'

**InputDataInterface — Deep learning processor IP core input interface**

'External Memory' (default) | 'None' | character vector

Specify the deep learning processor IP core input interface option as a character vector

Example: 'External Memory'

**OutputDataInterface — Deep learning processor IP core output interface**

'External Memory' (default) | 'None' | character vector

Specify the deep learning processor IP core output interface option as a character vector

Example: 'External Memory'

**ProcessorDataType — Deep learning processor IP core module data type**

'single' (default) | 'int8' | 'half' | character vector

Specify the deep learning processor IP core module data type as a character vector.

Example: 'single'

**Processing Module conv Properties****ModuleGeneration — Enable or disable convolution module generation as a part of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the convolution module as a part of the deep learning processor configuration.

**LRNBlockGeneration — Enable or disable local response normalization (LRN) block generation as a part of the convolution module of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the LRN block as a part of the convolution module of the deep learning processor configuration.

**ConvThreadNumber — Number of parallel convolution processor kernel threads**

16 (default) | 4 | 9 | 16 | 25 | 36 | 64 | 256 | unsigned integer

This parameter is the number of parallel 3-by-3 convolution kernel threads that are a part of the conv module within the dlhdl.ProcessorConfig object.

**InputMemorySize — Cache block RAM (BRAM) sizes**

[227 227 3] (default) | 3D positive integer array

This parameter is a 3D matrix representing input image size limited by the conv module BRAM size within the dlhdl.ProcessorConfig object.

**OutputMemorySize — Cache block RAM (BRAM) sizes**

[227 227 3] (default) | 3D positive integer array

This parameter is a 3D matrix representing output image size limited by the conv module BRAM size within the dlhdl.ProcessorConfig object.

**FeatureSizeLimit — Maximum input and output feature size**

2048 (default) | positive integer

This parameter is a positive integer representing the maximum input and output feature size as a part of the conv module within the dlhdl.ProcessorConfig object.

**Processing Module fc Properties****ModuleGeneration — Enable or disable fully connected module generation as a part of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the fully connected module as a part of the deep learning processor configuration.

**SoftmaxBlockGeneration — Enable or disable Softmax block generation as a part of the fully connected module of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the Softmax block as a part of the fully connected module of the deep learning processor configuration. When you set this property to off, the Softmax layer is still implemented in software.

**FCThreadNumber — Number of parallel fully connected (fc) MAC threads**

4 (default) | 4 | 8 | 16 | 32 | 64 | unsigned integer

This parameter is the number of parallel fc MAC threads that are a part of the fc module within the dlhdl.ProcessorConfig object.

**InputMemorySize — Cache block RAM (BRAM) sizes**

25088 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the fc module BRAM size within the dlhdl.ProcessorConfig object.

**OutputMemorySize — Cache block RAM (BRAM) sizes**

4096 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the `fc` module BRAM size within the `dlhdl.ProcessorConfig` object.

#### **Processing Module adder Properties**

##### **ModuleGeneration — Enable or disable adder module generation as a part of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the adder module as a part of the deep learning processor configuration.

##### **InputMemorySize — Cache block RAM (BRAM) sizes**

40 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the `adder` module BRAM size within the `dlhdl.ProcessorConfig` object.

##### **OutputMemorySize — Cache block RAM (BRAM) sizes**

40 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the `adder` module BRAM size within the `dlhdl.ProcessorConfig` object.

## **Methods**

### **Public Methods**

<code>getModuleProperty</code>	Use the <code>getModuleProperty</code> method to get values of module properties within the <code>dlhdl.ProcessorConfig</code> object
<code>setModuleProperty</code>	Use the <code>setModuleProperty</code> method to set properties of modules within the <code>dlhdl.ProcessorConfig</code> object
<code>estimatePerformance</code>	Retrieve layer-level latencies and performance by using <code>estimatePerformance</code> method
<code>estimateResources</code>	Return estimated resources used by custom bitstream configuration
<code>optimizeConfigurationForNetwork</code>	Retrieve optimized network-specific deep learning processor configuration

## **Examples**

### **Create a ProcessorConfig Object**

Create a custom processor configuration. Save the `ProcessorConfig` object to `hPC`.

```
hPC = dlhdl.ProcessorConfig
```

The result is:

```
hPC =
```

```
Processing Module "conv"
    ModuleGeneration: 'on'
    LRNBlockGeneration: 'on'
    ConvThreadNumber: 16
    InputMemorySize: [227 227 3]
    OutputMemorySize: [227 227 3]
    FeatureSizeLimit: 2048
```

```

Processing Module "fc"
    ModuleGeneration: 'on'
    SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 25088
        OutputMemorySize: 4096

Processing Module "adder"
    ModuleGeneration: 'on'
    InputMemorySize: 40
    OutputMemorySize: 40

Processor Top Level Properties
    RunTimeControl: 'register'
    InputDataInterface: 'External Memory'
    OutputDataInterface: 'External Memory'
    ProcessorDataType: 'single'

System Level Properties
    TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
    TargetFrequency: 200
        SynthesisTool: 'Xilinx Vivado'
        ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
        SynthesisToolChipFamily: 'Zynq UltraScale+'
        SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
        SynthesisToolPackageName: ''
        SynthesisToolSpeedValue: ''

```

## Modify Properties of ProcessorConfig Object

Modify the TargetPlatform, SynthesisTool, and TargetFrequency properties of hPC.

```

hPC.TargetPlatform = 'Xilinx Zynq ZC706 evaluation kit';
>> hPC.SynthesisTool = 'Xilinx Vivado';
>> hPC.TargetFrequency = 180;
hPC

```

The result is:

```

hPC =

```

---

```

Processing Module "conv"
    ModuleGeneration: 'on'
    LRNBlockGeneration: 'on'
    ConvThreadNumber: 16
    InputMemorySize: [227 227 3]
    OutputMemorySize: [227 227 3]
    FeatureSizeLimit: 2048

Processing Module "fc"
    ModuleGeneration: 'on'
    SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 25088
        OutputMemorySize: 4096

Processing Module "adder"
    ModuleGeneration: 'on'
    InputMemorySize: 40
    OutputMemorySize: 40

Processor Top Level Properties
    RunTimeControl: 'register'
    InputDataInterface: 'External Memory'
    OutputDataInterface: 'External Memory'
    ProcessorDataType: 'single'

System Level Properties
    TargetPlatform: 'Xilinx Zynq ZC706 evaluation kit'
    TargetFrequency: 180
        SynthesisTool: 'Xilinx Vivado'
        ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
        SynthesisToolChipFamily: 'Zynq'

```

```
SynthesisToolDeviceName: 'xc7z045'  
SynthesisToolPackageName: 'ffg900'  
SynthesisToolSpeedValue: '-2'
```

## Retrieve ProcessorConfig object for zcu102\_single bitstream

Retrieve the ProcessorConfig object for the zcu102\_single bitstream and store the object in hPC.

```
hPC = dlhdl.ProcessorConfig('Bitstream','zcu102_single')
```

The result is:

```
hPC =  
  
Processing Module "conv"  
    ModuleGeneration: 'on'  
    LRNBlockGeneration: 'on'  
    ConvThreadNumber: 16  
    InputMemorySize: [227 227 3]  
    OutputMemorySize: [227 227 3]  
    FeatureSizeLimit: 2048  
  
Processing Module "fc"  
    ModuleGeneration: 'on'  
    SoftmaxBlockGeneration: 'off'  
    FCThreadNumber: 4  
    InputMemorySize: 25088  
    OutputMemorySize: 4096  
  
Processing Module "adder"  
    ModuleGeneration: 'on'  
    InputMemorySize: 40  
    OutputMemorySize: 40  
  
Processor Top Level Properties  
    RunTimeControl: 'register'  
    InputDataInterface: 'External Memory'  
    OutputDataInterface: 'External Memory'  
    ProcessorDataType: 'single'  
  
System Level Properties  
    TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'  
    TargetFrequency: 220  
    SynthesisTool: 'Xilinx Vivado'  
    ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'  
    SynthesisToolChipFamily: 'Zynq UltraScale+'  
    SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'  
    SynthesisToolPackageName: ''  
    SynthesisToolSpeedValue: ''
```

## Set the ProcessorConfig object module data type to int8

Create a custom processor configuration. Save the ProcessorConfig object to hPC.

```
hPC = dlhdl.ProcessorConfig
```

Modify the ProcessorDataType to int8.

```
hPC.ProcessorDataType = 'int8'
```

The result is:

```
hPC =  
  
Processing Module "conv"  
    ModuleGeneration: 'on'  
    LRNBlockGeneration: 'on'  
    ConvThreadNumber: 16  
    InputMemorySize: [227 227 3]  
    OutputMemorySize: [227 227 3]  
    FeatureSizeLimit: 2048  
  
Processing Module "fc"
```

```

    ModuleGeneration: 'on'
    SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 25088
        OutputMemorySize: 4096

    Processing Module "adder"
        ModuleGeneration: 'on'
            InputMemorySize: 40
            OutputMemorySize: 40

    Processor Top Level Properties
        RunTimeControl: 'register'
        InputDataInterface: 'External Memory'
        OutputDataInterface: 'External Memory'
        ProcessorDataType: 'int8'

    System Level Properties
        TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
        TargetFrequency: 200
            SynthesisTool: 'Xilinx Vivado'
            ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
        SynthesisToolChipFamily: 'Zynq UltraScale+'
        SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
        SynthesisToolPackageName: ''
        SynthesisToolSpeedValue: ''

```

## See Also

### Functions

`dlhdl.buildProcessor`

### Classes

`dlhdl.Workflow`

### Topics

- “Custom Processor Configuration Workflow”
- “Deep Learning Processor IP Core”
- “Estimate Performance of Deep Learning Network”
- “Estimate Resource Utilization for Custom Processor Configuration”

### Introduced in R2020b

# estimatePerformance

**Class:** dlhdl.ProcessorConfig

**Package:** dlhdl

Retrieve layer-level latencies and performance by using `estimatePerformance` method

## Syntax

```
estimatePerformance(network)
performance = estimatePerformance(network)
performance = estimatePerformance(network,Name,Value)
```

## Description

`estimatePerformance(network)` returns the layer-level latencies and network performance for the object specified by the `network` argument.

`performance = estimatePerformance(network)` returns a table containing the `network` object layer-level latencies and performance.

`performance = estimatePerformance(network,Name,Value)` returns a table containing the `network` object layer-level latencies and performance, with one or more arguments specified by optional name-value pair arguments.

## Input Arguments

### **network — Network object**

SeriesNetwork object | DAGNetwork object | yolov2ObjectDetector object | dlquantizer object

Name of network object for performance estimate.

Example: `estimatePerformance(snet)`

### **Name-Value Pair Arguments**

Specify optional comma-separated pairs of `Name,Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1,Value1,...,NameN,ValueN`.

#### **FrameCount — Number of frames to consider for the calculation of performance estimation**

1 (default) | integer

Number of frames to consider for the calculation of performance estimation, specified as a positive number integer.

Example: '`FrameCount', 10`

## Output Arguments

**performance — Network object performance**

table

Network object performance for the ProcessorConfig object, returned as a table.

## Examples

### Estimate Performance of LogoNet Network

- 1 Create a file in your current working folder called `getLogoNetwork.m`. In the file, enter:

```
function net = getLogoNetwork
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
    net = data.convnet;
end
```

- 2 Create a `dlhdl.ProcessorConfig` object.

```
snet = getLogoNetwork;
hPC = dlhdl.ProcessorConfig;
```

- 3 To retrieve the layer-level latencies and performance for the LogoNet network, call the `estimatePerformance` method.

```
hPC.estimatePerformance(snet)
```

```
### Notice: The layer 'imageinput' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'classoutput' with type 'nnet.cnn.layer.ClassificationOutputLayer' is implemented in software.
```

Deep Learning Processor Estimator Performance Results					
	LastFrameLatency(cycles)	LastFrameLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	39426458	0.19713	1	39426458	5.1
conv_1	6822215	0.03411			
maxpool_1	3755088	0.01878			
conv_2	10440701	0.05220			
maxpool_2	1447840	0.00724			
conv_3	9362677	0.04681			
maxpool_3	1765856	0.00883			
conv_4	1377268	0.00689			
maxpool_4	28098	0.00014			
fc_1	2644886	0.01322			
fc_2	1692534	0.00846			
fc_3	89295	0.00045			

\* The clock frequency of the DL processor is: 200MHz

### Estimate Performance of ResNet-18 for Multiple Frame Inputs

Estimate the performance of the ResNet-18 network for multiple frames by using the `dlhdl.ProcessorConfig` object.

Load the ResNet-18 network and save it to `net`

```
net = resnet18;
```

Create a `dlhdl.ProcessorConfig` object and save to `hPC`

```
hPC = dlhdl.ProcessorConfig;
```

Retrieve layer level latencies and performance in frames per second (FPS) for multiple frames by using the `estimatePerformance` method with `FrameNumber` as an optional input argument.

```
hPC.estimatePerformance(net, 'FrameCount', 10);
```

```
### Optimizing series network: Fused 'nnet.cnn.layer.BatchNormLayer' into 'nnet.cnn.layer.Convolution2DLayer'  
### Notice: The layer 'data' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.  
### Notice: The layer 'ClassificationLayer_predictions' with type 'nnet.cnn.layer.ClassificationOutputLayer' is implemented in software.
```

Deep Learning Processor Estimator Performance Results					
	LastFrameLatency(cycles)	LastFrameLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	21219873	0.10610	10	210125220	9.5
____conv1	2165372	0.01083			
____pool1	646226	0.00323			
____res2a_branch2a	966221	0.00483			
____res2a_branch2b	966221	0.00483			
____res2a	210750	0.00105			
____res2b_branch2a	966221	0.00483			
____res2b_branch2b	966221	0.00483			
____res2b	210750	0.00105			
____res3a_branch1	540749	0.00270			
____res3a_branch2a	708564	0.00354			
____res3a_branch2b	919117	0.00460			
____res3a	105404	0.00053			
____res3b_branch2a	919117	0.00460			
____res3b_branch2b	919117	0.00460			
____res3b	105404	0.00053			
____res4a_branch1	509261	0.00255			
____res4a_branch2a	509261	0.00255			
____res4a_branch2b	905421	0.00453			
____res4a	52724	0.00026			
____res4b_branch2a	905421	0.00453			
____res4b_branch2b	905421	0.00453			
____res4b	52724	0.00026			
____res5a_branch1	751693	0.00376			
____res5a_branch2a	751693	0.00376			
____res5a_branch2b	1415373	0.00708			
____res5a	26368	0.00013			
____res5b_branch2a	1415373	0.00708			
____res5b_branch2b	1415373	0.00708			
____res5b	26368	0.00013			
____pool5	54594	0.00027			
fc1000	207351	0.00104			

\* The clock frequency of the DL processor is: 200MHz

## Tips

To obtain the performance estimation for a `dlquantizer` object, set the `dlhdl.ProcessorConfig` object `ProcessorDataType` to `int8`.

## See Also

`estimateResources` | `getModuleProperty` | `optimizeConfigurationForNetwork` | `setModuleProperty`

## Topics

“Estimate Performance of Deep Learning Network”

## Introduced in R2021a

# estimateResources

**Class:** dlhdl.ProcessorConfig

**Package:** dlhdl

Return estimated resources used by custom bitstream configuration

## Syntax

```
estimateResources
resources = estimateResources
estimateResources('Name','Value')
resources = estimateResources('Name','Value')
```

## Description

`estimateResources` returns the estimated resources used by the custom bitstream configuration.

`resources = estimateResources` returns a table containing the estimated resources used by the custom bitstream configuration.

`estimateResources('Name','Value')` returns the estimated resources used by the custom bitstream configuration, with additional options specified by one or more name-value arguments.

`resources = estimateResources('Name','Value')` returns the estimated resources used by the custom bitstream configuration, with additional options specified by one or more name-value arguments.

## Input Arguments

### Name-Value Pair Arguments

Specify optional comma-separated pairs of `Name`,`Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1`,`Value1`, ..., `NameN`,`ValueN`.

#### **IncludeReferenceDesign — Display reference design resource utilization**

false (default) | false | true | logical

Flag to enable the display of reference design resource utilization specified as a logical data type.

Example: '`IncludeReferenceDesign`',`true`

## Output Arguments

### **resources — Custom processor configuration object resource utilization table**

Resources used by the custom bitstream configuration, returned as a table.

## Examples

### Estimate Resources Used by Default Custom Processor Configuration

- 1 Create a default custom processor configuration object. Use the `dlhdl.ProcessorConfig` class.

```
hPC = dlhdl.ProcessorConfig;
```

- 2 To retrieve the resources used by the custom processor configuration, call the `estimateResources` method.

```
hPC.estimateResources;
```

- 3 Calling `estimateResources` returns these results:

```
Deep Learning Processor Estimator Resource Results
      DSPs      Block RAM*      LUTs(CLB/ALUT)
Available      -----      -----
DL_Processor    2520          912        274080
-----      -----
377( 15%)    508( 56%)  234175( 86%)
* Block RAM represents Block RAM tiles in Xilinx devices and Block RAM bits in Intel devices
```

### Estimate Resource Utilization for Custom Board and Reference Design

Rapidly prototype the deployment of deep learning networks to your custom board by using the `estimateResources` function. Estimate the resource utilization of the deep learning processor configuration for your custom board. Optimize the integration of custom IP cores and reference design into your system by using the `estimateResources` function to estimate the resource utilization of your reference design. The synthesis tool that you use must be in the list of tools supported by the `SynthesisTool` property of the `dlhdl.ProcessorConfig` object. For a list of supported tools and device families, see “[SynthesisTool](#)” on page 1-0 and “[SynthesisToolChipFamily](#)” on page 1-0 .

In this example, estimate the resource utilization for your custom board that has the Kintex® Ultrascale+™ chip family. Also estimate the resource utilization of the reference design for the Xilinx® Zynq® Ultrascale+™ MPSOC ZCU102 board.

#### Prerequisites

- Deep Learning HDL Toolbox™
- Deep Learning HDL Toolbox™ Support Package for Xilinx FPGA and SoC
- HDL Coder™

#### Estimate Resource Utilization for Kintex® Ultrascale+™ Board

To estimate the resource utilization for your custom board that has a Kintex® Ultrascale+™ chip family , use the `estimateResource` function of the `dlhdl.ProcessorConfig` object.

- 1 Add the `dlhdl_device_registration.m` file to the MATLAB® search path.
- 2 Create a `dlhdl.ProcessorConfig` object.
- 3 Update the `SynthesisToolChipFamily` and `SynthesisToolDevicename` properties of the `dlhdl.ProcessorConfig` object.

- 4** Use the `estimateResources` function to retrieve the resource utilization for your custom board.

Deep Learning HDL Toolbox™ does not support lookup table (LUT) estimation for custom boards.

```
hPC = dlhdl.ProcessorConfig;
hPC.SynthesisToolChipFamily = 'Kintex Ultrascale+';
hPC.SynthesisToolDeviceName = 'xcku11p-ffva1156-1-e';
hPC.estimateResources
```

Warning: Device family "Kintex Ultrascale+" is not currently supported for LUT Estimation. Suppo

Deep Learning Processor Estimator Resource Results

	DSPs	Block RAM*	LUTs (CLB/ALUT)
Available	2928	600	298560
DL_Processor	377( 13%)	508( 85%)	0( 0%)

\* Block RAM represents Block RAM tiles in Xilinx devices and Block RAM bits in Intel devices

## Estimate Resource Utilization for Custom Reference Design

Estimate the resource utilization for a reference design that you want to integrate into your system that has a Xilinx® Zynq® Ultrascale+™ MPSoC ZCU102 board. Use the `estimateResource` function with the `IncludeReferenceDesign` name-value argument. The `estimateResources` function uses the `ResourcesUsed.LogicElements`, `ResourcesUsed.DSP`, and `ResourcesUsed.RAM` information in the reference design plugin file to perform the resource estimation. To estimate resource utilization for your custom reference design, you must populate your reference design file with values for `ResourcesUsed.LogicElements`, `ResourcesUsed.DSP`, and `ResourcesUsed.RAM`. See “`ResourcesUsed`” on page 1-0 . The reference design used in this code is located at `$supportpackageinstallationfolder/Xilinx/boards/+DLZCU102/+matlab_libiio_3axi4_master_2019_1/plugin_rd.m`.

```
hPC_referencedesign = dlhdl.ProcessorConfig;
hPC_referencedesign.estimateResources('IncludeReferenceDesign',true)
```

Deep Learning Processor Estimator Resource Results

	DSPs	Block RAM*	LUTs (CLB/ALUT)
Available	2520	912	274080
Total	380( 16%)	586( 65%)	269176( 99%)
ReferenceDesign	3( 1%)	78( 9%)	35000( 13%)

\* Block RAM represents Block RAM tiles in Xilinx devices and Block RAM bits in Intel devices

The `estimateResources` function returns the resource utilization for the reference design and for the deep learning processor configuration.

## Supporting Files

### Device Registration File

Use the `dlhdl_device_registration.m` file to register a custom device family. Estimate the resource utilization of the custom device by using the `estimateResources` function.

```
type dlhdl_device_registration.m

function hFPGADeviceFamily = dlhdl_device_registration
% Register a new device family by providing the following details:
% 1. Device Family Name
% 2. Vendor(Intel/Xilinx)
% 3. DSP Width
% 4. RAM Width
% 5. RAM Depth
% 6. SplitDSP Width(Optional) - alternative DSP Width supported by the DSP macro
% 7. SplitRAM Width(Optional) - alternative RAM Width supported by the RAM macro

hFPGADeviceFamily = { ...
    kintex_ultrascale();...
};

end

function hFPGADeviceFamily = kintex_ultrascale()
% Datasheets :
% https://www.xilinx.com/support/documentation/user\_guides/ug579-ultrascale-dsp.pdf
% https://www.xilinx.com/support/documentation/user\_guides/ug573-ultrascale-memory-resources
hFPGADeviceFamily = hdlcoder.FPGADeviceInfo('Name', 'Kintex Ultrascale+');
hFPGADeviceFamily.Vendor = 'Xilinx';
hFPGADeviceFamily.DSPWidth = [27, 18];
hFPGADeviceFamily.RAMWidth = 36;
hFPGADeviceFamily.SplitRAMWidth = 18;
hFPGADeviceFamily.RAMDepth = 1024;
end
```

## See Also

[estimatePerformance](#) | [getModuleProperty](#) | [optimizeConfigurationForNetwork](#) | [setModuleProperty](#)

## Topics

“Estimate Resource Utilization for Custom Processor Configuration”

## Introduced in R2021a

# getModuleProperty

**Class:** dlhdl.ProcessorConfig

**Package:** dlhdl

Use the `getModuleProperty` method to get values of module properties within the `dlhdl.ProcessorConfig` object

## Syntax

```
getModuleProperty(ModuleName,ModulePropertyName)
```

## Description

The `getModuleProperty(ModuleName,ModulePropertyName)` method returns the value of the module property for modules within the `dlhdl.ProcessorConfig` object.

## Input Arguments

### ModuleName — Name of the module whose parameters are to be retrieved

"conv" | "fc" | "adder" | 'conv' | 'fc' | 'adder' | character vector | string

The `dlhdl.ProcessorConfig` object module name, specified as a character vector or string.

### ModulePropertyName — Name of the module property whose value is to be retrieved

character vector or string

'conv', 'fc', or 'adder' module properties specified as character vector.

Example: "ConvThreadNumber" or 'ConvThreadNumber'

This table lists module names and module property names.

Module Name	Module Property Name
conv	"ModuleGeneration" on page 1-0
conv	"LRNBlockGeneration" on page 1-0
conv	"ConvThreadNumber" on page 1-0
conv	"InputMemorySize" on page 1-0
conv	"OutputMemorySize" on page 1-0
conv	"FeatureSizeLimit" on page 1-0
fc	"ModuleGeneration" on page 1-0
fc	"SoftmaxBlockGeneration" on page 1-0
fc	"FCThreadNumber" on page 1-0
fc	"InputMemorySize" on page 1-0
fc	"OutputMemorySize" on page 1-0

adder	"ModuleGeneration" on page 1-0
adder	"InputMemorySize" on page 1-0
adder	"OutputMemorySize" on page 1-0

## Examples

### Retrieve ConvThreadNumber for conv Module Inside dlhdl.ProcessorConfig Object

- 1 Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `getModuleProperty` method to obtain the `ConvThreadNumber`.

```
hPC = dlhdl.ProcessorConfig;
hPC.getModuleProperty("conv", "ConvThreadNumber")
```

- 2 Once you execute the code, the result is:

```
ans =
```

```
16
```

### Retrieve InputMemorySize for fc Module Inside dlhdl.ProcessorConfig Object

- 1 Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `getModuleProperty` method to obtain the `ConvThreadNumber`.

```
hPC = dlhdl.ProcessorConfig;
hPC.getModuleProperty("fc", "InputMemorySize")
```

- 2 Once you execute the code, the result is:

```
ans =
```

```
25088
```

## See Also

`estimatePerformance` | `estimateResources` | `optimizeConfigurationForNetwork` | `setModuleProperty`

## Topics

["Deep Learning Processor Architecture"](#)  
["Estimate Performance of Deep Learning Network"](#)  
["Estimate Resource Utilization for Custom Processor Configuration"](#)

## Introduced in R2020b

# optimizeConfigurationForNetwork

**Class:** dlhdl.ProcessorConfig

**Package:** dlhdl

Retrieve optimized network-specific deep learning processor configuration

## Syntax

```
optimizeConfigurationForNetwork(network)
```

## Description

`optimizeConfigurationForNetwork(network)` returns an optimized deep learning processor configuration for the object specified by the `network` argument.

## Input Arguments

### **network — Network object**

`SeriesNetwork` object | `DAGNetwork` object | `yolov2ObjectDetector` object | `dlquantizer` object

Name of network object for optimized deep learning processor configuration, specified as a `SeriesNetwork`, `DAGNetwork`, `yolov2ObjectDetector`, or `dlquantizer` object.

Example: `optimizeConfigurationForNetwork(snet)`

## Examples

### Generate Optimized Processor Configuration for MobileNetV2 Network

- 1 Create a `dlhdl.ProcessorConfig` object.

```
net = mobilenetv2;
hPC = dlhdl.ProcessorConfig;
```

- 2 To retrieve an optimized processor configuration, call the `optimizeConfigurationForNetwork` method.

```
hPC.optimizeConfigurationForNetwork(net)
```

```
### Optimizing processor configuration for deep learning network begin.
### Optimizing series network: Fused 'nnet.cnn.layer.BatchNormLayer' into 'nnet.cnn.layer.Convolution2DLayer'
### Note: Processing module "conv" property "InputMemorySize" changed from "[227 227 3]" to "[224 224 3]".
### Note: Processing module "conv" property "OutputMemorySize" changed from "[227 227 3]" to "[112 112 32]".
### Note: Processing module "conv" property "FeatureSizeLimit" changed from "2048" to "1280".
### Note: Processing module "conv" property "LRNBlockGeneration" changed from "on" to "off" because there is no LRN layer in the do
### Note: Processing module "fc" property "InputMemorySize" changed from "25088" to "1280".
### Note: Processing module "fc" property "OutputMemorySize" changed from "4096" to "1000".
```

```
Processing Module "conv"
    ModuleGeneration: 'on'
    LRNBlockGeneration: 'off'
    ConvThreadNumber: 16
    InputMemorySize: [224 224 3]
    OutputMemorySize: [112 112 32]
    FeatureSizeLimit: 1280
```

```
Processing Module "fc"
    ModuleGeneration: 'on'
    SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 1280
        OutputMemorySize: 1000

Processing Module "adder"
    ModuleGeneration: 'on'
    InputMemorySize: 40
    OutputMemorySize: 40

Processor Top Level Properties
    RunTimeControl: 'register'
    InputDataInterface: 'External Memory'
    OutputDataInterface: 'External Memory'
    ProcessorDataType: 'single'

System Level Properties
    TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
    TargetFrequency: 200
        SynthesisTool: 'Xilinx Vivado'
        ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
    SynthesisToolChipFamily: 'Zynq UltraScale+'
    SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
    SynthesisToolPackageName: ''
    SynthesisToolSpeedValue: ''

### Optimizing processor configuration for deep learning network complete.
```

## See Also

[estimatePerformance](#) | [estimateResources](#) | [getModuleProperty](#) | [setModuleProperty](#)

## Topics

“Generate Custom Bitstream to Meet Custom Deep Learning Network Requirements”

## Introduced in R2021b

# setModuleProperty

**Class:** dlhdl.ProcessorConfig

**Package:** dlhdl

Use the `setModuleProperty` method to set properties of modules within the `dlhdl.ProcessorConfig` object

## Syntax

```
setModuleProperty(ModuleName, Name, Value)
```

## Description

The `setModuleProperty(ModuleName, Name, Value)` method sets the properties of the module mentioned in `ModuleName` by using the values specified as `Name, Value` pairs.

## Input Arguments

### **ModuleName — Name of the module whose parameters are to be set**

`"conv" | "fc" | "adder" | "conv" | "fc" | "adder" | string | character vector`

The `dlhdl.ProcessorConfig` object module name, specified as a character vector or string.

### **Name-Value Arguments**

Specify optional comma-separated pairs of `Name, Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1, Value1, . . . , NameN, ValueN`.

Example:

#### **conv module parameters**

##### **ModuleGeneration — Enable or disable convolution module generation as a part of the deep learning processor configuration**

`'on' (default) | 'off' | character vector`

Use this parameter to control generation of the convolution module as a part of the deep learning processor configuration.

Example: `'ModuleGeneration', 'on'`

##### **LRNBlockGeneration — Enable or disable local response normalization (LRN) block generation as a part of the convolution module of the deep learning processor configuration**

`'on' (default) | 'off' | character vector`

Use this parameter to control generation of the LRN block as a part of the convolution module of the deep learning processor configuration.

Example: `'LRNBlockGeneration', 'on'`

**ConvThreadNumber — Number of parallel convolution processor kernel threads**

16 (default) | 4 | 9 | 16 | 25 | 36 | 64 | 256 | unsigned integer

This parameter is the number of parallel 3-by-3 convolution kernel threads that are a part of the conv module within the `dlhdl.ProcessorConfig` object.

Example: `'ConvThreadNumber'`, 64

**InputMemorySize — Cache block RAM (BRAM) sizes**

[227 227 3] (default) | 3D positive integer array

This parameter is a 3D matrix representing input image size limited by the conv module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: `'InputMemorySize'`, [227 227 3]

**OutputMemorySize — Cache block RAM (BRAM) sizes**

[227 227 3] (default) | 3D positive integer array

This parameter is a 3D matrix representing output image size limited by the conv module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: `'OutputMemorySize'`, [227 227 3]

**FeatureSizeLimit — Maximum input and output feature size**

512 (default) | positive integer

This parameter is a positive integer representing the maximum input and output feature size as a part of the conv module within the `dlhdl.ProcessorConfig` object.

Example: `'FeatureSizeLimit'`, 512

**fc module parameters****ModuleGeneration — Enable or disable fully connected module generation as a part of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the fully connected module as a part of the deep learning processor configuration.

Example: `'ModuleGeneration'`, 'on'

**SoftmaxBlockGeneration — Enable or disable Softmax block generation as a part of the fully connected module of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the Softmax block as a part of the fully connected module of the deep learning processor configuration. When you set this property to off, the Softmax layer is still implemented in software.

Example: `'SoftmaxBlockGeneration'`, 'on'

**FCThreadNumber — Number of parallel fully connected (fc) MAC threads**

4 (default) | 4 | 8 | 16 | 32 | 64 | unsigned integer

This parameter is the number of parallel fc MAC threads that are a part of the fc module within the `dlhdl.ProcessorConfig` object.

Example: 'FCThreadNumber', 16

#### **InputMemorySize — Cache block RAM (BRAM) sizes**

9216 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the `fc` module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: 'InputMemorySize', 9216

#### **OutputMemorySize — Cache block RAM (BRAM) sizes**

4096 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the `fc` module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: 'OutputMemorySize', 4096

#### **adder module properties**

##### **ModuleGeneration — Enable or disable adder module generation as a part of the deep learning processor configuration**

'on' (default) | 'off' | character vector

Use this parameter to control generation of the adder module as a part of the deep learning processor configuration.

Example: 'ModuleGeneration', 'on'

#### **InputMemorySize — Cache block RAM (BRAM) sizes**

40 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the adder module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: 'InputMemorySize', 40

#### **OutputMemorySize — Cache block RAM (BRAM) sizes**

40 (default) | unsigned integer

This parameter is an unsigned integer representing cache BRAM size limited by the adder module BRAM size within the `dlhdl.ProcessorConfig` object.

Example: 'OutputMemorySize', 40

## **Examples**

### **Set Value for ConvThreadNumber Within `dlhdl.ProcessorConfig` Object**

- 1 Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `setModuleProperty` method to set the value for `convThreadNumber`.

```
hPC = dlhdl.ProcessorConfig;
hPC.setModuleProperty("conv", "ConvThreadNumber", 25)
hPC
```

- 2 Once you execute the code, the result is:

```
hPC =  
  
    Processing Module "conv"  
        ModuleGeneration: 'on'  
        LRNBlockGeneration: 'on'  
    SegmentationBlockGeneration: 'on'  
        ConvThreadNumber: 25  
        InputMemorySize: [227 227 3]  
        OutputMemorySize: [227 227 3]  
        FeatureSizeLimit: 2048  
  
    Processing Module "fc"  
        ModuleGeneration: 'on'  
        SoftmaxBlockGeneration: 'off'  
        FCThreadNumber: 4  
        InputMemorySize: 25088  
        OutputMemorySize: 4096  
  
    Processing Module "adder"  
        ModuleGeneration: 'on'  
        InputMemorySize: 40  
        OutputMemorySize: 40  
  
Processor Top Level Properties  
    RunTimeControl: 'register'  
    InputDataInterface: 'External Memory'  
    OutputDataInterface: 'External Memory'  
    ProcessorDataType: 'single'  
  
System Level Properties  
    TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'  
    TargetFrequency: 200  
    SynthesisTool: 'Xilinx Vivado'  
    ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'  
    SynthesisToolChipFamily: 'Zynq UltraScale+'  
    SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'  
    SynthesisToolPackageName: ''  
    SynthesisToolSpeedValue: ''
```

## Set Value for InputMemorySize Within dlhdl.ProcessorConfig Object

- 1 Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `setModuleProperty` method to set the value for `InputMemorySize`.

```
hPC = dlhdl.ProcessorConfig;  
hPC.setModuleProperty("fc", "InputMemorySize", 25060)  
hPC
```

- 2 Once you execute the code, the result is:

```
hPC =  
  
    Processing Module "conv"  
        ModuleGeneration: 'on'  
        LRNBlockGeneration: 'on'  
    SegmentationBlockGeneration: 'on'  
        ConvThreadNumber: 16  
        InputMemorySize: [227 227 3]  
        OutputMemorySize: [227 227 3]  
        FeatureSizeLimit: 2048  
  
    Processing Module "fc"  
        ModuleGeneration: 'on'  
        SoftmaxBlockGeneration: 'off'  
        FCThreadNumber: 4  
        InputMemorySize: 25060  
        OutputMemorySize: 4096  
  
    Processing Module "adder"  
        ModuleGeneration: 'on'  
        InputMemorySize: 40  
        OutputMemorySize: 40  
  
Processor Top Level Properties  
    RunTimeControl: 'register'
```

```

    InputDataInterface: 'External Memory'
    OutputDataInterface: 'External Memory'
    ProcessorDataType: 'single'

    System Level Properties
        TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
        TargetFrequency: 200
        SynthesisTool: 'Xilinx Vivado'
        ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
        SynthesisToolChipFamily: 'Zynq UltraScale+'
        SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
        SynthesisToolPackageName: ''
        SynthesisToolSpeedValue: ''

```

## Set Value for InputMemorySize Within dlhdl.ProcessorConfig Object

- Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `setModuleProperty` method to set the value for `InputMemorySize`.

```

hPC = dlhdl.ProcessorConfig;
hPC.setModuleProperty("adder", "InputMemorySize", 80)
hPC

```

- Once you execute the code, the result is:

```

hPC =

    Processing Module "conv"
        ModuleGeneration: 'on'
        LRNBlockGeneration: 'on'
        SegmentationBlockGeneration: 'on'
        ConvThreadNumber: 16
        InputMemorySize: [227 227 3]
        OutputMemorySize: [227 227 3]
        FeatureSizeLimit: 2048

    Processing Module "fc"
        ModuleGeneration: 'on'
        SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 25088
        OutputMemorySize: 4096

    Processing Module "adder"
        ModuleGeneration: 'on'
        InputMemorySize: 80
        OutputMemorySize: 40

    Processor Top Level Properties
        RunTimeControl: 'register'
        InputDataInterface: 'External Memory'
        OutputDataInterface: 'External Memory'
        ProcessorDataType: 'single'

    System Level Properties
        TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
        TargetFrequency: 200
        SynthesisTool: 'Xilinx Vivado'
        ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
        SynthesisToolChipFamily: 'Zynq UltraScale+'
        SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
        SynthesisToolPackageName: ''
        SynthesisToolSpeedValue: ''

```

## Turn off conv module Within dlhdl.ProcessorConfig Object

- Create an example object by using the `dlhdl.ProcessorConfig` class, and then use the `setModuleProperty` method to set the value for `ModuleGeneration`.

```
hPC = dlhdl.ProcessorConfig;
hPC.setModuleProperty("conv", "ModuleGeneration", "off")
hPC
```

- 2** Once you execute the code, the result is:

```
hPC =
    Processing Module "conv"
        ModuleGeneration: 'off'
    Processing Module "fc"
        ModuleGeneration: 'on'
        SoftmaxBlockGeneration: 'off'
        FCThreadNumber: 4
        InputMemorySize: 25088
        OutputMemorySize: 4096
    Processing Module "adder"
        ModuleGeneration: 'on'
        InputMemorySize: 40
        OutputMemorySize: 40
Processor Top Level Properties
    RunTimeControl: 'register'
    InputDataInterface: 'External Memory'
    OutputDataInterface: 'External Memory'
    ProcessorDataType: 'single'
System Level Properties
    TargetPlatform: 'Xilinx Zynq UltraScale+ MPSoC ZCU102 Evaluation Kit'
    TargetFrequency: 200
    SynthesisTool: 'Xilinx Vivado'
    ReferenceDesign: 'AXI-Stream DDR Memory Access : 3-AXIM'
    SynthesisToolChipFamily: 'Zynq UltraScale+'
    SynthesisToolDeviceName: 'xczu9eg-ffvb1156-2-e'
    SynthesisToolPackageName: ''
    SynthesisToolSpeedValue: ''
```

## See Also

[estimatePerformance](#) | [estimateResources](#) | [getModuleProperty](#) |  
[optimizeConfigurationForNetwork](#)

## Topics

[“Deep Learning Processor Architecture”](#)  
[“Estimate Performance of Deep Learning Network”](#)  
[“Estimate Resource Utilization for Custom Processor Configuration”](#)

## Introduced in R2020b

# dlhdl.buildProcessor

Build and generate custom processor IP

## Syntax

```
dlhdl.buildProcessor
dlhdl.buildProcessor(processorconfigobject)
dlhdl.buildProcessor(processorconfigobject,Name,Value)
```

## Description

`dlhdl.buildProcessor` generates a bitstream for the default `dlhdl.ProcessorConfig` object.

`dlhdl.buildProcessor(processorconfigobject)` generates a bitstream for the `processorconfigobject` object.

`dlhdl.buildProcessor(processorconfigobject,Name,Value)` generates a bitstream for the `processorconfigobject` object, with additional options specified by one or more `Name,Value` arguments.

## Examples

### Generate Custom Bitstream for Custom Processor Configuration

Create a custom processor configuration. Generate a bitstream for the custom processor configuration.

Create a `dlhdl.ProcessorConfig` object. Save the object in `hPC`.

```
hPC = dlhdl.ProcessorConfig
```

Generate a custom bitstream for `hPC`

```
dlhdl.buildProcessor(hPC)
```

### Generate Custom Bitstream and Specify Project Folder Name, Deep Learning Processor IP Core Name, and Target Code Generation language

Create a custom deep learning processor configuration. When you generate code specify the project folder name, deep learning processor IP core name, and target code generation language.

```
hPC = dlhdl.ProcessorConfig;
dlhdl.buildProcessor(hPC,'ProjectFolder','fconlyprocessor_prj',...
'ProcessorName','fconlyprocessor','HDLCoderConfig',{'TargetLanguage','Verilog'});
```

## Input Arguments

**processorconfigobject — Name of the object generated by using `dlhdl.buildProcessor`**  
 (default) | variable

Name of the custom processor configuration object, specified as a variable of type `dlhdl.ProcessorConfig`.

Example: `dlhdl.buildProcessor(hPC)`

### **Name-Value Pair Arguments**

Specify optional comma-separated pairs of `Name`,`Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1`,`Value1`, ..., `NameN`,`ValueN`.

Example:

#### **ProjectFolder — Project folder name**

`'dlhdl_prj'` (default)

Name of project folder where generated files are saved

Example: `'ProjectFolder'`, `'fconlyprocessor_prj'`

#### **ProcessorName — Name of generated deep learning processor IP core**

`"` (default) | character vector or string

Name of generated deep learning processor IP core

Example: `'ProcessorName'`, `'fconlyprocessor'`

#### **TargetLanguage — Target language**

`'VHDL'` (default) | `'Verilog'` | character vector or string

Specify whether to generate VHDL or Verilog code.

Example: `'HDLCoderConfig'`,`{'TargetLanguage','Verilog'}`

## **See Also**

`dlhdl.ProcessorConfig`

## **Topics**

[“Deep Learning Processor IP Core”](#)

[“Generate Custom Bitstream”](#)

[“Generate Custom Processor IP”](#)

## **Introduced in R2020b**

# hdlsetuptoolspath

Set up system environment to access FPGA synthesis software

## Syntax

```
hdlsetuptoolspath('ToolName',TOOLNAME,'ToolPath',TOOLPATH)
```

## Description

`hdlsetuptoolspath('ToolName',TOOLNAME,'ToolPath',TOOLPATH)` adds a third-party FPGA synthesis tool to your system path. It sets up the system environment variables for the synthesis tool. To configure one or more supported third-party FPGA synthesis tools to use with HDL Coder™, use the `hdlsetuptoolspath` function.

Before opening the HDL Workflow Advisor, add the tool to your system path. If you already have the HDL Workflow Advisor open, see “Add Synthesis Tool for Current HDL Workflow Advisor Session” (HDL Coder).

## Examples

### Set Up Intel Quartus Prime

The following command sets the synthesis tool path to point to an installed Intel Quartus® Prime Standard Edition 18.1 executable file. You must have already installed Altera® Quartus II.

```
hdlsetuptoolspath('ToolName','Altera Quartus II','ToolPath',...
'C:\intel\18.1\quartus\bin\quartus.exe');
```

### Set Up Intel Quartus Pro

The following command sets the synthesis tool path to point to an installed Intel Quartus Pro 19.2 executable file. You must have already installed Intel Quartus Pro.

```
hdlsetuptoolspath('ToolName','Intel Quartus Pro','ToolPath',...
'C:\intel\19.2_pro\quartus\bin64\qpro.exe');
```

---

**Note** An installation of Quartus Pro contains both `quartus.exe` and `qpro.exe` executable files. When both tools are added to the path by using `hdlsetuptoolspath`, HDL Coder checks the tool availability before running the HDL Workflow Advisor.

---

### Set Up Xilinx ISE

The following command sets the synthesis tool path to point to an installed Xilinx ISE 14.7 executable file. You must have already installed Xilinx ISE.

```
hdlsetuptoolspath('ToolName','Xilinx ISE','ToolPath',...
'C:\Xilinx\14.7\ISE_DS\ISE\bin\nt64\ise.exe');
```

## Set Up Xilinx Vivado

The following command sets the synthesis tool path to point to an installed Vivado® Design Suite 2019.1 batch file. You must have already installed Xilinx Vivado.

```
hdlsetuptoolpath('ToolName','Xilinx Vivado','ToolPath',...
    'C:\Xilinx\Vivado\2019.1\bin\vivado.bat');
```

## Set Up Microsemi Libero SoC

The following command sets the synthesis tool path to point to an installed Microsemi® Libero® Design Suite batch file. You must have already installed Microsemi Libero SoC.

```
hdlsetuptoolpath('ToolName','Microsemi Libero SoC','ToolPath',...
    'C:\Microsemi\Libero_SoC_v11.8\Designer\bin\libero.exe');
```

## Input Arguments

### TOOLNAME — Synthesis tool name

character vector

Synthesis tool name, specified as a character vector.

Example: 'Xilinx Vivado'

### TOOLPATH — Full path to the synthesis tool executable or batch file

character vector

Full path to the synthesis tool executable or batch file, specified as a character vector.

Example: 'C:\Xilinx\Vivado\2018.3\bin\vivado.bat'

## Tips

- If you have an icon for the tool on your Windows® desktop, you can find the full path to the synthesis tool.
  - 1 Right-click the icon and select **Properties**.
  - 2 Click the **Shortcut** tab.
- The `hdlsetuptoolpath` function changes the system path and system environment variables for only the current MATLAB® session. To execute `hdlsetuptoolpath` programmatically when MATLAB starts, add `hdlsetuptoolpath` to your `startup.m` script.

## See Also

`startup` | `setenv`

### Topics

“HDL Language Support and Supported Third-Party Tools and Hardware” (HDL Coder)

“Tool Setup” (HDL Coder)

“Add Synthesis Tool for Current HDL Workflow Advisor Session” (HDL Coder)

## Introduced in R2011a

# dlquantizer

Quantize a deep neural network to 8-bit scaled integer data types

## Description

Use the `dlquantizer` object to reduce the memory requirement of a deep neural network by quantizing weights, biases, and activations to 8-bit scaled integer data types.

## Creation

### Syntax

```
quantObj = dlquantizer(net)
quantObj = dlquantizer(net,Name,Value)
```

### Description

`quantObj = dlquantizer(net)` creates a `dlquantizer` object for the specified network.

`quantObj = dlquantizer(net,Name,Value)` creates a `dlquantizer` object for the specified network, with additional options specified by one or more name-value pair arguments.

Use `dlquantizer` to create an quantized network for GPU, FPGA, or CPU deployment. To learn about the products required to quantize and deploy the deep learning network to a GPU, FPGA, or CPU environment, see “Quantization Workflow Prerequisites”.

### Input Arguments

#### `net` — Pretrained neural network

DAGNetwork object | SeriesNetwork object | `yolov2ObjectDetector` object | `ssdObjectDetector` object

Pretrained neural network, specified as a `DAGNetwork`, `SeriesNetwork`, `yolov2ObjectDetector`, or a `ssdObjectDetector` object.

Quantization of `yolov2ObjectDetector` and `ssdObjectDetector` networks requires a GPU Coder™ license.

## Properties

#### `NetworkObject` — Pretrained neural network

DAGNetwork object | SeriesNetwork object | `yolov2ObjectDetector` object | `ssdObjectDetector` object

Pre-trained neural network, specified as a `DAGNetwork`, `SeriesNetwork`, `yolov2ObjectDetector`, or a `ssdObjectDetector` object.

**ExecutionEnvironment — Execution environment**

'GPU' (default) | 'FPGA' | 'CPU'

Specify the execution environment for the quantized network. When this parameter is not specified the default execution environment is GPU. To learn about the products required to quantize and deploy the deep learning network to a GPU, FPGA, or CPU environment, see “Quantization Workflow Prerequisites”.

Example: 'ExecutionEnvironment','FPGA'

**Simulation — Enable or disable MATLAB simulation workflow**

'off' (default) | 'on'

Enable or disable the MATLAB simulation workflow. When this parameter is set to on, the quantized network is validated by simulating the quantized network in MATLAB and comparing the single data type network prediction results to the simulated network prediction results.

Example: 'Simulation', 'on'

## Object Functions

calibrate Simulate and collect ranges of a deep neural network

validate Quantize and validate a deep neural network

## Examples

### Quantize a Neural Network for GPU Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network for GPU and explore the behavior of the quantized network. In this example, you quantize the squeezenet neural network after retraining the network to classify new images according to the Train Deep Learning Network to Classify New Images example. In this example, the memory required for the network is reduced approximately 75% through quantization while the accuracy of the network is not affected.

Load the pretrained network. `net` is the output network of the Train Deep Learning Network to Classify New Images example.

```
load net
net

net =
  DAGNetwork with properties:

    Layers: [68x1 nnet.cnn.layer.Layer]
    Connections: [75x2 table]
    InputNames: {'data'}
    OutputNames: {'new_classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all

layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

In this example, use the images in the `MerchData` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[calData, valData] = splitEachLabel(imds, 0.7, 'randomized');
aug_calData = augmentedImageDatastore([227 227], calData);
aug_valData = augmentedImageDatastore([227 227], valData);
```

Create a `dlquantizer` object and specify the network to quantize.

```
quantObj = dlquantizer(net);
```

Define a metric function to use to compare the behavior of the network before and after quantization. This example uses the `hComputeModelAccuracy` metric function.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
    %% Computes model-level accuracy statistics

    % Load ground truth
    tmp = readall(dataStore);
    groundTruth = tmp.response;

    % Compare with predicted label with actual ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx,:));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.
    predictionError = [predictionError{:}];
    accuracy = sum(predictionError)/numel(predictionError);
end
```

Specify the metric function in a `dlquantizationOptions` object.

```
quantOpts = dlquantizationOptions('MetricFcn', {@(x)hComputeModelAccuracy(x, net, aug_valData)});
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
calResults = calibrate(quantObj, aug_calData)
```

```
calResults=95x5 table
```

Optimized Layer Name	Network Layer Name	Learnables

---

{'conv1_relu_conv1_Weights'}	}	{'relu_conv1'}	}
{'conv1_relu_conv1_Bias'}	}	{'relu_conv1'}	}
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Weights'}	}	{'fire2-relu_squeeze1x1'}	"We
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Bias'}	}	{'fire2-relu_squeeze1x1'}	"B
{'fire2-expand1x1_fire2-relu_expand1x1_Weights'}	}	{'fire2-relu_expand1x1'}	"We
{'fire2-expand1x1_fire2-relu_expand1x1_Bias'}	}	{'fire2-relu_expand1x1'}	"B
{'fire2-expand3x3_fire2-relu_expand3x3_Weights'}	}	{'fire2-relu_expand3x3'}	"We
{'fire2-expand3x3_fire2-relu_expand3x3_Bias'}	}	{'fire2-relu_expand3x3'}	"B
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Weights'}	}	{'fire3-relu_squeeze1x1'}	"We
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Bias'}	}	{'fire3-relu_squeeze1x1'}	"B
{'fire3-expand1x1_fire3-relu_expand1x1_Weights'}	}	{'fire3-relu_expand1x1'}	"We
{'fire3-expand1x1_fire3-relu_expand1x1_Bias'}	}	{'fire3-relu_expand1x1'}	"B
{'fire3-expand3x3_fire3-relu_expand3x3_Weights'}	}	{'fire3-relu_expand3x3'}	"We
{'fire3-expand3x3_fire3-relu_expand3x3_Bias'}	}	{'fire3-relu_expand3x3'}	"B
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Weights'}	}	{'fire4-relu_squeeze1x1'}	"We
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Bias'}	}	{'fire4-relu_squeeze1x1'}	"B
:			

Use the **validate** function to quantize the learnable parameters in the convolution layers of the network and exercise the network. The function uses the metric function defined in the **dlquantizationOptions** object to compare the results of the network before and after quantization.

```
valResults = validate(quantObj, aug_valData, quantOpts)

valResults = struct with fields:
    NumSamples: 20
    MetricResults: [1×1 struct]
    Statistics: [2×2 table]
```

Examine the validation output to see the performance of the quantized network.

```
valResults.MetricResults.Result

ans=2×2 table
    NetworkImplementation      MetricOutput
    _____
    {'Floating-Point'}          1
    {'Quantized' }               1

valResults.Statistics

ans=2×2 table
    NetworkImplementation      LearnableParameterMemory(bytes)
    _____
    {'Floating-Point'}          2.9003e+06
    {'Quantized' }               7.3393e+05
```

In this example, the memory required for the network was reduced approximately 75% through quantization. The accuracy of the network is not affected.

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## Quantize a Neural Network for FPGA Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network, and explore the behavior of the quantized network. In this example, you quantize the `LogoNet` neural network. Quantization helps reduce the memory requirement of a deep neural network by quantizing weights, biases and activations of network layers to 8-bit scaled integer data types. Use MATLAB® to retrieve the prediction results from the target device.

To run this example, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

For additional requirements, see “Quantization Workflow Prerequisites”.

Create a file in your current working directory called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork()
    data = getLogoData();
    net = data.convnet;
end

function data = getLogoData()
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

Load the pretrained network.

```
snet = getLogoNetwork();

snet =
SeriesNetwork with properties:

    Layers: [22×1 nnet.cnn.layer.Layer]
    InputNames: {'imageinput'}
    OutputNames: {'classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

This example uses the images in the `logos_dataset` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```

curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir);
unzip('logos_dataset.zip');
imageData = imageDatastore(fullfile(curDir,'logos_dataset'),...
    'IncludeSubfolders',true,'FileExtensions','.JPG','LabelSource','foldernames');
[calibrationData, validationData] = splitEachLabel(imageData, 0.5,'randomized');

```

Create a `dlquantizer` object and specify the network to quantize.

```
dlQuantObj = dlquantizer(snet,'ExecutionEnvironment','FPGA');
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
dlQuantObj.calibrate(calibrationData)
```

ans =	Optimized Layer Name	Network Layer Name	Learnables / Activations	MinValue	MaxValue
	{'conv_1_Weights'}	{'conv_1'}	"Weights"	-0.048978	0.039352
	{'conv_1_Bias'}	{'conv_1'}	"Bias"	0.99996	1.0028
	{'conv_2_Weights'}	{'conv_2'}	"Weights"	-0.055518	0.061901
	{'conv_2_Bias'}	{'conv_2'}	"Bias"	-0.00061171	0.00227
	{'conv_3_Weights'}	{'conv_3'}	"Weights"	-0.045942	0.046927
	{'conv_3_Bias'}	{'conv_3'}	"Bias"	-0.0013998	0.0015218
	{'conv_4_Weights'}	{'conv_4'}	"Weights"	-0.045967	0.051
	{'conv_4_Bias'}	{'conv_4'}	"Bias"	-0.00164	0.0037892
	{'fc_1_Weights'}	{'fc_1'}	"Weights"	-0.051394	0.054344
	{'fc_1_Bias'}	{'fc_1'}	"Bias"	-0.00052319	0.00084454
	{'fc_2_Weights'}	{'fc_2'}	"Weights"	-0.05016	0.051557
	{'fc_2_Bias'}	{'fc_2'}	"Bias"	-0.0017564	0.0018502
	{'fc_3_Weights'}	{'fc_3'}	"Weights"	-0.050706	0.04678
	{'fc_3_Bias'}	{'fc_3'}	"Bias"	-0.02951	0.024855
	{'imageinput'}	{'imageinput'}	"Activations"	0	255
	{'imageinput_normalization'}	{'imageinput'}	"Activations"	-139.34	198.72

Create a target object with a custom name for your target device and an interface to connect your target device to the host computer. Interface options are JTAG and Ethernet. To create the target object, enter:

```
hTarget = dlhdl.Target('Intel','Interface','JTAG');
```

Define a metric function to use to compare the behavior of the network before and after quantization. Save this function in a local file.

```

function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
    %% hComputeModelAccuracy test helper function computes model level accuracy statistics

    % Copyright 2020 The MathWorks, Inc.

    % Load ground truth
    groundTruth = dataStore.Labels;

    % Compare predicted label with ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx, :));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.
    predictionError = [predictionError{:}];
    accuracy = sum(predictionError)/numel(predictionError);
end

```

Specify the metric function in a `dlquantizationOptions` object.

```
options = dlquantizationOptions('MetricFcn', ...
    {@(x)hComputeModelAccuracy(x, snet, validationData)}, 'Bitstream', 'arrial0soc_int8',...
    'Target', hTarget);
```

To compile and deploy the quantized network, run the `validate` function of the `dlquantizer` object. Use the `validate` function to quantize the learnable parameters in the convolution layers of the network and exercise the network. This function uses the output of the `compile` function to program the FPGA board by using the programming file. It also downloads the network weights and biases. The `deploy` function checks for the Intel Quartus tool and the supported tool version. It then starts programming the FPGA device by using the `.sof` file, displays progress messages, and the time it takes to deploy the network. The function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the network before and after quantization.

```
prediction = dlQuantObj.validate(validationData, options);
```

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```
### Programming FPGA Bitstream using JTAG...
### Programming the FPGA bitstream has been completed successfully.
### Loading weights to Conv Processor.
### Conv Weights loaded. Current time is 16-Jul-2020 12:45:10
### Loading weights to FC Processor.
### FC Weights loaded. Current time is 16-Jul-2020 12:45:26
### Finished writing input activations.
### Running single input activations.
```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570959	0.09047	30	380609145	11.8
conv_module	12667786	0.08445			
conv_1	3938907	0.02626			
maxpool_1	1544560	0.01030			
conv_2	2910954	0.01941			
maxpool_2	577524	0.00385			
conv_3	2552707	0.01702			
maxpool_3	676542	0.00451			
conv_4	455434	0.00304			
maxpool_4	11251	0.00008			
fc_module	903173	0.00602			
fc_1	536164	0.00357			
fc_2	342643	0.00228			
fc_3	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```
### Finished writing input activations.
### Running single input activations.
```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570364	0.09047	30	380612682	11.8
conv_module	12667103	0.08445			
conv_1	3939296	0.02626			

maxpool_1	1544371	0.01030
conv_2	2910747	0.01940
maxpool_2	577654	0.00385
conv_3	2551829	0.01701
maxpool_3	676548	0.00451
conv_4	455396	0.00304
maxpool_4	11355	0.00008
fc_module	903261	0.00602
fc_1	536206	0.00357
fc_2	342688	0.00228
fc_3	24365	0.00016

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13571561	0.09048	30	380608338	11.8
conv_1	12668340	0.08446			
maxpool_1	3939070	0.02626			
conv_2	2911061	0.01941			
maxpool_2	577557	0.00385			
conv_3	2552082	0.01701			
maxpool_3	676506	0.00451			
conv_4	455582	0.00304			
maxpool_4	11248	0.00007			
fc_module	903221	0.00602			
fc_1	536167	0.00357			
fc_2	342643	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13569862	0.09047	30	380613327	11.8
conv_1	12666756	0.08445			
maxpool_1	3939212	0.02626			
conv_2	2911184	0.01941			
maxpool_2	577275	0.00385			
conv_3	2552868	0.01702			
maxpool_3	676438	0.00451			
conv_4	455353	0.00304			
maxpool_4	11252	0.00008			
fc_module	903106	0.00602			
fc_1	536050	0.00357			
fc_2	342645	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s

Network	13570823	0.09047	30	380619836	11.8
conv_module	12667607	0.08445			
Conv_1	3939074	0.02626			
maxpool_1	1544519	0.01030			
conv_2	2910636	0.01940			
maxpool_2	577769	0.00385			
conv_3	2551800	0.01701			
maxpool_3	676795	0.00451			
conv_4	455859	0.00304			
maxpool_4	11248	0.00007			
fc_module	903216	0.00602			
fc_1	536165	0.00357			
fc_2	342643	0.00228			
fc_3	24406	0.00016			

\* The clock frequency of the DL processor is: 150MHz

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```
### FPGA bitstream programming has been skipped as the same bitstream is already loaded on the target FPGA.
### Deep learning network programming has been skipped as the same network is already loaded on the target FPGA.
### Finished writing input activations.
### Running single input activations.
```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13572329	0.09048	10	127265075	11.8
Conv_1	12669135	0.08446			
maxpool_1	3939559	0.02626			
conv_2	1545378	0.01030			
maxpool_2	2911243	0.01941			
conv_3	577422	0.00385			
maxpool_3	2552064	0.01701			
conv_4	676678	0.00451			
maxpool_4	455657	0.00304			
fc_module	11227	0.00007			
fc_1	903194	0.00602			
fc_2	536140	0.00357			
fc_3	342688	0.00228			

\* The clock frequency of the DL processor is: 150MHz

```
### Finished writing input activations.
### Running single input activations.
```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13572527	0.09048	10	127266427	11.8
Conv_1	12669266	0.08446			
maxpool_1	3939776	0.02627			
conv_2	1545632	0.01030			
maxpool_2	2911169	0.01941			
conv_3	577592	0.00385			
maxpool_3	2551613	0.01701			
conv_4	676811	0.00451			

```
maxpool_4           11348          0.00008
fc_module           903261         0.00602
    fc_1             536205         0.00357
    fc_2             342689         0.00228
    fc_3             24365          0.00016
* The clock frequency of the DL processor is: 150MHz
```

Examine the `MetricResults.Result` field of the validation output to see the performance of the quantized network.

```
validateOut = prediction.MetricResults.Result
ans =
NetworkImplementation      MetricOutput
_____
{'Floating-Point'}        0.9875
{'Quantized' }            0.9875
```

Examine the `QuantizedNetworkFPS` field of the validation output to see the frames per second performance of the quantized network.

```
prediction.QuantizedNetworkFPS
ans = 11.8126
```

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.


### Import a `dlquantizer` Object into the Deep Network Quantizer App

This example shows you how to import a `dlquantizer` object from the base workspace into the **Deep Network Quantizer** app. This allows you to begin quantization of a deep neural network using the command line or the app, and resume your work later in the app.


Open the **Deep Network Quantizer** app.

```
deepNetworkQuantizer
```

In the app, click **New** and select **Import dlquantizer object**.




In the dialog, select the `dlquantizer` object to import from the base workspace. For this example, use `quantObj` that you create in the above example Quantize a Neural Network for GPU Target.



The app imports any data contained in the `dlquantizer` object that was collected at the command line. This data can include the network to quantize, calibration data, validation data, and calibration statistics.

The app displays a table containing the calibration data contained in the imported `dlquantizer` object, `quantObj`. To the right of the table, the app displays histograms of the dynamic ranges of the parameters. The gray regions of the histograms indicate data that cannot be represented by the quantized representation. For more information on how to interpret these histograms, see “Quantization of Deep Neural Networks”.



## Quantize a Network for FPGA Deployment

To explore the behavior of a neural network that has quantized convolution layers, use the **Deep Network Quantizer** app. This example quantizes the learnable parameters of the convolution layers of the LogoNet neural network.

For this example, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

For additional requirements, see “Quantization Workflow Prerequisites”.

Create a file in your current working folder called `getLogoNetwork.m`. In the file, enter:

```
function net = getLogoNetwork
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
    net = data.convnet;
end
```

Load the pretrained network.

```
snet = getLogoNetwork;
snet =
    SeriesNetwork with properties:
        Layers: [22×1 nnet.cnn.layer.Layer]
        InputNames: {'imageinput'}
        OutputNames: {'classoutput'}
```

Define calibration and validation data to use for quantization.

The app uses calibration data to exercise the network and collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network. The app also exercises the dynamic ranges of the activations in all layers of the LogoNet network. For the best quantization results, the calibration data must be representative of inputs to the LogoNet network.

After quantization, the app uses the validation data set to test the network to understand the effects of the limited range and precision of the quantized learnable parameters of the convolution layers in the network.

In this example, use the images in the `logos_dataset` data set to calibrate and validate the LogoNet network. Define an `augmentedImagedatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

Expedite the calibration and validation process by using a subset of the `calibrationData` and `validationData`. Store the new reduced calibration data set in `calibrationData_concise` and the new reduced validation data set in `validationData_concise`.

```
curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir);
unzip('logos_dataset.zip');
imageData = imagedatstore(fullfile(curDir,'logos_dataset'),...
    'IncludeSubfolders',true,'FileExtensions','.JPG','LabelSource','foldernames');
[calibrationData, validationData] = splitEachLabel(imageData, 0.5,'randomized');
calibrationData_concise = calibrationData.subset(1:20);
validationData_concise = validationData.subset(1:1);
```


At the MATLAB command prompt, open the Deep Network Quantizer app.

```
deepNetworkQuantizer
```

Click **New** and select **Quantize a network**.

The app verifies your execution environment.

Select the execution environment and the network to quantize from the base workspace. For this example, select a FPGA execution environment and the series network snet.




The app displays the layer graph of the selected network.

In the **Calibrate** section of the app toolbar, under **Calibration Data**, select the `augmentedImagedatastore` object from the base workspace containing the calibration data `calibrationData_concise`.

Click **Calibrate**.

The **Deep Network Quantizer** app uses the calibration data to exercise the network and collect range information for the learnable parameters in the network layers.

When the calibration is complete, the app displays a table containing the weights and biases in the convolution and fully connected layers of the network. Also displayed are the dynamic ranges of the activations in all layers of the network and their minimum and maximum values during the calibration. The app displays histograms of the dynamic ranges of the parameters. The gray regions of the histograms indicate data that cannot be represented by the quantized representation. For more information on how to interpret these histograms, see “Quantization of Deep Neural Networks”.



In the **Quantize** column of the table, indicate whether to quantize the learnable parameters in the layer. You cannot quantize layers that are not convolution layers. Layers that are not quantized remain in single-precision.

In the **Validate** section of the app toolbar, under **Validation Data**, select the `augmentedImageDatastore` object from the base workspace containing the validation data `validationData_concise`.

In the **Hardware Settings** section of the toolbar, select from the options listed in the table:

Simulation Environment	Action
MATLAB (Simulate in MATLAB)	Simulates the quantized network in MATLAB. Validates the quantized network by comparing performance to single-precision version of the network.
Intel Arria 10 SoC (arria10soc_int8)	Deploys the quantized network to an Intel Arria 10 SoC board by using the <code>arria10soc_int8</code> bitstream. Validates the quantized network by comparing performance to single-precision version of the network.
Xilinx ZCU102 (zcu102_int8)	Deploys the quantized network to a Xilinx Zynq UltraScale+ MPSoC ZCU102 10 SoC board by using the <code>zcu102_int8</code> bitstream. Validates the quantized network by comparing performance to single-precision version of the network.

Xilinx ZC706 (zc706_int8)	Deploys the quantized network to a Xilinx Zynq-7000 ZC706 board by using the zc706_int8 bitstream. Validates the quantized network by comparing performance to single-precision version of the network.
---------------------------	---

When you select the Intel Arria 10 SoC (arria10soc\_int8), Xilinx ZCU102 (zcu102\_int8), or Xilinx ZC706 (zc706\_int8) options, select the interface to use to deploy and validate the quantized network. The **Target** interface options are listed in this table.

Target Option	Action
JTAG	Programs the target FPGA board selected in <b>Simulation Environment</b> by using a JTAG cable. For more information, see “JTAG Connection”
Ethernet	Programs the target FPGA board selected in <b>Simulation Environment</b> through the Ethernet interface. Specify the IP address for your target board in <b>IP Address</b> .

For this example, select Xilinx ZCU102 (zcu102\_int8), select **Ethernet**, and enter the board IP address.



In the **Validate** section of the app toolbar, under **Quantization Options**, select the **Default** metric function.


Click **Quantize and Validate**.

The **Deep Network Quantizer** app quantizes the weights, activations, and biases of convolution layers in the network to scaled 8-bit integer data types and uses the validation data to exercise the network. The app determines a metric function to use for the validation based on the type of network that is being quantized.

Type of Network	Metric Function
Classification	<b>Top-1 Accuracy</b> - Accuracy of the network
Object Detection	<b>Average Precision</b> - Average precision over all detection results. See <a href="#">evaluateDetectionPrecision</a> .
Regression	<b>MSE</b> - Mean squared error of the network
Semantic Segmentation	<a href="#">evaluateSemanticSegmentation</a> - Evaluate semantic segmentation data set against ground truth
Single Shot Detector (SSD)	<b>WeightedIOU</b> - Average IoU of each class, weighted by the number of pixels in that class

When the validation is complete, the app displays the results of the validation, including:

- Metric function used for validation
- Result of the metric function before and after quantization



Metric	Floating-Point Network Results	Quantized Network Results	Percent Change
FramesPerSecond	5.5102	19.1158	246.9166
Number of Threads (Convolution)	16.0000	64.0000	300.0000
Number of Threads (Fully Connected)	4.0000	16.0000	300.0000
LUT Utilization (%)	93.5610	79.2440	15.3023
BlockRAM Utilization (%)	63.7061	49.6711	22.0310
DSP Utilization (%)	14.7222	30.5952	107.8167
Top-1 Accuracy	1.0000	1.0000	0.0000

If you want to use a different metric function for validation, for example to use the Top-5 accuracy metric function instead of the default Top-1 accuracy metric function, you can define a custom metric function. Save this function in a local file.

```
function accuracy = hComputeAccuracy(predictionScores, net, dataStore)
% Computes model-level accuracy statistics

% Load ground truth
tmp = readall(dataStore);
groundTruth = tmp.response;

% Compare predicted label with ground truth
predictionError = {};
for idx=1:numel(groundTruth)
    [~, idy] = max(predictionScores(idx,:));
```

```


yActual = net.Layers(end).Classes(idy);
predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
end

% Sum all prediction errors.
predictionError = [predictionError{:}];
accuracy = sum(predictionError)/numel(predictionError);
end

```

To revalidate the network by using this custom metric function, under **Quantization Options**, enter the name of the custom metric function `hComputeAccuracy`. Select **Add** to add `hComputeAccuracy` to the list of metric functions available in the app. Select `hComputeAccuracy` as the metric function to use.

The custom metric function must be on the path. If the metric function is not on the path, this step produces an error.



Click **Quantize and Validate**.

The app quantizes the network and displays the validation results for the custom metric function.

Validation Summary			
Validation Results			
Number of samples: 1			
Metric	Floating-Point Network Results	Quantized Network Results	Percent Change
hComputeAccuracy	1.0000	1.0000	0.0000

The app displays only scalar values in the validation results table. To view the validation results for a custom metric function with nonscalar output, export the `dlquantizer` object, then validate the quantized network by using the `validate` function in the MATLAB command window.

After quantizing and validating the network, you can choose to export the quantized network.

Click the **Export** button. In the drop-down list, select **Export Quantizer** to create a `dlquantizer` object in the base workspace. You can deploy the quantized network to your target FPGA board and retrieve the prediction results by using MATLAB. See, “Deploy Quantized Network Example”.

## See Also

### Apps

[Deep Network Quantizer](#)

### Functions

`calibrate` | `validate` | `dlquantizationOptions`

### Topics

[“Quantization of Deep Neural Networks”](#)

[“Quantize Residual Network Trained for Image Classification and Generate CUDA Code”](#)

[“Quantize Object Detectors and Generate CUDA® Code”](#)

[“Quantize Network for FPGA Deployment”](#)

[“Deploy Quantized Network Example”](#)

[“Classify Images on an FPGA Using a Quantized DAG Network”](#)

[“Code Generation for Quantized Deep Learning Network on Raspberry Pi” \(MATLAB Coder\)](#)

### Introduced in R2020a

# dlquantizationOptions

Options for quantizing a trained deep neural network

## Description

The `dlquantizationOptions` object provides options for quantizing a trained deep neural network to scaled 8-bit integer data types. Use the `dlquantizationOptions` object to define the metric function to use that compares the accuracy of the network before and after quantization.

To learn about the products required to quantize a deep neural network, see “Quantization Workflow Prerequisites”.

## Creation

### Syntax

```
quantOpts = dlquantizationOptions
quantOpts = dlquantizationOptions(Name,Value)
```

#### Description

`quantOpts = dlquantizationOptions` creates a `dlquantizationOptions` object with default property values.

`quantOpts = dlquantizationOptions(Name,Value)` creates a `dlquantizationOptions` object with additional properties specified by one or more name-value pair arguments.

## Properties

### MetricFcn — Function to use for calculating validation metrics

cell array of function handles

Cell array of function handles specifying the functions for calculating validation metrics of quantized network.

Example: `options = dlquantizationOptions('MetricFcn', {@(x)hComputeModelAccuracy(x, net, groundTruth)});`

Data Types: cell

### FPGA Execution Environment Options

#### Bitstream — Bitstream name

'zcu102\_int8' | 'zc706\_int8' | 'arria10soc\_int8'

*This property affects FPGA targeting only.*

Name of the FPGA bitstream specified as a character vector.

Example: 'Bitstream', 'zcu102\_int8'

#### **Target — Name of the dlhdl.Target object**

hT

*This property affects FPGA targeting only.*

Name of the `dlhdl.Target` object that has the board name and board interface information.

Example: 'Target', hT

## Examples

### Quantize a Neural Network for GPU Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network for GPU and explore the behavior of the quantized network. In this example, you quantize the squeezenet neural network after retraining the network to classify new images according to the Train Deep Learning Network to Classify New Images example. In this example, the memory required for the network is reduced approximately 75% through quantization while the accuracy of the network is not affected.

Load the pretrained network. `net` is the output network of the Train Deep Learning Network to Classify New Images example.

```
load net
net

net =
  DAGNetwork with properties:

    Layers: [68x1 nnet.cnn.layer.Layer]
    Connections: [75x2 table]
    InputNames: {'data'}
    OutputNames: {'new_classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

In this example, use the images in the `MerchData` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[calData, valData] = splitEachLabel(imds, 0.7, 'randomized');
```

```
aug_calData = augmentedImageDatastore([227 227], calData);
aug_valData = augmentedImageDatastore([227 227], valData);
```

Create a `dlquantizer` object and specify the network to quantize.

```
quantObj = dlquantizer(net);
```

Define a metric function to use to compare the behavior of the network before and after quantization. This example uses the `hComputeModelAccuracy` metric function.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
%% Computes model-level accuracy statistics

    % Load ground truth
    tmp = readall(dataStore);
    groundTruth = tmp.response;

    % Compare with predicted label with actual ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx,:));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.
    predictionError = [predictionError{:}];
    accuracy = sum(predictionError)/numel(predictionError);
end
```

Specify the metric function in a `dlquantizationOptions` object.

```
quantOpts = dlquantizationOptions('MetricFcn',{@(x)hComputeModelAccuracy(x, net, aug_valData)});
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
calResults = calibrate(quantObj, aug_calData)
```

`calResults`=95×5 table

Optimized Layer Name	Network Layer Name	Learnables
{'conv1_relu_conv1_Weights'}	{'relu_conv1'}	"W"
{'conv1_relu_conv1_Bias'}	{'relu_conv1'}	"B"
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Weights'}	{'fire2-relu_squeeze1x1'}	"W"
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Bias'}	{'fire2-relu_squeeze1x1'}	"B"
{'fire2-expand1x1_fire2-relu_expand1x1_Weights'}	{'fire2-relu_expand1x1'}	"W"
{'fire2-expand1x1_fire2-relu_expand1x1_Bias'}	{'fire2-relu_expand1x1'}	"B"
{'fire2-expand3x3_fire2-relu_expand3x3_Weights'}	{'fire2-relu_expand3x3'}	"W"
{'fire2-expand3x3_fire2-relu_expand3x3_Bias'}	{'fire2-relu_expand3x3'}	"B"
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Weights'}	{'fire3-relu_squeeze1x1'}	"W"
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Bias'}	{'fire3-relu_squeeze1x1'}	"B"
{'fire3-expand1x1_fire3-relu_expand1x1_Weights'}	{'fire3-relu_expand1x1'}	"W"
{'fire3-expand1x1_fire3-relu_expand1x1_Bias'}	{'fire3-relu_expand1x1'}	"B"

```

{'fire3-expand3x3_fire3-relu_expand3x3_Weights' }    {'fire3-relu_expand3x3' }
{'fire3-expand3x3_fire3-relu_expand3x3_Bias'      }    {'fire3-relu_expand3x3' }
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Weights'}    {'fire4-relu_squeeze1x1'}
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Bias'   }    {'fire4-relu_squeeze1x1'}
:

```

Use the `validate` function to quantize the learnable parameters in the convolution layers of the network and exercise the network. The function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the network before and after quantization.

```

valResults = validate(quantObj, aug_valData, quantOpts)

valResults = struct with fields:
    NumSamples: 20
    MetricResults: [1×1 struct]
    Statistics: [2×2 table]

```

Examine the validation output to see the performance of the quantized network.

```

valResults.MetricResults.Result

ans=2×2 table
    NetworkImplementation      MetricOutput
    _____
    {'Floating-Point'}          1
    {'Quantized' }              1

valResults.Statistics

ans=2×2 table
    NetworkImplementation      LearnableParameterMemory(bytes)
    _____
    {'Floating-Point'}          2.9003e+06
    {'Quantized' }              7.3393e+05

```

In this example, the memory required for the network was reduced approximately 75% through quantization. The accuracy of the network is not affected.

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## Quantize a Neural Network for FPGA Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network, and explore the behavior of the quantized network. In this example, you quantize the LogoNet neural network. Quantization helps reduce the memory requirement of a deep neural network by quantizing weights, biases and activations of network layers to 8-bit scaled integer data types. Use MATLAB® to retrieve the prediction results from the target device.

To run this example, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

For additional requirements, see “Quantization Workflow Prerequisites”.

Create a file in your current working directory called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork()
    data = getLogoData();
    net = data.convnet;
end

function data = getLogoData()
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

Load the pretrained network.

```
snet = getLogoNetwork();

snet =
SeriesNetwork with properties:

    Layers: [22×1 nnet.cnn.layer.Layer]
    InputNames: {'imageinput'}
    OutputNames: {'classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

This example uses the images in the `logos_dataset` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir);
unzip('logos_dataset.zip');
 imageData = imageDatastore(fullfile(curDir,'logos_dataset'),...
    'IncludeSubfolders',true,'FileExtensions','.JPG','LabelSource','foldernames');
[calibrationData, validationData] = splitEachLabel(imageData, 0.5,'randomized');
```

Create a `dlquantizer` object and specify the network to quantize.

```
dlQuantObj = dlquantizer(snet,'ExecutionEnvironment','FPGA');
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
dlQuantObj.calibrate(calibrationData)
```

ans =	Optimized Layer Name	Network Layer Name	Learnables / Activations	MinValue	MaxValue
{'conv_1_Weights' }	{'conv_1' }	"Weights"	-0.048978	0.039352	
{'conv_1_Bias' }	{'conv_1' }	"Bias"	0.99996	1.0028	
{'conv_2_Weights' }	{'conv_2' }	"Weights"	-0.055518	0.061901	
{'conv_2_Bias' }	{'conv_2' }	"Bias"	0.00061171	0.00227	
{'conv_3_Weights' }	{'conv_3' }	"Weights"	-0.045942	0.046927	
{'conv_3_Bias' }	{'conv_3' }	"Bias"	-0.0013998	0.0015218	
{'conv_4_Weights' }	{'conv_4' }	"Weights"	-0.045967	0.051	
{'conv_4_Bias' }	{'conv_4' }	"Bias"	-0.00164	0.0037892	
{'fc_1_Weights' }	{'fc_1' }	"Weights"	-0.051394	0.054344	
{'fc_1_Bias' }	{'fc_1' }	"Bias"	-0.00052319	0.00084454	
{'fc_2_Weights' }	{'fc_2' }	"Weights"	-0.05016	0.051557	
{'fc_2_Bias' }	{'fc_2' }	"Bias"	-0.0017564	0.0018502	
{'fc_3_Weights' }	{'fc_3' }	"Weights"	-0.050706	0.04678	
{'fc_3_Bias' }	{'fc_3' }	"Bias"	-0.02951	0.024855	
{'imageinput' }	{'imageinput' }	"Activations"	0	255	
{'imageinput_normalization'}	{'imageinput' }	"Activations"	-139.34	198.72	

Create a target object with a custom name for your target device and an interface to connect your target device to the host computer. Interface options are JTAG and Ethernet. To create the target object, enter:

```
hTarget = dlhdl.Target('Intel', 'Interface', 'JTAG');
```

Define a metric function to use to compare the behavior of the network before and after quantization. Save this function in a local file.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
    %% hComputeModelAccuracy test helper function computes model level accuracy statistics

    % Copyright 2020 The MathWorks, Inc.

    % Load ground truth
    groundTruth = dataStore.Labels;

    % Compare predicted label with ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx, :));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.
    predictionError = [predictionError{:}];
    accuracy = sum(predictionError)/numel(predictionError);
end
```

Specify the metric function in a `dlquantizationOptions` object.

```
options = dlquantizationOptions('MetricFcn', ...
    {@(x)hComputeModelAccuracy(x, snet, validationData)}, 'Bitstream', 'arrial0soc_int8',...
    'Target', hTarget);
```

To compile and deploy the quantized network, run the `validate` function of the `dlquantizer` object. Use the `validate` function to quantize the learnable parameters in the convolution layers of the network and exercise the network. This function uses the output of the `compile` function to program the FPGA board by using the programming file. It also downloads the network weights and biases. The `deploy` function checks for the Intel Quartus tool and the supported tool version. It then starts programming the FPGA device by using the `.sof` file, displays progress messages, and the time it takes to deploy the network. The function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the network before and after quantization.

```
prediction = dlQuantObj.validate(validationData, options);
```

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```

### Programming FPGA Bitstream using JTAG...
### Programming the FPGA bitstream has been completed successfully.
### Loading weights to Conv Processor.
### Conv Weights loaded. Current time is 16-Jul-2020 12:45:10
### Loading weights to FC Processor.
### FC Weights loaded. Current time is 16-Jul-2020 12:45:26
### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13570959	0.09047	30	380609145	11.8
conv_1	12667786	0.08445			
maxpool_1	3938907	0.02626			
conv_2	1544560	0.01030			
maxpool_2	2910954	0.01941			
conv_3	577524	0.00385			
maxpool_3	2552707	0.01702			
conv_4	676542	0.00451			
maxpool_4	455434	0.00304			
fc_module	11251	0.00008			
fc_1	903173	0.00602			
fc_2	536164	0.00357			
fc_3	342643	0.00228			
	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```

### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13570364	0.09047	30	380612682	11.8
conv_1	12667103	0.08445			
maxpool_1	3939296	0.02626			
conv_2	1544371	0.01030			
maxpool_2	2910747	0.01940			
conv_3	577654	0.00385			
maxpool_3	2551829	0.01701			
conv_4	676548	0.00451			
maxpool_4	455396	0.00304			
fc_module	11355	0.00008			
fc_1	903261	0.00602			
fc_2	536206	0.00357			
fc_3	342688	0.00228			
	24365	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```

### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13571561	0.09048	30	380608338	11.8
conv_module	12668340	0.08446			
conv_1	3939070	0.02626			
maxpool_1	1545327	0.01030			
conv_2	2911061	0.01941			
maxpool_2	577557	0.00385			
conv_3	2552082	0.01701			
maxpool_3	676506	0.00451			
conv_4	455582	0.00304			
maxpool_4	11248	0.00007			
fc_module	903221	0.00602			
fc_1	536167	0.00357			
fc_2	342643	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13569862	0.09047	30	380613327	11.8
conv_module	12666756	0.08445			
conv_1	3939212	0.02626			
maxpool_1	1543267	0.01029			
conv_2	2911184	0.01941			
maxpool_2	577275	0.00385			
conv_3	2552868	0.01702			
maxpool_3	676438	0.00451			
conv_4	455353	0.00304			
maxpool_4	11252	0.00008			
fc_module	903106	0.00602			
fc_1	536050	0.00357			
fc_2	342645	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570823	0.09047	30	380619836	11.8
conv_module	12667607	0.08445			
conv_1	3939074	0.02626			
maxpool_1	1544519	0.01030			
conv_2	2910636	0.01940			
maxpool_2	577769	0.00385			
conv_3	2551800	0.01701			
maxpool_3	676795	0.00451			
conv_4	455859	0.00304			
maxpool_4	11248	0.00007			
fc_module	903216	0.00602			
fc_1	536165	0.00357			
fc_2	342643	0.00228			
fc_3	24406	0.00016			

\* The clock frequency of the DL processor is: 150MHz

offset_name	offset_address	allocated_space
-------------	----------------	-----------------

```

"InputDataOffset"           "0x00000000"      "48.0 MB"
"OutputResultOffset"        "0x03000000"      "4.0 MB"
"SystemBufferOffset"        "0x03400000"      "60.0 MB"
"InstructionDataOffset"    "0x07000000"      "8.0 MB"
"ConvWeightDataOffset"     "0x07800000"      "8.0 MB"
"FCWeightDataOffset"       "0x08000000"      "12.0 MB"
"EndOffset"                "0x08c00000"      "Total: 140.0 MB"

### FPGA bitstream programming has been skipped as the same bitstream is already loaded on the target FPGA.
### Deep learning network programming has been skipped as the same network is already loaded on the target FPGA.
### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13572329	0.09048	10	127265075	11.8
conv_1	12669135	0.08446			
maxpool_1	3939559	0.02626			
conv_2	1545378	0.01030			
maxpool_2	2911243	0.01941			
conv_3	577422	0.00385			
maxpool_3	2552064	0.01701			
conv_4	676678	0.00451			
maxpool_4	455657	0.00304			
fc_module	11227	0.00007			
fc_1	903194	0.00602			
fc_2	536140	0.00357			
fc_3	342688	0.00228			
fc_4	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```

### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

Network	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
conv_module	13572527	0.09048	10	127266427	11.8
conv_1	12669266	0.08446			
maxpool_1	3939776	0.02627			
conv_2	1545632	0.01030			
maxpool_2	2911169	0.01941			
conv_3	577592	0.00385			
maxpool_3	2551613	0.01701			
conv_4	676811	0.00451			
maxpool_4	455418	0.00304			
fc_module	11348	0.00008			
fc_1	903261	0.00602			
fc_2	536205	0.00357			
fc_3	342689	0.00228			
fc_4	24365	0.00016			

\* The clock frequency of the DL processor is: 150MHz

Examine the `MetricResults.Result` field of the validation output to see the performance of the quantized network.

```
validateOut = prediction.MetricResults.Result
```

```

ans =
NetworkImplementation      MetricOutput
_____
{'Floating-Point'}          0.9875

```

```
{'Quantized'      }          0.9875
```

Examine the `QuantizedNetworkFPS` field of the validation output to see the frames per second performance of the quantized network.

```
prediction.QuantizedNetworkFPS  
ans = 11.8126
```

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## See Also

### Apps

[Deep Network Quantizer](#)

### Functions

[calibrate](#) | [validate](#) | [dlquantizer](#)

### Topics

[“Quantization of Deep Neural Networks”](#)

**Introduced in R2020a**

# calibrate

Simulate and collect ranges of a deep neural network

## Syntax

```
calibrationResults = calibrate(quantObj, calData)
calibrationResults = calibrate(quantObj, calData, Name, Value)
```

## Description

`calibrationResults = calibrate(quantObj, calData)` exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network specified by `dlquantizer` object, `quantObj`, using the data specified by `calData`.

`calibrationResults = calibrate(quantObj, calData, Name, Value)` exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network specified by `dlquantizer` object, `quantObj`, using the data specified by `calData`, with additional arguments specified by one or more name-value pair arguments.

To learn about the products required to quantize a deep neural network, see “Quantization Workflow Prerequisites”

## Examples

### Quantize a Neural Network for GPU Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network for GPU and explore the behavior of the quantized network. In this example, you quantize the squeezeNet neural network after retraining the network to classify new images according to the Train Deep Learning Network to Classify New Images example. In this example, the memory required for the network is reduced approximately 75% through quantization while the accuracy of the network is not affected.

Load the pretrained network. `net` is the output network of the Train Deep Learning Network to Classify New Images example.

```
load net
net

net =
  DAGNetwork with properties:

    Layers: [68x1 nnet.cnn.layer.Layer]
    Connections: [75x2 table]
    InputNames: {'data'}
    OutputNames: {'new_classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

In this example, use the images in the `MerchData` data set. Define an `augmentedImage datastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[calData, valData] = splitEachLabel(imds, 0.7, 'randomized');
aug_calData = augmentedImage datastore([227 227], calData);
aug_valData = augmentedImage datastore([227 227], valData);
```

Create a `dlquantizer` object and specify the network to quantize.

```
quantObj = dlquantizer(net);
```

Define a metric function to use to compare the behavior of the network before and after quantization. This example uses the `hComputeModelAccuracy` metric function.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
%% Computes model-level accuracy statistics

% Load ground truth
tmp = readall(dataStore);
groundTruth = tmp.response;

% Compare with predicted label with actual ground truth
predictionError = {};
for idx=1:numel(groundTruth)
    [~, idy] = max(predictionScores(idx,:));
    yActual = net.Layers(end).Classes(idy);
    predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
end

% Sum all prediction errors.
predictionError = [predictionError{:}];
accuracy = sum(predictionError)/numel(predictionError);
end
```

Specify the metric function in a `dlquantizationOptions` object.

```
quantOpts = dlquantizationOptions('MetricFcn',{@(x)hComputeModelAccuracy(x, net, aug_valData)});
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
calResults = calibrate(quantObj, aug_calData)
```

calResults=95×5 *table*

Optimized Layer Name	Network Layer Name	Learnable
{'conv1_relu_conv1_Weights'}	{'relu_conv1'}	"W"
{'conv1_relu_conv1_Bias'}	{'relu_conv1'}	"B"
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Weights'}	{'fire2-relu_squeeze1x1'}	"W"
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Bias'}	{'fire2-relu_squeeze1x1'}	"B"
{'fire2-expand1x1_fire2-relu_expand1x1_Weights'}	{'fire2-relu_expand1x1'}	"W"
{'fire2-expand1x1_fire2-relu_expand1x1_Bias'}	{'fire2-relu_expand1x1'}	"B"
{'fire2-expand3x3_fire2-relu_expand3x3_Weights'}	{'fire2-relu_expand3x3'}	"W"
{'fire2-expand3x3_fire2-relu_expand3x3_Bias'}	{'fire2-relu_expand3x3'}	"B"
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Weights'}	{'fire3-relu_squeeze1x1'}	"W"
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Bias'}	{'fire3-relu_squeeze1x1'}	"B"
{'fire3-expand1x1_fire3-relu_expand1x1_Weights'}	{'fire3-relu_expand1x1'}	"W"
{'fire3-expand1x1_fire3-relu_expand1x1_Bias'}	{'fire3-relu_expand1x1'}	"B"
{'fire3-expand3x3_fire3-relu_expand3x3_Weights'}	{'fire3-relu_expand3x3'}	"W"
{'fire3-expand3x3_fire3-relu_expand3x3_Bias'}	{'fire3-relu_expand3x3'}	"B"
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Weights'}	{'fire4-relu_squeeze1x1'}	"W"
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Bias'}	{'fire4-relu_squeeze1x1'}	"B"
:		

Use the **validate** function to quantize the learnable parameters in the convolution layers of the network and exercise the network. The function uses the metric function defined in the **dlquantizationOptions** object to compare the results of the network before and after quantization.

```
valResults = validate(quantObj, aug_valData, quantOpts)

valResults = struct with fields:
    NumSamples: 20
    MetricResults: [1×1 struct]
    Statistics: [2×2 table]
```

Examine the validation output to see the performance of the quantized network.

**valResults.MetricResults.Result**

NetworkImplementation	MetricOutput
{'Floating-Point'}	1
{'Quantized'}	1

**valResults.Statistics**

NetworkImplementation	LearnableParameterMemory(bytes)
{'Floating-Point'}	2.9003e+06
{'Quantized'}	7.3393e+05

In this example, the memory required for the network was reduced approximately 75% through quantization. The accuracy of the network is not affected.

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## Quantize a Neural Network for FPGA Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network, and explore the behavior of the quantized network. In this example, you quantize the `LogoNet` neural network. Quantization helps reduce the memory requirement of a deep neural network by quantizing weights, biases and activations of network layers to 8-bit scaled integer data types. Use MATLAB® to retrieve the prediction results from the target device.

To run this example, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

For additional requirements, see “Quantization Workflow Prerequisites”.

Create a file in your current working directory called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork()
    data = getLogoData();
    net = data.convnet;
end

function data = getLogoData()
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

Load the pretrained network.

```
snet = getLogoNetwork();

snet =
    SeriesNetwork with properties:

    Layers: [22×1 nnet.cnn.layer.Layer]
    InputNames: {'imageinput'}
    OutputNames: {'classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

This example uses the images in the `logos_dataset` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
curDir = pwd;
newDir = fullfile(matlabroot, 'examples', 'deeplearning_shared', 'data', 'logos_dataset.zip');
copyfile(newDir, curDir);
unzip('logos_dataset.zip');
imageData = imageDatastore(fullfile(curDir, 'logos_dataset'), ...
    'IncludeSubfolders', true, 'FileExtensions', '.JPG', 'LabelSource', 'foldernames');
[calibrationData, validationData] = splitEachLabel(imageData, 0.5, 'randomized');
```

Create a `dlquantizer` object and specify the network to quantize.

```
dlQuantObj = dlquantizer(snet, 'ExecutionEnvironment', 'FPGA');
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
dlQuantObj.calibrate(calibrationData)
```

ans =	Optimized Layer Name	Network Layer Name	Learnables / Activations	MinValue	MaxValue
	{'conv_1_Weights'}	{'conv_1'}	"Weights"	-0.048978	0.039352
	{'conv_1_Bias'}	{'conv_1'}	"Bias"	0.99996	1.0028
	{'conv_2_Weights'}	{'conv_2'}	"Weights"	-0.055518	0.061901
	{'conv_2_Bias'}	{'conv_2'}	"Bias"	-0.00061171	0.00227
	{'conv_3_Weights'}	{'conv_3'}	"Weights"	-0.045942	0.046927
	{'conv_3_Bias'}	{'conv_3'}	"Bias"	-0.0013998	0.0015218
	{'conv_4_Weights'}	{'conv_4'}	"Weights"	-0.045967	0.051
	{'conv_4_Bias'}	{'conv_4'}	"Bias"	-0.00164	0.0037892
	{'fc_1_Weights'}	{'fc_1'}	"Weights"	-0.051394	0.054344
	{'fc_1_Bias'}	{'fc_1'}	"Bias"	-0.00052319	0.00084454
	{'fc_2_Weights'}	{'fc_2'}	"Weights"	-0.05016	0.051557
	{'fc_2_Bias'}	{'fc_2'}	"Bias"	-0.0017564	0.0018502
	{'fc_3_Weights'}	{'fc_3'}	"Weights"	-0.050706	0.04678
	{'fc_3_Bias'}	{'fc_3'}	"Bias"	-0.02951	0.024855
	{'imageinput'}	{'imageinput'}	"Activations"	0	255
	{'imageinput_normalization'}	{'imageinput'}	"Activations"	-139.34	198.72

Create a target object with a custom name for your target device and an interface to connect your target device to the host computer. Interface options are JTAG and Ethernet. To create the target object, enter:

```
hTarget = dlhdl.Target('Intel', 'Interface', 'JTAG');
```

Define a metric function to use to compare the behavior of the network before and after quantization. Save this function in a local file.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
    %% hComputeModelAccuracy test helper function computes model level accuracy statistics

    % Copyright 2020 The MathWorks, Inc.

    % Load ground truth
    groundTruth = dataStore.Labels;

    % Compare predicted label with ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx, :));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.

```

```

predictionError = [predictionError{:}];
accuracy = sum(predictionError)/numel(predictionError);
end

```

Specify the metric function in a `dlquantizationOptions` object.

```

options = dlquantizationOptions('MetricFcn', ...
    {@(x)hComputeModelAccuracy(x, snet, validationData)}, 'Bitstream', 'arrial0soc_int8',...
    'Target', hTarget);

```

To compile and deploy the quantized network, run the `validate` function of the `dlquantizer` object. Use the `validate` function to quantize the learnable parameters in the convolution layers of the network and exercise the network. This function uses the output of the `compile` function to program the FPGA board by using the programming file. It also downloads the network weights and biases. The `deploy` function checks for the Intel Quartus tool and the supported tool version. It then starts programming the FPGA device by using the `.sof` file, displays progress messages, and the time it takes to deploy the network. The function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the network before and after quantization.

```
prediction = dlQuantObj.validate(validationData,options);
```

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```

### Programming FPGA Bitstream using JTAG...
### Programming the FPGA bitstream has been completed successfully.
### Loading weights to Conv Processor.
### Conv Weights loaded. Current time is 16-Jul-2020 12:45:10
### Loading weights to FC Processor.
### FC Weights loaded. Current time is 16-Jul-2020 12:45:26
### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570959	0.09047	30	380609145	11.8
conv_module	12667786	0.08445			
conv_1	3938907	0.02626			
maxpool_1	1544560	0.01030			
conv_2	2910954	0.01941			
maxpool_2	577524	0.00385			
conv_3	2552707	0.01702			
maxpool_3	676542	0.00451			
conv_4	455434	0.00304			
maxpool_4	11251	0.00008			
fc_module	903173	0.00602			
fc_1	536164	0.00357			
fc_2	342643	0.00228			
fc_3	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```

### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570364	0.09047	30	380612682	11.8
conv_module	12667103	0.08445			
conv_1	3939296	0.02626			
maxpool_1	1544371	0.01030			
conv_2	2910747	0.01940			
maxpool_2	577654	0.00385			
conv_3	2551829	0.01701			
maxpool_3	676548	0.00451			
conv_4	455396	0.00304			
maxpool_4	11355	0.00008			
fc_module	903261	0.00602			
fc_1	536206	0.00357			
fc_2	342688	0.00228			
fc_3	24365	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13571561	0.09048	30	380608338	11.8
conv_module	12668340	0.08446			
conv_1	3939070	0.02626			
maxpool_1	1545327	0.01030			
conv_2	2911061	0.01941			
maxpool_2	577557	0.00385			
conv_3	2552082	0.01701			
maxpool_3	676506	0.00451			
conv_4	455582	0.00304			
maxpool_4	11248	0.00007			
fc_module	903221	0.00602			
fc_1	536167	0.00357			
fc_2	342643	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13569862	0.09047	30	380613327	11.8
conv_module	12666756	0.08445			
conv_1	3939212	0.02626			
maxpool_1	1543267	0.01029			
conv_2	2911184	0.01941			
maxpool_2	577275	0.00385			
conv_3	2552868	0.01702			
maxpool_3	676438	0.00451			
conv_4	455353	0.00304			
maxpool_4	11252	0.00008			
fc_module	903106	0.00602			
fc_1	536050	0.00357			
fc_2	342645	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570823	0.09047	30	380619836	11.8
conv_module	12667607	0.08445			
conv_1	3939074	0.02626			
maxpool_1	1544519	0.01030			
conv_2	2910636	0.01940			
maxpool_2	577769	0.00385			
conv_3	2551800	0.01701			
maxpool_3	676795	0.00451			
conv_4	455859	0.00304			
maxpool_4	11248	0.00007			
fc_module	903216	0.00602			
fc_1	536165	0.00357			
fc_2	342643	0.00228			
fc_3	24406	0.00016			

\* The clock frequency of the DL processor is: 150MHz

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```
### FPGA bitstream programming has been skipped as the same bitstream is already loaded on the target FPGA.
### Deep learning network programming has been skipped as the same network is already loaded on the target FPGA.
### Finished writing input activations.
### Running single input activations.
```

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13572329	0.09048	10	127265075	11.8
conv_module	12669135	0.08446			
conv_1	3939559	0.02626			
maxpool_1	1545378	0.01030			
conv_2	2911243	0.01941			
maxpool_2	577422	0.00385			
conv_3	2552064	0.01701			
maxpool_3	676678	0.00451			
conv_4	455657	0.00304			
maxpool_4	11227	0.00007			
fc_module	903194	0.00602			
fc_1	536140	0.00357			
fc_2	342688	0.00228			
fc_3	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```
### Finished writing input activations.
### Running single input activations.
```

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13572527	0.09048	10	127266427	11.8
conv_module	12669266	0.08446			
conv_1	3939776	0.02627			

```

maxpool_1           1545632          0.01030
conv_2              2911169          0.01941
maxpool_2           577592           0.00385
conv_3              2551613           0.01701
maxpool_3           676811            0.00451
conv_4              455418            0.00304
maxpool_4           11348             0.00008
fc_module           903261            0.00602
  fc_1               536205            0.00357
  fc_2               342689            0.00228
  fc_3               24365             0.00016
* The clock frequency of the DL processor is: 150MHz

```

Examine the `MetricResults.Result` field of the validation output to see the performance of the quantized network.

```

validateOut = prediction.MetricResults.Result
ans =
  NetworkImplementation      MetricOutput
  _____
  {'Floating-Point'}        0.9875
  {'Quantized' }            0.9875

```

Examine the `QuantizedNetworkFPS` field of the validation output to see the frames per second performance of the quantized network.

```

prediction.QuantizedNetworkFPS
ans = 11.8126

```

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## Input Arguments

**quantObj — Network to quantize**  
`dlquantizer` object

`dlquantizer` object containing the network to quantize.

**calData — Data to use for calibration of quantized network**  
`imageDatastore` object | `augmentedImageDatastore` object | `pixelLabelImageDatastore` object

Data to use for calibration of quantized network, specified as an `imageDatastore` object, an `augmentedImageDatastore` object, or a `pixelLabelImageDatastore` object.

## Name-Value Pair Arguments

Specify optional comma-separated pairs of `Name`, `Value` arguments. `Name` is the argument name and `Value` is the corresponding value. `Name` must appear inside quotes. You can specify several name and value pair arguments in any order as `Name1`, `Value1`, ..., `NameN`, `ValueN`.

Example: `calResults = calibrate(quantObj, calData, 'UseGPU', 'on')`

**UseGPU — Logical flag to use GPU for calibration**  
`'off'` (default) | `'on'`

Logical flag to use a GPU for calibration when the `dlquantizer` object `ExecutionEnvironment` is set to 'FPGA' or 'CPU'.

Example: 'UseGPU', 'on'

## Output Arguments

**calibrationResults – Dynamic ranges of network**  
table

Dynamic ranges of layers of the network, returned as a table. Each row in the table displays the minimum and maximum values of a learnable parameter of a convolution layer of the optimized network. The software uses these minimum and maximum values to determine the scaling for the data type of the quantized parameter.

## See Also

**Apps**  
**Deep Network Quantizer**

**Functions**  
`validate` | `dlquantizer` | `dlquantizationOptions`

**Topics**  
“Quantization of Deep Neural Networks”

**Introduced in R2020a**

# validate

Quantize and validate a deep neural network

## Syntax

```
validationResults = validate(quantObj, valData)
validationResults = validate(quantObj, valData, quantOpts)
```

## Description

`validationResults = validate(quantObj, valData)` quantizes the weights, biases, and activations in the convolution layers of the network, and validates the network specified by `dlquantizer` object, `quantObj` and using the data specified by `valData`.

`validationResults = validate(quantObj, valData, quantOpts)` quantizes the weights, biases, and activations in the convolution layers of the network, and validates the network specified by `dlquantizer` object, `quantObj`, using the data specified by `valData`, and the optional argument `quantOpts` that specifies a metric function to evaluate the performance of the quantized network.

To learn about the products required to quantize a deep neural network, see “Quantization Workflow Prerequisites”.

## Examples

### Quantize a Neural Network for GPU Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network for GPU and explore the behavior of the quantized network. In this example, you quantize the squeezenet neural network after retraining the network to classify new images according to the Train Deep Learning Network to Classify New Images example. In this example, the memory required for the network is reduced approximately 75% through quantization while the accuracy of the network is not affected.

Load the pretrained network. `net` is the output network of the Train Deep Learning Network to Classify New Images example.

```
load net
net

net =
  DAGNetwork with properties:

    Layers: [68x1 nnet.cnn.layer.Layer]
    Connections: [75x2 table]
    InputNames: {'data'}
    OutputNames: {'new_classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

In this example, use the images in the `MerchData` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[calData, valData] = splitEachLabel(imds, 0.7, 'randomized');
aug_calData = augmentedImageDatastore([227 227], calData);
aug_valData = augmentedImageDatastore([227 227], valData);
```

Create a `dlquantizer` object and specify the network to quantize.

```
quantObj = dlquantizer(net);
```

Define a metric function to use to compare the behavior of the network before and after quantization. This example uses the `hComputeModelAccuracy` metric function.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
%% Computes model-level accuracy statistics

    % Load ground truth
    tmp = readall(dataStore);
    groundTruth = tmp.response;

    % Compare with predicted label with actual ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx,:));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.
    predictionError = [predictionError{:}];
    accuracy = sum(predictionError)/numel(predictionError);
end
```

Specify the metric function in a `dlquantizationOptions` object.

```
quantOpts = dlquantizationOptions('MetricFcn',{@(x)hComputeModelAccuracy(x, net, aug_valData)});
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
calResults = calibrate(quantObj, aug_calData)
```

calResults=95×5 table

Optimized Layer Name	Network Layer Name	Learnable
{'conv1_relu_conv1_Weights'}	{'relu_conv1'}	"We
{'conv1_relu_conv1_Bias'}	{'relu_conv1'}	"B
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Weights'}	{'fire2-relu_squeeze1x1'}	"We
{'fire2-squeeze1x1_fire2-relu_squeeze1x1_Bias'}	{'fire2-relu_squeeze1x1'}	"B
{'fire2-expand1x1_fire2-relu_expand1x1_Weights'}	{'fire2-relu_expand1x1'}	"We
{'fire2-expand1x1_fire2-relu_expand1x1_Bias'}	{'fire2-relu_expand1x1'}	"B
{'fire2-expand3x3_fire2-relu_expand3x3_Weights'}	{'fire2-relu_expand3x3'}	"We
{'fire2-expand3x3_fire2-relu_expand3x3_Bias'}	{'fire2-relu_expand3x3'}	"B
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Weights'}	{'fire3-relu_squeeze1x1'}	"We
{'fire3-squeeze1x1_fire3-relu_squeeze1x1_Bias'}	{'fire3-relu_squeeze1x1'}	"B
{'fire3-expand1x1_fire3-relu_expand1x1_Weights'}	{'fire3-relu_expand1x1'}	"We
{'fire3-expand1x1_fire3-relu_expand1x1_Bias'}	{'fire3-relu_expand1x1'}	"B
{'fire3-expand3x3_fire3-relu_expand3x3_Weights'}	{'fire3-relu_expand3x3'}	"We
{'fire3-expand3x3_fire3-relu_expand3x3_Bias'}	{'fire3-relu_expand3x3'}	"B
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Weights'}	{'fire4-relu_squeeze1x1'}	"We
{'fire4-squeeze1x1_fire4-relu_squeeze1x1_Bias'}	{'fire4-relu_squeeze1x1'}	"B
:		

Use the **validate** function to quantize the learnable parameters in the convolution layers of the network and exercise the network. The function uses the metric function defined in the **dlquantizationOptions** object to compare the results of the network before and after quantization.

```
valResults = validate(quantObj, aug_valData, quantOpts)

valResults = struct with fields:
    NumSamples: 20
    MetricResults: [1x1 struct]
    Statistics: [2x2 table]
```

Examine the validation output to see the performance of the quantized network.

**valResults.MetricResults.Result**

NetworkImplementation	MetricOutput
{'Floating-Point'}	1
{'Quantized'}	1

**valResults.Statistics**

NetworkImplementation	LearnableParameterMemory(bytes)
{'Floating-Point'}	2.9003e+06
{'Quantized'}	7.3393e+05

In this example, the memory required for the network was reduced approximately 75% through quantization. The accuracy of the network is not affected.

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

## Quantize a Neural Network for FPGA Target

This example shows how to quantize learnable parameters in the convolution layers of a neural network, and explore the behavior of the quantized network. In this example, you quantize the `LogoNet` neural network. Quantization helps reduce the memory requirement of a deep neural network by quantizing weights, biases and activations of network layers to 8-bit scaled integer data types. Use MATLAB® to retrieve the prediction results from the target device.

To run this example, you need the products listed under **FPGA** in “Quantization Workflow Prerequisites”.

For additional requirements, see “Quantization Workflow Prerequisites”.

Create a file in your current working directory called `getLogoNetwork.m`. Enter these lines into the file:

```
function net = getLogoNetwork()
    data = getLogoData();
    net = data.convnet;
end

function data = getLogoData()
    if ~isfile('LogoNet.mat')
        url = 'https://www.mathworks.com/supportfiles/gpucoder/cnn_models/logo_detection/LogoNet.mat';
        websave('LogoNet.mat',url);
    end
    data = load('LogoNet.mat');
end
```

Load the pretrained network.

```
snet = getLogoNetwork();

snet =
    SeriesNetwork with properties:

    Layers: [22×1 nnet.cnn.layer.Layer]
    InputNames: {'imageinput'}
    OutputNames: {'classoutput'}
```

Define calibration and validation data to use for quantization.

The calibration data is used to collect the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. For the best quantization results, the calibration data must be representative of inputs to the network.

The validation data is used to test the network after quantization to understand the effects of the limited range and precision of the quantized convolution layers in the network.

This example uses the images in the `logos_dataset` data set. Define an `augmentedImageDatastore` object to resize the data for the network. Then, split the data into calibration and validation data sets.

```
curDir = pwd;
newDir = fullfile(matlabroot, 'examples', 'deeplearning_shared', 'data', 'logos_dataset.zip');
copyfile(newDir, curDir);
unzip('logos_dataset.zip');
imageData = imageDatastore(fullfile(curDir, 'logos_dataset'), ...
    'IncludeSubfolders', true, 'FileExtensions', '.JPG', 'LabelSource', 'foldernames');
[calibrationData, validationData] = splitEachLabel(imageData, 0.5, 'randomized');
```

Create a `dlquantizer` object and specify the network to quantize.

```
dlQuantObj = dlquantizer(snet, 'ExecutionEnvironment', 'FPGA');
```

Use the `calibrate` function to exercise the network with sample inputs and collect range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The function returns a table. Each row of the table contains range information for a learnable parameter of the optimized network.

```
dlQuantObj.calibrate(calibrationData)
```

ans =	Optimized Layer Name	Network Layer Name	Learnables / Activations	MinValue	MaxValue
	{'conv_1_Weights'}	{'conv_1'}	"Weights"	-0.048978	0.039352
	{'conv_1_Bias'}	{'conv_1'}	"Bias"	0.99996	1.0028
	{'conv_2_Weights'}	{'conv_2'}	"Weights"	-0.055518	0.061901
	{'conv_2_Bias'}	{'conv_2'}	"Bias"	-0.00061171	0.00227
	{'conv_3_Weights'}	{'conv_3'}	"Weights"	-0.045942	0.046927
	{'conv_3_Bias'}	{'conv_3'}	"Bias"	-0.0013998	0.0015218
	{'conv_4_Weights'}	{'conv_4'}	"Weights"	-0.045967	0.051
	{'conv_4_Bias'}	{'conv_4'}	"Bias"	-0.00164	0.0037892
	{'fc_1_Weights'}	{'fc_1'}	"Weights"	-0.051394	0.054344
	{'fc_1_Bias'}	{'fc_1'}	"Bias"	-0.00052319	0.00084454
	{'fc_2_Weights'}	{'fc_2'}	"Weights"	-0.05016	0.051557
	{'fc_2_Bias'}	{'fc_2'}	"Bias"	-0.0017564	0.0018502
	{'fc_3_Weights'}	{'fc_3'}	"Weights"	-0.050706	0.04678
	{'fc_3_Bias'}	{'fc_3'}	"Bias"	-0.02951	0.024855
	{'imageinput'}	{'imageinput'}	"Activations"	0	255
	{'imageinput_normalization'}	{'imageinput'}	"Activations"	-139.34	198.72

Create a target object with a custom name for your target device and an interface to connect your target device to the host computer. Interface options are JTAG and Ethernet. To create the target object, enter:

```
hTarget = dlhdl.Target('Intel', 'Interface', 'JTAG');
```

Define a metric function to use to compare the behavior of the network before and after quantization. Save this function in a local file.

```
function accuracy = hComputeModelAccuracy(predictionScores, net, dataStore)
    %% hComputeModelAccuracy test helper function computes model level accuracy statistics

    % Copyright 2020 The MathWorks, Inc.

    % Load ground truth
    groundTruth = dataStore.Labels;

    % Compare predicted label with ground truth
    predictionError = {};
    for idx=1:numel(groundTruth)
        [~, idy] = max(predictionScores(idx, :));
        yActual = net.Layers(end).Classes(idy);
        predictionError{end+1} = (yActual == groundTruth(idx)); %#ok
    end

    % Sum all prediction errors.

```

```

predictionError = [predictionError{:}];
accuracy = sum(predictionError)/numel(predictionError);
end

```

Specify the metric function in a `dlquantizationOptions` object.

```

options = dlquantizationOptions('MetricFcn', ...
    {@(x)hComputeModelAccuracy(x, snet, validationData)}, 'Bitstream', 'arrial0soc_int8',...
    'Target', hTarget);

```

To compile and deploy the quantized network, run the `validate` function of the `dlquantizer` object. Use the `validate` function to quantize the learnable parameters in the convolution layers of the network and exercise the network. This function uses the output of the `compile` function to program the FPGA board by using the programming file. It also downloads the network weights and biases. The `deploy` function checks for the Intel Quartus tool and the supported tool version. It then starts programming the FPGA device by using the `.sof` file, displays progress messages, and the time it takes to deploy the network. The function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the network before and after quantization.

```
prediction = dlQuantObj.validate(validationData,options);
```

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```

### Programming FPGA Bitstream using JTAG...
### Programming the FPGA bitstream has been completed successfully.
### Loading weights to Conv Processor.
### Conv Weights loaded. Current time is 16-Jul-2020 12:45:10
### Loading weights to FC Processor.
### FC Weights loaded. Current time is 16-Jul-2020 12:45:26
### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570959	0.09047	30	380609145	11.8
conv_module	12667786	0.08445			
conv_1	3938907	0.02626			
maxpool_1	1544560	0.01030			
conv_2	2910954	0.01941			
maxpool_2	577524	0.00385			
conv_3	2552707	0.01702			
maxpool_3	676542	0.00451			
conv_4	455434	0.00304			
maxpool_4	11251	0.00008			
fc_module	903173	0.00602			
fc_1	536164	0.00357			
fc_2	342643	0.00228			
fc_3	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```

### Finished writing input activations.
### Running single input activations.

```

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570364	0.09047	30	380612682	11.8
conv_module	12667103	0.08445			
conv_1	3939296	0.02626			
maxpool_1	1544371	0.01030			
conv_2	2910747	0.01940			
maxpool_2	577654	0.00385			
conv_3	2551829	0.01701			
maxpool_3	676548	0.00451			
conv_4	455396	0.00304			
maxpool_4	11355	0.00008			
fc_module	903261	0.00602			
fc_1	536206	0.00357			
fc_2	342688	0.00228			
fc_3	24365	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13571561	0.09048	30	380608338	11.8
conv_module	12668340	0.08446			
conv_1	3939070	0.02626			
maxpool_1	1545327	0.01030			
conv_2	2911061	0.01941			
maxpool_2	577557	0.00385			
conv_3	2552082	0.01701			
maxpool_3	676506	0.00451			
conv_4	455582	0.00304			
maxpool_4	11248	0.00007			
fc_module	903221	0.00602			
fc_1	536167	0.00357			
fc_2	342643	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

#### Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13569862	0.09047	30	380613327	11.8
conv_module	12666756	0.08445			
conv_1	3939212	0.02626			
maxpool_1	1543267	0.01029			
conv_2	2911184	0.01941			
maxpool_2	577275	0.00385			
conv_3	2552868	0.01702			
maxpool_3	676438	0.00451			
conv_4	455353	0.00304			
maxpool_4	11252	0.00008			
fc_module	903106	0.00602			
fc_1	536050	0.00357			
fc_2	342645	0.00228			
fc_3	24409	0.00016			

\* The clock frequency of the DL processor is: 150MHz

### Finished writing input activations.  
### Running single input activations.

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13570823	0.09047	30	380619836	11.8
conv_module	12667607	0.08445			
conv_1	3939074	0.02626			
maxpool_1	1544519	0.01030			
conv_2	2910636	0.01940			
maxpool_2	577769	0.00385			
conv_3	2551800	0.01701			
maxpool_3	676795	0.00451			
conv_4	455859	0.00304			
maxpool_4	11248	0.00007			
fc_module	903216	0.00602			
fc_1	536165	0.00357			
fc_2	342643	0.00228			
fc_3	24406	0.00016			

\* The clock frequency of the DL processor is: 150MHz

offset_name	offset_address	allocated_space
"InputDataOffset"	"0x00000000"	"48.0 MB"
"OutputResultOffset"	"0x03000000"	"4.0 MB"
"SystemBufferOffset"	"0x03400000"	"60.0 MB"
"InstructionDataOffset"	"0x07000000"	"8.0 MB"
"ConvWeightDataOffset"	"0x07800000"	"8.0 MB"
"FCWeightDataOffset"	"0x08000000"	"12.0 MB"
"EndOffset"	"0x08c00000"	"Total: 140.0 MB"

```
### FPGA bitstream programming has been skipped as the same bitstream is already loaded on the target FPGA.
### Deep learning network programming has been skipped as the same network is already loaded on the target FPGA.
### Finished writing input activations.
### Running single input activations.
```

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13572329	0.09048	10	127265075	11.8
conv_module	12669135	0.08446			
conv_1	3939559	0.02626			
maxpool_1	1545378	0.01030			
conv_2	2911243	0.01941			
maxpool_2	577422	0.00385			
conv_3	2552064	0.01701			
maxpool_3	676678	0.00451			
conv_4	455657	0.00304			
maxpool_4	11227	0.00007			
fc_module	903194	0.00602			
fc_1	536140	0.00357			
fc_2	342688	0.00228			
fc_3	24364	0.00016			

\* The clock frequency of the DL processor is: 150MHz

```
### Finished writing input activations.
### Running single input activations.
```

Deep Learning Processor Profiler Performance Results

	LastLayerLatency(cycles)	LastLayerLatency(seconds)	FramesNum	Total Latency	Frames/s
Network	13572527	0.09048	10	127266427	11.8
conv_module	12669266	0.08446			
conv_1	3939776	0.02627			

```

maxpool_1          1545632      0.01030
conv_2             2911169      0.01941
maxpool_2          577592       0.00385
conv_3             2551613      0.01701
maxpool_3          676811       0.00451
conv_4             455418        0.00304
maxpool_4          11348        0.00008
fc_module          903261       0.00602
  fc_1              536205       0.00357
  fc_2              342689       0.00228
  fc_3              24365        0.00016
* The clock frequency of the DL processor is: 150MHz

```

Examine the `MetricResults.Result` field of the validation output to see the performance of the quantized network.

```

validateOut = prediction.MetricResults.Result
ans =
NetworkImplementation      MetricOutput
_____
{'Floating-Point'}          0.9875
{'Quantized' }               0.9875

```

Examine the `QuantizedNetworkFPS` field of the validation output to see the frames per second performance of the quantized network.

```

prediction.QuantizedNetworkFPS
ans = 11.8126

```

The weights, biases, and activations of the convolution layers of the network specified in the `dlquantizer` object now use scaled 8-bit integer data types.

### **Validate Quantized Network by Using MATLAB Simulation**

This example shows how to quantize learnable parameters in the convolution layers of a neural network, and validate the quantized network. Rapidly prototype the quantized network by using MATLAB based simulation to validate the quantized network. For this type of simulation, you do not need hardware FPGA board from the prototyping process. In this example, you quantize the LogoNet neural network.


For this example, you need the products listed under `FPGA` in “Quantization Workflow Prerequisites”.

Load the pretrained network and analyze the network architecture.

```

snet = getLogoNetwork;
analyzeNetwork(snet);

```



Define calibration and validation data to use for quantization.

This example uses the `logos_dataset` data set. The data set consists of 320 images. Each image is 227-by-227 in size and has three color channels (RGB). Create an `augmentedImagedatastore` object to use for calibration and validation. Expedite the calibration and validation process by reducing the calibration data set to 20 images. The MATLAB simulation workflow has a maximum limit of five images when validating the quantized network. Reduce the validation data set sizes to five images.

```
curDir = pwd;
newDir = fullfile(matlabroot,'examples','deeplearning_shared','data','logos_dataset.zip');
copyfile(newDir,curDir,'f');
unzip('logos_dataset.zip');
imagedata = imagedatastore(fullfile(curDir,'logos_dataset'),...
    'IncludeSubfolders',true,'FileExtensions','.JPG','LabelSource','foldernames');
[calibrationData, validationData] = splitEachLabel(imagedata, 0.5,'randomized');
calibrationData_reduced = calibrationData.subset(1:20);
validationData_reduced = validationData.subset(1:5);
```

Create a quantized network by using the `dlquantizer` object. To use the MATLAB simulation environment set `Simulation` to on.

```
dlQuantObj = dlquantizer(snet,'ExecutionEnvironment','FPGA','Simulation','on')
```

Use the `calibrate` function to exercise the network with sample inputs and collect the range information. The `calibrate` function exercises the network and collects the dynamic ranges of the weights and biases in the convolution and fully connected layers of the network and the dynamic ranges of the activations in all layers of the network. The `calibrate` function returns a table. Each row of the table contains range information for a learnable parameter of the quantized network.

```
dlQuantObj.calibrate(calibrationData_reduced)
```

```
ans =
35x5 table
```

Optimized Layer Name	Network Layer Name	Learnables / Activations	MinValue
{'conv_1_Weights'}	{'conv_1'}	"Weights"	-0.048978
{'conv_1_Bias'}	{'conv_1'}	"Bias"	0.999900
{'conv_2_Weights'}	{'conv_2'}	"Weights"	-0.055518
{'conv_2_Bias'}	{'conv_2'}	"Bias"	-0.00061177
{'conv_3_Weights'}	{'conv_3'}	"Weights"	-0.045942
{'conv_3_Bias'}	{'conv_3'}	"Bias"	-0.0013998
{'conv_4_Weights'}	{'conv_4'}	"Weights"	-0.045961
{'conv_4_Bias'}	{'conv_4'}	"Bias"	-0.001640
{'fc_1_Weights'}	{'fc_1'}	"Weights"	-0.051394
{'fc_1_Bias'}	{'fc_1'}	"Bias"	-0.00052319
{'fc_2_Weights'}	{'fc_2'}	"Weights"	-0.050100
{'fc_2_Bias'}	{'fc_2'}	"Bias"	-0.0017564
{'fc_3_Weights'}	{'fc_3'}	"Weights"	-0.050700
{'fc_3_Bias'}	{'fc_3'}	"Bias"	-0.029510
{'imageinput'}	{'imageinput'}	"Activations"	(0)
{'imageinput_normalization'}	{'imageinput'}	"Activations"	-139.34
{'conv_1'}	{'conv_1'}	"Activations"	-431.03
{'relu_1'}	{'relu_1'}	"Activations"	(0)
{'maxpool_1'}	{'maxpool_1'}	"Activations"	(0)
{'conv_2'}	{'conv_2'}	"Activations"	-166.47
{'relu_2'}	{'relu_2'}	"Activations"	(0)
{'maxpool_2'}	{'maxpool_2'}	"Activations"	(0)
{'conv_3'}	{'conv_3'}	"Activations"	-219.60
{'relu_3'}	{'relu_3'}	"Activations"	(0)
{'maxpool_3'}	{'maxpool_3'}	"Activations"	(0)
{'conv_4'}	{'conv_4'}	"Activations"	-245.37
{'relu_4'}	{'relu_4'}	"Activations"	(0)
{'maxpool_4'}	{'maxpool_4'}	"Activations"	(0)
{'fc_1'}	{'fc_1'}	"Activations"	-123.79
{'relu_5'}	{'relu_5'}	"Activations"	(0)
{'fc_2'}	{'fc_2'}	"Activations"	-16.55
{'relu_6'}	{'relu_6'}	"Activations"	(0)
{'fc_3'}	{'fc_3'}	"Activations"	-13.04
{'softmax'}	{'softmax'}	"Activations"	1.4971e-22
{'classoutput'}	{'classoutput'}	"Activations"	1.4971e-22

Set your target metric function and create a `dlquantizationOptions` object with the target metric function and the validation data set. In this example the target metric function calculates the Top-5 accuracy.

```
options = dlquantizationOptions('MetricFcn', {@(x)hComputeAccuracy(x,snet,validationData_reduced)});
```

---

**Note** If no custom metric function is specified, the default metric function will be used for validation. The default metric function uses at most 5 files from the validation datastore when the MATLAB simulation environment is selected. Custom metric functions do not have this restriction.

---

Use the `validate` function to quantize the learnable parameters in the convolution layers of the network. The `validate` function simulates the quantized network in MATLAB. The `validate`

function uses the metric function defined in the `dlquantizationOptions` object to compare the results of the single data type network object to the results of the quantized network object.

```
prediction = dlQuantObj.validate(validationData_reduced,options)

### Notice: (Layer 1) The layer 'imageinput' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: (Layer 2) The layer 'out_imageinput' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: conv_1>>maxpool_4 ...
### Notice: (Layer 1) The layer 'imageinput' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: (Layer 14) The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: conv_1>>maxpool_4 ... complete.
Compiling leg: fc_1>>fc_3 ...
### Notice: (Layer 1) The layer 'maxpool_4' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: (Layer 7) The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: fc_1>>fc_3 ... complete.
### Should not enter here. It means a component is unaccounted for in MATLAB Emulation.
### Notice: (Layer 1) The layer 'fc_3' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: (Layer 2) The layer 'softmax' with type 'nnet.cnn.layer.SoftmaxLayer' is implemented in software.
### Notice: (Layer 3) The layer 'classoutput' with type 'nnet.cnn.layer.ClassificationOutputLayer' is implemented in software.

prediction =
struct with fields:
    NumSamples: 5
    MetricResults: [1x1 struct]
```

Examine the `MetricResults.Result` field of the validation output to see the performance of the quantized network.

```
validateOut = prediction.MetricResults.Result
```

```
validateOut =
```

NetworkImplementation	MetricOutput
{'Floating-Point'}	1
{'Quantized'}	1

## Input Arguments

### **quantObj — Network to quantize**

`dlquantizer` object

`dlquantizer` object specifying the network to quantize.

### **valData — Data to use for validation of quantized network**

`imageDataStore` object | `augmentedImageDataStore` object | `pixelLabelImageDataStore` object

Data to use for validation of quantized network, specified as an `imageDataStore` object, an `augmentedImageDataStore` object, or a `pixelLabelImageDataStore` object.

### **quantOpts — Options for quantizing network**

`dlQuantizationOptions` object

Options for quantizing the network, specified as a `dlQuantizationOptions` object.

## Output Arguments

### **validationResults — Results of quantization of network**

struct

Results of quantization of the network, returned as a struct. The struct contains these fields.

- **NumSamples** – The number of sample inputs used to validate the network.
- **MetricResults** – Struct containing results of the metric function defined in the `dlquantizationOptions` object. When more than one metric function is specified in the `dlquantizationOptions` object, `MetricResults` is an array of structs.

`MetricResults` contains these fields.

Field	Description
<code>MetricFunction</code>	Function used to determine the performance of the quantized network. This function is specified in the <code>dlquantizationOptions</code> object.
<code>Result</code>	Table indicating the results of the metric function before and after quantization.  The first row in the table contains the information for the original, floating-point implementation. The second row contains the information for the quantized implementation. The output of the metric function is displayed in the <code>MetricOutput</code> column.

## See Also

### **Apps**

**Deep Network Quantizer**

### **Functions**

`calibrate` | `dlquantizer` | `dlquantizationOptions`

### **Topics**

“Quantization of Deep Neural Networks”

### **Introduced in R2020a**

# dlhdl.Simulator class

**Package:** `dlhdl`

Create an object that retrieve intermediate layer results and validate deep learning network prediction accuracy

## Description

Use the `dlhdl.Simulator` class to creates a simulator object that you use to retrieve intermediate layer results and verify the accuracy of prediction results for your deep learning network without the need for hardware targets.

## Creation

```
simObj=dlhdl.Simulator('Network', Network, 'ProcessorConfig', ProcessorConfig)
```

creates a `dlhdl.Simulator` object that you use to retrieve intermediate layer results and verify the accuracy of prediction results for your deep learning network without the need for hardware targets.

### Input Arguments

#### **Network — Network object**

`SeriesNetwork` object | `DAGNetwork` object | `yolov2ObjectDetector` object | `dlquantizer` object

Name of the deep learning network object.

**Example:** `'network'`, `net` creates a workflow object for the saved pretrained network `net`. To specify `net`, you can import any of the existing supported pretrained networks or use transfer learning to adapt the network to your issue. See “Supported Pretrained Networks”.

```
net = resnet18;
hPC = dlhdl.ProcessorConfig;
simObj = dlhdl.Simulator('Network', net, 'Bitstream', hPC);
```

**Example:** `'network'`, `dlquantizeObj` creates a workflow object for the quantized network object `dlquantizeObj`. To specify `dlquantizeObj`, you can import any of the supported existing pretrained networks and create an object by using the `dlquantizer` class. For information on supported networks, see “Supported Pretrained Networks”.

```
net = resnet18;
dlquantObj = dlquantizer(net, 'ExecutionEnvironment', 'FPGA');
dlquantObj.calibrate(imdsTrain);
simObj = dlhdl.Simulator('Network', dlquantObj, 'Bitstream', hPC);
```

#### **ProcessorConfig — `dlhdl.ProcessorConfig` object**

`hPC`

Deep learning processor configuration object, specified as a `dlhdl.ProcessorConfig` object

Example: `'ProcessorConfig', hPC`

```
hPC = dlhdl.ProcessorConfig;
simObj = dlhdl.Simulator('Network',resnet18,'ProcessorConfig',hPC);
```

## Methods

### Public Methods

activations	Retrieve intermediate layers results for dlhdl.Simulator object
predict	Retrieve prediction results for dlhdl.Simulator object

## Examples

### Create a `dlhdl.Simulator` Object for the ResNet-18 Network

- 1 Retrieve the deep learning processor configuration for the zcu102\_single bitstream and save to hPC.

```
hPC = dlhdl.ProcessorConfig('Bitstream','zcu102_single');
2 Create a dlhdl.Simulator object with resnet18 as the network and hPC as the
ProcessorConfig object.
```

```
simObj = dlhdl.Simulator('Network',resnet18,'ProcessorConfig',hPC);
```

### Create a `dlhdl.Simulator` Object for the resnet18 Network and int8 data type Deep Learning Processor Configuration

- 1 Create a deep learning processor configuration that has the int8 data type and save it to hPC.

```
hPC = dlhdl.ProcessorConfig;
hPC.ProcessorDataType = 'int8';
2 Create a dlquantizer object with ResNet-18 as the network and FPGA execution environment.
Calibrate the quantized network object by using the calibrate function.
```

```
net = resnet18;
dlQuantObj = dlquantizer(net,'ExecutionEnvironment','FPGA');
dlQuantObj.calibrate(imageDataStore);
3 Create a dlhdl.Simulator object with dlQuantObj as the network and hPC as the
ProcessorConfig object.
```

```
simObj = dlhdl.Simulator('Network',dlQuantObj,'ProcessorConfig',hPC);
```

## See Also

`dlhdl.Workflow` | `dlhdl.Target`

### Topics

“Prototype and Verify Deep Learning Networks Without Target Hardware”

### Introduced in R2021b

# activations

**Class:** `dlhdl.Simulator`

**Package:** `dlhdl`

Retrieve intermediate layers results for `dlhdl.Simulator` object

## Syntax

```
activations(image,layername)
result = activations(image,layername)
```

## Description

`activations(image,layername)` returns intermediate layer activation data results for the image data in `image` and the name of the layer specified in `layername`. The result size depends on the output size of the layer. The layer output size can be retrieved by using the `analyzeNetwork` function.

`result = activations(image,layername)` stores the intermediate layer activation data results for the image data in `image` and the name of the layer specified in `layername` in `result`. The result size depends on the output size of the layer. The layer output size can be retrieved by using the `analyzeNetwork` function.

## Input Arguments

### **image — Input image**

`m`-by-`n`-by-`k` numeric array

Input image, specified as a `m`-by-`n`-by-`k` numeric array. `m`, `n`, and `k` must match the dimensions of the deep learning network input image layer. For example, for the LogoNet network, resize the input images to a 227-by-227-by-3 array.

Data Types: `single`

### **layername — Name of layer in deployed deep learning network**

`"` (default) | character vector

Name of the layer in the deployed deep learning network whose results are retrieved for the image specified in `imIn`.

Retrieve activations for convolution and fully connected layers if they are not followed by a ReLU layer. When followed by a ReLU layer, retrieve the activations of the following ReLU layer. To retrieve the activations for a batch normalization layer after a convolution layer, first retrieve the activations for the convolution layer. Activations retrieval is not supported for the dropout layer.

Example: `'maxpool_3'`

## Output Arguments

### **result — Intermediate layer activation data**

array of `single`

Intermediate layer activation data, returned as an array of singles. The array size depends on the layer output size. For example, for the ResNet-18 network `pool1` layer, the size of the returned result array is 56-by-56-by-64.

## Examples

### **Prototype and Verify Deep Learning Networks Without Target Hardware**

Rapidly prototype your custom deep learning network and bitstream by visualizing intermediate layer activation results and verifying prediction accuracy without target hardware by emulating the network and bitstream. To emulate the network and bitstream, create a `dlhdl.Simulator` object. Use the `dlhdl.Simulator` object to:

- Retrieve intermediate layer results by using the `activations` function.
- Verify prediction accuracy by using the `predict` function.

In this example, retrieve the intermediate layer activation results and verify the prediction accuracy for the ResNet-18 network and deep learning processor configuration for the `zcu102_single` bitstream.

### **Prerequisites**

- Deep Learning Toolbox™
- Deep Learning HDL Toolbox™
- Deep Learning Toolbox Model for ResNet-18 Network
- Deep Learning HDL Toolbox Support Package for Xilinx FPGA and SoC Devices
- Image Processing Toolbox™
- MATLAB Coder Interface for Deep learning Libraries™

### **Load Pretrained SeriesNetwork**

To load the pretrained network ResNet-18, enter:

```
snet = resnet18;
```

To view the layers of the pretrained network, enter:

```
analyzeNetwork(snet);
```

The first layer, the image input layer, requires input images of size 224-by-224-by-3, where 3 is the number of color channels.

```
inputSize = snet.Layers(1).InputSize;
```

## Define Training and Validation Data Sets

This example uses the MathWorks MerchData data set. This is a small data set containing 75 images of MathWorks merchandise, belonging to five different classes (cap, cube, playing cards, screwdriver, and torch).

```
curDir = pwd;
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[imdsTrain,imdsValidation] = splitEachLabel(imds,0.7,'randomized');
```

## Replace Final Layers

The fully connected layer and the classification layer of the pretrained network `net` are configured for 1000 classes. These two layers `fc1000` and `ClassificationLayer_predictions` in ResNet-18 contain information on how to combine the features that the network extracts into class probabilities and predicted labels. These layers must be fine-tuned for the new classification problem. Extract all the layers, except the last two layers, from the pretrained network.

```
lgraph = layerGraph(snet)

lgraph =
  LayerGraph with properties:

    Layers: [71x1 nnet.cnn.layer.Layer]
    Connections: [78x2 table]
    InputNames: {'data'}
    OutputNames: {'ClassificationLayer_predictions'}

numClasses = numel(categories(imdsTrain.Labels))
numClasses = 5

newLearnableLayer = fullyConnectedLayer(numClasses, ...
    'Name','new_fc', ...
    'WeightLearnRateFactor',10, ...
    'BiasLearnRateFactor',10);
lgraph = replaceLayer(lgraph,'fc1000',newLearnableLayer);
newClassLayer = classificationLayer('Name','new_classoutput');
lgraph = replaceLayer(lgraph,'ClassificationLayer_predictions',newClassLayer);
```

## Train Network

The network requires input images of size 224-by-224-by-3, but the images in the image datastores have different sizes. Use an augmented image datastore to automatically resize the training images. Specify additional augmentation operations to perform on the training images, such as randomly flipping the training images along the vertical axis and randomly translating them up to 30 pixels horizontally and vertically. Data augmentation helps prevent the network from overfitting and memorizing the exact details of the training images.

```
pixelRange = [-30 30];
imageAugmenter = imageDataAugmenter( ...
    'RandXReflection',true, ...
    'RandXTranslation',pixelRange, ...
    'RandYTranslation',pixelRange);
```

To automatically resize the validation images without performing further data augmentation, use an augmented image datastore without specifying any additional preprocessing operations.


```
augimdsTrain = augmentedImageDatastore(inputSize(1:2),imdsTrain, ...
'DataAugmentation',imageAugmenter);
augimdsValidation = augmentedImageDatastore(inputSize(1:2),imdsValidation);
```

Specify the training options. For transfer learning, keep the features from the early layers of the pretrained network (the transferred layer weights). To slow down learning in the transferred layers, set the initial learning rate to a small value. Specify the mini-batch size and validation data. The software validates the network for every **ValidationFrequency** iteration during training.

```
options = trainingOptions('sgdm', ...
'MiniBatchSize',10, ...
'MaxEpochs',6, ...
'InitialLearnRate',1e-4, ...
'Shuffle','every-epoch', ...
'ValidationData',augimdsValidation, ...
'ValidationFrequency',3, ...
'Verbose',false, ...
'Plots','training-progress');
```

Train the network that consists of the transferred and new layers. By default, **trainNetwork** uses a GPU if one is available (requires Parallel Computing Toolbox™ and a supported GPU device. See “GPU Support by Release” (Parallel Computing Toolbox)). Otherwise, the network uses a CPU (requires MATLAB Coder Interface for Deep learning Libraries™). You can also specify the execution environment by using the '**ExecutionEnvironment**' name-value argument of **trainingOptions**.

```
netTransfer = trainNetwork(augimdsTrain,lgraph,options);
```



## Retrieve Deep Learning Processor Configuration

Use the `dlhdl.ProcessorConfig` object to retrieve the deep learning processor configuration for the `zcu102_single` bitstream.

```
hPC = dlhdl.ProcessorConfig('Bitstream','zcu102_single');
```

## Create Simulator Object

Create a `dlhdl.Simulator` object with ResNet-18 as the network and `hPC` as the `ProcessorConfig` object.

```
simObj = dlhdl.Simulator('Network',netTransfer,'ProcessorConfig',hPC);

### Optimizing series network: Fused 'nnet.cnn.layer.BatchNormalizationLayer' into 'nnet.cnn.layer...
### Notice: The layer 'data' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'out_data' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: conv1>>pool1 ...
### Notice: The layer 'data' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: conv1>>pool1 ... complete.
Compiling leg: res2a_branch2a>>res2a_branch2b ...
### Notice: The layer 'pool1' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res2a_branch2a>>res2a_branch2b ... complete.
Compiling leg: res2b_branch2a>>res2b_branch2b ...
### Notice: The layer 'res2a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res2b_branch2a>>res2b_branch2b ... complete.
Compiling leg: res3a_branch1 ...
### Notice: The layer 'res2b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res3a_branch1 ... complete.
Compiling leg: res3a_branch2a>>res3a_branch2b ...
### Notice: The layer 'res2b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res3a_branch2a>>res3a_branch2b ... complete.
Compiling leg: res3b_branch2a>>res3b_branch2b ...
### Notice: The layer 'res3a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res3b_branch2a>>res3b_branch2b ... complete.
Compiling leg: res4a_branch1 ...
### Notice: The layer 'res3b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res4a_branch1 ... complete.
Compiling leg: res4a_branch2a>>res4a_branch2b ...
### Notice: The layer 'res3b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res4a_branch2a>>res4a_branch2b ... complete.
Compiling leg: res4b_branch2a>>res4b_branch2b ...
### Notice: The layer 'res4a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res4b_branch2a>>res4b_branch2b ... complete.
Compiling leg: res5a_branch1 ...
### Notice: The layer 'res4b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software
Compiling leg: res5a_branch1 ... complete.
Compiling leg: res5a_branch2a>>res5a_branch2b ...
```

```

### Notice: The layer 'res4b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res5a_branch2a>>res5a_branch2b ... complete.
Compiling leg: res5b_branch2a>>res5b_branch2b ...
### Notice: The layer 'res5a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res5b_branch2a>>res5b_branch2b ... complete.
Compiling leg: pool5 ...
### Notice: The layer 'res5b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: pool5 ... complete.
Compiling leg: new_fc ...
### Notice: The layer 'pool5' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: new_fc ... complete.
### Should not enter here. It means a component is unaccounted for in MATLAB Emulation.
### Notice: The layer 'new_fc' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'prob' with type 'nnet.cnn.layer.SoftmaxLayer' is implemented in software.
### Notice: The layer 'new_classoutput' with type 'nnet.cnn.layer.ClassificationOutputLayer' is implemented in software.

```

## Load Image for Prediction and Intermediate Layer Activation Results

Load the example image. Save it's size for future use.

```

imgFile = fullfile(pwd,'MerchData','MathWorks Cube','Mathworks_cube_0.jpg');
inputImg = imresize(imread(imgFile),inputSize(1:2));
imshow(inputImg)

```



## Show Activations of First Maxpool Layer

Investigate features by observing which areas in the convolution layers activate on an image. Compare that image to the corresponding areas in the original images. Each layer of a convolutional neural network consists of many 2-D arrays called *channels*. Pass the image through the network and examine the output activations of the pool1 layer.


```
act1 = simObj.activations(single(inputImg), 'pool1');
```

The activations are returned as a 3-D array, with the third dimension indexing the channel on the pool1 layer. To show these activations by using the `imtile` function, reshape the array to 4-D. The third dimension in the input to `imtile` represents the image color. Set the third dimension to have size 1 because the activations do not have color. The fourth dimension indexes the channel.

```
sz = size(act1);
act1 = reshape(act1,[sz(1) sz(2) 1 sz(3)]);
```

Display the activations. Each activation can take any value, so normalize the output by using the `mat2gray`. All activations are scaled so that the minimum activation is 0 and the maximum activation is 1. Display the 64 images on an 8-by-8 grid, one for each channel in the layer.

```
I = imtile(mat2gray(act1), 'GridSize',[8 8]);
imshow(I)
```




## Find Strongest Activation Channel

Find the strongest channels by programmatically investigating channels with large activations. Find the channel that has the largest activation by using the `max` function, resize the channel output, and display the activations.

```
[maxValue,maxValueIndex] = max(max(max(act1)));
act1chMax = act1(:,:, :, maxValueIndex);
act1chMax = mat2gray(act1chMax);
act1chMax = imresize(act1chMax,inputSize(1:2));

I = imtile({inputImg,act1chMax});
imshow(I)
```



Compare the strongest activation channel image to the original image. This channel activates on edges. It activates positively on light left/dark right edges and negatively on dark left/light right edges.

## Verify Prediction Results

Verify and display the prediction results of the `dlhdl.Simulator` object by using the `predict` function.

```
prediction = sim0bj.predict(single(inputImg));
[val, idx] = max(prediction);
netTransfer.Layers(end).ClassNames{idx}

ans =
'MathWorks Cube'
```

## See Also

`dlhdl.Simulator` | `predict`

**Topics**

“Prototype and Verify Deep Learning Networks Without Target Hardware”

**Introduced in R2021b**

# predict

**Class:** `dlhdl.Simulator`

**Package:** `dlhdl`

Retrieve prediction results for `dlhdl.Simulator` object

## Syntax

```
prediction = predict(image)
```

## Description

`prediction = predict(image)` returns a table containing the percentage prediction values for the input image specified by `image`.

## Input Arguments

### `image` — Input image

*m*-by-*n*-by-*k* numeric array

Input image, specified as a *m*-by-*n*-by-*k* numeric array. *m*, *n*, and *k* must match the dimensions of the deep learning network input image layer. For example, for the LogoNet network, resize the input images to a 227-by-227-by-3 array.

Data Types: `single`

## Output Arguments

### `prediction` — Network prediction for input image

table

Deep learning network prediction for the input image specified by `image`.

## Examples

### Prototype and Verify Deep Learning Networks Without Target Hardware

Rapidly prototype your custom deep learning network and bitstream by visualizing intermediate layer activation results and verifying prediction accuracy without target hardware by emulating the network and bitstream. To emulate the network and bitstream, create a `dlhdl.Simulator` object. Use the `dlhdl.Simulator` object to:

- Retrieve intermediate layer results by using the `activations` function.
- Verify prediction accuracy by using the `predict` function.

In this example, retrieve the intermediate layer activation results and verify the prediction accuracy for the ResNet-18 network and deep learning processor configuration for the `zcu102_single` bitstream.

## Prerequisites

- Deep Learning Toolbox™
- Deep Learning HDL Toolbox™
- Deep Learning Toolbox Model for ResNet-18 Network
- Deep Learning HDL Toolbox Support Package for Xilinx FPGA and SoC Devices
- Image Processing Toolbox™
- MATLAB Coder Interface for Deep learning Libraries™

## Load Pretrained SeriesNetwork

To load the pretrained network ResNet-18, enter:

```
snet = resnet18;
```

To view the layers of the pretrained network, enter:

```
analyzeNetwork(snet);
```

The first layer, the image input layer, requires input images of size 224-by-224-by-3, where 3 is the number of color channels.

```
inputSize = snet.Layers(1).InputSize;
```

## Define Training and Validation Data Sets

This example uses the MathWorks MerchData data set. This is a small data set containing 75 images of MathWorks merchandise, belonging to five different classes (cap, cube, playing cards, screwdriver, and torch).

```
curDir = pwd;
unzip('MerchData.zip');
imds = imageDatastore('MerchData', ...
    'IncludeSubfolders',true, ...
    'LabelSource','foldernames');
[imdsTrain,imdsValidation] = splitEachLabel(imds,0.7,'randomized');
```

## Replace Final Layers

The fully connected layer and the classification layer of the pretrained network `net` are configured for 1000 classes. These two layers `fc1000` and `ClassificationLayer_predictions` in ResNet-18 contain information on how to combine the features that the network extracts into class probabilities and predicted labels. These layers must be fine-tuned for the new classification problem. Extract all the layers, except the last two layers, from the pretrained network.

```
lgraph = layerGraph(snet)
lgraph =
  LayerGraph with properties:
    Layers: [71x1 nnet.cnn.layer.Layer]
    Connections: [78x2 table]
    InputNames: {'data'}
    OutputNames: {'ClassificationLayer_predictions'}
```

```

numClasses = numel(categories(imdsTrain.Labels))

numClasses = 5

newLearnableLayer = fullyConnectedLayer(numClasses, ...
    'Name','new_fc', ...
    'WeightLearnRateFactor',10, ...
    'BiasLearnRateFactor',10);
lgraph = replaceLayer(lgraph,'fc1000',newLearnableLayer);
newClassLayer = classificationLayer('Name','new_classoutput');
lgraph = replaceLayer(lgraph,'ClassificationLayer_predictions',newClassLayer);

```

## Train Network

The network requires input images of size 224-by-224-by-3, but the images in the image datastores have different sizes. Use an augmented image datastore to automatically resize the training images. Specify additional augmentation operations to perform on the training images, such as randomly flipping the training images along the vertical axis and randomly translating them up to 30 pixels horizontally and vertically. Data augmentation helps prevent the network from overfitting and memorizing the exact details of the training images.

```

pixelRange = [-30 30];
imageAugmenter = imageDataAugmenter( ...
    'RandXReflection',true, ...
    'RandXTranslation',pixelRange, ...
    'RandYTranslation',pixelRange);

```

To automatically resize the validation images without performing further data augmentation, use an augmented image datastore without specifying any additional preprocessing operations.

```

augimdsTrain = augmentedImageDatastore(inputSize(1:2),imdsTrain, ...
    'DataAugmentation',imageAugmenter);
augimdsValidation = augmentedImageDatastore(inputSize(1:2),imdsValidation);

```

Specify the training options. For transfer learning, keep the features from the early layers of the pretrained network (the transferred layer weights). To slow down learning in the transferred layers, set the initial learning rate to a small value. Specify the mini-batch size and validation data. The software validates the network for every `ValidationFrequency` iteration during training.


```

options = trainingOptions('sgdm', ...
    'MiniBatchSize',10, ...
    'MaxEpochs',6, ...
    'InitialLearnRate',1e-4, ...
    'Shuffle','every-epoch', ...
    'ValidationData',augimdsValidation, ...
    'ValidationFrequency',3, ...
    'Verbose',false, ...
    'Plots','training-progress');

```

Train the network that consists of the transferred and new layers. By default, `trainNetwork` uses a GPU if one is available (requires Parallel Computing Toolbox™ and a supported GPU device. See “GPU Support by Release” (Parallel Computing Toolbox)). Otherwise, the network uses a CPU (requires MATLAB Coder Interface for Deep learning Libraries™). You can also specify the execution environment by using the `'ExecutionEnvironment'` name-value argument of `trainingOptions`.

```
netTransfer = trainNetwork(augimdsTrain,lgraph,options);
```



## Retrieve Deep Learning Processor Configuration

Use the `dlhdl.ProcessorConfig` object to retrieve the deep learning processor configuration for the `zcu102_single` bitstream.

```
hPC = dlhdl.ProcessorConfig('Bitstream','zcu102_single');
```

## Create Simulator Object

Create a `dlhdl.Simulator` object with ResNet-18 as the network and `hPC` as the `ProcessorConfig` object.

```
simObj = dlhdl.Simulator('Network',netTransfer,'ProcessorConfig',hPC);
```

```
### Optimizing series network: Fused 'nnet.cnn.layer.BatchNormalizationLayer' into 'nnet.cnn.layer'
### Notice: The layer 'data' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'out_data' with type 'nnet.cnn.layer.RegistrationOutputLayer' is implemented in software
Compiling leg: conv1>>pool1 ...
### Notice: The layer 'data' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegistrationOutputLayer' is implemented in software
Compiling leg: conv1>>pool1 ... complete.
Compiling leg: res2a_branch2a>>res2a_branch2b ...
### Notice: The layer 'pool1' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegistrationOutputLayer' is implemented in software
Compiling leg: res2a_branch2a>>res2a_branch2b ... complete.
Compiling leg: res2b_branch2a>>res2b_branch2b ...
### Notice: The layer 'res2a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegistrationOutputLayer' is implemented in software
Compiling leg: res2b_branch2a>>res2b_branch2b ... complete.
Compiling leg: res3a_branch1 ...
### Notice: The layer 'res2b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegistrationOutputLayer' is implemented in software
```

```

Compiling leg: res3a_branch1 ... complete.
Compiling leg: res3a_branch2a>>res3a_branch2b ...
### Notice: The layer 'res2b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res3a_branch2a>>res3a_branch2b ... complete.
Compiling leg: res3b_branch2a>>res3b_branch2b ...
### Notice: The layer 'res3a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res3b_branch2a>>res3b_branch2b ... complete.
Compiling leg: res4a_branch1 ...
### Notice: The layer 'res3b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res4a_branch1 ... complete.
Compiling leg: res4a_branch2a>>res4a_branch2b ...
### Notice: The layer 'res3b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res4a_branch2a>>res4a_branch2b ... complete.
Compiling leg: res4b_branch2a>>res4b_branch2b ...
### Notice: The layer 'res4a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res4b_branch2a>>res4b_branch2b ... complete.
Compiling leg: res5a_branch1 ...
### Notice: The layer 'res4b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res5a_branch1 ... complete.
Compiling leg: res5a_branch2a>>res5a_branch2b ...
### Notice: The layer 'res4b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res5a_branch2a>>res5a_branch2b ... complete.
Compiling leg: res5b_branch2a>>res5b_branch2b ...
### Notice: The layer 'res5a_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: res5b_branch2a>>res5b_branch2b ... complete.
Compiling leg: pool5 ...
### Notice: The layer 'res5b_relu' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: pool5 ... complete.
Compiling leg: new_fc ...
### Notice: The layer 'pool5' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'output' with type 'nnet.cnn.layer.RegressionOutputLayer' is implemented in software.
Compiling leg: new_fc ... complete.
### Should not enter here. It means a component is unaccounted for in MATLAB Emulation.
### Notice: The layer 'new_fc' with type 'nnet.cnn.layer.ImageInputLayer' is implemented in software.
### Notice: The layer 'prob' with type 'nnet.cnn.layer.SoftmaxLayer' is implemented in software.
### Notice: The layer 'new_classoutput' with type 'nnet.cnn.layer.ClassificationOutputLayer' is implemented in software.

```

## Load Image for Prediction and Intermediate Layer Activation Results

Load the example image. Save its size for future use.

```

imgFile = fullfile(pwd,'MerchData','MathWorks Cube','Mathworks cube_0.jpg');
inputImg = imresize(imread(imgFile),inputSize(1:2));
imshow(inputImg)

```



### Show Activations of First Maxpool Layer

Investigate features by observing which areas in the convolution layers activate on an image. Compare that image to the corresponding areas in the original images. Each layer of a convolutional neural network consists of many 2-D arrays called *channels*. Pass the image through the network and examine the output activations of the pool1 layer.


```
act1 = sim0bj.activations(single(inputImg), 'pool1');
```

The activations are returned as a 3-D array, with the third dimension indexing the channel on the pool1 layer. To show these activations by using the `imtile` function, reshape the array to 4-D. The third dimension in the input to `imtile` represents the image color. Set the third dimension to have size 1 because the activations do not have color. The fourth dimension indexes the channel.

```
sz = size(act1);
act1 = reshape(act1,[sz(1) sz(2) 1 sz(3)]);
```

Display the activations. Each activation can take any value, so normalize the output by using the `mat2gray`. All activations are scaled so that the minimum activation is 0 and the maximum activation is 1. Display the 64 images on an 8-by-8 grid, one for each channel in the layer.

```
I = imtile(mat2gray(act1), 'GridSize', [8 8]);
imshow(I)
```




### Find Strongest Activation Channel

Find the strongest channels by programmatically investigating channels with large activations. Find the channel that has the largest activation by using the `max` function, resize the channel output, and display the activations.

```
[maxValue,maxValueIndex] = max(max(max(act1)));
act1chMax = act1(:,:,:,:maxValueIndex);
act1chMax = mat2gray(act1chMax);
act1chMax = imresize(act1chMax,inputSize(1:2));

I = imtile({inputImg,act1chMax});
imshow(I)
```



Compare the strongest activation channel image to the original image. This channel activates on edges. It activates positively on light left/dark right edges and negatively on dark left/light right edges.

### Verify Prediction Results

Verify and display the prediction results of the `dlhdl.Simulator` object by using the `predict` function.

```
prediction = simObj.predict(single(inputImg));
[val, idx] = max(prediction);
netTransfer.Layers(end).ClassNames{idx}

ans =
'MathWorks Cube'
```

### See Also

[activations](#) | `dlhdl.Simulator`

### Topics

["Prototype and Verify Deep Learning Networks Without Target Hardware"](#)

### Introduced in R2021b

# hdlcoder.ReferenceDesign class

**Package:** hdlcoder

Reference design registration object that describes SoC reference design

## Description

`refdesign = hdlcoder.ReferenceDesign('SynthesisTool', toolname)` creates a reference design object that you use to register a custom reference design for an SoC platform.

To specify the characteristics of your reference design, set the properties of the reference design object.

Use a reference design tool version that is compatible with the supported tool version. If you choose a different tool version, it is possible that HDL Coder is unable to create the reference design project for IP core integration.

## Construction

`refdesign = hdlcoder.ReferenceDesign('SynthesisTool', toolname)` creates a reference design object that you use to register a custom reference design for an SoC platform.

### Input Arguments

#### **toolname — Synthesis tool name**

Xilinx Vivado (default) | Altera Quartus II | Xilinx ISE | Xilinx Vivado

Synthesis tool name, specified as a character vector.

Example: 'Altera Quartus II'

## Properties

#### **ReferenceDesignName — Reference design name**

'' (default) | character vector

Reference design name, specified as a character vector. In the HDL Workflow Advisor, this name appears in the **Reference design** drop-down list.

Example: 'Default system (Vivado 2015.4)'

#### **BoardName — Board name**

'' (default) | character vector

Board associated with this reference design, specified as a character vector.

Example: 'Enclustra Mars ZX3 with PM3 base board'

#### **SupportedToolVersion — Supported tool version**

{ } (default) | cell array of character vectors

One or more tool versions that work with this reference design, specified as a cell array of character vectors.

Example: {'2015.4'}

Example: {'13.7', '14.0'}

**CustomConstraints — Design constraint file (optional)**

{ } (default) | cell array of character vectors

One or more design constraint files, specified as a cell array of character vectors. This property is optional.

Example: {'MarsZX3\_PM3.xdc'}

Example: {'MyDesign.qsf'}

**CustomFiles — Relative path to required file or folder (optional)**

{ } (default) | cell array of character vectors

One or more relative paths to files or folders that the reference design requires, specified as a cell array of character vectors. This property is optional.

Examples of required files or folders:

- Existing IP core used in the reference design.

For example, if the IP core, *my\_ip\_core*, is in the reference design folder, set **CustomFiles** to {'*my\_ip\_core*'}

- PS7 definition XML file.

For example, to include a PS7 definition XML file, *ps7\_system\_prj.xml*, in a folder, *data*, set **CustomFiles** to {fullfile('data', 'ps7\_system\_prj.xml')}

- Folder containing existing IP cores used in the reference design. HDL Coder supports only a specific IP core folder name for each synthesis tool:

- For Altera Qsys, IP core files must be in a folder named *ip*. Set **CustomFiles** to {'*ip*'}.
- For Xilinx Vivado, IP core files, or a zip file containing the IP core files, must be in a folder named *ipcore*. Set **CustomFiles** to {'*ipcore*'}.
- For Xilinx EDK, IP core files must be in a folder named *pcores*. Set **CustomFiles** to {'*pcores*'}.

---

**Note** To add IP modules to the reference design, it is recommended to create an IP repository folder that contains these IP modules, and then use the **addIPRepository** method.

---

Example: {'*my\_ip\_core*'}

Example: {fullfile('data', 'ps7\_system\_prj.xml')}

Example: {'*ip*'}

Example: {'*ipcore*'}

Example: {'*pcores*'}

**DeviceTreeName — Linux device tree name**

character vector

Specify the device tree file name. For an example that shows how to use different device tree file names when mapping the DUT ports to different AXI4-Stream channels, see [Dynamically Create Master Only or Slave Only or Both Master and Slave Reference Designs \(HDL Coder\)](#).

Example: 'devicetree\_axistream\_iio.dtb'

**AddJTAGMATLABasAXIMasterParameter — Control visibility of JTAG as AXI Master IP**  
true (default) | false | logical data type

Specify whether you want the parameter **Insert JTAG MATLAB as AXI Master (HDL Verifier Required)** to be displayed in the **Set Target Reference Design** task of the HDL Workflow Advisor. By default, this property value is set to **true**. The parameter is displayed in the **Set Target Reference Design** task. After you enable this property, to specify whether you want the code generator to insert the JTAG MATLAB as AXI Master IP, use the **JTAGMATLABasAXIMasterDefaultValue** property. If you do not want the parameter to be displayed, set the property value to **false**.

This property is optional.

Example: 'false'

**JTAGMATLABasAXIMasterDefaultValue — Specify whether to insert MATLAB as AXI Master IP**

'off' (default) | 'on' | character vector

Specify whether you want the code generator to insert the JTAG MATLAB as AXI Master IP. The values that you specify are the choices for the **Insert JTAG MATLAB as AXI Master (HDL Verifier Required)** drop-down in the **Set Target Reference Design** task of the HDL Workflow Advisor. To specify insertion of the JTAG as AXI Master automatically, before you set this property to **on**, set the **AddJTAGMATLABasAXIMasterParameter** property to **true**.

This property is optional.

Example: 'on'

**IPCacheZipFile — IP cache file to include in the project**

'' (default) | 'ipcache.zip' | character vector

Specify the IP cache zip file to include in your project. When you run the **IP Core Generation** workflow in the HDL Workflow Advisor, the code generator extracts this file in the **Create Project** task. The **Build FPGA Bitstream** task reuses the IP cache, which accelerates reference design synthesis.

This property is optional.

Example: 'ipcache.zip'

**ReportTimingFailure — Report timing failures as warnings or errors**

'hdlcoder.ReportTiming.Warning' (default) | 'hdlcoder.ReportTiming.Error'

Specify whether you want the code generator to report timing failures in the **Build FPGA Bitstream** task as warnings or errors. When you run the **IP Core Generation** workflow in the HDL Workflow Advisor, by default, the code generator reports any timing failures as error. If you have implemented

the custom logic to resolve timing failures, you can specify these failures to be reported as warning instead of error. To learn more, see “Resolve Timing Failures in IP Core Generation and Simulink Real-Time FPGA I/O Workflows” (HDL Coder).

This property is optional.

Example: 'hdlcoder.ReportTiming.Warning'

**HasProcessingSystem — Specify if reference design has existing Processing System (PS)**  
true (default) | false | logical data type

Specify if the reference design has an existing PS.

Example: 'false'

**GenerateIPCoreDeviceTreeNodes — Enable generation of device tree nodes for HDL Coder IP core**  
false (default) | true | logical data type

Enable generation of device tree nodes for an HDL Coder generated IP core, and then insert the nodes into the device tree. To enable the generation of device tree nodes for the IP core, `HasProcessingSystem` must be set to `true`.

Do not enable this property if you do not need any additional device tree nodes to be inserted into the registered device tree for the generated IP core.

Example: 'true'

**ResourcesUsed — Board resources used by reference design**  
structure

Board resources used by reference design, returned as a structure with the fields:

**LogicElements — Reference design resources utilized by FPGA lookup tables (LUTs)**  
0 (default)

Reference design resources utilized by FPGA lookup tables (LUTs), specified as a number.

Example: `hRD.ResourcesUsed.LogicElements = 100`

**DSP — Reference design resources utilized by FPGA DSP slices**  
0 (default)

Reference design resources utilized by FPGA DSP slices, specified as a number.

Example: `hRD.ResourcesUsed.DSP = 3`

**RAM — Reference design resources utilized by FPGA board RAM resources**  
0 (default)

Reference design resources utilized by FPGA board RAM resources, specified as a number.

Example: `hRD.ResourcesUsed.RAM = 32000`

## Methods

registerDeepLearningMemoryAddressSpace	Add memory address space to reference design
registerDeepLearningTargetInterface	Add and register a target interface
validateReferenceDesignForDeepLearning	Checks property values in reference design object

## See Also

`hdlcoder.Board`

## Topics

- “Define Custom Board and Reference Design for Zynq Workflow” (HDL Coder)
- “Define Custom Board and Reference Design for Intel SoC Workflow” (HDL Coder)
- “Register a Custom Board” (HDL Coder)
- “Register a Custom Reference Design” (HDL Coder)
- “Define Custom Parameters and Callback Functions for Custom Reference Design” (HDL Coder)
- “Board and Reference Design Registration System” (HDL Coder)

## Introduced in R2015a

# registerDeepLearningMemoryAddressSpace

**Class:** `hdlcoder.ReferenceDesign`

**Package:** `hdlcoder`

Add memory address space to reference design

## Syntax

```
registerDeepLearningMemoryAddressSpace(baseAddr,addrRange)
```

## Description

`registerDeepLearningMemoryAddressSpace(baseAddr,addrRange)` registers memory address space accessible by the deep learning processor IP core to your reference design. The deep learning processor IP core uses this registered memory space to store the inputs to the deep learning network, network weights, and intermediate computations performed by the deep learning processor.

## Input Arguments

### **baseAddr — Base address of the deep learning memory address space**

0x0 (default) | `uint32`

Base address of the deep learning memory address space, in bytes as `uint32`.

Example: 0x80000000

### **addrRange — Address range of the deep learning memory address space**

0x0 (default) | `uint32`

Address range of the deep learning memory address space, in bytes as `uint32`.

Example: 0x40000000

## Requirements

The registered memory address space must be accessible by the AXI4 Master interfaces in your reference design.

## Tips

- A minimum of 32 MB of memory address space is required to run any deep learning network. To run a variety of deep learning networks, it is recommended to register a minimum of 512 MB of memory address space.
- The `compile` method of the `dlhdl.Workflow` object generates the memory address space for a deep learning network. See `compile`. Determine the memory address space for your deep learning network by using the `compile` method of the `dlhdl.Workflow` object.

## See Also

`registerDeepLearningTargetInterface` | `validateReferenceDesignForDeepLearning`

**Introduced in R2021b**

# registerDeepLearningTargetInterface

**Class:** `hdlcoder.ReferenceDesign`

**Package:** `hdlcoder`

Add and register a target interface

## Syntax

```
registerDeepLearningTargetInterface(interfaceType)
```

## Description

`registerDeepLearningTargetInterface(interfaceType)` registers a target interface to an `hdlcoder.ReferenceDesign` object. Use the registered target interface to interact with the generated deep learning processor IP core by using MATLAB.

## Input Arguments

### **interfaceType — Target interface type**

'JTAG' (default) | 'JTAG' | string | character vector

Target interface type, specified as a string or character vector.

Example: 'JTAG'

## Limitations

To register a JTAG target interface to your reference design, your reference design must meet these requirements.

- The reference design must include JTAG MATLAB as AXI Master IP.
- The JTAG MATLAB as AXI Master IP must be one of the masters to the AXI4-Slave interface in the reference design.
- The JTAG MATLAB as AXI Master IP must have access to the same memory as the AXI4-Master interfaces in the reference design.

## See Also

`registerDeepLearningMemoryAddressSpace` | `validateReferenceDesignForDeepLearning`

## Introduced in R2021b

# validateReferenceDesignForDeepLearning

**Class:** `hdlcoder.ReferenceDesign`

**Package:** `hdlcoder`

Checks property values in reference design object

## Syntax

```
validateReferenceDesignForDeepLearning
```

## Description

`validateReferenceDesignForDeepLearning` checks that the `hdlcoder.ReferenceDesign` object is compatible with the deep learning processor IP core generation workflow.

## Reference Design Requirements

The `validateReferenceDesign` method checks your `hdlcoder.ReferenceDesign` object for these requirements:

- Your reference design must have an AXI4 Slave interface. You use this interface to access registers in the deep learning processor IP core.
- Your reference design must have three AXI4 Master interfaces with `InterfaceID` values of "AXI4 Master Activation Data", "AXI4 Master Weight Data", and "AXI4 Master Debug". The deep learning processor IP core uses these AXI4 Master interfaces to access memory for network storage and intermediate calculations.
- Your reference design must have a registered memory address space. Use the `registerDeepLearningMemoryAddressSpace` to register a memory address space. To run a variety of deep learning networks on your deep learning processor IP core, it is recommended to register a minimum of 512 MB of memory address space.

## Tips

Register a target interface for your reference design by using the `registerDeepLearningTargetInterface` method. You can use the registered target interface to run your deep learning network on the generated deep learning processor IP core by using MATLAB and a `dlhdl.Workflow` object.

## See Also

`registerDeepLearningMemoryAddressSpace` | `registerDeepLearningTargetInterface`

**Introduced in R2021b**

