



EVM-10L120

**XRS10L120 QFN
Evaluation Board User Manual**

Jan 16, 2008

**SERIAL ATA II PORT MULTIPLIER
XRS10L120 QFN
Evaluation Board User Manual**



XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

1.0 OVERVIEW	3
Figure 1.0 XRS10L120 Block Diagram.....	3
2.0 EVALUATION BOARD ARCHITECTURE.....	4
Figure 2.0 XRS10L120 Evaluation Board Rev 1.0.....	4
Figure 2.1 XRS10L120 photo.....	5
Figure 2.2 XRS10L120 Evaluation Kit.....	5
2.1 FUNCTIONALITY AND CONTROL.....	6
2.2 XRS10L120 REFERENCE CLOCK.....	6
2.3 MDIO BUS INTERFACE	7
Figure 2.3 MDIO Bus Interface	7
3.0 SETTING UP THE HARDWARE XRS10L120 EVALUATION BOARD.....	8
3.1 SETTING UP THE XRS10L120 EVALUATION BOARD FOR SERIAL ATA	8
PORT MULTIPLIER TESTING	8
Figure 3.0 Serial ATA Port Multiplier Test Setup with two Hard Disk drives	8
3.2 SETTING UP THE XRS10L120 EVALUATION BOARD FOR SATA PROTOCOL TESTING.....	9
Figure 3.1 Protocol Testing with SAS/SATA Analyzer Test Setup.....	9
4.0 INSTALLING THE XRS10L120/ XRS10L140 EVALUATION GUI	10
4.1 STARTING THE EVALUATION SOFTWARE.....	10
APPENDIX A. XRS10L120 EVALUATION BOARD SCHEMATICS	14
APPENDIX B. XRS10L120/240 EVAL BOARD LAYOUT FOR ALL LAYERS.....	21

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

1.0 OVERVIEW

BLOCK DIAGRAM OF XRS10L120




Figure 1.0 XRS10L120 Block Diagram

This is evaluation board manual is intended to help the user become familiarized to operate the XRS10L120 Evaluation Demo Board and run Serial ATA protocol with minimum effort.

Requirements:

1. XRS10L120 Evaluation Demo board
2. 5.0V AC adapter (or PC floppy drive power supply, or Lab power supply)
3. XRS10L120 data sheet
4. One PM-Aware SATA host port (to support multiple drives) or any legacy SATA host port (only drive on device port 0 can be recognized)
5. One or more Serial ATA hard drive(s) with SATA cables

Optional:

1. A Windows-XP/Window-2000 PC with a USB port (needed to change DUT settings from default)
2. XRS10L120 supplied GUI and USB driver to be installed on the PC (using Win98, 2000, or XP)
3. SAS/SATA Protocol Analyzer test equipment with SATA cables


XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

2.0 EVALUATION BOARD ARCHITECTURE

XRS10L120 Evaluation Board provides a simple and efficient way to quickly evaluation functionality and performance of the XRS10L120 Serial ATA PORT MULTIPLIER.

Figure 2.0 XRS10L120 Evaluation Board Rev 1.0



Evaluation board consists of XRS10L120 device (U30) connected to Five Serial ATA connectors J3,J4, J5,J6, J1 (J1 is a host port connection; J3,J4,J5 and J6 are use for SATA drive)

This evaluation board allows two different kinds of power supply connections:

- A) External +5.0 volts power supply with minimum of 1.0 Amperes (AC adapter included in the kit), or
- B) A PC floppy drive power supply connector

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

Figure 2.1 XRS10L120 photo




Figure 2.2 XRS10L120 Evaluation Kit





XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

The evaluation board operates with 25Mhz XTAL reference clock. There are two SMA connectors (J36 and J37) for external reference clock input. The header connector (J11) has an output clock of XRS10L120 (it is primarily used for testing purpose). The DIP switch (SW3) has options to turn on transmit SSC (Spread-Spectrum Clocking) for host or/and drive ports, and to increase transmit amplitude for eSATA. These settings are read by on-board USB MPU, and program the chip through MDIO interface. Below is the list of DIP switch options:

Position	Name	OFF (up) meaning	ON (down) meaning	Default
1	PWRDNB	Normal Operation	Shut down the chip	OFF
2	RSV3	Not used now, TBD		OFF
3	RSV2	Not used now, TBD		OFF
4	RSV1	Not used now, TBD		OFF
5	SSC_HST_B	No SSC on host port	Enable SSC on host port Transmit	OFF
6	SSC_DRV_B	No SSC on host port	Enable SSC on drive ports transmit	OFF
7	HI_HST_B	For normal SATA(1i,2i) on host port	For eSATA (1m,2m)	OFF
8	HI_DRV_B	For normal SATA(1i,2i) on drive port	For eSATA (1m,2m)	OFF

The evaluation board has two RESET buttons: 'RESET MPU' (SW1) and 'RESET DUT' (SW2). 'RESET MPU' resets whole board. MPU will take the DIP switch settings and program DUT accordingly. 'RESET DUT' will reset DUT only; MPU will NOT program DUT; DUT will run with power-on default setting.

The Exar's supplied **Graphical User Interface (GUI)** is used to program the XRS10L120 registers using the PC USB port. The USB cable connects from a PC USB port to the evaluation board connector J15. GUI is not necessary if customer just needs to run the DUT under default settings.

Evaluation Board operates with a single +5V power supply. The 5.0 volts power supply is stepped down to 3.3 volts using regulator U1. It is reduced further to 1.2 volts required by the XRS10L120 port multiplier.

2.1 FUNCTIONALITY AND CONTROL

The EXAR XRS10L120 is a Serial ATA II Port Multiplier designed for the next generation disk array systems and DVR systems. The XRS10L120 can support up to 2 device connections and utilizes the full bandwidth of the host connection.

The high-speed serial input features selectable equalization adjustment and the high-speed serial output features selectable pre-emphasis to compensate for line loss and ISI (Inter-Symbol Interference), and to increase maximum cable distances

All XRS10L120 registers read/write access can be programmed using the graphical user interface via the Management Data Input Output (MDIO) bus.

2.2 XRS10L120 REFERENCE CLOCK

All XRS10L120 boards are shipped with a standard 25.0 MHz reference clock crystal. The 25.0 MHz crystal is fed to the XRS10L120's on-chip oscillator pins XOG/XOD.

External reference clock inputs can be applied to the port multiplier via SMA connectors J36, J37.

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

2.3 MDIO BUS INTERFACE

The Management Data Input Output (MDIO) port is used to configure the XRS10L120 registers. The MDIO interface is a 2-wire serial transaction with 64 MDC clock cycles. Each transaction start with 32 cycles preamble, 2 cycles start of frame, 2 cycles of OPCODE, 5 cycles of port address, 5 cycles of device address, 2 cycles turn around and 16 cycles of address/data. Figure 3 show a representative of a single Management Data Input Output (MDIO) transaction

The Management Data Input Output (MDIO) interface is defined in IEEE 802.3ae (clause 45). MDIO uses an open drain driver with external pull-up resistor to 3.3V. For more detail timing of MDIO Read/Write timing specification, please refer to XRS10L120/240 datasheet.




Figure 2.3 MDIO Bus Interface

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

3.0 SETTING UP THE HARDWARE XRS10L120 EVALUATION BOARD

The XRS10L120 Evaluation Board can be used to test Serial ATA port multiplier functionality and monitor SAS/SATA protocol. The following sections cover the differences in each setup.

- 3.1 Setting up the XRS10L120 Evaluation Board for Serial ATA port multiplier (With Serial ATA hard disk drives)
- 3.2 Setting up the XRS10L120 Evaluation Board for SATA protocol testing (Need to have SATA protocol tracer or analyzer, Lecroy's Model SAS-001MA)

3.1 SETTING UP THE XRS10L120 EVALUATION BOARD FOR SERIAL ATA PORT MULTIPLIER TESTING

To successfully perform this test, you must have the following equipment:

- XRS10L120 Evaluation Board
- 5V AC Adapter (included in the evaluation kit)
- Two Serial ATA hard disk Drive
- Three Serial ATA cables
- Serial ATA Host Bus Adaptor

Startup procedure:

1. Connect 5.0V power supply to connector J8.
2. Turn on power and verify power supply on the board by checking Power LED and output of power regulator U1, U10.
3. Turn off power supply to evaluation board
4. Connect the Serial ATA flex-cable from Evaluation Drive ports (J3, J4) to Serial ATA hard disk drives. Verify the power connector of Serial ATA hard-disk drive.
5. Set SSC and amplitude options through DIP switch SW3 or leave them as default.
6. Turn on Power Supply, press 'MCU RESET' button on XRS10L120 Evaluation Board (SW2)
7. Connect the Serial ATA flex-cables from PC Host Bus Adaptor output to Evaluation Board host Port 0 (J1).

Optional steps (8 to 10) to access the MDIO registers:

8. Connect a USB cable from a PC USB port to evaluation board connector J15
9. Install USB driver from the included CD (under CD root directory) if asked by Windows.
10. Install the GUI (if haven't done before) by double-clicking the installer icon "XRS10L140 setup.exe" in the CD.




Figure 3.0 Serial ATA Port Multiplier Test Setup with two Hard Disk drives

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

3.2 SETTING UP THE XRS10L120 EVALUATION BOARD FOR SATA PROTOCOL TESTING

To successfully perform this test, you must have the following equipments:

- XRS10L120 Evaluation Board
- SAS/SATA Protocol Analyzer System (Lecroy's Model SAS 001MA)
- Personal Computer with USB Port and SAS/SATA Analyzer software control via USB




Figure 3.1 Protocol Testing with SAS/SATA Analyzer Test Setup

Startup procedure:

1. Connect 5.0 volts power supply to board connector.
2. Connect the SATA cables from PC host bus adaptor to SAS/SATA Analyzer "Initiator" port
3. Connect the SATA cables from Drive Port outputs to Serial ATA hard disk drive.
4. Set SSC and amplitude options through DIP switch SW3 or leave them as default.
5. Turn on Power Supply, press 'MCU RESET' button on XRS10L120 Evaluation Board (SW2).
6. Connect the SATA cables from SAS/SATA "target" port to Evaluation board Host Port 0 (J1).
7. Press Run button on the SAS/SATA Analyzer
8. Connect a USB cable from a PC USB port to evaluation board connector J15.
9. Install USB driver from the included CD (under CD root directory) if asked by Windows.
10. Install the GUI (if haven't done before) by double-clicking the installer icon "XRS10L140 setup.exe" in the CD.

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

Note 1. Difference between two RESET buttons: 'RESET MPU' will reset whole board. MPU will take the DIP switch settings and program DUT accordingly. 'RESET DUT' will reset DUT only, MPU will NOT program DUT anyway, DUT will go to power-on default state.

Note 2. Steps 8 to 10 are not necessary if customer just needs to run the DUT under default setting.

4.0 INSTALLING THE XRS10L120/ XRS10L140 EVALUATION GUI


To install the XRS10L120 GUI, double click on the installation file enclosed in the CD, as part of the evaluation package. It will place the relevant GUI files in an EXAR created folder. The installation program by default will copy all the files onto c:\Program File\Exar\XRS10L140 Evaluation directory.

4.1 STARTING THE EVALUATION SOFTWARE

The evaluation software allows the user to do the following:

- Configure the XRS10L120 for proper operation using the script file
- Programming MDIO individual registers value.

Once the XRS10L120 GUI is installed, it can be found through the **Start Menu->Exar->XRS10L140 Evaluation**. Once selected, it will open up the application.




Steps to Configure the XRS10L120 Evaluation board through GUI.

1. Connect the power supply to the board (all power is derived from the 5.0 volts supply).
2. Connect from USB Port to the evaluation board J15 connector.
3. Connect Serial ATA cables from J3, and J4 to SATA drives.
4. Power up the system and press the RESET MCU button.
5. The Evaluation Board is ready for script download.


XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

Under Menu **Test**, select **Script Interface**



The Graphical User Interface will open up another dialog box.




Select "Run Script File". Under directory XRS10L140 Evaluation\Scripts, select one of the script files as needed. Such as "RevC_SSC_HST.txt" will enable SSC on host port.

Please wait about 1 sec for the GUI to load the registers setting. After successfully program registers, the following dialog is display

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008




Select the OK button, and then connect the Serial ATA cable from your PC SATA Host adaptor to Evaluation Board Host Port 0 (J1 connector). In order to verify the status of your attached hard-drive, right click your mouse on “My Computer”, then choose manage option. Click the Disk Management utility. The following screen is displaying the four Serial ATA hard disk drives (Disk1, and Disk2 are for Port0 and Port1 of XRS10L120 evaluation board).



XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008

XRS10L120 individual register can be programmed using the Read/Write Address option under Test menu. Under the **Test** menu, select the **Read/Write Address** sub-menu. The following dialog box allow user to perform the Read/Write access to all MDIO device registers.




MDIO Device 0,1,2, and 3 can be selected under Device Drop-down box.
Press **Next** to increase the register address by one location.
Press **Previous** to decrease the register address by one location
Press **Read** to read-back register content
Press **Write** to program data value to XRS10L120 register
Press **OK** to close the Read/Write Address dialog box.

XRS10L120 QFN Evaluation Board User Manual


Jan 16, 2008

APPENDIX A. XRS10L120 QFN EVALUATION BOARD SCHEMATICS



XRS10L120 QFN Evaluation Board User Manual


Jan 16, 2008



Exar Corp.	
Title	EXSTOR 2 (XRS10L120) EVAL BOARD
Size	Document Number
A	LEDs, bypass and external passive components
Date	Wednesday, January 16, 2008
Sheet	2 of 7
Rev	1.0

XRS10L120 QFN Evaluation Board User Manual


Jan 16, 2008



EVA Corp.			
Title	EXSTOR 2 (XRS10L120) EVAL BOARD		
Size	Document Number	Rev	1.0
B	MDO		
Date:	Wednesday, January 16, 2008	Sheet	3 of 7

XRS10L120 QFN Evaluation Board User Manual


Jan 16, 2008



Exar Corp.			
Title	EXSTOR 2 (XRS10L120) EVAL BOARD		
Size	A	Document Number	Host connectors
Rev	1.0	Date:	Wednesday, January 16 2008
		Sheet	4 of 7

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008




Title	EXSTOR 2 (XRS10L120) EVAL BOARD
Size	A
Document Number	SMA Device Connectors
Rev	1.0
Date	Wednesday, January 16, 2008
Sheet	5 of 7



XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008



Note:
Place capacitors C58 and C62 as close to crystal as possible


Exar Corp.	
Title	EXSTOR 2 (XRS10L120) EVAL BOARD
Size	Document Number reference docks
Rev	1.0
Date	Wednesday, January 16, 2008
Sheet	6 of 7



EVM-10L120

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008




Exar Corp.	
Title	EXSTOR 2 (XRS10L120) EVAL BOARD
Size	Document Number A power connectors and regulators
Date	Wednesday, January 16, 2008
Sheet	7 of 7
Rev	1.0

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008


APPENDIX B. XRS10L120 QFN EVAL BOARD LAYOUT FOR ALL LAYERS




TOP Assembly

XRS10L120 QFN Evaluation Board User Manual


Jan 16, 2008




Layer 1




Layer 2: GND



Layer 3: PWR 1



Layer 4: PWR 2




Layer 5: GND




EVM-10L120

XRS10L120 QFN Evaluation Board User Manual

Jan 16, 2008



Layer 6: Bottom



Bottom Assembly