



# MAX9485 Evaluation Kit

## General Description

The MAX9485 evaluation kit (EV kit) evaluates the MAX9485, a programmable multiple-output clock generator. The EV kit provides a fixed 27MHz reference clock output, CLK0, and two buffered clock outputs, CLK1 and CLK2. The output frequency is 256, 384, or 768 times the chosen sampling frequency selected through an I<sup>2</sup>C interface or hardwire pins. The sampling frequencies are 12kHz, 32kHz, 44.1kHz, 48kHz, 64kHz, 88.2kHz, and 96kHz. The EV kit operates from a single 3.3V power supply.

## Features

- ◆ Low Single 3.3V Supply
- ◆ Controlled 50Ω Coplanar Traces
- ◆ I<sup>2</sup>C Interface or On-Board Hardwire Options for Output Clock Selection
- ◆ Fully Assembled and Tested

## Ordering Information

PART	TEMP RANGE	IC PACKAGE
MAX9485EVKIT	0°C to +70°C	20 TSSOP

## Component List

DESIGNATION	QTY	DESCRIPTION
C1, C2, C3	3	10μF ±20%, 6.3V X5R ceramic capacitors (0805) Taiyo Yuden JMK212BJ106MG TDK C2012X5R0J106M
C4, C5, C6, C9, C10, C11	6	0.01μF ±10%, 16V X7R ceramic capacitors (0402) Taiyo Yuden EMK105BJ103K or Murata GRM36X7R103K016
C7, C8, C17, C18, C19	0	Not installed, ceramic capacitors (0402)
C12, C13, C14	3	0.001μF ±10%, 50V X7R ceramic capacitors (0402) TDK C1005X7R1H102K
C15, C16	2	4.0pF ±0.25pF, 50V C0G ceramic capacitors (0402) TDK C1005C0G1H4R0CT

DESIGNATION	QTY	DESCRIPTION
C20	0	Not installed, ceramic capacitor (0603)
JU1–JU8	8	3-pin headers
JU9, JU10, JU11	3	2-pin headers
R1	0	Not installed, resistor (0402)
U1	1	MAX9485EUP (20-pin TSSOP)
INPUT, CLK0, CLK1, CLK2	4	SMA edge-mount connectors
Y1	1	Through-hole crystal resonator (with 14pF load capacitance) Ecliptek ECX-5527-27.000M
Y2	0	Not installed, SMD crystal resonator
—	8	Shunts
—	1	MAX9485 PC board

## Component Suppliers

SUPPLIER	PHONE	FAX	WEBSITE
Ecliptek	800-433-1280	714-433-1234	www.ecliptek.com
Murata	770-436-1300	770-436-3030	www.murata.com
Taiyo Yuden	800-348-2496	847-925-0899	www.t-yuden.com
TDK	847-803-6100	847-390-4405	www.component.tdk.com

**Note:** Indicate that you are using the MAX9485 when contacting these component suppliers.

# MAX9485 Evaluation Kit

## Quick Start

The MAX9485 EV kit is fully assembled and tested. Do not turn on the power supplies until all connections are completed.

### Recommended Equipment

- 3.3V, 500mA power supply
- Optional 0.0V to 3.0V, 10mA power supply (for VCXO tuning)
- Frequency counter(s)/500MHz oscilloscope

### Procedure

- 1) Verify that there are no shunts across JU1 and JU2. Verify that a shunt is across on JU3 (pins 1 and 2). (Set CLK1 and CLK2 at 73.728MHz.)
- 2) Verify that there is no shunt across JU4, and there is a shunt across JU5 (pins 1 and 2). (CLK0, CLK1, and CLK2 are enabled.)
- 3) Verify that there are shunts on JU6 (pins 1 and 2) (hardwire mode), JU7 (pins 1 and 2) (internal power reset), and there is a shunt across JU8 (pins 1 and 2).
- 4) Verify that there is no shunt across JU9, JU10, and JU11.
- 5) Connect frequency counter(s) to the CLK0, CLK1, and/or CLK2 SMA connectors.
- 6) Connect the positive of the power supply to VDD, VDDP, and DVDD pads.
- 7) Connect the power ground to the GND pads.
- 8) Turn on the power supply, and enable frequency counter(s).
- 9) Verify output frequency CLK0 is around 27.000MHz, and CLK1 and CLK2 are around 73.728MHz.

## Detailed Description

The MAX9485 EV kit contains the MAX9485, a programmable multiple-output clock generator. Output CLK0 provides a fixed 27MHz-reference output, and CLK1 and CLK2 provide two buffered clock outputs of 256, 384, or 768 times the chosen sampling frequency selected through an I<sup>2</sup>C interface or on-board hardwire option. Jumpers JU6, JU7, and JU8 are incorporated to control MODE,  $\overline{\text{RST}}$ , and TUN pins of the MAX9485 device, respectively. See Table 1 for JU6 function, Table 2 for JU7 function, and Table 3 for JU8 function.

### Hardwire Mode

The EV kit provides on-board hardwire selection. Jumpers JU1–JU5 control pins SCL/FS0, SDA/FS1, FS2, SAO2, and SAO1, respectively. To set the EV kit at hardwire mode, make sure a shunt is across pins 1 and 2 of jumper JU6 (MODE = high). Jumper JU1 controls

the sampling frequency, jumper JU2 controls the frequency-scaling factors, and jumper JU3 sets the sampling rate. See Table 4 for JU1, JU2, and JU3 functions.

Jumpers JU4 and JU5 control the SAO2 and SAO1 pins of the MAX9485 device, respectively. See Table 5 for JU5 function, and Table 6 for JU4 function.

### Software Mode

To use the I<sup>2</sup>C-compatible 2-wire interface, make sure a shunt is across pins 2 and 3 of jumper JU6 (MODE = low). Leave jumpers JU1, JU2, and JU3 uninstalled. Connect the external I<sup>2</sup>C clock to SCL pad and I<sup>2</sup>C data to SDA pad. At software mode, jumpers JU4 and JU5 set an 8-bit register for the device address; see Table 7 for setting the device address. Refer to the *Software Mode Programming* section on the MAX9485 IC data sheet for control register bit mapping.

### Using External Clock as Reference Input

To use an external clock as reference input, remove the crystal on the board (Y1 or Y2), and install a 0 $\Omega$  resistor on R1 pads, then connect the external clock to the INPUT connector. In this case, the function of tuning output frequency is invalid.

**Table 1. JU6 Function (MODE)**

SHUNT LOCATION	MODE PIN	OPERATING MODE
Pins 1 and 2 (default)	Connected to DVDD	Hardwire mode
Pins 2 and 3	Connected to GND	Software mode

**Table 2. JU7 Function ( $\overline{\text{RST}}$ )**

SHUNT LOCATION	$\overline{\text{RST}}$ PIN	CHIP RESET FUNCTION
Pins 1 and 2 (default)	Connected to DVDD	On-chip internal power-on reset
Pins 2 and 3	Connected to GND	External reset

**Table 3. JU8 Function (TUN)**

SHUNT LOCATION	TUN PIN
Pins 1 and 2 (default)	TUN = DVDD.
Pins 2 and 3	TUN = 0.0V.
Not installed	To tune VCO frequency, apply a 0.0V to 3.0V power supply to TUN pad.

# MAX9485 Evaluation Kit

Evaluates: MAX9485

**Table 4. JU1, JU2, and JU3 Functions**

JU1	SAMPLING FREQUENCY	JU3	SAMPLING RATE	CLK1 AND CLK2 FREQUENCY (MHz)					
	$f_s$ (kHz)			JU2	$256 \times f_s$	JU2	$384 \times f_s$	JU2	$768 \times f_s$
Any Setting	12	Not installed	Standard	Pins 2 and 3	3.072	Pins 1 and 2	4.608	Not installed	9.126
Pins 2 and 3	32	Pins 2 and 3	Standard	Pins 2 and 3	8.1920	Pins 1 and 2	12.2880	Not installed	24.5760
Pins 1 and 2	44.1	Pins 2 and 3	Standard	Pins 2 and 3	11.2896	Pins 1 and 2	16.9344	Not installed	33.8688
Not installed	48	Pins 2 and 3	Standard	Pins 2 and 3	12.2880	Pins 1 and 2	18.4320	Not installed	36.8640
Pins 2 and 3	64	Pins 1 and 2	Double	Pins 2 and 3	16.3840	Pins 1 and 2	24.5760	Not installed	49.1520
Pins 1 and 2	88.2	Pins 1 and 2	Double	Pins 2 and 3	22.5792	Pins 1 and 2	33.8688	Not installed	67.7376
Not installed (default)	96	Pins 1 and 2 (default)	Double	Pins 2 and 3	24.5760	Pins 1 and 2	36.8640	Not installed (default)	73.7280

**Table 5. JU5 Function (SAO1)**

SHUNT LOCATION	SAO1 PIN	CLK0
Pins 1 and 2 (default)	Connected to DVDD	Enabled
Pins 2 and 3	Connected to GND	Disabled
Not installed	Open	Reserved

**Table 6. JU4 Function (SAO2)**

SHUNT LOCATION	SAO2 PIN	CLK1	CLK2
Pins 1 and 2	Connected to DVDD	Disabled	Enabled
Pins 2 and 3	Connected to GND	Enabled	Disabled
Not installed	Floating	Enabled	Enabled

**Table 7. Setting Device Address**

JU5	SAO1 PIN	JU4	SAO2 PIN	DEVICE ADDRESS
Not installed	Open	Not installed	Open	110 0000
Pins 2 and 3	Connected to GND	Not installed	Open	110 0011
Pins 1 and 2	Connected to DVDD	Not installed	Open	110 0010
Not installed	Open	Pins 2 and 3	Connected to GND	110 0100
Pins 2 and 3	Connected to GND	Pins 2 and 3	Connected to GND	110 1000
Pins 1 and 2	Connected to DVDD	Pins 2 and 3	Connected to GND	111 0000
Not installed	Open	Pins 1 and 2	Connected to DVDD	111 0001
Pins 2 and 3	Connected to GND	Pins 1 and 2	Connected to DVDD	111 0010
Pins 1 and 2	Connected to DVDD	Pins 1 and 2	Connected to DVDD	111 0100

# MAX9485 Evaluation Kit

Evaluates: MAX9485




Figure 1. MAX9485 EV Kit Schematic

# MAX9485 Evaluation Kit

Evaluates: MAX9485




Figure 2. MAX9485 EV Kit Component Placement Guide—Component Side




Figure 3. MAX9485 EV Kit PC Board Layout—Component Side

# MAX9485 Evaluation Kit

**Evaluates: MAX9485**




Figure 4. MAX9485 EV Kit PC Board Layout—Inner Layer 2 (GND Layer)




Figure 5. MAX9485 EV Kit PC Board Layout—Inner Layer 3 (DVDD Layer)

# MAX9485 Evaluation Kit

Evaluates: MAX9485




Figure 6. MAX9485 EV Kit PC Board Layout—Solder Side

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

**Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600** \_\_\_\_\_ 7