

HP Archive

This vintage Hewlett Packard document was preserved
and distributed by

[www. hparchive.com](http://www.hparchive.com)

Please visit us on the web !

On-line curator: Glenn Robb

This document is for FREE distribution only!

INSTRUCTION AND OPERATING MANUAL

FOR

MODELS 335C & D

TELEVISION AURAL CARRIER
FREQUENCY MONITOR
and
MODULATION METER

Serial 1 and Above

PROPERTY OF
TEST MAINT.
17-4

HEWLETT-PACKARD COMPANY
395 PAGE MILL ROAD, PALO ALTO, CALIFORNIA, U.S.A.

I N S T R U C T I O N S

MODEL 335C
MODEL 335D

TELEVISION AURAL CARRIER
FREQUENCY MONITOR AND MODULATION METER

SPECIFICATIONS:

FREQUENCY MONITOR

<u>Frequency Range--</u>	<u>Channels</u>	<u>Frequency</u>
Model 335C	2 to 6 Inc.	59 to 88 Inc.
Model 335D	9 to 13 Inc.	179 to 216 Inc.

Deviation Range--

Model 335C +3KC to -3KC mean frequency deviation
Model 335D +6KC to -6KC mean frequency deviation

Accuracy--

Deviation indicator accuracy better than $\pm 0.001\%$ cycles/sec.

Power Required--

Approximately 1 to 4 watts

MODULATION METER

Modulation Range--

Meter indicates full scale on modulation swing of 33.3KC Scale calibrated to 100% at 25KC; 133% at 33.3KC.

Accuracy--

Within 5% modulation percentage over entire scale.

Meter Characteristics--

Meter damped in accordance with FCC requirements. Reads peak value of modulation peak of duration between 40 and 90 milliseconds. Meter returns from full reading to 10% of full value within 500 to 800 milliseconds.

Frequency Response--

Flat within $\pm \frac{1}{2}$ db from 50 to 15000 cycles/sec.

335C/D 11/22/49 Serial 1 to

External Meters--

Provisions are made for installation of remote meter having full scale sensitivity of 400 microamperes. Scale should indicate 100% modulation at 300 microamperes. Extra meters can be supplied with unit.

Peak Limit Range--

From 50% to 120% modulation (25KC = 100%). Provision for external peak indicators.

Frequency Range--

50 cps to 20 KC. Response flat within $\pm\frac{1}{2}$ db. Equipped with Standard 75 microsecond de-emphasis circuit.

Distortion--

Less than 0.25% at 100% modulation from 50 cycles/sec to 15 kc.

Output Voltage--

10 volts into 20,000 ohms at low frequencies at 100% modulation at low frequencies.

Noise--

At least 70 db below audio output level resulting from 100% modulation at low frequencies.

Monitoring Output--

4 mw into 600 ohms balanced, at 100% modulation at low frequencies.

Power Supply Rating--

Voltage - 105/125 volts
Frequency - 50/60 cycles/sec.
Wattage - 150 watts

Overall Dimensions--

Cabinet Model-	"lg X	"high X	"deep
Rack Model -	"lg X	"high X	"deep

Weight--

Cabinet Model -
Rack Model -

335c/D. 11-22-49 Serial 1 to

INTRODUCTORY

The -hp- Model 335C, 335D TV Aural Carrier Frequency Monitor and Modulation Meter has been designed for monitoring the carrier frequency and modulation of TV Aural broadcast transmitters.

The instrument also demodulates the carrier to provide essentially distortion-free audio output for aural monitoring and for measuring transmitter performance characteristics. The instrument has been carefully designed to provide the utmost in stability and in trouble-free performance. The carrier deviation meter reads the center frequency without being affected by modulation and does not require frequent calibration adjustments. The performance of the equipment is to a high degree independent of monitoring power supplied by the transmitter, line voltage variations, tube characteristics, and temperature changes within the range of variation normally encountered in broadcast service.

In addition to monitoring the carrier frequency and modulation of the transmitter, the Models 335C, 335D allow measurement of (a) incidental AM modulation, (b) FM noise, and (c) percentage modulation of the transmitter by the carrier null method.

This manual pertains to rack style and cabinet style instruments.

OPERATING INSTRUCTIONS

UNPACKING

The crystal oven, its crystal, and the 150 kc/s check crystal used in this instrument are packed separately to minimize the possibility of damage in transit. The crystal oven should be unwrapped carefully being careful not to damage the thermometer protruding from the side of the oven. The RF fittings for the rf input cable (not supplied) are also packaged with the crystal oven.

When the equipment is first unpacked, it should be carefully inspected for possible damage in transit and to make certain that all tubes and lamps are secure in their sockets. If any shipping damage is discovered, follow the directions set out in the Warranty at the back of the manual. If the instrument is returned to the factory for any reason, the crystal oven must be packed separately to prevent its falling out of the socket and damaging the interior of the cabinet. The 150 kc check crystal also should be packed separately.

The crystal oven and check crystal should be placed in their sockets before the dust cover is replaced in this inspection.

INSTALLATION

Location

Special precautions should be taken to install the Models 335C, 335D so that a generous circulation of air is maintained. In order to obtain good circulation, it is desirable to mount the instrument above patch cord panels or other low power systems. The instrument can be operated in quite high ambient temperatures if this precaution is followed.

In no case should the instrument be operated in surroundings such that the crystal oven thermostat loses control; the crystal oven thermostat pilot lamp should flash intermittently, showing that the thermostat is controlling the oven temperature. If the lamp does not light, the air flow around the instrument should be increased.

Electrical Connections

There are three sets of electrical connections to be made to the Model 335C and/or Model 335D. All of these connections are made on the back side of the instrument:

(1) The motor base type plug on the instrument should be connected to a nominal 115-volt, 50/60 cycle single phase supply. It should be noted that the power source for the oven is connected permanently across the input circuit ahead of the power switch so that the crystal will be maintained at the proper temperature when the equipment is turned off and not in use.

(2) A coaxial type connector (Navy type-49194) is provided and should be connected to the monitoring pick-up provided by the transmitter manufacturer. Fifty-ohm coaxial cable such as RG-8/U should be used to connect the Model 335C and/or Model 335D to the pick-up loop. Relatively long lengths of cable can be tolerated for this connection. Directions for adjusting the monitoring pick-up on the transmitter are given on page of this manual.

(3) An eight-point terminal strip provides connections for audio output, an external modulation meter, and external peak modulation indicator lights.

(a) Monitoring Output: When terminals 3 and 4 are connected together, terminals 1 and 2 provide an audio signal for feeding a 600-ohm balanced circuit. The nominal output is 1.5 volts (4 mw) at 100% modulation at low modulating frequencies.

(b) High Level Output: A high level output is provided between terminal 3 and ground (terminal 5) for use with a noise and distortion analyzer or a high impedance monitoring amplifier. The nominal output is 10 volts at 100% modulation

at low modulating frequencies and the applied load should not be less than 20,000 ohms. When making noise and distortion measurements, terminal 4 should be disconnected from terminal 3 to prevent any undesirable loading by the monitoring circuits.

(c) External Modulation Meter: Terminals 5 and 6 are normally joined by a 1000-ohm resistor. If an external modulation meter is to be used, this resistor should be removed and the meter connected between these terminals, 6 being the positive connection and 5 (ground) the negative. The external meter should be identical to the one in the instrument in order to indicate accurately and have the proper dynamic characteristics. It is recommended that extra modulation meters be obtained from the Hewlett-Packard Company, giving the serial number of the unit for which they are intended.

(d) External Peak Modulation Indicator: An external indicating lamp may be placed in parallel with the one in the instrument by connecting it between terminals 7 and 8. Either a 3- or a 6- watt, 120 volt lamp may be used. Not more than a few hundred micromicro-farads of capacity should be introduced by this connection so that it is desirable to use short lengths of low capacity cable.

All leads connecting to the terminal strip and AC power connections should be isolated from strong RF fields, preferably using shielded wire.

Initial Adjustments

The initial adjustments for this unit are the same as the usual operating adjustments, except for the adjustment of the transmitter pick-up loop. The following adjustments should be made when the Model 335C and/or Model 335D is first installed and as often as desired thereafter:

(1) Turn on the instrument and allow a heating period of at least a few hours, because the main crystal will take some time to be heated to its proper temperature. Disconnect the pick-up loop. During the warm-up, keep a close check reading on the crystal thermometer which is visible through the front panel. If the reading of this thermometer overshoots 65°C by any appreciable amount, the cause usually will be found to be that the mercury column in either the thermometer or thermostat is not united. These columns can be re-united by removing the unit in question and alternately heating and cooling the unit.

Steps 2 and 5 below can be performed after only a few minutes warm-up, although as long a warm-up as possible should be allowed before performing step 6.

(2) Open the panel door and set the "CALIBRATE - USE - CARRIER LEVEL" switch to the "CALIBRATE" position. The "CARRIER DEVIATION" meter will read close to center scale and

335C/D 11-22-49 Serial 1 to

the "PERCENT MODULATION" meter will read approximately 100%.

Adjust the "SET TO ZERO DEV." control so that the "CARRIER DEVIATION" meter reads exactly zero. Adjust the "SET TO 100%" control so that the "PERCENT MODULATION" meter reads exactly 100%. These controls adjust the counter circuits to normal operation.

(3) Set the "CALIBRATE - USE - CARRIER LEVEL" switch to a position halfway between "USE" and "CARRIER LEVEL." There is a detent mechanism at this point, although not labelled on the panel.

A reading on the "PERCENT MODULATION" meter between 40 and 75 will be obtained with no signal coming from the transmitter. This reading should be peaked by adjusting the condenser marked "MULT." on the chassis (not on front panel). With this condenser peaked, a reading of at least 40 on the "PERCENT MODULATION" meter should be obtained.

(4) The condenser marked "OSC" on the chassis should not need adjustment. However, if a reading of less than 40 is obtained with the previous adjustment in (3) above, it may be desirable to retune the oscillator tank circuit which will be found to vary slowly on one side of the maximum and rapidly on the other side. The proper setting for this condenser is that which will give a reading about 15% (Model 335C) or 30% (Model 335D) below the maximum on the side which varies slowly. This adjustment is not critical, since it affects only slightly the frequency and stability of the crystal oscillator.

(5) Next, set the "CALIBRATE - USE - CARRIER LEVEL" switch to the "CARRIER LEVEL" position and adjust the pick-up loop in the transmitter to give a reading between 50 and 100 on the "PERCENT MODULATION" meter. The carrier input level is not critical. The power from the transmitter can be adjusted from about one-tenth of a watt to 4 watts without affecting the accuracy of the Model 335C and/or Model 335D.

The reading on the "PERCENT MODULATION" meter with the switch in the "CARRIER LEVEL" position is approximately proportional to the input voltage. With 10 volts of RF voltage from the transmitter, a reading of approximately 100% will be obtained on the "PERCENT MODULATION" meter with the switch in the "CARRIER LEVEL" position.

(6) The frequency of the comparison oscillator in the equipment has been adjusted to the specified channel at the factory and can be expected to be within a few hundred cycles of the correct frequency when the instrument is received. After the equipment has been turned on for several hours, the temperature of the crystal oven will come up to 65° C. If it is desired to check the frequency of the monitor against

a standard transmission, this may be done and the frequency of the monitor can be adjusted by means of the screwdriver adjustment marked "CRYSTAL TUNING" under the cover on the front panel. This adjustment should be made with the switch in the "USE" position.

(7) The instrument is now ready for operation and only those adjustments described under "Maintenance" in this manual should be required.

CONTROLS

CALIBRATE - USE - CARRIER LEVEL

Connect front panel meters so as to enable the instrument to be calibrated, to check the performance of the comparison frequency multiplier circuits, and to measure the carrier input level from the transmitter.

SET TO 100%

Adjusts current in final switching tubes to proper magnitude to insure that sensitivity of both the CARRIER DEVIATION indication and PERCENT MODULATION indication are correct.

SET TO ZERO DEV.

Adjusts balancing current in CARRIER DEVIATION meter so that zero deviation is indicated when exactly 150 kc is applied to the counter circuits. This adjustment is made in the CALIBRATE position of the USE - CALIBRATE switch. In this position a 150 kc voltage from an internal 150 kc crystal-controlled oscillator is applied to the counter circuits.

CRYSTAL TUNING

Adjusts frequency of local crystal-controlled comparison oscillator so the monitor can be adjusted to read zero deviation for the correct frequency.

MODULATION POLARITY

Connects the modulation and peak indicators so they respond in accordance with either positive or negative swings of modulation.

PEAK MODULATION INDICATOR

Adjusts the firing point of the peak modulation indicator lamp so the modulation level at which the flash will be obtained can be set.

CRYSTAL TEMPERATURE

Thermometer which indicates temperature within crystal oven; normal temperature is approximately 65° C.

POWER ON

Controls the power supplied to the instrument from the power line. The crystal oven heater and its temperature controls are connected directly to the power line and are not controlled by the POWER ON switch.

FUSE-2A, FUSE-.25A

These fuse holders contain a 2 ampere and a .25 ampere cartridge fuse. The fuse may be replaced by unscrewing the fuseholder cap and inserting a new fuse.

In addition to these controls on the front panel, three controls are located on the chassis of the equipment. A potentiometer R49, located on a terminal board at the left side underneath the chassis, is provided to adjust the voltage regulator circuit if necessary when the voltage regulator tubes are changed. A screw driver control of the tuning condenser ("OSC") in the crystal tank circuit is located just behind the crystal oven on top of the chassis. Further back of the panel in the same area is located the crystal multiplier tank circuit control ("MULT") which is also a screwdriver adjustment.

When the equipment has been installed and adjusted in accordance with the foregoing instructions, nothing further is necessary during the operation except occasionally to check the readings of the "CARRIER DEVIATION" meter and the "MODULATION" meter in the "CALIBRATE" position. Any variations from these readings may be corrected from time to time by means of the "SET TO ZERO DEV." control and the "SET TO 100" control.

It may also be desirable occasionally to check the carrier level by returning the switch to the "CARRIER LEVEL" position and reading the modulation meter. Any reading in this position between 50 and 100 will provide satisfactory operation.

Over Modulation Indicator

The modulation meter in the Model 335C and Model 335D TV Aural Carrier Frequency Monitor and Modulation Meter has been designed so that it will indicate 90% of the value of a modulation peak of 85 milliseconds duration. Further, the modulation meter will fall to 10% from a 100% reading in not less than 500 milliseconds and not more than 800 milliseconds after the complete removal of 100% modulation. These design requirements are in accordance with FCC standards.

In practice, however, many bursts of modulation in a typical program are of much shorter duration than 85 milliseconds--perhaps one or two milliseconds--and the Models 335C, 335D do not indicate the full peak value of modulation bursts of extremely short duration. Nevertheless, these short intervals of high modulation are important, because, if substantial

overmodulation occurs on such peaks, the result may be detected in receivers and also may cause adjacent channel interference.

In order to prevent these conditions, it is recommended that the Models 335C, 335D be operated with their overmodulation indicator (lamp) adjusting knobs set not higher than 70% and that the modulation of the transmitter be adjusted so that occasional flashing of the overmodulation indicating lamp is obtained with common program material. This will mean that the general program level will result in the order of 50% modulation as indicated by the meter. Modulation peaks of short duration will be higher than this value but probably will not exceed 100%. This condition of operation is desirable as it permits the true capabilities of high quality, unique only to FM more nearly to be realized. Overmodulation is to be avoided as it results in considerable deterioration of the program quality.

Any limiting amplifier used in the audio system should be essentially instantaneous in its action. Limiting amplifiers having a control action slower than a few milliseconds will permit modulation peaks going considerably above the 100% level. This emphasis of short modulation peaks by limiting amplifiers is particularly bad in FM Systems due to the pre-emphasis of the high frequencies in the system. Therefore it is recommended that limiting amplifiers be avoided unless their characteristics and effects on the entire system are well known.

MEASUREMENTS

MEASUREMENT OF INCIDENTAL AMPLITUDE MODULATION ON FM BROADCAST CARRIERS

A special jack is provided in the -hp- Model 335C and 335D to facilitate the measurement of spurious AM modulation on the carrier of FM broadcast transmitters. This jack is located on the back of the instrument and is marked J3. Measurements of spurious AM modulation can be made with the use of this jack and a sensitive vacuum-tube voltmeter in the following manner:

(1) Couple the unmodulated RF voltage from the transmitter to the Model 335C and/or 335D so that the RF voltage causes a reading of 100% on the "PERCENT MODULATION" meter when the "CALIBRATE - USE - CARRIER LEVEL" switch in the "CARRIER LEVEL" position. This is equivalent to a carrier voltage of 10 volts or to an audio level (assuming 100% AM modulation of +22.2 db referred to a zero reference on one milliwatt in 600 ohms). If it is not possible to couple closely enough to obtain a reading of 100%, record the reading obtained.

(2) Connect a tip-and-sleeve 1/4" diameter telephone type plug to a sensitive vacuum tube voltmeter and connect the voltmeter to J3 on the back of the Model 335C/D. An -hp-

Model 400A, 400C, or the VTVM section of an -hp- Model 330B or 330C can be used for this measurement. The lead connecting the voltmeter to the jack should be shielded and the capacity should not exceed 100 mmf. Also connect a 2-megohm resistor across the terminals of the voltmeter so that the resistor is shunting the line to the Models 335C, 335D.

(3) Read and record the audio voltage reading obtained on the voltmeter.

(4) The percentage of AM modulation can then be obtained from the following formula:

$$\% \text{ AM} = \frac{\text{Audio Voltage} \times 1000}{\text{carrier reading in \%}}$$

For example, assume the RF input was set to 100% and that a reading of 0.1 volt was obtained on the voltmeter. Then, the percentage of amplitude modulation is:

$$\frac{0.1 \times 1000}{100} = \frac{100}{100} = 1\%$$

(5) On a db basis, 100% carrier reading corresponds to an audio level of +22.2 db. The meter reading of 0.1 volt corresponds to -17.8 db. Therefore the AM modulation expressed in db is 22.2 db +17.8 db or 40 db. Thus, the spurious AM is 40 db below the condition of 100% AM modulation.

NOISE GENERATED IN MONITOR

The noise generated in the Models 335C, 335D is at least 70 db below the audio output level resulting from 100% modulation at low frequencies. Assuming that 100% modulation at a low frequency provides exactly 10 volts output at the high-impedance audio output of the Models 335C, 335D, the noise as measured across a 20,000 ohm minimum load on terminals 3 and 5 should be not more than 3.2 millivolts.

NOISE SHOULD BE MEASURED WITH THE SWITCH IN THE "CALIBRATE" POSITION. IN NO CASE SHOULD NOISE BE MEASURED BY REMOVING THE RF INPUT FROM THE MONITOR WITH THE SWITCH IN THE "USE" POSITION, NOR SHOULD THE NOISE BE MEASURED BY SHORTING THE RF INPUT. WHEN THE RF IS REMOVED WITH THE SWITCH IN THE "USE" POSITION, THE MONITOR OPERATES WITH THE EQUIVALENT OF A FLOATING GRID CIRCUIT CAUSING AN INCREASE IN THE NOISE LEVEL.

MODULATION CHECK

The percent modulation of an FM transmitter may be measured conveniently by the carrier null method using the IF signal from this monitor. Jack J2, which is a phone jack on the rear of the chassis, supplies a small IF signal which is normally 150 kc in frequency and contains the full FM swing of

Serial 1 to
11-22-49
335C/D

the transmitter. This output should be connected to the antenna terminal of a communications type receiver, preferably one which will tune to 150 kc. However, the signal is approximately a square wave, so that the second or third harmonic could be used. The transmitter should be unmodulated and the receiver BFO adjusted to give a beat note of several hundred cycles. As sine wave modulation is gradually applied to the transmitter, the amplitude of the transmitter carrier, and hence the receiver beat note output, will go through successive amplitude nulls.

Combinations may be computed using the following relation:

$$\text{Modulation index} = \frac{\text{frequency swing}}{\text{modulating frequency}}$$

The values of the modulation index for which the carrier disappears are those which are equal to the argument of the zero order Bessel function when the function has zero value. These values of modulation indices are given in the following table. Additional values are spaced at intervals of pi.

<u>Null No.</u>	<u>Mod. Index</u>
1	2.405
2	5.520
3	8.654
4	11.792
5	14.931
6	18.071
7	21.212
8	24.353
9	27.494
10	30.635

If the receiver is tuned to 150 kc, a modulation swing of 25 kc is used at 100% modulation. However, if it is tuned to a harmonic, the modulation swing is also multiplied, giving a correspondingly higher modulation swing for 100% modulation.

It should be noted that the accuracy of measurement of modulation percentage is equal to the accuracy of calibration of the modulation frequency. Also, it is necessary that the modulation signal have low distortion if the nulls are to be very sharply indicated.

The method described is useful in setting the modulation monitor sensitivity if it becomes necessary to replace some critical part. Components whose value directly affects the accuracy of the modulation meter are R38, R39, R40, R53, R58, and the meter M1 itself. If any of these parts are replaced, it will be necessary to use exact duplicate values or reset R39 as follows: With the transmitter modulated 100% with some convenient frequency between 1 and 5 kc. Set R26 for

Serial 1 to

11/22/49

335C/D

100% reading in the "USE" position. Then switch to "CALIBRATE" and set R39 for 100% reading. The monitor should read correctly as long as this 100% reading is maintained in the "CALIBRATE" position.

MAINTENANCE

DAILY MAINTENANCE

A daily maintenance check of the Model 335C and/or Model 335D is recommended before the transmitter is put on the air. This check can be made quickly by means of the internal calibration controls provided on the equipment. The following procedure is recommended:

(1) Set the switch under the panel door to the "CALIBRATE" position. Set the "CARRIER DEVIATION" meter to zero and the "PERCENT MODULATION" meter to 100% by means of the correspondingly marked controls.

(2) Next, set the switch halfway between the USE and CARRIER LEVEL positions. In this position the MODULATION meter should read at least "40" with no power coming from the transmitter.

(3) When the transmitter power is turned on, set the switch to the CARRIER LEVEL position to make certain that RF power is being received from the transmitter. A reading between 50 and 100 should be obtained on the PERCENT MODULATION meter. Lower readings indicate insufficient power being received from the transmitter.

(4) Make certain that the front panel thermometer indicates that the temperature of the crystal oven is at 65 degrees Centigrade.

(5) Set the switch to the USE position. The instrument is now ready for use.

(6) If any of the above readings fail to come within the limits indicated, follow the procedure described under "Installation" or check for tube failure.

TUBE REPLACEMENT

All of the tubes in this instrument, with the exception of the crystal oscillator tube, can be changed without special precaution. When any tube is changed, it is desirable to go through the routine maintenance check as described above.

If the crystal oscillator tube is changed, a shift in frequency of the comparison oscillator may cause an error of several hundred cycles in the reading of the CARRIER DEVIATION meter. Although this variation is well within the limits of

accuracy prescribed for FM service, it is desirable to check this frequency when the oscillator tube V1 is replaced.

Tubes in the voltage regulator circuit can be replaced without appreciably affecting the accuracy of the instrument, although it is desirable to measure the regulated voltage whenever any of tubes V10B, V13, V14, or V15 are replaced. The regulated voltage should be set at 300 volts dc by means of R49.

If abnormally high or low line voltages are present at the station installation, it may be desirable to check the operation of the voltage regulator at line voltages within the range likely to be encountered. This check can be made by connecting a dc meter to the regulated side of the power supply and varying the input line voltage to the instrument with an auto-transformer over the anticipated range of line voltage. The dc voltage will be constant within the region of control of the regulator circuit and will change at the end of the region of control. This region of control can be adjusted somewhat by potentiometer R49. Normally, a variation in line voltage from 105 to 125 volts will have no measurable effect on the accuracy of the monitor.

STANDARDIZING OF COMPARISON OSCILLATOR FREQUENCY

Model 335C

The frequency of the local comparison oscillator is of the order of 10 megacycles. The circuits have been designed so this oscillator can operate at 1/10 or 1/20 of a frequency 150 kc less than the transmitter frequency. This design facilitates checking of the crystal oscillator in the monitor because the frequency is always a multiple of 10 kc. Thus, a source of 10 kc signal controlled by a crystal can be first set to zero beat with a W.W.V. transmission at 10 megacycles. Then this same 10 kc frequency will beat with the local comparison oscillator frequency to provide a difference signal well within the audio range. This beat can be brought to zero beat with the pre-standardized 10 kc signal by means of the crystal tuning adjustment of the FM monitor. The only equipment necessary for this adjustment is a receiver which will cover the frequency range around 10 megacycles and a source of 10 kc voltage which can be crystal controlled and adjusted slowly.

	<u>CHANNEL</u>		<u>N</u>	<u>CRYSTAL FREQ.</u>	<u>PLATE TANK FREQ.</u>
#2	59.75	Mc	10	5.96	11.92
#3	65.75	"	10	6.56	13.12
#4	71.75	"	20	3.58	14.32
#5	81.75	"	20	4.08	16.32
#6	87.75	"	20	4.38	17.52

Model 335D

The frequency of the local comparison oscillator is of the order of 20 megacycles. The circuits have been designed so this oscillator can operate at 1/10 of a frequency 150 kc less than the transmitter frequency. This design facilitates checking of the crystal oscillator in the monitor because the frequency is always a multiple of 10 kc. Thus, a source of 10 kc signal controlled by a crystal can be first set to zero beat with a W.W.V. transmission at 10 megacycles. Then this same 10 kc frequency will beat with the local comparison oscillator frequency to provide a difference signal well within the audio range. This beat can be brought to zero beat with the pre-standardized 10 kc signal by means of the crystal tuning adjustment of the FM monitor. The only equipment necessary for this adjustment is a receiver which will cover the frequency range around 10 megacycles and a source of 10 kc voltage which can be crystal controlled and adjusted slowly.

	<u>CHANNEL</u>	<u>N</u>	<u>CRYSTAL FREQ.</u>	<u>PLATE TANK FREQ.</u>
#7	179.75	10	17.96	35.92
#8	185.75	10	18.56	37.12
#9	191.75	10	19.16	38.32
#10	197.75	10	19.76	39.52
#11	203.75	10	20.36	40.72
#12	209.75	10	20.96	41.92
#13	215.75	10	21.56	43.12

Many stations will prefer to use standard monitoring service periodically to check their transmitters. In this case, it is desirable to adjust the transmitter in accordance with the instructions of the frequency monitoring service and adjust the FM monitor to the transmitter immediately thereafter.

Check of the crystal frequency should not be required except over very long intervals. The accuracy of the Model 335C and/or Model 335D is such as to insure variations in readings of not more than .0005% over long periods of time.

335c/D 11-22-49 Serial 1 to

R. F. TUNING

Retuning of the RF circuits is indicated if the "MODULATION" meter reads less than "40" when the "CALIBRATE" - "USE - CARRIER LEVEL" switch is set midway between the "USE and CARRIER LEVEL" positions with no power coming from the transmitter. (With power coming from the transmitter, the reading will be 10 or so higher on the MODULATION meter than with no transmitter power.)

To aid in tuning the oscillator, the "MODULATION" meter acts as a tuning indicator when the "CALIBRATE - USE - CARRIER LEVEL" switch is set midway between the "USE" and "CARRIER LEVEL" positions (with no transmitter power applied). This tuning should be made as follows:

(1) The dust cover should be removed from the instrument. Switch should be midway between USE AND CARRIER LEVEL positions.

(2) Tune C2 (marked "MULT" on chassis) for a maximum reading on "MODULATION" meter.

(3) Tune C6 (marked OSC on chassis) on the high frequency side of resonance for a reading about 15% (Model 335C) or 30% (Model 335D) below the maximum obtainable. On the high frequency side of resonance the meter reading varies much slower than on the low frequency side as C6 is tuned. By tuning 15% (Model 335C) or 30% (335D) or more down in level, the frequency of oscillation is made practically independent of tuning.

(4) If the reading on the "MODULATION" meter is now less than "40", a new 6AC7 tube should be inserted and allowed to heat for twenty minutes or more. The procedure should then be repeated.

CHANGE OF CHANNEL

If it is necessary to retune the oscillator completely as, for example, when a new crystal for a different channel is inserted, the following procedure is recommended.

With no crystal in the circuit or when the new crystal is inserted, a reading of about "20" is often obtained on the "MODULATION" meter when the switch is midway between the "USE" and "CARRIER LEVEL" positions. This reading is caused by oscillation due to the 150kc tuned circuits in the plate and screen circuits.

Now, perform step (3) above. The "MODULATION" meter reading will fall off when C6 is tuned to the proper frequency (unless C2 should happen to be tuned properly, in which case the "MODULATION" meter reading will rise).

Now perform steps (2) and (3) in that order to complete the retuning of the oscillator. There is a possibility that C2 "MULT." can be tuned to the wrong harmonic, because the tuning range of C2 is about 25% and the circuit tunes to the fourth harmonic of the crystal. This can be avoided by removing the bottom plate from the Model 335C/D and observing that condenser C2 "MULT" is adjusted near minimum capacity for the higher channels and near maximum capacity for the lower channels. Another indication of tuning C2 to the wrong harmonic is that the "CARRIER DEVIATION" meter will read off scale when the Model 335C or Model 335D is returned to service.

It should also be remembered that the frequency of oscillator V1 can be adjusted over a range of several kc of the transmitter antenna frequency by means of the "CRYSTAL TUNING" control. Therefore, when using a new crystal, the Models 335C and 335D should not be used on a new channel until the crystal frequency (and thus the accuracy of the Models 335C and 335D) has been checked accurately or the Models 335C or Model 335D zeroed against a transmitter whose frequency is known at the time of comparison.

CIRCUIT DESCRIPTION

BRIEF DESCRIPTION OF OPERATION

The general operation of the Models 335C and 335D can be described by referring to the block diagram on Page 10. The transmitter frequency is combined with an accurately controlled frequency derived from a crystal-controlled oscillator in the instrument so that a difference frequency of 150kc plus or minus the modulation components is obtained. The frequency of this 150kc mean difference frequency is measured by frequency counter circuits. The frequency counter circuits also demodulate the signal. From this demodulated signal the percentage of modulation is measured. Also, audio voltages are obtained for measuring the distortion and frequency response characteristics of the transmitter.

The local crystal-controlled oscillator operates at $1/10$, $1/20$ of a frequency 150kc less than the transmitter frequency. ($f_{\text{xtmitter}} - 150\text{kc}$) the output of the crystal controlled oscillator is multiplied four times and fed into a triode mixer at $1/5$ of the final frequency. The final multiplication is obtained in the mixer circuit.

The frequency counter circuits are of the pulse integrating type and are designed to provide a high degree of linearity over the frequency range of 190 kc to 210 kc. A direct current meter in the output circuit of these counter tubes is used to measure the frequency deviation of the carrier.

In order to use a meter of adequate sensitivity, a dc compensating current exactly equal to the current generated in the counter circuits with 150 kc applied is used to balance the meter current to zero when the carrier of the transmitter is on frequency. The sensitivity of this meter is such that, when the counter circuits are driven by a frequency which deviates by 3 kc above or 3 kc below 150kc, a full scale reading is obtained. (6kc above or 6 kc below 150kc in the use of the Model 335D).

Since the 150 kc signal applied to the counter circuits contains also the full modulation swing, the counter circuits can be arranged to demodulate the frequency modulation. The magnitude of this demodulated voltage is used to measure the percentage modulation of the transmitter. The audio amplifier which follows the frequency counter circuits, drives the modulation meter and the peak modulation indicator.

The frequency counter circuits are extremely stable and will drift generally less than 100 cycles over a 24-hour period. However, an internal 150 kc check frequency is provided to set the frequency deviation meter to zero deviation and thus assure accurate calibration of the frequency counter circuits.

The calibration of the modulation monitor is standardized by standardizing the current fed into the frequency counter circuits.

Audio output voltages are provided for monitoring or measuring the transmitter output.

The deviation meter is fully protected from overloads and no damage to the instrument will occur if the transmitter input is suddenly removed.

An external modulation meter may be connected in series with the internal meter. Terminals are provided at the rear of the chassis for this purpose.

DETAILED DESCRIPTION OF CIRCUITS

The schematic diagram of the Models 335C, 335D at the back of this manual should be followed in conjunction with the following description.

Tube V1 is the local crystal oscillator tube which generates the basic frequency with which the transmitter frequency is compared. This tube is operated as an electron coupled oscillator. The crystal is connected from grid to ground when switch S2 is in the USE position. The crystal is mounted in a double chamber over whose temperature is regulated by means of a mercury column thermostat. The

characteristics of this oven are such that the temperature at the crystal varies by considerably less than 1 degree C as a function of time and over an ambient range from +10 degrees to +40 degrees C.

The screen of V1 is tuned to the crystal frequency by means of L3 and C6. The plate is tuned to a suitable harmonic of the crystal frequency by means of L1, C2 and C3.

A small capacity C1 is connected directly across the crystal and provides for adjustment of the crystal frequency by about 3 kc around the nominal transmitter frequency.

V2A is the mixer tube. A signal from the transmitter is applied directly to the cathode of V2A across R9 and R10 parallel. The input signal is fed to the mixer through a 50-ohm concentric cable and the characteristics of the termination R9 and R10 are such that a standing wave ratio of not over 1.1/1 is obtained looking into the RF input. The grid of V2A is driven by the output voltage from the crystal oscillator tube at a frequency of four times the crystal frequency. This signal combines with the signal from the transmitter to give a difference frequency in the plate circuit of V2A which is 150 kc plus the full modulation swing contained in the monitored signal.

V1 is also arranged to provide the 150kc signal for calibration of the pulse counter circuits. This signal is obtained by switching a 150kc crystal between grid and ground of V1 and tuning the screen circuit of V1 to 150kc by means of L4 and C8. A 150kc resonant circuit, L2 and C5, is placed in series with the high frequency resonant circuit in the plate of V1. This is possible because the tuning capacities C8 and C5 are large enough to provide adequate by-passing for and high frequency voltages generated when V1 is connected in the USE position. Switching is done by means of switch S2B which connects the input of the counter circuits to either the output of mixer tube V2A in the USE position or directly to the 150kc voltage in the output of V1 in the CALIBRATE position.

V2B serves as an amplifier tube to amplify the 150kc signal. A crystal limiter, Y1 and Y2, is connected to the grid circuit of V2B so that the driving voltage is limited and clipped to provide a square wave shape.

V3 is a phase inverter which applies the 150kc signal to the grids of V4 and V5 which are the initial switching tubes. The space current for V4 and V5 are derived from a constant current generator tube V6. This tube has a large un-bypassed cathode resistor R60, and the grid of V6 is held at a constant potential from the regulated power supply by means of R23 and R24. With this circuit, the current passing through V6, and consequently V4 and V5, is, to a high degree, independent of the amplitude of the driving signal of tubes V4 and V5.

The operation of switching tubes V₄ and V₅ can be described as follows: The grid of V₄ is driven positive while the grid of V₅ is driven to cut off. All the current from V₆ flows through V₄ and R₂₁, thereby generating a flat topped wave across R₂₁. When the grid of V₅ is positive, a similar action takes place with all of the current flowing through R₂₂. Thus, the output of switching tubes V₄ and V₅ provides a driving signal in switching tubes V₇ and V₈ which is nearly independent of the amplitude of the 150kc voltage, provided the 150kc voltage is at least large enough to provide the switching action thus described. Switching tubes V₇ and V₈ operate in similar manner. When the grid of V₇ is driven positive, the constant current provided by V₉ flows through V₇. In this case, however, C₂₂ takes all of the current initially, but as the charge of C₂₂ is building up, more of the current flows through R₃₃ until finally C₂₂ is fully charged to a voltage which is exactly equal to the constant current provided by V₉ flowing through R₃₃. In this manner, a pulse of accurately controlled current flows through C₂₂ for each alternative half cycle. In a similar manner, the switching of V₈ generates a pulse of accurately controlled current through C₂₆.

C₂₂ and C₂₆ provide an additional function. Since C₂₂ is fully charged when the voltage changes so as to cause V₈ to conduct, the anode of tube V₇ is held at a low voltage, thus assisting in the cut-off of V₇ at the instant tube V₈ begins to draw current. In this manner, the time of rise of current conduction in tubes V₇ and V₈ is extremely rapid so that either one tube or the other is conducting the entire constant current.

If the circuit constants are so arranged that C₂₂ and C₂₆ are fully charged within 1/2 cycle of the highest frequency involved, the amount of current flowing through C₂₂ is a function of frequency only. The current pulses flowing through C₂₂ and C₂₆ are rectified by means of a bridge rectifier, and the resulting dc current is applied to M₂. This operation makes the response of M₂ directly proportional to frequency. In order to balance out the reading which would be obtained on M₂ with a 150kc signal, some current is applied in reverse through M₂. This current is generated by a voltage drop across resistor R₃₇ which carries the same current which flows through current regulator tube V₉ and through switching tubes V₇ and V₈.

The sensitivity of this circuit as a frequency meter is directly proportional to this constant current. The balancing current in the meter varies in exact accordance with the constant current. Thus, should there be variations in either the constant current or in the characteristics of the tubes, the meter will still read zero center with 150kc applied. The current applied to the deviation meter consists of a series of pulses of direct current, the AC components of

3350/D 11-22-49 Serial 1 to

which are by-passed through C30. C30 is also effective to low audio frequencies, thus preventing the meter from trying to follow the modulation.

When frequency modulation is applied to this counter circuit, the rectified value of the current varies linearly with modulation. This rectified current generates an audio signal in the primary of transformer T₄. V17 serves as an audio amplifier stabilized with feedback by means of tertiary winding on T₄ so that the response and gain is stabilized. The audio output from V17 is applied to V16A which serves as an impedance transformer to operate the modulation meter. V16B serves as an impedance transformer to provide a distortion-free audio output for monitoring and for measuring purposes.

The networks and the rectifier which determine the operation of modulation meter M1 are connected to the cathode circuit of V16A. This circuit is a peak reading voltmeter in which a dc voltage is generated across C39 equal in value to the peak value of the audio frequency. C38 is arranged to feed additional power into the modulation meter M1 on rapid upswings, and the network of R53, in combination with C38, together with the dynamic characteristics of the meter movement provide the desired response and time characteristics of the modulation meter. The same dc voltage which operates the modulation meter is fed through R61 to the grid of V11. V11 is a thyratron arranged to flash a lamp when the peak value of audio voltage exceeds a pre-set level which is controlled by R42 in the cathode circuit of V11.

Since the sensitivity of the deviation meter and the calibration of the modulation meter are dependent, among other things, on the magnitude of the constant current switched by tubes V7 and V8, arrangements have been made for accurately measuring that current. Switch S2C and S2B connect meter M1 to measure the constant current fed to the switching tubes. This current is adjusted by means of R26 in the grid of V9.

V10A is a tube which compensates for hum generated in the switching tubes. The hum voltage is picked up in T3, amplified in V10A, and applied as a control signal on V9. This feature is of importance when the equipment is used for measuring purposes.


Meter M1 is also arranged to measure the grid current of the mixer tube. When the switch is in the "CARRIER LEVEL" position, Meter M1 is connected to the grid circuit of V2A so that the grid current drawn by V2A because of application of input voltage can be determined. When switch S2 is in a position halfway between "USE" AND "CARRIER LEVEL", Meter M1 is connected so as to measure the grid current of V2A generated by the application of voltage from the local oscillator. Thus, the tuning of the circuits in the screen and plate of V1 can be adjusted to make sure adequate voltage is obtained from the local crystal to provide proper mixing action.

De-emphasis of the audio voltage is obtained by a network R52 and C46 in the grid of V16B.

V14, V10B, V13 and V15 provide a regulated voltage supply for the operation of the critical circuits in the equipment. V12 together with T1, L11, L12, C32, C33 and C34 provide the dc power for the operation of the equipment.

The rectifier crystals in the output of the switching tubes and other critical components are filtered and by-passed to eliminate spurious fr pickup which otherwise might have a deleterious effect on the operation of the equipment.

MODEL	335C	335D
C2	100 uuf	25 uuf
C6	100 uuf	50 uuf
L1	1.5 uh	.9 uh
L3	15 uh	1.5 uh



SCHEMATIC DIAGRAM OF MODELS 335C, 335D TV AURAL FREQUENCY MONITOR
AND MODULATION METER
Serial 1 to

PROPERTY OF
TEST MAINT.

TABLE OF REFERENCE PARTS

17-4

Circuit Ref.	Description	Stock No.	Mfr. & Mfrs. Designation
C1	CAPACITOR: variable; air; 25 mmf	12-15	Sarkes-Tarzian: J-24P
C2	CAPACITOR: variable; air; 100 mmf Model 335C only	12-17	
C2	CAPACITOR: variable; air; 25 mmf Model 335D only	12-9	
C3	This reference not assigned		
C4	CAPACITOR: fixed; mica; .005 mf; 300vdcw	14-14	Mica mold: Type W
C5	CAPACITOR: fixed; silver mica; 1400 mmf $\pm 5\%$; 500 vdcw		
C6	CAPACITOR: variable; air; 100 mmf Model 335C only	12-17	
C6	CAPACITOR: variable; air; 50 mmf Model 335D only	12-16	
C7	CAPACITOR: silver mica; 1800 mmf; 500 vdcw	15-19	Sangamo: Type CR
C8	CAPACITOR: silver mica; 1400 mmf $\pm 5\%$; 500 vdcw		
C9	CAPACITOR: mica; .005 mf; 300 vdcw	14-14	Mica mold: Type W
C10	CAPACITOR: cera mic; NPO: 22 mmf; 500 vdcw	15-2	Electrical Reac- tance Corp: CI-2
C11	CAPACITOR: mica; .005 mf; 300 vdcw	14-14	Micamold: Type W
C12	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C13	CAPACITOR: ceramic; NPO: 22 mmf 500 vdcw	15-2	Electrical Reac- tance Corp: CI-2
C14 a,b	CAPACITOR: paper; two sections each .25 mf; 600 vdcw	17-14	General Electric: 23F628
C15	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM

335C/D 11/29/49 Serial 1 to

TABLE OF REPLACEABLE PARTS

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
C16	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C17	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C18	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C19	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric: 23F467G103
C20	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric: 23F467G103
C21	CAPACITOR: ceramic; 1000 mmf; feed thru type	15-21	Electrical Reactance Corp; CF-1
C22	CAPACITOR: silver mica; 220 mmf ±2%	15-32	Aerovox: Type 1479 Temp. Coeff. D
C23	This reference not assigned		
C24 a,b	CAPACITOR: paper; two sections each .25 mmf; 600 vdcw	17-14	General Electric: 23F628
C25	CAPACITOR: paper; .02 mf; 600 vdcw	16-12	Aerovox: Type 684
C26	CAPACITOR: silver mica; 220 mmf ±2%	15-32	Aerovox: Type 1479 Temp. Coeff. D
C27	CAPACITOR: ceramic; 1000 mmf; feed thru type	15-21	Electrical Reactance Corp: CF-1
C28	This reference not assigned		
C29	CAPACITOR: ceramic; 1000 mmf; feed thru type	15-21	Electrical Reactance Corp: CF-1
C30	CAPACITOR: electrolytic; 50 mf; 50 vdcw	18-50	Mallory: TC-39

335C/D 11/29/49 Serial 1 to

TABLE OF REPLACEABLE PARTS

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
C31	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric 23F467G103
C32	CAPACITOR: paper; 4 mf; 600 vdcw	17-10	Cornell-Dubilier; TLA 6040
C33	CAPACITOR: paper; 4 mf; 600 vdcw	17-10	Cornell-Dubilier; TLA 6040
C34	CAPACITOR: paper; 4 mf; 600 vdcw	17-10	Cornell-Dubilier; TLA 6040
C35	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric; 23F467G103
C36	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric; 23F467G103
C37	CAPACITOR: paper; 4 mf; 600 vdcw	17-10	Cornell-Dubilier; TLA 6040
C38A	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric; 23F467G103
C38B	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric; 23F467G103
C39	CAPACITOR: paper; 4 mf; 600 vdcw	17-10	Cornell-Dubilier; TLA 6040
C40	CAPACITOR: electrolytic; 10 mf; 450 vdcw	18-10	Mallory; Type WB-72
C41	CAPACITOR: silver mica; NPO; 62 mmf; 500 vdcw	15-25	Aerovox; Type 1469
C42	CAPACITOR: electrolytic; 50 mf; 50 vdcw	18-50	Mallory; Type TC-39
C43	CAPACITOR: paper; 1 mf; 600 vdcw	17-12	General Electric; 23F467G103
C44	CAPACITOR: mica; 1000 mf; 300 vdcw	14-11	Micamold; Type OXM
C45	CAPACITOR: mica; 1000 mf; 300 vdcw	17-12	General Electric; 23F467G103

335C/D 11/29/49 Serial 1 to

TABLE OF REPLACEMENT PARTS

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
C46	CAPACITOR: silver mica; 510 mmf ±5% 500 vdcw	15-27	Micamold: Type PO
C47	CAPACITOR: ceramic; 110 mmf	15-22	Electrical Reactance Corp: SI-7
C48	This reference not assigned		
C49	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C50	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C51	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C52	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C53	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C54	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C55	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C56	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C57	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C58	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C59	CAPACITOR: mica; 1000 mmf; 300 vdcw	14-11	Micamold: Type OXM
C60	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C61	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold: Type OXM
C62	CAPACITOR: mica; 150 mmf; 500 vdcw	14-150	Micamold Type OXM

335C/D 11/29/49 Serial 1 to

335C/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
F1	FUSE: .25 amp; 3AG	211-6	Littelfuse: 312.250
F2	FUSE: 2 amp; slow-blow type; 3AG	211-16	Bussman: MDL2
I1	LAMP: 6 Watts; 120 volts;	211-5 S6/6W	General Electric S6/6W
I2	LAMP: 6-8 volts; .15 amps	211-47	General Electric #47
J1	UHF PANEL JACK: Navy Type -49194	38-50	Amphenol: #83-1R
J2	JACK:	38-10	Switchcraft: #12A
J3	JACK:	38-10	Switchcraft: #12A
L1	COIL: 1.5 microhenry Model 335C only	48-1	Electrical Reactance Corp.
L1	COIL: .9 microhenry Model 335D only	35F-60A	Hewlett-Packard
L2	COIL: 1.1 millihenry;	35F-60B	Hewlett-Packard
L3	COIL: 2 microhenry Model 335C only	35F-60C	Hewlett-Packard
L3	COIL: 1.5 microhenry Model 335D only	48-1	Electrical Reactance Corp.
L4	COIL: .9 millihenry	35F-60D	Hewlett-Packard
L5	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.
L6	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.
L7	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.
L8	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.
L9	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.

3350/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfg. & Mfgs. Designation
L10	COIL: 1.5 microhenry	48-1	Electrical Reactance Corp.
L11	REACTOR: 6 henries at 125 mads; 240 dc ohm	M-61	Robert M. Hadley Co.
L12	REACTOR: 6 henries at 125 mads; 240 dc ohm	M-61	Robert M. Hadley Co.
M1	METER: 400 microamp full scale; illuminated type	112-13	Weston: Model 861 Special Scale
M2	METER: zero center microammeter; 15-0-15 microamps full scale	112-12	Weston: Model 861 Special Scale
R1	RESISTOR: fixed; composition; 270,000 ohms; <u>+10%</u> ; 1/2 watt	23-270K	Allen-Bradley; EF-2741
R2	RESISTOR: wirewound; 5 ohms (part of oven assembly)		
R3	RESISTOR: fixed; composition; 82000 ohms; <u>+10%</u> ; 1 watt	24-82K	Allen-Bradley; GB-8231
R4	RESISTOR: Fixed; composition; 22,000 ohms; <u>+10%</u> ; 2 watts	25-22K	Allen-Bradley; HB-2231
R5	RESISTOR: fixed; composition; 120,000 ohms; <u>+10%</u> ; 1 watt	24-120K	Allen-Bradley; GB-1241
R6	RESISTOR: fixed; composition; 18,000 ohms; <u>+10%</u> ; 2 watts	25-18K	Allen-Bradley; HB-1831
R7	RESISTOR: fixed; composition; 30,000 ohms; <u>+10%</u> ; 1/2 watt	25-30K	Allen-Bradley; EB-3031
R8	RESISTOR: fixed; composition; 68,000 ohms; <u>+10%</u> ; 1 watt	24-6800	Allen-Bradley; GB-6821
R9	RESISTOR: fixed; composition; 100 ohms; <u>+10%</u> ; 2 watts	25-100	Allen-Bradley; HB-1011
R10	RESISTOR: fixed; composition; 100 ohms; <u>+10%</u> ; 2 watts	25-100	Allen-Bradley; HB-1011
R11	RESISTOR: fixed; composition; 10,000 ohms; <u>+10%</u> ; 1 watt	24-10K	Allen-Bradley; GB-1031

3350/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
R12	RESISTOR: fixed; composition; 100 ohms; $\pm 10\%$; 1 watt	24-100	Allen-Bradley GB-1011
R13	RESISTOR: fixed; composition; 820 ohms; $\pm 10\%$; 1 watt	24-820	Allen-Bradley GB-8211
R14	RESISTOR: fixed; composition; 8200 ohms; $\pm 10\%$; 1 watt	24-8200	Allen-Bradley GB-8221
R15	RESISTOR: fixed; composition; 560,000 ohms; $\pm 10\%$; 1 watt	24-560K	Allen-Bradley
R16	RESISTOR: fixed; composition; 82,000 ohms; $\pm 10\%$; 1 watt	24-82K	Allen-Bradley GB-8231
R17	RESISTOR: fixed; composition; 4700 ohms; $\pm 10\%$; 2 watts	25-4700	Allen-Bradley HB-4721
R18	RESISTOR: fixed; composition; 4700 ohms; $\pm 10\%$; 2 watts	25-4700	Allen-Bradley HB-4721
R19	RESISTOR: fixed; composition; 33,000 ohms; $\pm 10\%$; 1 watt	24-33K	Allen-Bradley GB-3331
R20	RESISTOR: fixed; composition; 33,000 ohms; $\pm 10\%$; 1 watt	24-33K	Allen-Bradley GB-3331
R21	RESISTOR: fixed; composition; 4700 ohms; $\pm 10\%$; 2 watts	25-4700	Allen-Bradley HB-4721
R22	RESISTOR: fixed; composition; 4700 ohms; $\pm 10\%$; 2 watts	25-4700	Allen-Bradley HB-4721
R23	RESISTOR: fixed; composition; 560,000 ohms; $\pm 10\%$; 1 watt	24-560K	Allen-Bradley GB-5641
R24	RESISTOR: fixed; composition; 82,000 ohms; $\pm 10\%$; 1 watt	24-82K	Allen-Bradley- GB-8231
R25	RESISTOR: fixed; composition; 830,000 ohms; $\pm 1\%$; 1 watt	31-830K	Wilkor: CP-1
R26	RESISTOR: variable; composition; 50,000 ohms	210-18	Centralab: 33-010-176
R27	RESISTOR: fixed; composition; 103,000 ohms; $\pm 1\%$; 1 watt	31-103.5K	Wilkor: CP-1
R28	RESISTOR: fixed; composition; 1550 ohms; $\pm 10\%$; 2 watts	35F-55F	Allen-Bradley HB-1521

3350/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. Mfrs. Designation
R29	RESISTOR: fixed; composition; 1000 ohms; <u>+10%</u> ; 1 watt	24-1K	Allen-Bradley GB-1021
R30	RESISTOR: fixed; composition; 220,000 ohms; <u>+10%</u> ; 1 watt	24-220K	Allen-Bradley GB-2241
R31	RESISTOR: fixed; composition; 33,000 ohms; <u>+10%</u> ; 1 watt	24-33K	Allen-Bradley GB-3331
R32	RESISTOR: fixed; composition; 33,000 ohms; <u>+10%</u> ; 1 watt	24-33K	Allen-Bradley GB-3331
R33	RESISTOR: fixed; wirewound; 1200 ohms	35F-55	Hewlett-Packard
R34	RESISTOR: fixed; wirewound; 1200 ohms	35F-55A	Hewlett-Packard
R35	RESISTOR: variable; wirewound; 300 ohms	210-53	Centralab 21-010-358
R36A	RESISTOR: fixed; wirewound; 6000 ohms		Hewlett-Packard
R36B or R37B	RESISTOR: fixed; composition; <u>+1%</u> ; 1 watt; exact value selected during Mfrs. Tests		Wilkor: CP-1
R37A	RESISTOR: fixed; wirewound; 510 ohms	35F-55C	Hewlett-Packard
R38	RESISTOR: fixed; wirewound; 62 ohms	35F-55D	Hewlett-Packard
R39	RESISTOR: variable; wirewound; 1000 ohms	210-5	Centralab: 210-5
R40	RESISTOR: fixed; wirewound; 4700 ohms	35F-55E	Hewlett-Packard
R41	RESISTOR: fixed; composition; 684,000 ohms; <u>+1%</u> ; 1 watt	31-68317K	Wilkor: CP-1
R42	RESISTOR: variable; wirewound; 25000 ohms	210-10	Clarostat: Type 58
R43	RESISTOR: fixed; composition; 14,400 ohms; <u>+1%</u> ; 1 watt	27-3	Wilkor: CP-1

335C/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. Mfrs. Designation
R44	RESISTOR: fixed; wirewound; 5000 ohms; $\pm 10\%$; 20 watts	27-3	Lectrohm: Type 2R
R45	RESISTOR: fixed; wirewound; 4000 ohms; $\pm 10\%$; 220 watts	27-7	Lectrohm: Type 2R
R46	RESISTOR: fixed; composition; 560,000 ohms; $\pm 10\%$; 1 watt	24-560K	Allen-Bradley GB-5641
R47A	RESISTOR: fixed; composition; 82000 ohms; $\pm 10\%$; 2 watts	25-82K	Allen-Bradley HB-8231
R47B	RESISTOR: fixed; composition; 82000 ohms; $\pm 10\%$; 2 watts	25-82K	Allen-Bradley HB-8231
R48	RESISTOR: fixed; composition; 316000 ohms; $\pm 1\%$; 1 watt	31-316K	Wilkor: CP-1
R49	RESISTOR: variable; composition; 20,000 ohms	210-16	Centralab: 33-010-725
R50	RESISTOR: fixed; composition; 90,000 ohms; $\pm 1\%$; 1 watt	31-90K	Wilkor: CP-1
R51	RESISTOR: fixed; composition; 10,000 ohms; $\pm 10\%$; 2 watts	25-10K	Allen-Bradley HB-1031
R52	RESISTOR: fixed; composition; 144,000 ohms; $\pm 1\%$; 1 watt	31-144K	Wilkor: CP-1
R53	RESISTOR: fixed; composition; 33,000 ohms; $\pm 1\%$; 1 watt	31-33	Wilkor: CP-1
R54	RESISTOR: fixed; composition; 5100 ohms; $\pm 10\%$; 1 watt	24-74	Allen-Bradley GB-5121
R55	RESISTOR: fixed; composition; 22,000 ohms; $\pm 10\%$; 2 watts	25-22K	Allen-Bradley HB-2231
R56	RESISTOR: fixed; composition; 216300 ohms; $\pm 10\%$; 1 watt	31-216.3K	Wilkor CP-1
R57	RESISTOR: fixed; composition; 2520 ohms; $\pm 1\%$; 1 watt	31-2520	Wilkor CP-1
R58	RESISTOR: fixed; composition; 62,000 ohms; $\pm 1\%$; 1 watt	31-62	Wilkor CP-1

335C/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
R59	RESISTOR: fixed; composition; 560 ohms; $\pm 10\%$; 1 watt	24-560	Allen-Bradley: GB-5611
R60	RESISTOR: fixed; composition; 2,200 ohms; $\pm 10\%$; 2 watts	25-2,200	Allen-Bradley: HB-2221
R61	RESISTOR: fixed; composition; 1 megohm; $\pm 10\%$; $\frac{1}{2}$ watt	23-1M	Allen-Bradley: EB-1051
R62	RESISTOR: fixed; composition; 18,000 ohms; $\pm 10\%$; 1 watt	24-18K	Allen-Bradley: GB-1831
R63	RESISTOR: fixed; composition; 56 ohms; $\pm 10\%$; $\frac{1}{2}$ watt	23-56	Allen-Bradley: EB-5601
R64	RESISTOR: fixed; composition; 8200 ohms; $\pm 10\%$; $\frac{1}{2}$ watt	23-8200	Allen-Bradley; EB-8221
R65	RESISTOR: fixed; composition; 12 ohms; $\pm 10\%$; $\frac{1}{2}$ watt	23-12	Allen-Bradley: EB-2301
R66	RESISTOR: composition; 1 watt; value selected to circuit during calibration		
R67	RESISTOR: fixed; composition; 56 ohms; $\pm 10\%$; $\frac{1}{2}$ watt	23-56	Allen-Bradley: EB-5601
R68	RESISTOR: fixed; composition; 120,000 ohms; $\pm 10\%$; 1 watt	24-120K	Allen-Bradley: GB-1241
R69	RESISTOR: fixed; composition; 18,000 ohms; $\pm 10\%$; 1 watt	24-18K	Allen-Bradley: GB-1831
R70	RESISTOR: fixed; composition; 2.2 megohms; $\pm 10\%$; 1 watt	24-2.2M	Allen-Bradley GB-2251
R71	RESISTOR: fixed; composition; 220,000 ohms; $\pm 10\%$; 1 watt	24-220K	Allen-Bradley GB-2241
Relay 1	RELAY: SPST: plug-in type	49-5	Sigmā Inst: 41ROZ
S1	SWITCH: toggle; SPST;	310-11	Arrow-H & H
S2	SWITCH: rotary	310-39	Hewlett-Packard
S3	SWITCH: toggle; DPDT	310-41	Arrow-H & H

335C/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
T1	TRANSFORMER: power	910-26	Excel Transformer 910-26
T2	TRANSFORMER: power	35F-8A	Excel Transformer 910-32
T3	TRANSFORMER: audio;	912-10	Peerless Electrical Prod. No 4603
T4	TRANSFORMER: audio	912-7	Transformer Engineers 912-17
T5	TRANSFORMER: audio	35F-9	Transformer Engineers 912-8
V1	TUBE: RMA type 6AC7	212-6AC7	
V2A,B	TUBE: RMA type 7F8	212-7F8	
V3	TUBE: RMA type 6AC7	212-6AC7	
V4	TUBE: RMA type 6V6	212-6V6	
V5	TUBE: RMA type 6V6	212-6V6	
V6	TUBE: RMA type 6V6	212-6V6	
V7	TUBE: RMA type 6V6	212-6V6	
V8	TUBE: RMA type 6V6	212-6V6	
V9	TUBE: RMA type 6V6	212-6V6	
V10A,B	TUBE: RMA type 6SL7-GT	212-6SL7-GT	
V11	TUBE: RMA type 2050	212-2050	
V12	TUBE: RMA type 5R4GY	212-5R4GY	
V13	TUBE: RMA type VR-75	212-VR-75	
V14	TUBE: RMA type 6Y6G	212-6Y6G	
V15	TUBE: RMA type VR-75	212-VR75	
V16A,B	TUBE: R,A type 6SN7-GT	212-6SN7-GT	

335c/D 11/29/49 Serial 1 to

Circuit Ref.	Description	-hp- Stock No.	Mfr. & Mfrs. Designation
V17	TUBE: RMA type 6SJ7	212-6SJ7	
Xtal 2	CRYSTAL: quartz; freq according to desired channel; temp coeff 1 cycle per mc per degree C.	41-(Spec. freq)	Bliley Type MC7
	CRYSTAL OVEN: (less crystal)	35F-25	Hewlett-Packard
	Replaceable Parts in Crystal Oven:		
Xtal 1	Crystal, quartz: 150 kc		Jas. Knight Co.
	Thermometer: contact	41-5	Precision Inst. Co. 40
	Thermometer:	41-6	Jensen Inst. Co. S.F.
Y1 to Y11	CRYSTAL RECTIFIER: Type 1N34	212-34	Sylvania: 1N34
	FUSEHOLDER:	312-8	Littlefuse: #342001
	DIAL LIGHT ASSEMBLY: (red)	213-93	Dial Light Co. 910 C-161
	KNOB: 1- $\frac{1}{2}$ " diam;	37-5	Kurz-Kasch: S380-64L
	KNOB: 1-1/8" diam:	37-11	Kurz-Kasch: S308-64
	KNOB: 11/16" diam	37-1	Federal Screw Prod: 1110
	RECEPTACLE: motor base type	38-52	General Electric: 2711
	LINE CORD: approximately 7 $\frac{1}{2}$ ft; parallel type contact plug on one end and motor base type receptacle on other	M-72	Hewlett-Packard
	TERMINAL STRIP:	36-38	Jones: 8-141-Y
	FLEXIBLE SHAFT:	312-47	National Co. Inc. TX-11

LIST OF MANUFACTURERS CODE LETTERS
FOR REPLACEABLE PARTS TABLE

<u>Code Letter</u>	<u>Manufacturer</u>
A	Aerovox Corp.
B	Allen-Bradley Co.
C	Amperite Co.
D	Arrow, Hart and Hegeman
E	Bussman Manufacturing Co.
F	Carborundum Co.
G	Centralab
H	Cinch Manufacturing Co.
I	Clarostat Manufacturing Co.
J	Cornell Dubilier Electric Co.
K	Electrical Reactance Co.
L	Erie Resistor Corp.
M	Federal Telephone and Radio Corp.
N	General Electric Co.
O	General Electric Supply Corp.
P	Girard-Hopkins
HP	Hewlett-Packard
Q	Industrial Products Co.
R	International Resistance Co.
S	Lectrohm, Inc.
T	Littelfuse, Inc.
U	Maguire Industries, Inc.
V	Micamold Radio Corp.
W	Oak Mfg. Co.
X	P. R. Mallory Co., Inc.
Y	Radio Corp. of America
Z	Sangamo Electric Co.
AA	Sarkes Tarzian
BB	Signal Indicator Co.
CC	Sprague Electric Co.
DD	Stackpole Carbon Co.
EE	Sylvania Electric Products, Inc.
FF	Western Electric Co.
GG	Wilkor Products, Inc.
HH	Amphenol
II	Dial Light Co. of America
JJ	Leecraft Manufacturing Co.
ZZ	Any tube having RMA standard characteristics

CLAIM FOR DAMAGE IN SHIPMENT

The instrument should be tested as soon as it is received. If it fails to operate properly, or is damaged in any way, a claim should be filed with the carrier. A full report of the damage should be obtained by the claim agent, and this report should be forwarded to us. We will then advise you of the disposition to be made of the equipment and arrange for repair or replacement. Include model number, type number and serial number when referring to this instrument for any reason.

WARRANTY

Hewlett-Packard Company warrants each instrument manufactured by them to be free from defects in material and workmanship. Our liability under this warranty is limited to servicing or adjusting any instrument returned to the factory for that purpose and to replace any defective parts thereof (except tubes, fuses and batteries). This warranty is effective for one year after delivery to the original purchaser when the instrument is returned, transportation charges prepaid by the original purchaser, and which upon our examination is disclosed to our satisfaction to be defective. If the fault has been caused by misuse or abnormal conditions of operation, repairs will be billed at cost. In this case, an estimate will be submitted before the work is started.

If any fault develops, the following steps should be taken:

1. Notify us, giving full details of the difficulty, and include the model number, type number and serial number. On receipt of this information, we will give you service instruction or shipping data.
2. On receipt of shipping instruction, forward the instrument prepaid, and repairs will be made at the factory. If requested, an estimate of the charges will be made before the work begins provided the instrument is not covered by the warranty.

SHIPPING

All shipments of Hewlett-Packard instruments should be made via Railway Express. The instruments should be packed in a wooden box and surrounded by two to three inches of excelsior or similar shock-absorbing material.

DO NOT HESITATE TO CALL ON US

HEWLETT-PACKARD COMPANY

Laboratory Instruments for *Speed and Accuracy*

395 PAGE MILL ROAD



PALO ALTO, CALIFORNIA