



# **SPECTRUM ANALYZERS**

## **3250 Series**



# **CDMA2000 Measurement**

## **User Manual**

Document part no. 47090/043

---



# **SPECTRUM ANALYZERS 3250 SERIES**

## **CDMA2000 Measurement User Manual**

© Aeroflex Ltd. 2010

*No part of this document may be reproduced or transmitted in any form  
or by any means, electronic or mechanical, including photocopying,  
or recorded by any information storage or retrieval system,  
without permission in writing by Aeroflex Ltd.  
(hereafter referred to throughout the document as 'Aeroflex').*

Document no. 47090/043 (PDF version)

Issue 1

4 March 2010

---

---

## About this manual

This manual explains how to use the CDMA2000 measurement option for 3250 Series Spectrum Analyzers.

### Intended audience

Persons engaged on work relating to the design and manufacture of RF and microwave sub-systems and modules, or the installation and maintenance of those systems.

Familiarity with the terms used in RF and microwave measurements is assumed.

### Document conventions

The following conventions apply throughout this manual:

**CAPS** Capitals are used to identify names of controls and panel markings.

**[CAPS]** Capitals in square brackets indicate hard key titles.

**[Italics]** Italics in square brackets indicate soft key titles.

### Associated publications

- 3250 Series Operating Manual  
(PDF version 46892/974, printed version 46882/974)

---

# Contents

<b>About this manual .....</b>	<b>2</b>
Intended audience .....	2
Document conventions .....	2
Associated publications .....	2
<b>Precautions .....</b>	<b>6</b>
<b>General .....</b>	<b>7</b>
Specifications .....	8
Frequency .....	8
Dynamic range and accuracy .....	8
A/D converter .....	8
Storage .....	8
Installing the CDMA2000 measurement option .....	9
<b>Measurement guide — general .....</b>	<b>10</b>
Preparation for measurement .....	10
General steps in making a measurement .....	10
<b>CDMA2000 measurement guide .....</b>	<b>12</b>
Spectral mask .....	15
Test purpose and concepts .....	15
Test procedure .....	15
Test results .....	15
Channel power .....	16
Test purpose and concepts .....	16
Test procedure .....	16
Test results .....	16
Adjacent channel power ratio .....	17
Test purpose and concepts .....	17
Test procedure .....	17
Test result .....	18
Code domain analysis .....	19
Test purpose and concepts .....	19
Test procedure .....	19
Test result .....	20
Modulation analysis .....	21
Composite EVM .....	21
QPSK EVM .....	23
CCDF (complementary cumulative distribution function) .....	25
Test purpose and concepts .....	25
Test procedure .....	25
Test result .....	25
<b>Menu descriptions .....</b>	<b>26</b>
CDMA2000 measurement mode .....	26
Frequency channel menu .....	26
Amplitude menu .....	26
Measure menu .....	27
Measure control menu .....	27
Marker menu .....	28
Display menu .....	28
Sweep menu .....	28
Preset menu .....	29
<b>Detailed description of commands .....</b>	<b>30</b>
General .....	30
SA command .....	30
Amplitude .....	31

---

RL.....	31
AT.....	32
SD.....	33
Display.....	34
GRAT.....	34
WH.....	35
File.....	36
FREAD.....	36
FSAVE.....	37
FLOAD.....	38
FDEL.....	39
FCOPY.....	40
FRENAME.....	41
FMOVE.....	42
Frequency.....	43
CF.....	43
REF.....	44
Marker.....	45
MS[1~9].....	45
MM[1~9].....	46
MF[1~9].....	47
MA[1~9].....	48
MAO.....	49
Measurement.....	50
MEA.....	50
SEMOUT.....	51
CHPOUT.....	52
ACPOUT.....	53
CDPOUT.....	54
CDEOUT.....	55
EVMOUT.....	56
QPSKEVMOUT.....	57
CCDFOUT.....	58
Measurement control.....	59
RADIOCONFIG.....	59
LCMASK.....	60
SYMB.....	61
Mode.....	62
MODE.....	62
Preset.....	63
PRST.....	63
Printer.....	64
HCOPY.....	64
Sweep.....	65
CO.....	65
SI.....	66
System.....	67
BEEP.....	67
ECHO.....	67
GPIB common commands.....	68
*CLS.....	68
*ESE.....	69
*ESR?.....	70
*IDN?.....	71
*OPC.....	72
*OPC?.....	73
*RST.....	74
*SRE.....	75
*STB?.....	76

---

---

GPIB common commands — others .....	77
ESE2.....	77
ESR2?.....	78
ERR .....	79
<b>Remote commands.....</b>	<b>80</b>
Ordered by function.....	80
Ordered by SA command .....	82
Ordered by SCPI command.....	84
<b>Error codes.....</b>	<b>86</b>

---

## **Precautions**

This document is intended to be used in conjunction with the 3250 Operating Manual, which contains a full list of safety precautions. Please ensure that you are familiar with these precautions before using the instrument.

---

## General

This option allows you to perform CDMA2000 power, spectrum and modulation measurements in accordance with the 3GPP2 CDMA2000 standard.

This user manual describes how to set up the system to perform CDMA2000 measurements, and the operation of each menu.

Note that the CDMA2000 measurement software must be installed on the system in order to use the CDMA2000 measurement option.

You can make the following measurements:

- Transmit Spectrum Mask
- Channel Power
- ACPR (Adjacent Channel Power Ratio)
- Code Domain Analysis (Code Domain Power & Code Domain Error)
- Composite EVM: provides the following numerical results in addition to this measurement
  - EVM Error (RMS): %
  - EVM Error (Peak): %
  - Rho: 0 to 1
  - Frequency Error: Hz
  - Peak CDE (I, Q): dB
- QPSK EVM
  - EVM Error (RMS): %
  - EVM Error (Peak): %
  - Origin Offset: %
  - Frequency Error: Hz
- CCDF



## Specifications

The instrument includes a wide-band RF digitizer, which is optimized for complex signal analysis applications in communications system test.

### Frequency

<b>Frequency range</b>	3 Hz to 3 / 8 GHz / 13.2 GHz / 26.5 GHz
Bandwidth	30 MHz
Resolution	1 Hz

### Dynamic range and accuracy

<b>Intermodulation free dynamic range Adjacent Channel Leakage Ratio (ACLR)</b>	Typically 80 dB
<b>Residual EVM</b>	<1% (nominal)

### A/D converter

<b>Resolution</b>	14 bits
<b>ADC clock</b>	Fixed 85.6 MHz
<b>Sample rate control</b>	IF: 21.4 MHz; IQ: variable 541.666ks/s to 42.8 Ms/s
<b>Amplitude flatness</b>	Typically 0.5 dB to 30 MHz
<b>Phase flatness</b>	0.05 radians pk-pk to 30 MHz

### Storage

<b>Data output</b>	Sampled digital I/Q data is stored in the digitizer's internal memory. Its resolution is 32 bits. It is transferred to the CPU over the PCI bus.
<b>Sample memory</b>	128 Mb (32 Msample)

## Installing the CDMA2000 measurement option

To license your CDMA2000 measurement option, use the following procedure.

**Note:** *when you add a new option, or update an existing option, you receive the updated version of all your current options because they are reloaded simultaneously. This process may also require you to update the signal analyzer program so that it is compatible with the new option.*

*If your analyzer came with the CDMA2000 measurement licensed, you can skip the licensing.*

*Keep a copy of your license key number in a secure location. If you lose your license key number, call your nearest service or sales office for assistance.*

*If you buy the digitizer with this option, it must be sent to the manufacturer. All hardware and software installations will be completed by the manufacturer, and the instrument returned to you.*

- 1 Connect keyboard and mouse to the PS2 ports or the USB ports.
- 2 Turn on the instrument. Wait until the instrument completes its power-up sequence.
- 3 Press [SYSTEM], [Option Info.], [Option Activate].
- 4 Select the *CDMA2000* field in the license active dialog window.

**Note:** *all purchased options must be selected.*

- 5 Enter the letters/digits of your 32-character license code using the mouse or the keyboard. The license key number is a hexadecimal number.
- 6 Press [Activate].
- 7 If licensing completes successfully then the *Activation Success* dialog window displays. If *Invalid License!* is displayed, enter the correct license code again.
- 8 Press *OK* or press any key, then exit from the license menu.

---


## Measurement guide — general

This section introduces you to making measurements of CDMA2000 signals. Using the procedures specified in this and the following section, you can carry out CDMA2000 signal analysis in the spectrum, code and modulation domains.

For 802.11a signals, additional hardware is needed to cover their 5 GHz signal band.

### Preparation for measurement

Before connecting a signal to the instrument, make sure the instrument can safely accept the signal level provided. The maximum RF input level is +30 dBm. If the RF input attenuator level is set to 10 dB, the input level can be increased to +40 dBm. Connect a 10 MHz reference input to synchronize the analyzer with a signal source. Fig. 1 shows the instrument set up for testing a device.



*Fig. 1 CDMA2000 measurement setup*

### General steps in making a measurement

All measurements made in 'CDMA2000 options' can be performed with the following steps.

#### 1 Select the measurement option

Press [MODE]. All of the installed and licensed options become available and are shown.

Press [CDMA2000] or [Basic]. Analyze the signal in CDMA2000 standard format or in non-standard format (see the Basic mode).

#### 2 Select measurement to be performed

Press [MEAS]. There are various measurement menu related to the CDMA2000 standards. Use this menu to select the specific measurement to be performed. When the trigger conditions are satisfied, digitized CDMA2000 signals are acquired and analyzed instantly.

Press [MEAS], [CONTROL]. Set up the specific parameters relating to the selected CDMA2000 measurement item.

### **3 Analyze displayed analysis results**

Depending on the measurement selected, you can adjust the way results are displayed using the [TRACE], [DISPLAY] menu. Use the [SPAN] and [AMPL] menus to set the scales of the X and Y axes.

## CDMA2000 measurement guide

Code Division Multiple Access 2000 (CDMA2000) is a wideband CDMA standard that has been adopted by 3GPP2. It provides a wideband air interface for third-generation global wireless communications systems. CDMA2000 is a derivative of the IS-95-B CDMA system, also known as ‘CDMAOne’, and provides backwards compatibility. In addition to this, CDMA2000 has the advantages of advanced data rate, better battery efficiency and increased capacity for subscribers on wireless communication channels.

CDMA2000 uses the Global Positioning System (GPS) for its synchronization. Both reverse and forward transmitter power controls are implemented with 1.25 ms intervals. CDMA2000 uses a direct sequence spread-spectrum (DSSS) for its spreading and multiple access techniques.

IS-2000 defines the wireless media protocol in the CDMA2000 standard and uses RCs (Radio Configuration) for classifying the CDMA2000 signal. The ‘RC’ in CDMA2000 defines the physical layer difference for each configuration. Table 1 shows the functional characteristics for different RCs.

**Table 1 Functional characteristics with RC on CDMA2000**

RC	SR	Data rate	FEC	OTD	Encoding	Mod
1	1	9.6 kbs	1/2	No	Conv	BPSK
2	1	14.4 kbps	3/4	No	Conv	BPSK
3	1	153.6 kbps	1/4	Yes	Conv & Turbo	QPSK
4	1	307.2 kbps	1/2	Yes	Conv & Turbo	QPSK
5	3	230.4 kbps	3/8	Yes	Conv & Turbo	QPSK
6	3	307.2 kbps	1/6	Yes	Conv & Turbo	QPSK
7	3	614.4 kbps	1/3	Yes	Conv & Turbo	QPSK
8	3	460.4 kbps	1/4 or 1/3	Yes	Conv & Turbo	QPSK
9	3	1036.8 kbps	1/2 or 1/3	Yes	Conv & Turbo	QPSK

The frequency bands used in a CDMA2000 system are called ‘Band Class’. They are categorized ‘Band class 0’ to ‘Band class 12’, as described in Table 2.

**Table 2 Frequency and channel assignments in CDMA2000**

<b>Band class</b>	<b>Main usage</b>	<b>UL span</b>	<b>DL span</b>
BC0	US Cellular	824 MHz–849 MHz	869 MHz–894 MHz
BC1	North American PCS	1850 MHz–1910 MHz	1930 MHz–1990 MHz
BC2	TACS Band	872 MHz–915 MHz	917 MHz–960 MHz
BC3	JTACS Band	887 MHz–925 MHz	832 MHz–870 MHz
BC4	Korean PCS	1750 MHz–1780 MHz	1840 MHz–1870 MHz
BC5	NMT-450	411 MHz–483 MHz	421 MHz–493 MHz
BC6	IMT2000	1920 MHz–1980 MHz	2110 MHz–2170 MHz
BC7	North American 700 MHz Cellular	776 MHz–794 MHz	746 MHz–764 MHz
BC8	1800 MHz	1710 MHz–1785 MHz	1805 MHz–1880 MHz
BC9	900 MHz Band	880 MHz–915 MHz	925 MHz–960 MHz
BC10	Secondary 800 MHz Band	806 MHz–901 MHz	851 MHz–940 MHz
BC11	400 MHz European PAMR Band	410 MHz–458 MHz	420 MHz–468 MHz
BC12	800 MHz PAMR Band	870 MHz–876 MHz	915 MHz–921 MHz

The CDMA2000 reverse link is different to that of CDMAOne. The MS can transmit more than one code channel to accommodate the high data rates. The minimum configuration consists of a reverse pilot (R-Pilot) channel to allow the BTS to perform synchronous detection, and a reverse fundamental channel (R-FCH) for voice. Additional channels, such as the reverse supplemental channels (R-SCHs) and the reverse dedicated control channel (R-DCCH), can be used to send data or signaling information respectively.

For backward compatibility with CDMAOne, CDMA2000 also has the access channel, reverse fundamental channel and reverse supplement code channel. Fig. 2 shows the structure of the code channels transmitted by a mobile station.




Fig. 2 Reverse CDMA channels received at the base station

## Spectral mask

### Test purpose and concepts

This test ensures that the DUT does not influence other CDMA2000 devices transmitting in adjacent channels. There are two standard masks and a user-definable mask. The user mask requires parameter definition in addition to simply declaring the mask type.

### Test procedure

Perform the steps below to measure the spectral mask of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator).

Set the following parameters to measure spectral mask in CDMA2000 mode:

- 1 Press [MODE] and select [CDMA2000].
- 2 Press [MEAS] and select [Spectral Mask].

Set the following parameters in CDMA2000 mode to adjust the input signal:

- 3 Press [FREQ] and select [Center Freq]. Set the center frequency to the same value as the RF input frequency.
- 4 Use the [SPAN] and [MARKER] functions to adjust the trace so that it can be analyzed effectively.

### Test results

The Spectral Mask measurement result should look like Fig. 3. The upper side of the window shows the graphical result for Spectral Mask. The text window below shows the result for its suitability for the Spectral Mask (pass or fail). If it fails, the fail frequency and its fail level appear in this lower text window.




Fig. 3 Result of measuring spectral mask for CDMA2000 signal



## Channel power

### Test purpose and concepts

From this measurement, you can find the total transmitted power within a defined channel for a CDMA2000 modulated signal. This measurement is used to design, characterize, evaluate, and verify transmitters and their components or devices for base stations and mobile stations.

### Test procedure

Perform the steps below to measure the channel power of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator)

Set the following parameters to measure channel power in CDMA2000 mode:

- 1 Press [MODE] and select [CDMA2000].
- 2 Press [MEAS] and select [Channel Power].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 3 Press [FREQ] and select [Center Freq]. Set the center frequency to the same value as the RF input frequency.
- 4 Use the [SPAN] and [MARKER] functions to adjust the trace so that it can be analyzed effectively.

### Test results

The Channel Power measurement result should look like Fig. 4. The upper part of the window shows the graphical result for Channel Power. The lower text window shows the result as a numerical value for absolute power and its mean power spectral density.




Fig. 4 Result of measuring channel power for CDMA2000 signal

## Adjacent channel power ratio

### Test purpose and concepts

The system, which uses CDMA, uses ACPR (adjacent channel power ratio) for the linearity test for the power amplifier. ACPR is defined as the ratio of main channel power level to leakage power level, generated by its own signal. This means that when a specific channel signal goes on, we define how much disturbing signal is generated by the non-linearity of the power amplifier.

To maintain a quality call by avoiding channel interference, it is important to measure and reduce any adjacent channel leakage power transmitted from a mobile phone. The characteristics of adjacent channel leakage power are mainly determined by the transmitter design, particularly the low-pass filter.

In this measurement, you set the specific offsets and reference bandwidths. The radio specifications recommend some common setups, as shown in Table 3.

**Table 3 ACPR setup recommendation in CDMA2000 Std.**

Communication standard	Test device	Offset frequency	Integration bandwidth	Main channel power reference
CDMA2000	Mobile	+/-900 kHz	30 kHz	Power in 1.23 MHz (dBm)
		+/-1.995 MHz	30 kHz	
	Base	+/-765 kHz	30 kHz	
		+/-1.995 MHz	30 kHz	

### Test procedure

Perform the steps below to measure the ACPR of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator).

Set the following parameters to measure ACPR in CDMA2000 mode:

- 1 Press [MODE] and select [CDMA2000].
- 2 Press [MEAS] and select [ACPR].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 3 Press [FREQ] and select [Center Freq]. Set the center frequency to the same value as the RF input frequency.

## Test result

Fig. 5 shows the ACPR measurement result in spectrum view mode. It shows the spectrum trace result and its integration bandwidth in detail. The lower text window shows the result as a numerical value for lower and upper offset channel power levels in absolute and relative scale.




Fig. 5 Result of measuring ACPR for CDMA2000 signal

## Code domain analysis

### Test purpose and concepts

This code domain power view provides information about the in-channel characteristics of the CDMA2000 signal. It directly informs you of the active channels with their individual channel powers. Since the code domain measurements despread and descramble the CDMA2000 signal into its physical channels, the number of active channels of various symbol rates can be observed.

Code Domain Power gives the distribution of signal energy among the code-channels, normalized by the total signal energy. Since CDP is a measure of relative energy levels, it is also a measure of relative average power levels over the measurement interval.

The mobile station can transmit several Walsh codes simultaneously in the reverse channel. For example, it can transmit a Dedicated Control Channel in addition to a Pilot Channel in a traffic channel. Table 4 shows the Walsh codes that are allocated in the CDMA2000 reverse channel.

**Table 4 Walsh code used in CDMA2000 reverse channel**

Channel type	Walsh function
Reverse Pilot Channel	W0/32
Enhanced Access Channel	W2/8
Reverse Common Control Channel	W2/8
Reverse Dedicated Control Channel	W8/16
Reverse Fundamental Channel	W4/16
Reverse Supplement Channel 1	W1/2, W2/4
Reverse Supplement Channel 2	W2/4, W6/8

### Test procedure

Perform the steps below to measure the code domain power of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator)

Set the following parameters to measure code domain power in CDMA2000 mode:

- 1 Press [MODE] and select [*CDMA2000*].
- 2 Press [MEAS] and select [*Code Domain..*].
- 3 Press [*Code Domain Pwr*] or [*Code Domain Err*].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 4 Press [FREQ] and select [*Center Freq*]. Set the center frequency to the same value as the RF input frequency.

## Test result

The Code Domain Power and Error measurement results should look like Fig. 6 and Fig. 7 respectively. The upper trace shows the graphical result for Code Domain Power or Error for the I channel and the lower trace shows the same result for the Q channel. The X-axis shows the Walsh Code number and the Y-axis shows the relative power level for each code in dB.




Fig. 6 Result of measuring code domain power for CDMA2000 signal




Fig. 7 Result of measuring code domain error for CDMA2000 signal

## Modulation analysis

### Composite EVM

#### Test purpose and concepts

In a digitally modulated signal, it is possible to predict what the ideal magnitude and phase of the carrier should be at any time, based on the transmitted data sequence. The transmitter's modulated signal is compared to an ideal signal vector. Rho values are in the range of 0 to 1. A value of 1 indicates perfect correlation to the reference (high modulation quality). The CDMA2000 base station standards require that transmitters have a Rho performance of 0.912 or greater.

In constant amplitude modulation schemes, such as QPSK, the phase and frequency error are the metrics for modulation quality. So phase and frequency errors can be measures of modulation quality for the CDMA2000 system. This modulation quality is quantified through Error Vector Magnitude (EVM) measurements.

#### Test procedure

Perform the steps below to measure the EVM of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator).

Set the following parameters to measure EVM in CDMA2000 mode:

- 1 Press [MODE] and select [*CDMA2000*].
- 2 Press [MEAS] and select [*Composite EVM*].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 3 Press [FREQ] and select [*Center*]. Set the center frequency to the same value as the RF input frequency.

## Test result

The CDMA2000 Composite EVM measurement result should look like Fig. 8. The numerical values for modulation accuracy are shown on the left side of this measurement window. The modulation accuracy result lists are as follows:

EVM Error (RMS)

EVM Error (Peak)

Rho

Frequency Error

Peak CDE (I,Q)




Fig. 8 Result of measuring Composite EVM for CDMA2000 signal

## QPSK EVM

### Test purpose and concepts

Phase and frequency errors are measures of modulation quality for the CDMA2000 system. This modulation quality is quantified through QPSK EVM measurements. Since the base stations in CDMA2000 systems use the QPSK modulation scheme, the phase and frequency accuracies of the transmitter are critical to the communications system's performance.

A QPSK EVM measurement is useful only in constant amplitude modulation schemes, and it cannot be used to analyze complex modulated signals. The input signal must be a single coded CDMA2000 channel, like a single R-Pilot or a single R-FCH.

### Test procedure

Perform the steps below to measure the modulation quality of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator).

Set the following parameters to measure modulation quality in CDMA2000 mode.

- 1 Press [MODE] and select [*CDMA2000*].
- 2 Press [MEAS] and select [*QPSK EVM*].
- 3 Press [MEAS], [CONTROL] and set the [*Radio Config*] and [*Long Code Mask*].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 4 Press [FREQ] and select [*Center Freq*]. Set the center frequency to the same value as the RF input frequency.



## Test result

The CDMA2000 QPSK measurement result should look like Fig. 9. The numerical values for modulation accuracy are shown on the left side of this measurement window. The modulation accuracy result lists are as follows:

EVM Error (RMS)

EVM Error (Peak)

Origin Offset

Frequency Error




Fig. 9 Result of measuring QPSK EVM for CDMA2000 signal

## CCDF (complementary cumulative distribution function)

### Test purpose and concepts

Many of the digitally modulated signals now look noise-like in the time and frequency domain. This means that statistical measurements of the signals can be a useful characterization. Power Complementary Cumulative Distribution Function (CCDF) curves characterize the higher-level power statistics of a digitally modulated signal. The curves can be useful in determining design parameters for digital communications systems.

### Test procedure

Perform the steps below to measure the CCDF of a CDMA2000 signal.

Confirm the input signal level is below the maximum allowed input level (+16 dBm with no RF input attenuator).

Set the following parameters to measure CCDF in CDMA2000 mode:

- 1 Press [MODE] and select [CDMA2000].
- 2 Press [MEAS] and select [CCDF].

Set the following parameters in CDMA2000 mode to adjust analysis:

- 3 Press [FREQ] and select [Center Freq]. Set the center frequency to the same value as the RF input frequency.

### Test result

Fig. 10 shows the analysis result for CCDF for a CDMA2000 signal. The left side of the window shows the statistical result for power distribution of the input signal, with its numerical value. The right side of the window shows the result graphically, with a 'Gaussian distribution' reference.





Fig. 10 Result of measuring CCDF for CDMA2000 signal

---

# Menu descriptions

## CDMA2000 measurement mode


To use CDMA2000 measurement options, first set the system to CDMA2000 mode.



Select [MODE], then press [CDMA2000] mode at the right side of the screen.

## Frequency channel menu

Press [FREQ] in CDMA2000 mode:




You can access frequency functions from this menu:

Center Freq	Allows you to specify the frequency of the CDMA2000 input signal.
-------------	---

## Amplitude menu

Press [AMPL] in CDMA2000 mode:




Amplitude menu keys are used for setting functions that affect the way data on the vertical axis is displayed or corrected.

Attenuation	This allows you to set the value of input attenuation, in the range 10 to 55 dB, using the numeric keys, step keys or scroll knob.
Internal Amp	This switches the internal amplifier in or out.
Ref. Offset	This allows you to set an amplitude correction for the reference level.
Cable Offset	This allows you to set an amplitude correction for the cable between the DUT and the instrument.
Att. Offset	This allows you to set an amplitude correction for the attenuator level.

## Measure menu


Press [MEAS] in CDMA2000 mode:



Spectral Mask	Measures the spectral mask of a CDMA2000 signal. The pass/fail result, based on a 3GPP2 Std spectral mask, is measured and displayed.
Channel Power	Measures the channel power of a CDMA2000 signal. The channel power on a CDMA2000 bandwidth can be measured and displayed in the lower part of the measurement window.
ACPR	Measures the adjacent channel power of a CDMA2000 signal. A ratio of main channel power level versus leakage power is shown in the lower part of the measurement window.
Code Domain	Measures the code domain power and code domain error for a CDMA2000 signal. The X-axis is the number of the Walsh code, and the Y-axis represents the relative code power level for each Walsh code, in dB.
Composite EVM	Measures the composite EVM error for a CDMA2000 signal. It shows the result as a constellation diagram and numerical result for EVM Error (RMS, Peak), Rho, Frequency Error, Peak CDE (I,Q).
QPSK EVM	Measures the QPSK EVM error for a CDMA2000 signal. It shows the result as a constellation diagram and numerical result for EVM Error (RMS, Peak), Origin Offset, Frequency Error, Peak CDE (I,Q).
CCDF	Measure the CCDF (Complementary Cumulative Distribution Function) of a CDMA2000 signal.

## Measure control menu


Press [CONTROL] in CDMA2000 mode:



Radio Config	Selects the Radio Configuration Std for CDMA2000 analysis mode. The default setting is RC3, and it can be set to RC1, RC2, RC3, RC4 with a spreading rate of 1.
Long Code Mask	Sets the Long Code Mask for CDMA2000 mode (in Radio Configuration 3 or 4 only).
Symbols	Sets the number of symbols used for QPSK analysis (in QPSK measurement only).

## Marker menu


Press [MARKER] in CDMA2000 mode:



Select Marker	Allows you to select one of the four possible markers. Having selected one of the markers, use the other soft keys on this menu to specify the type of marker or measurement.
Normal	Sets the specified marker to be a normal marker.
Delta	A delta marker is actually a pair of markers. By pressing Delta, you set a pair of markers at your current frequency offset. One of this pair of markers is fixed while the second of the pair can be moved using the scroll knob or the numeric keys. The frequency difference and the amplitude difference between these two points are displayed.
OFF	Switches the specified marker off.
All OFF	Switches all markers off. All markers are removed from the graticule display, and if the marker table is also being displayed, all entries are removed from it.

## Display menu


Press [DISPLAY] in CDMA2000 mode:



White Mode	Changes the screen background to white.
Graticule	Allows you to display or hide the graticule lines on the display.

## Sweep menu


Press [SWEEP] in CDMA2000 mode:



Single	The analyzer performs one single measurement and then stops. You have to press [Restart] every time you want to make another measurement.
Continuous	The analyzer continuously measures the signal it is receiving and repeatedly updates the plots and the measurements.

### Preset menu

Press [PRESET] in CDMA2000 mode:



The sub menus of [PRESET] have the same function as in the basic spectrum analysis mode. Please refer to the Spectrum Analyzer Operating Manual (part number 46892/974) for other soft key functions.

---

# Detailed description of commands

## General

This section gives detailed descriptions of the device messages for the spectrum analyzer in functional order. The following example shows the command format.

Note that ‘Δ’ = ‘blank’ throughout this document.

### SA command

### SCPI command

	Command Name
Function	The explanation of the command.
Remote Command	SA CommandΔsw SA CommandΔf SA Command? SCPI CommandΔsw SCPI CommandΔf SCPI Command?
Response Message	sw or f (Depending on command)
Value of f	Range of sw or f (Depending on command)
Suffix code	Unit of f (Depending on command)
Initial setting	Initial value for SA System
Example	SA Command sw; SA Command f; SA Command?; SCPI Command sw; SCPI Command f; SCPI Command?;

## Amplitude

### RL

#### :DISPlay:WINDow:TRACe:Y[:SCALe]:RLEVel

	Reference Level
Function	Sets the reference level value.
Remote Command	RLΔf RL? :DISPlay:WINDow:TRACe:Y[:SCALe]:RLEVelΔf :DISPlay:WINDow:TRACe:Y[:SCALe]:RLEVel?
Response Message	Reference Level (dBm)
Value of f	~ 170 dBm to 30 dBm (step: 1 dBm)
Suffix code	None : dBm DBM : dBm
Initial setting	0 dBm
Example	RL 10; RL 30DBM; RL ?; DISP:WIND:TRAC:Y:RLEV 10; DISP:WIND:TRAC:Y:RLEV 30DBM; DISP:WIND:TRAC:Y:RLEV?;



## AT

### [[:SENSE]:POWer[:RF]:ATTenuation

	Attenuation
Function	Sets the amount of attenuation for the input attenuator.
Remote Command	ATΔf AT? [:SENSe]:POWer[:RF]:ATTenuationΔf [:SENSe]:POWer[:RF]:ATTenuation?
Response Message	amount of attenuation (dB)
Value of f	0 dB to 55 dB (step: 5 dB)
Suffix code	None : dB DB : dB
Initial setting	10 dB
Example	AT 10; AT 10DB; AT?; POW:ATT 10; POW:ATT 10DB; POW:ATT?;

## SD

### :DISPlay:LPLot:WINDow:TRACe:Y[:SCALe]:PDIVision

	Scale/Divide
Function	Sets the scale/divide value.
Remote Command	SDΔf SD? :DISPlay:LPLot:WINDow:TRACe:Y[:SCALe]:PDIVisionΔf :DISPlay:LPLot:WINDow:TRACe:Y[:SCALe]:PDIVision?
Response Message	Scale/Divide (dB/div)
Value of f	0.01 dB to 20 dB (step: 0.01 dB)
Suffix code	None : dB/div DB : dB/div
Initial setting	10 dB/div
Example	SD 5; SD 10DB; SD?; DISP:LPL:WIND:TRAC:Y:PDIV 5; DISP:LPL:WIND:TRAC:Y:PDIV 10DB; DISP:LPL:WIND:TRAC:Y:PDIV?;

## Display

### GRAT

#### :DISPlay:WINDow:TRACe:GRATicule:GRID[:STATe]

	Graticule
Function	Sets the display graticule to Type1 or Type2 or OFF.
Remote Command	GRAT $\Delta$ sw GRAT? :DISPlay:WINDow:TRACe:GRATicule:GRID[:STATe] $\Delta$ sw :DISPlay:WINDow:TRACe:GRATicule:GRID[:STATe]?
Response Message	TYPE1 : Type1 TYPE2 : Type2 OFF : OFF
Value of sw	TYPE1 : Type1 TYPE2 : Type2 OFF : OFF
Initial setting	TYPE1
Example	GRAT TYPE1; GRAT? DISP:WIND:TRAC:Y:GRAT:GRID TYPE1; DISP:WIND:TRAC:Y:GRAT:GRID?;

## WH

### :DISPlay:LPLot:WINDow:WHITe

	White Mode	
Function	Turns the white mode ON or OFF.	
Remote Command	WH $\Delta$ n	
	WH $\Delta$ sw	
	WH?	
	:DISPlay:LPLot:WINDow:WHITe $\Delta$ n	
	:DISPlay: LPLot:WINDow:WHITe $\Delta$ sw	
	:DISPlay: LPLot:WINDow:WHITe?	
Response Message	1	: ON
	0	: OFF
Value of n	1	: ON
	0	: OFF
Value of sw	ON	: ON
	OFF	: OFF
Initial setting	0	
Example	WH 1;	
	WH ON;	
	WH?	
	DISP:WIND:WHIT 1;	
	DISP:WIND:WHIT ON;	
	DISP:WIND:WHIT?;	

## File

### FREAD

#### :MMEMory:CATalog

Function	File Read
Remote Command	Reads files in the selected folder. FREAD?Δ‘file_folder’ :MMEMory:CATalog?Δ‘file_folder’
Value of file_folder	File Folder
Response Message	File Name,File Size.
Example	FREAD? ‘C:’; FREAD? ‘D:\Temp’; MMEM:CAT? ‘C:’; MMEM:CAT? ‘D:\Temp’;

## FSAVE

### :MMEMory:STORe

	File Save
Function	Saves the file, type defined by the extension.
Remote Command	FSAVEΔ'file_name' :MMEMory:STOReΔ'file_name'
Value of file_name	File Path + File Name
Supported Extension	sts : Status bmp : Bitmap jpg : jpeg png : png
Example	FSAVE 'C:\demo.sts'; MMEM:STRO 'C:\demo.sts';

## FLOAD

### :MMEMory:LOAD

	File Load
Function	Loads the selected file.
Remote Command	FLOAD?Δ‘file_name’ :MMEMory:LOADΔ‘file_name’
Value of file_name	File Path + File Name
Supported extension	sts : Status
Example	FLOAD ‘C:\demo.sts’; MMEM:LOAD ‘C:\demo.sts’;

## FDEL

### :MMEMory:DELeTe

	File Delete
Function	Deletes the selected file.
Remote Command	FDELΔ'file_name' :MMEMory:DELeTeΔ'file_name'
Value of file_name	File Path + File Name
Example	FDEL 'C:\demo.sts'; MMEM:DEL 'C:\demo.sts';



## FCOPY

### :MMEMory:COPY

	File Copy
Function	Copies the selected file.
Remote Command	FCOPYΔ'src_file_name', 'dest_file_name' :MMEMory:COPYΔ'src_file_name', 'dest_file_name'
Value of src_file_name, dest_file_name	File Path + File Name
Example	FCOPY 'C:\demo.sts', 'D:\demo.sts'; MMEM:COPY 'C:\demo.sts', 'D:\demo.sts';

## **FRENAME**

### **:MMEMory:MOVE**

	File Rename
Function	Renames the selected file.
Remote Command	FRENAMEΔ'src_file_name','dest_file_name' :MMEMory:MOVEΔ'src_file_name','dest_file_name'
Value of src_file_name, dest_file_name	File Path + File Name
Example	FRENAME 'C:\demo.sts','C:\demo1_1.sts'; MMEM:MOVE 'C:\demo1.sts','C:\demo1_1.sts';

## FMOVE

### MMEMory:DATA

	File Move
Function	Sends or receives binary data of the selected file. The maximum size of the sent file is 2 Mbyte, and the maximum size of the received file is 30 Mbyte.
Remote Command	FMOVEΔ'file_name',definite_length_block FMOVE?Δ'file_name' MMEMory:DATAΔ'file_name',definite_length_block MMEMory:DATA?Δ'file_name'
Value of file_name	File Path + File Name
Value of definite_length_block	# + number of file size + file size + file data
Example	FMOVE 'C:\Sended_Sample.txt',#14abcd; cf) #+1+4+abcd FMOVE? 'C:\Received_Sample.txt'; MMEM:DATA 'C:\ Sended_Sample.txt',#14abcd; MMEM:DATA? 'C:\ Received_Sample.txt';

## Frequency

### CF

#### **[[:SENSe]:FREQuency:CENTer**

	Center Frequency
Function	Sets the center frequency.
Remote Command	CFΔf CF? [:SENSe]:FREQuency:CENTerΔf [:SENSe]:FREQuency:CENTer?
Response Message	Center Frequency (Hz) (Range : 1 kHz to 3 / 8 / 13.2 / 26.5 GHz)
Value of f	1 kHz to 3 / 8 / 13.2 / 26.5 GHz
Suffix code	None : Hz (10 <sup>0</sup> ) HZ : Hz (10 <sup>0</sup> ) KHZ : kHz (10 <sup>3</sup> ) MHZ : MHz (10 <sup>6</sup> ) GHZ : GHz (10 <sup>9</sup> )
Initial setting	2 GHz
Example	CF 123456; CF 50MHZ; CF?; FREQ:CEN7T 123456; FREQ:CEN 50MHZ; FREQ:CEN?;

## REF

### :INPut:REFerence

	Reference
Function	Sets the 10 MHz Reference.
Remote Command	REFΔsw REF? :INPut:REFerenceΔsw :INPut:REFerence?
Response Message	INT : Internal EXT : External
Value of sw	INTernal: Internal EXTernal: External
Initial setting	INT
Example	REF INT; RFC? INP:REF INT; INP:REF?

## Marker

### MS[1~9]

#### :CALCulate:MARKer[1~9]:STATe

	Marker State
Function	Sets the selected marker state.
Remote Command	MS[1~9]Δn MS[1~9]Δsw MS[1~9]? :CALCulate:CCDF:MARKer[1~9]:STATeΔn :CALCulate:CCDF:MARKer[1~9]:STATeΔsw :CALCulate:CCDF:MARKer[1~9]:STATe?
Response Message	1 : ON 0 : OFF
Value of n	1 : ON 0 : OFF
Value of sw	ON : ON OFF : OFF
Initial setting	0
Example	MS 1; MS5 1; MS5?; CALC:CCDF:MARK:STAT 1; CALC:CCDF:MARK5:STAT ON; CALC:CCDF:MARK5:STAT?

## MM[1~9]

### :CALCulate:MARKer[1~9]:MODE

	Marker Mode
Function	Sets the selected marker to Normal or Delta mode.
Remote Command	MM[1~9]Δsw MM[1~9]?
:	CALCulate:MARKer[1~9]:MODEΔsw :CALCulate:MARKer[1~9]:MODE?
Response Message	POS : Normal DELT : Delta OFF : OFF
Value of sw	POSition : Normal DELTa : Delta OFF : OFF
Initial setting	OFF
Example	MM POS; MM5?; CALC:CCDF:MARK:MODE POS; CALC:CCDF:MARK5:MODE?

## MF[1~9]

### :CALCulate:MARKer[1~9]:X

	Marker Frequency
Function	Sets the marker frequency of the selected marker. If the marker mode is delta mode, it sets the difference value of the marker frequency and the delta marker frequency.
Remote Command	MF[1~9] $\Delta$ f MF[1~9]? :CALCulate:MARKer[1~9]:X $\Delta$ f :CALCulate:MARKer[1~9]:X?
Response Message	Marker Frequency (Hz)
Value of f	Start Frequency to Stop Frequency
Suffix code	None : Hz ( $10^0$ ) HZ : Hz ( $10^0$ ) KHZ : kHz ( $10^3$ ) MHZ : MHz ( $10^6$ ) GHZ : GHz ( $10^9$ )
Initial setting	Center Frequency
Example	MF 123456; MF5.1GHZ; MF5?; CALC:MARK:X 123456; CALC:MARK5:X 1GHZ; CALC:MARK5:X?



## MA[1~9]

### :CALCulate:MARKer[1~9]:Y

Function	Marker Amplitude Returns the amplitude data.
Remote Command	MA[1~9]? :CALCulate:MARKer[1~9]:Y?
Response Message	Marker Amplitude
Example	MA?; MA5? CALC:MARK:Y? CALC:MARK5:Y?

## MAO

### :CALCulate:LPLot:MARKer:AOFF

	Marker All OFF
Function	Turns off all markers.
Remote Command	MAO :CALCulate:LPLot:MARKer:AOFF
Example	MAO; CALC:LPL:MARK:AOFF;

## Measurement

### MEA

#### :MEASure:STARt

	Measure Start
Function	Starts the measurement.
Remote Command	MEASw MEA? :MEASure:STARtsw :MEASure:STARt?
Response Message	SEM : Spectral Mask CHP : Channel Power ACP : Adjacent Channel Power CDP : Code Domain Power CDE : Code Domain Error EVM : EVM QPSKEVM : QPSK EVM CCDF : CCDF
Value of sw	SEM : Spectral Mask CHP : Channel Power ACP : Adjacent Channel Power CDP : Code Domain Power CDE : Code Domain Error EVM : EVM QPSKEVM : QPSK EVM CCDF : CCDF
Example	MEA SEM; MEA?; MEAS:STAR SEM; MEAS:STAR?;

## SEMOUT

### :FETCh|MEASure|READ:SEMask

	Spectral Mask Output
Function	Returns the output of the Spectral Mask.
Remote Command	SEMOUT? :FETCh MEASure READ:SEMask?
Response Message	Pass/Fail State
Example	SEMOUT?; MEAS:SEM?;

## CHPOUT

### **:FETCh|MEASure|READ:CHPower**

	Channel Power Output
Function	Returns the output level of the Channel Power.
Remote Command	CHPOUT? :FETCh MEASure READ:CHPower?
Response Message	Channel Power (dBm), Power Spectral Density (dBm/Hz)
Example	CHPOUT?; MEAS:CHP?;

## ACPOUT

### :FETCh|MEASure|READ:ACPower

	Adjacent Channel Power Output
Function	Returns the output of Adjacent Channel Power.
Remote Command	ACPOUT? FETCh MEASure READ:ACPower?
Response Message	Lower 2nd ACP, Lower 1st ACP, Main CHP, Upper 1st ACP, Upper 2nd ACP (dBm)
Example	ACPOUT?; EAS:ACP?;

## CDPOUT

### :FETCh|MEASure|READ:CDPower

	Code Domain Power Output
Function	Returns the output of Code Domain Power.
Remote Command	CDPOUT? :FETCh MEASure READ:CDPower?
Response Message	Ch0 I-Power (dB), Ch0 Q-Power (dB), ~ Ch31 I-Power (dB), Ch31 Q-Power (dB)
Example	CDPOUT?; MEAS:CDP?;

## CDEOUT

### :FETCh|MEASure|READ:CDError

	Code Domain Error Output
Function	Returns the Code Domain Error.
Remote Command	CDEOUT? :FETCh MEASure READ:CDError?
Response Message	Ch0 I-Error (dB), Ch0 Q-Error (dB), –Ch16 I-Error(dB), – Ch16 Q-Error (dB)
Example	CDEOUT?; MEAS:CDE?;



## EVMOUT

### :FETCh|MEASure|READ:EVM

	EVM Output
Function	Returns the output of EVM.
Remote Command	EVMOUT? :FETCh MEASure READ:EVM?
Response Message	EVM Error (RMS) (%), EVM Error (Peak) (%), Rho (%), Frequency Error (Hz), Peak CDE(I) (dB)( RC3 or RC4 only), Peak CDE(Q) (dB) (RC3 or RC4 only)
Example	EVMOUT?; MEAS:EVM?;

## QPSKEVMOUT

### :FETCh|MEASure|READ:EVM:QPSK

	QPSK EVM Output
Function	Returns the output of QPSK EVM.
Remote Command	QPSKEVMOUT? :FETCh MEASure READ:EVM:QPSK?
Response Message	EVM Error (RMS) (%), EVM Error (Peak) (%), Origin Offset (%), Frequency Error (Hz)
Example	QPSKEVMOUT?; MEAS:EVM:QPSK?;

## CCDFOUT

### :FETCh|MEASure|READ:CCDF

	CCDF Output
Function	Returns the output of CCDF.
Remote Command	CCDFOUT? :FETCh MEASure READ:CCDF?
Response Message	Average Power (dBm), Average Power Percent (%), 10% Level Difference (dB), 1% Level Difference (dB), 0.1% Level Difference (dB), 0.01% Level Difference (dB), 0.001% Level Difference (dB), 0.0001% Level Difference (dB), Crest Level Difference (dB), Counts
Example	CCDFOUT?; MEAS:CCDF?;

## Measurement control

### RADIOCONFIG

	Radio Configuration
Function	Sets the radio configuration.
Remote Command	RADIOCONFIG□sw RADIOCONFIG?
Response Message	RC1 : RC1 RC2 : RC2 RC3 : RC3 RC4 : RC4
Value of sw	RC1 : RC1 RC2 : RC2 RC3 : RC3 RC4 : RC4
Initial setting	RC3
Example	RADIOCONFIG RC3; RADIOCONFIG?;

## LCMASK

	Long Code Mask
Function	Sets to Long Code Mask in composite EVM mode.
Remote Command	LCMASK $\Delta$ n LCMASK?
Response Message	Long Code Mask
Value of n	n $\geq$ 0
Initial setting	0
Example	LCMASK 0; LCMASK?;

## SYMB

	Symbols
Function	Sets to Symbols in QPSK EVM mode.
Remote Command	SYMBΔn SYMB?
Response Message	Symbols
Value of n	n >= 0
Initial setting	0
Example	SYMB 0; SYMB?;

## Mode

### MODE

#### :INSTrument[:SElect]

	Mode
Function	Sets current mode.
Remote Command	MODE $\Delta$ sw MODE? :INSTrument[:SElect] $\Delta$ sw :INSTrument[:SElect]?
Response Message	SA : Spectrum mode BASIC : Basic mode CDMA2000 : CDMA2000 mode
Value of sw	SA : Spectrum mode BASIC : Basic mode CDMA2000 : CDMA2000 mode
Initial setting	SA
Example	MODE SA; MODE?; INST SA; INST?;

Preset

PRST

:SYSTem:PRESet

	Preset
Function values.	Executes preset. All instrument parameters are set to default
Remote Command	PRST :SYSTem:PRESet
Example	PRST; SYST:PRES;



Printer

HCOPY

:HCOPy[:IMMediate]

	Hard Copy
Function	Prints entire screen image.
Remote Command	HCOPY :HCOPy[:IMMediate]
Example	HCOPY; HCOP;

Sweep

CO

:INITiate:CONTinuous

	Continuous Sweep
Function	Sets the continuous sweep mode. Repeats active sweep.
Remote Command	CO :INITiate:CONTinuous
Example	CO; INIT:CONT;

## SI

### :INITiate[:IMMediate]

Function	Single Sweep Sets the single sweep mode. After activating sweep, stops sweep repeating.
Remote Command	SI :INITiate[:Immediate]
Example	SI; INIT;

## System

### BEEP

	Beep
Function	Turns beep on or off when pressing keypad.
Remote Command	BEEPΔn BEEPΔsw BEEP?
Response Message	1 : ON 0 : OFF
Value of n	1 : ON 0 : OFF
Value of sw	ON : ON OFF : OFF
Initial setting	0
Example	BEEP 1; BEEP ON; BEEP?;

### ECHO

	Echo
Function	Turns echo on or off when controlled by a hyperterminal.
Remote Command	ECHOΔn ECHOΔsw ECHO?
Response Message	1 : ON 0 : OFF
Value of n	1 : ON 0 : OFF
Value of sw	ON : ON OFF : OFF
Initial setting	1
Example	ECHO 1; ECHO ON; ECHO?;

## **GPIB common commands**

### **\*CLS**

	Clear Status Command
Function	Clears the status byte register.
Remote Command	*CLS
Example	*CLS;

### **\*ESE**

	Standard Event Status Enable
Function	Sets the standard event status enable register.
Remote Command	*ESEΔn *ESE?
Response Message	Register Value
Value of n	0 to 255: represents the sum of the bit-weighted values.
Example	*ESE 20: *ESE?;

### **\*ESR?**

Function	Standard Event Status Register Query
Remote Command	Returns the current value in the standard event status register.
Response Message	*ESR?
Example	Register Value
	*ESR?;

### **\*IDN?**

Function	Identification Query
Remote Command	Returns the model name, etc of the equipment.
Response Message	*IDN?
Example	Company, Model, Serial, Version
	*IDN?;



### **\*OPC**

	Operation Complete Command
Function	Sets the standard event register bit 0 to 1 when the requested action is complete.
Remote Command	*OPC
Example	*OPC;

### **\*OPC?**

	Operation Complete Query
Function	Sets the output queue to 1 to generate a MAV summary message when all pending select device operations have completed.
Remote Command	*OPC?
Response Message	1
Example	*OPC?;

### **\*RST**

	Rest Command
Function	Resets the device.
Remote Command	*RST
Example	*RST;

### **\*SRE**

	Service Request Enable Command
Function	Sets the bits in the service request enable register.
Remote Command	*SREΔn *SRE?
Response Message	Register Value
Value of n	0 to 255: represents the sum of the bit-weighted values.
Example	*SRE 32; *SRE?;

**\*STB?**

Function Returns Status Byte Command  
 Returns the current values of the status bytes including the MSS bit.

Remote Command \*STB?

Response Message Register Value

Bit	Bit weight	Bit name	Condition of status byte register
7	128	----	0 = Not used
6	64	MSS	0 = Service not requested 1 = Service requested
5	32	ESB	0 = Event status not generated 1 = Event status generated
4	16	MAV	0 = No data in output queue 1 = Data in output queue
3	8	ESB2	0 = Event status not generated 1 = Event status generated
2	4	----	0 = Not used
1	2	----	0 = Not used
0	1	----	0 = Not used

Example \*STB?;

## GPIB common commands — others

### ESE2

	Event Status Enable (End)
Function	Allows the End Event Status Enable Register to select which bit in the corresponding Event Register causes a TRUE ESB summary message bit 3 when set.
Remote Command	ESE2Δn ESE2?
Response Message	Register Value
Value of n	0 to 255; represents the sum of the bit-weighted values.
Example	ESE2 1; ESE2?;

## ESR2?

Function	Event Status Register (End) Query Allows the sum of binary-weighted event bit values of the End Event Status Register to be read out by converting them to decimal. After readout, the End Event status Register is reset to 0.
Remote Command	ESR2?
Response Message	Register Value

Bit	Bit weight	Event	Description
7	128	Not used	Not used
6	64	Not used	Not used
5	32	Not used	Not used
4	16	Measurement completed	Measurement has completed (Peak search, OBW, X dB, Noise marker, Freq. Counter, Limit Pass/Fail..)
3	8	AUTO TUNE completed	AUTO TUNE has completed.
2	4	Averaging completed	Sweeping according to the specified AVERAGE number has completed.
1	2	Calibration completed	Temp Cal, Pre-Filter Cal, ZNC Cal., Level Cal.. has completed.
0	1	Sweep completed	A single sweep has completed or is in standby.

Example                      ESR2?;

## ERR

### :SYSTem:ERRor[:NEXT]

	Error Code
Function	Returns the error code of the current function. The error code is cleared.
Remote Command	ERR?
Response Message	Error code
Example	ERR?;



# Remote commands

## Ordered by function

Index	Description	SA Command	SCPI Command	Suffix
<b>Amplitude</b>	Ref. Level	RL	:DISPlay:WINDow:TRACe:Y[:SCALe]:RLEVel	<amplitude> ?
<b>Amplitude</b>	Attenuation	AT	[:SENSe]:POWer[:RF]:ATTenuation	<amplitude> ?
<b>Amplitude</b>	Scale/Div	SD	:DISPlay:WINDow:TRACe:Y[:SCALe]:PDIVision	<amplitude> ?
<b>Display</b>	Graticule	GRAT	:DISPlay:WINDow:TRACe:GRATICule:GRID[:STATe]	OFF ON 0 1 ?
<b>Display</b>	White Mode	WH	:DISPlay:WINDow:WHITe	OFF ON 0 1 ?
<b>File</b>	Read	FREAD	:MMEMory:CATalog	? <'directory_name'>
<b>File</b>	Save	FSAVE	:MMEMory:STORe	<'file_name'>
<b>File</b>	Load	FLOAD	:MMEMory:LOAD	<'file_name'>
<b>File</b>	Delete	FDEL	:MMEMory:DELeTe	<'file_name'>
<b>File</b>	Copy	FCOPY	:MMEMory:COPIY	<'file_name1'>,<'file_name2'>
<b>File</b>	Rename	FRENAME	:MMEMory:MOVE	<'file_name1'>,<'file_name2'>
<b>File</b>	Move	FMOVE	:MMEMory:DATA	<'file_name'>,<definite_length_block > <'file_name'>
<b>Frequency</b>	Center Frequency	CF	[:SENSe]:FREQuency:CENTer	<frequency> ?
<b>Frequency</b>	Reference	REF	:INPut:REFerence	INTernal EXTernal ?
<b>Marker</b>	Marker State	MS[1~9]	:CALCulate:MARKer[1~9]:STATe	OFF ON 0 1 ?
<b>Marker</b>	Marker Mode	MM[1~9]	:CALCulate:MARKer[1~9]:MODE	POSition DELTA OFF ?
<b>Marker</b>	Marker Freq	MF[1~9]	:CALCulate:MARKer[1~9]:X	<frequency> ?
<b>Marker</b>	Marker Amplitude	MA[1~9]	:CALCulate:MARKer[1~9]:Y	?
<b>Marker</b>	Marker All Off	MAO	:CALCulate:LPLot:MARKer:AOff	none
<b>Measurement</b>	Meas. Start	MEA	:MEASure:STARt	SEM CHP ACP CDP CDE EVM QPSKEVM CCDF ?
<b>Measurement</b>	Spectral Mask Output	SEMOUT	:FETCh MEASure READ:SEMask	?
<b>Measurement</b>	Channel Power	CHPOUT	:FETCh MEASure READ:CHPower	?
<b>Measurement</b>	Adjacent Channel Power	ACPOUT	:FETCh MEASure READ:ACPower	?
<b>Measurement</b>	Code Domain Power	CDPOUT	:FETCh MEASure READ:CDPower	?
<b>Measurement</b>	Code Domain Error	CDEOUT	:FETCh MEASure READ:CDError	?
<b>Measurement</b>	EVM	EVMOUT	:FETCh MEASure READ:EVM	?
<b>Measurement</b>	QPSK EVM	QPSKEVMOUT	:FETCh MEASure READ:EVM:QPSK	?
<b>Measurement</b>	CCDF Output	CCDFOUT	:FETCh MEASure READ:CCDF	?
<b>Meas Control</b>	Radio Configuration	RADIOCONFIG		RC1 RC2 RC3 RC4 ?
<b>Meas Control</b>	Long Code Mask	LCMASK		<integer> ?
<b>Meas Control</b>	Symbols	SYMB		<integer> ?
<b>Mode</b>	Mode	MODE	:INSTrument[:SELeCt]	SA BASIC CDMA2000 ?
<b>Preset</b>	Preset	PRST	:SYSTem:PRESet	none
<b>Printer</b>	Hard Copy	HCOPY	:HCOPY[:IMMediate]	none
<b>Sweep</b>	Single	SI	:INITiate:LPLot[:IMMediate]	none
<b>Sweep</b>	Continuous	CO	:INITiate:LPLot:CONTinuous	OFF ON 0 1 ?
<b>System</b>	Beep	BEEP		OFF ON 0 1 ?
<b>System</b>	Echo	ECHO		OFF ON 0 1 ?

## REMOTE COMMANDS

---

<b>Common</b>	*CLS	*CLS	*CLS	none
<b>Common</b>	*ESE	*ESE	*ESE	<integer> ?
<b>Common</b>	*ESR	*ESR	*ESR	?
<b>Common</b>	*IDN	*IDN	*IDN	?
<b>Common</b>	*OPC	*OPC	*OPC	?
<b>Common</b>	*RST	*RST	*RST	none
<b>Common</b>	*SRE	*SRE	*SRE	<integer> ?
<b>Common</b>	*STB	*STB	*STB	?
<b>Others</b>	ESE2	ESE2		<integer> ?
<b>Others</b>	ESR2	ESR2		?
<b>Others</b>	Error Code	ERR	:SYSTem:ERRor[:NEXT]	?

## Ordered by SA command

Index	Description	SA Command	SCPI Command	Suffix
Common	*CLS	*CLS	*CLS	none
Common	*ESE	*ESE	*ESE	<integer> ?
Common	*ESR	*ESR	*ESR	?
Common	*IDN	*IDN	*IDN	?
Common	*OPC	*OPC	*OPC	?
Common	*RST	*RST	*RST	none
Common	*SRE	*SRE	*SRE	<integer> ?
Common	*STB	*STB	*STB	?
Measurement	Adjacent Channel Power	ACPOUT	:FETCh MEASure READ:ACPower	?
Amplitude	Attenuation	AT	[[:SENSe]:POWeR[:RF]:ATTenuation	<amplitude> ?
System	Beep	BEEP		OFF ON 0 1 ?
Measurement	CCDF Output	CCDFOUT	:FETCh MEASure READ:CCDF	?
Measurement	Code Domain Error	CDEOUT	:FETCh MEASure READ:CDError	?
Measurement	Code Domain Power	CDPOUT	:FETCh MEASure READ:CDPower	?
Frequency	Center Frequency	CF	[[:SENSe]:FREQuency:CENTer	<frequency> ?
Measurement	Channel Power	CHPOUT	:FETCh MEASure READ:CHPower	?
Sweep	Continuous	CO	:INITiate:LPLot:CONTinuous	OFF ON 0 1 ?
System	Echo	ECHO		OFF ON 0 1 ?
Others	Error Code	ERR	:SYSTem:ERRor[:NEXT]	?
Others	ESE2	ESE2		<integer> ?
Others	ESR2	ESR2		?
Measurement	EVM	EVMOUT	:FETCh MEASure READ:EVM	?
File	Copy	FCOPY	:MMEMory:COpy	<'file_name1'>,<'file_name2'>
File	Delete	FDEL	:MMEMory:DELeTe	<'file_name'>
File	Load	FLOAD	:MMEMory:LOAD	<'file_name'>
File	Move	FMOVE	:MMEMory:DATA	<'file_name'>, definite_length_block ? <'file_name'>
File	Read	FREAD	:MMEMory:CATalog	? <'directory_name'>
File	Rename	FRENAME	:MMEMory:MOVE	<'file_name1'>,<'file_name2'>
File	Save	FSAVE	:MMEMory:STORe	<'file_name'>
Display	Graticule	GRAT	:DISPlay:WINDow:TRACe:GRATicule :GRID[:STATe]	OFF ON 0 1 ?
Printer	Hard Copy	HCOPY	:HCOPY[:IMMediate]	none
Meas Control	Long Code Mask	LCMASK		<integer> ?
Marker	Marker Amplitude	MA[1~9]	:CALCulate:MARKer[1~9]:Y	?
Marker	Marker All Off	MAO	:CALCulate:LPLot:MARKer:AOff	none
Measurement	Meas. Start	MEA	:MEASure:STARt	SEM CHP ACP CDP CDE  EVM QPSKEVM CCDF ?
Marker	Marker Freq	MF[1~9]	:CALCulate:MARKer[1~9]:X	<frequency> ?
Marker	Marker Mode	MM[1~9]	:CALCulate:MARKer[1~9]:MODE	POSITION DELTA OFF ?
Mode	Mode	MODE	:INSTrument[:SELeCt]	SA BASIC CDMA2000 ?
Marker	Marker State	MS[1~9]	:CALCulate:MARKer[1~9]:STATe	OFF ON 0 1 ?
Preset	Preset	PRST	:SYSTem:PRESet	none
Measurement	QPSK EVM	QPSKEVMOUT	:FETCh MEASure READ:EVM:QPSK	?
Meas Control	Radio Configuration	RADIOCONFIG		RC1 RC2 RC3 RC4 ?
Frequency	Reference	REF	:INPut:REFerence	INTernal EXTernal ?
Amplitude	Ref. Level	RL	:DISPlay:WINDow:TRACe:Y[:SCALe] :RLEVel	<amplitude> ?
Amplitude	Scale/Div	SD	:DISPlay:WINDow:TRACe:Y[:SCALe] :PDIVision	<amplitude> ?
Measurement	Spectral Mask Output	SEMOUT	:FETCh MEASure READ:SEMask	?

## REMOTE COMMANDS

---

Sweep	Single	<b>SI</b>	:INITiate:LPLot[:IMMediate]	none
Meas Control	Symbols	<b>SYMB</b>		<integer> ?
Display	White Mode	<b>WH</b>	:DISPlay:WINDow:WHITe	OFF ON 0 1 ?

## Ordered by SCPI command

Index	Description	SA Command	SCPI Command	Suffix
Common	*CLS	*CLS	*CLS	none
Common	*ESE	*ESE	*ESE	<integer> ?
Common	*ESR	*ESR	*ESR	?
Common	*IDN	*IDN	*IDN	?
Common	*OPC	*OPC	*OPC	?
Common	*RST	*RST	*RST	none
Common	*SRE	*SRE	*SRE	<integer> ?
Common	*STB	*STB	*STB	?
Marker	Marker All Off	MAO	:CALCulate:LPLot:MARKer:AOff	none
Marker	Marker Mode	MM[1~9]	:CALCulate:MARKer[1~9]:MODE	POSition DELTA OFF ?
Marker	Marker State	MS[1~9]	:CALCulate:MARKer[1~9]:STATe	OFF ON 0 1 ?
Marker	Marker Freq	MF[1~9]	:CALCulate:MARKer[1~9]:X	<frequency> ?
Marker	Marker Amplitude	MA[1~9]	:CALCulate:MARKer[1~9]:Y	?
Display	Graticule	GRAT	:DISPlay:WINDow:TRACe:GRATICule:GRID[:STATe]	OFF ON 0 1 ?
Amplitude	Scale/Div	SD	:DISPlay:WINDow:TRACe:Y[:SCALE]:PDIVision	<amplitude> ?
Amplitude	Ref. Level	RL	:DISPlay:WINDow:TRACe:Y[:SCALE]:RLEVel	<amplitude> ?
Display	White Mode	WH	:DISPlay:WINDow:WHITe	OFF ON 0 1 ?
Measurement	Adjacent Channel Power	ACPOUT	:FETCh MEASure READ:ACPowEr	?
Measurement	CCDF Output	CCDFOUT	:FETCh MEASure READ:CCDF	?
Measurement	Code Domain Error	CDEOUT	:FETCh MEASure READ:CDError	?
Measurement	Code Domain Power	CDPOUT	:FETCh MEASure READ:CDPowEr	?
Measurement	Channel Power	CHPOUT	:FETCh MEASure READ:CHPowEr	?
Measurement	EVM	EVMOUT	:FETCh MEASure READ:EVM	?
Measurement	QPSK EVM	QPSKEVMOUT	:FETCh MEASure READ:EVM:QPSK	?
Printer	Hard Copy	HCOPY	:HCOpy[:IMMediate]	none
Sweep	Continuous	CO	:INITiate:LPLot:CONTInuous	OFF ON 0 1 ?
Sweep	Single	SI	:INITiate:LPLot[:IMMediate]	none
Frequency	Reference	REF	:INPUt:REFerence	INTernal EXTernal ?
Mode	Mode	MODE	:INSTrument[:SElect]	SA BASIC CDMA2000 ?
Measurement	Meas. Start	MEA	:MEASure:STARt	SEM CHP ACP CDP CDE EVM QPSKEVM CCDF ?
File	Read	FREAD	:MMEMory:CATalog	? <'directory_name'>
File	Copy	FCOPY	:MMEMory:COpy	<'file_name1'>,<'file_name2'>
File	Move	FMOVE	:MMEMory:DATA	<'file_name'>,definite_length_block ? <'file_name'>
File	Delete	FDEL	:MMEMory:DELeTe	<'file_name'>
File	Load	FLOAD	:MMEMory:LOAD	<'file_name'>
File	Rename	FRENAME	:MMEMory:MOVE	<'file_name1'>,<'file_name2'>
File	Save	FSAVE	:MMEMory:STORe	<'file_name'>
Others	Error Code	ERR	:SYSTem:ERRor[:NEXT]	?
Preset	Preset	PRST	:SYSTem:PRESet	none
Frequency	Center Frequency	CF	[:SENSe]:FREQuency:CENTer	<frequency> ?
Amplitude	Attenuation	AT	[:SENSe]:POWer[:RF]:ATTenuation	<amplitude> ?



---

## Error codes

Code	Description
990	Not supported in current mode
991	Not installed (option)
992	System is busy
993	Execution error (EXE)
994	Query error (QYE)
995	Suffix error
996	Input data size over error
997	Undefined command
998	Unnecessary suffix insertion
999	Undefined suffix

---

# AEROFLEX LIMITED

## SOFTWARE LICENSE AND WARRANTY

This document is an Agreement between the user of this Licensed Software, the Licensee, and Aeroflex Limited ('Aeroflex'), the Licensor. By installing or commencing to use the Licensed Software you accept the terms of this Agreement. If you do not agree to the terms of this Agreement do not use the Licensed Software.

### 1. DEFINITIONS

The following expressions will have the meanings set out below for the purposes of this Agreement:

Add-In Application Software	Licensed Software that may be loaded separately from time to time into the Designated Equipment to improve or modify its functionality
Computer Application Software	Licensed Software supplied to run on a standard PC or workstation
Designated Equipment	means either: the single piece of equipment or system supplied by Aeroflex upon which the Licensed Software is installed; or a computer that is connected to a single piece of equipment or system supplied by Aeroflex upon which computer the Licensed Software is installed
Downloaded Software	any software downloaded from an Aeroflex web site
Embedded Software	Licensed Software that forms part of the Designated Equipment supplied by Aeroflex and without which the Equipment cannot function
License Fee	means either the fee paid or other consideration given to Aeroflex for the use of the Licensed Software on the Designated Equipment
Licensed Software	all and any programs, listings, flow charts and instructions in whole or in part including Add-in, Computer Application, Downloaded and Embedded Software supplied to work with Designated Equipment
PXI Software	Licensed Software specific to Aeroflex's 3000 Series PXI product range

### 2. LICENSE FEE

The Licensee shall pay the License Fee to Aeroflex in accordance with the terms of the contract between the Licensee and Aeroflex.

### 3. TERM

This Agreement shall be effective from the date of receipt or download (where applicable) of the Licensed Software by the Licensee and shall continue in force until terminated under the provisions of Clause 8.

### 4. LICENCE

- 4.1 The following rights and restrictions in this Article 4 apply to all Licensed Software unless otherwise expressly stated in other Articles of this Agreement.
- 4.2 Unless and until terminated, this License confers upon the Licensee the non-transferable and non-exclusive right to use the Licensed Software on the Designated Equipment.
- 4.3 The Licensee may not use the Licensed Software on other than the Designated Equipment, unless written permission is first obtained from Aeroflex and until the appropriate additional License Fee has been paid to Aeroflex.
- 4.4 The Licensee may not amend or alter the Licensed Software and shall have no right or license other than that stipulated herein.
- 4.5 Except as specifically permitted elsewhere in this Agreement the Licensee may make not more than two copies of the Licensed Software (but not the Authoring and Language Manuals) in machine-readable form for operational security and shall ensure that all such copies include Aeroflex's copyright notice, together with any features which disclose the name of the Licensed Software and the Licensee. Furthermore, the Licensee shall not permit the Licensed Software or any part to be disclosed in any form to any third party and shall maintain the Licensed Software in secure premises to prevent any unauthorized disclosure. The Licensee shall notify Aeroflex immediately if the Licensee has knowledge that any unlicensed party possesses the Licensed Software. The Licensee's obligation to maintain confidentiality shall cease when the Licensed Software and all copies have been destroyed or returned. The copyright in the Licensed Software shall remain with Aeroflex. The Licensee will permit Aeroflex at all reasonable times to audit the use of the Licensed Software.
- 4.6 The Licensee will not disassemble or reverse engineer the Licensed Software, nor sub-license, lease, rent or part with possession or otherwise transfer the whole or any part of the Licensed Software.



**5 ADDITIONAL LICENSE RIGHTS SPECIFIC TO PXI SOFTWARE****5.1 Definitions for PXI Software**

The following expressions will have the meanings set out below for the purposes of the supplementary rights granted in this Article.

PXI Drivers	All 3000 Series PXI module device drivers including embedded firmware that are installed at runtime
PXI Executable Applications	All executable applications supplied with each 3000 Series PXI module including:- PXI Studio Soft Front Panels (manual operation graphical user interfaces) Utilities including: RF Investigator, PXI Version Information and Self Test
PXI Spectrum Analysis Library	The spectrum analysis measurement suite library .dll software supplied with each 3000 Series PXI module
PXI Optional Application Library	Individual measurement suite available from a range of optional .dll application libraries

**5.2 PXI Drivers, PXI Executable Applications and PXI Spectrum Analysis Library License Rights**

Subject to the License granted in Article 4 hereof notwithstanding the limitations on number of copies in Clause 4.5 hereof, the Licensee is entitled to make and distribute as many copies of the PXI Drivers and PXI Executable Applications as necessary for use with 3000 Series PXI modules acquired by the Licensee from Aeroflex or its authorized distributor or reseller provided that the Licensee may not sell or charge a fee for the PXI Drivers and PXI Executable Applications.

**5.3 PXI Optional Application Library License Rights**

Subject to the License granted in Article 4 hereof notwithstanding the limitations on number of copies in Clause 4.5 hereof, the Licensee is entitled to distribute as many copies of any PXI Optional Application Library as necessary for use with 3000 Series PXI modules acquired by the Licensee from Aeroflex or its authorized distributor or reseller provided that:

5.3.1 copies of the applicable PXI Optional Application Library are used solely with 3000 Series PXI modules which the customer has purchased with the corresponding option or part number for the applicable PXI Optional Application Library; and

5.3.2 the Licensee may not sell or charge a fee for the PXI Optional Application Library.

**6 WARRANTY**

6.1 Aeroflex certifies that the Licensed Software supplied by Aeroflex will at the time of delivery function substantially in accordance with the applicable Software Product Descriptions, Data Sheets or Product Specifications published by Aeroflex.

6.2 The warranty period (unless an extended warranty for Embedded Software has been purchased) from date of delivery in respect of each type of Licensed Software is:

PXI Drivers	24 months
Embedded Software	12 months
Add-In Application Software	90 days
Computer Application Software	90 days
Downloaded Software	No warranty

6.3 If during the appropriate Warranty Period the Licensed Software does not conform substantially to the Software Product Descriptions, Data Sheets or Product Specifications Aeroflex will provide:

6.3.1 In the case of Embedded Software and at Aeroflex's discretion either a fix for the problem or an effective and efficient work-around.

6.3.2 In the case of Add-In Application Software and Computer Application Software and at Aeroflex's discretion replacement of the software or a fix for the problem or an effective and efficient work-around.

6.4 Aeroflex does not warrant that the operation of any Licensed Software will be uninterrupted or error free.

6.5 The above Warranty does not apply to:

6.5.1 Defects resulting from software not supplied by Aeroflex, from unauthorized modification or misuse or from operation outside of the specification.

6.5.2 Third party produced proprietary software which Aeroflex may deliver with its products, in such case the third party software license agreement including its warranty terms shall apply.

6.6 The remedies offered above are sole and exclusive remedies and to the extent permitted by applicable law are in lieu of any implied conditions, guarantees or warranties whatsoever and whether statutory or otherwise as to the Licensed Software all of which are hereby expressly excluded.

**7. INDEMNITY**

7.1 Aeroflex shall defend, at its expense, any action brought against the Licensee alleging that the Licensed Software infringes any patent, registered design, trademark or copyright, and shall pay all Licensor's costs and damages finally awarded up to an aggregate equivalent to the License Fee provided the Licensee shall not have done or permitted to be done anything which may have been or become any such infringement and shall have exercised reasonable care in protecting the same failing which the Licensee shall indemnify Aeroflex against all claims costs and damages incurred and that Aeroflex is given prompt written notice of such claim and given information, reasonable assistance and sole authority to defend or settle such claim on behalf of the Licensee. In the defense or settlement of any such claim, Aeroflex may obtain for the Licensee the right to continue using the Licensed Software or replace it or modify it so that it becomes non-infringing.

7.2 Aeroflex shall not be liable if the alleged infringement:

- 7.2.1 is based upon the use of the Licensed Software in combination with other software not furnished by Aeroflex, or
  - 7.2.2 is based upon the use of the Licensed Software alone or in combination with other software in equipment not functionally identical to the Designated Equipment, or
  - 7.2.3 arises as a result of Aeroflex having followed a properly authorized design or instruction of the Licensee, or
  - 7.2.4 arises out of the use of the Licensed Software in a country other than the one disclosed to Aeroflex as the intended country of use of the Licensed Software at the commencement of this Agreement.
- 7.3 Aeroflex shall not be liable to the Licensee for any loss of use or for loss of profits or of contracts arising directly or indirectly out of any such infringement of patent, registered design, trademark or copyright. Notwithstanding anything in this Agreement to the contrary, the total liability of Aeroflex and its employees, in contract, tort, or otherwise (including negligence, warranty, indemnity, and strict liability) howsoever arising out of this License shall be limited to the total amount of the License Fee and total support fees actually paid to Aeroflex by the Licensee.

#### **8. TERMINATION**

- 8.1 Notwithstanding anything herein to the contrary, this License shall forthwith determine if the Licensee:
- 8.1.1 As an individual has a Receiving Order made against him or is adjudicated bankrupt or compounds with creditors or as a corporate body, compounds with creditors or has a winding-up order made against it or
  - 8.1.2 Parts with possession of the Designated Equipment.
- 8.2 This License may be terminated by notice in writing to the Licensee if the Licensee shall be in breach of any of its obligations hereunder and continue in such breach for a period of 21 days after notice thereof has been served on the Licensee.
- 8.3 On termination of this Agreement for any reason, Aeroflex may require the Licensee to return to Aeroflex all copies of the Licensed Software in the custody of the Licensee and the Licensee shall, at its own cost and expense, comply with such requirement within 14 days and shall, at the same time, certify to Aeroflex in writing that all copies of the Licensed Software in whatever form have been obliterated from the Designated Equipment.

#### **9. THIRD PARTY LICENCES**

- 9.1 The Licensed Software or part thereof may be the proprietary property of third party licensors. In such an event such third party licensors (as may be referenced on the software media, or any on screen message on start up of the software or on the order acknowledgement) and/or Aeroflex may directly enforce the terms of this Agreement and may terminate the Agreement if the Licensee is in breach of the conditions contained herein.
- 9.2 If any third party software supplied with the Licensed Software is supplied with, or contains or displays the third party's own license terms then the Licensee shall abide by such third party license terms (for the purpose of this Article the term "third party" shall include other companies within the Aeroflex group of companies).

#### **10. EXPORT REGULATIONS**

The Licensee undertakes that where necessary the Licensee will conform with all relevant export regulations imposed by the Governments of the United Kingdom and/or the United State of America.

#### **11. U.S. GOVERNMENT RESTRICTED RIGHTS**

The Licensed Software and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software-Restricted Rights at 48 CFR 52.227-19, as applicable.

#### **12. NOTICES**

Any notice to be given by the Licensee to Aeroflex shall be addressed to:  
Aeroflex Limited, Longacres House, Six Hills Way, Stevenage, SG1 2AN, UK.

#### **13. LAW AND JURISDICTION**

This Agreement shall be governed by the laws of England and shall be subject to the exclusive jurisdiction of the English courts. This agreement constitutes the whole agreement between the parties and may be changed only by a written agreement signed by both parties.

**CHINA Beijing**

Tel: [+86] (10) 6539 1166  
Fax: [+86] (10) 6539 1778

**CHINA Shanghai**

Tel: [+86] (21) 5109 5128  
Fax: [+86] (21) 5150 6112

**FINLAND**

Tel: [+358] (9) 2709 5541  
Fax: [+358] (9) 804 2441

**FRANCE**

Tel: [+33] 1 60 79 96 00  
Fax: [+33] 1 60 77 69 22

**GERMANY**

Tel: [+49] 8131 2926-0  
Fax: [+49] 8131 2926-130

**HONG KONG**

Tel: [+852] 2832 7988  
Fax: [+852] 2834 5364

**INDIA**

Tel: [+91] 80 [4] 115 4501  
Fax: [+91] 80 [4] 115 4502

**JAPAN**

Tel: [+81] 3 3500 5591  
Fax: [+81] 3 3500 5592

**KOREA**

Tel: [+82] (2) 3424 2719  
Fax: [+82] (2) 3424 8620

**SCANDINAVIA**

Tel: [+45] 9614 0045  
Fax: [+45] 9614 0047

**SPAIN**

Tel: [+34] (91) 640 11 34  
Fax: [+34] (91) 640 06 40

**UK Cambridge**

Tel: [+44] (0) 1763 262277  
Fax: [+44] (0) 1763 285353

**UK Stevenage**

Tel: [+44] (0) 1438 742200  
Fax: [+44] (0) 1438 727601  
Freephone: 0800 282388

**USA**

Tel: [+1] (316) 522 4981  
Fax: [+1] (316) 522 1360  
Toll Free: (800) 835 2352

*As we are always seeking to improve our products, the information in this document gives only a general indication of the product capacity, performance and suitability, none of which shall form part of any contract.  
We reserve the right to make design changes without notice.*

web [www.aeroflex.com](http://www.aeroflex.com)

Email [info-test@aeroflex.com](mailto:info-test@aeroflex.com)

November 2008