

**MT1000A Network Master Pro  
MT1100A Network Master Flex  
Remote Scripting Operation Manual**

12th Edition

**ANRITSU CORPORATION**

Document No.: M-W3736AE-12.0

- 
- This is an addendum to “Network Master Pro Operation Manual” and “Network Master Flex Operation Manual”.
  - For safety and warning information, please read “Network Master Pro Operation Manual” or “Network Master Flex Operation Manual” before attempting to use the equipment.
  - Keep this manual with the equipment.

#### Notes On Export Management

This product and its manuals may require an Export License/Approval by the Government of the product’s country of origin for re-export from your country. Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not. When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

October 6, 2014 (First Edition)  
October 21, 2016 (12th Edition)

---

Copyright ©2014-2016, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

---

# About This Manual

This operation manual describes the SCPI (Standard Commands for Programmable Instruments) commands for Network Master Pro/Flex.

**Note:** SCPI commands described in this manual are supported in Network Master Pro/Flex version 7.02.

Some commands or queries in this manual may require that specific hardware or software options are installed. These options must be purchased separately.

This operation manual uses the notations described in the following standards:

- IEEE: Std 488.2-1992
- SCPI: VERSION 1999.0 (SCPI Consortium)

---

# Contents

<b>1</b>	<b>Overview</b>	<b>45</b>
1.1	Ethernet Based Remote Control . . . . .	45
1.1.1	Connecting Cable . . . . .	45
1.1.2	Connect to an Instrument . . . . .	46
1.1.3	Ethernet Remote Control Settings . . . . .	46
1.1.4	Communication Buffers . . . . .	46
1.2	Program Messages . . . . .	47
1.2.1	Program Message Unit . . . . .	47
1.2.2	Program Headers . . . . .	48
1.2.3	Program Data . . . . .	49
1.2.4	Program Message Terminator . . . . .	50
1.2.5	Compound Program Messages . . . . .	50
1.2.6	Sequential Execution . . . . .	50
1.3	Response Messages . . . . .	51
1.3.1	Response Data . . . . .	51
1.3.2	Response Messages Terminator . . . . .	53
1.3.3	Prompt . . . . .	53
1.4	Status . . . . .	54
1.4.1	IEEE488.2 Standard Status and SCPI-defined Registers . . . . .	54
1.4.2	Network Master Unique Status Registers . . . . .	58
1.4.3	Reading, Writing and Clearing Status Registers . . . . .	61
1.5	Controller Example . . . . .	63
1.5.1	PuTTY . . . . .	63
1.6	Definitions . . . . .	66
1.6.1	NaN (Not a Number) . . . . .	66
1.6.2	→ Right Arrow . . . . .	66
1.6.3	Data Bit (DB) . . . . .	66
1.6.4	Port Number (Logical Port) . . . . .	66
<b>2</b>	<b>SCPI Conformance Information</b>	<b>69</b>
2.1	SCPI Version . . . . .	69
2.2	IEEE 488.2 Mandatory Commands . . . . .	70
2.2.1	*CLS . . . . .	70
2.2.2	*ESE . . . . .	70
2.2.3	*ESR? . . . . .	71
2.2.4	*IDN? . . . . .	71
2.2.5	*OPC . . . . .	71
2.2.6	*RST . . . . .	72
2.2.7	*SRE . . . . .	72
2.2.8	*STB? . . . . .	73
2.2.9	*TST? . . . . .	73
2.2.10	*WAI . . . . .	73
2.3	SCPI System Subsystem Commands . . . . .	74
2.3.1	SYSTem:VERSion? . . . . .	74
2.3.2	SYSTem:ERRor[:NEXT]? . . . . .	74
2.3.3	SYSTem:ERRor:ADDitional[:MESSAge] . . . . .	74
2.3.4	SYSTem:DATE . . . . .	75
2.3.5	SYSTem:TIME . . . . .	75
2.3.6	SYSTem:REBoot . . . . .	75

2.3.7	SYSTem:GPS:NSATellites?	76
2.3.8	SYSTem:GPS:TIME?	76
2.3.9	SYSTem:GPS:LOCation?	76
2.3.10	SYSTem:COMMunicate:TERMinator	76
2.3.11	SYSTem:PROMpt	76
2.3.12	SYSTem:LOCal:CONTRol	77
2.3.13	SYSTem:TIMing:EXTRernal?	77
2.3.14	SYSTem:STIMuli:INSert	77
2.3.15	SYSTem:STIMuli:CLR	77
2.3.16	SYSTem:WAIT[:IDLE]	78
2.3.17	SYSTem:WAIT:DURation	78
2.3.18	SYSTem:APPLication	78
2.3.19	SYSTem:APPLication?	78
2.4	SCPI Instrument Subsystem Commands	79
2.4.1	Connection to Application Server	79
2.4.2	Connection to multiple applications	79
2.4.3	Connection by multi-user	79
2.4.4	Force Termination of application Server	79
2.4.5	INSTrument:STARt[:DEFault]	81
2.4.6	INSTrument:STARt:LAST	82
2.4.7	INSTrument:STARt:GUI	82
2.4.8	INSTrument:TERMinate	82
2.4.9	INSTrument:TERMinate:FORCe	82
2.4.10	INSTrument:COUNT?	82
2.4.11	INSTrument:CATalog?	83
2.4.12	INSTrument:STATe?	83
2.4.13	INSTrument:CONNect	83
2.4.14	INSTrument:CONNect:ALL	83
2.4.15	INSTrument:CONNect[:CATalog]?	84
2.4.16	INSTrument:DISConnect	84
2.4.17	INSTrument[:SELect]	84
2.4.18	INSTrument:ERRor[:NEXT]?	85
2.4.19	INSTrument:PORT?	85
2.4.20	INSTrument:PORT:FREE?	85
2.4.21	INSTrument:PORT:CATalog?	85
2.4.22	INSTrument:MODule<Md>:CATalog?	85
2.4.23	INSTrument:CTRL:NAME?	86
2.4.24	INSTrument:CTRL:SN?	86
2.4.25	INSTrument:CTRL:TRT?	86
2.4.26	INSTrument:CTRL:OPTion:CATalog?	86
2.4.27	INSTrument:MODule<Md>:NAME?	86
2.4.28	INSTrument:MODule<Md>:SN?	86
2.4.29	INSTrument:MODule<Md>:TRT?	87
2.4.30	INSTrument:MODule<Md>:OPTion:CATalog?	87
2.5	SCPI Status Subsystem Commands	88
2.5.1	STATus:OPERation[:EVENT]?	88
2.5.2	STATus:OPERation:CONDition?	88
2.5.3	STATus:OPERation:ENABle	88
2.5.4	STATus:OPERation:PTRansition	89
2.5.5	STATus:OPERation:NTRansition	89
2.5.6	STATus:QUEStionable[:EVENT]?	89
2.5.7	STATus:QUEStionable:CONDition?	90
2.5.8	STATus:QUEStionable:ENABle	90
2.5.9	STATus:QUEStionable:PTRansition	90
2.5.10	STATus:QUEStionable:NTRansition	91
2.5.11	STATus:PORT[:EVENT]?	91
2.5.12	STATus:PORT:CONDition?	91
2.5.13	STATus:PORT:ENABle	91
2.5.14	STATus:PORT:PTRansition	92

2.5.15	STATus:PORT:NTRansition	92
2.5.16	STATus:PRESet	93
2.5.17	STATus:INTerface:PORT<Pt>[:EVENTt]?	93
2.5.18	STATus:INTerface:PORT<Pt>:CONDition?	94
2.6	Mass Memory Subsystem Commands	95
2.6.1	MMEMemory:LOAD	95
2.6.2	MMEMemory:STORe:STATe	95
2.6.3	MMEMemory:STORe:DATA	95
2.6.4	MMEMemory:DELeTe	96
2.6.5	MMEMemory:DATA?	96
2.6.6	MMEMemory:COpy	96
2.6.7	MMEMemory:MOVE	96
2.6.8	MMEMemory:INFO?	97
2.6.9	MMEMemory:CATalog?	97
2.6.10	MMEMemory:DCATalog?	97
2.6.11	MMEMemory:MDIRectory	97
2.6.12	MMEMemory:RDIRectory	98
2.6.13	MMEMemory:SAVE	98
<b>3</b>	<b>No frame</b>	<b>99</b>
3.1	Interface Setup	99
3.1.1	NFRame:PORT<Pt>:INTerface:TYPE	99
3.1.2	NFRame:PORT<Pt>:INTerface:BITRate	99
3.1.3	NFRame:PORT<Pt>:INTerface:LANE	100
3.1.4	NFRame:PORT<Pt>:TIMing	100
3.1.5	NFRame:PORT<Pt>[:RX]:INTerface:PATtern:FOLLow	101
3.1.6	NFRame:PORT<Pt>:TX:INTerface:PATtern	101
3.1.7	NFRame:PORT<Pt>:RX:INTerface:PATtern	102
3.1.8	NFRame:PORT<Pt>:TX:INTerface:PINVersion	102
3.1.9	NFRame:PORT<Pt>:RX:INTerface:PINVersion	102
3.1.10	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PATtern	103
3.1.11	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PATtern	103
3.1.12	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PINVersion	104
3.1.13	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PINVersion	104
3.1.14	NFRame:PORT<Pt>:TX:INTerface:PATtern:LANE:FOLLow	104
3.1.15	NFRame:PORT<Pt>:RX:INTerface:PATtern:LANE:FOLLow	105
3.2	Stimuli	105
3.2.1	NFRame:PORT<Pt>:STIMuli:TX:FOFFset	105
3.2.2	NFRame:PORT<Pt>:STIMuli:TX:LANE	106
3.3	Result	106
3.3.1	NFRame:PORT<Pt>[:RX]:IFETch?	106
3.4	Status	107
3.4.1	NFRame:STATus:PORT<Pt>[:RX]:AESummary[:EVENTt]?	107
3.4.2	NFRame:STATus:PORT<Pt>[:RX]:AESummary:CONDition?	107
3.4.3	NFRame:STATus:PORT<Pt>[:RX]:ALARm[:EVENTt]?	107
3.4.4	NFRame:STATus:PORT<Pt>[:RX]:ALARm:CONDition?	107
3.4.5	NFRame:STATus:PORT<Pt>[:RX]:ERRor[:EVENTt]?	108
3.4.6	NFRame:STATus:PORT<Pt>[:RX]:ERRor:CONDition?	108
3.4.7	NFRame:STATus:PORT<Pt>[:RX]:PSLevel?	108
3.4.8	NFRame:STATus:PORT<Pt>:TX:PSLevel?	108
3.4.9	NFRame:STATus:PORT<Pt>[:RX]:PFRequency?	108
3.4.10	NFRame:STATus:PORT<Pt>[:RX]:PDEVIation?	109
3.4.11	NFRame:STATus:PORT<Pt>[:RX]:PCDRlock?	109
<b>4</b>	<b>CPRI</b>	<b>111</b>
4.1	Port	111
4.1.1	CPRI:PORT<Pt>:MODE	111
4.1.2	CPRI:PORT<Pt>:TIMing:SOURce	111
4.1.3	CPRI:PORT<Pt>:LRATe	112
4.1.4	CPRI:PORT<Pt>:CONTEnts	112

4.1.5	CPRI:PORT<Pt>:PATtern	113
4.1.6	CPRI:PORT<Pt>:PINVersion	113
4.1.7	CPRI:PORT<Pt>:UP32	113
4.1.8	CPRI:PORT<Pt>:PVERsion	114
4.1.9	CPRI:PORT<Pt>:PROLe	114
4.1.10	CPRI:PORT<Pt>:SSEQence	114
4.1.11	CPRI:PORT<Pt>:CMHDlc	115
4.1.12	CPRI:PORT<Pt>:EENable	115
4.1.13	CPRI:PORT<Pt>:CMEPointer	116
4.1.14	CPRI:PORT<Pt>:SETup:FOLLow	116
4.2	Stimuli	117
4.2.1	CPRI:PORT<Pt>:STIMuli:ALARm	117
4.2.2	CPRI:PORT<Pt>:STIMuli:AINSerTion	117
4.2.3	CPRI:PORT<Pt>:STIMuli:ERRor	118
4.2.4	CPRI:PORT<Pt>:STIMuli:EINSerTion	118
4.2.5	CPRI:PORT<Pt>:STIMuli:EBLength	118
4.2.6	CPRI:PORT<Pt>:STIMuli:FOFFset	119
4.3	Result	120
4.3.1	CPRI:PORT<Pt>:IFETch?	120
4.4	Status	121
4.4.1	CPRI:PORT<Pt>:STATus:AESummary[:EVENT]?	121
4.4.2	CPRI:PORT<Pt>:STATus:AESummary:CONDiton?	121
4.4.3	CPRI:PORT<Pt>:STATus:ALARm<section>[:EVENT]?	121
4.4.4	CPRI:PORT<Pt>:STATus:ALARm<section>:CONDition?	122
4.4.5	CPRI:PORT<Pt>:STATus:ERRor[:EVENT]?	122
4.4.6	CPRI:PORT<Pt>:STATus:ERRor:CONDition?	122
4.4.7	CPRI:PORT<Pt>:STATus:TX:PSLevel?	122
4.4.8	CPRI:PORT<Pt>:STATus:RX:PSLevel?	122
4.4.9	CPRI:PORT<Pt>:STATus:TX:PDEViation?	123
4.4.10	CPRI:PORT<Pt>:STATus:RX:PDEViation?	123
4.4.11	CPRI:PORT<Pt>:STATus:TX:PBRate?	123
4.4.12	CPRI:PORT<Pt>:STATus:RX:PBRate?	123
4.4.13	CPRI:PORT<Pt>:STATus:TX:PPBRate?	123
4.4.14	CPRI:PORT<Pt>:STATus:RX:PPBRate?	123
4.4.15	CPRI:PORT<Pt>:STATus:LINK:STATE?	124
4.4.16	CPRI:PORT<Pt>:STATus:LINK:PROLe?	124
4.4.17	CPRI:PORT<Pt>:STATus:RX:LINK:PVERsion?	124
4.4.18	CPRI:PORT<Pt>:STATus:RX:LINK:HRATE?	124
4.4.19	CPRI:PORT<Pt>:STATus:RX:LINK:POINterp?	124
4.4.20	CPRI:PORT<Pt>:STATus:TX:LINK:PVERsion?	124
4.4.21	CPRI:PORT<Pt>:STATus:TX:LINK:HRATE?	125
4.4.22	CPRI:PORT<Pt>:STATus:TX:LINK:POINterp?	125
4.5	RTD	126
4.5.1	CPRI:PORT<Pt>:RTD:ENABle	126
4.5.2	CPRI:PORT<Pt>:RTD:MLIMit	126
4.5.3	CPRI:PORT<Pt>:RTD:NUMBer?	126
4.5.4	CPRI:PORT<Pt>:RTD:ATIME?	126
4.5.5	CPRI:PORT<Pt>:RTD:MTIME?	127
4.5.6	CPRI:PORT<Pt>:RTD:LTIME?	127
4.6	APS	128
4.6.1	CPRI:PORT<Pt>:APS:ENABle	128
4.6.2	CPRI:PORT<Pt>:APS:EVENT	128
4.6.3	CPRI:PORT<Pt>:APS:PERiod	129
4.6.4	CPRI:PORT<Pt>:APS:MLIMit	129
4.6.5	CPRI:PORT<Pt>:APS:NUMBer?	129
4.6.6	CPRI:PORT<Pt>:APS:ATIME?	129
4.6.7	CPRI:PORT<Pt>:APS:MTIME?	130
4.6.8	CPRI:PORT<Pt>:APS:LTIME?	130
4.6.9	CPRI:PORT<Pt>:APS:CTIME?	130

<b>5</b>	<b>2 Mbps</b>	<b>131</b>
5.1	Receiver	131
5.1.1	TMBPs:RX<Pt>[:ENABLEd]	131
5.1.2	TMBPs:RX<Pt>:FOLLow	131
5.1.3	TMBPs:RX<Pt>:CONNector	132
5.1.4	TMBPs:RX<Pt>:MODE	132
5.1.5	TMBPs:RX<Pt>:SENSitivity	132
5.1.6	TMBPs:RX<Pt>:CODE	133
5.1.7	TMBPs:RX<Pt>:PCMFrame	133
5.1.8	TMBPs:RX<Pt>:CRC4	133
5.1.9	TMBPs:RX<Pt>:EBITs	134
5.1.10	TMBPs:RX<Pt>:PATtern	134
5.1.11	TMBPs:RX<Pt>:PINVersion	135
5.1.12	TMBPs:RX<Pt>:PTSLots	135
5.1.13	TMBPs:RX<Pt>:UP16	136
5.1.14	TMBPs:RX<Pt>:UP32	136
5.1.15	TMBPs:RX<Pt>:UP2K	136
5.1.16	TMBPs:RX<Pt>:AUDio	137
5.1.17	TMBPs:RX<Pt>:ATSLot	137
5.1.18	TMBPs:RX<Pt>:CAS	137
5.2	Transmitter	138
5.2.1	TMBPs:TX<Pt>[:ENABLEd]	138
5.2.2	TMBPs:TX<Pt>:FOLLow	138
5.2.3	TMBPs:TX<Pt>:CONNector	138
5.2.4	TMBPs:TX<Pt>:DINSert[:ENABLE]	139
5.2.5	TMBPs:TX<Pt>:TIMing	139
5.2.6	TMBPs:TX<Pt>:FOFFset	139
5.2.7	TMBPs:TX<Pt>:CODE	140
5.2.8	TMBPs:TX<Pt>:PCMFrame	140
5.2.9	TMBPs:TX<Pt>:CRC4	140
5.2.10	TMBPs:TX<Pt>:SABits	141
5.2.11	TMBPs:TX<Pt>:SABMode	141
5.2.12	TMBPs:TX<Pt>:SABMode?	142
5.2.13	TMBPs:TX<Pt>:PATtern	142
5.2.14	TMBPs:TX<Pt>:PINVersion	142
5.2.15	TMBPs:TX<Pt>:PTSLots	143
5.2.16	TMBPs:TX<Pt>:UP16	143
5.2.17	TMBPs:TX<Pt>:UP32	143
5.2.18	TMBPs:TX<Pt>:UP2K	144
5.2.19	TMBPs:TX<Pt>:UTSLots	144
5.2.20	TMBPs:TX<Pt>:SCContent	145
5.2.21	TMBPs:TX<Pt>:SCTSlot	145
5.2.22	TMBPs:TX<Pt>:TFR	145
5.2.23	TMBPs:TX<Pt>:TLEVel	146
5.2.24	TMBPs:TX<Pt>:CAS	146
5.2.25	TMBPs:TX<Pt>:CASChannel	146
5.2.26	TMBPs:TX<Pt>:CASBits	147
5.2.27	TMBPs:TX<Pt>:COCBits	147
5.3	Stimuli	148
5.3.1	TMBPs:STIMuli:TX<Pt>:ALARm	148
5.3.2	TMBPs:STIMuli:TX<Pt>:ERRor	148
5.3.3	TMBPs:STIMuli:TX<Pt>:EINSert	149
5.3.4	TMBPs:STIMuli:TX<Pt>:EBLength	149
5.4	Result	149
5.4.1	TMBPs:RX<Pt>:IFETch?	149
5.5	Status	151
5.5.1	TMBPs:STATus:RX<Pt>:AESummary[:EVENT]?	151
5.5.2	TMBPs:STATus:RX<Pt>:AESummary:CONDition?	151
5.5.3	TMBPs:STATus:RX<Pt>:ALARm[:EVENT]?	151



5.5.4	TMBPs:STATus:RX<Pt>:ALARm:CONDition?	152
5.5.5	TMBPs:STATus:RX<Pt>:ERRor[:EVENT]?	152
5.5.6	TMBPs:STATus:RX<Pt>:ERRor:CONDition?	152
5.5.7	TMBPs:STATus:RX<Pt>:PSLevel?	153
5.5.8	TMBPs:STATus:RX<Pt>:PDEVIation?	153
5.5.9	TMBPs:STATus:RX<Pt>:PBRate?	153
5.5.10	TMBPs:STATus:RX<Pt>:PPBRate?	153
5.5.11	TMBPs:STATus:RX<Pt>:FNFWord?	153
5.5.12	TMBPs:STATus:RX<Pt>:FDUMp?	154
5.5.13	TMBPs:STATus:RX<Pt>:ACONtent?	154
5.5.14	TMBPs:STATus:RX<Pt>:AEBContent?	154
5.5.15	TMBPs:STATus:RX<Pt>:APPeak?	154
5.5.16	TMBPs:STATus:RX<Pt>:ANPeak?	154
5.5.17	TMBPs:STATus:RX<Pt>:ALEVel?	154
5.5.18	TMBPs:STATus:RX<Pt>:AFRequency?	155
5.5.19	TMBPs:STATus:RX<Pt>:ACOFfset?	155
5.5.20	TMBPs:STATus:RX<Pt>:CMSignal?	155
5.5.21	TMBPs:STATus:RX<Pt>:CBITs?	155
5.6	APS	156
5.6.1	TMBPs:APS:STARt	156
5.6.2	TMBPs:APS:STOP	156
5.6.3	TMBPs:APS:RX<Pt>:NUMBer?	156
5.6.4	TMBPs:APS:RX<Pt>:ATIMe?	156
5.6.5	TMBPs:APS:RX<Pt>:MTIMe?	156
5.6.6	TMBPs:APS:RX<Pt>:LTIMe?	157
5.6.7	TMBPs:APS:RX<Pt>:EVENT	157
5.6.8	TMBPs:APS:RX<Pt>:MLIMit	157
5.7	RTD	158
5.7.1	TMBPs:RTD:RX<Pt>:NUMBer?	158
5.7.2	TMBPs:RTD:RX<Pt>:ATIMe?	158
5.7.3	TMBPs:RTD:RX<Pt>:MTIMe?	158
5.7.4	TMBPs:RTD:RX<Pt>:LTIMe?	158
<b>6</b>	<b>T1</b>	<b>159</b>
6.1	Receiver	159
6.1.1	T1:RX<Pt>[:ENABled]	159
6.1.2	T1:RX<Pt>:FOLLow	159
6.1.3	T1:RX<Pt>:MODE	160
6.1.4	T1:RX<Pt>:CODE	160
6.1.5	T1:RX<Pt>:PCMFrame	160
6.1.6	T1:RX<Pt>:FTYPe	161
6.1.7	T1:RX<Pt>:PATTerN	161
6.1.8	T1:RX<Pt>:PINVersion	162
6.1.9	T1:RX<Pt>:PTSLots	162
6.1.10	T1:RX<Pt>:UP16	162
6.1.11	T1:RX<Pt>:UP32	163
6.1.12	T1:TX<Pt>:SCContent	163
6.1.13	T1:RX<Pt>:AUDio	163
6.1.14	T1:RX<Pt>:ATSLot	164
6.1.15	T1:RX<Pt>:UP2K	164
6.1.16	T1:RX<Pt>:CAS	164
6.2	Transmitter	165
6.2.1	T1:TX<Pt>[:ENABled]	165
6.2.2	T1:TX<Pt>:FOLLow	165
6.2.3	T1:TX<Pt>:DINSert[:ENABle]	166
6.2.4	T1:TX<Pt>:TIMing	166
6.2.5	T1:TX<Pt>:FOFFset	166
6.2.6	T1:TX<Pt>:CODE	167
6.2.7	T1:TX<Pt>:LBOut	167

6.2.8	T1:TX<Pt>:PCMFrame	167
6.2.9	T1:TX<Pt>:FTYPE	168
6.2.10	T1:TX<Pt>:PATtern	168
6.2.11	T1:TX<Pt>:PINVersion	169
6.2.12	T1:TX<Pt>:PTSLots	169
6.2.13	T1:TX<Pt>:UP16	170
6.2.14	T1:TX<Pt>:UP32	170
6.2.15	T1:TX<Pt>:UP2K	170
6.2.16	T1:TX<Pt>:UTSLots	171
6.2.17	T1:TX<Pt>:SCTSlot	171
6.2.18	T1:TX<Pt>:TFR	171
6.2.19	T1:TX<Pt>:TLEVel	172
6.2.20	T1:TX<Pt>:CAS	172
6.2.21	T1:TX<Pt>:CASChannel	172
6.2.22	T1:TX<Pt>:CASBits	173
6.2.23	T1:TX<Pt>:COCBits	173
6.2.24	T1:TX<Pt>:SF:CASBits	173
6.2.25	T1:TX<Pt>:SF:COCBits	174
6.3	Stimuli	174
6.3.1	T1:STIMuli:TX<Pt>:ALARm	174
6.3.2	T1:STIMuli:TX<Pt>:ERRor	175
6.3.3	T1:STIMuli:TX<Pt>:EINsert	175
6.3.4	T1:STIMuli:TX<Pt>:EBLength	176
6.3.5	T1:STIMuli:TX<Pt>:FDLink	176
6.3.6	T1:STIMuli:TX<Pt>:FDLink:UFDL	177
6.3.7	T1:STIMuli:TX<Pt>:FDLink:IBCode	177
6.4	Result	178
6.4.1	T1:RX<Pt>:IFETch?	178
6.5	Status	179
6.5.1	T1:STATus:RX<Pt>:AESummary[:EVENT]?	179
6.5.2	T1:STATus:RX<Pt>:AESummary:CONDition?	179
6.5.3	T1:STATus:RX<Pt>:ALARm[:EVENT]?	179
6.5.4	T1:STATus:RX<Pt>:ALARm:CONDition?	180
6.5.5	T1:STATus:RX<Pt>:ERRor[:EVENT]?	180
6.5.6	T1:STATus:RX<Pt>:ERRor:CONDition?	180
6.5.7	T1:STATus:RX<Pt>:PSLevel?	181
6.5.8	T1:STATus:RX<Pt>:PDEviation?	181
6.5.9	T1:STATus:RX<Pt>:PBRate?	181
6.5.10	T1:STATus:RX<Pt>:FDUMp?	181
6.5.11	T1:STATus:RX<Pt>:ACONtent?	181
6.5.12	T1:STATus:RX<Pt>:AIBContent?	181
6.5.13	T1:STATus:RX<Pt>:APPeak?	182
6.5.14	T1:STATus:RX<Pt>:ANPeak?	182
6.5.15	T1:STATus:RX<Pt>:ALEVel?	182
6.5.16	T1:STATus:RX<Pt>:AFRequency?	182
6.5.17	T1:STATus:RX<Pt>:ACOFset?	182
6.5.18	T1:STATus:RX<Pt>:PPBRate?	182
6.5.19	T1:STATus:RX<Pt>:FBIT?	183
6.5.20	T1:STATus:RX<Pt>:SBIT?	183
6.5.21	T1:STATus:RX<Pt>:MBIT?	183
6.5.22	T1:STATus:RX<Pt>:FDL:MODE	183
6.5.23	T1:STATus:RX<Pt>:FDL:MBIT:CODE?	183
6.5.24	T1:STATus:RX<Pt>:FDL:INBand:CODE?	184
6.5.25	T1:STATus:RX<Pt>:FDL:UDEFined	184
6.5.26	T1:STATus:RX<Pt>:FDL:UCODE	184
6.5.27	T1:STATus:RX<Pt>:FDL:TRIGger	184
6.5.28	T1:STATus:RX<Pt>:CBITs?	185
6.6	APS	186
6.6.1	T1:APS:STARt	186

6.6.2	T1:APS:STOP	186
6.6.3	T1:APS:RX<Pt>:NUMBer?	186
6.6.4	T1:APS:RX<Pt>:ATIME?	186
6.6.5	T1:APS:RX<Pt>:MTIME?	186
6.6.6	T1:APS:RX<Pt>:LTIME?	187
6.6.7	T1:APS:RX<Pt>:EVENT	187
6.6.8	T1:APS:RX<Pt>:MLIMit	187
6.7	RTD	188
6.7.1	T1:RTD:RX<Pt>:NUMBer?	188
6.7.2	T1:RTD:RX<Pt>:ATIME?	188
6.7.3	T1:RTD:RX<Pt>:MTIME?	188
6.7.4	T1:RTD:RX<Pt>:LTIME?	188
<b>7</b>	<b>E3</b>	<b>189</b>
7.1	Receiver	189
7.1.1	E3:RX<Pt>[:ENABled]	189
7.1.2	E3:RX<Pt>:MODE	189
7.1.3	E3:RX<Pt>:FOLLow	190
7.1.4	E3:RX<Pt>:PCMFrame	190
7.1.5	E3:RX<Pt>:PATtern	191
7.1.6	E3:RX<Pt>:PINVersion	191
7.1.7	E3:RX<Pt>:UP16	192
7.1.8	E3:RX<Pt>:UP32	192
7.1.9	E3:RX<Pt>:UP2K	192
7.2	Transmitter	193
7.2.1	E3:TX<Pt>[:ENABled]	193
7.2.2	E3:TX<Pt>:FOLLow	193
7.2.3	E3:TX<Pt>:TIMing	193
7.2.4	E3:TX<Pt>:FOFFset	194
7.2.5	E3:TX<Pt>:PCMFrame	194
7.2.6	E3:TX<Pt>:PATtern	195
7.2.7	E3:TX<Pt>:PINVersion	195
7.2.8	E3:TX<Pt>:UP16	196
7.2.9	E3:TX<Pt>:UP32	196
7.2.10	E3:TX<Pt>:UP2K	196
7.3	Stimuli	197
7.3.1	E3:STIMuli:TX<Pt>:ALARm	197
7.3.2	E3:STIMuli:TX<Pt>:ERRor	197
7.3.3	E3:STIMuli:TX<Pt>:EINSert	198
7.3.4	E3:STIMuli:TX<Pt>:EBLength	198
7.4	Results	199
7.4.1	E3:RX<Pt>:IFETch?	199
7.5	Status	200
7.5.1	E3:STATus:RX<Pt>:PSLevel?	200
7.5.2	E3:STATus:RX<Pt>:PDEViation?	200
7.5.3	E3:STATus:RX<Pt>:PBRate?	200
7.5.4	E3:STATus:RX<Pt>:PPBRate?	200
7.5.5	E3:STATus:RX<Pt>:AESummary[:EVENT]?	200
7.5.6	E3:STATus:RX<Pt>:AESummary:CONDition?	201
7.5.7	E3:STATus:RX<Pt>:ALARm[:EVENT]?	201
7.5.8	E3:STATus:RX<Pt>:ALARm:CONDition?	201
7.5.9	E3:STATus:RX<Pt>:ERRor[:EVENT]?	202
7.5.10	E3:STATus:RX<Pt>:ERRor:CONDition?	202
7.6	RTD	203
7.6.1	E3:RTD:RX<Pt>:NUMBer?	203
7.6.2	E3:RTD:RX<Pt>:ATIME?	203
7.6.3	E3:RTD:RX<Pt>:MTIME?	203
7.6.4	E3:RTD:RX<Pt>:LTIME?	203
<b>8</b>	<b>T3</b>	<b>205</b>

8.1	Receiver	205
8.1.1	T3:RX<Pt>[:ENABled]	205
8.1.2	T3:RX<Pt>:MODE	205
8.1.3	T3:RX<Pt>:FOLLow	206
8.1.4	T3:RX<Pt>:PCMFrame	206
8.1.5	T3:RX<Pt>:FTYPe	206
8.1.6	T3:RX<Pt>:PATtern	207
8.1.7	T3:RX<Pt>:PINVersion	207
8.1.8	T3:RX<Pt>:UP16	208
8.1.9	T3:RX<Pt>:UP32	208
8.1.10	T3:RX<Pt>:UP2K	208
8.2	Transmitter	209
8.2.1	T3:TX<Pt>[:ENABled]	209
8.2.2	T3:TX<Pt>:FOLLow	209
8.2.3	T3:TX<Pt>:TIMing	209
8.2.4	T3:TX<Pt>:FOFFset	210
8.2.5	T3:TX<Pt>:PCMFrame	210
8.2.6	T3:TX<Pt>:FTYPe	210
8.2.7	T3:TX<Pt>:LBOut	211
8.2.8	T3:TX<Pt>:PATtern	211
8.2.9	T3:TX<Pt>:PINVersion	212
8.2.10	T3:TX<Pt>:UP16	212
8.2.11	T3:TX<Pt>:UP32	212
8.2.12	T3:TX<Pt>:UP2K	213
8.3	Stimuli	214
8.3.1	T3:STIMuli:TX<Pt>:ALARm	214
8.3.2	T3:STIMuli:TX<Pt>:ERRor	214
8.3.3	T3:STIMuli:TX<Pt>:EINsert	215
8.3.4	T3:STIMuli:TX<Pt>:EBLength	215
8.4	Results	216
8.4.1	T3:RX<Pt>:IFETch?	216
8.5	Status	217
8.5.1	T3:STATus:RX<Pt>:PSLevel?	217
8.5.2	T3:STATus:RX<Pt>:PDEViation?	217
8.5.3	T3:STATus:RX<Pt>:PBRate?	217
8.5.4	T3:STATus:RX<Pt>:PPBRate?	217
8.5.5	T3:STATus:RX<Pt>:AESummary[:EVENT]?	217
8.5.6	T3:STATus:RX<Pt>:AESummary:CONDition?	218
8.5.7	T3:STATus:RX<Pt>:ALARm[:EVENT]?	218
8.5.8	T3:STATus:RX<Pt>:ALARm:CONDition?	218
8.5.9	T3:STATus:RX<Pt>:ERRor[:EVENT]?	219
8.5.10	T3:STATus:RX<Pt>:ERRor:CONDition?	219
8.6	RTD	220
8.6.1	T3:RTD:RX<Pt>:NUMBer?	220
8.6.2	T3:RTD:RX<Pt>:ATIME?	220
8.6.3	T3:RTD:RX<Pt>:MTIME?	220
8.6.4	T3:RTD:RX<Pt>:LTIME?	220
<b>9</b>	<b>E4</b>	<b>221</b>
9.1	Receiver	221
9.1.1	E4:RX<Pt>[:ENABled]	221
9.1.2	E4:RX<Pt>:GAIN	221
9.1.3	E4:RX<Pt>:FOLLow	222
9.1.4	E4:RX<Pt>:PCMFrame	222
9.1.5	E4:RX<Pt>:PATtern	223
9.1.6	E4:RX<Pt>:PINVersion	223
9.1.7	E4:RX<Pt>:UP16	224
9.1.8	E4:RX<Pt>:UP32	224
9.1.9	E4:RX<Pt>:UP2K	224

9.2	Transmitter	225
9.2.1	E4:TX<Pt>[:ENABled]	225
9.2.2	E4:TX<Pt>:FOLLow	225
9.2.3	E4:TX<Pt>:TIMing	225
9.2.4	E4:TX<Pt>:FOFFset	226
9.2.5	E4:TX<Pt>:PCMFrame	226
9.2.6	E4:TX<Pt>:PATtern	227
9.2.7	E4:TX<Pt>:PINVersion	227
9.2.8	E4:TX<Pt>:UP16	228
9.2.9	E4:TX<Pt>:UP32	228
9.2.10	E4:TX<Pt>:UP2K	228
9.3	Stimuli	229
9.3.1	E4:STIMuli:TX<Pt>:ALARm	229
9.3.2	E4:STIMuli:TX<Pt>:ERRor	229
9.3.3	E4:STIMuli:TX<Pt>:EINSert	230
9.3.4	E4:STIMuli:TX<Pt>:EBLength	230
9.4	Status	231
9.4.1	E4:STATus:RX<Pt>:PSLevel?	231
9.4.2	E4:STATus:RX<Pt>:PDEViation?	231
9.4.3	E4:STATus:RX<Pt>:PBRate?	231
9.4.4	E4:STATus:RX<Pt>:PPBRate?	231
9.4.5	E4:STATus:RX<Pt>:AESummary[:EVENT]?	231
9.4.6	E4:STATus:RX<Pt>:AESummary:CONDition?	232
9.4.7	E4:STATus:RX<Pt>:ALARm[:EVENT]?	232
9.4.8	E4:STATus:RX<Pt>:ALARm:CONDition?	232
9.4.9	E4:STATus:RX<Pt>:ERRor[:EVENT]?	233
9.4.10	E4:STATus:RX<Pt>:ERRor:CONDition?	233
9.5	Results	234
9.5.1	E4:RX<Pt>:IFETch?	234
9.6	RTD	235
9.6.1	E4:RTD:RX<Pt>:NUMBer?	235
9.6.2	E4:RTD:RX<Pt>:ATIME?	235
9.6.3	E4:RTD:RX<Pt>:MTIME?	235
9.6.4	E4:RTD:RX<Pt>:LTIME?	235
<b>10</b>	<b>SDH</b>	<b>237</b>
10.1	Receiver	237
10.1.1	SDH:RX<Pt>:INTerface	237
10.1.2	SDH:RX<Pt>:STMLevel	237
10.1.3	SDH:RX<Pt>:AUGRoup	238
10.1.4	SDH:RX<Pt>:CONCatenation	238
10.1.5	SDH:RX<Pt>:CONTainer	239
10.1.6	SDH:RX<Pt>:SSTRucture	239
10.1.7	SDH:RX<Pt>:PATtern	240
10.1.8	SDH:RX<Pt>:UP16	240
10.1.9	SDH:RX<Pt>:UP32	241
10.1.10	SDH:RX<Pt>:UP2K	241
10.1.11	SDH:RX<Pt>:PINVersion	241
10.1.12	SDH:RX<Pt>:TCM	242
10.1.13	SDH:RX<Pt>:TUG3	242
10.1.14	SDH:RX<Pt>:TUG2	242
10.1.15	SDH:RX<Pt>:TU12	243
10.1.16	SDH:RX<Pt>:TU11	243
10.1.17	SDH:RX<Pt>:CHANnel	244
10.1.18	SDH:RX<Pt>:MAPPing	244
10.1.19	SDH:RX<Pt>:GAIN	244
10.1.20	SDH:RX<Pt>:FOLLow	245
10.1.21	SDH:RX<Pt>:MEASurement:HPLM	245
10.1.22	SDH:RX<Pt>:MEASurement:LPLM	245

---

10.2	Transmitter	246
10.2.1	SDH:TX<Pt>:INterface	246
10.2.2	SDH:TX<Pt>[:ENable]	246
10.2.3	SDH:TX<Pt>:OPTical	246
10.2.4	SDH:TX<Pt>:ELECtrical	247
10.2.5	SDH:TX<Pt>:STMLevel	247
10.2.6	SDH:TX<Pt>:AUGRoup	248
10.2.7	SDH:TX<Pt>:CONCatenation	248
10.2.8	SDH:TX<Pt>:CONTainer	249
10.2.9	SDH:TX<Pt>:SSTRucture	249
10.2.10	SDH:TX<Pt>:PATtern	250
10.2.11	SDH:TX<Pt>:UP16	250
10.2.12	SDH:TX<Pt>:UP32	251
10.2.13	SDH:TX<Pt>:UP2K	251
10.2.14	SDH:TX<Pt>:PINVersion	251
10.2.15	SDH:TX<Pt>:TIMing	252
10.2.16	SDH:TX<Pt>:TCM	252
10.2.17	SDH:TX<Pt>:TUG3	252
10.2.18	SDH:TX<Pt>:TUG2	253
10.2.19	SDH:TX<Pt>:TU12	253
10.2.20	SDH:TX<Pt>:TU11	254
10.2.21	SDH:TX<Pt>:CHANnel	254
10.2.22	SDH:TX<Pt>:MAPPing	254
10.2.23	SDH:TX<Pt>:SOH:DEFault	255
10.2.24	SDH:TX<Pt>:SOH:TRACe	255
10.2.25	SDH:TX<Pt>:SOH:TRACe:CRC	255
10.2.26	SDH:TX<Pt>:SOH	256
10.2.27	SDH:TX<Pt>:VC4:POH:DEFault	257
10.2.28	SDH:TX<Pt>:VC4:POH:TRACe	257
10.2.29	SDH:TX<Pt>:VC4:POH:TRACe:CRC	257
10.2.30	SDH:TX<Pt>:VC4:POH:TTCM	258
10.2.31	SDH:TX<Pt>:VC4:POH	258
10.2.32	SDH:TX<Pt>:VC3:POH:DEFault	259
10.2.33	SDH:TX<Pt>:VC3:POH:TRACe	259
10.2.34	SDH:TX<Pt>:VC3:POH:TRACe:CRC	259
10.2.35	SDH:TX<Pt>:VC3:POH:TTCM	260
10.2.36	SDH:TX<Pt>:VC3:POH	260
10.2.37	SDH:TX<Pt>:VC12:POH:DEFault	260
10.2.38	SDH:TX<Pt>:VC12:POH:TRACe	261
10.2.39	SDH:TX<Pt>:VC12:POH:TRACe:CRC	261
10.2.40	SDH:TX<Pt>:VC12:POH:TTCM	261
10.2.41	SDH:TX<Pt>:VC12:POH	262
10.2.42	SDH:TX<Pt>:VC11:POH:DEFault	262
10.2.43	SDH:TX<Pt>:VC11:POH:TRACe	262
10.2.44	SDH:TX<Pt>:VC11:POH:TRACe:CRC	263
10.2.45	SDH:TX<Pt>:VC11:POH:TTCM	263
10.2.46	SDH:TX<Pt>:VC11:POH	264
10.2.47	SDH:TX<Pt>:AU3:VC3:POH:DEFault	264
10.2.48	SDH:TX<Pt>:AU3:VC3:POH:TRACe	264
10.2.49	SDH:TX<Pt>:AU3:VC3:POH:TRACe:CRC	265
10.2.50	SDH:TX<Pt>:AU3:VC3:POH:TTCM	265
10.2.51	SDH:TX<Pt>:AU3:VC3:POH	265
10.2.52	SDH:TX<Pt>:FOLLow	266
10.2.53	SDH:TX<Pt>:OTHRough	266
10.2.54	SDH:TX<Pt>:OTHRough:BYTE	267
10.2.55	SDH:TX<Pt>:STL:MMAPing:LANE	267
10.3	Stimuli	268
10.3.1	SDH:STIMuli:TX<Pt>:FOFFset	268
10.3.2	SDH:STIMuli:TX<Pt>:ALARm	269

10.3.3	SDH:STIMuli:TX<Pt>:AINsert	269
10.3.4	SDH:STIMuli:TX<Pt>:ANLength	270
10.3.5	SDH:STIMuli:TX<Pt>:AALength	270
10.3.6	SDH:STIMuli:TX<Pt>:ERRor	271
10.3.7	SDH:STIMuli:TX<Pt>:EINsert	272
10.3.8	SDH:STIMuli:TX<Pt>:EBLength	272
10.3.9	SDH:STIMuli:TX<Pt>:ENLength	273
10.3.10	SDH:STIMuli:TX<Pt>:EELength	273
10.3.11	SDH:STIMuli:TX<Pt>:PTSequence	273
10.3.12	SDH:STIMuli:TX<Pt>:PMove	274
10.3.13	SDH:STIMuli:TX<Pt>:PJUMp	275
10.3.14	SDH:STIMuli:TX<Pt>:STL:AERRor:LANE	275
10.3.15	SDH:STIMuli:TX<Pt>:STL:ALARm	276
10.3.16	SDH:STIMuli:TX<Pt>:STL:AINsert	276
10.3.17	SDH:STIMuli:TX<Pt>:STL:ABLength	276
10.3.18	SDH:STIMuli:TX<Pt>:STL:AALength	277
10.3.19	SDH:STIMuli:TX<Pt>:STL:ANLength	277
10.3.20	SDH:STIMuli:TX<Pt>:STL:ERRor	277
10.3.21	SDH:STIMuli:TX<Pt>:STL:EINsert	278
10.3.22	SDH:STIMuli:TX<Pt>:STL:EELength	278
10.3.23	SDH:STIMuli:TX<Pt>:STL:ENLength	278
10.3.24	SDH:STIMuli:TX<Pt>:STL:SKEW:BIT	279
10.3.25	SDH:STIMuli:TX<Pt>:STL:SKEW:NS?	279
10.3.26	SDH:STIMuli:TX<Pt>:STL:SKEW:LANE	279
10.4	Result	280
10.4.1	SDH:RX<Pt>:IFETch?	280
10.4.2	SDH:PMOVement:RX<Pt>:FETCh?	284
10.5	Status	284
10.5.1	SDH:STATus:RX<Pt>:AESummary[:EVENT]?	284
10.5.2	SDH:STATus:RX<Pt>:AESummary:CONDition?	284
10.5.3	SDH:STATus:RX<Pt>:ALARm<section>[:EVENT]?	285
10.5.4	SDH:STATus:RX<Pt>:ALARm<section>:CONDition?	286
10.5.5	SDH:STATus:RX<Pt>:ERRor<section>[:EVENT]?	286
10.5.6	SDH:STATus:RX<Pt>:ERRor<section>:CONDition?	287
10.5.7	SDH:STATus:RX<Pt>:PSLevel?	287
10.5.8	SDH:STATus:TX<Pt>:PSLevel?	287
10.5.9	SDH:STATus:RX<Pt>:PDEViation?	287
10.5.10	SDH:STATus:RX<Pt>:PBRate?	287
10.5.11	SDH:STATus:RX<Pt>:DIFFerence?	288
10.5.12	SDH:STATus:RX<Pt>:RACCumulated	288
10.5.13	SDH:STATus:RX<Pt>:PPBRate?	288
10.5.14	SDH:STATus:RX<Pt>:CAPTure:SOH:TRACe?	288
10.5.15	SDH:STATus:RX<Pt>:CAPTure<Frame>:SOH?	289
10.5.16	SDH:STATus:RX<Pt>:CAPTure:VC4:POH:TRACe?	289
10.5.17	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC4:POH?	290
10.5.18	SDH:STATus:RX<Pt>:CAPTure:VC3:POH:TRACe?	290
10.5.19	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC3:POH?	290
10.5.20	SDH:STATus:RX<Pt>:CAPTure:VC12:POH:TRACe?	291
10.5.21	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC12:POH?	291
10.5.22	SDH:STATus:RX<Pt>:CAPTure:VC11:POH:TRACe?	291
10.5.23	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC11:POH?	291
10.5.24	SDH:STATus:RX<Pt>:CAPTure:AU3:VC3:POH:TRACe?	292
10.5.25	SDH:STATus:RX<Pt>:CAPTure<Frame>:AU3:VC3:POH?	292
10.6	APS	293
10.6.1	SDH:APS:STARt	293
10.6.2	SDH:APS:STOP	293
10.6.3	SDH:APS:RX<Pt>:PINterpret?	293
10.6.4	SDH:APS:RX<Pt>:NUMBer?	293
10.6.5	SDH:APS:RX<Pt>:ATIME?	293

10.6.6	SDH:APS:RX<Pt>:MTIME?	294
10.6.7	SDH:APS:RX<Pt>:LTIME?	294
10.6.8	SDH:APS:RX<Pt>:CTIME?	294
10.6.9	SDH:APS:RX<Pt>:EVENT	295
10.6.10	SDH:APS:RX<Pt>:MLIMit	295
10.6.11	SDH:APS:RX<Pt>:PERiod	296
10.6.12	SDH:APS:RX<Pt>:CONFig	296
10.6.13	SDH:APS:RX<Pt>:RTYPE	297
10.6.14	SDH:APS:RX<Pt>:K1	298
10.6.15	SDH:APS:RX<Pt>:K2	298
10.6.16	SDH:APS:RX<Pt>:APPLY	298
10.7	Tributary Scan	298
10.7.1	SDH:TSCan:START	298
10.7.2	SDH:TSCan:STOP	299
10.7.3	SDH:TSCan:RX<Pt>:NHOCOnTainer?	299
10.7.4	SDH:TSCan:RX<Pt>:GHOCOnTainer?	299
10.7.5	SDH:TSCan:RX<Pt>:SHOCOnTainer	299
10.7.6	SDH:TSCan:RX<Pt>:SHOCOnTainer?	299
10.7.7	SDH:TSCan:RX<Pt>:DHOCOnTainer?	300
10.7.8	SDH:TSCan:RX<Pt>:NLOCOnTainer?	300
10.7.9	SDH:TSCan:RX<Pt>:GLOCOnTainer?	300
10.7.10	SDH:TSCan:RX<Pt>:DLOCOnTainer?	300
10.7.11	SDH:TSCan:RX<Pt>:DMUX?	301
10.8	RTD	302
10.8.1	SDH:RTD:RX<Pt>:MLIMit	302
10.8.2	SDH:RTD:RX<Pt>:NUMBer?	302
10.8.3	SDH:RTD:RX<Pt>:ATIME?	302
10.8.4	SDH:RTD:RX<Pt>:MTIME?	302
10.8.5	SDH:RTD:RX<Pt>:LTIME?	303
10.8.6	SDH:RTD:RX<Pt>:CTIME?	303
<b>11</b>	<b>SONET</b>	<b>305</b>
11.1	Receiver	305
11.1.1	SONet:RX<Pt>:INTerface	305
11.1.2	SONet:RX<Pt>:OCLevel	305
11.1.3	SONet:RX<Pt>:STSLevel	306
11.1.4	SONet:RX<Pt>:STS3c	306
11.1.5	SONet:RX<Pt>:CONCatenation	307
11.1.6	SONet:RX<Pt>:CONTainer	307
11.1.7	SONet:RX<Pt>:SSTRucture	308
11.1.8	SONet:RX<Pt>:PATTern	308
11.1.9	SONet:RX<Pt>:UP32	309
11.1.10	SONet:RX<Pt>:UP2K	309
11.1.11	SONet:RX<Pt>:PINVersion	309
11.1.12	SONet:RX<Pt>:TCM	310
11.1.13	SONet:RX<Pt>:TUG3	310
11.1.14	SONet:RX<Pt>:VTG	310
11.1.15	SONet:RX<Pt>:VT2	311
11.1.16	SONet:RX<Pt>:VT15	311
11.1.17	SONet:RX<Pt>:CHANnel	312
11.1.18	SONet:RX<Pt>:MAPPing	312
11.1.19	SONet:RX<Pt>:GAIN	312
11.1.20	SONet:RX<Pt>:FOLLow	313
11.1.21	SONet:RX<Pt>:MEASurement:PLMP	313
11.1.22	SONet:RX<Pt>:MEASurement:PLMV	313
11.2	Transmitter	314
11.2.1	SONet:TX<Pt>:INTerface	314
11.2.2	SONet:TX<Pt>[:ENABle]	314
11.2.3	SONet:TX<Pt>:OPTical	314



11.2.4	SONet:TX<Pt>:ELECtrical	315
11.2.5	SONet:TX<Pt>:OCLevel	315
11.2.6	SONet:TX<Pt>:STSLevel	316
11.2.7	SONet:TX<Pt>:STS3c	316
11.2.8	SONet:TX<Pt>:CONCatenation	317
11.2.9	SONet:TX<Pt>:CONTainer	317
11.2.10	SONet:TX<Pt>:SSTRucture	318
11.2.11	SONet:TX<Pt>:PATtern	318
11.2.12	SONet:TX<Pt>:UP32	319
11.2.13	SONet:TX<Pt>:UP2K	319
11.2.14	SONet:TX<Pt>:PINVersion	319
11.2.15	SONet:TX<Pt>:TIMing	320
11.2.16	SONet:TX<Pt>:TCM	320
11.2.17	SONet:TX<Pt>:TUG3	320
11.2.18	SONet:TX<Pt>:VTG	321
11.2.19	SONet:TX<Pt>:VT2	321
11.2.20	SONet:TX<Pt>:VT15	322
11.2.21	SONet:TX<Pt>:CHANnel	322
11.2.22	SONet:TX<Pt>:MAPPing	322
11.2.23	SONet:TX<Pt>:TOH:DEFault	323
11.2.24	SONet:TX<Pt>:TOH:TRACe	323
11.2.25	SONet:TX<Pt>:TOH:TRACe:CRC	323
11.2.26	SONet:TX<Pt>:TOH	324
11.2.27	SONet:TX<Pt>:STS3:POH:DEFault	325
11.2.28	SONet:TX<Pt>:STS3:POH:TRACe	325
11.2.29	SONet:TX<Pt>:STS3:POH:TRACe:CRC	325
11.2.30	SONet:TX<Pt>:STS3:POH:TTCM	326
11.2.31	SONet:TX<Pt>:STS3:POH	326
11.2.32	SONet:TX<Pt>:STS1:POH:DEFault	327
11.2.33	SONet:TX<Pt>:STS1:POH:TRACe	327
11.2.34	SONet:TX<Pt>:STS1:POH:TRACe:CRC	327
11.2.35	SONet:TX<Pt>:STS1:POH:TTCM	328
11.2.36	SONet:TX<Pt>:STS1:POH	328
11.2.37	SONet:TX<Pt>:VT2:POH:DEFault	328
11.2.38	SONet:TX<Pt>:VT2:POH:TRACe	329
11.2.39	SONet:TX<Pt>:VT2:POH:TRACe:CRC	329
11.2.40	SONet:TX<Pt>:VT2:POH:TTCM	329
11.2.41	SONet:TX<Pt>:VT2:POH	330
11.2.42	SONet:TX<Pt>:VT15:POH:DEFault	330
11.2.43	SONet:TX<Pt>:VT15:POH:TRACe	330
11.2.44	SONet:TX<Pt>:VT15:POH:TRACe:CRC	331
11.2.45	SONet:TX<Pt>:VT15:POH:TTCM	331
11.2.46	SONet:TX<Pt>:VT15:POH	332
11.2.47	SONet:TX<Pt>:STS1:STS1:POH:DEFault	332
11.2.48	SONet:TX<Pt>:STS1:STS1:POH:TRACe	332
11.2.49	SONet:TX<Pt>:STS1:STS1:POH:TRACe:CRC	333
11.2.50	SONet:TX<Pt>:STS1:STS1:POH:TTCM	333
11.2.51	SONet:TX<Pt>:STS1:STS1:POH	333
11.2.52	SONet:TX<Pt>:FOLLow	334
11.2.53	SONet:TX<Pt>:OTHRough	334
11.2.54	SONet:TX<Pt>:OTHRough:BYTE	335
11.2.55	SONet:TX<Pt>:STL:MMAPing:LANE	335
11.3	Stimuli	336
11.3.1	SONet:STIMuli:TX<Pt>:FOFFset	336
11.3.2	SONet:STIMuli:TX<Pt>:ALARm	337
11.3.3	SONet:STIMuli:TX<Pt>:AINSerT	337
11.3.4	SONet:STIMuli:TX<Pt>:ANLength	338
11.3.5	SONet:STIMuli:TX<Pt>:AALength	338
11.3.6	SONet:STIMuli:TX<Pt>:ERRor	339

11.3.7	SONet:STIMuli:TX<Pt>:EINSert	340
11.3.8	SONet:STIMuli:TX<Pt>:EBLength	340
11.3.9	SONet:STIMuli:TX<Pt>:ENLength	341
11.3.10	SONet:STIMuli:TX<Pt>:EELength	341
11.3.11	SONet:STIMuli:TX<Pt>:PTSequence	341
11.3.12	SONet:STIMuli:TX<Pt>:PMOVe	342
11.3.13	SONet:STIMuli:TX<Pt>:PJUMp	343
11.3.14	SONet:STIMuli:TX<Pt>:STL:AERRor:LANE	343
11.3.15	SONet:STIMuli:TX<Pt>:STL:ALARm	344
11.3.16	SONet:STIMuli:TX<Pt>:STL:AINSert	344
11.3.17	SONet:STIMuli:TX<Pt>:STL:ABLength	344
11.3.18	SONet:STIMuli:TX<Pt>:STL:AALength	345
11.3.19	SONet:STIMuli:TX<Pt>:STL:ANLength	345
11.3.20	SONet:STIMuli:TX<Pt>:STL:ERRor	345
11.3.21	SONet:STIMuli:TX<Pt>:STL:EINSert	346
11.3.22	SONet:STIMuli:TX<Pt>:STL:EELength	346
11.3.23	SONet:STIMuli:TX<Pt>:STL:ENLength	346
11.3.24	SONet:STIMuli:TX<Pt>:STL:SKEW:BIT	347
11.3.25	SONet:STIMuli:TX<Pt>:STL:SKEW:NS?	347
11.3.26	SONet:STIMuli:TX<Pt>:STL:SKEW:LANE	347
11.3.27	SONet:STIMuli:TX<Pt>:STL:SKEW:LANE?	347
11.4	Result	348
11.4.1	SONet:RX<Pt>:IFETch?	348
11.4.2	SONet:PMOVement:RX<Pt>:FETCh?	352
11.5	Status	352
11.5.1	SONet:STATus:RX<Pt>:AESummary[:EVENT]?	352
11.5.2	SONet:STATus:RX<Pt>:AESummary:CONDition?	352
11.5.3	SONet:STATus:RX<Pt>:ALARm<section>[:EVENT]?	353
11.5.4	SONet:STATus:RX<Pt>:ALARm<section>:CONDition?	354
11.5.5	SONet:STATus:RX<Pt>:ERRor<section>[:EVENT]?	354
11.5.6	SONet:STATus:RX<Pt>:ERRor<section>:CONDition?	355
11.5.7	SONet:STATus:RX<Pt>:PSLevel?	355
11.5.8	SONet:STATus:TX<Pt>:PSLevel?	355
11.5.9	SONet:STATus:RX<Pt>:PDEViation?	355
11.5.10	SONet:STATus:RX<Pt>:PBRate?	355
11.5.11	SONet:STATus:RX<Pt>:DIFference?	356
11.5.12	SONet:STATus:RX<Pt>:RACCumulated	356
11.5.13	SONet:STATus:RX<Pt>:PPBRate?	356
11.5.14	SONet:STATus:RX<Pt>:CAPTure:TOH:TRACe?	356
11.5.15	SONet:STATus:RX<Pt>:CAPTure<Frame>:TOH?	357
11.5.16	SONet:STATus:RX<Pt>:CAPTure:STS3:POH:TRACe?	357
11.5.17	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS3:POH?	358
11.5.18	SONet:STATus:RX<Pt>:CAPTure:STS1:POH:TRACe?	358
11.5.19	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS1:POH?	358
11.5.20	SONet:STATus:RX<Pt>:CAPTure:VT2:POH:TRACe?	359
11.5.21	SONet:STATus:RX<Pt>:CAPTure<Frame>:VT2:POH?	359
11.5.22	SONet:STATus:RX<Pt>:CAPTure:VT15:POH:TRACe?	359
11.5.23	SONet:STATus:RX<Pt>:CAPTure<Frame>:VT15:POH?	359
11.5.24	SONet:STATus:RX<Pt>:CAPTure:STS1:STS1:POH:TRACe?	360
11.5.25	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS1:STS1:POH?	360
11.6	APS	361
11.6.1	SONet:APS:STARt	361
11.6.2	SONet:APS:STOP	361
11.6.3	SONet:APS:RX<Pt>:PINTerpret?	361
11.6.4	SONet:APS:RX<Pt>:NUMBer?	361
11.6.5	SONet:APS:RX<Pt>:ATIME?	361
11.6.6	SONet:APS:RX<Pt>:MTIME?	362
11.6.7	SONet:APS:RX<Pt>:LTIME?	362
11.6.8	SONet:APS:RX<Pt>:CTIME?	362

11.6.9	SONet:APS:RX<Pt>:EVENT	363
11.6.10	SONet:APS:RX<Pt>:MLIMit	363
11.6.11	SONet:APS:RX<Pt>:PERiod	364
11.6.12	SONet:APS:RX<Pt>:CONFig	364
11.6.13	SONet:APS:RX<Pt>:RTYPE	365
11.6.14	SONet:APS:RX<Pt>:K1	366
11.6.15	SONet:APS:RX<Pt>:K2	366
11.6.16	SONet:APS:RX<Pt>:APPLY	366
11.7	Tributary Scan	366
11.7.1	SONet:TSCan:START	366
11.7.2	SONet:TSCan:STOP	367
11.7.3	SONet:TSCan:RX<Pt>:NHOCOnTainer?	367
11.7.4	SONet:TSCan:RX<Pt>:GHOCOnTainer?	367
11.7.5	SONet:TSCan:RX<Pt>:SHOCOnTainer	367
11.7.6	SONet:TSCan:RX<Pt>:SHOCOnTainer?	367
11.7.7	SONet:TSCan:RX<Pt>:DHOCOnTainer?	368
11.7.8	SONet:TSCan:RX<Pt>:NLOCOnTainer?	368
11.7.9	SONet:TSCan:RX<Pt>:GLOCOnTainer?	368
11.7.10	SONet:TSCan:RX<Pt>:DLOCOnTainer?	368
11.7.11	SONet:TSCan:RX<Pt>:DMUX?	369
11.8	RTD	370
11.8.1	SONet:RTD:RX<Pt>:MLIMit	370
11.8.2	SONet:RTD:RX<Pt>:NUMBER?	370
11.8.3	SONet:RTD:RX<Pt>:ATIME?	370
11.8.4	SONet:RTD:RX<Pt>:MTIME?	370
11.8.5	SONet:RTD:RX<Pt>:LTIME?	371
11.8.6	SONet:RTD:RX<Pt>:CTIME?	371
<b>12</b>	<b>Ethernet</b>	<b>373</b>
12.1	Port Setup	373
12.1.1	ETHernet:PORT<Pt>:ITYPe	373
12.1.2	ETHernet:PORT<Pt>:MODE	374
12.1.3	ETHernet:PORT<Pt>:ANEGotiate	374
12.1.4	ETHernet:PORT<Pt>:FMODE	375
12.1.5	ETHernet:PORT<Pt>:CMODE	375
12.1.6	ETHernet:PORT<Pt>:TIMing:SOURce	376
12.1.7	ETHernet:PORT<Pt>:PFRames	376
12.1.8	ETHernet:PORT<Pt>:FEC	376
12.2	WAN	378
12.2.1	ETHernet:PORT<Pt>:WAN[:ENABLE]	378
12.2.2	ETHernet:PORT<Pt>:WAN:TERMinology	378
12.2.3	ETHernet:PORT<Pt>:WAN:SOH:DEFault	378
12.2.4	ETHernet:PORT<Pt>:WAN:SOH:TRACe	379
12.2.5	ETHernet:PORT<Pt>:WAN:SOH:TRACe:CRC	379
12.2.6	ETHernet:PORT<Pt>:WAN:SOH	380
12.2.7	ETHernet:PORT<Pt>:WAN:POH:DEFault	381
12.2.8	ETHernet:PORT<Pt>:WAN:POH:TRACe	381
12.2.9	ETHernet:PORT<Pt>:WAN:POH:TRACe:CRC	381
12.2.10	ETHernet:PORT<Pt>:WAN:POH	382
12.3	Reflector	383
12.3.1	ETHernet:PORT<Pt>:REFLector:SWAP[:ENABLE]	383
12.3.2	ETHernet:PORT<Pt>:REFLector:SSMac	383
12.3.3	ETHernet:PORT<Pt>:REFLector:SMAC	383
12.3.4	ETHernet:PORT<Pt>:REFLector:IPSWap	384
12.3.5	ETHernet:PORT<Pt>:REFLector:PSWap	384
12.3.6	ETHernet:PORT<Pt>:REFLector:ATCP	384
12.4	PCS	385
12.4.1	ETHernet:PORT<Pt>:PCS:MMAPing:LANE	385
12.5	Traffic	385

12.5.1	ETHernet:TRAFfic:GENerator:START	385
12.5.2	ETHernet:PORT<Pt>:TRAFfic:GENerator:START	385
12.5.3	ETHernet:TRAFfic:GENerator:STOP	386
12.5.4	ETHernet:PORT<Pt>:TRAFfic:GENerator:STOP	386
12.5.5	ETHernet:PORT<Pt>:TRAFfic:GENerator:STATUs?	386
12.5.6	ETHernet:PORT<Pt>:TRAFfic:DMODE	386
12.5.7	ETHernet:PORT<Pt>:TRAFfic:DURation	387
12.5.8	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:TXMode	387
12.5.9	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile	387
12.5.10	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMP[:MODE]	388
12.5.11	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad[:CONSTant]	388
12.5.12	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP[:MODE]	389
12.5.13	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:START	389
12.5.14	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:END	390
12.5.15	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STEP	390
12.5.16	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:DURation	391
12.5.17	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMP:DURation	391
12.5.18	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:PROFile	392
12.5.19	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE[:START]	392
12.5.20	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:END	392
12.5.21	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:STEP	393
12.5.22	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:DURation	393
12.5.23	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:PROFile	394
12.5.24	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VIDeo	394
12.5.25	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VOICe	395
12.5.26	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:NChannels	395
12.5.27	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:MODE	395
12.5.28	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:MODE	396
12.5.29	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:BNUMber	396
12.5.30	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:PDUTy[:DUTY]	397
12.5.31	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:PDUTy:PERiod	397
12.5.32	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:DUTY?	397
12.5.33	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:PERiod?	397
12.5.34	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:BLENght	398
12.5.35	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONSTant:BGAP	398
12.5.36	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:RMODE	399
12.5.37	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENght:START	399
12.5.38	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENght:END	400
12.5.39	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BGAP	400
12.6	Frame Content	401
12.6.1	ETHernet:PORT<Pt>:STReam<St>:FRAMed	401
12.6.2	ETHernet:PORT<Pt>:STReam<St>:MAC:SOURce	401
12.6.3	ETHernet:PORT<Pt>:STReam<St>:MAC:DESTination	401
12.6.4	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP	402
12.6.5	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:LKUP	402
12.6.6	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:RESult?	402
12.6.7	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP	403
12.6.8	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP:LKUP	403
12.6.9	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP:RESult?	403
12.6.10	ETHernet:PORT<Pt>:STReam<St>:MAC:BRoadcast	403
12.6.11	ETHernet:PORT<Pt>:STReam<St>:MAC:DEFault	404
12.6.12	ETHernet:PORT<Pt>:STReam<St>:MAC:ETYPe	404
12.6.13	ETHernet:PORT<Pt>:STReam<St>:MAC:L3EType	405
12.6.14	ETHernet:PORT<Pt>:STReam<St>:MPLS[:ENABle]	405
12.6.15	ETHernet:PORT<Pt>:STReam<St>:MPLS:LCount	405
12.6.16	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:LABel	406
12.6.17	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:EBITs	406
12.6.18	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:TTL	407
12.6.19	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet[:ENABle]	407

12.6.20	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:AINCrement	407
12.6.21	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:SMAC	408
12.6.22	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:DMAC	408
12.6.23	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:ETYPe	409
12.6.24	ETHernet:PORT<Pt>:STReam<St>:MIM[:ENABle]	409
12.6.25	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:DEI	409
12.6.26	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:PRiority	410
12.6.27	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:VID	410
12.6.28	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:UCA	411
12.6.29	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:DEI	411
12.6.30	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:PRiority	411
12.6.31	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:SID	412
12.6.32	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:SMAC	412
12.6.33	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:DMAC	412
12.6.34	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:ETYPe	413
12.6.35	ETHernet:PORT<Pt>:STReam<St>:VLAN[:ENABle]	413
12.6.36	ETHernet:PORT<Pt>:STReam<St>:VLAN:LCount	414
12.6.37	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ID	414
12.6.38	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI	415
12.6.39	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI	415
12.6.40	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:PRiority	416
12.6.41	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ETYPe	416
12.6.42	ETHernet:PORT<Pt>:STReam<St>:LLC[:ENABle]	417
12.6.43	ETHernet:PORT<Pt>:STReam<St>:SNAP[:ENABle]	417
12.6.44	ETHernet:PORT<Pt>:STReam<St>:L2Custom[:ENABle]	418
12.6.45	ETHernet:PORT<Pt>:STReam<St>:IPV4[:ENABle]	418
12.6.46	ETHernet:PORT<Pt>:STReam<St>:IPV4:SOURce	418
12.6.47	ETHernet:PORT<Pt>:STReam<St>:IPV4:DESTination	419
12.6.48	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway[:ENABle]	419
12.6.49	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway:ADDRess	420
12.6.50	ETHernet:PORT<Pt>:STReam<St>:IPV4:NETMask	420
12.6.51	ETHernet:PORT<Pt>:STReam<St>:IPV4:HOST	420
12.6.52	ETHernet:PORT<Pt>:STReam<St>:IPV4:TTL	421
12.6.53	ETHernet:PORT<Pt>:STReam<St>:IPV4:TOS	421
12.6.54	ETHernet:PORT<Pt>:STReam<St>:IPV4:IDENtifier	422
12.6.55	ETHernet:PORT<Pt>:STReam<St>:IPV4:AINCrement	422
12.6.56	ETHernet:PORT<Pt>:STReam<St>:IPV4:MF	422
12.6.57	ETHernet:PORT<Pt>:STReam<St>:IPV4:DF	423
12.6.58	ETHernet:PORT<Pt>:STReam<St>:IPV4:RES	423
12.6.59	ETHernet:PORT<Pt>:STReam<St>:IPV4:PROToCol	424
12.6.60	ETHernet:PORT<Pt>:STReam<St>:IPV4:TLENgth?	424
12.6.61	ETHernet:PORT<Pt>:STReam<St>:IPV4:CHECksum?	424
12.6.62	ETHernet:PORT<Pt>:STReam<St>:DNS[:ENABle]	424
12.6.63	ETHernet:PORT<Pt>:STReam<St>:DNS:PRIMary	425
12.6.64	ETHernet:PORT<Pt>:STReam<St>:DNS:SECondary	425
12.6.65	ETHernet:PORT<Pt>:STReam<St>:IPV6[:ENABle]	426
12.6.66	ETHernet:PORT<Pt>:STReam<St>:IPV6:TCLass	426
12.6.67	ETHernet:PORT<Pt>:STReam<St>:IPV6:FLABel	426
12.6.68	ETHernet:PORT<Pt>:STReam<St>:IPV6:NHeader	427
12.6.69	ETHernet:PORT<Pt>:STReam<St>:IPV6:HLIMit	427
12.6.70	ETHernet:PORT<Pt>:STReam<St>:IPV6:SOURce	428
12.6.71	ETHernet:PORT<Pt>:STReam<St>:IPV6:DESTination	428
12.6.72	ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig	428
12.6.73	ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig:RESult?	429
12.6.74	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESS:IID	429
12.6.75	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESS:IID:AUTO	429
12.6.76	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESS:LINKlocal?	430
12.6.77	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESS:RAFLag?	430
12.6.78	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESS:SRCMac?	430

---

12.6.79	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLEsS:PREFix?	430
12.6.80	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLEsS:PRFLag?	430
12.6.81	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLEsS:LTIme?	431
12.6.82	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLEsS:RENew	431
12.6.83	ETHernet:PORT<Pt>:STReam<St>:IPV6:PLENght?	431
12.6.84	ETHernet:PORT<Pt>:STReam<St>:L3Custom[:ENABle]	431
12.6.85	ETHernet:PORT<Pt>:STReam<St>:DHCP[:ENABle]	432
12.6.86	ETHernet:PORT<Pt>:STReam<St>:DHCP:RENew	432
12.6.87	ETHernet:PORT<Pt>:STReam<St>:DHCP:DNS	432
12.6.88	ETHernet:PORT<Pt>:STReam<St>:DHCP:GATeway	433
12.6.89	ETHernet:PORT<Pt>:STReam<St>:DHCP:LETime?	433
12.6.90	ETHernet:PORT<Pt>:STReam<St>:UDP[:ENABle]	433
12.6.91	ETHernet:PORT<Pt>:STReam<St>:UDP:SPORt	434
12.6.92	ETHernet:PORT<Pt>:STReam<St>:UDP:DPORt	434
12.6.93	ETHernet:PORT<Pt>:STReam<St>:UDP:LENGth?	434
12.6.94	ETHernet:PORT<Pt>:STReam<St>:UDP:CNULl	435
12.6.95	ETHernet:PORT<Pt>:STReam<St>:UDP:CHECksum?	435
12.6.96	ETHernet:PORT<Pt>:STReam<St>:TCP[:ENABle]	435
12.6.97	ETHernet:PORT<Pt>:STReam<St>:TCP:ACONnect	436
12.6.98	ETHernet:PORT<Pt>:STReam<St>:TCP:LMODe	436
12.6.99	ETHernet:PORT<Pt>:STReam<St>:TCP:SPORt	436
12.6.100	ETHernet:PORT<Pt>:STReam<St>:TCP:DPORt	437
12.6.101	ETHernet:PORT<Pt>:STReam<St>:TCP:SEQuence	437
12.6.102	ETHernet:PORT<Pt>:STReam<St>:TCP:AINCrement	438
12.6.103	ETHernet:PORT<Pt>:STReam<St>:TCP:ACKNowledge	438
12.6.104	ETHernet:PORT<Pt>:STReam<St>:TCP:REServed	438
12.6.105	ETHernet:PORT<Pt>:STReam<St>:TCP:FCWR	439
12.6.106	ETHernet:PORT<Pt>:STReam<St>:TCP:FECE	439
12.6.107	ETHernet:PORT<Pt>:STReam<St>:TCP:FURG	440
12.6.108	ETHernet:PORT<Pt>:STReam<St>:TCP:FAcK	440
12.6.109	ETHernet:PORT<Pt>:STReam<St>:TCP:FPSH	440
12.6.110	ETHernet:PORT<Pt>:STReam<St>:TCP:FRST	441
12.6.111	ETHernet:PORT<Pt>:STReam<St>:TCP:FSYN	441
12.6.112	ETHernet:PORT<Pt>:STReam<St>:TCP:FFIN	442
12.6.113	ETHernet:PORT<Pt>:STReam<St>:TCP:WINDow	442
12.6.114	ETHernet:PORT<Pt>:STReam<St>:TCP:UPOinter	442
12.6.115	ETHernet:PORT<Pt>:STReam<St>:TCP:CHECksum?	443
12.6.116	ETHernet:PORT<Pt>:STReam1:BER:UTGenerator	443
12.6.117	ETHernet:PORT<Pt>:STReam1:BER:SEQuence	443
12.6.118	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure[:ENABled]	444
12.6.119	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:DTYPE	444
12.6.120	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MLIMit	444
12.6.121	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MDISruption	445
12.6.122	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:EFPeriod	445
12.6.123	ETHernet:PORT<Pt>:STReam1:BER:STHResholds[:ENABle]	445
12.6.124	ETHernet:PORT<Pt>:STReam1:BER:STHResholds:VALue	446
12.6.125	ETHernet:PORT<Pt>:STReam<St>:PAYLoad	446
12.6.126	ETHernet:PORT<Pt>:STReam<St>:UP16	447
12.6.127	ETHernet:PORT<Pt>:STReam<St>:UP32	447
12.6.128	ETHernet:PORT<Pt>:STReam:PCMA	447
12.6.129	ETHernet:PORT<Pt>:STReam:CROsSprbs	448
12.6.130	ETHernet:PORT<Pt>:STReam<St>:LATency	448
12.6.131	ETHernet:PORT<Pt>:STReam<St>:JITTer	448
12.6.132	ETHernet:PORT<Pt>:STReam<St>:FLOsS	449
12.6.133	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds[:ENABle]	449
12.6.134	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds:MODE	449
12.6.135	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds:COUNt	450
12.6.136	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds:RATIo	450
12.6.137	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds[:ENABle]	451

12.6.138	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds:VALue	451
12.6.139	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds[:ENABLE]	451
12.6.140	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds:VALue	452
12.6.141	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:FIELd	452
12.6.142	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:TYPE	453
12.6.143	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:OFFSet	453
12.6.144	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:LENGth	454
12.6.145	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:STARt	454
12.6.146	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:END	454
12.6.147	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:STEP	455
12.6.148	ETHernet:PORT<Pt>:STReam<St>:CUSTom:LENGth	455
12.6.149	ETHernet:PORT<Pt>:STReam<St>:CUSTom:DATA	456
12.7	Settings	457
12.7.1	ETHernet:PORT<Pt>:SETTings:AARP	457
12.7.2	ETHernet:PORT<Pt>:SETTings:ANDP	457
12.7.3	ETHernet:PORT<Pt>:SETTings:APINg	457
12.7.4	ETHernet:PORT<Pt>:SETTings:ACMA	458
12.7.5	ETHernet:PORT<Pt>:SETTings:PLENenght	458
12.7.6	ETHernet:PORT<Pt>:SETTings:IPViolations	458
12.7.7	ETHernet:PORT<Pt>:SETTings:ILThreshold	459
12.7.8	ETHernet:PORT<Pt>:SETTings:FIViolations	459
12.7.9	ETHernet:PORT<Pt>:SETTings:JFSize	459
12.7.10	ETHernet:PORT<Pt>:SETTings:FRESults	460
12.7.11	ETHernet:PORT<Pt>:SETTings:ACISetup	460
12.7.12	ETHernet:PORT<Pt>:SETTings:ASTGenerator	460
12.7.13	ETHernet:PORT<Pt>:SETTings:BER:OBAMeasuring	461
12.7.14	ETHernet:PORT<Pt>:SETTings:BER:IAFFilter	461
12.7.15	ETHernet:PORT<Pt>:SETTings:BER:CLFrames	461
12.7.16	ETHernet:PORT<Pt>:SETTings:BER:HIDeframeloss	462
12.8	Filter	463
12.8.1	ETHernet:PORT<Pt>:FILTer[:ENABLE]	463
12.8.2	ETHernet:PORT<Pt>:FILTer:RESet	463
12.8.3	ETHernet:PORT<Pt>:FILTer:ENCapsulation	463
12.8.4	ETHernet:PORT<Pt>:FILTer:PROTOcols	464
12.8.5	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>[:ENABLE]	465
12.8.6	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SMAC	465
12.8.7	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DMAC	465
12.8.8	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMSMac	466
12.8.9	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMDMac	466
12.8.10	ETHernet:PORT<Pt>:FILTer:POFFset	467
12.8.11	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:PATtern	467
12.8.12	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SPORT	467
12.8.13	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DPORt	468
12.8.14	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV4	468
12.8.15	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DIV4	469
12.8.16	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV6	469
12.8.17	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:HIV6	470
12.8.18	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:FIV6	470
12.8.19	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:LABel	471
12.8.20	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:EBITs	471
12.8.21	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:BOLStack	472
12.8.22	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:TTL	472
12.8.23	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:ID	473
12.8.24	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:CFI	473
12.8.25	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:DEI	474
12.8.26	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:PRiority	474
12.8.27	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMSMac	475
12.8.28	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMDMac	475
12.8.29	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:ID	475

12.8.30	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:PRiority	476
12.8.31	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:DEI	476
12.8.32	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:ID	477
12.8.33	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:PRiority	477
12.8.34	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:DEI	478
12.8.35	ETHERnet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:UCA	478
12.9	Thresholds	479
12.9.1	ETHERnet:PORT<Pt>:THResholds[:ENABle]	479
12.9.2	ETHERnet:PORT<Pt>:THResholds:SELect	479
12.9.3	ETHERnet:PORT<Pt>:THResholds:VALue	480
12.10	SyncE	482
12.10.1	ETHERnet:SYNCe:PTHROUGH:FCAPture	482
12.10.2	ETHERnet:PORT<Pt>:SYNCe:PTHROUGH:QLEVel[:ENABle]	482
12.10.3	ETHERnet:PORT<Pt>:SYNCe:PTHROUGH:QLEVel:USER	482
12.10.4	ETHERnet:PORT<Pt>:SYNCe[:ENABle]	483
12.10.5	ETHERnet:PORT<Pt>:SYNCe:MODE	483
12.10.6	ETHERnet:PORT<Pt>:SYNCe:FCAPture	483
12.10.7	ETHERnet:PORT<Pt>:SYNCe:QLEVel	484
12.10.8	ETHERnet:PORT<Pt>:SYNCe:MAC	484
12.10.9	ETHERnet:PORT<Pt>:SYNCe:MAC:AUTO	484
12.10.10	ETHERnet:PORT<Pt>:SYNCe:EFLag	485
12.11	Precision Time Protocol - IEEE 1588v2	486
12.11.1	ETHERnet:PORT<Pt>:PTP[:ENABle]	486
12.11.2	ETHERnet:PORT<Pt>:PTP:SONLy	486
12.11.3	ETHERnet:PORT<Pt>:PTP:CAST	486
12.11.4	ETHERnet:PORT<Pt>:PTP:UNEGotiate	487
12.11.5	ETHERnet:PORT<Pt>:PTP:PROFile	487
12.11.6	ETHERnet:PORT<Pt>:PTP:DOMain	487
12.11.7	ETHERnet:PORT<Pt>:PTP:TPRotocol	488
12.11.8	ETHERnet:PORT<Pt>:PTP:MAC[:SOURce]	488
12.11.9	ETHERnet:PORT<Pt>:PTP:MAC:AUTO	489
12.11.10	ETHERnet:PORT<Pt>:PTP:MAC:DESTination	489
12.11.11	ETHERnet:PORT<Pt>:PTP:MAC:SMULTicast	489
12.11.12	ETHERnet:PORT<Pt>:PTP:MAC:ARP	490
12.11.13	ETHERnet:PORT<Pt>:PTP:MAC:ARP:RESult?	490
12.11.14	ETHERnet:PORT<Pt>:PTP:MAC:NDP	490
12.11.15	ETHERnet:PORT<Pt>:PTP:MAC:NDP:RESult?	490
12.11.16	ETHERnet:PORT<Pt>:PTP:PTYPe	491
12.11.17	ETHERnet:PORT<Pt>:PTP:EXT	491
12.11.18	ETHERnet:PORT<Pt>:PTP:EXT:TYPE	491
12.11.19	ETHERnet:PORT<Pt>:PTP:EXT:LENGth	492
12.11.20	ETHERnet:PORT<Pt>:PTP:EXT:DATA	492
12.11.21	ETHERnet:PORT<Pt>:PTP:IP:IPV4:SOURce	493
12.11.22	ETHERnet:PORT<Pt>:PTP:IP:IPV4:DESTination	493
12.11.23	ETHERnet:PORT<Pt>:PTP:IP:IPV6:SOURce	493
12.11.24	ETHERnet:PORT<Pt>:PTP:IP:IPV6:DESTination	494
12.11.25	ETHERnet:PORT<Pt>:PTP:IPV6:ADDRconfig	494
12.11.26	ETHERnet:PORT<Pt>:PTP:IPV6:ADDRconfig:RESult?	494
12.11.27	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:IID	495
12.11.28	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:IID:AUTO	495
12.11.29	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:LINKlocal?	495
12.11.30	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:RAFLag?	495
12.11.31	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:SRcMac?	496
12.11.32	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:PREFix?	496
12.11.33	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:PRFLag?	496
12.11.34	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:LTIME?	496
12.11.35	ETHERnet:PORT<Pt>:PTP:IPV6:SLESS:RENew	496
12.11.36	ETHERnet:PORT<Pt>:PTP:IP:DSCP:EVENT	496
12.11.37	ETHERnet:PORT<Pt>:PTP:IP:DSCP:NORMal	497



12.11.38	ETHernet:PORT<Pt>:PTP:TUNNeling	497
12.11.39	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LCount	497
12.11.40	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ID	498
12.11.41	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI	498
12.11.42	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI	499
12.11.43	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:PRiority	499
12.11.44	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ETYPe	500
12.11.45	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LCount	500
12.11.46	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:LABel	501
12.11.47	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:EBITs	501
12.11.48	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:TTL	501
12.11.49	ETHernet:PORT<Pt>:PTP:FCAPture	502
12.11.50	ETHernet:PORT<Pt>:PTP:FCAPture:DIRecotry	502
12.11.51	ETHernet:PORT<Pt>:PTP:ELOG	503
12.11.52	ETHernet:PORT<Pt>:PTP:SMODE	503
12.11.53	ETHernet:PORT<Pt>:PTP:DMEChanism	503
12.11.54	ETHernet:PORT<Pt>:PTP:CLOCK:SOURce	504
12.11.55	ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity	504
12.11.56	ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity:AUTO	504
12.11.57	ETHernet:PORT<Pt>:PTP:CLOCK:P1	505
12.11.58	ETHernet:PORT<Pt>:PTP:CLOCK:P2	505
12.11.59	ETHernet:PORT<Pt>:PTP:CLOCK:CLASs	505
12.11.60	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy	506
12.11.61	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy:USER	506
12.11.62	ETHernet:PORT<Pt>:PTP:CLOCK:TSOURce	507
12.11.63	ETHernet:PORT<Pt>:PTP:CLOCK:TSOURce:USER	507
12.11.64	ETHernet:PORT<Pt>:PTP:TIMing:AINTerval	508
12.11.65	ETHernet:PORT<Pt>:PTP:TIMing:ATIMEout	508
12.11.66	ETHernet:PORT<Pt>:PTP:TIMing:UOFFset	509
12.11.67	ETHernet:PORT<Pt>:PTP:TIMing:SINTerval	509
12.11.68	ETHernet:PORT<Pt>:PTP:TIMing:DRINterval	510
12.11.69	ETHernet:PORT<Pt>:PTP:TIMing:UDURation	510
12.11.70	ETHernet:PORT<Pt>:PTP:TIMing:GCABle	511
12.11.71	ETHernet:PORT<Pt>:PTP:LOG?	511
12.12	Follow	512
12.12.1	ETHernet:FOLLow:TRAFfic	512
12.12.2	ETHernet:FOLLow:STReam<St>	512
12.12.3	ETHernet:FOLLow:GATeway<St>	512
12.12.4	ETHernet:FOLLow:SETTings	513
12.12.5	ETHernet:FOLLow:FILTer	513
12.12.6	ETHernet:FOLLow:THResholds	513
12.12.7	ETHernet:FOLLow:SYNCe	514
12.12.8	ETHernet:FOLLow:PTP	514
12.12.9	ETHernet:PORT<Pt>:FOLLow:TRAFfic	514
12.12.10	ETHernet:PORT<Pt>:FOLLow:STReam<St>	515
12.12.11	ETHernet:PORT<Pt>:FOLLow:GATeway<St>	515
12.12.12	ETHernet:PORT<Pt>:FOLLow:SETTings	515
12.12.13	ETHernet:PORT<Pt>:FOLLow:FILTer	516
12.12.14	ETHernet:PORT<Pt>:FOLLow:THResholds	516
12.12.15	ETHernet:PORT<Pt>:FOLLow:SYNCe	516
12.12.16	ETHernet:PORT<Pt>:FOLLow:PTP	517
12.12.17	ETHernet:PORT<Pt>:FOLLow:WAN	517
12.13	Stimuli	518
12.13.1	ETHernet:PORT<Pt>:STIMuli:ALARm	518
12.13.2	ETHernet:PORT<Pt>:STIMuli:ERRor	518
12.13.3	ETHernet:PORT<Pt>:STIMuli:EINSerTion	519
12.13.4	ETHernet:PORT<Pt>:STIMuli:EBLength	519
12.13.5	ETHernet:PORT<Pt>:STIMuli:FEC:ERRor:LANE	520
12.13.6	ETHernet:PORT<Pt>:STIMuli:WAN:ALARm	520

12.13.7	ETHernet:PORT<Pt>:STIMuli:WAN:ERRor	521
12.13.8	ETHernet:PORT<Pt>:STIMuli:WAN:EINsertion	521
12.13.9	ETHernet:PORT<Pt>:STIMuli:WAN:EBLength	521
12.13.10	ETHernet:PORT<Pt>:STIMuli:DEViation	522
12.13.11	ETHernet:PORT<Pt>:STIMuli:PCS:ALARm	522
12.13.12	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor	523
12.13.13	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor:LANE	523
12.13.14	ETHernet:PORT<Pt>:STIMuli:PCS:EINsertion	524
12.13.15	ETHernet:PORT<Pt>:STIMuli:PCS:EBLength	524
12.13.16	ETHernet:PORT<Pt>:STIMuli:PCS:ERATe	524
12.13.17	ETHernet:PORT<Pt>:STIMuli:PCS:EELength	525
12.13.18	ETHernet:PORT<Pt>:STIMuli:PCS:ENLength	525
12.13.19	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:BIT	525
12.13.20	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:TYPE	526
12.13.21	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:LANE	526
12.13.22	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:NS?	526
12.14	Result	527
12.14.1	ETHernet:PORT<Pt>:IFETch?	527
12.14.2	ETHernet:PORT<Pt>:TFETch?	532
12.14.3	ETHernet:PORT<Pt>:TFRDiffrnce:PSElection	533
12.15	Status	534
12.15.1	ETHernet:STATus:PORT<Pt>:AESummary[:EVENT]?	534
12.15.2	ETHernet:STATus:PORT<Pt>:AESummary:CONDition?	534
12.15.3	ETHernet:STATus:PORT<Pt>:ALARm<section>[:EVENT]?	535
12.15.4	ETHernet:STATus:PORT<Pt>:ALARm<section>:CONDition?	536
12.15.5	ETHernet:STATus:PORT<Pt>:ERRor<section>[:EVENT]?	536
12.15.6	ETHernet:STATus:PORT<Pt>:ERRor<section>:CONDition?	537
12.15.7	ETHernet:STATus:PORT<Pt>:LINK?	537
12.15.8	ETHernet:STATus:PORT<Pt>:INTerface?	537
12.15.9	ETHernet:STATus:PORT<Pt>:FRAMES?	537
12.15.10	ETHernet:STATus:PORT<Pt>:MPLS?	537
12.15.11	ETHernet:STATus:PORT<Pt>:VLAN?	538
12.15.12	ETHernet:STATus:PORT<Pt>:SPeed?	538
12.15.13	ETHernet:STATus:PORT<Pt>:DUPLex?	538
12.15.14	ETHernet:STATus:PORT<Pt>:MDI?	538
12.15.15	ETHernet:STATus:PORT<Pt>:L10G?	538
12.15.16	ETHernet:STATus:PORT<Pt>:LFS?	539
12.15.17	ETHernet:STATus:PORT<Pt>:ANComplete?	539
12.15.18	ETHernet:STATus:PORT<Pt>:PCAPable?	539
12.15.19	ETHernet:STATus:PORT<Pt>:APRequest?	539
12.15.20	ETHernet:STATus:PORT<Pt>:RFAult?	539
12.15.21	ETHernet:STATus:PORT<Pt>:LClock?	540
12.15.22	ETHernet:STATus:PORT<Pt>:SADuplex?	540
12.15.23	ETHernet:STATus:PORT<Pt>:UTILization?	540
12.15.24	ETHernet:STATus:PORT<Pt>:THRoughput?	540
12.15.25	ETHernet:STATus:PORT<Pt>:EFRames?	541
12.15.26	ETHernet:STATus:PORT<Pt>:PCS:SHLock?	541
12.15.27	ETHernet:STATus:PORT<Pt>:PCS:AMLock?	541
12.15.28	ETHernet:STATus:PORT<Pt>:TIMing?	541
12.15.29	ETHernet:STATus:PORT<Pt>:TIMing:SOURce?	541
12.15.30	ETHernet:STATus:PORT<Pt>:SYNCe?	542
12.15.31	ETHernet:STATus:PORT<Pt>:PTP:LClock?	542
12.15.32	ETHernet:STATus:PORT<Pt>:PTP:WCLock?	542
12.15.33	ETHernet:STATus:PORT<Pt>:PTP:PCLock?	542
12.15.34	ETHernet:STATus:PORT<Pt>:PTP:GClock?	543
12.15.35	ETHernet:STATus:PORT<Pt>:PTP:FMASters?	543
12.15.36	ETHernet:STATus:PORT<Pt>:WAN:CAPTure:SOH:TRACe?	543
12.15.37	ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:SOH?	544
12.15.38	ETHernet:STATus:PORT<Pt>:WAN:CAPTure:POH:TRACe?	544

12.15.39	ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:POH?	545
12.16	Ping	546
12.16.1	ETHernet:PING:START	546
12.16.2	ETHernet:PING:STOP	546
12.16.3	ETHernet:PING:SETup:PORT<Pt>:DMODE	546
12.16.4	ETHernet:PING:SETup:PORT<Pt>:SDURation	546
12.16.5	ETHernet:PING:SETup:PORT<Pt>:RDURation	547
12.16.6	ETHernet:PING:SETup:PORT<Pt>:INTerval	547
12.16.7	ETHernet:PING:SETup:PORT<Pt>:FSIZE	547
12.16.8	ETHernet:PING:SETup:PORT<Pt>:TOUT	548
12.16.9	ETHernet:PING:RESults:SUMMary?	548
12.16.10	ETHernet:PING:RESults:RTT?	548
12.16.11	ETHernet:PING:RESults:NREQuests?	549
12.16.12	ETHernet:PING:RESults:SREQuest?	549
12.17	Traceroute	550
12.17.1	ETHernet:TRACeroute:START	550
12.17.2	ETHernet:TRACeroute:STOP	550
12.17.3	ETHernet:TRACeroute:SETup:NATTempts	550
12.17.4	ETHernet:TRACeroute:SETup:MNHops	550
12.17.5	ETHernet:TRACeroute:SETup:TOUT	551
12.17.6	ETHernet:TRACeroute:SETup:NTPHosts	551
12.17.7	ETHernet:TRACeroute:RESults:NHOPs?	551
12.17.8	ETHernet:TRACeroute:RESults:HOP?	552
12.18	RFC2544	553
12.18.1	ETHernet:RFC:START	553
12.18.2	ETHernet:RFC:STOP	553
12.18.3	ETHernet:RFC:SETup:GENeral:MODE	553
12.18.4	ETHernet:RFC:SETup:GENeral:TSElection	553
12.18.5	ETHernet:RFC:SETup:GENeral:E2E:OWAY	554
12.18.6	ETHernet:RFC:SETup:GENeral:E2E:ADDRESS	554
12.18.7	ETHernet:RFC:SETup:GENeral:E2E:TDIRection	554
12.18.8	ETHernet:RFC:SETup:GENeral:E2E:SSTORE	555
12.18.9	ETHernet:RFC:SETup:GENeral:TLFrames	555
12.18.10	ETHernet:RFC:SETup:GENeral:IAFFilter	555
12.18.11	ETHernet:RFC:SETup:GENeral:JITTer	556
12.18.12	ETHernet:RFC:SETup:GENeral:ACCumulate	556
12.18.13	ETHernet:RFC:SETup:GENeral:TCLayer	556
12.18.14	ETHernet:RFC:SETup:GENeral:TTYPe	557
12.19	RFC2544 - Throughput	558
12.19.1	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:MODE	558
12.19.2	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:USER	558
12.19.3	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:JUMBo	559
12.19.4	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:BEGin	559
12.19.5	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:END	559
12.19.6	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:STEP	560
12.19.7	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:CONStant	560
12.19.8	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STOP	560
12.19.9	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MINimum	561
12.19.10	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MAXimum	561
12.19.11	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STEP	562
12.19.12	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch[:ENABLE]	562
12.19.13	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:MODE	563
12.19.14	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:RESolution	563
12.19.15	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:STEP	563
12.19.16	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:REPeats	564
12.20	RFC2544 - Frame Loss	565
12.20.1	ETHernet:RFC:SETup:PORT<Pt>:FLOSS:FSIZE:MODE	565
12.20.2	ETHernet:RFC:SETup:PORT<Pt>:FLOSS:FSIZE:USER	565
12.20.3	ETHernet:RFC:SETup:PORT<Pt>:FLOSS:FSIZE:JUMBo	566

12.20.4	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:FSIZe:BEgIn	566
12.20.5	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:FSIZe:END	566
12.20.6	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:FSIZe:STEP	567
12.20.7	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:FSIZe:CONStant	567
12.20.8	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:STOP	567
12.20.9	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:MINimum	568
12.20.10	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:MAXimum	568
12.20.11	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:STEP	569
12.20.12	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:ASEarch[:ENABle]	569
12.20.13	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:ASEarch:MODE	570
12.20.14	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLOad:ASEarch:RESolution	570
12.20.15	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:DURation:STEP	570
12.20.16	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:DURation:REPeats	571
12.21	RFC2544 - Throughput and Frame Loss	572
12.21.1	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:MODE	572
12.21.2	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:USER	572
12.21.3	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:JUMBo	573
12.21.4	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:BEgIn	573
12.21.5	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:END	573
12.21.6	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:STEP	574
12.21.7	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:CONStant	574
12.21.8	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:STOP	574
12.21.9	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:MINimum	575
12.21.10	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:MAXimum	575
12.21.11	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:STEP	576
12.21.12	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:ASEarch[:ENABle]	576
12.21.13	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:ASEarch:MODE	577
12.21.14	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLOad:ASEarch:RESolution	577
12.21.15	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:STEP	577
12.21.16	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:REPeats	578
12.22	RFC2544 - Latency	579
12.22.1	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:MODE	579
12.22.2	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:USER	579
12.22.3	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:JUMBo	580
12.22.4	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:BEgIn	580
12.22.5	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:END	580
12.22.6	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:STEP	581
12.22.7	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:CONStant	581
12.22.8	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:MINimum	582
12.22.9	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:MAXimum	582
12.22.10	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:STEP	583
12.22.11	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:ONLY	583
12.22.12	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:OTEST	584
12.22.13	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLOad:TLEVel	584
12.22.14	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:STEP	584
12.22.15	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:REPeats	585
12.23	RFC2544 - Burst	586
12.23.1	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:MODE	586
12.23.2	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:USER	586
12.23.3	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:JUMBo	587
12.23.4	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:BEgIn	587
12.23.5	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:END	587
12.23.6	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:STEP	588
12.23.7	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:CONStant	588
12.23.8	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:MODE	589
12.23.9	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:BEgIn	589
12.23.10	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:END	589
12.23.11	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STEP	590
12.23.12	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:CONStant	590

12.23.13	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STOP	590
12.23.14	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch[:ENABLE]	591
12.23.15	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:MODE	591
12.23.16	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:RESolution	592
12.23.17	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:STEP	592
12.23.18	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:REPeats	592
12.24	RFC2544 - Result	594
12.24.1	ETHernet:RFC:RESult:TEST	594
12.24.2	ETHernet:RFC:RESult:PORT<Pt>:NSTep?	594
12.24.3	ETHernet:RFC:RESult:PORT<Pt>:SElect	594
12.24.4	ETHernet:RFC:RESult:PORT<Pt>:FETCh?	595
12.25	Y.1564 Service Activation Test	596
12.25.1	ETHernet:SATest:START	596
12.25.2	ETHernet:SATest:STOP	596
12.25.3	ETHernet:SATest:SETup:TMODE	596
12.25.4	ETHernet:SATest:SETup:OWTest:LTRemote[:ENABLE]	596
12.25.5	ETHernet:SATest:SETup:OWTest:RTLLocal[:ENABLE]	597
12.25.6	ETHernet:SATest:SETup:OWTest:BSYMMetry	597
12.25.7	ETHernet:SATest:SETup:OWTest:SYNChronization	597
12.25.8	ETHernet:SATest:SETup:OWTest:TLSAddresses[:ENABLE]	598
12.25.9	ETHernet:SATest:SETup:CCFC	598
12.25.10	ETHernet:SATest:SETup:CBRate	598
12.25.11	ETHernet:SATest:SETup:SPTDuration	599
12.25.12	ETHernet:SATest:SETup:SPTDuration:CDURATION	599
12.25.13	ETHernet:SATest:SETup:COFail	600
12.25.14	ETHernet:SATest:SETup:GENeral:IAFFilter	600
12.25.15	ETHernet:SATest:SETup:SERvice<no>[:ENABLE]	600
12.25.16	ETHernet:SATest:SETup:SERvice<no>:NAME	601
12.25.17	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]	601
12.25.18	ETHernet:SATest:SETup:SERvice<no>:RTLLocal[:CIRate]	601
12.25.19	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]:PROFile	602
12.25.20	ETHernet:SATest:SETup:SERvice<no>:RTLLocal[:CIRate]:PROFile	602
12.25.21	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]:ENCoding:VIDeo	602
12.25.22	ETHernet:SATest:SETup:SERvice<no>:RTLLocal[:CIRate]:ENCoding:VIDeo	603
12.25.23	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]:ENCoding:VOICe	603
12.25.24	ETHernet:SATest:SETup:SERvice<no>:RTLLocal[:CIRate]:ENCoding:VOICe	604
12.25.25	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]:NCHannels	604
12.25.26	ETHernet:SATest:SETup:SERvice<no>:RTLLocal[:CIRate]:NCHannels	604
12.25.27	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:EIRate	605
12.25.28	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:EIRate	605
12.25.29	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:TPOLicing[:ENABLE]	605
12.25.30	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:TPOLicing[:ENABLE]	606
12.25.31	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:TPOLicing:MARGin	606
12.25.32	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:TPOLicing:MARGin	606
12.25.33	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CBSize	607
12.25.34	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CBSize	607
12.25.35	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:EBSize	607
12.25.36	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:EBSize	608
12.25.37	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare[:ENABLE]	608
12.25.38	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CAVare[:ENABLE]	608
12.25.39	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare:CMETHod	609
12.25.40	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CAVare:CMETHod	609
12.25.41	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare:DSCP:GREen	609
12.25.42	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CAVare:DSCP:GREen	610
12.25.43	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare:DSCP:YELLow	610
12.25.44	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CAVare:DSCP:YELLow	610
12.25.45	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare:PCP:GREen	611
12.25.46	ETHernet:SATest:SETup:SERvice<no>:RTLLocal:CAVare:PCP:GREen	611
12.25.47	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare:PCP:YELLow	611

12.25.48	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:CAVare:PCP:YELLOW	612
12.25.49	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:SACRiteria:FTDelay	612
12.25.50	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:SACRiteria:FTDelay	612
12.25.51	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:SACRiteria:FDVariation	613
12.25.52	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:SACRiteria:FDVariation	613
12.25.53	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:SACRiteria:FLRatio	613
12.25.54	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:SACRiteria:FLRatio	614
12.25.55	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:SACRiteria:AVAILability	614
12.25.56	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:SACRiteria:AVAILability	614
12.25.57	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:FSMode	615
12.25.58	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:FSMode	615
12.25.59	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CFSize	616
12.25.60	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:CFSize	616
12.25.61	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:EMIX	617
12.25.62	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:EMIX	618
12.25.63	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:MTU	618
12.25.64	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:MTU	619
12.25.65	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:UDFSize	619
12.25.66	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:UDFSize	619
12.25.67	ETHernet:SAtest:SETup:SERvice<no>:SCTSteps:SDURation	620
12.25.68	ETHernet:SAtest:SETup:SERvice<no>:SCTSteps:NSTep	620
12.25.69	ETHernet:SAtest:SETup:SERvice<no>:SCTSteps:SLOPe	620
12.25.70	ETHernet:SAtest:RESult:TSYNchronization?	621
12.25.71	ETHernet:SAtest:RESult:SCTest[:LTRemote]?	621
12.25.72	ETHernet:SAtest:RESult:SCTest:RTLocal?	621
12.25.73	ETHernet:SAtest:RESult:SCTest:SERvice<no>[:LTRemote]:CIRate?	622
12.25.74	ETHernet:SAtest:RESult:SCTest:SERvice<no>:RTLocal:CIRate?	622
12.25.75	ETHernet:SAtest:RESult:SCTest:SERvice<no>[:LTRemote]:EIRate?	623
12.25.76	ETHernet:SAtest:RESult:SCTest:SERvice<no>:RTLocal:EIRate?	623
12.25.77	ETHernet:SAtest:RESult:SCTest:SERvice<no>[:LTRemote]:TPOLicing?	623
12.25.78	ETHernet:SAtest:RESult:SCTest:SERvice<no>:RTLocal:TPOLicing?	624
12.25.79	ETHernet:SAtest:RESult:SCTest:SERvice<no>[:LTRemote]:CBSize?	624
12.25.80	ETHernet:SAtest:RESult:SCTest:SERvice<no>:RTLocal:CBSize?	624
12.25.81	ETHernet:SAtest:RESult:SCTest:SERvice<no>[:LTRemote]:EBSize?	624
12.25.82	ETHernet:SAtest:RESult:SCTest:SERvice<no>:RTLocal:EBSize?	625
12.25.83	ETHernet:SAtest:RESult:SPTest[:LTRemote]?	625
12.25.84	ETHernet:SAtest:RESult:SPTest:RTLocal?	625
12.25.85	ETHernet:SAtest:RESult:SPTest:SERvice<no>[:LTRemote]?	626
12.25.86	ETHernet:SAtest:RESult:SPTest:SERvice<no>:RTLocal?	626
12.26	Cable Test	627
12.26.1	ETHernet:CABLE:STARt	627
12.26.2	ETHernet:CABLE:STOP	627
12.26.3	ETHernet:CABLE:CCStandard	628
12.26.4	ETHernet:CABLE:RESults:PAIR<Pr>?	629
12.27	IP Channel Statistics	630
12.27.1	ETHernet:CStat:STARt	630
12.27.2	ETHernet:CStat:STOP	630
12.27.3	ETHernet:CStat:SETup:FOLLOW	630
12.27.4	ETHernet:CStat:SETup:PORT<Pt>:FOLLOW	630
12.27.5	ETHernet:CStat:SETup:PORT<Pt>:CDEFinitions	631
12.27.6	ETHernet:CStat:SETup:PORT<Pt>:MERGe	631
12.27.7	ETHernet:CStat:SETup:PORT<Pt>:FRESults	632
12.27.8	ETHernet:CStat:RESults:PORT<Pt>:NCHannels?	632
12.27.9	ETHernet:CStat:RESults:PORT<Pt>:DFRames?	632
12.27.10	ETHernet:CStat:RESults:PORT<Pt>:FETCh?	632
12.27.11	ETHernet:CStat:RESults:RESet	634
12.28	Monitor Generator	635
12.28.1	ETHernet:MONGen:SETup:GENeral:IAFFilter	635
12.29	Sync Test	636

12.29.1	ETHernet:SYNTest:SETup:MPERiod	636
12.29.2	ETHernet:SYNTest:SETup:MPERiod:USERdefined	636
12.29.3	ETHernet:SYNTest:SETup:PPS:CABLEcorrection	636
12.29.4	ETHernet:SYNTest:SETup:PACKet:CABLEcorrection	637
12.29.5	ETHernet:THResholds:PPS:PHASe[:ENABLE]	637
12.29.6	ETHernet:THResholds:PPS:PHASe:MINValue	637
12.29.7	ETHernet:THResholds:PPS:PHASe:MAXValue	638
12.29.8	ETHernet:THResholds:PPS:FILTEred[:ENABLE]	638
12.29.9	ETHernet:THResholds:PPS:FILTEred:MINValue	638
12.29.10	ETHernet:THResholds:PPS:FILTEred:MAXValue	639
12.29.11	ETHernet:THResholds:PPS:DEViation[:ENABLE]	639
12.29.12	ETHernet:THResholds:PPS:DEViation:MINValue	639
12.29.13	ETHernet:THResholds:PPS:DEViation:MAXValue	640
12.29.14	ETHernet:THResholds:OWD:SYNC[:ENABLE]	640
12.29.15	ETHernet:THResholds:OWD:SYNC:MINValue	640
12.29.16	ETHernet:THResholds:OWD:SYNC:MAXValue	641
12.29.17	ETHernet:THResholds:OWD:FOLLOw[:ENABLE]	641
12.29.18	ETHernet:THResholds:OWD:FOLLOw:MINValue	641
12.29.19	ETHernet:THResholds:OWD:FOLLOw:MAXValue	642
12.29.20	ETHernet:THResholds:OWD:DELay[:ENABLE]	642
12.29.21	ETHernet:THResholds:OWD:DELay:MINValue	642
12.29.22	ETHernet:THResholds:OWD:DELay:MAXValue	643
12.30	Frame Capture	643
12.30.1	ETHernet:PORT<Pt>:CAPTure:STARt	643
12.30.2	ETHernet:PORT<Pt>:CAPTure:STOP	643
12.30.3	ETHernet:PORT<Pt>:CAPTure:STATus?	643
12.30.4	ETHernet:PORT<Pt>:CAPTure:BUFSize	644
12.30.5	ETHernet:PORT<Pt>:CAPTure:SLICing	644
12.30.6	ETHernet:PORT<Pt>:CAPTure:ALOCation	644
12.30.7	ETHernet:PORT<Pt>:CAPTure:TXFRame	645
12.30.8	ETHernet:PORT<Pt>:CAPTure:TRIGger:TYPE	645
12.30.9	ETHernet:PORT<Pt>:CAPTure:TRIGger:POSition	646
12.30.10	ETHernet:PORT<Pt>:CAPTure:TRIGger:ERRor	646
12.30.11	ETHernet:PORT<Pt>:CAPTure:TRIGger:OFFSet	646
12.30.12	ETHernet:PORT<Pt>:CAPTure:TRIGger:PATTErn	647
12.30.13	ETHernet:PORT<Pt>:CAPTure:STORe	647
12.30.14	ETHernet:PORT<Pt>:CAPTure:BUFFer?	647
12.31	OAM	648
12.31.1	ETHernet:PORT<Pt>:OAM:PROTOcol	648
12.31.2	ETHernet:PORT<Pt>:OAM:SMAC	648
12.31.3	ETHernet:PORT<Pt>:OAM:MAC:ETYPe	649
12.31.4	ETHernet:PORT<Pt>:OAM:AH:DISCOvery[:ENABLE]	649
12.31.5	ETHernet:PORT<Pt>:OAM:AH:DISCOvery:LMODE	649
12.31.6	ETHernet:PORT<Pt>:OAM:AH:DISCOvery:VOUI	650
12.31.7	ETHernet:PORT<Pt>:OAM:AH:DISCOvery:VSINfo	650
12.31.8	ETHernet:PORT<Pt>:OAM:AH:DISCOvery:UNIDirectional	650
12.31.9	ETHernet:PORT<Pt>:OAM:AH:DISCOvery:VRETrival	651
12.31.10	ETHernet:PORT<Pt>:OAM:AH:LDEFects:LFAults	651
12.31.11	ETHernet:PORT<Pt>:OAM:AH:LDEFects:DGASp	651
12.31.12	ETHernet:PORT<Pt>:OAM:AH:LDEFects:CEvent	652
12.31.13	ETHernet:PORT<Pt>:OAM:AG[:ENABLE]	652
12.31.14	ETHernet:PORT<Pt>:OAM:AG:MEPid	652
12.31.15	ETHernet:PORT<Pt>:OAM:AG:MDLevel	653
12.31.16	ETHernet:PORT<Pt>:OAM:AG:DOMain	653
12.31.17	ETHernet:PORT<Pt>:OAM:AG:MAIDentifier	653
12.31.18	ETHernet:PORT<Pt>:OAM:AG:CCM:INTerval	654
12.31.19	ETHernet:PORT<Pt>:OAM:AG:LBM:OTLV	654
12.31.20	ETHernet:PORT<Pt>:OAM:AG:LBM:TLVLength	655
12.31.21	ETHernet:PORT<Pt>:OAM:AG:LBM:DTLV:VALue	655

---

12.31.22	ETHernet:PORT<Pt>:OAM:AG:LBM:TTLV:VALue	655
12.31.23	ETHernet:PORT<Pt>:OAM:AG:LTM:TTL	656
12.31.24	ETHernet:PORT<Pt>:OAM:AG:LTM:TID	656
12.31.25	ETHernet:PORT<Pt>:OAM:AG:MEPList:ADD	656
12.31.26	ETHernet:PORT<Pt>:OAM:AG:MEPList:DELeTe[:MEP]	657
12.31.27	ETHernet:PORT<Pt>:OAM:AG:MEPList:CATalog?	657
12.31.28	ETHernet:PORT<Pt>:OAM:Y[:ENABle]	657
12.31.29	ETHernet:PORT<Pt>:OAM:Y:MEPid	657
12.31.30	ETHernet:PORT<Pt>:OAM:Y:MEGid	658
12.31.31	ETHernet:PORT<Pt>:OAM:Y:MEGLLevel	658
12.31.32	ETHernet:PORT<Pt>:OAM:Y:CCM:INTErval	659
12.31.33	ETHernet:PORT<Pt>:OAM:Y:LBM:OTLV	659
12.31.34	ETHernet:PORT<Pt>:OAM:Y:LBM:TLVLength	659
12.31.35	ETHernet:PORT<Pt>:OAM:Y:LBM:DTLV:VALue	660
12.31.36	ETHernet:PORT<Pt>:OAM:Y:LBM:TTLV:VALue	660
12.31.37	ETHernet:PORT<Pt>:OAM:Y:LTM:TTL	660
12.31.38	ETHernet:PORT<Pt>:OAM:Y:LTM:TID	661
12.31.39	ETHernet:PORT<Pt>:OAM:Y:TST:FTSend	661
12.31.40	ETHernet:PORT<Pt>:OAM:Y:TST:RATE	661
12.31.41	ETHernet:PORT<Pt>:OAM:Y:TST:OTLV	662
12.31.42	ETHernet:PORT<Pt>:OAM:Y:TST:TLVLength	662
12.31.43	ETHernet:PORT<Pt>:OAM:Y:TST:TTLV:VALue	662
12.31.44	ETHernet:PORT<Pt>:OAM:Y:MCC:OUI	663
12.31.45	ETHernet:PORT<Pt>:OAM:Y:MCC:DATA	663
12.31.46	ETHernet:PORT<Pt>:OAM:Y:LCK:CMEG	663
12.31.47	ETHernet:PORT<Pt>:OAM:Y:LCK:RATE	664
12.31.48	ETHernet:PORT<Pt>:OAM:Y:AIS:CMEG	664
12.31.49	ETHernet:PORT<Pt>:OAM:Y:AIS:RATE	664
12.31.50	ETHernet:PORT<Pt>:OAM:Y:DMONe:TYPE	665
12.31.51	ETHernet:PORT<Pt>:OAM:Y:DMONe:RATE	665
12.31.52	ETHernet:PORT<Pt>:OAM:Y:DMONe:FTSend	666
12.31.53	ETHernet:PORT<Pt>:OAM:Y:DMONe:OTLV	666
12.31.54	ETHernet:PORT<Pt>:OAM:Y:DMONe:TLVLength	666
12.31.55	ETHernet:PORT<Pt>:OAM:Y:DMONe:DTLV:VALue	667
12.31.56	ETHernet:PORT<Pt>:OAM:Y:DMONe:TTLV:VALue	667
12.31.57	ETHernet:PORT<Pt>:OAM:Y:DMM:TYPE	667
12.31.58	ETHernet:PORT<Pt>:OAM:Y:DMM:RATE	668
12.31.59	ETHernet:PORT<Pt>:OAM:Y:DMM:FTSend	668
12.31.60	ETHernet:PORT<Pt>:OAM:Y:DMM:FVTHreshold	668
12.31.61	ETHernet:PORT<Pt>:OAM:Y:DMM:OTLV	669
12.31.62	ETHernet:PORT<Pt>:OAM:Y:DMM:TLVLength	669
12.31.63	ETHernet:PORT<Pt>:OAM:Y:DMM:DTLV:VALue	669
12.31.64	ETHernet:PORT<Pt>:OAM:Y:DMM:TTLV:VALue	670
12.31.65	ETHernet:PORT<Pt>:OAM:Y:LMM:RATE	670
12.31.66	ETHernet:PORT<Pt>:OAM:Y:LMM:FTSend	670
12.31.67	ETHernet:PORT<Pt>:OAM:Y:LMM:FLTHreshold	671
12.31.68	ETHernet:PORT<Pt>:OAM:Y:SLM:RATE	671
12.31.69	ETHernet:PORT<Pt>:OAM:Y:SLM:FTSend	671
12.31.70	ETHernet:PORT<Pt>:OAM:Y:SLM:FLTHreshold	672
12.31.71	ETHernet:PORT<Pt>:OAM:Y:EXM:DATA	672
12.31.72	ETHernet:PORT<Pt>:OAM:Y:VSM:DATA	672
12.31.73	ETHernet:PORT<Pt>:OAM:Y:MEPList:ADD	673
12.31.74	ETHernet:PORT<Pt>:OAM:Y:MEPList:DELeTe[:MEP]	673
12.31.75	ETHernet:PORT<Pt>:OAM:Y:MEPList:CATalog?	673
12.31.76	ETHernet:PORT<Pt>:OAM:DISCoveRy:TYPE	673
12.31.77	ETHernet:PORT<Pt>:OAM:DISCoveRy:INTErval	674
12.31.78	ETHernet:PORT<Pt>:OAM:DISCoveRy:DMAX	674
12.31.79	ETHernet:PORT<Pt>:OAM:DISCoveRy:CATalog?	675
12.31.80	ETHernet:PORT<Pt>:OAM:MPLS[:ENABle]	675



12.31.81	ETHernet:PORT<Pt>:OAM:MPLS:LCOunt	675
12.31.82	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:LAbel	676
12.31.83	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TCLass	676
12.31.84	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TTL	676
12.31.85	ETHernet:PORT<Pt>:OAM:MPLS:TPRofile[:ENABLE]	677
12.31.86	ETHernet:PORT<Pt>:OAM:MIM[:ENABLE]	677
12.31.87	ETHernet:PORT<Pt>:OAM:MIM:BTAG:DEI	677
12.31.88	ETHernet:PORT<Pt>:OAM:MIM:BTAG:PRiority	678
12.31.89	ETHernet:PORT<Pt>:OAM:MIM:BTAG:VID	678
12.31.90	ETHernet:PORT<Pt>:OAM:MIM:ITAG:UCA	678
12.31.91	ETHernet:PORT<Pt>:OAM:MIM:ITAG:DEI	679
12.31.92	ETHernet:PORT<Pt>:OAM:MIM:ITAG:PRiority	679
12.31.93	ETHernet:PORT<Pt>:OAM:MIM:ITAG:SID	679
12.31.94	ETHernet:PORT<Pt>:OAM:MIM:SMAC	680
12.31.95	ETHernet:PORT<Pt>:OAM:MIM:ETHernet:DMAC	680
12.31.96	ETHernet:PORT<Pt>:OAM:VLAN[:ENABLE]	680
12.31.97	ETHernet:PORT<Pt>:OAM:VLAN:LCOunt	681
12.31.98	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ID	681
12.31.99	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI	682
12.31.100	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI	682
12.31.101	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:PRiority	683
12.31.102	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ETYPe	683
12.31.103	ETHernet:PORT<Pt>:OAM:OUTPut:ULBM	684
12.31.104	ETHernet:PORT<Pt>:OAM:OUTPut:MLBM	684
12.31.105	ETHernet:PORT<Pt>:OAM:OUTPut:LTM	684
12.31.106	ETHernet:PORT<Pt>:OAM:OUTPut:MCC	684
12.31.107	ETHernet:PORT<Pt>:OAM:OUTPut:EXM	684
12.31.108	ETHernet:PORT<Pt>:OAM:OUTPut:VSM	685
12.31.109	ETHernet:PORT<Pt>:OAM:OUTPut:TST	685
12.31.110	ETHernet:PORT<Pt>:OAM:OUTPut:LMM	685
12.31.111	ETHernet:PORT<Pt>:OAM:OUTPut:SLM	685
12.31.112	ETHernet:PORT<Pt>:OAM:OUTPut:DMONe	685
12.31.113	ETHernet:PORT<Pt>:OAM:OUTPut:DMM	686
12.31.114	ETHernet:PORT<Pt>:OAM:OUTPut:CCM	686
12.31.115	ETHernet:PORT<Pt>:OAM:OUTPut:AIS	686
12.31.116	ETHernet:PORT<Pt>:OAM:OUTPut:LCK	686
12.31.117	ETHernet:PORT<Pt>:OAM:OUTPut:LOOP	687
12.31.118	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:MODE?	687
12.31.119	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:PARSer?	687
12.31.120	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:MUXer?	687
12.31.121	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:OUI?	688
12.31.122	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:VSI?	688
12.31.123	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:UNIDirectional?	688
12.31.124	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:LEVents?	688
12.31.125	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:LBACK?	688
12.31.126	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:VRETrieval?	688
12.31.127	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:REVIsion?	689
12.31.128	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:MAC?	689
12.31.129	ETHernet:PORT<Pt>:OAM:STATus:AH:REMote:MPDU?	689
12.31.130	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:MODE?	689
12.31.131	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:PARSer?	689
12.31.132	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:MUXer?	689
12.31.133	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:UNIDirectional?	690
12.31.134	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LEVents?	690
12.31.135	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LBACK?	690
12.31.136	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:VRETrieval?	690
12.31.137	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:REVIsion?	690
12.31.138	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:MPDU?	690
12.31.139	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:STATe?	691

12.31.140	ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:REQuest	691
12.31.141	ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:RESPOuse?	692
12.31.142	ETHernet:PORT<Pt>:OAM:LOG?	692
12.32	TCP Throughput Test - RFC-6349	693
12.32.1	ETHernet:TtTest:SEtup:TCPPort	693
12.32.2	ETHernet:TtTest:SEtup:FATSequence	693
12.32.3	ETHernet:TtTest:SEtup:CIPerf	693
12.32.4	ETHernet:TtTest:SEtup:SLSName	694
12.32.5	ETHernet:TtTest:SEtup:LLSName	694
12.32.6	ETHernet:TtTest:SEtup:SRSName	694
12.32.7	ETHernet:TtTest:SEtup:LRSName	695
12.32.8	ETHernet:TtTest:SEtup:TDLR	695
12.32.9	ETHernet:TtTest:SEtup:TDRL	695
12.32.10	ETHernet:TtTest:SEtup:TDSimultaneos	696
12.32.11	ETHernet:TtTest:SEtup[:LTrRemote]:CIRate	696
12.32.12	ETHernet:TtTest:SEtup[:LTrRemote]:MTUSize	696
12.32.13	ETHernet:TtTest:SEtup:RTLocal:CIRate	697
12.32.14	ETHernet:TtTest:SEtup:RTLocal:MTUSize	697
12.32.15	ETHernet:TtTest:SEtup:PMTU:DISCover[:ENABle]	697
12.32.16	ETHernet:TtTest:SEtup:PMTU:DISCover:MINimum	698
12.32.17	ETHernet:TtTest:SEtup:PMTU:DISCover:MAXimum	698
12.32.18	ETHernet:TtTest:SEtup:BRtt	698
12.32.19	ETHernet:TtTest:SEtup:BRtt:AUTO	699
12.32.20	ETHernet:TtTest:SEtup:BRtt:AUTO:DURation	699
12.32.21	ETHernet:TtTest:SEtup:WStTest[:ENABle]	699
12.32.22	ETHernet:TtTest:SEtup:WStTest:MODE	700
12.32.23	ETHernet:TtTest:SEtup:WScan[:LTrRemote]:SDURation	700
12.32.24	ETHernet:TtTest:SEtup:WScan[:LTrRemote]:AMODE:MWSize	700
12.32.25	ETHernet:TtTest:SEtup:WScan:RTLocal:SDURation	701
12.32.26	ETHernet:TtTest:SEtup:WScan:RTLocal:AMODE:MWSize	701
12.32.27	ETHernet:TtTest:SEtup:WScan:AMODE[:LTrRemote]:STEP<no>[:ENABle]	701
12.32.28	ETHernet:TtTest:SEtup:WScan:AMODE:RTLocal:STEP<no>[:ENABle]	702
12.32.29	ETHernet:TtTest:SEtup:WScan:EMODE[:LTrRemote]:STEP<no>[:ENABle]	702
12.32.30	ETHernet:TtTest:SEtup:WScan:EMODE[:LTrRemote]:STEP<no>:WSIZE	702
12.32.31	ETHernet:TtTest:SEtup:WScan:EMODE[:LTrRemote]:STEP<no>:CONNECTIONs	703
12.32.32	ETHernet:TtTest:SEtup:WScan:EMODE:RTLocal:STEP<no>[:ENABle]	703
12.32.33	ETHernet:TtTest:SEtup:WScan:EMODE:RTLocal:STEP<no>:WSIZE	703
12.32.34	ETHernet:TtTest:SEtup:WScan:EMODE:RTLocal:STEP<no>:CONNECTIONs	704
12.32.35	ETHernet:TtTest:SEtup:TtEst[:LTrRemote]:THReshold[:ENABle]	704
12.32.36	ETHernet:TtTest:SEtup:TtEst[:LTrRemote]:THReshold:PERCentage	704
12.32.37	ETHernet:TtTest:SEtup:TtEst[:LTrRemote]:SDURation	705
12.32.38	ETHernet:TtTest:SEtup:TtEst:RTLocal:THReshold[:ENABle]	705
12.32.39	ETHernet:TtTest:SEtup:TtEst:RTLocal:THReshold:PERCentage	705
12.32.40	ETHernet:TtTest:SEtup:TtEst:RTLocal:SDURation	706
12.32.41	ETHernet:TtTest:SEtup:TtEst:EMODE[:LTrRemote][:ENABle]	706
12.32.42	ETHernet:TtTest:SEtup:TtEst:EMODE[:LTrRemote]:WSIZE	706
12.32.43	ETHernet:TtTest:SEtup:TtEst:EMODE[:LTrRemote]:CONNECTIONs	707
12.32.44	ETHernet:TtTest:SEtup:TtEst:EMODE:RTLocal[:ENABle]	707
12.32.45	ETHernet:TtTest:SEtup:TtEst:EMODE:RTLocal:WSIZE	707
12.32.46	ETHernet:TtTest:SEtup:TtEst:EMODE:RTLocal:CONNECTIONs	708
12.32.47	ETHernet:TtTest:SEtup:MSERvice[:ENABle]	708
12.32.48	ETHernet:TtTest:SEtup:MSERvice[:LTrRemote]:TDURation	708
12.32.49	ETHernet:TtTest:SEtup:MSERvice[:LTrRemote]:WSIZE	709
12.32.50	ETHernet:TtTest:SEtup:MSERvice[:LTrRemote]:WSIZE:AUTO	709
12.32.51	ETHernet:TtTest:SEtup:MSERvice:RTLocal:TDURation	709
12.32.52	ETHernet:TtTest:SEtup:MSERvice:RTLocal:WSIZE	710
12.32.53	ETHernet:TtTest:SEtup:MSERvice:RTLocal:WSIZE:AUTO	710
12.32.54	ETHernet:TtTest:SEtup:MSERvice:SERvice<no>[:ENABle]	710
12.32.55	ETHernet:TtTest:SEtup:MSERvice:SERvice<no>:DPORT	711

12.32.56	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DOT	711
12.32.57	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:NAME	711
12.32.58	ETHernet:TTTest:RESult:PARAmeters?	711
12.32.59	ETHernet:TTTest:RESult:WSCan?	712
12.32.60	ETHernet:TTTest:RESult:THRoughput?	712
12.32.61	ETHernet:TTTest:RESult:THRoughput:EXPort	713
12.32.62	ETHernet:TTTest:RESult:MSERvice?	714
12.32.63	ETHernet:TTTest:RESult:MSERvice:TOTAl?	714
12.32.64	ETHernet:TTTest:RESult:MSERvice:EXPort	715
<b>13</b>	<b>Fibre Channel</b>	<b>717</b>
13.1	Port	717
13.1.1	FCHannel:PORT<Pt>:MODE	717
13.1.2	FCHannel:TX<Pt>:TIMing	717
13.2	Interface	718
13.2.1	FCHannel:PORT<Pt>:TOPology	718
13.2.2	FCHannel:PORT<Pt>:PTP:LOGin	718
13.2.3	FCHannel:PORT<Pt>:FABRic:LOGin	718
13.2.4	FCHannel:PORT<Pt>:FCONtrol[:ENABLE]	719
13.2.5	FCHannel:PORT<Pt>:FCONtrol:LCRedit	719
13.2.6	FCHannel:PORT<Pt>:FCONtrol:RCRedit	719
13.2.7	FCHannel:PORT<Pt>:SOURce:WWN	720
13.2.8	FCHannel:PORT<Pt>:SOURce:WWN:DEFault	720
13.2.9	FCHannel:PORT<Pt>:SOURce:ID	720
13.2.10	FCHannel:PORT<Pt>:DESTination:WWN	721
13.2.11	FCHannel:PORT<Pt>:DESTination:ID	721
13.2.12	FCHannel:PORT<Pt>:DESTination:LOGin	721
13.3	Frame	722
13.3.1	FCHannel:PORT<Pt>:FRAMe:FRAMing	722
13.3.2	FCHannel:PORT<Pt>:FRAMe:CONTEnt	722
13.3.3	FCHannel:PORT<Pt>:FRAMe:UP32	723
13.3.4	FCHannel:PORT<Pt>:FRAMe:HEADer:SID	723
13.3.5	FCHannel:PORT<Pt>:FRAMe:HEADer:OID	723
13.3.6	FCHannel:PORT<Pt>:FRAMe:HEADer:RID	724
13.4	Generator	724
13.4.1	FCHannel:PORT<Pt>:TRAFfic:DMODE	724
13.4.2	FCHannel:PORT<Pt>:TRAFfic:DSEConds	724
13.4.3	FCHannel:PORT<Pt>:TRAFfic:DFRames	725
13.4.4	FCHannel:PORT<Pt>:TRAFfic:ASTGenerator	725
13.4.5	FCHannel:TRAFfic:GENerator:START	725
13.4.6	FCHannel:TRAFfic:GENerator:STOP	726
13.4.7	FCHannel:PORT<Pt>:TRAFfic:GENerator:START	726
13.4.8	FCHannel:PORT<Pt>:TRAFfic:GENerator:STOP	726
13.4.9	FCHannel:PORT<Pt>:TRAFfic:GENerator:STATus?	726
13.5	Stream	726
13.5.1	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:PROFile	726
13.5.2	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad[:CONStant]	727
13.5.3	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:RAMP[:MODE]	727
13.5.4	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:RAMP:START	727
13.5.5	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:RAMP:END	728
13.5.6	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:RAMP:STEP	728
13.5.7	FCHannel:PORT<Pt>:TRAFfic:STReam:LLOad:RAMP:DURation	728
13.5.8	FCHannel:PORT<Pt>:TRAFfic:STReam:FSIZE	729
13.5.9	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency[:ENABLE]	729
13.5.10	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds[:ENABLE]	729
13.5.11	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds:VALue	730
13.5.12	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer[:ENABLE]	730
13.5.13	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds[:ENABLE]	730
13.5.14	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds:VALue	731

13.5.15	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure[:ENABLE]	731
13.5.16	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:MDISruption	731
13.5.17	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds[:ENABLE]	732
13.5.18	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds:VALue	732
13.6	Settings	733
13.6.1	FCHannel:PORT<Pt>:SETTings:BER:OBAMeasuring	733
13.6.2	FCHannel:PORT<Pt>:SETTings:BER:IAFFilter	733
13.6.3	FCHannel:PORT<Pt>:SETTings:BER:CLFrames	733
13.6.4	FCHannel:PORT<Pt>:SETTings:BER:HIDEframeLoss	734
13.7	Thresholds	735
13.7.1	FCHannel:PORT<Pt>:THResholds[:ENABLE]	735
13.7.2	FCHannel:PORT<Pt>:THResholds:SElect	735
13.7.3	FCHannel:PORT<Pt>:THResholds:VALue	736
13.8	Follow	736
13.8.1	FCHannel:PORT<Pt>:FOLLow:GENerator	736
13.8.2	FCHannel:PORT<Pt>:FOLLow:THResholds	737
13.8.3	FCHannel:PORT<Pt>:FOLLow:FRAMe	737
13.8.4	FCHannel:PORT<Pt>:FOLLow:STReam	737
13.9	Stimuli	738
13.9.1	FCHannel:PORT<Pt>:STIMuli:ALARm	738
13.9.2	FCHannel:PORT<Pt>:STIMuli:ERRor	738
13.9.3	FCHannel:PORT<Pt>:STIMuli:EINSertion	739
13.9.4	FCHannel:PORT<Pt>:STIMuli:EBLength	739
13.9.5	FCHannel:PORT<Pt>:STIMuli:FOFFset	740
13.10	Results	741
13.10.1	FCHannel:PORT<Pt>:IFETch?	741
13.10.2	FCHannel:PORT<Pt>:TFETch?	742
13.11	Status	743
13.11.1	FCHannel:STATus:PORT<Pt>:AESummary[:EVENT]?	743
13.11.2	FCHannel:STATus:PORT<Pt>:AESummary:CONDition?	743
13.11.3	FCHannel:STATus:PORT<Pt>:ALARm[:EVENT]?	743
13.11.4	FCHannel:STATus:PORT<Pt>:ALARm:CONDition?	744
13.11.5	FCHannel:STATus:PORT<Pt>:ERRor[:EVENT]?	744
13.11.6	FCHannel:STATus:PORT<Pt>:ERRor:CONDition?	744
13.11.7	FCHannel:STATus:PORT<Pt>:SID?	744
13.11.8	FCHannel:STATus:PORT<Pt>:DID?	744
13.11.9	FCHannel:STATus:PORT<Pt>:PDEViation?	745
<b>14</b>	<b>OTN</b>	<b>747</b>
14.1	Transmitter	747
14.1.1	OTN:TX<Pt>:INTerface	747
14.1.2	OTN:TX<Pt>[:ENABLEd]	747
14.1.3	OTN:TX<Pt>:TIMing	748
14.1.4	OTN:TX<Pt>:MAPPing:CSIGnal	748
14.1.5	OTN:TX<Pt>:PATtern	750
14.1.6	OTN:TX<Pt>:PINVersion	750
14.1.7	OTN:TX<Pt>:UP32	750
14.1.8	OTN:TX<Pt>:UP2K	751
14.1.9	OTN:TX<Pt>:MAPPing:OUTPutsignal	751
14.1.10	OTN:TX<Pt>:FEC	752
14.1.11	OTN:TX<Pt>:MAPPing:MULTiplexing<stage>	752
14.1.12	OTN:TX<Pt>:MAPPing:LANE	753
14.1.13	OTN:TX<Pt>:COPY	753
14.1.14	OTN:TX<Pt>:CSF	754
14.1.15	OTN:TX<Pt>:FOLLow	755
14.1.16	OTN:OH:TX<Pt>:OTN:OH	755
14.1.17	OTN:OH:TX<Pt>:OTN:OH:DEFault	756
14.1.18	OTN:TX<Pt>:TP	756
14.1.19	OTN:TX<Pt>:TS	758

14.1.20	OTN:TX<Pt>:ODUFlex:TS	759
14.1.21	OTN:TX<Pt>:ALlocated	760
14.1.22	OTN:TX<Pt>:GFP:PTI	761
14.1.23	OTN:TX<Pt>:GFP:PFI	761
14.1.24	OTN:TX<Pt>:GFP:EXI	761
14.1.25	OTN:TX<Pt>:GFP:UPI	762
14.1.26	OTN:TX<Pt>:GFP:EXTHeader:CID	762
14.1.27	OTN:TX<Pt>:GFP:EXTHeader:SPARe	762
14.1.28	OTN:TX<Pt>:GFP:PTIMes	763
14.2	Receiver	764
14.2.1	OTN:RX<Pt>:INTerface	764
14.2.2	OTN:RX<Pt>:MAPPing:CSIGnal	764
14.2.3	OTN:RX<Pt>:PATtern	765
14.2.4	OTN:RX<Pt>:PINVersion	766
14.2.5	OTN:RX<Pt>:UP32	766
14.2.6	OTN:RX<Pt>:UP2K	766
14.2.7	OTN:RX<Pt>:MAPPing:INPutsignal	767
14.2.8	OTN:RX<Pt>:MAPPing:MULTiplexing<stage>	768
14.2.9	OTN:RX<Pt>:FEC	768
14.2.10	OTN:RX<Pt>:FOLLow	769
14.2.11	OTN:RX<Pt>:TP	769
14.2.12	OTN:RX<Pt>:TS	770
14.2.13	OTN:RX<Pt>:ODUFlex:TS	771
14.2.14	OTN:RX<Pt>:TPTS:DETECT	772
14.2.15	OTN:RX<Pt>:MEAS:TTI:DET	773
14.3	Measurement Setup	774
14.3.1	OTN:TX<Pt>:MEAS:TTI:ENCoding	774
14.3.2	OTN:RX<Pt>:MEAS:TCM:ENABle	774
14.3.3	MEASurement:SETup:OTN:RX<Pt>:MSIMdetection<stage>:SETup	775
14.3.4	MEASurement:SETup:OTN:RX<Pt>:MSIMdetection<stage>:MSIM?	775
14.3.5	MEASurement:SETup:PERformance:OTN:RX<Pt>:PARAmeter	776
14.3.6	MEASurement:SETup:PERformance:OTN:RX<Pt>:ALLocation	776
14.3.7	MEASurement:SETup:PERformance:OTN:TPERiod	776
14.3.8	MEASurement:SETup:PERformance:OTN:RX<Pt>:OBJectives	777
14.4	Result	778
14.4.1	OTN:RX<Pt>:IFETch?	778
14.5	Status	781
14.5.1	OTN:STATus:RX<Pt>:AESummary[:EVENT]?	781
14.5.2	OTN:STATus:RX<Pt>:AESummary:CONDition?	781
14.5.3	OTN:STATus:RX<Pt>:ALARm<section>[:EVENT]?	782
14.5.4	OTN:STATus:RX<Pt>:ALARm<section>:CONDition?	782
14.5.5	OTN:STATus:RX<Pt>:ERRor<section>[:EVENT]?	784
14.5.6	OTN:STATus:RX<Pt>:ERRor<section>:CONDition?	784
14.5.7	OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]?	786
14.5.8	OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition?	786
14.5.9	OTN:STATus:RX<Pt>:OTU:ASUMmary[:EVENT]?	787
14.5.10	OTN:STATus:RX<Pt>:OTU:ASUMmary:CONDition?	787
14.5.11	OTN:STATus:RX<Pt>:OTU:ESUMmary[:EVENT]?	787
14.5.12	OTN:STATus:RX<Pt>:OTU:ESUMmary:CONDition?	788
14.5.13	OTN:STATus:RX<Pt>:OTU:ALARm<section>[:EVENT]?	788
14.5.14	OTN:STATus:RX<Pt>:OTU:ALARm<section>:CONDition?	788
14.5.15	OTN:STATus:RX<Pt>:OTU:ERRor<section>[:EVENT]?	789
14.5.16	OTN:STATus:RX<Pt>:OTU:ERRor<section>:CONDition?	790
14.5.17	OTN:STATus:RX<Pt>:SONE:ASUMmary[:EVENT]?	791
14.5.18	OTN:STATus:RX<Pt>:SONE:ASUMmary:CONDition?	791
14.5.19	OTN:STATus:RX<Pt>:SONE:ESUMmary[:EVENT]?	791
14.5.20	OTN:STATus:RX<Pt>:SONE:ESUMmary:CONDition?	792
14.5.21	OTN:STATus:RX<Pt>:SONE:ALARm<section>[:EVENT]?	792
14.5.22	OTN:STATus:RX<Pt>:SONE:ALARm<section>:CONDition?	792

14.5.23	OTN:STATUS:RX<Pt>:SONE:ERRor<section>[:EVENT]?	792
14.5.24	OTN:STATUS:RX<Pt>:SONE:ERRor<section>:CONDition?	793
14.5.25	OTN:STATUS:RX<Pt>:STWO:ASUMmary[:EVENT]?	794
14.5.26	OTN:STATUS:RX<Pt>:STWO:ASUMmary:CONDition?	794
14.5.27	OTN:STATUS:RX<Pt>:STWO:ESUMmary[:EVENT]?	794
14.5.28	OTN:STATUS:RX<Pt>:STWO:ESUMmary:CONDition?	795
14.5.29	OTN:STATUS:RX<Pt>:STWO:ALARm<section>[:EVENT]?	795
14.5.30	OTN:STATUS:RX<Pt>:STWO:ALARm<section>:CONDition?	795
14.5.31	OTN:STATUS:RX<Pt>:STWO:ERRor<section>[:EVENT]?	795
14.5.32	OTN:STATUS:RX<Pt>:STWO:ERRor<section>:CONDition?	796
14.5.33	OTN:STATUS:RX<Pt>:STHRee:ASUMmary[:EVENT]?	796
14.5.34	OTN:STATUS:RX<Pt>:STHRee:ASUMmary:CONDition?	796
14.5.35	OTN:STATUS:RX<Pt>:STHRee:ESUMmary[:EVENT]?	796
14.5.36	OTN:STATUS:RX<Pt>:STHRee:ESUMmary:CONDition?	797
14.5.37	OTN:STATUS:RX<Pt>:STHRee:ALARm<section>[:EVENT]?	797
14.5.38	OTN:STATUS:RX<Pt>:STHRee:ALARm<section>:CONDition?	797
14.5.39	OTN:STATUS:RX<Pt>:STHRee:ERRor<section>[:EVENT]?	797
14.5.40	OTN:STATUS:RX<Pt>:STHRee:ERRor<section>:CONDition?	798
14.5.41	OTN:STATUS:RX<Pt>:CLlent:ASUMmary[:EVENT]?	798
14.5.42	OTN:STATUS:RX<Pt>:CLlent:ASUMmary:CONDition?	798
14.5.43	OTN:STATUS:RX<Pt>:CLlent:ESUMmary[:EVENT]?	798
14.5.44	OTN:STATUS:RX<Pt>:CLlent:ESUMmary:CONDition?	799
14.5.45	OTN:STATUS:RX<Pt>:CLlent:ALARm<section>[:EVENT]?	799
14.5.46	OTN:STATUS:RX<Pt>:CLlent:ALARm<section>:CONDition?	799
14.5.47	OTN:STATUS:RX<Pt>:CLlent:ERRor<section>[:EVENT]?	799
14.5.48	OTN:STATUS:RX<Pt>:CLlent:ERRor<section>:CONDition?	800
14.5.49	OTN:STATUS:RX<Pt>:PSLevel?	801
14.5.50	OTN:STATUS:TX<Pt>:PSLevel?	801
14.5.51	OTN:STATUS:RX<Pt>:FREQuency?	801
14.5.52	OTN:STATUS:TX<Pt>:FREQuency?	801
14.5.53	OTN:STATUS:RX<Pt>:CAPTure:OH?	802
14.6	Stimuli	803
14.6.1	OTN:STIMuli:TX<Pt>:TYPE	803
14.6.2	OTN:STIMuli:TX<Pt>:AEINsert:LEVel	803
14.6.3	OTN:STIMuli:TX<Pt>:AEINsert:TYPE	804
14.6.4	OTN:STIMuli:TX<Pt>:AEINsert:INSert	805
14.6.5	OTN:STIMuli:TX<Pt>:AEINsert:BURSt	805
14.6.6	OTN:STIMuli:TX<Pt>:AEINsert:AERRor	805
14.6.7	OTN:STIMuli:TX<Pt>:AEINsert:NORMal	806
14.6.8	OTN:STIMuli:TX<Pt>:AEINsert:RATE	806
14.6.9	OTN:STIMuli:TX<Pt>:JUSTification:LEVel	807
14.6.10	OTN:STIMuli:TX<Pt>:JUSTification:BURSt	807
14.6.11	OTN:STIMuli:TX<Pt>:JUSTification:MOVement	807
14.6.12	OTN:STIMuli:TX<Pt>:JMOVE	808
14.6.13	OTN:STIMuli:TX<Pt>:FREQuency:OFFSet	808
14.6.14	OTN:STIMuli:TX<Pt>:PAYLoad:OFFSet<stage>	808
14.6.15	OTN:STIMuli:TX<Pt>:GMP:AEINsert:LEVel	809
14.6.16	OTN:STIMuli:TX<Pt>:GMP:AEINsert:TYPE	809
14.6.17	OTN:STIMuli:TX<Pt>:GMP:AEINsert:INSert	810
14.6.18	OTN:STIMuli:TX<Pt>:GMP:AEINsert:EBITs	810
14.6.19	OTN:STIMuli:TX<Pt>:GFP:AEINsert:TYPE	811
14.6.20	OTN:STIMuli:TX<Pt>:GFP:AEINsert:INSert	811
14.6.21	OTN:STIMuli:TX<Pt>:GFP:AEINsert:EBITs	812
14.6.22	OTN:STIMuli:TX<Pt>:GFP:AEINsert:BURSt	812
14.6.23	OTN:STIMuli:TX<Pt>:GFP:AEINsert:CMF:INTerval	812
14.6.24	OTN:STIMuli:TX<Pt>:FEC:AEINsert:TYPE	813
14.6.25	OTN:STIMuli:TX<Pt>:FEC:AEINsert:INSert	813
14.6.26	OTN:STIMuli:TX<Pt>:FEC:AEINsert:RMANtissa	813
14.6.27	OTN:STIMuli:TX<Pt>:FEC:AEINsert:REXPnent	814

14.6.28	OTN:STIMuli:TX<Pt>:FEC:AEINsert:EFAS	814
14.6.29	OTN:STIMuli:TX<Pt>:FEC:AEINsert:SUBRow	815
14.6.30	OTN:STIMuli:TX<Pt>:LLD:AEINsert:TYPE	815
14.6.31	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ALARm	815
14.6.32	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ERRor	816
14.6.33	OTN:STIMuli:TX<Pt>:LLD:AEINsert:INSert	816
14.6.34	OTN:STIMuli:TX<Pt>:LLD:AEINsert:BURSt	816
14.6.35	OTN:STIMuli:TX<Pt>:LLD:AEINsert:AERRor	817
14.6.36	OTN:STIMuli:TX<Pt>:LLD:AEINsert:NORMal	817
14.6.37	OTN:STIMuli:TX<Pt>:LLD:AEINsert:LANE	817
14.6.38	OTN:STIMuli:TX<Pt>:LLD:SKIEW:LANE	818
14.6.39	OTN:STIMuli:TX<Pt>:LLD:SKIEW:BIT	818
14.6.40	OTN:STIMuli:TX<Pt>:LLD:SKIEW:TYPE	819
14.7	Tributary Scan	820
14.7.1	OTN:TSCan:STARt	820
14.7.2	OTN:TSCan:STOP	820
14.7.3	OTN:TSCan:RX<Pt>:ODU2:NUMBer?	820
14.7.4	OTN:TSCan:RX<Pt>:ODU2:GET?	820
14.7.5	OTN:TSCan:RX<Pt>:ODU2:DETailed?	820
14.7.6	OTN:TSCan:RX<Pt>:ODU1:NUMBer?	821
14.7.7	OTN:TSCan:RX<Pt>:ODU1:GET?	821
14.7.8	OTN:TSCan:RX<Pt>:ODU1:SCANning	821
14.7.9	OTN:TSCan:RX<Pt>:ODU1:DETailed?	821
14.7.10	OTN:TSCan:RX<Pt>:ODU0:NUMBer?	822
14.7.11	OTN:TSCan:RX<Pt>:ODU0:GET?	822
14.7.12	OTN:TSCan:RX<Pt>:ODU0:DETailed?	822
14.8	APS	823
14.8.1	OTN:APS:RX<Pt>:BEVent	823
14.8.2	OTN:APS:RX<Pt>:EEVent	824
14.8.3	OTN:APS:RX<Pt>:PERiod	824
14.8.4	OTN:APS:RX<Pt>:MLIMit	825
14.8.5	OTN:APS:STARt	825
14.8.6	OTN:APS:STOP	825
14.8.7	OTN:APS:RX<Pt>:NUMBer?	825
14.8.8	OTN:APS:RX<Pt>:MTIME?	826
14.8.9	OTN:APS:RX<Pt>:LTIME?	826
14.8.10	OTN:APS:RX<Pt>:ATIME?	826
14.8.11	OTN:APS:RX<Pt>:CTIME?	826
14.9	RTD	827
14.9.1	OTN:RTD:RX<Pt>:MLIMit	827
14.9.2	OTN:RTD:RX<Pt>:NUMBer?	827
14.9.3	OTN:RTD:RX<Pt>:ATIME?	827
14.9.4	OTN:RTD:RX<Pt>:MTIME?	827
14.9.5	OTN:RTD:RX<Pt>:LTIME?	828
14.9.6	OTN:RTD:RX<Pt>:CTIME?	828
<b>15</b>	<b>Pluggable Module</b>	<b>829</b>
15.1	Status	829
15.1.1	PMODule:STATus:PORT<Pt>:PRESent?	829
15.1.2	PMODule:STATus:PORT<Pt>:VENDor?	829
15.1.3	PMODule:STATus:PORT<Pt>:WAVelength?	829
15.1.4	PMODule:STATus:PORT<Pt>:BRATE?	829
15.1.5	PMODule:STATus:PORT<Pt>:COMPLiance?	830
15.1.6	PMODule:STATus:PORT<Pt>:PNUMBER?	830
15.1.7	PMODule:STATus:PORT<Pt>:REVISION?	830
15.1.8	PMODule:STATus:PORT<Pt>:SNUMBER?	830
15.1.9	PMODule:STATus:PORT<Pt>:DATE?	830
15.1.10	PMODule:STATus:PORT<Pt>:LOT?	830
15.1.11	PMODule:STATus:PORT<Pt>:TPOWER?	831

15.1.12	PMODule:STATus:PORT<Pt>:RPOWER?	831
15.1.13	PMODule:STATus:PORT<Pt>:STATus?	831
15.1.14	PMODule:STATus:PORT<Pt>:GALarm?	831
15.1.15	PMODule:STATus:PORT<Pt>:PALarm?	831
15.1.16	PMODule:STATus:PORT<Pt>:AESummary[:EVENT]?	832
15.1.17	PMODule:STATus:PORT<Pt>:AESummary:CONDition?	832
15.1.18	PMODule:STATus:PORT<Pt>:ALARm[:EVENT]?	832
15.1.19	PMODule:STATus:PORT<Pt>:ALARm:CONDition?	832
15.2	MDIO	833
15.2.1	PMODule:PORT<Pt>:MDIO:WRITE	833
15.2.2	PMODule:PORT<Pt>:MDIO:READ?	833
15.3	I2C	833
15.3.1	PMODule:PORT<Pt>:I2C:WRITE	833
15.3.2	PMODule:PORT<Pt>:I2C:READ?	834
15.4	Tx reference clock output	834
15.4.1	PMODule:TOUTput:PORT<Pt>[:ENABLE]	834
15.4.2	PMODule:TOUTput:PORT<Pt>:FREQuency	834
15.4.3	PMODule:TOUTput:PORT<Pt>:SYNC:FREQuency	835
<b>16</b>	<b>Common Application Settings</b>	<b>837</b>
16.1	RTD	837
16.1.1	RTD:MODE	837
16.1.2	RTD:PERiod	837
16.1.3	RTD:IFMData	838
16.1.4	RTD:PDH:RX<Pt>:MLIMit	838
16.2	Hierarchy	839
16.2.1	HIERarchy:PORT<Pt>:OTN:TX	839
16.2.2	HIERarchy:PORT<Pt>:OTN:RX	839
16.2.3	HIERarchy:PORT<Pt>:SDH:TX	839
16.2.4	HIERarchy:PORT<Pt>:SDH:RX	840
16.2.5	HIERarchy:PORT<Pt>:PDH:TX	840
16.2.6	HIERarchy:PORT<Pt>:PDH:RX	840
<b>17</b>	<b>Measurement</b>	<b>841</b>
17.1	Application, Start and Stop	841
17.1.1	MEASurement:APPLication?	841
17.1.2	MEASurement:STARt	842
17.1.3	MEASurement:STOP	842
17.2	Setup	842
17.2.1	MEASurement:SETup:PORT<Pt>:TERMinology	842
17.2.2	MEASurement:SETup:SELect	842
17.2.3	MEASurement:SETup:ILENght	843
17.2.4	MEASurement:SETup:STARt	843
17.2.5	MEASurement:SETup:STAT	844
17.2.6	MEASurement:SETup:STOP	844
17.2.7	MEASurement:SETup:SPAT	845
17.2.8	MEASurement:SETup:SDURation	845
17.2.9	MEASurement:SETup:MALLocation	846
17.2.10	MEASurement:SETup:PERFormance:TMBPs:PARAmeter	846
17.2.11	MEASurement:SETup:PERFormance:T1:PARAmeter	847
17.2.12	MEASurement:SETup:PERFormance:E3:PARAmeter	847
17.2.13	MEASurement:SETup:PERFormance:T3:PARAmeter	847
17.2.14	MEASurement:SETup:PERFormance:E4:PARAmeter	848
17.2.15	MEASurement:SETup:PERFormance:SDH:PARAmeter	848
17.2.16	MEASurement:SETup:PERFormance:SDH:MUX	848
17.2.17	MEASurement:SETup:PERFormance:SDH:VC4	849
17.2.18	MEASurement:SETup:PERFormance:SDH:VC3	849
17.2.19	MEASurement:SETup:PERFormance:SDH:VC12	849
17.2.20	MEASurement:SETup:PERFormance:SDH:TPERiod	850
17.2.21	MEASurement:SETup:PERFormance:SONet:PARAmeter	850



17.2.22	MEASurement:SETup:PERFormance:SONet:MUX	851
17.2.23	MEASurement:SETup:PERFormance:SONet:STS3	851
17.2.24	MEASurement:SETup:PERFormance:SONet:STS1	851
17.2.25	MEASurement:SETup:PERFormance:SONet:VT2	852
17.2.26	MEASurement:SETup:PERFormance:SONet:TPERiod	852
17.2.27	MEASurement:SETup:PERFormance:WAN:PARAmeter	852
17.2.28	MEASurement:SETup:EVALuation:RX<Pt>[:ENABle]	853
17.2.29	MEASurement:SETup:EVALuation:RX<Pt>:INTerface	853
17.2.30	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM	853
17.2.31	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ALARm	854
17.2.32	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ERRor	854
17.2.33	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:TYPE	855
17.2.34	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:PASS	855
17.2.35	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:FAIL	856
17.2.36	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:PASS	856
17.2.37	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:FAIL	856
17.2.38	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:ITEM	857
17.2.39	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:TYPE	857
17.2.40	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:PASS	858
17.2.41	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:FAIL	858
17.2.42	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:PASS	858
17.2.43	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:FAIL	859
17.2.44	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:PASS	859
17.2.45	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:FAIL	859
17.2.46	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:HREFerence	860
17.2.47	MEASurement:SETup:EVALuation:E3:RX<Pt>:ITEM	860
17.2.48	MEASurement:SETup:EVALuation:E3:RX<Pt>:TYPE	861
17.2.49	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:PASS	861
17.2.50	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:FAIL	861
17.2.51	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:PASS	862
17.2.52	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:FAIL	862
17.2.53	MEASurement:SETup:EVALuation:E4:RX<Pt>:ITEM	863
17.2.54	MEASurement:SETup:EVALuation:E4:RX<Pt>:TYPE	863
17.2.55	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:PASS	864
17.2.56	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:FAIL	864
17.2.57	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:PASS	864
17.2.58	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:FAIL	865
17.2.59	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM	865
17.2.60	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ALARm	866
17.2.61	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ERRor	867
17.2.62	MEASurement:SETup:EVALuation:SDH:RX<Pt>:TYPE	867
17.2.63	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:PASS	868
17.2.64	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:FAIL	868
17.2.65	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:PASS	868
17.2.66	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:FAIL	869
17.2.67	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM	869
17.2.68	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ALARm	870
17.2.69	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ERRor	871
17.2.70	MEASurement:SETup:EVALuation:SONet:RX<Pt>:TYPE	871
17.2.71	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:PASS	872
17.2.72	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:FAIL	872
17.2.73	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:PASS	872
17.2.74	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:FAIL	873
17.2.75	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM	873
17.2.76	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ALARm	873
17.2.77	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ERRor	875
17.2.78	MEASurement:SETup:EVALuation:OTN:RX<Pt>:TYPE	876
17.2.79	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:PASS	876
17.2.80	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:FAIL	876

17.2.81	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:PASS	877
17.2.82	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:FAIL	877
17.2.83	MEASurement:SETup:EVALuation:BER:OBAMeasuring	877
17.2.84	MEASurement:SETup:EVALuation:BER:IAFFilter	878
17.2.85	MEASurement:SETup:EVALuation:BER:CLFrames	878
17.2.86	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds[:ENABLE]	878
17.2.87	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:MODE	879
17.2.88	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:COUNT	879
17.2.89	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:RATio	879
17.2.90	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:PERCent	880
17.2.91	MEASurement:SETup:POINtermovement:SDH:MODE	880
17.2.92	MEASurement:SETup:POINtermovement:SONet:MODE	880
17.3	Information	881
17.3.1	MEASurement:INFO:TBEgin?	881
17.3.2	MEASurement:INFO:TEND?	881
17.3.3	MEASurement:INFO:MDURation?	881
17.3.4	MEASurement:INFO:STATus<Pt>?	881
17.3.5	MEASurement:INFO:IMIN?	882
17.3.6	MEASurement:INFO:IMAX?	882
17.4	Event Log	882
17.4.1	MEASurement:ELOG:MINimum?	882
17.4.2	MEASurement:ELOG:MAXimum?	882
17.4.3	MEASurement:ELOG:FETCh?	882
17.4.4	MEASurement:ELOG:FETCh:NEXt?	883
17.4.5	MEASurement:ELOG:EXPort	883
17.5	Result	883
17.5.1	MEASurement:RESult:SUMMary?	883
17.5.2	MEASurement:RESult:SUMMary:STATistics:PORT<Pt>?	883
<b>A</b>	<b>Example Scripts</b>	<b>885</b>
A.1	Hints	885
A.2	2 Mbps BERT	886
A.3	2 Mbps Status & Stimuli	887
A.4	E3 BERT	888
A.5	E4 BERT	889
A.6	SDH BERT	890
A.7	Ethernet BERT	891
A.8	Fibre Channel BERT	892
A.9	OTN BERT	893
A.10	CPRI BERT	894

## List of Figures

1.1	System setup using Ethernet	45
1.2	Connector panel	45
1.3	Configure TCP <b>Port</b> for Remote Control	46
1.4	Program message structure	47
1.5	Program message unit	47
1.6	Response message structure	51
1.7	IEEE488.2 standard status and SCPI-defined registers/queues. $\oplus$ means logical OR.	54
1.8	The Network Master Unique Status registers for some of the supported interfaces. Similar registers exist for T1, OTN, Physical, and T3 interfaces	58
1.9	The general structure for the Alarms and Errors status register for the interfaces	59

---

1.10	The structure for the Port Status register . . . . .	59
1.11	The register model for the Network Master Unique Status registers. . . . .	60
1.12	Enable <b>Implicit CR in every LF</b> in PuTTY . . . . .	63
1.13	<b>IP Address</b> on the instrument . . . . .	64
1.14	Specify the destination and <b>Open</b> the connection in PuTTY . . . . .	64
1.15	Connection established with PuTTY . . . . .	65
1.16	Data bit . . . . .	66
1.17	Correspondence between physical and logical port numbers (Three ports) . . . . .	66
1.18	Correspondence between physical and logical port numbers (One port) . . . . .	67
1.19	Correspondence between physical and logical port numbers (Two ports) . . . . .	67
2.1	INST:STAR automatically <i>connects</i> and selects started application server. . . . .	80
2.2	Original client session has to <i>disconnect</i> , before another client session can <i>connect</i> . . . . .	80
2.3	When connected to multiple application servers, client session <i>selects</i> to which application server the application specific commands are dispatched. . . . .	80



---

# Chapter 1

## Overview

The Network Master command based remote control functions support the built-in Ethernet service interface. Software specifications are in conformity with the IEEE488.2 standard based on SCPI version 1999 (Standard Commands for Programmable Instruments). Network Master becomes an automated measurement instrument when it is connected to an external controller.




Figure 1.1: System setup using Ethernet

### 1.1 Ethernet Based Remote Control

#### 1.1.1 Connecting Cable

To use remote control via the Ethernet service interface, connect an Ethernet cable to the Ethernet connector next to the power socket.



Figure 1.2: Connector panel

## 1.1.2 Connect to an Instrument

Remote commands are exchanged with the Network Master over a raw TCP/IP connection. Connect TCP port 56001 for program/response communication, see section 1.5 Controller Example.

## 1.1.3 Ethernet Remote Control Settings

### Port Number

To change a TCP port number (for a valid range, see Table 1.1) type the number in the **TCP Port** field (see Figure 1.3).




Figure 1.3: Configure TCP Port for Remote Control

Setup item	Description	Allowable range
Port Number	TCP Port Number	1024 to 65535 (default: 56001)

Table 1.1: Allowable TCP port range

## 1.1.4 Communication Buffers

The input- and output streams are buffered. Besides the TCP receive buffer (87380 bytes) and the TCP transmit buffer (16384 bytes), the two streams share a common command/response buffer of 32 entries. Each buffer entry can hold a compound program message of maximum 4 KB or a response message of maximum 64 KB.

Program data transferred as <ARBITRARY BLOCK PROGRAM DATA> does not go through the internal buffer, but is streamed directly from the TCP receive buffer to the internal file system. Similar for response data of type <DEFINITE LENGTH ARBITRARY BLOCK RESPONSE DATA>; it is streamed directly from the internal file system to the TCP transmit buffer.

## 1.2 Program Messages

Program messages are the remote commands sent to Network Master as shown in Figure 1.4.




Figure 1.4: Program message structure

A program message consists of one or more program message units separated with a semicolon (;). Space(s) before or after a semicolon is ignored (space has no meaning). For more information on program message units, see section 1.2.1 Program Message Unit.

When a program message is sent to Network Master, a terminator is appended after it. Network Master receives the program message by detecting the terminator. For a description of the terminator, see section 1.2.4 Program Message Terminator.

The Network Master is able to handle program messages with a maximum length of 4096 characters including the message terminator.

### 1.2.1 Program Message Unit

A program message unit consists of a program header and a program data, see Figure 1.5.




Figure 1.5: Program message unit

There must be one or more spaces between a program header and a program data. Network Master recognizes the program header and program data using the space(s). One or more spaces before a program header are ignored.

## 1.2.2 Program Headers

The program header specifies the function of the command message unit sent from the controller to Network Master. There are two types of program headers:

- Program headers for command message units.
- Program headers for query message units. Similar to headers for command message unit, but are always followed by a question mark "?".

The Network Master supports some of the common commands defined in the IEEE488.2 standard. These common commands are special in the way that they are always preceded by an asterisk "\*"; e.g. \*IDN?. All other commands are referred to as "device specific commands". Device specific commands consists of two or more <program mnemonic>'s (hereinafter called "mnemonic") separated with a colon ":".

[:]<program mnemonic>[:<program mnemonic>]...      e.g. SYSTem:TIME

A mnemonic is a character string, which consists of capital and small letters. The capital part of the mnemonic is also referred to as the short form of the mnemonic.

- Long form program header: INSTrument:STARt
- Short form program header: INST:STAR

The Network Master recognizes a mnemonic even if only the short form is sent. For example, mnemonic INSTrument is recognized as a normal mnemonic when INST is sent.

In this way, capital and small letters are used for recognizing long and short forms of a mnemonic, The Network Master does not distinguish between capital and small letters when reading the program header. However, the Network Master only accepts the short form or the complete long form of a mnemonic. Hence INSTru is **not** a valid mnemonic. The following program headers are all acceptable and assumed to be the same:

- SYSTEM:POWER:SOURCE?
- system:power:source?
- SySteM:PoWeR:SoUr?
- syst:POW:sour?



### 1.2.3 Program Data

Program data is sent following the program header as parameters specified in the command message unit. This operation manual uses the notations given below in Table 1.2 for indicating the program data format. Most of them are defined in the IEEE488.2 standard.

Program data type	Description
<BOOLEAN PROGRAM DATA>	Defined in IEEE488.2 Indicates On/Off, Enable/Disable, or Yes/No. To specify On/Enable state, set {ON 1}. To specify Off/Disable state, set {OFF 0}.
<NUMERIC PROGRAM DATA>	Comprises <DECIMAL NUMERIC PROGRAM DATA> and <NON-DECIMAL NUMERIC PROGRAM DATA> as defined in IEEE488.2 The Network Master accepts both decimal and non-decimal entries for the <NUMERIC PROGRAM DATA>.
<DECIMAL NUMERIC PROGRAM DATA>	Defined in IEEE488.2 Comprises <NR1>, <NR2> and <NR3> decimal values, where <NR1> indicates an integer value. <NR2> indicates a numeric value in fixed point format. <NR3> indicates a numeric value in floating point format. Examples: <NR1>: 123 <NR2>: -123.456 <NR3>: 1.23E-3
<NONDECIMAL NUMERIC PROGRAM DATA>	Defined in IEEE488.2 Comprises <HEXADECIMAL>, <OCTAL> or <BINARY> program data. See below for further details.
<HEXADECIMAL>	Conforms to the hexadecimal format defined in IEEE488.2 as follows: #{H h}{A a B b C c D d E e F f <digit>}... <digit> is an ASCII character with a value in the range of 0x30 to 0x39 (48 to 57 in decimal), that is, a numeric 0 to 9. Examples: #h1234ABCD #Hfe1a9
<OCTAL>	Conforms to the octal format defined in IEEE488.2 as follows: #{Q q}{0 1 2 3 4 5 6 7}... Examples: #q12345670 #Q77
<BINARY>	Conforms to the binary format defined in IEEE488.2 as follows: #{B b}{0 1}... Examples: #b10101010 #B110
<STRING PROGRAM DATA>	Defined in IEEE488.2 A character string in a pair of single quotation marks (') or double quotation marks ("). Examples: "Network Master" 'Testing the network'

continued on next page...

...continued from previous page

Program data type	Description
<CHARACTER PROGRAM DATA>	Defined in IEEE488.2 Indicates two or more mnemonics for selections. Like program header mnemonics, <CHARACTER PROGRAM DATA> mnemonics can have a short and a long form. The syntax used in the Network Master additionally allows a digit as the first character of a mnemonic and also allows a dash (-) inside a mnemonic.

Table 1.2: Acceptable program data

### 1.2.4 Program Message Terminator

A program message terminator indicates the end of the program message. Upon reception of a terminator, the Network Master assumes that the program message is complete and starts processing the message. A terminator must always be added to the end of a program message. For Network Master the program message terminator is:

[<WHITE SPACE>]{NL} for Ethernet based remote control

<WHITE SPACE> is one or more ASCII characters with a value in the range of 0x00 to 0x09 or 0x0B to 0x20 (0 to 9 or 11 to 32 in decimal). These ranges include the ASCII control characters and space, except NL (newline). Since <WHITE SPACE> includes CR (0x0D) (13 in decimal), {CR}{NL} is also interpreted as a terminator by Network Master in Ethernet based remote control - to keep compatibility with conventional models.

### 1.2.5 Compound Program Messages

Compound headers are supported by the Network Master. Examples of the use of the compound headers are shown below.

The three program message units:

```
SYSTem:TIME?
SYSTem:DATE?
SYSTem:POWer:SOURce?
```

can be combined in one program message as follows:

```
SYSTem:TIME?; :SYSTem:DATE?; :SYSTem:POWer:SOURce?
```

or just:

```
SYSTem:TIME?; DATE?; POWer:SOURce?
```

(SYST: mnemonic can be omitted in the second and third program data units)

For further information on compound headers, see Appendix A of the IEEE488.2 standard.

### 1.2.6 Sequential Execution

The Network Master processes one program message unit at a time and in the same order in which they are arranged within the program message. The Network Master will not start processing a new program message until the processing of the current program message is finished.

## 1.3 Response Messages

Response messages are messages sent from a Network Master to a controller as reply to queries, see Figure 1.6.




Figure 1.6: Response message structure

A response message consists of one or more response data separated with a semicolon (;). The response message is terminated with the response message terminator.

### 1.3.1 Response Data

Response data is a data returned by Network Master as reply to a query received from the controller. Table 1.3 shows examples of the response data format used in this manual.

Response data type	Description
<BOOLEAN RESPONSE DATA>	Defined in SCPI-99 Indicates On/Off, Enable/Disable, or Yes/No. When "1" is returned, it indicates an On/Enable state. When "0" is returned, it indicates an Off/Disable state.
<NR1 NUMERIC RESPONSE DATA>	Defined in IEEE488.2 Indicates an decimal integer value. Examples: 123 -500
<NR2 NUMERIC RESPONSE DATA>	Defined in IEEE488.2 Indicates a numeric value in fixed point format. Examples: 123.45 -500.0

continued on next page...

...continued from previous page

<b>Response data type</b>	<b>Description</b>
<NR3 NUMERIC RESPONSE DATA>	Defined in IEEE488.2 Indicates a numeric value in floating point format. Examples: 1.23E3 -5.67E-4
<HEXADECIMAL NUMERIC RESPONSE DATA>	Conforms to the hexadecimal format defined in IEEE488.2 as follows: #H{A B C D E F <digit>}... <digit> is an ASCII character with a value in the range of 0x30 to 0x39 (48 to 57 in decimal), a numeric 0 to 9. Example: #H0011EEFF
<BINARY NUMERIC RESPONSE DATA>	Conforms to the binary format defined in IEEE488.2 as follows: #B{0 1}... Example: #B10101010
<STRING RESPONSE DATA>	Defined in IEEE488.2 A character string enclosed in a pair of double quotation marks ("). Example: "Network Master - Testing the network."
<CHARACTER RESPONSE DATA>	Defined in IEEE488.2 Indicates two or more mnemonics for selections. Like program header mnemonics, <CHARACTER RESPONSE DATA> mnemonics can have a short and a long form. The Network Master always returns the short form. The syntax used in the Network Master additionally allows a digit as the first character of a mnemonic and also allows a dash (-) inside a mnemonic.
<EXPRESSION RESPONSE DATA>	Defined in IEEE488.2 A Network Master-defined set of <RESPONSE DATA> elements separated by a comma (,) and enclosed by a set of parenthesis. Example: (2,0.5), (3,0.25), (4,1.75) For further details refer to the detailed description of the Network Master specific commands.
<DEFINITE LENGTH ARBITRARY BLOCK RESPONSE DATA>	Defined in IEEE488.2 This response data type is used when the instrument streams binary data (typically PDF files) to the controller. It is defined as #<nonzero digit><digits><8 bit data bytes> , where: <nonzero digit> is a single ASCII character in the range of '1'-'9'. It represents the length of <digits> in number of bytes. <digits> is a number of ASCII characters in the range of '0'-'9', which together are a decimal representation of the number of succeeding data bytes.
	Example: #49137<9137 bytes of binary data>

Table 1.3: Network Master response data

### 1.3.2 Response Messages Terminator

A response message terminator indicates the end of the response message. Network Master appends the terminator to the end of a response message to indicate the end of the message. For Network Master the response message terminator is {NL} .

### 1.3.3 Prompt

For Ethernet based remote control a prompt can optionally be returned by the Network Master when all commands in a program message has completed. The prompt is inserted after the response message if any. It can be useful to enable the prompt when manually typing commands on the command line of the remote control interface. The prompt inserted is:

```
SCPI:>
```

See section [2.3.12](#) on page [77](#) and section [1.5](#) Controller Example.

## 1.4 Status

### 1.4.1 IEEE488.2 Standard Status and SCPI-defined Registers




Figure 1.7: IEEE488.2 standard status and SCPI-defined registers/queues. ⊕ means logical OR.

## Status Byte

Bit	Name	Description
0	Port 1	Summary-message bit for the Port Event Summary register. Use the <code>STATUS:PRESet</code> command described in section 2.5.16 and the <code>STATUS:PORT:ENABle</code> command described in section 2.5.13 to enable generation of this summary-message.
1	Event Queue	Summary-message bit for the Event Queue for the currently selected application server. Use the <code>SYSTEM:ERRor[:NEXT]?</code> command described in section 2.3.2 to retrieve the messages.
2	Error Queue	Summary-message bit for the Error queue for all connected application servers. Use the <code>INSTRument:ERRor[:NEXT]?</code> command described in section 2.4.18 to retrieve the messages.
3	QUESTionable	Summary-message bit for the Questionable Status register. Use the <code>STATUS:QUESTionable:ENABle</code> command described in section 2.5.8 to enable generation of this summary-message.
4	Output Queue	Summary-message bit for the Output Queue.
5	Standard Event	Summary-message bit for the Standard Event Status register. Use the <code>*ESE</code> command described in section 2.2.2 to enable generation of this summary-message.
6	Master Summary	The Master Summary Status message. Use the <code>*SRE</code> command described in section 2.2.7 to enable generation of this summary-message.
7	OPERation	Summary-message bit for the Operation Status register. Use the <code>STATUS:OPERation:ENABle</code> command described in section 2.5.2 to enable generation of this summary-message.

Table 1.4: Bits in the Status Byte register (unused bits are not listed)

For more information about the Status Byte register, see section 2.2.8 on page 73.

## Standard Event Status

Bit	Name	Description
0	Operation Complete	The condition bit changes to 1 when <code>*OPC</code> command is received.
3	Device Dependent Error	The condition bit changes to 1 when a required SW or HW options is missing or the Error/Event queue is full.
4	Execution Error	The condition bit changes to 1 when a command fail to execute properly.
5	Command Error	The condition bit changes to 1 when a unknown or errored command is received.
7	Power On	The condition bit changes to 1 when the external power supply is connected.

Table 1.5: Bits in the Standard Event Status register (unused bits are not listed)

All condition bits are immediately changed back to 0 after they are set. This means that the only way to check the bits is to read the Event register. For more information on what triggers the Device Dependent,

Execution and Command Errors see the Error/Event Queue section on page page 56.

For more information on the Standard Event Status register see section 2.2.2 on page 70.

### Error/Event Queue

When an unexpected error or event occurs, an entry is added to the Error/Event queue. This queue can hold 4 errors or events. If the queue overflows, the most recent events are discarded. A summary-message in bit 2 of the Status Byte is 1 when the queue is not empty. Table 1.6 gives an overview of the different errors and events inserted in the queue.

For more information about the Event queue, see section 2.4.18 on page 85.

Event Number	Error Description
0	No Error (when queue is empty)
<i>Command errors (Command Error bit is simultaneously set)</i>	
-100	Command error
-102	Syntax error
-104	Data type error
-115	Unexpected number of parameters
-130	Suffix error
-131	Invalid suffix
-138	Suffix not allowed
<i>Execution errors (Execution Error bit is simultaneously set)</i>	
-200	Execution error
-220	Parameter error
-221	Settings conflict
-222	Data out of range
-224	Illegal parameter value
-250	Mass storage error
<i>Device Dependent errors (Device Dependent Error bit is simultaneously set)</i>	
1	Options Missing
-350	Queue overflow

Table 1.6: Errors and events that can occur in the Error/Event queue

For more information about the Error queue, see section 2.3.2 on page 74.



## Questionable Status

Bit	Name	Description
<i>No bits in this register are currently in use.</i>		

Table 1.7: Bit in the Questionable Status register (unused bits are not listed)

For more information about the Questionable Status register, see section [2.5.6](#) on page [89](#).

## Operation Status

Bit	Name	Description
4	Measuring	The measuring condition bit changes to 1 when the an Application Server is running a measurement or a test. It returns to 0 when the measurement or test is stopped.

Table 1.8: Bit in the Operation Status register (unused bits are not listed)

For more information about the Operation Status register, see section [2.5.1](#) on page [88](#).

### 1.4.2 Network Master Unique Status Registers

Figure 1.8 shows the structure of the Network Master Unique Status registers.




Figure 1.8: The Network Master Unique Status registers for some of the supported interfaces. Similar registers exist for T1, OTN, Physical, and T3 interfaces

The Network Master Unique Status registers are used to report alarms and errors for all interfaces. Each interface has one or more registers to represent the current alarm and error status. Each of these Alarm and Error registers are summarized in a General Interface Summary register (AESummary), see Figure 1.9. The exact layout of each register is found under the Status section for each interface. There are two Port Status




Figure 1.9: The general structure for the Alarms and Errors status register for the interfaces

registers, one for each port on the Network Master. The Port Status registers summarize the AESummary registers from the active interfaces. The Port Status registers are again summarized in bit 0 and 1 of the Status Byte, see Figure 1.10.




Figure 1.10: The structure for the Port Status register

All Network Master Unique Status registers follow the register model defined in section 11.4.2 of IEEE488.2. The register model is shown in Figure 1.11.




Figure 1.11: The register model for the Network Master Unique Status registers.

### Condition Registers

The Condition registers reflect the real-time status of the instrument or summary-message bits of other status registers.

### Transition Filters

The transition filters for the Network Master's Unique Status registers are locked to the "Positive transition" criteria. This means that events will be generated when the condition bits goes from 0 to 1. It is not possible to change the transition criteria.

### Event Registers

The Event registers store the transition filter output. These registers are cleared when read.

### Event Enable Registers

The Event Enable registers cannot be read or written and on power-on they are all set to zero. To enable the Event Enable registers and hence generation of summary-messages, the STATUS:PRESet command must be send. The STATUS:PRESet command changes all the bits in the Event Enable registers to 1.

### Summary Register

The summarized status of the following registers is stored in the Summary Register (Refer to Table 1.9).

- Alarm event registers
- Error event registers
- Event registers of lower layer summary registers

Like other status registers, the Summary register consists of the Condition register and the Event register, according to the register model defined in section 11.4.2 of IEEE488.2. The Summary register is locked to positive transition criteria because it consists of lower layer Event registers.

### 1.4.3 Reading, Writing and Clearing Status Registers

The following two tables list the possibilities for reading and writing the various status registers and queues. They also show when and how registers are cleared or enabled.

Registers		Reading	Writing
IEEE488.2 standard status registers	Status Byte	*STB?	Not possible
	Service Request Enable	*SRE?	*SRE
	Standard Event Status	*ESR? After reading, the register con- tent is cleared.	Not possible
	Standard Event Status Enable	*ESE?	*ESE
SCPI defined status registers	Error/Event Queue	SYST:ERR? After reading, the error/event is removed from the queue.	Not possible
	Operation Event	STAT:OPER? After reading, the register con- tent is cleared.	Not possible
	Operation En- able	STAT:OPER:ENAB?	STAT:OPER:ENAB
	Questionable Event	STAT:QUES? After reading, the register con- tent is cleared.	Not possible
	Questionable Enable	STAT:QUES:ENAB?	STAT:QUES:ENAB
Network Master unique status registers	Condition	<Interface>:STAT:<Port>: <Register>:COND?	Not possible
	Transition Filter	Not possible	Not possible
	Event	<Interface>:STAT:<Port>: <Register>? After reading, the register content is cleared.	Not possible
	Enable	Not possible	Not possible

Table 1.9: Reading and writing of Status registers

<b>Registers</b>		<b>*RST</b>	<b>*CLS</b>	<b>PowerOn</b>	<b>STAT:PRES</b>
IEEE488.2 standard status registers	Status Byte	No Changes	Cleared	Cleared	No Changes
	Service Request Enable	No Changes	No Changes	Cleared	No Changes
	Standard Event Status	No Changes	Cleared	Cleared	No Changes
	Standard Event Status Enable	No Changes	No Changes	Cleared	No Changes
SCPI defined status registers	Error/Event Queue	No Changes	Cleared	Cleared	No Changes
	Operation Event	No Changes	Cleared	Cleared	No Changes
	Operation En- able	No Changes	No Changes	Cleared	No Changes
	Questionable Event	No Changes	Cleared	Cleared	No Changes
	Questionable Enable	No Changes	No Changes	Cleared	No Changes
Network Master Unique Status registers	Condition	No Changes	No Changes	Cleared	No Changes
	Transition Filter	No Changes	No Changes	No Changes	No Changes
	Event	No Changes	Cleared	Cleared	No Changes
	Enable	No Changes	No Changes	Cleared	Enabled (all 1's)

Table 1.10: Status registers behaviour for different commands/events

### Notes

The Condition register of the Summary register is locked to positive transition criteria. Therefore, if clearing the register (\*CLS) while an alarm or error is occurring, the register bits stay in "0" (cleared) in spite of the alarm or error occurrence.

## 1.5 Controller Example

One example of how to connect a controller to the Network Master instrument is described in this section.

### 1.5.1 PuTTY

PuTTY is a free Telnet/SSH client which supports raw TCP connections. With PuTTY it is possible to get terminal emulation access to the instrument. It is recommended to enable the prompt when using PuTTY. PuTTY does not support file streaming like the MEAS:EXP command.

PuTTY can be downloaded from <http://www.chiark.greenend.org.uk/~sgtatham/putty/>

#### Setup

1. Install PuTTY.
2. Start PuTTY.
3. In the PuTTY Configuration enable **Implicit CR in every LF** at **Category:→Terminal**.




Figure 1.12: Enable **Implicit CR in every LF** in PuTTY

4. In the instrument GUI, find the instrument's **IP Address** information, see Figure 1.13. Then type it in PuTTY, see Figure 1.14.




Figure 1.13: IP Address on the instrument

5. In PuTTY, type 56001 in the **Port** field, select the **Raw** radio button in the **Connection type** field, and click the **Open** button. see Figure 1.14.





Figure 1.14: Specify the destination and **Open** the connection in PuTTY



6. A window appears, see Figure 1.15.



```
192.168.0.1 - PuTTY
SYST:PROM ON
SCPI:> SYST:ERR?
0,"No error"
SCPI:> █
```

Figure 1.15: Connection established with PuTTY

## 1.6 Definitions

### 1.6.1 NaN (Not a Number)

NaN is defined in SCPI-99. NaN is represented as 9.91E37 (<NR3 NUMERIC RESPONSE DATA>) as defined in IEEE 754. NaN is also used to represent missing data.

### 1.6.2 → Right Arrow

The right arrow → used in this document has two meanings:

- On the left side of the arrow is a query and returned value on the right hand side.  
Example: `TMBP:RX1:PATT?` → `PRBS11`

### 1.6.3 Data Bit (DB)

Data bit is represented as DBx where x represents the bit index in a register. DB1 is always LSB.




Figure 1.16: Data bit

### 1.6.4 Port Number (Logical Port)

Specify a logical port number assigned for each started application as a port number <Pt> in the SCPI command. The logical port numbers will be assigned in the order of Module1-Port1, Module1-Port2, Module2-Port1, and Module2-Port2. The logical port number starts with "1" regardless of the physical port numbers.

#### Example of logical port assignment when using the application start command

- `INST:STAR TP-BERT-OTN,1-PORT2,1-PORT1,2-PORT1` (Figure 1.17)  
Physical Port : Logical Port  
1-PORT1 : PORT1  
1-PORT2 : PORT2  
2-PORT1 : PORT3

When setting CFP for 2-PORT1 by using command, specify "3" for <Pt> in `OTN:TX<PT>:INTerface`.  
Example: `OTN:TX3:INT CFP`




Figure 1.17: Correspondence between physical and logical port numbers (Three ports)

- `INST:STAR TP-BERT-OTN,2-PORT2` (Figure 1.18)  
Physical Port : Logical Port  
2-PORT2 : PORT1




Figure 1.18: Correspondence between physical and logical port numbers (One port)

- `INST:STAR TP-BERT-ETH,1-PORT2,2-PORT1` (Figure 1.19)  
 Physical Port : Logical Port  
 1-PORT2 : PORT1  
 2-PORT1 : PORT2




Figure 1.19: Correspondence between physical and logical port numbers (Two ports)

## Notes

- The physical ports (1-PORT1, 2-PORT1 etc.) specified at application startup basically do not match the logical port numbers assigned in each application.
- The logical ports are not assigned in the same order of the physical ports described in the SCPI command for starting application.(Figure 1.17) For example, the following two commands include the same physical port numbers in different orders. However, for the both cases, 1-PORT is assigned to logical PORT1 and 1-PORT2 is assigned to logical PORT2.  
`INST:STAR TP-BERT-OTN,1-PORT1,1-PORT2`  
`INST:STAR TP-BERT-OTN,1-PORT2,1-PORT1`
- When multiple applications are started, the logical ports are numbered from 1 for each application.



---

## Chapter 2

# SCPI Conformance Information

### 2.1 SCPI Version

The Network Master Remote Control application conforms to SCPI 1999.0

## 2.2 IEEE 488.2 Mandatory Commands

### 2.2.1 \*CLS

<b>Syntax</b>	*CLS
<b>Description</b>	This command clears all the event registers summarized in the Status Byte register. The error queue is emptied. Neither the Standard Event Status Enable register, nor the Service Request Enable register are affected by this command.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	*CLS
<b>Note</b>	All active (SCPI) sessions has their own set of standard registers.

### 2.2.2 \*ESE

<b>Syntax</b>	*ESE <mask>
<b>Description</b>	This command sets bits in the Standard Event Status Enable register. A 1 in a bit in the enable register enables the corresponding bit in the Standard Event Status register. This register is cleared at power-on. The *RST and *CLS commands do not affect this register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the enable mask: DB1 (1) = Operation Complete DB2 = NOT USED DB3 = NOT USED DB4 (8) = Device Dependent Error DB5 (16) = Execution Error DB6 (32) = Command Error DB7 = NOT USED DB8 (128) = Power On <i>MINimum=0, MAXimum=255</i>
<b>Response</b>	None.
<b>Example</b>	*ESE 16
<b>Note</b>	All active sessions has their own Standard Event Status Enable register.

<b>Syntax</b>	*ESE?
<b>Description</b>	This query returns the contents of the Standard Event Status Enable register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA> See the *ESE command for bit values for the enable mask.
<b>Example</b>	*ESE? → 16
<b>Note</b>	

## 2.2.3 \*ESR?

<b>Syntax</b>	*ESR?
<b>Description</b>	This query returns the contents of the Standard Event Status register. This register is cleared after being read.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1 (1) = Operation Complete DB2 = NOT USED DB3 = NOT USED DB4 (8) = Device Dependent Error DB5 (16) = Execution Error DB6 (32) = Command Error DB7 = NOT USED DB8 (128) = Power On
<b>Example</b>	*ESR? → 49
<b>Note</b>	All active sessions has their own Standard Event Status register.

## 2.2.4 \*IDN?

<b>Syntax</b>	*IDN?
<b>Description</b>	This query returns the instrument identification over the interface.
<b>Parameter</b>	None.
<b>Response</b>	<manufacturer>,<model>,<serial>,<version> = <ARBITRARY ASCII RESPONSE DATA>
<b>Example</b>	*IDN? → Anritsu,MT1000A,6123456789,1.00
<b>Note</b>	

## 2.2.5 \*OPC

<b>Syntax</b>	*OPC
<b>Description</b>	This command causes the instrument to generate the operation complete message in the Standard Event Status register when all pending selected instrument operations have been finished.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	*OPC
<b>Note</b>	All active sessions has their own Standard Event Status register.

<b>Syntax</b>	*OPC?
<b>Description</b>	This query places the ASCII character '1' into the instrument's output queue when all pending operations have been finished.
<b>Parameter</b>	None.
<b>Response</b>	<operation complete> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	*OPC? → 1
<b>Note</b>	Only application servers connected to by the current session are synchronized.

## 2.2.6 \*RST

<b>Syntax</b>	*RST
<b>Description</b>	This command sets the instrument to reset setting (standard setting) stored in internal storage. The instrument is placed in the idle state awaiting a command. All running application/servers are closed when the *RST command is issued. The following are not changed: - Service Request Enable register (SRE) - Standard Event Status register (ESR) - Standard Event Status Enable register (ESE) - Any instrument specific Status Event or Status Event Enable registers
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	*RST
<b>Note</b>	*RST is specially configured to be compatible with SCPI remote control. Only application servers connected to by the current session will set to the initial state..

## 2.2.7 \*SRE

<b>Syntax</b>	*SRE <enable mask>
<b>Description</b>	This command sets bits in the Service Request Enable register. A 1 in a bit in the enable register enables the corresponding bit in the Status Byte, also sets the Master Summary Status bit (DB7) in the Status Byte. The register is cleared at power-on. The *RST and *CLS commands do not affect the register.
<b>Parameter</b>	<enable mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1 (1) = Port Event Summary DB2 (2) = Event Queue Summary for the currently selected application server. DB3 (4) = Error Queue Summary for all connected application servers. DB4 (8) = Questionable Status Summary DB5 (16) = Message Available (MAV) DB6 (32) = Standard Event Status Summary (ESB) DB7 = NOT USED DB8 (128) = Operation Status Summary <i>MINimum=0, MAXimum=255</i>
<b>Response</b>	None.
<b>Example</b>	*SRE 255
<b>Note</b>	All active sessions has their own Service Request Enable register.

<b>Syntax</b>	*SRE?
<b>Description</b>	This query returns the contents of the Service Request Enable register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA> See the *SRE command for bit values for the enable mask.
<b>Example</b>	*SRE? → 255
<b>Note</b>	



## 2.2.8 \*STB?

<b>Syntax</b>	*STB?
<b>Description</b>	This query returns the contents of the Status Byte register. The Master Summary Status (MSS) bit is true when any bit of the STB register is set and a matching bit in the Service Request Enable Register is set, see *SRE. The Status Byte register including the MSS is not altered by this query.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1 (1) = Port Event Summary DB2 (2) = Event Queue Summary for the currently selected application server. DB3 (4) = Error Queue Summary for all connected application servers. DB4 (8) = Questionable Status Summary DB5 (16) = Message Available (MAV) DB6 (32) = Standard Event Status Summary (ESB) DB7 (64) = Master Summary Status (MSS) DB8 (128) = Operation Status Summary
<b>Example</b>	*STB? → 7
<b>Note</b>	

## 2.2.9 \*TST?

<b>Syntax</b>	*TST?
<b>Description</b>	This query returns whether or not the instrument completed the self-test without any detected errors.
<b>Parameter</b>	None.
<b>Response</b>	<result> = <NR1 NUMERIC RESPONSE DATA> 0: No self-test errors detected 1: Self-test error detected
<b>Example</b>	*TST? → 0
<b>Note</b>	Self-test is performed automatically at the time of power up.

## 2.2.10 \*WAI

<b>Syntax</b>	*WAI
<b>Description</b>	This command prevents the instrument from executing any further commands until the current command has been finished. All pending operations are completed during the wait period.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	*WAI
<b>Note</b>	*WAI functions for commands called "overlap command". For now Network Master does not have any overlap commands. So *WAI does not work on the current Network Master.

## 2.3 SCPI System Subsystem Commands

### 2.3.1 SYSTem:VERSion?

<b>Syntax</b>	SYSTem:VERSion?
<b>Description</b>	This query returns the SCPI revision to which the system complies.
<b>Parameter</b>	None.
<b>Response</b>	<version> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SYST:VERS? → 1999.0
<b>Note</b>	

### 2.3.2 SYSTem:ERRor[:NEXT]?

<b>Syntax</b>	SYSTem:ERRor[:NEXT]?
<b>Description</b>	This query returns the oldest entry of the error queue and removes the returned entry from the queue.
<b>Parameter</b>	None.
<b>Response</b>	<error number> = <NR1 NUMERIC RESPONSE DATA> <description> = <STRING RESPONSE DATA>
<b>Example</b>	SYST:ERR? → -222,"Data out of range"
<b>Note</b>	All active sessions has their own error queue. Application server ID is added to each error message when the additional message is selected TEST or BOTH. Application server ID is -1 for system errors. Application server ID is fixed to 0 if no error message is in error queue. Error command is added to each error message when the additional message is selected COMMand or BOTH.

### 2.3.3 SYSTem:ERRor:ADDITIONal[:MESSAge]

<b>Syntax</b>	SYSTem:ERRor:ADDITIONal[:MESSAge] <message>
<b>Description</b>	This command select additional message in the error message.
<b>Parameter</b>	<message> = <CHARACTER PROGRAM DATA> NONE TEST COMMand BOTH
<b>Response</b>	None.
<b>Example</b>	SYST:ERR:ADD BOTH SYST:ERR? → -115,"Unexpected number of parameters:-1:INST:TERM"
<b>Note</b>	This setting is applied only for the current session and defaulted to NONE when session closed. See also SYSTem:ERRor[:NEXT]?

<b>Syntax</b>	SYSTem:ERRor:ADDITIONal[:MESSAge]?
<b>Description</b>	This query returns additional message in the error message.
<b>Parameter</b>	None.
<b>Response</b>	<message> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SYST:ERR:ADD? → NON
<b>Note</b>	

## 2.3.4 SYSTem:DATE

<b>Syntax</b>	SYSTem:DATE <year>,<month>,<day>
<b>Description</b>	This command sets the date of the internal calendar.
<b>Parameters</b>	<year> = <NUMERIC PROGRAM DATA> <i>MINimum = 1997, MAXimum = 2036</i>
	<month> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 12</i>
	<day> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 31</i>
<b>Response</b>	None.
<b>Example</b>	SYST:DATE 2009,12,31
<b>Note</b>	

<b>Syntax</b>	SYSTem:DATE?
<b>Description</b>	This query returns the date of the internal calendar.
<b>Parameter</b>	None.
<b>Response</b>	<year>,<month>,<day> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SYST:DATE? → 2009,07,04
<b>Note</b>	

## 2.3.5 SYSTem:TIME

<b>Syntax</b>	SYSTem:TIME <hour>,<minute>,<second>
<b>Description</b>	This command sets the time of the internal clock.
<b>Parameters</b>	<hour> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 23</i>
	<minute> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i>
	<second> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i>
<b>Response</b>	None.
<b>Example</b>	SYST:TIME 23,59,59
<b>Note</b>	

<b>Syntax</b>	SYSTem:TIME?
<b>Description</b>	This query gets the time of the internal clock.
<b>Parameter</b>	None.
<b>Response</b>	<hour>,<minute>,<second> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SYST:TIME? → 15,45,03
<b>Note</b>	

## 2.3.6 SYSTem:REBoot

<b>Syntax</b>	SYSTem:REBoot
<b>Description</b>	This command will force a reboot of the instrument. A TCP remote connection to the instrument will be lost.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SYST:REB
<b>Note</b>	

## 2.3.7 SYSTem:GPS:NSATellites?

<b>Syntax</b>	SYSTem:GPS:NSATellites?
<b>Description</b>	This query returns the number of satellites found by GPS.
<b>Parameter</b>	None.
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SYST:GPS:NSAT? → 5
<b>Note</b>	Return "0" if GPS is not available.

## 2.3.8 SYSTem:GPS:TIME?

<b>Syntax</b>	SYSTem:GPS:TIME?
<b>Description</b>	This query returns the GPS time.
<b>Parameter</b>	None.
<b>Response</b>	<time> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SYST:GPS:TIME? → 2014-01-01T12:34:56
<b>Note</b>	Return "0" if GPS is not available.

## 2.3.9 SYSTem:GPS:LOCation?

<b>Syntax</b>	SYSTem:GPS:LOCation?
<b>Description</b>	This query returns the location.
<b>Parameter</b>	None.
<b>Response</b>	<location> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SYST:GPS:LOC? → 85 26.8444N, 22 20.4508E
<b>Note</b>	Return "0" if GPS is not available.

## 2.3.10 SYSTem:COMMunicate:TERMinator

<b>Syntax</b>	SYSTem:COMMunicate:TERMinator <terminator>
<b>Description</b>	This command sets the terminator code which is appended to the query response.
<b>Parameter</b>	<terminator> = <CHARACTER PROGRAM DATA> NONE(only GPIB) LF CRLF
<b>Response</b>	None.
<b>Example</b>	SYST:COMM:TERM LF
<b>Note</b>	This setting is applied only for the current session and defaulted to CRLF when session closed.

<b>Syntax</b>	SYSTem:COMMunicate:TERMinator?
<b>Description</b>	This query returns the terminator code which is appended to the query response.
<b>Parameter</b>	None.
<b>Response</b>	<terminator> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SYST:COMM:TERM? → LF
<b>Note</b>	

## 2.3.11 SYSTem:PROMpt

<b>Syntax</b>	SYSTem:PROMpt <enable>
<b>Description</b>	This command enables/disables appending of prompt to all replies from Remote Control interface.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SYST:PROM 1
<b>Note</b>	The prompt string is "SCPI:> " This setting is applied only for the current session and forgets when session closed.

<b>Syntax</b>	SYSTem:PROMpt?
<b>Description</b>	This query returns status of the prompt.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN PROGRAM DATA>
<b>Example</b>	SYST:PROM? → SCPI:>1
<b>Note</b>	

### 2.3.12 SYSTem:LOCal:CONTRol

<b>Syntax</b>	SYSTem:LOCal:CONTRol <enable>
<b>Description</b>	This command enables/disables local control.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SYST:LOC:CONT 1
<b>Note</b>	This setting is applied all connected sessions and forgets when turn off SCPI.

<b>Syntax</b>	SYSTem:LOCal:CONTRol?
<b>Description</b>	This query returns enables/disables local control.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN PROGRAM DATA>
<b>Example</b>	SYST:LOC:CONT? → 1
<b>Note</b>	

### 2.3.13 SYSTem:TIMing:EXTernal?

<b>Syntax</b>	SYSTem:TIMing:EXTernal?
<b>Description</b>	This query returns external clock input signal status.
<b>Response</b>	<clock> = <STRING RESPONSE DATA> "2M" : 2MHz clock or E1 (SETS) signal "1.5M" : T1 (BITS) signal "10M" : 10MHz clock signal "N/A" : No Input
<b>Example</b>	SYST:TIM:EXT? → "2M"
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

### 2.3.14 SYSTem:STIMuli:INSert

<b>Syntax</b>	SYSTem:STIMuli:INSert
<b>Description</b>	This command emulates pressing the Error Insert button of the GUI. Errors are inserted in the outgoing data stream according to the configuration of the active Stimuli setup(s).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SYST:STIM:INS
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

### 2.3.15 SYSTem:STIMuli:CLR

<b>Syntax</b>	SYSTem:STIMuli:CLR
<b>Description</b>	This command clears the Stimuli setup(s) for all interfaces.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SYST:STIM:CLR
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

## 2.3.16 SYSTem:WAIT[:IDLE]

<b>Syntax</b>	SYSTem:WAIT[:IDLE]
<b>Description</b>	This command waits for the instrument to go into IDLE state, i.e. no measurement or test is pending, running, loading or being stored. It also waits for load and save of settings to finish.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SYST:WAIT
<b>Note</b>	<p>There must be a connected application server for this command to be recognized as a legal command.</p> <p>Be careful when using this command as it may lead to undesired blocking of the remote interface. In some situations the instrument requires a remote command or other user intervention in order to return to IDLE state; e.g. when a measurement is running and measurement stop mode is set to MANual (MEAS:SET:STOP → MAN). In this situation, for the instrument to return to IDLE state press the START/STOP button on the GUI or apply the MEASurement:STOP command. The latter is NOT possible if SYST:WAIT:IDLE is currently being executed.</p> <p>If an undesired blocking occurs close and re-open the remote connection.</p> <p>And then send *RST command to reset undesired blocking remote connection.</p>

## 2.3.17 SYSTem:WAIT:DURation

<b>Syntax</b>	SYSTem:WAIT:DURation <seconds>
<b>Description</b>	This command waits for the specified number of seconds.
<b>Parameter</b>	<seconds> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 3600</i>
<b>Response</b>	None.
<b>Example</b>	SYST:WAIT:DUR 5
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

## 2.3.18 SYSTem:APPLication

<b>Syntax</b>	SYSTem:APPLication <application>
<b>Description</b>	This command selects between the BERT, APS and RTD applications <application> = <CHARACTER PROGRAM DATA> BERT: BERT Application APS: APS Application RTD: RTD Application <i>DEFault = BERT</i>
<b>Response</b>	None.
<b>Example</b>	SYST:APP BERT
<b>Note</b>	This command only applies in the OTN or SDH/SONET/PDH/DSn BERT applications

## 2.3.19 SYSTem:APPLication?

<b>Syntax</b>	SYSTem:APPLication?
<b>Description</b>	This command returns the application type
<b>Response</b>	<app> = <CHARACTER PROGRAM DATA> BERT: BERT Application APS: APS Application RTD: RTD Application
<b>Example</b>	SYST:APP? → BERT
<b>Note</b>	This command only applies in the OTN or SDH/SONET/PDH/DSn BERT applications

## 2.4 SCPI Instrument Subsystem Commands

To use the application-specific SCPI commands, you need to connect the client session to the application server. By sending SCPI commands to an application server connected, you can control the application.

### 2.4.1 Connection to Application Server

To connect the client session to an application server, there are following methods.

- Use `INST:CONN:ALL` command  
This command connects a client session to the application server which is not occupied. If other client session is already connected to the server (application server is occupied), the connection attempted by using this command fails.
- Use `INST:CONN` command  
This command connects client sessions to all application servers which are not occupied.
- Use `INST:STAR` command  
This command starts an application server newly and connects the client session to the application server.

### 2.4.2 Connection to multiple applications

A client session can connect to multiple application servers simultaneously. In this case, the destination of SCPI command will be the selected application server.

The destination application server of SCPI command can be set by using `INST:SEL` command. To confirm the selected application server, use `INST?` command.

When an application server has started newly by `INST:STAR` command, the server will be set to the destination application server of SCPI command.

### 2.4.3 Connection by multi-user

When using the application server by multi-users, multiple client sessions connect to a Network Master. Under this condition, be careful whether the application server is not occupied by other users.

Network Master CANNOT connect another client session newly to the application server that client session has already connected.

To connect to the application server that other client session is connecting, you need to release the application server by disconnecting the client session which is connecting currently. There are following methods to release the application server.

- Use `INST:DISC` command  
You can disconnect the server by sending `INST:DISC` command from the connecting client session.
- Terminating the Client Session  
After the client session terminated, all application servers which were connected is released. You can terminate the client session by disconnecting connection to Network Master from the User PC.

You can connect client session(s) to the released application server again by using `INST:CONN` command or `INST:CONN:ALL` command.

### 2.4.4 Force Termination of application Server

The application server that session is connecting does not accept SCPI command from another session.

An exception is `INST:TERM:FORC` command. This command is accepted always even if sent from other session and terminates the application server that other session is connecting.




Figure 2.1: INST:STAR automatically connects and selects started application server.




Figure 2.2: Original client session has to disconnect, before another client session can connect.




Figure 2.3: When connected to multiple application servers, client session selects to which application server the application specific commands are dispatched.



## 2.4.5 INSTRUMENT:START[:DEFAULT]

<b>Syntax</b>	INSTRUMENT:START[:DEFAULT] <app name>[, <port name>[, <port name>, ...]]
<b>Description</b>	This command starts an application server with default settings.
<b>Parameters</b>	<p>&lt;app name&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>TP-APS-OTN: OTN Automatic Protection Switching application.  TP-APS-SDHPDH: SDH/PDH Automatic Protection Switching application.  TP-APS-SDHPDH-OTN: SDH/PDH over OTN Automatic Protection Switching application.  TP-BERT-CPRI: CPRI Bit Error Rate Test application.  TP-BERT-CPRI-OTN: CPRI over OTN Bit Error Rate Test application.  TP-BERT-ETH: Ethernet Bit Error Rate Test application.  TP-BERT-ETH-OTN: Ethernet over OTN Bit Error Rate Test application.  TP-BERT-FC: Fibre Channel Bit Error Rate Test application.  TP-BERT-FC-OTN: Fibre Channel over OTN Bit Error Rate Test application.  TP-BERT-OTN: OTN Bit Error Rate Test application.  TP-BERT-SDHPDH: PDH/SDH Bit Error Rate Test application.  TP-BERT-SDHPDH-OTN: PDH/SDH over OTN Bit Error Rate Test application.  TP-CABLE-ETH: Ethernet cable test application.  TP-CHSTAT-ETH: Ethernet channel statistics application.  TP-MONGEN-ETH: Ethernet monitor/generate application.  TP-MONGEN-ETH-OTN: Ethernet over OTN monitor/generate application.  TP-NOFRAME-DEVICE: No frame device test (Unframed Bit Error Rate Test) application.  TP-PASS-CPRI: CPRI pass-through application.  TP-PASS-ETH: Ethernet pass-through application.  TP-PING-ETH: Ethernet ICMP ping application.  TP-REFL-ETH: Ethernet reflector application.  TP-REFL-ETH-OTN: Ethernet over OTN reflector application.  TP-REFL-FC: Fibre Channel reflector application.  TP-REFL-FC-OTN: Fibre Channel over OTN reflector application.  TP-RFC-ETH: Ethernet RFC-2544 test application.  TP-RFC-ETH-OTN: Ethernet over OTN RFC-2544 test application.  TP-RFC6349-ETH: Ethernet RFC-6349 test application.  TP-RTD-OTN: OTN Round Trip Delay test application.  TP-RTD-SDHPDH: SDH/PDH Round Trip Delay test application.  TP-RTD-SDHPDH-OTN: SDH/PDH Round Trip Delay test application.  TP-SAT-ETH: Ethernet Service Activation Test application.  TP-SAT-ETH-OTN: Ethernet over OTN Service Activation Test application.  TP-TRACE-ETH: Ethernet trace-route application.  TP-SYNCTEST-ETH: Ethernet sync test application.  OTDR-OTDR: OTDR application.</p> <p>&lt;port name&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>1-PORT1: Port 1 on module 1  1-PORT2: Port 2 on module 1  2-PORT1: Port 1 on module 2  2-PORT2: Port 2 on module 2  1-PORT-SING1: Single port 1 on module 1 (for MU110011A/MU110012A)</p> <p>The physical port(s) given as parameters are assigned to logical port numbers in the application server. The logical port number range is from 1 to the actual number of port assigned to the application server.</p> <p>The list of ports returned by the INSTRUMENT:STATE? &lt;id&gt; command reveals the virtual port number sequence. The ports will be shown sorted in (1<sup>st</sup>) module order and (2<sup>nd</sup>) port order.</p>
<b>Response</b>	None.
<b>Example</b>	<pre>INST:STAR TP-BERT-OTN,1-PORT1 INST? → 2</pre>
<b>Note</b>	<p>Operators can get started application server ID by using the INSTRUMENT:SELEct? command. When you start an application server, the application server will be connected and selected automatically.</p> <p>When using this command, the application server will be started with DEFault setup.</p>

## 2.4.6 INSTRUMENT:START:LAST

<b>Syntax</b>	INSTRUMENT:START:LAST <app name>[, <port name>[, <port name>,...]]
<b>Description</b>	This command starts an application server and loads the applicable auto saved settings.
<b>Parameters</b>	The parameters of this command are similar to the parameters of the INSTRUMENT:START[:DEFAULT] command above.
<b>Response</b>	None.
<b>Example</b>	INST:STAR:LAST TP-BERT-OTN,1-PORT1 INST? → 2
<b>Note</b>	Operators can get started application server ID by using the INSTRUMENT:SElect? command. When you start an application server, the application server will be connected and selected automatically. When using this command, the application server will be started with LAST setup.

## 2.4.7 INSTRUMENT:START:GUI

<b>Syntax</b>	INSTRUMENT:START:GUI [<test index>]
<b>Description</b>	This command starts GUI for the application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA> Defaults to the current application server if a value is omitted.
<b>Response</b>	None.
<b>Example</b>	INST:STAR TP-BERT-OTN,1-PORT1 INST:STAR:GUI
<b>Note</b>	Must connect to the application server first.

## 2.4.8 INSTRUMENT:TERMINATE

<b>Syntax</b>	INSTRUMENT:TERMINATE [<test index>]
<b>Description</b>	This command terminates an application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA> Defaults to the current application server if a value is omitted.
<b>Response</b>	None.
<b>Example</b>	INST:STAR TP-BERT-OTN,1-PORT1 INST? → 2 INST:TERM 2
<b>Note</b>	Must connect to the application server first.

## 2.4.9 INSTRUMENT:TERMINATE:FORCE

<b>Syntax</b>	INSTRUMENT:TERMINATE:FORCE [<test index>]
<b>Description</b>	This command force terminates an application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA> Defaults to the current application server if a value is omitted.
<b>Response</b>	None.
<b>Example</b>	INST:STAR TP-BERT-OTN,1-PORT1 INST? → 2 INST:TERM:FORC 2
<b>Note</b>	WARNING. This command can terminate the application to which the other session communicating.

## 2.4.10 INSTRUMENT:COUNT?

<b>Syntax</b>	INSTRUMENT:COUNT?
<b>Description</b>	This query returns the number of active application servers.
<b>Parameter</b>	None.
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	INST:COUN? → 2
<b>Note</b>	

## 2.4.11 INSTRUMENT:CATalog?

<b>Syntax</b>	INSTRUMENT:CATalog?
<b>Description</b>	This query returns test indices, application name and port name of all active application servers.
<b>Parameter</b>	None.
<b>Response</b>	<test index> = <EXPRESSION RESPONSE DATA> Expression format: (<test index>,<app name>,<port name>)
<b>Example</b>	INST:CAT? → (1,TP-SAT-ETH,1-PORT1),(2,TP-BERT-SDHPDH,1-PORT2)
<b>Note</b>	Return -1 if no application server is running.

## 2.4.12 INSTRUMENT:STATe?

<b>Syntax</b>	INSTRUMENT:STATe? <test index>
<b>Description</b>	This query returns status information about a given application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA>
<b>Response</b>	<app name> = <CHARACTER RESPONSE DATA> <client connection> = <CHARACTER RESPONSE DATA> NON IP Address <select status> = <CHARACTER RESPONSE DATA> NON SELECTED <port name> = <CHARACTER RESPONSE DATA> Expression format: Character list
<b>Example</b>	INST:STAT? 1 → TP-BERT-OTN,192.168.128.21,SELECTED,1-PORT1,2-PORT2...
<b>Note</b>	

## 2.4.13 INSTRUMENT:CONNect

<b>Syntax</b>	INSTRUMENT:CONNect <test index>
<b>Description</b>	This command allows client session to connect to an existing application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	INST:CONN 1
<b>Note</b>	This command fails if the application server is already connect to by another client session. Use INSTRUMENT:CATalog? query to acquire the list of all existing application servers. If command succeeds, the application server will be selected automatically.

## 2.4.14 INSTRUMENT:CONNect:ALL

<b>Syntax</b>	INSTRUMENT:CONNect:ALL
<b>Description</b>	This command allows client session to connect to all existing application servers.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	INST:CONN:ALL
<b>Note</b>	This command fails if no application server is selected when the command exits, e.g. because all application servers was already connected to by other client sessions, or because there are no application servers at all. If connected to multiple application servers, the application server with the lowest index will be selected, but selected index will not change if an application server was already selected prior to issuing this command.

## 2.4.15 INSTRUMENT:CONNECT[:CATalog]?

<b>Syntax</b>	INSTRUMENT:CONNECT[:CATalog]?
<b>Description</b>	This query returns indices of all application servers for the current client session.
<b>Parameter</b>	None.
<b>Response</b>	<test index> = <EXPRESSION RESPONSE DATA> Expression format: Numeric list
<b>Example</b>	INST:CONN? → 0,1,...
<b>Note</b>	Return -1 if current client session has no application servers.

## 2.4.16 INSTRUMENT:DISConnect

<b>Syntax</b>	INSTRUMENT:DISConnect <test index>
<b>Description</b>	This command disconnect the application server from the client session.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	INST:DISC 1
<b>Note</b>	When current application is disconnected, the application server lowest ID will be selected automatically. When a client session is disconnected all the currently connected application servers will be disconnected automatically.

## 2.4.17 INSTRUMENT[:SElect]

<b>Syntax</b>	INSTRUMENT[:SElect] <test index>
<b>Description</b>	This command select the current application server.
<b>Parameter</b>	<test index> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	INST:STAR TP-BERT-OTN,1-PORT1 INST? → 1 INST:STAR TP-BERT-OTN,1-PORT2 INST? → 2 INST 1
<b>Note</b>	All future commands are forwarded to the current application server until the current application server is changed.

<b>Syntax</b>	INSTRUMENT[:SElect]?
<b>Description</b>	This query returns index of the currently selected application server.
<b>Parameter</b>	None.
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	INST:STAR TP-BERT-OTN,1-PORT1 INST? → 1 INST:STAR TP-BERT-OTN,1-PORT2 INST? → 2 INST 1
<b>Note</b>	Return -1 if current client session does not have a currently selected application server.

## 2.4.18 INSTRument:ERRor[:NEXT]?

<b>Syntax</b>	INSTRument:ERRor[:NEXT]?
<b>Description</b>	This query returns the oldest entry of the event queue for the currently selected application server and removes the returned entry from the queue.
<b>Parameter</b>	None.
<b>Response</b>	<description> = <STRING RESPONSE DATA>
<b>Example</b>	INST:ERR? → "Signal abnormal"
<b>Note</b>	Application server has its own event queue. This event queue is not destroyed when the session is closed. Before checking the server status by using this command, controller may check DB2 (Event Queue Summary) of the Status Byte Register to see if it is set. DB2 of the Status Byte Register will aggregate input from potentially many application servers, and clear if event queues of all servers are empty.

## 2.4.19 INSTRument:PORT?

<b>Syntax</b>	INSTRument:PORT?
<b>Description</b>	This query returns ports assigned for the currently selected application server.
<b>Parameter</b>	None.
<b>Response</b>	<port name> = <CHARACTER RESPONSE DATA> Expression format: Character list
<b>Example</b>	INST:STAR TP-BERT-OTN, 1-PORT1, 1-PORT2 INST:PORT? → 1-PORT1, 1-PORT2
<b>Note</b>	Operates on the application server currently selected by the INSTRument:SElect command. Returns NON if the client session does not have a currently selected application server. Returns NON if no ports are assigned for the currently selected application server.

## 2.4.20 INSTRument:PORT:FREE?

<b>Syntax</b>	INSTRument:PORT:FREE? <app name>
<b>Description</b>	This query returns all unused ports for the target application name.
<b>Parameter</b>	<app name> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<port name> = <CHARACTER RESPONSE DATA> Expression format: Character list
<b>Example</b>	INST:PORT:FREE? TP-BERT-OTN → 1-PORT1, 1-PORT2
<b>Note</b>	

## 2.4.21 INSTRument:PORT:CATalog?

<b>Syntax</b>	INSTRument:PORT:CATalog?
<b>Description</b>	This query returns all ports of device.
<b>Parameter</b>	None.
<b>Response</b>	<port name> = <CHARACTER RESPONSE DATA> Expression format: Character list
<b>Example</b>	INST:PORT:CAT? → 1-PORT1, 1-PORT2
<b>Note</b>	When SCPI client uses any of the STATus:PORT: commands, <bit> index is the same as returned by the INSTRument:PORT:CATalog?

## 2.4.22 INSTRument:MODule:CATalog?

<b>Syntax</b>	INSTRument:MODule:CATalog?
<b>Description</b>	This query returns module names of device.
<b>Parameter</b>	None.
<b>Response</b>	{<module n>,*} = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:MOD:CAT? → MU100010A, MU100011A
<b>Note</b>	

**2.4.23 INSTRument:CTRL:NAME?**

<b>Syntax</b>	INSTRument:CTRL:NAME?
<b>Description</b>	This query returns model name.
<b>Parameter</b>	None.
<b>Response</b>	<model name> = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:CTRL:NAME? → MT1000A
<b>Note</b>	

**2.4.24 INSTRument:CTRL:SN?**

<b>Syntax</b>	INSTRument:CTRL:SN?
<b>Description</b>	This query returns controller serial number.
<b>Parameter</b>	None.
<b>Response</b>	<serial number> = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:CTRL:SN? → 1234567890
<b>Note</b>	

**2.4.25 INSTRument:CTRL:TRT?**

<b>Syntax</b>	INSTRument:CTRL:TRT?
<b>Description</b>	This query returns controller total run time(sec).
<b>Parameter</b>	None.
<b>Response</b>	<time> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	INST:CTRL:TRT? → 5000000
<b>Note</b>	

**2.4.26 INSTRument:CTRL:OPTion:CATalog?**

<b>Syntax</b>	INSTRument:CTRL:OPTion:CATalog?
<b>Description</b>	This query returns controller enabled options.
<b>Parameter</b>	None.
<b>Response</b>	{<option n>,}* = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:CTRL:OPT:CAT? → MT1000A-303,MT1000A-005
<b>Note</b>	

**2.4.27 INSTRument:MODule<Md>:NAME?**

<b>Syntax</b>	INSTRument:MODule<Md>:NAME?
<b>Description</b>	This query returns module model number.
<b>Parameter</b>	None.
<b>Response</b>	<model name> = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:MOD1:NAME? → MT1000A
<b>Note</b>	

**2.4.28 INSTRument:MODule<Md>:SN?**

<b>Syntax</b>	INSTRument:MODule<Md>:SN?
<b>Description</b>	This query returns module serial number.
<b>Parameter</b>	None.
<b>Response</b>	<serial number> = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:MOD1:SN? → 1234567890
<b>Note</b>	

**2.4.29 INSTRument:MODule<Md>:TRT?**

<b>Syntax</b>	INSTRument:MODule<Md>:TRT?
<b>Description</b>	This query returns module total run time(sec).
<b>Parameter</b>	None.
<b>Response</b>	<time> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	INST:MOD1:TRT? → 5000000
<b>Note</b>	

**2.4.30 INSTRument:MODule<Md>:OPTion:CATalog?**

<b>Syntax</b>	INSTRument:MODule<Md>:OPTion:CATalog?
<b>Description</b>	This query returns module enabled options.
<b>Parameter</b>	None.
<b>Response</b>	{<option n>,*} = <CHARACTER RESPONSE DATA>
<b>Example</b>	INST:MOD1:OPT:CAT? → MU100010A-001,MU100010A-002
<b>Note</b>	

## 2.5 SCPI Status Subsystem Commands

### 2.5.1 STATus:OPERation[:EVENTt]?

<b>Syntax</b>	STATus:OPERation[:EVENTt]?
<b>Description</b>	This query returns and clears the operation event register.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1-DB4 = NOT USED DB5 (16) = Measuring DB6-DB16 = NOT USED
<b>Example</b>	STAT:OPER? → 16
<b>Note</b>	All active sessions has their own register and it is cleared when the session starts.

### 2.5.2 STATus:OPERation:CONDition?

<b>Syntax</b>	STATus:OPERation:CONDition?
<b>Description</b>	This query returns the operation condition register.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1-DB4 = NOT USED DB5 (16) = Measuring DB6-DB16 = NOT USED
<b>Example</b>	STAT:OPER:COND? → 16
<b>Note</b>	

### 2.5.3 STATus:OPERation:ENABle

<b>Syntax</b>	STATus:OPERation:ENABle <mask>
<b>Description</b>	This command sets the enable mask for the operation event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB4 = NOT USED DB5 (16) = Measuring DB6-DB16 = NOT USED <i>MINimum = 0, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:OPER:ENAB 65535
<b>Note</b>	

<b>Syntax</b>	STATus:OPERation:ENABle?
<b>Description</b>	This query returns the enable mask for the operation event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:OPER:ENAB? → 16
<b>Note</b>	



## 2.5.4 STATus:OPERation:PTRansition

<b>Syntax</b>	STATus:OPERation:PTRansition <mask>
<b>Description</b>	This command sets the positive transition filter for the operation event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB4 = NOT USED DB5 (16) = Measuring DB6-DB16 = NOT USED <i>MINimum = 0, DEFault = 65535, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:OPER:PTR 16384
<b>Note</b>	

<b>Syntax</b>	STATus:OPERation:PTRansition?
<b>Description</b>	This query returns the positive transition filter for the operation event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:OPER:PTR? → 16384
<b>Note</b>	

## 2.5.5 STATus:OPERation:NTRansition

<b>Syntax</b>	STATus:OPERation:NTRansition <mask>
<b>Description</b>	This command sets the negative transition filter for the operation event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB4 = NOT USED DB5 (16) = Measuring DB6-DB16 = NOT USED <i>MINimum = 0, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:OPER:NTR 16384
<b>Note</b>	

<b>Syntax</b>	STATus:OPERation:NTRansition?
<b>Description</b>	This query returns the negative transition filter for the operation event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:OPER:NTR? → 16384
<b>Note</b>	

## 2.5.6 STATus:QUEStionable[:EVENT]?

<b>Syntax</b>	STATus:QUEStionable[:EVENT]?
<b>Description</b>	This query returns and clears the questionable event register.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1-DB14 = NOT USED DB15 (16384) = Command Warning DB16 = NOT USED
<b>Example</b>	STAT:QUES? → 16384
<b>Note</b>	All active sessions has their own register and it is cleared when the session starts.

## 2.5.7 STATus:QUEStionable:CONDition?

<b>Syntax</b>	STATus:QUEStionable:CONDition?
<b>Description</b>	This query returns the questionable condition register.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1-DB14 = NOT USED DB15 (16384) = Command Warning DB16 = NOT USED
<b>Example</b>	STAT:QUES:COND? → 16384
<b>Note</b>	

## 2.5.8 STATus:QUEStionable:ENABLE

<b>Syntax</b>	STATus:QUEStionable:ENABLE <mask>
<b>Description</b>	This command sets the enable mask for the questionable event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB14 = NOT USED DB15 (16384) = Command Warning DB16 = NOT USED <i>MINimum = 0, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:QUES:ENAB 16384
<b>Note</b>	

<b>Syntax</b>	STATus:QUEStionable:ENABLE?
<b>Description</b>	This query returns the enable mask for the questionable event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:QUES:ENAB? → 16384
<b>Note</b>	

## 2.5.9 STATus:QUEStionable:PTRansition

<b>Syntax</b>	STATus:QUEStionable:PTRansition <mask>
<b>Description</b>	This command sets the positive transition filter for the questionable event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB14 = NOT USED DB15 (16384) = Command Warning DB16 = NOT USED <i>MINimum = 0, DEFault = 65535, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:QUES:PTR 16384
<b>Note</b>	

<b>Syntax</b>	STATus:QUEStionable:PTRansition?
<b>Description</b>	This query returns the positive transition filter for the questionable event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:QUES:PTR? → 16384
<b>Note</b>	

## 2.5.10 STATus:QUEStionable:NTRansition

<b>Syntax</b>	STATus:QUEStionable:NTRansition <mask>
<b>Description</b>	This command sets the negative transition filter for the questionable event register.
<b>Parameter</b>	<mask> = <NUMERIC PROGRAM DATA> The bits and their values for the register: DB1-DB14 = NOT USED DB15 (16384) = Command Warning DB16 = NOT USED <i>MINimum = 0, MAXimum = 65535</i>
<b>Response</b>	None.
<b>Example</b>	STAT:QUES:NTR 16384
<b>Note</b>	

<b>Syntax</b>	STATus:QUEStionable:NTRansition?
<b>Description</b>	This query returns the negative transition filter for the questionable event register.
<b>Parameter</b>	None.
<b>Response</b>	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	STAT:QUES:NTR? → 16384
<b>Note</b>	

## 2.5.11 STATus:PORT[:EVENT]?

<b>Syntax</b>	STATus:PORT[:EVENT]? <port name>
<b>Description</b>	This query returns and clears the port event register.
<b>Parameter</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	STAT:PORT? 1-PORT1 → 1
<b>Note</b>	All active sessions has their own register and it is cleared when the session starts. <port name> is the same as the one returned by INSTRument:PORT:CATalog?.

## 2.5.12 STATus:PORT:CONDition?

<b>Syntax</b>	STATus:PORT:CONDition? <port name>
<b>Description</b>	This query returns the port condition register.
<b>Parameter</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	STAT:PORT:COND? 1-PORT1 → 1
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

## 2.5.13 STATus:PORT:ENABLE

<b>Syntax</b>	STATus:PORT:ENABLE <port name>,<enable>
<b>Description</b>	This command sets the enable mask for the port event register.
<b>Parameters</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list <enable> = <BOOLEAN PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	STAT:PORT:ENAB 1-PORT1,ON
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

<b>Syntax</b>	STATus:PORT:ENABle? <port name>
<b>Description</b>	This query returns the enable mask for the port event register.
<b>Parameter</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	STAT:PORT:ENAB? 1-PORT1 → 1
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

#### 2.5.14 STATus:PORT:PTRansition

<b>Syntax</b>	STATus:PORT:PTRansition <port name>,<enable>
<b>Description</b>	This command sets the positive transition filter for the port event register.
<b>Parameters</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list <enable> = <BOOLEAN PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	STAT:PORT:PTR 1-PORT1,ON
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

<b>Syntax</b>	STATus:PORT:PTRansition? <port name>
<b>Description</b>	This query returns the positive transition filter for the port event register.
<b>Parameter</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	STAT:PORT:PTR? 1-PORT1 → 1
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

#### 2.5.15 STATus:PORT:NTRansition

<b>Syntax</b>	STATus:PORT:NTRansition <port name>,<enable>
<b>Description</b>	This command sets the negative transition filter for the port event register.
<b>Parameters</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list <enable> = <BOOLEAN PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	STAT:PORT:NTR 1-PORT1,OFF
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

<b>Syntax</b>	STATus:PORT:NTRansition? <port name>
<b>Description</b>	This query returns the negative transition filter for the port event register.
<b>Parameter</b>	<port name> = <CHARACTER PROGRAM DATA> Expression format: Character list
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	STAT:PORT:NTR? 1-PORT1 → 0
<b>Note</b>	<port name> is the same as one of the returned by the INSTRument:PORT:CATalog?

## 2.5.16 STATus:PRESet

<b>Syntax</b>	STATus:PRESet
<b>Description</b>	For the instrument-dependent status data structures, the PRESet commands sets the enable register to all 1's and the transition filter register to recognize only positive transitions. For the SCPI-mandated status structures (operation, questionable and port status) the PRE-Set command sets the transition filter registers to recognize only positive transitions and set the enable registers to 0's. This command does not affect either the Status Byte or the Standard Event Status register. PRESet does not clear any of the event registers or any item from the error or event queues.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	STAT:PRES
<b>Note</b>	All active sessions has their own set of registers. This command affects registers in all connected application servers.

## 2.5.17 STATus:INTerface:PORT&lt;Pt&gt;[:EVENT]?

<b>Syntax</b>	STATus:INTerface:PORT<Pt>[:EVENT]?
<b>Description</b>	This query returns and clears the device dependent interface event status register. Events are summarized in Status Byte DB1 for port, DB2 for port 2 and so on.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> The bits and their values for the register: DB1 (1) = 2 Mbps Summary DB2 (2) = SDH/SONET Summary DB3 (4) = E3 Summary DB4 (8) = E4 Summary DB5 (16) = NOT USED. Reserved for V-Series/Codir. Summary DB6 (32) = Ethernet Summary DB7 (64) = T1 Summary DB8 (128) = OTN Summary DB9 (256) = NoFrame Summary DB10 (512) = Physical Summary DB11 (1024) = T3 Summary DB12 (2048) = Fibre Channel Summary DB13 (4096) = CPRI Summary DB14 - DB16 = NOT USED
<b>Example</b>	STAT:INT:PORT1? → 16
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

## 2.5.18 STATus:INTerface:PORT&lt;Pt&gt;:CONDition?

<b>Syntax</b>	STATus:INTerface:PORT<Pt>:CONDition?
<b>Description</b>	This query returns the instrument dependent interface status condition register. This register summarize all events/alarms from the different interfaces.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<p>&lt;register&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p> <p>The bits and their values for the register:</p> <p>DB1 (1) = 2 Mbps Summary</p> <p>DB2 (2) = SDH/SONET Summary</p> <p>DB3 (4) = E3 Summary</p> <p>DB4 (8) = E4 Summary</p> <p>DB5 (16) = NOT USED. Reserved for V-Series/Codir. Summary</p> <p>DB6 (32) = Ethernet Summary</p> <p>DB7 (64) = T1 Summary</p> <p>DB8 (128) = OTN Summary</p> <p>DB9 (256) = NoFrame Summary</p> <p>DB10 (512) = Physical Summary</p> <p>DB11 (1024) = T3 Summary</p> <p>DB12 (2048) = Fibre Channel Summary</p> <p>DB13 (4096) = CPRI Summary</p> <p>DB14 - DB16 = NOT USED</p>
<b>Example</b>	STAT:INT:PORT1:COND? → 16
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command.

## 2.6 Mass Memory Subsystem Commands

The commands in this section operates on files and directories placed in the following storage areas:

Location	Description
Internal/	The internal storage of the Network Master.
Usb/	An USB connected storage device. This location is only accessible when a USB storage device is mounted.
Internal/remote/	A remote network drive. Refer to the User Manual for information on how to connect to an external storage location. This location is only accessible when external storage is configured and the Network Master is able to connect to it.

Files must be located in one of the locations described in the table above - or a in a sub-directory of one of these.

### 2.6.1 MMEMory:LOAD

<b>Syntax</b>	MMEMory:LOAD <file>
<b>Description</b>	This command loads a file into the currently selected application server. The file may contain settings only or both settings and results data.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path and name of the file to be loaded.
<b>Response</b>	None
<b>Example</b>	MMEM:LOAD "Internal/SAT-settings.cfg"
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command. The application server must be in the idle state and the content of the loaded file must match the application server type.

### 2.6.2 MMEMory:STORe:STATe

<b>Syntax</b>	MMEMory:STORe:STATe <file>
<b>Description</b>	This command stores the current settings to a file on the instrument.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path and name of the file to store the data.
<b>Response</b>	None
<b>Example</b>	MMEM:STOR:STAT "Internal/my-bert-settings.cfg"
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command. The application server must be in the idle state.

### 2.6.3 MMEMory:STORe:DATA

<b>Syntax</b>	MMEMory:STORe:DATA <file>
<b>Description</b>	This command stores the current settings and result data to a file on the instrument.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path and name of the file to store the data.
<b>Response</b>	None
<b>Example</b>	MMEM:STOR:DATA "Usb/my-bert-result.res"
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command. The application server must be in the idle state.

## 2.6.4 MMEMory:DELeTe

<b>Syntax</b>	MMEMory:DELeTe <file>
<b>Description</b>	This command deletes a file.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path to the file to be deleted.
<b>Response</b>	None.
<b>Example</b>	MMEM:DEL "Internal/report.pdf"
<b>Note</b>	

## 2.6.5 MMEMory:DATA?

<b>Syntax</b>	MMEMory:DATA? <file>
<b>Description</b>	This command retrieves a file.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path to the file to be retrieved.
<b>Response</b>	<DEFINITE LENGTH ARBITRARY BLOCK RESPONSE DATA> = #<nonzero digit><digits><8 bit data bytes>, where: <nonzero digit> is a single ASCII character in the range of '1'-'9'. It represents the length of <digits> in number of bytes. <digits> is a number of ASCII characters in the range of '0'-'9', which together are a decimal representation of the number of succeeding data bytes.
<b>Example</b>	MMEM:DATA? "Internal/report.pdf" → #49137<9137 bytes of binary data>
<b>Note</b>	This command cannot be used together with other commands in a compound command.

## 2.6.6 MMEMory:COPIY

<b>Syntax</b>	MMEMory:COPIY <source-file>,<destination-file>
<b>Description</b>	This command copies a file.
<b>Parameter</b>	<source-file> = <STRING PROGRAM DATA> The path to the file to be copied. <destination-file> = <STRING PROGRAM DATA> The path to the new file.
<b>Response</b>	None.
<b>Example</b>	MMEM:COPIY "Internal/report.pdf","Usb/report.pdf"
<b>Note</b>	

## 2.6.7 MMEMory:MOVE

<b>Syntax</b>	MMEMory:MOVE <old-file>,<new-file>
<b>Description</b>	This command moves or renames a file.
<b>Parameter</b>	<old-file> = <STRING PROGRAM DATA> The path to the file to be moved or renamed. <new-file> = <STRING PROGRAM DATA> The new path to the file.
<b>Response</b>	None.
<b>Example</b>	MMEM:MOVE "Internal/report.pdf","Usb/report.pdf"
<b>Note</b>	



## 2.6.8 MMEMemory:INFO?

<b>Syntax</b>	MMEMemory:INFO? <file>
<b>Description</b>	This command retrieves information about a file.
<b>Parameter</b>	<file> = <STRING PROGRAM DATA> The path to the file to retrieve file information about.
<b>Response</b>	<file-date-time> = <STRING RESPONSE DATA> Last file modification date. <file-size> = <NR1 NUMERIC RESPONSE DATA> The file size in bytes.
<b>Example</b>	MME:INFO? "Internal/report.pdf" → "2015-05-29 16:02:20",9137
<b>Note</b>	

## 2.6.9 MMEMemory:CATalog?

<b>Syntax</b>	MMEMemory:CATalog? <directory>[,<pattern>]
<b>Description</b>	This command lists the files present in a directory.
<b>Parameters</b>	<directory> = <STRING PROGRAM DATA> The path to the directory to be listed. <pattern> = <STRING PROGRAM DATA> An optional case sensitive file name pattern. Wildcard characters are * and ?.
<b>Response</b>	({<item>} + {,}*) = <EXPRESSION RESPONSE DATA> A list of quoted file and directory names.
<b>Example</b>	MME:CAT? "Internal/reports" → ("report.pdf","setup.cfg")
<b>Note</b>	

## 2.6.10 MMEMemory:DCATalog?

<b>Syntax</b>	MMEMemory:DCATalog? <directory>
<b>Description</b>	This command lists the sub-directories present in a directory.
<b>Parameter</b>	<directory> = <STRING PROGRAM DATA> The path to the directory to be listed.
<b>Response</b>	({<directory>} + {,}*) = <EXPRESSION RESPONSE DATA> A list for quoted directory names.
<b>Example</b>	MME:DCAT? "Internal/" → ("diagnostics","favorites","logs","remote","screens","windowsinstaller")
<b>Note</b>	

## 2.6.11 MMEMemory:MDIRectory

<b>Syntax</b>	MMEMemory:MDIRectory <directory>
<b>Description</b>	This command makes a new sub-directory.
<b>Parameter</b>	<directory> = <STRING PROGRAM DATA> The path to the directory to be created.
<b>Response</b>	None.
<b>Example</b>	MME:MDIR "Internal/reports"
<b>Note</b>	

## 2.6.12 MMEMemory:RDIrectory

<b>Syntax</b>	MMEMemory:RDIrectory <directory>[,<force>]
<b>Description</b>	This command removes an existing directory.
<b>Parameter</b>	<directory> = <STRING PROGRAM DATA> The path to the directory to be created. <force> = <BOOLEAN PROGRAM DATA> If set to ON then ALL CONTENTS i.e. files and sub-directories will be deleted.
<b>Response</b>	None.
<b>Example</b>	MMEMemory:RDIR "Internal/reports"
<b>Note</b>	None.

## 2.6.13 MMEMemory:SAVE

<b>Syntax</b>	MMEMemory:SAVE <enable>
<b>Description</b>	This command enables or disables auto saving configuration when the application is terminated
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>Default = OFF</i>
<b>Response</b>	None.
<b>Example</b>	INST:STAR:LAST TP-BERT-OTN,1-PORT1 MMEMemory:SAVE ON INST? → 2 INST:TERM 2
<b>Note</b>	

<b>Syntax</b>	MMEMemory:SAVE?
<b>Description</b>	This query returns whether or not auto saving configuration enabled when the application is terminated .
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MMEMemory:SAVE? → 1
<b>Note</b>	

---

## Chapter 3

# No frame

### 3.1 Interface Setup

#### 3.1.1 NFRame:PORT<Pt>:INTerface:TYPE

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:TYPE <type>
<b>Description</b>	This command sets the interface type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF QSFP: QSFP optical interface (40 Gbps) CXP: CXP optical interface (100 Gbps) CFP: CFP optical interface (40/100 Gbps) CFP2: CFP2 optical interface (100 Gbps) QSFP28ADpt: CFP2-QSFP28 Adaptor interface (100 Gbps) <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:INT:TYPE QSFP
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:TYPE?
<b>Description</b>	This query returns the interface type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:INT:TYPE? → QSFP
<b>Note</b>	

#### 3.1.2 NFRame:PORT<Pt>:INTerface:BITRate

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:BITRate <bitrate>
<b>Description</b>	This command sets the interface bitrate.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> E100G: 100G Ethernet E40G: 40G Ethernet STM256: STM256/OC768 OTU4 OTU3 OTU3E1 OTU3E2 <i>DEFault = E100G</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:INT:BITR E100G
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:BITRate?
<b>Description</b>	This query returns the interface bitrate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:INT:BITR? → E100G
<b>Note</b>	

### 3.1.3 NFRame:PORT<Pt>:INTerface:LANE

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:LANE <type>
<b>Description</b>	This command sets the lane type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> LANE10: 10 Lane LANE20: 20 Lane LANE4 : 4 Lane <i>DEFault = LANE10</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:INT:LANE LANE10
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:INTerface:LANE?
<b>Description</b>	This query returns the lane type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:INT:LANE? → LANE10
<b>Note</b>	

### 3.1.4 NFRame:PORT<Pt>:TIMing

<b>Syntax</b>	NFRame:PORT<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal clock. EXTernal: External clock. <i>DEFault = INT</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TIM INT
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TIM? → INT
<b>Note</b>	

## 3.1.5 NFRame:PORT&lt;Pt&gt;[:RX]:INTerface:PATtern:FOLLow

<b>Syntax</b>	NFRame:PORT<Pt>[:RX]:INTerface:PATtern:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow transmitter setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> OFF: Do not follow ON: Follow the transmitter setup <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:INT:PATT:FOLL ON
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>[:RX]:INTerface:PATtern:FOLLow?
<b>Description</b>	This query returns if the receiver follow transmitter setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:INT:PATT:FOLL? → ON
<b>Note</b>	

## 3.1.6 NFRame:PORT&lt;Pt&gt;:TX:INTerface:PATtern

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> PRBS7 PRBS9 PRBS15 PRBS23 PRBS31 SWAVE: Square Wave <i>DEFault = PRBS7</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TX:INT:PATT PRBS31
<b>Note</b>	This command sets all lane when 4Lane is selected

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TX:INT:PATT? → PRBS31
<b>Note</b>	

## 3.1.7 NFRame:PORT&lt;Pt&gt;:RX:INTerface:PATtern

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> PRBS7 PRBS9 PRBS15 PRBS23 PRBS31 <i>DEFault = PRBS7</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:RX:INT:PATT PRBS31
<b>Note</b>	This command sets all lane when 4Lane is selected

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:RX:INT:PATT? → PRBS31
<b>Note</b>	

## 3.1.8 NFRame:PORT&lt;Pt&gt;:TX:INTerface:PINVersion

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TX:INT:PINV ON
<b>Note</b>	This command sets all lane when 4Lane is selected

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inversion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TX:INT:PINV? → 1
<b>Note</b>	

## 3.1.9 NFRame:PORT&lt;Pt&gt;:RX:INTerface:PINVersion

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:RX:INT:PINV ON
<b>Note</b>	This command sets all lane when 4Lane is selected

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inversion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:RX:INT:PINV? → 1
<b>Note</b>	

## 3.1.10 NFRame:PORT&lt;Pt&gt;:TX:INTerface:LANE&lt;Ln&gt;:PATtern

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PATtern <type>
<b>Description</b>	This command sets the pattern type(each lane).
<b>Parameters</b>	<Pt> = Port number <Ln> = Lane number (1-4) <type> = <CHARACTER PROGRAM DATA> PRBS7 PRBS9 PRBS15 PRBS23 PRBS31 <i>DEFault = PRBS7</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TX:INT:LANE2:PATT PRBS31
<b>Note</b>	This command can be used on 4Lane

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PATtern?
<b>Description</b>	This query returns the pattern type(each lane).
<b>Parameter</b>	<Pt> = Port number <Ln> = Lane number (1-4)
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TX:INT:LANE2:PATT? → PRBS31
<b>Note</b>	

## 3.1.11 NFRame:PORT&lt;Pt&gt;:RX:INTerface:LANE&lt;Ln&gt;:PATtern

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PATtern <type>
<b>Description</b>	This command sets the pattern type(each lane).
<b>Parameters</b>	<Pt> = Port number <Ln> = Lane number (1-4) <type> = <CHARACTER PROGRAM DATA> PRBS7 PRBS9 PRBS15 PRBS23 PRBS31 <i>DEFault = PRBS7</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:RX:INT:LANE2:PATT PRBS31
<b>Note</b>	This command can be used on 4Lane

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PATtern?
<b>Description</b>	This query returns the pattern type(each lane).
<b>Parameter</b>	<Pt> = Port number <Ln> = Lane number (1-4)
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:RX:INT:LANE2:PATT? → PRBS31
<b>Note</b>	

**3.1.12 NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PINVersion**

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion(each lane).
<b>Parameters</b>	<Pt> = Port number <Ln> = Lane number (1-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TX:INT:LANE2:PINV ON
<b>Note</b>	This command can be used on 4Lane

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:LANE<Ln>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern(each lane).
<b>Parameter</b>	<Pt> = Port number <Ln> = Lane number (1-4)
<b>Response</b>	<inversion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TX:INT:LANE2:PINV? → 1
<b>Note</b>	

**3.1.13 NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PINVersion**

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion(each lane).
<b>Parameters</b>	<Pt> = Port number <Ln> = Lane number (1-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:RX:INT:LANE2:PINV ON
<b>Note</b>	This command can be used on 4Lane

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:LANE<Ln>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern(each lane).
<b>Parameter</b>	<Pt> = Port number <Ln> = Lane number (1-4)
<b>Response</b>	<inversion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:RX:INT:LANE2:PINV? → 1
<b>Note</b>	

**3.1.14 NFRame:PORT<Pt>:TX:INTerface:PATtern:LANE:FOLLow**

<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PATtern:LANE:FOLLow <follow>
<b>Description</b>	This command sets the transmitter follow the pattern of lane2 to lane4 from lane1 or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> OFF: Do not follow ON: Follow the lane2 to lane4 from lane1 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:TX:INT:PATT:LANE:FOLL ON
<b>Note</b>	



<b>Syntax</b>	NFRame:PORT<Pt>:TX:INTerface:PATtern:LANE:FOLLow?
<b>Description</b>	This query returns if the transmitter follow pattern setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:TX:INT:PATT:LANE:FOLL? → ON
<b>Note</b>	

### 3.1.15 NFRame:PORT<Pt>:RX:INTerface:PATtern:LANE:FOLLow

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PATtern:LANE:FOLLow <follow>
<b>Description</b>	This command sets the receiver follow the pattern of lane2 to lane4 from lane1 or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> OFF: Do not follow ON: Follow the lane2 to lane4 from lane1 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:RX:INT:PATT:LANE:FOLL ON
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:RX:INTerface:PATtern:LANE:FOLLow?
<b>Description</b>	This query returns if the receiver follow pattern setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	NFR:PORT1:RX:INT:PATT:LANE:FOLL? → ON
<b>Note</b>	

## 3.2 Stimuli

### 3.2.1 NFRame:PORT<Pt>:STIMuli:TX:FOFFset

<b>Syntax</b>	NFRame:PORT<Pt>:STIMuli:TX:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-200.0, MAXimum=200.0, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:STIM:TX:FOFF 10.0
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:STIMuli:TX:FOFFset?
<b>Description</b>	This query returns the frequency offset (ppm) for the clock source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	NFR:PORT1:STIM:TX:FOFF? → 10.0
<b>Note</b>	

### 3.2.2 NFRame:PORT<Pt>:STIMuli:TX:LANE

<b>Syntax</b>	NFRame:PORT<Pt>:STIMuli:TX:LANE <lane>
<b>Description</b>	This command sets the bit error insertion lane.
<b>Parameters</b>	<Pt> = Port number <lane> = <NUMERIC PROGRAM DATA> 4 lane: <i>MINimum=#B0, MAXimum=#B1111, DEFault=#B0</i> 10 lane: <i>MINimum=#B0, MAXimum=#B1111111111, DEFault=#B0</i> 20 lane: <i>MINimum=#B0, MAXimum=#B11111111111111111111, DEFault=#B0</i>
<b>Response</b>	None.
<b>Example</b>	NFR:PORT1:STIM:TX:LANE #B101 This command add error into lane 0 and 2.
<b>Note</b>	

<b>Syntax</b>	NFRame:PORT<Pt>:STIMuli:TX:LANE?
<b>Description</b>	This query returns the bit error insertion lane.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	NFR:PORT1:STIM:TX:LANE? → #B1010 → #B1010000000 → #B10100000000000000000
<b>Note</b>	

## 3.3 Result

### 3.3.1 NFRame:PORT<Pt>[:RX]:IFETch?

<b>Syntax</b>	NFRame:PORT<Pt>[:RX]:IFETch? <parameter>
<b>Description</b>	This query fetches an NoFrame interval if available.
<b>Parameters</b>	<Pt> = Port number ({<parameter>} + {,}*) = <EXPRESSION PROGRAM DATA> The response format is listed for each parameter.  <b>Alarms</b> LOS: Loss of signal. Response: <Seconds>,<Ratio>  <b>Errors</b> LSSx: Loss of signal synchronization of lane x (x = 0-19). Response: <Seconds>,<Ratio> ERRPRBS: PRBS Error (total). Response: <Count>,<Ratio> ERRPRBSx: PRBS Error of lane x (x = 0-19). Response: <Count>,<Ratio>  <b>Rx Frequency</b> FREQDEV: Frequency deviation. Response: <ppm> FREQDEVx: Frequency deviation of lane x (x = 0-19). Response: <ppm>
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> Expression format: Numeric List Each result is formatted according to the specification in the parameter field. Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).
<b>Example</b>	NFR:PORT1:IFET? (LOS,LSS0) → (3,0.00532),(4,0.00709)
<b>Notes</b>	This command fetches the results from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2). If the requested result is not available, NaN (section 1.6.1) is returned. If there is one or more results, the last ",," is always removed.

## 3.4 Status

### 3.4.1 NFRame:STATus:PORT<Pt>[:RX]:AESummary[:EVENT]?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:AESummary[:EVENT]?
<b>Description</b>	This query returns the NoFrame alarms and errors summary event register. The content of this event register is summarized in DB9 of the STATus:INterface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:AES? → 1
<b>Note</b>	

### 3.4.2 NFRame:STATus:PORT<Pt>[:RX]:AESummary:CONDition?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:AESummary:CONDition?
<b>Description</b>	This query returns the NoFrame alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:AES:COND? → 2
<b>Note</b>	

### 3.4.3 NFRame:STATus:PORT<Pt>[:RX]:ALARm[:EVENT]?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the NFRame:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = LOS, Loss of signal DB2 (2) = LSS, Loss of signal synchronization DB3 (4) = CDRL, CDR Lock status DB4 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:ALAR? → 2
<b>Notes</b>	

### 3.4.4 NFRame:STATus:PORT<Pt>[:RX]:ALARm:CONDition?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = LOS, Loss of signal DB2 (2) = LSS, Loss of signal synchronization DB3 (4) = CDRL, CDR Lock status DB4 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:ALAR:COND? → 4
<b>Notes</b>	

## 3.4.5 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:ERRor[:EVENT]?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:ERRor[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the NFRame:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = PRBS Error DB2 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:ERR? → 1
<b>Notes</b>	

## 3.4.6 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:ERRor:CONDition?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:ERRor:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = PRBS Error DB2 - DB16 = NOT USED
<b>Example</b>	NFR:STAT:PORT1:ERR:COND? → 1
<b>Notes</b>	

## 3.4.7 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:PSLevel?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> " <power> dBm": Min: " < <min> dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	NFR:STAT:PORT1:PSL? → "-3 dBm"
<b>Note</b>	

## 3.4.8 NFRame:STATus:PORT&lt;Pt&gt;:TX:PSLevel?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>:TX:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> " <power> dBm": Min: " < <min> dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	NFR:STAT:PORT1:TX:PSL? → "-3 dBm"
<b>Note</b>	

## 3.4.9 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:PFRequency?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:PFRequency? [<lane>]
<b>Description</b>	This query returns the physical frequency. Unit: Hz.
<b>Parameters</b>	<Pt> = Port number <lane> = Lane number (0-9)
<b>Response</b>	<frequency> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	NFR:STAT:PORT1:PFR? → 103125000192 <sup>1</sup> NFR:STAT:PORT1:PFR? 0 → 5250845696
<b>Note</b>	<sup>1</sup> <lane> is not used if the Lane Select is 20 Lane.

## 3.4.10 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:PDEViation?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:PDEViation? [<lane>]
<b>Description</b>	This query returns the physical frequency deviation. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <lane> = Lane number (0-9)
<b>Response</b>	<deviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	NFR:STAT:PORT1:PDEV? → 0.0 <sup>1</sup> NFR:STAT:PORT1:PDEV? 0 → 0.0
<b>Note</b>	<sup>1</sup> <lane> is not used if the Lane Select is 20 Lane.

## 3.4.11 NFRame:STATus:PORT&lt;Pt&gt;[:RX]:PCDRlock?

<b>Syntax</b>	NFRame:STATus:PORT<Pt>[:RX]:PCDRlock? [<lane>]
<b>Description</b>	This query returns the physical CDR lock status.
<b>Parameters</b>	<Pt> = Port number <lane> = Lane number (0-9)
<b>Response</b>	<status> = <BOOLEAN RESPONSE DATA> 0: CDR Locked 1: CDR Unlocked
<b>Example</b>	NFR:STAT:PORT1:PCDR? → 0 <sup>1</sup> NFR:STAT:PORT1:PCDR? 0 → 0
<b>Note</b>	<sup>1</sup> <lane> is not used if the Lane Select is 20 Lane.



---

## Chapter 4

# CPRI

### 4.1 Port

#### 4.1.1 CPRI:PORT<Pt>:MODE

<b>Syntax</b>	CPRI:PORT<Pt>:MODE <mode>
<b>Description</b>	This command sets the port mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Port off NORMal: Normal THRough: (1 Port / 2 Port) Pass Through Mode <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:MODE NORM
<b>Note</b>	This command is disabled when over OTN is selected.

<b>Syntax</b>	CPRI:PORT<Pt>:MODE?
<b>Description</b>	This query returns the port mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:MODE? → NORM
<b>Note</b>	This command is disabled when over OTN is selected.

#### 4.1.2 CPRI:PORT<Pt>:TIMing:SOURce

<b>Syntax</b>	CPRI:PORT<Pt>:TIMing:SOURce <source>
<b>Description</b>	This command sets Timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal clock EXTernal: External clock GPS: GPS signal RX: Received clock <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:TIM:SOUR INT
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:TIMing:SOURce?
<b>Description</b>	This query returns the timing source
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:TIM:SOUR? → INT
<b>Note</b>	

## 4.1.3 CPRI:PORT&lt;Pt&gt;:LRATe

<b>Syntax</b>	CPRI:PORT<Pt>:LRATe <rate>
<b>Description</b>	This command set Line Rate.
<b>Parameters</b>	<Pt> = Port number <rate> = <CHARACTER PROGRAM DATA> 614M: 641.4Mbps(CPRI) 768M: 768.0Mbps(OBSAI) 1228M: 1228.8Mbps(CPRI) 1536M: 1536.0Mbps(OBSAI) 2457M: 2457.6Mbps(CPRI) 3072M: 3072.0Mbps(CPRI/OBSAI) 4915M: 4915.2Mbps(CPRI) 6144M: 6144.0Mbps(CPRI/OBSAI) 9830M: 9830.4Mbps(CPRI) 10137M: 10137.6Mbps(CPRI) <i>DEFault = 614M</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:LRAT 614M
<b>Note</b>	This command is disabled when over OTN is selected. When selecting 768M or 4915M, the contents of signal becomes unframed.

<b>Syntax</b>	CPRI:PORT<Pt>:LRATe?
<b>Description</b>	This query returns Line rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:LRAT? → 614M
<b>Note</b>	This command is disabled when over OTN is selected.

## 4.1.4 CPRI:PORT&lt;Pt&gt;:CONTents

<b>Syntax</b>	CPRI:PORT<Pt>:CONTents <contents>
<b>Description</b>	This command sets contents.
<b>Parameter</b>	<Pt> = Port number <contents> = <CHARACTER PROGRAM DATA> UFRamed: Unframed LINK: CPRI Link
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:CONT UFR
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:CONTents?
<b>Description</b>	This query returns contents.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<contents> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:CONT? → UFR
<b>Note</b>	



## 4.1.5 CPRI:PORT&lt;Pt&gt;:PATTern

<b>Syntax</b>	CPRI:PORT<Pt>:PATTern <type>
<b>Description</b>	This command sets Pattern type.
<b>Parameter</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> PRBS15: PRBS15 pattern PRBS20: PRBS20 pattern PRBS23: PRBS23 pattern PRBS31: PRBS31 pattern USER32BIT: User Pattern (32bit) OFF: Pattern OFF
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:PATT PRBS15
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:PATTern?
<b>Description</b>	This query returns pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:PATT? → PRBS15
<b>Note</b>	

## 4.1.6 CPRI:PORT&lt;Pt&gt;:PINVersion

<b>Syntax</b>	CPRI:PORT<Pt>:PINVersion <inversion>
<b>Description</b>	This command sets Inversion.
<b>Parameter</b>	<Pt> = Port number <inversion> = <CHARACTER PROGRAM DATA> NORMal: Invert Off INVerted: Invert On
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:PINV NORM
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:PINVersion?
<b>Description</b>	This query returns inversion or normal
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inversion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:PINV? → NORM
<b>Note</b>	

## 4.1.7 CPRI:PORT&lt;Pt&gt;:UP32

<b>Syntax</b>	CPRI:PORT<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when CONTENT is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:UP32 "0110"
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:UP32? → "0110"
<b>Note</b>	

#### 4.1.8 CPRI:PORT<Pt>:PVERsion

<b>Syntax</b>	CPRI:PORT<Pt>:PVERsion <version>
<b>Description</b>	This command sets protocol version.
<b>Parameter</b>	<Pt> = Port number <version> = <CHARACTER PROGRAM DATA> PVER1: Protocol version 1 (= Scrambling OFF) PVER2: Protocol version 2 (= Scrambling ON)
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:PVER PVER1
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:PVERsion?
<b>Description</b>	This query returns protocol version.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<version> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:PVER? → PVER1
<b>Note</b>	

#### 4.1.9 CPRI:PORT<Pt>:PROLe

<b>Syntax</b>	CPRI:PORT<Pt>:PROLe <role>
<b>Description</b>	This command sets port role.
<b>Parameter</b>	<Pt> = Port number <role> = <CHARACTER PROGRAM DATA> MASTer: Master SLAVe: Slave
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:PROL MAST
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:PROLe?
<b>Description</b>	This query returns port role.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<role> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:PROL? → MAST
<b>Note</b>	

#### 4.1.10 CPRI:PORT<Pt>:SSEQence

<b>Syntax</b>	CPRI:PORT<Pt>:SSEQence <sequence>
<b>Description</b>	This command enables/disables start-up sequence.
<b>Parameter</b>	<Pt> = Port number <sequence> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:SSEQ OFF
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:SSEQence?
<b>Description</b>	This query returns enables/disables start-up sequence.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:SSEQ? → 0
<b>Note</b>	

#### 4.1.11 CPRI:PORT<Pt>:CMHDlc

<b>Syntax</b>	CPRI:PORT<Pt>:CMHDlc <hdlc>
<b>Description</b>	This command sets CM HDLC.
<b>Parameter</b>	<Pt> = Port number <hdlc> = <CHARACTER PROGRAM DATA> NONE: NONE 240K: 240k 480K: 480k 960K: 960k 1920K: 1920k 2400K: 2400k HIGH: Highest Possible
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:CMHD NONE
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:CMHDlc?
<b>Description</b>	This query returns CM HDLC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<hdlc> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:CMHD? → NONE
<b>Note</b>	

#### 4.1.12 CPRI:PORT<Pt>:EENable

<b>Syntax</b>	CPRI:PORT<Pt>:EENable <enable>
<b>Description</b>	This command sets Ethernet Enable.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:EEN OFF
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:EENable?
<b>Description</b>	This query returns Ethernet enables/disables.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:EEN? → 0
<b>Note</b>	

## 4.1.13 CPRI:PORT&lt;Pt&gt;:CMEPointer

<b>Syntax</b>	CPRI:PORT<Pt>:CMEPointer <pointer>
<b>Description</b>	This command sets the control manager ethernet pointer.
<b>Parameters</b>	<Pt> = Port number <pointer> = <NUMERIC PROGRAM DATA> <i>MINimum=20, MAXimum=63, DEFault=20</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:CMEP 63
<b>Note</b>	This command cannot be executed when Ethernet is disabled.

<b>Syntax</b>	CPRI:PORT<Pt>:CMEPointer?
<b>Description</b>	This query returns the control manager ethernet pointer.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pointer> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:CMEP? → 20
<b>Note</b>	

## 4.1.14 CPRI:PORT&lt;Pt&gt;:SETup:FOLLow

<b>Syntax</b>	CPRI:PORT<Pt>:SETup:FOLLow <follow>
<b>Description</b>	This command enables/disables that port2 follows port1.
<b>Parameter</b>	<Pt> = Port number <follow> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT2:SET:FOLL OFF
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:SETup:FOLLow?
<b>Description</b>	This query returns enables/disables that port2 follows port1.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:SET:FOLL? → OFF
<b>Note</b>	

## 4.2 Stimuli

### 4.2.1 CPRI:PORT<Pt>:STIMuli:ALARm

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:ALARm <alarm>
<b>Description</b>	This command sets stimuli alarm.
<b>Parameter</b>	<Pt> = Port number <alarm> = <CHARACTER PROGRAM DATA> SLOS: Optical Loss of signal LOS: Loss of Signal LOF: Loss of Frame LSS: Loss of signal synchronization RLOS: Remote LOS RLOF: Remote LOF RAI: L1-RAI (Remote Alarm Indication) SDI: L1-SDI (SAP Defect Indication) RESet: L1-Reset (Master:Reset confirmation; Slave:Reset Request)
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:ALAR LOF
<b>Note</b>	When :CONTents is UNFramed only SLOS and LSS is valid.

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:ALARm?
<b>Description</b>	This query returns stimuli alarm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:ALAR? → LOS
<b>Note</b>	

### 4.2.2 CPRI:PORT<Pt>:STIMuli:AINSertion

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:AINSertion <insertion>
<b>Description</b>	This command set Alarm insertion.
<b>Parameter</b>	<Pt> = Port number <insertion> = <CHARACTER RESPONSE DATA> OFF: Off PERManent: Permanent <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:AINS OFF
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:AINSertion?
<b>Description</b>	This query returns Alarm insertion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:AINS? → OFF
<b>Note</b>	

## 4.2.3 CPRI:PORT&lt;Pt&gt;:STIMuli:ERRor

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:ERRor <error>
<b>Description</b>	This command sets stimuli Error.
<b>Parameter</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> LCV: LCV SHV: SHV K307: K30.7 PE: Pattern Error
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:ERR NONE
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:ERRor?
<b>Description</b>	This query returns stimuli alarm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:ERR? → LCV
<b>Note</b>	

## 4.2.4 CPRI:PORT&lt;Pt&gt;:STIMuli:EINsertion

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:EINsertion <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 B08: Burst · 1E-08 B09: Burst · 1E-09 B10: Burst · 1E-10 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:EINS OFF
<b>Note</b>	None.

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:EINsertion?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:EINS? → B04
<b>Note</b>	

## 4.2.5 CPRI:PORT&lt;Pt&gt;:STIMuli:EBLength

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:EBLength <length>
<b>Description</b>	This command sets Error Burst Length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=256, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:EBL 64
<b>Note</b>	This command is enabled when error insertion is Manual.

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:EBLength?
<b>Description</b>	This query returns Error Burst Length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:EBL → 64
<b>Note</b>	

#### 4.2.6 CPRI:PORT<Pt>:STIMuli:FOFFset

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-100, MAXimum=100, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:STIM:FOFF 0
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:STIMuli:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STIM:FOFF → 0
<b>Note</b>	

## 4.3 Result

### 4.3.1 CPRI:PORT<Pt>:IFETch?

<b>Syntax</b>	CPRI:PORT<Pt>:IFETch? <parameter>
<b>Description</b>	This query fetches a CPRI interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{&lt;parameter&gt;} + {,}* = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>SLOS: Optical loss of signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOS: Loss of signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOF: Loss of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LSS: Loss of signal synchronization. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>L1Remote Alarm</b></p> <p>RLOS: Remote loss. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RLOF: Remote loss of frame. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RRAI: Remote alarm indication. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RSDI: Remote SAP defect indication. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RES: Reset. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>LCV: LCV. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>SHV: SHV. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>K307: K30.7. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PE: Pattern error. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Frame</b></p> <p>TXHF: TX hyper frames. Response: &lt;Count&gt;</p> <p>TXCW: TX code words. Response: &lt;Count&gt;</p> <p>RXHF: RX hyper frames. Response: &lt;Count&gt;</p> <p>RXCW: RX code words. Response: &lt;Count&gt;</p> <p><b>Delay</b></p> <p>DEL: Delay. Response: &lt;second&gt;</p> <p>AVED: Average Delay. Response: &lt;Count&gt;</p> <p>MIND: Maximum Delay. Response: &lt;Count&gt;</p> <p>MAXD: Minimum Delay. Response: &lt;Count&gt;</p> <p>DMC: Measurement Count. Response: &lt;Count&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	CPRI:PORT1:IFET? (LOS,LOF) → (3,0.00532),(4,0.00709)
<b>Notes</b>	<p>This command fetches the results from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2).</p> <p>If the requested result is not available, NaN (section 1.6.1) is returned.</p> <p>If there is one or more results, the last ",," is always removed.</p>



## 4.4 Status

### 4.4.1 CPRI:PORT<Pt>:STATUS:AESummary[:EVENT]?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:AESummary[:EVENT]?
<b>Description</b>	This query returns the alarms and errors summary event register. The content of this event register is summarized in DB13 of the STATUS:INTERface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> sb1 (1) = CPRI Alarm sb2 (2) = CPRI Remote Alarm sb3 (4) = CPRI Error sb4 - sb16 = NOT USED
<b>Example</b>	CPRI:PORT1:STAT:AES? → 3
<b>Note</b>	

### 4.4.2 CPRI:PORT<Pt>:STATUS:AESummary:CONDition?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as CPRI:PORT<Pt>:STATUS:AESummary[:EVENT]?
<b>Example</b>	CPRI:PORT1:STAT:AES:COND? → 3
<b>Note</b>	

### 4.4.3 CPRI:PORT<Pt>:STATUS:ALARm<section>[:EVENT]?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns one of the alarms event register.
<b>Parameters</b>	<Pt> = Port number <section> = CPRI Alarm(1), CPRI L1Remote Alarm(2)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: sb1 (1) = Signal Loss sb2 (2) = LOS sb3 (4) = LOF sb4 (8) = LSS sb5 - sb16 = NOT USED  <section> = 2: sb1 (1) = Remote LOS sb2 (2) = Remote LOF sb3 (4) = RAI sb4 (8) = SDI sb5 (16) = Reset sb6 - sb16 = NOT USED
<b>Example</b>	CPRI:PORT1:STAT:ALAR1? → 1
<b>Note</b>	

## 4.4.4 CPRI:PORT&lt;Pt&gt;:STATUS:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:ALARm<section>:CONDition?
<b>Description</b>	This query returns one of the alarms condition registers.
<b>Parameters</b>	<Pt> = Port number <section> = CPRI Alarm(1), CPRI L1Remote Alarm(2)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as CPRI:PORT<Pt>:STATUS:ALARm<section>[:EVENTt]?
<b>Example</b>	CPRI:PORT1:STAT:ALAR1:COND? → 1
<b>Note</b>	

## 4.4.5 CPRI:PORT&lt;Pt&gt;:STATUS:ERRor[:EVENTt]?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:ERRor[:EVENTt]?
<b>Description</b>	This query returns the errors event register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> sb1 (1) = LCV sb2 (2) = SHV sb3 (4) = K30.7 sb4 (8) = Pattern error sb5 - sb16 = NOT USED
<b>Example</b>	CPRI:PORT1:STAT:ERR? → 3
<b>Note</b>	

## 4.4.6 CPRI:PORT&lt;Pt&gt;:STATUS:ERRor:CONDition?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:ERRor:CONDition?
<b>Description</b>	This query returns errors condition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as CPRI:PORT<Pt>:STATUS:ERRor[:EVENTt]?
<b>Example</b>	CPRI:PORT1:STAT:ERR:COND? → 3
<b>Note</b>	

## 4.4.7 CPRI:PORT&lt;Pt&gt;:STATUS:TX:PSLevel?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:TX:PSLevel?
<b>Description</b>	This query returns the TX signal level. Unit: dBm.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<signal-level> = <STRING RESPONSE DATA> " <signal-level> dBm": Min: "< <min> dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	CPRI:PORT1:STAT:TX:PSL? → "-3dBm"
<b>Note</b>	

## 4.4.8 CPRI:PORT&lt;Pt&gt;:STATUS:RX:PSLevel?

<b>Syntax</b>	CPRI:PORT<Pt>:STATUS:RX:PSLevel?
<b>Description</b>	This query returns the RX signal level. Unit: dBm.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<signal-level> = <STRING RESPONSE DATA> " <signal-level> dBm": Min: "< <min> dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	CPRI:PORT1:STAT:RX:PSL? → "-3dBm"
<b>Note</b>	

## 4.4.9 CPRI:PORT&lt;Pt&gt;:STATus:TX:PDEVIation?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:PDEVIation? [<unit>]
<b>Description</b>	This query returns TX deviation.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million BPS = Bits per second
<b>Response</b>	<pdeviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:PDEV? PPM → -3
<b>Note</b>	

## 4.4.10 CPRI:PORT&lt;Pt&gt;:STATus:RX:PDEVIation?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:PDEVIation? [<unit>]
<b>Description</b>	This query returns RX deviation.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million BPS = Bits per second
<b>Response</b>	<pdeviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:PDEV? PPM → 10
<b>Note</b>	

## 4.4.11 CPRI:PORT&lt;Pt&gt;:STATus:TX:PBRate?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:PBRate?
<b>Description</b>	This query returns the bit rate on TX.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pbrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:PBR? → 614400000
<b>Note</b>	

## 4.4.12 CPRI:PORT&lt;Pt&gt;:STATus:RX:PBRate?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:PBRate?
<b>Description</b>	This query returns the bit rate on RX.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pbrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:PBR? → 614400000
<b>Note</b>	

## 4.4.13 CPRI:PORT&lt;Pt&gt;:STATus:TX:PPBRate?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:PPBRate?
<b>Description</b>	This query returns the pattern bit rate on TX.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<ppbrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:PPBR? → 614400000
<b>Note</b>	

## 4.4.14 CPRI:PORT&lt;Pt&gt;:STATus:RX:PPBRate?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:PPBRate?
<b>Description</b>	This query returns the pattern bit rate on RX.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<ppbrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:PPBR? → 614400000
<b>Note</b>	

## 4.4.15 CPRI:PORT&lt;Pt&gt;:STATus:LINK:STATe?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:LINK:STATe?
<b>Description</b>	This query returns the CPRI link State.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:LINK:STAT? → "Standby"
<b>Note</b>	

## 4.4.16 CPRI:PORT&lt;Pt&gt;:STATus:LINK:PROLe?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:LINK:PROLe?
<b>Description</b>	This query returns the port role of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<role> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:LINK:PROL? → "Master"
<b>Note</b>	

## 4.4.17 CPRI:PORT&lt;Pt&gt;:STATus:RX:LINK:PVERsion?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:LINK:PVERsion?
<b>Description</b>	This query returns the protocol version of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<version> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:LINK:PVER? → "Version 1"
<b>Note</b>	

## 4.4.18 CPRI:PORT&lt;Pt&gt;:STATus:RX:LINK:HRATe?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:LINK:HRATe?
<b>Description</b>	This query returns the HDLC Rate of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:LINK:HRAT? → "2400 kbit/s HDLC"
<b>Note</b>	

## 4.4.19 CPRI:PORT&lt;Pt&gt;:STATus:RX:LINK:POINterp?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:RX:LINK:POINterp?
<b>Description</b>	This query returns the ethernet pointer of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pointer> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:RX:LINK:POIN? → 20
<b>Note</b>	

## 4.4.20 CPRI:PORT&lt;Pt&gt;:STATus:TX:LINK:PVERsion?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:LINK:PVERsion?
<b>Description</b>	This query returns the protocol version of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<version> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:LINK:PVER? → "Version 1"
<b>Note</b>	

## 4.4.21 CPRI:PORT&lt;Pt&gt;:STATus:TX:LINK:HRATe?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:LINK:HRATe?
<b>Description</b>	This query returns the HDLC Rate of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER PROGRAM DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:LINK:HRAT? → "2400 kbit/s HDLC"
<b>Note</b>	

## 4.4.22 CPRI:PORT&lt;Pt&gt;:STATus:TX:LINK:POINterp?

<b>Syntax</b>	CPRI:PORT<Pt>:STATus:TX:LINK:POINterp?
<b>Description</b>	This query returns the ethernet pointer of CPRI link.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pointer> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:STAT:TX:LINK:POIN? → 20
<b>Note</b>	

## 4.5 RTD

### 4.5.1 CPRI:PORT<Pt>:RTD:ENABle

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:ENABle <enable>
<b>Description</b>	This command enables/disables Thresholds.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:RTD:ENAB ON
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:ENABle?
<b>Description</b>	This query returns enables/disables Thresholds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:RTD:ENAB? → OFF
<b>Note</b>	

### 4.5.2 CPRI:PORT<Pt>:RTD:MLIMit

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:MLIMit <limit>
<b>Description</b>	This command sets the Threshold of maximum limit. Unit: us.
<b>Parameters</b>	<Pt> = Port number <limit> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1,000,000, DEFault=1,000,000</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:RTD:MLIM 1000000.00
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:MLIMit?
<b>Description</b>	This query returns the Threshold of maximum limit. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<limit> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:RTD:MLIM? → 1000000.00
<b>Note</b>	

### 4.5.3 CPRI:PORT<Pt>:RTD:NUMBer?

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:NUMBer?
<b>Description</b>	This query returns the number of the RTD data.?
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:RTD:NUMB? → 1
<b>Note</b>	

### 4.5.4 CPRI:PORT<Pt>:RTD:ATIMe?

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:ATIMe?
<b>Description</b>	This query returns the Average delay. Unit:us.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<delay> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:RTD:ATIM? → 1.46
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

#### 4.5.5 CPRI:PORT<Pt>:RTD:MTIME?

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:MTIME?
<b>Description</b>	This query returns the maximum delay. Unit:us.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<delay> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	CPRI:PORT1:RTD:MTIM? → 1.46
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

#### 4.5.6 CPRI:PORT<Pt>:RTD:LTIME?

<b>Syntax</b>	CPRI:PORT<Pt>:RTD:LTIME?
<b>Description</b>	This query returns the minimum delay. Unit:us.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<delay> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:RTD:LTIM? → 1.46
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

## 4.6 APS

### 4.6.1 CPRI:PORT<Pt>:APS:ENABLE

<b>Syntax</b>	CPRI:PORT<Pt>:APS:ENABLE <enable>
<b>Description</b>	This command enables/disables APS measurement.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:APS:ENAB ON
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:APS:ENABLE?
<b>Description</b>	This query returns enables/disables Thresholds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:ENAB? → OFF
<b>Note</b>	

### 4.6.2 CPRI:PORT<Pt>:APS:EVENT

<b>Syntax</b>	CPRI:PORT<Pt>:APS:EVENT <events>
<b>Description</b>	This command sets the time reference event.
<b>Parameters</b>	<Pt> = Port number ({<events>} * {,}*) = <EXPRESSION PROGRAM DATA> SLOS : Signal loss LOS : LOS LOF : LOF LCV : LCV SHV : SHV PE : Pattern error RLOS : Remote LOS RLOF : Remote LOF RAI : RAI SDI : SDI RESet : Reset
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:APS:EVENT (LOS,LOF)
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:APS:EVENT?
<b>Description</b>	This query returns the time reference event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<events>),}* = <EXPRESSION RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:EVENT? → (LOS,LOF)
<b>Note</b>	



### 4.6.3 CPRI:PORT<Pt>:APS:PERiod

<b>Syntax</b>	CPRI:PORT<Pt>:APS:PERiod <period>
<b>Description</b>	This command sets the error free period.
<b>Parameters</b>	<Pt> = Port number <period> = <NUMERIC PROGRAM DATA> 1,10,20,30,40,50,60,70,80,90,100 Unit ms <i>DEFault = 100</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:APS:PER 10
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:APS:PERiod?
<b>Description</b>	This query returns the error free period.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<period> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:PER? → 10
<b>Note</b>	

### 4.6.4 CPRI:PORT<Pt>:APS:MLIMit

<b>Syntax</b>	CPRI:PORT<Pt>:APS:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 1000.000, DEFault = 50.000</i>
<b>Response</b>	None.
<b>Example</b>	CPRI:PORT1:APS:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	CPRI:PORT<Pt>:APS:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:MLIM? → 50.000
<b>Note</b>	

### 4.6.5 CPRI:PORT<Pt>:APS:NUMBER?

<b>Syntax</b>	CPRI:PORT<Pt>:APS:NUMBER?
<b>Description</b>	This query returns the number of times an APS Protocol event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:NUMB? → 17
<b>Note</b>	

### 4.6.6 CPRI:PORT<Pt>:APS:ATIME?

<b>Syntax</b>	CPRI:PORT<Pt>:APS:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 1000 ms. The maximum measurable time will be responded if the result exceeds 1000 ms.

## 4.6.7 CPRI:PORT&lt;Pt&gt;:APS:MTIME?

<b>Syntax</b>	CPRI:PORT<Pt>:APS:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	CPRI:PORT1:APS:MTIM? → 4.000,0
<b>Note</b>	The maximum measurable time is 1000 ms. The maximum measurable time will be responded if the result exceeds 1000 ms.

## 4.6.8 CPRI:PORT&lt;Pt&gt;:APS:LTIME?

<b>Syntax</b>	CPRI:PORT<Pt>:APS:LTIME?
<b>Description</b>	This query returns the least (minimum) time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:LTIM? → 4.000
<b>Note</b>	The maximum measurable time is 1000 ms. The maximum measurable time will be responded if the result exceeds 1000 ms.

## 4.6.9 CPRI:PORT&lt;Pt&gt;:APS:CTIME?

<b>Syntax</b>	CPRI:PORT<Pt>:APS:CTIME?
<b>Description</b>	This query returns the current time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<current> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	CPRI:PORT1:APS:CTIM? → 4.000
<b>Note</b>	The maximum measurable time is 1000 ms. The maximum measurable time will be responded if the result exceeds 9999.999 ms.

---

# Chapter 5

## 2 Mbps

### 5.1 Receiver

#### 5.1.1 TMBPs:RX<Pt>[:ENABled]

<b>Syntax</b>	TMBPs:RX<Pt>[:ENABled] <interface>
<b>Description</b>	This command enables or disables the 2 Mbps receiver.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1 ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the 2 Mbps receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1? → ON TMBP:RX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E1 is over SDH or SONET.

#### 5.1.2 TMBPs:RX<Pt>:FOLLow

<b>Syntax</b>	TMBPs:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX: Transmitter of the same port RX1: Receiver of port 1 <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:FOLL TX (i.e., RX1 follows TX1) TMBP:RX2:FOLL RX1 (i.e., RX2 follows RX1)
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:FOLLow?
<b>Description</b>	This query returns if the receiver follow another setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:FOLL? → TX
<b>Note</b>	

## 5.1.3 TMBPs:RX&lt;Pt&gt;:CONNector

<b>Syntax</b>	TMBPs:RX<Pt>:CONNector <type>
<b>Description</b>	This command sets the physical type of connector.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> BALanced: Using balanced connector UNBalanced: Using unbalanced connector <i>DEFault = UNBalanced</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:CONN BAL
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:CONNector?
<b>Description</b>	This query returns the physical type of connector.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:CONN? → BAL
<b>Note</b>	

## 5.1.4 TMBPs:RX&lt;Pt&gt;:MODE

<b>Syntax</b>	TMBPs:RX<Pt>:MODE <mode>
<b>Description</b>	This command sets the signal termination mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> TERMinate: Nominal impedance. Normal frequency dependent AGC. BRIDged: High impedance. MONitor: Nominal impedance. Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:MODE TERM
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:MODE?
<b>Description</b>	This query returns the signal termination mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:MODE? → TERM
<b>Note</b>	

## 5.1.5 TMBPs:RX&lt;Pt&gt;:SENSitivity

<b>Syntax</b>	TMBPs:RX<Pt>:SENSitivity <sens>
<b>Description</b>	This command sets the input sensitivity.
<b>Parameters</b>	<Pt> = Port number <sens> = <CHARACTER PROGRAM DATA> FULL M20DB: Input sensitivity -20 dB M33DB: Input sensitivity -33 dB <i>DEFault = FULL</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:SENS FULL
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:SENSitivity?
<b>Description</b>	This query returns the input sensitivity
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<sens> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:SENS? → FULL
<b>Note</b>	

### 5.1.6 TMBPs:RX<Pt>:CODE

<b>Syntax</b>	TMBPs:RX<Pt>:CODE <code>
<b>Description</b>	This command sets the line code type.
<b>Parameters</b>	<Pt> = Port number <code> = <CHARACTER PROGRAM DATA> AMI HDB3 <i>DEFault = HDB3</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:CODE AMI
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:CODE?
<b>Description</b>	This query returns the line code type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<code> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:CODE? → AMI
<b>Note</b>	

### 5.1.7 TMBPs:RX<Pt>:PCMFrame

<b>Syntax</b>	TMBPs:RX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:PCMF? → 1
<b>Note</b>	

### 5.1.8 TMBPs:RX<Pt>:CRC4

<b>Syntax</b>	TMBPs:RX<Pt>:CRC4 <enable>
<b>Description</b>	This command enables or disables the CRC4 bits.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:CRC4 ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:CRC4?
<b>Description</b>	This query returns the state (enabled/disabled) of the CRC4 bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:CRC4? → 1
<b>Note</b>	

### 5.1.9 TMBPs:RX<Pt>:EBITs

<b>Syntax</b>	TMBPs:RX<Pt>:EBITs <enable>
<b>Description</b>	This command enables or disables the E-bits.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:EBIT ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:EBITs?
<b>Description</b>	This query returns the state (enabled/disabled) of the E-bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:EBIT? → 1
<b>Note</b>	

### 5.1.10 TMBPs:RX<Pt>:PATtern

<b>Syntax</b>	TMBPs:RX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS6 PRBS7 PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 QRSS11 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS11</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:PATT? → PRBS11
<b>Note</b>	

### 5.1.11 TMBPs:RX<Pt>:PINVersion

<b>Syntax</b>	TMBPs:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, QRSSxx, ALT11, ALT13, ALT17, ALT324, USER32BIT and USER2048BIT.

<b>Syntax</b>	TMBPs:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:PINV? → 1
<b>Note</b>	

### 5.1.12 TMBPs:RX<Pt>:PTSLots

<b>Syntax</b>	TMBPs:RX<Pt>:PTSLots <slots>
<b>Description</b>	This command sets the pattern time slots.
<b>Parameters</b>	<Pt> = Port number <slots> = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of slot number(s) ranging from 1 to 31
<b>Response</b>	None.
<b>Examples</b>	TMBP:RX1:PTSL (1,3,5)
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:PTSLots?
<b>Description</b>	This query returns the pattern time slots.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<slots> = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	TMBP:RX1:PTSL? → (1,3,5)
<b>Note</b>	

## 5.1.13 TMBPs:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	TMBPs:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 5.1.14 TMBPs:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	TMBPs:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	TMBP:RX2:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	TMBP:RX2:UP32? → "01101"
<b>Note</b>	

## 5.1.15 TMBPs:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	TMBPs:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when TMBP:RX2:PATT is USER2048BIT

<b>Syntax</b>	TMBPs:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	None.
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	TMBP:RX1:UP2K? → "12DF"
<b>Note</b>	



## 5.1.16 TMBPs:RX&lt;Pt&gt;:AUDio

<b>Syntax</b>	TMBPs:RX<Pt>:AUDio <type>
<b>Description</b>	This command sets the audio decoding.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:AUD ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:AUDio?
<b>Description</b>	This query returns the audio decoding.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:RX1:AUD? → ON
<b>Note</b>	

## 5.1.17 TMBPs:RX&lt;Pt&gt;:ATSLot

<b>Syntax</b>	TMBPs:RX<Pt>:ATSLot <timeslotno>
<b>Description</b>	This command sets the audio timeslot to be monitored.
<b>Parameters</b>	<Pt> = Port number <timeslotno> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=31</i> <i>DEFault=2</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:ATSL 4
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:ATSLot?
<b>Description</b>	This query returns the monitored audio timeslot.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslotno> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:ATSL? → 4
<b>Note</b>	

## 5.1.18 TMBPs:RX&lt;Pt&gt;:CAS

<b>Syntax</b>	TMBPs:RX<Pt>:CAS <enable>
<b>Description</b>	This command enables or disables the channel associated signaling.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:RX1:CAS ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:RX<Pt>:CAS?
<b>Description</b>	This query returns the state (enabled/disabled) of the channel associated signaling.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RX1:CAS? → 1
<b>Note</b>	

## 5.2 Transmitter

### 5.2.1 TMBPs:TX<Pt>[:ENABled]

<b>Syntax</b>	TMBPs:TX<Pt>[:ENABled] <interface>
<b>Description</b>	This command enables or disables the 2 Mbps transmitter.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	TMBP:TX1 ON TMBP:TX1:ENAB ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the 2 Mbps transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	TMBP:TX1? → ON TMBP:TX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E1 is over SDH or SONET.

### 5.2.2 TMBPs:TX<Pt>:FOLLow

<b>Syntax</b>	TMBPs:TX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the transmitter setting to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX1: Follow the setting of the port 1 transmitter <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX2:FOLL TX1 (i.e., TX2 follows TX1)
<b>Note</b>	This command is not valid for :TX1

<b>Syntax</b>	TMBPs:TX<Pt>:FOLLow?
<b>Description</b>	This query returns if the transmitter follow the TX1 settings.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX2:FOLL? → TX1
<b>Note</b>	This command is not valid for :TX1

### 5.2.3 TMBPs:TX<Pt>:CONNector

<b>Syntax</b>	TMBPs:TX<Pt>:CONNector <type>
<b>Description</b>	This command sets the physical type of connector.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> BALanced: Using balanced connector UNBalanced: Using unbalanced connector <i>DEFault = UNBalanced</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CONN BAL
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CONNector?
<b>Description</b>	This query returns the physical type of connector.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CONN? → BAL
<b>Note</b>	

### 5.2.4 TMBPs:TX<Pt>:DINSert[:ENABle]

<b>Syntax</b>	TMBPs:TX<Pt>:DINSert[:ENABle] <enable>
<b>Description</b>	This command enables/disables Drop and Insert.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:DINS OFF
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:DINSert[:ENABle]?
<b>Description</b>	This query returns whether or not Drop and Insert is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:DINS? → 0
<b>Note</b>	

### 5.2.5 TMBPs:TX<Pt>:TIMing

<b>Syntax</b>	TMBPs:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal timing source EXTernal: External timing source RX: Received signal on the same port <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:TIM? → INT
<b>Note</b>	

### 5.2.6 TMBPs:TX<Pt>:FOFFset

<b>Syntax</b>	TMBPs:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-125, MAXimum=125, DEFault=0</i> <i>Allowed suffix = ppm</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:FOFF Oppm
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset (ppm) for the clock source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:FOFF? → 0
<b>Note</b>	

### 5.2.7 TMBPs:TX<Pt>:CODE

<b>Syntax</b>	TMBPs:TX<Pt>:CODE <code>
<b>Description</b>	This command sets the line code type.
<b>Parameters</b>	<Pt> = Port number <code> = <CHARACTER PROGRAM DATA> AMI HDB3 <i>DEFault = HDB3</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CODE AMI
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CODE?
<b>Description</b>	This query returns the line code type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<code> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CODE? → AMI
<b>Note</b>	

### 5.2.8 TMBPs:TX<Pt>:PCMFrame

<b>Syntax</b>	TMBPs:TX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:PCMF? → 1
<b>Note</b>	

### 5.2.9 TMBPs:TX<Pt>:CRC4

<b>Syntax</b>	TMBPs:TX<Pt>:CRC4 <enable>
<b>Description</b>	This command enables or disables the CRC4 bits.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CRC4 ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CRC4?
<b>Description</b>	This query returns the state (enabled/disabled) of the CRC4 bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CRC4? → 1
<b>Note</b>	

### 5.2.10 TMBPs:TX<Pt>:SABits

<b>Syntax</b>	TMBPs:TX<Pt>:SABits <frame1>,<frame3>,<frame5>,<frame7>
<b>Description</b>	This command sets the Sa-bits.
<b>Parameters</b>	<Pt> = Port number <frame1> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000, MAXimum=#B11111</i> <i>DEFault=#B11111</i> <frame3> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000, MAXimum=#B11111</i> <i>DEFault=#B11111</i> <frame5> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000, MAXimum=#B11111</i> <i>DEFault=#B11111</i> <frame7> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000, MAXimum=#B11111</i> <i>DEFault=#B11111</i>
<b>Response</b>	None.
<b>Examples</b>	TMBP:TX1:SAB #B11111,#B11111,#B11111,#B11111 TMBP:TX1:SAB 31,31,31,31 TMBP:TX1:SAB min,max,def,0
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:SABits?
<b>Description</b>	This query returns the Sa-Bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frame1> = <BINARY NUMERIC RESPONSE DATA> <frame3> = <BINARY NUMERIC RESPONSE DATA> <frame5> = <BINARY NUMERIC RESPONSE DATA> <frame7> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:SAB? → #B11111,#B11111,#B11111,#B11111
<b>Note</b>	

### 5.2.11 TMBPs:TX<Pt>:SABMode

<b>Syntax</b>	TMBPs:TX<Pt>:SABMode <mode>
<b>Description</b>	This command sets the Sa-Bits mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> INSert BYPass <i>DEFault = BYPass</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:SABM INS
<b>Note</b>	

## 5.2.12 TMBPs:TX&lt;Pt&gt;:SABMode?

<b>Syntax</b>	TMBPs:TX<Pt>:SABMode?
<b>Description</b>	This query returns the Sa-Bits mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:SABM? → INS
<b>Note</b>	

## 5.2.13 TMBPs:TX&lt;Pt&gt;:PATtern

<b>Syntax</b>	TMBPs:TX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS6 PRBS7 PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 QRSS11 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS11</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:PATT? → PRBS11
<b>Note</b>	

## 5.2.14 TMBPs:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	TMBPs:TX<Pt>:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inversion> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, QRSSxx, ALT11, ALT13, ALT17, ALT324, USER32BIT and USER2048BIT.

<b>Syntax</b>	TMBPs:TX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inversion> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:PINV? → 1
<b>Note</b>	

### 5.2.15 TMBPs:TX<Pt>:PTSLots

<b>Syntax</b>	TMBPs:TX<Pt>:PTSLots <timeslot>
<b>Description</b>	This command sets the pattern time slots.
<b>Parameters</b>	<Pt> = Port number <timeslots> = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of slot number(s) ranging from 1 to 31
<b>Response</b>	None.
<b>Examples</b>	TMBP:TX1:PTSL (1,3,5)
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:PTSLots?
<b>Description</b>	This query returns the pattern time slots.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslot> = <EXPRESSION RESPONSE DATA> Format: Numeric List.
<b>Example</b>	TMBP:TX1:PTSL? → (1,3,5)
<b>Note</b>	

### 5.2.16 TMBPs:TX<Pt>:UP16

<b>Syntax</b>	TMBPs:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

### 5.2.17 TMBPs:TX<Pt>:UP32

<b>Syntax</b>	TMBPs:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	TMBP:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	TMBP:TX1:UP32? → "01101"
<b>Note</b>	

### 5.2.18 TMBPs:TX<Pt>:UP2K

<b>Syntax</b>	TMBPs:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when TMBP:TX1:PATT is USER2048BIT

<b>Syntax</b>	TMBPs:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	TMBP:TX1:UP2K? → "12DF"
<b>Note</b>	

### 5.2.19 TMBPs:TX<Pt>:UTSLots

<b>Syntax</b>	TMBPs:TX<Pt>:UTSLots <content>
<b>Description</b>	This command sets the content of unused time slots.
<b>Parameters</b>	<Pt> = Port number <content> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000000, MAXimum=#B11111111</i> <i>DEFault=#B01010101</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:UTSL 128
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:UTSLots?
<b>Description</b>	This query returns the content of unused time slots.
<b>Parameter</b>	<Pt> = Port number <content> = <BINARY NUMERIC RESPONSE DATA>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:UTSL? → #B10101010
<b>Note</b>	



## 5.2.20 TMBPs:TX&lt;Pt&gt;:SCContent

<b>Syntax</b>	TMBPs:TX<Pt>:SCContent <content>
<b>Description</b>	This command sets the channel content.
<b>Parameters</b>	<Pt> = Port number <content> = <CHARACTER PROGRAM DATA> OFF TONE TRANSPARENT SPEECH <i>Default=OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:SCC TONE
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:SCContent?
<b>Description</b>	This query returns the channel content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:TX1:SCC? → TONE
<b>Note</b>	

## 5.2.21 TMBPs:TX&lt;Pt&gt;:SCTSLOT

<b>Syntax</b>	TMBPs:TX<Pt>:SCTSLOT <timeslot>
<b>Description</b>	This command sets the channel time slot.
<b>Parameters</b>	<Pt> = Port number <timeslot> = <NUMERIC PROGRAM DATA> <i>Minimum=1, Maximum=31</i> <i>Default=2</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:SCTS 4
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:SCTSLOT?
<b>Description</b>	This query returns the channel time slot.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslot> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:SCTS? → 4
<b>Note</b>	

## 5.2.22 TMBPs:TX&lt;Pt&gt;:TFR

<b>Syntax</b>	TMBPs:TX<Pt>:TFR <frequency>
<b>Description</b>	This command sets the tone frequency.
<b>Parameters</b>	<Pt> = Port number <frequency> = <NUMERIC PROGRAM DATA> <i>Minimum = 1 Hz, Maximum = 4000 Hz</i> <i>Default = 440</i> <i>Allowed suffixes = HZ, KHZ</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:TFR 500HZ
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:TFR?
<b>Description</b>	This query returns the tone frequency (Hz).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frequency> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:TFR? → 500
<b>Note</b>	

### 5.2.23 TMBPs:TX<Pt>:TLEVel

<b>Syntax</b>	TMBPs:TX<Pt>:TLEVel <level>
<b>Description</b>	This command sets the tone level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum = -70, MAXimum = 3</i> <i>DEFault = -20</i> <i>Allowed suffixes = dB</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:TLEV 2dB
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:TLEVel?
<b>Description</b>	This query returns the tone level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:TLEV? → 2
<b>Note</b>	

### 5.2.24 TMBPs:TX<Pt>:CAS

<b>Syntax</b>	TMBPs:TX<Pt>:CAS <enable>
<b>Description</b>	This command enables or disables the channel associated signaling.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CAS ON
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CAS?
<b>Description</b>	This query returns the state (enabled/disabled) of the channel associated signaling.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CAS? → 1
<b>Note</b>	

### 5.2.25 TMBPs:TX<Pt>:CASChannel

<b>Syntax</b>	TMBPs:TX<Pt>:CASChannel <channel>
<b>Description</b>	This command sets the CAS channel number.
<b>Parameters</b>	<Pt> = Port number <channel> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=30, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CASC 5
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CASChannel?
<b>Description</b>	This query returns the CAS channel number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<channel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CASC? → 5
<b>Note</b>	

### 5.2.26 TMBPs:TX<Pt>:CASBits

<b>Syntax</b>	TMBPs:TX<Pt>:CASBits <bits>
<b>Description</b>	This command sets the CAS channel bits.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1111</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:CASB #B1111
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:CASBits?
<b>Description</b>	This query returns the CAS channel bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:CASB? → #B1111
<b>Note</b>	

### 5.2.27 TMBPs:TX<Pt>:COCBits

<b>Syntax</b>	TMBPs:TX<Pt>:COCBits <bits>
<b>Description</b>	This command sets the CAS other channel bits.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1001</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:TX1:COCB #B0000
<b>Note</b>	

<b>Syntax</b>	TMBPs:TX<Pt>:COCBits?
<b>Description</b>	This query returns the CAS other channel bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:TX1:COCB? → #B0000
<b>Note</b>	

## 5.3 Stimuli

### 5.3.1 TMBPs:STIMuli:TX<Pt>:ALARm

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:ALARm <type>
<b>Description</b>	This command sets the alarm type to be generated.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> NALarm: No alarm NSIGnal: No signal AIS: Alarm indication signal NFRame: No frame DALarm: Distant alarm (RDI) NSYNc: No pattern sync NCAM: No CAS MFAS DMF: Distant MF alarm <i>DEFault = NALarm</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:STIM:TX1:ALAR NSIG
<b>Note</b>	

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the generated alarm type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:STIM:TX1:ALAR? → NSIG
<b>Note</b>	

### 5.3.2 TMBPs:STIMuli:TX<Pt>:ERRor

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:ERRor <destination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<Pt> = Port number <destination> = <CHARACTER PROGRAM DATA> FAS FNFas: FAS and NFAS FWORd: FAS word CRC4 CMFas: CRC4 MFAS CODE PATtern CAMFas: CAS MFAS EBIT: E-Bit PSLip: Pattern slip FSLip: Frame slip TRANSPARENT: Transparent <i>DEFault = CRC4</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:STIM:TX1:ERR FAS
<b>Note</b>	

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<destination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:STIM:TX1:ERR? → FAS
<b>Note</b>	

### 5.3.3 TMBPs:STIMuli:TX<Pt>:EINsert

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:EINsert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B02: Burst · 1E-02 B03: Burst · 1E-03 B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 ES: Errored seconds SES: Severe errored seconds <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:EINsert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:STIM:TX1:EINS? → MAN
<b>Note</b>	

### 5.3.4 TMBPs:STIMuli:TX<Pt>:EBLength

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:STIM:TX1:EBL 1
<b>Note</b>	For TMBP:STIM:TX<Pt>:ERR? → FWORD, <i>MAXimum = 16</i>

<b>Syntax</b>	TMBPs:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STIM:TX1:EBL? → 1
<b>Note</b>	

## 5.4 Result

### 5.4.1 TMBPs:RX<Pt>:IFETch?

<b>Syntax</b>	TMBPs:RX<Pt>:IFETch? <parameter>
<b>Description</b>	This command fetches results from a 2 Mbps interval if available.
<b>Parameters</b>	<Pt> = Port number ({<parameter>} + {,}*) = <EXPRESSION PROGRAM DATA> The response format is listed for each parameter. <b>Alarms</b>

continued on next page...

... continued from previous page

	<p>NSIGnal: No signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  AIS: Alarm indication Signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NFRame: No frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NCMF: No CRC4 multi frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  DALarm: Distant alarm. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NSYNc: No sync. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NCAM: No CAS MF. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  DMF: Distant MF. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>FAS: Frame alignment signal. Response: &lt;Count&gt;,&lt;Ratio&gt;  PATtern: Pattern. Response: &lt;Count&gt;,&lt;Ratio&gt;  CRC4: CRC4. Response: &lt;Count&gt;,&lt;Ratio&gt;  CRCM: CRC4 MFAS. Response: &lt;Count&gt;,&lt;Ratio&gt;  EBIT: E-Bits. Response: &lt;Count&gt;,&lt;Ratio&gt;  CODE: Code. Response: &lt;Count&gt;,&lt;Ratio&gt;  PSLip: Pattern slip. Response: &lt;Count&gt;,&lt;Ratio&gt;  PBLock: Pattern block. Response: &lt;Count&gt;,&lt;Ratio&gt;  FSLip: Frame slip. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>FAS performance errors</b></p> <p>FES: FAS ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FSES: FAS SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FBBE: FAS BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FALS: FAS ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FUAT: FAS UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FAVT: FAS AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FEFS: FAS EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>Pattern performance errors</b></p> <p>PES: Pattern ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PSES: Pattern SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PBBE: Pattern BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PALS: Pattern ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PUAT: Pattern UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PAVT: Pattern AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PEFS: Pattern EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>CRC4 performance errors</b></p> <p>CES: CRC4 ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CSES: CRC4 SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CBBE: CRC4 BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CALs: CRC4 ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CUAT: CRC4 UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CAVT: CRC4 AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  CEFS: CRC4 EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>E-Bit performance errors</b></p> <p>EES: E-Bit ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  ESES: E-Bit SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  EBBE: E-Bit BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  EALS: E-Bit ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  EUAT: E-Bit UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  EAVT: E-Bit AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  EEFS: E-Bit EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> Expression format: Numeric List

continued on next page...

... continued from previous page

	Each result is formatted according to the specification in the parameter field. Values that are not relevant or applicable for the current measurement, returns NaN (section 1.6.1).
<b>Example</b>	TMBP:RX1:IFET? (AIS,FES) → (9,0.0429),(10,0.0343)
<b>Note</b>	This command fetches the results from the interval selected using the MEASurement:SETup:SELEct command (see section 17.2.2). If the requested result is not available, NaN (section 1.6.1) is returned. If there is one or more results, the last "," is always removed.

## 5.5 Status

### 5.5.1 TMBPs:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns alarms and errors summary event register. The content of this event register is summarized in DB1 of the STATus:INTErface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:AES? → 1 TMBP:STAT:RX1:AES:EVEN? → 1
<b>Note</b>	

### 5.5.2 TMBPs:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary operation register query.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:AES:COND? → 1
<b>Note</b>	

### 5.5.3 TMBPs:STATus:RX<Pt>:ALARm[:EVENT]?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns alarms event register query. The content of this register is summarized in DB1 of the TMBPs:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No sync DB2 (2) = Distant MF DB3 (4) = No CAS MF DB4 (8) = Distant DB5 (16) = No CRC4 MF DB6 (32) = No frame DB7 (64) = Alarm indication signal (AIS) DB8 (128) = No signal DB9 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:ALAR? → 64
<b>Note</b>	

## 5.5.4 TMBPs:STATus:RX&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns alarms condition register query.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No sync DB2 (2) = Distant MF DB3 (4) = No CAS MF DB4 (8) = Distant DB5 (16) = No CRC4 MF DB6 (32) = No Frame DB7 (64) = Alarm Indication Signal (AIS) DB8 (128) = No Signal DB9 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:ALAR:COND? → 64
<b>Note</b>	

## 5.5.5 TMBPs:STATus:RX&lt;Pt&gt;:ERRor[:EVENT]?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns errors event register. The content of this register is summarized in DB2 of the TMBPs:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern slip DB2 (2) = Pattern DB3 (4) = E-Bit DB4 (8) = CRC4 DB5 (16) = Frame slip DB6 (32) = CRC4 MFAS DB7 (64) = FAS DB8 (128) = Code DB9 (256) = Sequence DB10 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:ERR? → 64
<b>Note</b>	

## 5.5.6 TMBPs:STATus:RX&lt;Pt&gt;:ERRor:CONDition?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns errors condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern slip DB2 (2) = Pattern DB3 (4) = E-Bit DB4 (8) = CRC4 DB5 (16) = Frame slip DB6 (32) = CRC4 MFAS DB7 (64) = FAS DB8 (128) = Code DB9 (256) = Sequence DB10 - DB16 = NOT USED
<b>Example</b>	TMBP:STAT:RX1:ERR:COND? → 64
<b>Note</b>	



## 5.5.7 TMBPs:STATus:RX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns physical signal level. Unit: dB.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:PSL? → 0
<b>Note</b>	Minimum level is -11 dB.

## 5.5.8 TMBPs:STATus:RX&lt;Pt&gt;:PDEVIation?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:PDEVIation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:PDEV? → 0, 0
<b>Note</b>	

## 5.5.9 TMBPs:STATus:RX&lt;Pt&gt;:PBRate?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:PBR? → 2048000
<b>Note</b>	

## 5.5.10 TMBPs:STATus:RX&lt;Pt&gt;:PPBRate?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns payload pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:PPBR? → 64000
<b>Note</b>	

## 5.5.11 TMBPs:STATus:RX&lt;Pt&gt;:FNFWord?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:FNFWord?
<b>Description</b>	This query returns FAS Non FAS word. Returns the content of time slot 0. Data length is always 2 · 64 bit shown as hexadecimal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<hex> = <HEXADECIMAL NUMERIC RESPONSE DATA> Frame Group I, Frame 0-7 <hex> = <HEXADECIMAL NUMERIC RESPONSE DATA> Frame Group II, Frame 8-15
<b>Example</b>	TMBP:STAT:RX1:FNFW? → #H5F1BDF1B5F1B5F9b, #HDF1BDF1BDF1BDF9B
<b>Note</b>	

## 5.5.12 TMBPs:STATus:RX&lt;Pt&gt;:FDUMp?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:FDUMp?
<b>Description</b>	This query returns a sample of a full E1 Frame (32 bytes).
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<hex> = <EXPRESSION RESPONSE DATA> Expression format: Numeric list Contains all 32 Frame timeslots.
<b>Example</b>	TMBP:STAT:RX1:FDUM? → #H1B,#H55,#H55,...
<b>Note</b>	

## 5.5.13 TMBPs:STATus:RX&lt;Pt&gt;:ACONtent?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ACONtent?
<b>Description</b>	This query returns audio channel content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiocontent> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:ACON? → #B01010101
<b>Note</b>	For sub-rates this field shows the content of the sub channel.

## 5.5.14 TMBPs:STATus:RX&lt;Pt&gt;:AEBCContent?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:AEBCContent?
<b>Description</b>	This query returns sub channel audio even bit inverting content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiocontent> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:AEBC? → #B10000000
<b>Note</b>	With A-law coded speech, it is possible to observe the A-law code words before the even bit inverting.

## 5.5.15 TMBPs:STATus:RX&lt;Pt&gt;:APPeak?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:APPeak?
<b>Description</b>	This query returns sub channel audio positive peak value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<positivepeak> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:APP? → 85
<b>Note</b>	This query only applies for A-law speech and shows the largest received A-law coded value.

## 5.5.16 TMBPs:STATus:RX&lt;Pt&gt;:ANPeak?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ANPeak?
<b>Description</b>	This query returns sub channel audio negative peak value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<negativepeak> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:ANP? → -85
<b>Note</b>	This query only applies for A-law speech and shows the smallest received A-law coded value.

## 5.5.17 TMBPs:STATus:RX&lt;Pt&gt;:ALEVel?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ALEVel?
<b>Description</b>	This query returns sub channel audio level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiolevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:ALEV? → -4
<b>Note</b>	

## 5.5.18 TMBPs:STATus:RX&lt;Pt&gt;:AFRequency?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:AFRequency?
<b>Description</b>	This query returns sub channel audio tone frequency. Unit: Hz.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiofrequency> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:AFR? → 366
<b>Note</b>	

## 5.5.19 TMBPs:STATus:RX&lt;Pt&gt;:ACOFfset?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:ACOFfset?
<b>Description</b>	This query returns sub channel audio coder offset.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<coderoffset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:ACOF? → 0
<b>Note</b>	Only available for 64 or 32 kbps audio sub channels.

## 5.5.20 TMBPs:STATus:RX&lt;Pt&gt;:CMSignal?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:CMSignal?
<b>Description</b>	This query returns CAS MFAS signal status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<status> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:STAT:RX1:CMS? → #B00000101
<b>Note</b>	

## 5.5.21 TMBPs:STATus:RX&lt;Pt&gt;:CBITs?

<b>Syntax</b>	TMBPs:STATus:RX<Pt>:CBITs?
<b>Description</b>	This query returns CAS bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <EXPRESSION RESPONSE DATA> Expression format: Numeric list Contains all 30 CAS bit sets.
<b>Example</b>	TMBP:STAT:RX1:CBIT? → (#B0101,#B0101, ..., #B0101,#B0101)
<b>Note</b>	

## 5.6 APS

This section document commands for Automatic Protection Switching testing.

### 5.6.1 TMBPs:APS:START

<b>Syntax</b>	TMBPs:APS:START
<b>Description</b>	This command starts the APS (Automatic Protection Switching).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	TMBP:APS:STAR
<b>Note</b>	

### 5.6.2 TMBPs:APS:STOP

<b>Syntax</b>	TMBPs:APS:STOP
<b>Description</b>	This command stops the APS (Automatic Protection Switching) command.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	TMBP:APS:STOP
<b>Note</b>	

### 5.6.3 TMBPs:APS:RX<Pt>:NUMBer?

<b>Syntax</b>	TMBPs:APS:RX<Pt>:NUMBer?
<b>Description</b>	This query returns the number of times a reference event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:APS:RX1:NUMB? → 17
<b>Note</b>	

### 5.6.4 TMBPs:APS:RX<Pt>:ATIME?

<b>Syntax</b>	TMBPs:APS:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:APS:RX1:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

### 5.6.5 TMBPs:APS:RX<Pt>:MTIME?

<b>Syntax</b>	TMBPs:APS:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	TMBP:APS:RX1:MTIM? → 29.170,0
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

## 5.6.6 TMBPs:APS:RX&lt;Pt&gt;:LTIMe?

<b>Syntax</b>	TMBPs:APS:RX<Pt>:LTIMe?
<b>Description</b>	This query returns the minimum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:APS:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

## 5.6.7 TMBPs:APS:RX&lt;Pt&gt;:EVENT

<b>Syntax</b>	TMBPs:APS:RX<Pt>:EVENTt <event>
<b>Description</b>	This command sets the Time Reference event.
<b>Parameters</b>	<Pt> = Port number <event> = <CHARACTER PROGRAM DATA> AIS = Alarm indication signal NFRame = No frame PERRor = Pattern error
<b>Response</b>	None.
<b>Example</b>	TMBP:APS:RX1:EVEN AIS
<b>Note</b>	

<b>Syntax</b>	TMBPs:APS:RX<Pt>:EVENT?
<b>Description</b>	This query returns the time reference event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	TMBP:APS:RX1:EVEN? → AIS
<b>Note</b>	

## 5.6.8 TMBPs:APS:RX&lt;Pt&gt;:MLIMit

<b>Syntax</b>	TMBPs:APS:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 4000.000, DEFault = 50.000</i>
<b>Response</b>	None.
<b>Example</b>	TMBP:APS:RX1:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	TMBPs:APS:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:APS:RX1:MLIM? → 50.000
<b>Note</b>	

## 5.7 RTD

This section document commands to retrieve Round Trip Delay measurement results. Commands for general RTD settings are described in section 16.1 on page 837.

### 5.7.1 TMBPs:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	TMBPs:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 5.7.2 TMBPs:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	TMBPs:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 5.7.3 TMBPs:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	TMBPs:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	TMBP:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 5.7.4 TMBPs:RTD:RX<Pt>:LTIME?

<b>Syntax</b>	TMBPs:RTD:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	TMBP:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

---

## Chapter 6

# T1

## 6.1 Receiver

### 6.1.1 T1:RX<Pt>[:ENABLEd]

<b>Syntax</b>	T1:RX<Pt>[:ENABLEd] <interface>
<b>Description</b>	This command enables or disables the T1 receiver.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1 ON
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>[:ENABLEd]?
<b>Description</b>	This query returns the state (enabled/disabled) of the T1 receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1? → ON T1:RX1:ENAB? → SDH
<b>Note</b>	Returns SDH if T1 is over SDH or SONET.

### 6.1.2 T1:RX<Pt>:FOLLow

<b>Syntax</b>	T1:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX: Transmitter of the same port RX1: Receiver of port 1 <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:FOLL TX (i.e., RX1 follows TX1) T1:RX2:FOLL RX1 (i.e., RX2 follows RX1)
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:FOLLow?
<b>Description</b>	This query returns if the receiver follow another setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:FOLL? → TX
<b>Note</b>	

## 6.1.3 T1:RX&lt;Pt&gt;:MODE

<b>Syntax</b>	T1:RX<Pt>:MODE <mode>
<b>Description</b>	This command sets the signal termination mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> TERMinate: Nominal impedance. Normal frequency dependent AGC. BRIDged: High impedance. MONitor: Nominal impedance. Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:MODE TERM
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:MODE?
<b>Description</b>	This query returns the signal termination mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:MODE? → TERM
<b>Note</b>	

## 6.1.4 T1:RX&lt;Pt&gt;:CODE

<b>Syntax</b>	T1:RX<Pt>:CODE <code>
<b>Description</b>	This command sets the line code type.
<b>Parameters</b>	<Pt> = Port number <code> = <CHARACTER PROGRAM DATA> AMI B8ZS <i>DEFault = B8ZS</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:CODE AMI
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:CODE?
<b>Description</b>	This query returns the line code type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<code> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:CODE? → AMI
<b>Note</b>	

## 6.1.5 T1:RX&lt;Pt&gt;:PCMFrame

<b>Syntax</b>	T1:RX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RX1:PCMF? → 1
<b>Note</b>	



## 6.1.6 T1:RX&lt;Pt&gt;:FTYPE

<b>Syntax</b>	T1:RX<Pt>:FTYPE <type>
<b>Description</b>	This command sets the PCM frame type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> TSF: T1 SF/D4 mode TESF: T1 ESF mode JESF: J1 ESF mode <i>DEFault = TSF</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:FTYP TESH
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:FTYPE?
<b>Description</b>	This query returns PCM frame type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:FTYP? → TESH
<b>Note</b>	

## 6.1.7 T1:RX&lt;Pt&gt;:PATTERN

<b>Syntax</b>	T1:RX<Pt>:PATTERN <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS11</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:PATT PRBS11

<b>Syntax</b>	T1:RX<Pt>:PATTERN?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:PATT? → PRBS11
<b>Note</b>	

## 6.1.8 T1:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	T1:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBS <sub>xxx</sub> , QRSS <sub>xxx</sub> , ALT11, ALT13, ALT17, ALT324, USER32BIT and USER2048BIT.

<b>Syntax</b>	T1:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RX1:PINV? → 1
<b>Note</b>	

## 6.1.9 T1:RX&lt;Pt&gt;:PTSLots

<b>Syntax</b>	T1:RX<Pt>:PTSLots <slots>
<b>Description</b>	This command sets the pattern time slots.
<b>Parameters</b>	<Pt> = Port number <slots> = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of slot number(s) ranging from 1 to 23
<b>Response</b>	None.
<b>Examples</b>	T1:RX1:PTSL (1,3,5)
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:PTSLots?
<b>Description</b>	This query returns the pattern time slots.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<slots> = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	T1:RX1:PTSL? → (1,3,5)
<b>Note</b>	

## 6.1.10 T1:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	T1:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	T1:RX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 6.1.11 T1:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	T1:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters.
<b>Response</b>	None.
<b>Examples</b>	T1:RX2:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T1:RX2:UP32? → "01101"
<b>Note</b>	

## 6.1.12 T1:TX&lt;Pt&gt;:SCContent

<b>Syntax</b>	T1:TX<Pt>:SCContent <content>
<b>Description</b>	This command sets the channel content.
<b>Parameters</b>	<Pt> = Port number <content> = <CHARACTER PROGRAM DATA> OFF TONE TRANSPARENT SPEECH <i>DEFAULT=OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:SCC TONE
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:SCContent?
<b>Description</b>	This query returns the channel content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:SCC? → TONE
<b>Note</b>	

## 6.1.13 T1:RX&lt;Pt&gt;:AUDio

<b>Syntax</b>	T1:RX<Pt>:AUDio <type>
<b>Description</b>	This command sets the audio decoding.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFAULT = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:AUD ON
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:AUDio?
<b>Description</b>	This query returns the audio decoding.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:RX1:AUD? → ON
<b>Note</b>	

#### 6.1.14 T1:RX<Pt>:ATSLot

<b>Syntax</b>	T1:RX<Pt>:ATSLot <timeslotno>
<b>Description</b>	This command sets the audio timeslot to be monitored.
<b>Parameters</b>	<Pt> = Port number <timeslotno> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=23, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:ATSL 4
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:ATSLot?
<b>Description</b>	This query returns the monitored audio timeslot.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslotno> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RX1:ATSL? → 4
<b>Note</b>	

#### 6.1.15 T1:RX<Pt>:UP2K

<b>Syntax</b>	T1:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	T1:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when T1:RX2:PATT is USER2048BIT

<b>Syntax</b>	T1:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T1:RX1:UP2K? → "12DF"
<b>Note</b>	

#### 6.1.16 T1:RX<Pt>:CAS

<b>Syntax</b>	T1:RX<Pt>:CAS <enable>
<b>Description</b>	This command enables or disables the channel associated signaling.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:RX1:CAS ON
<b>Note</b>	

<b>Syntax</b>	T1:RX<Pt>:CAS?
<b>Description</b>	This query returns the state (enabled/disabled) of the channel associated signaling.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RX1:CAS? → 1
<b>Note</b>	

## 6.2 Transmitter

### 6.2.1 T1:TX<Pt>[:ENABLED]

<b>Syntax</b>	T1:TX<Pt>[:ENABLED] <interface>
<b>Description</b>	This command enables or disables the T1 transmitter.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	T1:TX1 ON T1:TX1:ENAB ON
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>[:ENABLED]?
<b>Description</b>	This query returns the state (enabled/disabled) of the T1 transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	T1:TX1? → ON T1:TX1:ENAB? → SDH
<b>Note</b>	Returns SDH if T1 is over SDH or SONET.

### 6.2.2 T1:TX<Pt>:FOLLOW

<b>Syntax</b>	T1:TX<Pt>:FOLLOW <follow>
<b>Description</b>	This command sets the transmitter setting to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX1: Follow the setting of the port 1 transmitter <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX2:FOLL TX1 (i.e., TX2 follows TX1)
<b>Note</b>	This command is not valid for :TX1

<b>Syntax</b>	T1:TX<Pt>:FOLLOW?
<b>Description</b>	This query returns if the transmitter follow the TX1 settings.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX2:FOLL? → TX1
<b>Note</b>	This command is not valid for :TX1

## 6.2.3 T1:TX&lt;Pt&gt;:DINSert[:ENABLE]

<b>Syntax</b>	T1:TX<Pt>:DINSert[:ENABLE] <enable>
<b>Description</b>	This command enables/disables Drop and Insert.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:DINS OFF
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:DINSert[:ENABLE]?
<b>Description</b>	This query returns whether or not Drop and Insert is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:DINS? → 0
<b>Note</b>	

## 6.2.4 T1:TX&lt;Pt&gt;:TIMing

<b>Syntax</b>	T1:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal timing source EXTernal: External timing source RX: Received signal on the same port <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:TIM? → INT
<b>Note</b>	

## 6.2.5 T1:TX&lt;Pt&gt;:FOFFset

<b>Syntax</b>	T1:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-125, MAXimum=125, DEFault=0</i> <i>Allowed suffixes = ppm</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:FOFF 0ppm
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset (ppm) for the clock source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:FOFF? → 0
<b>Note</b>	

## 6.2.6 T1:TX&lt;Pt&gt;:CODE

<b>Syntax</b>	T1:TX<Pt>:CODE <code>
<b>Description</b>	This command sets the line code type.
<b>Parameters</b>	<Pt> = Port number <code> = <CHARACTER PROGRAM DATA> AMI B8ZS <i>DEFault = B8ZS</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:CODE AMI
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:CODE?
<b>Description</b>	This query returns the line code type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<code> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:CODE? → AMI
<b>Note</b>	

## 6.2.7 T1:TX&lt;Pt&gt;:LBOOut

<b>Syntax</b>	T1:TX<Pt>:LBOOut <lbo>
<b>Description</b>	This command sets the line build out.
<b>Parameters</b>	<Pt> = Port number <lbo> = <CHARACTER PROGRAM DATA> 0TO133: 0 to 133 feet 133TO266: 133 tp 266 feet 266TO399: 266 to 399 feet 399TO533: 399 tp 533 feet 533TO655: 533 to 655 feet GMOde: Gain mode (Monitor) DB0: 0 db DB7: -7.5 db DB15: -15 db DB22: -22.5 db <i>DEFault = 0TO133</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:LBO 133TO266
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:LBOOut?
<b>Description</b>	This query returns the line build out setting.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lbo> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:LBO? → 0TO133
<b>Note</b>	

## 6.2.8 T1:TX&lt;Pt&gt;:PCMFrame

<b>Syntax</b>	T1:TX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:PCMF? → 1
<b>Note</b>	

### 6.2.9 T1:TX<Pt>:FTYPE

<b>Syntax</b>	T1:TX<Pt>:FTYPE <type>
<b>Description</b>	This command sets the PCM frame type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> TSF: T1 SF/D4 mode TESF: T1 ESF mode JESF: J1 ESF mode <i>DEFault = TSF</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:FTYP TESF
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:FTYPE?
<b>Description</b>	This query returns PCM frame type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:FTYP? → TESF
<b>Note</b>	

### 6.2.10 T1:TX<Pt>:PATTERN

<b>Syntax</b>	T1:TX<Pt>:PATTERN <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS11</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:PATT PRBS11



<b>Syntax</b>	T1:TX<Pt>:PATTern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:TX1:PATT? → PRBS11
<b>Note</b>	

### 6.2.11 T1:TX<Pt>:PINVersion

<b>Syntax</b>	T1:TX<Pt>:PINVersion <inversion>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inversion> = <BOOLEAN PROGRAM DATA> <i>Default = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, QRSSxx, ALT11, ALT13, ALT17, ALT324, USER32BIT and USER2048BIT.

<b>Syntax</b>	T1:TX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inversion> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:PINV? → 1
<b>Note</b>	

### 6.2.12 T1:TX<Pt>:PTSLots

<b>Syntax</b>	T1:TX<Pt>:PTSLots <timeslot>
<b>Description</b>	This command sets the pattern time slots.
<b>Parameters</b>	<Pt> = Port number <timeslots> = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of slot number(s) ranging from 1 to 23
<b>Response</b>	None.
<b>Example</b>	T1:TX1:PTSL (1,3,5)
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:PTSLots?
<b>Description</b>	This query returns the pattern time slots.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslot> = <EXPRESSION RESPONSE DATA> Format: Numeric List.
<b>Example</b>	T1:TX1:PTSL? → (1,3,5)
<b>Note</b>	

## 6.2.13 T1:TX&lt;Pt&gt;:UP16

<b>Syntax</b>	T1:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	T1:TX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 6.2.14 T1:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	T1:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters.
<b>Response</b>	None.
<b>Examples</b>	T1:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T1:TX1:UP32? → "01101"
<b>Note</b>	

## 6.2.15 T1:TX&lt;Pt&gt;:UP2K

<b>Syntax</b>	T1:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	T1:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when T1:TX2:PATT is USER2048BIT

<b>Syntax</b>	T1:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T1:TX1:UP2K? → "12DF"
<b>Note</b>	

## 6.2.16 T1:TX&lt;Pt&gt;:UTSLots

<b>Syntax</b>	T1:TX<Pt>:UTSLots <content>
<b>Description</b>	This command sets the content of unused time slots.
<b>Parameters</b>	<Pt> = Port number <content> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000000, MAXimum=#B11111111, DEFault=#B01010101</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:UTSL 128
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:UTSLots?
<b>Description</b>	This query returns the content of unused time slots.
<b>Parameter</b>	<Pt> = Port number <content> = <BINARY NUMERIC RESPONSE DATA>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:UTSL? → #B10101010
<b>Note</b>	

## 6.2.17 T1:TX&lt;Pt&gt;:SCTSslot

<b>Syntax</b>	T1:TX<Pt>:SCTSslot <timeslot>
<b>Description</b>	This command sets the channel time slot.
<b>Parameters</b>	<Pt> = Port number <timeslot> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=23, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:SCTS 4
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:SCTSslot?
<b>Description</b>	This query returns the sub channel time slot.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeslot> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:SCTS? → 4
<b>Note</b>	

## 6.2.18 T1:TX&lt;Pt&gt;:TFR

<b>Syntax</b>	T1:TX<Pt>:TFR <frequency>
<b>Description</b>	This command sets the tone frequency.
<b>Parameters</b>	<Pt> = Port number <frequency> = <NUMERIC PROGRAM DATA> <i>MINimum = 1 hz, MAXimum = 4000 hz</i> <i>DEFault = 440</i> <i>Allowed suffixes = HZ, KHZ</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:TFR 500HZ
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:TFR?
<b>Description</b>	This query returns the tone frequency (Hz).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frequency> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:TFR? → 500
<b>Note</b>	

## 6.2.19 T1:TX&lt;Pt&gt;:TLEVel

<b>Syntax</b>	T1:TX<Pt>:TLEVel <level>
<b>Description</b>	This command sets the tone level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum = -70, MAXimum = 3</i> <i>DEFault = -20</i> <i>Allowed suffixes = dB</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:TLEV 2dB
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:TLEV?
<b>Description</b>	This query returns the tone level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:TLEV? → 2
<b>Note</b>	

## 6.2.20 T1:TX&lt;Pt&gt;:CAS

<b>Syntax</b>	T1:TX<Pt>:CAS <enable>
<b>Description</b>	This command enables or disables the channel associated signaling.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:CAS ON
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:CAS?
<b>Description</b>	This query returns the state (enabled/disabled) of the channel associated signaling.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:CAS? → 1
<b>Note</b>	

## 6.2.21 T1:TX&lt;Pt&gt;:CASChannel

<b>Syntax</b>	T1:TX<Pt>:CASChannel <channel>
<b>Description</b>	This command sets the CAS channel number.
<b>Parameters</b>	<Pt> = Port number <channel> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=24, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:CASC 5
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:CASChannel?
<b>Description</b>	This query returns the CAS channel number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<channel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:CASC? → 5
<b>Note</b>	

## 6.2.22 T1:TX&lt;Pt&gt;:CASBits

<b>Syntax</b>	T1:TX<Pt>:CASBits <bits>
<b>Description</b>	This command sets the CAS channel bits.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1111</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:CASB #B1111
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:CASBits?
<b>Description</b>	This query returns the CAS channel bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:CASB? → #B1111
<b>Note</b>	

## 6.2.23 T1:TX&lt;Pt&gt;:COCBits

<b>Syntax</b>	T1:TX<Pt>:COCBits <bits>
<b>Description</b>	This command sets the CAS other channel bits.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1001</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:COCB #B0000
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:COCBits?
<b>Description</b>	This query returns the CAS other channel bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:COCB? → #B0000
<b>Note</b>	

## 6.2.24 T1:TX&lt;Pt&gt;:SF:CASBits

<b>Syntax</b>	T1:TX<Pt>:SF:CASBits <bits>
<b>Description</b>	This command sets the CAS channel bits for SF framing.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00, MAXimum=#B11, DEFault=#B11</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:SF:CASB #B11
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:SF:CASBits?
<b>Description</b>	This query returns the CAS channel bits for SF framing.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:SF:CASB? → #B11
<b>Note</b>	

## 6.2.25 T1:TX&lt;Pt&gt;:SF:COCBits

<b>Syntax</b>	T1:TX<Pt>:SF:COCBits <bits>
<b>Description</b>	This command sets the CAS other channel bits for SF framing.
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00, MAXimum=#B11, DEFault=#B11</i>
<b>Response</b>	None.
<b>Example</b>	T1:TX1:SF:COCB #B00
<b>Note</b>	

<b>Syntax</b>	T1:TX<Pt>:SF:COCBits?
<b>Description</b>	This query returns the CAS other channel bits for SF framing.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:TX1:SF:COCB? → #B00
<b>Note</b>	

## 6.3 Stimuli

## 6.3.1 T1:STIMuli:TX&lt;Pt&gt;:ALARm

<b>Syntax</b>	T1:STIMuli:TX<Pt>:ALARm <type>
<b>Description</b>	This command sets the alarm type to be generated.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> NALarm: No alarm OOF: Out of frame NSIGnal: No signal AIS: Alarm indication signal RAI: Remote Alarm Indication NSYNc: No pattern sync (LSS) <i>DEFault = NALarm</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:ALAR NSIG
<b>Note</b>	

<b>Syntax</b>	T1:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the generated alarm type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:ALAR? → NSIG
<b>Note</b>	

## 6.3.2 T1:STIMuli:TX&lt;Pt&gt;:ERRor

<b>Syntax</b>	T1:STIMuli:TX<Pt>:ERRor <destination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<Pt> = Port number <destination> = <CHARACTER PROGRAM DATA> OFF CRC6: CRC-6 PATtern: Pattern Error FBIT: F-Bit SBIT: S-Bit BPV: Bipolar Violation PSLip: Pattern slip EXZ: Excessive Zeroes <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:ERR CODE
<b>Note</b>	

<b>Syntax</b>	T1:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<destination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:ERR? → CODE
<b>Note</b>	

## 6.3.3 T1:STIMuli:TX&lt;Pt&gt;:EINSert

<b>Syntax</b>	T1:STIMuli:TX<Pt>:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B02: Burst · 1E-02 B03: Burst · 1E-03 B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 ES: Errored seconds SES: Severe errored seconds <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14

<b>Syntax</b>	T1:STIMuli:TX<Pt>:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:EINS? → MAN
<b>Note</b>	

## 6.3.4 T1:STIMuli:TX&lt;Pt&gt;:EBLength

<b>Syntax</b>	T1:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:EBL 1
<b>Note</b>	For T1:STIM:TX<Pt>:ERR? → CODE, <i>MAXimum = 1</i>

<b>Syntax</b>	T1:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:EBL? → 1
<b>Note</b>	

## 6.3.5 T1:STIMuli:TX&lt;Pt&gt;:FDLink

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink <code>
<b>Description</b>	This command sets the transmitted FDL- or in-bound code.
<b>Parameters</b>	<Pt> = Port number <code> = <CHARACTER PROGRAM DATA> OFF: LLA: LLD: PLA: PLD: ULB: NLA: USER: Use the user defined FDL value ACS: DCS: AN1: DN1: AN2: DN2: 100K: UINBand: Use the user defined in-band coed. <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:FDL LLA
<b>Note</b>	

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink?
<b>Description</b>	This query returns the transmitted FDL- or inbound code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<code> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:FDL? → LLA
<b>Note</b>	



## 6.3.6 T1:STIMuli:TX&lt;Pt&gt;:FDLink:UFDL

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink:UFDL <value>
<b>Description</b>	This command sets the user defined FDL code.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=63, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:F DL:UF DL #B111111
<b>Note</b>	

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink:UFDL?
<b>Description</b>	This query returns the user defined FDL code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:F DL:UF DL? → 63
<b>Note</b>	

## 6.3.7 T1:STIMuli:TX&lt;Pt&gt;:FDLink:IBCode

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink:IBCode <value>
<b>Description</b>	This command sets the user defined in-bound code.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=16777215, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	T1:STIM:TX1:F DL:IB C #HFFFFFFE
<b>Note</b>	

<b>Syntax</b>	T1:STIMuli:TX<Pt>:FDLink:IBCode?
<b>Description</b>	This query returns the user defined in-bound code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STIM:TX1:F DL:IB C? → 16777214
<b>Note</b>	

## 6.4 Result

### 6.4.1 T1:RX<Pt>:IFETch?

<b>Syntax</b>	T1:RX<Pt>:IFETch? <parameter>
<b>Description</b>	This command fetches results from a T1 interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{(&lt;parameter&gt;} + {, }*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>NSIGNAL: No signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AIS: Alarm indication Signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>OOF: Out of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>NSYNc: No sync (LSS). Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RAI: Remote Alarm Indication. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>PATtern: Pattern. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PSLip: Pattern slip. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PBLock: Pattern block. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CODE: Bipolar Violation (BPV). Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>FBIT: F-bit. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>SBIT: S-bit. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CRC6: CRC-6. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>EZERro: Excessive Zeroes. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>FAS performance errors</b></p> <p>FES: FAS ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FSES: FAS SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FBBE: FAS BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FALS: FAS ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FUAT: FAS UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FAVT: FAS AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FEFS: FAS EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>Pattern performance errors</b></p> <p>PES: Pattern ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSES: Pattern SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PBBE: Pattern BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PALS: Pattern ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PUAT: Pattern UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PAVT: Pattern AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PEFS: Pattern EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>CRC6 performance errors</b></p> <p>CES: CRC6 ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CSES: CRC6 SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CBBE: CRC6 BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CALS: CRC6 ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CUAT: CRC6 UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CAVT: CRC6 AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>CEFS: CRC6 EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;), }* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Expression format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field. Values that are not relevant or applicable for the current measurement, returns NaN (section 1.6.1).</p>
<b>Example</b>	T1:RX1:IFET? (AIS,PATT) → (9,0.0429) ,(10,0.0343)
<b>Note</b>	This command fetches the results from the interval selected using the MEASurement:SEtup:SElect command (see section 17.2.2). If the requested result is not available, NaN (section 1.6.1) is returned. If there is one or more results, the last “,” is always removed.

## 6.5 Status

### 6.5.1 T1:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	T1:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns alarms and errors summary event register. The content of this event register is summarized in DB7 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:AES? → 1 T1:STAT:RX1:AES:EVENT? → 1
<b>Note</b>	

### 6.5.2 T1:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	T1:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary operation register query.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:AES:COND? → 1
<b>Note</b>	

### 6.5.3 T1:STATus:RX<Pt>:ALARm[:EVENT]?

<b>Syntax</b>	T1:STATus:RX<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns alarms event register query. The content of this register is summarized in DB1 of the T1:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No sync (LSS) DB2 (2) = NOT USED DB3 (4) = CRC6err DB4 (8) = Remote Alarm Indication (RAI) DB5 (16) = NOT USED DB6 (32) = Out of frame (OOF) DB7 (64) = Alarm indication signal (AIS) DB8 (128) = No signal DB9 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:ALAR? → 64
<b>Note</b>	

## 6.5.4 T1:STATus:RX&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	T1:STATus:RX<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns alarms condition register query.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No sync (LSS) DB2 (2) = NOT USED DB3 (4) = CRC6err DB4 (8) = Remote Alarm Indication (RAI) DB5 (16) = NOT USED DB6 (32) = Out of frame (OOF) DB7 (64) = Alarm indication signal (AIS) DB8 (128) = No signal DB9 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:ALAR:COND? → 64
<b>Note</b>	

## 6.5.5 T1:STATus:RX&lt;Pt&gt;:ERRor[:EVENT]?

<b>Syntax</b>	T1:STATus:RX<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns errors event register. The content of this register is summarized in DB2 of the T1:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern slip DB2 (2) = Pattern DB3 (4) = S-Bit DB4 (8) = CRC-6 DB5 (16) = NOT USED DB6 (32) = Excessive Zeroes (EXZ) DB7 (64) = F-Bit DB8 (128) = Bipolar Violation (BPV) DB9 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:ERR? → 64
<b>Note</b>	

## 6.5.6 T1:STATus:RX&lt;Pt&gt;:ERRor:CONDition?

<b>Syntax</b>	T1:STATus:RX<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns errors condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern slip DB2 (2) = Pattern DB3 (4) = S-Bit DB4 (8) = CRC-6 DB5 (16) = NOT USED DB6 (32) = Excessive Zeroes (EXZ) DB7 (64) = F-Bit DB8 (128) = Bipolar Violation (BPV) DB9 - DB16 = NOT USED
<b>Example</b>	T1:STAT:RX1:ERR:COND? → 64
<b>Note</b>	

## 6.5.7 T1:STATus:RX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	T1:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns physical signal level. Unit: dB.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:PSL? → 0
<b>Note</b>	Minimum level is -11 dB.

## 6.5.8 T1:STATus:RX&lt;Pt&gt;:PDEVIation?

<b>Syntax</b>	T1:STATus:RX<Pt>:PDEVIation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:PDEV? → 0, 0
<b>Note</b>	

## 6.5.9 T1:STATus:RX&lt;Pt&gt;:PBRate?

<b>Syntax</b>	T1:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:PBR? → 1544000
<b>Note</b>	

## 6.5.10 T1:STATus:RX&lt;Pt&gt;:FDUMp?

<b>Syntax</b>	T1:STATus:RX<Pt>:FDUMp?
<b>Description</b>	This query returns a sample of a full DS1 Frame (24 bytes).
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<hex> = <EXPRESSION RESPONSE DATA> Expression format: Numeric list Contains all 24 Frame timeslots.
<b>Example</b>	T1:STAT:RX1:FDUM? → #H55,#H55,#H55,...
<b>Note</b>	

## 6.5.11 T1:STATus:RX&lt;Pt&gt;:ACONtent?

<b>Syntax</b>	T1:STATus:RX<Pt>:ACONtent?
<b>Description</b>	This query returns audio channel content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiocontent> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:ACON? → #B01010101
<b>Note</b>	For sub-rates this field shows the content of the sub channel.

## 6.5.12 T1:STATus:RX&lt;Pt&gt;:AIBContent?

<b>Syntax</b>	T1:STATus:RX<Pt>:AIBContent?
<b>Description</b>	This query returns sub channel audio all bit inverting content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiocontent> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:AIBC? → #B10000000
<b>Note</b>	With u-law coded speech, it is possible to observe the u-law code words before the bit inverting.

**6.5.13 T1:STATus:RX<Pt>:APPeak?**

<b>Syntax</b>	T1:STATus:RX<Pt>:APPeak?
<b>Description</b>	This query returns sub channel audio positive peak value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<positivepeak> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:APP? → 85
<b>Note</b>	This query only applies for u-law speech and shows the largest received u-law coded value.

**6.5.14 T1:STATus:RX<Pt>:ANPeak?**

<b>Syntax</b>	T1:STATus:RX<Pt>:ANPeak?
<b>Description</b>	This query returns sub channel audio negative peak value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<negativepeak> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:ANP? → -85
<b>Note</b>	This query only applies for u-law speech and shows the smallest received u-law coded value.

**6.5.15 T1:STATus:RX<Pt>:ALEVel?**

<b>Syntax</b>	T1:STATus:RX<Pt>:ALEVel?
<b>Description</b>	This query returns sub channel audio level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiollevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:ALEV? → -4
<b>Note</b>	

**6.5.16 T1:STATus:RX<Pt>:AFRequency?**

<b>Syntax</b>	T1:STATus:RX<Pt>:AFRequency?
<b>Description</b>	This query returns sub channel audio tone frequency. Unit: Hz.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<audiofrequency> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:AFR? → 366
<b>Note</b>	

**6.5.17 T1:STATus:RX<Pt>:ACOFfset?**

<b>Syntax</b>	T1:STATus:RX<Pt>:ACOFfset?
<b>Description</b>	This query returns sub channel audio coder offset.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<coderoffset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:ACOF? → 0
<b>Note</b>	Only available for 64 kbps audio channels.

**6.5.18 T1:STATus:RX<Pt>:PPBRate?**

<b>Syntax</b>	T1:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns payload pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:PPBR? → 64000
<b>Note</b>	

## 6.5.19 T1:STATus:RX&lt;Pt&gt;:FBIT?

<b>Syntax</b>	T1:STATus:RX<Pt>:FBIT?
<b>Description</b>	This query returns FAS bits. (Frame Alignment Signal bits). Data is shown as binary.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FBIT? → #B101010
<b>Note</b>	

## 6.5.20 T1:STATus:RX&lt;Pt&gt;:SBIT?

<b>Syntax</b>	T1:STATus:RX<Pt>:SBIT?
<b>Description</b>	This query returns S-Bits (Multi Frame Alignment Signal bits). Data is shown as binary.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:SBIT? → #B001110
<b>Note</b>	

## 6.5.21 T1:STATus:RX&lt;Pt&gt;:MBIT?

<b>Syntax</b>	T1:STATus:RX<Pt>:MBIT?
<b>Description</b>	This query returns M-Bits (Data Link Message bits). Data is shown as binary.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:MBIT? → #B000000000000000
<b>Note</b>	

## 6.5.22 T1:STATus:RX&lt;Pt&gt;:FDL:MODE

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:MODE <interface>
<b>Description</b>	This command selects the FDL mode. This can be MBIT or INBand.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> MBIT INBand <i>DEFault = MBIT</i>
<b>Response</b>	None.
<b>Example</b>	T1:STAT:RX1:FDL:MODE INB
<b>Note</b>	

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:MODE?
<b>Description</b>	This query returns the state of the FDL mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:MODE? → MBIT
<b>Note</b>	

## 6.5.23 T1:STATus:RX&lt;Pt&gt;:FDL:MBIT:CODE?

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:MBIT:CODE?
<b>Description</b>	This query returns MBIT FDL Code (Data Link Message mnemonic).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:MBIT:CODE? → PLA
<b>Note</b>	

## 6.5.24 T1:STATus:RX&lt;Pt&gt;:FDL:INBand:CODE?

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:INBand:CODE?
<b>Description</b>	This query returns Inband FDL Code (Data Link Message mnemonic).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:INB:CODE? → AN1
<b>Note</b>	

## 6.5.25 T1:STATus:RX&lt;Pt&gt;:FDL:UDEFined

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:UDEFined <enable>
<b>Description</b>	This command enables or disables the User Defined check mark.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:STAT:RX1:FDL:UDEF 1
<b>Note</b>	

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:UDEFined?
<b>Description</b>	This query returns the state of the User Defined check mark.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:UDEF? → 1
<b>Note</b>	

## 6.5.26 T1:STATus:RX&lt;Pt&gt;:FDL:UCODE

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:UCODE <max>
<b>Description</b>	This command sets the FDL User Code.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 16777215, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	T1:STAT:RX1:FDL:UCOD 123456
<b>Note</b>	

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:UCODE?
<b>Description</b>	This query returns the FDL User Code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:UCOD? → 123456
<b>Note</b>	

## 6.5.27 T1:STATus:RX&lt;Pt&gt;:FDL:TRIGger

<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:TRIGger <interface>
<b>Description</b>	This command enables or disables the FDL trigger.
<b>Parameters</b>	<Pt> = Port number <interface> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T1:STAT:RX1:FDL:TRIG ON
<b>Note</b>	



<b>Syntax</b>	T1:STATus:RX<Pt>:FDL:TRIGger?
<b>Description</b>	This query returns the state of the FDL trigger.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	T1:STAT:RX1:FDL:TRIG? → 1
<b>Note</b>	

### 6.5.28 T1:STATus:RX<Pt>:CBITs?

<b>Syntax</b>	T1:STATus:RX<Pt>:CBITs?
<b>Description</b>	This query returns CAS bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bits> = <EXPRESSION RESPONSE DATA> Expression format: Numeric list Contains all 24 CAS bit sets.
<b>Example</b>	T1:STAT:RX1:CBIT? → (#B0101,#B0101, ..., #B0101,#B0101)
<b>Note</b>	

## 6.6 APS

### 6.6.1 T1:APS:START

<b>Syntax</b>	T1:APS:START
<b>Description</b>	This command starts the APS (Automatic Protection Switching).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	T1:APS:STAR
<b>Note</b>	

### 6.6.2 T1:APS:STOP

<b>Syntax</b>	T1:APS:STOP
<b>Description</b>	This command stops the APS (Automatic Protection Switching) command.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	T1:APS:STOP
<b>Note</b>	

### 6.6.3 T1:APS:RX<Pt>:NUMBER?

<b>Syntax</b>	T1:APS:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of times a reference event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:APS:RX1:NUMB? → 17
<b>Note</b>	

### 6.6.4 T1:APS:RX<Pt>:ATIME?

<b>Syntax</b>	T1:APS:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:APS:RX1:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

### 6.6.5 T1:APS:RX<Pt>:MTIME?

<b>Syntax</b>	T1:APS:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	T1:APS:RX1:MTIM? → 29.170,0
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

### 6.6.6 T1:APS:RX<Pt>:LTIMe?

<b>Syntax</b>	T1:APS:RX<Pt>:LTIMe?
<b>Description</b>	This query returns the minimum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:APS:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time is 4000 ms. The maximum measurable time will be responded if the result exceeds 4000 ms.

### 6.6.7 T1:APS:RX<Pt>:EVENT

<b>Syntax</b>	T1:APS:RX<Pt>:EVENTt <event>
<b>Description</b>	This command sets the Time Reference event.
<b>Parameters</b>	<Pt> = Port number <event> = <CHARACTER PROGRAM DATA> AIS = Alarm indication signal OOF = Out of frame PERRor = Pattern error
<b>Response</b>	None.
<b>Example</b>	T1:APS:RX1:EVEN AIS
<b>Note</b>	

<b>Syntax</b>	T1:APS:RX<Pt>:EVENT?
<b>Description</b>	This query returns the time reference event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T1:APS:RX1:EVEN? → AIS
<b>Note</b>	

### 6.6.8 T1:APS:RX<Pt>:MLIMit

<b>Syntax</b>	T1:APS:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 4000.000, DEFault = 50.000</i>
<b>Response</b>	None.
<b>Example</b>	T1:APS:RX1:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	T1:APS:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:APS:RX1:MLIM? → 50.000
<b>Note</b>	

## 6.7 RTD

This section document commands to retrieve Round Trip Delay measurement results. Commands for general RTD settings are described in section 16.1 on page 837.

### 6.7.1 T1:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	T1:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 6.7.2 T1:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	T1:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 6.7.3 T1:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	T1:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	T1:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 6.7.4 T1:RTD:RX<Pt>:LTIME?

<b>Syntax</b>	T1:RTD:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T1:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

---

# Chapter 7

## E3

### 7.1 Receiver

#### 7.1.1 E3:RX<Pt>[:ENABled]

<b>Syntax</b>	E3:RX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the receiver.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	E3:RX1 ON E3:RX1:ENAB ON
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	E3:RX1? → ON E3:RX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E3 is over SDH or SONET.

#### 7.1.2 E3:RX<Pt>:MODE

<b>Syntax</b>	E3:RX<Pt>:MODE <mode>
<b>Description</b>	This command sets the signal termination mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> TERMinate: Nominal impedance. Normal frequency dependent AGC. MONitor: Nominal impedance. Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	E3:RX1:MODE TERM
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>:MODE?
<b>Description</b>	This query returns the signal termination mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:RX1:MODE? → TERM
<b>Note</b>	

## 7.1.3 E3:RX&lt;Pt&gt;:FOLLow

<b>Syntax</b>	E3:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX: Transmitter of the same port RX1: Receiver of port 1 <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	E3:RX1:FOLL TX
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>:FOLLow?
<b>Description</b>	This query returns if the receiver follow another setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:RX1:FOLL? → TX
<b>Note</b>	

## 7.1.4 E3:RX&lt;Pt&gt;:PCMFrame

<b>Syntax</b>	E3:RX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	E3:RX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RX1:PCMF? → 1
<b>Note</b>	

## 7.1.5 E3:RX&lt;Pt&gt;:PATtern

<b>Syntax</b>	E3:RX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS31 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	E3:RX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:RX1:PATT? → PRBS11
<b>Note</b>	

## 7.1.6 E3:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	E3:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	E3:RX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, FOX, ALL1, ALL0, ALT11, ALT13, ALT17, ALT324, UP16 and UP2K.

<b>Syntax</b>	E3:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RX1:PINV? → 1
<b>Note</b>	

## 7.1.7 E3:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	E3:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	E3:RX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 7.1.8 E3:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	E3:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Example</b>	E3:RX2:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	E3:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E3:RX2:UP32? → "01101"
<b>Note</b>	

## 7.1.9 E3:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	E3:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	E3:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when E3:RX2:PATT is USER2048BIT

<b>Syntax</b>	E3:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E3:RX1:UP2K? → "12DF"
<b>Note</b>	



## 7.2 Transmitter

### 7.2.1 E3:TX<Pt>[:ENABled]

<b>Syntax</b>	E3:TX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the transmitter.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	E3:TX1 ON E3:TX1:ENAB ON
<b>Note</b>	The ENABled command is the default node for E3:TX<Pt>.

<b>Syntax</b>	E3:TX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	E3:TX1? → ON E3:TX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E3 is over SDH or SONET.

### 7.2.2 E3:TX<Pt>:FOLLow

<b>Syntax</b>	E3:TX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the transmitter setting to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX1: Follow the setting of the port 1 transmitter <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	E3:TX2:FOLL TX1
<b>Note</b>	This command is not valid for :TX1

<b>Syntax</b>	E3:TX<Pt>:FOLLow?
<b>Description</b>	This query returns if the transmitter follow the TX1 settings.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:TX2:FOLL? → TX1
<b>Note</b>	This command is not valid for :TX1

### 7.2.3 E3:TX<Pt>:TIMing

<b>Syntax</b>	E3:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal timing source EXTernal: External timing source RX: Received signal on the same port <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	E3:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:TX1:TIM? → INT
<b>Note</b>	

#### 7.2.4 E3:TX<Pt>:FOFFset

<b>Syntax</b>	E3:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-125, MAXimum=125, DEFault=0</i> <i>Allowed suffix = ppm</i>
<b>Response</b>	None.
<b>Example</b>	E3:TX1:FOFF -25ppm
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:TX1:FOFF? → -25
<b>Note</b>	

#### 7.2.5 E3:TX<Pt>:PCMFframe

<b>Syntax</b>	E3:TX<Pt>:PCMFframe <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	E3:TX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:PCMFframe?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:TX1:PCMF? → 1
<b>Note</b>	

## 7.2.6 E3:TX&lt;Pt&gt;:PATtern

<b>Syntax</b>	E3:TX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;  OFF  USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT.  USER32BIT: 32 bit user defined pattern.  USER2048BIT: 2048 bit user defined pattern.  PRBS9  PRBS11  PRBS15  PRBS20  PRBS23  PRBS31  FOX  FOXCMA3000  ALL0  ALL1  ALT11: Alternating 1:1  ALT13: Alternating 1:3  ALT17: Alternating 1:7  ALT324: Alternating 3:24  <i>DEFault = PRBS23</i></p>
<b>Response</b>	None.
<b>Example</b>	E3:TX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:TX1:PATT? → PRBS11
<b>Note</b>	

## 7.2.7 E3:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	E3:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command sets pattern inversion.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;inverted&gt; = &lt;BOOLEAN PROGRAM DATA&gt;  <i>DEFault = OFF</i></p>
<b>Response</b>	None.
<b>Example</b>	E3:TX1:PINV ON
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:PINVersion?
<b>Description</b>	This query returns pattern inversion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:TX1:PINV? → 1
<b>Note</b>	

## 7.2.8 E3:TX&lt;Pt&gt;:UP16

<b>Syntax</b>	E3:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	E3:TX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 7.2.9 E3:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	E3:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Example</b>	E3:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	E3:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E3:TX1:UP32? → "01101"
<b>Note</b>	

## 7.2.10 E3:TX&lt;Pt&gt;:UP2K

<b>Syntax</b>	E3:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	E3:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when E3:TX2:PATT is USER2048BIT

<b>Syntax</b>	E3:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E3:TX1:UP2K? → "12DF"
<b>Note</b>	

## 7.3 Stimuli

### 7.3.1 E3:STIMuli:TX<Pt>:ALARm

<b>Syntax</b>	E3:STIMuli:TX<Pt>:ALARm <alarmtype>
<b>Description</b>	This command sets the alarm type to generate.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> NALarm: No alarm NSIGnal: No signal AIS: Alarm Indication Signal NFRame: No frame DALarm: Distant alarm (RDI) NSYNc: No pattern sync <i>DEFault = NALarm</i>
<b>Response</b>	None.
<b>Example</b>	E3:STIM:TX1:ALAR NALarm
<b>Note</b>	

<b>Syntax</b>	E3:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the stimuli alarm type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:STIM:TX1:ALAR? → NSIG
<b>Note</b>	

### 7.3.2 E3:STIMuli:TX<Pt>:ERRor

<b>Syntax</b>	E3:STIMuli:TX<Pt>:ERRor <errordestination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<Pt> = Port number <errordestination> = <CHARACTER PROGRAM DATA> FRAME: Frame CODE: Code PATtern: Pattern PSLip: Pattern slip <i>DEFault = FRAME</i>
<b>Response</b>	None.
<b>Example</b>	E3:STIM:TX1:ERR CODE
<b>Note</b>	

<b>Syntax</b>	E3:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errordestination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:STIM:TX1:ERR? → CODE
<b>Note</b>	

## 7.3.3 E3:STIMuli:TX&lt;Pt&gt;:EINSert

<b>Syntax</b>	E3:STIMuli:TX<Pt>:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B02: Burst · 1E-02 B03: Burst · 1E-03 B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	E3:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section <a href="#">2.3.14</a>

<b>Syntax</b>	E3:STIMuli:TX<Pt>:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E3:STIM:TX1:EINS? → MAN
<b>Note</b>	

## 7.3.4 E3:STIMuli:TX&lt;Pt&gt;:EBLength

<b>Syntax</b>	E3:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	E3:STIM:TX1:EBL 1
<b>Note</b>	

<b>Syntax</b>	E3:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:STIM:TX1:EBL? → 1
<b>Note</b>	

## 7.4 Results

### 7.4.1 E3:RX<Pt>:IFETch?

<b>Syntax</b>	E3:RX<Pt>:IFETch? <parameters>
<b>Description</b>	This query fetches an interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{(&lt;parameter&gt;} + {, }*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>NSIG: No signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AIS: Alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>NFR: No frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>NSYN: No sync. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>DAL: Distant Alarm. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>FASW: FAS words. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CODE: Code. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PATT: Pattern. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PSL: Pattern slip. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PBL: Pattern block. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Rx frequency</b></p> <p>DEV: Frequency deviation. Response: &lt;ppm&gt;</p> <p><b>FAS performance errors</b></p> <p>FES: FAS ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FSES: FAS SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FBBE: FAS BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FALS: FAS ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FUAT: FAS UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FAVT: FAS AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FEFS: FAS EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>Pattern performance errors</b></p> <p>PES: Pattern ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSES: Pattern SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PBBE: Pattern BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PALS: Pattern ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PUAT: Pattern UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PAVT: Pattern AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PEFS: Pattern EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Expression format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	E3:RX1:IFET? (FES,PATT) → (2,0.5),(4,0.25)
<b>Notes</b>	<p>This command fetches the result from the interval selected by the MEASurement:SEtup:SElect command (see section 17.2.2).</p> <p>NFR, DAL, FASW, FASB return NaN (section 1.6.1), if the PCM frame is disabled (E3:RX&lt;Pt&gt;:PCMFrame? → 0).</p> <p>If requested result is not available, NaN (section 1.6.1) is returned.</p> <p>If there is one or more results, the last "," is always removed.</p>

## 7.5 Status

### 7.5.1 E3:STATus:RX<Pt>:PSLevel?

<b>Syntax</b>	E3:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns physical signal level. Unit: dB.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:STAT:RX1:PSL? → 0
<b>Note</b>	Minimum level is -48 dB.

### 7.5.2 E3:STATus:RX<Pt>:PDEVIation?

<b>Syntax</b>	E3:STATus:RX<Pt>:PDEVIation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:STAT:RX1:PDEV? → 0, 0
<b>Note</b>	

### 7.5.3 E3:STATus:RX<Pt>:PBRate?

<b>Syntax</b>	E3:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:STAT:RX1:PBR? → 34368000
<b>Note</b>	

### 7.5.4 E3:STATus:RX<Pt>:PPBRate?

<b>Syntax</b>	E3:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns payload pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:STAT:RX1:PPBR? → 34099504
<b>Note</b>	

### 7.5.5 E3:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	E3:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the E3 alarms and errors summary event register. The content of this event register is summarized in DB3 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:AES? → 1
<b>Note</b>	



### 7.5.6 E3:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	E3:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the E3 alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:AES:COND? → 2
<b>Note</b>	

### 7.5.7 E3:STATus:RX<Pt>:ALARm[:EVENT]?

<b>Syntax</b>	E3:STATus:RX<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the E3:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = Alarm Indication Signal (AIS) DB3 (4) = No frame DB4 (8) = Distant DB5 (16) = No sync DB6 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:ALAR? → 2
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (E3:RX<Pt>:PCMFrame? → 1).

### 7.5.8 E3:STATus:RX<Pt>:ALARm:CONDition?

<b>Syntax</b>	E3:STATus:RX<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = Alarm Indication Signal (AIS) DB3 (4) = No frame DB4 (8) = Distant DB5 (16) = No sync DB6 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:ALAR:COND? → 4
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (E3:RX<Pt>:PCMFrame? → 1).

**7.5.9 E3:STATus:RX<Pt>:ERRor[:EVENT]?**

<b>Syntax</b>	E3:STATus:RX<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the E3:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = FAS words DB2 (2) = NOT USED DB3 (4) = Pattern DB4 (8) = Code DB5 (16) = Pattern slip (PSL) DB6 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:ERR? → 8
<b>Notes</b>	The FAS words and FAS bits are only valid when the PCM frame is enabled (E3:RX<Pt>:PCMFrame? → 1). The Code is not valid when using E3 over SDH.

**7.5.10 E3:STATus:RX<Pt>:ERRor:CONDition?**

<b>Syntax</b>	E3:STATus:RX<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = FAS words DB2 (2) = NOT USED DB3 (4) = Pattern DB4 (8) = Code DB5 (16) = Pattern slip (PSL) DB6 - DB16 = NOT USED
<b>Example</b>	E3:STAT:RX1:ERR:COND? → 8
<b>Note</b>	The FAS words and FAS bits are only valid when the PCM frame is enabled (E3:RX<Pt>:PCMFrame? → 1). The Code is not valid when using E3 over SDH.

## 7.6 RTD

This section document commands to retrieve Round Trip Delay measurement results. Commands for general RTD settings are described in section 16.1 on page 837.

### 7.6.1 E3:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	E3:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 7.6.2 E3:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	E3:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 7.6.3 E3:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	E3:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 7.6.4 E3:RTD:RX<Pt>:LTIME?

<b>Syntax</b>	E3:RTD:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	E3:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.



---

## Chapter 8

# T3

### 8.1 Receiver

#### 8.1.1 T3:RX<Pt>[:ENABled]

<b>Syntax</b>	T3:RX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the receiver.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	T3:RX1 ON T3:RX1:ENAB ON
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	T3:RX1? → ON T3:RX1:ENAB? → SDH
<b>Note</b>	Returns SDH if T3 is over SDH or SONET.

#### 8.1.2 T3:RX<Pt>:MODE

<b>Syntax</b>	T3:RX<Pt>:MODE <mode>
<b>Description</b>	This command sets the signal termination mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> TERMinate: Nominal impedance. Normal frequency dependent AGC. MONitor: Nominal impedance. Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:MODE TERM
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:MODE?
<b>Description</b>	This query returns the signal termination mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:RX1:MODE? → TERM
<b>Note</b>	

## 8.1.3 T3:RX&lt;Pt&gt;:FOLLow

<b>Syntax</b>	T3:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX: Transmitter of the same port RX1: Receiver of port 1 <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:FOLL TX
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:FOLLow?
<b>Description</b>	This query returns if the receiver follow another setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:RX1:FOLL? → TX
<b>Note</b>	

## 8.1.4 T3:RX&lt;Pt&gt;:PCMFrame

<b>Syntax</b>	T3:RX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:RX1:PCMF? → 1
<b>Note</b>	

## 8.1.5 T3:RX&lt;Pt&gt;:FTYPE

<b>Syntax</b>	T3:RX<Pt>:FTYPE <type>
<b>Description</b>	This command sets the PCM frame type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> M13: M13 mode CBIT: C-bit mode <i>DEFault = M13</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:FTYP CBIT
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:FTYPE?
<b>Description</b>	This query returns PCM frame type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:RX1:FTYP? → CBIT
<b>Note</b>	

## 8.1.6 T3:RX&lt;Pt&gt;:PATtern

<b>Syntax</b>	T3:RX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:RX1:PATT? → PRBS11
<b>Note</b>	

## 8.1.7 T3:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	T3:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	T3:RX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, FOX, ALL1, ALL0, ALT11, ALT13, ALT17, ALT324, UP16 and UP2K.

<b>Syntax</b>	T3:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:RX1:PINV? → 1
<b>Note</b>	

## 8.1.8 T3:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	T3:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	T3:RX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 8.1.9 T3:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	T3:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters.
<b>Response</b>	None.
<b>Example</b>	T3:RX2:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	T3:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T3:RX2:UP32? → "01101"
<b>Note</b>	

## 8.1.10 T3:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	T3:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	T3:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when T3:RX2:PATT is USER2048BIT

<b>Syntax</b>	T3:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T3:RX1:UP2K? → "12DF"
<b>Note</b>	



## 8.2 Transmitter

### 8.2.1 T3:TX<Pt>[:ENABled]

<b>Syntax</b>	T3:TX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the transmitter.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	T3:TX1 ON T3:TX1:ENAB ON
<b>Note</b>	The ENABled command is the default node for T3:TX<Pt>.

<b>Syntax</b>	T3:TX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	T3:TX1? → ON T3:TX1:ENAB? → SDH
<b>Note</b>	Returns SDH if T3 is over SDH or SONET.

### 8.2.2 T3:TX<Pt>:FOLLow

<b>Syntax</b>	T3:TX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the transmitter setting to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX1: Follow the setting of the port 1 transmitter <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX2:FOLL TX1
<b>Note</b>	This command is not valid for :TX1

<b>Syntax</b>	T3:TX<Pt>:FOLLow?
<b>Description</b>	This query returns if the transmitter follow the TX1 settings.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:TX2:FOLL? → TX1
<b>Note</b>	This command is not valid for :TX1

### 8.2.3 T3:TX<Pt>:TIMing

<b>Syntax</b>	T3:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal timing source EXTernal: External timing source RX: Received signal on the same port <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:TX1:TIM? → INT
<b>Note</b>	

#### 8.2.4 T3:TX<Pt>:FOFFset

<b>Syntax</b>	T3:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-125, MAXimum=125, DEFault=0</i> <i>Allowed suffix = ppm</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:FOFF -25ppm
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:TX1:FOFF? → -25
<b>Note</b>	

#### 8.2.5 T3:TX<Pt>:PCMFrame

<b>Syntax</b>	T3:TX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:TX1:PCMF? → 1
<b>Note</b>	

#### 8.2.6 T3:TX<Pt>:FTYPe

<b>Syntax</b>	T3:TX<Pt>:FTYPe <type>
<b>Description</b>	This command sets the PCM frame type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> M13: M13 mode CBIT: C-bit mode <i>DEFault = M13</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:FTYP CBIT
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:FTYPE?
<b>Description</b>	This query returns PCM frame type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:TX1:FTYP? → CBIT
<b>Note</b>	

### 8.2.7 T3:TX<Pt>:LBOOut

<b>Syntax</b>	T3:TX<Pt>:LBOOut <lbo>
<b>Description</b>	This command sets the line build out.
<b>Parameters</b>	<Pt> = Port number <lbo> = <CHARACTER PROGRAM DATA> HIGH: High-0 ft DSX: DSX-450 ft <i>DEFault = HIGH</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:LBO DSX
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:LBOOut?
<b>Description</b>	This query returns the line build out setting.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lbo> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:TX1:LBO? → DSX
<b>Note</b>	

### 8.2.8 T3:TX<Pt>:PATTern

<b>Syntax</b>	T3:TX<Pt>:PATTern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 QRSS20 FOX FOXCMA3000 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	T3:TX1:PATT PRBS11
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:PATTern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:TX1:PATT? → PRBS11
<b>Note</b>	

### 8.2.9 T3:TX<Pt>:PINVersion

<b>Syntax</b>	T3:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command sets pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	T3:TX1:PINV ON
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:PINVersion?
<b>Description</b>	This query returns pattern inversion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:TX1:PINV? → 1
<b>Note</b>	

### 8.2.10 T3:TX<Pt>:UP16

<b>Syntax</b>	T3:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	T3:TX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

### 8.2.11 T3:TX<Pt>:UP32

<b>Syntax</b>	T3:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters.
<b>Response</b>	None.
<b>Examples</b>	T3:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	T3:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T3:TX1:UP32? → "01101"
<b>Note</b>	

### 8.2.12 T3:TX<Pt>:UP2K

<b>Syntax</b>	T3:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	T3:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when T3:TX2:PATT is USER2048BIT

<b>Syntax</b>	T3:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	T3:TX1:UP2K? → "12DF"
<b>Note</b>	

## 8.3 Stimuli

### 8.3.1 T3:STIMuli:TX<Pt>:ALARm

<b>Syntax</b>	T3:STIMuli:TX<Pt>:ALARm <alarmtype>
<b>Description</b>	This command sets the alarm type to generate.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> NALarm: No alarm NSIGnal: No signal AIS: Alarm Indication Signal RAI: Remote Alarm Indication IDLE: Idle NFRame: No frame (LOF) NSYNc: No pattern sync (LSS) <i>DEFault = NALarm</i>
<b>Response</b>	None.
<b>Example</b>	T3:STIM:TX1:ALAR NALarm
<b>Note</b>	

<b>Syntax</b>	T3:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the stimuli alarm type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:STIM:TX1:ALAR? → NSIG
<b>Note</b>	

### 8.3.2 T3:STIMuli:TX<Pt>:ERRor

<b>Syntax</b>	T3:STIMuli:TX<Pt>:ERRor <errordestination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<Pt> = Port number <errordestination> = <CHARACTER PROGRAM DATA> OFF CBIT: C-Bit FBIT: F-Bit PBIT: P-Bit FEBE: PATtern: Pattern Error PSLip: Pattern slip BPV: <i>DEFault = FBIT</i>
<b>Response</b>	None.
<b>Example</b>	T3:STIM:TX1:ERR FEBE
<b>Note</b>	

<b>Syntax</b>	T3:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errordestination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:STIM:TX1:ERR? → FEBE
<b>Note</b>	

## 8.3.3 T3:STIMuli:TX&lt;Pt&gt;:EINSert

<b>Syntax</b>	T3:STIMuli:TX<Pt>:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B02: Burst · 1E-02 B03: Burst · 1E-03 B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	T3:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14

<b>Syntax</b>	T3:STIMuli:TX<Pt>:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	T3:STIM:TX1:EINS? → MAN
<b>Note</b>	

## 8.3.4 T3:STIMuli:TX&lt;Pt&gt;:EBLength

<b>Syntax</b>	T3:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	T3:STIM:TX1:EBL 1
<b>Note</b>	

<b>Syntax</b>	T3:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:STIM:TX1:EBL? → 1
<b>Note</b>	

## 8.4 Results

### 8.4.1 T3:RX<Pt>:IFETch?

<b>Syntax</b>	T3:RX<Pt>:IFETch? <parameters>
<b>Description</b>	This query fetches an interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{&lt;parameter&gt;} + {,}* = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>NSIG: No signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AIS: Alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>NFR: No frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>NSYN: No sync (LSS). Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>DAL: Distant Alarm (RAI). Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>IDLE: Idle alarm. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>CODE: Code (BPV). Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>FBIT: F-bit. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CBIT: C-bit. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PATT: Pattern. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PSL: Pattern slip. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PBL: Pattern block. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PAR: Parity. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>FEBE: FEBE. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Rx frequency</b></p> <p>DEV: Frequency deviation. Response: &lt;ppm&gt;</p> <p><b>FAS performance errors</b></p> <p>FES: FAS ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FSES: FAS SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FBBE: FAS BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FALS: FAS ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FUAT: FAS UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FAVT: FAS AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>FEFS: FAS EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>Pattern performance errors</b></p> <p>PES: Pattern ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSES: Pattern SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PBBE: Pattern BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PALS: Pattern ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PUAT: Pattern UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PAVT: Pattern AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PEFS: Pattern EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Expression format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN.</p>
<b>Example</b>	T3:RX1:IFET? (FES,PATT) → (2,0.5),(4,0.25)
<b>Notes</b>	<p>This command fetches the result from the interval selected by the MEASurement:SEtup:SElect command (see section 17.2.2).</p> <p>NFR, DAL, FASW, FASB return NaN, if the PCM frame is disabled (T3:RX&lt;Pt&gt;:PCMFrame? → 0).</p> <p>If requested result is not available, NaN is returned.</p> <p>If there is one or more results, the last ",," is always removed.</p>



## 8.5 Status

### 8.5.1 T3:STATus:RX<Pt>:PSLevel?

<b>Syntax</b>	T3:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns physical signal level. Unit: dB.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:STAT:RX1:PSL? → 0
<b>Note</b>	Minimum level is -48 dB.

### 8.5.2 T3:STATus:RX<Pt>:PDEVIation?

<b>Syntax</b>	T3:STATus:RX<Pt>:PDEVIation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:STAT:RX1:PDEV? → 0, 0
<b>Note</b>	

### 8.5.3 T3:STATus:RX<Pt>:PBRate?

<b>Syntax</b>	T3:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:STAT:RX1:PBR? → 44736000
<b>Note</b>	

### 8.5.4 T3:STATus:RX<Pt>:PPBRate?

<b>Syntax</b>	T3:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns payload pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:STAT:RX1:PPBR? → 44209704
<b>Note</b>	

### 8.5.5 T3:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	T3:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the T3 alarms and errors summary event register. The content of this event register is summarized in DB11 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:AES? → 1
<b>Note</b>	

## 8.5.6 T3:STATus:RX&lt;Pt&gt;:AESummary:CONDition?

<b>Syntax</b>	T3:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the T3 alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:AES:COND? → 2
<b>Note</b>	

## 8.5.7 T3:STATus:RX&lt;Pt&gt;:ALARm[:EVENT]?

<b>Syntax</b>	T3:STATus:RX<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the T3:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = NOT USED DB3 (4) = Alarm Indication Signal (AIS) DB4 (8) = No frame (LOF) DB5 (16) = NOT USED DB6 (32) = Distant (RAI) DB7 (64) = No sync (LSS) DB8 (128) = Idle DB9 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:ALAR? → 2
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (T3:RX<Pt>:PCMFrame? → 1).

## 8.5.8 T3:STATus:RX&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	T3:STATus:RX<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = NOT USED DB3 (4) = Alarm Indication Signal (AIS) DB4 (8) = No frame (LOF) DB5 (16) = NOT USED DB6 (32) = Distant (RAI) DB7 (64) = No sync (LSS) DB8 (128) = Idle DB9 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:ALAR:COND? → 4
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (T3:RX<Pt>:PCMFrame? → 1).

## 8.5.9 T3:STATus:RX&lt;Pt&gt;:ERRor[:EVENT]?

<b>Syntax</b>	T3:STATus:RX<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the T3:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = F-bit DB2 (2) = NOT USED DB3 (4) = Pattern DB4 (8) = Code (BPV) DB5 (16) = Pattern slip (PSL) DB6 (32) = Parity DB7 (64) = C-bit DB8 (128) = FEBE DB9 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:ERR? → 8
<b>Notes</b>	The FAS words and FAS bits are only valid when the PCM frame is enabled (T3:RX<Pt>:PCMFrame? → 1). The Code is not valid when using T3 over SDH.

## 8.5.10 T3:STATus:RX&lt;Pt&gt;:ERRor:CONDition?

<b>Syntax</b>	T3:STATus:RX<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = F-bit DB2 (2) = NOT USED DB3 (4) = Pattern DB4 (8) = Code (BPV) DB5 (16) = Pattern slip (PSL) DB6 (32) = Parity DB7 (64) = C-bit DB8 (128) = FEBE DB9 - DB16 = NOT USED
<b>Example</b>	T3:STAT:RX1:ERR:COND? → 8
<b>Note</b>	The FAS words and FAS bits are only valid when the PCM frame is enabled (T3:RX<Pt>:PCMFrame? → 1). The Code is not valid when using T3 over SDH.

## 8.6 RTD

This section document commands to retrieve Round Trip Delay measurement results. Commands for general RTD settings are described in section 16.1 on page 837.

### 8.6.1 T3:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	T3:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 8.6.2 T3:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	T3:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 8.6.3 T3:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	T3:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	T3:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 8.6.4 T3:RTD:RX<Pt>:LTIME?

<b>Syntax</b>	T3:RTD:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	T3:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

---

# Chapter 9

## E4

### 9.1 Receiver

#### 9.1.1 E4:RX<Pt>[:ENABled]

<b>Syntax</b>	E4:RX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the receiver.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	E4:RX1 ON E4:RX1:ENAB ON
<b>Note</b>	ENABled is the default node for E4:RX<Pt>.

<b>Syntax</b>	E4:RX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	E4:RX1? → ON E4:RX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E4 is over SDH or SONET.

#### 9.1.2 E4:RX<Pt>:GAIN

<b>Syntax</b>	E4:RX<Pt>:GAIN <gain>
<b>Description</b>	This command sets the gain for the receiver.
<b>Parameters</b>	<Pt> = Port number <gain> = <CHARACTER PROGRAM DATA> TERMinate: Nominal impedance. Normal frequency dependent AGC. MONitor: Nominal impedance. Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:GAIN MON
<b>Note</b>	

<b>Syntax</b>	E4:RX<Pt>:GAIN?
<b>Description</b>	This query returns the gain of the receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<gain> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:RX1:GAIN? → MON
<b>Note</b>	

## 9.1.3 E4:RX&lt;Pt&gt;:FOLLow

<b>Syntax</b>	E4:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX: Transmitter of the same port RX1: Receiver of port 1 <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:FOLL TX
<b>Note</b>	

<b>Syntax</b>	E4:RX<Pt>:FOLLow?
<b>Description</b>	This query returns if the receiver follow another setup.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:RX1:FOLL? → TX
<b>Note</b>	

## 9.1.4 E4:RX&lt;Pt&gt;:PCMFrame

<b>Syntax</b>	E4:RX<Pt>:PCMFrame <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	E4:RX<Pt>:PCMFrame?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RX1:PCMF? → 1
<b>Note</b>	

## 9.1.5 E4:RX&lt;Pt&gt;:PATtern

<b>Syntax</b>	E4:RX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OFF USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT. USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 QRSS20 ALL0 ALL1 ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 ALT324: Alternating 3:24 <i>DEfault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	E4:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:RX1:PATT? → PRBS11
<b>Note</b>	

## 9.1.6 E4:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	E4:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEfault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:PINV ON
<b>Note</b>	The following patterns can be inverted: PRBSxx, QRSSxx, ALL1, ALL0, ALT11, ALT13, ALT17 and UP16.

<b>Syntax</b>	E4:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RX1:PINV? → 1
<b>Note</b>	

## 9.1.7 E4:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	E4:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535</i> <i>DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	E4:RX1:UP16 #B1111000011110000
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 9.1.8 E4:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	E4:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when <b>PATtern</b> is <b>USER32BIT</b> .
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	E4:RX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	E4:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E4:RX1:UP32? → "01101"
<b>Note</b>	

## 9.1.9 E4:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	E4:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	E4:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when E4:RX2:PATT is <b>USER2048BIT</b>

<b>Syntax</b>	E4:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E4:RX1:UP2K? → "12DF"
<b>Note</b>	



## 9.2 Transmitter

### 9.2.1 E4:TX<Pt>[:ENABled]

<b>Syntax</b>	E4:TX<Pt>[:ENABled] <state>
<b>Description</b>	This command enables/disables the transmitter.
<b>Parameters</b>	<Pt> = Port number <state> = <CHARACTER PROGRAM DATA> OFF ON <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	E4:TX ON E4:TX1:ENAB ON
<b>Note</b>	The ENABled command is the default node for E4:TX.

<b>Syntax</b>	E4:TX<Pt>[:ENABled]?
<b>Description</b>	This query returns the state (enabled/disabled) of the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<state> = <CHARACTER RESPONSE DATA>
<b>Examples</b>	E4:TX? → ON E4:TX1:ENAB? → SDH
<b>Note</b>	Returns SDH if E4 is over SDH or SONET.

### 9.2.2 E4:TX<Pt>:FOLLow

<b>Syntax</b>	E4:TX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the transmitter setting to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <follow> = <CHARACTER PROGRAM DATA> NONE: Do not follow TX1: Follow the setting of the port 1 transmitter <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	E4:TX2:FOLL TX1
<b>Note</b>	This command is not valid for :TX1

<b>Syntax</b>	E4:TX<Pt>:FOLLow?
<b>Description</b>	This query returns if the transmitter follow the TX1 settings.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<follow> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:TX2:FOLL? → TX1
<b>Note</b>	This command is not valid for :TX1

### 9.2.3 E4:TX<Pt>:TIMing

<b>Syntax</b>	E4:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal timing source EXTernal: External timing source RX: Received signal on the same port <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:TX1:TIM? → INT
<b>Note</b>	

#### 9.2.4 E4:TX<Pt>:FOFFset

<b>Syntax</b>	E4:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-125, MAXimum=125, DEFault=0</i> <i>Allowed suffix = ppm</i>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:FOFF 0ppm
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:TX1:FOFF? → 0
<b>Note</b>	Returned value is in ppm.

#### 9.2.5 E4:TX<Pt>:PCMFframe

<b>Syntax</b>	E4:TX<Pt>:PCMFframe <enable>
<b>Description</b>	This command enables or disables the PCM frame.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:PCMF ON
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:PCMFframe?
<b>Description</b>	This query returns whether or not PCM frame is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:TX1:PCMF? → 1
<b>Note</b>	

## 9.2.6 E4:TX&lt;Pt&gt;:PATtern

<b>Syntax</b>	E4:TX<Pt>:PATtern <type>
<b>Description</b>	This command sets the pattern type.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;  OFF  USER16BIT: Obsolete. For backward compatibility only. Same as USER32BIT.  USER32BIT: 32 bit user defined pattern.  USER2048BIT: 2048 bit user defined pattern.  PRBS9  PRBS11  PRBS15  PRBS20  PRBS23  PRBS29  PRBS31  QRSS20  ALL0  ALL1  ALT11: Alternating 1:1  ALT13: Alternating 1:3  ALT17: Alternating 1:7  ALT324: Alternating 3:24  <i>DEFault = PRBS23</i></p>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:TX1:PATT? → PRBS11
<b>Note</b>	

## 9.2.7 E4:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	E4:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command sets pattern inversion.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;inverted&gt; = &lt;BOOLEAN PROGRAM DATA&gt;  <i>DEFault = OFF</i></p>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:PINV ON
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:PINVersion?
<b>Description</b>	This query returns pattern inversion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:TX1:PINV? → 1
<b>Note</b>	

## 9.2.8 E4:TX&lt;Pt&gt;:UP16

<b>Syntax</b>	E4:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535</i> <i>DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	E4:TX1:UP16 #B1111000011110000
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 9.2.9 E4:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	E4:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when <b>PATtern</b> is <b>USER32BIT</b> .
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	E4:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	E4:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E4:TX1:UP32? → "01101"
<b>Note</b>	

## 9.2.10 E4:TX&lt;Pt&gt;:UP2K

<b>Syntax</b>	E4:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	E4:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when E4:TX2:PATT is <b>USER2048BIT</b>

<b>Syntax</b>	E4:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	E4:TX1:UP2K? → "12DF"
<b>Note</b>	

## 9.3 Stimuli

### 9.3.1 E4:STIMuli:TX<Pt>:ALARm

<b>Syntax</b>	E4:STIMuli:TX<Pt>:ALARm <alarmtype>
<b>Description</b>	This command sets the alarm type to generate.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> NALarm: No alarm NSIGnal: No signal AIS: Alarm Indication Signal NFRame: No frame DALarm: Distant alarm (RDI) NSYNc: No pattern sync <i>DEFault = NALarm</i>
<b>Response</b>	None.
<b>Example</b>	E4:STIM:TX1:ALAR NSIG
<b>Note</b>	

<b>Syntax</b>	E4:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the stimuli alarm type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:STIM:TX1:ALAR? → NSIG
<b>Note</b>	

### 9.3.2 E4:STIMuli:TX<Pt>:ERRor

<b>Syntax</b>	E4:STIMuli:TX<Pt>:ERRor <errordestination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<Pt> = Port number <errordestination> = <CHARACTER PROGRAM DATA> FRAMe: Frame PATTern: Pattern PSLip: Pattern slip <i>DEFault = FRAMe</i>
<b>Response</b>	None.
<b>Example</b>	E4:STIM:TX1:ERR PATT
<b>Note</b>	

<b>Syntax</b>	E4:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errordestination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:STIM:TX1:ERR? → PATT
<b>Note</b>	

### 9.3.3 E4:STIMuli:TX<Pt>:EINSert

<b>Syntax</b>	E4:STIMuli:TX<Pt>:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B02: Burst · 1E-02 B03: Burst · 1E-03 B04: Burst · 1E-04 B05: Burst · 1E-05 B06: Burst · 1E-06 B07: Burst · 1E-07 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	E4:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section <a href="#">2.3.14</a>

<b>Syntax</b>	E4:STIMuli:TX<Pt>:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	E4:STIM:TX1:EINS? → MAN
<b>Note</b>	

### 9.3.4 E4:STIMuli:TX<Pt>:EBLength

<b>Syntax</b>	E4:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	E4:STIM:TX1:EBL 1
<b>Note</b>	

<b>Syntax</b>	E4:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:STIM:TX1:EBL? → 1
<b>Note</b>	

## 9.4 Status

### 9.4.1 E4:STATus:RX<Pt>:PSLevel?

<b>Syntax</b>	E4:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns physical signal level. Unit: dB.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA>
<b>Example</b>	E4:STAT:RX1:PSL? → "-0.5"
<b>Notes</b>	If signal levels is too high, the response will be "TOO HIGH".

### 9.4.2 E4:STATus:RX<Pt>:PDEVIation?

<b>Syntax</b>	E4:STATus:RX<Pt>:PDEVIation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:STAT:RX1:PDEV? → 1,136
<b>Note</b>	

### 9.4.3 E4:STATus:RX<Pt>:PBRate?

<b>Syntax</b>	E4:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:STAT:RX1:PBR? → 139264000
<b>Note</b>	

### 9.4.4 E4:STATus:RX<Pt>:PPBRate?

<b>Syntax</b>	E4:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns payload pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:STAT:RX1:PPBR? → 137361488
<b>Note</b>	

### 9.4.5 E4:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	E4:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the E4 alarms and errors summary event register. The content of this event register is summarized in DB4 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:AES? → 1
<b>Note</b>	

## 9.4.6 E4:STATus:RX&lt;Pt&gt;:AESummary:CONDition?

<b>Syntax</b>	E4:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the E4 alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:AES:COND? → 2
<b>Note</b>	

## 9.4.7 E4:STATus:RX&lt;Pt&gt;:ALARm[:EVENT]?

<b>Syntax</b>	E4:STATus:RX<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the E4:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = Alarm Indication Signal (AIS) DB3 (4) = No frame DB4 (8) = Distant DB5 (16) = No sync DB6 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:ALAR? → 2
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (E4:RX<Pt>:PCMFrame? → 1).

## 9.4.8 E4:STATus:RX&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	E4:STATus:RX<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = No signal DB2 (2) = Alarm Indication Signal (AIS) DB3 (4) = No frame DB4 (8) = Distant DB5 (16) = No sync DB6 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:ALAR:COND? → 4
<b>Note</b>	The No frame and Distant are only valid when the PCM frame is enabled (E4:RX<Pt>:PCMFrame? → 1).



## 9.4.9 E4:STATus:RX&lt;Pt&gt;:ERRor[:EVENT]?

<b>Syntax</b>	E4:STATus:RX<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the E4:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = FAS words DB2 - DB3 = NOT USED DB4 (8) = Pattern DB5 (16) = Pattern slip DB6 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:ERR? → 8
<b>Note</b>	The FAS words is only valid when PCM frame is enabled (E4:RX<Pt>:PCMFrame? → 1).

## 9.4.10 E4:STATus:RX&lt;Pt&gt;:ERRor:CONDition?

<b>Syntax</b>	E4:STATus:RX<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = FAS words DB2 - DB3 = NOT USED DB4 (8) = Pattern DB5 (16) = Pattern slip DB6 - DB16 = NOT USED
<b>Example</b>	E4:STAT:RX1:ERR:COND? → 8
<b>Notes</b>	The FAS words is only valid when the PCM frame is enabled (E4:RX<Pt>:PCMFrame? → 1).

## 9.5 Results

### 9.5.1 E4:RX<Pt>:IFETch?

<b>Syntax</b>	E4:RX<Pt>:IFETch? <parameters>
<b>Description</b>	This query fetches an interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{&lt;parameter&gt;} + {,}* = &lt;EXPRESSION PROGRAM DATA&gt; The response format is listed for each parameter.</p> <p><b>Alarms</b>  NSIG: No signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  AIS: Alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NFR: No frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  DAL: Distant alarm. Response: &lt;Seconds&gt;,&lt;Ratio&gt;  NSYN: No sync. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b>  FASW: FAS words. Response: &lt;Count&gt;,&lt;Ratio&gt;  PATT: PAttern. Response: &lt;Count&gt;,&lt;Ratio&gt;  PSL: Pattern Slip. Response: &lt;Count&gt;,&lt;Ratio&gt;  PBL: Pattern block. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Rx frequency</b>  DEV: Frequency deviation. Response: &lt;ppm&gt;  DIFF: Frequency difference (RX1-RX2). Response: &lt;ppm&gt; (Only for RX1, RX2 is always NaN (section 1.6.1))</p> <p><b>FAS performance errors</b>  FES: FAS ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FSES: FAS SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FBBE: FAS BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FALS: FAS ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FUAT: FAS UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FAVT: FAS AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  FEFS: FAS EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>Pattern performance errors</b>  PES: Pattern ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PSES: Pattern SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PBBE: Pattern BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PALS: Pattern ALS. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PUAT: Pattern UAT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PAVT: Pattern AVT. Response: &lt;Count&gt;,&lt;Ratio%&gt;  PEFS: Pattern EFS. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;  Expression format: Numeric List  Each result is formatted according to the specification in the parameter field.  Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	E4:RX1:IFET? (FES,PATT) → (2,0.5),(4,0.25)
<b>Notes</b>	<p>This command fetches the result from the interval selected by the MEASurement:SETup:SElect command (see section 17.2.2).  NFR, DAL, FASW, FASB will only return NaN (section 1.6.1), if the PCM frame is disabled (E4:RX&lt;Pt&gt;:PCMFrame? → 0).  If requested result is not available, NaN (section 1.6.1) is returned.  If there is one or more results, the last ",," is always removed.</p>

## 9.6 RTD

This section document commands to retrieve Round Trip Delay measurement results. Commands for general RTD settings are described in section 16.1 on page 837.

### 9.6.1 E4:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	E4:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 9.6.2 E4:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	E4:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 9.6.3 E4:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	E4:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 9.6.4 E4:RTD:RX<Pt>:LTIME?

<b>Syntax</b>	E4:RTD:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	E4:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.



---

# Chapter 10

## SDH

Use `MEAS:SET:PORT<Pt>:TERM` to change the SDH/SONET terminology (see section 17.2.1).

### 10.1 Receiver

#### 10.1.1 SDH:RX<Pt>:INTerface

<b>Syntax</b>	SDH:RX<Pt>:INTerface <mode>
<b>Description</b>	This command sets the used interface or switches off the receiver.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Disables receiver ELECtrical: Electrical interface SFP: SFP/SFP+ optical interface CFP: CFP optical interface OPTical: Obsolete. For CMA 3000 backward compatibility only. Same as SFP <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:INT OFF
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:INTerface?
<b>Description</b>	This query returns the used interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:INT? → OFF
<b>Note</b>	Returns OTN when SDH over OTN.

#### 10.1.2 SDH:RX<Pt>:STMLevel

<b>Syntax</b>	SDH:RX<Pt>:STMLevel <level>
<b>Description</b>	This command sets the STM level of the SDH receiver.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 1: STM-1 signal. 4: STM-4 signal. 16: STM-16 signal. 64: STM-64 signal. 256: STM-256 signal. PRBSTRANS: Trans.(PRBS). NULLTRANS: Trans.(NULL). <i>DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:STML 1
<b>Note</b>	Setting the STM level may change the VC-4 concatenation level.

<b>Syntax</b>	SDH:RX<Pt>:STMLevel?
<b>Description</b>	This query returns the STM level of the SDH receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:STML? → 1
<b>Note</b>	

### 10.1.3 SDH:RX<Pt>:AUGroup

<b>Syntax</b>	SDH:RX<Pt>:AUGroup <aug>
<b>Description</b>	This command sets the AU Group(s) to be used in the signal structure.
<b>Parameters</b>	<Pt> = Port number <aug> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 768, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:AUGR 1
<b>Note</b>	The specified AUG cannot exceed the STM level divided by the VC-4 concatenation level.

<b>Syntax</b>	SDH:RX<Pt>:AUGroup?
<b>Description</b>	This query returns AU Group(s) used in the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<aug> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:AUGR? → 1
<b>Note</b>	

### 10.1.4 SDH:RX<Pt>:CONCatenation

<b>Syntax</b>	SDH:RX<Pt>:CONCatenation <level>
<b>Description</b>	This command sets the VC concatenation level.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> VC3 VC4 4C 16C 64C 256C <i>DEFault = VC4</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:CONC VC4
<b>Note</b>	Setting the VC concatenation level may change the STM level.

<b>Syntax</b>	SDH:RX<Pt>:CONCatenation?
<b>Description</b>	This query returns the VC concatenation level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:CONC? → VC4
<b>Note</b>	

## 10.1.5 SDH:RX&lt;Pt&gt;:CONTainer

<b>Syntax</b>	SDH:RX<Pt>:CONTainer <type>
<b>Description</b>	This command sets the container type (container-n).
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> C3 C4 C11 C12 <i>DEFault = C4</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:CONT C4
<b>Note</b>	Setting the container type.

<b>Syntax</b>	SDH:RX<Pt>:CONTainer?
<b>Description</b>	This query returns the container type (container-n).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:CONT? → 4C
<b>Note</b>	

## 10.1.6 SDH:RX&lt;Pt&gt;:SSTRucture

<b>Syntax</b>	SDH:RX<Pt>:SSTRucture <structure>
<b>Description</b>	This command sets the expected SDH signal structure.
<b>Parameters</b>	<Pt> = Port number <structure> = <CHARACTER PROGRAM DATA> BULK: Bulk data in the VC-4. E1: E1 signal in a VC-12 in one or all AU-4's E3: E3 signal in a VC-3 in one or all AU-4's DS1: DS1 signal in a VC-11 in one or all AU-4's DS3: DS3 signal in a VC-3 in one or all AU-4's E4: E4 signal in a VC-4 in one or all AU-4's <i>DEFault = BULK</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:SSTR BULK
<b>Note</b>	Choosing any of the interfaces above requires the corresponding option to be present.

<b>Syntax</b>	SDH:RX<Pt>:SSTRucture?
<b>Description</b>	This query returns the expected SDH signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<structure> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:SSTR? → BULK
<b>Note</b>	

## 10.1.7 SDH:RX&lt;Pt&gt;:PATtern

<b>Syntax</b>	SDH:RX<Pt>:PATtern <pattern>
<b>Description</b>	This command sets the pattern to be expected as payload when SSTRucture is BULK.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;pattern&gt; = &lt;CHARACTER PROGRAM DATA&gt;  OFF  USER32BIT: 32 bit user defined pattern.  USER2048BIT: 2048 bit user defined pattern.  PRBS9: PRBS-9 pattern.  PRBS11: PRBS-11 pattern.  PRBS15: PRBS-15 pattern.  PRBS20: PRBS-20 pattern.  PRBS23: PRBS23 pattern.  PRBS29: PRBS-29 pattern.  PRBS31: PRBS-31 pattern.  ALL0: Pattern of all zeros.  ALL1: Pattern of all ones.  ALT11: Alternating 1:1  ALT13: Alternating 1:3  ALT17: Alternating 1:7  B2IN8: Random pattern with two ones for every eight bits.  <i>DEFault = PRBS23</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern to be expected as payload when SSTRucture is BULK.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:PATT? → PRBS23
<b>Note</b>	

## 10.1.8 SDH:RX&lt;Pt&gt;:UP16

<b>Syntax</b>	SDH:RX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;pattern&gt; = &lt;STRING PROGRAM DATA&gt;  Valid characters: '0' and '1'  The string must consist of 1 to 16 characters.</p>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.



## 10.1.9 SDH:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	SDH:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	SDH:RX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:RX1:UP32? → "01101"
<b>Note</b>	

## 10.1.10 SDH:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	SDH:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when SDH:RX1:PATT is USER2048BIT

<b>Syntax</b>	SDH:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:RX1:UP2K? → "12DF"
<b>Note</b>	

## 10.1.11 SDH:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	SDH:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion (when SSTRucture is BULK).
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:PINV OFF
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:RX1:PINV? → 0
<b>Note</b>	

## 10.1.12 SDH:RX&lt;Pt&gt;:TCM

<b>Syntax</b>	SDH:RX<Pt>:TCM <mode>
<b>Description</b>	This command sets the Tandem Connection Monitoring mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Off VC4: N1 (VC-4) VC3: N1 (VC-3) VC12: N2 (VC-12) VC11: N2 (VC-12) <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:TCM OFF
<b>Note</b>	This command requires the TCM option to be present.

<b>Syntax</b>	SDH:RX<Pt>:TCM?
<b>Description</b>	This query returns Tandem Connection Monitoring mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:TCM? → OFF
<b>Note</b>	

## 10.1.13 SDH:RX&lt;Pt&gt;:TUG3

<b>Syntax</b>	SDH:RX<Pt>:TUG3 <id>
<b>Description</b>	This command sets the TUG-3 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-3 number one. 2: TUG-3 number two. 3: TUG-3 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:TUG3 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:RX<Pt>:TUG3?
<b>Description</b>	This query returns TUG3 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:TUG3? → 1
<b>Note</b>	

## 10.1.14 SDH:RX&lt;Pt&gt;:TUG2

<b>Syntax</b>	SDH:RX<Pt>:TUG2 <id>
<b>Description</b>	This command sets the TUG-2 number for signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-2 number one. 2: TUG-2 number two. ... 7: TUG-2 number seven. <i>MINimum = 1, MAXimum = 7, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:TUG2 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:RX<Pt>:TUG2?
<b>Description</b>	This query returns TUG2 number for signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:TUG2? → 1
<b>Note</b>	

### 10.1.15 SDH:RX<Pt>:TU12

<b>Syntax</b>	SDH:RX<Pt>:TU12 <id>
<b>Description</b>	This command sets the TU-12 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TU-12 number one. 2: TU-12 number two. 3: TU-12 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:TU12 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:RX<Pt>:TU12?
<b>Description</b>	This query returns TU-12 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:TU12? → 1
<b>Note</b>	

### 10.1.16 SDH:RX<Pt>:TU11

<b>Syntax</b>	SDH:RX<Pt>:TU11 <id>
<b>Description</b>	This command sets the TU-11 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TU-11 number one. 2: TU-11 number two. 3: TU-11 number three. 4: TU-11 number four. <i>MINimum = 1, MAXimum = 4, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:TU11 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:RX<Pt>:TU11?
<b>Description</b>	This query returns TU-11 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:TU11? → 1
<b>Note</b>	

## 10.1.17 SDH:RX&lt;Pt&gt;:CHANnel

<b>Syntax</b>	SDH:RX<Pt>:CHANnel <id>
<b>Description</b>	This command sets the channel number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=84, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:CHAN 1
<b>Note</b>	This value influences the TUG-3, TUG-2, TU-12 and TU-11 numbers.

<b>Syntax</b>	SDH:RX<Pt>:CHANnel?
<b>Description</b>	This query returns the channel number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RX1:CHAN? → 1
<b>Note</b>	

## 10.1.18 SDH:RX&lt;Pt&gt;:MAPPING

<b>Syntax</b>	SDH:RX<Pt>:MAPPING <type>
<b>Description</b>	This command sets the mapping type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SYNChronous: Synchronous mapping. ASYNChronous: Asynchronous mapping. <i>DEFault = SYNC</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:MAPP SYNC
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:MAPPING?
<b>Description</b>	This query returns returns the mapping type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:MAPP? → SYNC
<b>Note</b>	

## 10.1.19 SDH:RX&lt;Pt&gt;:GAIN

<b>Syntax</b>	SDH:RX<Pt>:GAIN <type>
<b>Description</b>	This command sets the receiver gain.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> TERMinate: Frequency dependent AGC. MONitor: Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:GAIN TERM
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:GAIN?
<b>Description</b>	This query returns the receiver gain.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:GAIN? → TERM
<b>Note</b>	

## 10.1.20 SDH:RX&lt;Pt&gt;:FOLLOW

<b>Syntax</b>	SDH:RX<Pt>:FOLLOW <mode>
<b>Description</b>	This command sets the receiver setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX: Follows setup of the Tx port. RX1: Follows setup of the Rx port1. <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:FOLL NONE
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:FOLLOW?
<b>Description</b>	This query returns the receiver setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:RX1:FOLL? → NONE
<b>Note</b>	

## 10.1.21 SDH:RX&lt;Pt&gt;:MEASUREMENT:HPLM

<b>Syntax</b>	SDH:RX<Pt>:MEASUREMENT:HPLM <enable>
<b>Description</b>	This command enables or disables HP-PLM measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:MEAS:HPLM ON
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:MEASUREMENT:HPLM?
<b>Description</b>	This query returns whether or not HP-PLM measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:RX1:MEAS:HPLM? → 1
<b>Note</b>	

## 10.1.22 SDH:RX&lt;Pt&gt;:MEASUREMENT:LPLM

<b>Syntax</b>	SDH:RX<Pt>:MEASUREMENT:LPLM <enable>
<b>Description</b>	This command enables or disables LP-PLM measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RX1:MEAS:LPLM ON
<b>Note</b>	

<b>Syntax</b>	SDH:RX<Pt>:MEASUREMENT:LPLM?
<b>Description</b>	This query returns whether or not LP-PLM measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:RX1:MEAS:LPLM? → 1
<b>Note</b>	

## 10.2 Transmitter

### 10.2.1 SDH:TX<Pt>:INTerface

<b>Syntax</b>	SDH:TX<Pt>:INTerface <mode>
<b>Description</b>	This command sets the used interface of the transmitter.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> ELECtrical: Electrical interface SFP: SFP/SFP+ optical interface CFP: CFP optical interface <i>DEFault = ELEC</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:INT SFP
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:INTerface?
<b>Description</b>	This query returns the used interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:INT? → SFP
<b>Note</b>	Returns OTN when SDH over OTN.

### 10.2.2 SDH:TX<Pt>[:ENABLE]

<b>Syntax</b>	SDH:TX<Pt>[:ENABLE] <mode>
<b>Description</b>	This command sets the mode of the transmitter.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Turn off the transmitter. NORMal: Normal transmission mode using the configured signal. THRough: Through mode. The signal from the receiver is transmitted. OTHRough: OH overwrite through mode. THA: Obsolete. For CMA 3000 backward compatibility only. Same as THRough. <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1 NORM
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>[:ENABLE]?
<b>Description</b>	This query returns the mode of the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1? → NORM
<b>Note</b>	

### 10.2.3 SDH:TX<Pt>:OPTical

<b>Syntax</b>	SDH:TX<Pt>:OPTical <mode>
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SDH:TX<Pt>:INT SFP and SDH:TX<Pt>
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:OPT NORM
<b>Note</b>	Compared to CMA 3000 there is no longer a suffix on the last node.

<b>Syntax</b>	SDH:TX<Pt>:OPTical?
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SDH:TX<Pt>?
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:OPT? → NORM
<b>Note</b>	

#### 10.2.4 SDH:TX<Pt>:ELECtrical

<b>Syntax</b>	SDH:TX<Pt>:ELECtrical <mode>
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SDH:TX<Pt>:INT ELEC and SDH:TX<Pt>
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:ELEC NORM
<b>Note</b>	Compared to CMA 3000 mode=THB is no longer supported.

<b>Syntax</b>	SDH:TX<Pt>:ELECtrical?
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SDH:TX<Pt>?
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:ELEC? → NORM
<b>Note</b>	

#### 10.2.5 SDH:TX<Pt>:STMLevel

<b>Syntax</b>	SDH:TX<Pt>:STMLevel <level>
<b>Description</b>	This command sets the STM level of the transmitted SDH signal.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 1: STM-1 signal. 4: STM-4 signal. 16: STM-16 signal. 64: STM-64 signal. 256: STM-256 signal. PRBSTRANS: Trans.(PRBS). NULLTRANS: Trans.(NULL). <i>DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:STML 1
<b>Note</b>	Setting the STM level may change the VC-4 concatenation level.

<b>Syntax</b>	SDH:TX<Pt>:STMLevel?
<b>Description</b>	This query returns the STM level of the transmitted SDH signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:STML? → 1
<b>Note</b>	

## 10.2.6 SDH:TX&lt;Pt&gt;:AUGRoup

<b>Syntax</b>	SDH:TX<Pt>:AUGRoup <value>
<b>Description</b>	This command sets the AUG where the test signal is inserted.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> ALL 1 to 768 <i>DEFAult = ALL</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AUGR ALL
<b>Note</b>	The specified AUG cannot exceed the STM level divided by the VC-4 concatenation level.

<b>Syntax</b>	SDH:TX<Pt>:AUGRoup?
<b>Description</b>	This query returns the AUG where the test signal has been inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:AUGR? → ALL
<b>Note</b>	

## 10.2.7 SDH:TX&lt;Pt&gt;:CONCatenation

<b>Syntax</b>	SDH:TX<Pt>:CONCatenation <level>
<b>Description</b>	This command sets the VC concatenation level.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> VC3 VC4 4C 16C 64C 256C <i>DEFAult = VC4</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:CONC 4C
<b>Note</b>	Setting the VC concatenation level may change the STM level.

<b>Syntax</b>	SDH:TX<Pt>:CONCatenation?
<b>Description</b>	This query returns the VC concatenation level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:CONC? → 4C
<b>Note</b>	



## 10.2.8 SDH:TX&lt;Pt&gt;:CONTainer

<b>Syntax</b>	SDH:TX<Pt>:CONTainer <type>
<b>Description</b>	This command sets the container type (container-n).
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> C3 C4 C11 C12 <i>DEFault = C4</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:CONT C4
<b>Note</b>	Setting the container type.

<b>Syntax</b>	SDH:TX<Pt>:CONTainer?
<b>Description</b>	This query returns the container type (container-n).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:CONT? → 4C
<b>Note</b>	

## 10.2.9 SDH:TX&lt;Pt&gt;:SSTRucture

<b>Syntax</b>	SDH:TX<Pt>:SSTRucture <structure>
<b>Description</b>	This command sets the SDH signal structure.
<b>Parameters</b>	<Pt> = Port number <structure> = <CHARACTER PROGRAM DATA> BULK: Bulk data in the VC-4. E1: E1 signal in a VC-12 in one or all AU-4's E3: E3 signal in a VC-3 in one or all AU-4's DS1: DS1 signal in a VC-11 in one or all AU-4's DS3: DS3 signal in a VC-3 in one or all AU-4's E4: E4 signal in a VC-4 in one or all AU-4's <i>DEFault = BULK</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:SSTR BULK
<b>Note</b>	Choosing any of the interfaces above requires the corresponding option to be present.

<b>Syntax</b>	SDH:TX<Pt>:SSTRucture?
<b>Description</b>	This query returns the SDH signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<structure> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:SSTR? → BULK
<b>Note</b>	

## 10.2.10 SDH:TX&lt;Pt&gt;:PATtern

<b>Syntax</b>	SDH:TX<Pt>:PATtern <pattern>
<b>Description</b>	This command sets the pattern to be used as payload when SSTRucture is BULK.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;pattern&gt; = &lt;CHARACTER PROGRAM DATA&gt;  OFF  USER32BIT: 32 bit user defined pattern.  USER2048BIT: 2048 bit user defined pattern.  PRBS9: PRBS-9 pattern.  PRBS11: PRBS-11 pattern.  PRBS15: PRBS-15 pattern.  PRBS20: PRBS-20 pattern.  PRBS23: PRBS23 pattern.  PRBS29: PRBS-29 pattern.  PRBS31: PRBS-31 pattern.  ALL0: Pattern of all zeros.  ALL1: Pattern of all ones.  ALT11: Alternating 1:1  ALT13: Alternating 1:3  ALT17: Alternating 1:7  B2IN8: Random pattern with two ones for every eight bits.  <i>DEFault = PRBS23</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:PATtern?
<b>Description</b>	Queries the pattern to be used as payload when SSTRucture is BULK.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:PATT? → PRBS23
<b>Note</b>	

## 10.2.11 SDH:TX&lt;Pt&gt;:UP16

<b>Syntax</b>	SDH:TX<Pt>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;pattern&gt; = &lt;STRING PROGRAM DATA&gt;  Valid characters: '0' and '1'  The string must consist of 1 to 16 characters.</p>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

## 10.2.12 SDH:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	SDH:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	SDH:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:TX1:UP32? → "01101"
<b>Note</b>	

## 10.2.13 SDH:TX&lt;Pt&gt;:UP2K

<b>Syntax</b>	SDH:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when SDH:TX1:PATT is USER2048BIT

<b>Syntax</b>	SDH:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:TX1:UP2K? → "12DF"
<b>Note</b>	

## 10.2.14 SDH:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	SDH:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion (when SSTRucture is BULK).
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:PINV OFF
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:PINV? → 0
<b>Note</b>	

## 10.2.15 SDH:TX&lt;Pt&gt;:TIMing

<b>Syntax</b>	SDH:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal clock. EXTernal: External clock. RX: Received Rx signal clock. <i>DEFault = INT</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:TIM? → INT
<b>Note</b>	

## 10.2.16 SDH:TX&lt;Pt&gt;:TCM

<b>Syntax</b>	SDH:TX<Pt>:TCM <mode>
<b>Description</b>	This command sets the TCM mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Off VC4: N1 (VC-4) VC3: N1 (VC-3) VC12: N2 (VC-12) VC11: N2 (VC-12) <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TCM OFF
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:TCM?
<b>Description</b>	Queries the TCM mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:TCM? → OFF
<b>Note</b>	

## 10.2.17 SDH:TX&lt;Pt&gt;:TUG3

<b>Syntax</b>	SDH:TX<Pt>:TUG3 <id>
<b>Description</b>	This command sets the TUG-3 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-3 number one. 2: TUG-3 number two. 3: TUG-3 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TUG3 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:TX<Pt>:TUG3?
<b>Description</b>	This query returns TUG3 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:TUG3? → 1
<b>Note</b>	

### 10.2.18 SDH:TX<Pt>:TUG2

<b>Syntax</b>	SDH:TX<Pt>:TUG2 <id>
<b>Description</b>	This command sets the TUG-2 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-2 number one. 2: TUG-2 number two. ... 7: TUG-2 number seven. <i>MINimum = 1, MAXimum = 7, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TUG2 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:TX<Pt>:TUG2?
<b>Description</b>	This query returns TUG2 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:TUG2? → 1
<b>Note</b>	

### 10.2.19 SDH:TX<Pt>:TU12

<b>Syntax</b>	SDH:TX<Pt>:TU12 <id>
<b>Description</b>	This command sets the TU-12 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TU-12 number one. 2: TU-12 number two. 3: TU-12 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TU12 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:TX<Pt>:TU12?
<b>Description</b>	This query returns TU-12 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:TU12? → 1
<b>Note</b>	

## 10.2.20 SDH:TX&lt;Pt&gt;:TU11

<b>Syntax</b>	SDH:TX<Pt>:TU11 <id>
<b>Description</b>	This command sets the TU-11 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TU-11 number one. 2: TU-11 number two. 3: TU-11 number three. 4: TU-11 number four. <i>MINimum = 1, MAXimum = 4, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:TU11 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SDH:TX<Pt>:TU11?
<b>Description</b>	This query returns TU-11 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:TU11? → 1
<b>Note</b>	

## 10.2.21 SDH:TX&lt;Pt&gt;:CHANnel

<b>Syntax</b>	SDH:TX<Pt>:CHANnel <id>
<b>Description</b>	This command sets the channel number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=84, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:CHAN 1
<b>Note</b>	The value influences the TUG-3, TUG-2 and TU-12 numbers.

<b>Syntax</b>	SDH:TX<Pt>:CHANnel?
<b>Description</b>	This query returns the channel number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:CHAN? → 1
<b>Note</b>	

## 10.2.22 SDH:TX&lt;Pt&gt;:MAPPing

<b>Syntax</b>	SDH:TX<Pt>:MAPPing <type>
<b>Description</b>	This command sets the mapping type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SYNchronous: Synchronous mapping. ASYNchronous: Asynchronous mapping. <i>DEFault = SYNC</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:MAPP SYNC
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:MAPPing?
<b>Description</b>	This query returns the mapping type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:MAPP? → SYNC
<b>Note</b>	

### 10.2.23 SDH:TX<Pt>:SOH:DEFault

<b>Syntax</b>	SDH:TX<Pt>:SOH:DEFault
<b>Description</b>	This command sets all STM SOH bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:SOH:DEF
<b>Note</b>	There is no query version of this command.

### 10.2.24 SDH:TX<Pt>:SOH:TRACe

<b>Syntax</b>	SDH:TX<Pt>:SOH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the SOH trace (J0) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: The string to be used as section trace string. <i>DEFault = "Message_Test_J0"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:SOH:TRAC "Message_Test_J0",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated.


<b>Syntax</b>	SDH:TX<Pt>:SOH:TRACe?
<b>Description</b>	This query returns the SOH trace for string and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:SOH:TRAC? → "Message_Test_J0",#H20
<b>Note</b>	

### 10.2.25 SDH:TX<Pt>:SOH:TRACe:CRC

<b>Syntax</b>	SDH:TX<Pt>:SOH:TRACe:CRC <mode>
<b>Description</b>	This command sets the SOH trace (J0) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:SOH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:SOH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the SOH trace (J0) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:SOH:TRAC:CRC? → 1
<b>Note</b>	

10.2.26 SDH:TX<Pt>:SOH

<b>Syntax</b>	SDH:TX<Pt>:SOH <SOH-byte>,<value1>[,<value2>[,<value3>]]
<b>Description</b>	This command sets the value of the specified bytes in the SOH.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;SOH-byte&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A1: 3 bytes.  A2: 3 bytes.  J0: 3 bytes. Note: The defined trace string will be disabled.  B1: 2 bytes. &lt;value3&gt; is ignored.  E1: 3 bytes.  F1: 3 bytes.  D1: 3 bytes.  D2: 3 bytes.  D3: 3 bytes.  K1: 3 bytes.  K2: 3 bytes.  D4: 3 bytes.  D5: 3 bytes.  D6: 3 bytes.  D7: 3 bytes.  D8: 3 bytes.  D9: 3 bytes.  D10: 3 bytes.  D11: 3 bytes.  D12: 3 bytes.  S1: 3 bytes.  Z2: 3 byte.  E2: 3 bytes.  M0: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored. <sup>1</sup>  M1: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored.</p>  <p>&lt;value1&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p> <p>&lt;value2&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p> <p>&lt;value3&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p>
<b>Response</b>	None.
<b>Examples</b>	SDH:TX1:SOH A1,0,0,0 SDH:TX1:SOH D7,253,32,26 SDH:TX1:SOH B1,4,5 SDH:TX1:SOH M1,0
<b>Note</b>	<sup>1</sup> Only valid for SDH:TX<Pt>:STMLLevel = 64 or 256.



<b>Syntax</b>	SDH:TX<Pt>:SOH? <SOH-byte>
<b>Description</b>	This query returns the value of the specified bytes in the SOH.
<b>Parameters</b>	<Pt> = Port number <SOH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value1> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value2> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value3> = <HEXADECIMAL NUMERIC RESPONSE DATA>]]
<b>Examples</b>	SDH:TX1:SOH? A1 → #H00,#H00,#H00 SDH:TX1:SOH? D7 → #HFD,#H20,#H1A SDH:TX1:SOH? B1 → #H04,#H05 SDH:TX1:SOH? M1 → #H00
<b>Note</b>	

### 10.2.27 SDH:TX<Pt>:VC4:POH:DEFault

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:DEFault
<b>Description</b>	This command sets all VC-4 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC4:POH:DEF
<b>Note</b>	There is no query version of this command.

### 10.2.28 SDH:TX<Pt>:VC4:POH:TRACe

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-4 path trace (J1) to the specified string and its idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: The string to be used as path trace string. <i>DEFault = "Message_Test_J1"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC4:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated.

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TRACe?
<b>Description</b>	This query returns the VC-4 path trace text and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC4:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	

### 10.2.29 SDH:TX<Pt>:VC4:POH:TRACe:CRC

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC4:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC4:POH:TRAC:CRC? → 1
<b>Note</b>	

### 10.2.30 SDH:TX<Pt>:VC4:POH:TTCM

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-4 TCM trace (N1) to the specified string and its idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_N1" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC4:POH:TTCM "Apid_TCM_N1",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH:TTCM?
<b>Description</b>	This query returns the VC-4 TCM trace text and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC4:POH:TTCM? → "Apid_TCM_N1",#H20
<b>Note</b>	

### 10.2.31 SDH:TX<Pt>:VC4:POH

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VC-4 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum</i> = 0, <i>MAXimum</i> = 255
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC4:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC4:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VC-4 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Examples</b>	SDH:TX1:VC4:POH? C2 → #H00 SDH:TX1:VC4:POH? H4 → #HFF
<b>Note</b>	

**10.2.32 SDH:TX<Pt>:VC3:POH:DEFault**

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:DEFault
<b>Description</b>	This command sets all VC-3 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC3:POH:DEF
<b>Note</b>	There is no query version of this command.

**10.2.33 SDH:TX<Pt>:VC3:POH:TRACe**

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-3 path trace (J1) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Message_Test_J1" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC3:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TRACe?
<b>Description</b>	This query returns the VC-3 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC3:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	

**10.2.34 SDH:TX<Pt>:VC3:POH:TRACe:CRC**

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC3:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC3:POH:TRAC:CRC? → 1
<b>Note</b>	

## 10.2.35 SDH:TX&lt;Pt&gt;:VC3:POH:TTCM

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-3 TCM trace (N1) to the specified string, and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_N1" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC3:POH:TTCM "Apid_TCM_N1",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH:TTCM?
<b>Description</b>	This query returns the VC-3 TCM trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC3:POH:TTCM? → "Apid_TCM_N1",#H20
<b>Note</b>	

## 10.2.36 SDH:TX&lt;Pt&gt;:VC3:POH

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VC-3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte. Only available when there is no TCM. <value> = <NUMERIC PROGRAM DATA> <i>MINimum</i> = 0, <i>MAXimum</i> = 255
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC3:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC3:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VC-3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC3:POH? C2 → #H00
<b>Note</b>	

## 10.2.37 SDH:TX&lt;Pt&gt;:VC12:POH:DEFault

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:DEFault
<b>Description</b>	This command sets all VC-12 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC12:POH:DEF
<b>Note</b>	There is no query version of this command.

## 10.2.38 SDH:TX&lt;Pt&gt;:VC12:POH:TRACe

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-12 path trace (J2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Message_Test_J2" <idlechar> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC12:POH:TRAC "Message_Test_J2",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TRACe?
<b>Description</b>	This query returns the VC-12 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC12:POH:TRAC? → "Message_Test_J2",#H20
<b>Note</b>	

## 10.2.39 SDH:TX&lt;Pt&gt;:VC12:POH:TRACe:CRC

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J2) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC12:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J2) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC12:POH:TRAC:CRC? → 1
<b>Note</b>	

## 10.2.40 SDH:TX&lt;Pt&gt;:VC12:POH:TTCM

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-12 TCM trace (N2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_N2" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC12:POH:TTCM "Apid_TCM_N2",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH:TTCM?
<b>Description</b>	This query returns the VC-12 trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC12:POH:TTCM? → "Apid_TCM_N2",#H20
<b>Note</b>	

#### 10.2.41 SDH:TX<Pt>:VC12:POH

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VC-12 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5 byte. N2: N2 byte. K4: K4 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC12:POH V5,#H04
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC12:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VC-11 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC12:POH? V5 → #H04
<b>Note</b>	

#### 10.2.42 SDH:TX<Pt>:VC11:POH:DEFault

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:DEFault
<b>Description</b>	This command sets all VC-11 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC11:POH:DEF
<b>Note</b>	There is no query version of this command.

#### 10.2.43 SDH:TX<Pt>:VC11:POH:TRACe

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-11 path trace (J2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Message_Test_J2"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC11:POH:TRAC "Message_Test_J2",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TRACe?
<b>Description</b>	This query returns the VC-11 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC11:POH:TRAC? → "Message_Test_J2",#H20
<b>Note</b>	

#### 10.2.44 SDH:TX<Pt>:VC11:POH:TRACe:CRC

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J2) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC11:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J2) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC11:POH:TRAC:CRC? → 1
<b>Note</b>	

#### 10.2.45 SDH:TX<Pt>:VC11:POH:TTCM

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-11 TCM trace (N2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Apid_TCM_N2"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC11:POH:TTCM "Apid_TCM_N2",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH:TTCM?
<b>Description</b>	This query returns the VC-11 trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC11:POH:TTCM? → "Apid_TCM_N2",#H20
<b>Note</b>	

## 10.2.46 SDH:TX&lt;Pt&gt;:VC11:POH

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VC-11 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5 byte. N2: N2 byte. K4: K4 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:VC11:POH V5,#H04
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:VC11:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VC-11 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:VC11:POH? V5 → #H04
<b>Note</b>	

## 10.2.47 SDH:TX&lt;Pt&gt;:AU3:VC3:POH:DEFault

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:DEFault
<b>Description</b>	This command sets all VC-3 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AU3:VC3:POH:DEF
<b>Note</b>	There is no query version of this command.

## 10.2.48 SDH:TX&lt;Pt&gt;:AU3:VC3:POH:TRACe

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-3 path trace (J1) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Message_Test_J1"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TRACe?
<b>Description</b>	This query returns the VC-3 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	



## 10.2.49 SDH:TX&lt;Pt&gt;:AU3:VC3:POH:TRACe:CRC

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TRAC:CRC? → 1
<b>Note</b>	

## 10.2.50 SDH:TX&lt;Pt&gt;:AU3:VC3:POH:TTCM

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VC-3 TCM trace (N1) to the specified string, and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Apid_TCM_N1"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TTCM "Apid_TCM_N1",#H20
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH:TTCM?
<b>Description</b>	This query returns the VC-3 TCM trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:AU3:VC3:POH:TTCM? → "Apid_TCM_N1",#H20
<b>Note</b>	

## 10.2.51 SDH:TX&lt;Pt&gt;:AU3:VC3:POH

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VC-3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte. Only available when there is no TCM. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:AU3:VC3:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:AU3:VC3:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VC-3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TX1:AU3:VC3:POH? C2 → #H00
<b>Note</b>	

### 10.2.52 SDH:TX<Pt>:FOLLow

<b>Syntax</b>	SDH:TX<Pt>:FOLLow <mode>
<b>Description</b>	This command sets the transmitter setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX1: Follows setup of the Tx port1. <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:FOLL NONE
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:FOLLow?
<b>Description</b>	This query returns the transmitter setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:FOLL? → NONE
<b>Note</b>	

### 10.2.53 SDH:TX<Pt>:OTHRough

<b>Syntax</b>	SDH:TX<Pt>:OTHRough <mode>
<b>Description</b>	This command sets the OH Overwrite Position.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SOH: SOH Data. A1A2: A1/A2 byte. K1K2: K1/K2 byte. S1: S1 byte. DCC1TO3: DCC1-3 byte. DCC4TO12: DCC4-12 byte. J0: J0 byte. SOH1BYTE: 1 byte of SOH.(selectable) <i>DEFault = SOH</i>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:OTHR A1A2
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:OTHRough?
<b>Description</b>	This query returns the OH Overwrite Position.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<position> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:OTHR? → A1A2
<b>Note</b>	

## 10.2.54 SDH:TX&lt;Pt&gt;:OTHRough:BYTE

<b>Syntax</b>	SDH:TX<Pt>:OTHRough:BYTE <byte>
<b>Description</b>	This command sets the OH Overwrite Position.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;byte&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A11-A13: A1 bytes.  A21-A23: A2 bytes.  J0: J0 byte.  E1: E1 byte.  F1: F1 byte.  D1: D1 byte.  D2: D2 byte.  D3: D3 byte.  K1: K1 byte.  K2: K2 byte.  D4: D4 byte.  D5: D5 byte.  D6: D6 byte.  D7: D7 byte.  D8: D8 byte.  D9: D9 byte.  D10: D10 byte.  D11: D11 byte.  D12: D12 byte.  S1: S1 byte.  M0: M0 byte.  M1: M1 byte.  E2: E2 byte.  X18-X99: X&lt;Line&gt;&lt;Column&gt;  <i>DEFault = A11</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:OTHR:BYTE A11
<b>Note</b>	

<b>Syntax</b>	SDH:TX<Pt>:OTHRough:BYTE?
<b>Description</b>	This query returns the OH Overwrite Position.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<byte> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:TX1:OTHR:BYTE? → A11
<b>Note</b>	

## 10.2.55 SDH:TX&lt;Pt&gt;:STL:MMAPing:LANE

<b>Syntax</b>	SDH:TX<Pt>:STL:MMAPing:LANE <value>
<b>Description</b>	This command sets the STL lane marker assignment.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{(&lt;value&gt;),}* = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>Format: Numeric List</p> <p>List consist of the value of the lane marker ranging from 0 to 3.</p>
<b>Response</b>	None.
<b>Example</b>	SDH:TX1:STL:MMA:LANE (0,1,2,3)
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:TX<Pt>:STL:MMAPIng:LANE?
<b>Description</b>	This query returns the STL lane marker assignment.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<value>),}* = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	SDH:TX1:STL:MMAPIng:LANE? → (0,1,2,3)
<b>Note</b>	This command can be used on 40G

## 10.3 Stimuli

### 10.3.1 SDH:STIMuli:TX<Pt>:FOFFset

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> MT1000A: <i>MINimum</i> =-50, <i>MAXimum</i> =50, <i>DEFault</i> =0 MT1100A: <i>MINimum</i> =-200.0, <i>MAXimum</i> =200.0, <i>DEFault</i> = 0
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:FOFF 0
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	MT1000A: <offset> = <NR1 NUMERIC RESPONSE DATA> MT1100A: <offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MT1000A: SDH:STIM:TX1:FOFF? → 0 MT1100A: SDH:STIM:TX1:FOFF? → 0.0
<b>Note</b>	

## 10.3.2 SDH:STIMuli:TX&lt;Pt&gt;:ALARm

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ALARm <alarmtype>
<b>Description</b>	This command sets the type of alarm to be generated.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> LOS: Loss of signal LOF: Loss of frame OOF: Out of frame MSAIS: MS alarm indication signal MSRDI: MS remote defect indicator AUAIS: AU alarm indication signal AULOP: AU loss of pointer HPTIM: HP trace identifier mismatch HPPLM: HP payload label mismatch HPUNEQ: HP unequipped HPRDI: HP remote defect indicator TUAIS: TU alarm indication signal TULOP: TU loss of pointer TULOM: TU loss of multiframe LPTIM: LP trace identifier mismatch LPUNEQ: LP unequipped LPRDI: LP remote defect indicator LPPLM: LP payload label mismatch LSS: Loss of signal synchronization TCUNEQ: TC unequipped TCLTC: TC loss of tandem connection TCTIM: TC trace identifier mismatch TCAIS: TC alarm indication signal TCRDI: TC remote defect indicator TCODI: TC outgoing defect indicator <i>DEFault = LOS</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:ALAR LOS
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the type of alarm to be generated.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:ALAR? → LOS
<b>Note</b>	

## 10.3.3 SDH:STIMuli:TX&lt;Pt&gt;:AINSert

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:AINSert <insertion>
<b>Description</b>	This command sets the method to insert alarm.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF PERManent ALTernate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:AINS PERM
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:AINSert?
<b>Description</b>	This query returns the alarm insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:AINS? → PERM
<b>Note</b>	

### 10.3.4 SDH:STIMuli:TX<Pt>:ANLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ANLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SDH:STIM:TX<Pt>:AINS
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:ANL 1
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ANLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:ANL? → 1
<b>Note</b>	

### 10.3.5 SDH:STIMuli:TX<Pt>:AALength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:AALength <frames>
<b>Description</b>	This command sets the alternate alarm length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SDH:STIM:TX<Pt>:AINS
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:AAL 1
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:AALength?
<b>Description</b>	This query returns the alternate alarm length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:AAL? → 1
<b>Note</b>	

## 10.3.6 SDH:STIMuli:TX&lt;Pt&gt;:ERRor

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ERRor <errordestination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;errordestination&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A1A2: Frame alignment word  B1: B1 checksum byte  B2: B2 checksum byte  MSREI: MS remote error indication  B3: B3 checksum byte  HPREI: HP Remote error indication  V5LPB3: B3 checksum of the low-order path  LPREI: LP remote error indication  PRBS: Pattern error  ETRans: ERR-TRANS  TCIEC: Tandem Connection incoming error count  TCREI: Tandem Connection remote error indication  TCOEI: Tandem Connection outgoing error indication  TCBIP2: 2-bit Bit Interleaved Parity for Tandem Connection  <i>DEFault = A1A2</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:ERR MSREI
<b>Note</b>	Some errors are depended on type of content, setting them without the correct type of content will set EINSert to OFF. Changing the error may also change the insert method. See section 11.3.7.

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errordestination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:ERR? → MSREI
<b>Note</b>	

## 10.3.7 SDH:STIMuli:TX&lt;Pt&gt;:EINsert

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EINsert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B03: Burst · 1E-03 <sup>1</sup> B04: Burst · 1E-04 <sup>1</sup> B05: Burst · 1E-05 <sup>1</sup> B06: Burst · 1E-06 <sup>2</sup> B07: Burst · 1E-07 B08: Burst · 1E-08 B09: Burst · 1E-09 B10: Burst · 1E-10 ALTErnate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14. <sup>1</sup> Is available for PRBS and ETRans (B03 is only available for ETRans if the STM Level is 1). <sup>2</sup> Is available for PRBS, ETRans, B2, V5LPB3, LPREI, TCIEC, TCBIP2, TCREI and TCOEI. Selecting an unsupported burst rate will reset the rate to the closest possible.

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EINsert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:EINS? → MAN
<b>Note</b>	

## 10.3.8 SDH:STIMuli:TX&lt;Pt&gt;:EBLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, DEFault = 1</i> Maximum depends on the error insert method, see SDH:STIM:TX<Pt>:EINS B03 - B10: Maximum = 1 MANual: Maximum = 8000 <sup>1</sup>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:EBL 1
<b>Note</b>	<sup>1</sup> If VC12 is active the maximum value for LPREI, V5LPB3, TCIEC, TCBIP2, TCREI and TCOEI is 2000. The maximum value is 4000 when :STIM:TX<Pt>:ERR is PRBS (Pattern error).

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:EBL? → 1
<b>Note</b>	



### 10.3.9 SDH:STIMuli:TX<Pt>:ENLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ENLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SDH:STIM:TX<Pt>:EINS
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:ENL 1
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:ENLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:ENL? → 1
<b>Note</b>	

### 10.3.10 SDH:STIMuli:TX<Pt>:EELength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EELength <frames>
<b>Description</b>	This command sets the alternate error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SDH:STIM:TX<Pt>:EINS
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:EEL 1
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:EELength?
<b>Description</b>	This query returns the alternate error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:EEL? → 1
<b>Note</b>	

### 10.3.11 SDH:STIMuli:TX<Pt>:PTSequence

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:PTSequence <type>,<sequence>
<b>Description</b>	This command sets the SDH pointer test sequence.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> AU4: AU-4 pointer AU3: AU-3 pointer TU3: TU-3 pointer TU12: TU-12 pointer TU11: TU-11 pointer <sequence> = <CHARACTER PROGRAM DATA> NONE: No test sequence SALternating: Single alternating RDOuble: Regular + double RMISsing: Regular + missing DALternating: Double alternating
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:PTS AU4,NONE
<b>Note</b>	

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:PTSequence? <type>
<b>Description</b>	This query returns the SDH pointer test sequence.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> AU4: AU-4 pointer AU3: AU-3 pointer TU3: TU-3 pointer TU12: TU-12 pointer TU11: TU-11 pointer
<b>Response</b>	<sequence> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:PTS? AU4 → NONE
<b>Note</b>	

### 10.3.12 SDH:STIMuli:TX<Pt>:PMOVE

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:PMOVe <type>,<value>
<b>Description</b>	This command sets the SDH pointer movement sequence. The value specifies the number of pointer increments.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> AU4: AU-4 pointer AU3: AU-3 pointer TU3: TU-3 pointer TU12: TU-12 pointer TU11: TU-11 pointer <value> = <NUMERIC PROGRAM DATA> <i>MINimum</i> = -100, <i>MAXimum</i> = 100
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:PMOV AU4,9
<b>Notes</b>	There is no query version of this command. A value of zero has no effect. A negative value results in pointer decrements.

## 10.3.13 SDH:STIMuli:TX&lt;Pt&gt;:PJUMp

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:PJUMp <type>,<value>[,<ndf>]
<b>Description</b>	This command sets the SDH pointer jump. The value specifies the new pointer value.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;  AU4: AU-4 pointer  AU3: AU-3 pointer  TU3: TU-3 pointer  TU12: TU-12 pointer  TU11: TU-11 pointer</p> <p>&lt;value&gt; = &lt;NUMERIC PROGRAM DATA&gt;  The valid range depends on SDH:STIMuli:TX&lt;Pt&gt;:PTYPe  AU4: 0 to 782  AU3: 0 to 782  TU3: 0 to 764  TU12: 0 to 139  TU11: 0 to 103</p> <p>&lt;ndf&gt; = &lt;CHARACTER PROGRAM DATA&gt;  WITH: With new data flag (NDF)  WOUT: Without new data flag (NDF)  <i>DEFault = WITH</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:PJUM AU4,300
<b>Notes</b>	There is no query version of this command. A negative value disables new data flag (NDF).

## 10.3.14 SDH:STIMuli:TX&lt;Pt&gt;:STL:AERRor:LANE

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AERRor:LANE <lane>
<b>Description</b>	This command sets the lane of the multi lane alarm/error to be inserted.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;lane&gt; = &lt;NUMERIC PROGRAM DATA&gt;  <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1000</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:AERR:LANE #B01 SDH:STIM:TX1:STL:AERR:LANE #B0100 These commands add error into lane 1.
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AERRor:LANE?
<b>Description</b>	This query returns the lane of the multi lane alarm/error to be inserted.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:AERR:LANE? → #B0100
<b>Note</b>	This command can be used on 40G

## 10.3.15 SDH:STIMuli:TX&lt;Pt&gt;:STL:ALARm

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ALARm <alarmtype>
<b>Description</b>	This command sets the type of alarm to be inserted.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> LOFOOF: LOF/OOF-STL LOROOR: LOR/OOR-STL <i>DEFault = LOFOOF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:ALAR LOFOOF
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ALARm?
<b>Description</b>	This query returns the type of alarm to be inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:ALAR? → LOFOOF
<b>Note</b>	This command can be used on 40G

## 10.3.16 SDH:STIMuli:TX&lt;Pt&gt;:STL:AINSert

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AINSert <insertion>
<b>Description</b>	This command sets the method to insert alarm.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual ALTErnate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:AINS MAN
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AINSert?
<b>Description</b>	This query returns the alarm insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:AINS? → MAN
<b>Note</b>	This command can be used on 40G

## 10.3.17 SDH:STIMuli:TX&lt;Pt&gt;:STL:ABLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ABLength <frames>
<b>Description</b>	This command sets the alarm burst length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:ABL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ABLength?
<b>Description</b>	This query returns the alarm burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:ABL? → 8000
<b>Note</b>	This command can be used on 40G

### 10.3.18 SDH:STIMuli:TX<Pt>:STL:AALength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AALength <frames>
<b>Description</b>	This command sets the alternate alarm length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:AAL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:AALength?
<b>Description</b>	This query returns the alternate alarm length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:AAL? → 8000
<b>Note</b>	This command can be used on 40G

### 10.3.19 SDH:STIMuli:TX<Pt>:STL:ANLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ANLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:ANL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ANLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:ANL? → 8000
<b>Note</b>	This command can be used on 40G

### 10.3.20 SDH:STIMuli:TX<Pt>:STL:ERRor

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ERRor <errortype>
<b>Description</b>	This command sets the type of error to be inserted.
<b>Parameters</b>	<Pt> = Port number <errortype> = <CHARACTER PROGRAM DATA> A1A2: A1A2-STL <i>DEFault = A1A2</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:ERR A1A2
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ERRor?
<b>Description</b>	This query returns the type of error to be inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:ERR? → A1A2
<b>Note</b>	This command can be used on 40G

### 10.3.21 SDH:STIMuli:TX<Pt>:STL:EINSert

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF ALternate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:EINS ALT
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:EINS? → ALT
<b>Note</b>	This command can be used on 40G

### 10.3.22 SDH:STIMuli:TX<Pt>:STL:EELength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:EELength <frames>
<b>Description</b>	This command sets the alternate error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:EEL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:EELength?
<b>Description</b>	This query returns the alternate error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:EEL? → 8000
<b>Note</b>	This command can be used on 40G

### 10.3.23 SDH:STIMuli:TX<Pt>:STL:ENLength

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ENLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:ENL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:ENLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:ENL? → 8000
<b>Note</b>	This command can be used on 40G

### 10.3.24 SDH:STIMuli:TX<Pt>:STL:SKEW:BIT

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:SKEW:BIT <bits>
<b>Description</b>	This command sets the bits of the skew .
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 138240, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:SKEW:BIT 1000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:SKEW:BIT?
<b>Description</b>	This query returns the bits of the skew .
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:SKEW:BIT? → 1000
<b>Note</b>	This command can be used on 40G

### 10.3.25 SDH:STIMuli:TX<Pt>:STL:SKEW:NS?

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:SKEW:NS?
<b>Description</b>	This query returns the time of the skew to be inserted. Unit: ns
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<skew> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:SKEW:NS? → 100.469
<b>Note</b>	This command can be used on 40G

### 10.3.26 SDH:STIMuli:TX<Pt>:STL:SKEW:LANE

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:SKEW:LANE <lane>
<b>Description</b>	This command sets the lane of the skew to be inserted.
<b>Parameters</b>	<Pt> = Port number <lane> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1000</i>
<b>Response</b>	None.
<b>Example</b>	SDH:STIM:TX1:STL:SKEW:LANE #B01 SDH:STIM:TX1:STL:SKEW:LANE #B0100 These commands add skew into lane 1.
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SDH:STIMuli:TX<Pt>:STL:SKEW:LANE?
<b>Description</b>	This query returns the lane of the skew to be inserted.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STIM:TX1:STL:SKEW:LANE? → #B0100
<b>Note</b>	This command can be used on 40G

## 10.4 Result

### 10.4.1 SDH:RX<Pt>:IFETch?

<b>Syntax</b>	SDH:RX<Pt>:IFETch? <parameter>
<b>Description</b>	This query fetches a SDH interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {,}*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>LOS: Loss of signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>GAIS: Generic alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOF: Loss of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>OOF: Out of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>MSAIS: Multiplex section alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>MSRDI: Multiplex section remote defect indicator. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AUAIS: Administrative unit - alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AULOP: Administrative unit - loss of pointer. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>HPTIM: High-order path trace identifier mismatch. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>HPPLM: Payload label mismatch. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>HPUNEQ: High-order path unequipped. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>HPRDI: High-order path remote defect indicator. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>TUAIS: Tributary unit alarm indication signal<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>TULOP: Tributary unit loss of pointer<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>TULOM: Tributary unit loss of multi frame<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LPTIM: Low-order path trace identifier mismatch<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LPUNEQ: Low-order path unequipped<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LPRDI: Low-order path remote defect indicator<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LPPLM: Low-order path payload label mismatch<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LSS: Loss of signal synchronization<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>A1A2: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B1: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B2: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>MSREI: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B3: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>HPREI: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>V5LPB3: <sup>1</sup>Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>ERRPRBS: Pattern errors<sup>1</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>ERRPRBSBLK: Pattern block errors<sup>1</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>LPREI: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>AUNDF: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>TUNDF: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>SAPS: Switch APS. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Rx frequency</b></p> <p>FREQ: Frequency deviation. Response: &lt;ppm&gt;</p> <p>FREQDIF: Frequency difference (RX1-RX2). Response: &lt;ppm&gt; (Only for RX1, RX2 is always NaN (section 1.6.1))</p> <p><b>Mux quality</b></p> <p>MFES: Forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MFSES: Forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MFUNAV: Forward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBES: Backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBSES: Backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBUNAV: Backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>VC-4 quality</b></p> <p>VC4FES: Forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>VC4FSES: Forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>

continued on next page...



... continued from previous page

VC4FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
VC4BES: Backward ES. Response: <Count>,<Ratio%>  
VC4BSES: Backward SES. Response: <Count>,<Ratio%>  
VC4BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**VC-3 quality<sup>1</sup>**  
VC3FES: Forward ES. Response: <Count>,<Ratio%>  
VC3FSES: Forward SES. Response: <Count>,<Ratio%>  
VC3FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
VC3BES: Backward ES. Response: <Count>,<Ratio%>  
VC3BSES: Backward SES. Response: <Count>,<Ratio%>  
VC3BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**VC-12 quality<sup>1</sup>**  
VC12FES: Forward ES. Response: <Count>,<Ratio%>  
VC12FSES: Forward SES. Response: <Count>,<Ratio%>  
VC12FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
VC12BES: Backward ES. Response: <Count>,<Ratio%>  
VC12BSES: Backward SES. Response: <Count>,<Ratio%>  
VC12BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**VC-11 quality<sup>1</sup>**  
VC11FES: Forward ES. Response: <Count>,<Ratio%>  
VC11FSES: Forward SES. Response: <Count>,<Ratio%>  
VC11FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
VC11BES: Backward ES. Response: <Count>,<Ratio%>  
VC11BSES: Backward SES. Response: <Count>,<Ratio%>  
VC11BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**Bulk quality**  
ES: ES. Response: <Count>,<Ratio%>  
SES: SES. Response: <Count>,<Ratio%>  
UNAV: UNAV. Response: <Count>,<Ratio%>  
**AU-4 pointer**  
AUPOINT: AU pointer. Response: <Count>  
AUNEG: Negative. Response: <Count>  
AUPOS: Positive. Response: <Count>  
**TU-3 or TU-12 or TU-11 pointer<sup>1</sup>**  
TUPOINT: TU pointer. Response: <Count>  
TUNEG: Negative. Response: <Count>  
TUPOS: Positive. Response: <Count>  
**Justification<sup>1</sup>**  
JNEG: Negative justification. Response: <Count>  
JPOS: Positive justification. Response: <Count>  
**MUX performance<sup>1</sup>**  
PMPES: Performance MUX PO limit ES. Response: <Count>,<Ratio%>  
PMPSES: Performance MUX PO limit SES. Response: <Count>,<Ratio%>  
PMPBBE: Performance MUX PO limit BBE. Response: <Count>,<Ratio%>  
PMBS1ES: Performance MUX BIS limit S1ES. Response: <Count>  
PMBS2ES: Performance MUX BIS limit S2ES. Response: <Count>  
PMBS1SES: Performance MUX BIS limit S1SES. Response: <Count>  
PMBS2SES: Performance MUX BIS limit S2SES. Response: <Count>  
PMFSTAT: Performance MUX forward status.  
Response: <STRING RESPONSE DATA>  
PMFES: Performance MUX forward ES. Response: <Count>,<Ratio%>  
PMFSES: Performance MUX forward SES. Response: <Count>,<Ratio%>  
PMFUNAV: Performance MUX forward UNAV. Response: <Count>,<Ratio%>  
PMFBBE: Performance MUX forward BBE. Response: <Count>,<Ratio%>  
PMBSTAT: Performance MUX backward status.  
Response: <STRING RESPONSE DATA>  
PMBES: Performance MUX backward ES. Response: <Count>,<Ratio%>

continued on next page...

...continued from previous page

PMBSES: Performance MUX backward SES. Response: <Count>,<Ratio%>  
PMBUNAV: Performance MUX backward UNAV. Response: <Count>,<Ratio%>  
PMBBBE: Performance MUX backward BBE. Response: <Count>,<Ratio%>  
**VC-4 performance<sup>1</sup>**  
PVC4PES: Performance VC4 PO limit ES. Response: <Count>,<Ratio%>  
PVC4PSES: Performance VC4 PO limit SES. Response: <Count>,<Ratio%>  
PVC4PBBE: Performance VC4 PO limit BBE. Response: <Count>,<Ratio%>  
PVC4BS1ES: Performance VC4 BIS limit S1ES. Response: <Count>  
PVC4BS2ES: Performance VC4 BIS limit S2ES. Response: <Count>  
PVC4BS1SES: Performance VC4 BIS limit S1SES. Response: <Count>  
PVC4BS2SES: Performance VC4 BIS limit S2SES. Response: <Count>  
PVC4FSTAT: Performance VC4 forward status.  
Response: <STRING RESPONSE DATA>  
PVC4FES: Performance VC4 forward ES. Response: <Count>,<Ratio%>  
PVC4FSES: Performance VC4 forward SES. Response: <Count>,<Ratio%>  
PVC4FUNAV: Performance VC4 forward UNAV. Response: <Count>,<Ratio%>  
PVC4FBBE: Performance VC4 forward BBE. Response: <Count>,<Ratio%>  
PVC4BSTAT: Performance VC4 backward status.  
Response: <STRING RESPONSE DATA>  
PVC4BES: Performance VC4 backward ES. Response: <Count>,<Ratio%>  
PVC4BSES: Performance VC4 backward SES. Response: <Count>,<Ratio%>  
PVC4BUNAV: Performance VC4 backward UNAV. Response: <Count>,<Ratio%>  
PVC4BBBE : Performance VC4 backward BBE. Response: <Count>,<Ratio%>  
**VC-12 performance<sup>1</sup>**  
PVC12PES: Performance VC12 PO limit ES. Response: <Count>,<Ratio%>  
PVC12PSES: Performance VC12 PO limit SES. Response: <Count>,<Ratio%>  
PVC12PBBE: Performance VC12 PO limit BBE. Response: <Count>,<Ratio%>  
PVC12BS1ES: Performance VC12 BIS limit S1ES. Response: <Count>  
PVC12BS2ES: Performance VC12 BIS limit S2ES. Response: <Count>  
PVC12BS1SES: Performance VC12 BIS limit S1SES. Response: <Count>  
PVC12BS2SES: Performance VC12 BIS limit S2SES. Response: <Count>  
PVC12FSTAT: Performance VC12 forward status.  
Response: <STRING RESPONSE DATA>  
PVC12FES: Performance VC12 forward ES. Response: <Count>,<Ratio%>  
PVC12FSES: Performance VC12 forward SES. Response: <Count>,<Ratio%>  
PVC12FUNAV: Performance VC12 forward UNAV. Response: <Count>,<Ratio%>  
PVC12FBBE: Performance VC12 forward BBE. Response: <Count>,<Ratio%>  
PVC12BSTAT: Performance VC12 backward status.  
Response: <STRING RESPONSE DATA>  
PVC12BES: Performance VC12 backward ES. Response: <Count>,<Ratio%>  
PVC12BSES: Performance VC12 backward SES. Response: <Count>,<Ratio%>  
PVC12BUNAV: Performance VC12 backward UNAV. Response: <Count>,<Ratio%>  
PVC12BBBE: Performance VC12 backward BBE. Response: <Count>,<Ratio%>  
**VC-11 performance<sup>1</sup>**  
PVC11PES: Performance VC11 PO limit ES. Response: <Count>,<Ratio%>  
PVC11PSES: Performance VC11 PO limit SES. Response: <Count>,<Ratio%>  
PVC11PBBE: Performance VC11 PO limit BBE. Response: <Count>,<Ratio%>  
PVC11BS1ES: Performance VC11 BIS limit S1ES. Response: <Count>  
PVC11BS2ES: Performance VC11 BIS limit S2ES. Response: <Count>  
PVC11BS1SES: Performance VC11 BIS limit S1SES. Response: <Count>  
PVC11BS2SES: Performance VC11 BIS limit S2SES. Response: <Count>  
PVC11FSTAT: Performance VC11 forward status.  
Response: <STRING RESPONSE DATA>  
PVC11FES: Performance VC11 forward ES. Response: <Count>,<Ratio%>  
PVC11FSES: Performance VC11 forward SES. Response: <Count>,<Ratio%>  
PVC11FUNAV: Performance VC11 forward UNAV. Response: <Count>,<Ratio%>  
PVC11FBBE: Performance VC11 forward BBE. Response: <Count>,<Ratio%>

continued on next page...

...continued from previous page

	<p>PVC11BSTAT: Performance VC11 backward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PVC11BES: Performance VC11 backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC11BSES: Performance VC11 backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC11BUNAV: Performance VC11 backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC11BBBE: Performance VC11 backward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>VC-3 performance<sup>1</sup></b></p> <p>PVC3PES: Performance VC3 PO limit ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3PSES: Performance VC3 PO limit SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3PBBE: Performance VC3 PO limit BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3BS1ES: Performance VC3 BIS limit S1ES. Response: &lt;Count&gt;</p> <p>PVC3BS2ES: Performance VC3 BIS limit S2ES. Response: &lt;Count&gt;</p> <p>PVC3BS1SES: Performance VC3 BIS limit S1SES. Response: &lt;Count&gt;</p> <p>PVC3BS2SES: Performance VC3 BIS limit S2SES. Response: &lt;Count&gt;</p> <p>PVC3FSTAT: Performance VC3 forward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PVC3FES: Performance VC3 forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3FSES: Performance VC3 forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3FUNAV: Performance VC3 forward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3FBBE: Performance VC3 forward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3BSTAT: Performance VC3 backward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PVC3BES: Performance VC3 backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3BSES: Performance VC3 backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3BUNAV: Performance VC3 backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVC3BBBE: Performance VC3 backward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>SDH TCM<sup>1</sup></b></p> <p>TCUNEQ: Tandem connection unequipped. response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCLTC: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCTIM: Tandem connection trace identifier mismatch. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCAIS: Tandem connection alarm indication signal. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCRDI: Tandem connection remote defect indicator. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCODI: Tandem Connection Outgoing Defect Indicator. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCIEC: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCBIP2: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCREI: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCOEI: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TAPID: TCM APID. Response N1 or N2 TCM ID: &lt;id&gt;</p> <p><b>STL</b></p> <p>LOFSTL: STL LOF. Response: &lt;Seconds&gt; x 4 lanes</p> <p>LORSTL: STL LOR. Response: &lt;Seconds&gt; x 4 lanes</p> <p>OOFSTL: STL OOF. Response: &lt;Frames&gt; x 4 lanes</p> <p>OORSTL: STL OOR. Response: &lt;Frames&gt; x 4 lanes</p> <p>A1A2STL: A1A2-STL. Response: &lt;Count&gt; x 4 lanes</p> <p>OLA: OLA. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RSKEW: Relative Skew. Response: &lt;Nanoseconds&gt; x 4 lanes</p> <p>MMAP: Marker Map. Response: &lt;NR1&gt; x 4 lanes</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	<p>SDH:RX1:IFET? (LOS,LOF,00F) → (3,0.00532),(4,0.00709),(5,0.00887)</p>
<b>Notes</b>	<p>This command fetches the results from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2).</p> <p><sup>1</sup> Requires the current interface/application is active in the measurement.</p> <p>If the requested result is not available, NaN (section 1.6.1) is returned.</p>

continued on next page...

... continued from previous page

	If there is one or more results, the last "," is always removed.
--	--

### 10.4.2 SDH:PMOVement:RX<Pt>:FETCh?

<b>Syntax</b>	SDH:PMOVement:RX<Pt>:FETCh? <pointer>,<min_time>,<max_time>
<b>Description</b>	This query fetches the pointer values.
<b>Parameters</b>	<p>&lt;pointer&gt; = &lt;CHARACTER PROGRAM DATA&gt;  AU: AU-4 or AU-3 pointer movements  TU: TU pointer movements. TU-3 or TU-12 or TU-11 depending on SDH interface setup.</p> <p>&lt;min_time&gt; = &lt;NUMERIC PROGRAM DATA&gt;  <i>MINimum=0, MAXimum=31536000</i>  Beginning of the interval in seconds.</p> <p>&lt;max_time&gt; = &lt;NUMERIC PROGRAM DATA&gt;  <i>MINimum=0, MAXimum=31536000</i>  End of the interval in seconds.</p>
<b>Response</b>	<p>{&lt;pointermovements&gt;}* = &lt;EXPRESSION RESPONSE DATA&gt;  The response is all pointer movements taking place in the requested time interval.  Format: (pointerChange0,timestamp0),(pointerChange1,timestamp1),...</p>
<b>Example</b>	SDH:PMOV:RX1:FETC? AU,0,3600 → (1,10.000),(-1,15.002)
<b>Notes</b>	<p>The interval is closed, i.e., it includes both endpoints.  The displayed resolution of the timestamps is 1/1000 second = 0.001s.</p>

## 10.5 Status

### 10.5.1 SDH:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	SDH:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the alarms and errors summary event register. The content of this event register is summarized in DB2 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<p>&lt;register&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;  DB1 (1) = Physical and high-order alarm summary  DB2 (2) = Low-order path and tandem connection alarm summary  DB3 (4) = Error section 1 summary  DB4 (8) = Error section 2 summary  DB5 (16) = STL alarm summary  DB6 (32) = STL error summary  DB7 - DB16 = NOT USED</p>
<b>Example</b>	SDH:STAT:RX1:AES? → 3
<b>Note</b>	SDH can embed E1, E3 or E4 so if a PDH signal is embedded it is a good idea to send the following query STAT:INT:PORT<Pt>[:EVENT]? to see if there is alarms or error at the embedded signal.

### 10.5.2 SDH:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	SDH:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<p>&lt;register&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;  Same as SDH:STATus:RX&lt;Pt&gt;:AESummary[:EVENT]?</p>
<b>Example</b>	SDH:STAT:RX1:AES:COND? → 3
<b>Note</b>	

## 10.5.3 SDH:STATus:RX&lt;Pt&gt;:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	SDH:STATus:RX<Pt>:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns one of the alarms event register. These registers are summarized in DB1 and DB2 of the SDH:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Physical- and high-order path alarms(1), Low-order path and tandem connection alarms(2) or STL alarms(3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: DB1 (1) = LOS, Loss of signal DB2 (2) = LOF, Loss of frame DB3 (4) = OOF, Out of frame DB4 (8) = MS-AIS, Multiplex section - alarm indication signal DB5 (16) = MS-RDI, Multiplex section - remote defect indicator DB6 (32) = AU-AIS, Administrative unit - alarm indication signal DB7 (64) = AU-LOP, Administrative unit - loss of pointer DB8 (128) = HP-TIM, High-order path - trace identifier mismatch DB9 (256) = HP-PLM, High-order path - payload label mismatch DB10 (512) = HP-UNEQ, High-order path - unequipped DB11 (1024) = HP-RDI, High-order path - remote defect indicator DB12 (2048) = TU-AIS, Tributary unit - alarm indication signal DB13 (4096) = TU-LOP, Tributary unit - loss of pointer DB14 (8192) = TU-LOM, Tributary unit - loss of multi frame DB15 (16384) = G-AIS, Generic alarm indication signal DB16 = NOT USED  <section> = 2: DB1 (1) = LP-TIM, Low-order path - trace identifier mismatch DB2 (2) = LP-UNEQ, Low-order path - unequipped DB3 (4) = LP-RDI, Low-order path - remote defect indicator DB4 (8) = LSS, Loss of signal synchronization DB5 = NOT USED DB6 (32) = LP-PLM, Low-order path - payload label mismatch DB7 (64) = TC-UNEQ, Tandem connection - unequipped DB8 (128) = TC-LTC, Tandem connection - loss of tandem connection DB9 (256) = TC-TIM, Tandem connection - trace identifier mismatch DB10 (512) = TC-AIS, Tandem connection - alarm indication signal DB11 (1024) = TC-RDI, Tandem connection - remote defect indicator DB12 (2048) = TC-ODI, Tandem connection - outgoing defect indicator DB13 - DB16 = NOT USED  <section> = 3: DB1 (1) = STL LOF DB2 (2) = STL OOF DB3 (4) = STL LOR DB4 (8) = STL OOR DB5 (16) = OLA DB6 - DB16 = NOT USED
<b>Example</b>	SDH:STAT:RX1:ALAR1? → 1
<b>Note</b>	

## 10.5.4 SDH:STATus:RX&lt;Pt&gt;:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	SDH:STATus:RX<Pt>:ALARm<section>:CONDition?
<b>Description</b>	This query returns one of the alarms condition registers. These registers are summarized in DB3 and DB4 of the SDH:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Physical- and high-order path alarms(1), Low-order path and tandem connection alarms(2) or STL alarms(3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as SDH:STATus:RX<Pt>:ALARm<section>[:EVENT]?
<b>Example</b>	SDH:STAT:RX1:ALAR1:COND? → 1
<b>Note</b>	

## 10.5.5 SDH:STATus:RX&lt;Pt&gt;:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	SDH:STATus:RX<Pt>:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the SDH:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = (1-3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: DB1 (1) = A1A2 DB2 (2) = B1 DB3 (4) = B2 DB4 (8) = MS-REI DB5 (16) = B3 DB6 (32) = HP-REI DB7 (64) = V5/LP-B3 DB8 (128) = LP-REI DB9 (256) = PRBS DB10 (512) = TU-NDF DB11 (1024) = AU-NDF DB12 (2048) = APS DB13 - DB16 = NOT USED  <section> = 2: DB1 (1) = TU-NEG DB2 (2) = TU-POS DB3 (4) = AU-NEG DB4 (8) = AU-POS DB5 not used DB6 (32) = TC-IEC DB7 (64) = TC-BIP-2 DB8 (128) = TC-REI DB9 (256) = TC-OEI DB10 - DB16 = NOT USED  <section> = 3: DB1 (1) = A1A2-STL DB2 - DB16 = NOT USED
<b>Example</b>	SDH:STAT:RX1:ERR1? → 3
<b>Note</b>	

### 10.5.6 SDH:STATus:RX<Pt>:ERRor<section>:CONDition?

<b>Syntax</b>	SDH:STATus:RX<Pt>:ERRor<section>:CONDition?
<b>Description</b>	This query returns errors condition register.
<b>Parameters</b>	<Pt> = Port number <section> = (1-3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as SDH:STATus:RX<Pt>:ERRor<section>[:EVENT]?
<b>Example</b>	SDH:STAT:RX1:ERR1:COND? → 3
<b>Note</b>	

### 10.5.7 SDH:STATus:RX<Pt>:PSLevel?

<b>Syntax</b>	SDH:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> "N/A": Module not present or not ready. - Electrical(STM1) - "<power> dBm": Min: "< -48 dBm", Max: "Exceeds Level" - Optical(Both module types) - "<power> dBm": Min: "< -27 dBm", Max: "Exceeds Level"
<b>Example</b>	SDH:STAT:RX1:PSL? → "-3 dBm"
<b>Note</b>	

### 10.5.8 SDH:STATus:TX<Pt>:PSLevel?

<b>Syntax</b>	SDH:STATus:TX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> "<power> dBm": Min: "< -27 dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	SDH:STAT:TX1:PSL? → "-3 dBm"
<b>Note</b>	Only available for Optical.

### 10.5.9 SDH:STATus:RX<Pt>:PDEViation?

<b>Syntax</b>	SDH:STATus:RX<Pt>:PDEViation? [<unit>]
<b>Description</b>	This query returns the physical deviation.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million BPS = Bits per second <i>DEFault = PPM</i>
<b>Response</b>	<deviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:PDEV? PPM → 0
<b>Note</b>	

### 10.5.10 SDH:STATus:RX<Pt>:PBRate?

<b>Syntax</b>	SDH:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns the physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:PBR? → 155520000
<b>Note</b>	

## 10.5.11 SDH:STATus:RX&lt;Pt&gt;:DIFFerence?

<b>Syntax</b>	SDH:STATus:RX<Pt>:DIFFerence?
<b>Description</b>	This query returns physical bit rate difference between port A and port B (RX1 - RX2). Units: ppm, bps and bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA> <acc> = <NR1 NUMERIC RESPONSE DATA> Accumulated difference in bits.
<b>Example</b>	SDH:STAT:RX1:DIFF? → -1, -4, -324
<b>Note</b>	A valid response is only available if both RX1 and RX2 are on. Using either RX1 or RX2 will give the same results.

## 10.5.12 SDH:STATus:RX&lt;Pt&gt;:RACCumulated

<b>Syntax</b>	SDH:STATus:RX<Pt>:RACCumulated
<b>Description</b>	This command resets the accumulated difference.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:STAT:RX1:RACC
<b>Note</b>	Using either RX1 or RX2 will give the same results.

## 10.5.13 SDH:STATus:RX&lt;Pt&gt;:PPBRate?

<b>Syntax</b>	SDH:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns physical pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:PPBR? → 149760000
<b>Note</b>	

## 10.5.14 SDH:STATus:RX&lt;Pt&gt;:CAPTure:SOH:TRACe?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:SOH:TRACe?
<b>Description</b>	This query returns the SOH trace (J0) for the latest captured frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J0_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:SOH:TRAC? → "Message_Test_J0"
<b>Note</b>	If one of the alarms LOS or LOF is present, an empty string is returned.



## 10.5.15 SDH:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:SOH?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:SOH? <SOH-byte>
<b>Description</b>	This query returns the SOH bytes from the selected frame. 256 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <SOH-byte> = <CHARACTER PROGRAM DATA> A1: Returns 3 bytes. A2: Returns 3 bytes. J0: Returns 3 bytes. B1: Returns 3 bytes. E1: Returns 3 bytes. F1: Returns 3 bytes. D1: Returns 3 bytes. D2: Returns 3 bytes. D3: Returns 3 bytes. H1: Returns 3 bytes. H2: Returns 3 bytes. H3: Returns 3 bytes. B2: Returns 3 bytes. K1: Returns 3 bytes. K2: Returns 3 bytes. D4: Returns 3 bytes. D5: Returns 3 bytes. D6: Returns 3 bytes. D7: Returns 3 bytes. D8: Returns 3 bytes. D9: Returns 3 bytes. D10: Returns 3 bytes. D11: Returns 3 bytes. D12: Returns 3 bytes. S1: Returns 3 bytes. Z2: Returns 3 bytes. E2: Returns 3 bytes. M0: Returns 1 byte. <sup>1</sup> M1: Returns 1 byte.
<b>Response</b>	<byte1>[,<byte2>[,<byte3>]] = <HEXADECIMAL NUMERIC RESPONSE DATA> Refer to <SOH-byte> parameter description above to see how many bytes this command returns.
<b>Examples</b>	SDH:STAT:RX1:CAPT64:SOH? A1 → #HF6,#HF6,#HF6 SDH:STAT:RX2:CAPT23:SOH? H1 → #H69,#H93,#H93 SDH:STAT:RX1:CAPT1:SOH? M1 → #H00
<b>Note</b>	If one of the alarms LOS or LOF is present NaN (section 1.6.1) is returned. <sup>1</sup> Only valid for SDH:RX<Pt>:STMLevel = 64 or 256.

## 10.5.16 SDH:STATus:RX&lt;Pt&gt;:CAPTure:VC4:POH:TRACe?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:VC4:POH:TRACe?
<b>Description</b>	This query returns the VC4 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:VC4:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or AULOP is present, an empty string is returned.

## 10.5.17 SDH:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:VC4:POH?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC4:POH? <POH-byte>
<b>Description</b>	This query returns the VC4 path overhead bytes from the selected frame. 256 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT1:VC4:POH? H4 → #HFF
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or AULOP is present NaN (section 1.6.1) is returned.

## 10.5.18 SDH:STATus:RX&lt;Pt&gt;:CAPTure:VC3:POH:TRACe?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:VC3:POH:TRACe?
<b>Description</b>	This command queries the VC3 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:VC3:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present, an empty string is returned.

## 10.5.19 SDH:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:VC3:POH?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC3:POH? <POH-byte>
<b>Description</b>	This query returns the VC3 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT1:VC3:POH? C2 → #HA3
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present NaN (section 1.6.1) is returned. Use the SDH:RX<Pt>:VC3:POH:CMASk command to selected which bytes to be captured.

**10.5.20 SDH:STATus:RX<Pt>:CAPTure:VC12:POH:TRACe?**

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:VC12:POH:TRACe?
<b>Description</b>	This query returns VC12 path overhead trace (J2) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J2_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:VC12:POH:TRAC? → "Message_Test_J2"
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present, an empty string is returned.

**10.5.21 SDH:STATus:RX<Pt>:CAPTure<Frame>:VC12:POH?**

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC12:POH? <POH-byte>
<b>Description</b>	This query returns the VC12 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5-SL byte. J2: J2 byte. N2: N2 byte. K4: K4 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT1:VC12:POH? V5 → #H04
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present NaN (section 1.6.1) is returned.

**10.5.22 SDH:STATus:RX<Pt>:CAPTure:VC11:POH:TRACe?**

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:VC11:POH:TRACe?
<b>Description</b>	This query returns VC11 path overhead trace (J2) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J2_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:VC11:POH:TRAC? → "Message_Test_J2"
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present, an empty string is returned.

**10.5.23 SDH:STATus:RX<Pt>:CAPTure<Frame>:VC11:POH?**

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:VC11:POH? <POH-byte>
<b>Description</b>	This query returns the VC11 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5-SL byte. J2: J2 byte. N2: N2 byte. K4: K4 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT1:VC11:POH? V5 → #H04
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or LPUNEQ is present NaN (section 1.6.1) is returned.

## 10.5.24 SDH:STATus:RX&lt;Pt&gt;:CAPTure:AU3:VC3:POH:TRACe?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure:AU3:VC3:POH:TRACe?
<b>Description</b>	This query returns the VC3 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT:AU3:VC3:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or AULOP is present, an empty string is returned.

## 10.5.25 SDH:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:AU3:VC3:POH?

<b>Syntax</b>	SDH:STATus:RX<Pt>:CAPTure<Frame>:AU3:VC3:POH? <POH-byte>
<b>Description</b>	This query returns the VC3 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:STAT:RX1:CAPT1:AU3:VC3:POH? H4 → #HFF
<b>Note</b>	If one of the alarms LOS, LOF, HPUNEQ or AULOP is present NaN (section 1.6.1) is returned.

## 10.6 APS

### 10.6.1 SDH:APS:START

<b>Syntax</b>	SDH:APS:START
<b>Description</b>	This command starts the APS (Automatic Protection Switching).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SDH:APS:STAR
<b>Note</b>	

### 10.6.2 SDH:APS:STOP

<b>Syntax</b>	SDH:APS:STOP
<b>Description</b>	This command stops the APS (Automatic Protection Switching).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SDH:APS:STOP
<b>Note</b>	

### 10.6.3 SDH:APS:RX<Pt>:PINTerpret?

<b>Syntax</b>	SDH:APS:RX<Pt>:PINTerpret?
<b>Description</b>	This query returns the protocol interpretation.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interpretation> = <STRING RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:PINT? → "00:00:19   Number 0   Time: 0.000ms ----- k1: Signal degrade (protection) Destination Node (K1) 2 k2: Short Source Node (K2) 7"
<b>Note</b>	

### 10.6.4 SDH:APS:RX<Pt>:NUMBER?

<b>Syntax</b>	SDH:APS:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of times an APS Protocol event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:NUMB? → 17
<b>Note</b>	

### 10.6.5 SDH:APS:RX<Pt>:ATIME?

<b>Syntax</b>	SDH:APS:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**10.6.6 SDH:APS:RX<Pt>:MTIME?**

<b>Syntax</b>	SDH:APS:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	SDH:APS:RX1:MTIM? → 4.000,0
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**10.6.7 SDH:APS:RX<Pt>:LTIME?**

<b>Syntax</b>	SDH:APS:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:LTIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**10.6.8 SDH:APS:RX<Pt>:CTIME?**

<b>Syntax</b>	SDH:APS:RX<Pt>:CTIME?
<b>Description</b>	This query returns the current time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<current> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:CTIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 99999.999 ms.

## 10.6.9 SDH:APS:RX&lt;Pt&gt;:EVENT

<b>Syntax</b>	SDH:APS:RX<Pt>:EVENT <event>
<b>Description</b>	This command sets the time reference event.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;event&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>LOS = Loss of signal  LOF = Loss of frame  OOF = Out of frame  MSAIS = MS alarm indication signal  MSRDI = MS remote defect indicator  APSS = APS switch-over  AUAIS = AU alarm indication signal  AULOP = AU loss of pointer  HPTIM = HP trace identifier mismatch  HPPLM = HP payload label mismatch  HPUNEQ = HP unequipped  TULOM = TU loss of multiframe  TUAIS = TU alarm indication signal  TULOP = TU loss of pointer  LPTIM = LP trace identifier mismatch  LPPLM = LP payload label mismatch  LPUNEQ = LP unequipped  A1A2 = Frame alignment word error  B1 = B1 checksum byte error  B2 = B2 checksum byte error  MSREI = MS remote error indication  B3 = B3 checksum byte error  V5 = B3 checksum of the low-order path  PERRor = Pattern error  ANYERROR = Any errors  <i>DEFault = LOS</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:EVEN LOF
<b>Note</b>	

<b>Syntax</b>	SDH:APS:RX<Pt>:EVENT?
<b>Description</b>	This query returns the time reference event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:EVEN? → LOF
<b>Note</b>	

## 10.6.10 SDH:APS:RX&lt;Pt&gt;:MLIMit

<b>Syntax</b>	SDH:APS:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;max&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p><i>MINimum = 0.000, MAXimum = 10000.000, DEFault = 50.000</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	SDH:APS:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:MLIM? → 50.000
<b>Note</b>	

### 10.6.11 SDH:APS:RX<Pt>:PERiod

<b>Syntax</b>	SDH:APS:RX<Pt>:PERiod <period>
<b>Description</b>	This command sets the error free period.
<b>Parameters</b>	<Pt> = Port number <period> = <NUMERIC PROGRAM DATA> 1,10,20,30,40,50,60,70,80,90,100 Unit ms <i>DEFault = 1</i>
<b>Response</b>	None
<b>Example</b>	SDH:APS:RX1:PER 1
<b>Note</b>	

<b>Syntax</b>	SDH:APS:RX<Pt>:PERiod?
<b>Description</b>	This query returns the error free period.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<period> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:PER? → 1
<b>Note</b>	

### 10.6.12 SDH:APS:RX<Pt>:CONFig

<b>Syntax</b>	SDH:APS:RX<Pt>:CONFig <protection>,<path>
<b>Description</b>	This command sets the protection type and the path or architecture.
<b>Parameters</b>	<Pt> = Port number <protection> = <CHARACTER PROGRAM DATA> RING = Ring protection LINear = Linear <i>DEFault = RING</i> <path> = <CHARACTER PROGRAM DATA> Ring Path: SHRT = Short path LONG = Long path <i>DEFault = SHRT</i>  Linear Architecture: 1P1 = 1+1 Architecture 1N = 1:n Architecture
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:CONF RING,SHRT
<b>Notes</b>	

<b>Syntax</b>	SDH:APS:RX<Pt>:CONFig?
<b>Description</b>	This query returns the protection type and the path or architecture.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<protection> = <CHARACTER RESPONSE DATA> <path> = <CHARACTER PROGRAM DATA>
<b>Example</b>	SDH:APS:RX1:CONF? → RING,SHRT
<b>Note</b>	



## 10.6.13 SDH:APS:RX&lt;Pt&gt;:RTYPE

<b>Syntax</b>	SDH:APS:RX<Pt>:RTYPE <type>
<b>Description</b>	This command sets the request type for the transmitter.
<b>Parameter</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>Ring Request Types: for SDH:APS:RX&lt;Pt&gt;:CONFig? → RING,....</p> <p>RLOP = Lockout of protection (span)</p> <p>RFSS = Forced switch (span)</p> <p>RFSR = Forced switch (ring)</p> <p>RSFS = Signal fail (span)</p> <p>RSFR = Signal fail (ring)</p> <p>RSDP = Signal degrade (protection)</p> <p>RSDS = Signal degrade (span)</p> <p>RSDR = Signal degrade (ring)</p> <p>RMSS = Manual switch (span)</p> <p>RMSR = Manual switch (ring)</p> <p>RWTR = Wait to restore</p> <p>REXS = Exercise (span)</p> <p>REXR = Exercise (ring)</p> <p>RRRS = Reverse request (span)</p> <p>RRRR = Reverse request (ring)</p> <p>RNRQ = No request</p> <p><i>DEFault = RLOP</i></p> <p>Linear Request Types: for SDH:APS:RX&lt;Pt&gt;:CONFig? → LIN,....</p> <p>LLOP = Lockout of protection</p> <p>LFSW = Forced switch</p> <p>LSFH = Signal fail (high priority)</p> <p>LSFL = Signal fail (low priority)</p> <p>LSDH = Signal degrade (high priority)</p> <p>LSDL = Signal degrade (low priority)</p> <p>LMSW = Manual switch (ring)</p> <p>LWTR = Wait to restore</p> <p>LEXC = Exercise</p> <p>LRRQ = Reverse request</p> <p>LDNR = Do not revert</p> <p>LNRQ = No request</p> <p><i>DEFault = LLOP</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:RTYP RLOP
<b>Note</b>	Use the SDH:APS:RX<Pt>:APPLY command to apply the request to the transmitter.

<b>Syntax</b>	SDH:APS:RX<Pt>:RTYPE?
<b>Description</b>	This query returns the request type for the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:RTYP? → RLOP
<b>Note</b>	

## 10.6.14 SDH:APS:RX&lt;Pt&gt;:K1

<b>Syntax</b>	SDH:APS:RX<Pt>:K1 <value>
<b>Description</b>	This command sets the destination node/source channel (K1).
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:K1 3
<b>Notes</b>	Cannot be changed if the SDH:APS:CONFig command is set to LIN, 1P1. Changes to SDH:APS:CONFig will reset this value to 0.

<b>Syntax</b>	SDH:APS:RX<Pt>:K1?
<b>Description</b>	This query returns the destination node/source channel (K1).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:K1? → 3
<b>Note</b>	

## 10.6.15 SDH:APS:RX&lt;Pt&gt;:K2

<b>Syntax</b>	SDH:APS:RX<Pt>:K2 <value>
<b>Description</b>	This command sets the source node/bridged channel (K2).
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:K2 3
<b>Notes</b>	Cannot be changed if the SDH:APS:CONFig command is set to LIN, 1P1. Changes to SDH:APS:CONFig will reset this value to 0.

<b>Syntax</b>	SDH:APS:RX<Pt>:K2?
<b>Description</b>	This query returns the source node/bridged channel (K2).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:APS:RX1:K2? → 3
<b>Note</b>	

## 10.6.16 SDH:APS:RX&lt;Pt&gt;:APPLy

<b>Syntax</b>	SDH:APS:RX<Pt>:APPLy
<b>Description</b>	This command applies the K1/K2 request setup to the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SDH:APS:RX1:APPL
<b>Notes</b>	

## 10.7 Tributary Scan

## 10.7.1 SDH:TSCan:STARt

<b>Syntax</b>	SDH:TSCan:STARt
<b>Description</b>	This command starts the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SDH:TSC:STAR
<b>Note</b>	It is possible to run only one test or measurement at a time. The SDH interface must be active for at least one of the receivers.

### 10.7.2 SDH:TSCan:STOP

<b>Syntax</b>	SDH:TSCan:STOP
<b>Description</b>	This command stops the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SDH:TSC:STOP
<b>Note</b>	

### 10.7.3 SDH:TSCan:RX<Pt>:NHOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:NHOCContainer?
<b>Description</b>	This query returns the number of High-order containers (VC-4/3)
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TSC:RX1:NHOC? → 4
<b>Note</b>	If '0' is returned, no High-order containers were found. To get more information, use the SDH:TSCan:RX<Pt>:MUX? query.

### 10.7.4 SDH:TSCan:RX<Pt>:GHOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:GHOCContainer?
<b>Description</b>	This query returns the state of High-order containers (VC-4/3)
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<p>{&lt;value&gt;,+} = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p> <p>The values are presented in ascending order, meaning that VC-4 #1 is the first on the list.</p> <p>0 = No alarms or errors.</p> <p>1 = Alarms or errors present.</p>
<b>Example</b>	SDH:TSC:RX1:GHOC? → (0,0,1,0)
<b>Note</b>	If there is one or more results, the last ",," is always removed.

### 10.7.5 SDH:TSCan:RX<Pt>:SHOCContainer

<b>Syntax</b>	SDH:TSCan:RX<Pt>:SHOCContainer <VC4>
<b>Description</b>	This command sets the High-order container (VC-4/3) for scanning.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;VC4&gt; = High-order container number</p> <p><i>MINimum=1, MAXimum=768</i></p>
<b>Response</b>	None.
<b>Example</b>	SDH:TSC:RX1:SHOC 2
<b>Note</b>	

### 10.7.6 SDH:TSCan:RX<Pt>:SHOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:SHOCContainer?
<b>Description</b>	This query returns the High-order container (VC-4/3) set for scanning.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<VC4> = High-order container number
<b>Example</b>	SDH:TSC:RX1:SHOC? → 2
<b>Note</b>	

## 10.7.7 SDH:TSCan:RX&lt;Pt&gt;:DHOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:DHOCContainer? <VC4/3>
<b>Description</b>	This query returns the detailed alarm and error information from a High-order container (VC-4/3).
<b>Parameters</b>	<Pt> = Port number <VC4> = High-order container number <i>MINimum=1, MAXimum=768</i>
<b>Response</b>	<selected>, = <STRING RESPONSE DATA>. {RXn}␣{High-order}, separated by one space character. RXn = RX1 or RX2 High-order = VC-4#0 ... VC-4#64 or VC-3#0 ... VC-3#192 ({<alarmerrors>,*}) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SDH:TSC:RX1:DHOC? 1 → "RX1 VC-4#1", ("B1", "A1A2")
<b>Note</b>	If there is one or more responses, the last ", " is always removed.

## 10.7.8 SDH:TSCan:RX&lt;Pt&gt;:NLOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:NLOCContainer?
<b>Description</b>	This query returns the number of Low-order containers (VC-3/12/11).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:TSC:RX1:NLOC? → 3
<b>Note</b>	

## 10.7.9 SDH:TSCan:RX&lt;Pt&gt;:GLOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:GLOCContainer?
<b>Description</b>	This query returns the state of Low-order containers (VC-3/12/11).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	({<value>,*}) = <NR1 NUMERIC RESPONSE DATA> The values are presented in ascending order, meaning that VC-4 #1 is the first in the list. 0 = No alarms or errors. 1 = Alarms or errors present.
<b>Example</b>	SDH:TSC:RX1:GLOC? → (0,1,1)
<b>Note</b>	If there is one or more responses, the last ", " is always removed.

## 10.7.10 SDH:TSCan:RX&lt;Pt&gt;:DLOCContainer?

<b>Syntax</b>	SDH:TSCan:RX<Pt>:DLOCContainer? <VC3/12/11>
<b>Description</b>	This query returns the detailed alarm and error information from a Low-order container (VC-3/12/11).
<b>Parameters</b>	<Pt> = Port number <VC3/12/11> = Low-order container number <i>MINimum=1, MAXimum=84</i>
<b>Response</b>	<selected>, = <STRING RESPONSE DATA>. {RXn}␣{High-order}:{Low-order}, First separated by one space character and next with a colon char. RXn = RX1 or RX2 High-order = VC-4#0 ... VC-4#64 or VC-3#0 ... VC-3#192 Low-order = VC-3#1 ... VC-3#3 or VC-12#1 ... VC-12#63 or VC-11#1 ... VC-11#84 ({<alarmerrors>,*}) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SDH:TSC:RX1:DLOC? 1 → "RX1 VC-4#1:VC-3#1", ("B1", "A1A2")
<b>Notes</b>	To select the High-order container, use the SDH:TSCan:RX<rx>:SHOCContainer command. If there is one or more responses, the last ", " is always removed.

**10.7.11 SDH:TSCan:RX<Pt>:DMUX?**

<b>Syntax</b>	SDH:TSCan:RX<Pt>:DMUX?
<b>Description</b>	This query returns the detailed alarm and error information from the MUX.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<selected> = <STRING RESPONSE DATA>. {Rx} MUX ({<alarmerrors>, }*) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SDH:TSC:RX1:DMUX? → "Rx1 MUX", ("LOS", "LOF", "OOF")
<b>Notes</b>	This query is only available when no High-order containers are present. To determine if MUX is available, use the SDH:TSCan:RX<Pt>:NHOCContainer? query. If there is one or more responses, the last ",," is always removed.

## 10.8 RTD

This section document commands for the Round Trip Delay application. Commands for general RTD settings are described in section 16.1 on page 837.

### 10.8.1 SDH:RTD:RX<Pt>:MLIMit

<b>Syntax</b>	SDH:RTD:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: us.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0, MAXimum = 1000000.0, DEFault = MAXimum</i>
<b>Response</b>	None.
<b>Example</b>	SDH:RTD:RX1:MLIM 0.0
<b>Note</b>	

<b>Syntax</b>	SDH:RTD:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RTD:RX1:MLIM? → 0.0
<b>Note</b>	

### 10.8.2 SDH:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	SDH:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 10.8.3 SDH:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	SDH:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 10.8.4 SDH:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	SDH:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	SDH:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 10.8.5 SDH:RTD:RX<Pt>:LTIMe?

<b>Syntax</b>	SDH:RTD:RX<Pt>:LTIMe?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 10.8.6 SDH:RTD:RX<Pt>:CTIMe?

<b>Syntax</b>	SDH:RTD:RX<Pt>:CTIMe?
<b>Description</b>	This query returns the current time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SDH:RTD:RX1:CTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds 99999999.9 us.





---

# Chapter 11

## SONET

Use `MEAS:SET:PORT<Pt>:TERM` to change the SDH/SONET terminology (see section 17.2.1).

### 11.1 Receiver

#### 11.1.1 SONet:RX<Pt>:INterface

<b>Syntax</b>	SONet:RX<Pt>:INterface <mode>
<b>Description</b>	This command sets the used interface or switches off the receiver.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Disables receiver ELECtrical: Electrical interface SFP: SFP/SFP+ optical interface CFP: CFP optical interface OPTical: Obsolete. For CMA 3000 backward compatibility only. Same as SFP <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:INT OFF
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:INterface?
<b>Description</b>	This query returns the used interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:INT? → OFF
<b>Note</b>	Returns OTN when SONET over OTN.

#### 11.1.2 SONet:RX<Pt>:OCLevel

<b>Syntax</b>	SONet:RX<Pt>:OCLevel <level>
<b>Description</b>	This command sets the OC level of the SONET receiver.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 3: OC-3 signal. 12: OC-12 signal. 48: OC-48 signal. 192: OC-192 signal. 768: OC-768 signal. <i>DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:OCL 3
<b>Note</b>	Setting the OC level may change the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:RX<Pt>:OCLevel?
<b>Description</b>	This query returns the OC level of the SONET receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:OCL? → 3
<b>Note</b>	

### 11.1.3 SONet:RX<Pt>:STSLevel

<b>Syntax</b>	SONet:RX<Pt>:STSLevel <level>
<b>Description</b>	This command sets the STS level of the SONET receiver.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 3: STS-3 signal. 12: STS-12 signal. 48: STS-48 signal. 192: STS-192 signal. 768: STS-768 signal. <i>DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:STSL 3
<b>Note</b>	Setting the STS level may change the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:RX<Pt>:STSLevel?
<b>Description</b>	This query returns the STS level of the SONET receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:STSL? → 3
<b>Note</b>	

### 11.1.4 SONet:RX<Pt>:STS3c

<b>Syntax</b>	SONet:RX<Pt>:STS3c <sts>
<b>Description</b>	This command sets the STS Group(s) to be used in the signal structure.
<b>Parameters</b>	<Pt> = Port number <sts> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 768, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:STS3 1
<b>Note</b>	The specified STS3c cannot exceed the OC level divided by the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:RX<Pt>:STS3c?
<b>Description</b>	This query returns STS Group(s) used in the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<sts> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:STS3? → 1
<b>Note</b>	

## 11.1.5 SONet:RX&lt;Pt&gt;:CONCatenation

<b>Syntax</b>	SONet:RX<Pt>:CONCatenation <level>
<b>Description</b>	This command sets the STS concatenation level.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> STS1SPE STS3CSPE STS12C STS48C STS192C STS768C <i>DEFault = STS3CSPE</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:CONC STS3CSPE
<b>Note</b>	Setting the STS concatenation level may change the OC level.

<b>Syntax</b>	SONet:RX<Pt>:CONCatenation?
<b>Description</b>	This query returns the STS concatenation level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:CONC? → STS3CSPE
<b>Note</b>	

## 11.1.6 SONet:RX&lt;Pt&gt;:CONTainer

<b>Syntax</b>	SONet:RX<Pt>:CONTainer <type>
<b>Description</b>	This command sets the container type (container-n).
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> C3 C4 C11 C12 <i>DEFault = C4</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:CONT C4
<b>Note</b>	Setting the container type.

<b>Syntax</b>	SONet:RX<Pt>:CONTainer?
<b>Description</b>	This query returns the container type (container-n).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:CONT? → C4
<b>Note</b>	

## 11.1.7 SONet:RX&lt;Pt&gt;:SSTRucture

<b>Syntax</b>	SONet:RX<Pt>:SSTRucture <structure>
<b>Description</b>	This command sets the expected SONET signal structure.
<b>Parameters</b>	<Pt> = Port number <structure> = <CHARACTER PROGRAM DATA> BULK: Bulk data in the STS3. E1: E1 signal in a VT2 in one or all STS's E3: E3 signal in a STS1 in one or all STS's DS1: DS1 signal in a VT15 in one or all STS's DS3: DS3 signal in a STS1 in one or all STS's E4: E4 signal in a STS3 in one or all STS's <i>DEFault = BULK</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:SSTR BULK
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:SSTRucture?
<b>Description</b>	This query returns the expected SONET signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<structure> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:SSTR? → BULK
<b>Note</b>	

## 11.1.8 SONet:RX&lt;Pt&gt;:PATtern

<b>Syntax</b>	SONet:RX<Pt>:PATtern <pattern>
<b>Description</b>	This command sets the pattern to be expected as payload when SSTRucture is BULK.
<b>Parameters</b>	<Pt> = Port number <pattern> = <CHARACTER PROGRAM DATA> OFF USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9: PRBS-9 pattern. PRBS11: PRBS-11 pattern. PRBS15: PRBS-15 pattern. PRBS20: PRBS-20 pattern. PRBS23: PRBS23 pattern. PRBS29: PRBS-29 pattern. PRBS31: PRBS-31 pattern. ALL0: Pattern of all zeros. ALL1: Pattern of all ones. ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 B2IN8: Random pattern with two ones for every eight bits. <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:PATtern?
<b>Description</b>	This query returns the pattern to be expected as payload when SSTRucture is BULK.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:PATT? → PRBS23
<b>Note</b>	

## 11.1.9 SONet:RX&lt;Pt&gt;:UP32

<b>Syntax</b>	SONet:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	SON:RX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SON:RX1:UP32? → "01101"
<b>Note</b>	

## 11.1.10 SONet:RX&lt;Pt&gt;:UP2K

<b>Syntax</b>	SONet:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	SON:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when SON:RX1:PATT is USER2048BIT

<b>Syntax</b>	SONet:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SON:RX1:UP2K? → "12DF"
<b>Note</b>	

## 11.1.11 SONet:RX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	SONet:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion (when SSTRucture is BULK).
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:PINV OFF
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:RX1:PINV? → 0
<b>Note</b>	

## 11.1.12 SONet:RX&lt;Pt&gt;:TCM

<b>Syntax</b>	SONet:RX<Pt>:TCM <mode>
<b>Description</b>	This command sets the Tandem Connection Monitoring mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Off STS3: Z5 (STS3) STS1: Z5 (STS1) VT2: Z6 (VT2) VT15: Z6 (VT1.5) <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:TCM OFF
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:TCM?
<b>Description</b>	This query returns Tandem Connection Monitoring mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:TCM? → OFF
<b>Note</b>	

## 11.1.13 SONet:RX&lt;Pt&gt;:TUG3

<b>Syntax</b>	SONet:RX<Pt>:TUG3 <id>
<b>Description</b>	This command sets the TUG-3 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-3 number one. 2: TUG-3 number two. 3: TUG-3 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:TUG3 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:RX<Pt>:TUG3?
<b>Description</b>	This query returns TUG3 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:TUG3? → 1
<b>Note</b>	

## 11.1.14 SONet:RX&lt;Pt&gt;:VTG

<b>Syntax</b>	SONet:RX<Pt>:VTG <id>
<b>Description</b>	This command sets the VTG number for signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VTG number one. 2: VTG number two. ... 7: VTG number seven. <i>MINimum = 1, MAXimum = 7, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:VTG 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:RX<Pt>:VTG?
<b>Description</b>	This query returns VTG number for signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:VTG? → 1
<b>Note</b>	

### 11.1.15 SONet:RX<Pt>:VT2

<b>Syntax</b>	SONet:RX<Pt>:VT2 <id>
<b>Description</b>	This command sets the VT2 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VT2 number one. 2: VT2 number two. 3: VT2 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:VT2 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:RX<Pt>:VT2?
<b>Description</b>	This query returns VT2 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:VT2? → 1
<b>Note</b>	

### 11.1.16 SONet:RX<Pt>:VT15

<b>Syntax</b>	SONet:RX<Pt>:VT15 <id>
<b>Description</b>	This command sets the VT1.5 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VT1.5 number one. 2: VT1.5 number two. 3: VT1.5 number three. 4: VT1.5 number four. <i>MINimum = 1, MAXimum = 4, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:VT15 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:RX<Pt>:VT15?
<b>Description</b>	This query returns VT1.5 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:VT15? → 1
<b>Note</b>	

## 11.1.17 SONet:RX&lt;Pt&gt;:CHANnel

<b>Syntax</b>	SONet:RX<Pt>:CHANnel <id>
<b>Description</b>	This command sets the channel number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=84, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:CHAN 1
<b>Note</b>	This value influences the TUG-3, VTG, VT2 and VT1.5 numbers.

<b>Syntax</b>	SONet:RX<Pt>:CHANnel?
<b>Description</b>	This query returns the channel number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RX1:CHAN? → 1
<b>Note</b>	

## 11.1.18 SONet:RX&lt;Pt&gt;:MAPPING

<b>Syntax</b>	SONet:RX<Pt>:MAPPING <type>
<b>Description</b>	This command sets the mapping type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SYNChronous: Synchronous mapping. ASYNChronous: Asynchronous mapping. <i>DEFault = SYNC</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:MAPP SYNC
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:MAPPING?
<b>Description</b>	This query returns returns the mapping type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:MAPP? → SYNC
<b>Note</b>	

## 11.1.19 SONet:RX&lt;Pt&gt;:GAIN

<b>Syntax</b>	SONet:RX<Pt>:GAIN <type>
<b>Description</b>	This command sets the receiver gain.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> TERMinate: Frequency dependent AGC. MONitor: Frequency linear AGC. <i>DEFault = TERMinate</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:GAIN TERM
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:GAIN?
<b>Description</b>	This query returns the receiver gain.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:GAIN? → TERM
<b>Note</b>	



## 11.1.20 SONet:RX&lt;Pt&gt;:FOLLow

<b>Syntax</b>	SONet:RX<Pt>:FOLLow <mode>
<b>Description</b>	This command sets the receiver setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX: Follows setup of the Tx port. RX1: Follows setup of the Rx port1. <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:FOLL NONE
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:FOLLow?
<b>Description</b>	This query returns the receiver setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:RX1:FOLL? → NONE
<b>Note</b>	

## 11.1.21 SONet:RX&lt;Pt&gt;:MEASurement:PLMP

<b>Syntax</b>	SONet:RX<Pt>:MEASurement:PLMP <detected>
<b>Description</b>	This command enables or disables PLM-P measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:MEAS:PLMP ON
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:MEASurement:PLMP?
<b>Description</b>	This query returns whether or not PLM-P measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:RX1:MEAS:PLMP? → 1
<b>Note</b>	

## 11.1.22 SONet:RX&lt;Pt&gt;:MEASurement:PLMV

<b>Syntax</b>	SONet:RX<Pt>:MEASurement:PLMV <detected>
<b>Description</b>	This command enables or disables PLM-V measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SON:RX1:MEAS:PLMV ON
<b>Note</b>	

<b>Syntax</b>	SONet:RX<Pt>:MEASurement:PLMV?
<b>Description</b>	This query returns whether or not PLM-V measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:RX1:MEAS:PLMV? → 1
<b>Note</b>	

## 11.2 Transmitter

### 11.2.1 SONet:TX<Pt>:INTerface

<b>Syntax</b>	SONet:TX<Pt>:INTerface <mode>
<b>Description</b>	This command sets the used interface of the transmitter.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> ELEctrical: Electrical interface SFP: SFP/SFP+ optical interface CFP: CFP optical interface <i>DEFault = ELEC</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:INT SFP
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:INTerface?
<b>Description</b>	This query returns the used interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:INT? → SFP
<b>Note</b>	Returns OTN when SONET over OTN.

### 11.2.2 SONet:TX<Pt>[:ENABLE]

<b>Syntax</b>	SONet:TX<Pt>[:ENABLE] <mode>
<b>Description</b>	This command sets the mode of the transmitter.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Turn off the transmitter. NORMal: Normal transmission mode using the configured signal. THRough: Through mode. The signal from the receiver is transmitted. OTHRough: OH overwrite through mode. THA: Obsolete. For CMA 3000 backward compatibility only. Same as THRough. <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1 NORM
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>[:ENABLE]?
<b>Description</b>	This query returns the mode of the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1? → NORM
<b>Note</b>	

### 11.2.3 SONet:TX<Pt>:OPTical

<b>Syntax</b>	SONet:TX<Pt>:OPTical <mode>
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SON:TX<Pt>:INT SFP and SON:TX<Pt>
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:OPT NORM
<b>Note</b>	Compared to CMA 3000 there is no longer a suffix on the last node.

<b>Syntax</b>	SONet:TX<Pt>:OPTical?
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SON:TX<Pt>?
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:OPT? → NORM
<b>Note</b>	

#### 11.2.4 SONet:TX<Pt>:ELECtrical

<b>Syntax</b>	SONet:TX<Pt>:ELECtrical <mode>
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SON:TX<Pt>:INT ELEC and SON:TX<Pt>
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:ELEC NORM
<b>Note</b>	Compared to CMA 3000 mode=THB is no longer supported.

<b>Syntax</b>	SONet:TX<Pt>:ELECtrical?
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as SON:TX<Pt>?
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:ELEC? → NORM
<b>Note</b>	

#### 11.2.5 SONet:TX<Pt>:OCLevel

<b>Syntax</b>	SONet:TX<Pt>:OCLevel <level>
<b>Description</b>	This command sets the OC level of the transmitted SONET signal.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 3: OC-3 signal. 12: OC-12 signal. 48: OC-48 signal. 192: OC-192 signal. 768: OC-768 signal. <i>DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:OCL 3
<b>Notes</b>	Setting the OC level may change the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:TX<Pt>:OCLevel?
<b>Description</b>	This query returns the OC level of the transmitted SONET signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:OCL? → 1
<b>Note</b>	

## 11.2.6 SONet:TX&lt;Pt&gt;:STSLevel

<b>Syntax</b>	SONet:TX<Pt>:STSLevel <level>
<b>Description</b>	This command sets the STS level of the SONET receiver.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> 3: STS-3 signal. 12: STS-12 signal. 48: STS-48 signal. 192: STS-192 signal. 768: STS-768 signal. <i>DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STSL 3
<b>Note</b>	Setting the STS level may change the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:TX<Pt>:STSLevel?
<b>Description</b>	This query returns the STS level of the SONET receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STSL? → 3
<b>Note</b>	

## 11.2.7 SONet:TX&lt;Pt&gt;:STS3c

<b>Syntax</b>	SONet:TX<Pt>:STS3c <value>
<b>Description</b>	This command sets the STS where the test signal is inserted.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> ALL 1 to 768 <i>DEFault = ALL</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3 ALL
<b>Note</b>	The specified STS3c cannot exceed the OC level divided by the STS-3cSPE concatenation level.

<b>Syntax</b>	SONet:TX<Pt>:STS3c?
<b>Description</b>	This query returns the STS where the test signal has been inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS3? → ALL
<b>Note</b>	

## 11.2.8 SONet:TX&lt;Pt&gt;:CONCatenation

<b>Syntax</b>	SONet:TX<Pt>:CONCatenation <level>
<b>Description</b>	This command sets the STS concatenation level.
<b>Parameters</b>	<Pt> = Port number <level> = <CHARACTER PROGRAM DATA> STS1SPE STS3CSPE STS12C STS48C STS192C STS768C <i>DEFault = STS3CSPE</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:CONC STS3CSPE
<b>Note</b>	Setting the STS concatenation level may change the STM level.

<b>Syntax</b>	SONet:TX<Pt>:CONCatenation?
<b>Description</b>	This query returns the STS concatenation level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:CONC? → STS3CSPE
<b>Note</b>	

## 11.2.9 SONet:TX&lt;Pt&gt;:CONTainer

<b>Syntax</b>	SONet:TX<Pt>:CONTainer <type>
<b>Description</b>	This command sets the container type (container-n).
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> C3 C4 C11 C12 <i>DEFault = C4</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:CONT C4
<b>Note</b>	Setting the container type.

<b>Syntax</b>	SONet:TX<Pt>:CONTainer?
<b>Description</b>	This query returns the container type (container-n).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:CONT? → C4
<b>Note</b>	

## 11.2.10 SONet:TX&lt;Pt&gt;:SSTRucture

<b>Syntax</b>	SONet:TX<Pt>:SSTRucture <structure>
<b>Description</b>	This command sets the SONET signal structure.
<b>Parameters</b>	<Pt> = Port number <structure> = <CHARACTER PROGRAM DATA> BULK: Bulk data in the STS3. E1: E1 signal in a VC-12 in one or all STS's E3: E3 signal in a VC-3 in one or all STS's DS1: DS1 signal in a VC-11 in one or all STS's DS3: DS3 signal in a VC-3 in one or all STS's E4: E4 signal in a VC-4 in one or all STS's <i>DEFault = BULK</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:SSTR BULK
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:SSTRucture?
<b>Description</b>	This query returns the SONET signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<structure> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:SSTR? → BULK
<b>Note</b>	

## 11.2.11 SONet:TX&lt;Pt&gt;:PATTern

<b>Syntax</b>	SONet:TX<Pt>:PATTern <pattern>
<b>Description</b>	This command sets the pattern to be used as payload when SSTRucture is BULK.
<b>Parameters</b>	<Pt> = Port number <pattern> = <CHARACTER PROGRAM DATA> OFF USER32BIT: 32 bit user defined pattern. USER2048BIT: 2048 bit user defined pattern. PRBS9: PRBS-9 pattern. PRBS11: PRBS-11 pattern. PRBS15: PRBS-15 pattern. PRBS20: PRBS-20 pattern. PRBS23: PRBS23 pattern. PRBS29: PRBS-29 pattern. PRBS31: PRBS-31 pattern. ALL0: Pattern of all zeros. ALL1: Pattern of all ones. ALT11: Alternating 1:1 ALT13: Alternating 1:3 ALT17: Alternating 1:7 B2IN8: Random pattern with two ones for every eight bits. <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:PATT PRBS23
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:PATTern?
<b>Description</b>	Queries the pattern to be used as payload when SSTRucture is BULK.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:PATT? → PRBS23
<b>Note</b>	

## 11.2.12 SONet:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	SONet:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTERN is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Examples</b>	SON:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SON:TX1:UP32? → "01101"
<b>Note</b>	

## 11.2.13 SONet:TX&lt;Pt&gt;:UP2K

<b>Syntax</b>	SONet:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	SON:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when SON:TX1:PATT is USER2048BIT

<b>Syntax</b>	SONet:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	SON:TX1:UP2K? → "12DF"
<b>Note</b>	

## 11.2.14 SONet:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	SONet:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion (when SSTRUCTURE is BULK).
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>Default = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:PINV OFF
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:PINV? → 0
<b>Note</b>	

## 11.2.15 SONet:TX&lt;Pt&gt;:TIMing

<b>Syntax</b>	SONet:TX<Pt>:TIMing <source>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal clock. EXTernal: External clock. RX: Received Rx signal clock. <i>DEFault = INT</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:TIM? → INT
<b>Note</b>	

## 11.2.16 SONet:TX&lt;Pt&gt;:TCM

<b>Syntax</b>	SONet:TX<Pt>:TCM <mode>
<b>Description</b>	This command sets the TCM mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Off STS3: Z5 (STS3) STS1: Z5 (STS1) VT2: Z6 (VT2) VT15: Z6 (VT1.5) <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TCM OFF
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:TCM?
<b>Description</b>	Queries the TCM mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:TCM? → OFF
<b>Note</b>	

## 11.2.17 SONet:TX&lt;Pt&gt;:TUG3

<b>Syntax</b>	SONet:TX<Pt>:TUG3 <id>
<b>Description</b>	This command sets the TUG-3 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: TUG-3 number one. 2: TUG-3 number two. 3: TUG-3 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TUG3 1
<b>Note</b>	This value influences the channel number.



<b>Syntax</b>	SONet:TX<Pt>:TUG3?
<b>Description</b>	This query returns TUG3 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:TUG3? → 1
<b>Note</b>	

### 11.2.18 SONet:TX<Pt>:VTG

<b>Syntax</b>	SONet:TX<Pt>:VTG <id>
<b>Description</b>	This command sets the VTG number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VTG number one. 2: VTG number two. ... 7: VTG number seven. <i>MINimum = 1, MAXimum = 7, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VTG 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:TX<Pt>:VTG?
<b>Description</b>	This query returns VTG number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VTG? → 1
<b>Note</b>	

### 11.2.19 SONet:TX<Pt>:VT2

<b>Syntax</b>	SONet:TX<Pt>:VT2 <id>
<b>Description</b>	This command sets the VT2 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VT2 number one. 2: VT2 number two. 3: VT2 number three. <i>MINimum = 1, MAXimum = 3, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:TX<Pt>:VT2?
<b>Description</b>	This query returns VT2 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT2? → 1
<b>Note</b>	

## 11.2.20 SONet:TX&lt;Pt&gt;:VT15

<b>Syntax</b>	SONet:TX<Pt>:VT15 <id>
<b>Description</b>	This command sets the VT1.5 number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> 1: VT1.5 number one. 2: VT1.5 number two. 3: VT1.5 number three. 4: VT1.5 number four. <i>MINimum = 1, MAXimum = 4, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15 1
<b>Note</b>	This value influences the channel number.

<b>Syntax</b>	SONet:TX<Pt>:VT15?
<b>Description</b>	This query returns VT1.5 number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT15? → 1
<b>Note</b>	

## 11.2.21 SONet:TX&lt;Pt&gt;:CHANnel

<b>Syntax</b>	SONet:TX<Pt>:CHANnel <id>
<b>Description</b>	This command sets the channel number for the signal structure.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=84, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:CHAN 1
<b>Note</b>	The value influences the TUG-3, TUG-2 and TU-12 numbers.

<b>Syntax</b>	SONet:TX<Pt>:CHANnel?
<b>Description</b>	This query returns the channel number for the signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:CHAN? → 1
<b>Note</b>	

## 11.2.22 SONet:TX&lt;Pt&gt;:MAPPING

<b>Syntax</b>	SONet:TX<Pt>:MAPPING <type>
<b>Description</b>	This command sets the mapping type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SYNChronous: Synchronous mapping. ASYNchronous: Asynchronous mapping. <i>DEFault = SYNC</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:MAPP SYNC
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:MAPPING?
<b>Description</b>	This query returns the mapping type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:MAPP? → SYNC
<b>Note</b>	

### 11.2.23 SONet:TX<Pt>:TOH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:TOH:DEFault
<b>Description</b>	This command sets all OC TOH bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TOH:DEF
<b>Note</b>	There is no query version of this command.

### 11.2.24 SONet:TX<Pt>:TOH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:TOH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the TOH trace (J0) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: The string to be used as section trace string. <i>DEFault = "Message_Test_J0"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TOH:TRAC "Message_Test_J0",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated.


<b>Syntax</b>	SONet:TX<Pt>:TOH:TRACe?
<b>Description</b>	This query returns the TOH trace for string and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:TOH:TRAC? → "Message_Test_J0",#H20
<b>Note</b>	

### 11.2.25 SONet:TX<Pt>:TOH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:TOH:TRACe:CRC <mode>
<b>Description</b>	This command sets the TOH trace (J0) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:TOH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:TOH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the TOH trace (J0) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:TOH:TRAC:CRC? → 1
<b>Note</b>	

11.2.26 SONet:TX<Pt>:TOH

<b>Syntax</b>	SONet:TX<Pt>:TOH <TOH-byte>,<value1>[,<value2>[,<value3>]]
<b>Description</b>	This command sets the value of the specified bytes in the TOH.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;TOH-byte&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A1: 3 bytes.  A2: 3 bytes.  J0: 3 bytes. Note: The defined trace string will be disabled.  B1: 2 bytes. &lt;value3&gt; is ignored.  E1: 3 bytes.  F1: 3 bytes.  D1: 3 bytes.  D2: 3 bytes.  D3: 3 bytes.  K1: 3 bytes.  K2: 3 bytes.  D4: 3 bytes.  D5: 3 bytes.  D6: 3 bytes.  D7: 3 bytes.  D8: 3 bytes.  D9: 3 bytes.  D10: 3 bytes.  D11: 3 bytes.  D12: 3 bytes.  S1: 3 bytes.  Z2: 3 bytes.  E2: 3 bytes.  M0: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored. <sup>1</sup>  M1: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored.</p>  <p>&lt;value1&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p> <p>&lt;value2&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p> <p>&lt;value3&gt; = &lt;NUMERIC PROGRAM DATA&gt;  MINimum = 0, MAXimum = 255</p>
<b>Response</b>	None.
<b>Examples</b>	SON:TX1:TOH A1,0,0,0 SON:TX1:TOH D7,253,32,26 SON:TX1:TOH B1,4,5 SON:TX1:TOH M1,0
<b>Note</b>	<sup>1</sup> Only valid for SONet:TX<Pt>:OCLLevel = 192 or 768.

<b>Syntax</b>	SONet:TX<Pt>:TOH? <TOH-byte>
<b>Description</b>	This query returns the value of the specified bytes in the TOH.
<b>Parameters</b>	<Pt> = Port number <SOH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value1> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value2> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value3> = <HEXADECIMAL NUMERIC RESPONSE DATA>]]
<b>Examples</b>	SON:TX1:TOH? A1 → #H00,#H00,#H00 SON:TX1:TOH? D7 → #HFD,#H20,#H1A SON:TX1:TOH? B1 → #H04,#H05 SON:TX1:TOH? M1 → #H00
<b>Note</b>	

### 11.2.27 SONet:TX<Pt>:STS3:POH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:DEFault
<b>Description</b>	This command sets all STS3 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3:POH:DEF
<b>Note</b>	There is no query version of this command.

### 11.2.28 SONet:TX<Pt>:STS3:POH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the STS3 path trace (J1) to the specified string and its idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: The string to be used as path trace string. <i>DEFault</i> = "Message_Test_J1" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated.

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TRACe?
<b>Description</b>	This query returns the STS3 path trace text and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS3:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	

### 11.2.29 SONet:TX<Pt>:STS3:POH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:STS3:POH:TRAC:CRC? → 1
<b>Note</b>	

### 11.2.30 SONet:TX<Pt>:STS3:POH:TTCM

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the STS3 TCM trace (Z5) to the specified string and its idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_Z5" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3:POH:TTCM "Apid_TCM_Z5",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH:TTCM?
<b>Description</b>	This query returns the STS3 TCM trace text and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS3:POH:TTCM? → "Apid_TCM_Z5",#H20
<b>Note</b>	

### 11.2.31 SONet:TX<Pt>:STS3:POH

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the STS3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte. Only available when there is no TCM. <value> = <NUMERIC PROGRAM DATA> <i>MINimum</i> = 0, <i>MAXimum</i> = 255
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS3:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS3:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the STS3 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Examples</b>	SON:TX1:STS3:POH? C2 → #H00 SON:TX1:STS3:POH? H4 → #HFF
<b>Note</b>	

## 11.2.32 SONet:TX&lt;Pt&gt;:STS1:POH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:DEFault
<b>Description</b>	This command sets all STS1 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:POH:DEF
<b>Note</b>	There is no query version of this command.

## 11.2.33 SONet:TX&lt;Pt&gt;:STS1:POH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the STS1 path trace (J1) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Message_Test_J1" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TRACe?
<b>Description</b>	This query returns the STS1 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	

## 11.2.34 SONet:TX&lt;Pt&gt;:STS1:POH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:POH:TRAC:CRC? → 1
<b>Note</b>	

## 11.2.35 SONet:TX&lt;Pt&gt;:STS1:POH:TTCM

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the STS1 TCM trace (Z5) to the specified string, and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_Z5" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:POH:TTCM "Apid_TCM_Z5",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH:TTCM?
<b>Description</b>	This query returns the STS1 TCM trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:POH:TTCM? → "Apid_TCM_Z5",#H20
<b>Note</b>	

## 11.2.36 SONet:TX&lt;Pt&gt;:STS1:POH

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the STS1 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte. Only available when there is no TCM. <value> = <NUMERIC PROGRAM DATA> <i>MINimum</i> = 0, <i>MAXimum</i> = 255
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the STS1 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:POH? C2 → #H00
<b>Note</b>	

## 11.2.37 SONet:TX&lt;Pt&gt;:VT2:POH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:DEFault
<b>Description</b>	This command sets all VT2 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2:POH:DEF
<b>Note</b>	There is no query version of this command.



## 11.2.38 SONet:TX&lt;Pt&gt;:VT2:POH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VT2 path trace (J2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Message_Test_J2" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2:POH:TRAC "Message_Test_J2",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TRACe?
<b>Description</b>	This query returns the VT2 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT2:POH:TRAC? → "Message Test J2",#H20
<b>Note</b>	

## 11.2.39 SONet:TX&lt;Pt&gt;:VT2:POH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J2) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J2) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:VT2:POH:TRAC:CRC? → 1
<b>Note</b>	

## 11.2.40 SONet:TX&lt;Pt&gt;:VT2:POH:TTCM

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VT2 TCM trace (Z6) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault</i> = "Apid_TCM_Z6" <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault</i> = #H20
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2:POH:TTCM "Apid_TCM_Z6",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH:TTCM?
<b>Description</b>	This query returns the VT2 trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT2:POH:TTCM? → "Apid_TCM_Z6",#H20
<b>Note</b>	

#### 11.2.41 SONet:TX<Pt>:VT2:POH

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VT2 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5 byte. Z6: Z6 byte. Z7: Z7 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT2:POH V5,#H04
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT2:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VT2 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT2:POH? V5 → #H04
<b>Note</b>	

#### 11.2.42 SONet:TX<Pt>:VT15:POH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:DEFault
<b>Description</b>	This command sets all VT1.5 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15:POH:DEF
<b>Note</b>	There is no query version of this command.

#### 11.2.43 SONet:TX<Pt>:VT15:POH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the VT1.5 path trace (J2) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Message_Test_J2"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15:POH:TRAC "Message_Test_J2",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TRACe?
<b>Description</b>	This query returns the VT1.5 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT15:POH:TRAC? → "Message_Test_J2",#H20
<b>Note</b>	

#### 11.2.44 SONet:TX<Pt>:VT15:POH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J2) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J2) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:VT15:POH:TRAC:CRC? → 1
<b>Note</b>	

#### 11.2.45 SONet:TX<Pt>:VT15:POH:TTCM

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the VT1.5 TCM trace (Z6) to the specified string and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Apid_TCM_Z6"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15:POH:TTCM "Apid_TCM_Z6",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH:TTCM?
<b>Description</b>	This query returns the VT1.5 trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT15:POH:TTCM? → "Apid_TCM_Z6",#H20
<b>Note</b>	

## 11.2.46 SONet:TX&lt;Pt&gt;:VT15:POH

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the VT1.5 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5 byte. Z6: Z6 byte. Z7: Z7 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:VT15:POH V5,#H04
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:VT15:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the VT1.5 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:VT15:POH? V5 → #H04
<b>Note</b>	

## 11.2.47 SONet:TX&lt;Pt&gt;:STS1:STS1:POH:DEFault

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:DEFault
<b>Description</b>	This command sets all STS1 path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:STS1:POH:DEF
<b>Note</b>	There is no query version of this command.

## 11.2.48 SONet:TX&lt;Pt&gt;:STS1:STS1:POH:TRACe

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the STS1 path trace (J1) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Message_Test_J1"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:STS1:POH:TRAC "Message_Test_J1",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TRACe?
<b>Description</b>	This query returns the STS1 path trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:STS1:POH:TRAC? → "Message_Test_J1",#H20
<b>Note</b>	

## 11.2.49 SONet:TX&lt;Pt&gt;:STS1:STS1:POH:TRACe:CRC

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the section overhead trace (J1) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:STS1:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the overhead trace (J1) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:STS1:POH:TRAC:CRC? → 1
<b>Note</b>	

## 11.2.50 SONet:TX&lt;Pt&gt;:STS1:STS1:POH:TTCM

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TTCM <string>[,<idlechar>]
<b>Description</b>	This command sets the STS1 TCM trace (Z5) to the specified string, and the idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> Quoted string: Path trace string. <i>DEFault = "Apid_TCM_Z5"</i> <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:STS1:POH:TTCM "Apid_TCM_Z5",#H20
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH:TTCM?
<b>Description</b>	This query returns the STS1 TCM trace.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA>, <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:STS1:POH:TTCM? → "Apid_TCM_Z5",#H20
<b>Note</b>	

## 11.2.51 SONet:TX&lt;Pt&gt;:STS1:STS1:POH

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the STS1 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte. Only available when there is no TCM. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STS1:STS1:POH C2,0
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:STS1:STS1:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the STS1 path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TX1:STS1:STS1:POH? C2 → #H00
<b>Note</b>	

### 11.2.52 SONet:TX<Pt>:FOLLOw

<b>Syntax</b>	SONet:TX<Pt>:FOLLOw <mode>
<b>Description</b>	This command sets the transmitter setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX1: Follows setup of the Tx port1. <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:FOLL NONE
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:FOLLow?
<b>Description</b>	This query returns the transmitter setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:FOLL? → NONE
<b>Note</b>	

### 11.2.53 SONet:TX<Pt>:OTHRough

<b>Syntax</b>	SONet:TX<Pt>:OTHRough <mode>
<b>Description</b>	This command sets the OH Overwrite Position.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> TOH: SOH Data. A1A2: A1/A2 byte. K1K2: K1/K2 byte. S1: S1 byte. DCC1TO3: DCC1-3 byte. DCC4TO12: DCC4-12 byte. J0: J0 byte. TOH1BYTE: 1 byte of TOH.(selectable) <i>DEFault = TOH</i>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:OTHR A1A2
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:OTHRough?
<b>Description</b>	This query returns the OH Overwrite Position.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<position> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:OTHR? → A1A2
<b>Note</b>	

## 11.2.54 SONet:TX&lt;Pt&gt;:OTHRough:BYTE

<b>Syntax</b>	SONet:TX<Pt>:OTHRough:BYTE <byte>
<b>Description</b>	This command sets the OH Overwrite Position.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;byte&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A11-A13: A1 bytes.  A21-A23: A2 bytes.  J0: J0 byte.  E1: E1 byte.  F1: F1 byte.  D1: D1 byte.  D2: D2 byte.  D3: D3 byte.  K1: K1 byte.  K2: K2 byte.  D4: D4 byte.  D5: D5 byte.  D6: D6 byte.  D7: D7 byte.  D8: D8 byte.  D9: D9 byte.  D10: D10 byte.  D11: D11 byte.  D12: D12 byte.  S1: S1 byte.  M0: M0 byte.  M1: M1 byte.  E2: E2 byte.  X18-X99: X&lt;Line&gt;&lt;Column&gt;  <i>DEFault = A11</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:OTHR:BYTE A11
<b>Note</b>	

<b>Syntax</b>	SONet:TX<Pt>:OTHRough:BYTE?
<b>Description</b>	This query returns the OH Overwrite Position.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<byte> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:TX1:OTHR:BYTE? → A11
<b>Note</b>	

## 11.2.55 SONet:TX&lt;Pt&gt;:STL:MMAPIng:LANE

<b>Syntax</b>	SONet:TX<Pt>:STL:MMAPIng:LANE <lanes>
<b>Description</b>	This command sets the STL lane marker assignment.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{(&lt;lanes&gt;),}* = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>Format: Numeric List</p> <p>List consist of the value of the lane marker ranging from 0 to 3.</p>
<b>Response</b>	None.
<b>Example</b>	SON:TX1:STL:MMAPIng:LANE (0,1,2,3)
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:TX<Pt>:STL:MMAPing:LANE?
<b>Description</b>	This query returns the STL lane marker assignment.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<lanes>),}* = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	SON:TX1:STL:MMAP:LANE? → (0,1,2,3)
<b>Note</b>	This command can be used on 40G

## 11.3 Stimuli

### 11.3.1 SONet:STIMuli:TX<Pt>:FOFFset

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> MT1000A: <i>MINimum</i> =-50, <i>MAXimum</i> =50, <i>DEFault</i> =0 MT1100A: <i>MINimum</i> =-200.0, <i>MAXimum</i> =200.0, <i>DEFault</i> = 0
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:FOFF 0
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	MT1000A: <offset> = <NR1 NUMERIC RESPONSE DATA> MT1100A: <offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MT1000A: SON:STIM:TX1:FOFF? → 0 MT1100A: SON:STIM:TX1:FOFF? → 0.0
<b>Note</b>	



## 11.3.2 SONet:STIMuli:TX&lt;Pt&gt;:ALARm

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ALARm <alarmtype>
<b>Description</b>	This command sets the type of alarm to be generated.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;alarmtype&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>LOS: Loss of signal  LOF: Loss of frame  OOF: Out of frame  AISL(MSAIS): MS alarm indication signal  RDIL(MSRDI): MS remote defect indicator  AISP(AUAIS): AU alarm indication signal  LOPP(AULOP): AU loss of pointer  TIMP(HPTIM): HP trace identifier mismatch  PLMP(HPPLM): HP payload label mismatch  UNEQP(HPUNEQ): HP unequipped  RDIP(HPRDI): HP remote defect indicator  AISV(TUAIS): TU alarm indication signal  LOPV(TULOP): TU loss of pointer  LOMV(TULOM): TU loss of multiframe  TIMV(LPTIM): LP trace identifier mismatch  UNEQV(LPUNEQ): LP unequipped  RDIV(LPRDI): LP remote defect indicator  PLMV(LPPLM): LP payload label mismatch  LSS: Loss of signal synchronization  TCUNEQ: TC unequipped  TCLTC: TC loss of tandem connection  TCTIM: TC trace identifier mismatch  TCAIS: TC alarm indication signal  TCRDI: TC remote defect indicator  TCODI: TC outgoing defect indicator  <i>DEFault = LOS</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:ALAR LOS
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ALARm?
<b>Description</b>	This query returns the type of alarm to be generated.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:ALAR? → LOS
<b>Note</b>	

## 11.3.3 SONet:STIMuli:TX&lt;Pt&gt;:AINSert

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:AINSert <insertion>
<b>Description</b>	This command sets the method to insert alarm.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;insertion&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>OFF  PERManent  ALTerminate  <i>DEFault = OFF</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:AINS PERM
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:AINSer?
<b>Description</b>	This query returns the alarm insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:AINS? → PERM
<b>Note</b>	

### 11.3.4 SONet:STIMuli:TX<Pt>:ANLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ANLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SON:STIM:TX<Pt>:AINS
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:ANL 1
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ANLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:ANL? → 1
<b>Note</b>	

### 11.3.5 SONet:STIMuli:TX<Pt>:AALength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:AALength <frames>
<b>Description</b>	This command sets the alternate alarm length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SON:STIM:TX<Pt>:AINS
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:AAL 1
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:AALength?
<b>Description</b>	This query returns the alternate alarm length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:AAL? → 1
<b>Note</b>	

## 11.3.6 SONet:STIMuli:TX&lt;Pt&gt;:ERRor

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ERRor <errordestination>
<b>Description</b>	This command sets the error destination.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;errordestination&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A1A2: Frame alignment word</p> <p>B1: B1 checksum byte</p> <p>B2: B2 checksum byte</p> <p>REIL(MSREI): MS remote error indication</p> <p>B3: B3 checksum byte</p> <p>REIP(HPREI): HP Remote error indication</p> <p>V5LPB3: B3 checksum of the low-order path</p> <p>REIV(LPREI): LP remote error indication</p> <p>PRBS: Pattern error</p> <p>ETRans: ERR-TRANS</p> <p>TCIEC: Tandem Connection incoming error count</p> <p>TCREI: Tandem Connection remote error indication</p> <p>TCOEI: Tandem Connection outgoing error indication</p> <p>TCBIP2: 2-bit Bit Interleaved Parity for Tandem Connection</p> <p><i>DEFault = A1A2</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:ERR MSREI
<b>Note</b>	Some errors are depended on type of content, setting them without the correct type of content will set EINSert to OFF. Changing the error may also change the insert method. See section 11.3.7.

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ERRor?
<b>Description</b>	This query returns the error destination.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errordestination> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:ERR? → MSREI
<b>Note</b>	

## 11.3.7 SONet:STIMuli:TX&lt;Pt&gt;:EINsert

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EINsert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual B03: Burst · 1E-03 <sup>1</sup> B04: Burst · 1E-04 <sup>1</sup> B05: Burst · 1E-05 <sup>1</sup> B06: Burst · 1E-06 <sup>2</sup> B07: Burst · 1E-07 B08: Burst · 1E-08 B09: Burst · 1E-09 B10: Burst · 1E-10 ALternate DEFault = OFF
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14. <sup>1</sup> Is available for PRBS and ETRans (B03 is only available for ETRans if the STM Level is 1). <sup>2</sup> Is available for PRBS, ETRans, B2, V5LPB3, REIL, TCIEC, TCBIP2, TCREI and TCOEI. Selecting an unsupported burst rate will reset the rate to the closest possible.

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EINsert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:EINS? → MAN
<b>Note</b>	

## 11.3.8 SONet:STIMuli:TX&lt;Pt&gt;:EBLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EBLength <burstlength>
<b>Description</b>	This command sets the error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <burstlength> = <NUMERIC PROGRAM DATA> MINimum = 1, DEFault = 1 Maximum depends on the error insert method, see SON:STIM:TX<Pt>:EINS B03 - B10: Maximum = 1 MANual: Maximum = 8000 <sup>1</sup>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:EBL 1
<b>Note</b>	<sup>1</sup> If VC12 is active the maximum value for REIL, V5LPB3, TCIEC, TCBIP2, TCREI and TCOEI is 2000. The maximum value is 4000 when :STIM:TX<Pt>:ERR is PRBS (Pattern error).

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EBLength?
<b>Description</b>	This query returns the error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<burstlength> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:EBL? → 1
<b>Note</b>	

### 11.3.9 SONet:STIMuli:TX<Pt>:ENLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ENLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SON:STIM:TX<Pt>:EINS
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:ENL 1
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:ENLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:ENL? → 1
<b>Note</b>	

### 11.3.10 SONet:STIMuli:TX<Pt>:EELength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EELength <frames>
<b>Description</b>	This command sets the alternate error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i> Maximum depends on the error insert method, see SON:STIM:TX<Pt>:EINS
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:EEL 1
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:EELength?
<b>Description</b>	This query returns the alternate error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:EEL? → 1
<b>Note</b>	

### 11.3.11 SONet:STIMuli:TX<Pt>:PTSequence

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:PTSequence <type>,<sequence>
<b>Description</b>	This command sets the SONET pointer test sequence.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> STS3: STS3 pointer STS1: STS1 pointer TU3: TU-3 pointer VT2: VT2 pointer VT15: VT1.5 pointer <sequence> = <CHARACTER PROGRAM DATA> NONE: No test sequence SALternating: Single alternating RDOuble: Regular + double RMISsing: Regular + missing DALternating: Double alternating
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:PTS STS3,NONE
<b>Note</b>	

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:PTSequence? <type>
<b>Description</b>	This query returns the SONET pointer test sequence.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> STS3: STS3 pointer STS1: STS1 pointer TU3: TU-3 pointer VT2: VT2 pointer VT15: VT1.5 pointer
<b>Response</b>	<sequence> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:PTS? STS3 → NONE
<b>Note</b>	

### 11.3.12 SONet:STIMuli:TX<Pt>:PMOVE

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:PMOVE <type>,<value>
<b>Description</b>	This command sets the SONET pointer movement sequence. The value specifies the number of pointer increments.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> STS3: STS3 pointer STS1: STS1 pointer TU3: TU-3 pointer VT2: VT2 pointer VT15: VT1.5 pointer <value> = <NUMERIC PROGRAM DATA> <i>MINimum = -100, MAXimum = 100</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:PMOV AU4,9
<b>Notes</b>	There is no query version of this command. A value of zero has no effect. A negative value results in pointer decrements.

## 11.3.13 SONet:STIMuli:TX&lt;Pt&gt;:PJUMp

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:PJUMp <type>,<value>[,<ndf>]
<b>Description</b>	This command sets the SONET pointer jump. The value specifies the new pointer value.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;            STS3: STS3 pointer            STS1: STS1 pointer            TU3: TU-3 pointer            VT2: VT2 pointer            VT15: VT1.5 pointer</p> <p>&lt;value&gt; = &lt;NUMERIC PROGRAM DATA&gt;            The valid range depends on SONet:STIMuli:TX&lt;Pt&gt;:PTYPE            STS3: 0 to 782            STS1: 0 to 782            TU3: 0 to 764            VT2: 0 to 139            VT15: 0 to 103</p> <p>&lt;ndf&gt; = &lt;CHARACTER PROGRAM DATA&gt;            WITH: With new data flag (NDF)            WOUT: Without new data flag (NDF)  <i>DEFault = WITH</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:PJUM AU4,300
<b>Notes</b>	There is no query version of this command. A negative value disables new data flag (NDF).

## 11.3.14 SONet:STIMuli:TX&lt;Pt&gt;:STL:AERRor:LANE

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AERRor:LANE <lane>
<b>Description</b>	This command sets the lane of the multi lane alarm/error to be inserted.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;lane&gt; = &lt;NUMERIC PROGRAM DATA&gt;  <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1000</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:AERR:LANE #B01 SON:STIM:TX1:STL:AERR:LANE #B0100 These commands add error into lane 1.
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AERRor:LANE?
<b>Description</b>	This query returns the lane of the multi lane alarm/error to be inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:AERR:LANE? → #B0100
<b>Note</b>	This command can be used on 40G

## 11.3.15 SONet:STIMuli:TX&lt;Pt&gt;:STL:ALARm

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ALARm <alarmtype>
<b>Description</b>	This command sets the type of alarm to be inserted.
<b>Parameters</b>	<Pt> = Port number <alarmtype> = <CHARACTER PROGRAM DATA> LOFOOF: LOF/OOF-STL LOROOR: LOR/OOR-STL <i>DEFault = LOFOOF</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:ALAR LOF
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ALARm?
<b>Description</b>	This query returns the type of alarm to be inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarmtype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:ALAR? → LOF
<b>Note</b>	This command can be used on 40G

## 11.3.16 SONet:STIMuli:TX&lt;Pt&gt;:STL:AINSert

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AINSert <insertion>
<b>Description</b>	This command sets the method to insert alarm.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF MANual ALTErnate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:AINS MAN
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AINSert?
<b>Description</b>	This query returns the alarm insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:AINS? → MAN
<b>Note</b>	This command can be used on 40G

## 11.3.17 SONet:STIMuli:TX&lt;Pt&gt;:STL:ABLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ABLength <frames>
<b>Description</b>	This command sets the alarm burst length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:ABL 8000
<b>Note</b>	This command can be used on 40G



<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ABLength?
<b>Description</b>	This query returns the alarm burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:ABL? → 8000
<b>Note</b>	This command can be used on 40G

### 11.3.18 SONet:STIMuli:TX<Pt>:STL:AALength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AALength <frames>
<b>Description</b>	This command sets the alternate alarm length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:AAL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:AALength?
<b>Description</b>	This query returns the alternate alarm length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:AAL? → 8000
<b>Note</b>	This command can be used on 40G

### 11.3.19 SONet:STIMuli:TX<Pt>:STL:ANLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ANLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:ANL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ANLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:ANL? → 8000
<b>Note</b>	This command can be used on 40G

### 11.3.20 SONet:STIMuli:TX<Pt>:STL:ERRor

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ERRor <errortype>
<b>Description</b>	This command sets the type of error to be inserted.
<b>Parameters</b>	<Pt> = Port number <errortype> = <CHARACTER PROGRAM DATA> A1A2: A1A2-STL <i>DEFault = A1A2</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:ERR A1A2
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ERRor?
<b>Description</b>	This query returns the type of error to be inserted.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:ERR? → A1A2
<b>Note</b>	This command can be used on 40G

### 11.3.21 SONet:STIMuli:TX<Pt>:STL:EINSert

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:EINSert <insertion>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> OFF ALternate <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:EINS ALT
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:EINSert?
<b>Description</b>	This query returns the error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:EINS? → ALT
<b>Note</b>	This command can be used on 40G

### 11.3.22 SONet:STIMuli:TX<Pt>:STL:EELength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:EELength <frames>
<b>Description</b>	This command sets the alternate error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:EEL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:EELength?
<b>Description</b>	This query returns the alternate error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:EEL? → 8000
<b>Note</b>	This command can be used on 40G

### 11.3.23 SONet:STIMuli:TX<Pt>:STL:ENLength

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ENLength <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:ENL 8000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:ENLength?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:ENL? → 8000
<b>Note</b>	This command can be used on 40G

#### 11.3.24 SONet:STIMuli:TX<Pt>:STL:SKEW:BIT

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:SKEW:BIT <bits>
<b>Description</b>	This command sets the bits of the skew .
<b>Parameters</b>	<Pt> = Port number <bits> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 138240, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:SKEW:BIT 1000
<b>Note</b>	This command can be used on 40G

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:SKEW:BIT?
<b>Description</b>	This query returns the bits of the skew .
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:SKEW:BIT? → 1000
<b>Note</b>	This command can be used on 40G

#### 11.3.25 SONet:STIMuli:TX<Pt>:STL:SKEW:NS?

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:SKEW:NS?
<b>Description</b>	This query returns the time of the skew to be inserted. Unit: ns
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<skew> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:SKEW:NS? → 100.469
<b>Note</b>	This command can be used on 40G

#### 11.3.26 SONet:STIMuli:TX<Pt>:STL:SKEW:LANE

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:SKEW:LANE <lane>
<b>Description</b>	This command sets the lane of the skew to be inserted.
<b>Parameters</b>	<Pt> = Port number <lane> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B1000</i>
<b>Response</b>	None.
<b>Example</b>	SON:STIM:TX1:STL:SKEW:LANE #B01 SON:STIM:TX1:STL:SKEW:LANE #B0100 These commands add skew into lane 1.
<b>Note</b>	This command can be used on 40G

#### 11.3.27 SONet:STIMuli:TX<Pt>:STL:SKEW:LANE?

<b>Syntax</b>	SONet:STIMuli:TX<Pt>:STL:SKEW:LANE?
<b>Description</b>	This query returns the lane of the skew to be inserted.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STIM:TX1:STL:SKEW:LANE? → #B0100
<b>Note</b>	This command can be used on 40G

## 11.4 Result

### 11.4.1 SONet:RX<Pt>:IFETch?

<b>Syntax</b>	SONet:RX<Pt>:IFETch? <parameter>
<b>Description</b>	This query fetches a SONET interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {,}*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Alarms</b></p> <p>LOS: Loss of signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>G-AIS: Generic alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOF: Loss of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>OOF: Out of frame. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AIISL: Multiplex section alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RDIL: Multiplex section remote defect indicator. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AISP: Administrative unit - alarm indication signal. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOPP: Administrative unit - loss of pointer. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>TIMP: High-order path trace identifier mismatch. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>PLMP: Payload label mismatch. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>UNEQP: High-order path unequipped. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RDIP: High-order path remote defect indicator. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>AISV: Tributary unit alarm indication signal<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOPV: Tributary unit loss of pointer<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LOMV: Tributary unit loss of multi frame<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>TIMV: Low-order path trace identifier mismatch<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>UNEQV: Low-order path unequipped<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RDIV: Low-order path remote defect indicator<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>PLMV: Low-order path payload label mismatch<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>LSS: Loss of signal synchronization<sup>1</sup>. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p><b>Errors</b></p> <p>A1A2: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B1: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B2: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>REIL: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>B3: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>REIP: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>V5LPB3: <sup>1</sup>Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>ERRPRBS: Pattern errors<sup>1</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>ERRPRBSBLK: Pattern block errors<sup>1</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>REIV: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>STSNDF: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>VTNDF: Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>SAPS: Switch APS. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>Rx frequency</b></p> <p>FREQ: Frequency deviation. Response: &lt;ppm&gt;</p> <p>FREQDIF: Frequency difference (RX1-RX2). Response: &lt;ppm&gt; (Only for RX1, RX2 is always NaN (section 1.6.1))</p> <p><b>Mux quality</b></p> <p>MFES: Forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MFSES: Forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MFUNAV: Forward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBES: Backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBSES: Backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>MBUNAV: Backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>STS3CSPE quality</b></p> <p>STS3CSPEFES: Forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>STS3CSPEFSES: Forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p>

continued on next page...

... continued from previous page

STS3CSPEFUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
 STS3CSPEBES: Backward ES. Response: <Count>,<Ratio%>  
 STS3CSPEBSES: Backward SES. Response: <Count>,<Ratio%>  
 STS3CSPEBUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**STS1SPE quality<sup>1</sup>**  
 STS1SPEFES: Forward ES. Response: <Count>,<Ratio%>  
 STS1SPEFSES: Forward SES. Response: <Count>,<Ratio%>  
 STS1SPEFUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
 STS1SPEBES: Backward ES. Response: <Count>,<Ratio%>  
 STS1SPEBSES: Backward SES. Response: <Count>,<Ratio%>  
 STS1SPEBUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**VT2 quality<sup>1</sup>**  
 VT2FES: Forward ES. Response: <Count>,<Ratio%>  
 VT2FSES: Forward SES. Response: <Count>,<Ratio%>  
 VT2FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
 VT2BES: Backward ES. Response: <Count>,<Ratio%>  
 VT2BSES: Backward SES. Response: <Count>,<Ratio%>  
 VT2BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**VT15 quality<sup>1</sup>**  
 VT15FES: Forward ES. Response: <Count>,<Ratio%>  
 VT15FSES: Forward SES. Response: <Count>,<Ratio%>  
 VT15FUNAV: Forward UNAV. Response: <Count>,<Ratio%>  
 VT15BES: Backward ES. Response: <Count>,<Ratio%>  
 VT15BSES: Backward SES. Response: <Count>,<Ratio%>  
 VT15BUNAV: Backward UNAV. Response: <Count>,<Ratio%>  
**Bulk quality**  
 ES: ES. Response: <Count>,<Ratio%>  
 SES: SES. Response: <Count>,<Ratio%>  
 UNAV: UNAV. Response: <Count>,<Ratio%>  
**STS pointer**  
 STSPOINT: AU pointer. Response: <Count>  
 STSNEG: Negative. Response: <Count>  
 STSPOS: Positive. Response: <Count>  
**VT pointer<sup>1</sup>**  
 VTPOINT: VT pointer. Response: <Count>  
 VTNEG: Negative. Response: <Count>  
 VTPOS: Positive. Response: <Count>  
**Justification<sup>1</sup>**  
 JNEG: Negative justification. Response: <Count>  
 JPOS: Positive justification. Response: <Count>  
**MUX performance<sup>1</sup>**  
 PMPES: Performance MUX PO limit ES. Response: <Count>,<Ratio%>  
 PMPSES: Performance MUX PO limit SES. Response: <Count>,<Ratio%>  
 PMPBBE: Performance MUX PO limit BBE. Response: <Count>,<Ratio%>  
 PMBS1ES: Performance MUX BIS limit S1ES. Response: <Count>  
 PMBS2ES: Performance MUX BIS limit S2ES. Response: <Count>  
 PMBS1SES: Performance MUX BIS limit S1SES. Response: <Count>  
 PMBS2SES: Performance MUX BIS limit S2SES. Response: <Count>  
 PMFSTAT: Performance MUX forward status.  
 Response: <STRING RESPONSE DATA>  
 PMFES: Performance MUX forward ES. Response: <Count>,<Ratio%>  
 PMFSES: Performance MUX forward SES. Response: <Count>,<Ratio%>  
 PMFUNAV: Performance MUX forward UNAV. Response: <Count>,<Ratio%>  
 PMFBBE: Performance MUX forward BBE. Response: <Count>,<Ratio%>  
 PMBSTAT: Performance MUX backward status.  
 Response: <STRING RESPONSE DATA>  
 PMBES: Performance MUX backward ES. Response: <Count>,<Ratio%>

continued on next page...

...continued from previous page

PMBSES: Performance MUX backward SES. Response: <Count>,<Ratio%>  
PMBUNAV: Performance MUX backward UNAV. Response: <Count>,<Ratio%>  
PMBBBE: Performance MUX backward BBE. Response: <Count>,<Ratio%>  
**STS3CSPE performance<sup>1</sup>**  
PSTS3CSPEPES: Performance VC4 PO limit ES. Response: <Count>,<Ratio%>  
PSTS3CSPEPSES: Performance VC4 PO limit SES. Response: <Count>,<Ratio%>  
PSTS3CSPEPBBE: Performance VC4 PO limit BBE. Response: <Count>,<Ratio%>  
PSTS3CSPEBS1ES: Performance VC4 BIS limit S1ES. Response: <Count>  
PSTS3CSPEBS2ES: Performance VC4 BIS limit S2ES. Response: <Count>  
PSTS3CSPEBS1SES: Performance VC4 BIS limit S1SES. Response: <Count>  
PSTS3CSPEBS2SES: Performance VC4 BIS limit S2SES. Response: <Count>  
PSTS3CSPEFSTAT: Performance VC4 forward status.  
Response: <STRING RESPONSE DATA>  
PSTS3CSPEFES: Performance VC4 forward ES. Response: <Count>,<Ratio%>  
PSTS3CSPEFSES: Performance VC4 forward SES. Response: <Count>,<Ratio%>  
PSTS3CSPEFUNAV: Performance VC4 forward UNAV. Response: <Count>,<Ratio%>  
PSTS3CSPEFBBE: Performance VC4 forward BBE. Response: <Count>,<Ratio%>  
PSTS3CSPEBSTAT: Performance VC4 backward status.  
Response: <STRING RESPONSE DATA>  
PSTS3CSPEBES: Performance VC4 backward ES. Response: <Count>,<Ratio%>  
PSTS3CSPEBSES: Performance VC4 backward SES. Response: <Count>,<Ratio%>  
PSTS3CSPEBUNAV: Performance VC4 backward UNAV. Response: <Count>,<Ratio%>  
PSTS3CSPEBBE: Performance VC4 backward BBE. Response: <Count>,<Ratio%>  
**VT2 performance<sup>1</sup>**  
PVT2PES: Performance VC12 PO limit ES. Response: <Count>,<Ratio%>  
PVT2PSES: Performance VC12 PO limit SES. Response: <Count>,<Ratio%>  
PVT2PBBE: Performance VC12 PO limit BBE. Response: <Count>,<Ratio%>  
PVT2BS1ES: Performance VC12 BIS limit S1ES. Response: <Count>  
PVT2BS2ES: Performance VC12 BIS limit S2ES. Response: <Count>  
PVT2BS1SES: Performance VC12 BIS limit S1SES. Response: <Count>  
PVT2BS2SES: Performance VC12 BIS limit S2SES. Response: <Count>  
PVT2FSTAT: Performance VC12 forward status.  
Response: <STRING RESPONSE DATA>  
PVT2FES: Performance VC12 forward ES. Response: <Count>,<Ratio%>  
PVT2FSES: Performance VC12 forward SES. Response: <Count>,<Ratio%>  
PVT2FUNAV: Performance VC12 forward UNAV. Response: <Count>,<Ratio%>  
PVT2FBBE: Performance VC12 forward BBE. Response: <Count>,<Ratio%>  
PVT2BSTAT: Performance VC12 backward status.  
Response: <STRING RESPONSE DATA>  
PVT2BES: Performance VC12 backward ES. Response: <Count>,<Ratio%>  
PVT2BSES: Performance VC12 backward SES. Response: <Count>,<Ratio%>  
PVT2BUNAV: Performance VC12 backward UNAV. Response: <Count>,<Ratio%>  
PVT2BBBE: Performance VC12 backward BBE. Response: <Count>,<Ratio%>  
**VT1.5 performance<sup>1</sup>**  
PVT15PES: Performance VC11 PO limit ES. Response: <Count>,<Ratio%>  
PVT15PSES: Performance VC11 PO limit SES. Response: <Count>,<Ratio%>  
PVT15PBBE: Performance VC11 PO limit BBE. Response: <Count>,<Ratio%>  
PVT15BS1ES: Performance VC11 BIS limit S1ES. Response: <Count>  
PVT15BS2ES: Performance VC11 BIS limit S2ES. Response: <Count>  
PVT15BS1SES: Performance VC11 BIS limit S1SES. Response: <Count>  
PVT15BS2SES: Performance VC11 BIS limit S2SES. Response: <Count>  
PVT15FSTAT: Performance VC11 forward status.  
Response: <STRING RESPONSE DATA>  
PVT15FES: Performance VC11 forward ES. Response: <Count>,<Ratio%>  
PVT15FSES: Performance VC11 forward SES. Response: <Count>,<Ratio%>  
PVT15FUNAV: Performance VC11 forward UNAV. Response: <Count>,<Ratio%>  
PVT15FBBE: Performance VC11 forward BBE. Response: <Count>,<Ratio%>

continued on next page...

...continued from previous page

	<p>PVT15BSTAT: Performance VC11 backward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PVT15BES: Performance VC11 backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVT15BSES: Performance VC11 backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVT15BUNAV: Performance VC11 backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PVT15BBBE: Performance VC11 backward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>STS1SPE performance<sup>1</sup></b></p> <p>PSTS1SPEPES: Performance VC3 PO limit ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEPSES: Performance VC3 PO limit SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEPBBE: Performance VC3 PO limit BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEBS1ES: Performance VC3 BIS limit S1ES. Response: &lt;Count&gt;</p> <p>PSTS1SPEBS2ES: Performance VC3 BIS limit S2ES. Response: &lt;Count&gt;</p> <p>PSTS1SPEBS1SES: Performance VC3 BIS limit S1SES. Response: &lt;Count&gt;</p> <p>PSTS1SPEBS2SES: Performance VC3 BIS limit S2SES. Response: &lt;Count&gt;</p> <p>PSTS1SPEFSTAT: Performance VC3 forward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PSTS1SPEFES: Performance VC3 forward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEFSES: Performance VC3 forward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEFUNAV: Performance VC3 forward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEFBBE: Performance VC3 forward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEBSTAT: Performance VC3 backward status. Response: &lt;STRING RESPONSE DATA&gt;</p> <p>PSTS1SPEBES: Performance VC3 backward ES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEBSES: Performance VC3 backward SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEBUNAV: Performance VC3 backward UNAV. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>PSTS1SPEBBBE: Performance VC3 backward BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p><b>SDH TCM<sup>1</sup></b></p> <p>TCUNEQ: Tandem connection unequipped. response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCLTC: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCTIM: Tandem connection trace identifier mismatch. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCAIS: Tandem connection alarm indication signal. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCRDI: Tandem connection remote defect indicator. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCODI: Tandem Connection Outgoing Defect Indicator. Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCIEC: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCBIP2: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCREI: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TCOEI: Response: &lt;Count&gt;,&lt;Ratio%&gt;</p> <p>TAPID: TCM APID. Response N1 or N2 TCM ID: &lt;id&gt;</p> <p><b>STL</b></p> <p>LOFSTL: STL LOF. Response: &lt;Seconds&gt; x 4 lanes</p> <p>LORSTL: STL LOR. Response: &lt;Seconds&gt; x 4 lanes</p> <p>OOFSTL: STL OOF. Response: &lt;Frames&gt; x 4 lanes</p> <p>ORSTL: STL OOR. Response: &lt;Frames&gt; x 4 lanes</p> <p>A1A2STL: A1A2-STL. Response: &lt;Count&gt; x 4 lanes</p> <p>OLA: OLA. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p> <p>RSKEW: Relative Skew. Response: &lt;Nanoseconds&gt; x 4 lanes</p> <p>MMAP: Marker Map. Response: &lt;NR1&gt; x 4 lanes</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	SON:RX1:IFET? (LOS,LOF,00F) → (3,0.00532),(4,0.00709),(5,0.00887)
<b>Notes</b>	<p>This command fetches the results from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2).</p> <p><sup>1</sup> Requires the current interface/application is installed and is currently active in the measurement.</p>

continued on next page...

... continued from previous page

	If requested result is not available, NaN (section 1.6.1) is returned. If there is one or more results, the last "," is always removed.
--	--

### 11.4.2 SONet:PMOVement:RX<Pt>:FETCh?

<b>Syntax</b>	SONet:PMOVement:RX<Pt>:FETCh? <pointer>,<min_time>,<max_time>
<b>Description</b>	This query fetches the pointer values.
<b>Parameters</b>	<pointer> = <CHARACTER PROGRAM DATA> STS: STS3 or STS1 pointer movements VT: VT pointer movements. VTG or VT2 or VT1.5 depending on SONET interface setup. <min_time> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=31536000</i> Beginning of the interval in seconds. <max_time> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=31536000</i> End of the interval in seconds.
<b>Response</b>	{<pointermovements>}* = <EXPRESSION RESPONSE DATA> The response is all pointer movements taking place in the requested time interval. Format: (pointerChange0,timestamp0),(pointerChange1,timestamp1),...
<b>Example</b>	SON:PMOV:RX1:FETC? AU,0,3600 → (1,10.000),(-1,15.002)
<b>Notes</b>	The interval is closed, i.e., it includes both endpoints. The displayed resolution of the timestamps is 1/1000 second = 0.001s.

## 11.5 Status

### 11.5.1 SONet:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	SONet:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the alarms and errors summary event register. The content of this event register is summarized in DB2 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Physical and high-order alarm summary DB2 (2) = Low-order path and tandem connection alarm summary DB3 (4) = Error section 1 summary DB4 (8) = Error section 2 summary DB5 (16) = STL alarm summary DB6 (32) = STL error summary DB7 - DB16 = NOT USED
<b>Example</b>	SON:STAT:RX1:AES? → 3
<b>Note</b>	SDH can embed E1, E3 or E4 so if a PDH signal is embedded it is a good idea to send the following query STAT:INT:PORT<Pt>[:EVENT]? to see if there is alarms or error at the embedded signal.

### 11.5.2 SONet:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	SONet:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as SONet:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Example</b>	SON:STAT:RX1:AES:COND? → 3
<b>Note</b>	



## 11.5.3 SONet:STATus:RX&lt;Pt&gt;:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	SONet:STATus:RX<Pt>:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns one of the alarms event register. These registers are summarized in DB1 and DB2 of the SONet:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Physical- and high-order path alarms(1), Low-order path and tandem connection alarms(2) or STL alarms(3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: DB1 (1) = LOS, Loss of signal DB2 (2) = LOF, Loss of frame DB3 (4) = OOF, Out of frame DB4 (8) = AISL, Multiplex section - alarm indication signal DB5 (16) = RDIL, Multiplex section - remote defect indicator DB6 (32) = AISP, Administrative unit - alarm indication signal DB7 (64) = LOPP, Administrative unit - loss of pointer DB8 (128) = TIMP, High-order path - trace identifier mismatch DB9 (256) = PLMP, High-order path - payload label mismatch DB10 (512) = UNEQP, High-order path - unequipped DB11 (1024) = RDIP, High-order path - remote defect indicator DB12 (2048) = AISV, Tributary unit - alarm indication signal DB13 (4096) = LOPV, Tributary unit - loss of pointer DB14 (8192) = LOMV, Tributary unit - loss Of multi frame DB15 (16384) = G-AIS, Generic alarm indication signal DB16 = NOT USED  <section> = 2: DB1 (1) = TIMV, Low-order path - trace identifier mismatch DB2 (2) = UNEQV, Low-order path - unequipped DB3 (4) = RDIV, Low-order path - remote defect indicator DB4 (8) = LSS, Loss of signal synchronization DB5 = NOT USED DB6 (32) = PLMV, Low-order path - payload label mismatch DB7 (64) = TC-UNEQ, Tandem connection - unequipped DB8 (128) = TC-LTC, Tandem connection - loss of tandem connection DB9 (256) = TC-TIM, Tandem connection - trace identifier mismatch DB10 (512) = TC-AIS, Tandem connection - alarm indication signal DB11 (1024) = TC-RDI, Tandem connection - remote defect indicator DB12 (2048) = TC-ODI, Tandem connection - outgoing defect indicator DB13 - DB16 = NOT USED  <section> = 3: DB1 (1) = STL LOF DB2 (2) = STL OOF DB3 (4) = STL LOR DB4 (8) = STL OOR DB5 (16) = OLA DB6 - DB16 = NOT USED
<b>Example</b>	SON:STAT:RX1:ALAR1? → 1
<b>Note</b>	

## 11.5.4 SONet:STATus:RX&lt;Pt&gt;:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	SONet:STATus:RX<Pt>:ALARm<section>:CONDition?
<b>Description</b>	This query returns one of the alarms condition registers. These registers are summarized in DB3 and DB4 of the SONet:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Physical- and high-order path alarms(1), Low-order path and tandem connection alarms(2) or STL alarms(3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as SONet:STATus:RX<Pt>:ALARm<section>[:EVENT]?
<b>Example</b>	SON:STAT:RX1:ALAR1:COND? → 1
<b>Note</b>	

## 11.5.5 SONet:STATus:RX&lt;Pt&gt;:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	SONet:STATus:RX<Pt>:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the SONet:STATus:RX<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = (1-3)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: DB1 (1) = A1A2 DB2 (2) = B1 DB3 (4) = B2 DB4 (8) = REIL DB5 (16) = B3 DB6 (32) = REIP DB7 (64) = V5/LP-B3 DB8 (128) = REIV DB9 (256) = PRBS DB10 (512) = VT-NDF DB11 (1024) = STS-NDF DB12 (2048) = APS DB13 - DB16 = NOT USED  <section> = 2: DB1 (1) = TU-NEG DB2 (2) = TU-POS DB3 (4) = AU-NEG DB4 (8) = AU-POS DB5 not used DB6 (32) = TC-IEC DB7 (64) = TC-BIP-2 DB8 (128) = TC-REI DB9 (256) = TC-OEI DB10 - DB16 = NOT USED  <section> = 3: DB1 (1) = A1A2-STL DB2 - DB16 = NOT USED
<b>Example</b>	SON:STAT:RX1:ERR1? → 3
<b>Note</b>	

## 11.5.6 SONet:STATus:RX&lt;Pt&gt;:ERRor&lt;section&gt;:CONDition?

<b>Syntax</b>	SONet:STATus:RX<Pt>:ERRor<section>:CONDition?
<b>Description</b>	This query returns errors condition register.
<b>Parameters</b>	<Pt> = Port number <section> = (1-2)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as SONet:STATus:RX<Pt>:ERRor<section>[:EVENT]?
<b>Example</b>	SON:STAT:RX1:ERR1:COND? → 3
<b>Note</b>	

## 11.5.7 SONet:STATus:RX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	SONet:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> "N/A": Module not present or not ready. - Electrical(STM1) - " <power> dBm": Min: "< -48 dBm", Max: "Exceeds Level" - Optical(Both module types) - " <power> dBm": Min: "< -27 dBm", Max: "Exceeds Level"
<b>Example</b>	SON:STAT:RX1:PSL? → "-3 dBm"
<b>Note</b>	

## 11.5.8 SONet:STATus:TX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	SONet:STATus:TX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> " <power> dBm": Min: "< -27 dBm", Max: "Exceeds Level" "N/A": Module not present or not ready.
<b>Example</b>	SON:STAT:TX1:PSL? → "-3 dBm"
<b>Note</b>	Only available for Optical.

## 11.5.9 SONet:STATus:RX&lt;Pt&gt;:PDEViation?

<b>Syntax</b>	SONet:STATus:RX<Pt>:PDEViation? [<unit>]
<b>Description</b>	This query returns the physical deviation.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million BPS = Bits per second <i>DEFault = PPM</i>
<b>Response</b>	<deviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:PDEV? PPM → 0
<b>Note</b>	

## 11.5.10 SONet:STATus:RX&lt;Pt&gt;:PBRate?

<b>Syntax</b>	SONet:STATus:RX<Pt>:PBRate?
<b>Description</b>	This query returns the physical bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:PBR? → 155520000
<b>Note</b>	

## 11.5.11 SONet:STATus:RX&lt;Pt&gt;:DIFFerence?

<b>Syntax</b>	SONet:STATus:RX<Pt>:DIFFerence?
<b>Description</b>	This query returns physical bit rate difference between port A and port B (RX1 - RX2). Units: ppm, bps and bits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA> <acc> = <NR1 NUMERIC RESPONSE DATA> Accumulated difference in bits.
<b>Example</b>	SON:STAT:RX1:DIFF? → -1,-4,-324
<b>Note</b>	A valid response is only available if both RX1 and RX2 are on. Using either RX1 or RX2 will give the same results.

## 11.5.12 SONet:STATus:RX&lt;Pt&gt;:RACCumulated

<b>Syntax</b>	SONet:STATus:RX<Pt>:RACCumulated
<b>Description</b>	This command resets the accumulated difference.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:STAT:RX1:RACC
<b>Note</b>	Using either RX1 or RX2 will give the same results.

## 11.5.13 SONet:STATus:RX&lt;Pt&gt;:PPBRate?

<b>Syntax</b>	SONet:STATus:RX<Pt>:PPBRate?
<b>Description</b>	This query returns physical pattern bit rate. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:PPBR? → 149760000
<b>Note</b>	

## 11.5.14 SONet:STATus:RX&lt;Pt&gt;:CAPTure:TOH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:TOH:TRACe?
<b>Description</b>	This query returns the TOH trace (J0) for the latest captured frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J0_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:TOH:TRAC? → "Message_Test_J0"
<b>Note</b>	If one of the alarms LOS or LOF is present, an empty string is returned.

## 11.5.15 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:TOH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:TOH? <TOH-byte>
<b>Description</b>	This query returns the TOH bytes from the selected frame. 256 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <TOH-byte> = <CHARACTER PROGRAM DATA> A1: Returns 3 bytes. A2: Returns 3 bytes. J0: Returns 3 bytes. B1: Returns 3 bytes. E1: Returns 3 bytes. F1: Returns 3 bytes. D1: Returns 3 bytes. D2: Returns 3 bytes. D3: Returns 3 bytes. H1: Returns 3 bytes. H2: Returns 3 bytes. H3: Returns 3 bytes. B2: Returns 3 bytes. K1: Returns 3 bytes. K2: Returns 3 bytes. D4: Returns 3 bytes. D5: Returns 3 bytes. D6: Returns 3 bytes. D7: Returns 3 bytes. D8: Returns 3 bytes. D9: Returns 3 bytes. D10: Returns 3 bytes. D11: Returns 3 bytes. D12: Returns 3 bytes. S1: Returns 3 bytes. Z2: Returns 3 bytes. E2: Returns 3 bytes. M0: Returns 1 byte. <sup>1</sup> M1: Returns 1 byte.
<b>Response</b>	<byte1>[,<byte2>[,<byte3>]] = <HEXADECIMAL NUMERIC RESPONSE DATA> Refer to <TOH-byte> parameter description above to see how many bytes this command returns.
<b>Examples</b>	SON:STAT:RX1:CAPT64:TOH? A1 → #HF6,#HF6,#HF6 SON:STAT:RX2:CAPT23:TOH? H1 → #H69,#H93,#H93 SON:STAT:RX1:CAPT1:TOH? M1 → #H00
<b>Note</b>	If one of the alarms LOS or LOF is present NaN (section 1.6.1) is returned. <sup>1</sup> Only valid for SONet:RX<Pt>:OCLevel = 192 or 768.

## 11.5.16 SONet:STATus:RX&lt;Pt&gt;:CAPTure:STS3:POH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:STS3:POH:TRACe?
<b>Description</b>	This query returns the STS3 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:STS3:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or LOPP is present, an empty string is returned.

## 11.5.17 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:STS3:POH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS3:POH? <POH-byte>
<b>Description</b>	This query returns the STS3 path overhead bytes from the selected frame. 256 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT1:STS3:POH? H4 → #HFF
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or LOPP is present NaN (section 1.6.1) is returned.

## 11.5.18 SONet:STATus:RX&lt;Pt&gt;:CAPTure:STS1:POH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:STS1:POH:TRACe?
<b>Description</b>	This command queries the STS1 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:STS1:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present, an empty string is returned.

## 11.5.19 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:STS1:POH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS1:POH? <POH-byte>
<b>Description</b>	This query returns the STS1 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT1:STS1:POH? C2 → #HA3
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present NaN (section 1.6.1) is returned. Use the SONet:RX<Pt>:STS1:POH:CMASk command to selected which bytes to be captured.

## 11.5.20 SONet:STATus:RX&lt;Pt&gt;:CAPTure:VT2:POH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:VT2:POH:TRACe?
<b>Description</b>	This query returns VT2 path overhead trace (J2) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J2_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:VT2:POH:TRAC? → "Message_Test_J2"
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present, an empty string is returned.

## 11.5.21 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:VT2:POH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:VT2:POH? <POH-byte>
<b>Description</b>	This query returns the VT2 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5-SL byte. J2: J2 byte. Z6: Z6 byte. Z7: Z7 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT1:VT2:POH? V5 → #H04
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present NaN (section 1.6.1) is returned.

## 11.5.22 SONet:STATus:RX&lt;Pt&gt;:CAPTure:VT15:POH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:VT15:POH:TRACe?
<b>Description</b>	This query returns VT1.5 path overhead trace (J2) for the latest captured frames. 64 new frames are captured every second.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J2_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:VT15:POH:TRAC? → "Message_Test_J2"
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present, an empty string is returned.

## 11.5.23 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:VT15:POH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:VT15:POH? <POH-byte>
<b>Description</b>	This query returns the VT1.5 path overhead bytes from the selected frame. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> V5: V5-SL byte. J2: J2 byte. Z6: Z6 byte. Z7: Z7 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT1:VT15:POH? V5 → #H04
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or UNEQV is present NaN (section 1.6.1) is returned.

## 11.5.24 SONet:STATus:RX&lt;Pt&gt;:CAPTure:STS1:STS1:POH:TRACe?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure:STS1:STS1:POH:TRACe?
<b>Description</b>	This query returns the STS1 path overhead trace (J1) for the latest captured frames. 64 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT:STS1:STS1:POH:TRAC? → "Message_Test_J1"
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or LOPP is present, an empty string is returned.

## 11.5.25 SONet:STATus:RX&lt;Pt&gt;:CAPTure&lt;Frame&gt;:STS1:STS1:POH?

<b>Syntax</b>	SONet:STATus:RX<Pt>:CAPTure<Frame>:STS1:STS1:POH? <POH-byte>
<b>Description</b>	This query returns the STS1 path overhead bytes from the selected frame. 256 new frames are captured every second.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. Z3: Z3 byte. Z4: Z4 byte. Z5: Z5 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	SON:STAT:RX1:CAPT1:STS1:STS1:POH? H4 → #HFF
<b>Note</b>	If one of the alarms LOS, LOF, UNEQP or LOPP is present NaN (section 1.6.1) is returned.



## 11.6 APS

### 11.6.1 SONet:APS:START

<b>Syntax</b>	SONet:APS:START
<b>Description</b>	This command starts the APS (Automatic Protection Switching).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SON:APS:STAR
<b>Note</b>	

### 11.6.2 SONet:APS:STOP

<b>Syntax</b>	SONet:APS:STOP
<b>Description</b>	This command stops the APS (Automatic Protection Switching) command.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SON:APS:STOP
<b>Note</b>	

### 11.6.3 SONet:APS:RX<Pt>:PINTerpret?

<b>Syntax</b>	SONet:APS:RX<Pt>:PINTerpret?
<b>Description</b>	This query returns the protocol interpretation.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interpretation> = <STRING RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:PINT? → "00:00:19   Number 0   Time: 0.000ms ----- k1: Signal degrade (protection) Destination Node (K1) 2 k2: Short Source Node (K2) 7"
<b>Note</b>	

### 11.6.4 SONet:APS:RX<Pt>:NUMBER?

<b>Syntax</b>	SONet:APS:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of times an APS Protocol event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:NUMB? → 17
<b>Note</b>	

### 11.6.5 SONet:APS:RX<Pt>:ATIME?

<b>Syntax</b>	SONet:APS:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**11.6.6 SONet:APS:RX<Pt>:MTIME?**

<b>Syntax</b>	SONet:APS:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	SON:APS:RX1:MTIM? → 29.17,0
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**11.6.7 SONet:APS:RX<Pt>:LTIME?**

<b>Syntax</b>	SONet:APS:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:LTIM? → 29.17
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

**11.6.8 SONet:APS:RX<Pt>:CTIME?**

<b>Syntax</b>	SONet:APS:RX<Pt>:CTIME?
<b>Description</b>	This query returns the current time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<current> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:CTIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 99999.999 ms.

## 11.6.9 SONet:APS:RX&lt;Pt&gt;:EVENT

<b>Syntax</b>	SONet:APS:RX<Pt>:EVENT <event>
<b>Description</b>	This command sets the Time Reference event.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;event&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>LOS = Loss of signal  LOF = Loss of frame  OOF = Out of frame  AISL = MS alarm indication signal  RDIL = MS remote defect indicator  APSS = APS switch-over  AISP = AU alarm indication signal  LOPP = AU loss of pointer  TIMP = HP trace identifier mismatch  PLMP = HP payload label mismatch  UNEQP = HP unequipped  LOMV = TU loss of multiframe  AISV = TU alarm indication signal  LOPV = TU loss of pointer  TIMV = LP trace identifier mismatch  PLMV = LP payload label mismatch  UNEQV = LP unequipped  A1A2 = Frame alignment word error  B1 = B1 checksum byte error  B2 = B2 checksum byte error  REIL = MS remote error indication  B3 = B3 checksum byte error  V5 = B3 checksum of the low-order path  PERRor = Pattern error  ANYERROR = Any errors  <i>DEFault = LOS</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:EVEN LOF
<b>Note</b>	

<b>Syntax</b>	SONet:APS:RX<Pt>:EVENT?
<b>Description</b>	This query returns the time reference event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:EVEN? → LOF
<b>Note</b>	

## 11.6.10 SONet:APS:RX&lt;Pt&gt;:MLIMit

<b>Syntax</b>	SONet:APS:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;max&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p><i>MINimum = 0.000, MAXimum = 10000.000, DEFault = 50.000</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	SONet:APS:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:MLIM? → 50.000
<b>Note</b>	

### 11.6.11 SONet:APS:RX<Pt>:PERiod

<b>Syntax</b>	SONet:APS:RX<Pt>:PERiod <period>
<b>Description</b>	This command sets the error free period.
<b>Parameters</b>	<Pt> = Port number <period> = <CHARACTER PROGRAM DATA> 1,10,20,30,40,50,60,70,80,90,100 Unit ms <i>DEFault = 1</i>
<b>Response</b>	None
<b>Example</b>	SON:APS:RX1:PER 1
<b>Note</b>	

<b>Syntax</b>	SONet:APS:RX<Pt>:PERiod?
<b>Description</b>	This query returns the error free period.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<period> = <CHARACTER PROGRAM DATA>
<b>Example</b>	SON:APS:RX1:PER? → 1
<b>Note</b>	

### 11.6.12 SONet:APS:RX<Pt>:CONFig

<b>Syntax</b>	SONet:APS:RX<Pt>:CONFig <protection>,<path>
<b>Description</b>	This command sets the protection type and the path or architecture.
<b>Parameters</b>	<Pt> = Port number <protection> = <CHARACTER PROGRAM DATA> RING = Ring protection LINEar = Linear <i>DEFault = RING</i> <path> = <CHARACTER PROGRAM DATA> Ring Path: SHRT = Short path LONG = Long path <i>DEFault = SHRT</i>  Linear Architecture: 1P1 = 1+1 Architecture 1N = 1:n Architecture
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:CONF RING,SHRT
<b>Notes</b>	

<b>Syntax</b>	SONet:APS:RX<Pt>:CONFig?
<b>Description</b>	This query returns the protection type and the path or architecture.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<protection> = <CHARACTER RESPONSE DATA> <path> = <CHARACTER PROGRAM DATA>
<b>Example</b>	SON:APS:RX1:CONF? → RING,SHRT
<b>Note</b>	

## 11.6.13 SONet:APS:RX&lt;Pt&gt;:RTYPE

<b>Syntax</b>	SONet:APS:RX<Pt>:RTYPE <type>
<b>Description</b>	This command sets the request type for the transmitter.
<b>Parameter</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>Ring Request Types: for SONet:APS:RX&lt;Pt&gt;:CONFig? → RING,....</p> <p>RLOP = Lockout of protection (span)</p> <p>RFSS = Forced switch (span)</p> <p>RFSR = Forced switch (ring)</p> <p>RSFS = Signal fail (span)</p> <p>RSFR = Signal fail (ring)</p> <p>RSDP = Signal degrade (protection)</p> <p>RSDS = Signal degrade (span)</p> <p>RSDR = Signal degrade (ring)</p> <p>RMSS = Manual switch (span)</p> <p>RMSR = Manual switch (ring)</p> <p>RWTR = Wait to restore</p> <p>REXS = Exercise (span)</p> <p>REXR = Exercise (ring)</p> <p>RRRS = Reverse request (span)</p> <p>RRRR = Reverse request (ring)</p> <p>RNRQ = No request</p> <p><i>DEFault = RLOP</i></p> <p>Linear Request Types: for SDH:APS:RX&lt;Pt&gt;:CONFig? → LIN,....</p> <p>LLOP = Lockout of protection</p> <p>LFSW = Forced switch</p> <p>LSFH = Signal fail (high priority)</p> <p>LSFL = Signal fail (low priority)</p> <p>LSDH = Signal degrade (high priority)</p> <p>LSDL = Signal degrade (low priority)</p> <p>LMSW = Manual switch (ring)</p> <p>LWTR = Wait to restore</p> <p>LEXC = Exercise</p> <p>LRRQ = Reverse request</p> <p>LDNR = Do not revert</p> <p>LNRQ = No request</p> <p><i>DEFault = LLOP</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:RTYP RLOP
<b>Notes</b>	Use the SONet:APS:RX<Pt>:APPLy command to apply the request to the transmitter.

<b>Syntax</b>	SONet:APS:RX<Pt>:RTYPE?
<b>Description</b>	This query returns the request type for the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:RTYP? → RLOP
<b>Note</b>	

## 11.6.14 SONet:APS:RX&lt;Pt&gt;:K1

<b>Syntax</b>	SONet:APS:RX<Pt>:K1 <value>
<b>Description</b>	This command sets the destination node/source channel (K1).
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:K1 3
<b>Notes</b>	Cannot be changed if the SONet:APS:CONFig command is set to LIN, 1P1. Changes to SONet:APS:CONFig will reset this value to 0.

<b>Syntax</b>	SONet:APS:RX<Pt>:K1?
<b>Description</b>	This query returns the destination node/source channel (K1).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:K1? → 3
<b>Note</b>	

## 11.6.15 SONet:APS:RX&lt;Pt&gt;:K2

<b>Syntax</b>	SONet:APS:RX<Pt>:K2 <value>
<b>Description</b>	This command sets the source node/bridged channel (K2).
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:K2 3
<b>Notes</b>	Cannot be changed if the SONet:APS:CONFig command is set to LIN, 1P1. Changes to SONet:APS:CONFig will reset this value to 0.

<b>Syntax</b>	SONet:APS:RX<Pt>:K2?
<b>Description</b>	This query returns the source node/bridged channel (K2).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:APS:RX1:K2? → 3
<b>Note</b>	

## 11.6.16 SONet:APS:RX&lt;Pt&gt;:APPLy

<b>Syntax</b>	SONet:APS:RX<Pt>:APPLy
<b>Description</b>	This command applies the K1/K2 request setup to the transmitter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	SON:APS:RX1:APPL
<b>Notes</b>	

## 11.7 Tributary Scan

## 11.7.1 SONet:TSCan:STARt

<b>Syntax</b>	SONet:TSCan:STARt
<b>Description</b>	This command starts the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SON:TSC:STAR
<b>Note</b>	It is possible to run only one test or measurement at a time. The SONET interface must be active for at least one of the receivers.

## 11.7.2 SONet:TSCan:STOP

<b>Syntax</b>	SONet:TSCan:STOP
<b>Description</b>	This command stops the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	SON:TSC:STOP
<b>Note</b>	

## 11.7.3 SONet:TSCan:RX&lt;Pt&gt;:NHOCContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:NHOCContainer?
<b>Description</b>	This query returns the number of High-order containers (STS3/STS1)
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TSC:RX1:NHOC? → 4
<b>Note</b>	If '0' is returned, no High-order containers were found. To get more information, use the SONet:TSCan:RX<Pt>:MUX? query.

## 11.7.4 SONet:TSCan:RX&lt;Pt&gt;:GHOCContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:GHOCContainer?
<b>Description</b>	This query returns the state of High-order containers (STS3/STS1)
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<p>{&lt;value&gt;,}+ = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p> <p>The values are presented in ascending order, meaning that STS3 #1 is the first on the list.</p> <p>0 = No alarms or errors.</p> <p>1 = Alarms or errors present.</p>
<b>Example</b>	SON:TSC:RX1:GHOC? → (0,0,1,0)
<b>Note</b>	If there is one or more results, the last ",," is always removed.

## 11.7.5 SONet:TSCan:RX&lt;Pt&gt;:SHOCContainer

<b>Syntax</b>	SONet:TSCan:RX<Pt>:SHOCContainer <STS>
<b>Description</b>	This command sets the High-order container (STS3/STS1) for scanning.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;STS&gt; = High-order container number</p> <p><i>MINimum=1, MAXimum=768</i></p>
<b>Response</b>	None.
<b>Example</b>	SON:TSC:RX1:SHOC 2
<b>Note</b>	

## 11.7.6 SONet:TSCan:RX&lt;Pt&gt;:SHOCContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:SHOCContainer?
<b>Description</b>	This query returns the High-order container (STS3/STS1) set for scanning.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STS> = High-order container number
<b>Example</b>	SON:TSC:RX1:SHOC? → 2
<b>Note</b>	

## 11.7.7 SONet:TSCan:RX&lt;Pt&gt;:DHOContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:DHOContainer? <STS3/STS1>
<b>Description</b>	This query returns the detailed alarm and error information from a High-order container (STS3/STS1).
<b>Parameters</b>	<Pt> = Port number <VC4> = High-order container number <i>MINimum=1, MAXimum=768</i>
<b>Response</b>	<selected>, = <STRING RESPONSE DATA>. {RXn}␣{High-order}, separated by one space character. RXn = RX1 or RX2 High-order = STS3#0 ... STS3#64 or STS1#0 ... STS1#192 ({<alarmerrors>,*}) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SON:TSC:RX1:DHOC? 1 → "RX1 STS3#1",("B1","A1A2")
<b>Note</b>	If there is one or more responses, the last "," is always removed.

## 11.7.8 SONet:TSCan:RX&lt;Pt&gt;:NLOContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:NLOContainer?
<b>Description</b>	This query returns the number of Low-order containers (STS1/VT2/VT1.5).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:TSC:RX1:NLOC? → 3
<b>Note</b>	

## 11.7.9 SONet:TSCan:RX&lt;Pt&gt;:GLOContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:GLOContainer?
<b>Description</b>	This query returns the state of Low-order containers (STS1/VT2/VT1.5).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	({<value>,*}) = <NR1 NUMERIC RESPONSE DATA> The values are presented in ascending order, meaning that STS3 #1 is the first in the list. 0 = No alarms or errors. 1 = Alarms or errors present.
<b>Example</b>	SON:TSC:RX1:GLOC? → (0,1,1)
<b>Note</b>	If there is one or more responses, the last "," is always removed.

## 11.7.10 SONet:TSCan:RX&lt;Pt&gt;:DLOContainer?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:DLOContainer? <STS1/VT2/VT15>
<b>Description</b>	This query returns the detailed alarm and error information from a Low-order container (STS1/VT2/VT1.5).
<b>Parameters</b>	<Pt> = Port number <STS1/VT2/VT15> = Low-order container number <i>MINimum=1, MAXimum=84</i>
<b>Response</b>	<selected>, = <STRING RESPONSE DATA>. {RXn}␣{High-order}:{Low-order}, First separated by one space character and next with a colon char. RXn = RX1 or RX2 High-order = STS3#0 ... STS3#64 or STS1#0 ... STS1#192 Low-order = STS1#1 ... STS1#3 or VT2#1 ... VT2#63 or VT1.5#1 ... VT1.5#84 ({<alarmerrors>,*}) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SON:TSC:RX1:DLOC? 1 → "RX1 STS3#1:STS1#1",("B1","A1A2")
<b>Notes</b>	To select the High-order container, use the SONet:TSCan:RX<rx>:SHOContainer command. If there is one or more responses, the last "," is always removed.



## 11.7.11 SONet:TSCan:RX&lt;Pt&gt;:DMUX?

<b>Syntax</b>	SONet:TSCan:RX<Pt>:DMUX?
<b>Description</b>	This query returns the detailed alarm and error information from the MUX.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<selected> = <STRING RESPONSE DATA>. {Rx} MUX ({<alarmerrors>, }*) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	SON:TSC:RX1:DMUX? → "Rx1 MUX", ("LOS", "LOF", "OOF")
<b>Notes</b>	This query is only available when no High-order containers are present. To determine if MUX is available, use the SONet:TSCan:RX<Pt>:NHOCContainer? query. If there is one or more responses, the last ",," is always removed.

## 11.8 RTD

This section document commands for the Round Trip Delay application. Commands for general RTD settings are described in section 16.1 on page 837.

### 11.8.1 SONet:RTD:RX<Pt>:MLIMit

<b>Syntax</b>	SONet:RTD:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: us.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0, MAXimum = 1000000.0, DEFault = MAXimum</i>
<b>Response</b>	None.
<b>Example</b>	SON:RTD:RX1:MLIM 0.0
<b>Note</b>	

<b>Syntax</b>	SONet:RTD:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RTD:RX1:MLIM? → 0.0
<b>Note</b>	

### 11.8.2 SONet:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	SONet:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 11.8.3 SONet:RTD:RX<Pt>:ATIMe?

<b>Syntax</b>	SONet:RTD:RX<Pt>:ATIMe?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 11.8.4 SONet:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	SONet:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	SON:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

## 11.8.5 SONet:RTD:RX&lt;Pt&gt;:LTIMe?

<b>Syntax</b>	SONet:RTD:RX<Pt>:LTIMe?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

## 11.8.6 SONet:RTD:RX&lt;Pt&gt;:CTIMe?

<b>Syntax</b>	SONet:RTD:RX<Pt>:CTIMe?
<b>Description</b>	This query returns the current time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	SON:RTD:RX1:CTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds 99999999.9 us.



---

# Chapter 12

## Ethernet

By default, the Ethernet settings cannot be changed during a measurement. Use `ETH:PORT<Pt>:SETT:ACIS` to change this behavior (see section 12.7.11).

### 12.1 Port Setup

#### 12.1.1 ETHernet:PORT<Pt>:ITYPE

<b>Syntax</b>	ETHernet:PORT<Pt>:ITYPE <interface>
<b>Description</b>	This command sets the interface type.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> ELECtrical: Electrical interface (10/100/1000 Mbps) SFP: SFP optical interface (100/1000 Mbps) SFPP: SFP+ optical interface (10 Gbps) QSFP: QSFP optical interface (40 Gbps) CXP: CXP optical interface (100 Gbps) CFP: CFP optical interface (40/100 Gbps) CFP2: CFP2 optical interface (100 Gbps) QSFP28ADpt: CFP2-QSFP28 Adaptor interface (100 Gbps) OPTical: Obsolete. For CMA 3000 backward compatibility only. Same as SFP. 10Gbps: Obsolete. For CMA 3000 backward compatibility only. Same as SFPP. <i>DEFault = ELECtrical</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:ITYP ELEC
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:ITYPE?
<b>Description</b>	This query returns the interface type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:ITYP? → ELEC
<b>Note</b>	

## 12.1.2 ETHernet:PORT&lt;Pt&gt;:MODE

<b>Syntax</b>	ETHernet:PORT<Pt>:MODE <mode>
<b>Description</b>	The command sets the port mode
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Port off ANEGotiate: Port ON in auto negotiation mode FORCed: Port ON in forced mode <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:MODE ANEG
<b>Note</b>	ANEGotiate does not apply to the 10Gbps interface.

<b>Syntax</b>	ETHernet:PORT<Pt>:MODE?
<b>Description</b>	This query returns the port mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:MODE? → ANEG
<b>Note</b>	

## 12.1.3 ETHernet:PORT&lt;Pt&gt;:ANEGotiate

<b>Syntax</b>	ETHernet:PORT<Pt>:ANEGotiate <speedduplex>
<b>Description</b>	This command sets the speed(s) and duplex to auto negotiate for electrical interface.
<b>Parameters</b>	<Pt> = Port number ({<speedduplex>} + {,}*) = <EXPRESSION PROGRAM DATA> 10MH: 10Mbps half duplex 10MF: 10Mbps full duplex 100MH: 100Mbps half duplex 100MF: 100Mbps full duplex 1GF: 1Gbps full duplex
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:ANEG (10MH,100MF)
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:ANEGotiate?
<b>Description</b>	This query returns the auto negotiation speed(s) and duplex for electrical interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<speedduplex>),}* = <EXPRESSION RESPONSE DATA> <speedduplex> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:ANEG? → (10MH,100MF)
<b>Note</b>	

## 12.1.4 ETHernet:PORT&lt;Pt&gt;:FMODE

<b>Syntax</b>	ETHernet:PORT<Pt>:FMODE <mode>
<b>Description</b>	This command set the speed/duplex in forced mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> 10MH: 10Mbps half duplex 10MF: 10Mbps full duplex 100MH: 100Mbps half duplex 100MF: 100Mbps full duplex 1GF: 1Gbps full duplex 10GF: 10Gbps full duplex 40GF: 40Gbps full duplex 100GF: 100bps full duplex <i>DEFault = 10MH</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:FMODE 100MF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FMODE?
<b>Description</b>	This query returns forced mode speed/duplex.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FMODE? → 100MF
<b>Note</b>	

## 12.1.5 ETHernet:PORT&lt;Pt&gt;:CMODE

<b>Syntax</b>	ETHernet:PORT<Pt>:CMODE <mode>
<b>Description</b>	This command sets the 1000Mbps clock mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> MASTer: Master PMASter: Prefer master SLAVe: Slave PSLave: Prefer slave <i>DEFault = PMASter</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CMODE MAST
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:CMODE?
<b>Description</b>	This query returns the 1000Mbps clock mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CMODE? → SLAV
<b>Note</b>	

## 12.1.6 ETHernet:PORT&lt;Pt&gt;:TIMing:SOURce

<b>Syntax</b>	ETHernet:PORT<Pt>:TIMing:SOURce <source>
<b>Description</b>	This command set the transmitter timing source.
<b>Parameter</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Internal clock. EXTernal: External input clock (2MHz/E1(SETS)/T1(BITS)). GPS: GPS signal. RX: Received clock. PTP: PTP(IEEE 1588v2) recovered clock. <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TIM:SOUR INT
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TIMing:SOURce?
<b>Description</b>	This query returns the transmitter timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TIM:SOUR? → INT
<b>Note</b>	

## 12.1.7 ETHernet:PORT&lt;Pt&gt;:PFRames

<b>Syntax</b>	ETHernet:PORT<Pt>:PFRames <respond>
<b>Description</b>	This command enable or disable respond to PAUSE frames.
<b>Parameters</b>	<Pt> = Port number <respond> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PFR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PFRames?
<b>Description</b>	This query returns the state of respond to PAUSE frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<respond> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PFR? → 1
<b>Note</b>	

## 12.1.8 ETHernet:PORT&lt;Pt&gt;:FEC

<b>Syntax</b>	ETHernet:PORT<Pt>:FEC <mode>
<b>Description</b>	The command sets the FEC mode
<b>Parameters</b>	<Pt> = Port number <mode> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:FEC ON
<b>Note</b>	This command can be used on MU110013A. This command can be used when interface type is CFP2 or QSFP28 Adpt..



---

<b>Syntax</b>	ETHernet:PORT<Pt>:FEC?
<b>Description</b>	This query returns the FEC mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<respond> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FEC? → 1
<b>Note</b>	This command can be used on MU110013A. This command can be used when interface type is CFP2 or QSFP28 Adpt..

## 12.2 WAN

### 12.2.1 ETHernet:PORT<Pt>:WAN[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN[:ENABle] <enable>
<b>Description</b>	This command enables or disables the WAN layer of the 10Gbps interface.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:WAN ON
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN[:ENABle]?
<b>Description</b>	This query returns whether or not WAN is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN? → 1
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.2 ETHernet:PORT<Pt>:WAN:TERMinology

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:TERMinology <terminology>
<b>Description</b>	This command sets the WAN terminology.
<b>Parameters</b>	<Pt> = Port number <terminology> = <CHARACTER PROGRAM DATA> SONet: SONET terminology SDH: SDH terminology <i>DEFault = SONet</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:TERM SON
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:TERMinology?
<b>Description</b>	This query returns the WAN terminology.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<terminology> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN:TERM? → SON
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.3 ETHernet:PORT<Pt>:WAN:SOH:DEFault

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH:DEFault
<b>Description</b>	This command sets all WAN section overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:SOH:DEF
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.4 ETHernet:PORT<Pt>:WAN:SOH:TRACe

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the WAN section overhead trace (J0) to the specified string.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> This quoted string is used as section trace string. <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:SOH:TRAC "Anritsu Network Master",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated. This command can be used on V2.00 or later


<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH:TRACe?
<b>Description</b>	This query returns the WAN section overhead trace string and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA> <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN:SOH:TRAC? → "Anritsu Network Master",#H20
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.5 ETHernet:PORT<Pt>:WAN:SOH:TRACe:CRC

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH:TRACe:CRC <mode>
<b>Description</b>	This command sets the SOH trace (J0) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: CRC OFF ON : CRC ON <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:SOH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the SOH trace (J0) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN:SOH:TRAC:CRC? → ON
<b>Note</b>	

### 12.2.6 ETHernet:PORT<Pt>:WAN:SOH

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH <SOH-byte>,<value1>[,<value2>[,<value3>]]
<b>Description</b>	This command sets the value of the specified bytes in the WAN section overhead.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;SOH-byte&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>A1: 3 bytes.  A2: 3 bytes.  J0: 3 bytes. Note: The defined trace string will be disabled.  B1: 2 bytes. &lt;value3&gt; is ignored.  E1: 3 bytes.  F1: 3 bytes.  D1: 3 bytes.  D2: 3 bytes.  D3: 3 bytes.  K1: 3 bytes.  K2: 3 bytes.  D4: 3 bytes.  D5: 3 bytes.  D6: 3 bytes.  D7: 3 bytes.  D8: 3 bytes.  D9: 3 bytes.  D10: 3 bytes.  D11: 3 bytes.  D12: 3 bytes.  S1: 3 bytes.  Z2: 3 bytes.  E2: 3 bytes.  M0: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored.  M1: 1 byte. &lt;value2&gt; and &lt;value3&gt; are ignored.</p>  <p>&lt;value1&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p>&lt;value2&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p>&lt;value3&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p>MINimum = #H00, MAXimum = #HFF</p>
<b>Response</b>	None.
<b>Examples</b>	<pre>ETH:PORT1:WAN:SOH A1,#H00,#H00,#H00 ETH:PORT1:WAN:SOH D7,#HFD,#H20,#H1A ETH:PORT1:WAN:SOH B1,#H04,#H05 ETH:PORT1:WAN:SOH M1,#H00</pre>
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:SOH? <SOH-byte>
<b>Description</b>	This query returns the value of the specified bytes in the WAN section overhead.
<b>Parameters</b>	<Pt> = Port number <SOH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value1> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value2> = <HEXADECIMAL NUMERIC RESPONSE DATA> [,<value3> = <HEXADECIMAL NUMERIC RESPONSE DATA>]]
<b>Examples</b>	ETH:PORT1:WAN:SOH? A1 → #H00,#H00,#H00 ETH:PORT1:WAN:SOH? D7 → #HFD,#H20,#H1A ETH:PORT1:WAN:SOH? B1 → #H04,#H05 ETH:PORT1:WAN:SOH? M1 → #H00
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.7 ETHernet:PORT<Pt>:WAN:POH:DEFault

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH:DEFault
<b>Description</b>	This command sets all WAN path overhead bytes to their default value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:POH:DEF
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.8 ETHernet:PORT<Pt>:WAN:POH:TRACe

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH:TRACe <string>[,<idlechar>]
<b>Description</b>	This command sets the WAN path trace (J1) to the specified string and it's idle char.
<b>Parameters</b>	<Pt> = Port number <string> = <STRING PROGRAM DATA> This quoted string is used as section trace string. <idlechar> = <NUMERIC PROGRAM DATA> <i>DEFault = #H20</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:POH:TRAC "Anritsu Network Master",#H20
<b>Note</b>	If the entered trace string is more than 15 characters long, the string will be truncated. This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH:TRACe?
<b>Description</b>	This query returns the WAN path trace string and idle char.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<string> = <STRING RESPONSE DATA> <idlechar> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN:POH:TRAC? → "Anritsu Network Master",#H20
<b>Note</b>	This command can be used on V2.00 or later

### 12.2.9 ETHernet:PORT<Pt>:WAN:POH:TRACe:CRC

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH:TRACe:CRC <mode>
<b>Description</b>	This command sets the POH trace (J0) CRC mode (OFF/ON).
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: CRC OFF ON : CRC ON <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:POH:TRAC:CRC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH:TRACe:CRC?
<b>Description</b>	This query returns the mode of the POH trace (J0) CRC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:WAN:POH:TRAC:CRC? → ON
<b>Note</b>	

### 12.2.10 ETHernet:PORT<Pt>:WAN:POH

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH <POH-byte>,<value>
<b>Description</b>	This command sets the value of the specified byte in the WAN path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA> C2: C2 byte. G1: G1 byte. F2: Z1 / F2 byte. H4: Z2 / H4 byte. F3: Z3 / F3 byte. K3: Z4 / K3 byte. N1: Z5 / N1 byte. <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:WAN:POH C2,0
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:WAN:POH? <POH-byte>
<b>Description</b>	This query returns the value of the specified byte in the WAN path overhead.
<b>Parameters</b>	<Pt> = Port number <POH-byte> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:WAN:POH? C2 → #H0 ETH:PORT1:WAN:POH? H4 → #HFF
<b>Note</b>	This command can be used on V2.00 or later

## 12.3 Reflector

### 12.3.1 ETHernet:PORT<Pt>:REFLector:SWAP[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SWAP[:ENABLE] <enable>
<b>Description</b>	This command sets the Swap Parameter Enable.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:SWAP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SWAP[:ENABLE]?
<b>Description</b>	This query returns the Swap Parameter Enable.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:SWAP? → 1
<b>Note</b>	

### 12.3.2 ETHernet:PORT<Pt>:REFLector:SSMac

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SSMac <enable>
<b>Description</b>	This command enables/disables swapping of specific MAC addresses when the port is in reflector mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:SSM ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SSMac?
<b>Description</b>	This query returns whether or not swapping of specific MAC addresses is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:SSM? → 1
<b>Note</b>	

### 12.3.3 ETHernet:PORT<Pt>:REFLector:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SMAC <address>
<b>Description</b>	This command sets the specific MAC address to swap when MAC address swapping is enabled.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:SMAC "00-50-C2-35-D2-EF"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:SMAC?
<b>Description</b>	This query returns the specific MAC address to swap.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:SMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

## 12.3.4 ETHernet:PORT&lt;Pt&gt;:REFLector:IPSWap

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:IPSWap <enable>
<b>Description</b>	This command enables/disables the IP address swap mode when the port is in reflector mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:IPSW ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:IPSWap?
<b>Description</b>	This query returns the IP address swap mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:IPSW? → 1
<b>Note</b>	

## 12.3.5 ETHernet:PORT&lt;Pt&gt;:REFLector:PSWap

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:PSWap <enable>
<b>Description</b>	This command enables/disables swapping of port numbers in UDP and TCP frames when the port is in reflector mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:PSW ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:PSWap?
<b>Description</b>	This query returns whether or not port swapping is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:PSW? → 1
<b>Note</b>	

## 12.3.6 ETHernet:PORT&lt;Pt&gt;:REFLector:ATCP

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:ATCP <enable>
<b>Description</b>	This command enables/disables ACK on TCP frames when the port is in reflector mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:REFL:ATCP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:REFLector:ATCP?
<b>Description</b>	This query returns whether or not ACK on TCP frames is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:REFL:ATCP? → 1
<b>Note</b>	



## 12.4 PCS

### 12.4.1 ETHernet:PORT<Pt>:PCS:MMAPIng:LANE

<b>Syntax</b>	ETHernet:PORT<Pt>:PCS:MMAPIng:LANE <value>
<b>Description</b>	This command sets the PCS lane marker assignment.
<b>Parameters</b>	<Pt> = Port number {(<value>),}* = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of the value of the lane marker. 40G: 0 to 3 100G: 0 to 19
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PCS:MMAPIng:LANE (1,3,0,2) ETH:PORT1:PCS:MMAPIng:LANE (0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19)
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:PCS:MMAPIng:LANE?
<b>Description</b>	This query returns the PCS lane marker assignment.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<value>),}* = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	ETH:PORT1:PCS:MMAPIng:LANE? → (0,1,2,3) → (0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19)
<b>Note</b>	This command can be used on 40/100G

## 12.5 Traffic

BERT, RFC-6349, Ping, and Traceroute applications use stream number one only. Setting other streams has no effect in these applications.

### 12.5.1 ETHernet:TRAFfic:GENerator:STARt

<b>Syntax</b>	ETHernet:TRAFfic:GENerator:STARt
<b>Description</b>	This command starts the traffic generator.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:TRAF:GEN:STAR
<b>Note</b>	This command applies to all ports.

### 12.5.2 ETHernet:PORT<Pt>:TRAFfic:GENerator:STARt

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:GENerator:STARt
<b>Description</b>	This command starts the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:GEN:STAR
<b>Note</b>	This command requires that the Port is enabled (ETHernet:PORT<Pt>:MODE).

### 12.5.3 ETHernet:TRAFfic:GENerator:STOP

<b>Syntax</b>	ETHernet:TRAFfic:GENerator:STOP
<b>Description</b>	This command stops the traffic generator.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:TRAF:GEN:STOP
<b>Note</b>	This command applies to all ports.

### 12.5.4 ETHernet:PORT<Pt>:TRAFfic:GENerator:STOP

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:GENerator:STOP
<b>Description</b>	This command stops the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:GEN:STOP
<b>Note</b>	

### 12.5.5 ETHernet:PORT<Pt>:TRAFfic:GENerator:STATus?

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:GENerator:STATus?
<b>Description</b>	This query returns the current status of the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<stat> = <NR1 NUMERIC RESPONSE DATA> 0: Traffic generator inactive 1: Traffic generator active
<b>Example</b>	ETH:PORT1:TRAF:GEN:STAT? → 1
<b>Note</b>	

### 12.5.6 ETHernet:PORT<Pt>:TRAFfic:DMODE

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:DMODE <mode>
<b>Description</b>	This command sets the duration mode for the traffic generator.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> CONTInuous: Continuous FRAMes: Frames SECOnds: Seconds <i>DEFault = CONTInuous</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:DMOD CONT
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:DMODE?
<b>Description</b>	This query returns the duration mode for the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:DMOD? → SEC
<b>Note</b>	

### 12.5.7 ETHernet:PORT<Pt>:TRAFfic:DURation

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:DURation <duration>
<b>Description</b>	This command sets the duration for the traffic generator.
<b>Parameters</b>	<Pt> = Port number <duration> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 200000000, DEFault = 5</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:DUR 1
<b>Note</b>	Unit for this command can be either [frames] or [seconds] depending on DMODE.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:DURation?
<b>Description</b>	This query returns the duration for the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:DUR? → 1
<b>Note</b>	

### 12.5.8 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:TXMode

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:TXMode <mode>
<b>Description</b>	This command sets the transmitting mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> NORMAl: BURSt: Burst transmitting <i>DEFault = NORMAl</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:TXM BURS
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:TXMode?
<b>Description</b>	This query returns the transmitting mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:TXM? → BURS
<b>Note</b>	

### 12.5.9 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile <profile>
<b>Description</b>	This command sets the stream Line Load Profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <profile> = <CHARACTER PROGRAM DATA> CONStant: Constant line load profile RAMP: Ramp line load profile <i>DEFault = CONStant</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF CONS
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile?
<b>Description</b>	This query returns the stream Line Load Profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF? → RAMP
<b>Note</b>	

### 12.5.10 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp[:MODE]

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp[:MODE] <enable>
<b>Description</b>	This command enables/disables milliseconds ramp.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF:MRAM ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp[:MODE]?
<b>Description</b>	This query returns if milliseconds ramp is enabled/disabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF:MRAM? → 0
<b>Note</b>	

### 12.5.11 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad[:CONStant]

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad[:CONStant] <load>
<b>Description</b>	This command sets the stream Line Load in constant mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000<sup>1</sup>, DEFault=100.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS, IFG. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL 10.0000
<b>Notes</b>	The minimum possible line load is 0.0008PCT. The maximum combined line load for all 16 streams is 100PCT. <sup>1</sup> The maximum allowed Line Load varies depending on the stream frame size. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad[:CONStant]? [<suffix>]
<b>Description</b>	This query returns the stream Line Load is constant mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second IFG: Inter Frame Gap <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL? → 10.0000
<b>Note</b>	

### 12.5.12 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP[:MODE]

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP[:MODE] <mode>
<b>Description</b>	This command sets the ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> KEEPend: Maintain line load level at ramp end INVert: Invert ramp REPeat: Repeat ramp <i>DEFault = KEEPend</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP KEEP
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP[:MODE]?
<b>Description</b>	This query returns the ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP? → INV
<b>Note</b>	

### 12.5.13 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STARt

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STARt <load>
<b>Description</b>	This command sets the stream initial line load in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000<sup>1</sup>, DEFault=0.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS, IFG. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:STAR 10.0000
<b>Notes</b>	The minimum possible line load is 0.0008PCT. The maximum combined line load for all 16 streams are 100PCT. <sup>1</sup> The maximum allowed Line Load varies depending on the stream frame size. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STARt? [<suffix>]
<b>Description</b>	This query returns the stream initial line load in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second IFG: Inter Frame Gap <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:STAR? → 10.0000
<b>Note</b>	

#### 12.5.14 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:END

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:END <load>
<b>Description</b>	This command sets the stream end line load in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000<sup>1</sup>, DEFault=0.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS, IFG. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:END 10.0000
<b>Notes</b>	The minimum possible line load is 0.0008PCT. The maximum combined line load for all 16 streams are 100PCT. <sup>1</sup> The maximum allowed Line Load varies depending on the stream frame size. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:END? [<suffix>]
<b>Description</b>	This query returns the stream end line load in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second IFG: Inter Frame Gap <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:END? → 10.0000
<b>Note</b>	

#### 12.5.15 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STEP

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STEP <load>
<b>Description</b>	This command sets the stream line load step size, in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000<sup>1</sup>, DEFault=1.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS, IFG. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:STEP 10.0000
<b>Notes</b>	The minimum possible line load is 0.0008PCT. <sup>1</sup> The maximum allowed Line Load varies depending on the stream frame size. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:STEP? [<suffix>]
<b>Description</b>	This query returns the stream line load step size, in ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second IFG: Inter Frame Gap <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:STEP? → 10.0000
<b>Note</b>	

### 12.5.16 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:DURation

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:DURation <dur>
<b>Description</b>	This command sets the stream step line load duration in ramp mode. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <dur> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 3600, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:DUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:RAMP:DURation?
<b>Description</b>	This query returns the stream step line load duration in ramp mode. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<load> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:RAMP:DUR? → 10
<b>Note</b>	

### 12.5.17 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp:DURation

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp:DURation <dur>
<b>Description</b>	This command sets the stream step line load duration in milliseconds ramp mode. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <dur> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.001, MAXimum = 3.000, DEFault = 0.001</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF:MRAM:DUR 1.000
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:LLoad:PROFile:MRAMp:DURation?
<b>Description</b>	This query returns the stream step line load duration in milliseconds ramp mode. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<load> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:LL:PROF:MRAM:DUR? → 1.000
<b>Note</b>	

## 12.5.18 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:FSIZE:PROFile

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:PROFile <profile>
<b>Description</b>	This command sets the stream frame size profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <profile> = <CHARACTER PROGRAM DATA> CONStant: Constant frame size STEPped: Stepped frame size profile RANDom: Random frame size profile BINCrement: 1 byte increment <i>DEFault = CONStant</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:PROF CONS
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:PROFile?
<b>Description</b>	This query returns the stream frame size profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:PROF? → RAND
<b>Note</b>	

## 12.5.19 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:FSIZE[:STARt]

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE[:STARt] <size>
<b>Description</b>	This command sets start frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ 120
<b>Notes</b>	This is used as the frame size for the Constant profile and start frame size for the Stepped and Random profiles. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE[:STARt]?
<b>Description</b>	This query returns the start frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ? → 100
<b>Note</b>	

## 12.5.20 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:FSIZE:END

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZE:END <size>
<b>Description</b>	This command sets end frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:END 320
<b>Notes</b>	This is used as the end frame size for the Stepped and Random profiles. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.



<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:END?
<b>Description</b>	This query returns the end frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:END? → 320
<b>Note</b>	

### 12.5.21 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:STEP

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:STEP <size>
<b>Description</b>	This command sets step frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:STEP 100
<b>Notes</b>	This is used as the step frame size for the Stepped profile.

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:STEP?
<b>Description</b>	This query returns the step frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:STEP? → 100
<b>Note</b>	

### 12.5.22 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:DURation

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:DURation <duration>
<b>Description</b>	This command sets the step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <duration> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 3600, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:DUR 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:FSIZe:DURation?
<b>Description</b>	This query returns the step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:FSIZ:DUR? → 10
<b>Note</b>	

## 12.5.23 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:PROFile

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:PROFile <profile>
<b>Description</b>	This command sets the stream profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <profile> = <CHARACTER PROGRAM DATA> DATA: Data VIDeo: Video VOICe: Voice <i>DEFault = DATA</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:PROF VID
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:PROFile?
<b>Description</b>	This query returns the stream profile.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:PROF? → VID
<b>Note</b>	

## 12.5.24 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:ENCoding:VIDeo

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VIDeo <codec>
<b>Description</b>	This command sets the stream encoding video codec.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <codec> = <CHARACTER PROGRAM DATA> SDMPEG2: SDTV (MPEG2) HDMPEG2: HDTV (MPEG2) HDMPEG4: HDTV (MPEG4) <i>DEFault = SDMPEG2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:ENC:VID HDMPEG2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VIDeo?
<b>Description</b>	This query returns the stream encoding video codec.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<codec> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:ENC:VID? → HDMPEG2
<b>Note</b>	

## 12.5.25 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:ENCoding:VOICe

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VOICe <codec>
<b>Description</b>	This command sets the stream encoding voice codec.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <codec> = <CHARACTER PROGRAM DATA> G711: VoIP G.711 G7231: VoIP G.723.1 G729: VoIP G.729 <i>DEFault = G711</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:ENC:VOIC G7231
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:ENCoding:VOICe?
<b>Description</b>	This query returns the stream encoding voice codec.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<codec> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:ENC:VOIC? → G7231
<b>Note</b>	

## 12.5.26 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:NCHannels

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:NCHannels <channel>
<b>Description</b>	This command sets the number of channels.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <channel> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 100000, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:NCH 3
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:NCHannels?
<b>Description</b>	This query returns the number of channels.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<channel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:NCH? → 3
<b>Note</b>	

## 12.5.27 ETHernet:PORT&lt;Pt&gt;:TRAFfic:STReam&lt;St&gt;:BURSt:MODE

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:MODE <mode>
<b>Description</b>	This command sets the burst mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> OFF : OFF CONStant : constant RAMP : ramp <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:MOD RAMP
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:MODE?
<b>Description</b>	This query returns the burst mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:MOD? → RAMP
<b>Note</b>	

### 12.5.28 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:MODE

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:MODE <enable>
<b>Description</b>	This command enables/disables number of burst mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:NBUR:MOD ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:MODE?
<b>Description</b>	This query returns if number of burst mode is enabled/disabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:NBUR:MOD? → 0
<b>Note</b>	

### 12.5.29 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:BNUmber

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:BNUmber <number>
<b>Description</b>	This command sets the number of burst .
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <number> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 65535, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:NBUR:BNUM 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:NBURst:BNUmber?
<b>Description</b>	This query returns the number of burst.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:NBUR:BNUM? → 100
<b>Note</b>	

**12.5.30 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PDUTy[:DUTY]**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PDUTy[:DUTY] <duty>, <period>
<b>Description</b>	This command sets the burst configuraiton . Duty is prior than period . Period Unit: Milliseconds
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <duty> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00000, MAXimum = 100.00000, DEFault = 0.00000</i> <period> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00001, MAXimum = 5000.0000, DEFault = 1.0000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:PDUT 100.0000, 1.0000
<b>Note</b>	

**12.5.31 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PDUTy:PERiod**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PDUTy:PERiod <duty>, <period>
<b>Description</b>	This command sets the burst configuraiton. Period is prior than duty. Period Unit: Milliseconds
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <duty> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00000, MAXimum = 100.00000, DEFault = 0.00000</i> <period> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00001, MAXimum = 5000.0000, DEFault = 1.0000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:PDUT:PER 100.0000, 1.0000
<b>Note</b>	

**12.5.32 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:DUTY?**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:DUTY?
<b>Description</b>	This query returns the duty percentage.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<duty> = <NUMERIC PROGRAM DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:DUTY? → 100.00000
<b>Note</b>	

**12.5.33 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PERiod?**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:PERiod?
<b>Description</b>	This query returns the period milliseconds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<period> = <NUMERIC PROGRAM DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:PER? → 1.00000
<b>Note</b>	

**12.5.34 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BLENgth**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BLENgth <length>[,<suffix>]
<b>Description</b>	This command sets the burst length of constant.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 8.0000, MAXimum = 919117647.0000, DEFault = 1.0000</i> <suffix> = <CHARACTER PROGRAM DATA> FRAMes : number of frames BYTes : bytes MSEConds : milli seconds <i>DEFault = FRAMes</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:BLEN 10
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BLENgth? [<suffix>]
<b>Description</b>	This query returns the burst length of constant.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> FRAMes: number of frames BYTes: bytes MSEConds: milli seconds <i>DEFault = FRAMes</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:BLEN? → 10
<b>Note</b>	

**12.5.35 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BGAP**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BGAP <length>[,<suffix>]
<b>Description</b>	This command sets the inter burst gap of constant.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 128 bytes, MAXimum = 6250000000 bytes, DEFault = 1024 bytes</i> <suffix> = <CHARACTER PROGRAM DATA> BYTes : bytes MSEConds : milli seconds <i>DEFault = BYTes</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:BGAP 10
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:CONStant:BGAP? [<suffix>]
<b>Description</b>	This query returns the inter burst gap of constant.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> BYTes: bytes MSEConds: milli seconds <i>DEFault = BYTes</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:CONS:BGAP? → 10
<b>Note</b>	

**12.5.36 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:RMODE**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:RMODE <mode>
<b>Description</b>	This command sets the burst ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> KEEPend : keep end REPeat : repeat <i>DEFault = KEEPend</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:RMOD KEEP
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:RMODE?
<b>Description</b>	This query returns the burst ramp mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:RMOD? → KEEP
<b>Note</b>	

**12.5.37 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENght:STARt**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENght:STARt <length>[,<suffix>]
<b>Description</b>	This command sets the burst ramp start length of ramp.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 8.0000, MAXimum = 919117647.0000, DEFault = 1.0000</i> <suffix> = <CHARACTER PROGRAM DATA> FRAMES : number of frames BYTes : bytes MSEConds : milli seconds <i>DEFault = FRAMES</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BLEN:STAR 10
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENght:STARt? [<suffix>]
<b>Description</b>	This query returns the burst ramp end length of ramp.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> FRAMES: number of frames BYTes: bytes MSEConds: milli seconds <i>DEFault = FRAMES</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BLEN:STAR? → 10
<b>Note</b>	

**12.5.38 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENgth:END**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENgth:END <length>[,<suffix>]
<b>Description</b>	This command sets the burst ramp end length of ramp.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 8.0000, MAXimum = 919117647.0000, DEFault = 1.0000</i> <suffix> = <CHARACTER PROGRAM DATA> FRAMes : number of frames BYTes : bytes MSEConds : seconds <i>DEFault = FRAMes</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BLEN:END 10
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BLENgth:END? [<suffix>]
<b>Description</b>	This query returns the burst ramp start length of ramp.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> FRAMes: number of frames BYTes: bytes MSEConds: milli seconds <i>DEFault = FRAMes</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BLEN:END? → 10
<b>Note</b>	

**12.5.39 ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BGAP**

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BGAP <length>[,<suffix>]
<b>Description</b>	This command sets the inter burst gap of ramp.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 128 bytes, MAXimum = 6250000000 bytes, DEFault = 1024 bytes</i> <suffix> = <CHARACTER PROGRAM DATA> BYTes : bytes MSEConds : milli seconds <i>DEFault = BYTes</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BGAP 10
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TRAFfic:STReam<St>:BURSt:RAMP:BGAP? [<suffix>]
<b>Description</b>	This query returns the inter burst gap of ramp.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> BYTes: bytes MSEConds: milli seconds <i>DEFault = BYTes</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TRAF:STR1:BURS:RAMP:BGAP? → 10
<b>Note</b>	



## 12.6 Frame Content

### 12.6.1 ETHernet:PORT<Pt>:STReam<St>:FRAMed

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FRAMed <enable>
<b>Description</b>	This command enables/disables framed Ethernet.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:FRAM OFF
<b>Note</b>	BER is the only allowed protocol when framed Ethernet is OFF (unframed).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FRAMed?
<b>Description</b>	This query returns if framed Ethernet is enabled/disabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:FRAM? → 0
<b>Note</b>	

### 12.6.2 ETHernet:PORT<Pt>:STReam<St>:MAC:SOURce

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:SOURce <address>
<b>Description</b>	This command sets the MAC source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:SOUR "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:SOURce?
<b>Description</b>	This query returns the MAC source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:SOUR? → "00-50-C2-35-D2-EF"
<b>Note</b>	

### 12.6.3 ETHernet:PORT<Pt>:STReam<St>:MAC:DESTination

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:DESTination <address>
<b>Description</b>	This command sets the MAC destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:DEST "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:DESTination?
<b>Description</b>	This query returns the MAC destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:DEST? → "00-50-C2-35-D2-EF"
<b>Note</b>	

#### 12.6.4 ETHernet:PORT<Pt>:STReam<St>:MAC:ARP

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP <enable>
<b>Description</b>	This command enables/disables use of ARP to resolve destination MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:ARP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP?
<b>Description</b>	This query returns whether or not ARP is used.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:ARP? → 1
<b>Note</b>	

#### 12.6.5 ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:LKUP

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:LKUP
<b>Description</b>	This command execute ARP. this command valid only when IPv4 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:ARP:LKUP
<b>Note</b>	

#### 12.6.6 ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:RESult?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ARP:RESult?
<b>Description</b>	This query returns the ARP condition. this command valid only when IPv4 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<status> = <CHARACTER RESPONSE DATA> SUCCESS: ARP lookup succeeded. TIMEOUT: ARP lookup timed out.
<b>Example</b>	ETH:PORT1:STR1:MAC:ARP:RES? → SUCCESS
<b>Note</b>	

## 12.6.7 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MAC:NDP

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP <enable>
<b>Description</b>	This command enables/disables use of NDP to resolve destination MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:NDP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP?
<b>Description</b>	This query returns whether or not NDP is used.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:NDP? → 1
<b>Note</b>	

## 12.6.8 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MAC:NDP:LKUP

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP:LKUP
<b>Description</b>	This command execute NDP. this command valid only when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:NDP:LKUP
<b>Note</b>	

## 12.6.9 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MAC:NDP:RESult?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:NDP:RESult?
<b>Description</b>	This query returns the NDP condition. this command valid only when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<status> = <CHARACTER RESPONSE DATA> SUCCESS: ARP lookup succeeded. TIMEOUT: ARP lookup timed out.
<b>Example</b>	ETH:PORT1:STR1:MAC:NDP:RES? → SUCCESS
<b>Note</b>	

## 12.6.10 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MAC:BRoadcast

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:BRoadcast <percentage>
<b>Description</b>	This command sets the percentage of stream packets that will be transmitted as broadcast packets.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <percentage> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0, MAXimum=100.0, DEFault=0.0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:BRO 10.0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:BRoAdcast?
<b>Description</b>	This query returns the stream broadcast percentage.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<percentage> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:BR0? → 10.5
<b>Note</b>	

### 12.6.11 ETHernet:PORT<Pt>:STReam<St>:MAC:DEFAult

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:DEFAult <enable>
<b>Description</b>	This command enables/disables use of default source MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFAult = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:DEF ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:DEFAult?
<b>Description</b>	This query returns if the default source MAC address is used.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:DEF? → 1
<b>Note</b>	

### 12.6.12 ETHernet:PORT<Pt>:STReam<St>:MAC:ETYPe

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ETYPe <type>
<b>Description</b>	This command sets MAC level Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:ETYP #H8100
<b>Note</b>	This command can only be used when MPLS is disabled and VLAN is enabled. When IPv4 and IPv6 is disabled this level is set by :MAC:L3EType command (see section 12.6.13).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:ETYPe?
<b>Description</b>	This query returns MAC level Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:ETYP? → #H8100
<b>Note</b>	This command can only be used when MPLS is disabled and VLAN is enabled.

**12.6.13 ETHernet:PORT<Pt>:STReam<St>:MAC:L3EType**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:L3EType <type>
<b>Description</b>	This command sets the Ethertype for layer three when no protocol is defined for this layer.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <type> = <NUMERIC PROGRAM DATA> <i>MINimum=1501, MAXimum=65535, DEFault=1501</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MAC:L3ET #H0800
<b>Note</b>	This command can only be used when IPv4 or IPv6 is disabled. When VLAN is enabled this level is set by :MAC:ETYPe command (see section 12.6.12).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MAC:L3EType?
<b>Description</b>	This query returns the Ethertype for layer three when no protocol is defined for this layer.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MAC:L3ET? → #0800
<b>Note</b>	This command can only be used when IPv4 or IPv6 is disabled.

**12.6.14 ETHernet:PORT<Pt>:STReam<St>:MPLS[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS[:ENABLE] <enable>
<b>Description</b>	This command enables/disables MPLS.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS[:ENABLE]?
<b>Description</b>	This query returns the state of MPLS.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS? → 1
<b>Note</b>	

**12.6.15 ETHernet:PORT<Pt>:STReam<St>:MPLS:LCount**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LCount <levels>
<b>Description</b>	This command sets the number of active MPLS levels.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:LC 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LCOUNT?
<b>Description</b>	This query returns the number of active MPLS levels.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:LC? → 2
<b>Note</b>	

### 12.6.16 ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:LABel

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:LABel <label>
<b>Description</b>	This command sets the MPLS label.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N <sup>1</sup> ) <label> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1048575, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:LAB 1048575
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:LABel?
<b>Description</b>	This query returns the MPLS label.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N)
<b>Response</b>	<label> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:LAB? → 1048575
<b>Note</b>	

### 12.6.17 ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:EBITs

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:EBITs <value>
<b>Description</b>	This command sets the MPLS experimental bits.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:EBIT 5
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:EBITs?
<b>Description</b>	This query returns the MPLS experimental bits.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:EBIT? → 5
<b>Note</b>	

## 12.6.18 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MPLS:LEVel&lt;Lv&gt;:TTL

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:TTL <value>
<b>Description</b>	This command sets the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:TTL 32
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:LEVel<Lv>:TTL?
<b>Description</b>	This query returns the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:LEV1:TTL? → 32
<b>Note</b>	

## 12.6.19 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MPLS:ETHernet[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet[:ENABLE] <enable>
<b>Description</b>	This command enables/disables Ethernet over MPLS
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet[:ENABLE]?
<b>Description</b>	This query returns the state of Ethernet over MPLS.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH? → 1
<b>Note</b>	

## 12.6.20 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MPLS:ETHernet:AINCrement

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:AINCrement <enable>
<b>Description</b>	This command enables/disables EoMPLS auto incrementation of sequence numbers.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:AINC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:AINCrement?
<b>Description</b>	This query returns the state of EoMPLS auto incrementation of sequence numbers.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:AINC? → 1
<b>Note</b>	

### 12.6.21 ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:SMAC <address>
<b>Description</b>	This command sets EoMPLS source MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:SMAC "66-60-C2-35-D3-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:SMAC?
<b>Description</b>	This query returns the EoMPLS source MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:SMAC? → "66-60-C2-35-D3-EF"
<b>Note</b>	

### 12.6.22 ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:DMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:DMAC <address>
<b>Description</b>	This command sets the EoMPLS destination MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:DMAC "66-60-C2-35-D3-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:DMAC?
<b>Description</b>	This query returns the EoMPLS destination MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:DMAC? → "66-60-C2-35-D3-EF"
<b>Note</b>	



## 12.6.23 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MPLS:ETHernet:ETYPe

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:ETYPe <type>
<b>Description</b>	This command sets the EoMPLS Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:ETYP #H8100
<b>Note</b>	This command can only be used when MPLS and VLAN are enabled.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MPLS:ETHernet:ETYPe?
<b>Description</b>	This query returns the EoMPLS Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MPLS:ETH:ETYP? → #H8100
<b>Note</b>	

## 12.6.24 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MIM[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM[:ENABLE] <enable>
<b>Description</b>	This command enables/disables MiM.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM[:ENABLE]?
<b>Description</b>	This query returns whether or not MiM is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM? → 1
<b>Note</b>	

## 12.6.25 ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:MIM:BTAG:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:DEI <enable>
<b>Description</b>	This command sets the B-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:DEI ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:DEI?
<b>Description</b>	This query returns the B-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:DEI? → 1
<b>Note</b>	

### 12.6.26 ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:PRiority

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:PRiority <priority>
<b>Description</b>	This command sets the B-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <priority> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:PR 7
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:PRiority?
<b>Description</b>	This query returns the B-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:PR? → 7
<b>Note</b>	

### 12.6.27 ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:VID

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:VID <vid>
<b>Description</b>	This command sets the B-TAG Backbone VLAN ID.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <vid> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:VID 1024
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:BTAG:VID?
<b>Description</b>	This query returns the B-TAG Backbone VLAN ID.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<vid> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:BTAG:VID? → 1024
<b>Note</b>	

**12.6.28 ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:UCA**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:UCA <enable>
<b>Description</b>	This command sets the I-TAG UCA bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:UCA ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:UCA?
<b>Description</b>	This query returns the I-TAG UCA bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:UCA? → 1
<b>Note</b>	

**12.6.29 ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:DEI**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:DEI <enable>
<b>Description</b>	This command sets the I-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:DEI ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:DEI?
<b>Description</b>	This query returns the I-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:DEI? → 1
<b>Note</b>	

**12.6.30 ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:PRiority**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:PRiority <priority>
<b>Description</b>	This command sets the I-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <priority> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:PR 7
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:Priority?
<b>Description</b>	This query returns the I-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:PR? → 7
<b>Note</b>	

### 12.6.31 ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:SID

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:SID <sid>
<b>Description</b>	This command sets the I-TAG SID.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <sid> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 16777215, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:SID 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ITAG:SID?
<b>Description</b>	This query returns the I-TAG SID.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<sid> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ITAG:SID? → 1
<b>Note</b>	

### 12.6.32 ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:SMAC <address>
<b>Description</b>	This command sets the encapsulated customer source MAC address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:SMAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:SMAC?
<b>Description</b>	This query returns the encapsulated customer source MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:SMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

### 12.6.33 ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:DMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:DMAC <address>
<b>Description</b>	This command sets the encapsulated customer destination MAC address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:DMAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:DMAC?
<b>Description</b>	This query returns the encapsulated customer destination MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:DMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

### 12.6.34 ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:ETYPe

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:ETYPe <type>
<b>Description</b>	This command sets the encapsulated customer Ethernet Type.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:ETYP #H8100
<b>Note</b>	This command can only be used when MiM and VLAN is enabled. When IPv4 and IPv6 is disabled this level is set by :MAC:L3EType command (see section <a href="#">12.6.13</a> ).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:MIM:ETHernet:ETYPe?
<b>Description</b>	This query returns the encapsulated customer Ethernet Type.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:MIM:ETH:ETYP? → #H8100
<b>Note</b>	

### 12.6.35 ETHernet:PORT<Pt>:STReam<St>:VLAN[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN[:ENABle] <enable>
<b>Description</b>	This command enables/disables VLAN.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN[:ENABle]?
<b>Description</b>	This query returns whether or not VLAN is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<boolean> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN? → 1
<b>Note</b>	

**12.6.36 ETHernet:PORT<Pt>:STReam<St>:VLAN:LCCount**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LCCount <levels>
<b>Description</b>	This command sets the number of active VLAN levels.
<b>Parameters</b>	<Pt> = Port number
	<St> = Stream number (1-16)
	<levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LC 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LCCount?
<b>Description</b>	This query returns the number of active VLAN levels.
<b>Parameters</b>	<Pt> = Port number
	<St> = Stream number (1-16)
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LC? → 2
<b>Note</b>	

**12.6.37 ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ID**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ID <number>
<b>Description</b>	This command sets the VLAN ID.
<b>Parameters</b>	<Pt> = Port number
	<St> = Stream number (1-16)
	<Lv> = VLAN level (1-N <sup>1</sup> )
	<number> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4095, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:ID 1024
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ID?
<b>Description</b>	This query returns the VLAN ID.
<b>Parameters</b>	<Pt> = Port number
	<St> = Stream number (1-16)
	<Lv> = VLAN level (1-N)
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:ID? → 1024
<b>Note</b>	

**12.6.38 ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:CFI ON
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:CFI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI?

**12.6.39 ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:DEI ON
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:DEI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:DEI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:CFI?

**12.6.40 ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:PRiority**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:PRiority <priority>
<b>Description</b>	This command sets the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N <sup>1</sup> ) <priority> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:PR 7
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:PRiority?
<b>Description</b>	This query returns the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N)
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:PR? → 7
<b>Note</b>	

**12.6.41 ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ETYPe**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ETYPe <type>
<b>Description</b>	This command sets the VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N) <sup>1</sup> <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200 <i>DEFault=#H8100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:ETYP #H8100
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels (1-M), where M is the number of active VLAN Levels minus one (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). It is not possible to use this command for VLAN level N as Ethertype because: <ul style="list-style-type: none"> <li>- When IPv4 or IPv6 is enabled this level is automatically set according to the selected higher-level protocol.</li> <li>- When IPv4 and IPv6 is disabled this level is set by :MAC:L3EType command (see section 12.6.13).</li> </ul> MAC level Ethertype is set by :MAC:ETYPe command (see section 12.6.12).



<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VLAN:LEVel<Lv>:ETYPe?
<b>Description</b>	This query returns the VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <Lv> = VLAN level (1-N <sup>1</sup> )
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VLAN:LEV1:ETYP? → #H8100
<b>Note</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97).

#### 12.6.42 ETHernet:PORT<Pt>:STReam<St>:LLC[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LLC[:ENABLE] <enable>
<b>Description</b>	This command enables/disables LLC1 (logical link control type 1).
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:LLC ON
<b>Note</b>	Disabling LLC will automatically also disable SNAP.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LLC[:ENABLE]?
<b>Description</b>	This query returns whether or not LLC1 is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:LLC? → 1
<b>Note</b>	

#### 12.6.43 ETHernet:PORT<Pt>:STReam<St>:SNAP[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:SNAP[:ENABLE] <enable>
<b>Description</b>	This command enables/disables SNAP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:SNAP ON
<b>Note</b>	Enabling SNAP will automatically also enable LLC.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:SNAP[:ENABLE]?
<b>Description</b>	This query returns whether or not SNAP is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable > = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:SNAP? → 1
<b>Note</b>	

**12.6.44 ETHernet:PORT<Pt>:STReam<St>:L2Custom[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:L2Custom[:ENABLE] <enable>
<b>Description</b>	This command enables/disables L2Custom.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:L2C ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:L2Custom[:ENABLE]?
<b>Description</b>	This query returns whether or not L2Custom is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<boolean> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:L2C? → 1
<b>Note</b>	

**12.6.45 ETHernet:PORT<Pt>:STReam<St>:IPV4[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4[:ENABLE] <enable>
<b>Description</b>	This command enables/disables IPv4.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4 ON
<b>Note</b>	Enabling of this parameter will disable IPv6

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4[:ENABLE]?
<b>Description</b>	This query returns whether or not IPv4 is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4? → 1
<b>Note</b>	

**12.6.46 ETHernet:PORT<Pt>:STReam<St>:IPV4:SOURce**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:SOURce <address>
<b>Description</b>	This command sets the IPv4 source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:SOUR "172.29.2.36"
<b>Note</b>	Only the character '.' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:SOURce?
<b>Description</b>	This query returns the IPv4 source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:SOUR? → "172.29.2.36"
<b>Note</b>	

#### 12.6.47 ETHernet:PORT<Pt>:STReam<St>:IPV4:DESTination

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:DESTination <address>
<b>Description</b>	This command sets the IPv4 destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:DEST "172.29.2.36"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:DESTination?
<b>Description</b>	This query returns the IPv4 destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:DEST? → "172.29.2.36"
<b>Note</b>	

#### 12.6.48 ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway[:ENABLE] <enable>
<b>Description</b>	This command enables/disables use of the IPv4 gateway.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:GAT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway[:ENABLE]?
<b>Description</b>	This query returns whether or not the IPv4 gateway is used.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:GAT? → 1
<b>Note</b>	

**12.6.49 ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway:ADDRess**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway:ADDRess <address>
<b>Description</b>	This command sets the IPv4 default gateway.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:GAT:ADDR "172.29.2.36"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:GATeway:ADDRess?
<b>Description</b>	This query returns the IPv4 default gateway.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:GAT:ADDR? → "172.29.2.36"
<b>Note</b>	

**12.6.50 ETHernet:PORT<Pt>:STReam<St>:IPV4:NETMask**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:NETMask <mask>
<b>Description</b>	This command sets the IPv4 netmask.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mask> = <STRING PROGRAM DATA> IPv4 netmask
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:NETM "255.255.255.0"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:NETMask?
<b>Description</b>	This query returns the IPv4 netmask.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:NETM? → "255.255.255.0"
<b>Note</b>	

**12.6.51 ETHernet:PORT<Pt>:STReam<St>:IPV4:HOST**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:HOST <host>
<b>Description</b>	This command sets the IPv4 destination host name which is used in case DNS is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <host> = <STRING PROGRAM DATA> Host name (max. 255 characters)
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:HOST "www.anritsu.com"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:HOST?
<b>Description</b>	This query return the IPv4 destination host name.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<host> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:HOST? → "www.anritsu.com"
<b>Note</b>	

### 12.6.52 ETHernet:PORT<Pt>:STReam<St>:IPV4:TTL

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:TTL <value>
<b>Description</b>	This command sets the IPv4 time to live.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:TTL 32
<b>Note</b>	This command sets the same storage parameter within the instrument as the IPv6 command ETHernet:PORT<Pt>:STReam<St>:IPV6:HLIMit (see section 12.6.69).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:TTL?
<b>Description</b>	This query returns the IPv4 time to live.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:TTL? → 32
<b>Note</b>	

### 12.6.53 ETHernet:PORT<Pt>:STReam<St>:IPV4:TOS

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:TOS <value>
<b>Description</b>	This command sets the IPv4 DSCP/TOS byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV4:TOS #HFF ETH:PORT1:STR1:IPV4:TOS 128
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:TOS?
<b>Description</b>	This query returns the IPv4 DSCP/TOS byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:TOS? → 255
<b>Note</b>	

**12.6.54 ETHernet:PORT<Pt>:STReam<St>:IPV4:IDENtifier**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:IDENtifier <value>
<b>Description</b>	This command sets the IPv4 identifier field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535, DEFault=43981</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV4:IDEN #HABCD ETH:PORT1:STR1:IPV4:IDEN 12345
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:IDENtifier?
<b>Description</b>	This query returns the IPv4 identifier field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:IDEN? → 43981
<b>Note</b>	

**12.6.55 ETHernet:PORT<Pt>:STReam<St>:IPV4:AINCrement**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:AINCrement <enable>
<b>Description</b>	This command enables/disables auto incrementation of the IPv4 identifier field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:AINC OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:AINCrement?
<b>Description</b>	This query returns whether or not auto incrementation of the IPv4 identifier field is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:AINC? → 0
<b>Note</b>	

**12.6.56 ETHernet:PORT<Pt>:STReam<St>:IPV4:MF**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:MF <boolean>
<b>Description</b>	This command sets/clears the IPv4 more fragments flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <boolean> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:MF 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:MF?
<b>Description</b>	This query returns the IPv4 more fragments flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<boolean> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:MF? → 1
<b>Note</b>	

### 12.6.57 ETHernet:PORT<Pt>:STReam<St>:IPV4:DF

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:DF <boolean>
<b>Description</b>	This command sets/clears the IPv4 don't fragment flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <boolean> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:DF 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:DF?
<b>Description</b>	This query returns the IPv4 don't fragment flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<boolean> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:DF? → 1
<b>Note</b>	

### 12.6.58 ETHernet:PORT<Pt>:STReam<St>:IPV4:RES

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:RES <boolean>
<b>Description</b>	This command sets/clears the IPv4 reserved flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <boolean> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV4:RES 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:RES?
<b>Description</b>	This query returns the IPv4 reserved flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<boolean> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:RES? → 0
<b>Note</b>	

**12.6.59 ETHernet:PORT<Pt>:STReam<St>:IPV4:PROTOcol**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:PROTOcol <value>
<b>Description</b>	This command sets the IPv4 protocol byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=253</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV4:PROT #HFD ETH:PORT1:STR1:IPV4:PROT 17
<b>Notes</b>	This command sets the same storage parameter within the instrument as the IPv6 command <b>ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:IPV6:NHeader</b> (see section 12.6.68). In case UDP or TCP is enabled, the value set by this command is not used. Instead values 17 (UDP) or 6 (TCP) are automatically inserted in the IPv4 header.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:PROTOcol?
<b>Description</b>	This query returns the IPv4 protocol byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:PROT? → 6
<b>Note</b>	

**12.6.60 ETHernet:PORT<Pt>:STReam<St>:IPV4:TLENgth?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:TLENgth?
<b>Description</b>	This query returns the Total Length field in the IP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:TLEN? → 62
<b>Note</b>	

**12.6.61 ETHernet:PORT<Pt>:STReam<St>:IPV4:CHECksum?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV4:CHECksum?
<b>Description</b>	This query returns the checksum field in the IP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<checksum> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV4:CHEC? → #HA2E3
<b>Note</b>	

**12.6.62 ETHernet:PORT<Pt>:STReam<St>:DNS[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS[:ENABle] <enable>
<b>Description</b>	This command enables/disables DNS.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DNS ON
<b>Note</b>	



<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS[:ENABle]?
<b>Description</b>	This query returns whether or not DNS is used.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DNS? → 1
<b>Note</b>	

### 12.6.63 ETHernet:PORT<Pt>:STReam<St>:DNS:PRIMary

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS:PRIMary <address>
<b>Description</b>	This command sets primary DNS sever address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DNS:PRIM "172.29.2.36"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS:PRIMary?
<b>Description</b>	This query returns the primary DNS server address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DNS:PRIM? → "172.29.2.36"
<b>Note</b>	

### 12.6.64 ETHernet:PORT<Pt>:STReam<St>:DNS:SECOndary

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS:SECOndary <address>
<b>Description</b>	This command sets secondary DNS sever address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DNS:SEC "172.29.2.37"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DNS:SECOndary?
<b>Description</b>	This query returns the secondary DNS server address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DNS:SEC? → "172.29.2.37"
<b>Note</b>	

**12.6.65 ETHernet:PORT<Pt>:STReam<St>:IPV6[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6[:ENABLE] <enable>
<b>Description</b>	This command enables/disables IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6 ON
<b>Note</b>	Enabling of this parameter will disable IPv4

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6[:ENABLE]?
<b>Description</b>	This query returns whether or not IPv6 is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6? → 1
<b>Note</b>	

**12.6.66 ETHernet:PORT<Pt>:STReam<St>:IPV6:TCLass**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:TCLass <value>
<b>Description</b>	This command sets the IPv6 traffic class byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV6:TCL #HFF ETH:PORT1:STR1:IPV6:TCL 128
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:TCLass?
<b>Description</b>	This query returns the IPv6 traffic class byte.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:TCL? → 255
<b>Note</b>	

**12.6.67 ETHernet:PORT<Pt>:STReam<St>:IPV6:FLABel**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:FLABel <value>
<b>Description</b>	This command sets the IPv6 flow label field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1048575, DEFault=0</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV6:FLAB #FFFFFF ETH:PORT1:STR1:IPV6:FLAB 1024
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:FLABel?
<b>Description</b>	This query returns the IPv6 flow label field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:FLAB? → 1024
<b>Note</b>	

### 12.6.68 ETHernet:PORT<Pt>:STReam<St>:IPV6:NHeader

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:NHeader <value>
<b>Description</b>	This command sets the IPv6 next header field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=253</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:IPV6:NH #HFF ETH:PORT1:STR1:IPV6:NH 128
<b>Notes</b>	This command sets the same storage parameter within the instrument as the IPv4 command <code>ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:IPV4:PRoToCol</code> (see section 12.6.59). In case UDP or TCP is enabled, the value set by this command is not used. Instead values 17 (UDP) or 6 (TCP) are automatically inserted in the IPv6 header.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:NHeader?
<b>Description</b>	This query returns the IPv6 next header field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:NH? → 233
<b>Note</b>	

### 12.6.69 ETHernet:PORT<Pt>:STReam<St>:IPV6:HLIMit

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:HLIMit <value>
<b>Description</b>	This command sets the IPv6 hop limit field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:HLIM 32
<b>Note</b>	This command sets the same storage parameter within the instrument as the IPv4 command <code>ETHernet:PORT&lt;Pt&gt;:STReam&lt;St&gt;:IPV4:TTL</code> (see section 12.6.52).

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:HLIMit?
<b>Description</b>	This query returns the IPv6 hop limit field.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:HLIM? → 32
<b>Note</b>	

**12.6.70 ETHernet:PORT<Pt>:STReam<St>:IPV6:SOURce**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SOURce <address>
<b>Description</b>	This command sets the IPv6 source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv6 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:SOUR "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SOURce?
<b>Description</b>	This query returns the IPv6 source address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SOUR? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.6.71 ETHernet:PORT<Pt>:STReam<St>:IPV6:DESTination**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:DESTination <address>
<b>Description</b>	This command sets the IPv6 destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <address> = <STRING PROGRAM DATA> IPv6 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:DEST "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:DESTination?
<b>Description</b>	This query returns the IPv6 destination address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:DEST? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.6.72 ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig <mode>
<b>Description</b>	This command sets the address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> MANual: Manual SLESs: Stateless <i>DEFault = SLESs</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:ADDR SLES
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig?
<b>Description</b>	This query returns the address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:ADDR? → SLES
<b>Note</b>	

### 12.6.73 ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig:RESult?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:ADDRconfig:RESult?
<b>Description</b>	This query returns the result of address config for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> SUCCESS: Address configuration succeeded. TIMEOUT: Address configuration timed out.
<b>Example</b>	ETH:PORT1:STR1:IPV6:ADDR:RES? → TIMEOUT
<b>Note</b>	

### 12.6.74 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID <mode>
<b>Description</b>	This command sets the interface ID for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <id> = <STRING PROGRAM DATA> The interface ID string must consist of 16 hexadecimal digits.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:IID "00-00-00-00-00-00-00-00"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID?
<b>Description</b>	This query returns the address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<mode> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:IID? → "00-00-00-00-00-00-00-00"
<b>Note</b>	

### 12.6.75 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID:AUTO

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID:AUTO <enable>
<b>Description</b>	This command enables/disables Interface ID.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:IID:AUTO ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:IID:AUTO?
<b>Description</b>	This query returns whether or not Interface ID is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:IID:AUTO? → 1
<b>Note</b>	

### 12.6.76 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:LINKlocal?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:LINKlocal?
<b>Description</b>	This query returns the link local address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:LINK? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

### 12.6.77 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:RAFLag?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:RAFLag?
<b>Description</b>	This query returns the stateless RA flags.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<flags> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:RAFL? → "0x00"
<b>Note</b>	

### 12.6.78 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:SRCMac?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:SRCMac?
<b>Description</b>	This query returns the stateless source MAC address.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:SRCM? → "00-00-00-00-00-00"
<b>Note</b>	

### 12.6.79 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:PREFfix?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:PREFfix?
<b>Description</b>	This query returns the stateless prefix.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<prefix> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:PREF? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

### 12.6.80 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:PRFLag?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:PRFLag?
<b>Description</b>	This query returns the stateless prefix flags.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<flags> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:PRFL? → "0x00"
<b>Note</b>	

**12.6.81 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:LTIme?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:LTIme?
<b>Description</b>	This query returns the stateless life time.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<time> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:LTIM? → "Fri Jan 8 14:24:44 2010"
<b>Note</b>	

**12.6.82 ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:RENew**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:SLESs:RENew
<b>Description</b>	This command execute Stateless address configuration. This command valid only when IpV6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:IPV6:SLES:REN
<b>Note</b>	

**12.6.83 ETHernet:PORT<Pt>:STReam<St>:IPV6:PLENght?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:IPV6:PLENght?
<b>Description</b>	This query returns the Payload Length field in the IP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:IPV6:PLEN? → 62
<b>Note</b>	

**12.6.84 ETHernet:PORT<Pt>:STReam<St>:L3Custom[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:L3Custom[:ENABle] <enable>
<b>Description</b>	This command enables/disables Layer3 CUSTOM.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:L3C ON
<b>Note</b>	Enabling of this parameter will disable IPv4 and IPv6

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:L3Custom[:ENABle]?
<b>Description</b>	This query returns whether or not Layer3 CUSTOM is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:L3C? → 1
<b>Note</b>	

**12.6.85 ETHernet:PORT<Pt>:STReam<St>:DHCP[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP[:ENABle] <enable>
<b>Description</b>	This command enables/disables DHCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DHCP ON
<b>Note</b>	When DHCP is enabled a new DHCP discover message is transmitted. Use the query ETH:PORT1:STR1:DHCP:LET? (see section 12.6.89) to check if lease is obtained.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP[:ENABle]?
<b>Description</b>	This query returns whether or not DHCP is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DHCP? → 1
<b>Note</b>	

**12.6.86 ETHernet:PORT<Pt>:STReam<St>:DHCP:RENew**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:RENew <enable>
<b>Description</b>	This command enables/disables renewal of DHCP lease when link is reestablished.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DHCP:REN ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:RENew?
<b>Description</b>	This query returns whether or not DHCP lease is renewed when link reestablished.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DHCP:REN? → 1
<b>Note</b>	

**12.6.87 ETHernet:PORT<Pt>:STReam<St>:DHCP:DNS**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:DNS <enable>
<b>Description</b>	This command enables/disables whether DNS server info should be obtained through DHCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DHCP:DNS ON
<b>Note</b>	



<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:DNS?
<b>Description</b>	This query returns whether or not DNS server info is obtained through DHCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DHCP:DNS? → 1
<b>Note</b>	

### 12.6.88 ETHernet:PORT<Pt>:STReam<St>:DHCP:GATeway

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:GATeway <enable>
<b>Description</b>	This command enables/disables whether gateway setup should be obtained through DHCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:DHCP:GAT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:GATeway?
<b>Description</b>	This query returns whether or not gateway setup is obtained through DHCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DHCP:GAT? → 1
<b>Note</b>	

### 12.6.89 ETHernet:PORT<Pt>:STReam<St>:DHCP:LETime?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:DHCP:LETime?
<b>Description</b>	This query returns the current DHCP lease expire time.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<time> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:DHCP:LET? → "Fri Jan 8 14:24:44 2010"
<b>Note</b>	"N/A" is returned if DHCP is disabled or a lease has not been obtained .

### 12.6.90 ETHernet:PORT<Pt>:STReam<St>:UDP[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP[:ENABLE] <enable>
<b>Description</b>	This command enables/disables UDP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UDP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP[:ENABLE]?
<b>Description</b>	This query returns whether or not UDP is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP? → 1
<b>Note</b>	

**12.6.91 ETHernet:PORT<Pt>:STReam<St>:UDP:SPORt**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:SPORt <value>
<b>Description</b>	This command sets the UDP source port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UDP:SPOR 22
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:SPORt?
<b>Description</b>	This query returns the UDP source port
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP:SPOR? → 22
<b>Note</b>	

**12.6.92 ETHernet:PORT<Pt>:STReam<St>:UDP:DPORt**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:DPORt <value>
<b>Description</b>	This command sets the UDP destination port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UDP:DPOR 22
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:DPORt?
<b>Description</b>	This query returns the UDP destination port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP:DPOR? → 22
<b>Note</b>	

**12.6.93 ETHernet:PORT<Pt>:STReam<St>:UDP:LENGth?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:LENGth?
<b>Description</b>	This query returns the Length field in the UDP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP:LENG? → 62
<b>Note</b>	

**12.6.94 ETHernet:PORT<Pt>:STReam<St>:UDP:CNULI**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:CNULI <enable>
<b>Description</b>	This command enables/disables forcing of the UDP header checksum to null.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UDP:CNUL ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:CNULI?
<b>Description</b>	This query returns whether or not forcing of UDP checksum to null is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP:CNUL? → 1
<b>Note</b>	

**12.6.95 ETHernet:PORT<Pt>:STReam<St>:UDP:CHECKsum?**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UDP:CHECKsum?
<b>Description</b>	This query returns the checksum field in the UDP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<checksum> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UDP:CHEC? → #HA2E3
<b>Note</b>	

**12.6.96 ETHernet:PORT<Pt>:STReam<St>:TCP[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP[:ENABLE] <enable>
<b>Description</b>	This command enables/disables TCP.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP[:ENABLE]?
<b>Description</b>	This query returns whether or not TCP is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP? → 1
<b>Note</b>	

**12.6.97 ETHernet:PORT<Pt>:STReam<St>:TCP:ACONnect**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:ACONnect <enable>
<b>Description</b>	This command enables/disables automatic TCP connect.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:ACON ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:ACONnect?
<b>Description</b>	This query returns whether or not automatic TCP connect is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:ACON? → 1
<b>Note</b>	

**12.6.98 ETHernet:PORT<Pt>:STReam<St>:TCP:LMODe**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:LMODe <enable>
<b>Description</b>	This command enables/disables TCP listen mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:LMO ON
<b>Note</b>	Requires ACONnect to be enabled.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:LMODe?
<b>Description</b>	This query returns whether or not TCP listen mode is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:LMO? → 1
<b>Note</b>	

**12.6.99 ETHernet:PORT<Pt>:STReam<St>:TCP:SPORt**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:SPORt <value>
<b>Description</b>	This command sets the TCP source port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:SPOR 22
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:SPORt?
<b>Description</b>	This query returns the TCP source port
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:SPOR? → 22
<b>Note</b>	

### 12.6.100 ETHernet:PORT<Pt>:STReam<St>:TCP:DPORT

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:DPORT <value>
<b>Description</b>	This command sets the TCP destination port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:DPOR 22
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:DPORT?
<b>Description</b>	This query returns the TCP destination port.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:DPOR? → 22
<b>Note</b>	

### 12.6.101 ETHernet:PORT<Pt>:STReam<St>:TCP:SEQuence

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:SEQuence <value>
<b>Description</b>	This command sets the TCP sequence number.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4294967295, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:SEQ 123456
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:SEQuence?
<b>Description</b>	This query returns the TCP sequence number.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:SEQ? → 123456
<b>Note</b>	

**12.6.102 ETHernet:PORT<Pt>:STReam<St>:TCP:AINCrement**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:AINCrement <enable>
<b>Description</b>	This command enables/disables auto incrementation of the TCP sequence number.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:AINC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:AINCrement?
<b>Description</b>	This query returns whether or not auto incrementation of the TCP sequence number is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:AINC? → 1
<b>Note</b>	

**12.6.103 ETHernet:PORT<Pt>:STReam<St>:TCP:ACKnowledge**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:ACKnowledge <value>
<b>Description</b>	This command sets the TCP acknowledgment number.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:ACKN 123456
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:ACKnowledge?
<b>Description</b>	This query returns the TCP acknowledgment number.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:ACKN? → 123456
<b>Note</b>	

**12.6.104 ETHernet:PORT<Pt>:STReam<St>:TCP:REServed**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:REServed <value>
<b>Description</b>	This command sets the TCP reserved value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 63, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:RES 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:REServed?
<b>Description</b>	This query returns the TCP reserved value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:RES? → 10
<b>Note</b>	

### 12.6.105 ETHernet:PORT<Pt>:STReam<St>:TCP:FCWR

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FCWR <enable>
<b>Description</b>	This command enables/disables the TCP CWR flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FCWR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FCWR?
<b>Description</b>	This query returns the TCP CWR flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FCWR? → 1
<b>Note</b>	

### 12.6.106 ETHernet:PORT<Pt>:STReam<St>:TCP:FECE

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FECE <enable>
<b>Description</b>	This command enables/disables the TCP ECE flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FECE ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FECE?
<b>Description</b>	This query returns the TCP ECE flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FECE? → 1
<b>Note</b>	

**12.6.107 ETHernet:PORT<Pt>:STReam<St>:TCP:FURG**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FURG <enable>
<b>Description</b>	This command enables/disables the TCP URG flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FURG ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FURG?
<b>Description</b>	This query returns the TCP URG flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FURG? → 1
<b>Note</b>	

**12.6.108 ETHernet:PORT<Pt>:STReam<St>:TCP:FAck**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FAck <enable>
<b>Description</b>	This command enables/disables the TCP ACK flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FAck ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FAck?
<b>Description</b>	This query returns the TCP ACK flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FAck? → 1
<b>Note</b>	

**12.6.109 ETHernet:PORT<Pt>:STReam<St>:TCP:FPSH**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FPSH <enable>
<b>Description</b>	This command enables/disables the TCP PSH flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FPSH ON
<b>Note</b>	



<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FPSH?
<b>Description</b>	This query returns the TCP PSH flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FPSH? → 1
<b>Note</b>	

### 12.6.110 ETHernet:PORT<Pt>:STReam<St>:TCP:FRST

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FRST <enable>
<b>Description</b>	This command enables/disables the TCP RST flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FRST ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FRST?
<b>Description</b>	This query returns the TCP RST flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FRST? → 1
<b>Note</b>	

### 12.6.111 ETHernet:PORT<Pt>:STReam<St>:TCP:FSYN

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FSYN <enable>
<b>Description</b>	This command enables/disables the TCP SYN flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FSYN ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FSYN?
<b>Description</b>	This query returns the TCP SYN flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FSYN? → 1
<b>Note</b>	

**12.6.112 ETHernet:PORT<Pt>:STReam<St>:TCP:FFIN**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FFIN <enable>
<b>Description</b>	This command enables/disables the TCP FIN flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:FFIN ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:FFIN?
<b>Description</b>	This query returns the TCP FIN flag.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:FFIN? → 1
<b>Note</b>	

**12.6.113 ETHernet:PORT<Pt>:STReam<St>:TCP:WINDow**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:WINDow <value>
<b>Description</b>	This command sets the TCP window size.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:WIND 1000
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:WINDow?
<b>Description</b>	This query returns the TCP window size.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:WIND? → 1000
<b>Note</b>	

**12.6.114 ETHernet:PORT<Pt>:STReam<St>:TCP:UPOinter**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:UPOinter <value>
<b>Description</b>	This command sets the TCP urgent pointer.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:TCP:UPO 1000
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:UPOinter?
<b>Description</b>	This query returns the TCP urgent pointer.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:UPO? → 1000
<b>Note</b>	

### 12.6.115 ETHernet:PORT<Pt>:STReam<St>:TCP:CHECKsum?

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:TCP:CHECKsum?
<b>Description</b>	This query returns the checksum field in the TCP header.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<length> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:TCP:CHEC? → #HA2E3
<b>Note</b>	

### 12.6.116 ETHernet:PORT<Pt>:STReam1:BER:UTGenerator

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:UTGenerator <enable>
<b>Description</b>	This command enables/disables automatic start of the transmitter when running a BER measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:UTG ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:UTGenerator?
<b>Description</b>	This query return if the transmitter automatically starts when running a BER measurement.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:UTG? → 1
<b>Note</b>	

### 12.6.117 ETHernet:PORT<Pt>:STReam1:BER:SEQUence

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SEQUence <enable>
<b>Description</b>	This command enables/disables sequence checking when using unframed Ethernet.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SEQ ON
<b>Note</b>	This is only valid when FRAMed is OFF.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SEQUence?
<b>Description</b>	This query returns if sequence checking is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SEQ? → 1
<b>Note</b>	

**12.6.118 ETHernet:PORT<Pt>:STReam1:BER:SDMeasure[:ENABled]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure[:ENABled] <enable>
<b>Description</b>	This command enables/disables Service Disruption Measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SDM ON
<b>Note</b>	This is only valid when FRAMED is ON.

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure[:ENABled]?
<b>Description</b>	This query returns if Service Disruption Measurement is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SDM? → 1
<b>Note</b>	

**12.6.119 ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:DTYPe**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:DTYPe <type>
<b>Description</b>	This command sets the Disruption Type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> PACK: Packet LOS: Loss of Signal
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:DTYP PACK
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:DTYPe?
<b>Description</b>	This query returns the Disruption Type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:DTYP? → PACK
<b>Note</b>	

**12.6.120 ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MLIMit**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MLIMit <value>
<b>Description</b>	This command sets the Max Limit. Unit: Microseconds.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 5000000, DEFault = 50000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:MLIM 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MLIMit?
<b>Description</b>	This query returns the Max Limit. Unit: Microseconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:MLIM? → 10
<b>Note</b>	

**12.6.121 ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MDISruption**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MDISruption <value>
<b>Description</b>	This command sets the Min Disruption Frames.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 5000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:MDIS 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:MDISruption?
<b>Description</b>	This query return the Min Disruption Frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:MDIS? → 5
<b>Note</b>	

**12.6.122 ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:EFPeriod**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:EFPeriod <value>
<b>Description</b>	This command sets the LOS Error Free Period. Unit: Milliseconds
<b>Parameters</b>	<Pt> = Port number <value> = <NR1 NUMERIC RESPONSE DATA> <i>MINimum = 0.1, MAXimum = 1000.0, DEFault = 10.0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:AFP 5.0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:SDMeasure:EFPeriod?
<b>Description</b>	This query return the LOS Error Free Period. Unit: Milliseconds
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:SDM:AFP? → 5.0
<b>Note</b>	

**12.6.123 ETHernet:PORT<Pt>:STReam1:BER:STHResholds[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:STHResholds[:ENABLE] <enable>
<b>Description</b>	This command enables/disables BER Sequence error thresholds.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:BER:STHR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:STHResholds[:ENABLE]?
<b>Description</b>	This query returns whether or not BER Sequence error thresholds are enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:STR1:BER:STHR? → 1
<b>Note</b>	

**12.6.124 ETHernet:PORT<Pt>:STReam1:BER:STHResholds:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:STHResholds:VALue <value>
<b>Description</b>	This command sets the Sequence errors threshold value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:BER:STHR:VAL 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam1:BER:STHResholds:VALue?
<b>Description</b>	This query returns the Sequence errors threshold value.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:BER:STHR:VAL? → 10
<b>Note</b>	

**12.6.125 ETHernet:PORT<Pt>:STReam<St>:PAYLoad**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:PAYLoad <pattern>
<b>Description</b>	This command sets stream payload pattern
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <pattern> = <CHARACTER PROGRAM DATA> FOX: 'Fox' pattern 5555: 'All-5s' pattern PRBS9: PRBS9 sequence PRBS11: PRBS11 sequence PRBS15: PRBS15 sequence PRBS20: PRBS20 sequence PRBS23: PRBS23 sequence PRBS29: PRBS29 sequence PRBS31: PRBS31 sequence HFTest: HF test pattern CRPAT: Compliant random Pattern JTPAT: Jitter tolerance pattern SPAT: Supply noise test sequence USER32BIT: 32 bit user defined pattern. USER16BIT: Obsolete. For CMA 3000 backward compatibility only. Same as USER32BIT. <i>DEFault = PRBS23</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:PAYL FOX
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:PAYLoad?
<b>Description</b>	This query returns the stream payload pattern
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:PAYL? → SPAT
<b>Note</b>	

**12.6.126 ETHernet:PORT<Pt>:STReam<St>:UP16**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UP16 <pattern>
<b>Description</b>	This command sets the 16 bit user pattern.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <pattern> = <STRING PROGRAM DATA> Valid characters: '0' and '1' The string must consist of 1 to 16 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UP16 "101101"
<b>Note</b>	This command is for backward compatibility only, and a query command is not available. Actually the new 32 bit user pattern is set by this command.

**12.6.127 ETHernet:PORT<Pt>:STReam<St>:UP32**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PAYLoad is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:UP32? → "01101"
<b>Note</b>	

**12.6.128 ETHernet:PORT<Pt>:STReam:PCMA**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam:PCMA <enable>
<b>Description</b>	This command set PRBS pattern for CMA 3000 compatibility.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR:PCMA ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam:PCMA?
<b>Description</b>	This query returns whether PRBS pattern for CMA 3000 compatibility.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR:PCMA? → 1
<b>Note</b>	

**12.6.129 ETHernet:PORT<Pt>:STReam:CROSPrbs**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam:CROSPrbs <enable>
<b>Description</b>	This command set Enable or Disable cross pattern by Frame by Frame.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFAult = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR:CROS ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam:CROSPrbs?
<b>Description</b>	This query returns Enable or Disable cross pattern by Frame by Frame.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR:CROS? → 1
<b>Note</b>	

**12.6.130 ETHernet:PORT<Pt>:STReam<St>:LATency**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency <enable>
<b>Description</b>	This command enables/disables stream latency measurement.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFAult=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:LAT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency?
<b>Description</b>	This query returns whether or not stream latency measurement is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:LAT? → 1
<b>Note</b>	

**12.6.131 ETHernet:PORT<Pt>:STReam<St>:JITTer**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer <enable>
<b>Description</b>	This command enables/disables stream jitter measurement.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFAult=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:JITT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer?
<b>Description</b>	This query returns whether or not stream jitter measurement is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:JITT? → 1
<b>Note</b>	



**12.6.132 ETHernet:PORT<Pt>:STReam<St>:FLOsS**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOsS <enable>
<b>Description</b>	This command enables/disables multistream frame loss measurement.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:FLOS ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOsS?
<b>Description</b>	This query returns whether or not multistream frame loss measurement is enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:FLOS? → 1
<b>Note</b>	

**12.6.133 ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables Frameloss thresholds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:FLOS:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not Frameloss thresholds are enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:STR1:FLOS:THR? → 1
<b>Note</b>	

**12.6.134 ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds:MODE**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOsS:THResholds:MODE <mode>
<b>Description</b>	This command sets the Frameloss thresholds mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <NUMERIC PROGRAM DATA> COUNT: Count RATE: Rate <i>DEFault=COUNT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:MODE COUNT
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:MODE? <mode>
<b>Description</b>	This query returns the Frameloss thresholds mode.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:MODE? → COUNT
<b>Note</b>	

### 12.6.135 ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:COUNT

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:COUNT <value>
<b>Description</b>	This command sets the Frameloss thresholds count value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:COUN 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:COUNT?
<b>Description</b>	This query returns the Frameloss thresholds count value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:COUN? → 100
<b>Note</b>	

### 12.6.136 ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:RATio

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:RATio <ratio>
<b>Description</b>	This command sets the Frameloss thresholds ratio% value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <ratio> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00000, MAXimum = 100.00000, DEFault = 0.00000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:RAT 10.00000
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:FLOs:THResholds:RATio?
<b>Description</b>	This query returns the Frameloss thresholds ratio% value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:FLOS:THR:RAT? → 10.00000
<b>Note</b>	

**12.6.137 ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables Latency thresholds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:LAT:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not Latency thresholds are enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:STR1:LAT:THR? → 1
<b>Note</b>	

**12.6.138 ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds:VALue <value>
<b>Description</b>	This command sets the Latency thresholds value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 429496729.5, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:LAT:THR:VAL 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:LATency:THResholds:VALue?
<b>Description</b>	This query returns the level for the Latency thresholds value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:LAT:THR:VAL? → 10
<b>Note</b>	

**12.6.139 ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds[:ENABle]**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables Jitter thresholds.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:STR1:JITT:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not Jitter thresholds are enabled.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:STR1:JITT:THR? → 1
<b>Note</b>	

#### 12.6.140 ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds:VALue

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds:VALue <value>
<b>Description</b>	This command sets the Jitter thresholds value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 429496729.5, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:JITT:THR:VAL 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:JITTer:THResholds:VALue?
<b>Description</b>	This query returns the Jitter thresholds value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:JITT:THR:VAL? → 10
<b>Note</b>	

#### 12.6.141 ETHernet:PORT<Pt>:STReam<St>:VARIABLE<No>:FIELD

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIABLE<No>:FIELD <protocol>
<b>Description</b>	This command sets the variable field protocol.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <protocol> = <CHARACTER PROGRAM DATA> OFF: OFF SMAC: Source MAC Address DMAC: Destination MAC Address VLANx: VLAN ID where x is the VLAN level (1-8) BTAG: B-Tag VID ITAG: I-Tag SID MPLSx: MPLS where x is the MPLS level (1-8) MIMDMAC: MiM Destination MAC Address EMDM: EoMPLS destination MAC Address MIMSMAC: MiM Source MAC Address EMSM: EoMPLS source MAC Address SIV4: Source IPv4 DIV4: Destination IPv4 SIV6: Source IPv6 DIV6: Destination IPv6 CUST: Custom Header <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:FIEL SMAC
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:FIEld?
<b>Description</b>	This query returns the variable field protocol.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<protocol> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:FIEL? → SMAC
<b>Note</b>	

### 12.6.142 ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:TYPE

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:TYPE <type>
<b>Description</b>	This command sets the variable field type.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <type> = <CHARACTER PROGRAM DATA> INCREMENT: Increment DECREMENT: Decrement RANDOM: Random <i>DEFault = INCREMENT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:TYPE INCREMENT
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:TYPE?
<b>Description</b>	This query returns the variable field type.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:TYPE? → INCREMENT
<b>Note</b>	

### 12.6.143 ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:OFFSet

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:OFFSet <offset>
<b>Description</b>	This command sets the variable field offset.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <offset> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 127, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:OFFS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:OFFSet?
<b>Description</b>	This query returns the variable field offset.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:OFFS? → 1
<b>Note</b>	

**12.6.144 ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:LENGth**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:LENGth <length>
<b>Description</b>	This command sets the variable field length.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 32, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:LENG 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:LENGth?
<b>Description</b>	This query returns the variable field length.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field Number (1-2)
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:LENG? → 1
<b>Note</b>	

**12.6.145 ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:STARt**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:STARt <start>
<b>Description</b>	This command sets the variable field start value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <start> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:STAR 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:STARt?
<b>Description</b>	This query returns the variable field start value.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<start> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:STAR? → 1
<b>Note</b>	

**12.6.146 ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:END**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARIable<No>:END <end>
<b>Description</b>	This command sets the variable field end value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <end> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:END 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARiable<No>:END?
<b>Description</b>	This query returns the variable field end value.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<end> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:END? → 10
<b>Note</b>	

### 12.6.147 ETHernet:PORT<Pt>:STReam<St>:VARiable<No>:STEP

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARiable<No>:STEP <step>
<b>Description</b>	This command sets the variable field step value.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2) <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 2147483648, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:VAR1:STEP 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:VARiable<No>:STEP?
<b>Description</b>	This query returns the variable field step value.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16) <No> = Variable field number (1-2)
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:VAR1:STEP? → 1
<b>Note</b>	

### 12.6.148 ETHernet:PORT<Pt>:STReam<St>:CUSTom:LENGth

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:CUSTom:LENGth <length>
<b>Description</b>	This command sets the custom header length.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 2, MAXimum = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:CUST:LENG 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:CUSTom:LENGth?
<b>Description</b>	This query returns the custom header length.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STR1:CUST:LENG? → 2
<b>Note</b>	

**12.6.149 ETHernet:PORT<Pt>:STReam<St>:CUSTom:DATA**

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:CUSTom:DATA <data>
<b>Description</b>	This command sets the custom header data.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <data> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STR1:CUST:DAT "33FF0011"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STReam<St>:CUSTom:DATA?
<b>Description</b>	This query returns the custom header data.
<b>Parameter</b>	<Pt> = Port number <St> = Stream number (1-16)
<b>Response</b>	<data> = <STRING PROGRAM DATA>
<b>Example</b>	ETH:PORT1:STR1:CUST:DAT? → "33FF0011"
<b>Note</b>	



## 12.7 Settings

### 12.7.1 ETHernet:PORT<Pt>:SETTings:AARP

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:AARP <enable>
<b>Description</b>	This command enables/disables answering incoming ARP requests.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:AARP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:AARP?
<b>Description</b>	This query returns the state of answering incoming ARP requests.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:AARP? → 1
<b>Note</b>	

### 12.7.2 ETHernet:PORT<Pt>:SETTings:ANDP

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ANDP <enable>
<b>Description</b>	This command enables/disables answering incoming NDP requests.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:ANDP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ANDP?
<b>Description</b>	This query returns enables/disables answering incoming NDP requests.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:ANDP? → 1
<b>Note</b>	

### 12.7.3 ETHernet:PORT<Pt>:SETTings:APINg

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:APINg <enable>
<b>Description</b>	This command enables/disables answering incoming PING requests.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:APIN ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:APINg?
<b>Description</b>	This query returns the state of answering incoming PING requests.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:APIN? → 1
<b>Note</b>	

## 12.7.4 ETHernet:PORT&lt;Pt&gt;:SETTings:ACMA

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ACMA <enable>
<b>Description</b>	This command enables/disables answering incoming Network Master configuration frames.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:ACMA ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ACMA?
<b>Description</b>	This query returns the state of answering incoming Network Master configuration frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:ACMA? → 1
<b>Note</b>	

## 12.7.5 ETHernet:PORT&lt;Pt&gt;:SETTings:PLENenght

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:PLENenght <length>
<b>Description</b>	This command sets the expected preamble length at 1Gbps and lower speeds.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 15, DEFault = 8</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:PLEN 8
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:PLENenght?
<b>Description</b>	This query returns the expected preamble length at 1Gbps and lower speeds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:PLEN? → 8
<b>Note</b>	

## 12.7.6 ETHernet:PORT&lt;Pt&gt;:SETTings:IPViolations

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:IPViolations <enable>
<b>Description</b>	This command sets ignore preamble violations.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:IPV ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:IPViolations?
<b>Description</b>	This query returns ignore preamble violations.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:IPV? → 1
<b>Note</b>	

### 12.7.7 ETHernet:PORT<Pt>:SETTings:ILThreshold

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ILThreshold <length>
<b>Description</b>	This command sets the IFG lower threshold.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 8, MAXimum = 27, DEFault = 12</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:ILT 12
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ILThreshold?
<b>Description</b>	This query returns the IFG lower threshold.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:ILT? → 12
<b>Note</b>	

### 12.7.8 ETHernet:PORT<Pt>:SETTings:FIViolations

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:FIViolations <enable>
<b>Description</b>	This command enables/disables filter IFG violations caused by master/slave clock synchronization.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:FIV ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:FIViolations?
<b>Description</b>	This query returns the state of filter IFG violations caused by master/slave clock synchronization.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:FIV? → 1
<b>Note</b>	

### 12.7.9 ETHernet:PORT<Pt>:SETTings:JFSize

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:JFSize <length>
<b>Description</b>	This command sets the jumbo frame size upper limit.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 9018</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:JFS 9018
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:JFSize?
<b>Description</b>	This query returns the jumbo frame size upper limit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:JFS? → 9018
<b>Note</b>	

## 12.7.10 ETHernet:PORT&lt;Pt&gt;:SETTings:FRESults

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:FRESults <format>
<b>Description</b>	This command sets the format of the results.
<b>Parameters</b>	<Pt> = Port number <format> = <CHARACTER PROGRAM DATA> SI: SI prefix notation ENG: Engineering exponent notation SCI: Scientific exponent notation UNF: Unformatted <i>DEFault = SI</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:FRES ENG
<b>Note</b>	This only affects the GUI and reports. This setting applies to all ports.

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:FRESults?
<b>Description</b>	This query returns the format of the results.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<format> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:FRES? → ENG
<b>Note</b>	This setting applies to all ports.

## 12.7.11 ETHernet:PORT&lt;Pt&gt;:SETTings:ACISetup

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ACISetup <enable>
<b>Description</b>	This command enables/disables allow changes to interface setup while measuring.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:ACIS ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ACISetup?
<b>Description</b>	This query returns the state of allow changes to interface setup while measuring.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:ACIS? → 1
<b>Note</b>	

## 12.7.12 ETHernet:PORT&lt;Pt&gt;:SETTings:ASTGenerator

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ASTGenerator <enable>
<b>Description</b>	This command enables/disables automatically start the traffic generator when measurement is started.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:ASTG ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:ASTGenerator?
<b>Description</b>	This query returns the state of automatically start the traffic generator when measurement is started.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:ASTG? → 1
<b>Note</b>	

### 12.7.13 ETHernet:PORT<Pt>:SETTings:BER:OBAMeasuring

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:OBAMeasuring <enable>
<b>Description</b>	This command enables/disables only show BER alarms when measuring.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:BER:OBAM ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:OBAMeasuring?
<b>Description</b>	This query returns if BER alarms should only be shown when measuring.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:BER:OBAM? → 1
<b>Note</b>	This setting applies to all ports.

### 12.7.14 ETHernet:PORT<Pt>:SETTings:BER:IAFFilter

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:IAFFilter <enable>
<b>Description</b>	This command enables/disables include addresses in frame filter on receiver.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:BER:IAFF OFF
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:IAFFilter?
<b>Description</b>	This query returns if include addresses in frame filter on receiver is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:BER:IAFF? → 0
<b>Note</b>	This setting applies to all ports.

### 12.7.15 ETHernet:PORT<Pt>:SETTings:BER:CLFrames

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:CLFrames <enable>
<b>Description</b>	This command enables/disables count lost frames as pattern errors.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:BER:CLF ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:CLFrames?
<b>Description</b>	This query return if count lost frames as pattern errors is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:BER:CLF? → 1
<b>Note</b>	This setting applies to all ports.

### 12.7.16 ETHernet:PORT<Pt>:SETTings:BER:HIDeframeloss

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:HIDeframeloss <enable>
<b>Description</b>	This command show/hide Frame loss secs. count.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SETT:BER:HID ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PORT<Pt>:SETTings:BER:HIDeframeloss?
<b>Description</b>	This query return if Frame loss secs. count is show/hide.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SETT:BER:HID? → 1
<b>Note</b>	This setting applies to all ports.

## 12.8 Filter

Generally eight separate filters are available for each port of the instrument. In the following section these filters are identified using the :FILTer<Ft> program mnemonic, where <Ft> = Filter number (1-8).

### 12.8.1 ETHernet:PORT<Pt>:FILTer[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer[:ENABle] <enable>
<b>Description</b>	This command enables/disables filtering.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT ON
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:FILTer

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer[:ENABle]?
<b>Description</b>	This query returns whether or not filtering is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:FILT? → 1
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:FILTer?

### 12.8.2 ETHernet:PORT<Pt>:FILTer:RESet

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:RESet
<b>Description</b>	This command resets the filter settings to the default values.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:FILT:RES
<b>Note</b>	Note this does not change ETHernet:PORT<Pt>:FILTer[:ENABle]

### 12.8.3 ETHernet:PORT<Pt>:FILTer:ENCapsulation

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:ENCapsulation <ether-type>, <snap>, <llc>
<b>Description</b>	This command sets the allowed encapsulation types.
<b>Parameters</b>	<Pt> = Port number <ether-type> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i> <snap> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i> <llc> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:FILT:ENC ON, OFF, ON
<b>Notes</b>	Setting all off will disable the encapsulation filter. For the encapsulation filter to be active, at least one of the eight available general filters must be enabled. The general filters are enabled using the ETHernet:PORT<Pt>:FILTer:FILTer<Ft>[:ENABle] command (see 12.8.5).

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:ENCapsulation?
<b>Description</b>	This query returns the allowed encapsulation types.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ether-type> = <BOOLEAN RESPONSE DATA>
	<snap> = <BOOLEAN RESPONSE DATA>
	<llc> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:ENC? → 1, 0, 1
<b>Note</b>	

#### 12.8.4 ETHernet:PORT<Pt>:FILTer:PROTOcols

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:PROTOcols <type>,<filter>[,<mask>]	
<b>Description</b>	This commands enables/disables protocol type filters and masks.	
<b>Parameters</b>	<Pt> = Port number	
	<type> = <CHARACTER PROGRAM DATA> DMAC: Destination MAC Address SMAC: Source MAC Address VLANx: VLAN ID where x is the VLAN level (1-8) BTAG: MiM B-Tag ITAG: MiM I-Tag MIMDMAC: MiM Destination MAC Address MIMSMAC: MiM Source MAC Address MPLSx: MPLS where x is the MPLS level (1-8) EMDM: EoMPLS destination MAC Address EMSM: EoMPLS source MAC Address SIV4: Source IPv4 DIV4: Destination IPv4 POFF: Pattern/Offset DPOR: Destination TCP/UDP port SIV6: Source IPv6 HIV6: Hop destination IPv6 FIV6: Final destination IPv6 SPOR: Source TCP/UDP port	
	<filter> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>	
	<mask> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>	
	<b>Response</b>	None.
	<b>Examples</b>	ETH:PORT1:FILT:PROT MPLS4, ON ETH:PORT1:FILT:PROT MPLS4, ON, ON
	<b>Note</b>	<mask> can only be enabled if <filter> is enabled.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:PROTOcols? <type>
<b>Description</b>	This query returns if the protocol type filters and masks are enabled/disabled.
<b>Parameters</b>	<Pt> = Port number
	<type> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<filter> = <BOOLEAN RESPONSE DATA>
	<mask> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:PROT? MPLS4 → 1, 1
<b>Note</b>	



### 12.8.5 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>[:ENABle] <enable>
<b>Description</b>	This command enables/disables the specific filter.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) (see 12.8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFAult = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1 ON
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:FILTer:FILTer<Ft>

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>[:ENABle]?
<b>Description</b>	This query returns whether or not the specific filter is enabled.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:FILT:FILT1? → 1
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:FILTer:FILTer<Ft>?

### 12.8.6 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SMAC <filter>[,<mask>]
<b>Description</b>	This command sets the MAC source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:SMAC "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:SMAC "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SMAC?
<b>Description</b>	This query returns the MAC source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:SMAC? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

### 12.8.7 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DMAC <filter>[,<mask>]
<b>Description</b>	This command sets the MAC destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:DMAC "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:DMAC "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DMAC?
<b>Description</b>	This query returns the MAC destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:DMAC? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

### 12.8.8 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMSMac

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMSMac <filter>[,<mask>]
<b>Description</b>	This command sets the EoMPLS MAC source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:EMSM "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:EMSM "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMSMac?
<b>Description</b>	This query returns the EoMPLS MAC source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:EMSM? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

### 12.8.9 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMDMac

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMDMac <filter>[,<mask>]
<b>Description</b>	This command sets the EoMPLS MAC destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:EMDM "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:EMDM "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:EMDMac?
<b>Description</b>	This query returns the EoMPLS MAC destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:EMDM? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

## 12.8.10 ETHernet:PORT&lt;Pt&gt;:FILTer:POFFset

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:POFFset <offset>
<b>Description</b>	This commands sets the pattern offset for the pattern filter.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 15956, DEFault = 2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:FILT:POFF 3
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:POFFset?
<b>Description</b>	This query returns the pattern offset for the pattern filter.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:POFF? → 3
<b>Note</b>	

## 12.8.11 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:PATtern

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:PATtern <filter>[,<mask>]
<b>Description</b>	This command sets the Pattern filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 2<sup>32</sup> - 1, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 2<sup>32</sup> - 1, DEFault = 0</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:PATT 170 ETH:PORT1:FILT:FILT1:PATT #HAA, #HFF
<b>Note</b>	If the pattern is shorter than 32 bit it will be padded with '0' until a length of 32 bit is reached. (e.i., "101" becomes "000000000000000000000000000000101")

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:PATtern?
<b>Description</b>	This query returns the Pattern filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:PATT? → 170, 256
<b>Note</b>	

## 12.8.12 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:SPORT

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SPORT <filter>[,<mask>]
<b>Description</b>	This command sets the TCP/UDP source port filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 65535</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:SPOR 81 ETH:PORT1:FILT:FILT1:SPOR 1, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SPORt?
<b>Description</b>	This query returns the TCP/UDP source port filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:SPOR? → 1,1
<b>Note</b>	

### 12.8.13 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DPORT

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DPORT <filter>[,<mask>]
<b>Description</b>	This command sets the TCP/UDP destination port filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 65535, DEFault = 0</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:DPOR 81 ETH:PORT1:FILT:FILT1:DPOR 1,1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DPORT?
<b>Description</b>	This query returns the TCP/UDP destination port filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:DPOR? → 1,1
<b>Note</b>	

### 12.8.14 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV4

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV4 <filter>[,<mask>]
<b>Description</b>	This command sets the IPv4 source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:SIV4 "192.168.0.1" ETH:PORT1:FILT:FILT1:SIV4 "192.168.0.1", "255.255.0.0"
<b>Note</b>	Only the character '.' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV4?
<b>Description</b>	This query returns the IPv4 source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:SIV4? → "192.168.0.1", "255.255.0.0"
<b>Note</b>	

## 12.8.15 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:DIV4

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DIV4 <filter>[,<mask>]
<b>Description</b>	This command sets the IPv4 destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:DIV4 "192.168.0.1" ETH:PORT1:FILT:FILT1:DIV4 "192.168.0.1", "255.255.0.0"
<b>Note</b>	Only the character '.' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:DIV4?
<b>Description</b>	This query returns the IPv4 destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:DIV4? → "192.168.0.1", "255.255.0.0"
<b>Note</b>	

## 12.8.16 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:SIV6

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV6 <filter>[,<mask>]
<b>Description</b>	This command sets the IPv6 source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:SIV6 "2002:0000:0000:0000:0000:0000:0000:001F" ETH:PORT1:FILT:FILT1:SIV6 "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	Only the character '.' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:SIV6?
<b>Description</b>	This query returns the IPv6 source filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:SIV6? → "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	

## 12.8.17 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:HIV6

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:HIV6 <filter>[,<mask>]
<b>Description</b>	This command sets the IPv6 hop destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:HIV6 "2002:0000:0000:0000:0000:0000:0000:001F" ETH:PORT1:FILT:FILT1:HIV6 "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	Only the character '?' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:HIV6?
<b>Description</b>	This query returns the IPv6 hop destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:HIV6? → "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	

## 12.8.18 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:FIV6

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:FIV6 <filter>[,<mask>]
<b>Description</b>	This command sets the IPv6 final destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:FIV6 "2002:0000:0000:0000:0000:0000:0000:001F" ETH:PORT1:FILT:FILT1:FIV6 "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	Only the character '?' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:FIV6?
<b>Description</b>	This query returns the IPv6 final destination filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:FIV6? → "2002:0000:0000:0000:0000:0000:0000:0000", "FFFF:0000:0000:0000:0000:0000:0000:0000"
<b>Note</b>	

## 12.8.19 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MPLS&lt;Lv&gt;:LABel

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:LABel <filter>[,<mask>]
<b>Description</b>	This command sets the MPLS level filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 1048575, DEFault = 0 <mask> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 1048575, DEFault = 1048575
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MPLS1:LAB 10 ETH:PORT1:FILT:FILT1:MPLS1:LAB 10, 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:LABel?
<b>Description</b>	This query returns the MPLS level filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MPLS1:LAB? → 10,10
<b>Note</b>	

## 12.8.20 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MPLS&lt;Lv&gt;:EBITs

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:EBITs <filter>[,<mask>]
<b>Description</b>	This command sets the MPLS experimental bits filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 7, DEFault = 0 <mask> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 7, DEFault = 7
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MPLS1:EBIT 3 ETH:PORT1:FILT:FILT1:MPLS1:EBIT 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:EBITs?
<b>Description</b>	This query returns the MPLS experimental bits filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MPLS1:EBIT? → 3,1
<b>Note</b>	

## 12.8.21 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MPLS&lt;Lv&gt;:BOLStack

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:BOLStack <filter>[,<mask>]
<b>Description</b>	This command sets the MPLS bottom of label stack filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MPLS1:BOLS 1 ETH:PORT1:FILT:FILT1:MPLS1:BOLS 1, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:BOLStack?
<b>Description</b>	This query returns the MPLS bottom of label stack filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MPLS1:BOLS? → 1,1
<b>Note</b>	

## 12.8.22 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MPLS&lt;Lv&gt;:TTL

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:TTL <filter>[,<mask>]
<b>Description</b>	This command sets the MPLS TTL filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 255, DEFault = 255</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MPLS1:TTL 3 ETH:PORT1:FILT:FILT1:MPLS1:TTL 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MPLS<Lv>:TTL?
<b>Description</b>	This query returns the MPLS TTL filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MPLS1:TTL? → 3,1
<b>Note</b>	



## 12.8.23 ETHernet:PORT&lt;Pt&gt;:FILTER:FILTER&lt;Ft&gt;:VLAN&lt;Lv&gt;:ID

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:ID <filter>[,<mask>]
<b>Description</b>	This command sets the VLAN ID filter and mask.
<b>Parameters</b>	<Pt> = Port number
	<Ft> = Filter number (1-8)
	<Lv> = Level number (1-8)
	<filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 0</i>
	<mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 4095</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:VLAN1:ID 3 ETH:PORT1:FILT:FILT1:VLAN1:ID 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:ID?
<b>Description</b>	This query returns the VLAN ID filter and mask.
<b>Parameters</b>	<Pt> = Port number
	<Ft> = Filter number (1-8)
	<Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA>
	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:VLAN1:ID? → 3,1
<b>Note</b>	

## 12.8.24 ETHernet:PORT&lt;Pt&gt;:FILTER:FILTER&lt;Ft&gt;:VLAN&lt;Lv&gt;:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:CFI <filter>[,<mask>]
<b>Description</b>	This command sets the VLAN CFI filter and mask.
<b>Parameters</b>	<Pt> = Port number
	<Ft> = Filter number (1-8)
	<Lv> = Level number (1-8)
	<filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 0</i>
	<mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:VLAN1:CFI 1 ETH:PORT1:FILT:FILT1:VLAN1:CFI 1, 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:CFI?
<b>Description</b>	This query returns the VLAN CFI filter and mask.
<b>Parameters</b>	<Pt> = Port number
	<Ft> = Filter number (1-8)
	<Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA>
	<mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:VLAN1:CFI? → 3,1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:VLAN<Lv>:DEI?

## 12.8.25 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:VLAN&lt;Lv&gt;:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:DEI <filter>[,<mask>]
<b>Description</b>	This command sets the VLAN DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 1, DEFault = 0 <mask> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 1, DEFault = 1
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:VLAN1:DEI 1 ETH:PORT1:FILT:FILT1:VLAN1:DEI 1, 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:DEI?
<b>Description</b>	This query returns the VLAN DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:VLAN1:DEI? → 3,1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:CFI?

## 12.8.26 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:VLAN&lt;Lv&gt;:PRiority

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:PRiority <filter>[,<mask>]
<b>Description</b>	This command sets the VLAN priority filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8) <filter> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 7, DEFault = 0 <mask> = <NUMERIC PROGRAM DATA> MINimum = 0, MAXimum = 7, DEFault = 7
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:VLAN1:PR 3 ETH:PORT1:FILT:FILT1:VLAN1:PR 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:VLAN<Lv>:PRiority?
<b>Description</b>	This query returns the VLAN priority filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <Lv> = Level number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:VLAN1:PR? → 3,1
<b>Note</b>	

## 12.8.27 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MMSMac

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMSMac <filter>[,<mask>]
<b>Description</b>	This command sets the MiM source MAC address filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMSM "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:MMSM "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMSMac?
<b>Description</b>	This query returns the MiM source MAC address filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMSM? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

## 12.8.28 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MMDMac

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMDMac <filter>[,<mask>]
<b>Description</b>	This command sets the MIM destination MAC filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <STRING PROGRAM DATA> <mask> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMDM "00-50-C2-35-D2-EF" ETH:PORT1:FILT:FILT1:MMDM "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMDMac?
<b>Description</b>	This query returns the MIM destination MAC filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <STRING RESPONSE DATA> <mask> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMDM? → "00-50-C2-35-D2-EF", "FF-FF-FF-FF-FF-FF"
<b>Note</b>	

## 12.8.29 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MMBTAG:ID

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:ID <filter>[,<mask>]
<b>Description</b>	This command sets the MiM B-Tag VLAN ID filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 4095</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMBTAG:ID 3 ETH:PORT1:FILT:FILT1:MMBTAG:ID 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:ID?
<b>Description</b>	This query returns the MiM B-Tag VLAN ID filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMBTAG:ID? → 3,1
<b>Note</b>	

### 12.8.30 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:PRiority

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:PRiority <filter>[,<mask>]
<b>Description</b>	This command sets the MiM B-Tag Priority (PCP) filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 7</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMBTAG:PR 3 ETH:PORT1:FILT:FILT1:MMBTAG:PR 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:PRiority?
<b>Description</b>	This query returns the MiM B-Tag Priority (PCP) filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMBTAG:PR? → 3,1
<b>Note</b>	

### 12.8.31 ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:DEI <filter>[,<mask>]
<b>Description</b>	This command sets the MiM B-Tag DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMBTAG:DEI 1 ETH:PORT1:FILT:FILT1:MMBTAG:DEI 1, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMBTAG:DEI?
<b>Description</b>	This query returns the MiM B-Tag DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMBTAG:DEI? → 1,1
<b>Note</b>	

**12.8.32 ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:ID**

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:ID <filter>[,<mask>]
<b>Description</b>	This command sets the MiM I-Tag Service ID filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 16777215, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 16777215, DEFault = 16777215</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMITAG:ID 3 ETH:PORT1:FILT:FILT1:MMITAG:ID 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:ID?
<b>Description</b>	This query returns the MiM I-Tag Service ID filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMITAG:ID? → 3,1
<b>Note</b>	

**12.8.33 ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:PRIORITY**

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:PRIORITY <filter>[,<mask>]
<b>Description</b>	This command sets the MiM I-Tag Priority (PCP) filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 7</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMITAG:PR 3 ETH:PORT1:FILT:FILT1:MMITAG:PR 3, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTER:FILTER<Ft>:MMITAG:PRIORITY?
<b>Description</b>	This query returns the MiM I-Tag Priority (PCP) filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMITAG:PR? → 3,1
<b>Note</b>	

## 12.8.34 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MMITAG:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:DEI <filter>[,<mask>]
<b>Description</b>	This command sets the MiM I-Tag DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMITAG:DEI 1 ETH:PORT1:FILT:FILT1:MMITAG:DEI 1, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:DEI?
<b>Description</b>	This query returns the MiM I-Tag DEI filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMITAG:DEI? → 1,1
<b>Note</b>	

## 12.8.35 ETHernet:PORT&lt;Pt&gt;:FILTer:FILTer&lt;Ft&gt;:MMITAG:UCA

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:UCA <filter>[,<mask>]
<b>Description</b>	This command sets the MiM I-Tag UCA filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8) <filter> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 0</i> <mask> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:FILT:FILT1:MMITAG:UCA 1 ETH:PORT1:FILT:FILT1:MMITAG:UCA 1, 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FILTer:FILTer<Ft>:MMITAG:UCA?
<b>Description</b>	This query returns the MiM I-Tag UCA filter and mask.
<b>Parameters</b>	<Pt> = Port number <Ft> = Filter number (1-8)
<b>Response</b>	<filter> = <NR1 NUMERIC RESPONSE DATA> <mask> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:FILT:FILT1:MMITAG:UCA? → 1,1
<b>Note</b>	

## 12.9 Thresholds

### 12.9.1 ETHernet:PORT<Pt>:THResholds[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables thresholds.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:PORT1:THR ON
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:THResholds

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not thresholds are enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	ETH:PORT1:THR? → 1
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:THResholds?

### 12.9.2 ETHernet:PORT<Pt>:THResholds:SElect

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds:SElect <type>, <enable>
<b>Description</b>	This command enables/disables the specific threshold type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> ALL: All thresholds UTIL: Utilization THR: Throughput ERR: Errored frames  Measurement thresholds: COL: Collision rate UNI: Unicast frames MULTI: Multicast frames BROAD: Broadcast frames PAUSE: Pause frames FRAG: Fragmented frames UNDER: Undersized frames OVER: Oversized frames FCS: FCS errored frames IFG: IFG violations PRE: Preamble violations DIFF: Difference Tx-Rx DIFFO: Same as DIFF OVRFCSErr: Oversized & FCS Errored frames IPCHKSUM: IP checksum errored frames  <i>DEFault = ALL</i> <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:THR:SEL UTIL, ON
<b>Note</b>	Measurement thresholds are only active when a measurement is running.

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds:SElect? <type>
<b>Description</b>	This query returns whether or not the specific threshold type is enabled.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:THR:SEL? UTIL → 1
<b>Note</b>	

### 12.9.3 ETHernet:PORT<Pt>:THResholds:VALue

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds:VALue <type>, <compare>, <value>
<b>Description</b>	This command sets the level for the specific threshold type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> UTIL: Utilization <sup>1</sup> THR: Throughput <sup>2</sup> ERR: Errored frames  Measurement thresholds: COL: Collision rate UNI: Unicast frames MULTI: Multicast frames BROAD: Broadcast frames PAUSE: Pause frames FRAG: Fragmented frames UNDER: Undersized frames OVER: Oversized frames FCS: FCS errored frames IFG: IFG violations PRE: Preamble violations DIFF: Difference Tx-Rx <sup>3</sup> DIFFO: Same as DIFF OVRFCSErr: Oversized & FCS Errored frames IPCHKSUM: IP checksum errored frames  <compare> = <CHARACTER PROGRAM DATA> GT: Greater than LT: Less than GTEQ: Greater than or equal to LTEQ: Less than or equal to <i>DEFAult = LT</i>  <value> = <NUMERIC PROGRAM DATA> Absolute values: Decimals are rounded. Maximum is 4000000000 Percentage values: Allows one decimal, Maximum is 100.0 <i>DEFAult = 0, MINimum = 0</i> <i>Allowed Suffixes = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:THR:VAL UTIL, GT, 10.5PCT
<b>Notes</b>	Measurement thresholds are only active when a measurement is running. <sup>1</sup> Utilization only supports percentage values. <sup>2</sup> Throughput only supports absolute values, the unit is MBPS, and has one decimal. Maximum = 10000.0 <sup>3</sup> Difference only supports absolute count values.



---

<b>Syntax</b>	ETHernet:PORT<Pt>:THResholds:VALue? <type>
<b>Description</b>	This query returns the level for the specific threshold type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<compare> = <CHARACTER RESPONSE DATA> <value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:THR:VAL? UTIL → GT, 10.5PCT
<b>Note</b>	

## 12.10 SyncE

### 12.10.1 ETHernet:SYNCe:PTHRough:FCAPture

<b>Syntax</b>	ETHernet:SYNCe:PTHRough:FCAPture <enable>
<b>Description</b>	This command enables/disables SyncE frame capture when the ports are in pass-through mode.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SYNC:PTHR:FCAP OFF
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:SYNCe:PTHRough:FCAPture?
<b>Description</b>	This query returns whether or not SyncE frame capture is enabled when the ports are in pass-through mode.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SYNC:PTHR:FCAP? → 0
<b>Note</b>	This command can be used on V2.00 or later

### 12.10.2 ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel[:ENABLE] <enable>
<b>Description</b>	This command enables/disables modification of quality level in SSM messages.
<b>Parameters</b>	<Pt> = Port number Port number 1 denotes messages passing from port 1 to port 2 Port number 2 denotes messages passing from port 2 to port 1 <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:PTHR:QLEV OFF
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel[:ENABLE]?
<b>Description</b>	This query returns whether or not modification of quality level in SSM messages is enabled.
<b>Parameter</b>	<Pt> = Port number Port number 1 denotes messages passing from port 1 to port 2 Port number 2 denotes messages passing from port 2 to port 1
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:PTHR:QLEV? → 0
<b>Note</b>	This command can be used on V2.00 or later

### 12.10.3 ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel:USER

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel:USER <level>
<b>Description</b>	This command sets the quality level to be inserted in SSM messages.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:PTHR:QLEV:USER 0
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:PTHRough:QLEVel:USER?
<b>Description</b>	This query returns the quality level to be inserted in SSM messages.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:PTHR:QLEV:USER? → 0
<b>Note</b>	This command can be used on V2.00 or later

#### 12.10.4 ETHernet:PORT<Pt>:SYNCe[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe[:ENABLE] <enable>
<b>Description</b>	This command enables/disables SyncE for the port.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC ON
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:SYNCe

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe[:ENABLE]?
<b>Description</b>	This query returns whether or not SyncE is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC? → 1
<b>Note</b>	

#### 12.10.5 ETHernet:PORT<Pt>:SYNCe:MODE

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MODE <mode>
<b>Description</b>	This command set the SyncE operation mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> MONitor : Non-synchronous/Monitor-only mode SYNCronous : Active synchronous mode <i>DEFault = MONitor</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:MODE MON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MODE?
<b>Description</b>	This query returns the SyncE operation mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:MODE? → SYNC
<b>Note</b>	

#### 12.10.6 ETHernet:PORT<Pt>:SYNCe:FCAPture

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:FCAPture <enable>
<b>Description</b>	This command enables/disables SyncE frame capture.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:FCAP OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:FCAPture?
<b>Description</b>	This query returns whether or not SyncE frame capture is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:FCAP? → 1
<b>Note</b>	

### 12.10.7 ETHernet:PORT<Pt>:SYNCe:QLEVel

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:QLEVel <qualityLevel>
<b>Description</b>	This command sets the quality level of the transmitter clock.
<b>Parameters</b>	<Pt> = Port number <qualityLevel> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=15, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:QLEV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:QLEVel?
<b>Description</b>	This query returns configured clock quality level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<qualityLevel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:QLEV? → 0
<b>Note</b>	

### 12.10.8 ETHernet:PORT<Pt>:SYNCe:MAC

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MAC <address>
<b>Description</b>	This command sets the MAC source address for transmitted ESMC messages.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:MAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MAC?
<b>Description</b>	This query returns the MAC source address for transmitted ESMC messages.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:MAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

### 12.10.9 ETHernet:PORT<Pt>:SYNCe:MAC:AUTO

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MAC:AUTO <automatic>
<b>Description</b>	This command enables/disables automatic generation of source MAC address.
<b>Parameters</b>	<Pt> = Port number <automatic> = <CHARACTER PROGRAM DATA> ON: Lock the MAC parameter to the value of default MAC source address. OFF: Unlock the MAC parameter value. <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:MAC:AUTO ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:MAC:AUTO?
<b>Description</b>	This query returns whether or not automatic generation of source MAC address is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<automatic> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:MAC:AUTO? → ON
<b>Note</b>	

### 12.10.10 ETHernet:PORT<Pt>:SYNCe:EFLag

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:EFLag <behavior>
<b>Description</b>	This command set the SyncE Event flag behavior.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> DYNamic : Event flag bit is dynamically set ST0 : Event flag bit is set to 0 ST1 : Event flag bit is set to 1 <i>DEFault = DYNamic</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:SYNC:EFL DYN
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:SYNCe:EFLag?
<b>Description</b>	This query returns the SyncE Event flag behavior.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:SYNC:EFL? → DYN
<b>Note</b>	

## 12.11 Precision Time Protocol - IEEE 1588v2

### 12.11.1 ETHernet:PORT<Pt>:PTP[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the Precision Time Protocol.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP ON
<b>Note</b>	This is the default node for ETHernet:PORT<Pt>:PTP

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP[:ENABLE]?
<b>Description</b>	This query returns whether or not the Precision Time Protocol is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP? → 1
<b>Note</b>	

### 12.11.2 ETHernet:PORT<Pt>:PTP:SONLy

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:SONLy <enable>
<b>Description</b>	This command enables/disables slave only clock mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:SONL ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:SONLy?
<b>Description</b>	This query returns whether or not slave only clock mode is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:SONL? → 1
<b>Note</b>	

### 12.11.3 ETHernet:PORT<Pt>:PTP:CAST

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CAST <cast>
<b>Description</b>	This command sets the multicast/unicast mode.
<b>Parameters</b>	<Pt> = Port number <cast> = <CHARACTER PROGRAM DATA> MULTicast: Multicast mode UNICast: Unicast mode <i>DEFault = UNICast</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CAST DEF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CAST?
<b>Description</b>	This query returns the multicast/unicast mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<cast> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CAST? → MULT
<b>Note</b>	

**12.11.4 ETHernet:PORT<Pt>:PTP:UNEGotiate**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:UNEGotiate <enable>
<b>Description</b>	This command enables/disables unicast negotiate mode.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault</i> = <i>ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:UNEG ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:UNEGotiate?
<b>Description</b>	This query returns whether or not unicast negotiate mode is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:UNEG? → 1
<b>Note</b>	

**12.11.5 ETHernet:PORT<Pt>:PTP:PROFile**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:PROFile <profile>
<b>Description</b>	This command sets the PTP profile.
<b>Parameters</b>	<Pt> = Port number <profile> = <CHARACTER PROGRAM DATA> UDEFined: User Defined G82651: G.8265.1 G82751: G.8275.1 <i>DEFault</i> = <i>UDEFined</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:PROF G82651
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:PROFile?
<b>Description</b>	This query returns the PTP profile.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:PROF? → G82651
<b>Note</b>	

**12.11.6 ETHernet:PORT<Pt>:PTP:DOMain**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:DOMain <domain>
<b>Description</b>	This command sets the PTP domain Id.
<b>Parameters</b>	<Pt> = Port number <domain> = <CHARACTER PROGRAM DATA> <i>DEFault</i> : Default domain for multicast ALT1: Alternate 1 for multicast ALT2: Alternate 2 for multicast ALT3: Alternate 3 for multicast <i>UDEFault</i> : Default domain for unicast 5..255 : Alternative domains
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:DOM DEF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:DOMain?
<b>Description</b>	This query returns the PTP domain Id.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<domain> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:DOM? → DEF
<b>Note</b>	

### 12.11.7 ETHernet:PORT<Pt>:PTP:TPRotocol

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TPRotocol <protocol>
<b>Description</b>	This command sets the transport protocol to use for PTP communication.
<b>Parameters</b>	<Pt> = Port number <protocol> = <CHARACTER PROGRAM DATA> IPV4: UDP IPv4 IPV6: UDP IPv6 IEEE: IEEE 802.3 <i>Default = IPV4</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TPR IPV6
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TPRotocol?
<b>Description</b>	This query returns the transport protocol to use for PTP communication.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<protocol> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TPR? → IPV6
<b>Note</b>	

### 12.11.8 ETHernet:PORT<Pt>:PTP:MAC[:SOURce]

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC[:SOURce] <address>
<b>Description</b>	This command sets the PTP MAC source address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC[:SOURce]?
<b>Description</b>	This query returns the PTP MAC source address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:MAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	



**12.11.9 ETHernet:PORT<Pt>:PTP:MAC:AUTO**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:AUTO <automatic>
<b>Description</b>	This command enables/disables automatic generation of PTP source MAC address.
<b>Parameters</b>	<Pt> = Port number <automatic> = <CHARACTER PROGRAM DATA> ON: Lock the MAC parameter to the value of default MAC source address. OFF: Unlock the MAC parameter value. <i>DEFault</i> = ON
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC:AUTO ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:AUTO?
<b>Description</b>	This query returns whether or not automatic generation of PTP source MAC address is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<automatic> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:MAC:AUTO? → ON
<b>Note</b>	

**12.11.10 ETHernet:PORT<Pt>:PTP:MAC:DESTination**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:DESTination <address>
<b>Description</b>	This command sets the PTP MAC destination address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC:DEST "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator. This value is used when ETHernet:PORT<Pt>:PTP:SONLy is enabled and ETHernet:PORT<Pt>:PTP:CAST is set to UNICast.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:DESTination?
<b>Description</b>	This query returns the PTP MAC destination address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:MAC:DEST? → "00-50-C2-35-D2-EF"
<b>Note</b>	

**12.11.11 ETHernet:PORT<Pt>:PTP:MAC:SMULticast**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:SMULticast <address type>
<b>Description</b>	This command sets multicast destination MAC addresses.
<b>Parameters</b>	<Pt> = Port number <address type> = <CHARACTER PROGRAM DATA> AUTO: Use default multicast addresses. Peer delay multicast address is set according to IEEE1588v2 standard one. NONForwardable: Use only non-forwardable multicast address 01-80-C2-00-00-0E. This parameter should be used for G.8275.1. FORWardable: Use only forwardable multicast address 01-1B-19-00-00-00. This parameter should be used for G.8275.1. <i>DEFault</i> = AUTO
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC:SMUL NONF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:SMULticast?
<b>Description</b>	This query returns multicast destination MAC addresses
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:MAC:SMUL? → FORW
<b>Note</b>	

### 12.11.12 ETHernet:PORT<Pt>:PTP:MAC:ARP

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:ARP
<b>Description</b>	this command execute ARP for IEEE1588v2.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC:ARP
<b>Note</b>	

### 12.11.13 ETHernet:PORT<Pt>:PTP:MAC:ARP:RESult?

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:ARP:RESult?
<b>Description</b>	This query returns that ARP lookup succeeded or arp lookup timed out.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> SUCCESS: ARP lookup succeeded. TIMEOUT: ARP lookup timed out.
<b>Example</b>	ETH:PORT1:PTP:MAC:ARP:RES? → SUCCESS
<b>Note</b>	

### 12.11.14 ETHernet:PORT<Pt>:PTP:MAC:NDP

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:NDP
<b>Description</b>	This command execute NDP for PTP
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:MAC:NDP
<b>Note</b>	

### 12.11.15 ETHernet:PORT<Pt>:PTP:MAC:NDP:RESult?

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:MAC:NDP:RESult?
<b>Description</b>	This query returns that NDP lookup succeeded or NDP lookup timed out.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> SUCCESS: NDP lookup succeeded. TIMEOUT: NDP lookup timed out.
<b>Example</b>	ETH:PORT1:PTP:MAC:NDP:RES? → SUCCESS
<b>Note</b>	

**12.11.16 ETHernet:PORT<Pt>:PTP:PTYPE**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:PTYPE <payload type>
<b>Description</b>	This command sets payload type for IPv6 header.
<b>Parameters</b>	<Pt> = Port number <payload type> = <CHARACTER PROGRAM DATA> AUTO: IPv6 Payload length is set by auto. NULL: IPv6 Payload length is set 0. <i>DEFault = AUTO</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:PTYP NULL
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:PTYPE?
<b>Description</b>	This query returns payload type for IPv6 header.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:PTYP? → NULL
<b>Note</b>	

**12.11.17 ETHernet:PORT<Pt>:PTP:EXT**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT <enable>
<b>Description</b>	This command enables/disables the extended IPv6 header.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:EXT ON
<b>Notes</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT?
<b>Description</b>	This query returns the extended IPv6 header is enables or disables .
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:EXT? → 1
<b>Note</b>	

**12.11.18 ETHernet:PORT<Pt>:PTP:EXT:TYPE**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:TYPE <type>
<b>Description</b>	This command sets the type of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> HOP: Hop-by-Hop Options ROUTing: Routing(Type 0) DESTination: Destination Options
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:EXT:TYPE HOP
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:TYPE?
<b>Description</b>	This query returns the type of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:EXT:TYPE? → HOP
<b>Note</b>	

### 12.11.19 ETHernet:PORT<Pt>:PTP:EXT:LENGth

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:LENGth <length>
<b>Description</b>	This command sets the length of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=6, MAXimum=254, DEFault=6</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:EXT:LENG 6
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:LENGth?
<b>Description</b>	This query returns the length of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:EXT:LENG? → 0
<b>Note</b>	

### 12.11.20 ETHernet:PORT<Pt>:PTP:EXT:DATA

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:DATA <data>
<b>Description</b>	This command sets the data of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number <data> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:EXT:DATA "0123456789AB"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:EXT:DATA?
<b>Description</b>	This query returns the data of extension header for PTP. This command is only valid when IPv6 is selected on layer3.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:EXT:DATA? → "0123456789AB"
<b>Note</b>	

**12.11.21 ETHernet:PORT<Pt>:PTP:IP:IPV4:SOURce**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV4:SOURce <address>
<b>Description</b>	This command sets the PTP IPv4 source address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:IPV4:SOUR "172.29.2.36"
<b>Note</b>	Only the character '.' is accepted as separator. This value is used when ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV4

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV4:SOURce?
<b>Description</b>	This query returns the PTP IPv4 source address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:IPV4:SOUR? → "172.29.2.36"
<b>Note</b>	

**12.11.22 ETHernet:PORT<Pt>:PTP:IP:IPV4:DESTination**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV4:DESTination <address>
<b>Description</b>	This command sets the PTP IPv4 destination address. Used in unicast slave mode.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> IPv4 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:IPV4:DEST "172.29.2.36"
<b>Note</b>	Only the character '.' is accepted as separator. This value is used when ETHernet:PORT<Pt>:PTP:SONLy is enabled and ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV4 and ETHernet:PORT<Pt>:PTP:CAST is set to UNICast.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV4:DESTination?
<b>Description</b>	This query returns the PTP IPv4 destination address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:IPV4:DEST? → "172.29.2.36"
<b>Note</b>	

**12.11.23 ETHernet:PORT<Pt>:PTP:IP:IPV6:SOURce**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV6:SOURce <address>
<b>Description</b>	This command sets the PTP IPv6 source address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> IPv6 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:IPV6:SOUR "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV6

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV6:SOURce?
<b>Description</b>	This query returns the PTP IPv6 source address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:IPV6:SOUR? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.11.24 ETHernet:PORT<Pt>:PTP:IP:IPV6:DESTination**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV6:DESTination <address>
<b>Description</b>	This command sets the PTP IPv6 destination address. Used in unicast slave mode.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> IPv6 address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:IPV6:DEST "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:SONly is enabled and ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV6 and ETHernet:PORT<Pt>:PTP:CAST is set to UNICast.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:IPV6:DESTination?
<b>Description</b>	This query returns the PTP IPv6 destination address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:IPV6:DEST? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.11.25 ETHernet:PORT<Pt>:PTP:IPV6:ADDRconfig**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:ADDRconfig <mode>
<b>Description</b>	This command sets the PTP address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number <St> = Stream number (1-16) <mode> = <CHARACTER PROGRAM DATA> MANual: Manual SLESs: Stateless <i>DEFault = SLESs</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IPV6:ADDR SLES
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:ADDRconfig?
<b>Description</b>	This query returns the PTP address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:ADDR? → SLES
<b>Note</b>	

**12.11.26 ETHernet:PORT<Pt>:PTP:IPV6:ADDRconfig:RESult?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:ADDRconfig:RESult?
<b>Description</b>	This query returns the PTP result of address config for IPv6.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> SUCCESS: Address configuration succeeded. TIMEOUT: Address configuration timed out.
<b>Example</b>	ETH:PORT1:PTP:IPV6:ADDR:RES? → TIMEOUT
<b>Note</b>	

**12.11.27 ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID <mode>
<b>Description</b>	This command sets the PTP interface ID for IPv6.
<b>Parameters</b>	<Pt> = Port number <id> = <STRING PROGRAM DATA> The interface ID string must consist of 16 hexadecimal digits.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:IID "00-00-00-00-00-00-00-00"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID?
<b>Description</b>	This query returns the PTP address configuration mode for IPv6.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<mode> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:IID? → "00-00-00-00-00-00-00-00"
<b>Note</b>	

**12.11.28 ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID:AUTO**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID:AUTO <enable>
<b>Description</b>	This command enables/disables Interface ID for PTP.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:IID:AUTO ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:IID:AUTO?
<b>Description</b>	This query returns whether or not Interface ID for PTP is enabled.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:IID:AUTO? → 1
<b>Note</b>	

**12.11.29 ETHernet:PORT<Pt>:PTP:IPV6:SLESs:LINKlocal?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:LINKlocal?
<b>Description</b>	This query returns the PTP link local address.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:LINK? → "1234:5678:9ABC:DEF0:1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.11.30 ETHernet:PORT<Pt>:PTP:IPV6:SLESs:RAFLag?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLESs:RAFLag?
<b>Description</b>	This query returns the PTP stateless RA flags.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<flags> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLES:RAFL? → "0x00"
<b>Note</b>	

**12.11.31 ETHernet:PORT<Pt>:PTP:IPV6:SLEs:SRcMac?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLEs:SRcMac?
<b>Description</b>	This query returns the PTP stateless source MAC address.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLEs:SRcM? → "00-00-00-00-00-00"
<b>Note</b>	

**12.11.32 ETHernet:PORT<Pt>:PTP:IPV6:SLEs:PReFix?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLEs:PReFix?
<b>Description</b>	This query returns the PTP stateless prefix.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<prefix> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLEs:PReF? → "1234:5678:9ABC:DEF0"
<b>Note</b>	

**12.11.33 ETHernet:PORT<Pt>:PTP:IPV6:SLEs:PRFLag?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLEs:PRFLag?
<b>Description</b>	This query returns the PTP stateless prefix flags.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<flags> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLEs:PRFL? → "0x00"
<b>Note</b>	

**12.11.34 ETHernet:PORT<Pt>:PTP:IPV6:SLEs:LTIme?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLEs:LTIme?
<b>Description</b>	This query returns the PTP stateless life time.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<time> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLEs:LTIm? → "Fri Jan 8 14:24:44 2010"
<b>Note</b>	

**12.11.35 ETHernet:PORT<Pt>:PTP:IPV6:SLEs:RENew**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IPV6:SLEs:RENew
<b>Description</b>	This command execute PTP stateless address configuration. This command valid only when IPv6 is selected on layer3.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IPV6:SLEs:REN
<b>Note</b>	

**12.11.36 ETHernet:PORT<Pt>:PTP:IP:DSCP:EvEnt**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:DSCP:EvEnt <value>
<b>Description</b>	This command sets the DSCP value to use for PTP event messages.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=63, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:DSCP:EvEnt 0
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV4 or IPV6.



<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:DSCP:EVENT?
<b>Description</b>	This query returns the DSCP value to use for PTP event messages.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:DSCP:EVENT? → 0
<b>Note</b>	

### 12.11.37 ETHernet:PORT<Pt>:PTP:IP:DSCP:NORMal

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:DSCP:NORMal <value>
<b>Description</b>	This command sets the DSCP value to use for normal PTP messages (not PTP events).
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=63, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:IP:DSCP:NORM 0
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:TPRotocol is set to IPV4 or IPV6.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:IP:DSCP:NORMal?
<b>Description</b>	This query returns the DSCP value to use for normal PTP messages (not PTP events).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:IP:DSCP:NORM? → 0
<b>Note</b>	

### 12.11.38 ETHernet:PORT<Pt>:PTP:TUNNeling

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling <tunneling>
<b>Description</b>	This command sets the tunneling mode to use for PTP communication.
<b>Parameters</b>	<Pt> = Port number <tunneling> = <CHARACTER PROGRAM DATA> NONE: No tunneling VLAN: VLAN MPLS: MPLS <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN NONE
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling?
<b>Description</b>	This query returns the tunneling protocol to use for PTP communication.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tunneling> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN? → NONE
<b>Note</b>	

### 12.11.39 ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LCount

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LCount <levels>
<b>Description</b>	This command sets the number of active VLAN levels.
<b>Parameters</b>	<Pt> = Port number <levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LC 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LCOUNT?
<b>Description</b>	This query returns the number of active VLAN levels.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LC? → 2
<b>Note</b>	

#### 12.11.40 ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ID

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ID <number>
<b>Description</b>	This command sets the VLAN ID.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <number> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4095, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:ID 1024
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ID?
<b>Description</b>	This query returns the VLAN ID.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:ID? → 1024
<b>Note</b>	

#### 12.11.41 ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:CFI 1
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:CFI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI?

**12.11.42 ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:DEI 1
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:DEI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:DEI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:CFI?

**12.11.43 ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:PRiority**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:PRiority <priority>
<b>Description</b>	This command sets the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <priority> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:PR 7
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:PRiority?
<b>Description</b>	This query returns the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:PR? → 7
<b>Note</b>	

## 12.11.44 ETHernet:PORT&lt;Pt&gt;:PTP:TUNNeling:VLAN:LEVel&lt;Lv&gt;:ETYPe

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ETYPe <type>
<b>Description</b>	This command sets the VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N) <sup>1</sup> <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200 <i>DEFault=#H8100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:ETYP #H8100
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels (1-M), where M is the number of active VLAN Levels minus one(see section 12.31.97). Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). It is not possible to use this command for VLAN level N as Ethertype because this level is automatically set according to the selected higher-level protocol.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:VLAN:LEVel<Lv>:ETYPe?
<b>Description</b>	This query returns the VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N) <sup>1</sup>
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:VLAN:LEV1:ETYP? → #H86DD
<b>Note</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels (see section 12.31.97).

## 12.11.45 ETHernet:PORT&lt;Pt&gt;:PTP:TUNNeling:MPLS:LCCount

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LCCount <levels>
<b>Description</b>	This command sets the number of active MPLS levels.
<b>Parameters</b>	<Pt> = Port number <levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LC 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LCCount?
<b>Description</b>	This query returns the number of active MPLS levels.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LC? → 2
<b>Note</b>	

**12.11.46 ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:LABel**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:LABel <label>
<b>Description</b>	This command sets the MPLS label.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <label> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1048575, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:LAB 1048575
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:LABel?
<b>Description</b>	This query returns the MPLS label.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<label> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:LAB? → 1048575
<b>Note</b>	

**12.11.47 ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:EBITs**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:EBITs <value>
<b>Description</b>	This command sets the MPLS experimental bits.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:EBIT 5
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:EBITs?
<b>Description</b>	This query returns the MPLS experimental bits.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:EBIT? → 5
<b>Note</b>	

**12.11.48 ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:TTL**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:TTL <value>
<b>Description</b>	This command sets the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:TTL 32
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels (see section 12.31.81). Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TUNNeling:MPLS:LEVel<Lv>:TTL?
<b>Description</b>	This query returns the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TUNN:MPLS:LEV1:TTL? → 32
<b>Note</b>	

#### 12.11.49 ETHernet:PORT<Pt>:PTP:FCAPture

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:FCAPture <enable>
<b>Description</b>	This command enables/disables PTP frame capture.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:FCAP OFF
<b>Note</b>	Only frames for the configured domain ID will be captured.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:FCAPture?
<b>Description</b>	This query returns whether or not PTP frame capture is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:FCAP? → 1
<b>Note</b>	

#### 12.11.50 ETHernet:PORT<Pt>:PTP:FCAPture:DIRecotry

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:FCAPture:DIRecotry <directory>
<b>Description</b>	This command sets the PTP frame capture directory.
<b>Parameters</b>	<Pt> = Port number <directory> = <CHARACTER PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:FCAP:DIR "pcapdir"
<b>Note</b>	Only frames for the configured domain ID will be captured.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:FCAPture:DIRecotry?
<b>Description</b>	This query returns the PTP frame capture directory.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:FCAP:DIR? → "Internal/pcapdir"
<b>Note</b>	There must be a connected application server for this command to be recognized as a legal command. The application server must be in the idle state. Directory must be selected to the Internal/ directory or a sub-directory hereof. When a USB storage device is mounted, files can stored via the Usb/ directory. If the USB storage is not accessible, directory will be "Internal/" even if "Usb/" is selected.

**12.11.51 ETHernet:PORT<Pt>:PTP:ELOG**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:ELOG <enable>
<b>Description</b>	This command enables/disables Extended logging in the IEEE 1588 clock log. All received and transmitted PTP messages will be logged.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:ELOG OFF
<b>Note</b>	Only frames for the configured domain ID will be captured.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:ELOG?
<b>Description</b>	This query returns whether or not Extended logging in the IEEE 1588 clock log is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:ELOG? → 1
<b>Note</b>	

**12.11.52 ETHernet:PORT<Pt>:PTP:SMODE**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:SMODE <mode>
<b>Description</b>	This command sets the PTP step mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> ONE: One step mode TWO: Two step mode <i>DEFault = ONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:SMOD ON
<b>Note</b>	<mode> = ONE forces ETHernet:PORT<Pt>:PTP:DMECHANISM to RRESponse

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:SMODE?
<b>Description</b>	This query returns the PTP step mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:SMOD? → TW
<b>Note</b>	

**12.11.53 ETHernet:PORT<Pt>:PTP:DMECHANISM**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:DMECHANISM <mechanism>
<b>Description</b>	This command sets the PTP delay mechanism.
<b>Parameters</b>	<Pt> = Port number <mechanism> = <CHARACTER PROGRAM DATA> RRESponse: Request-Response delay mechanism PEER: Peer delay mechanism <i>DEFault = RRESponse</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:DMEC RRES
<b>Note</b>	<mechanism> = PEER forces ETHernet:PORT<Pt>:PTP:SMODE to TWO

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:DMECHANISM?
<b>Description</b>	This query returns the PTP delay mechanism.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mechanism> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:DMEC? → RRES
<b>Note</b>	

**12.11.54 ETHernet:PORT<Pt>:PTP:CLOCK:SOURce**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:SOURce <source>
<b>Description</b>	This command sets the PTP clock source.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> INTernal: Use the internal instrument clock. GPS: Use the attach GPS device for time reference. <i>DEFault = INTernal</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:SOUR INT
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:SOURce?
<b>Description</b>	This query returns the PTP clock source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:SOUR? → INT
<b>Note</b>	

**12.11.55 ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity <id>
<b>Description</b>	This command sets the PTP clock identity.
<b>Parameters</b>	<Pt> = Port number <id> = <STRING PROGRAM DATA> The identity string must consist of 16 hexadecimal digits.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:IDEN "00-00-00-00-00-00-00-00"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity?
<b>Description</b>	This query returns the PTP clock identity.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:IDEN? → "00-00-00-00-00-00-00-00"
<b>Note</b>	

**12.11.56 ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity:AUTO**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:IDENtity:AUTO <automatic>
<b>Description</b>	This command enables/disables automatic generation of an identity from the PTP source MAC address.
<b>Parameters</b>	<Pt> = Port number <automatic> = <CHARACTER PROGRAM DATA> ON: Lock the identity parameter to the value of the PTP MAC source address. OFF: Unlock the identity parameter value. <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:IDEN:AUTO ON
<b>Note</b>	Auto generation is performed as described in IEEE 1588v2.



<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:IDENTity:AUTO?
<b>Description</b>	This query returns whether or not automatic generation of an identity from the PTP source MAC address is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<automatic> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:IDEN:AUTO? → ON
<b>Note</b>	

### 12.11.57 ETHernet:PORT<Pt>:PTP:CLOCK:P1

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:P1 <priority>
<b>Description</b>	This command sets the PTP clock "priority 1" priority .
<b>Parameters</b>	<Pt> = Port number <priority> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=255</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:P1 255
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:P1?
<b>Description</b>	This query returns the PTP clock "priority 1" priority.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:P1? → 255
<b>Note</b>	

### 12.11.58 ETHernet:PORT<Pt>:PTP:CLOCK:P2

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:P2 <priority>
<b>Description</b>	This command sets the PTP clock "priority 2" priority .
<b>Parameters</b>	<Pt> = Port number <priority> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=255</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:P2 255
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:P2?
<b>Description</b>	This query returns the PTP clock "priority 2" priority.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:P2? → 255
<b>Note</b>	

### 12.11.59 ETHernet:PORT<Pt>:PTP:CLOCK:CLASs

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:CLASs <class>
<b>Description</b>	This command sets the PTP clock class.
<b>Parameters</b>	<Pt> = Port number <class> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=255</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:CLAS 255
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:CLASs?
<b>Description</b>	This query returns the PTP clock class.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<class> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:CLAS? → 255
<b>Note</b>	

### 12.11.60 ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy <accuracy>
<b>Description</b>	This command sets the PTP clock accuracy.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;accuracy&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>NS25: 25 nano seconds  NS100: 100 nano seconds  NS250: 250 nano seconds  US1: 1 micro second  US2: 2.5 micro seconds  US10: 10 micro seconds  US25: 25 micro seconds  US100: 100 micro seconds  US250: 250 micro seconds  MS1: 1 milli second  MS2: 2.5 milli seconds  MS10: 10 milli seconds  MS25: 25 milli seconds  MS100: 100 milli seconds  MS250: 250 milli seconds  S1: 1 second  S10: 10 seconds  PS10: Above 10 seconds  UNKNown: Unknown accuracy  CPRTC: T-GM connected to a PRTC in locked-mode<sup>1</sup>  NPRTC: T-GM not connected to a PRTC in locked-mode, or T-BC<sup>1</sup>  USER: Use user defined value  <i>DEFault = UNKNown</i></p>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:ACC UNKN
<b>Note</b>	<sup>1</sup> Only available when the Profile is G.8275.1.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy?
<b>Description</b>	This query returns the PTP clock accuracy.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<accuracy> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:ACC? → UNKN
<b>Note</b>	

### 12.11.61 ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy:USER

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy:USER <value>
<b>Description</b>	This command sets the user defined PTP clock accuracy.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;value&gt; = &lt;NUMERIC PROGRAM DATA&gt;  <i>MINimum=0, MAXimum=255, DEFault=254</i></p>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:ACC:USER 0
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy is set to USER.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:ACCuracy:USER?
<b>Description</b>	This query returns the user defined PTP clock accuracy.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:ACC:USER? → 254
<b>Note</b>	

### 12.11.62 ETHernet:PORT<Pt>:PTP:CLOCK:TSource

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:TSource <source>
<b>Description</b>	This command sets the PTP clock time source value.
<b>Parameters</b>	<Pt> = Port number <source> = <CHARACTER PROGRAM DATA> ATOMIC: Atomicclock GPS: GPS clock TRADio: Terrestrial Radio PTP: PTP clock NTP: NTP clock HSET: Hand set OTHer: Other IOSCillator: Internal Oscillator USER: Use user defined value <i>DEFault = IOSCillator</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:TSource IOSC
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:TSource?
<b>Description</b>	This query returns the PTP clock time source value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<source> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:TSource? → IOSC
<b>Note</b>	

### 12.11.63 ETHernet:PORT<Pt>:PTP:CLOCK:TSource:USER

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:TSource:USER <value>
<b>Description</b>	This command sets the user defined PTP clock time source value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=160</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:CLOC:TSource:USER 255
<b>Note</b>	This value is used when ETHernet:PORT<Pt>:PTP:CLOCK:TSource is set to USER.

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:CLOCK:TSource:USER?
<b>Description</b>	This query returns the user defined PTP clock time source value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:CLOC:TSource:USER? → 255
<b>Note</b>	

**12.11.64 ETHernet:PORT<Pt>:PTP:TIMing:AINTerval**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:AINTerval <interval>
<b>Description</b>	This command sets the PTP timing announce interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> FS8: 1/8 second FS4: 1/4 second FS2: 1/2 second S05: 1/2 second (for backward compatibility only) S1: 1 second S2: 2 seconds S4: 4 seconds S8: 8 seconds S16: 16 seconds S32: 32 seconds <i>DEFault = S2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:AINT S2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:AINTerval?
<b>Description</b>	This query returns the PTP timing announce interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:AINT? → S1
<b>Note</b>	

**12.11.65 ETHernet:PORT<Pt>:PTP:TIMing:ATIMEout**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:ATIMEout <intervals>
<b>Description</b>	This command sets the PTP timing announce timeout value. Unit: number of announce intervals.
<b>Parameters</b>	<Pt> = Port number <intervals> = <NUMERIC PROGRAM DATA> <i>MINimum=2, MAXimum=255, DEFault=3</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:ATIM 3
<b>Note</b>	The actual timeout period will be ATIMEout multiplied by AINTerval

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:ATIMEout?
<b>Description</b>	This query returns the PTP timing announce timeout value. Unit: number of announce intervals.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<intervals> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:ATIM? → 3
<b>Note</b>	

**12.11.66 ETHernet:PORT<Pt>:PTP:TIMing:UOFFset**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:UOFFset <offset>
<b>Description</b>	This command sets the nominal offset between UTC time and PTP/TAI time. The value is used for conversion and comparison of UTC and PTP/TAI time.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-32768, MAXimum=32767, DEFault=35</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:UOFF 35
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:UOFFset?
<b>Description</b>	This query returns the nominal offset between UTC time and PTP/TAI time.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:UOFF? → 34
<b>Note</b>	

**12.11.67 ETHernet:PORT<Pt>:PTP:TIMing:SINTerval**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:SINTerval <interval>
<b>Description</b>	This command sets the PTP timing sync interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> FS128: 1/128 second FS64: 1/64 second FS32: 1/32 second FS16: 1/16 second FS8: 1/8 second FS4: 1/4 second FS2: 1/2 second S05: 1/2 second (for backward compatibility only) S1: 1 second S2: 2 seconds S4: 4 seconds S8: 8 seconds S16: 16 seconds S32: 32 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:SINT S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:SINTerval?
<b>Description</b>	This query returns the PTP timing sync interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:SINT? → S1
<b>Note</b>	

## 12.11.68 ETHernet:PORT&lt;Pt&gt;:PTP:TIMing:DRINterval

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:DRINterval <interval>
<b>Description</b>	This command sets the PTP timing delay request interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> FS128: 1/128 second FS64: 1/64 second FS32: 1/32 second FS16: 1/16 second FS8: 1/8 second FS4: 1/4 second FS2: 1/2 second S05: 1/2 second (for backward compatibility only) S1: 1 second S2: 2 seconds S4: 4 seconds S8: 8 seconds S16: 16 seconds S32: 32 seconds DISabled: Use one-way-operation. (Disable delay requests/response) DEFault = S1
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:DRIN S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:DRINterval?
<b>Description</b>	This query returns the PTP timing delay request interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:DRIN? → S1
<b>Note</b>	

## 12.11.69 ETHernet:PORT&lt;Pt&gt;:PTP:TIMing:UDURation

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:UDURation <interval>
<b>Description</b>	This command sets the PTP timing unicast duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <timeout> = <NUMERIC PROGRAM DATA> MINimum = 60, MAXimum = 1000, DEFault = 300
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:UDUR 300
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:UDURation?
<b>Description</b>	This query returns the PTP timing unicast duration.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:UDUR? → 300
<b>Note</b>	

**12.11.70 ETHernet:PORT<Pt>:PTP:TIMing:GCABle**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:GCABle <delay>
<b>Description</b>	This command sets the delay time of GPS antenna cable length. Unit: nano Seconds.
<b>Parameters</b>	<Pt> = Port number <delay> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1000000000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:PTP:TIM:GCAB 35
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:TIMing:GCABle?
<b>Description</b>	This query returns the nominal offset between UTC time and PTP/TAI time.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<delay> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:TIM:GCAB? → 35
<b>Note</b>	

**12.11.71 ETHernet:PORT<Pt>:PTP:LOG?**

<b>Syntax</b>	ETHernet:PORT<Pt>:PTP:LOG?
<b>Description</b>	This query returns a lists of logged PTP events.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<log> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:PTP:LOG? → " 10:25:26.729 IEEE1588v2 ENABLED 10:25:26.729 Wall Clock: 10:26:00.000099450 10:25:26.740 Master: 0050FFFE235D2E:0 10:25:26.740 Master: cls:255 acc:254 var:4d2c 10:25:26.740 Master: prio1:255 prio2:255 10:25:26.740 Clock State: LISTENING "
<b>Note</b>	If the list is empty an execution error will be reported.

## 12.12 Follow

### 12.12.1 ETHernet:FOLLow:TRAFfic

<b>Syntax</b>	ETHernet:FOLLow:TRAFfic <enable>
<b>Description</b>	This command sets traffic setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:TRAF ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:TRAFfic?
<b>Description</b>	This query returns whether or not traffic setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:TRAF? → 1
<b>Note</b>	

### 12.12.2 ETHernet:FOLLow:STReam<St>

<b>Syntax</b>	ETHernet:FOLLow:STReam<St> <enable>
<b>Description</b>	This command sets stream setup for PORT2 stream <St> to follow PORT1 stream <St>.
<b>Parameters</b>	<St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:STR2 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:STReam<St>?
<b>Description</b>	This query returns whether or not stream setup for PORT2 stream <St> follows PORT1 stream <St>.
<b>Parameter</b>	<St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:STR1? → 0
<b>Note</b>	

### 12.12.3 ETHernet:FOLLow:GATeway<St>

<b>Syntax</b>	ETHernet:FOLLow:GATeway<St> <enable>
<b>Description</b>	This command sets gateway setup for PORT2 stream <St> to follow PORT1 stream <St>.
<b>Parameters</b>	<St> = Stream number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:GAT1 OFF
<b>Note</b>	This will only have an effect if ETHernet:FOLLow:STReam<St> is enabled.

<b>Syntax</b>	ETHernet:FOLLow:GATeway<St>?
<b>Description</b>	This query returns whether or not gateway setup for PORT2 stream <St> follows PORT1 stream <St>.
<b>Parameter</b>	<St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:GAT1? → 0
<b>Note</b>	



### 12.12.4 ETHernet:FOLLow:SETTings

<b>Syntax</b>	ETHernet:FOLLow:SETTings <enable>
<b>Description</b>	This command sets settings setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:SETT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:SETTings?
<b>Description</b>	This query returns whether or not settings setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:SETT? → 1
<b>Note</b>	

### 12.12.5 ETHernet:FOLLow:FILTer

<b>Syntax</b>	ETHernet:FOLLow:FILTer <enable>
<b>Description</b>	This command sets filter setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:FILT OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:FILTer?
<b>Description</b>	This query returns whether or not filter setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:FILT? → 0
<b>Note</b>	

### 12.12.6 ETHernet:FOLLow:THResholds

<b>Syntax</b>	ETHernet:FOLLow:THResholds <enable>
<b>Description</b>	This command sets threshold setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:THResholds?
<b>Description</b>	This query returns whether or not threshold setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:THR? → 1
<b>Note</b>	

## 12.12.7 ETHernet:FOLLow:SYNCe

<b>Syntax</b>	ETHernet:FOLLow:SYNCe <enable>
<b>Description</b>	This command sets SyncE setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:SYNC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:SYNCe?
<b>Description</b>	This query returns whether or not SyncE setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:SYNC? → 1
<b>Note</b>	

## 12.12.8 ETHernet:FOLLow:PTP

<b>Syntax</b>	ETHernet:FOLLow:PTP <enable>
<b>Description</b>	This command sets Precision Time Protocol setup for PORT2 to follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:FOLL:PTP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:FOLLow:PTP?
<b>Description</b>	This query returns whether or not Precision Time Protocol setup for PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:FOLL:PTP? → 1
<b>Note</b>	

## 12.12.9 ETHernet:PORT&lt;Pt&gt;:FOLLow:TRAFfic

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:TRAFfic <enable>
<b>Description</b>	This command sets traffic setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:TRAF ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:TRAFfic?
<b>Description</b>	This query returns whether or not traffic setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:TRAF? → 1
<b>Note</b>	

**12.12.10 ETHernet:PORT<Pt>:FOLLow:STReam<St>**

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:STReam<St> <enable>
<b>Description</b>	This command sets stream setup for port <Pt> stream <St> to follow PORT1 stream <St>.
<b>Parameter</b>	<Pt> = Port number (2-4)
	<St> = Stream number (1-16)
	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:STR1 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:STReam<St>?
<b>Description</b>	This query returns whether or not stream setup for port <Pt> stream <St> follows PORT1 stream <St>.
<b>Parameter</b>	<Pt> = Port number (2-4)
	<St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:STR1? → 1
<b>Note</b>	

**12.12.11 ETHernet:PORT<Pt>:FOLLow:GATeway<St>**

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:GATeway<St> <enable>
<b>Description</b>	This command sets gateway setup for port <Pt> stream <St> to follow PORT1 stream <St>.
<b>Parameter</b>	<Pt> = Port number (2-4)
	<St> = Stream number (1-16)
	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:GAT1 OFF
<b>Note</b>	This will only have an effect if ETH:PORT<Pt>:FOLLow:STReam<St> is enabled.

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:GATeway<St>?
<b>Description</b>	This query returns whether or not gateway setup for port <Pt> stream <St> follows PORT1 stream <St>.
<b>Parameter</b>	<Pt> = Port number (2-4)
	<St> = Stream number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:GAT1? → 0
<b>Note</b>	

**12.12.12 ETHernet:PORT<Pt>:FOLLow:SETTings**

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:SETTings <enable>
<b>Description</b>	This command sets settings setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:SETT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:SETTings?
<b>Description</b>	This query returns whether or not settings setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:SETT? → 1
<b>Note</b>	

### 12.12.13 ETHernet:PORT<Pt>:FOLLOW:FILTer

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:FILTer <enable>
<b>Description</b>	This command sets filter setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:FILT OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:FILTer?
<b>Description</b>	This query returns whether or not filter setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:FILT? → 0
<b>Note</b>	

### 12.12.14 ETHernet:PORT<Pt>:FOLLOW:THResholds

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:THResholds <enable>
<b>Description</b>	This command sets threshold setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:THResholds?
<b>Description</b>	This query returns whether or not threshold setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:THR? → 1
<b>Note</b>	

### 12.12.15 ETHernet:PORT<Pt>:FOLLOW:SYNCe

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLOW:SYNCe <enable>
<b>Description</b>	This command sets SyncE setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:SYNC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:SYNCe?
<b>Description</b>	This query returns whether or not SyncE setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:SYNC? → 1
<b>Note</b>	

### 12.12.16 ETHernet:PORT<Pt>:FOLLow:PTP

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:PTP <enable>
<b>Description</b>	This command sets Precision Time Protocol setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:PTP ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:PTP?
<b>Description</b>	This query returns whether or not Precision Time Protocol setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:PTP? → 1
<b>Note</b>	

### 12.12.17 ETHernet:PORT<Pt>:FOLLow:WAN

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:WAN <enable>
<b>Description</b>	This command sets WAN setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT2:FOLL:WAN ON
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:FOLLow:WAN?
<b>Description</b>	This query returns whether or not WAN setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT2:FOLL:WAN? → 1
<b>Note</b>	This command can be used on V2.00 or later

## 12.13 Stimuli

### 12.13.1 ETHernet:PORT<Pt>:STIMuli:ALARm

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:ALARm <alarm>
<b>Description</b>	This command sets the stimuli alarm state.
<b>Parameters</b>	<Pt> = Port number <alarm> = <CHARACTER PROGRAM DATA> NONE: No alarm LINK: No link REM: Remote fault LF: Local fault <sup>1</sup> <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:ALAR LINK
<b>Note</b>	<sup>1</sup> Requires 10G as the active interface.

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:ALARm?
<b>Description</b>	This query returns the stimuli alarm state.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:ALAR? → LINK
<b>Note</b>	

### 12.13.2 ETHernet:PORT<Pt>:STIMuli:ERRor

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:ERRor <error>
<b>Description</b>	This command sets the stimuli error/violation type.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> NONE: No error IFG: IFG <sup>1</sup> FCS: FCS PRE: Preamble PAUS: PAUSE frames IPCS: Wrong IP checksum FRAG: Fragmented IP L4CS: Wrong layer 4 checksum PRBS: PRBS bit error BSEQ: BER sequence error SYMB: Error symbol / Invalid 10G block <sup>2</sup> FSYMBFFEC symbol error <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:ERR L4CS
<b>Note</b>	<sup>1</sup> Not available when 10Gbps is enabled. <sup>2</sup> When 10G is enabled, invalid 10G blocks are inserted instead of error symbols.

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:ERRor?
<b>Description</b>	This query returns the stimuli error/violation type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:ERR? → L4CS
<b>Note</b>	

## 12.13.3 ETHernet:PORT&lt;Pt&gt;:STIMuli:EINsertion

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:EINsertion <mode>
<b>Description</b>	This command sets the stimuli error insertion mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Stimuli disabled MANual B1: Burst every 1 second B10: Burst every 10 seconds BE2: Burst · 1E-02 BE3: Burst · 1E-03 BE4: Burst · 1E-04 BE5: Burst · 1E-05 BE6: Burst · 1E-06 BE7: Burst · 1E-07 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:EINS MAN
<b>Note</b>	If insertion is set to MANual, errors are inserted with SYST:STIM:INS. See section 2.3.14. BE2-BE7 can only be used with PRBS bit error.

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:EINsertion?
<b>Description</b>	This query returns the stimuli error insertion mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:EINS? → MAN
<b>Note</b>	

## 12.13.4 ETHernet:PORT&lt;Pt&gt;:STIMuli:EBLength

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:EBLength <length>
<b>Description</b>	This command sets the error burst length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1<sup>1</sup>, MAXimum = 65535<sup>1</sup>, DEFault = 1<sup>1</sup></i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:EBL 128
<b>Note</b>	<sup>1</sup> The following error types have other MINimum, MAXimum and DEFault values. IFG: <i>MINimum = 2, MAXimum = 100, DEFault = 2</i> FRAG: <i>MINimum = 2, MAXimum = 5, DEFault = 2</i> PRBS: <i>MINimum = 1, MAXimum = 255, DEFault = 1</i> BSEQ: <i>MINimum = 2, MAXimum = 2, DEFault = 2</i>

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:EBLength?
<b>Description</b>	This query returns the error burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:EBL? → 128
<b>Note</b>	

## 12.13.5 ETHernet:PORT&lt;Pt&gt;:STIMuli:FEC:ERRor:LANE

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:FEC:ERRor:LANE <content>
<b>Description</b>	This command sets the lane number.
<b>Parameters</b>	<Pt> = Port number <content> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B1111, DEFault=#B0000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:FEC:ERR:LANE #B1001 This command add error into lane 0 and 3.
<b>Note</b>	This command can be used on 100G(on MU110013A CFP2 or QSFP28 Adpt.)

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:FEC:ERRor:LANE?
<b>Description</b>	This query returns the lane number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:FEC:ERR:LANE? → #B0000
<b>Note</b>	This command can be used on 100G(on MU110013A CFP2 or QSFP28 Adpt.)

## 12.13.6 ETHernet:PORT&lt;Pt&gt;:STIMuli:WAN:ALARm

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:ALARm <alarm>
<b>Description</b>	This command sets the WAN stimuli alarm state.
<b>Parameters</b>	<Pt> = Port number <alarm> = <CHARACTER PROGRAM DATA> NONE: No alarm LOS: Loss of signal LOF: Loss of frame OOF: Out of frame STIM: Section/Mux section trace identifier mismatch LAIS: Line/Mux section - alarm indication signal LRDI: Line/Mux section - remote defect indicator PAIS: Path/Administrative unit - alarm indication signal PLOP: Path/Administrative unit - loss of pointer PTIM: Path/High-order path - trace identifier mismatch PPLM: Path/High-order path - payload label mismatch PUNEQ: Path/High-order path - unequipped PRDI: Path enhanced/High-order path - remote defect indicator LCD: Loss of code-group delineation <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:WAN:ALAR LOS
<b>Note</b>	<sup>1</sup> Only available when the WAN terminology is SONET. This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:ALARm?
<b>Description</b>	This query returns the WAN stimuli alarm state.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:WAN:ALAR? → LOS
<b>Note</b>	This command can be used on V2.00 or later



**12.13.7 ETHernet:PORT<Pt>:STIMuli:WAN:ERRor**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:ERRor <error>
<b>Description</b>	This command sets the WAN stimuli error/violation type.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> NONE: No error A1A2: Frame alignment word B1: B1 checksum byte B2: B2 checksum byte LREI: Line/Multiplex section - remote error indication B3: B3 checksum byte PREI: Path/High-order path - remote error indication <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:WAN:ERR B1
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:ERRor?
<b>Description</b>	This query returns the WAN stimuli error/violation type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:WAN:ERR? → B1
<b>Note</b>	This command can be used on V2.00 or later

**12.13.8 ETHernet:PORT<Pt>:STIMuli:WAN:EINSErtion**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:EINSErtion <mode>
<b>Description</b>	This command sets the WAN stimuli error insertion mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Stimuli disabled MANual <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:WAN:EINS MAN
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:EINSErtion?
<b>Description</b>	This query returns the WAN stimuli error insertion mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:WAN:EINS? → MAN
<b>Note</b>	This command can be used on V2.00 or later

**12.13.9 ETHernet:PORT<Pt>:STIMuli:WAN:EBLEngth**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:EBLEngth <length>
<b>Description</b>	This command sets the WAN stimuli error burst length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 8000, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:WAN:EBL 128
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:WAN:EBLength?
<b>Description</b>	This query returns the WAN stimuli error burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:WAN:EBL? → 128
<b>Note</b>	This command can be used on V2.00 or later

### 12.13.10 ETHernet:PORT<Pt>:STIMuli:DEVIation

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:DEVIation <deviation>
<b>Description</b>	This command sets the amount of deviation to apply to the transmitted Ethernet signal. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <deviation> = <NUMERIC PROGRAM DATA> MT1000A: <i>MINimum</i> =-100, <i>MAXimum</i> =100, <i>DEFault</i> =0 MT1100A: <i>MINimum</i> =-200.0, <i>MAXimum</i> =200.0, <i>DEFault</i> = 0
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:DEV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:DEVIation?
<b>Description</b>	This query returns the amount of deviation to apply to the transmitted Ethernet signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	MT1000A: <deviation> = <NR1 NUMERIC RESPONSE DATA> MT1100A: <deviation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MT1000A: ETH:PORT1:STIM:DEV? → 0 MT1100A: ETH:PORT1:STIM:DEV? → 0.0
<b>Note</b>	

### 12.13.11 ETHernet:PORT<Pt>:STIMuli:PCS:ALARm

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ALARm <alarm>
<b>Description</b>	This command sets the stimuli alarm state.
<b>Parameters</b>	<Pt> = Port number <alarm> = <CHARACTER PROGRAM DATA> NONE: No alarm HIBER: High BER <i>DEFault</i> = <i>NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:ALAR HIBER
<b>Note</b>	<sup>1</sup> Requires 10G as the active interface. This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ALARm?
<b>Description</b>	This query returns the stimuli alarm state.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:ALAR? → HIBER
<b>Note</b>	This command can be used on 10/40/100G

## 12.13.12 ETHernet:PORT&lt;Pt&gt;:STIMuli:PCS:ERRor

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor <error>
<b>Description</b>	This command sets the stimuli error/violation type.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> NONE: No error INVBT00: INVBT2D: INVBT33: INVBT66: INVSH00: INVSH11: INVMARKER: BIP: <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:ERR NONE
<b>Note</b>	This command can be used on 10/40/100G INVMARKER and BIP cannot be used on 10G.

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor?
<b>Description</b>	This query returns the stimuli error/violation type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:ERR? → NONE
<b>Note</b>	This command can be used on 10/40/100G

## 12.13.13 ETHernet:PORT&lt;Pt&gt;:STIMuli:PCS:ERRor:LANE

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor:LANE <content>
<b>Description</b>	This command sets the lane number.
<b>Parameters</b>	<Pt> = Port number <content> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000000000000000000, MAXimum=#B11111111111111111111, DE-Fault=#B1000000000000000000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:ERR:LANE #B1001000001 This command add error into lane 0, 3 and 9.
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERRor:LANE?
<b>Description</b>	This query returns the lane number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:ERR:LANE? → #B10010000010000000000
<b>Note</b>	This command can be used on 40/100G

**12.13.14 ETHernet:PORT<Pt>:STIMuli:PCS:EINSeRTion**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EINSeRTion <error>
<b>Description</b>	This command sets the PCS error insertion mode.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> OFF: Stimuli disabled MANual BURSt RATE ALTeRnate ALL <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:EINS MAN
<b>Note</b>	This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EINSeRTion?
<b>Description</b>	This query returns the PCS stimuli insertion mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:EINS? → MAN
<b>Note</b>	This command can be used on 10/40/100G

**12.13.15 ETHernet:PORT<Pt>:STIMuli:PCS:EBLeNgtH**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EBLeNgtH <length>
<b>Description</b>	This command sets the PCS stimuli error burst length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 256, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:EBL 128
<b>Note</b>	This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EBLeNgtH?
<b>Description</b>	This query returns the PCS stimuli error burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:EBL? → 128
<b>Note</b>	This command can be used on 10/40/100G

**12.13.16 ETHernet:PORT<Pt>:STIMuli:PCS:ERATe**

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERATe <rate>
<b>Description</b>	This command sets the PCS stimuli error rate.
<b>Parameters</b>	<Pt> = Port number <rate> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:ERAT 1E-8
<b>Note</b>	This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ERATe?
<b>Description</b>	This query returns the PCS stimuli error rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rate> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:ERAT? → 1E-8
<b>Note</b>	This command can be used on 10/40/100G

### 12.13.17 ETHernet:PORT<Pt>:STIMuli:PCS:EELength

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EELength <length>
<b>Description</b>	This command sets the PCS stimuli alternate error length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 256, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:EEL 128
<b>Note</b>	This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:EELength?
<b>Description</b>	This query returns the PCS stimuli alternate error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:EEL? → 128
<b>Note</b>	This command can be used on 10/40/100G

### 12.13.18 ETHernet:PORT<Pt>:STIMuli:PCS:ENLength

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ENLength <length>
<b>Description</b>	This command sets the PCS stimuli alternate normal length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 312500000, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:ENL 128
<b>Note</b>	This command can be used on 10/40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:ENLength?
<b>Description</b>	This query returns the PCS stimuli alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:ENL? → 128
<b>Note</b>	This command can be used on 10/40/100G

### 12.13.19 ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:BIT

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:BIT <bit>
<b>Description</b>	This command sets the PCS stimuli skew bit.
<b>Parameters</b>	<Pt> = Port number <bit> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 8448, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:BIT 128
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:BIT?
<b>Description</b>	This query returns the PCS stimuli skew bit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:BIT? → 128
<b>Note</b>	This command can be used on 40/100G

### 12.13.20 ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:TYPE

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:TYPE <error>
<b>Description</b>	This command sets the PCS stimuli skew type.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> TXLANE: PCS stimuli skew type Tx lane PHYLANE: PCS stimuli skew type physical lane <i>DEFault = TXLANE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:TYPE PHYLANE
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:TYPE?
<b>Description</b>	This query returns the PCS stimuli skew type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:TYPE? → PHYLANE
<b>Note</b>	This command can be used on 40/100G

### 12.13.21 ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:LANE

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:LANE <content>
<b>Description</b>	This command sets the PCS stimuli skew lane number.
<b>Parameters</b>	<Pt> = Port number <content> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000000000000000000, MAXimum=#B11111111111111111111, DE-Fault=#B1000000000000000000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:LANE #B1001000001 This command add error into lane 0, 3 and 9.
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:LANE?
<b>Description</b>	This query returns the PCS stimuli skew lane number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:LANE? → #B10010000010000000000
<b>Note</b>	This command can be used on 40/100G

### 12.13.22 ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:NS?

<b>Syntax</b>	ETHernet:PORT<Pt>:STIMuli:PCS:SKEW:NS?
<b>Description</b>	This query returns the PCS stimuli skew(ns).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:STIM:PCS:SKEW:NS? → 819.2
<b>Note</b>	This command can be used on 40/100G

## 12.14 Result

### 12.14.1 ETHernet:PORT<Pt>:IFETch?

<b>Syntax</b>	ETHernet:PORT<Pt>:IFETch? <parameter>
<b>Description</b>	This query fetches an Ethernet interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {,}*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>Performance</b></p> <p>UTIL: Utilization. Response: &lt;Min%&gt;,&lt;Max%&gt;,&lt;Avg%&gt;</p> <p>THR: Throughput (bps). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p>FRAT: Frame rate (fps). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p><b>Frame Stat</b></p> <p>TFR: Total frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>TGFR: Total good frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>UFR: Unicast frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>MFR: Multicast frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>BFR: Broadcast frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PFR: Pause frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>MPLS Frame Stat</b></p> <p>MPFR: MPLS frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>MLM: MPLS level max. Response: &lt;Count&gt;</p> <p>MLMIN: MPLS level min. Response: &lt;Count&gt;</p> <p>EMFR: EoMPLS frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>LMPLS&lt;Lv&gt;: Last received MPLS Label, Priority and TTL. &lt;Lv&gt; = MPLS level. Response: &lt;label&gt;,&lt;priority&gt;,&lt;TTL&gt;</p> <p><b>VLAN Frame Stat</b></p> <p>VFR: VLAN frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>VLM: VLAN level max. Response: &lt;Count&gt;</p> <p>VLMIN: VLAN level min. Response: &lt;Count&gt;</p> <p>LVLAN&lt;Lv&gt;: Last received VLAN ID and priority. &lt;Lv&gt; = VLAN level. Response: &lt;id&gt;,&lt;priority&gt;</p> <p><b>MiM Frame Stat</b></p> <p>MIMFR: MiM frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>LBTAG: Last received B-TAG VLAN ID and priority Response: &lt;id&gt;,&lt;priority&gt;</p> <p>LITAG: Last received I-TAG service ID and priority Response: &lt;id&gt;,&lt;priority&gt;</p> <p><b>Frame Alarms &amp; Errors</b></p> <p>TEFR: Total errored frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>FFR: Fragmented frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>UNFR: Undersized frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>OVFR: Oversized frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>FEFR: FCS errored frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>ESFR: Error symbol frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>OVRFCSEERR: Oversized &amp; FCS errored frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>IPCHKSUM: IP checksum errored frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>I10GB: Invalid 10G Blocks<sup>2</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>COLL: Collisions. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>PV: Preamble violations. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>IV: IFG violations. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>LF: 10/40/100G Local Faults. Response: &lt;Count&gt;</p> <p>10GLF: Obsolete. For CMA 3000 backward compatibility only. Same as LF.</p> <p>RF: 10/40/100G Remote Faults. Response: &lt;Count&gt;</p> <p>10GRF: Obsolete. For CMA 3000 backward compatibility only. Same as RF.</p> <p><b>Burst Stat</b></p> <p>BUFR: Bursted frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>NOB: Number of bursts. Response: &lt;Count&gt;</p> <p>AVGB: Average burst size. Response: &lt;Count&gt;,&lt;Bytes&gt;</p>

continued on next page...

... continued from previous page

	<p>MAXB: Maximum burst size. Response: &lt;Count&gt;,&lt;Bytes&gt;  MINB: Minimum burst size. Response: &lt;Count&gt;,&lt;Bytes&gt;  <b>Size Distribution (Rx)</b>  R46: 46-63<sup>4</sup>. Response: &lt;Count&gt;,&lt;Ratio&gt;  R64: 64-127. Response: &lt;Count&gt;,&lt;Ratio&gt;  R128: 128-255. Response: &lt;Count&gt;,&lt;Ratio&gt;  R256: 256-511. Response: &lt;Count&gt;,&lt;Ratio&gt;  R512: 512-1023. Response: &lt;Count&gt;,&lt;Ratio&gt;  R1024: 1024-1518. Response: &lt;Count&gt;,&lt;Ratio&gt;  RJUM: Jumbo frames. Response: &lt;Count&gt;,&lt;Ratio&gt;  FSIZ: Frame size (bytes). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  <b>Transmit Stat</b>  TFR: Total frames. Response: &lt;Count&gt;  TTGB: Total good bytes (bytes). Response: &lt;Count&gt;  TUFR: Unicast frames. Response: &lt;Count&gt;  TMFR: Multicast frames. Response: &lt;Count&gt;  TBFR: Broadcast frames. Response: &lt;Count&gt;  TFE: FCS errors. Response: &lt;Count&gt;  TTE: Total errors. Response: &lt;Count&gt;  T46: 46-63<sup>4</sup>. Response: &lt;Count&gt;  T64: 64-127. Response: &lt;Count&gt;  T128: 128-255. Response: &lt;Count&gt;  T256: 256-511. Response: &lt;Count&gt;  T512: 512-1023. Response: &lt;Count&gt;  T1024: 1024-1518. Response: &lt;Count&gt;  TJUM: Jumbo frames. Response: &lt;Count&gt;  TFRD: Total frames difference (Tx-Rx&lt;ref-port&gt;)<sup>3</sup>.  Response: &lt;Count&gt;,&lt;Count&gt;  <b>Multistream Transmit Stat</b>  STFx: Stream x frames. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  STBx: Stream x bytes (bytes). Response: &lt;CountTx&gt;,&lt;CountRx&gt;  x = Stream number (1-16)  <b>Multistream Throughput Stat</b>  SFPSx: Stream x frames per second (fps). Response: &lt;CountTx&gt;,&lt;CountRx&gt;  SBPSx: Stream x bits per seconds (bps). Response: &lt;CountTx&gt;,&lt;CountRx&gt;  x = Stream number (1-16)  <b>Multistream Frame Loss</b>  SFLx: Stream x frame loss. Response: &lt;Count&gt;,&lt;Ratio&gt;  x = Stream number (1-16)  <b>Multistream Latency/Jitter</b>  SLx: Latency (<math>\mu</math>s). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  SJx: Jitter (<math>\mu</math>s). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  x = Stream number (1-16)  <b>BER - Alarms &amp; Errors</b>  LOS: Loss of signal. Response: &lt;Count&gt;,&lt;Ratio&gt;  NLS: No link Seconds. Response: &lt;Count&gt;,&lt;Ratio&gt;  RFS: Remote fault seconds. Response: &lt;Count&gt;,&lt;Ratio&gt;  BPBC: Pattern bit count. Response: &lt;Count&gt;  BPE: Pattern errors. Response: &lt;Count&gt;,&lt;Ratio&gt;  PSA: PRBS Sync Alarm.<sup>6</sup> Response: &lt;Count&gt;  BSE: Sequence errors. Response: &lt;Count&gt;  BSSL: Sequence sync. Lost. Response: &lt;Count&gt;  BFL: Frame loss. Response: &lt;Count&gt;  BFLS: Frame loss seconds. Response: &lt;Count&gt;  SDMD: Maximum disruption. Response: &lt;Microseconds&gt;  SDAD: Average disruption. Response: &lt;Microseconds&gt;,&lt;Count&gt;  MES: M.2100 ES. Response: &lt;Seconds&gt;,&lt;Ratio&gt;</p>
--	--

continued on next page...



...continued from previous page

MSES: M.2100 SES. Response: <Seconds>,<Ratio>  
 MALS: M.2100 ALS. Response: <Seconds>,<Ratio>  
 MUAT: M.2100 UAT. Response: <Seconds>,<Ratio>  
 MAVT: M.2100 AVT. Response: <Seconds>,<Ratio>  
 MEFS: M.2100 EFS. Response: <Seconds>,<Ratio>  
 TDL: Stream 1 Throughput Data Layer (bps). Response: <Min>,<Max>,<Avg>  
 TNL: Stream 1 Throughput Network Layer (bps). Response: <Min>,<Max>,<Avg>  
 TLL: Stream 1 Throughput Link Layer (bps). Response: <Min>,<Max>,<Avg>  
 TPPL: Stream 1 Throughput Physical Layer without Preamble (bps).  
 Response: <Min>,<Max>,<Avg>  
 TPL: Stream 1 Throughput Physical Layer (bps). Response: <Min>,<Max>,<Avg>  
 TUL: Stream 1 Throughput Utilization Layer (bps). Response: <Min>,<Max>,<Avg>  
**WAN - Alarms**  
 WLOS: Loss of signal. Response: <Seconds>,<Ratio>  
 WLOF: Loss of frame. Response: <Seconds>,<Ratio>  
 WSEF: WSEF/OOF -Severely errored frame/Out of frame. Response: <Seconds>,<Ratio>  
 WSTIM: Section/Mux section - Trace identifier mismatch. Response: <Seconds>,<Ratio>  
 WLAIS: Line/Mux section - alarm indication signal. Response: <Seconds>,<Ratio>  
 WLRDI: Line/Mux section - remote defect indicator. Response: <Seconds>,<Ratio>  
 WPAIS: Path/Administrative unit - alarm indication signal.  
 Response: <Seconds>,<Ratio>  
 WPLOP: Path/Administrative unit - loss of pointer. Response: <Seconds>,<Ratio>  
 WPTIM: Path/High-order path - trace Identifier mismatch.  
 Response: <Seconds>,<Ratio>  
 WPPLM: Path/High-order path - payload label mismatch. Response: <Seconds>,<Ratio>  
 WPUNEQ: Path/High-order path - unequipped. Response: <Seconds>,<Ratio>  
 WPRDI: Path/High-order path - remote defect indication.  
 Response: <Seconds>,<Ratio>  
 WPLCD: Loss of code-group delineation. Response: <Seconds>,<Ratio>  
**WAN - Errors**  
 WA1A2: Response: <Count>,<Ratio>  
 WB1: Response: <Count>,<Ratio>  
 WB2: Response: <Count>,<Ratio>  
 WLREI: Line/Mux section - remote error indication. Response: <Count>,<Ratio>  
 WB3: Response: <Count>,<Ratio>  
 WPREI: Path/High-order path - remote error indication. Response: <Count>,<Ratio>  
**WAN - Mux quality**  
 WMFES: Mux forward ES. Response: <Count>,<Ratio>  
 WMFSES: Mux forward SES. Response: <Count>,<Ratio>  
 WMFUNAV: Mux forward UNAV. Response: <Count>,<Ratio>  
 WMBES: Mux backward ES. Response: <Count>,<Ratio>  
 WMBSES: Mux backward SES. Response: <Count>,<Ratio>  
 WMBUNAV: Mux backward UNAV Response: <Count>,<Ratio>  
**WAN - SPE quality**  
 WSFES: SPE forward ES. Response: <Count>,<Ratio>  
 WSFSES: SPE forward SES. Response: <Count>,<Ratio>  
 WSFUNAV: SPE forward UNAV. Response: <Count>,<Ratio>  
 WSBES: SPE backward ES. Response: <Count>,<Ratio>  
 WSBSES: SPE backward SES. Response: <Count>,<Ratio>  
 WSBUNAV: SPE backward UNAV Response: <Count>,<Ratio>  
**SyncE - Synchronous Ethernet**  
 QLD: Quality level distribution. Response: A percentage value for each of the 16 QLs  
 <Count>,...  
 QLR: Quality level reports. Response: <Count>,<Rate>  
 QLU: Quality level unavailable time (SSF). Response: <Seconds>,<Ratio>  
 QLT: Quality level transmission count. Response: <Count>,<Ratio>  
**PTP - Precision Time Protocol**

continued on next page...

...continued from previous page

<p>PAC: Announce count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PSC: Sync count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PFUC: Follow up count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PDRC: Delay request count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PDRESC: Delay response count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PPDRC: Peer delay request count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PPDRESC: Peer delay response count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PPDFC: Peer delay follow-up count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  SIGN: Signaling messages count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  MGM: Management messages count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  PO: Offset. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  PAO: Absolute offset. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  POD: Offset deviation. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  POV: Offset variance. Unit: (seconds)<sup>2</sup>. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  PMPD: Mean path delay. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  PPMPD: Peer mean path delay. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  PPDV: Packet delay variation. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  PICST: IEEE Clock State Transitions. Response: &lt;Count&gt;  PISTE: IEEE State Transition Events. Response: &lt;Count&gt;  PIF: IEEE Faults. Response: &lt;Count&gt;  PICGC: IEEE Changes in Grandmaster Clock. Response: &lt;Count&gt;  PGW: GPS vs Wall clock. Unit: Nano seconds. Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;  <b>OAM 802.ah</b>  OINF: Information count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OEVENT: Event count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OVREQ: Variable Request count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OVRES: Variable response count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OLBCK: Loopback count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  ODUP: Duplicate count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OUNS: Unsupported count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OORG: Organization count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  <b>OAM 802.ag and Y.1731</b>  OCCM: CCM count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OLBM: LBM count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OLBR: LBR count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OLTM: LTM count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OLTR: LTR count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OOTH: Other count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  OTOT: Total count. Response: &lt;CountTx&gt;,&lt;CountRx&gt;  <b>Sync Test</b>  BRATE: Bitrate<sup>5</sup>. Unit: bps. Response: &lt;Count&gt;  BRATED: Bitrate difference<sup>5</sup>. Unit: ppb. Response: &lt;Count&gt;  PHASE: Phase error result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PHASEAVG: Average phase error result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PHASEMIN: Minimum phase error result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PHASEMAX: Maximum phase error result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  FILTERED: Filtered TE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  FILTEREDAVG: Average filtered TE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  FILTEREDMIN: Minimum filtered TE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  FILTEREDMAX: Maximum filtered TE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PPS: 1PPS deviation result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PPSAVG: Average 1PPS deviation average result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PPSMIN: Minimum 1PPS deviation result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  PPSMAX: Maximum 1PPS deviation result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;  SYNCAVG: Average sync message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p>
---

continued on next page...

...continued from previous page

	<p>SYNCPMIN: Minimum sync message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>SYNCPMAX: Maximum sync message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>FOLLOWAVG: Average followup message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>FOLLOWMIN: Minimum followup message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>FOLLOWMAX: Maximum followup message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>DELAYAVG: Average delay request Message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>DELAYMIN: Minimum delay request Message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>DELAYMAX: Maximum delay request Message transmission time<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>CTE: cTE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>DTE: dTE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>MAXTE: Maximum TE result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>CTE1: cTE1 result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>CTE4: cTE4 result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>MAXTE1: Max—TE1— result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>MAXTE4: Max—TE4— result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p>TERR: Terr result<sup>5</sup>. Unit: Nano seconds. Response: &lt;Seconds&gt;</p> <p><b>PCS Alarms &amp; Errors</b></p> <p>ISH: Invalid Sync Header. Response: &lt;Lane&gt;,&lt;Total&gt;</p> <p>IAM: Invalid Alignment Marker. Response: &lt;Lane&gt;,&lt;Total&gt;</p> <p>BIP: BIP Error. (bit) Response: &lt;Lane&gt;,&lt;Total&gt;</p> <p>IBLOCK: Invalid Block. Response: &lt;Count&gt;</p> <p>HBER: High BER. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p><b>PCS Status</b></p> <p>SHLOCK: Sync header Lock. &lt;Lane&gt;</p> <p>AMLOCK: Align Marker Lock. &lt;Lane&gt;</p> <p>MMAP: Marker Map. &lt;Lane&gt;</p> <p>RSKEW: Relative Skew. Unit: Nano seconds. &lt;Lane&gt;</p> <p>ALIGN: Alignment Status. &lt;Lane&gt;</p> <p><b>FEC Errors</b></p> <p>FECORCW: FEC Corrected Codewords. Response: &lt;Count&gt;</p> <p>FECUCORCW: FEC Uncorrected Codewords. Response: &lt;Count&gt;</p> <p>FECSYMERR: FEC Symbol errors. Response: &lt;Count&gt;</p> <p>FECSYMERRRATE: FEC Symbol errors rate. Response: &lt;Count&gt;</p> <p>FECLOFA: Loss of Alignment. Response: &lt;Count&gt;</p> <p>FECMMAP: FEC Lane Marker. &lt;Lane&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Format: Numeric List</p> <p>Each result is formatted according to the specification in the parameter field.</p> <p>Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Examples</b>	<p>ETH:PORT1:IFET? (TGFR) → (6400,0.853)</p> <p>ETH:PORT1:IFET? (UFR,BFR) → (251923,0.900), (27992,0.100)</p>
<b>Notes</b>	<p>This command fetches the results from the interval selected using the MEASUREMENT:SETUP:SELECT command (see section 17.2.2).</p> <p><sup>1</sup> Results are only available when the WAN terminology is SONET.</p> <p><sup>2</sup> Results are only available at 10G.</p> <p><sup>3</sup> &lt;ref-port&gt; is set with the command ETH:PORT1:TFRD:PSEL</p> <p><sup>4</sup> Result are only available at MPLS/IP over OTN.</p> <p><sup>5</sup> Result are only available on the Sync Test application.</p>

continued on next page...

... continued from previous page

<sup>6</sup> Result are only available when cross pattern by Frame by Frame is available.  
If the requested result is not available, NaN (section 1.6.1) is returned.  
If there is one or more results, the last "," is always removed.

### 12.14.2 ETHernet:PORT<Pt>:TFETch?

<b>Syntax</b>	ETHernet:PORT<Pt>:TFETch? <parameter>
<b>Description</b>	This query fetches thresholds for a Ethernet interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>{(&lt;parameter&gt;} + {,})* = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p><b>Performance</b> UTIL: Utilization. THR: Throughput.</p> <p><b>Frame Stat</b> UFR: Unicast frames. MFR: Multicast frames. BFR: Broadcast frames. PFR: Pause frames. FFR: Fragmented frames. UNFR: Undersized frames. OVFR: Oversized frames. FEFR: FCS errored frames. OVRFCSErr: Oversized &amp; FCS errored frames. IPCHKSUM: IP checksum errored frames. COLL: Collisions. PV: Preamble violations. IV: IFG violations. TEFR: Total errored frames.</p> <p><b>Transmit Stat</b> TFRD: Total frames difference (Tx-Rx&lt;ref-port&gt;)<sup>1</sup>.</p> <p><b>BER - Alarms &amp; Errors</b> BPE: Pattern errors. BSE: Sequence errors. SDMD: Maximum disruption.</p> <p><b>Multistream Frame Loss</b> SFLx: Stream x frame loss. x = Stream number (1-16)</p> <p><b>Multistream Latency/Jitter</b> SLx: Latency (<math>\mu</math>s). SJx: Jitter (<math>\mu</math>s). x = Stream number (1-16)</p> <p><b>Sync Test</b> PHASE: 1PPS phase error<sup>2</sup>. FILTERED: Filtered TE<sup>2</sup>. PPS: 1PPS deviation<sup>2</sup>. SYNC: Sync message transmission time<sup>2</sup>. FOLLOW: Followup message transmission time<sup>2</sup>. DELAY: Delay request message transmission time<sup>2</sup>.</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p>Format: Numeric List</p> <p>&lt;result&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p> <p>0: Pass 1: Fail</p>
<b>Example</b>	ETH:PORT1:TFET? (TEFR,UTIL,TFRD) → (1),(1),(1,0)
<b>Note</b>	<p>This query fetches from the interval selected using the MEASurement:SEtup:SElect command (see section 17.2.2).</p> <p><sup>1</sup> &lt;ref-port&gt; is set with the command ETH:PORT1:TFRD:PSEL</p> <p><sup>2</sup> Result are only available on the Sync Test application.</p>

### 12.14.3 ETHernet:PORT<Pt>:TFRDifference:PSELection

<b>Syntax</b>	ETHernet:PORT<Pt>:TFRDifference:PSELection <port>
<b>Description</b>	This command sets the Rx port number for total frames difference.
<b>Parameters</b>	<Pt> = Port number <port> = <CHARACTER PROGRAM DATA> PORTx: Rx port number x
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:TFRD:PSEL PORT1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:TFRDifference:PSELection?
<b>Description</b>	This query returns the Rx port number for total frames difference.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<port> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:TFRD:PSEL? → PORT1
<b>Note</b>	

## 12.15 Status

### 12.15.1 ETHernet:STATus:PORT<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the Ethernet alarms and errors summary event register. The content of this event register is summarized in DB6 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 (4) = WAN physical and Line/Mux alarm summary <sup>1</sup> DB4 (8) = WAN path/High-order alarm summary <sup>1</sup> DB5 (16) = WAN error summary <sup>1</sup> DB6 (32) = PCS alarm summary <sup>2</sup> DB7 (64) = PCS error summary <sup>2</sup> DB8 (128) = Sync Test alarm summary <sup>3</sup> DB9 (256) = FEC error summary <sup>4</sup> DB10 - DB16 = NOT USED
<b>Example</b>	ETH:STAT:PORT1:AES? → 1
<b>Note</b>	<sup>1</sup> WAN errors/alarms are only valid if WAN is enabled. <sup>2</sup> PCS errors/alarms are only available at 40/100G. <sup>3</sup> Sync Test alarms are only valid if the Sync Test application. <sup>4</sup> FEC errors are only available at 100G(on MU110013A CFP2 or QSFP28 Adpt.).

### 12.15.2 ETHernet:STATus:PORT<Pt>:AESummary:CONDition?

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the Ethernet alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as ETHernet:STATus:PORT<Pt>:AESummary[:EVENT]?
<b>Example</b>	ETH:STAT:PORT1:AES:COND? → 1
<b>Note</b>	

### 12.15.3 ETHernet:STATus:PORT<Pt>:ALARm<section>[:EVENT]?

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the ETHernet:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Ethernet(1), WAN Physical and Line/Mux(2), WAN Path/High-order(3), PCS(4), or Sync Test(5)
<b>Response</b>	<p>&lt;register&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p> <p>&lt;section&gt; = 1:  DB1 (1) = No link  DB2 (2) = Remote fault  DB3 (4) = Threshold(s) exceeded  DB4 (8) = BER alarms <sup>1</sup>  DB5 (16) = Loss of signal  DB6 - DB8 = NOT USED  DB9 (256) = SyncE Timeout alarm  DB10 (512) = PTP Synchronization Timeout alarm  DB11 (1024) = Timing Source alarm  DB12 - DB16 = NOT USED</p> <p>&lt;section&gt; = 2:<sup>2</sup>  DB1 (1) = Loss of signal  DB2 (2) = Loss of frame  DB3 (4) = Severely errored frame/Out of frame  DB4 (8) = Section/Mux section - trace identifier mismatch  DB5 (16) = Line/Mux section - alarm indication signal  DB6 (32) = Line/Mux section - remote defect indicator  DB7 - DB16 = NOT USED</p> <p>&lt;section&gt; = 3:<sup>2</sup>  DB1 (1) = Path/Administrative unit - alarm indication signal  DB2 (2) = Path/Administrative unit - loss of pointer  DB3 (4) = Path/High-order path - trace Identifier mismatch  DB4 (8) = Path/High-order path - payload label mismatch  DB5 (16) = Path/High-order path - unequipped  DB6 (32) = Path/High-order path - remote defect indication  DB7 (64) = Path - enhanced remote defect indication payload <sup>3</sup>  DB8 (128) = Path - enhanced remote defect indication server <sup>3</sup>  DB9 (256) = Path - enhanced remote defect indication connectivity <sup>3</sup>  DB10 (512) = Loss of code-group delineation  DB11 (1024) = Loss of signal synchronization  DB12 - DB16 = NOT USED</p> <p>&lt;section&gt; = 4:<sup>4</sup>  DB1 (1) = High BER  DB2 (2) = Alignment Status  DB3 - DB16 = NOT USED</p> <p>&lt;section&gt; = 5:<sup>5</sup>  DB1 (1) = Ext.ref. clock  DB2 (2) = Ext. ref. 1PPS  DB3 (4) = 1PPS  DB4 - DB16 = NOT USED</p>
<b>Example</b>	ETH:STAT:PORT1:ALAR1? → 1
<b>Notes</b>	<sup>1</sup> BER Alarms are only valid if BER is enabled. <sup>2</sup> WAN Alarms are only valid if WAN is enabled. <sup>3</sup> Only available when the WAN terminology is SONET. <sup>4</sup> Only available at 40/100G. <sup>5</sup> Only available on Sync Test application.

## 12.15.4 ETHernet:STATus:PORT&lt;Pt&gt;:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:ALARm<section>:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameters</b>	<Pt> = Port number <section> = Ethernet(1) , WAN Physical and Line/Mux(2), WAN Path/High-order(3), PCS(4), or Sync Test(5)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as ETHernet:STATus:PORT<Pt>:ALARm<section>[:EVENT]?
<b>Example</b>	ETH:STAT:PORT1:ALAR1:COND? → 1
<b>Note</b>	

## 12.15.5 ETHernet:STATus:PORT&lt;Pt&gt;:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the ETHernet:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number <section> = Ethernet(1), WAN(2), PCS(3) or FEC(4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA>  <section> = 1: DB1 (1) = Errored frames DB2 (2) = Multistream frame loss <sup>1</sup> DB3 (4) = Bit errors DB4 - DB16 = NOT USED  <section> = 2: <sup>2</sup> DB1 (1) = A1A2 DB2 (2) = B1 DB3 (4) = B2 DB4 (8) = Line/Mux section REI DB5 (16) = B3 DB6 (32) = Path/High-order path REI DB7 (64) = STS-192C/AU4-64C positive DB8 (128) = STS-192C/AU4-64C negative DB9 - DB16 = NOT USED  <section> = 3: <sup>3</sup> DB1 (1) = Invalid Sync header DB2 (2) = Invalid Align Marker DB3 (4) = Invalid Block DB4 (8) = BIP Error DB5 - DB16 = NOT USED  <section> = 4: <sup>4</sup> DB1 (1) = LOFA DB2 (2) = FEC Corrected Codewords DB3 (4) = FEC Uncorrected Codewords DB4 (8) = FEC Symbol Errors DB5 (16) = LOFAML DB6 - DB16 = NOT USED
<b>Example</b>	ETH:STAT:PORT1:ERR1? → 1
<b>Notes</b>	<sup>1</sup> Multistream frame loss is only valid when multistream frame loss is enabled and a measurement is running. <sup>2</sup> WAN errors are only valid if WAN is enabled. <sup>3</sup> Only available at 40/100G. <sup>3</sup> Only available at 100G(on MU110013A CFP2 or QSFP28 Adpt.).



**12.15.6 ETHernet:STATus:PORT<Pt>:ERRor<section>:CONDition?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:ERRor<section>:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameters</b>	<Pt> = Port number <section> = Ethernet(1), WAN(2), PCS(3), FEC(4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> Same as ETHernet:STATus:PORT<Pt>:ERRor<section>[:EVENTt]?
<b>Example</b>	ETH:STAT:PORT1:ERR1:COND? → 1
<b>Note</b>	

**12.15.7 ETHernet:STATus:PORT<Pt>:LINK?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:LINK?
<b>Description</b>	This query returns if there is link.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<link> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:LINK? → 1
<b>Note</b>	

**12.15.8 ETHernet:STATus:PORT<Pt>:INTerface?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:INTerface?
<b>Description</b>	This query returns the current type of interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <STRING RESPONSE DATA> "ELECTRICAL" "OPTICAL" "N/A": No link
<b>Example</b>	ETH:STAT:PORT1:INT? → "ELECTRICAL"
<b>Note</b>	

**12.15.9 ETHernet:STATus:PORT<Pt>:FRAMes?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:FRAMes?
<b>Description</b>	This query returns if frames are present.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:FRAM? → 1
<b>Note</b>	

**12.15.10 ETHernet:STATus:PORT<Pt>:MPLS?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:MPLS?
<b>Description</b>	This query returns if any frames with MPLS and Ethernet over MPLS are present.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mpls> = <NR1 NUMERIC RESPONSE DATA> <eompls> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:MPLS? → 1,1
<b>Note</b>	

**12.15.11 ETHernet:STATus:PORT<Pt>:VLAN?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:VLAN?
<b>Description</b>	This query returns if any frames with VLAN are present.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<vlan> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:VLAN? → 1
<b>Note</b>	

**12.15.12 ETHernet:STATus:PORT<Pt>:SPeed?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:SPeed?
<b>Description</b>	This query returns the current speed. Unit: Mbps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<speed> = <NR1 NUMERIC RESPONSE DATA> 0 means no link.
<b>Example</b>	ETH:STAT:PORT1:SP? → 100
<b>Note</b>	

**12.15.13 ETHernet:STATus:PORT<Pt>:DUPLex?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:DUPLex?
<b>Description</b>	This query returns the current duplex type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<duplex> = <STRING RESPONSE DATA> "HDX": half duplex "FDX": full duplex "N/A": No link
<b>Example</b>	ETH:STAT:PORT1:DUPL? → "HDX"
<b>Note</b>	

**12.15.14 ETHernet:STATus:PORT<Pt>:MDI?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:MDI?
<b>Description</b>	This query returns the current MDI type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mdi> = <STRING RESPONSE DATA> "MDI" "MDIX" "N/A": No link
<b>Example</b>	ETH:STAT:PORT1:MDI? → "MDI"
<b>Note</b>	

**12.15.15 ETHernet:STATus:PORT<Pt>:L10G?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:L10G?
<b>Description</b>	Obsolete. For CMA 3000 backward compatibility only. Same as ETHernet:STATus:PORT<Pt>:LFS?
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lf> = <BOOLEAN RESPONSE DATA> <rf> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:L10G? → 1, 0
<b>Note</b>	

**12.15.16 ETHernet:STATus:PORT<Pt>:LFS?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:LFS?
<b>Description</b>	This query returns if any Local faults or Remote faults are present.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lf> = <BOOLEAN RESPONSE DATA> <rf> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:LFS? → 1, 0
<b>Note</b>	

**12.15.17 ETHernet:STATus:PORT<Pt>:ANComplete?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:ANComplete?
<b>Description</b>	This query returns if auto negotiation is completed.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ancomp> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:ANC? → 1
<b>Note</b>	

**12.15.18 ETHernet:STATus:PORT<Pt>:PCAPable?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PCAPable?
<b>Description</b>	This query returns the Link Partner Ability - Pause Capable
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pcable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PCAP? → 1
<b>Note</b>	ETHernet:STATus:PORT<Pt>:ANComplete? must be 1 before this query is valid.

**12.15.19 ETHernet:STATus:PORT<Pt>:APRequest?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:APRequest?
<b>Description</b>	This query returns the Link Partner Abilities - Asymmetric Pause Request
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<apreq> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:APR? → 1
<b>Note</b>	ETHernet:STATus:PORT<Pt>:ANComplete? must be 1 before this query is valid.

**12.15.20 ETHernet:STATus:PORT<Pt>:RFAult?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:RFAult?
<b>Description</b>	This query returns the Link Partner Abilities - Remote Fault
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rfault> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:RFA? → 1
<b>Note</b>	ETHernet:STATus:PORT<Pt>:ANComplete? must be 1 before this query is valid.

**12.15.21 ETHernet:STATus:PORT<Pt>:LCLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:LCLock?
<b>Description</b>	This query returns the local clock status at electrical gigabit connection.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <STRING RESPONSE DATA> "Slave" "Master" "Fault" "N/A": No link or not electrical gigabit connection.
<b>Example</b>	ETH:STAT:PORT1:LCL? → "Master"
<b>Notes</b>	ETHernet:STATus:PORT<Pt>:ANComplete? must be 1 before this query is valid.

**12.15.22 ETHernet:STATus:PORT<Pt>:SADuplex?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:SADuplex?
<b>Description</b>	This query returns the Link partner ability - speed and duplex
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<sad>),}* = <EXPRESSION RESPONSE DATA> 10MH: 10Mbps half duplex 10MF: 10Mbps full duplex 100MH: 100Mbps half duplex 100MF: 100Mbps full duplex 1GH: 1Gbps half duplex 1GF: 1Gbps full duplex
<b>Example</b>	ETH:STAT:PORT1:SAD? → (10MH,10MF,100MH,100MF)
<b>Note</b>	ETHernet:STATus:PORT<Pt>:ANComplete? must be 1 before this query is valid.

**12.15.23 ETHernet:STATus:PORT<Pt>:UTILization?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:UTILization?
<b>Description</b>	This query returns the current utilization. Unit: %.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<util> = <NR2 NUMERIC RESPONSE DATA> <threshold> = <BOOLEAN RESPONSE DATA> 1: Threshold exceeded 0: Threshold not exceeded / disabled
<b>Example</b>	ETH:STAT:PORT1:UTIL? → 97.1, 0
<b>Note</b>	

**12.15.24 ETHernet:STATus:PORT<Pt>:THRoughput?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:THRoughput?
<b>Description</b>	This query returns the current throughput. Unit: bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<thr> = <NR2 NUMERIC RESPONSE DATA> <threshold> = <BOOLEAN RESPONSE DATA> 1: Threshold exceeded 0: Threshold not exceeded / disabled
<b>Example</b>	ETH:STAT:PORT1:THR? → 97100000, 0
<b>Note</b>	

**12.15.25 ETHernet:STATus:PORT<Pt>:EFRames?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:EFRames?
<b>Description</b>	This query returns the current amount of errored frames. Unit: %.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<errored> = <NR2 NUMERIC RESPONSE DATA> <threshold> = <BOOLEAN RESPONSE DATA> 1: Threshold exceeded 0: Threshold not exceeded / disabled
<b>Example</b>	ETH:STAT:PORT1:EFR? → 0.5, 0
<b>Note</b>	

**12.15.26 ETHernet:STATus:PORT<Pt>:PCS:SHLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PCS:SHLock?
<b>Description</b>	This query returns whether or not 40/100G PCS sync header is locked.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<shlock> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PCS:SHL? → 1
<b>Note</b>	This command can be used on V2.00 or later

**12.15.27 ETHernet:STATus:PORT<Pt>:PCS:AMLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PCS:AMLock?
<b>Description</b>	This query returns whether or not 40/100G PCS alignment marker is locked.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<shlock> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PCS:AML? → 1
<b>Note</b>	This command can be used on V2.00 or later

**12.15.28 ETHernet:STATus:PORT<Pt>:TIMing?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:TIMing?
<b>Description</b>	This query returns the timing status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitRate> = <NR1 NUMERIC RESPONSE DATA> Unit: bps. <bitRateDeviation> = <NR1 NUMERIC RESPONSE DATA> Unit: ppb.
<b>Example</b>	ETH:STAT:PORT1:TIM? → 10000001000,100
<b>Note</b>	

**12.15.29 ETHernet:STATus:PORT<Pt>:TIMing:SOURce?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:TIMing:SOURce?
<b>Description</b>	This query returns the status of the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timingSrcProblem> = <BOOLEAN RESPONSE DATA> 1 is returned if the timing signal is absent.
<b>Example</b>	ETH:STAT:PORT1:TIM:SOUR? → 0
<b>Note</b>	

**12.15.30 ETHernet:STATus:PORT<Pt>:SYNCe?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:SYNCe?
<b>Description</b>	This query returns the status of the SyncE.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<qualityLevel> = <NR1 NUMERIC RESPONSE DATA> <qlTimeout> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:SYNC? → 15,0
<b>Note</b>	

**12.15.31 ETHernet:STATus:PORT<Pt>:PTP:LCLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PTP:LCLock?
<b>Description</b>	This query returns the status of the PTP clock.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<clockState> = <STRING RESPONSE DATA> "INITIALIZING", "FAULTY", "DISABLED", "LISTENING", "PRE_MASTER", "MASTER", "PASSIVE", "UNCALIBRATED" or "SLAVE". <offset> = <NR2 NUMERIC RESPONSE DATA> Unit: Seconds. <meanPathDelay> = <NR2 NUMERIC RESPONSE DATA> Unit: Seconds.
<b>Example</b>	ETH:STAT:PORT1:PTP:LCL? → "Listening",0.001002003,0.123456789
<b>Note</b>	

**12.15.32 ETHernet:STATus:PORT<Pt>:PTP:WCLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PTP:WCLock?
<b>Description</b>	This query returns the status of the PTP wall clock.
<b>Parameter</b>	<Pt> = Port number (1-2)
<b>Response</b>	<dateTime> = <STRING RESPONSE DATA> Format: "YYYY-MM-DDThh:mm:ss" <offset> = <NR1 NUMERIC RESPONSE DATA> Offset from UTC time given by an attached GPS receiver. Unit: Nano seconds.
<b>Example</b>	ETH:STAT:PORT1:PTP:WCL? → "2011-09-16T15:16:17",2345
<b>Note</b>	

**12.15.33 ETHernet:STATus:PORT<Pt>:PTP:PCLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PTP:PCLock?
<b>Description</b>	This query returns the properties of the PTP parent clock.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<parentId> = <STRING RESPONSE DATA> <parentPort> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PTP:PCL? → "00-00-00-00-00-00-00-00",0
<b>Note</b>	

**12.15.34 ETHernet:STATus:PORT<Pt>:PTP:GCLock?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PTP:GCLock?
<b>Description</b>	This query returns the properties of the grandmaster clock.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<clockId> = <STRING RESPONSE DATA> <class> = <NR1 NUMERIC RESPONSE DATA> <accuracy> = <NR1 NUMERIC RESPONSE DATA> <logVarianceOffsetAnnounced> = <NR3 NUMERIC RESPONSE DATA> <logVarianceOffsetObserved> = <NR3 NUMERIC RESPONSE DATA> <priority1> = <NR1 NUMERIC RESPONSE DATA> <priority2> = <NR1 NUMERIC RESPONSE DATA> <logVarianceOffsetAnnouncedRaw> = <NR1 NUMERIC RESPONSE DATA> <stepsRemoved> = <NR1 NUMERIC RESPONSE DATA> <timeSource> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PTP:GCL? → "00-00-00-00-00-00-00-00",255,254,1.23E-16,2.34E-16,255,255,22564,0,160
<b>Note</b>	

**12.15.35 ETHernet:STATus:PORT<Pt>:PTP:FMASters?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:PTP:FMASters?
<b>Description</b>	This query returns a list of maximum five foreign masters and their properties.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<master>),}* = <EXPRESSION RESPONSE DATA> <master> is split into three separate results (<clockId>,<port>,<announceCount>): <clockId> = <STRING RESPONSE DATA> <port> = <NR1 NUMERIC RESPONSE DATA> <announceCount> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:PTP:FMASters? → ("00-00-00-00-00-00-00-11",111,99), ("00-00-00-00-00-00-00-22",222,88)
<b>Note</b>	If the list is empty an execution error will be reported.

**12.15.36 ETHernet:STATus:PORT<Pt>:WAN:CAPTure:SOH:TRACe?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:WAN:CAPTure:SOH:TRACe?
<b>Description</b>	This query returns the section overhead trace (J0) for the latest captured frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J0_trace> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:WAN:CAPT:SOH:TRAC? → "Message_Test_J0"
<b>Notes</b>	If one of the alarms LOS or LOF is present, an empty string is returned. New frames are captured every second. This command can be used on V2.00 or later

**12.15.37 ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:SOH?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:SOH? <SOH-byte>
<b>Description</b>	This query returns the section overhead bytes from the selected frame.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <SOH-byte> = <CHARACTER PROGRAM DATA> A1: Returns 3 bytes. A2: Returns 3 bytes. J0: Returns 3 bytes. B1: Returns 3 bytes. E1: Returns 3 bytes. F1: Returns 3 bytes. D1: Returns 3 bytes. D2: Returns 3 bytes. D3: Returns 3 bytes. H1: Returns 3 bytes. H2: Returns 3 bytes. H3: Returns 3 bytes. B2: Returns 3 bytes. K1: Returns 3 bytes. K2: Returns 3 bytes. D4: Returns 3 bytes. D5: Returns 3 bytes. D6: Returns 3 bytes. D7: Returns 3 bytes. D8: Returns 3 bytes. D9: Returns 3 bytes. D10: Returns 3 bytes. D11: Returns 3 bytes. D12: Returns 3 bytes. S1: Returns 3 bytes. Z2: Returns 3 bytes. E2: Returns 3 bytes. M0: Returns 1 byte. M1: Returns 1 byte.
<b>Response</b>	<byte1>[,<byte2>[,<byte3>]] = <HEXADECIMAL NUMERIC RESPONSE DATA> Refer to <SOH-byte> parameter description above to see how many bytes this command returns.
<b>Examples</b>	ETH:STAT:PORT1:WAN:CAPT64:SOH? A1 → #HF6,#HF6,#HF6 ETH:STAT:PORT1:WAN:CAPT23:SOH? H1 → #H69,#H93,#H93 ETH:STAT:PORT1:WAN:CAPT1:SOH? M1 → #H00
<b>Notes</b>	If one of the alarms LOS or LOF is present NaN (section 1.6.1) is returned. 64 new frames are captured every second. This command can be used on V2.00 or later

**12.15.38 ETHernet:STATus:PORT<Pt>:WAN:CAPTure:POH:TRACe?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:WAN:CAPTure:POH:TRACe?
<b>Description</b>	This query returns the VC4 path overhead trace (J1) for the latest captured frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<J1_trace> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:WAN:CAPT:POH:TRAC? → "Message_Test_J1"
<b>Notes</b>	If one of the alarms LOS, LOF, UNEQ or LOP is present, an empty string is returned. New frames are captured every second. This command can be used on V2.00 or later



**12.15.39 ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:POH?**

<b>Syntax</b>	ETHernet:STATus:PORT<Pt>:WAN:CAPTure<Frame>:POH? <POH-byte>
<b>Description</b>	This query returns the VC4 path overhead bytes from the selected frame.
<b>Parameters</b>	<Pt> = Port number <Frame> = Frame number (1-64) <POH-byte> = <CHARACTER PROGRAM DATA> J1: J1 byte. B3: B3 byte. C2: C2 byte. G1: G1 byte. F2: F2 byte. H4: H4 byte. F3: F3 byte. K3: K3 byte. N1: N1 byte.
<b>Response</b>	<byte> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:STAT:PORT1:WAN:CAPT1:POH? H4 → #HFF
<b>Notes</b>	If one of the alarms LOS, LOF, UNEQ or LOP is present NaN (section 1.6.1) is returned. 64 new frames are captured every second. This command can be used on V2.00 or later

## 12.16 Ping

### 12.16.1 ETHernet:PING:START

<b>Syntax</b>	ETHernet:PING:START
<b>Description</b>	This command starts the Ping test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:PING:STAR
<b>Note</b>	

### 12.16.2 ETHernet:PING:STOP

<b>Syntax</b>	ETHernet:PING:STOP
<b>Description</b>	This command stops the Ping test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:PING:STOP
<b>Note</b>	

### 12.16.3 ETHernet:PING:SETup:PORT<Pt>:DMODE

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:DMODE <mode>
<b>Description</b>	This command sets the test mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> CONTInuous SECOnds REQuests <i>DEFault = REQuests</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:DMOD SEC
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:DMODE?
<b>Description</b>	This query returns the test mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:DMOD? → SEC
<b>Note</b>	This setting applies to all ports.

### 12.16.4 ETHernet:PING:SETup:PORT<Pt>:SDURATION

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:SDURATION <seconds>
<b>Description</b>	This command sets the test duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <seconds> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 2000000, DEFault = 30</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:SDUR 5
<b>Note</b>	DMODE must be set to SECOnds for this command to have effect. This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:SDURation?
<b>Description</b>	This query returns the test duration. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<seconds> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:SDUR? → 5
<b>Note</b>	This setting applies to all ports.

### 12.16.5 ETHernet:PING:SETup:PORT<Pt>:RDURation

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:RDURation <requests>
<b>Description</b>	This command sets the test duration. Unit: Requests.
<b>Parameters</b>	<Pt> = Port number <requests> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 65000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:RDUR 5
<b>Note</b>	DMODE must be set to REQuests for this command to have effect. This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:RDURation?
<b>Description</b>	This query returns the test duration. Unit: Requests.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<requests> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:RDUR? → 5
<b>Note</b>	This setting applies to all ports.

### 12.16.6 ETHernet:PING:SETup:PORT<Pt>:INTerval

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:INTerval <interval>
<b>Description</b>	This command sets the requests interval. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <interval> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 60, DEFault = 4</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:INT 5
<b>Note</b>	0 means that request are send as fast as possible. This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:INTerval?
<b>Description</b>	This query returns the requests interval. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<seconds> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:INT? → 5
<b>Note</b>	This setting applies to all ports.

### 12.16.7 ETHernet:PING:SETup:PORT<Pt>:FSIZE

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:FSIZE <size>
<b>Description</b>	This command sets the frame size. Unit: Bytes.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 70</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:FSIZ 100
<b>Notes</b>	<sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup. This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:FSIZe?
<b>Description</b>	This query returns the frame size. Unit: Bytes.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:FSIZ? → 100
<b>Note</b>	This setting applies to all ports.

### 12.16.8 ETHernet:PING:SETup:PORT<Pt>:TOUT

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:TOUT <timeout>
<b>Description</b>	This command sets the time out value. Unit: Milliseconds.
<b>Parameters</b>	<Pt> = Port number <timeout> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 15000, DEFault = 500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PING:SET:PORT1:TOUT 100
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	ETHernet:PING:SETup:PORT<Pt>:TOUT?
<b>Description</b>	This query returns the time out value. Unit: Milliseconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timeout> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:SET:PORT1:TOUT? → 100
<b>Note</b>	This setting applies to all ports.

### 12.16.9 ETHernet:PING:RESults:SUMMary?

<b>Syntax</b>	ETHernet:PING:RESults:SUMMary?
<b>Description</b>	This query returns the result summary.
<b>Parameter</b>	None.
<b>Response</b>	<sent> = <NR1 NUMERIC RESPONSE DATA> Number of sent requests. <received> = <NR1 NUMERIC RESPONSE DATA> Number of received responses. <lost> = <NR1 NUMERIC RESPONSE DATA> Number of request time outs.
<b>Example</b>	ETH:PING:RES:SUMM? → 10,7,3
<b>Note</b>	

### 12.16.10 ETHernet:PING:RESults:RTT?

<b>Syntax</b>	ETHernet:PING:RESults:RTT?
<b>Description</b>	Returns round trip times. Unit: Milliseconds.
<b>Parameter</b>	None.
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA> Minimum round trip time. <max> = <NR2 NUMERIC RESPONSE DATA> Maximum round trip time. <avg> = <NR2 NUMERIC RESPONSE DATA> Average round trip time.
<b>Example</b>	ETH:PING:RES:RTT? → 0.075,2.913,0.484
<b>Note</b>	

**12.16.11 ETHernet:PING:RESults:NREQuests?**

<b>Syntax</b>	ETHernet:PING:RESults:NREQuests?
<b>Description</b>	Returns the number of sent requests.
<b>Parameter</b>	None.
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PING:RES:NREQ? → 10
<b>Note</b>	

**12.16.12 ETHernet:PING:RESults:SREQuest?**

<b>Syntax</b>	ETHernet:PING:RESults:SREQuest? <index>
<b>Description</b>	Returns the result of a single request.
<b>Parameter</b>	{(<index>),}* = <EXPRESSION PROGRAM DATA> Expression format: Numeric List <i>MINimum</i> = 1
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> <result> is split into 2 separate results (<rtt>,<seq-nr>):  <rtt> = <NR2 NUMERIC RESPONSE DATA> Round trip time. Unit: Milliseconds. NaN (section 1.6.1) means time out.  <seq-nr> = <NR1 NUMERIC RESPONSE DATA> Request sequence number.
<b>Example</b>	ETH:PING:RES:SREQ? (1,3:5) → (2.913,1),(1.236,3),(3.528,4),(0.879,5)
<b>Notes</b>	Use the NREQuests command above to get the maximum allowed index. Results are returned in the order they are entered in the <index> parameter.

## 12.17 Traceroute

### 12.17.1 ETHernet:TRACeroute:STARt

<b>Syntax</b>	ETHernet:TRACeroute:STARt
<b>Description</b>	This command starts the Traceroute test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:STAR
<b>Note</b>	

### 12.17.2 ETHernet:TRACeroute:STOP

<b>Syntax</b>	ETHernet:TRACeroute:STOP
<b>Description</b>	This command stops the Traceroute test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:STOP
<b>Note</b>	

### 12.17.3 ETHernet:TRACeroute:SETup:NATTempts

<b>Syntax</b>	ETHernet:TRACeroute:SETup:NATTempts <attempts>
<b>Description</b>	This command sets the number of attempts.
<b>Parameter</b>	<attempts> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 1000000, DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:SET:NATT 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:TRACeroute:SETup:NATTempts?
<b>Description</b>	This query returns the number of attempts.
<b>Parameter</b>	None.
<b>Response</b>	<attempts> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TRAC:SET:NATT? → 5
<b>Note</b>	

### 12.17.4 ETHernet:TRACeroute:SETup:MNHops

<b>Syntax</b>	ETHernet:TRACeroute:SETup:MNHops <hops>
<b>Description</b>	This command sets the maximum number of hops.
<b>Parameter</b>	<hops> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 255, DEFault = 30</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:SET:MNH 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:TRACeroute:SETup:MNHops?
<b>Description</b>	This query returns the maximum number of hops.
<b>Parameter</b>	None.
<b>Response</b>	<hops> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TRAC:SET:MNH? → 5
<b>Note</b>	

### 12.17.5 ETHernet:TRACeroute:SETup:TOUT

<b>Syntax</b>	ETHernet:TRACeroute:SETup:TOUT <timeout>
<b>Description</b>	This command sets the time out value. Unit: Milliseconds.
<b>Parameter</b>	<timeout> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 15000, DEFault = 500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:SET:TOUT 100
<b>Note</b>	

<b>Syntax</b>	ETHernet:TRACeroute:SETup:TOUT?
<b>Description</b>	This query returns the time out value. Unit: Milliseconds.
<b>Parameter</b>	None.
<b>Response</b>	<timeout> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TRAC:SET:TOUT? → 100
<b>Note</b>	

### 12.17.6 ETHernet:TRACeroute:SETup:NTPHosts

<b>Syntax</b>	ETHernet:TRACeroute:SETup:NTPHosts <pings>
<b>Description</b>	This command sets the number of times to ping a host.
<b>Parameter</b>	<pings> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000000, DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TRAC:SET:NTPH 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:TRACeroute:SETup:NTPHosts?
<b>Description</b>	This query returns the number of times to ping a host.
<b>Parameter</b>	None.
<b>Response</b>	<pings> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TRAC:SET:NTPH? → 5
<b>Note</b>	

### 12.17.7 ETHernet:TRACeroute:RESults:NHOPs?

<b>Syntax</b>	ETHernet:TRACeroute:RESults:NHOPs?
<b>Description</b>	Returns the number of found hops.
<b>Parameter</b>	None.
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TRAC:RES:NHOP? → 10
<b>Note</b>	

## 12.17.8 ETHernet:TRACeroute:RESults:HOP?

<b>Syntax</b>	ETHernet:TRACeroute:RESults:HOP? <index>
<b>Description</b>	Returns the result from a single hop.
<b>Parameter</b>	{(<index>),}* = <EXPRESSION PROGRAM DATA> Expression format: Numeric List <i>MINimum</i> = 1
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> <result> is split into 5 separate results (<host>,<minrtt>,<maxrtt>,<avgrrt>,<timeouts>):  <host> = <STRING RESPONSE DATA> Host IP address. "d" at the end of the string means that this is the destination. "<timeout>" means that an IP address was unattainable.  <minrtt> = <NR2 NUMERIC RESPONSE DATA> Minimum Round trip time. Unit: Milliseconds. NaN (section 1.6.1) means no ping replies.  <maxrtt> = <NR2 NUMERIC RESPONSE DATA> Maximum Round trip time. Unit: Milliseconds. NaN (section 1.6.1) means no ping replies.  <avgrrt> = <NR2 NUMERIC RESPONSE DATA> Average Round trip time. Unit: Milliseconds. NaN (section 1.6.1) means no ping replies.  <timeouts> = <NR1 NUMERIC RESPONSE DATA> Number of ping timeouts. NaN (section 1.6.1) means no ping requests sent.
<b>Example</b>	ETH:TRAC:RES:HOP? (1:2) → ("192.168.1.1",0.7888,0.8278,0.8078,0), ("192.168.2.1(d)",0.5263,0.6689,0.591667,0)
<b>Notes</b>	Use NHOPs to get the maximum allowed index. Results are return in the order they are entered in the <index> parameter.



## 12.18 RFC2544

### 12.18.1 ETHernet:RFC:START

<b>Syntax</b>	ETHernet:RFC:START
<b>Description</b>	This command starts the RFC2544 test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:STAR
<b>Note</b>	

### 12.18.2 ETHernet:RFC:STOP

<b>Syntax</b>	ETHernet:RFC:STOP
<b>Description</b>	This command stops the RFC2544 test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:STOP
<b>Note</b>	

### 12.18.3 ETHernet:RFC:SETup:GENeral:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:MODE <mode>
<b>Description</b>	This command sets the RFC2544 test mode.
<b>Parameter</b>	<mode> = <CHARACTER PROGRAM DATA> SRouter: Switch/Router RLatency: Router latency SENetwork: Single ended network E2End: End to end network <i>DEFault = SR</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:RFC:SET:GEN:MODE SR ETH:RFC:SET:GEN:MODE E2E
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:MODE?
<b>Description</b>	This query returns the RFC2544 test mode.
<b>Parameter</b>	None.
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:MODE? → SEN
<b>Note</b>	

### 12.18.4 ETHernet:RFC:SETup:GENeral:TSElection

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TSElection <test>
<b>Description</b>	This command sets the RFC2544 tests to be executed.
<b>Parameter</b>	({<test>* {,}*} = <EXPRESSION PROGRAM DATA> THR: Throughput FLOS: Frame loss TAFL: Throughput and Frame loss LAT: Latency BURS: Burst
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:TSEL (FLOS,LAT,BURS)
<b>Note</b>	THR and/or FLOS can not be selected with TAFL. Setting no parameters will clear the test selection.

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TSElection?
<b>Description</b>	This query returns the RFC2544 test that will be executed.
<b>Parameter</b>	None.
<b>Response</b>	{(<test>),}* = <EXPRESSION RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:TSEL? → (FLOS,LAT,BUR)
<b>Note</b>	

### 12.18.5 ETHernet:RFC:SETup:GENeral:E2E:OWAY

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:OWAY <enable>
<b>Description</b>	This command sets One Way testing for End to End network test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:E2E:OWAY ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:OWAY?
<b>Description</b>	This query returns the state of End to End One Way testing.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:E2E:OWAY? → 1
<b>Note</b>	

### 12.18.6 ETHernet:RFC:SETup:GENeral:E2E:ADDRESS

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:ADDRESS <enable>
<b>Description</b>	This command enables/disables use of master source addresses for destination on slave side for End to End Network test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:E2E:ADDR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:ADDRESS?
<b>Description</b>	This query returns whether or not master source addresses are used for destination on slave side.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:E2E:ADDR? → 1
<b>Note</b>	

### 12.18.7 ETHernet:RFC:SETup:GENeral:E2E:TDIRrection

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:TDIRrection <dir>
<b>Description</b>	This command sets the End to End One Way transmission direction.
<b>Parameter</b>	<dir> = <CHARACTER PROGRAM DATA> MASTer: Master to slave SLAVe: Slave to master <i>DEFault = SLAVe</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:E2E:TDIR MAST
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:TDIRection?
<b>Description</b>	This query returns the End to End One Way transmission direction.
<b>Parameter</b>	None.
<b>Response</b>	<dir> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:E2E:TDIR? → MAST
<b>Note</b>	

### 12.18.8 ETHernet:RFC:SETup:GENeral:E2E:SSTore

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:SSTore <enable>
<b>Description</b>	This commands enables/disables storing of results on the slave side for End to End Network test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:E2E:SST OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:E2E:SSTore?
<b>Description</b>	This query returns whether or not results are stored on slave side in End to End Network test.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:E2E:SST? → 0
<b>Note</b>	

### 12.18.9 ETHernet:RFC:SETup:GENeral:TLFrames

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TLFrames <enable>
<b>Description</b>	This command enables/disables transmission of learning frames prior to test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:TLF OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TLFrames?
<b>Description</b>	This query returns whether or not learning frames are used.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:TLF? → 0
<b>Note</b>	

### 12.18.10 ETHernet:RFC:SETup:GENeral:IAFFilter

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:IAFFilter <enable>
<b>Description</b>	This command selects if addresses should be included in frame filter on receiver.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:IAFF OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:IAFFilter?
<b>Description</b>	This query returns whether or not addresses are included in frame filter on receiver.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:IAFF? → 0
<b>Note</b>	

### 12.18.11 ETHernet:RFC:SETup:GENeral:JITTer

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:JITTer <enable>
<b>Description</b>	This command enables/disables jitter measurement with latency test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:JITT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:JITTer?
<b>Description</b>	This query returns whether or not jitter measurement is enabled with latency test.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:JITT? → 1
<b>Note</b>	

### 12.18.12 ETHernet:RFC:SETup:GENeral:ACCumulate

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:ACCumulate <enable>
<b>Description</b>	This command sets if repeated steps should be accumulated.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:ACC OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:ACCumulate?
<b>Description</b>	This query returns whether or not repeated steps are accumulated.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:ACC? → 0
<b>Note</b>	

### 12.18.13 ETHernet:RFC:SETup:GENeral:TCLayer

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TCLayer <layer>
<b>Description</b>	This command selects the throughput calculation layer.
<b>Parameter</b>	<layer> = <CHARACTER PROGRAM DATA> UTIL: Utilization PHYP: Physical with preamble PHYS: Physical without preamble LINK: Link NETWork: Network DATA: Data <i>DEFault = PHYS</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:TCL LINK
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TCLayer?
<b>Description</b>	This query returns the throughput calculation layer.
<b>Parameter</b>	None.
<b>Response</b>	<layer> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:TCL? → LINK
<b>Note</b>	

#### 12.18.14 ETHernet:RFC:SETup:GENeral:TTYPe

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TTYPe <layer>
<b>Description</b>	This command sets the throughput calculation type.
<b>Parameter</b>	<type> = <CHARACTER PROGRAM DATA> AVG: Average MAX: Maximum <i>DEFault = MAX</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:GEN:TTYP AVG
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:GENeral:TTYPe?
<b>Description</b>	This query returns the throughput calculation type.
<b>Parameter</b>	None.
<b>Response</b>	<layer> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:GEN:TTYP? → AVG
<b>Note</b>	

## 12.19 RFC2544 - Throughput

### 12.19.1 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:MODE <mode>
<b>Description</b>	This command sets the RFC2544 throughput frame size mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> USER: User defined STEPped: Stepped CONStant: Constant <i>DEFault = USER</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:MODE?
<b>Description</b>	This query returns the RFC2544 throughput frame size mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:MODE? → CONS
<b>Note</b>	

### 12.19.2 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:USER

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:USER {<size>}*
<b>Description</b>	This command sets the RFC2544 throughput user defined frame size(s).
<b>Parameters</b>	<Pt> = Port number ({<size>} * {,}*) = <EXPRESSION PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 768: 768 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes JUMB: Jumbo frame size use :JUMBo to define.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:USER (64,256,JUMB)
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:USER?
<b>Description</b>	This query returns the RFC2544 throughput user defined frame size(s).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<size>),}* = <EXPRESSION RESPONSE DATA> <size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:USER? → (64,256,JUMB)
<b>Note</b>	

**12.19.3 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:JUMBo**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:JUMBo <size>
<b>Description</b>	This command sets the RFC2544 throughput jumbo frame size.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 1582</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:JUMB 6000
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:JUMBo?
<b>Description</b>	This query returns the RFC2544 throughput jumbo frame size.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:JUMB? → 6000
<b>Note</b>	

**12.19.4 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:BEGin <size>
<b>Description</b>	This command sets the RFC2544 throughput begin frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:BEG 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:BEGin?
<b>Description</b>	This query returns the RFC2544 throughput begin frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:BEG? → 128
<b>Note</b>	

**12.19.5 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZE:END <size>
<b>Description</b>	This command sets the RFC2544 throughput end frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:END 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:END?
<b>Description</b>	This query returns the RFC2544 throughput end frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:END? → 128
<b>Note</b>	

### 12.19.6 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:STEP <size>
<b>Description</b>	This command sets the RFC2544 throughput step frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:STEP 128
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:STEP?
<b>Description</b>	This query returns the RFC2544 throughput step frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:STEP? → 128
<b>Note</b>	

### 12.19.7 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:CONStant <size>
<b>Description</b>	This command sets the RFC2544 throughput frame size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:CONS 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:FSIZe:CONStant?
<b>Description</b>	This query returns the RFC2544 throughput frame size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:FSIZ:CONS? → 128
<b>Note</b>	

### 12.19.8 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STOP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STOP <enable>
<b>Description</b>	This command enables or disables stop on no frame loss at maximum utilization.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:STOP ON
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.



<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STOP?
<b>Description</b>	This query return the state of stop on no frame loss at maximum utilization.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:STOP? → 1
<b>Note</b>	

### 12.19.9 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MINimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MINimum <load>
<b>Description</b>	This command sets the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 1.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:MIN 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MINimum must be smaller or equal to :MAXimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MINimum? [<suffix>]
<b>Description</b>	This query returns the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:MIN? → 10
<b>Note</b>	

### 12.19.10 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MAXimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MAXimum <load>
<b>Description</b>	This command sets the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 100.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:MAX 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MAXimum must be larger or equal to :MINimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:MAXimum? [<suffix>]
<b>Description</b>	This query returns the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:MAX? → 10
<b>Note</b>	

### 12.19.11 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STEP <load>
<b>Description</b>	This command sets the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 10.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:STEP 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:STEP? [<suffix>]
<b>Description</b>	This query returns the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:STEP? → 10
<b>Note</b>	

### 12.19.12 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch[:ENABLE]

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the line load Auto Search.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:RFC:SET:PORT1:THR:LL:ASE ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch[:ENABLE]?
<b>Description</b>	This query returns whether or not the line load Auto Search is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:ASE? → 1
<b>Note</b>	

**12.19.13 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:MODE**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:MODE <mode>
<b>Description</b>	This command sets the auto search mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SMARt BINary <i>DEFault = SMARt</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:ASE:MODE BIN
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:MODE?
<b>Description</b>	This query returns the auto search mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:ASE:MODE? → BIN
<b>Note</b>	

**12.19.14 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:RESolution**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:RESolution <res>
<b>Description</b>	This command sets the auto search resolution.
<b>Parameters</b>	<Pt> = Port number <res> = <CHARACTER PROGRAM DATA> 01: 0.1% 1: 1% 10: 10% <i>DEFault = 01</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:ASE:RES 10
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:LLoad:ASEarch:RESolution?
<b>Description</b>	This query returns the auto search resolution.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<res> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:LL:ASE:RES? → 10
<b>Note</b>	

**12.19.15 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:STEP**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:STEP <step>
<b>Description</b>	This command sets the step duration. Unit: seconds.
<b>Parameters</b>	<Pt> = Port number <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 1000000000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:DUR:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:STEP?
<b>Description</b>	This query returns the step duration. Unit: Seconds. Unit: seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:DUR:STEP? → 5
<b>Note</b>	

### 12.19.16 ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:REPeats

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:REPeats <rep>
<b>Description</b>	This command sets the number of repeats.
<b>Parameters</b>	<Pt> = Port number <rep> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:THR:DUR:REP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:THRoughput:DURation:REPeats?
<b>Description</b>	This query returns the number of repeats.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rep> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:THR:DUR:REP? → 5
<b>Note</b>	

## 12.20 RFC2544 - Frame Loss

### 12.20.1 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:MODE <mode>
<b>Description</b>	This command sets the RFC2544 frame loss frame size mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> USER: User defined STEPped: Stepped CONStant: Constant <i>DEFault = USER</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:MODE?
<b>Description</b>	This query returns the RFC2544 frame loss frame size mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:MODE? → CONS
<b>Note</b>	

### 12.20.2 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:USER

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:USER {<size>}*
<b>Description</b>	This command sets the RFC2544 frame loss user defined frame size(s) for user defined mode.
<b>Parameters</b>	<Pt> = Port number ({<size>} * {,}*) = <EXPRESSION PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 768: 768 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes JUMB: Jumbo frame size use :JUMBo to define.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:USER (64,256,JUMB)
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:USER?
<b>Description</b>	This query returns the RFC2544 frame loss user defined frame size(s) for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<size>),}* = <EXPRESSION RESPONSE DATA> <size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:USER? → (64,256,JUMB)
<b>Note</b>	

**12.20.3 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:JUMBo**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:JUMBo <size>
<b>Description</b>	This command sets the RFC2544 frame loss jumbo frame size for user defined mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 1582</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:JUMB 6000
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:JUMBo?
<b>Description</b>	This query returns the RFC2544 frame loss jumbo frame size for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:JUMB? → 6000
<b>Note</b>	

**12.20.4 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:BEGin <size>
<b>Description</b>	This command sets the RFC2544 frame loss begin frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:BEG 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:BEGin?
<b>Description</b>	This query returns the RFC2544 frame loss begin frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:BEG? → 128
<b>Note</b>	

**12.20.5 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:END <size>
<b>Description</b>	This command sets the RFC2544 frame loss end frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:END 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:END?
<b>Description</b>	This query returns the RFC2544 frame loss end frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:END? → 128
<b>Note</b>	

### 12.20.6 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:STEP <size>
<b>Description</b>	This command sets the RFC2544 frame loss step frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:STEP 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:STEP?
<b>Description</b>	This query returns the RFC2544 frame loss step frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:STEP? → 128
<b>Note</b>	

### 12.20.7 ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:CONStant <size>
<b>Description</b>	This command sets the RFC2544 frame loss frame size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:CONS 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:FSIZe:CONStant?
<b>Description</b>	This query returns the RFC2544 frame loss frame size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:FSIZ:CONS? → 128
<b>Note</b>	

### 12.20.8 ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:STOP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:STOP <enable>
<b>Description</b>	This command enables or disables stop on no frame loss at maximum utilization.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:STOP ON
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:STOP?
<b>Description</b>	This query returns the state for stop on no frame loss at maximum utilization.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:STOP? → 1
<b>Note</b>	

### 12.20.9 ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:MINimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:MINimum <load>
<b>Description</b>	This command sets the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 1.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:MIN 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MINimum must be smaller or equal to :MAXimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:MINimum? [<suffix>]
<b>Description</b>	This query returns the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:MIN? → 10
<b>Note</b>	

### 12.20.10 ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:MAXimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOSs:LLoad:MAXimum <load>
<b>Description</b>	This command sets the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 100.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:MAX 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MAXimum must be larger or equal to :MINimum.



<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:MAXimum? [<suffix>]
<b>Description</b>	This query returns the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:MAX? → 10
<b>Note</b>	

### 12.20.11 ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:STEP <load>
<b>Description</b>	This command sets the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 10.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:STEP 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:STEP? [<suffix>]
<b>Description</b>	This query returns the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:STEP? → 10
<b>Note</b>	

### 12.20.12 ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASEarch[:ENABLE]

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASEarch[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the line load Auto Search.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASEarch[:ENABLE]?
<b>Description</b>	This query returns whether or not the line load Auto Search is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE? → 1
<b>Note</b>	

**12.20.13 ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:MODE**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:MODE <mode>
<b>Description</b>	This command sets the auto search mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SMARt BINary <i>DEFault = SMARt</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE:MODE BIN
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:MODE?
<b>Description</b>	This query returns the auto search mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE:MODE? → BIN
<b>Note</b>	

**12.20.14 ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:RESolution**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:RESolution <res>
<b>Description</b>	This command sets the auto search resolution.
<b>Parameters</b>	<Pt> = Port number <res> = <CHARACTER PROGRAM DATA> 01: 0.1% 1: 1% 10: 10% <i>DEFault = 01</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE:RES 10
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:LLoad:ASearch:RESolution?
<b>Description</b>	This query returns the auto search resolution.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<res> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:LL:ASE:RES? → 10
<b>Note</b>	

**12.20.15 ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:STEP**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:STEP <step>
<b>Description</b>	This command sets the step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 100000000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:DUR:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:STEP?
<b>Description</b>	This query returns the step duration. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:DUR:STEP? → 5
<b>Note</b>	

### 12.20.16 ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:REPeats

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:REPeats <rep>
<b>Description</b>	This command sets the number of repeats.
<b>Parameters</b>	<Pt> = Port number <rep> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:DUR:REP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:FLOs:DURation:REPeats?
<b>Description</b>	This query returns the number of repeats.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rep> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:FLOS:DUR:REP? → 5
<b>Note</b>	

## 12.21 RFC2544 - Throughput and Frame Loss

### 12.21.1 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:MODE <mode>
<b>Description</b>	This command sets the RFC2544 throughput and frame loss frame size mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> USER: User defined STEPped: Stepped CONStant: Constant <i>DEFault = USER</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:MODE?
<b>Description</b>	This query returns the RFC2544 throughput and frame loss frame size mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:MODE? → CONS
<b>Note</b>	

### 12.21.2 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:USER

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:USER {<size>}*
<b>Description</b>	This command sets the RFC2544 throughput and frame loss user defined frame size(s) for user defined mode.
<b>Parameters</b>	<Pt> = Port number ({<size>} * {,}*) = <EXPRESSION PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 768: 768 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes JUMB: Jumbo frame size use :JUMBo to define.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:USER (64,256,JUMB)
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:USER?
<b>Description</b>	This query returns the RFC2544 throughput and frame loss user defined frame size(s) for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<size>),}* = <EXPRESSION RESPONSE DATA> <size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:USER? → (64,256,JUMB)
<b>Note</b>	

**12.21.3 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:JUMBo**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:JUMBo <size>
<b>Description</b>	This command sets the RFC2544 throughput and frame loss jumbo frame size for user defined mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 1582</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:JUMB 6000
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:JUMBo?
<b>Description</b>	This query returns the RFC2544 throughput and frame loss jumbo frame size for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:JUMB? → 6000
<b>Note</b>	

**12.21.4 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:BEGin <size>
<b>Description</b>	This command sets the RFC2544 throughput and frame loss begin frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:BEG 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:BEGin?
<b>Description</b>	This query returns the RFC2544 throughput and frame loss begin frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:BEG? → 128
<b>Note</b>	

**12.21.5 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZE:END <size>
<b>Description</b>	This command sets the RFC2544 throughput and frame loss end frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:END 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:END?
<b>Description</b>	This query returns the RFC2544 throughput and frame loss end frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:END? → 128
<b>Note</b>	

### 12.21.6 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:STEP <size>
<b>Description</b>	This command sets the RFC2544 step frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:STEP 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:STEP?
<b>Description</b>	This query returns the RFC2544 step frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:STEP? → 128
<b>Note</b>	

### 12.21.7 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:CONStant <size>
<b>Description</b>	This command sets the RFC2544 frame size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:CONS 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:FSIZe:CONStant?
<b>Description</b>	This query returns the RFC2544 frame size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:FSIZ:CONS? → 128
<b>Note</b>	

### 12.21.8 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STOP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STOP <enable>
<b>Description</b>	This command enables or disables stop on no frame loss at maximum utilization.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:STOP ON
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STOP?
<b>Description</b>	This query returns the state for stop on no frame loss at maximum utilization.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:STOP? → 1
<b>Note</b>	

### 12.21.9 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MINimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MINimum <load>
<b>Description</b>	This command sets the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 1.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:MIN 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MINimum must be smaller or equal to :MAXimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MINimum? [<suffix>]
<b>Description</b>	This query returns the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:MIN? → 10
<b>Note</b>	

### 12.21.10 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MAXimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MAXimum <load>
<b>Description</b>	This command sets the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 100.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:MAX 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT. :MAXimum must be larger or equal to :MINimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:MAXimum? [<suffix>]
<b>Description</b>	This query returns the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:MAX? → 10
<b>Note</b>	

### 12.21.11 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STEP <load>
<b>Description</b>	This command sets the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 10.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:STEP 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:STEP? [<suffix>]
<b>Description</b>	This query returns the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:STEP? → 10
<b>Note</b>	

### 12.21.12 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch[:ENABLE]

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the line load Auto Search.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch[:ENABLE]?
<b>Description</b>	This query returns whether or not the line load Auto Search is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE? → 1
<b>Note</b>	



**12.21.13 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:MODE**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:MODE <mode>
<b>Description</b>	This command sets the auto search mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SMARt BINary <i>DEFault = SMARt</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE:MODE BIN
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:MODE?
<b>Description</b>	This query returns the auto search mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE:MODE? → BIN
<b>Note</b>	

**12.21.14 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:RESolution**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:RESolution <res>
<b>Description</b>	This command sets the auto search resolution.
<b>Parameters</b>	<Pt> = Port number <res> = <CHARACTER PROGRAM DATA> 01: 0.1% 1: 1% 10: 10% <i>DEFault = 01</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE:RES 10
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:LLoad:ASEarch:RESolution?
<b>Description</b>	This query returns the auto search resolution.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<res> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:LL:ASE:RES? → 10
<b>Note</b>	

**12.21.15 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:STEP**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:STEP <step>
<b>Description</b>	This command sets the step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 100000000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:DUR:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:STEP?
<b>Description</b>	This query returns the step duration. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:DUR:STEP? → 5
<b>Note</b>	

### 12.21.16 ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:REPeats

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:REPeats <rep>
<b>Description</b>	This command sets the number of repeats.
<b>Parameters</b>	<Pt> = Port number <rep> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:DUR:REP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:TAFLoss:DURation:REPeats?
<b>Description</b>	This query returns the number of repeats.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rep> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:TAFL:DUR:REP? → 5
<b>Note</b>	

## 12.22 RFC2544 - Latency

### 12.22.1 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:MODE <mode>
<b>Description</b>	This command sets the RFC2544 latency frame size mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> USER: User defined STEPped: Stepped CONStant: Constant <i>DEFault = USER</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:MODE?
<b>Description</b>	This query returns the RFC2544 latency frame size mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:MODE? → CONS
<b>Note</b>	

### 12.22.2 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:USER

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:USER {<size>}*
<b>Description</b>	This command sets the RFC2544 latency user defined frame size(s) for user defined mode.
<b>Parameters</b>	<Pt> = Port number ({<size>} * {,}*) = <EXPRESSION PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 768: 768 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes JUMB: Jumbo frame size use :JUMBo to define.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:USER (64,256,JUMB)
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:USER?
<b>Description</b>	This query returns the RFC2544 latency user defined frame size(s) for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<size>),}* = <EXPRESSION RESPONSE DATA> <size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:USER? → (64,256,JUMB)
<b>Note</b>	

**12.22.3 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:JUMBo**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:JUMBo <size>
<b>Description</b>	This command sets the RFC2544 latency the jumbo frame size for user defined mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 1582</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:JUMB 6000
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:JUMBo?
<b>Description</b>	This query returns the RFC2544 latency jumbo frame size for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:JUMB? → 6000
<b>Note</b>	

**12.22.4 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:BEGin <size>
<b>Description</b>	This command sets the RFC2544 latency begin frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:BEG 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:BEGin?
<b>Description</b>	This query returns the RFC2544 latency begin frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:BEG? → 128
<b>Note</b>	

**12.22.5 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZE:END <size>
<b>Description</b>	This command sets the RFC2544 latency end frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:END 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:END?
<b>Description</b>	This query returns the RFC2544 latency end frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:END? → 128
<b>Note</b>	

### 12.22.6 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:STEP <size>
<b>Description</b>	This command sets the RFC2544 latency step frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:STEP 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:STEP?
<b>Description</b>	This query returns the RFC2544 latency step frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:STEP? → 128
<b>Note</b>	

### 12.22.7 ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:CONStant <size>
<b>Description</b>	This command sets the RFC2544 latency frame size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:CONS 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:FSIZe:CONStant?
<b>Description</b>	This query returns the RFC2544 latency frame size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:FSIZ:CONS? → 128
<b>Note</b>	

## 12.22.8 ETHernet:RFC:SETup:PORT&lt;Pt&gt;:LATency:LLoad:MINimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:MINimum <load>
<b>Description</b>	This command sets the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 1.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:MIN 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. In Router Latency Mode the maximum allowed line load is 1Mbps. MINimum, MAXimum and DEFault are all in PCT. :MINimum must be smaller or equal to :MAXimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:MINimum? [<suffix>]
<b>Description</b>	This query returns the minimum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:MIN? → 10
<b>Note</b>	

## 12.22.9 ETHernet:RFC:SETup:PORT&lt;Pt&gt;:LATency:LLoad:MAXimum

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:MAXimum <load>
<b>Description</b>	This command sets the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 100.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:MAX 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. In Router Latency Mode the maximum allowed line load is 1Mbps. MINimum, MAXimum and DEFault are all in PCT. :MAXimum must be larger or equal to :MINimum.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:MAXimum? [<suffix>]
<b>Description</b>	This query returns the maximum line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:MAX? → 10
<b>Note</b>	

**12.22.10 ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:STEP**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:STEP <load>
<b>Description</b>	This command sets the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0008, MAXimum = 100.0000, DEFault = 10.0000</i> <i>Allowed suffixes = PCT, MBPS, KBPS. Default = PCT</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:STEP 10
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. In Router Latency Mode the maximum allowed line load is 1Mbps. MINimum, MAXimum and DEFault are all in PCT.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:STEP? [<suffix>]
<b>Description</b>	This query returns the step line load percentage.
<b>Parameters</b>	<Pt> = Port number <suffix> = <CHARACTER PROGRAM DATA> PCT: Percent KBPS: Kilo bit per second MBPS: Mega bit per second <i>DEFault = PCT</i>
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:STEP? → 10
<b>Note</b>	

**12.22.11 ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:ONLY**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:ONLY <enable>
<b>Description</b>	This command selects whether or not only to run steps where other test passed.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:ONLY ON
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:ONLY?
<b>Description</b>	This query returns 1 if only steps are run where other test passed.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:ONLY? → 1
<b>Note</b>	

## 12.22.12 ETHernet:RFC:SETup:PORT&lt;Pt&gt;:LATency:LLoad:OTEST

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:OTEST <test>
<b>Description</b>	This command selects the other test to follow.
<b>Parameters</b>	<Pt> = Port number <test> = <CHARACTER PROGRAM DATA> THROUGHput: Throughput FLOSs: Frame loss TAFLoss: Throughput and frame Loss <i>DEFault = THR</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:OTES FLOS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:OTEST?
<b>Description</b>	This query returns the test followed.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<test> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:OTES? → FLOS
<b>Note</b>	

## 12.22.13 ETHernet:RFC:SETup:PORT&lt;Pt&gt;:LATency:LLoad:TLEVel

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:TLEVel <tol>
<b>Description</b>	This command sets the Tolerance level percentage (Utilization multiplier). Unit: percentage.
<b>Parameters</b>	<Pt> = Port number <tol> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100, DEFault=100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:TLEV 85
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:LLoad:TLEVel?
<b>Description</b>	This query returns the Tolerance level percentage (Utilization multiplier).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tol> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:LL:TLEV? → 85
<b>Note</b>	

## 12.22.14 ETHernet:RFC:SETup:PORT&lt;Pt&gt;:LATency:DURation:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:STEP <step>
<b>Description</b>	This command sets the step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 100000000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:DUR:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.



<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:STEP?
<b>Description</b>	This query returns the step duration. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:DUR:STEP? → 5
<b>Note</b>	

### 12.22.15 ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:REPeats

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:REPeats <rep>
<b>Description</b>	This command sets the number of repeats.
<b>Parameters</b>	<Pt> = Port number <rep> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:DUR:REP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:LATency:DURation:REPeats?
<b>Description</b>	This query returns the number of repeats.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rep> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:LAT:DUR:REP? → 5
<b>Note</b>	

## 12.23 RFC2544 - Burst

### 12.23.1 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:MODE <mode>
<b>Description</b>	This command sets the RFC2544 burst frame size mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> USER: User defined STEPped: Stepped CONStant: Constant <i>DEFault = USER</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:MODE?
<b>Description</b>	This query returns the RFC2544 burst frame size mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:MODE? → CONS
<b>Note</b>	

### 12.23.2 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:USER

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:USER {<size>}*
<b>Description</b>	This command sets the RFC2544 burst user defined frame size(s) for user defined mode.
<b>Parameters</b>	<Pt> = Port number ({<size>} * {,}*) = <EXPRESSION PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 768: 768 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes JUMB: Jumbo frame size use :JUMBo to define.
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:USER (64,256,JUMB)
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:USER?
<b>Description</b>	This query returns the RFC2544 burst user defined frame size(s) for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<size>),}* = <EXPRESSION RESPONSE DATA> <size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:USER? → (64,256,JUMB)
<b>Note</b>	

**12.23.3 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:JUMBo**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:JUMBo <size>
<b>Description</b>	This command sets the RFC2544 burst jumbo frame size for user defined mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1519, MAXimum = 16000, DEFault = 1582</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:JUMB 6000
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:JUMBo?
<b>Description</b>	This query returns the RFC2544 burst jumbo frame size for user defined mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:JUMB? → 6000
<b>Note</b>	

**12.23.4 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:BEGin <size>
<b>Description</b>	This command sets the RFC2544 burst begin frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:BEG 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:BEGin?
<b>Description</b>	This query returns the RFC2544 burst begin frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:BEG? → 128
<b>Note</b>	

**12.23.5 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:END <size>
<b>Description</b>	This command sets the RFC2544 burst end frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:END 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:END?
<b>Description</b>	This query returns the RFC2544 burst end frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:END? → 128
<b>Note</b>	

### 12.23.6 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:STEP <size>
<b>Description</b>	This command sets the RFC2544 burst step frame size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 16000, DEFault = 64</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:STEP 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:STEP?
<b>Description</b>	This query returns the RFC2544 burst step frame size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:STEP? → 128
<b>Note</b>	

### 12.23.7 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:CONStant <size>
<b>Description</b>	This command sets the RFC2544 burst frame size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 44<sup>1</sup>, MAXimum = 16000, DEFault = 256</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:CONS 128
<b>Notes</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test. <sup>1</sup> The minimum allowed frame size varies depending on the stream frame setup.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FSIZe:CONStant?
<b>Description</b>	This query returns the RFC2544 burst frame size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FSIZ:CONS? → 128
<b>Note</b>	

**12.23.8 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:MODE**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:MODE <mode>
<b>Description</b>	This command sets the RFC2544 frames per burst mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> STEPped: Stepped CONStant: Constant <i>DEFault = STEPped</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:MODE CONS
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:MODE?
<b>Description</b>	This query returns the RFC2544 frames per burst mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:MODE? → CONS
<b>Note</b>	

**12.23.9 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:BEGin**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:BEGin <size>
<b>Description</b>	This command sets the RFC2544 burst begin size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 300000000, DEFault = 100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:BEG 10
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:BEGin?
<b>Description</b>	This query returns the RFC2544 burst begin size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:BEG? → 10
<b>Note</b>	

**12.23.10 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:END**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:END <size>
<b>Description</b>	This command sets the RFC2544 burst end size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 300000000, DEFault = 2000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:END 20
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:END?
<b>Description</b>	This query returns the RFC2544 burst end size for stepped mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:END? → 20
<b>Note</b>	

### 12.23.11 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STEP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STEP <size>
<b>Description</b>	This command sets the RFC2544 burst step size for stepped mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 300000000, DEFault = 100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STEP?
<b>Description</b>	This query returns the RFC2544 burst step size.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:STEP? → 5
<b>Note</b>	

### 12.23.12 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:CONStant

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:CONStant <size>
<b>Description</b>	This command sets the RFC2544 burst size for constant mode.
<b>Parameters</b>	<Pt> = Port number <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 300000000, DEFault = 2000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:CONS 500
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:CONStant?
<b>Description</b>	This query returns the RFC2544 burst size for constant mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:CONS? → 500
<b>Note</b>	

### 12.23.13 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STOP

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STOP <enable>
<b>Description</b>	This command enables or disables stop on no frame loss at maximum burst size.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:STOP ON
<b>Note</b>	This setting is used in Switch/Router and Single ended network mode.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:STOP?
<b>Description</b>	This query returns whether or not stop on no frame loss at maximum burst size is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:STOP? → 1
<b>Note</b>	

#### 12.23.14 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch[:ENABle]

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch[:ENABle] <enable>
<b>Description</b>	This command enables/disables frames per burst auto search.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE ON
<b>Note</b>	This setting is used in Switch/Router and Single ended network mode. In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch[:ENABle]?
<b>Description</b>	This query returns whether or not frames per burst auto search is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE? → 0
<b>Note</b>	

#### 12.23.15 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:MODE

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:MODE <mode>
<b>Description</b>	This command sets the frames per burst auto search mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SMARt: Smart search BINary: Binary search <i>DEFault = SMARt</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE:MODE SMAR
<b>Note</b>	This setting is used when ETH:RFC:SET:PORT1:BURS:FPB:ASE is enabled.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:MODE?
<b>Description</b>	This query returns the frames per burst auto search mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE:MODE? → SMAR,BIN
<b>Note</b>	

**12.23.16 ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:RESolution**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:RESolution <resolution>
<b>Description</b>	This command sets the frames per burst auto search resolution.
<b>Parameters</b>	<Pt> = Port number <resolution> = <CHARACTER PROGRAM DATA> PM1: 1 per mille ( 0.1%) PM10: 10 per mille ( 1.0%) PM100: 100 per mille (10.0%) <i>DEFault = PM1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE:RES PM10
<b>Note</b>	This setting is used when ETH:RFC:SET:PORT1:BURS:FPB:ASE is enabled.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:FPBurst:ASEarch:RESolution?
<b>Description</b>	This query returns the frames per burst auto search resolution.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<resolution> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:FPB:ASE:RES? → PM10
<b>Note</b>	

**12.23.17 ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:STEP**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:STEP <step>
<b>Description</b>	This command sets the RFC2544 burst step duration. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 3, MAXimum = 100000000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:DUR:STEP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:STEP?
<b>Description</b>	This query returns the step duration. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:DUR:STEP? → 5
<b>Note</b>	

**12.23.18 ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:REPeats**

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:REPeats <rep>
<b>Description</b>	This command sets the number of repeats.
<b>Parameters</b>	<Pt> = Port number <rep> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:DUR:REP 5
<b>Note</b>	In Switch/Router mode PORT1 setup is used. PORT2 setup can be set but will be ignored during the test.



---

<b>Syntax</b>	ETHernet:RFC:SETup:PORT<Pt>:BURSt:DURation:REPeats?
<b>Description</b>	This query returns the number of repeats.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rep> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:SET:PORT1:BURS:DUR:REP? → 5
<b>Note</b>	

## 12.24 RFC2544 - Result

### 12.24.1 ETHernet:RFC:RESult:TEST

<b>Syntax</b>	ETHernet:RFC:RESult:TEST <test>
<b>Description</b>	This command selects the test to fetch results from.
<b>Parameter</b>	<test> = <CHARACTER PROGRAM DATA> LATency: Latency test THRoughput: Throughput test FLOs: Frame loss test TAFLoss: Throughput and frame loss test BURSt: Burst test <i>DEFault = LATency</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:RES:TEST LAT
<b>Note</b>	This setting is not stored as part of a settings- or result file.

<b>Syntax</b>	ETHernet:RFC:RESult:TEST?
<b>Description</b>	This query returns the selected test to fetch results from.
<b>Parameter</b>	None.
<b>Response</b>	<test> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:RFC:RES:TEST? → LAT
<b>Note</b>	

### 12.24.2 ETHernet:RFC:RESult:PORT<Pt>:NSTep?

<b>Syntax</b>	ETHernet:RFC:RESult:PORT<Pt>:NSTep? <dir>
<b>Description</b>	This query returns the number of steps for a given port/direction for the selected test type.
<b>Parameters</b>	<Pt> = Port number <dir> = <CHARACTER PROGRAM DATA> TX = Transmitter TXR = Transmitter Remote (only E2E test mode) RX = Receiver RXR = Receiver Remote (only E2E test mode) <i>DEFault = TX</i>
<b>Response</b>	<steps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:RES:PORT1:NST? RX → 6
<b>Note</b>	Can only be used while a RFC test is in memory.

### 12.24.3 ETHernet:RFC:RESult:PORT<Pt>:SElect

<b>Syntax</b>	ETHernet:RFC:RESult:PORT<Pt>:SElect <dir>, <step>
<b>Description</b>	This command selects the direction and step to fetch results from.
<b>Parameters</b>	<Pt> = Port number <dir> = <CHARACTER PROGRAM DATA> TX = Transmitter TXR = Transmitter Remote (only E2E test mode) RX = Receiver RXR = Receiver Remote (only E2E test mode) <i>DEFault = TX</i> <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:RFC:RES:PORT1:SEL TX, 2
<b>Note</b>	Use the ETHernet:RFC:RESult:PORT<Pt>:NSTep? command (see section <a href="#">12.24.2</a> ) to get the number of steps. This setting is not stored as part of a settings- or result file.

<b>Syntax</b>	ETHernet:RFC:RESult:PORT<Pt>:SElect?
<b>Description</b>	This query returns the selected direction and step to fetch results from.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<dir> = <CHARACTER RESPONSE DATA> <step> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:RFC:RES:PORT1:SEL? → TX, 2
<b>Note</b>	

#### 12.24.4 ETHernet:RFC:RESult:PORT<Pt>:FETCh?

<b>Syntax</b>	ETHernet:RFC:RESult:PORT<Pt>:FETCh? <parameters>
<b>Description</b>	This query fetches the RFC2544 results.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {,}*) = &lt;EXPRESSION PROGRAM DATA&gt; The response format is listed for each parameter.</p> <p><b>Common</b></p> <p>REP: Repeat. Response: &lt;NR1&gt; STEP: Step. Response: &lt;NR1&gt; TFR: Total frames. Response: &lt;NR1&gt; FSIZ: Frame size. Unit: bytes. Response: &lt;NR1&gt; FRAT: Frame rate<sup>1</sup> (only TX). Unit: fps. Response: &lt;NR1&gt; LL: Line load<sup>1</sup> (only TX). Unit: Mbps<sup>2</sup>. Response: &lt;NR2&gt; LLA: Actual line load<sup>1</sup> (only TX). Unit: Mbps<sup>2</sup>. Response: &lt;NR2&gt; THR: Throughput<sup>1</sup> (only RX). Unit: Mbps<sup>2</sup>. Response: &lt;NR2&gt; UTIL: Utilization<sup>1</sup> (only RX). Unit: %. Response: &lt;NR2&gt;</p> <p><b>Latency</b></p> <p>LJIT: Latency/Jitter (Min,Max,Avg) (only RX). Unit: us. Response: &lt;NR2&gt;</p> <p><b>Throughput</b></p> <p>FLOS: Frames lost<sup>3</sup> (only RX). Response: &lt;NR2&gt;</p> <p><b>Frame Loss</b></p> <p>FLOS: Frames lost<sup>3</sup> (only RX). Response: &lt;NR2&gt; LRAT: Loss rate<sup>3</sup> (only RX). Unit: %. Response: &lt;NR2&gt;</p> <p><b>Throughput and Frame Loss</b></p> <p>FLOS: Frames lost<sup>3</sup> (only RX). Response: &lt;NR2&gt; LRAT: Loss rate<sup>3</sup> (only RX). Unit: %. Response: &lt;NR2&gt;</p> <p><b>Burst</b></p> <p>BSIZ: Burst size FLOS: Frames lost<sup>3</sup> (only RX). Response: &lt;NR2&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt; Expression format: Numeric List Each result is formatted according to the specification in the parameter field.</p>
<b>Example</b>	ETH:RFC:RES:PORT1:FETC? (REP,FSIZ,LL) → (0), (64), (90.0000)
<b>Notes</b>	<p>This query fetches the result from the test, direction and step selected by the ETHernet:RFC:RESult:TEST command (see section 12.24.1) and ETHernet:RFC:RESult:PORT&lt;Pt&gt;:SElect command (see section 12.24.3).</p> <p>If a requested result is not available, NaN (section 1.6.1) is returned.</p> <p>If there is one or more results, the last ", " is always removed.</p> <p><sup>1</sup> Not available for Burst Test.</p> <p><sup>2</sup> When running a Router Latency Test the unit is kbps.</p> <p><sup>3</sup> When Accumulate repeated steps is enabled, see ETHernet:RFC:SETup:GENeral:ACCumulate, three values are returned: (Min,Max,Avg).</p>

## 12.25 Y.1564 Service Activation Test

### 12.25.1 ETHernet:SATest:STARt

<b>Syntax</b>	ETHernet:SATest:STARt
<b>Description</b>	This command starts a service activation test (described in ITU-T Y.1564).
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:STAR
<b>Note</b>	

### 12.25.2 ETHernet:SATest:STOP

<b>Syntax</b>	ETHernet:SATest:STOP
<b>Description</b>	This command stops the service activation test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:STOP
<b>Note</b>	

### 12.25.3 ETHernet:SATest:SETup:TMODe

<b>Syntax</b>	ETHernet:SATest:SETup:TMODe <mode>
<b>Description</b>	This command sets the service activation test mode.
<b>Parameters</b>	<mode> = <CHARACTER PROGRAM DATA> OWAY: One-way testing RTRip: Round-trip testing <i>DEFault = RTRip</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:TMOD OWA
<b>Note</b>	For round-trip testing the test setup is done using the local-to-remote commands with the ":LTRemote" node, while the test result is retrieved using the remote-to-local commands with the "RTLocal" node.

<b>Syntax</b>	ETHernet:SATest:SETup:TMODe?
<b>Description</b>	This query returns the service activation test mode.
<b>Parameter</b>	None.
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:TMOD? → OW
<b>Note</b>	

### 12.25.4 ETHernet:SATest:SETup:OWTest:LTRemote[:ENABle]

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:LTRemote[:ENABle] <enable>
<b>Description</b>	This command enables/disables the one-way test in the local to remote direction.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:OWT:LTR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:LTRemote[:ENABle]?
<b>Description</b>	This query returns whether or not the local to remote direction is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:OWT:LTR? → 1
<b>Note</b>	

**12.25.5 ETHernet:SATest:SETup:OWTest:RTLocal[:ENABLE]**

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:RTLocal[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the one-way test in the remote to local direction.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:OWT:RTL ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:RTLocal[:ENABLE]?
<b>Description</b>	This query returns whether or not the remote to local direction is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:OWT:RTL? → 1
<b>Note</b>	

**12.25.6 ETHernet:SATest:SETup:OWTest:BSYMMetry**

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:BSYMMetry <symmetry>
<b>Description</b>	This command sets the one-way test bandwidth symmetry.
<b>Parameters</b>	<symmetry> = <CHARACTER PROGRAM DATA> SYMMetric: Symmetric bandwidth ASYMMetric: Asymmetric bandwidth <i>DEFault = SYMMetric</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:OWT:BSYM SYMM
<b>Note</b>	The value is significant only for bi-directional one-way tests (both ETHernet:SATest:SETup:OWTest:RTLocal and ETHernet:SATest:SETup:OWTest:LTRemote are enabled). For bi-directional one-way tests using SYMMetric bandwidth setup, it is the ETHernet:SATest:SETup:SERvice<no>[:LTRemote] node that are used to define the traffic in both directions.

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:BSYMMetry?
<b>Description</b>	This query returns the bandwidth symmetry parameter.
<b>Parameter</b>	None.
<b>Response</b>	<symmetry> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:OWT:BSYM? → SYMM
<b>Note</b>	

**12.25.7 ETHernet:SATest:SETup:OWTest:SYNChronization**

<b>Syntax</b>	ETHernet:SATest:SETup:OWTest:SYNChronization <mode>
<b>Description</b>	This command sets the one-way test time synchronization mode.
<b>Parameters</b>	<mode> = <CHARACTER PROGRAM DATA> PRETest: Pre-test synchronization GPS: GPS. <i>DEFault = PRETest</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:OWT:SYNC PRET
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:OWTest:SYNChronization?
<b>Description</b>	This query returns the time synchronization mode.
<b>Parameter</b>	None.
<b>Response</b>	<symmetry> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:OWT:SYNC? → GPS
<b>Note</b>	

### 12.25.8 ETHernet:SAtest:SETup:OWTest:TLSAddresses[:ENABle]

<b>Syntax</b>	ETHernet:SAtest:SETup:OWTest:TLSAddresses[:ENABle] <enable>
<b>Description</b>	This command enables/disables transfer of local source addresses to be used as destination addresses on remote side.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:OWT:TLISA ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:OWTest:TLSAddresses[:ENABle]?
<b>Description</b>	This query returns whether or not local source addresses are used as destination addresses on remote side.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:OWT:TLISA? → 1
<b>Note</b>	

### 12.25.9 ETHernet:SAtest:SETup:CCFC

<b>Syntax</b>	ETHernet:SAtest:SETup:CCFC <enable>
<b>Description</b>	This command enables/disables compatible configuration frames with CMA3000 and V2.X or older.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:CCFC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:CCFC?
<b>Description</b>	This query returns the state of compatible configuration frames with CMA3000 and V2.X or older.
<b>Parameter</b>	None
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:CCFC? → 1
<b>Note</b>	

### 12.25.10 ETHernet:SAtest:SETup:CBRate

<b>Syntax</b>	ETHernet:SAtest:SETup:CBRate <unit>
<b>Description</b>	This command sets the calculated bit rate base.
<b>Parameters</b>	<unit> = <CHARACTER PROGRAM DATA> IRATe: Information rate ULRate: Utilized line rate <i>DEFault = IRATe</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:CBR IRAT
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:CBRate?
<b>Description</b>	This query returns the calculated bit rate base.
<b>Parameter</b>	None.
<b>Response</b>	<unit> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:CBR? → IRAT
<b>Note</b>	

### 12.25.11 ETHernet:SAtest:SETup:SPTDuration

<b>Syntax</b>	ETHernet:SAtest:SETup:SPTDuration <duration>
<b>Description</b>	This command sets the service performance test duration.
<b>Parameters</b>	<duration> = <CHARACTER PROGRAM DATA> 15M: 15 minutes 2H: 2 hours 24H: 24 hours CUSTom: Use the custom value <i>DEFault = CUSTom</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SPTD 15M
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SPTDuration?
<b>Description</b>	This query returns the service performance test duration.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SPTD? → 15M
<b>Note</b>	

### 12.25.12 ETHernet:SAtest:SETup:SPTDuration:CDURATION

<b>Syntax</b>	ETHernet:SAtest:SETup:SPTDuration:CDURATION <hours>,<minutes>,<seconds>
<b>Description</b>	This command sets the service performance test custom duration.
<b>Parameters</b>	<hours> = <NUMERIC PROGRAM DATA> (0-23) <minutes> = <NUMERIC PROGRAM DATA> (0-1439) <seconds> = <NUMERIC PROGRAM DATA> (0-86399)
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SPTD:CDUR 0,5,0
<b>Note</b>	Although larger number can be given, duration cannot exceed 23 hours, 59 minutes and 59 seconds.

<b>Syntax</b>	ETHernet:SAtest:SETup:SPTDuration:CDURATION?
<b>Description</b>	This query returns the service performance test custom duration.
<b>Parameter</b>	None.
<b>Response</b>	<hours> = <NR1 NUMERIC RESPONSE DATA> <minutes> = <NR1 NUMERIC RESPONSE DATA> <seconds> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SPTD:CDUR? → 0,5,0
<b>Note</b>	

**12.25.13 ETHernet:SATest:SETup:COFail**

<b>Syntax</b>	ETHernet:SATest:SETup:COFail <enable>
<b>Description</b>	This command enables/disables continue on fail. When enabled, all the service configuration tests are performed despite violation of the service acceptance criteria.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:COF OFF
<b>Note</b>	Service performance test is never performed if the service acceptance criteria is exceeded.

<b>Syntax</b>	ETHernet:SATest:SETup:COFail?
<b>Description</b>	This query returns whether or not continue on fail is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:COF? → 0
<b>Note</b>	

**12.25.14 ETHernet:SATest:SETup:GENeral:IAFFilter**

<b>Syntax</b>	ETHernet:SATest:SETup:GENeral:IAFFilter
<b>Description</b>	This command selects if addresses should be included in frame filter on receiver.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:GEN:IAFF ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:GENeral:IAFFilter?
<b>Description</b>	This query returns addresses should be included in frame filter on receiver.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:GEN:IAFF? → 1
<b>Note</b>	

**12.25.15 ETHernet:SATest:SETup:SERvice<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables a service.
<b>Parameters</b>	<no> = Service number (1-8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not a service is enabled.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV? → 0
<b>Note</b>	



**12.25.16 ETHernet:SATest:SETup:SERvice<no>:NAME**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:NAME <name>
<b>Description</b>	This command changes the name of a service.
<b>Parameters</b>	<no> = Service number (1-8) <name> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:NAME "Video"
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:NAME?
<b>Description</b>	This query returns the name of a service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:NAME? → "Video"
<b>Note</b>	

**12.25.17 ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate] <rate>
<b>Description</b>	This command sets the committed information rate for the specified service. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <rate> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1 1.12
<b>Note</b>	If set to zero, the CIR test steps are excluded. This value is automatically calculated when the profile is Video or Voice. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote][:CIRate]?
<b>Description</b>	This query returns the committed information rate for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<rate> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1? → 1.12
<b>Note</b>	

**12.25.18 ETHernet:SATest:SETup:SERvice<no>:RTLocal[:CIRate]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal[:CIRate] <rate>
<b>Description</b>	This command sets the committed information rate for the specified service. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <rate> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL 1.12
<b>Note</b>	If set to zero, the CIR test steps are excluded. This value is automatically calculated when the profile is Video or Voice. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal[:CIRate]?
<b>Description</b>	This query returns the committed information rate for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<rate> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL? → 1.12
<b>Note</b>	

**12.25.19 ETHernet:SATest:SETup:SERVice<no>[:LTRemote][:CIRate]:PROFile**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote][:CIRate]:PROFile <profile>
<b>Description</b>	This command sets the stream Profile.
<b>Parameters</b>	<no> = Service number (1-8) <profile> = <CHARACTER PROGRAM DATA> DATA: Data VIDeo: Video VOICe: Voice <i>DEFault = DATA</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:PROF VID
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote][:CIRate]:PROFile?
<b>Description</b>	This query returns the stream Profile.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:PROF? → VID
<b>Note</b>	

**12.25.20 ETHernet:SATest:SETup:SERVice<no>:RTLocal[:CIRate]:PROFile**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal[:CIRate]:PROFile <profile>
<b>Description</b>	This command sets the stream Profile.
<b>Parameters</b>	<no> = Service number (1-8) <profile> = <CHARACTER PROGRAM DATA> DATA: Data VIDeo: Video VOICe: Voice <i>DEFault = DATA</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:PROF VID
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal[:CIRate]:PROFile?
<b>Description</b>	This query returns the stream Profile.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:PROF? → VID
<b>Note</b>	

**12.25.21 ETHernet:SATest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VIDeo**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VIDeo <encoding>
<b>Description</b>	This command sets the stream Encoding Video.
<b>Parameters</b>	<no> = Service number (1-8) <encoding> = <CHARACTER PROGRAM DATA> SDMPEG2: SDTV (MPEG2) HDMPEG2: HDTV (MPEG2) HDMPEG4: MPEG4 (H.264) SD <i>DEFault = SDMPEG2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:ENC:VID HDMPEG2
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VIDeo?
<b>Description</b>	This query returns the stream Encoding Video.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<encoding> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:ENC:VID? → HDMPEG2
<b>Note</b>	

### 12.25.22 ETHernet:SAtest:SETup:SERVice<no>:RTLocal[:CIRate]:ENCoding:VIDeo

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal[:CIRate]:ENCoding:VIDeo <encoding>
<b>Description</b>	This command sets the stream Encoding Video.
<b>Parameters</b>	<no> = Service number (1-8) <encoding> = <CHARACTER PROGRAM DATA> SDMPEG2: SDTV (MPEG2) HDMPEG2: HDTV (MPEG2) HDMPEG4: MPEG4 (H.264) SD <i>DEFault = SDMPEG2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:ENC:VID HDMPEG2
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal[:CIRate]:ENCoding:VIDeo?
<b>Description</b>	This query returns the stream Encoding Video.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<encoding> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:ENC:VID? → HDMPEG2
<b>Note</b>	

### 12.25.23 ETHernet:SAtest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VOICe

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VOICe <encoding>
<b>Description</b>	This command sets the stream Encoding Voice.
<b>Parameters</b>	<no> = Service number (1-8) <encoding> = <CHARACTER PROGRAM DATA> G711: VoIP G.711 G7231: VoIP G.723.1 G729: VoIP G.729 <i>DEFault = G711</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:ENC:VOIC G7231
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>[:LTRemote][:CIRate]:ENCoding:VOICe?
<b>Description</b>	This query returns the stream Encoding Voice.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<encoding> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:ENC:VOIC? → G7231
<b>Note</b>	

## 12.25.24 ETHernet:SAtest:SETup:SERvice&lt;no&gt;:RTLocal[:CIRate]:ENCoding:VOICe

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal[:CIRate]:ENCoding:VOICe <encoding>
<b>Description</b>	This command sets the stream Encoding Voice.
<b>Parameters</b>	<no> = Service number (1-8) <encoding> = <CHARACTER PROGRAM DATA> G711: VoIP G.711 G7231: VoIP G.723.1 G729: VoIP G.729 <i>DEFault = G711</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:ENC:VOIC G7231
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal[:CIRate]:ENCoding:VOICe?
<b>Description</b>	This query returns the stream Encoding Voice.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<encoding> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:ENC:VOIC? → G7231
<b>Note</b>	

## 12.25.25 ETHernet:SAtest:SETup:SERvice&lt;no&gt;[:LTRemote]:CIRate:NCHannels

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CIRate:NCHannels <channel>
<b>Description</b>	This command sets the number of channels.
<b>Parameters</b>	<no> = Service number (1-8) <channel> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 100000, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:NCH 3
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CIRate:NCHannels?
<b>Description</b>	This query returns the number of channels.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<channel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:NCH? → 3
<b>Note</b>	

## 12.25.26 ETHernet:SAtest:SETup:SERvice&lt;no&gt;:RTLocal[:CIRate]:NCHannels

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal[:CIRate]:NCHannels <channel>
<b>Description</b>	This command sets the number of channels.
<b>Parameters</b>	<no> = Service number (1-8) <channel> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 100000, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:NCH 3
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal[:CIRate]:NCHannels?
<b>Description</b>	This query returns the number of channels.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<channel> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:NCH? → 3
<b>Note</b>	

**12.25.27 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EIRate**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EIRate <rate>
<b>Description</b>	This command sets the excess information rate for the specified service. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <rate> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:EIR 0.10
<b>Note</b>	If set to zero, the CIR test steps are excluded. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EIRate?
<b>Description</b>	This query returns the excess information rate for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<rate> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:EIR? → 0.12
<b>Note</b>	

**12.25.28 ETHernet:SATest:SETup:SERVice<no>:RTLocal:EIRate**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:EIRate <rate>
<b>Description</b>	This command sets the excess information rate for the specified service. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <rate> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EIR 0.12
<b>Note</b>	If set to zero, the CIR test steps are excluded. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLLocal:EIRate?
<b>Description</b>	This query returns the excess information rate for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<rate> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EIR? → 0.12
<b>Note</b>	

**12.25.29 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:TPOLicing[:ENABle]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:TPOLicing[:ENABle] <enable>
<b>Description</b>	This command enables/disables the traffic policing test steps.
<b>Parameters</b>	<no> = Service number (1-8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:TPOL OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:TPOLicing[:ENABle]?
<b>Description</b>	This query returns whether or not traffic policing test is enabled.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:TPOL? → 0
<b>Note</b>	

**12.25.30 ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing[:ENABLE]**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the traffic policing test steps.
<b>Parameters</b>	<no> = Service number (1-8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:TPOL OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing[:ENABLE]?
<b>Description</b>	This query returns whether or not traffic policing test not is enabled.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:TPOL? → 0
<b>Note</b>	

**12.25.31 ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:TPOLicing:MARGin**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:TPOLicing:MARGin <margin>
<b>Description</b>	This command sets the acceptable traffic policing margin. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <margin> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:TPOL:MARG 10
<b>Note</b>	The minimum possible margin is 0.01 Mbps for line speeds up to 1Gbps. The minimum possible margin is 0.10 Mbps for 10Gbps line speeds. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:TPOLicing:MARGin?
<b>Description</b>	This query returns the acceptable traffic policing margin.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<margin> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:TPOL:MARG? → 10.15
<b>Note</b>	

**12.25.32 ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing:MARGin**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing:MARGin <margin>
<b>Description</b>	This command sets the acceptable traffic policing margin. Unit: Mbps.
<b>Parameters</b>	<no> = Service number (1-8) <margin> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = see note<sup>1</sup>, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:TPOL:MARG 10
<b>Note</b>	The minimum possible margin is 0.01 Mbps for line speeds up to 1Gbps. The minimum possible margin is 0.10 Mbps for 10Gbps line speeds. <sup>1</sup> Maximum value depends on the current frame size setup.

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:TPOLicing:MARGin?
<b>Description</b>	This query returns the acceptable traffic policing margin.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<margin> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:TPOL:MARG? → 10.15
<b>Note</b>	

**12.25.33 ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CBSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CBSize <size>
<b>Description</b>	This command sets the committed burst size for the specified service. Unit: Bytes.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:CBS 10000
<b>Note</b>	If set to zero, the CBS test is excluded. If set to a value greater than zero but below the MTU size then the MTU size will be applied.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CBSize?
<b>Description</b>	This query returns the committed burst size for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:CBS? → 10000
<b>Note</b>	

**12.25.34 ETHernet:SATest:SETup:SERvice<no>:RTLocal:CBSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:CBSize <size>
<b>Description</b>	This command sets the committed burst size for the specified service. Unit: Bytes.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CBS 10000
<b>Note</b>	If set to zero, the CBS test is excluded. If set to a value greater than zero but below the MTU size then the MTU size will be applied.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:CBSize?
<b>Description</b>	This query returns the committed burst size for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CBS? → 10000
<b>Note</b>	

**12.25.35 ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:EBSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:EBSize <size>
<b>Description</b>	This command sets the excess burst size for the specified service. Unit: Bytes.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:EBS 10000
<b>Note</b>	If set to zero, the EBS test is excluded. If set to a value greater than zero but below the MTU size then the MTU size will be applied.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:EBSize?
<b>Description</b>	This query returns the excess burst size for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:EBS? → 1
<b>Note</b>	

**12.25.36 ETHernet:SATest:SETup:SERvice<no>:RTLocal:EBSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:EBSize <size>
<b>Description</b>	This command sets the excess burst size for the specified service. Unit: Bytes.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EBS 1
<b>Note</b>	If set to zero, the EBS test is excluded. If set to a value greater than zero but below the MTU size then the MTU size will be applied.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:EBSize?
<b>Description</b>	This query returns the excess burst size for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EBS? → 1
<b>Note</b>	

**12.25.37 ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare[:ENABLE]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the color awareness of a service.
<b>Parameters</b>	<no> = Service number (1-8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:CAV OFF
<b>Note</b>	When disabled the color mode is colorblind.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:CAVare[:ENABLE]?
<b>Description</b>	This query returns whether or not color awareness of a service service is enabled.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:CAV? → 0
<b>Note</b>	

**12.25.38 ETHernet:SATest:SETup:SERvice<no>:RTLocal:CAVare[:ENABLE]**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:CAVare[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the color awareness of a service.
<b>Parameters</b>	<no> = Service number (1-8) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV OFF
<b>Note</b>	When disabled the color mode is colorblind.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:CAVare[:ENABLE]?
<b>Description</b>	This query returns whether or not color awareness of a service service is enabled.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV? → 0
<b>Note</b>	



**12.25.39 ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:CMETHOD**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:CMETHOD <method>
<b>Description</b>	This command sets the color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <method> = <CHARACTER PROGRAM DATA> DSCP: Differentiated Services Code Point PCP: Priority Code Point <i>DEFault = DSCP</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:CAV:CMET DSCP
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:CMETHOD?
<b>Description</b>	This query returns the color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<method> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:CAV:CMET? → DSCP
<b>Note</b>	

**12.25.40 ETHernet:SAtest:SETup:SERvice<no>:RTLocal:CAVare:CMETHOD**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:CAVare:CMETHOD <method>
<b>Description</b>	This command sets the color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <method> = <CHARACTER PROGRAM DATA> DSCP: Differentiated Service Code Point PCP: Priority Code Point <i>DEFault = DSCP</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:CAV:CMET DSCP
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>:RTLocal:CAVare:CMETHOD?
<b>Description</b>	This query returns the color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<method> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:RTL:CAV:CMET? → DSCP
<b>Note</b>	

**12.25.41 ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:DSCP:GREEN**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:DSCP:GREEN <value>
<b>Description</b>	This command sets the green value for the DSCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 63, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAtest:SET:SERV1:CAV:DSCP:GRE 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERvice<no>[:LTRemote]:CAVare:DSCP:GREEN?
<b>Description</b>	This query returns the green value for the DSCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAtest:SET:SERV1:CAV:DSCP:GRE? → 1
<b>Note</b>	

**12.25.42 ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:GREen**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:GREen <value>
<b>Description</b>	This command sets the green value for the DSCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 63, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SA:SET:SERV1:RTL:CAV:DSCP:GRE 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:GREen?
<b>Description</b>	This query returns the green value for the DSCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SA:SET:SERV1:RTL:CAV:DSCP:GRE? → 1
<b>Note</b>	

**12.25.43 ETHernet:SAtest:SETup:SERVice<no>[:LTRemote]:CAVare:DSCP:YELLow**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>[:LTRemote]:CAVare:DSCP:YELLow <value>
<b>Description</b>	This command sets the yellow value for the DSCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 63, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SA:SET:SERV1:CAV:DSCP:YELL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>[:LTRemote]:CAVare:DSCP:YELLow?
<b>Description</b>	This query returns the yellow value for the DSCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SA:SET:SERV1:CAV:DSCP:YELL? → 1
<b>Note</b>	

**12.25.44 ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:YELLow**

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:YELLow <value>
<b>Description</b>	This command sets the yellow value for the DSCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 63, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SA:SET:SERV1:RTL:CAV:DSCP:YELL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SAtest:SETup:SERVice<no>:RTLocal:CAVare:DSCP:YELLow?
<b>Description</b>	This query returns the yellow value for the DSCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SA:SET:SERV1:RTL:CAV:DSCP:YELL? → 1
<b>Note</b>	

**12.25.45 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:GREen**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:GREen <value>
<b>Description</b>	This command sets the green value for the PCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:CAV:PCP:GRE 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:GREen?
<b>Description</b>	This query returns the green value for the PCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:CAV:PCP:GRE? → 1
<b>Note</b>	

**12.25.46 ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:GREen**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:GREen <value>
<b>Description</b>	This command sets the green value for the PCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV:PCP:GRE 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:GREen?
<b>Description</b>	This query returns the green value for the PCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV:PCP:GRE? → 1
<b>Note</b>	

**12.25.47 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:YELLow**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:YELLow <value>
<b>Description</b>	This command sets the yellow value for the PCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:CAV:PCP:YELL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CAVare:PCP:YELLow?
<b>Description</b>	This query returns the yellow value for the PCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:CAV:PCP:YELL? → 1
<b>Note</b>	

**12.25.48 ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:YELLow**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:YELLow <value>
<b>Description</b>	This command sets the yellow value for the PCP color method for the specified service.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV:PCP:YELL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CAVare:PCP:YELLow?
<b>Description</b>	This query returns the yellow value for the PCP color method for the specified service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CAV:PCP:YELL? → 1
<b>Note</b>	

**12.25.49 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FTDdelay**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FTDdelay <delay>
<b>Description</b>	This command sets the acceptable frame transfer delay value. Unit: ms.
<b>Parameters</b>	<no> = Service number (1-8) <delay> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 2000.000, DEFault = 0.500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FTD 1.100
<b>Note</b>	The precision is three decimals.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FTDdelay?
<b>Description</b>	This query returns the acceptable frame transfer delay value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<delay> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FTD? → 10.000
<b>Note</b>	

**12.25.50 ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FTDdelay**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FTDdelay <delay>
<b>Description</b>	This command sets the acceptable frame transfer delay value. Unit: ms.
<b>Parameters</b>	<no> = Service number (1-8) <delay> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 2000.000, DEFault = 0.500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FTD 10.000
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FTDdelay?
<b>Description</b>	This query returns the acceptable frame transfer delay value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<delay> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FTD? → 10.000
<b>Note</b>	

**12.25.51 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FDVariation**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FDVariation <variation>
<b>Description</b>	This command sets the acceptable frame delay variation value. Unit: ms.
<b>Parameters</b>	<no> = Service number (1-8) <variation> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 2000.000, DEFault = 0.050</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FDV 20.000
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FDVariation?
<b>Description</b>	This query returns the acceptable frame delay variation value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<variation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FDV? → 20.000
<b>Note</b>	

**12.25.52 ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FDVariation**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLLocal:SACRiteria:FDVariation <variation>
<b>Description</b>	This command sets the acceptable frame delay variation value. Unit: ms.
<b>Parameters</b>	<no> = Service number (1-8) <variation> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 2000.000, DEFault = 0.050</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FDV 20.000
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLLocal:SACRiteria:FDVariation?
<b>Description</b>	This query returns the acceptable frame delay variation value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<variation> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FDV? → 20.000
<b>Note</b>	

**12.25.53 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FLRatio**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FLRatio <ratio>
<b>Description</b>	This command sets the acceptable frame loss ratio.
<b>Parameters</b>	<no> = Service number (1-8) <ratio> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00, MAXimum = 1.00, DEFault = 0.00</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FLR 0.000015 ETH:SAT:SET:SERV1:SACR:FLR 15e-06
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:FLRatio?
<b>Description</b>	This query returns the acceptable frame loss ratio.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<ratio> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:FLR? → 1.50e-05
<b>Note</b>	

## 12.25.54 ETHernet:SATest:SETup:SERVice&lt;no&gt;:RTLocal:SACRiteria:FLRatio

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FLRatio <ratio>
<b>Description</b>	This command sets the acceptable frame loss ratio.
<b>Parameters</b>	<no> = Service number (1-8) <ratio> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00, MAXimum = 1.00, DEFault = 0.00</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FLR 0.000015 ETH:SAT:SET:SERV1:RTL:SACR:FLR 15e-06
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:FLRatio?
<b>Description</b>	This query returns the acceptable frame loss ratio.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<ratio> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:FLR? → 1.50e-05
<b>Note</b>	

## 12.25.55 ETHernet:SATest:SETup:SERVice&lt;no&gt;[:LTRemote]:SACRiteria:AVAILability

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:AVAILability <value>
<b>Description</b>	This command sets the acceptable availability. Unit: percentage.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100, DEFault=100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:AVA 99
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:SACRiteria:AVAILability?
<b>Description</b>	This query returns the acceptable availability.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SACR:AVA? → 99
<b>Note</b>	

## 12.25.56 ETHernet:SATest:SETup:SERVice&lt;no&gt;:RTLocal:SACRiteria:AVAILability

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:AVAILability <value>
<b>Description</b>	This command sets the acceptable availability. Unit: percentage.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 100.00, DEFault = 100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:AVA 99
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:SACRiteria:AVAILability?
<b>Description</b>	This query returns the acceptable availability.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:SACR:AVA? → 99
<b>Note</b>	

**12.25.57 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:FSMode**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:FSMode <mode>
<b>Description</b>	This command sets the configured frame size mode.
<b>Parameters</b>	<no> = Service number (1-8) <mode> = <CHARACTER PROGRAM DATA> CONStant: Fixed frame size <sup>1</sup> EMIX: A mix of frame sizes <sup>2</sup> <i>DEFault = CONStant</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:FSM CONS
<b>Note</b>	<sup>1</sup> Uses the frame size defined by the command: ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:FSIZE. <sup>2</sup> Uses the frame sizes defined by the command: ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EMIX.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:FSMode?
<b>Description</b>	This query returns the configured frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:FSM? → CONS
<b>Note</b>	

**12.25.58 ETHernet:SATest:SETup:SERVice<no>:RTLocal:FSMode**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:FSMode <mode>
<b>Description</b>	This command sets the configured frame size mode.
<b>Parameters</b>	<no> = Service number (1-8) <mode> = <CHARACTER PROGRAM DATA> CONStant: Fixed frame size <sup>1</sup> EMIX: A mix of frame sizes <sup>2</sup> <i>DEFault = CONStant</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:FSM CONS
<b>Note</b>	<sup>1</sup> Uses the frame size defined by the command: ETHernet:SATest:SETup:SERVice<no>:RTLLocal:FSIZE. <sup>2</sup> Uses the frame sizes defined by the command: ETHernet:SATest:SETup:SERVice<no>:RTLLocal:EMIX.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLLocal:FSMode?
<b>Description</b>	This query returns the configured frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:FSM? → CONS
<b>Note</b>	

**12.25.59 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CFSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CFSize <size>
<b>Description</b>	This command sets the constant frame size.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <CHARACTER PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes MTU: Use the MTU value <sup>1</sup> USER: Use the user defined value <sup>2</sup> <i>DEFault = 512</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:CFS 256
<b>Note</b>	<sup>1</sup> The MTU value is modified by the command: ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:MTU. <sup>2</sup> The user defined value is modified by the command: ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:UDFSize.

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:CFSize?
<b>Description</b>	This query returns the constant frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:CFS? → 256
<b>Note</b>	

**12.25.60 ETHernet:SATest:SETup:SERVice<no>:RTLocal:CFSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CFSize <size>
<b>Description</b>	This command sets the constant frame size.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <CHARACTER PROGRAM DATA> 64: 64 bytes 128: 128 bytes 256: 256 bytes 512: 512 bytes 1024: 1024 bytes 1280: 1280 bytes 1518: 1518 bytes MTU: Use the MTU value <sup>1</sup> USER: Use the user defined value <sup>2</sup> <i>DEFault = 512</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CFS 256
<b>Note</b>	<sup>1</sup> The MTU value is modified by the command: ETHernet:SATest:SETup:SERVice<no>:RTLocal:MTU. <sup>2</sup> The user defined value is modified by the command: ETHernet:SATest:SETup:SERVice<no>:RTLocal:UDFSize.



<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:CFSize?
<b>Description</b>	This query returns the constant frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:CFS? → 256
<b>Note</b>	

### 12.25.61 ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EMIX

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EMIX <mix>
<b>Description</b>	This command defines the EMIX sequence.
<b>Parameters</b>	<p>&lt;no&gt; = Service number (1-8)</p> <p>&lt;mix&gt; = &lt;STRING PROGRAM DATA&gt;</p> <p>This quoted string defines the EMIX sequence by a sequence of the letters 'a'-'h' or 'u'. Specify:</p> <p>'a' for a 64 bytes frame</p> <p>'b' for a 128 bytes frame</p> <p>'c' for a 256 bytes frame</p> <p>'d' for a 512 bytes frame</p> <p>'e' for a 1024 bytes frame</p> <p>'f' for a 1280 bytes frame</p> <p>'g' for a 1518 bytes frame</p> <p>'h' for a MTU sized frame <sup>1</sup></p> <p>'u' for a user defined sized frame <sup>2</sup></p> <p><i>DEFault</i> = "abceg"</p>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:EMIX "ababccdddhu"
<b>Note</b>	<p>Illegal characters are removed from the EMIX string and if the string is more than 16 characters long, the string will be truncated.</p> <p><sup>1</sup> The MTU value is modified by the command: ETHernet:SATest:SETup:SERVice&lt;no&gt;[:LTRemote]:MTU.</p> <p><sup>2</sup> The user defined value is modified by the command: ETHernet:SATest:SETup:SERVice&lt;no&gt;[:LTRemote]:UDFSize.</p>

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:EMIX?
<b>Description</b>	This query returns the EMIX sequence.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<emix> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:EMIX? → "ababccdddhu"
<b>Note</b>	

## 12.25.62 ETHernet:SATest:SETup:SERVice&lt;no&gt;:RTLocal:EMIX

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:EMIX <mix>
<b>Description</b>	This command defines the EMIX sequence.
<b>Parameters</b>	<p>&lt;no&gt; = Service number (1-8)</p> <p>&lt;mix&gt; = &lt;STRING PROGRAM DATA&gt;</p> <p>This quoted string defines the EMIX sequence by a sequence of the letters 'a'-'h' or 'u'. Specify:</p> <p>'a' for a 64 bytes frame</p> <p>'b' for a 128 bytes frame</p> <p>'c' for a 256 bytes frame</p> <p>'d' for a 512 bytes frame</p> <p>'e' for a 1024 bytes frame</p> <p>'f' for a 1280 bytes frame</p> <p>'g' for a 1518 bytes frame</p> <p>'h' for a MTU sized frame <sup>1</sup></p> <p>'u' for a user defined sized frame <sup>2</sup></p> <p><i>DEFault</i> = "abceg"</p>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EMIX "ababccdddhu"
<b>Note</b>	<p>Illegal characters are removed from the EMIX string and if the string is more than 16 characters long, the string will be truncated.</p> <p><sup>1</sup> The MTU value is modified by the command: ETHernet:SATest:SETup:SERVice&lt;no&gt;:RTLocal:MTU.</p> <p><sup>2</sup> The user defined value is modified by the command: ETHernet:SATest:SETup:SERVice&lt;no&gt;:RTLocal:UDFSize.</p>

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:RTLocal:EMIX?
<b>Description</b>	This query returns the EMIX sequence.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<emix> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:EMIX? → "ababccdddhu"
<b>Note</b>	

## 12.25.63 ETHernet:SATest:SETup:SERVice&lt;no&gt;[:LTRemote]:MTU

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:MTU <value>
<b>Description</b>	This command sets the MTU value. Unit: bytes.
<b>Parameters</b>	<p>&lt;no&gt; = Service number (1-8)</p> <p>&lt;value&gt; = &lt;NUMERIC PROGRAM DATA&gt;</p> <p><i>MINimum</i> = 1518, <i>MAXimum</i> = 16000, <i>DEFault</i> = 1518</p>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:MTU 10101

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>[:LTRemote]:MTU?
<b>Description</b>	This query returns the MTU value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:MTU? → 10101
<b>Note</b>	

**12.25.64 ETHernet:SATest:SETup:SERvice<no>:RTLocal:MTU**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:MTU <value>
<b>Description</b>	This command sets the MTU value. Unit: bytes.
<b>Parameters</b>	<no> = Service number (1-8) <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 1518, MAXimum = 16000, DEFault = 1518</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:MTU 10101

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:MTU?
<b>Description</b>	This query returns the MTU value.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:MTU? → 10101
<b>Note</b>	

**12.25.65 ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:UDFSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:UDFSize <size>
<b>Description</b>	This command sets the user defined frame size.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 46<sup>1</sup>, MAXimum = 16000, DEFault = 512</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:UDFS 111
<b>Note</b>	<sup>1</sup> The minimum allowed frame size varies depending on the frame content setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>[:LTRemote]:UDFSize?
<b>Description</b>	This query returns the user defined frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:UDFS? → 111
<b>Note</b>	

**12.25.66 ETHernet:SATest:SETup:SERvice<no>:RTLocal:UDFSize**

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:UDFSize <size>
<b>Description</b>	This command sets the user defined frame size.
<b>Parameters</b>	<no> = Service number (1-8) <size> = <NUMERIC PROGRAM DATA> <i>MINimum = 46<sup>1</sup>, MAXimum = 16000, DEFault = 512</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:UDFS 111
<b>Note</b>	<sup>1</sup> The minimum allowed frame size varies depending on the frame content setup.

<b>Syntax</b>	ETHernet:SATest:SETup:SERvice<no>:RTLocal:UDFSize?
<b>Description</b>	This query returns the user defined frame size.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:RTL:UDFS? → 111
<b>Note</b>	

**12.25.67 ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SDURation**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SDURation <duration>
<b>Description</b>	This command sets the service configuration test steps duration. Unit: seconds.
<b>Parameters</b>	<no> = Service number (1-8) <duration> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 60, DEFault = 3</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:SDUR 5
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SDURation?
<b>Description</b>	This query returns the service configuration test steps duration.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:SDUR? → 5
<b>Note</b>	

**12.25.68 ETHernet:SATest:SETup:SERVice<no>:SCTSteps:NSTep**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:NSTep <duration>
<b>Description</b>	This command sets the service configuration test number of steps.
<b>Parameters</b>	<no> = Service number (1-8) <steps> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 10, DEFault = 4</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:NST 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:NSTep?
<b>Description</b>	This query returns the service configuration test number of steps.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<steps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:NST? → 2
<b>Note</b>	

**12.25.69 ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SLOPe**

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SLOPe <slope>
<b>Description</b>	This command sets the service configuration test slope.
<b>Parameters</b>	<no> = Service number (1-8) <slope> = <CHARACTER PROGRAM DATA> ASCending: Use an ascending slope (lowest rate first) DESCending: Use a descending slope (CIR rate first) <i>DEFault = ASCending</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:SLOP ASC
<b>Note</b>	

<b>Syntax</b>	ETHernet:SATest:SETup:SERVice<no>:SCTSteps:SLOPe?
<b>Description</b>	This query returns the service configuration test slope.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<slope> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SAT:SET:SERV1:SCTS:SLOP? → ASC
<b>Note</b>	

**12.25.70 ETHernet:SATest:RESult:TSYNchronization?**

<b>Syntax</b>	ETHernet:SATest:RESult:TSYNchronization?
<b>Description</b>	Returns the status of the timing synchronization during the service activation test period. For one-way testing the signals from the GPS system are needed to achieve the required accuracy of the frame transfer delay measurement.
<b>Parameter</b>	None.
<b>Response</b>	<local-status> = <STRING RESPONSE DATA> "Pending" or "Fail" or "Pass" denotes the synchronization status on the local side. <remote-status> = <STRING RESPONSE DATA> "Pending" or "Fail" or "Pass" denotes the synchronization status on the remote side.
<b>Example</b>	ETH:SAT:RES:TSYN? → Pass,Fail
<b>Note</b>	

**12.25.71 ETHernet:SATest:RESult:SCTest[:LTRemote]?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest[:LTRemote]?
<b>Description</b>	Returns the overall result of all service configuration tests in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<status> = <STRING RESPONSE DATA> "Pending" or "Fail" or "Pass" denotes the status of the test step.
<b>Example</b>	ETH:SAT:RES:SCT? → Pass
<b>Note</b>	

**12.25.72 ETHernet:SATest:RESult:SCTest:RTLLocal?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:RTLLocal?
<b>Description</b>	Returns the overall result of all service configuration tests in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<status> = <STRING RESPONSE DATA> "Pending" or "Fail" or "Pass" denotes the status of the test step.
<b>Example</b>	ETH:SAT:RES:SCT:RTL? → Pass
<b>Note</b>	

**12.25.73 ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate? <step>
<b>Description</b>	Returns the results of the specified step of a service configuration test.
<b>Parameters</b>	<no> = Service number (1-8) <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 10, DEFault = 1</i>
<b>Response</b>	<status> = <STRING RESPONSE DATA> "Fail" or "Pass" denotes the status of the test step. <IR-min> = <NR2 NUMERIC RESPONSE DATA> Minimum information rate. Unit: Mbps. <IR-avg> = <NR2 NUMERIC RESPONSE DATA> Average information rate. Unit: Mbps. <IR-max> = <NR2 NUMERIC RESPONSE DATA> Maximum information rate. Unit: Mbps. <FL-count> = <NR1 NUMERIC RESPONSE DATA> Frame loss. Unit: Frames. <FL-rate> = <NR3 NUMERIC RESPONSE DATA> Frame loss ratio. <FTD-min> = <NR1 NUMERIC RESPONSE DATA> Minimum frame transfer delay. Unit: ms. <FTD-avg> = <NR1 NUMERIC RESPONSE DATA> Average frame transfer delay. Unit: ms. <FTD-max> = <NR1 NUMERIC RESPONSE DATA> Maximum frame transfer delay. Unit: ms. <FDV-min> = <NR1 NUMERIC RESPONSE DATA> Minimum frame delay variation. Unit: ms. <FDV-avg> = <NR1 NUMERIC RESPONSE DATA> Average frame delay variation. Unit: ms. <FDV-max> = <NR1 NUMERIC RESPONSE DATA> Maximum frame delay variation. Unit: ms.
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:CIR? 1 → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.74 ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLLocal:CIRate?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLLocal:CIRate? <step>
<b>Description</b>	Returns the results of the specified step of a service configuration test.
<b>Parameters</b>	<no> = Service number (1-8) <step> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 10, DEFault = 1</i>
<b>Response</b>	The same response parameters as for the command: <b>ETHernet:SATest:RESult:SCTest:SERVice&lt;no&gt;[:LTRemote]:CIRate</b>
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:RTL:CIR? 1 → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.75 ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:EIRate?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:EIRate? [<color>]
<b>Description</b>	Returns the results of the specified excess information rate test.
<b>Parameters</b>	<no> = Service number (1-8) <color> = <CHARACTER PROGRAM DATA> GREen: Green color counters YELLow: Yellow color counters TOTAl: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware. <i>DEFault = TOTAl</i>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:EIR? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.76 ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLLocal:EIRate?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLLocal:EIRate? [<color>]
<b>Description</b>	Returns the results of the specified excess information rate test.
<b>Parameters</b>	<no> = Service number (1-8) <color> = <CHARACTER PROGRAM DATA> GREen: Green color counters YELLow: Yellow color counters TOTAl: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware. <i>DEFault = TOTAl</i>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:RTL:EIR? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.77 ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:TPOLicing?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:TPOLicing? [<color>]
<b>Description</b>	Returns the results of the specified traffic policing test.
<b>Parameters</b>	<no> = Service number (1-8) <color> = <CHARACTER PROGRAM DATA> GREen: Green color counters YELLow: Yellow color counters TOTAl: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware. <i>DEFault = TOTAl</i>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:TPOL? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.78 ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLocal:TPOLicing?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLocal:TPOLicing? [<color>]
<b>Description</b>	Returns the results of the specified traffic policing test.
<b>Parameters</b>	<no> = Service number (1-8) <color> = <CHARACTER PROGRAM DATA> GREen: Green color counters YELLow: Yellow color counters TOTal: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware. <i>DEFault = TOTal</i>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:RTL:TPOL? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.79 ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CBSize?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CBSize?
<b>Description</b>	Returns the results of the committed burst size test.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:CBS? → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.80 ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLocal:CBSize?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>:RTLocal:CBSize?
<b>Description</b>	Returns the results of the committed burst size test.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:RTL:CBS? → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.81 ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:EBSize?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:EBSize? [<color>]
<b>Description</b>	Returns the results of the excess burst size test.
<b>Parameters</b>	<no> = Service number (1-8) <color> = <CHARACTER PROGRAM DATA> GREen: Green color counters YELLow: Yellow color counters TOTal: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware. <i>DEFault = TOTal</i>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERVice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:EBS? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	



**12.25.82 ETHernet:SATest:RESult:SCTest:SERvice<no>:RTLLocal:EBSize?**

<b>Syntax</b>	ETHernet:SATest:RESult:SCTest:SERvice<no>:RTLLocal:EBSize? [ <i>&lt;color&gt;</i> ]
<b>Description</b>	Returns the results of the excess burst size test.
<b>Parameters</b>	<p><i>&lt;no&gt;</i> = Service number (1-8)</p> <p><i>&lt;color&gt;</i> = <i>&lt;CHARACTER PROGRAM DATA&gt;</i>  GREEN: Green color counters  YELLOW: Yellow color counters  TOTAL: In color blind mode this is the only result available. Sum of green and yellow color counters when color aware.  <i>DEFault = TOTAL</i></p>
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SCTest:SERvice<no>[:LTRemote]:CIRate
<b>Example</b>	ETH:SAT:RES:SCT:SERV1:RTL:EBS? GRE → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3
<b>Note</b>	

**12.25.83 ETHernet:SATest:RESult:SPTest[:LTRemote]?**

<b>Syntax</b>	ETHernet:SATest:RESult:SPTest[:LTRemote]?
<b>Description</b>	Returns the overall result of all service performance tests in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<p><i>&lt;status&gt;</i> = <i>&lt;STRING RESPONSE DATA&gt;</i>  "Pending" or "Fail" or "Pass" denotes the status of the test step.</p>
<b>Example</b>	ETH:SAT:RES:SPT? → Pass
<b>Note</b>	

**12.25.84 ETHernet:SATest:RESult:SPTest:RTLLocal?**

<b>Syntax</b>	ETHernet:SATest:RESult:SPTest:RTLLocal?
<b>Description</b>	Returns the overall result of all service performance tests in the remote to local direction.
<b>Parameter</b>	<i>&lt;no&gt;</i> = Service number (1-8)
<b>Response</b>	<p><i>&lt;status&gt;</i> = <i>&lt;STRING RESPONSE DATA&gt;</i>  "Pending" or "Fail" or "Pass" denotes the status of the test step.</p>
<b>Example</b>	ETH:SAT:RES:SPT:RTL? → Pass
<b>Note</b>	

**12.25.85 ETHernet:SATest:RESult:SPTest:SERVice<no>[:LTRemote]?**

<b>Syntax</b>	ETHernet:SATest:RESult:SPTest:SERVice<no>[:LTRemote]?
<b>Description</b>	Returns the results of a service performance test of a service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	<status> = <STRING RESPONSE DATA> "Fail" or "Pass" denotes the status of the test step. <IR-min> = <NR2 NUMERIC RESPONSE DATA> Minimum information rate. Unit: Mbps. <IR-avg> = <NR2 NUMERIC RESPONSE DATA> Average information rate. Unit: Mbps. <IR-max> = <NR2 NUMERIC RESPONSE DATA> Maximum information rate. Unit: Mbps. <FL-count> = <NR1 NUMERIC RESPONSE DATA> Frame loss. Unit: Frames. <FL-rate> = <NR3 NUMERIC RESPONSE DATA> Frame loss ratio. <FTD-min> = <NR1 NUMERIC RESPONSE DATA> Minimum frame transfer delay. Unit: ms. <FTD-avg> = <NR1 NUMERIC RESPONSE DATA> Average frame transfer delay. Unit: ms. <FTD-max> = <NR1 NUMERIC RESPONSE DATA> Maximum frame transfer delay. Unit: ms. <FDV-min> = <NR1 NUMERIC RESPONSE DATA> Minimum frame delay variation. Unit: ms. <FDV-avg> = <NR1 NUMERIC RESPONSE DATA> Average frame delay variation. Unit: ms. <FDV-max> = <NR1 NUMERIC RESPONSE DATA> Maximum frame delay variation. Unit: ms. <Availability> = <NR2 NUMERIC RESPONSE DATA> Availability (link). Unit: percentage. <Unavailable> = <NR1 NUMERIC RESPONSE DATA> Unavailable time. Unit: seconds.
<b>Example</b>	ETH:SAT:RES:SPT:SERV1? → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3,100.00,0
<b>Note</b>	

**12.25.86 ETHernet:SATest:RESult:SPTest:SERVice<no>:RTLLocal?**

<b>Syntax</b>	ETHernet:SATest:RESult:SPTest:SERVice<no>:RTLLocal?
<b>Description</b>	Returns the results of a service performance test of a service.
<b>Parameter</b>	<no> = Service number (1-8)
<b>Response</b>	The same response parameters as for the command: ETHernet:SATest:RESult:SPTest:SERVice<no>[:LTRemote]?
<b>Example</b>	ETH:SAT:RES:SPT:SERV1:RTL? → Pass,1.00,2.00,3.00,0,0.00E+00,1,2,3,1,2,3,100.00,0
<b>Note</b>	

## 12.26 Cable Test



### 12.26.1 ETHernet:CABLe:START

<b>Syntax</b>	ETHernet:CABLe:START
<b>Description</b>	This command starts the cable test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:CABL:STAR
<b>Note</b>	

### 12.26.2 ETHernet:CABLe:STOP

<b>Syntax</b>	ETHernet:CABLe:STOP
<b>Description</b>	This command stops the cable test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:CABL:STOP
<b>Note</b>	

### 12.26.3 ETHernet:CABLe:CCStandard

<b>Syntax</b>	ETHernet:CABLe:CCStandard <ccs>
<b>Description</b>	This command sets the color coding standard.
<b>Parameter</b>	<port> = <CHARACTER PROGRAM DATA> T568A: CAT5 T568B: CAT5E <i>DEFault = T568A</i>
<b>Response</b>	None.
<b>Example</b>	ETH:CABL:CCS T568B
<b>Notes</b>	<p>T568A:</p>  <p>Pair 1: Pin 4,5 Pair 2: Pin 3,6 Pair 3: Pin 1,2 Pair 4: Pin 7,8</p> <p>T568B:</p>  <p>Pair 1: Pin 4,5 Pair 2: Pin 1,2 Pair 3: Pin 3,6 Pair 4: Pin 7,8</p>

<b>Syntax</b>	ETHernet:CABLe:CCStandard?
<b>Description</b>	This query returns the color coding standard.
<b>Parameter</b>	None.
<b>Response</b>	<ccs> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:CABL:CCS? → T568B
<b>Note</b>	

**12.26.4 ETHernet:CABLe:RESults:PAIR<Pr>?**

<b>Syntax</b>	ETHernet:CABLe:RESults:PAIR<Pr>?
<b>Description</b>	This query returns the status of a pair.
<b>Parameter</b>	<Pr> = Pair number (1-4)
<b>Response</b>	<status> = <CHARACTER RESPONSE DATA> OK: Pair is ok SHRT: Pair is shorted OPEN: Pair is open FAIL: Pair is fail(Pair Busy/Invalid) NA: Status not available
	<distance> = <NR2 NUMERIC RESPONSE DATA> Distance to fault. Unit: Meters. If there is no fault it will return 0.0.
<b>Examples</b>	ETH:CABL:RES:PAIR1? → OK,0.0 ETH:CABL:RES:PAIR2? → SHRT,20.6 ETH:CABL:RES:PAIR3? → OPEN,2.4
<b>Note</b>	Results cannot be obtained during testing.

## 12.27 IP Channel Statistics

### 12.27.1 ETHernet:CStat:START

<b>Syntax</b>	ETHernet:CStat:START
<b>Description</b>	This command starts the IP Channel Statistics test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:CST:STAR
<b>Note</b>	This command will make the PHY reset, which will results in link loss for a couple of seconds. This command can be used on V2.00 or later

### 12.27.2 ETHernet:CStat:STOP

<b>Syntax</b>	ETHernet:CStat:STOP
<b>Description</b>	This command stops the IP Chanel Statistics test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:CST:STOP
<b>Note</b>	This command will make the phy reset, which will results in link loss for a couple of seconds. This command can be used on V2.00 or later

### 12.27.3 ETHernet:CStat:SETup:FOLLow

<b>Syntax</b>	ETHernet:CStat:SETup:FOLLow <enable>
<b>Description</b>	This command enables/disables PORT2 follow PORT1.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:CST:SET:FOLL OFF
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:CStat:SETup:FOLLOW?
<b>Description</b>	This query returns whether or not PORT2 follows PORT1.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:CST:SET:FOLL? → 0
<b>Note</b>	This command can be used on V2.00 or later

### 12.27.4 ETHernet:CStat:SETup:PORT<Pt>:FOLLow

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:FOLLow <enable>
<b>Description</b>	This command sets CStat setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:CST:SET:PORT2:FOLL ON
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:FOLLOW?
<b>Description</b>	This query returns whether or not CStat setup for port <Pt> follows PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:CST:SET:PORT2:FOLL? → 1
<b>Note</b>	This command can be used on V2.00 or later

**12.27.5 ETHernet:CStat:SETup:PORT<Pt>:CDEFinitions**

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:CDEFinitions <definitions>
<b>Description</b>	This command sets the active channel definitions.
<b>Parameters</b>	<Pt> = Port number {(<definitions>} + {, }*) = <EXPRESSION PROGRAM DATA> SMAC: Source MAC address DMAC: Destination MAC address PINF: Protocol information VLAN: VLAN MPLS: MPLS SIP: Source IP address DIP: Destination IP address IPNH: IP next header SPOR: Source TCP/UDP port DPOR: Destination TCP/UDP port
<b>Response</b>	None.
<b>Example</b>	ETH:CST:SET:PORT1:CDEF (SMAC,SPOR)
<b>Note</b>	Changing the channel definitions while a test is running will reset the results for both ports. This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:CDEFinitions?
<b>Description</b>	This query returns the active channel definitions.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<definition>),}* = <EXPRESSION RESPONSE DATA> <definition> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:CST:SET:PORT1:CDEF? → (SMAC,SPOR)
<b>Note</b>	This command can be used on V2.00 or later

**12.27.6 ETHernet:CStat:SETup:PORT<Pt>:MERGe**

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:MERGe <definition>
<b>Description</b>	This command sets which channel definition to merge.
<b>Parameters</b>	<Pt> = Port number <definition> = <CHARACTER PROGRAM DATA> SMAC: Source MAC address DMAC: Destination MAC address PINF: Protocol information VLAN: VLAN MPLS: MPLS SIP: Source IP address DIP: Destination IP address IPNH: IP next header SPOR: Source TCP/UDP port DPOR: Destination TCP/UDP port SDMP: Source and destination MAC address pairs OFF: Undo merge. <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:CST:SET:PORT1:MERG SMAC
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:MERGe?
<b>Description</b>	This query returns the currently merged channel definition.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<definition> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:CST:SET:PORT1:MERG? → SMAC
<b>Note</b>	This command can be used on V2.00 or later

**12.27.7 ETHernet:CStat:SETup:PORT<Pt>:FRESults**

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:FRESults <format>
<b>Description</b>	This command sets the format of the IP Channel Statistics test results.
<b>Parameters</b>	<Pt> = Port number <format> = <CHARACTER PROGRAM DATA> UNF: Unformatted SI: SI prefix notation ENG: Engineering exponent notation HEX: Hexadecimal notation <i>DEFault = SI</i>
<b>Response</b>	None.
<b>Example</b>	ETH:CST:SET:PORT1:FRES ENG
<b>Note</b>	This only affects the GUI and reports. This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:CStat:SETup:PORT<Pt>:FRESults?
<b>Description</b>	This query returns the format of the IP Channel Statistics test results.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<format> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:CST:SET:PORT1:FRES? → ENG
<b>Note</b>	This command can be used on V2.00 or later

**12.27.8 ETHernet:CStat:RESults:PORT<Pt>:NCHannels?**

<b>Syntax</b>	ETHernet:CStat:RESults:PORT<Pt>:NCHannels?
<b>Description</b>	This query returns the maximum number of channels.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:CST:RES:PORT1:NCH? → 3
<b>Note</b>	If no channels are available NaN (section 1.6.1) is returned. This command can be used on V2.00 or later

**12.27.9 ETHernet:CStat:RESults:PORT<Pt>:DFRames?**

<b>Syntax</b>	ETHernet:CStat:RESults:PORT<Pt>:DFRames?
<b>Description</b>	This query returns the number of discarded frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:CST:RES:PORT1:DFR? → 3
<b>Note</b>	On high speed links the Channel Statistics may sometimes discard frames due to overload. When this happens, the number of frames discarded can be read using this command. This command can be used on V2.00 or later

**12.27.10 ETHernet:CStat:RESults:PORT<Pt>:FETCh?**

<b>Syntax</b>	ETHernet:CStat:RESults:PORT<Pt>:FETCh? <number>, <parameter>
<b>Description</b>	This query returns Channel Stat results.
<b>Parameters</b>	<Pt> = Port number <number> = <NUMERIC PROGRAM DATA> The channel number from which to fetch results from. <i>MINimum = 1, DEFault = 1</i> ({<parameter>} + {,}*) = <EXPRESSION PROGRAM DATA>
	<b>Channel Definitions</b> SMAC: Source MAC address DMAC: Destination MAC address

continued on next page...



... continued from previous page

PINF: Protocol information  
 VLAN: VLAN  
 MPLS: MPLS  
 SIP: Source IP address  
 DIP: Destination IP address  
 IPNH: IP next header  
 SPOR: Source TCP/UDP port  
 DPOR: Destination TCP/UDP port

**Frame Statistics**

FCT: Frame count  
 FRAT: Frame rate  
 BCT: Byte count  
 THR: Throughput  
 OFR: Over Frames  
 UFR: Under Frames

**Size Distribution Statistics**

S64: 64-127  
 S128: 128-255  
 S256: 256-511  
 S512: 512-1023  
 S1024: 1024-1518  
 S1519: Above 1519

**MPLS Statistics**

MPLSF: MPLS frames  
 MPLSB: MPLS bytes

**IP Statistics**

IPP: IP packets  
 IPPR: IP packet rate  
 IPB: IP bytes  
 IP4TH: IP throughput  
 IP4HB: IP header bytes  
 IPF: IP fragments  
 TTLV: TTL violations

**IPv4 Statistics**

IP4P: IPv4 packets  
 IP4PR: IPv4 packet rate  
 IP4B: IPv4 bytes  
 IP4TH: IPv4 Throughput  
 IP4HB: IPv4 header bytes  
 IP4HE: IPv4 header errors

**IPv6 Statistics**

IP6P: IPv6 packets  
 IP6PR: IPv6 packet rate  
 IP6B: IPv6 bytes  
 IP6TH: IPv6 throughput  
 IP6HB: IPv6 header bytes

**TCP Statistics**

TPAC: TCP packets  
 TBYT: TCP bytes  
 TPR: TCP packet rate

continued on next page...

...continued from previous page

	<p>TTHR: TCP throughput</p> <p><b>UDP Statistics</b>  UPAC: UDP packets  UBYT: UDP bytes  UPR: UDP packet rate  UTHR: UDP throughput  TUEF: TCP/UDP errored frames</p>
<b>Response</b>	<p>{{(&lt;result&gt;, }+), }* = &lt;EXPRESSION RESPONSE DATA&gt;</p> <p><b>Channel Definitions</b>  &lt;result&gt; = &lt;STRING RESPONSE DATA&gt;</p> <p><b>Statistics</b>  &lt;result&gt; = &lt;NR1 NUMERIC RESPONSE DATA&gt;</p>
<b>Example</b>	ETH:CST:RES:PORT1:FETC? 1, (SMAC, S64) → ("00-00-91-E2-15-01"), (45)
<b>Note</b>	Use NChannels? to get the maximum channel number. It is not possible to get results from definitions not enabled by the CDEFinitions command. This command can be used on V2.00 or later

### 12.27.11 ETHernet:CStat:RESults:RESet

<b>Syntax</b>	ETHernet:CStat:RESults:RESet
<b>Description</b>	This command resets the IP Channel Statistics test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	ETH:CST:RES:RES
<b>Note</b>	This command can be used on V2.00 or later

## 12.28 Monitor Generator

### 12.28.1 ETHernet:MONGen:SETup:GENeral:IAFFilter

<b>Syntax</b>	ETHernet:MONGen:SETup:GENeral:IAFFilter
<b>Description</b>	This command selects if addresses should be included in frame filter on receiver.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:MONG:SET:GEN:IAFF ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:MONGen:SETup:GENeral:IAFFilter?
<b>Description</b>	This query returns addresses should be included in frame filter on receiver.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:MONG:SET:GEN:IAFF? → 1
<b>Note</b>	

## 12.29 Sync Test

### 12.29.1 ETHernet:SYNTest:SETup:MPERiod

<b>Syntax</b>	ETHernet:SYNTest:SETup:MPERiod <period>
<b>Description</b>	This command select the measurement period.
<b>Parameter</b>	<period> = <CHARACTER PROGRAM DATA> DUR100S: 100 seconds DUR1000S: 1000 seconds USERDEFINE: User define
<b>Response</b>	None.
<b>Example</b>	ETH:SYNT:SET:MPER DUR100S
<b>Note</b>	

<b>Syntax</b>	ETHernet:SYNTest:SETup:MPERiod?
<b>Description</b>	This query returns the measurement period.
<b>Parameter</b>	None.
<b>Response</b>	<period> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:SYNT:SET:MPER? → DUR100S
<b>Note</b>	

### 12.29.2 ETHernet:SYNTest:SETup:MPERiod:USERdefined

<b>Syntax</b>	ETHernet:SYNTest:SETup:MPERiod:USERdefined <period>
<b>Description</b>	This command select the measurement period.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum = 100, MAXimum = 86400, DEFault = 100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SYNT:SET:MPER:USER 0
<b>Note</b>	This parameter is used only when MPERiod is USERDEFINE.

<b>Syntax</b>	ETHernet:SYNTest:SETup:MPERiod:USERdefined?
<b>Description</b>	This query returns the measurement period.
<b>Parameter</b>	None.
<b>Response</b>	<period> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SYNT:SET:MPER:USER? → 0
<b>Note</b>	This parameter is used only when MPERiod is USERDEFINE.

### 12.29.3 ETHernet:SYNTest:SETup:PPS:CABLEcorrection

<b>Syntax</b>	ETHernet:SYNTest:SETup:PPS:CABLEcorrection <correction>
<b>Description</b>	This command set the PPS cable correction.
<b>Parameter</b>	<correction> = <NUMERIC PROGRAM DATA> <i>MINimum = -100000000, MAXimum = 100000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SYNT:SET:PPS:CABL 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:SYNTest:SETup:PPS:CABLEcorrection?
<b>Description</b>	This query returns the PPS cable correction.
<b>Parameter</b>	None.
<b>Response</b>	<correction> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SYNT:SET:PPS:CABL? → 0
<b>Note</b>	

#### 12.29.4 ETHernet:SYNTest:SETup:PACKet:CABLecorrection

<b>Syntax</b>	ETHernet:SYNTest:SETup:PACKet:CABLecorrection <correction>
<b>Description</b>	This command set the Ethernet cable correction.
<b>Parameter</b>	<correction> = <NUMERIC PROGRAM DATA> <i>MINimum = -100000000, MAXimum = 100000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:SYNT:SET:PACK:CABL 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:SYNTest:SETup:PACKet:CABLecorrection?
<b>Description</b>	This query returns the Ethernet cable correction.
<b>Parameter</b>	None.
<b>Response</b>	<correction> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:SYNT:SET:PACK:CABL? → 0
<b>Note</b>	

#### 12.29.5 ETHernet:THResholds:PPS:PHASe[:ENABle]

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe[:ENABle] <enable>
<b>Description</b>	This command enables or disables the 1PPS phase error thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:PHAS OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe[:ENABle]?
<b>Description</b>	This query returns whether or not the 1PPS phase error thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:PHAS? → 0
<b>Note</b>	

#### 12.29.6 ETHernet:THResholds:PPS:PHASe:MINValue

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe:MINValue <value>
<b>Description</b>	This command set the minimum 1PPS phase error thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:PHAS:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe:MINValue?
<b>Description</b>	This query returns the minimum 1PPS phase error thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:PHAS:MINV? → 0
<b>Note</b>	

**12.29.7 ETHernet:THResholds:PPS:PHASe:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe:MAXValue <value>
<b>Description</b>	This command set the maximum 1PPS phase error thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:PHAS:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:PHASe:MAXValue?
<b>Description</b>	This query returns the maximum 1PPS phase error thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:PHAS:MAXV? → 0
<b>Note</b>	

**12.29.8 ETHernet:THResholds:PPS:FILTeRed[:ENABle]**

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTeRed[:ENABle] <enable>
<b>Description</b>	This command enables or disables the filtered TE thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:FILT OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTeRed[:ENABle]?
<b>Description</b>	This query returns whether or not the filtered TE thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:FILT? → 0
<b>Note</b>	

**12.29.9 ETHernet:THResholds:PPS:FILTeRed:MINValue**

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTeRed:MINValue <value>
<b>Description</b>	This command set the minimum filtered TE thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:FILT:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTeRed:MINValue?
<b>Description</b>	This query returns the minimum filtered TE thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:FILT:MINV? → 0
<b>Note</b>	

**12.29.10 ETHernet:THResholds:PPS:FILTered:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTered:MAXValue <value>
<b>Description</b>	This command set the maximum filtered TE thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:FILT:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:FILTered:MAXValue?
<b>Description</b>	This query returns the maximum filtered TE thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:FILT:MAXV? → 0
<b>Note</b>	

**12.29.11 ETHernet:THResholds:PPS:DEViation[:ENABLE]**

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the 1PPS deviation thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:DEV OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation[:ENABLE]?
<b>Description</b>	This query returns whether or not the 1PPS deviation thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:DEV? → 0
<b>Note</b>	

**12.29.12 ETHernet:THResholds:PPS:DEViation:MINValue**

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation:MINValue <value>
<b>Description</b>	This command set the minimum 1PPS deviation thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:DEV:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation:MINValue?
<b>Description</b>	This query returns the minimum 1PPS deviation thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:DEV:MINV? → 0
<b>Note</b>	

**12.29.13 ETHernet:THResholds:PPS:DEViation:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation:MAXValue <value>
<b>Description</b>	This command set the maximum 1PPS deviation thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1500000000, MAXimum = 1500000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:PPS:DEV:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:PPS:DEViation:MAXValue?
<b>Description</b>	This query returns the maximum 1PPS deviation thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:PPS:DEV:MAXV? → 0
<b>Note</b>	

**12.29.14 ETHernet:THResholds:OWD:SYNC[:ENABLE]**

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the Sync message transmission time thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:SYNC OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC[:ENABLE]?
<b>Description</b>	This query returns whether or not the Sync message transmission time thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:SYNC? → 0
<b>Note</b>	

**12.29.15 ETHernet:THResholds:OWD:SYNC:MINValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC:MINValue <value>
<b>Description</b>	This command set the minimum sync message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:SYNC:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC:MINValue?
<b>Description</b>	This query returns the minimum sync message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:SYNC:MINV? → 0
<b>Note</b>	



**12.29.16 ETHernet:THResholds:OWD:SYNC:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC:MAXValue <value>
<b>Description</b>	This command set the maximum sync message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:SYNC:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:SYNC:MAXValue?
<b>Description</b>	This query returns the maximum sync message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:SYNC:MAXV? → 0
<b>Note</b>	

**12.29.17 ETHernet:THResholds:OWD:FOLLOW[:ENABLE]**

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLOW[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the follow up message transmission time thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:FOLL OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLOW[:ENABLE]?
<b>Description</b>	This query returns whether or not the follow up message transmission time thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:FOLL? → 0
<b>Note</b>	

**12.29.18 ETHernet:THResholds:OWD:FOLLOW:MINValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLOW:MINValue <value>
<b>Description</b>	This command set the minimum follow up message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:FOLL:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLOW:MINValue?
<b>Description</b>	This query returns the minimum follow up message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:FOLL:MINV? → 0
<b>Note</b>	

**12.29.19 ETHernet:THResholds:OWD:FOLLow:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLow:MAXValue <value>
<b>Description</b>	This command set the maximum follow up message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:FOLL:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:FOLLow:MAXValue?
<b>Description</b>	This query returns the maximum follow up message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:FOLL:MAXV? → 0
<b>Note</b>	

**12.29.20 ETHernet:THResholds:OWD:DELay[:ENABLE]**

<b>Syntax</b>	ETHernet:THResholds:OWD:DELay[:ENABLE] <enable>
<b>Description</b>	This command enables or disables the delay request message transmission time thresholds.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:DEL OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:DELay[:ENABLE]?
<b>Description</b>	This query returns whether or not the delay request message transmission time thresholds enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:DEL? → 0
<b>Note</b>	

**12.29.21 ETHernet:THResholds:OWD:DELay:MINValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:DELay:MINValue <value>
<b>Description</b>	This command set the minimum delay request message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:DEL:MINV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:DELay:MINValue?
<b>Description</b>	This query returns the minimum delay request message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:DEL:MINV? → 0
<b>Note</b>	

**12.29.22 ETHernet:THResholds:OWD:DELaY:MAXValue**

<b>Syntax</b>	ETHernet:THResholds:OWD:DELaY:MAXValue <value>
<b>Description</b>	This command set the maximum delay request message transmission time thresholds.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum = -1000000000, MAXimum = 1000000000, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:THR:OWD:DEL:MAXV 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:THResholds:OWD:DELaY:MAXValue?
<b>Description</b>	This query returns the maximum delay request message transmission time thresholds.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:THR:OWD:DEL:MAXV? → 0
<b>Note</b>	

**12.30 Frame Capture****12.30.1 ETHernet:PORT<Pt>:CAPTure:STARt**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:STARt
<b>Description</b>	This command starts the frame capture.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:STAR
<b>Note</b>	This command can be used on V2.00 or later

**12.30.2 ETHernet:PORT<Pt>:CAPTure:STOP**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:STOP
<b>Description</b>	This command stops the frame capture.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:STOP
<b>Note</b>	This command can be used on V2.00 or later

**12.30.3 ETHernet:PORT<Pt>:CAPTure:STATus?**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:STATus?
<b>Description</b>	This query returns the current status of the frame capture.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<status> = <CHARACTER RESPONSE DATA> IDLE WAITING: Waiting for Trigger CAPTURING FINISHED_CAPTURE SAVING FINISHED_SAVE
<b>Example</b>	ETH:PORT1:CAPT:STAT? → IDLE
<b>Note</b>	This command can be used on V2.00 or later

**12.30.4 ETHernet:PORT<Pt>:CAPTure:BUFSize**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:BUFSize <size>
<b>Description</b>	This command sets the capture buffer size.
<b>Parameters</b>	<Pt> = Port number <size> = <CHARACTER PROGRAM DATA> KB512: 512 KByte MB1: 1 MByte MB2: 2 MByte MB4: 4 MByte MB8: 8 MByte MB16: 16 MByte MB32: 32 MByte MB64: 64 MByte MB128: 128 MByte <i>DEFault = MB1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:BUFS MB1
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:BUFSize?
<b>Description</b>	This query returns the capture buffer size.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<size> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:BUFS? → MB1
<b>Note</b>	This command can be used on V2.00 or later

**12.30.5 ETHernet:PORT<Pt>:CAPTure:SLICing**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:SLICing <type>
<b>Description</b>	This command sets the frame slicing type.
<b>Parameters</b>	<type> = <CHARACTER PROGRAM DATA> NONE: Whole frame B64: Top 64 Byte B128: Top 128 Byte <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:SLIC B64
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:SLICing?
<b>Description</b>	This query returns the frame slicing type.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:SLIC? → B64
<b>Note</b>	This command can be used on V2.00 or later

**12.30.6 ETHernet:PORT<Pt>:CAPTure:ALOCation**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:ALOCation <type>
<b>Description</b>	This command sets the buffer handling allocation type.
<b>Parameters</b>	<type> = <CHARACTER PROGRAM DATA> STOP: Stop when full WRAP: Overwrite <i>DEFault = STOP</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:ALOC WRAP
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:ALOCation?
<b>Description</b>	This query returns the buffer handling allocation type.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:ALOC? → WRAP
<b>Note</b>	This command can be used on V2.00 or later

### 12.30.7 ETHernet:PORT<Pt>:CAPTure:TXFRame

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TXFRame <enable>
<b>Description</b>	This command enables/disables capturing transmitted frames.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TXFR ON
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TXFRame?
<b>Description</b>	This query returns whether or not capturing transmitted frames is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TXFR? → 1
<b>Note</b>	This command can be used on V2.00 or later

### 12.30.8 ETHernet:PORT<Pt>:CAPTure:TRIGger:TYPE

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:TYPE <type>
<b>Description</b>	This command sets the capture trigger type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> MANual ERRor PATtern: Field match <i>DEFault = MANual</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TRIG:TYPE MAN
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:TYPE?
<b>Description</b>	This query returns the capture trigger type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TRIG:TYPE? → MAN
<b>Note</b>	This command can be used on V2.00 or later

**12.30.9 ETHernet:PORT<Pt>:CAPTure:TRIGger:POSition**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:POSition <position>
<b>Description</b>	This command sets the capture trigger position.
<b>Parameters</b>	<Pt> = Port number <position> = <CHARACTER PROGRAM DATA> TOP MIDDLE <i>DEFault = TOP</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TRIG:POS MIDDLE
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:POSition?
<b>Description</b>	This query returns the capture trigger position.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<position> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TRIG:POS? → MIDDLE
<b>Note</b>	This command can be used on V2.00 or later

**12.30.10 ETHernet:PORT<Pt>:CAPTure:TRIGger:ERRor**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:ERRor <type>
<b>Description</b>	This command sets the error type of capture trigger.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> ANY: Any type FRAGMENT: Fragment OVERUNDER: Oversized or undersized OVER: Oversized UNDER: Undersized FCSERR: FCS error OVRFCSErr: Oversized & FCS Error IPCHKSUM: IP checksum error <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TRIG:ERR ANY
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:ERRor?
<b>Description</b>	This query returns the error type of capture trigger.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TRIG:ERR? → ANY
<b>Note</b>	This command can be used on V2.00 or later

**12.30.11 ETHernet:PORT<Pt>:CAPTure:TRIGger:OFFSet**

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:OFFSet <offset>
<b>Description</b>	This command sets the pattern offset for the capture trigger.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 15999, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TRIG:OFFS 12
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:OFFSet?
<b>Description</b>	This query returns the pattern offset for the capture trigger.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<offset> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TRIG:OFFS? → 12
<b>Note</b>	This command can be used on V2.00 or later

### 12.30.12 ETHernet:PORT<Pt>:CAPTure:TRIGger:PATtern

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:PATtern <pattern>
<b>Description</b>	This command sets the pattern for the capture trigger.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 32 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:TRIG:PATT "0800"
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:TRIGger:PATtern?
<b>Description</b>	This query returns the pattern for the capture trigger.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:TRIG:PATT? → "0800"
<b>Note</b>	This command can be used on V2.00 or later

### 12.30.13 ETHernet:PORT<Pt>:CAPTure:STORe

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:STORe [<file>]
<b>Description</b>	This command stores the current capture data to a given file on the instrument.
<b>Parameter</b>	<Pt> = Port number <file> = <STRING PROGRAM DATA> The path and name of the file to store the data.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:CAPT:STOR "Internal/my-frame-capture.pcap"
<b>Note</b>	This command can be used on V2.00 or later The application server must be in the idle state. Files must be saved to the Internal/ directory or a sub-directory hereof. When a USB storage device is mounted, files can stored via the Usb/ directory. Default File Path is Internal/.

### 12.30.14 ETHernet:PORT<Pt>:CAPTure:BUFFer?

<b>Syntax</b>	ETHernet:PORT<Pt>:CAPTure:BUFFer?
<b>Description</b>	This query returns the buffer usage percentage (0-100).
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<percentage> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:CAPT:BUFF? → 30
<b>Note</b>	This command can be used on V2.00 or later

## 12.31 OAM

The commands in this section is available to all Ethernet applications but the following: Cable Test, Reflector and Pass Through.

Use the general `ETHernet:PORT<Pt>:IFETch?` command to retrieve OAM results.

### 12.31.1 ETHernet:PORT<Pt>:OAM:PROTOcol

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:PROTOcol <protocol>
<b>Description</b>	This command sets the OAM protocol to use.
<b>Parameters</b>	<Pt> = Port number <protocol> = <CHARACTER PROGRAM DATA> AH: OAM according to IEEE 802.3ah AG: OAM according to IEEE 802.1AG Y: OAM according to IEEE Y.1731 <i>DEFault = AH</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:PROT AH
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:PROTOcol?
<b>Description</b>	This query returns the OAM protocol setting.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<protocol> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:PROT? → AH
<b>Note</b>	

### 12.31.2 ETHernet:PORT<Pt>:OAM:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:SMAC <address>
<b>Description</b>	This command sets the OAM source MAC address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:SMAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:SMAC?
<b>Description</b>	This query returns the OAM source MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:SMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	



### 12.31.3 ETHernet:PORT<Pt>:OAM:MAC:ETYPe

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MAC:ETYPe <type>
<b>Description</b>	This command sets the encapsulated customer Ethernet Type.
<b>Parameters</b>	<Pt> = Port number <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MAC:ETYP #H8100
<b>Note</b>	This setting is used when ETH:PORT1:OAM:VLAN is enabled only.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MAC:ETYPe?
<b>Description</b>	This query returns the encapsulated customer Ethernet Type.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MAC:ETYP? → #H8100
<b>Note</b>	

### 12.31.4 ETHernet:PORT<Pt>:OAM:AH:DISCcovery[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCcovery[:ENABLE] <enable>
<b>Description</b>	This command enables/disables IEEE 802.3ah protocol activity.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCcovery[:ENABLE]?
<b>Description</b>	This query returns whether or not IEEE 802.3ah protocol activity is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC? → 0
<b>Note</b>	

### 12.31.5 ETHernet:PORT<Pt>:OAM:AH:DISCcovery:LMODe

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCcovery:LMODe <mode>
<b>Description</b>	This command sets the link mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> PASSive: ACTive: <i>DEFault = PASSive</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:LMOD PASS
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:LMODE?
<b>Description</b>	This query returns the link mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:LMOD? → PASS
<b>Note</b>	

### 12.31.6 ETHernet:PORT<Pt>:OAM:AH:DISCover:VOUI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VOUI <value>
<b>Description</b>	This command sets the vendor OUI.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=16777215, DEFault=145</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VOUI #H91
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VOUI?
<b>Description</b>	This query returns the vendor OUI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VOUI? → 145
<b>Note</b>	

### 12.31.7 ETHernet:PORT<Pt>:OAM:AH:DISCover:VSInfo

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VSInfo <value>
<b>Description</b>	This command sets the vendor specific information.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=268435455, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VSIN 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VSInfo?
<b>Description</b>	This query returns the vendor specific information.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VSIN? → 1
<b>Note</b>	

### 12.31.8 ETHernet:PORT<Pt>:OAM:AH:DISCover:UNIDirectional

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:UNIDirectional <enable>
<b>Description</b>	This command enables/disables unidirectional operation.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:UNID OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:UNIDirectional?
<b>Description</b>	This query returns whether or not unidirectional operation is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:UNID? → 0
<b>Note</b>	

### 12.31.9 ETHernet:PORT<Pt>:OAM:AH:DISCover:VRETrival

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VRETrival <enable>
<b>Description</b>	This command enables/disables variable retrieval.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VRET OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:DISCover:VRETrival?
<b>Description</b>	This query returns whether or not variable retrieval is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:DISC:VRET? → 0
<b>Note</b>	

### 12.31.10 ETHernet:PORT<Pt>:OAM:AH:LDEFects:LFAults

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:LFAults <enable>
<b>Description</b>	This command enables/disables detection of local link faults.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:LFA OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:LFAults?
<b>Description</b>	This query returns whether or not detection of local link faults is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:LFA? → 0
<b>Note</b>	

### 12.31.11 ETHernet:PORT<Pt>:OAM:AH:LDEFects:DGASp

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:DGASp <enable>
<b>Description</b>	This command enables/disables detection of dying gasp.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:DGAS OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:DGASp?
<b>Description</b>	This query returns whether or not detection of dying gasp is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:DGAS? → 0
<b>Note</b>	

### 12.31.12 ETHernet:PORT<Pt>:OAM:AH:LDEFects:CEvent

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:CEvent <enable>
<b>Description</b>	This command enables/disables detection of critical events.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:CE OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AH:LDEFects:CEvent?
<b>Description</b>	This query returns whether or not detection of critical events is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AH:LDEF:CE? → 0
<b>Note</b>	

### 12.31.13 ETHernet:PORT<Pt>:OAM:AG[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG[:ENABLE] <enable>
<b>Description</b>	This command enables/disables IEEE 802.1ah protocol activity.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG[:ENABLE]?
<b>Description</b>	This query returns whether or not IEEE 802.1ah protocol activity is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG? → 0
<b>Note</b>	

### 12.31.14 ETHernet:PORT<Pt>:OAM:AG:MEPid

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MEPid <id>
<b>Description</b>	This command sets the management end point ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:MEP 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MEPid?
<b>Description</b>	This query returns the management end point ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:MEP? → 1
<b>Note</b>	

### 12.31.15 ETHernet:PORT<Pt>:OAM:AG:MDLevel

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MDLevel <level>
<b>Description</b>	This command sets the maintenance domain level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:MDL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MDLevel?
<b>Description</b>	This query returns the maintenance domain level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:MDL? → 1
<b>Note</b>	

### 12.31.16 ETHernet:PORT<Pt>:OAM:AG:DOMain

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:DOMain <name>
<b>Description</b>	This command sets the domain name.
<b>Parameters</b>	<Pt> = Port number <name> = <STRING PROGRAM DATA> Domain name string.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:DOM "Domain"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:DOMain?
<b>Description</b>	This query returns the domain name.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:DOM? → "Domain"
<b>Note</b>	

### 12.31.17 ETHernet:PORT<Pt>:OAM:AG:MAIDentifier

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MAIDentifier <name>
<b>Description</b>	This command sets the maintenance association identifier.
<b>Parameters</b>	<Pt> = Port number <name> = <STRING PROGRAM DATA> Association string.
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:MAID "Anritsu"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MAIDentifier?
<b>Description</b>	This query returns the maintenance association identifier.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:MAID? → "Anritsu"
<b>Note</b>	

### 12.31.18 ETHernet:PORT<Pt>:OAM:AG:CCM:INTerval

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:CCM:INTerval <interval>
<b>Description</b>	This command sets the continuity check message interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS10: 10 milli seconds MS100: 100 milli seconds S1: 1 second S10: 10 seconds S60: 1 minute S600: 10 minutes <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:CCM:INT S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:CCM:INTerval?
<b>Description</b>	This query returns the continuity check message interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:CCM:INT? → S1
<b>Note</b>	

### 12.31.19 ETHernet:PORT<Pt>:OAM:AG:LBM:OTLV

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:OTLV <tlv>
<b>Description</b>	This command sets the loop-back message optional TLV type.
<b>Parameters</b>	<Pt> = Port number <tlv> = <CHARACTER PROGRAM DATA> NONE: No TLV DATA: Data TLV TEST: Test TLV <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:OTLV NONE
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:OTLV?
<b>Description</b>	This query returns the loop-back message optional TLV type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tlv> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:OTLV? → NONE
<b>Note</b>	

**12.31.20 ETHernet:PORT<Pt>:OAM:AG:LBM:TLVLength**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:TLVLength <length>
<b>Description</b>	This command sets the loop-back message TLV length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=32, MAXimum=1480, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:TLVL 60
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:TLVLength?
<b>Description</b>	This query returns the loop-back message TLV length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:TLVL? → 60
<b>Note</b>	

**12.31.21 ETHernet:PORT<Pt>:OAM:AG:LBM:DTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:DTLV:VALue <value>
<b>Description</b>	This command sets the data loop-back message TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:DTLV:VAL ""
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:DTLV:VALue?
<b>Description</b>	This query returns the data loop-back message TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:DTLV:VAL? → ""
<b>Note</b>	

**12.31.22 ETHernet:PORT<Pt>:OAM:AG:LBM:TTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:TTLV:VALue <value>
<b>Description</b>	This command sets the loop-back message test TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <CHARACTER PROGRAM DATA> ZERos: Zeros without CRC-32 ZCRC: Zeros with CRC-32 <i>DEFault = ZERos</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:TTLV:VAL ZER
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LBM:TTLV:VALue?
<b>Description</b>	This query returns the loop-back message test TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LBM:TTLV:VAL? → ZER
<b>Note</b>	

**12.31.23 ETHernet:PORT<Pt>:OAM:AG:LTM:TTL**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LTM:TTL <ttl>
<b>Description</b>	This command sets the link trace message TTL.
<b>Parameters</b>	<Pt> = Port number <ttl> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=65</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LTM:TTL 65
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LTM:TTL?
<b>Description</b>	This query returns the link trace message TTL.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ttl> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LTM:TTL? → 65
<b>Note</b>	

**12.31.24 ETHernet:PORT<Pt>:OAM:AG:LTM:TID**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LTM:TID <id>
<b>Description</b>	This command sets the link trace message transmission ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=65535, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:AG:LTM:TID 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:LTM:TID?
<b>Description</b>	This query returns the link trace message transmission ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:AG:LTM:TID? → 1
<b>Note</b>	

**12.31.25 ETHernet:PORT<Pt>:OAM:AG:MEPList:ADD**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MEPList:ADD <mepId>,<mac>[,<level>[,<association>],<domain>]
<b>Description</b>	This command adds a management end point to the MEP list.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i> <mac> = <STRING PROGRAM DATA> <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i> <association> = <STRING PROGRAM DATA> <domain> = <STRING PROGRAM DATA>
<b>Response</b>	None
<b>Example</b>	ETH:PORT1:OAM:AG:MEPL:ADD 234,"00-00-00-00-00-11"
<b>Note</b>	



**12.31.26 ETHernet:PORT<Pt>:OAM:AG:MEPList:DElete[:MEP]**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MEPList:DElete[:MEP] <mepId>
<b>Description</b>	This command deletes a management end point from the MEP list.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None
<b>Example</b>	ETH:PORT1:OAM:AG:MEPL:DEL 234
<b>Note</b>	

**12.31.27 ETHernet:PORT<Pt>:OAM:AG:MEPList:CATalog?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:AG:MEPList:CATalog?
<b>Description</b>	This query returns the items on the management end point list.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<endPoint>),}* = <EXPRESSION RESPONSE DATA> <endPoint> is split into five separate results: (<mepId>,<mac>,<level>,<association>,<domain>)
<b>Example</b>	ETH:PORT1:OAM:AG:MEPL:CAT? → (234,00-00-00-00-00-11,1,Association-A,Domain1), (345,00-00-00-00-00-22,1,Association-B,Domain2)
<b>Note</b>	If the list is empty an execution error will be reported.

**12.31.28 ETHernet:PORT<Pt>:OAM:Y[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y[:ENABLE] <enable>
<b>Description</b>	This command enables/disables Y.1731 protocol activity.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y[:ENABLE]?
<b>Description</b>	This query returns whether or not Y.1731 protocol activity is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y? → 0
<b>Note</b>	

**12.31.29 ETHernet:PORT<Pt>:OAM:Y:MEPid**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEPid <id>
<b>Description</b>	This command sets the management end point ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:MEP 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEPid?
<b>Description</b>	This query returns the management end point ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:MEP? → 1
<b>Note</b>	

### 12.31.30 ETHernet:PORT<Pt>:OAM:Y:MEGid

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEGid <id>
<b>Description</b>	This command sets the MEG ID.
<b>Parameters</b>	<Pt> = Port number <id> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:MEG "A"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEGid?
<b>Description</b>	This query returns the MEG ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:MEG? → "A"
<b>Note</b>	

### 12.31.31 ETHernet:PORT<Pt>:OAM:Y:MEGLevel

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEGLevel <level>
<b>Description</b>	This command sets the MEG level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:MEGL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEGLevel?
<b>Description</b>	This query returns the MEG level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:MEGL? → 1
<b>Note</b>	

**12.31.32 ETHernet:PORT<Pt>:OAM:Y:CCM:INTerval**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:CCM:INTerval <interval>
<b>Description</b>	This command sets the continuity check messages interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS10: 10 milli seconds MS100: 100 milli seconds S1: 1 second S10: 10 seconds S60: 1 minute S600: 10 minutes <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:CCM:INT S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:CCM:INTerval?
<b>Description</b>	This query returns the continuity check messages interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:CCM:INT? → S1
<b>Note</b>	

**12.31.33 ETHernet:PORT<Pt>:OAM:Y:LBM:OTLV**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:OTLV <tlv>
<b>Description</b>	This command sets the loop-back message optional TLV type.
<b>Parameters</b>	<Pt> = Port number <tlv> = <CHARACTER PROGRAM DATA> NONE: No TLV DATA: Data TLV TEST: Test TLV <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:OTLV NON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:OTLV?
<b>Description</b>	This query returns the loop-back message optional TLV type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tlv> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:OTLV? → NON
<b>Note</b>	

**12.31.34 ETHernet:PORT<Pt>:OAM:Y:LBM:TLVLength**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:TLVLength <length>
<b>Description</b>	This command sets the loop-back message TLV length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=32, MAXimum=1480, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:TLVL 60
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:TLVLength?
<b>Description</b>	This query returns the loop-back message TLV length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:TLVL? → 60
<b>Note</b>	

### 12.31.35 ETHernet:PORT<Pt>:OAM:Y:LBM:DTLV:VALue

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:DTLV:VALue <value>
<b>Description</b>	This command sets the loop-back message data TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:DTLV:VAL ""
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:DTLV:VALue?
<b>Description</b>	This query returns the loop-back message data TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:DTLV:VAL? → ""
<b>Note</b>	

### 12.31.36 ETHernet:PORT<Pt>:OAM:Y:LBM:TTLV:VALue

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:TTLV:VALue <value>
<b>Description</b>	This command sets the loop-back message test TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <CHARACTER PROGRAM DATA> ZERos: Zeros without CRC-32 ZCRC: Zeros with CRC-32 <i>DEFault = ZERos</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:TTLV:VAL ZER
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LBM:TTLV:VALue?
<b>Description</b>	This query returns the loop-back message test TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LBM:TTLV:VAL? → ZER
<b>Note</b>	

### 12.31.37 ETHernet:PORT<Pt>:OAM:Y:LTM:TTL

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LTM:TTL <ttl>
<b>Description</b>	This command sets the link trace message TTL.
<b>Parameters</b>	<Pt> = Port number <ttl> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=255, DEFault=65</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LTM:TTL 65
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LTM:TTL?
<b>Description</b>	This query returns the link trace message TTL.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tTl> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LTM:TTL? → 65
<b>Note</b>	

### 12.31.38 ETHernet:PORT<Pt>:OAM:Y:LTM:TID

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LTM:TID <id>
<b>Description</b>	This command sets the link trace message transaction ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=65535, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LTM:TID 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LTM:TID?
<b>Description</b>	This query returns the link trace message transaction ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LTM:TID? → 1
<b>Note</b>	

### 12.31.39 ETHernet:PORT<Pt>:OAM:Y:TST:FTSend

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:FTSend <count>
<b>Description</b>	This command sets the number of test frames to send.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=100, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:TST:FTS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:FTSend?
<b>Description</b>	This query returns the number of test frames to send.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:TST:FTS? → 1
<b>Note</b>	

### 12.31.40 ETHernet:PORT<Pt>:OAM:Y:TST:RATE

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:RATE <interval>
<b>Description</b>	This command sets the test rate.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS100: 100 milli seconds S1: 1 second S10: 10 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:TST:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:RATE?
<b>Description</b>	This query returns the test rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:TST:RATE? → S1
<b>Note</b>	

#### 12.31.41 ETHernet:PORT<Pt>:OAM:Y:TST:OTLV

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:OTLV <tlv>
<b>Description</b>	This command sets the test optional TLV type.
<b>Parameters</b>	<Pt> = Port number <tlv> = <CHARACTER PROGRAM DATA> NONE: No TLV TEST: Test TLV <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:TST:OTLV NONE
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:OTLV?
<b>Description</b>	This query returns the test optional TLV type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tlv> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:TST:OTLV? → NONE
<b>Note</b>	

#### 12.31.42 ETHernet:PORT<Pt>:OAM:Y:TST:TLVLength

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:TLVLength <length>
<b>Description</b>	This command sets the test TLV length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=32, MAXimum=1480, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:TST:TLVL 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:TLVLength?
<b>Description</b>	This query returns the test TLV length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:TST:TLVL? → 0
<b>Note</b>	

#### 12.31.43 ETHernet:PORT<Pt>:OAM:Y:TST:TTLV:VALue

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:TTLV:VALue <value>
<b>Description</b>	This command sets the test TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <CHARACTER PROGRAM DATA> ZERos: Zeros without CRC-32 ZCRC: Zeros with CRC-32 <i>DEFault = ZERos</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:TST:TTLV:VAL ZER
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:TST:TTLV:VALue?
<b>Description</b>	This query returns the test TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:TST:TTLV:VAL? → ZER
<b>Note</b>	

#### 12.31.44 ETHernet:PORT<Pt>:OAM:Y:MCC:OUI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MCC:OUI <value>
<b>Description</b>	This command sets the MCC OUI.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=16777215, DEFault=145</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:MCC:OUI #H91
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MCC:OUI?
<b>Description</b>	This query returns the MCC OUI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:MCC:OUI? → 145
<b>Note</b>	

#### 12.31.45 ETHernet:PORT<Pt>:OAM:Y:MCC:DATA

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MCC:DATA <pattern>
<b>Description</b>	This command sets the MCC data.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:MCC:DATA "12345AB"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MCC:DATA?
<b>Description</b>	This query returns the MCC data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:MCC:DATA? → "12345AB"
<b>Note</b>	

#### 12.31.46 ETHernet:PORT<Pt>:OAM:Y:LCK:CMEG

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LCK:CMEG <level>
<b>Description</b>	This command sets the lock condition client MEG level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LCK:CMEG 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LCK:CMEG?
<b>Description</b>	This query returns the lock condition client MEG level
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LCK:CMEG? → 0
<b>Note</b>	

### 12.31.47 ETHernet:PORT<Pt>:OAM:Y:LCK:RATE

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LCK:RATE <rate>
<b>Description</b>	This command sets the lock condition rate.
<b>Parameters</b>	<Pt> = Port number <rate> = <CHARACTER PROGRAM DATA> S1: 1 second S60: 1 minute <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LCK:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LCK:RATE?
<b>Description</b>	This query returns the lock condition rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LCK:RATE? → S1
<b>Note</b>	

### 12.31.48 ETHernet:PORT<Pt>:OAM:Y:AIS:CMEG

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:AIS:CMEG <level>
<b>Description</b>	This command sets the alarm indication signal client MEG level.
<b>Parameters</b>	<Pt> = Port number <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:AIS:CMEG 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:AIS:CMEG?
<b>Description</b>	This query returns the alarm indication signal client MEG level.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<level> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:AIS:CMEG? → 0
<b>Note</b>	

### 12.31.49 ETHernet:PORT<Pt>:OAM:Y:AIS:RATE

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:AIS:RATE <rate>
<b>Description</b>	This command sets the alarm indication signal rate.
<b>Parameters</b>	<Pt> = Port number <rate> = <CHARACTER PROGRAM DATA> S1: 1 second S60: 1 minute <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:AIS:RATE S1
<b>Note</b>	



<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:AIS:RATE?
<b>Description</b>	This query returns the alarm indication signal rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:AIS:RATE? → S1
<b>Note</b>	

### 12.31.50 ETHernet:PORT<Pt>:OAM:Y:DMONe:TYPE

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TYPE <mode>
<b>Description</b>	This command sets the one-way delay measurement mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> ODEMand: On-demand mode PROactive: Proactive mode <i>DEFault = PROactive</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TYPE PRO
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TYPE?
<b>Description</b>	This query returns the one-way delay measurement mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TYPE? → PR
<b>Note</b>	

### 12.31.51 ETHernet:PORT<Pt>:OAM:Y:DMONe:RATE

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:RATE <interval>
<b>Description</b>	This command sets the one-way delay measurement rate.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS100: 100 milli seconds S1: 1 second S10: 10 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:RATE?
<b>Description</b>	This query returns the one-way delay measurement rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:RATE? → S1
<b>Note</b>	

## 12.31.52 ETHernet:PORT&lt;Pt&gt;:OAM:Y:DMONe:FTSend

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:FTSend <count>
<b>Description</b>	This command sets the number of one-way delay measurement frames to send.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=1000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:FTS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:FTSend?
<b>Description</b>	This query returns the number of one-way delay measurement frames to send.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:FTS? → 1
<b>Note</b>	

## 12.31.53 ETHernet:PORT&lt;Pt&gt;:OAM:Y:DMONe:OTLV

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:OTLV <tlv>
<b>Description</b>	This command sets the one-way delay measurement optional TLV type.
<b>Parameters</b>	<Pt> = Port number <tlv> = <CHARACTER PROGRAM DATA> NONE: No TLV DATA: Data TLV TEST: Test TLV <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:OTLV NONE
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:OTLV?
<b>Description</b>	This query returns the one-way delay measurement optional TLV type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tlv> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:OTLV? → NONE
<b>Note</b>	

## 12.31.54 ETHernet:PORT&lt;Pt&gt;:OAM:Y:DMONe:TLVLength

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TLVLength <length>
<b>Description</b>	This command sets the one-way delay measurement TLV length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=32, MAXimum=1480, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TLVL 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TLVLength?
<b>Description</b>	This query returns the one-way delay measurement TLV length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TLVL? → 0
<b>Note</b>	

**12.31.55 ETHernet:PORT<Pt>:OAM:Y:DMONe:DTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:DTLV:VALue <value>
<b>Description</b>	This command sets the data TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:DTLV:VAL ""
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:DTLV:VALue?
<b>Description</b>	This query returns the data TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:DTLV:VAL? → ""
<b>Note</b>	

**12.31.56 ETHernet:PORT<Pt>:OAM:Y:DMONe:TTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TTLV:VALue <value>
<b>Description</b>	This command sets the test TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=500, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TTLV:VAL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMONe:TTLV:VALue?
<b>Description</b>	This query returns the test TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMON:TTLV:VAL? → 1
<b>Note</b>	

**12.31.57 ETHernet:PORT<Pt>:OAM:Y:DMM:TYPE**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TYPE <mode>
<b>Description</b>	This command sets the delay measurement message type.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> ODEMand: On-demand mode PROactive: Proactive mode <i>DEFault = PROactive</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TYPE PRO
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TYPE?
<b>Description</b>	This query returns the delay measurement message type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TYPE? → PR
<b>Note</b>	

**12.31.58 ETHernet:PORT<Pt>:OAM:Y:DMM:RATE**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:RATE <interval>
<b>Description</b>	This command sets the delay measurement message rate.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS100: 100 milli seconds S1: 1 second S10: 10 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:RATE?
<b>Description</b>	This query returns the delay measurement message rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:RATE? → S1
<b>Note</b>	

**12.31.59 ETHernet:PORT<Pt>:OAM:Y:DMM:FTSend**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:FTSend <count>
<b>Description</b>	This command sets the number of delay measurement message frames to send.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=1000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:FTS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:FTSend?
<b>Description</b>	This query returns the number of delay measurement message frames to send.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:FTS? → 1
<b>Note</b>	

**12.31.60 ETHernet:PORT<Pt>:OAM:Y:DMM:FVTHreshold**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:FVTHreshold <count>
<b>Description</b>	This command sets the delay measurement message frame variation threshold.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:FVTH 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:FVTHreshold?
<b>Description</b>	This query returns the frame variation.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:FVTH? → 0
<b>Note</b>	

**12.31.61 ETHernet:PORT<Pt>:OAM:Y:DMM:OTLV**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:OTLV <tlv>
<b>Description</b>	This command sets the delay measurement message optional TLV type.
<b>Parameters</b>	<Pt> = Port number <tlv> = <CHARACTER PROGRAM DATA> NONE: No TLV DATA: Data TLV TEST: Test TLV <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:OTLV NONE
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:OTLV?
<b>Description</b>	This query returns the delay measurement message optional TLV type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<tlv> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:OTLV? → NONE
<b>Note</b>	

**12.31.62 ETHernet:PORT<Pt>:OAM:Y:DMM:TLVLength**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TLVLength <length>
<b>Description</b>	This command sets the delay measurement message TLV length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum=32, MAXimum=1480, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TLVL 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TLVLength?
<b>Description</b>	This query returns the delay measurement message TLV length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TLVL? → 0
<b>Note</b>	

**12.31.63 ETHernet:PORT<Pt>:OAM:Y:DMM:DTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:DTLV:VALue <value>
<b>Description</b>	This command sets the delay measurement message data TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:DTLV:VAL ""
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:DTLV:VALue?
<b>Description</b>	This query returns the delay measurement message data TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:DTLV:VAL? → ""
<b>Note</b>	

**12.31.64 ETHernet:PORT<Pt>:OAM:Y:DMM:TTLV:VALue**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TTLV:VALue <value>
<b>Description</b>	This command sets the delay measurement message test TLV value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=500, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TTLV:VAL 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:DMM:TTLV:VALue?
<b>Description</b>	This query returns the delay measurement message test TLV value.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:DMM:TTLV:VAL? → 1
<b>Note</b>	

**12.31.65 ETHernet:PORT<Pt>:OAM:Y:LMM:RATE**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:RATE <interval>
<b>Description</b>	This command sets the loss measurement message interval length.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS100: 100 milli seconds S1: 1 second S10: 10 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:RATE?
<b>Description</b>	This query returns the loss measurement message interval length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:RATE? → S1
<b>Note</b>	

**12.31.66 ETHernet:PORT<Pt>:OAM:Y:LMM:FTSend**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:FTSend <count>
<b>Description</b>	This command sets the number of loss measurement message frames to send.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=1000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:FTS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:FTSend?
<b>Description</b>	This query returns the number of loss measurement message frames to send.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:FTS? → 1
<b>Note</b>	

**12.31.67 ETHernet:PORT<Pt>:OAM:Y:LMM:FLTHreshold**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:FLTHreshold <threshold>
<b>Description</b>	This command sets the loss measurement message frame loss threshold.
<b>Parameters</b>	<Pt> = Port number <threshold> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=5, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:FLTH 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:LMM:FLTHreshold?
<b>Description</b>	This query returns the loss measurement message frame loss threshold.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<threshold> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:LMM:FLTH? → 0
<b>Note</b>	

**12.31.68 ETHernet:PORT<Pt>:OAM:Y:SLM:RATE**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:RATE <interval>
<b>Description</b>	This command sets the synthetic loss measurement rate.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> MS100: 100 milli seconds S1: 1 second S10: 10 seconds <i>DEFault = S1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:RATE S1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:RATE?
<b>Description</b>	This query returns the synthetic loss measurement rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:RATE? → S1
<b>Note</b>	

**12.31.69 ETHernet:PORT<Pt>:OAM:Y:SLM:FTSend**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:FTSend <count>
<b>Description</b>	This command sets the number of synthetic loss measurement frames to send.
<b>Parameters</b>	<Pt> = Port number <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=1000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:FTS 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:FTSend?
<b>Description</b>	This query returns the number of synthetic loss measurement frames to send.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:FTS? → 1
<b>Note</b>	

**12.31.70 ETHernet:PORT<Pt>:OAM:Y:SLM:FLTHreshold**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:FLTHreshold <threshold>
<b>Description</b>	This command sets the synthetic loss measurement frame loss threshold.
<b>Parameters</b>	<Pt> = Port number <threshold> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=5, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:FLTH 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:SLM:FLTHreshold?
<b>Description</b>	This query returns the frame loss threshold.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<threshold> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:SLM:FLTH? → 0
<b>Note</b>	

**12.31.71 ETHernet:PORT<Pt>:OAM:Y:EXM:DATA**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:EXM:DATA <pattern>
<b>Description</b>	This command sets the experimental message data.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:EXM:DATA "12345AB"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:EXM:DATA?
<b>Description</b>	This query returns the experimental message data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:EXM:DATA? → "12345AB"
<b>Note</b>	

**12.31.72 ETHernet:PORT<Pt>:OAM:Y:VSM:DATA**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:VSM:DATA <pattern>
<b>Description</b>	This command sets the vendor specific message data.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:Y:VSM:DATA "12345AB"
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:VSM:DATA?
<b>Description</b>	This query returns the vendor specific message data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:Y:VSM:DATA? → "12345AB"
<b>Note</b>	



**12.31.73 ETHernet:PORT<Pt>:OAM:Y:MEPList:ADD**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEPList:ADD <mepId>,<mac>[,<level>[,<megId>]]
<b>Description</b>	This command adds a management end point to the MEP list.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i> <mac> = <STRING PROGRAM DATA> <level> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i> <association> = <STRING PROGRAM DATA> <domain> = <STRING PROGRAM DATA>
<b>Response</b>	None
<b>Example</b>	ETH:PORT1:OAM:Y:MEPL:ADD 234,"00-00-00-00-00-11"
<b>Note</b>	

**12.31.74 ETHernet:PORT<Pt>:OAM:Y:MEPList:DELeTe[:MEP]**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEPList:DELeTe[:MEP] <mepId>
<b>Description</b>	This command deletes a management end point from the MEP list.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None
<b>Example</b>	ETH:PORT1:OAM:Y:MEPL:DEL 234
<b>Note</b>	

**12.31.75 ETHernet:PORT<Pt>:OAM:Y:MEPList:CATalog?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:Y:MEPList:CATalog?
<b>Description</b>	This query returns the items on the management end point list.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<endPoint>),}* = <EXPRESSION RESPONSE DATA> <endPoint> is split into five separate results: (<mepId>,<mac>,<level>,<association>,<domain>)
<b>Example</b>	ETH:PORT1:OAM:Y:MEPL:CAT? → (234,00-00-00-00-00-11,1,Association-A,Domain1), (345,00-00-00-00-00-22,1,Association-B,Domain2)
<b>Note</b>	If the list is empty an execution error will be reported.

**12.31.76 ETHernet:PORT<Pt>:OAM:DISCcovery:TYPE**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCcovery:TYPE <mode>
<b>Description</b>	This command sets the discovery type.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> CCM: LBM: <i>DEFault = CCM</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:DISC:TYPE CCM
<b>Note</b>	This setting applies to the 802.1ag and Y.1731 protocols.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCoverY:TYPE?
<b>Description</b>	This query returns the discovery type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:DISC:TYPE? → CCM
<b>Note</b>	

### 12.31.77 ETHernet:PORT<Pt>:OAM:DISCoverY:INTerval

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCoverY:INTerval <interval>
<b>Description</b>	This command sets the discovery interval.
<b>Parameters</b>	<Pt> = Port number <interval> = <CHARACTER PROGRAM DATA> S5: 5 seconds S15: 15 seconds S60: 1 minute <i>DEFault = S5</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:DISC:INT S5
<b>Note</b>	This setting applies to the 802.1ag and Y.1731 protocols.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCoverY:INTerval?
<b>Description</b>	This query returns the discovery interval.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:DISC:INT? → S5
<b>Note</b>	

### 12.31.78 ETHernet:PORT<Pt>:OAM:DISCoverY:DMAX

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCoverY:DMAX <value>
<b>Description</b>	This command sets the maximum number of devices to discover.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=32, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:DISC:DMAX 1
<b>Note</b>	This setting applies to the 802.1ag and Y.1731 protocols.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCoverY:DMAX?
<b>Description</b>	This query returns the maximum number of devices to discover.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:DISC:DMAX? → 1
<b>Note</b>	

**12.31.79 ETHernet:PORT<Pt>:OAM:DISCover:CATalog?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:DISCover:CATalog?
<b>Description</b>	This query returns the list of discovered OAM MEPs.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Response</b>	{(<endPoint>),}* = <EXPRESSION RESPONSE DATA> <endPoint> is split into five separate results: (<mepId>,<mac>,<level>,<associationOrMeg>,<domain>)
<b>Example</b>	ETH:PORT1:OAM:DISC:CAT? → (234,00-00-00-00-00-11,1,Association-A,Domain1), (345,00-00-00-00-00-22,1,Association-B,Domain2)
<b>Note</b>	The <domain> string is not returned when Y.1731 is active. The time for this command to return can extend to the value in the ETH:PORT1:OAM:DISC:INT setting.

**12.31.80 ETHernet:PORT<Pt>:OAM:MPLS[:ENABLE]**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS[:ENABLE] <enable>
<b>Description</b>	This command enables/disables MPLS.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS[:ENABLE]?
<b>Description</b>	This query returns the state of MPLS.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS? → 1
<b>Note</b>	

**12.31.81 ETHernet:PORT<Pt>:OAM:MPLS:LCOunt**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LCOunt <levels>
<b>Description</b>	This command sets the number of active MPLS levels.
<b>Parameters</b>	<Pt> = Port number <levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS:LCO 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LCOunt?
<b>Description</b>	This query returns the number of active MPLS levels.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS:LCO? → 2
<b>Note</b>	

**12.31.82 ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:LABel**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:LABel <label>
<b>Description</b>	This command sets the MPLS label.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <label> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1048575, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:LAB 1048575
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels. Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:LABel?
<b>Description</b>	This query returns the MPLS label.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<label> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:LAB? → 1048575
<b>Note</b>	

**12.31.83 ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TCLass**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TCLass <value>
<b>Description</b>	This command sets the MPLS traffic class.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:TCL 5
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels. Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TCLass?
<b>Description</b>	This query returns the MPLS traffic class.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:TCL? → 5
<b>Note</b>	

**12.31.84 ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TTL**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TTL <value>
<b>Description</b>	This command sets the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N <sup>1</sup> ) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=32</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:TTL 32
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active MPLS Levels. Level 1 corresponds to the level at the top of the label stack and N is the level at the bottom of the stack (bottom of stack flag set).

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:LEVel<Lv>:TTL?
<b>Description</b>	This query returns the MPLS time to live.
<b>Parameters</b>	<Pt> = Port number <Lv> = MPLS level (1-N)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS:LEV1:TTL? → 32
<b>Note</b>	

### 12.31.85 ETHernet:PORT<Pt>:OAM:MPLS:TPRofile[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:TPRofile[:ENABle] <enable>
<b>Description</b>	This command enables/disables MPLS transport profile.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MPLS:TPR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MPLS:TPRofile[:ENABle]?
<b>Description</b>	This query returns the state of MPLS transport profile.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MPLS:TPR? → 1
<b>Note</b>	

### 12.31.86 ETHernet:PORT<Pt>:OAM:MIM[:ENABle]

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM[:ENABle] <enable>
<b>Description</b>	This command enables/disables MAC in MAC (alias PBB).
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM[:ENABle]?
<b>Description</b>	This query returns whether or not MAC in MAC is enabled.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM? → 1
<b>Note</b>	

### 12.31.87 ETHernet:PORT<Pt>:OAM:MIM:BTAG:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:DEI <enable>
<b>Description</b>	This command sets the B-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:DEI ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:DEI?
<b>Description</b>	This query returns the B-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:DEI? → 1
<b>Note</b>	

### 12.31.88 ETHernet:PORT<Pt>:OAM:MIM:BTAG:PRiority

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:PRiority <priority>
<b>Description</b>	This command sets the B-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <priority> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:PRI 7
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:PRiority?
<b>Description</b>	This query returns the B-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:PRI? → 7
<b>Note</b>	

### 12.31.89 ETHernet:PORT<Pt>:OAM:MIM:BTAG:VID

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:VID <vid>
<b>Description</b>	This command sets the B-TAG Backbone VLAN ID.
<b>Parameters</b>	<Pt> = Port number <vid> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4095, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:VID 1024
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:BTAG:VID?
<b>Description</b>	This query returns the B-TAG Backbone VLAN ID.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<vid> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:BTAG:VID? → 1024
<b>Note</b>	

### 12.31.90 ETHernet:PORT<Pt>:OAM:MIM:ITAG:UCA

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:UCA <enable>
<b>Description</b>	This command sets the I-TAG UCA bit.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:UCA ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:UCA?
<b>Description</b>	This query returns the I-TAG UCA bit.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:UCA? → 1
<b>Note</b>	

### 12.31.91 ETHernet:PORT<Pt>:OAM:MIM:ITAG:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:DEI <enable>
<b>Description</b>	This command sets the I-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault=OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:DEI ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:DEI?
<b>Description</b>	This query returns the I-TAG DEI bit.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:DEI? → 1
<b>Note</b>	

### 12.31.92 ETHernet:PORT<Pt>:OAM:MIM:ITAG:PRIority

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:PRIority <priority>
<b>Description</b>	This command sets the I-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number <priority> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 7, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:PRI 7
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:PRIority?
<b>Description</b>	This query returns the I-TAG Priority (PCP).
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:PRI? → 7
<b>Note</b>	

### 12.31.93 ETHernet:PORT<Pt>:OAM:MIM:ITAG:SID

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:SID <sid>
<b>Description</b>	This command sets the I-TAG SID.
<b>Parameters</b>	<Pt> = Port number <sid> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 16777215, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:SID 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ITAG:SID?
<b>Description</b>	This query returns the I-TAG SID.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<sid> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:ITAG:SID? → 1
<b>Note</b>	

#### 12.31.94 ETHernet:PORT<Pt>:OAM:MIM:SMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:SMAC <address>
<b>Description</b>	This command sets the MAC in MAC source MAC address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:SMAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:SMAC?
<b>Description</b>	This query returns the MAC in MAC source MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:SMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

#### 12.31.95 ETHernet:PORT<Pt>:OAM:MIM:ETHernet:DMAC

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ETHernet:DMAC <address>
<b>Description</b>	This command sets the MAC in MAC destination MAC address.
<b>Parameters</b>	<Pt> = Port number <address> = <STRING PROGRAM DATA> MAC address
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:MIM:ETH:DMAC "00-50-C2-35-D2-EF"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:MIM:ETHernet:DMAC?
<b>Description</b>	This query returns the MAC in MAC destination MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<address> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:MIM:ETH:DMAC? → "00-50-C2-35-D2-EF"
<b>Note</b>	

#### 12.31.96 ETHernet:PORT<Pt>:OAM:VLAN[:ENABLE]

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN[:ENABLE] <enable>
<b>Description</b>	This command enables/disables VLAN.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>Default = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN ON
<b>Note</b>	



<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN[:ENABLE]?
<b>Description</b>	This query returns whether or not VLAN is enabled.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<boolean> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN? → 1
<b>Note</b>	

### 12.31.97 ETHernet:PORT<Pt>:OAM:VLAN:LCOunt

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LCOunt <levels>
<b>Description</b>	This command sets the number of active VLAN levels.
<b>Parameters</b>	<Pt> = Port number <levels> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LCO 2
<b>Note</b>	

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LCOunt?
<b>Description</b>	This query returns the number of active VLAN levels.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<levels> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LCO? → 2
<b>Note</b>	

### 12.31.98 ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ID

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ID <number>
<b>Description</b>	This command sets the VLAN ID.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <number> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4095, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:ID 1024
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels. Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ID?
<b>Description</b>	This query returns the VLAN ID.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:ID? → 1024
<b>Note</b>	

**12.31.99 ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:CFI ON
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels. Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:CFI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI?

**12.31.100 ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI <enable>
<b>Description</b>	This command enables/disables the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:DEI ON
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels. Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). <sup>2</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>3</sup> This command is as same as ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:DEI?
<b>Description</b>	This query returns the state of the VLAN canonical format indicator.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:DEI? → 1
<b>Note</b>	<sup>1</sup> CFI bit in the VLAN tag was renamed to 'DEI' in IEEE802.1Q 2014 edition <sup>2</sup> This command is as same as ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:CFI?

**12.31.101 ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:PRIority**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:PRIority <priority>
<b>Description</b>	This command sets the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> ) <priority> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=7, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:PRI 7
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels. Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame).

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:PRIority?
<b>Description</b>	This query returns the VLAN priority.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N)
<b>Response</b>	<priority> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:PRI? → 7
<b>Note</b>	

**12.31.102 ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ETYPe**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ETYPe <type>
<b>Description</b>	This command sets the VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N) <sup>1</sup> <type> = <NUMERIC PROGRAM DATA> Acceptable values: #H8100 #H88A8 #H9100 #H9200 <i>DEFault=#H8100</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:ETYP #H8100
<b>Notes</b>	<sup>1</sup> It is only possible to use this command for levels (1-M), where M is the number of active VLAN Levels minus one. Level 1 corresponds to the outer tag (closest to the Ethernet header) and N is the inner tag (closest to the payload portion of the frame). It is not possible to use this command for VLAN level N because Ethertype at this level is automatically set. MAC level Ethertype is set by :ETH:PORT1:OAM:MAC:ETYPe command.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:VLAN:LEVel<Lv>:ETYPe?
<b>Description</b>	This query returns the OAM VLAN Ethertype.
<b>Parameters</b>	<Pt> = Port number <Lv> = VLAN level (1-N <sup>1</sup> )
<b>Response</b>	<type> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:VLAN:LEV1:ETYP? → #H8100
<b>Note</b>	<sup>1</sup> It is only possible to use this command for levels 1-N, where N is the number of active VLAN Levels.

**12.31.103 ETHernet:PORT<Pt>:OAM:OUTPut:ULBM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:ULBM <mepId>
<b>Description</b>	This command activates OAM unicast loop-back message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:ULBM 10
<b>Note</b>	Only used when 802.ag or Y.1731 is active.

**12.31.104 ETHernet:PORT<Pt>:OAM:OUTPut:MLBM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:MLBM <mepId>
<b>Description</b>	This command activates OAM multicast loop-back message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:MLBM 10
<b>Note</b>	Only used when 802.ag or Y.1731 is active.

**12.31.105 ETHernet:PORT<Pt>:OAM:OUTPut:LTM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LTM <mepId>
<b>Description</b>	This command activates the link trace message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:LTM 10
<b>Note</b>	Only used when 802.ag or Y.1731 is active.

**12.31.106 ETHernet:PORT<Pt>:OAM:OUTPut:MCC**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:MCC <mepId>
<b>Description</b>	This command activates the MCC event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:MCC 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.107 ETHernet:PORT<Pt>:OAM:OUTPut:EXM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:EXM <mepId>
<b>Description</b>	This command activates the experimental OAM message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:EXM
<b>Note</b>	Only used when Y.1731 is active.

**12.31.108 ETHernet:PORT<Pt>:OAM:OUTPut:VSM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:VSM <mepId>
<b>Description</b>	This command activates the vendor specific OAM message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:VSM 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.109 ETHernet:PORT<Pt>:OAM:OUTPut:TST**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:TST <mepId>
<b>Description</b>	This command activates the OAM test event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:TST 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.110 ETHernet:PORT<Pt>:OAM:OUTPut:LMM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LMM <mepId>
<b>Description</b>	This command activates the loss measurement message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:LMM 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.111 ETHernet:PORT<Pt>:OAM:OUTPut:SLM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:SLM <mepId>
<b>Description</b>	This command activates the synthetic loss measurement event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:SLM 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.112 ETHernet:PORT<Pt>:OAM:OUTPut:DMONe**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:DMONe <mepId>
<b>Description</b>	This command activates the one-way delay measurement event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:DMON 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.113 ETHernet:PORT<Pt>:OAM:OUTPut:DMM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:DMM <mepId>
<b>Description</b>	This command activates the delay measurement message event.
<b>Parameters</b>	<Pt> = Port number <mepId> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=8191</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:DMM 10
<b>Note</b>	Only used when Y.1731 is active.

**12.31.114 ETHernet:PORT<Pt>:OAM:OUTPut:CCM**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:CCM <enable>
<b>Description</b>	This command enables/disables continuity check messages.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:CCM OFF
<b>Note</b>	Only used when 802.ag or Y.1731 is active.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:CCM?
<b>Description</b>	This query returns whether or not continuity check messages are enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:OUTP:CCM? → 0
<b>Note</b>	

**12.31.115 ETHernet:PORT<Pt>:OAM:OUTPut:AIS**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:AIS <enable>
<b>Description</b>	This command enables/disables AIS alarm.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:AIS OFF
<b>Note</b>	Only used when Y.1731 is active.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:AIS?
<b>Description</b>	This query returns whether or not AIS alarm is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:OUTP:AIS? → 0
<b>Note</b>	

**12.31.116 ETHernet:PORT<Pt>:OAM:OUTPut:LCK**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LCK <enable>
<b>Description</b>	This command enables/disables lock condition.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:LCK OFF
<b>Note</b>	Only used when Y.1731 is active.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LCK?
<b>Description</b>	This query returns whether or not lock condition is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:OUTP:LCK? → 0
<b>Note</b>	

### 12.31.117 ETHernet:PORT<Pt>:OAM:OUTPut:LOOP

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LOOP <enable>
<b>Description</b>	This command enables/disables 802.3ah loop.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:OUTP:LOOP OFF
<b>Note</b>	Only used when 802.3ah is active.

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:OUTPut:LOOP?
<b>Description</b>	This query returns whether or not 802.3ah loop is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:OUTP:LOOP? → 0
<b>Note</b>	

### 12.31.118 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MODE?

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MODE?
<b>Description</b>	This query returns the remote mode string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:MODE? → "N/A"
<b>Note</b>	

### 12.31.119 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:PARSer?

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:PARSer?
<b>Description</b>	This query returns the remote parser string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:PARS? → "N/A"
<b>Note</b>	

### 12.31.120 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MUXer?

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MUXer?
<b>Description</b>	This query returns the remote muxer string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:MUX? → "N/A"
<b>Note</b>	

**12.31.121 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:OUI?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:OUI?
<b>Description</b>	This query returns the remote OUI string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:OUI? → "N/A"
<b>Note</b>	

**12.31.122 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:VSI?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:VSI?
<b>Description</b>	This query returns the remote VSI string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:VSI? → "N/A"
<b>Note</b>	

**12.31.123 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:UNIDirectional?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:UNIDirectional?
<b>Description</b>	This query returns the remote unidirectional support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:UNID? → "N/A"
<b>Note</b>	

**12.31.124 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:LEVents?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:LEVents?
<b>Description</b>	This query returns the remote link events support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:LEV? → "Supported"
<b>Note</b>	

**12.31.125 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:LBACk?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:LBACk?
<b>Description</b>	This query returns the remote loop-back support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:LBAC? → "Unsupported"
<b>Note</b>	

**12.31.126 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:VRETrieval?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:VRETrieval?
<b>Description</b>	This query returns the remote variable retrieval support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:VRET? → "N/A"
<b>Note</b>	



**12.31.127 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:REVision?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:REVision?
<b>Description</b>	This query returns the remote revision number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:REV? → 0
<b>Note</b>	

**12.31.128 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MAC?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MAC?
<b>Description</b>	This query returns the remote MAC address.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:MAC? → "N/A"
<b>Note</b>	

**12.31.129 ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MPDU?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:REMOte:MPDU?
<b>Description</b>	This query returns the remote maximum PDU size.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:REM:MPDU? → 0
<b>Note</b>	

**12.31.130 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:MODE?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:MODE?
<b>Description</b>	This query returns the local mode string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:MODE? → "N/A"
<b>Note</b>	

**12.31.131 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:PARSer?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:PARSer?
<b>Description</b>	This query returns the local parser string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:PARS? → "N/A"
<b>Note</b>	

**12.31.132 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:MUXer?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAL:MUXer?
<b>Description</b>	This query returns the local muxer string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:MUX? → "N/A"
<b>Note</b>	

**12.31.133 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:UNIDirectional?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:UNIDirectional?
<b>Description</b>	This query returns the local unidirectional support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:UNID? → "N/A"
<b>Note</b>	

**12.31.134 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LEVents?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LEVents?
<b>Description</b>	This query returns the local link events support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:LEV? → "Supported"
<b>Note</b>	

**12.31.135 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LBACk?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:LBACk?
<b>Description</b>	This query returns the local loop-back support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:LBAC? → "Unsupported"
<b>Note</b>	

**12.31.136 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:VRETrieval?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:VRETrieval?
<b>Description</b>	This query returns the local variable retrieval support status.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:VRET? → "N/A"
<b>Note</b>	

**12.31.137 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:REVision?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:REVision?
<b>Description</b>	This query returns the local revision number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:REV? → 0
<b>Note</b>	

**12.31.138 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:MPDU?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:MPDU?
<b>Description</b>	This query returns the local maximum PDU size.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:MPDU? → 0
<b>Note</b>	

**12.31.139 ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:STATe?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:LOCAl:STATe?
<b>Description</b>	This query returns the local state string.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:LOC:STAT? → "N/A"
<b>Note</b>	

**12.31.140 ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:REQuest**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:REQuest <variable>
<b>Description</b>	This command requests the specified variable from the remote side.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;variable&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>TUCodes: Tx Unsupported codes  RUCodes: Rx Unsupported codes  TINformation: Tx Information  RINformation: Rx Information  TUEvent: Tx Unique Event  RUEvent: Rx Unique Event  TDEvent: Tx Duplicate Event  RDEvent: Rx Duplicate Event  TLBControl: Tx Loop-back control  RLBControl: Rx Loop-back control  TVREquest: Tx Variable request  RVREquest: Rx Variable request  TVResponse: Tx Variable response  RVResponse: Rx Variable response  TOSpecific: Tx Organizational specific  ROSPecific: Rx Organizational specific  LSYConfig: Local errored symbol config  LSYevent: Local errored symbol event  LFConfig: Local errored frame config  LFEEvent: Local errored frame event  LPConfig: Local errored period config  LPEEvent: Local errored period event  LSConfig: Local errored seconds config  LSEEvent: Local errored seconds event  RSYevent: Remote errored symbol event  RFEEvent: Remote errored frame event  RPEEvent: Remote errored period event  RSEEvent: Remote errored seconds event  FLOerror: Frames lost to OAM error  <i>DEFault = TUC</i></p>
<b>Response</b>	None.
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:VAR:REQ TUC
<b>Note</b>	The requested parameter is fetched with the command ETH:PORT1:OAM:STAT:AH:VAR:RESP? I may take a few seconds before the response is obtainable.

**12.31.141 ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:RESPonse?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:STATus:AH:VARiable:RESPonse?
<b>Description</b>	This command fetches the latest variable response from the remote side.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<variable> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:STAT:AH:VAR:RESP? → "Unsupported Codes Tx : 0"
<b>Note</b>	

**12.31.142 ETHernet:PORT<Pt>:OAM:LOG?**

<b>Syntax</b>	ETHernet:PORT<Pt>:OAM:LOG?
<b>Description</b>	This query returns a lists of logged OAM events.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<log> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:PORT1:OAM:LOG? → "16:15:54 LTM transaction ID 1 passed 16:16:01 MCC message sent "
<b>Note</b>	

## 12.32 TCP Throughput Test - RFC-6349

The SCPI commands in this section are available in the following application:

- TP-RFC6349-ETH: Ethernet RFC-6349 test application.

This applications supports one port only.

### 12.32.1 ETHernet:TTTest:SETup:TCPPort

<b>Syntax</b>	ETHernet:TTTest:SETup:TCPPort <port>
<b>Description</b>	This command sets the TCP port number.
<b>Parameter</b>	<port> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535, DEFault=5001</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TCPP 5001
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TCPPort?
<b>Description</b>	This query returns the TCP port number.
<b>Parameter</b>	None.
<b>Response</b>	<port> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TCPP? → 5001
<b>Note</b>	

### 12.32.2 ETHernet:TTTest:SETup:FATSequence

<b>Syntax</b>	ETHernet:TTTest:SETup:FATSequence <enable>
<b>Description</b>	This command enables/disables full auto test sequence.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:FATS OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:FATSequence?
<b>Description</b>	This query returns whether or not full auto test sequence is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:FATS? → 0
<b>Note</b>	

### 12.32.3 ETHernet:TTTest:SETup:CIPerf

<b>Syntax</b>	ETHernet:TTTest:SETup:CIPerf <enable>
<b>Description</b>	This command enables/disables connection to iPerf server.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:CIP OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:CIPerf?
<b>Description</b>	This query returns whether or not connection to iPerf server is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:CIP? → 0
<b>Note</b>	

**12.32.4 ETHernet:TTTest:SETup:SLSName**

<b>Syntax</b>	ETHernet:TTTest:SETup:SLSName <name>
<b>Description</b>	This command sets the short local site name.
<b>Parameter</b>	<name> = <STRING PROGRAM DATA> The supplied name is truncated to a maximum of 4 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:SLSN "LOC"
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:SLSName?
<b>Description</b>	This query returns the short local site name.
<b>Parameter</b>	None.
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:SLSN? → "LOC"
<b>Note</b>	

**12.32.5 ETHernet:TTTest:SETup:LLSName**

<b>Syntax</b>	ETHernet:TTTest:SETup:LLSName <name>
<b>Description</b>	This command sets the long local site name.
<b>Parameter</b>	<name> = <STRING PROGRAM DATA> The supplied name is truncated to a maximum of 12 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:LLSN "LOCAL"
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:LLSName?
<b>Description</b>	This query returns the long local site name.
<b>Parameter</b>	None.
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:LLSN? → "LOCAL"
<b>Note</b>	

**12.32.6 ETHernet:TTTest:SETup:SRSName**

<b>Syntax</b>	ETHernet:TTTest:SETup:SRSName <name>
<b>Description</b>	This command sets the short remote site name.
<b>Parameter</b>	<name> = <STRING PROGRAM DATA> The supplied name is truncated to a maximum of 4 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:SRSN "S123"
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:SRSName?
<b>Description</b>	This query returns the short remote site name.
<b>Parameter</b>	None.
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:SRSN? → "S123"
<b>Note</b>	

**12.32.7 ETHernet:TTTest:SETup:LRSName**

<b>Syntax</b>	ETHernet:TTTest:SETup:LRSName <name>
<b>Description</b>	This command sets the long remote site name.
<b>Parameter</b>	<name> = <STRING PROGRAM DATA> The supplied name is truncated to a maximum of 12 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:LRSN "SITE-1-23"
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:LRSName?
<b>Description</b>	This query returns the long remote site name.
<b>Parameter</b>	None.
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:LRSN? → "SITE-1-23"
<b>Note</b>	

**12.32.8 ETHernet:TTTest:SETup:TDLR**

<b>Syntax</b>	ETHernet:TTTest:SETup:TDLR <enable>
<b>Description</b>	This command enables/disables the test direction local to remote.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TDLR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TDLR?
<b>Description</b>	This query returns whether or not the test direction local to remote is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TDLR? → 1
<b>Note</b>	

**12.32.9 ETHernet:TTTest:SETup:TDRL**

<b>Syntax</b>	ETHernet:TTTest:SETup:TDRL <enable>
<b>Description</b>	This command enables/disables the test direction remote to local.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TDRL OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TDRL?
<b>Description</b>	This query returns whether or not the test direction remote to local is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TDRL? → 0
<b>Note</b>	

**12.32.10 ETHernet:TTTest:SETup:TDSimultaneos**

<b>Syntax</b>	ETHernet:TTTest:SETup:TDSimultaneos <enable>
<b>Description</b>	This command enables/disables the test direction both simultaneous.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TDS OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TDSimultaneos?
<b>Description</b>	This query returns whether or not the test direction simultaneous is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TDS? → 0
<b>Note</b>	

**12.32.11 ETHernet:TTTest:SETup[:LTRemote]:CIRate**

<b>Syntax</b>	ETHernet:TTTest:SETup[:LTRemote]:CIRate <rate>
<b>Description</b>	This command sets the local to remote CIR rate (upstream). Unit: Mbps.
<b>Parameter</b>	<rate> = <NUMERIC PROGRAM DATA> <i>MINimum=0.010, MAXimum=10000, DEFault=1000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:CIR 1000
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup[:LTRemote]:CIRate?
<b>Description</b>	This query returns the local to remote CIR rate.
<b>Parameter</b>	None.
<b>Response</b>	<rate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:CIR? → 1000
<b>Note</b>	

**12.32.12 ETHernet:TTTest:SETup[:LTRemote]:MTUSize**

<b>Syntax</b>	ETHernet:TTTest:SETup[:LTRemote]:MTUSize <size>
<b>Description</b>	This command sets the local to remote MTU size.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=64, MAXimum=15982, DEFault=1500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MTUS 1500
<b>Note</b>	This MTU size is used when <code>ETHernet:TTTest:SETup:PMTU:DISCover:ENABle</code> is disabled.

<b>Syntax</b>	ETHernet:TTTest:SETup[:LTRemote]:MTUSize?
<b>Description</b>	This query returns the local to remote MTU size.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MTUS? → 1500
<b>Note</b>	



**12.32.13 ETHernet:TTTest:SETup:RTLocal:CIRate**

<b>Syntax</b>	ETHernet:TTTest:SETup:RTLocal:CIRate <rate>
<b>Description</b>	This command sets the remote to local CIR rate (downstream). Unit: Mbps.
<b>Parameter</b>	<rate> = <NUMERIC PROGRAM DATA> <i>MINimum=0.010, MAXimum=10000, DEFault=1000</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:RTL:CIR 1000
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:RTLocal:CIRate?
<b>Description</b>	This query returns the remote to local CIR rate.
<b>Parameter</b>	None.
<b>Response</b>	<rate> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:RTL:CIR? → 1000
<b>Note</b>	

**12.32.14 ETHernet:TTTest:SETup:RTLocal:MTUSize**

<b>Syntax</b>	ETHernet:TTTest:SETup:RTLocal:MTUSize <size>
<b>Description</b>	This command sets the remote to local MTU size.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=64, MAXimum=15982, DEFault=1500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:RTL:MTUS 1500
<b>Note</b>	This MTU size is used when ETHernet:TTTest:SETup:PMTU:DISCover:ENABLE is disabled.

<b>Syntax</b>	ETHernet:TTTest:SETup:RTLocal:MTUSize?
<b>Description</b>	This query returns the remote to local MTU size.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:RTL:MTUS? → 1500
<b>Note</b>	

**12.32.15 ETHernet:TTTest:SETup:PMTU:DISCover[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover[:ENABLE] <enable>
<b>Description</b>	This command enables/disables path MTU discovery.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:PMTU:DISC ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover[:ENABLE]?
<b>Description</b>	This query returns whether or not path MTU discovery is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:PMTU:DISC? → 1
<b>Note</b>	

**12.32.16 ETHernet:TTTest:SETup:PMTU:DISCover:MINimum**

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover:MINimum <size>
<b>Description</b>	This command sets the path MTU discovery minimum size.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=64, MAXimum=15982, DEFault=512</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:PMTU:DISC:MIN 512
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover:MINimum?
<b>Description</b>	This query returns the path MTU discovery minimum size.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:PMTU:DISC:MIN? → 512
<b>Note</b>	

**12.32.17 ETHernet:TTTest:SETup:PMTU:DISCover:MAXimum**

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover:MAXimum <size>
<b>Description</b>	This command sets the path MTU discovery maximum size.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=64, MAXimum=15982, DEFault=1500</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:PMTU:DISC:MAX 1500
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:PMTU:DISCover:MAXimum?
<b>Description</b>	This query returns the path MTU discovery maximum size.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:PMTU:DISC:MAX? → 1500
<b>Note</b>	

**12.32.18 ETHernet:TTTest:SETup:BRTT**

<b>Syntax</b>	ETHernet:TTTest:SETup:BRTT <size>
<b>Description</b>	This command sets the baseline RTT. Unit: ms.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=0.001, MAXimum=5000, DEFault=2</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:BRTT 2
<b>Note</b>	This value is used when <code>ETHernet:TTTest:SETup:BRTT:AUTO</code> is disabled.

<b>Syntax</b>	ETHernet:TTTest:SETup:BRTT?
<b>Description</b>	This query returns the baseline RTT.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:BRTT? → 0.020
<b>Note</b>	

**12.32.19 ETHernet:TTTest:SETup:BRtt:AUTO**

<b>Syntax</b>	ETHernet:TTTest:SETup:BRtt:AUTO <enable>
<b>Description</b>	This command enables/disables a test to determine the baseline RTT.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:BRtt:AUTO ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:BRtt:AUTO?
<b>Description</b>	This query returns whether or not the test to determine the baseline RTT is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:BRtt:AUTO? → 1
<b>Note</b>	

**12.32.20 ETHernet:TTTest:SETup:BRtt:AUTO:DURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:BRtt:AUTO:DURation <duration>
<b>Description</b>	This command sets the duration of the RTT discovery test. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=5, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:BRtt:AUTO:DUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:BRtt:AUTO:DURation?
<b>Description</b>	This query returns the the RTT discovery test duration.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:BRtt:AUTO:DUR? → 10
<b>Note</b>	

**12.32.21 ETHernet:TTTest:SETup:WSTTest[:ENABle]**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSTTest[:ENABle] <enable>
<b>Description</b>	This command enables/disables the window scan and throughput test.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSTT ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSTTest[:ENABle]?
<b>Description</b>	This query returns whether or not the window scan and throughput test is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSTT? → 1
<b>Note</b>	

**12.32.22 ETHernet:TTTest:SETup:WSTTest:MODE**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSTTest:MODE <mode>
<b>Description</b>	This command sets the window scan and throughput test mode.
<b>Parameter</b>	<mode> = <CHARACTER PROGRAM DATA> AUTO: Scans the window size in four predefined steps. EXPert: Scans the window size in a number of user defined steps. <i>DEFault = AUTO</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSTT:MODE AUTO
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSTTest:MODE?
<b>Description</b>	This query returns the window scan and throughput test mode.
<b>Parameter</b>	None.
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSTT:MODE? → AUTO
<b>Note</b>	

**12.32.23 ETHernet:TTTest:SETup:WSCan[:LTRemote]:SDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan[:LTRemote]:SDURation <duration>
<b>Description</b>	This command sets the window scan step duration in the local to remote direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:SDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan[:LTRemote]:SDURation?
<b>Description</b>	This query returns the window scan step duration in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:SDUR? → 10
<b>Note</b>	

**12.32.24 ETHernet:TTTest:SETup:WSCan[:LTRemote]:AMODE:MWSize**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan[:LTRemote]:AMODE:MWSize <size>
<b>Description</b>	This command sets the auto mode max window size in the local to remote direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=16384, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:MWS 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan[:LTRemote]:AMODE:MWSize?
<b>Description</b>	This query returns the auto mode max window size in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:MWS? → 65535
<b>Note</b>	

**12.32.25 ETHernet:TTTest:SETup:WSCan:RTLocal:SDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:RTLocal:SDURation <duration>
<b>Description</b>	This command sets the window scan step duration. in the remote to local direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:RTL:SDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:RTLocal:SDURation?
<b>Description</b>	This query returns the window scan step duration in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:RTL:SDUR? → 10
<b>Note</b>	

**12.32.26 ETHernet:TTTest:SETup:WSCan:RTLocal:AMODE:MWSize**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:RTLocal:AMODE:MWSize <size>
<b>Description</b>	This command sets the auto mode max window size in the remote to local direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=16384, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:RTL:AMOD:MWS 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:RTLocal:AMODE:MWSize?
<b>Description</b>	This query returns the auto mode max window size in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:RTL:AMOD:MWS? → 65535
<b>Note</b>	

**12.32.27 ETHernet:TTTest:SETup:WSCan:AMODE[:LTRemote]:STEP<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:AMODE[:LTRemote]:STEP<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the auto mode steps in the local to remote direction.
<b>Parameters</b>	<no> = Step number (1-3) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:STEP1 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:AMODE[:LTRemote]:STEP<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not the auto mode step is enabled in the local to remote direction.
<b>Parameter</b>	<no> = Step number (1-3)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:STEP1? → 1
<b>Note</b>	

**12.32.28 ETHernet:TTTest:SETup:WSCan:AMODE:RTL:STEP<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:AMODE:RTL:STEP<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the auto mode steps in the remote to local direction.
<b>Parameters</b>	<no> = Step number (1-3) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:RTL:STEP1 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:AMODE:RTL:STEP<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not the auto mode step is enabled in the remote to local direction.
<b>Parameter</b>	<no> = Step number (1-3)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:AMOD:RTL:STEP1? → 1
<b>Note</b>	

**12.32.29 ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the expert mode steps in the local to remote direction.
<b>Parameters</b>	<no> = Step number (1-5) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not the expert mode step is enabled in the local to remote direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1? → 1
<b>Note</b>	

**12.32.30 ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:WSIZE <size>
<b>Description</b>	This command sets the expert mode step window size in the local to remote direction.
<b>Parameters</b>	<no> = Step number (1-5) <size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:WSIZE?
<b>Description</b>	This query returns the expert mode step window size in the local to remote direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1:WSIZ? → 65535
<b>Note</b>	

**12.32.31 ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:CONNECTIONS**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:CONNECTIONS <count>
<b>Description</b>	This command sets the expert mode step connections count in the local to remote direction.
<b>Parameters</b>	<no> = Step number (1-5) <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=16, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1:CONN 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE[:LTRemote]:STEP<no>:CONNECTIONS?
<b>Description</b>	This query returns the expert mode step connections count in the local to remote direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:STEP1:CONN? → 1
<b>Note</b>	

**12.32.32 ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the expert mode steps in the remote to local direction.
<b>Parameters</b>	<no> = Step number (1-5) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1 ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not the expert mode step is enabled in the remote to local direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1? → 1
<b>Note</b>	

**12.32.33 ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:WSIZE <size>
<b>Description</b>	This command sets the expert mode step window size in the remote to local direction.
<b>Parameters</b>	<no> = Step number (1-5) <size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:WSIZE?
<b>Description</b>	This query returns the expert mode step window size in the remote to local direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1:WSIZ? → 65535
<b>Note</b>	

**12.32.34 ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:CONNections**

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:CONNections <count>
<b>Description</b>	This command sets the expert mode step connections count in the remote to local direction.
<b>Parameters</b>	<no> = Step number (1-5) <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=16, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1:CONN 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:WSCan:EMODE:RTLLocal:STEP<no>:CONNections?
<b>Description</b>	This query returns the expert mode step connections count in the remote to local direction.
<b>Parameter</b>	<no> = Step number (1-5)
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:WSC:EMOD:RTL:STEP1:CONN? → 1
<b>Note</b>	

**12.32.35 ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold[:ENABle]**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold[:ENABle] <enable>
<b>Description</b>	This command enables/disables throughput test threshold in the local to remote direction.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold[:ENABle]?
<b>Description</b>	This query returns whether or not throughput test threshold is enabled in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:THR? → 1
<b>Note</b>	

**12.32.36 ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold:PERCentage**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold:PERCentage <pct>
<b>Description</b>	This command sets the throughput test threshold value in the local to remote direction. Unit: percentage.
<b>Parameter</b>	<pct> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100.00, DEFault=95</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:THR:PERC 95
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:THReshold:PERCentage?
<b>Description</b>	This query returns the throughput test threshold value in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<pct> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:THR:PERC? → 95.00
<b>Note</b>	



**12.32.37 ETHernet:TTTest:SETup:TTESt[:LTRemote]:SDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:SDURation <duration>
<b>Description</b>	This command sets the throughput test step duration in the local to remote direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:SDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt[:LTRemote]:SDURation?
<b>Description</b>	This query returns the throughput test step duration in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:SDUR? → 10
<b>Note</b>	

**12.32.38 ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold[:ENABle]**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold[:ENABle] <enable>
<b>Description</b>	This query returns whether or not throughput test threshold is enabled in the remote to local direction.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:THR ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold[:ENABle]?
<b>Description</b>	This query returns whether or not throughput test threshold is enabled in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:THR? → 1
<b>Note</b>	

**12.32.39 ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold:PERCentage**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold:PERCentage <pct>
<b>Description</b>	This command sets the throughput test threshold value in the remote to local direction. Unit: percentage.
<b>Parameter</b>	<pct> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100.00, DEFault=95</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:THR:PERC 95
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:THReshold:PERCentage?
<b>Description</b>	This query returns the throughput test threshold value in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<pct> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:THR:PERC? → 95
<b>Note</b>	

**12.32.40 ETHernet:TTTest:SETup:TTESt:RTLocal:SDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:SDURation <duration>
<b>Description</b>	This command sets the throughput test step duration in the remote to local direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:SDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:RTLocal:SDURation?
<b>Description</b>	This query returns the throughput test step duration in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:RTL:SDUR? → 10
<b>Note</b>	

**12.32.41 ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote][:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote][:ENABLE] <enable>
<b>Description</b>	This command enables/disables expert mode throughput test in the local to remote direction.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote][:ENABLE]?
<b>Description</b>	This query returns whether or not expert mode throughput test is enabled in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD? → 1
<b>Note</b>	

**12.32.42 ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:WSIZE <size>
<b>Description</b>	This command sets the expert mode throughput test window size in the local to remote direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:WSIZE?
<b>Description</b>	This query returns the expert mode throughput test window size in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:WSIZ? → 65535
<b>Note</b>	

**12.32.43 ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:CONNections**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:CONNections <count>
<b>Description</b>	This command sets the expert mode throughput test connection count in the local to remote direction.
<b>Parameter</b>	<count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=16, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:CONN 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE[:LTRemote]:CONNections?
<b>Description</b>	This query returns the expert mode throughput test connection count in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:CONN? → 1
<b>Note</b>	

**12.32.44 ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal[:ENABLE] <enable>
<b>Description</b>	This command enables/disables expert mode throughput test in the remote to local direction.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL ON
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal[:ENABLE]?
<b>Description</b>	This query returns whether or not expert mode throughput test is enabled in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL? → 1
<b>Note</b>	

**12.32.45 ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal:WSIZE <size>
<b>Description</b>	This command sets the expert mode throughput test window size in the remote to local direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODE:RTLlocal:WSIZE?
<b>Description</b>	This query returns the expert mode throughput test window size in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL:WSIZ? → 65535
<b>Note</b>	

**12.32.46 ETHernet:TTTest:SETup:TTESt:EMODe:RTLocal:CONNections**

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODe:RTLocal:CONNections <count>
<b>Description</b>	This command sets the expert mode throughput test connection count in the remote to local direction.
<b>Parameter</b>	<count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=16, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL:CONN 1
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:TTESt:EMODe:RTLocal:CONNections?
<b>Description</b>	This query returns the expert mode throughput test connection count in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<count> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:TTESt:EMOD:RTL:CONN? → 1
<b>Note</b>	

**12.32.47 ETHernet:TTTest:SETup:MSERvice[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:ENABLE] <enable>
<b>Description</b>	This command enables/disables multi service.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:ENABLE]?
<b>Description</b>	This query returns whether or not multi service is enabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER? → 0
<b>Note</b>	

**12.32.48 ETHernet:TTTest:SETup:MSERvice[:LTRemote]:TDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:TDURation <duration>
<b>Description</b>	This command sets the multi service test duration in the local to remote direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:TDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:TDURation?
<b>Description</b>	This query returns the multi service test duration in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:TDUR? → 10
<b>Note</b>	

**12.32.49 ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE <size>
<b>Description</b>	This command sets the multi service window size in the local to remote direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE?
<b>Description</b>	This query returns the multi service window size in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:WSIZ? → 65535
<b>Note</b>	This value is used when ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE:AUTO is disabled.

**12.32.50 ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE:AUTO**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE:AUTO <enable>
<b>Description</b>	This command enables/disables multi service window size automatic calculation in the local to remote direction. The window size is calculated from the bandwidth delay product (BDP).
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:WSIZ:AUTO OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice[:LTRemote]:WSIZE:AUTO?
<b>Description</b>	This query returns whether or not multi service window size automatic calculation is enabled in the local to remote direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:WSIZ:AUTO? → 0
<b>Note</b>	

**12.32.51 ETHernet:TTTest:SETup:MSERvice:RTLocal:TDURation**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:TDURation <duration>
<b>Description</b>	This command sets the multi service test duration in the remote to local direction. Unit: seconds.
<b>Parameter</b>	<duration> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=86399, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:RTL:TDUR 10
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:TDURation?
<b>Description</b>	This query returns the multi service test duration in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:RTL:TDUR? → 10
<b>Note</b>	

**12.32.52 ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE <size>
<b>Description</b>	This command sets the multi service window size in the remote to local direction.
<b>Parameter</b>	<size> = <NUMERIC PROGRAM DATA> <i>MINimum=8, MAXimum=8388607, DEFault=65535</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:RTL:WSIZ 65535
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE?
<b>Description</b>	This query returns the multi service window size in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<size> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:RTL:WSIZ? → 65535
<b>Note</b>	

**12.32.53 ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE:AUTO**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE:AUTO <enable>
<b>Description</b>	This command enables/disables multi service window size automatic calculation in the remote to local direction.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:RTL:WSIZ:AUTO OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:RTLocal:WSIZE:AUTO?
<b>Description</b>	This query returns whether or not multi service window size automatic calculation is enabled in the remote to local direction.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:RTL:WSIZ:AUTO? → 0
<b>Note</b>	

**12.32.54 ETHernet:TTTest:SETup:MSERvice:SERVICE<no>[:ENABLE]**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERVICE<no>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the specified multi service service.
<b>Parameters</b>	<no> = Service number (1-16) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:SERV1 OFF
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERVICE<no>[:ENABLE]?
<b>Description</b>	This query returns whether or not a specific multi service service is enabled.
<b>Parameter</b>	<no> = Service number (1-16)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:SERV1? → 0
<b>Note</b>	

**12.32.55 ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DPORT**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DPORT <no>
<b>Description</b>	This command sets the destination port of a specific service.
<b>Parameters</b>	<no> = Service number (1-16) <no> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535, DEFault=5001</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:DPOR 5001
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DPORT?
<b>Description</b>	This query returns the destination port of a specific service.
<b>Parameter</b>	<no> = Service number (1-16)
<b>Response</b>	<no> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:DPOR? → 5001
<b>Note</b>	

**12.32.56 ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DOT**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DOT <value>
<b>Description</b>	This command sets the DSCP or TOS value of a specific service.
<b>Parameters</b>	<no> = Service number (1-16) <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:DOT 0
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:DOT?
<b>Description</b>	This query returns the DSCP or TOS value of a specific service.
<b>Parameter</b>	<no> = Service number (1-16)
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:DOT? → 0
<b>Note</b>	

**12.32.57 ETHernet:TTTest:SETup:MSERvice:SERvice<no>:NAME**

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:NAME <name>
<b>Description</b>	This command sets the name of a specific service.
<b>Parameters</b>	<no> = Service number (1-16) <name> = <STRING PROGRAM DATA> The supplied name is truncated to a maximum of 7 characters.
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:NAME "Video"
<b>Note</b>	

<b>Syntax</b>	ETHernet:TTTest:SETup:MSERvice:SERvice<no>:NAME?
<b>Description</b>	This query returns the name of a specific service.
<b>Parameter</b>	<no> = Service number (1-16)
<b>Response</b>	<name> = <STRING RESPONSE DATA>
<b>Example</b>	ETH:TTT:SET:MSER:SERV1:NAME? → "Video"
<b>Note</b>	

**12.32.58 ETHernet:TTTest:RESult:PARAmeters?**

<b>Syntax</b>	ETHernet:TTTest:RESult:PARameters? <direction>
<b>Description</b>	Returns the result of measured parameter values during the test.
<b>Parameter</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. <i>DEFault = LTRemote</i>
<b>Response</b>	<mtu> = <NR1 NUMERIC RESPONSE DATA> MTU value. Unit: Octets. <rtt> = <NR2 NUMERIC RESPONSE DATA> RTT. Unit: ms. <bdp> = <NR1 NUMERIC RESPONSE DATA> Calculated BDP value. <cir0> = <NR1 NUMERIC RESPONSE DATA> Layer 0 CIR. Unit: Bytes. <cir4> = <NR1 NUMERIC RESPONSE DATA> Layer 4 CIR. Unit: Bytes.
<b>Example</b>	ETH:TTT:RES:PAR? RTL → 1500,0.005,261,1000000000,949284785
<b>Note</b>	

### 12.32.59 ETHernet:TTTest:RESult:WScan?

<b>Syntax</b>	ETHernet:TTTest:RESult:WScan? <direction>
<b>Description</b>	Returns the results of the window scan in the specified direction.
<b>Parameter</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. LTRBoth: Results for the local to remote direction in the simultaneous test step. RTLBoth: Results for the remote to local direction in the simultaneous test step. <i>DEFault = LTRemote</i>
<b>Response</b>	A list of results for all window scans and throughput steps. <status> = <STRING RESPONSE DATA> "Pending", "Done", "Pass" or "Fail" denotes the status of the test. <window-size> = <NR1 NUMERIC RESPONSE DATA> Window size. Unit: Bytes. <connections> = <NR1 NUMERIC RESPONSE DATA> Number of connections. <avg-throughput> = <NR1 NUMERIC RESPONSE DATA> Average throughput rate. Unit: bps. <ideal-throughput> = <NR1 NUMERIC RESPONSE DATA> Ideal throughput rate. Unit: bps. <avg-RTT> = <NR2 NUMERIC RESPONSE DATA> Average RTT. Unit: ms. <tcp-eff> = <NR2 NUMERIC RESPONSE DATA> TCP Efficiency. Unit: percentage.
<b>Example</b>	ETH:TTT:RES:WSC? RTL → (Pass,1460,1,419779200,94928478,0.002,100.00)
<b>Note</b>	There are no window scan results for LTRBoth and RTLBoth

### 12.32.60 ETHernet:TTTest:RESult:THRoughput?

<b>Syntax</b>	ETHernet:TTTest:RESult:THRoughput? <direction>
<b>Description</b>	Returns the results of the throughput test in the specified direction.
<b>Parameter</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. LTRBoth: Results for the local to remote direction in the simultaneous test step.

continued on next page...



... continued from previous page

	RTLBoth: Results for the remote to local direction in the simultaneous test step. <i>DEFault = LTRemote</i>
<b>Response</b>	<> = <NR1 NUMERIC RESPONSE DATA> Average throughput. Unit: bps.
	<> = <NR1 NUMERIC RESPONSE DATA> Ideal throughput. Unit: bps.
	<> = <NR1 NUMERIC RESPONSE DATA> Actual transfer time. Unit: seconds.
	<> = <NR1 NUMERIC RESPONSE DATA> Ideal transfer time. Unit: seconds.
	<> = <NR1 NUMERIC RESPONSE DATA> Transfer time ratio.
	<> = <NR1 NUMERIC RESPONSE DATA> Window size. Unit: bytes.
	<> = <NR1 NUMERIC RESPONSE DATA> Number of services/connections.
	<> = <NR1 NUMERIC RESPONSE DATA> Transmitted bytes. Unit: bytes.
	<> = <NR1 NUMERIC RESPONSE DATA> Retransmitted bytes. Unit: bytes.
	<> = <NR1 NUMERIC RESPONSE DATA> Retransmitted percentage.
	<> = <NR1 NUMERIC RESPONSE DATA> TCP Efficiency. Unit: percentage.
	<> = <NR1 NUMERIC RESPONSE DATA> Baseline RTT. Unit: ms.
	<> = <NR1 NUMERIC RESPONSE DATA> Minimum RTT. Unit: ms.
	<> = <NR1 NUMERIC RESPONSE DATA> Average RTT. Unit: ms.
	<> = <NR1 NUMERIC RESPONSE DATA> Maximum RTT. Unit: ms.
	<> = <NR1 NUMERIC RESPONSE DATA> Buffer delay. Unit: percentage.
	<b>Example</b>
<b>Note</b>	

### 12.32.61 ETHernet:TTTest:RESult:THRoughput:EXPort

<b>Syntax</b>	ETHernet:TTTest:RESult:THRoughput:EXPort <direction> <file> [<delimiter>]
<b>Description</b>	This command writes the data of the throughput graph to the specified file in a CSV format. The file can be written to the internal disk or to a connected USB memory device. The specified delimiter is used as field delimiter. Lines are terminated with CR-LF (0x0d,0x10).
<b>Parameters</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. LTRBoth: Results for the local to remote direction in the simultaneous test step. RTLBoth: Results for the remote to local direction in the simultaneous test step.
	<file> = <STRING PROGRAM DATA> The path and name of the file to store the data.
	<delimiter> = <CHARACTER PROGRAM DATA> COMMa: Use ',' as field separator. SEMicolon: Use ';' as field separator. TABulator: Use a tabulator character (0x09) as field separator. <i>DEFault = COMMa</i>

continued on next page...

...continued from previous page

<b>Response</b>	None.
<b>Example</b>	ETH:TTT:RES:THR:EXP RTL,"Internal/graph-data.csv",TAB
<b>Note</b>	Files must be saved to the Internal/ directory or a sub-directory hereof. When a USB storage device is mounted, files are stored via the Usb/ directory.

### 12.32.62 ETHernet:TTTest:RESult:MSERvice?

<b>Syntax</b>	ETHernet:TTTest:RESult:MSERvice? <direction>
<b>Description</b>	Returns the results of all multi service services in the specified direction.
<b>Parameter</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. LTRBoth: Results for the local to remote direction in the simultaneous test step. RTLBoth: Results for the remote to local direction in the simultaneous test step. <i>DEFault = LTRemote</i>
<b>Response</b>	A list of results for for all services. <min-RTT> = <NR2 NUMERIC RESPONSE DATA> Minimum RTT. Unit: ms. <avg-RTT> = <NR2 NUMERIC RESPONSE DATA> Average RTT. Unit: ms. <max-RTT> = <NR2 NUMERIC RESPONSE DATA> Maximum RTT. Unit: ms. <avg-throughput> = <NR1 NUMERIC RESPONSE DATA> Average throughput rate. Unit: bps. <tcp-eff> = <NR2 NUMERIC RESPONSE DATA> TCP efficiency. Unit: percentage.
<b>Example</b>	ETH:TTT:RES:MSER? RTL → (0.010,0.020,0.050,10100,50.00),(0.010,0.020,0.040,20200,100.00)
<b>Note</b>	

### 12.32.63 ETHernet:TTTest:RESult:MSERvice:TOTal?

<b>Syntax</b>	ETHernet:TTTest:RESult:MSERvice:TOTal? <direction>
<b>Description</b>	Returns the result totals of all multi service services in the specified direction.
<b>Parameter</b>	<direction> = <CHARACTER PROGRAM DATA> LTRemote: Results for the local to remote direction. RTLlocal: Results for the remote to local direction. LTRBoth: Results for the local to remote direction in the simultaneous test step. RTLBoth: Results for the remote to local direction in the simultaneous test step. <i>DEFault = LTRemote</i>
<b>Response</b>	A list results for for all services. <min-RTT> = <NR2 NUMERIC RESPONSE DATA> Minimum RTT. Unit: ms. <avg-RTT> = <NR2 NUMERIC RESPONSE DATA> Average RTT. Unit: ms. <max-RTT> = <NR2 NUMERIC RESPONSE DATA> Maximum RTT. Unit: ms. <avg-throughput> = <NR1 NUMERIC RESPONSE DATA> Average throughput rate. Unit: bps. <tcp-eff> = <NR2 NUMERIC RESPONSE DATA> TCP efficiency. Unit: percentage.
<b>Example</b>	ETH:TTT:RES:MSER:TOT? RTL → (0.010,0.020,0.050,1.100,50.00),(0.010,0.020,0.040,2.200,100.00)
<b>Note</b>	

## 12.32.64 ETHernet:TTTest:RESult:MSERvice:EXPort

<b>Syntax</b>	ETHernet:TTTest:RESult:MSERvice:EXPort <direction> <file> [<delimiter>]
<b>Description</b>	This command writes the data of the multi service throughput graph to the specified file in a CSV format. The file can be written to the internal disk or to a connected USB memory device. The specified delimiter is used as field delimiter. Lines are terminated with CR-LF (0x0d,0x10).
<b>Parameters</b>	<p>&lt;direction&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>LTRemote: Results for the local to remote direction.  RTLlocal: Results for the remote to local direction.  LTRBoth: Results for the local to remote direction in the simultaneous test step.  RTLBoth: Results for the remote to local direction in the simultaneous test step.</p> <p>&lt;file&gt; = &lt;STRING PROGRAM DATA&gt;</p> <p>The path and name of the file to store the data.</p> <p>&lt;delimiter&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>COMMa: Use ',' as field separator.  SEMicolon: Use ';' as field separator.  TABulator: Use a tabulator character (0x09) as field separator.  <i>DEFault = COMMa</i></p>
<b>Response</b>	None.
<b>Example</b>	ETH:TTT:RES:MSER:EXP RTL,"Internal/graph-data.csv",TAB
<b>Note</b>	Files must be saved to the <b>Internal/</b> directory or a sub-directory hereof. When a USB storage device is mounted, files are stored via the <b>Usb/</b> directory.



---

## Chapter 13

# Fibre Channel

### 13.1 Port

#### 13.1.1 FCHannel:PORT<Pt>:MODE

<b>Syntax</b>	FCHannel:PORT<Pt>:MODE <mode>
<b>Description</b>	This command sets the port mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Port off FC100: 1Gb/s 100MBytes/s FC200: 2Gb/s 200MBytes/s FC400: 4Gb/s 400MBytes/s FC800: 8Gb/s 800MBytes/s FC1200: 10Gb/s 1200MBytes/s <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:MODE FC100
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:MODE?
<b>Description</b>	This query returns the port mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:MODE? → FC100
<b>Note</b>	

#### 13.1.2 FCHannel:TX<Pt>:TIMing

<b>Syntax</b>	FCHannel:TX<Pt>:TIMing <timing>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <timing> = <CHARACTER PROGRAM DATA> INTernal: Internal clock EXTernal: External clock GPS: GPS signal RX: Received clock <i>DEFault = INT</i>
<b>Response</b>	None
<b>Example</b>	FCH:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	FCHannel:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timing> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:TX1:TIM? → INT
<b>Note</b>	

## 13.2 Interface

### 13.2.1 FCHannel:PORT<Pt>:TOPology

<b>Syntax</b>	FCHannel:PORT<Pt>:TOPology <topology>
<b>Description</b>	This command sets the topology
<b>Parameters</b>	<Pt> = Port number <topology> = <CHARACTER PROGRAM DATA> PTPoint: Point to Point FABRic: Fabric <i>DEFault = PTPoint</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TOP FABR
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TOPology?
<b>Description</b>	This query returns the topology
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<topology> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TOP? → FABR
<b>Note</b>	

### 13.2.2 FCHannel:PORT<Pt>:PTP:LOGin

<b>Syntax</b>	FCHannel:PORT<Pt>:PTP:LOGin <enable>
<b>Description</b>	This command enables/disables point to point login
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:PTP:LOG OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:PTP:LOGin?
<b>Description</b>	This query returns whether or not point to point login is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:PTP:LOG? → 0
<b>Note</b>	

### 13.2.3 FCHannel:PORT<Pt>:FABRic:LOGin

<b>Syntax</b>	FCHannel:PORT<Pt>:FABRic:LOGin
<b>Description</b>	This command activates the fabric login.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FABR:LOG
<b>Note</b>	

### 13.2.4 FCHannel:PORT<Pt>:FCONtrol[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol[:ENABle] <enable>
<b>Description</b>	This command enables/disables flow control.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FCON OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol[:ENABle]?
<b>Description</b>	This query returns whether or not flow control is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FCON? → 0
<b>Note</b>	

### 13.2.5 FCHannel:PORT<Pt>:FCONtrol:LCRedit

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol:LCRedit <credit>
<b>Description</b>	This command sets the local credit.
<b>Parameters</b>	<Pt> = Port number <credit> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=65535, DEFault=64</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FCON:LCR 64
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol:LCRedit?
<b>Description</b>	This query returns the local credit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<credit> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FCON:LCR? → 64
<b>Note</b>	

### 13.2.6 FCHannel:PORT<Pt>:FCONtrol:RCRedit

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol:RCRedit <credit>
<b>Description</b>	This command sets the remote credit.
<b>Parameters</b>	<Pt> = Port number <credit> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=65535, DEFault=64</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FCON:RCR 64
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FCONtrol:RCRedit?
<b>Description</b>	This query returns the remote credit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<credit> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FCON:RCR? → 64
<b>Note</b>	

## 13.2.7 FCHannel:PORT&lt;Pt&gt;:SOURce:WWN

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:WWN <wwn>
<b>Description</b>	This command sets the source port WWN.
<b>Parameters</b>	<Pt> = Port number <wwn> = <STRING PROGRAM DATA> Port WWN
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SOUR:WWN "00-00-00-00-00-00-00-00"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:WWN?
<b>Description</b>	This query returns the source port WWN.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<wwn> = <STRING RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SOUR:WWN? → "00-00-00-00-00-00-00-00"
<b>Note</b>	

## 13.2.8 FCHannel:PORT&lt;Pt&gt;:SOURce:WWN:DEFault

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:WWN:DEFault <enable>
<b>Description</b>	This command enables/disables default port WWN.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SOUR:WWN:DEF ON
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:WWN:DEFault?
<b>Description</b>	This query returns whether or not default port WWN is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SOUR:WWN:DEF? → 1
<b>Note</b>	

## 13.2.9 FCHannel:PORT&lt;Pt&gt;:SOURce:ID

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:ID <id>
<b>Description</b>	This command sets the source ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=16777215, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SOUR:ID 0
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:SOURce:ID?
<b>Description</b>	This query returns the source ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SOUR:ID? → 0
<b>Note</b>	



**13.2.10 FCHannel:PORT<Pt>:DESTination:WWN**

<b>Syntax</b>	FCHannel:PORT<Pt>:DESTination:WWN <wwn>
<b>Description</b>	This command sets the destination port WWN.
<b>Parameters</b>	<Pt> = Port number <wwn> = <STRING PROGRAM DATA> Port WWN
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:DEST:WWN "00-00-00-00-00-00-00-00"
<b>Note</b>	Only the character '-' is accepted as separator.

<b>Syntax</b>	FCHannel:PORT<Pt>:DESTination:WWN?
<b>Description</b>	This query returns the destination port WWN.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<wwn> = <STRING RESPONSE DATA>
<b>Example</b>	FCH:PORT1:DEST:WWN? → "00-00-00-00-00-00-00-00"
<b>Note</b>	

**13.2.11 FCHannel:PORT<Pt>:DESTination:ID**

<b>Syntax</b>	FCHannel:PORT<Pt>:DESTination:ID <id>
<b>Description</b>	This command sets the destination ID.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=16777215, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:DEST:ID 0
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:DESTination:ID?
<b>Description</b>	This query returns the destination ID.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:DEST:ID? → 0
<b>Note</b>	

**13.2.12 FCHannel:PORT<Pt>:DESTination:LOGin**

<b>Syntax</b>	FCHannel:PORT<Pt>:DESTination:LOGin
<b>Description</b>	This command activates port login.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:DEST:LOG
<b>Note</b>	

## 13.3 Frame

### 13.3.1 FCHannel:PORT<Pt>:FRAMe:FRAMing

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:FRAMing <type>
<b>Description</b>	This command sets the frame structure.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> FT0: SOF:Data:EOF FT1: SOF:Header:Data:CRC:EOF <i>DEFault = FT1</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:FRAM FT1
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:FRAMing?
<b>Description</b>	This query returns the frame structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:FRAM? → FT1
<b>Note</b>	

### 13.3.2 FCHannel:PORT<Pt>:FRAMe:CONTent

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:CONTent <content>
<b>Description</b>	This command sets the data content.
<b>Parameters</b>	<Pt> = Port number <content> = <CHARACTER PROGRAM DATA> FOX 5555 PRBS9 PRBS11 PRBS15 PRBS20 PRBS23 PRBS29 PRBS31 BHFTest BCRPat BJTPat BSPat USER32BIT ZERO <i>DEFault = FOX</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:CONT 5555
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:CONTent?
<b>Description</b>	This query returns the data content.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<content> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:CONT? → 5555
<b>Note</b>	

### 13.3.3 FCHannel:PORT<Pt>:FRAMe:UP32

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when <b>CONTent</b> is <b>USER32BIT</b> .
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:UP32 "0110"
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:UP32? → "0110"
<b>Note</b>	

### 13.3.4 FCHannel:PORT<Pt>:FRAMe:HEADer:SID

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:HEADer:SID <id>
<b>Description</b>	This command sets the Seq ID in the frame header.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:HEAD:SID #HAE FCH:PORT1:FRAM:HEAD:SID 174
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:HEADer:SID?
<b>Description</b>	This query returns the Seq ID in the frame header.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:HEAD:SID? → 174
<b>Note</b>	

### 13.3.5 FCHannel:PORT<Pt>:FRAMe:HEADer:OID

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:HEADer:OID <id>
<b>Description</b>	This command sets the OX ID in the frame header.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:HEAD:OID #HAE FCH:PORT1:FRAM:HEAD:OID 174
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAMe:HEADer:OID?
<b>Description</b>	This query returns the OX ID in the frame header.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:HEAD:OID? → 174
<b>Note</b>	

### 13.3.6 FCHannel:PORT<Pt>:FRAME:HEADer:RID

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAME:HEADer:RID <id>
<b>Description</b>	This command sets the Rx ID in the frame header.
<b>Parameters</b>	<Pt> = Port number <id> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=65535, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:FRAM:HEAD:RID #HAE FCH:PORT1:FRAM:HEAD:RID 174
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FRAME:HEADer:RID?
<b>Description</b>	This query returns the Rx ID in the frame header.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<id> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:FRAM:HEAD:RID? → 174
<b>Note</b>	

## 13.4 Generator

### 13.4.1 FCHannel:PORT<Pt>:TRAFfic:DMODE

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DMODE <mode>
<b>Description</b>	This command sets the duration mode for the traffic generator.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> CONTInuous: Continuous FRAMes: Frames SECOnds: Seconds <i>DEFault = CONTInuous</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:DMOD CONT
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DMODE?
<b>Description</b>	This query returns the duration mode for the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:DMOD? → CONT
<b>Note</b>	

### 13.4.2 FCHannel:PORT<Pt>:TRAFfic:DSECOnds

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DSECOnds <seconds>
<b>Description</b>	This command sets the duration for the traffic generator in seconds.
<b>Parameters</b>	<Pt> = Port number <seconds> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=200000000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:DSEC 1
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DSEConds?
<b>Description</b>	This query returns the duration for the traffic generator in seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<seconds> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:DSEC? → 1
<b>Note</b>	

### 13.4.3 FCHannel:PORT<Pt>:TRAFfic:DFRames

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DFRames <frames>
<b>Description</b>	This command sets the duration for the traffic generator in number of frames.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=200000000, DEFault=1</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:DFR 1
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:DFRames?
<b>Description</b>	This query returns the duration for the traffic generator in number of frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:DFR? → 1
<b>Note</b>	

### 13.4.4 FCHannel:PORT<Pt>:TRAFfic:ASTGenerator

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:ASTGenerator <enable>
<b>Description</b>	This command enables/disables automatic start of the transmitter when running a BER measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:ASTG OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:ASTGenerator?
<b>Description</b>	This query returns whether or not transmitter automatically starts when running a BER measurement.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:ASTG? → 0
<b>Note</b>	

### 13.4.5 FCHannel:TRAFfic:GENerator:STARt

<b>Syntax</b>	FCHannel:TRAFfic:GENerator:STARt
<b>Description</b>	This command starts the traffic generator.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:TRAF:GEN:STAR
<b>Note</b>	This command applies to all ports.

### 13.4.6 FCHannel:TRAFfic:GENerator:STOP

<b>Syntax</b>	FCHannel:TRAFfic:GENerator:STOP
<b>Description</b>	This command stops the traffic generator.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:TRAF:GEN:STOP
<b>Note</b>	This command applies to all ports.

### 13.4.7 FCHannel:PORT<Pt>:TRAFfic:GENerator:START

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:GENerator:START
<b>Description</b>	This command starts the traffic generator.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:GEN:STAR
<b>Note</b>	This command requires that the Port is enabled (FCHannel:PORT<Pt>:MODE).

### 13.4.8 FCHannel:PORT<Pt>:TRAFfic:GENerator:STOP

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:GENerator:STOP
<b>Description</b>	This command stops the traffic generator.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:GEN:STOP
<b>Note</b>	

### 13.4.9 FCHannel:PORT<Pt>:TRAFfic:GENerator:STATus?

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:GENerator:STATus?
<b>Description</b>	This query returns the current status of the traffic generator.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<stat> = <BOOLEAN RESPONSE DATA> 0: Traffic generator inactive 1: Traffic generator active
<b>Example</b>	FCH:PORT1:TRAF:GEN:STAT? → 0
<b>Note</b>	

## 13.5 Stream

### 13.5.1 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:PROFile

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:PROFile <profile>
<b>Description</b>	This command sets the stream Line Load Profile.
<b>Parameters</b>	<Pt> = Port number <profile> = <CHARACTER PROGRAM DATA> CONStant: Constant line load profile RAMP: Ramp line load profile <i>DEFault = CONStant</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:PROF RAMP
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:PROFile?
<b>Description</b>	This query returns the stream Line Load Profile.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<profile> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:PROF? → RAMP
<b>Note</b>	

### 13.5.2 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad[:CONStant]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad[:CONStant] <load>
<b>Description</b>	This command sets the stream Line Load in constant mode. Unit: Percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000, DEFault=100.0000</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL 50
<b>Note</b>	The minimum possible line load is 0.0008.

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad[:CONStant]?
<b>Description</b>	This query returns the stream Line Load in constant mode. Unit: Percentage.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL? → 50
<b>Note</b>	

### 13.5.3 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP[:MODE]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP[:MODE] <mode>
<b>Description</b>	This command sets the ramp mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> KEEPend: Maintain line load level at ramp end REPeat: Repeat ramp INVert: Invert ramp <i>DEFault = INVert</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP KEEP
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP[:MODE]?
<b>Description</b>	This query returns the ramp mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP? → KEEP
<b>Note</b>	

### 13.5.4 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STARt

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STARt <load>
<b>Description</b>	This command sets the stream initial line load in ramp mode. Unit: Percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000, DEFault=0.0000</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:STAR 20
<b>Note</b>	The minimum possible line load is 0.0008.

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STARt?
<b>Description</b>	This query returns the stream initial line load in ramp mode. Unit: Percentage.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:STAR? → 20
<b>Note</b>	

### 13.5.5 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:END

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:END <load>
<b>Description</b>	This command sets the stream end line load in ramp mode. Unit: Percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000, DEFault=0.0000</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:END 50
<b>Note</b>	The minimum possible line load is 0.0008.

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:END?
<b>Description</b>	This query returns the stream end line load in ramp mode. Unit: Percentage.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:END? → 50
<b>Note</b>	

### 13.5.6 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STEP

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STEP <load>
<b>Description</b>	This command sets the stream line load step size, in ramp mode. Unit: Percentage.
<b>Parameters</b>	<Pt> = Port number <load> = <NUMERIC PROGRAM DATA> <i>MINimum=0.0000, MAXimum=100.0000, DEFault=1.0000</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:STEP 2
<b>Note</b>	The minimum possible line load is 0.0008.

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:STEP?
<b>Description</b>	This query returns the stream line load step size, in ramp mode. Unit: Percentage.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<load> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:STEP? → 2
<b>Note</b>	

### 13.5.7 FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:DURation

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:DURation <dur>
<b>Description</b>	This command sets the stream step line load duration in ramp mode. Unit: Seconds.
<b>Parameters</b>	<Pt> = Port number <dur> = <NUMERIC PROGRAM DATA> <i>MINimum=3, MAXimum=3600, DEFault=10</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:DUR 5
<b>Note</b>	



<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LLoad:RAMP:DURation?
<b>Description</b>	This query returns the stream step line load duration in ramp mode. Unit: Seconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<dur> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LL:RAMP:DUR? → 5
<b>Note</b>	

### 13.5.8 FCHannel:PORT<Pt>:TRAFfic:STReam:FSIZe

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:FSIZe <dur>
<b>Description</b>	This command sets the frame size. Unit: Bytes
<b>Parameters</b>	<Pt> = Port number <dur> = <NUMERIC PROGRAM DATA> <i>MINimum=8<sup>1</sup>, MAXimum=3240, DEFault=8</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:FSIZ 8
<b>Note</b>	The frame size must be a multiple of 4. <sup>1</sup> The minimum allowed frame size varies depending on the port mode. FC400: <i>MINimum = 64</i> FC800: <i>MINimum = 256</i> FC1200: <i>MINimum = 256</i>

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:FSIZe?
<b>Description</b>	This query returns the frame size. Unit: Bytes
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<dur> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:FSIZ? → 8
<b>Note</b>	

### 13.5.9 FCHannel:PORT<Pt>:TRAFfic:STReam:LATency[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency[:ENABle] <enable>
<b>Description</b>	This command enables/disables stream latency measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency[:ENABle]?
<b>Description</b>	This query returns whether or not stream latency measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT? → 0
<b>Note</b>	

### 13.5.10 FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables stream latency threshold.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT:THR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not stream latency threshold is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT:THR? → 0
<b>Note</b>	

### 13.5.11 FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds:VALue

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds:VALue <value>
<b>Description</b>	This command sets the Latency thresholds value. Unit: Microseconds.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=429496729.5, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT:THR:VAL 10.5
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:LATency:THResholds:VALue?
<b>Description</b>	This query returns the Latency thresholds value. Unit: Microseconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:LAT:THR:VAL? → 10.5
<b>Note</b>	

### 13.5.12 FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer[:ENABle] <enable>
<b>Description</b>	This command enables/disables stream jitter measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer[:ENABle]?
<b>Description</b>	This query returns whether or not stream jitter measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT? → 0
<b>Note</b>	

### 13.5.13 FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables stream jitter threshold.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT:THR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not stream jitter threshold is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT:THR? → 0
<b>Note</b>	

#### 13.5.14 FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds:VALue

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds:VALue <value>
<b>Description</b>	This command sets the stream jitter threshold value. Unit: Microseconds.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=429496792.5, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT:THR:VAL 10.5
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:JITTer:THResholds:VALue?
<b>Description</b>	This query returns the stream jitter threshold value. Unit: Microseconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:JITT:THR:VAL? → 10.5
<b>Note</b>	

#### 13.5.15 FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure[:ENABle] <enable>
<b>Description</b>	This command enables/disables Service Disruption Measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure[:ENABle]?
<b>Description</b>	This query returns whether or not Service Disruption Measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM? → 0
<b>Note</b>	

#### 13.5.16 FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:MDISruption

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:MDISruption <value>
<b>Description</b>	This command sets the Min Disruption Frames.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 5000, DEFault = 10</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:MDIS 5
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:MDISruption?
<b>Description</b>	This query return the Min Disruption Frames.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:MDIS? → 5
<b>Note</b>	

### 13.5.17 FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables Service Disruption threshold.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:THR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not Service Disruption threshold is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:THR? → 0
<b>Note</b>	

### 13.5.18 FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds:VALue

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds:VALue <value>
<b>Description</b>	This command sets the Service Disruption threshold value. Unit: Microseconds.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 5000000, DEFault = 50000</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:THR:VAL 10
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:TRAFfic:STReam:BER:SDMeasure:THResholds:VALue?
<b>Description</b>	This query returns the Service Disruption threshold value. Unit: Microseconds.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TRAF:STR:BER:SDM:THR:VAL? → 10
<b>Note</b>	This only applies to Ethernet and Fibre Channel.

## 13.6 Settings

### 13.6.1 FCHannel:PORT<Pt>:SETTings:BER:OBAMeasuring

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:OBAMeasuring <enable>
<b>Description</b>	This command enables/disables only show BER alarms when measuring.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SETT:BER:OBAM ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:OBAMeasuring?
<b>Description</b>	This query returns if BER alarms should only be shown when measuring.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SETT:BER:OBAM? → 1
<b>Note</b>	This setting applies to all ports.

### 13.6.2 FCHannel:PORT<Pt>:SETTings:BER:IAFFilter

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:IAFFilter <enable>
<b>Description</b>	This command enables/disables include addresses in frame filter on receiver.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SETT:BER:IAFF OFF
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:IAFFilter?
<b>Description</b>	This query returns if include addresses in frame filter on receiver is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SETT:BER:IAFF? → 0
<b>Note</b>	This setting applies to all ports.

### 13.6.3 FCHannel:PORT<Pt>:SETTings:BER:CLFrames

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:CLFrames <enable>
<b>Description</b>	This command enables/disables count lost frames as pattern errors.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SETT:BER:CLF ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:CLFrames?
<b>Description</b>	This query return if count lost frames as pattern errors is enabled/disabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SETT:BER:CLF? → 1
<b>Note</b>	This setting applies to all ports.

## 13.6.4 FCHannel:PORT&lt;Pt&gt;:SETTings:BER:HIDeframeloss

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:HIDeframeloss <enable>
<b>Description</b>	This command show/hide Frame/Pattern loss secs. count.
<b>Parameter</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:SETT:BER:HID ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	FCHannel:PORT<Pt>:SETTings:BER:HIDeframeloss?
<b>Description</b>	This query return if Frame/Pattern loss secs. count is show/hide.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:SETT:BER:HID? → 1
<b>Note</b>	This setting applies to all ports.

## 13.7 Thresholds

### 13.7.1 FCHannel:PORT<Pt>:THResholds[:ENABle]

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds[:ENABle] <enable>
<b>Description</b>	This command enables/disables thresholds.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:THR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds[:ENABle]?
<b>Description</b>	This query returns whether or not thresholds is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:THR? → 0
<b>Note</b>	

### 13.7.2 FCHannel:PORT<Pt>:THResholds:SElect

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds:SElect <type>, <enable>
<b>Description</b>	This command enables/disables the specific threshold type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> ALL: All thresholds UTIL: Utilization THR: Throughput ERR: Errored frames UNDer: Undersized frames OVER: Oversized frames CRC: CRC errored frames IFG: IFG violations SYMBol: Symbol errors CRD: CRD errors <i>DEFault = ALL</i> <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:THR:SEL UTIL, ON
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds:SElect? <type>
<b>Description</b>	This query returns whether or not the specific threshold type is enabled.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA>
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT1:THR:SEL? UTIL → 1
<b>Note</b>	

## 13.7.3 FCHannel:PORT&lt;Pt&gt;:THResholds:VALue

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds:VALue <type>, <compare>, <value>
<b>Description</b>	This command sets the level for the specific threshold type.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;  UTIL: Utilization<sup>1</sup>  THR: Throughput<sup>2</sup>  ERR: Errored frames  UNDer: Undersized frames  OVER: Oversized frames  CRC: CRC errored frames  IFG: IFG violations  SYMBol: Symbol errors  CRD: CRD errors</p> <p>&lt;compare&gt; = &lt;CHARACTER PROGRAM DATA&gt;  GT: Greater than  LT: Less than  GTEQ: Greater than or equal to  LTEQ: Less than or equal to  <i>DEFault = LT</i></p> <p>&lt;value&gt; = &lt;NUMERIC PROGRAM DATA&gt;  Absolute values: Decimals are rounded. Maximum is 4000000000  Percentage values: Allows one decimal, Maximum is 100.0  <i>DEFault = 0, MINimum = 0</i>  <i>Allowed Suffixes = PCT</i></p>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:THR:VAL UTIL, GT, 10.5PCT
<b>Note</b>	<sup>1</sup> Utilization only supports percentage values. <sup>2</sup> Throughput only supports absolute values, the unit is MBPS, and has one decimal. Maximum = 10000.0

<b>Syntax</b>	FCHannel:PORT<Pt>:THResholds:VALue? <type>
<b>Description</b>	This query returns the level for the specific threshold type.
<b>Parameter</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;type&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p>
<b>Response</b>	<p>&lt;compare&gt; = &lt;CHARACTER RESPONSE DATA&gt;</p> <p>&lt;value&gt; = &lt;NR2 NUMERIC RESPONSE DATA&gt;  Count or percentage.</p>
<b>Example</b>	FCH:PORT1:THR:VAL? UTIL → GT, 10.5PCT
<b>Note</b>	

## 13.8 Follow

## 13.8.1 FCHannel:PORT&lt;Pt&gt;:FOLLow:GENerator

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLow:GENerator <enable>
<b>Description</b>	This command enables/disables generator setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<p>&lt;Pt&gt; = Port number (2-4)</p> <p>&lt;enable&gt; = &lt;BOOLEAN PROGRAM DATA&gt;  <i>DEFault = OFF</i></p>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT2:FOLL:GEN OFF
<b>Note</b>	



<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:GENerator?
<b>Description</b>	This query returns whether or not generator setup for port <Pt> to follow PORT1 is enabled.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT2:FOLL:GEN? → 0
<b>Note</b>	

### 13.8.2 FCHannel:PORT<Pt>:FOLLOW:THResholds

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:THResholds <enable>
<b>Description</b>	This command enables/disables thresholds setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT2:FOLL:THR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:THResholds?
<b>Description</b>	This query returns whether or not thresholds setup for port <Pt> to follow PORT1 is enabled.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT2:FOLL:THR? → 0
<b>Note</b>	

### 13.8.3 FCHannel:PORT<Pt>:FOLLOW:FRAMe

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:FRAMe <enable>
<b>Description</b>	This command enables/disables frame setup for port <Pt> to follow PORT1.
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT2:FOLL:FRAM OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:FRAMe?
<b>Description</b>	This query returns whether or not frame setup for port <Pt> to follow PORT1 is enabled.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT2:FOLL:FRAM? → 0
<b>Note</b>	

### 13.8.4 FCHannel:PORT<Pt>:FOLLOW:STReam

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLOW:STReam <enable>
<b>Description</b>	This command enables/disables stream setup for port <Pt> to follow PORT1
<b>Parameter</b>	<Pt> = Port number (2-4) <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT2:FOLL:STR OFF
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:FOLLow:STReam?
<b>Description</b>	This query returns whether or not stream setup for port <Pt> to follow PORT1 is enabled.
<b>Parameter</b>	<Pt> = Port number (2-4)
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	FCH:PORT2:FOLL:STR? → 0
<b>Note</b>	

## 13.9 Stimuli

### 13.9.1 FCHannel:PORT<Pt>:STIMuli:ALARm

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:ALARm <alarm>
<b>Description</b>	This command sets the stimuli alarm state.
<b>Parameters</b>	<Pt> = Port number <alarm> = <CHARACTER PROGRAM DATA> NONE: No alarm LRESet: List reset LRResponse: List reset response NOPerational: Not operational OFFLine: Offline <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:STIM:ALAR LRES
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:ALARm?
<b>Description</b>	This query returns the stimuli alarm state.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<alarm> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:STIM:ALAR? → LRES
<b>Note</b>	

### 13.9.2 FCHannel:PORT<Pt>:STIMuli:ERRor

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:ERRor <error>
<b>Description</b>	This command sets the stimuli error state.
<b>Parameters</b>	<Pt> = Port number <error> = <CHARACTER PROGRAM DATA> NONE: No error BIT: Bit SYMBOL: Symbol RRDY: R_RDY CRC: CRC <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:STIM:ERR BIT
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:ERRor?
<b>Description</b>	This query returns the stimuli error state.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<error> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:STIM:ERR? → BIT
<b>Note</b>	

### 13.9.3 FCHannel:PORT<Pt>:STIMuli:EINsertion

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:EINsertion <mode>
<b>Description</b>	This command sets the stimuli error insertion mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Stimuli disabled MANual B1: Burst every 1 second B10: Burst every 10 seconds BE2: Burst · 1E-02 BE3: Burst · 1E-03 BE4: Burst · 1E-04 BE5: Burst · 1E-05 BE6: Burst · 1E-06 BE7: Burst · 1E-07 <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:STIM:EINS MAN
<b>Note</b>	

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:EINsertion?
<b>Description</b>	This query returns the stimuli error insertion mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	FCH:PORT1:STIM:EINS? → MAN
<b>Note</b>	

### 13.9.4 FCHannel:PORT<Pt>:STIMuli:EBLength

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:EBLength <length>
<b>Description</b>	This command sets the error burst length.
<b>Parameters</b>	<Pt> = Port number <length> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 4000<sup>1</sup>, DEFault = 1</i>
<b>Response</b>	None.
<b>Example</b>	FCH:PORT1:STIM:EBL 128
<b>Note</b>	<sup>1</sup> The following error type have other MAXimum value. RRDY: <i>MAXimum = 500</i> SYMBOL: <i>MAXimum = 1000</i>

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:EBLength?
<b>Description</b>	This query returns the error burst length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<length> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:STIM:EBL? → 128
<b>Note</b>	

## 13.9.5 FCHannel:PORT&lt;Pt&gt;:STIMuli:FOFFset

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:FOFFset <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> MT1000A: <i>MINimum=-100, MAXimum=100, DEFault=0</i> MT1100A: <i>MINimum=-200.0, MAXimum=200.0, DEFault = 0</i>
<b>Response</b>	None
<b>Example</b>	FCH:PORT1:STIM:FOFF 0
<b>Note</b>	The offset is applied to the internal clock source only.

<b>Syntax</b>	FCHannel:PORT<Pt>:STIMuli:FOFFset?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	MT1000A: <offset> = <NR1 NUMERIC RESPONSE DATA> MT1100A: <offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MT1100A: FCH:PORT1:STIM:FOFF? → 0.0
<b>Note</b>	

## 13.10 Results

### 13.10.1 FCHannel:PORT<Pt>:IFETch?

<b>Syntax</b>	FCHannel:PORT<Pt>:IFETch? <parameter>
<b>Description</b>	This query fetches an Fibre Channel interval if available.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {,}*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>BERT</b></p> <p>BPBC: Pattern bit count. Response: &lt;Count&gt;</p> <p>BPE: Pattern errors. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>BFL: Frame loss. Response: &lt;Count&gt;</p> <p>BFLS: Frame loss seconds. Response: &lt;Count&gt;</p> <p>BPLS: Pattern loss seconds. Response: &lt;Count&gt;</p> <p>BL: Latency (microseconds). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p>BJ: Jitter (microseconds). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p>BSD: Service disruption (microseconds). Response: &lt;Max&gt;,&lt;Avg&gt;,&lt;Count&gt;</p> <p><b>Reflector</b></p> <p>RFFRM: Reflected frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RFBYT: Reflected bytes. Response: &lt;Count&gt;</p> <p>NRFFR: Not reflected frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>NRFBY: Not reflected bytes. Response: &lt;Count&gt;</p> <p>TOFRM: Total frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>TOBYT: Reflected bytes. Response: &lt;Count&gt;</p> <p><b>Link</b></p> <p>SER: Symbol errors. Response: &lt;Count&gt;</p> <p>RRDY: R_RDY. Response: &lt;CountTx&gt;,&lt;CountRx&gt;</p> <p>LR: Link reset. Response: &lt;Count&gt;</p> <p>LRR: Link reset response. Response: &lt;Count&gt;</p> <p>NOS: Not operational seconds. Response: &lt;Count&gt;</p> <p>OLS: Offline seconds. Response: &lt;Count&gt;</p> <p><b>Frame</b></p> <p>FRM: Frames. Response: &lt;CountTx&gt;,&lt;CountRx&gt;</p> <p>BYT: Bytes. Response: &lt;CountTx&gt;,&lt;CountRx&gt;</p> <p>IV: IFG violations. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CRC: CRC errors. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>SEFR: Symbol error frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CRD: CRD errors. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>CRD: CRD errors. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>TER: Terminate errors. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>EFRM: Errored frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RFRM: Reflected frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>RBYT: Reflected bytes. Response: &lt;Count&gt;</p> <p>NRFRM: Not reflected frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>NRBYT: Not reflected bytes. Response: &lt;Count&gt;</p> <p>TFRM: Total frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>TBYT: Total bytes. Response: &lt;Count&gt;</p> <p><b>Performance</b></p> <p>LRAT: Line rate (bps). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p>FRAT: Frame rate (fps). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p>UTIL: Utilization. Response: &lt;Min%&gt;,&lt;Max%&gt;,&lt;Avg%&gt;</p> <p>THR: Throughput (bps). Response: &lt;Min&gt;,&lt;Max&gt;,&lt;Avg&gt;</p> <p><b>Size Distribution</b></p> <p>UNFR: Undersized frames. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>R28: 28-196. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>R200: 200-396. Response: &lt;Count&gt;,&lt;Ratio&gt;</p> <p>R400: 400-596. Response: &lt;Count&gt;,&lt;Ratio&gt;</p>

continued on next page...

... continued from previous page

	R600: 600-796. Response: <Count>,<Ratio> R800: 800-996. Response: <Count>,<Ratio> R1000: 1000-1196. Response: <Count>,<Ratio> R1200: 1200-1396. Response: <Count>,<Ratio> R1400: 1400-1596. Response: <Count>,<Ratio> R1600: 1600-1796. Response: <Count>,<Ratio> R1800: 1800-1996. Response: <Count>,<Ratio> R2000: 2000-2196. Response: <Count>,<Ratio> OVFR: Oversized frames. Response: <Count>,<Ratio> FSIZ: Frame size (bytes). Response: <Avg>
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> Expression format: Numeric List Each result is formatted according to the specification in the parameter field. Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).
<b>Examples</b>	FCH:PORT1:IFET? (UTIL) → (0.0000,50.0000,41.1117) FCH:PORT1:IFET? (BPE,BPLS) → (13944487,0.000979),(104)
<b>Notes</b>	This command fetches the results from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2). If the requested result is not available, NaN (section 1.6.1) is returned. If there is one or more results, the last "," is always removed.

### 13.10.2 FCHannel:PORT<Pt>:TFETch?

<b>Syntax</b>	FCHannel:PORT<Pt>:TFETch? <parameter>
<b>Description</b>	This query fetches thresholds for a Fibre Channel interval if available.
<b>Parameters</b>	<Pt> = Port number ({<parameter>} + {,})* = <EXPRESSION PROGRAM DATA> <b>Frame</b> IV: IFG violations. CRC: CRC errors. SEFR: Symbol error frames. CRD: CRD errors. EFRM: Errored frames <b>Performance</b> UTIL: Utilization (pct). THR: Throughput (bps). <b>Size Distribution</b> UNFR: Undersized frames. OVFR: Oversized frames.
<b>Response</b>	{(<result>),}* = <EXPRESSION RESPONSE DATA> Expression format: Numeric List <result> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:PORT1:TFET? (UTIL,UNFR) → (1),(0)
<b>Note</b>	This query fetches from the interval selected using the MEASurement:SETup:SElect command (see section 17.2.2).

## 13.11 Status

### 13.11.1 FCHannel:STATus:PORT<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the Fibre Channel alarms and errors summary event register. The content of this event register is summarized in DB12 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:AES? → 1
<b>Note</b>	

### 13.11.2 FCHannel:STATus:PORT<Pt>:AESummary:CONDition?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the Fibre Channel alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 (2) = Error summary DB3 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:AES:COND? → 2
<b>Note</b>	

### 13.11.3 FCHannel:STATus:PORT<Pt>:ALARm[:EVENT]?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 of the FCHannel:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Signal Present DB2 (2) = Sync Acquired DB3 (4) = Link DB4 (8) = Fabric Login DB5 (16) = Port Login DB6 (32) = Pattern Sync DB7 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:ALAR? → 2
<b>Notes</b>	

## 13.11.4 FCHannel:STATus:PORT&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Signal Present DB2 (2) = Sync Acquired DB3 (4) = Link DB4 (8) = Fabric Login DB5 (16) = Port Login DB6 (32) = Pattern Sync DB7 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:ALAR:COND? → 4
<b>Notes</b>	

## 13.11.5 FCHannel:STATus:PORT&lt;Pt&gt;:ERRor[:EVENT]?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:ERRor[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB2 of the FCHannel:STATus:PORT<Pt>:AESummary:CONDition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern error DB2 (2) = Traffic error DB3 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:ERR? → 1
<b>Notes</b>	

## 13.11.6 FCHannel:STATus:PORT&lt;Pt&gt;:ERRor:CONDition?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:ERRor:CONDition?
<b>Description</b>	This query returns the errors condition register.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Pattern error DB2 (2) = Traffic error DB3 - DB16 = NOT USED
<b>Example</b>	FCH:STAT:PORT1:ERR:COND? → 1
<b>Notes</b>	

## 13.11.7 FCHannel:STATus:PORT&lt;Pt&gt;:SID?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:SID?
<b>Description</b>	This query returns the source ID if Login is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<link> = <HEXADECIMAL NUMERIC RESPONSE DATA <sub>i</sub> >
<b>Example</b>	FCH:STAT:PORT1:SID? → #H11
<b>Note</b>	NaN (section 1.6.1) is returned if Login is not enabled or port is off.

## 13.11.8 FCHannel:STATus:PORT&lt;Pt&gt;:DID?

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:DID?
<b>Description</b>	This query returns the destination ID if Login is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<link> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:STAT:PORT1:DID? → #H22
<b>Note</b>	NaN (section 1.6.1) is returned if Login is not enabled or port is off.



**13.11.9 FCHannel:STATus:PORT<Pt>:PDEViation?**

<b>Syntax</b>	FCHannel:STATus:PORT<Pt>:PDEViation?
<b>Description</b>	This query returns physical deviation. Units: ppm and bps.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ppm> = <NR1 NUMERIC RESPONSE DATA> <bps> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	FCH:STAT:PORT1:PDEV? → 0, 0
<b>Note</b>	



---

# Chapter 14

## OTN

### 14.1 Transmitter

#### 14.1.1 OTN:TX<Pt>:INTerface

<b>Syntax</b>	OTN:TX<Pt>:INTerface <mode>
<b>Description</b>	This command sets the used interface of the transmitter.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SFP: SFP/SFP+ optical interface QSFP: QSFP+ optical interface CFP: CFP optical interface CFP2: CFP2 optical interface QSFP28ADpt: CFP2-QSFP28 Adaptor interface <i>DEFault = SFP</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:INT SFP
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:INTerface?
<b>Description</b>	This query returns the used interface.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:INT? → SFP
<b>Note</b>	

#### 14.1.2 OTN:TX<Pt>[:ENABled]

<b>Syntax</b>	OTN:TX<Pt>[:ENABled] <mode>
<b>Description</b>	This command sets the mode of the optical transmitters.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: OFF NORMal: Normal (Optical) THROUGH: Through Rx (pass through mode) OVERwrite: OH Overwrite <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1 OFF
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>[:ENABLEd]?
<b>Description</b>	This query returns the mode of the optical transmitters.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1? → OFF
<b>Note</b>	

### 14.1.3 OTN:TX<Pt>:TIMing

<b>Syntax</b>	OTN:TX<Pt>:TIMing <timing>
<b>Description</b>	This command sets the timing source.
<b>Parameters</b>	<Pt> = Port number <timing> = <CHARACTER PROGRAM DATA> INTernal: Internal clock EXTernal: External clock GPS: GPS signal RX: Received clock <i>DEFault = INT</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:TIM INT
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:TIMing?
<b>Description</b>	This query returns the timing source.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<timing> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:TIM? → INT
<b>Note</b>	

### 14.1.4 OTN:TX<Pt>:MAPPING:CSIGNAL

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:CSIGNAL <signal>
<b>Description</b>	This command sets the expected client signal structure.
<b>Parameters</b>	<Pt> = Port number <signal> = <CHARACTER PROGRAM DATA> PRBS NUL STM256 STS768 STM64 STS192 STM16 STS48 STM4 STS12 STM1 STS3 STM64S STS192S STM16S STS48S PRBSTRANS NULLTRANS GBE100 GBE40 GBE10

continued on next page...

...continued from previous page

	GBE ETHERNET FC1200 FC800 FC400 FC200 FC100 10137M 9830M 6144M 4915M 3072M 2457M 1228M 614M MPLS IPV4PDU IPV6PDU <i>DEFault = PRBS</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX2:MAPP:CSIG PRBS
<b>Note</b>	Available for SDH/SONET option: STM256/STS768 STM64/STM64S/STS192/STS192S/STM16/STM16S/STS48/STS48S STM4/STS12/STM1/STS3 PRBSTRANS/NULLTRANS Available for Ethernet option: GBE100/GBE40 GBE10/GBE Available for FC option: FC1200/FC800 FC400/FC200/FC100 Available for CPRI option: 10137M/9830M/6144M/4915M/3072M/2457M/1228M/614M
<b>Syntax</b>	OTN:TX<Pt>:MAPPING:CSIGNAL?
<b>Description</b>	This query returns the expected client signal structure.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signal> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX2:MAPP:CSIG? → PRBS
<b>Note</b>	

## 14.1.5 OTN:TX&lt;Pt&gt;:PATTern

<b>Syntax</b>	OTN:TX<Pt>:PATTern <pattern>
<b>Description</b>	This command sets the pattern type when CSIGNAL is PRBS.
<b>Parameters</b>	<Pt> = Port number <pattern> = <CHARACTER PROGRAM DATA> PRBS9:PRBS9 pattern PRBS11:PRBS11 pattern PRBS15:PRBS15 pattern PRBS20:PRBS20 pattern PRBS23:PRBS23 pattern PRBS29:PRBS29 pattern PRBS31:PRBS31 pattern USER32BIT: User Pattern (32bit) USER2048BIT: User Pattern (2048bit) <i>DEFault = PRBS31</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX2:PATT PRBS31
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:PATTern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX2:PATT? → PRBS31
<b>Note</b>	

## 14.1.6 OTN:TX&lt;Pt&gt;:PINVersion

<b>Syntax</b>	OTN:TX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:PINV ON
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	OTN:TX1:PINV? → 1
<b>Note</b>	

## 14.1.7 OTN:TX&lt;Pt&gt;:UP32

<b>Syntax</b>	OTN:TX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None
<b>Example</b>	OTN:TX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	OTN:TX1:UP32? → "01101"
<b>Note</b>	

#### 14.1.8 OTN:TX<Pt>:UP2K

<b>Syntax</b>	OTN:TX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	OTN:TX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when OTN:TX1:PATT is USER2048BIT

<b>Syntax</b>	OTN:TX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	OTN:TX1:UP2K? → "12DF"
<b>Note</b>	

#### 14.1.9 OTN:TX<Pt>:MAPPING:OUTPutsignal

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:OUTPutsignal <signal>
<b>Description</b>	This command sets OTN output signal.
<b>Parameters</b>	<Pt> = Port number <signal> = <CHARACTER PROGRAM DATA> OTU1 OTU2 OTU2EXTOPU2 OTU1E OTU2E OTU1F OTU2F OTU3 OTU3E1 OTU3E2 OTU4 <i>Default = OTU2</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:MAPP:OUTP OTU2
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:OUTPutsignal?
<b>Description</b>	This query returns OTN output signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signal> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:MAPP:OUTP? → OTU2
<b>Note</b>	

## 14.1.10 OTN:TX&lt;Pt&gt;:FEC

<b>Syntax</b>	OTN:TX<Pt>:FEC <fec>
<b>Description</b>	This command sets OTU FEC control.
<b>Parameters</b>	<Pt> = Port number <fec> = <CHARACTER PROGRAM DATA> NOFec: No forward error correction RS: RS (255,239) <i>DEFault = RS</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:FEC RS
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:FEC?
<b>Description</b>	This query returns OTU FEC control.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<fec> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:FEC? → RS
<b>Note</b>	

## 14.1.11 OTN:TX&lt;Pt&gt;:MAPPING:MULTIplexing&lt;stage&gt;

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:MULTIplexing<stage> <odutype>
<b>Description</b>	This command sets the ODU type of each multiplexing stage.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3) <odutype> = <CHARACTER PROGRAM DATA> NONE: None ODTU01: ODTU01 ODTU12PT20: ODTU12 (PT=20) ODTU12PT21: ODTU12 (PT=21) ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13PT20: ODTU13 (PT=20) ODTU13PT21: ODTU13 (PT=21) ODTU23PT20: ODTU23 (PT=20) ODTU23PT20EXTOPU2: ODTU23 (PT=20)(Ext. OPU2) ODTU23PT21: ODTU23 (PT=21) ODTU23PT21EXTOPU2: ODTU23 (PT=21)(Ext. OPU2) ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48ODU2: ODTU4.8 (ODU2) ODTU48EXTOPU2: ODTU4.8 (Ext. OPU2) ODTU48ODU2E: ODTU4.8 (ODU2e) ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts <i>DEFault = NONE</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:MAPP:MULT1 NONE
<b>Note</b>	



<b>Syntax</b>	OTN:TX<Pt>:MAPPING:MULTIplexing<stage>?
<b>Description</b>	This query returns the ODU type of each multiplexing stage.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3)
<b>Response</b>	<odutype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:MAPP:MULT1? → NONE
<b>Note</b>	

#### 14.1.12 OTN:TX<Pt>:MAPPING:LANE

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:LANE <value>
<b>Description</b>	This command sets the LLD lane marker assignment.
<b>Parameters</b>	<Pt> = Port number {(<value>),}* = <EXPRESSION PROGRAM DATA> Format: Numeric List List consist of the value of the lane marker. OTU3: 0 to 3 OTU4: 0 to 19
<b>Response</b>	None.
<b>Example</b>	OTN:TX1:MAPP:LANE (0,1,2,3) OTN:TX1:MAPP:LANE (0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19)
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:TX<Pt>:MAPPING:LANE?
<b>Description</b>	This query returns the LLD lane marker assignment.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	{(<value>),}* = <EXPRESSION RESPONSE DATA> Format: Numeric List
<b>Example</b>	OTN:TX1:MAPP:LANE? → (0,1,2,3) → (0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19)
<b>Note</b>	This command can be used on 40/100G

#### 14.1.13 OTN:TX<Pt>:COPY

<b>Syntax</b>	OTN:TX<Pt>:COPY <odutype>,<mode>
<b>Description</b>	This command sets the copy mode of dummy CH.
<b>Parameters</b>	<Pt> = Port number <odutype> = <CHARACTER PROGRAM DATA> ODTU01 ODTU12 ODTU21 ODTU2TS ODTU13 ODTU23 ODTU31 ODTU3E28 ODTU2E3E1 ODTU3TS ODTU41 ODTU42 ODTU48 ODTU431 ODTU4TS <mode> = <CHARACTER PROGRAM DATA> COPY

continued on next page...

...continued from previous page

	UNUSe <i>DEFault = COPY</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:COPY ODTU01,COPY
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:COPY? <odutype>
<b>Description</b>	This query returns the copy mode of dummy CH.
<b>Parameters</b>	<Pt> = Port number <odutype> = <CHARACTER PROGRAM DATA> ODTU01 ODTU12 ODTU21 ODTU2TS ODTU13 ODTU23 ODTU31 ODTU3E28 ODTU2E3E1 ODTU3TS ODTU41 ODTU42 ODTU48 ODTU431 ODTU4TS
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:COPY? ODTU01 → COPY
<b>Note</b>	

#### 14.1.14 OTN:TX<Pt>:CSF

<b>Syntax</b>	OTN:TX<Pt>:CSF <csf>
<b>Description</b>	This command sets the insertion mode of CSF.
<b>Parameters</b>	<Pt> = Port number <csf> = <CHARACTER PROGRAM DATA> GFPT: GFP-T CSF Replacement ETHer: Ethernet Block Replacement <i>DEFault = ETH</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:CSF ETH
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:CSF?
<b>Description</b>	This query returns the insertion mode of CSF.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<csf> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:CSF? → ETH
<b>Note</b>	

## 14.1.15 OTN:TX&lt;Pt&gt;:FOLLow

<b>Syntax</b>	OTN:TX<Pt>:FOLLow <mode>
<b>Description</b>	This command sets the transmitter setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX1: Follows setup of the Tx port1. <i>DEFault = NONE</i>
<b>Response</b>	None.
<b>Example</b>	OTN:TX1:FOLL NONE
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:FOLLow?
<b>Description</b>	This query returns the transmitter setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:TX1:FOLL? → NONE
<b>Note</b>	

## 14.1.16 OTN:OH:TX&lt;Pt&gt;:OTN:OH

<b>Syntax</b>	OTN:OH:TX<Pt>:OTN:OH <odutype>,<row>,<column>,<data>
<b>Description</b>	This command sets the value of the specified bytes in the OH.
<b>Parameters</b>	<Pt> = Port number <odutype> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU2E: ODU2e ODU1E: ODU1e ODU2F: ODU2f ODU1F: ODU1f ODUFLEX: ODUflex ODU3: ODU3 ODU3E1: ODU3e1 ODU3E2: ODU3e2 ODU4: ODU4 ODUC: ODUC <row> = <NUMERIC PROGRAM DATA> OH Row Number (1-4) <column> = <NUMERIC PROGRAM DATA> OH Column Number (1-16) <data> = <NUMERIC PROGRAM DATA> Hexadecimal format Multi frame sequence data. Data length depends on the position of OH. The pattern is padded with zeros until multi frame sequence data length.
<b>Response</b>	None
<b>Example</b>	OTN:OH:TX1:OTN:OH ODU2,3,3,#H1
<b>Note</b>	The parameter error will occur when you specify a position that can not overwrite.

<b>Syntax</b>	OTN:OH:TX<Pt>:OTN:OH? <odutype>,<row>,<column>
<b>Description</b>	This query returns the value of the specified bytes in the OH.
<b>Parameters</b>	<Pt> = Port number <odutype> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU2E: ODU2e ODU1E: ODU1e ODU2F: ODU2f ODU1F: ODU1f ODUFLEX: ODUFlex ODU3: ODU3 ODU3E1: ODU3e1 ODU3E2: ODU3e2 ODU4: ODU4 ODUC: ODUC <row> = <NUMERIC PROGRAM DATA> OH Row Number (1-4) <column> = <NUMERIC PROGRAM DATA> OH Column Number (1-16)
<b>Response</b>	<data> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:OH:TX1:OTN:OH? ODU2,3,3 → #1
<b>Note</b>	

#### 14.1.17 OTN:OH:TX<Pt>:OTN:OH:DEFault

<b>Syntax</b>	OTN:OH:TX<Pt>:OTN:OH:DEFault <route>
<b>Description</b>	This command sets all overhead bytes to their default value.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU1E: ODU1e ODU2E: ODU2e ODU1F: ODU1f ODU2F: ODU2f ODUFLEX: ODUFlex ODU3: ODU3 ODU3E1: ODU3e1 ODU3E2: ODU3e2 ODU4: ODU4 ODUC: ODUC
<b>Response</b>	None
<b>Example</b>	OTN:OH:TX1:OTN:OH:DEF ODU2
<b>Note</b>	

#### 14.1.18 OTN:TX<Pt>:TP

<b>Syntax</b>	OTN:TX<Pt>:TP <route>,<tp>
<b>Description</b>	This command sets the TP to be used as the main transmission channel.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13

continued on next page...

...continued from previous page

	ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts <i>DEFault = ODTU21</i>
	<tp> = <NUMERIC PROGRAM DATA> ODTU01: TP: 1-2 ODTU12(Pt=0x20) TP: 1-4 ODTU12(Pt=0x21) TP: 1-4 ODTU21 TP: 1-8 ODTU2TS TP: 1-8 ODTU13(Pt=0x20) TP: 1-16 ODTU13(Pt=0x21) TP: 1-16 ODTU23(Pt=0x20) TP: 1-4 ODTU23(Pt=0x21) TP: 1-4 ODTU31 TP: 1-32 ODTU3E28 TP: 1-32 ODTU2E3E1 TP: 1-4 ODTU3TS TP: 1-32 ODTU41 TP: 1-80 ODTU42 TP: 1-80 ODTU48 TP: 1-80 ODTU431 TP: 1-80 ODTU4TS TP: 1-80
<b>Response</b>	None
<b>Example</b>	OTN:TX1:TP ODTU01,1
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:TP? <route>
<b>Description</b>	This query returns the TP to be used as the main transmission channel.
<b>Parameter</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts
<b>Response</b>	<tp> = <NUMERIC PROGRAM DATA>
<b>Example</b>	OTN:TX1:TP? ODTU01 → 1
<b>Note</b>	

## 14.1.19 OTN:TX&lt;Pt&gt;:TS

<b>Syntax</b>	OTN:TX<Pt>:TS <route>,<ts>
<b>Description</b>	This command sets a set of TS(s) to be used as the main transmission channel.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;route&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ODTU01: ODTU01  ODTU12: ODTU12  ODTU21: ODTU2.1  ODTU2TS: ODTU2.ts  ODTU13: ODTU13  ODTU23: ODTU23  ODTU31: ODTU3.1  ODTU3E28: ODTU3e2.8  ODTU2E3E1: ODTU2e3e1  ODTU3TS: ODTU3.ts  ODTU41: ODTU4.1  ODTU42: ODTU4.2  ODTU48: ODTU4.8  ODTU431: ODTU4.31  ODTU4TS: ODTU4.ts</p> <p><i>Default = ODTU21</i></p> <p>(&lt;ts&gt; {,&lt;ts&gt;}) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The format is listed for each parameter.</p>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:TS ODTU12, (1,2)
<b>Note</b>	<p>ODTU01 TS: will become the same value as TP.</p> <p>ODTU12 (PT=0x20) TS: will become the same value as TP.</p> <p>ODTU12 (PT=0x21) TS1: 1-8, TS2: 1-8. Two different TS numbers must be specified. The two values should not overlap.</p> <p>ODTU2.1 TS: 1-8  ODTU2TS TS: 1-8</p> <p>ODTU13(P=0x20) TS: will become the same value as TP.  ODTU13(P=0x21) TS: 1-32</p> <p>ODTU23(P=0x20) TS: 1-16  ODTU23(P=0x21) TS: 1-32</p> <p>ODTU31 TS: 1-32  ODTU3E28 TS: 1-32</p> <p>ODTU2E3E1 TS: 1-16  ODTU3TS TS: 1-32</p> <p>ODTU41 TS: 1-80  ODTU42 TS: 1-80  ODTU48 TS: 1-80  ODTU431 TS: 1-80  ODTU4TS TS: 1-80</p>

<b>Syntax</b>	OTN:TX<Pt>:TS? <route>
<b>Description</b>	This command returns a set of TS(s) to be used as the main transmission channel.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;route&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ODTU01: ODTU01  ODTU12: ODTU12  ODTU21: ODTU2.1  ODTU2TS: ODTU2.ts  ODTU13: ODTU13  ODTU23: ODTU23  ODTU31: ODTU3.1</p>

continued on next page...

...continued from previous page

	ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts
<b>Response</b>	(<ts> {,<ts>}) = <EXPRESSION RESPONSE DATA> The response format is listed for each parameter.
<b>Example</b>	OTN:TX1:TS? ODTU12 → (1)
<b>Note</b>	

#### 14.1.20 OTN:TX<Pt>:ODUFlex:TS

<b>Syntax</b>	OTN:TX<Pt>:ODUFlex:TS <ts>
<b>Description</b>	This command sets the size of a TS set to be used in ODUflex.
<b>Parameters</b>	<Pt> = Port number <ts> = <NUMERIC PROGRAM DATA> ODTU2.ts - PRBS/Ethernet: 1-8 ODTUk.ts - FC400: 4 ODTUk.ts - FC800: 7 ODTUk.ts - 3072M: 3 ODTUk.ts - 4915M: 4 ODTUk.ts - 6144M: 5 ODTUk.ts - 9830M: 8 ODTU3.ts - PRBS: 1-32 ODTU4.ts - PRBS: 1-80 ODTU3.ts - Ethernet: 1-32 ODTU4.ts - Ethernet: 1-80 ODTU3.ts - 10137M: 9 ODTU4.ts - 10137M: 8
<b>Response</b>	None
<b>Example</b>	OTN:TX1:ODUF:TS 1

<b>Syntax</b>	OTN:TX<Pt>:ODUFlex:TS?
<b>Description</b>	This command returns the size of a TS set to be used in ODUflex.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ts> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:ODUF:TS? → 1
<b>Note</b>	

## 14.1.21 OTN:TX&lt;Pt&gt;:ALlocated

<b>Syntax</b>	OTN:TX<Pt>:ALlocated <route>,<allocated>
<b>Description</b>	This command sets the channel allocation.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;route&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ODTU12: ODTU12  ODTU21: ODTU2.1  ODTU1321: ODTU13 (PT=0x21)  ODTU2320: ODTU23 (PT=0x20)  ODTU2321: ODTU23 (PT=0x21)  ODTU31: ODTU3.1  ODTU3E28: ODTU3e2.8  ODTU3TS: ODTU3.ts  ODTU41: ODTU4.1  ODTU42: ODTU4.2  ODTU48: ODTU4.8  ODTU431: ODTU4.31  ODTU4TS: ODTU4.ts</p> <p>&lt;allocated&gt; = &lt;STRING PROGRAM DATA&gt;</p> <p>"0" : All Allocated  "80" : CH1 Unallocated  "40" : CH2 Unallocated  "20" : CH3 Unallocated  "10" : CH4 Unallocated  "8" : CH5 Unallocated  "4" : CH6 Unallocated  "2" : CH7 Unallocated  "1" : CH8 Unallocated  <i>DEFault = 0</i></p>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:ALL ODTU12,"0"
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:ALlocated? <route>
<b>Description</b>	This query returns the channel allocation.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;route&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ODTU12: ODTU12  ODTU21: ODTU2.1  ODTU1321: ODTU13 (PT=0x21)  ODTU2320: ODTU23 (PT=0x20)  ODTU2321: ODTU23 (PT=0x21)  ODTU31: ODTU3.1  ODTU3E28: ODTU3e2.8  ODTU3TS: ODTU3.ts  ODTU41: ODTU4.1  ODTU42: ODTU4.2  ODTU48: ODTU4.8  ODTU431: ODTU4.31  ODTU4TS: ODTU4.ts</p>
<b>Response</b>	<allocated> = <STRING RESPONSE DATA>
<b>Example</b>	OTN:TX1:ALL? ODTU12 → "0"
<b>Note</b>	



## 14.1.22 OTN:TX&lt;Pt&gt;:GFP:PTI

<b>Syntax</b>	OTN:TX<Pt>:GFP:PTI <pti>
<b>Description</b>	This command sets GFP-F Payload Type Identifier.
<b>Parameters</b>	<Pt> = Port number <pti> = <NUMERIC PROGRAM DATA> <i>MINimum=#B000, MAXimum=#B111, DEFault=#B000</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:PTI #B000
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:PTI?
<b>Description</b>	This query returns GFP-F Payload Type Identifier.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pti> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:PTI? → #B000
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.23 OTN:TX&lt;Pt&gt;:GFP:PFI

<b>Syntax</b>	OTN:TX<Pt>:GFP:PFI <pfi>
<b>Description</b>	This command sets GFP-F Payload Frame check sequence Indicator.
<b>Parameters</b>	<Pt> = Port number <pfi> = <BOOLEAN PROGRAM DATA> <i>DEFault=0</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:PFI 0
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:PFI?
<b>Description</b>	This query returns GFP-F Payload Frame check sequence Indicator.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<pfi> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:PFI? → 0
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.24 OTN:TX&lt;Pt&gt;:GFP:EXI

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXI <exi>
<b>Description</b>	This command sets GFP-F Extension header Identifier.
<b>Parameters</b>	<Pt> = Port number <exi> = <NUMERIC PROGRAM DATA> <i>MINimum=#B0000, MAXimum=#B0001, DEFault=#B0000</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:EXI #B0000
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXI?
<b>Description</b>	This query returns GFP-F Extension header Identifier.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<exi> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:EXI? → #B0000
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.25 OTN:TX&lt;Pt&gt;:GFP:UPI

<b>Syntax</b>	OTN:TX<Pt>:GFP:UPI <upi>
<b>Description</b>	This command sets GFP-F User Payload Identifier.
<b>Parameters</b>	<Pt> = Port number <upi> = <NUMERIC PROGRAM DATA> <i>MINimum=#B00000000, MAXimum=#B11111111, DEFault=#B00000001</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:UPI #B00000001
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:UPI?
<b>Description</b>	This query returns GFP-F User Payload Identifier.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<upi> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:UPI? → #B00000001
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.26 OTN:TX&lt;Pt&gt;:GFP:EXTHHeader:CID

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXTHHeader:CID <cid>
<b>Description</b>	This command sets Channel ID of GFP-F extension header.
<b>Parameters</b>	<Pt> = Port number <cid> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:EXTH:CID 0
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXTHHeader:CID?
<b>Description</b>	This query returns Channel ID of GFP-F extension header.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<cid> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:EXTH:CID? → 0
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.27 OTN:TX&lt;Pt&gt;:GFP:EXTHHeader:SPARe

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXTHHeader:SPARe <spare>
<b>Description</b>	This command sets spare field of GFP-F extension header.
<b>Parameters</b>	<Pt> = Port number <spare> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=255, DEFault=0</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:EXTH:SPAR 0
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:EXTHHeader:SPARe?
<b>Description</b>	This query returns spare field of GFP-F extension header.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<spare> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:EXTH:SPAR? → 0
<b>Note</b>	This command can be used on V2.00 or later

## 14.1.28 OTN:TX&lt;Pt&gt;:GFP:PTIMes

<b>Syntax</b>	OTN:TX<Pt>:GFP:PTIMes <ptimes>
<b>Description</b>	This command sets GFP-F cHEC Presync Times.
<b>Parameters</b>	<Pt> = Port number <ptimes> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=14, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:GFP:PTIM 1
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	OTN:TX<Pt>:GFP:PTIMes?
<b>Description</b>	This query returns GFP-F cHEC Presync Times.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<ptimes> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TX1:GFP:PTIM? → 1
<b>Note</b>	This command can be used on V2.00 or later

## 14.2 Receiver

### 14.2.1 OTN:RX<Pt>:INTerface

<b>Syntax</b>	OTN:RX<Pt>:INTerface <mode>
<b>Description</b>	This command sets the used interface or switches off the receiver.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> OFF: Off SFP: SFP / SFP+ optical interface QSFP: QSFP+ optical interface CFP: CFP optical interface CFP2: CFP2 optical interface QSFP28ADpt: CFP2-QSFP28 Adaptor interface <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:INT OFF
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:INTerface?
<b>Description</b>	This query returns the mode of the optical receiver.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:INT? → OFF
<b>Note</b>	

### 14.2.2 OTN:RX<Pt>:MAPPING:CSIGNAL

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:CSIGNAL <signal>
<b>Description</b>	This command sets the client signal.
<b>Parameters</b>	<Pt> = Port number <signal> = <CHARACTER PROGRAM DATA> PRBS NUL STM256 STS768 STM64 STS192 STM16 STS48 STM4 STS12 STM1 STS3 STM64S STS192S STM16S STS48S PRBSTRANS NULLTRANS GBE100 GBE40 GBE10 GBE ETHERNET FC1200 FC800

continued on next page...

...continued from previous page

	FC400 FC200 FC100 10137M 9830M 6144M 4915M 3072M 2457M 1228M 614M MPLS IPV4PDU IPV6PDU <i>DEFault = PRBS</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:MAPP:CSIG PRBS
<b>Note</b>	Available for SDH/SONET option: STM256/STS768 STM64/STM64S/STS192/STS192S/STM16/STM16S/STS48/STS48S STM4/STS12/STM1/STS3 PRBSTRANS/NULLTRANS Available for Ethernet option: GBE100/GBE40 GBE10/GBE Available for FC option: FC1200/FC800 FC400/FC200/FC100 Available for CPRI option: 10137M/9830M/6144M/4915M/3072M/2457M/1228M/614M

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:CSIGNAL?
<b>Description</b>	This query returns the client signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signal> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:MAPP:CSIG? → PRBS
<b>Note</b>	

### 14.2.3 OTN:RX<Pt>:PATTERN

<b>Syntax</b>	OTN:RX<Pt>:PATTERN <pattern>
<b>Description</b>	This command sets the pattern type when CSIGNAL is PRBS.
<b>Parameters</b>	<Pt> = Port number <pattern> = <CHARACTER PROGRAM DATA> PRBS9:PRBS9 pattern PRBS11:PRBS11 pattern PRBS15:PRBS15 pattern PRBS20:PRBS20 pattern PRBS23:PRBS23 pattern PRBS29:PRBS29 pattern PRBS31:PRBS31 pattern USER32BIT: User Pattern (32bit) USER2048BIT: User Pattern (2048bit) <i>DEFault = PRBS31</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:PATT PRBS31
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:PATTern?
<b>Description</b>	This query returns the pattern type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:PATT? → PRBS31
<b>Note</b>	

#### 14.2.4 OTN:RX<Pt>:PINVersion

<b>Syntax</b>	OTN:RX<Pt>:PINVersion <inverted>
<b>Description</b>	This command enables or disables PRBS pattern inversion.
<b>Parameters</b>	<Pt> = Port number <inverted> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:PINV ON
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:PINVersion?
<b>Description</b>	This query returns the inversion state (enabled/disabled) of the PRBS pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<inverted> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	OTN:RX1:PINV? → 1
<b>Note</b>	

#### 14.2.5 OTN:RX<Pt>:UP32

<b>Syntax</b>	OTN:RX<Pt>:UP32 <pattern>
<b>Description</b>	This command sets the 32 bit wide variable length user defined pattern used when PATTern is USER32BIT.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use binary digits '0' and '1' to describe the pattern. The string must consist of 1 to 32 characters (one bit resolution).
<b>Response</b>	None
<b>Example</b>	OTN:RX1:UP32 "01101"
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:UP32?
<b>Description</b>	This query returns the 32 bit wide user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	OTN:RX1:UP32? → "01101"
<b>Note</b>	

#### 14.2.6 OTN:RX<Pt>:UP2K

<b>Syntax</b>	OTN:RX<Pt>:UP2K <pattern>
<b>Description</b>	This command sets the 2048 bit wide user defined pattern.
<b>Parameters</b>	<Pt> = Port number <pattern> = <STRING PROGRAM DATA> Use hexadecimal upper or lower case. The string must consist of 2 to 512 characters (one byte resolution).
<b>Response</b>	None.
<b>Example</b>	OTN:RX1:UP2K "12DF"
<b>Notes</b>	The pattern is padded with zeros until it is a multiple of eight bits long. In effect when OTN:RX1:PATT is USER2048BIT

<b>Syntax</b>	OTN:RX<Pt>:UP2K?
<b>Description</b>	This query returns the 2048 bit user defined pattern.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<pattern> = <STRING RESPONSE DATA>
<b>Example</b>	OTN:RX1:UP2K? → "12DF"
<b>Note</b>	

#### 14.2.7 OTN:RX<Pt>:MAPPING:INPutsignal

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:INPutsignal <signal>
<b>Description</b>	This command sets OTN input signal.
<b>Parameters</b>	<Pt> = Port number <signal> = <CHARACTER PROGRAM DATA> OTU1 OTU2 OTU2EXTOPU2 OTU1E OTU2E OTU1F OTU2F OTU3 OTU3E1 OTU3E2 OTU4 <i>DEFault = OTU2</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:MAPP:INP OTU2
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:INPutsignal?
<b>Description</b>	This query returns OTN input signal.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signal> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:MAPP:INP? → OTU2
<b>Note</b>	

## 14.2.8 OTN:RX&lt;Pt&gt;:MAPPING:MULTIPLEXING&lt;stage&gt;

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:MULTIPLEXING<stage> <odutype>
<b>Description</b>	This command sets the ODU type of each multiplexing stage.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3) <odutype> = <CHARACTER PROGRAM DATA> NONE: None ODTU01: ODTU01 ODTU12PT20: ODTU12 (PT=20) ODTU12PT21: ODTU12 (PT=21) ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13PT20: ODTU13 (PT=20) ODTU13PT21: ODTU13 (PT=21) ODTU23PT20: ODTU23 (PT=20) ODTU23PT20EXTOPU2: ODTU23 (PT=20)(Ext. OPU2) ODTU23PT21: ODTU23 (PT=21) ODTU23PT21EXTOPU2: ODTU23 (PT=21)(Ext. OPU2) ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48ODU2: ODTU4.8 (ODU2) ODTU48EXTOPU2: ODTU4.8 (Ext. OPU2) ODTU48ODU2E: ODTU4.8 (ODU2e) ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts <i>DEFAULT = NONE</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:MAPP:MULT1 NONE
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:MAPPING:MULTIPLEXING<stage>?
<b>Description</b>	This query returns the ODU type of each multiplexing stage.
<b>Parameter</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3)
<b>Response</b>	<odutype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:MAPP:MULT1? → NONE
<b>Note</b>	

## 14.2.9 OTN:RX&lt;Pt&gt;:FEC

<b>Syntax</b>	OTN:RX<Pt>:FEC <fec>
<b>Description</b>	This command sets OTU FEC control.
<b>Parameters</b>	<Pt> = Port number <fec> = <CHARACTER PROGRAM DATA> NOFec: No FEC RS: RS(255,239) <i>DEFAULT = RS</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:FEC RS
<b>Note</b>	



<b>Syntax</b>	OTN:RX<Pt>:FEC?
<b>Description</b>	This query returns OTU FEC control.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<fec> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:FEC? → RS
<b>Note</b>	

#### 14.2.10 OTN:RX<Pt>:FOLLow

<b>Syntax</b>	OTN:RX<Pt>:FOLLow <follow>
<b>Description</b>	This command sets the receiver setup to follow another setup or not to follow.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> NONE: Do not follow. TX: Follows setup of the Tx port. RX1: Follows setup of the Rx port1. <i>DEFault = TX</i>
<b>Response</b>	None.
<b>Example</b>	OTN:RX1:FOLL TX
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:FOLLow?
<b>Description</b>	This query returns the receiver setup to follow another setup or not to follow.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:FOLL? → TX
<b>Note</b>	

#### 14.2.11 OTN:RX<Pt>:TP

<b>Syntax</b>	OTN:RX<Pt>:TP <route>,<tp>
<b>Description</b>	This command sets the TP to be used as the main received channel.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts <tp> = <NUMERIC PROGRAM DATA> ODTU01: TP: 1-2 ODTU12(Pt=0x20) TP: 1-4 ODTU12(Pt=0x21) TP: 1-4 ODTU21: TP: 1-8 ODTU2TS: TP: 1-8 ODTU13(Pt=0x20) TP: 1-16

continued on next page...

... continued from previous page

	ODTU13(Pt=0x21) TP: 1-16 ODTU23(Pt=0x20) TP: 1-4 ODTU23(Pt=0x21) TP: 1-4 ODTU31 TP: 1-32 ODTU3E28 TP: 1-4 ODTU2E3E1 TP: 1-32 ODTU3TS TP: 1-32 ODTU41 TP: 1-80 ODTU42 TP: 1-80 ODTU48 TP: 1-80 ODTU431 TP: 1-80 ODTU4TS TP: 1-80
<b>Response</b>	None
<b>Example</b>	OTN:RX1:TP ODTU01,1
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:TP? <route>
<b>Description</b>	This query returns the TP to be used as the main received channel.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts
<b>Response</b>	<tp> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RX1:TP? ODTU01 → 1
<b>Note</b>	

### 14.2.12 OTN:RX<Pt>:TS

<b>Syntax</b>	OTN:RX<Pt>:TS <route>,<ts>
<b>Description</b>	This command sets a set of TS(s) to be used as the main received channel.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1

continued on next page...

...continued from previous page

	ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts (<ts> {,<ts>}) = <EXPRESSION PROGRAM DATA> The format is listed for each parameter.
<b>Response</b>	None
<b>Example</b>	OTN:RX1:TS ODTU12, (1,2)
<b>Note</b>	ODTU01 TS : 1-2 will become the same value as TP. ODTU12 (PT=0x20) TS : 1-4 will become the same value as TP. ODTU12 (PT=0x21) TS1: 1-8, TS2: 1-8 TS2 must not overlap and TS1. ODTU2.1 TS: 1-8 ODTU2TS TS: 1-8 ODTU13(PT=0x20) TS: will become the same value as TP. ODTU13(PT=0x21) TS: 1-32 ODTU23(PT=0x20) TS: 1-16 ODTU23(PT=0x21) TS: 1-32 ODTU31 TS: 1-32 ODTU3E28 TS: 1-32 ODTU2E3E1 TS: 1-16 ODTU3TS TS: 1-32 ODTU41 TS: 1-80 ODTU42 TS: 1-80 ODTU48 TS: 1-80 ODTU431 TS: 1-80 ODTU4TS TS: 1-80

<b>Syntax</b>	OTN:RX<Pt>:TS? <route>
<b>Description</b>	This command returns a set of TS(s) to be used as the main received channel.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts
<b>Response</b>	(<ts> {,<ts>}) = <EXPRESSION RESPONSE DATA> The response format is listed for each parameter.
<b>Example</b>	OTN:RX1:TS? ODTU12 → 1,2
<b>Note</b>	

### 14.2.13 OTN:RX<Pt>:ODUFlex:TS

<b>Syntax</b>	OTN:RX<Pt>:ODUFlex:TS <ts>
<b>Description</b>	This command sets the size of a TS set to be used in ODUFlex.
<b>Parameters</b>	<Pt> = Port number

continued on next page...

... continued from previous page

	<ts> = <NUMERIC PROGRAM DATA> ODTU2.ts: PRBS/Ethernet: 1-8 ODTUk.ts: FC400: 4 ODTUk.ts: FC800: 7 ODTUk.ts - 3072M: 3 ODTUk.ts - 4915M: 4 ODTUk.ts - 6144M: 5 ODTUk.ts - 9830M: 8 ODTU3.ts - PRBS: 1-32 ODTU4.ts - PRBS: 1-80 ODTU3.ts - Ethernet: 1-32 ODTU4.ts - Ethernet: 1-80 ODTU3.ts - 10137M: 9 ODTU4.ts - 10137M: 8
<b>Response</b>	None
<b>Example</b>	OTN:RX1:ODUF:TS 1
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:ODUFlex:TS?
<b>Description</b>	This command returns the size of a TS set to be used in ODUflex.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<ts> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RX1:ODUF:TS? → 1
<b>Note</b>	

#### 14.2.14 OTN:RX<Pt>:TPTS:DETect

<b>Syntax</b>	OTN:RX<Pt>:TPTS:DETect <route>,<mode>
<b>Description</b>	This commands sets the TP and TS detection mode.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts <mode> = <CHARACTER PROGRAM DATA> MANual: Manual TPDetect: Auto Detect TP TSDetect: Auto Detect TS <i>DEFault = MANual</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:TPTS:DET ODTU12,MAN
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:TPTS:DETect? <route>
<b>Description</b>	This query returns the TP and TS detection mode.
<b>Parameters</b>	<Pt> = Port number <route> = <CHARACTER PROGRAM DATA> ODTU01: ODTU01 ODTU12: ODTU12 ODTU21: ODTU2.1 ODTU2TS: ODTU2.ts ODTU13: ODTU13 ODTU23: ODTU23 ODTU31: ODTU3.1 ODTU3E28: ODTU3e2.8 ODTU2E3E1: ODTU2e3e1 ODTU3TS: ODTU3.ts ODTU41: ODTU4.1 ODTU42: ODTU4.2 ODTU48: ODTU4.8 ODTU431: ODTU4.31 ODTU4TS: ODTU4.ts
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:TPTS:DET? ODTU12 → MAN
<b>Note</b>	

#### 14.2.15 OTN:RX<Pt>:MEAS:TTI:DET

<b>Syntax</b>	OTN:RX<Pt>:MEAS:TTI:DET <type>,<detection>
<b>Description</b>	This command sets TTI detection type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SM PM TCM1 TCM2 TCM3 TCM4 TCM5 TCM6 <detection> = <CHARACTER PROGRAM DATA> OFF: OFF SAPI: SAPI DAPI: DAPI SDAPI: SAPI and DAPI ALL: SAPI, DAPI and Operator Code <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:MEAS:TTI:DET TCM1,SDAPI
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:MEAS:TTI:DET? <type>
<b>Description</b>	This query returns TTI detection type.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> SM PM TCM1 TCM2 TCM3 TCM4 TCM5 TCM6
<b>Response</b>	<detection> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:RX1:MEAS:TTI:DET? TCM1 → SDAPI
<b>Note</b>	

## 14.3 Measurement Setup

### 14.3.1 OTN:TX<Pt>:MEAS:TTI:ENCoding

<b>Syntax</b>	OTN:TX<Pt>:MEAS:TTI:ENCoding <encoding>
<b>Description</b>	This command sets the TTI encoding standard.
<b>Parameters</b>	<Pt> = Port number <encoding> = <CHARACTER PROGRAM DATA> ITUT: ITU-T ANSI: ANSI <i>DEFault = ITUT</i>
<b>Response</b>	None
<b>Example</b>	OTN:TX1:MEAS:TTI:ENC ITUT
<b>Note</b>	

<b>Syntax</b>	OTN:TX<Pt>:MEAS:TTI:ENCoding?
<b>Description</b>	This query returns the TTI encoding standard.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<encoding> = <CHARACTER PROGRAM DATA>
<b>Example</b>	OTN:TX1:MEAS:TTI:ENC? → ITUT
<b>Note</b>	

### 14.3.2 OTN:RX<Pt>:MEAS:TCM:ENABle

<b>Syntax</b>	OTN:RX<Pt>:MEAS:TCM:ENABle <enable>
<b>Description</b>	This command enables or disables TCM measurement.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None
<b>Example</b>	OTN:RX1:MEAS:TCM:ENAB ON
<b>Note</b>	

<b>Syntax</b>	OTN:RX<Pt>:MEAS:TCM:ENABle?
<b>Description</b>	This query returns whether or not TCM measurement is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	OTN:RX1:MEAS:TCM:ENAB? → 1
<b>Note</b>	

## 14.3.3 MEASurement:SETup:OTN:RX&lt;Pt&gt;:MSIMdetection&lt;stage&gt;:SETup

<b>Syntax</b>	MEASurement:SETup:OTN:RX<Pt>:MSIMdetection<stage>:SETup <type>
<b>Description</b>	This command sets the MSIM detection type.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3) <type> = <CHARACTER PROGRAM DATA> NONE: None TXDATA: Use Tx OH preset PSI data RECEIVED: Use received PSI data <i>DEFault = NONE</i>
<b>Response</b>	None
<b>Example</b>	MEAS:SET:OTN:RX1:MSIM1:SET NONE
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:OTN:RX<Pt>:MSIMdetection<stage>:SETup?
<b>Description</b>	This query returns the MSIM detection type.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3)
<b>Response</b>	<type> = <CHARACTER PROGRAM DATA>
<b>Example</b>	MEAS:SET:OTN:RX1:MSIM1:SET? → NONE
<b>Note</b>	

## 14.3.4 MEASurement:SETup:OTN:RX&lt;Pt&gt;:MSIMdetection&lt;stage&gt;:MSIM?

<b>Syntax</b>	MEASurement:SETup:OTN:RX<Pt>:MSIMdetection<stage>:MSIM?
<b>Description</b>	This query returns the expected MSIM detection pattern.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-3)
<b>Response</b>	<value> = <HEXADECIMAL NUMERIC RESPONSE DATA> The MSIM detection pattern varies depending on the :MSIMdetection<stage>:SETup and the ODU type. ODTU01: PSI[2:3] ODTU12(PT20): PSI[2:5] ODTU12(PT21): PSI[2:9] ODTU21: PSI[2:9] ODTU13(PT20): PSI[2:17] ODTU13(PT21): PSI[2:33] ODTU23(PT20): PSI[2:17] ODTU23(PT20): PSI[2:33] ODTU31: PSI[2:33] ODTU3E28: PSI[2:33] ODTU2E3E1: PSI[2:17] ODTU3TS: PSI[2:33] ODTU41: PSI[2:81] ODTU42: PSI[2:81] ODTU48: PSI[2:81] ODTU431: PSI[2:81] ODTU4TS: PSI[2:81]
<b>Example</b>	MEAS:SET:OTN:RX1:MSIM1:MSIM? → 0
<b>Note</b>	

## 14.3.5 MEASurement:SETup:PERFormance:OTN:RX&lt;Pt&gt;:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for OTN. Enables/Disables the G.8201 or M.2401 performance evaluation.
<b>Parameters</b>	<Pt> = Port number <param> = <CHARACTER PROGRAM DATA> G8201: G.8201 M2401: M.2401/M.2110 <i>DEFault = M2401</i>
<b>Response</b>	None
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:PAR G8201
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:PARAmeter?
<b>Description</b>	This query returns the performance parameter for OTN.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:PAR? → G8201
<b>Note</b>	

## 14.3.6 MEASurement:SETup:PERFormance:OTN:RX&lt;Pt&gt;:ALLocation

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:ALLocation <path>,<percentage>
<b>Description</b>	This command sets the allocation percentage for M.2401/M.2110.
<b>Parameters</b>	<Pt> = Port number <path> = <CHARACTER PROGRAM DATA> OTU: ODU: TCMi: i = 1 - 6 <i>DEFault = OTU</i> <number> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=100.00</i>
<b>Response</b>	None
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:ALL OTU,0
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:ALLocation? <path>
<b>Description</b>	This query returns the allocation percentage for M.2401/M.2110.
<b>Parameters</b>	<Pt> = Port number <path> = <CHARACTER RESPONSE DATA>
<b>Response</b>	<percentage> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:ALL? OTU → 0.00
<b>Note</b>	

## 14.3.7 MEASurement:SETup:PERFormance:OTN:TPERiod

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:TPERiod <period>
<b>Description</b>	This command sets the evaluation period for OTN. For M.2401/M.2110.
<b>Parameter</b>	<period> = <CHARACTER PROGRAM DATA> 15M: 15 minutes 1H: 1 hour 2H: 2 hours 24H: 24 hours 7D: 7 days <i>DEFault = 15M</i>
<b>Response</b>	None
<b>Example</b>	MEAS:SET:PERF:OTN:TPER 15M
<b>Note</b>	



<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:TPERiod?
<b>Description</b>	This query returns the evaluation item for OTN. For M.2401/M.2110.
<b>Response</b>	<period> = <CHARACTER RESPONSE DATA> 15M: 15 minutes 1H: 1 hour 2H: 2 hours 24H: 24 hours 7D: 7 days
<b>Example</b>	MEAS:SET:PERF:OTN:TPER? → 15M
<b>Note</b>	

### 14.3.8 MEASurement:SETup:PERFormance:OTN:RX<Pt>:OBJectives

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:OBJectives <sesr>,<bber>
<b>Description</b>	This command sets the Performance Objectives.
<b>Parameters</b>	<Pt> = Port number <sesr> = <NUMERIC PROGRAM DATA> 0.01E-8 to 9.99E-1, default is 1.00E-1 <bber> = <NUMERIC PROGRAM DATA> 0.01E-8 to 9.99E-1, default is 1.00E-1
<b>Response</b>	None
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:OBJ 1.00E-1,1.00E-1
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:OTN:RX<Pt>:OBJectives?
<b>Description</b>	This query returns the Performance Objectives.
<b>Parameter</b>	<Pt> = Port number
<b>Responses</b>	<sser> = <NR3 NUMERIC RESPONSE DATA> <bber> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:OTN:RX1:OBJ? → 1.00E-1,1.00E-1
<b>Note</b>	

## 14.4 Result

### 14.4.1 OTN:RX<Pt>:IFETch?

<b>Syntax</b>	OTN:RX<Pt>:IFETch? <parameter>
<b>Description</b>	This query returns the results of item specified by the parameter.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>({&lt;parameter&gt;} + {, }*) = &lt;EXPRESSION PROGRAM DATA&gt;</p> <p>The response format is listed for each parameter.</p> <p><b>LLD<sup>1</sup></b>  LOFLLD: LOF Lane  OOFLLD: OOF  FASLLD: FAS LLD  MFASLLD: MFAS LLD  LLMLLD: LLM LLD  LOR: LOR  OOR: OOR  OLA: OLA  MMAP: Marker Map  RSKEW: Relative Skew</p> <p><b>OTU</b>  LOS: LOS  LOF: LOF  LOM: LOM  OOF: OOF  FAS: FAS  OOM: OOM  MFAS: MFAS  FECC: FEC-Correctable  FECU: FEC-Uncorrectable  SMTIM: SM-TIM  SMBIAE: SM-BIAE  SMBDI: SM-BDI  SMIAE: SM-IAE  SMBIP8: SM-BIP8  SMBEI: SM-BEI  AIS: AIS  OCI: OCI  LCK: LCK  PMTIM: PM-TIM  PMBDI: PM-BDI  PMBIP8: PM-BIP8  PMBEI: PM-BEI</p> <p><b>Stage n ODU (n = 0-3)</b>  SnLOFLOM: Stage n LOFLOM  SnOOF: Stage n OOF  SnFAS: Stage n FAS  SnOOM: Stage n OOM  SnMFAS: Stage n MFAS  SnAIS: Stage n AIS  SnOCI: Stage n OCI  SnLCK: Stage n LCK  SnPMTIM: Stage n PM-TIM  SnPMBDI: Stage n PM-BDI  SnPMBIP8: Stage n PM-BIP8</p>

continued on next page...

... continued from previous page

SnPMBEI: Stage n PM-BEI  
 SnPLM: Stage n PLM  
 SnFSF: Stage n FSF  
 SnFSD: Stage n FSD  
 SnBSF: Stage n BSF  
 SnBSD: Stage n BSD  
 SnMSIM: Stage n MSIM

**Client**  
 AISC: Client-AIS  
 CSF: CSF  
 LSS: LSS  
 PRBSBIT: PRBS Bit Error  
 CFREQ: Client frequency  
 COFFS: Client frequency offset

**High-order ODU TCM (i = 1-6)**  
 TCMiTIM: TCMi-TIM  
 TCMiBIAE: TCMi-BIAE  
 TCMiBDI: TCMi-BDI  
 TCMiIAE: TCMi-IAE  
 TCMiLTC: TCMi-LTC  
 TCMiBIP8: TCMi-BIP8  
 TCMiBEI: TCMi-BEI

**Stage n Justification (n = 0-2)**  
 SnFREQ: Stage n Frequency deviation  
 SnINC: Stage n Inc  
 SnINC1: Stage n Inc >1  
 SnINC2: Stage n Inc >2  
 SnDEC: Stage n Dec  
 SnDEC1: Stage n Dec >1  
 SnDEC2: Stage n Dec >2  
 SnINCO: Stage n Inc Over  
 SnDECO: Stage n Dec Over  
 SnCRC8: Stage n CRC8 Error  
 SnCRC5: Stage n CRC5 Error  
 SnCMMIN: Stage n Cm(t) Minimum  
 SnCMMAX: Stage n Cm(t) Maximum  
 SnPJC: Stage n PJC  
 SnPJC2: Stage n 2PJC  
 SnPJC3: Stage n 3PJC  
 SnNJC: Stage n NJC  
 SnNJC2: Stage n 2NJC

**GFP**  
 GTFR: GFP-F Total Frame  
 GIFR: GFP-F Idle Frame  
 GCFR: GFP-F Client Frame  
 GSSF: GFP-F SSF  
 GCMFSIG: GFP-F CMF Loss of Signal  
 GCMFSYNC: GFP-F CMF Loss of Sync  
 GFCS: GFP-F FCS Error  
 GCHECC: GFP-F/T cHEC correctable errors  
 GCHECU: GFP-F/T cHEC uncorrectable errors  
 GTHECC: GFP-F/T tHEC correctable errors  
 GTHECU: GFP-F/T tHEC uncorrectable errors

continued on next page...

... continued from previous page

	<p>GEHECC: GFP-F eHEC correctable errors  GEHECU: GFP-F eHEC uncorrectable errors  GIGFR: GFP-T Invalid GFP Frame  GSCRC: GFP-T Superblock CRC Error  GCSFSIG: GFP-T CSF Signal  GCSFSYNC: GFP-T CSF Sync  GPTI: GFP-F PTI Mismatch  GUPI: GFP-F UPI Mismatch  GTTFR: GFP-F Tx Total Frame  GTIFR: GFP-F Tx Idle Frame  GTCFR: GFP-F Tx Client Frame  GTCMF: GFP-F Tx CMF</p> <p><b>OTU Performance</b>  NSTAT, FSTAT: Near-end/Far-end Status. Response: &lt;STRING&gt;  NSES, FSES: Near-end/Far-end SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  NBBE, FBBE: Near-end/Far-end BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  NUAS, FUAS: Near-end/Far-end UAS. Response: &lt;Count&gt;</p> <p><b>Stage n ODU Performance (n = 0-3)</b>  SnNSTAT, SnFSTAT, SnBSTAT:  Near-end/Far-end/Bidirectional Status. Response: &lt;STRING&gt;  SnNSES, SnFSES, SnBSES:  Near-end/Far-end/Bidirectional SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  SnNBBE, SnFBBE, SnBBBE:  Near-end/Far-end/Bidirectional BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  SnNUAS, SnFUAS, SnBUAS:  Near-end/Far-end/Bidirectional UAS. Response: &lt;Count&gt;</p> <p><b>High-order ODU TCMi Performance (i = 1-6)</b>  TCMiNSTAT, TCMiFSTAT, TCMiBSTAT:  Near-end/Far-end/Bidirectional Status. Response: &lt;STRING&gt;  TCMiNSES, TCMiFSES, TCMiBSES:  Near-end/Far-end/Bidirectional SES. Response: &lt;Count&gt;,&lt;Ratio%&gt;  TCMiNBBE, TCMiFBBE, TCMiBBBE:  Near-end/Far-end/Bidirectional BBE. Response: &lt;Count&gt;,&lt;Ratio%&gt;  TCMiNUAS, TCMiFUAS, TCMiBUAS:  Near-end/Far-end/Bidirectional UAS. Response: &lt;Count&gt;</p>
<b>Response</b>	<p>{(&lt;result&gt;),}* = &lt;EXPRESSION RESPONSE DATA&gt;  Format: Numeric List  Each result is formatted according to the specification in the parameter field.  Values that are not relevant or applicable for the current measurement return NaN (section 1.6.1).</p>
<b>Example</b>	<p>OTN:RX1:IFET? (LOS,LOF,00F) → (3,0.00532),(4,0.00709),(5,0.00887)</p>
<b>Notes</b>	<p>This command fetches the results from the interval selected using the MEASurement:SEtup:SElect command (see section 17.2.2).  <sup>1</sup> Results are only available at OTU3/4.  If the requested result is not available, NaN (section 1.6.1) is returned.  If there is one or more results, the last ”,” is always removed.</p>

## 14.5 Status

### 14.5.1 OTN:STATus:RX<Pt>:AESummary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the alarms and errors summary event register. The content of this event register is summarized in DB8 of the STATus:INTerface:PORT<Pt>:EVENT register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 (16) Alarm section 5 summary DB6 (32) Alarm section 6 summary DB7 (64) Alarm section 7 summary DB8 (128) Alarm section 8 summary DB9 (256) Alarm section 9 summary DB10 (512) Alarm section 10 summary DB11 (1024) Error section 1 summary DB12 (2048) Error section 2 summary DB13 (4096) Error section 3 summary DB14 (8192) Error section 4 summary DB15 (16384) Error section 5 summary DB16 (32768) Error section 6 summary
<b>Example</b>	OTN:STAT:RX1:AES? → 65
<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]?

### 14.5.2 OTN:STATus:RX<Pt>:AESummary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary condition register. The content of this event register is summarized in DB8 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 (16) Alarm section 5 summary DB6 (32) Alarm section 6 summary DB7 (64) Alarm section 7 summary DB8 (128) Alarm section 8 summary DB9 (256) Alarm section 9 summary DB10 (512) Alarm section 10 summary DB11 (1024) Error section 1 summary DB12 (2048) Error section 2 summary DB13 (4096) Error section 3 summary DB14 (8192) Error section 4 summary DB15 (16384) Error section 5 summary DB16 (32768) Error section 6 summary
<b>Example</b>	OTN:STAT:RX1:AES:COND? → 1024
<b>Note</b>	

continued on next page...

... continued from previous page

<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition?
-------------	---

### 14.5.3 OTN:STATus:RX<Pt>:ALARm<section>[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the alarms event register. The content of this register is summarized in DB1 through DB10 of the OTN:STATus:RX<Pt>:AESummary:Event register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-10)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.18
<b>Example</b>	OTN:STAT:RX1:ALAR5? → 92
<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? OTN:STATus:RX<Pt>:OTU:ASUMmary[:EVENT]? OTN:STATus:RX<Pt>:SONE:ASUMmary[:EVENT]? OTN:STATus:RX<Pt>:STWO:ASUMmary[:EVENT]? OTN:STATus:RX<Pt>:STHRee:ASUMmary[:EVENT]? OTN:STATus:RX<Pt>:CLIent:ASUMmary[:EVENT]? OTN:STATus:RX<Pt>:OTU:ALARm<section>[:EVENT]? OTN:STATus:RX<Pt>:SONE:ALARm<section>[:EVENT]? OTN:STATus:RX<Pt>:STWO:ALARm<section>[:EVENT]? OTN:STATus:RX<Pt>:STHRee:ALARm<section>[:EVENT]? OTN:STATus:RX<Pt>:CLIent:ALARm<section>[:EVENT]?

### 14.5.4 OTN:STATus:RX<Pt>:ALARm<section>:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:ALARm<section>:CONDition?
<b>Description</b>	This query returns the alarms condition register query.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-10)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.18
<b>Example</b>	OTN:STAT:RX1:ALAR5:COND? → 0
<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? OTN:STATus:RX<Pt>:OTU:ASUMmary:CONDition? OTN:STATus:RX<Pt>:SONE:ASUMmary:CONDition? OTN:STATus:RX<Pt>:STWO:ASUMmary:CONDition? OTN:STATus:RX<Pt>:STHRee:ASUMmary:CONDition? OTN:STATus:RX<Pt>:CLIent:ASUMmary:CONDition? OTN:STATus:RX<Pt>:OTU:ALARm<section>:CONDition? OTN:STATus:RX<Pt>:SONE:ALARm<section>:CONDition? OTN:STATus:RX<Pt>:STWO:ALARm<section>:CONDition? OTN:STATus:RX<Pt>:STHRee:ALARm<section>:CONDition? OTN:STATus:RX<Pt>:CLIent:ALARm<section>:CONDition?

Table 14.18: Alarm Items

OTU/ODU Section	1	2	3	4
<b>DB1 (1)</b>	LOS	TCM1-TIM	TCM5-BDI	Client-AIS
<b>DB2 (2)</b>	OTU-AIS	TCM2-TIM	TCM6-BDI	CSF
<b>DB3 (4)</b>	LOF	TCM3-TIM	TCM1-IAE	LSS
<b>DB4 (8)</b>	OOF	TCM4-TIM	TCM2-IAE	LOF-LLD
<b>DB5 (16)</b>	LOM	TCM5-TIM	TCM3-IAE	OOF-LLD
<b>DB6 (32)</b>	OOM	TCM6-TIM	TCM4-IAE	LOR-LLD
<b>DB7 (64)</b>	SM-TIM	TCM1-BIAE	TCM5-IAE	OOR-LLD
<b>DB8 (128)</b>	SM-BIAE	TCM2-BIAE	TCM6-IAE	Not used
<b>DB9 (256)</b>	SM-BDI	TCM3-BIAE	TCM1-LTC	Not used
<b>DB10 (512)</b>	SM-IAE	TCM4-BIAE	TCM2-LTC	Not used
<b>DB11 (1024)</b>	ODU-AIS	TCM5-BIAE	TCM3-LTC	Not used
<b>DB12 (2048)</b>	ODU-LCK	TCM6-BIAE	TCM4-LTC	Not used
<b>DB13 (4096)</b>	ODU-OCI	TCM1-BDI	TCM5-LTC	Not used
<b>DB14 (8192)</b>	PM-TIM	TCM2-BDI	TCM6-LTC	Not used
<b>DB15 (16384)</b>	PM-BDI	TCM3-BDI	PLM	Not used
<b>DB16 (32768)</b>		TCM4-BDI	MSIM	Not used
Stage 1 Section	5	6	7	
<b>DB1 (1)</b>	LOFLOM	TCM3-BIAE	TCM1-LTC	
<b>DB2 (2)</b>	OOF	TCM4-BIAE	TCM2-LTC	
<b>DB3 (4)</b>	OOM	TCM5-BIAE	TCM3-LTC	
<b>DB4 (8)</b>	ODU-AIS	TCM6-BIAE	TCM4-LTC	
<b>DB5 (16)</b>	ODU-LCK	TCM1-BDI	TCM5-LTC	
<b>DB6 (32)</b>	ODU-OCI	TCM2-BDI	TCM6-LTC	
<b>DB7 (64)</b>	PM-TIM	TCM3-BDI	PLM	
<b>DB8 (128)</b>	PM-BDI	TCM4-BDI	Client-AIS	
<b>DB9 (256)</b>	TCM1-TIM	TCM5-BDI	CSF	
<b>DB10 (512)</b>	TCM2-TIM	TCM6-BDI	MSIM	
<b>DB11 (1024)</b>	TCM3-TIM	TCM1-IAE	Not used	
<b>DB12 (2048)</b>	TCM4-TIM	TCM2-IAE	Not used	
<b>DB13 (4096)</b>	TCM5-TIM	TCM3-IAE	Not used	
<b>DB14 (8192)</b>	TCM6-TIM	TCM4-IAE	Not used	
<b>DB15 (16384)</b>	TCM1-BIAE	TCM5-IAE	Not used	
<b>DB16 (32768)</b>	TCM2-BIAE	TCM6-IAE	Not used	
Stage 2 Section	8	9	10	
<b>DB1 (1)</b>	LOFLOM	TCM3-BIAE	TCM1-LTC	
<b>DB2 (2)</b>	OOF	TCM4-BIAE	TCM2-LTC	
<b>DB3 (4)</b>	OOM	TCM5-BIAE	TCM3-LTC	
<b>DB4 (8)</b>	ODU-AIS	TCM6-BIAE	TCM4-LTC	
<b>DB5 (16)</b>	ODU-LCK	TCM1-BDI	TCM5-LTC	
<b>DB6 (32)</b>	ODU-OCI	TCM2-BDI	TCM6-LTC	
<b>DB7 (64)</b>	PM-TIM	TCM3-BDI	PLM	
<b>DB8 (128)</b>	PM-BDI	TCM4-BDI	Client-AIS	
<b>DB9 (256)</b>	TCM1-TIM	TCM5-BDI	CSF	
<b>DB10 (512)</b>	TCM2-TIM	TCM6-BDI	Not used	
<b>DB11 (1024)</b>	TCM3-TIM	TCM1-IAE	Not used	
<b>DB12 (2048)</b>	TCM4-TIM	TCM2-IAE	Not used	
<b>DB13 (4096)</b>	TCM5-TIM	TCM3-IAE	Not used	
<b>DB14 (8192)</b>	TCM6-TIM	TCM4-IAE	Not used	
<b>DB15 (16384)</b>	TCM1-BIAE	TCM5-IAE	Not used	
<b>DB16 (32768)</b>	TCM2-BIAE	TCM6-IAE	Not used	

## 14.5.5 OTN:STATUS:RX&lt;Pt&gt;:ERROR&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:ERROR<section>[:EVENT]?
<b>Description</b>	This query returns the errors event register. The content of this register is summarized in DB11 through DB16 of the OTN:STATUS:RX<Pt>:AESummary:Event register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-6)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.19
<b>Response</b>	
<b>Example</b>	OTN:STAT:RX1:ERR1? → 0
<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATUS:RX<Pt>:MSTage:AESummary[:EVENT]? OTN:STATUS:RX<Pt>:OTU:ESUMmary[:EVENT]? OTN:STATUS:RX<Pt>:SONE:ESUMmary[:EVENT]? OTN:STATUS:RX<Pt>:STWO:ESUMmary[:EVENT]? OTN:STATUS:RX<Pt>:STHRee:ESUMmary[:EVENT]? OTN:STATUS:RX<Pt>:CLient:ESUMmary[:EVENT]? OTN:STATUS:RX<Pt>:OTU:ERRor<section>[:EVENT]? OTN:STATUS:RX<Pt>:SONE:ERRor<section>[:EVENT]? OTN:STATUS:RX<Pt>:STWO:ERRor<section>[:EVENT]? OTN:STATUS:RX<Pt>:STHRee:ERRor<section>[:EVENT]? OTN:STATUS:RX<Pt>:CLient:ERRor<section>[:EVENT]?

## 14.5.6 OTN:STATUS:RX&lt;Pt&gt;:ERROR&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:ERROR<section>:CONDition?
<b>Description</b>	This query returns the errors condition register query.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-6)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.19
<b>Example</b>	OTN:STAT:RX1:ERR1:COND? → 0
<b>Note</b>	This command is for compatibility of V2.xx or V1.xx. Following commands are endorsed on V3.00 or later. OTN:STATUS:RX<Pt>:MSTage:AESummary:CONDition? OTN:STATUS:RX<Pt>:OTU:ESUMmary:CONDition? OTN:STATUS:RX<Pt>:SONE:ESUMmary:CONDition? OTN:STATUS:RX<Pt>:STWO:ESUMmary:CONDition? OTN:STATUS:RX<Pt>:STHRee:ESUMmary:CONDition? OTN:STATUS:RX<Pt>:CLient:ESUMmary:CONDition? OTN:STATUS:RX<Pt>:OTU:ERRor<section>:CONDition? OTN:STATUS:RX<Pt>:SONE:ERRor<section>:CONDition? OTN:STATUS:RX<Pt>:STWO:ERRor<section>:CONDition? OTN:STATUS:RX<Pt>:STHRee:ERRor<section>:CONDition? OTN:STATUS:RX<Pt>:CLient:ERRor<section>:CONDition?



Table 14.19: Error Items

OTU/ODU Section	1	2
<b>DB1 (1)</b>	FAS	TCM3-BEI
<b>DB2 (2)</b>	MFAS	TCM4-BEI
<b>DB3 (4)</b>	SM-BIP8	TCM5-BEI
<b>DB4 (8)</b>	SM-BEI	TCM6-BEI
<b>DB5 (16)</b>	FCE	CRC8 Error
<b>DB6 (32)</b>	FUEB	CRC5 Error
<b>DB7 (64)</b>	PM-BIP8	FAS-LLD
<b>DB8 (128)</b>	PM-BEI	ILA/OLA
<b>DB9 (256)</b>	TCM1-BIP8	MFAS LLD
<b>DB10 (512)</b>	TCM2-BIP8	LLM LLD
<b>DB11 (1024)</b>	TCM3-BIP8	Not used
<b>DB12 (2048)</b>	TCM4-BIP8	Not used
<b>DB13 (4096)</b>	TCM5-BIP8	Not used
<b>DB14 (8192)</b>	TCM6-BIP8	Not used
<b>DB15 (16384)</b>	TCM1-BEI	Not used
<b>DB16 (32768)</b>	TCM2-BEI	Not used
Stage 1 Section	3	4
<b>DB1 (1)</b>	FAS	CRC5 Error
<b>DB2 (2)</b>	PM-BIP8	Not used
<b>DB3 (4)</b>	PM-BEI	Not used
<b>DB4 (8)</b>	TCM1-BIP8	Not used
<b>DB5 (16)</b>	TCM2-BIP8	Not used
<b>DB6 (32)</b>	TCM3-BIP8	Not used
<b>DB7 (64)</b>	TCM4-BIP8	Not used
<b>DB8 (128)</b>	TCM5-BIP8	Not used
<b>DB9 (256)</b>	TCM6-BIP8	Not used
<b>DB10 (512)</b>	TCM1-BEI	Not used
<b>DB11 (1024)</b>	TCM2-BEI	Not used
<b>DB12 (2048)</b>	TCM3-BEI	Not used
<b>DB13 (4096)</b>	TCM4-BEI	Not used
<b>DB14 (8192)</b>	TCM5-BEI	Not used
<b>DB15 (16384)</b>	TCM6-BEI	Not used
<b>DB16 (32768)</b>	CRC8 Error	Not used
Stage 2 Section	5	6
<b>DB1 (1)</b>	FAS	cHEC correctable
<b>DB2 (2)</b>	PM-BIP8	cHEC uncorrectable
<b>DB3 (4)</b>	PM-BEI	tHEC correctable
<b>DB4 (8)</b>	TCM1-BIP8	tHEC uncorrectable
<b>DB5 (16)</b>	TCM2-BIP8	Invalid GFP Frame
<b>DB6 (32)</b>	TCM3-BIP8	Superblock CRC
<b>DB7 (64)</b>	TCM4-BIP8	CSF Signal
<b>DB8 (128)</b>	TCM5-BIP8	CSF Sync
<b>DB9 (256)</b>	TCM6-BIP8	Not used
<b>DB10 (512)</b>	TCM1-BEI	Not used
<b>DB11 (1024)</b>	TCM2-BEI	Not used
<b>DB12 (2048)</b>	TCM3-BEI	Not used
<b>DB13 (4096)</b>	TCM4-BEI	Not used
<b>DB14 (8192)</b>	TCM5-BEI	Not used
<b>DB15 (16384)</b>	TCM6-BEI	Not used
<b>DB16 (32768)</b>	PRBS Bit Error	Not used

## 14.5.7 OTN:STATus:RX&lt;Pt&gt;:MSTage:AESummary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]?
<b>Description</b>	This query returns the alarms and errors summary event register. The content of this event register is summarized in DB8 of the STATus:INTerface:PORT<Pt>[:EVENT] register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) OTU Alarm summary DB2 (2) Stage 1 Alarm summary DB3 (4) Stage 2 Alarm summary DB4 (8) Stage 3 Alarm summary DB5 - DB7 NOT USED DB8 (128) Client Alarm summary DB9 (256) OTU Error summary DB10 (512) Stage 1 Error summary DB11 (1024) Stage 2 Error summary DB12 (2048) Stage 3 Error summary DB13 - DB15 NOT USED DB16 (32768) Client Error summary
<b>Example</b>	OTN:STAT:RX1:MST:AES? → 65
<b>Note</b>	

## 14.5.8 OTN:STATus:RX&lt;Pt&gt;:MSTage:AESummary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition?
<b>Description</b>	This query returns alarms and errors summary condition register. The content of this event register is summarized in DB8 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) OTU Alarm summary DB2 (2) Stage 1 Alarm summary DB3 (4) Stage 2 Alarm summary DB4 (8) Stage 3 Alarm summary DB5 - DB7 NOT USED DB8 (128) Client Alarm summary DB9 (256) OTU Error summary DB10 (512) Stage 1 Error summary DB11 (1024) Stage 2 Error summary DB12 (2048) Stage 3 Error summary DB13 - DB15 NOT USED DB16 (32768) Client Error summary
<b>Example</b>	OTN:STAT:RX1:MST:AES:COND? → 1024
<b>Note</b>	

## 14.5.9 OTN:STATus:RX&lt;Pt&gt;:OTU:ASUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ASUMmary[:EVENT]?
<b>Description</b>	This query returns the OTU alarms summary event register. The content of this register is summarized in DB1 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB8 NOT USED DB9 (256) Alarm section 9 summary DB10 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:OTU:ASUM? → 14
<b>Note</b>	

## 14.5.10 OTN:STATus:RX&lt;Pt&gt;:OTU:ASUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ASUMmary:CONDition?
<b>Description</b>	This query returns OTU alarms summary condition register. The content of this register is summarized in DB1 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB8 NOT USED DB9 (256) Alarm section 9 summary DB10 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:OTU:ASUM:COND? → 12
<b>Note</b>	

## 14.5.11 OTN:STATus:RX&lt;Pt&gt;:OTU:ESUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ESUMmary[:EVENT]?
<b>Description</b>	This query returns the OTU errors summary event register. The content of this event register is summarized in DB9 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB8 NOT USED DB9 (256) Error section 9 summary DB10 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:OTU:ESUM? → 14
<b>Note</b>	

## 14.5.12 OTN:STATus:RX&lt;Pt&gt;:OTU:ESUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ESUMmary:CONDition?
<b>Description</b>	This query returns OTU errors summary condition register. The content of this event register is summarized in DB9 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB8 NOT USED DB9 (256) Error section 9 summary DB10 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:OTU:ESUM:COND? → 12
<b>Note</b>	

## 14.5.13 OTN:STATus:RX&lt;Pt&gt;:OTU:ALARm&lt;section&gt;[:EVENTt]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ALARm<section>[:EVENTt]?
<b>Description</b>	This query returns the OTU alarms event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:OTU:ASUMmary[:EVENTt]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.20
<b>Example</b>	OTN:STAT:RX1:OTU:ALAR5? → 92
<b>Note</b>	

## 14.5.14 OTN:STATus:RX&lt;Pt&gt;:OTU:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ALARm<section>:CONDition?
<b>Description</b>	This query returns the OTU alarms condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:OTU:ASUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.20
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:OTU:ALAR5:COND? → 0
<b>Note</b>	

Table 14.20: Alarm Items

OTU/ODU Section	1	2	3	4
<b>DB1 (1)</b>	LOS	TCM1-TIM	TCM5-BDI	FSF
<b>DB2 (2)</b>	OTU-AIS	TCM2-TIM	TCM6-BDI	FSD
<b>DB3 (4)</b>	LOF	TCM3-TIM	TCM1-IAE	BSF
<b>DB4 (8)</b>	OOF	TCM4-TIM	TCM2-IAE	BSD
<b>DB5 (16)</b>	LOM	TCM5-TIM	TCM3-IAE	Not used
<b>DB6 (32)</b>	OOM	TCM6-TIM	TCM4-IAE	Not used
<b>DB7 (64)</b>	SM-TIM	TCM1-BIAE	TCM5-IAE	Not used
<b>DB8 (128)</b>	SM-BIAE	TCM2-BIAE	TCM6-IAE	Not used
<b>DB9 (256)</b>	SM-BDI	TCM3-BIAE	TCM1-LTC	Not used
<b>DB10 (512)</b>	SM-IAE	TCM4-BIAE	TCM2-LTC	Not used
<b>DB11 (1024)</b>	ODU-AIS	TCM5-BIAE	TCM3-LTC	Not used
<b>DB12 (2048)</b>	ODU-LCK	TCM6-BIAE	TCM4-LTC	Not used
<b>DB13 (4096)</b>	ODU-OCI	TCM1-BDI	TCM5-LTC	Not used
<b>DB14 (8192)</b>	PM-TIM	TCM2-BDI	TCM6-LTC	Not used
<b>DB15 (16384)</b>	PM-BDI	TCM3-BDI	PLM	Not used
<b>DB16 (32768)</b>	Not used	TCM4-BDI	MSIM	Not used
OTL Section	5-8	9		
<b>DB1 (1)</b>	Not used	ILA/OLA		
<b>DB2 (2)</b>	Not used	LOF-OTL		
<b>DB3 (4)</b>	Not used	OOF-OTL		
<b>DB4 (8)</b>	Not used	LOR-OTL		
<b>DB5 (16)</b>	Not used	OOR-OTL		
<b>DB6 (32)</b>	Not used	Not used		
<b>DB7 (64)</b>	Not used	Not used		
<b>DB8 (128)</b>	Not used	Not used		
<b>DB9 (256)</b>	Not used	Not used		
<b>DB10 (512)</b>	Not used	Not used		
<b>DB11 (1024)</b>	Not used	Not used		
<b>DB12 (2048)</b>	Not used	Not used		
<b>DB13 (4096)</b>	Not used	Not used		
<b>DB14 (8192)</b>	Not used	Not used		
<b>DB15 (16384)</b>	Not used	Not used		
<b>DB16 (32768)</b>	Not used	Not used		

#### 14.5.15 OTN:STATus:RX<Pt>:OTU:ERRor<section>[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the OTU errors event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:OTU:ESUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.21
<b>Response</b>	
<b>Example</b>	OTN:STAT:RX1:OTU:ERR1? → 0
<b>Note</b>	

Table 14.21: Error Items

OTU/ODU Section	1	2
DB1 (1)	FAS	TCM3-BEI
DB2 (2)	MFAS	TCM4-BEI
DB3 (4)	SM-BIP8	TCM5-BEI
DB4 (8)	SM-BEI	TCM6-BEI
DB5 (16)	FEC Correctable	CRC8 Error
DB6 (32)	FEC Uncorrectable	CRC5 Error
DB7 (64)	PM-BIP8	Not used
DB8 (128)	PM-BEI	Not used
DB9 (256)	TCM1-BIP8	Not used
DB10 (512)	TCM2-BIP8	Not used
DB11 (1024)	TCM3-BIP8	Not used
DB12 (2048)	TCM4-BIP8	Not used
DB13 (4096)	TCM5-BIP8	Not used
DB14 (8192)	TCM6-BIP8	Not used
DB15 (16384)	TCM1-BEI	Not used
DB16 (32768)	TCM2-BEI	Not used
OTL Section	3-8	9
DB1 (1)	Not used	FAS-OTL
DB2 (2)	Not used	MFAS-OTL
DB3 (4)	Not used	LLM-OTL
DB4 (8)	Not used	Not used
DB5 (16)	Not used	Not used
DB6 (32)	Not used	Not used
DB7 (64)	Not used	Not used
DB8 (128)	Not used	Not used
DB9 (256)	Not used	Not used
DB10 (512)	Not used	Not used
DB11 (1024)	Not used	Not used
DB12 (2048)	Not used	Not used
DB13 (4096)	Not used	Not used
DB14 (8192)	Not used	Not used
DB15 (16384)	Not used	Not used
DB16 (32768)	Not used	Not used

#### 14.5.16 OTN:STATus:RX<Pt>:OTU:ERRor<section>:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:OTU:ERRor<section>:CONDition?
<b>Description</b>	This query returns the OTU errors condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:OTU:ESUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.21
<b>Example</b>	OTN:STAT:RX1:OTU:ERR1:COND? → 0
<b>Note</b>	

## 14.5.17 OTN:STATus:RX&lt;Pt&gt;:SONE:ASUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ASUMmary[:EVENT]?
<b>Description</b>	This query returns the stage1 ODU alarms summary event register. The content of this event register is summarized in DB2 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:SONE:ASUM? → 6
<b>Note</b>	

## 14.5.18 OTN:STATus:RX&lt;Pt&gt;:SONE:ASUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ASUMmary:CONDition?
<b>Description</b>	This query returns stage1 ODU alarms summary condition register. The content of this event register is summarized in DB2 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:SONE:ASUM:COND? → 3
<b>Note</b>	

## 14.5.19 OTN:STATus:RX&lt;Pt&gt;:SONE:ESUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ESUMmary[:EVENT]?
<b>Description</b>	This query returns the stage1 ODU errors summary event register. The content of this event register is summarized in DB10 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:SONE:ESUM? → 6
<b>Note</b>	

## 14.5.20 OTN:STATus:RX&lt;Pt&gt;:SONE:ESUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ESUMmary:CONDition?
<b>Description</b>	This query returns stage1 ODU errors summary condition register. The content of this event register is summarized in DB10 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:SONE:ESUM:COND? → 3
<b>Note</b>	

## 14.5.21 OTN:STATus:RX&lt;Pt&gt;:SONE:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the stage1 ODU alarms event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:SONE:ASUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Example</b>	OTN:STAT:RX1:SONE:ALAR4? → 1
<b>Note</b>	

## 14.5.22 OTN:STATus:RX&lt;Pt&gt;:SONE:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ALARm<section>:CONDition?
<b>Description</b>	This query returns the stage1 ODU alarms condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:SONE:ASUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:SONE:ALAR5:COND? → 0
<b>Note</b>	

## 14.5.23 OTN:STATus:RX&lt;Pt&gt;:SONE:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the stage1 ODU errors event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:SONE:ESUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Response</b>	
<b>Example</b>	OTN:STAT:RX1:SONE:ERR1? → 0
<b>Note</b>	



Table 14.22: Alarm Items

ODU Section	1	2	3	4
DB1 (1)	Not used	Not used	Not used	FSF
DB2 (2)	Not used	Not used	Not used	FSD
DB3 (4)	LOFLOM	Not used	Not used	BSF
DB4 (8)	OOF	Not used	Not used	BSD
DB5 (16)	Not used	Not used	Not used	Not used
DB6 (32)	OOM	Not used	Not used	Not used
DB7 (64)	Not used	Not used	Not used	Not used
DB8 (128)	Not used	Not used	Not used	Not used
DB9 (256)	Not used	Not used	Not used	Not used
DB10 (512)	Not used	Not used	Not used	Not used
DB11 (1024)	ODU-AIS	Not used	Not used	Not used
DB12 (2048)	ODU-LCK	Not used	Not used	Not used
DB13 (4096)	ODU-OCI	Not used	Not used	Not used
DB14 (8192)	PM-TIM	Not used	Not used	Not used
DB15 (16384)	PM-BDI	Not used	PLM	Not used
DB16 (32768)	Not used	Not used	MSIM	Not used

Table 14.23: Error Items

ODU Section	1	2
DB1 (1)	FAS	Not used
DB2 (2)	Not used	Not used
DB3 (4)	Not used	Not used
DB4 (8)	Not used	Not used
DB5 (16)	Not used	CRC8 Error
DB6 (32)	Not used	CRC5 Error
DB7 (64)	PM-BIP8	Not used
DB8 (128)	PM-BEI	Not used
DB9 (256)	Not used	Not used
DB10 (512)	Not used	Not used
DB11 (1024)	Not used	Not used
DB12 (2048)	Not used	Not used
DB13 (4096)	Not used	Not used
DB14 (8192)	Not used	Not used
DB15 (16384)	Not used	Not used
DB16 (32768)	Not used	Not used

#### 14.5.24 OTN:STATus:RX<Pt>:SONE:ERRor<section>:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:SONE:ERRor<section>:CONDition?
<b>Description</b>	This query returns the stage1 ODU errors condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:SONE:ESUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Example</b>	OTN:STAT:RX1:SONE:ERR1:COND? → 0
<b>Note</b>	

## 14.5.25 OTN:STATus:RX&lt;Pt&gt;:STWO:ASUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STWO:ASUMmary[:EVENT]?
<b>Description</b>	This query returns the stage2 ODU alarms summary event register. The content of this event register is summarized in DB3 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STWO:ASUM? → 6
<b>Note</b>	

## 14.5.26 OTN:STATus:RX&lt;Pt&gt;:STWO:ASUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STWO:ASUMmary:CONDition?
<b>Description</b>	This query returns stage2 ODU errors summary condition register. The content of this event register is summarized in DB3 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STWO:ASUM:COND? → 3
<b>Note</b>	

## 14.5.27 OTN:STATus:RX&lt;Pt&gt;:STWO:ESUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STWO:ESUMmary[:EVENT]?
<b>Description</b>	This query returns the stage2 ODU errors summary event register. The content of this event register is summarized in DB11 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STWO:ESUM? → 6
<b>Note</b>	

## 14.5.28 OTN:STATUS:RX&lt;Pt&gt;:STWO:ESUMmary:CONDition?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:STWO:ESUMmary:CONDition?
<b>Description</b>	This query returns stage2 ODU errors summary condition register. The content of this event register is summarized in DB11 of the OTN:STATUS:RX<Pt>:MSTage:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STWO:ESUM:COND? → 3
<b>Note</b>	

## 14.5.29 OTN:STATUS:RX&lt;Pt&gt;:STWO:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:STWO:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the stage2 ODU alarms event register. The content of this register is summarized in DB?? OTN:STATUS:RX<Pt>:STWO:ASUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Example</b>	OTN:STAT:RX1:STWO:ALAR5? → 92
<b>Note</b>	

## 14.5.30 OTN:STATUS:RX&lt;Pt&gt;:STWO:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:STWO:ALARm<section>:CONDition?
<b>Description</b>	This query returns the stage2 ODU alarms condition register query. The content of this register is summarized in DB?? OTN:STATUS:RX<Pt>:STWO:ASUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:STWO:ALAR5:COND? → 0
<b>Note</b>	

## 14.5.31 OTN:STATUS:RX&lt;Pt&gt;:STWO:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATUS:RX<Pt>:STWO:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the stage2 ODU errors event register. The content of this register is summarized in DB?? of the OTN:STATUS:RX<Pt>:STWO:ESUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Response</b>	
<b>Example</b>	OTN:STAT:RX1:STWO:ERR1? → 0
<b>Note</b>	

## 14.5.32 OTN:STATus:RX&lt;Pt&gt;:STWO:ERRor&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STWO:ERRor<section>:CONDition?
<b>Description</b>	This query returns the stage2 ODU errors condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:STWO:ESUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Example</b>	OTN:STAT:RX1:STWO:ERR1:COND? → 0
<b>Note</b>	

## 14.5.33 OTN:STATus:RX&lt;Pt&gt;:STHRee:ASUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ASUMmary[:EVENT]?
<b>Description</b>	This query returns the stage3 ODU alarms summary event register. The content of this event register is summarized in DB4 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STHR:ASUM? → 6
<b>Note</b>	

## 14.5.34 OTN:STATus:RX&lt;Pt&gt;:STHRee:ASUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ASUMmary:CONDition?
<b>Description</b>	This query returns stage3 ODU alarms summary condition register. The content of this event register is summarized in DB4 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 (4) Alarm section 3 summary DB4 (8) Alarm section 4 summary DB5 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STHR:ASUM:COND? → 3
<b>Note</b>	

## 14.5.35 OTN:STATus:RX&lt;Pt&gt;:STHRee:ESUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ESUMmary[:EVENT]?
<b>Description</b>	This query returns the stage3 ODU errors summary event register. The content of this event register is summarized in DB12 of the OTN:STATus:RX<Pt>:MSTage:AESummary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STHR:ESUM? → 6
<b>Note</b>	

## 14.5.36 OTN:STATus:RX&lt;Pt&gt;:STHRee:ESUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ESUMmary:CONDition?
<b>Description</b>	This query returns stage3 ODU errors summary condition register. The content of this event register is summarized in DB12 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:STHR:ESUM:COND? → 3
<b>Note</b>	

## 14.5.37 OTN:STATus:RX&lt;Pt&gt;:STHRee:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the stage3 ODU alarms event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:STHRee:ASUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Example</b>	OTN:STAT:RX1:STHR:ALAR5? → 92
<b>Note</b>	

## 14.5.38 OTN:STATus:RX&lt;Pt&gt;:STHRee:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ALARm<section>:CONDition?
<b>Description</b>	This query returns the stage3 ODU alarms condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:STHRee:ASUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-4)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.22
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:STHR:ALAR5:COND? → 0
<b>Note</b>	

## 14.5.39 OTN:STATus:RX&lt;Pt&gt;:STHRee:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the stage3 ODU errors event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:STHRee:ESUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:STHR:ERR1? → 0
<b>Note</b>	

## 14.5.40 OTN:STATus:RX&lt;Pt&gt;:STHRee:ERRor&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:STHRee:ERRor<section>:CONDition?
<b>Description</b>	This query returns the stage3 ODU errors condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:STHRee:ESUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.23
<b>Example</b>	OTN:STAT:RX1:STHR:ERR1:COND? → 0
<b>Note</b>	

## 14.5.41 OTN:STATus:RX&lt;Pt&gt;:CLient:ASUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ASUMmary[:EVENT]?
<b>Description</b>	This query returns the client alarms summary event register. The content of this event register is summarized in DB8 of the OTN:STATus:RX<Pt>:MSTage:AESUMmary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:CLI:ASUM? → 1
<b>Note</b>	

## 14.5.42 OTN:STATus:RX&lt;Pt&gt;:CLient:ASUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ASUMmary:CONDition?
<b>Description</b>	This query returns client alarms summary condition register. The content of this event register is summarized in DB8 of the OTN:STATus:RX<Pt>:MSTage:AESUMmary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:CLI:ASUM:COND? → 1
<b>Note</b>	

## 14.5.43 OTN:STATus:RX&lt;Pt&gt;:CLient:ESUMmary[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ESUMmary[:EVENT]?
<b>Description</b>	This query returns the client errors summary event register. The content of this event register is summarized in DB16 of the OTN:STATus:RX<Pt>:MSTage:AESUMmary[:EVENT]? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Error section 1 summary DB2 (2) Error section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:CLI:ESUM? → 2
<b>Note</b>	

## 14.5.44 OTN:STATus:RX&lt;Pt&gt;:CLient:ESUMmary:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ESUMmary:CONDition?
<b>Description</b>	This query returns client errors summary condition register. The content of this event register is summarized in DB16 of the OTN:STATus:RX<Pt>:MSTage:AESummary:CONDition? register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) Alarm section 1 summary DB2 (2) Alarm section 2 summary DB3 - DB16 NOT USED
<b>Example</b>	OTN:STAT:RX1:CLI:ESUM:COND? → 3
<b>Note</b>	

## 14.5.45 OTN:STATus:RX&lt;Pt&gt;:CLient:ALARm&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ALARm<section>[:EVENT]?
<b>Description</b>	This query returns the client alarms event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:CLient:ASUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.24
<b>Example</b>	OTN:STAT:RX1:CLI:ALAR1? → 4
<b>Note</b>	

## 14.5.46 OTN:STATus:RX&lt;Pt&gt;:CLient:ALARm&lt;section&gt;:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ALARm<section>:CONDition?
<b>Description</b>	This query returns the client alarms condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:CLient:ASUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1)
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> See Table 14.24
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:CLI:ALAR5:COND? → 6
<b>Note</b>	

## 14.5.47 OTN:STATus:RX&lt;Pt&gt;:CLient:ERRor&lt;section&gt;[:EVENT]?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ERRor<section>[:EVENT]?
<b>Description</b>	This query returns the client errors event register. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:CLient:ESUMmary[:EVENT]? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.25
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:CLI:ERR1? → 0
<b>Note</b>	

Table 14.24: Alarm Items

Client Section	1
DB1 (1)	Client-AIS
DB2 (2)	CSF
DB3 (4)	LSS
DB4 (8)	Not used
DB5 (16)	Not used
DB6 (32)	Not used
DB7 (64)	Not used
DB8 (128)	Not used
DB9 (256)	Not used
DB10 (512)	Not used
DB11 (1024)	Not used
DB12 (2048)	Not used
DB13 (4096)	Not used
DB14 (8192)	Not used
DB15 (16384)	Not used
DB16 (32768)	Not used

Table 14.25: Error Items

Client Section	1	2
DB1 (1)	PRBS Bit Error	cHEC Correctable
DB2 (2)	Not used	cHEC Uncorrectable
DB3 (4)	Not used	tHEC Correctable
DB4 (8)	Not used	tHEC Uncorrectable
DB5 (16)	Not used	Invalid GFP Frame
DB6 (32)	Not used	Superblock CRC
DB7 (64)	Not used	CSF Signal
DB8 (128)	Not used	CSF Sync
DB9 (256)	Not used	FCS
DB10 (512)	Not used	eHEC Correctable
DB11 (1024)	Not used	eHEC Uncorrectable
DB12 (2048)	Not used	CMF Loss of Sync.
DB13 (4096)	Not used	CMF Loss of Signal
DB14 (8192)	Not used	SSF
DB15 (16384)	Not used	PTI Mismatch
DB16 (32768)	Not used	UPI Mismatch

#### 14.5.48 OTN:STATus:RX<Pt>:CLient:ERRor<section>:CONDition?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CLient:ERRor<section>:CONDition?
<b>Description</b>	This query returns the client errors condition register query. The content of this register is summarized in DB?? of the OTN:STATus:RX<Pt>:CLient:ESUMmary:CONDition? register.
<b>Parameters</b>	<Pt> = Port number <section> = Section number (1-2)
<b>Response</b>	<register>=<NR1 NUMERIC RESPONSE DATA> See Table 14.25
<b>Example</b>	OTN:STAT:RX1:CLI:ERR1:COND? → 0
<b>Note</b>	



## 14.5.49 OTN:STATus:RX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	OTN:STATus:RX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal input level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> "<power> dBm" : Min: "< -27 dBm" , Max: "Exceeds Level" "Module not ready" "Unknown module" "No module"
<b>Example</b>	OTN:STAT:RX1:PSL? → "-12 dBm"
<b>Note</b>	

## 14.5.50 OTN:STATus:TX&lt;Pt&gt;:PSLevel?

<b>Syntax</b>	OTN:STATus:TX<Pt>:PSLevel?
<b>Description</b>	This query returns the physical signal output level. Unit: dBm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<signallevel> = <STRING RESPONSE DATA> "<power> dBm" : Min: "< -27 dBm" , Max: "Exceeds Level" "Module not ready" "Unknown module" "No module"
<b>Example</b>	OTN:STAT:TX1:PSL? → "-3 dBm"
<b>Note</b>	

## 14.5.51 OTN:STATus:RX&lt;Pt&gt;:FREQuency?

<b>Syntax</b>	OTN:STATus:RX<Pt>:FREQuency? <unit>
<b>Description</b>	This query returns the physical frequency error.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million HZ = Hz <i>DEFault = PPM</i>
<b>Response</b>	<signalfreq> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:FREQ? PPM → 3
<b>Note</b>	

## 14.5.52 OTN:STATus:TX&lt;Pt&gt;:FREQuency?

<b>Syntax</b>	OTN:STATus:TX<Pt>:FREQuency? <unit>
<b>Description</b>	This query returns the physical frequency error.
<b>Parameters</b>	<Pt> = Port number <unit> = <CHARACTER PROGRAM DATA> PPM = Parts per million HZ = Hz <i>DEFault = PPM</i>
<b>Response</b>	<signalfreq> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:TX1:FREQ? PPM → 3
<b>Note</b>	

## 14.5.53 OTN:STATus:RX&lt;Pt&gt;:CAPTure:OH?

<b>Syntax</b>	OTN:STATus:RX<Pt>:CAPTure:OH? <odutype>,<row>,<column>
<b>Description</b>	This query returns the multi frame sequence data of selected position of OH. Data length depends on the selected position of OH.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;odutype&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ODU2: ODU2  ODU1: ODU1  ODU0: ODU0  ODU2E: ODU2e  ODU1E: ODU1e  ODU2F: ODU2f  ODU1F: ODU1f  ODUFLEX: ODUflex  ODU3: ODU3  ODU3E1: ODU3e1  ODU3E2: ODU3e2  ODU4: ODU4  ODUC: ODUC</p> <p>&lt;row&gt; = OH row number(1-4)</p> <p>&lt;column&gt; = OH column number (1-16)</p>
<b>Response</b>	<data> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STAT:RX1:CAPT:OH? ODU2,2,16 → #H08
<b>Note</b>	When querying the row 4, columns 15 with this command, it always returns PSI[0].

## 14.6 Stimuli

### 14.6.1 OTN:STIMuli:TX<Pt>:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:TYPE <type>
<b>Description</b>	Choose the type of alarm/error that is inserted by the command SYSTem:STIMuli:INSert.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> AEINsert: Normal alarm/error GMP: GMP error GFP: GFP error FEC: FEC test error LLD: LLD error/alarm <sup>1</sup> <i>DEFault = AEINsert</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:TYPE AEIN
<b>Note</b>	<sup>1</sup> LLD error/alarm are only available at OTU3/4.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:TYPE?
<b>Description</b>	
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:TYPE? → AEIN
<b>Note</b>	

### 14.6.2 OTN:STIMuli:TX<Pt>:AEINsert:LEVel

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:LEVel <odutype>
<b>Description</b>	This command sets the ODU type to insert the error or alarm.
<b>Parameters</b>	<Pt> = Port number <odutype> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU2E: ODU2e ODU1E: ODU1e ODU2F: ODU2f ODU1F: ODU1f ODUFLEX: ODUFlex ODU3: ODU3 ODU3E1: ODU3e1 ODU3E2: ODU3e2 ODU4: ODU4 ODUC: ODUC <i>DEFault = ODU2</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:LEV ODU2
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:LEVel?
<b>Description</b>	This query returns the ODU type to insert the error or alarm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<odutype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:LEV? → ODU2
<b>Note</b>	

## 14.6.3 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:TYPE <aerrortype>
<b>Description</b>	This command sets the type to insert alarm/error.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;aerrortype&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>NONE: (None)</p> <p>BITALL: Bit All</p> <p>FAS: OTU-FAS</p> <p>MFAS: MFAS</p> <p>SMBIP8: SM-BIP8</p> <p>SMBEI: SM-BEI</p> <p>PMBIP8: PM-BIP8</p> <p>PMBEI: PM-BEI</p> <p>TCMiBIP8: TCMi-BIP8 ( i = 1-6 )</p> <p>TCMiBEI: TCMi-BEI ( i = 1-6 )</p> <p>FASODU: ODU-FAS</p> <p>PRBSBIT: PRBS Bit Error</p> <p>OOOF: OTU-OOOF/LOF</p> <p>OOM: OOM/LOM</p> <p>AISOTU: OTU-AIS</p> <p>SMTIM: SM-TIM</p> <p>SMBIAE: SM-BIAE</p> <p>SMBDI: SM-BDI</p> <p>SMIAE: SM-IAE</p> <p>AISODU: ODU-AIS</p> <p>OCI: ODU-OCI</p> <p>LCK: ODU-LCK</p> <p>PMTIM: PM-TIM</p> <p>PMBDI: PM-BDI</p> <p>TCMiTIM: TCMi-TIM ( i = 1-6 )</p> <p>TCMiBIAE: TCMi-BIAE ( i = 1-6 )</p> <p>TCMiIAE: TCMi-IAE ( i = 1-6 )</p> <p>TCMiBDI: TCMi-BDI ( i = 1-6 )</p> <p>TCMiLTC: TCMi-LTC ( i = 1-6 )</p> <p>OOOFODU: ODU-OOOF/LOF</p> <p>OOMODU: ODU-OOM/LOM</p> <p>AISC: Client-AIS</p> <p>CSF: CSF</p> <p>FSF: FSF</p> <p>FSD: FSD</p> <p>BSF: BSF</p> <p>BSD: BSD</p> <p>LOS: LOS</p> <p><i>DEFault = NONE</i></p>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:TYPE OOF
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:TYPE?
<b>Description</b>	This query returns the alarm/error insertion type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<aerrortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:TYPE? → OOF
<b>Note</b>	

## 14.6.4 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:INSert

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:INSert <insertion>
<b>Description</b>	This command sets the method to insert alarm/error.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> SINGle BURSt ALTErnate RATE ALL <i>DEFault = SINGle</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:INS SING
<b>Note</b>	If insertion is set to SINGle, errors are inserted with SYST:STIM:INS. See section 2.3.14.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:INSert?
<b>Description</b>	This query returns the alarm/error insertion method.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:INS? → SING
<b>Note</b>	

## 14.6.5 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:BURSt

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:BURSt <frames>
<b>Description</b>	This command sets the alarm/error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4300000, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:BURS 1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:BURSt?
<b>Description</b>	This query returns the alarm/error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:BURS? → 1
<b>Note</b>	

## 14.6.6 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:AERRor

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:AERRor <frames>
<b>Description</b>	This command sets the alternate alarm/error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4300000, DEFault=0</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:AERR 0
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:AERRor?
<b>Description</b>	This query returns the alternate alarm/error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:AERR? → 0
<b>Note</b>	

## 14.6.7 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:NORMal

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:NORMal <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=4300000, DEFault=1</i> <i>DEFault = 1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:NORM 1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:NORMal?
<b>Description</b>	This query returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:NORM? → 1
<b>Note</b>	

## 14.6.8 OTN:STIMuli:TX&lt;Pt&gt;:AEINsert:RATE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:RATE <rate>
<b>Description</b>	This command sets the rate to insert errors.
<b>Parameters</b>	<Pt> = Port number <rate> = <CHARACTER PROGRAM DATA> R1E2: 1.0E-2 R1E3: 1.0E-3 R1E4: 1.0E-4 R1E5: 1.0E-5 R1E6: 1.0E-6 R1E7: 1.0E-7 R1E8: 1.0E-8 R1E9: 1.0E-9 R1E10: 1.0E-10 <i>DEFault = R1E9</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:AEIN:RATE R1E9
<b>Note</b>	Available when the insertion mode is Rate. Not all error rates are available for all error types.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:AEINsert:RATE?
<b>Description</b>	This command returns the rate to insert errors.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<rate> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:AEIN:RATE? → R1E9
<b>Note</b>	

## 14.6.9 OTN:STIMuli:TX&lt;Pt&gt;:JUSTification:LEVel

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:LEVel <odotype>
<b>Description</b>	This command sets the ODU type to adjust the pointer. Only OPuk those are mapped into AMP or BMP are available.
<b>Parameters</b>	<Pt> = Port number  <odotype> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU2E: ODU2e ODU3: ODU3 ODU3E1: ODU3e1 <i>DEFault = ODU2</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:JUST:LEV ODU2
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:LEVel?
<b>Description</b>	This query returns the ODU type to adjust the pointer.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<odotype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:JUST:LEV? → ODU2
<b>Note</b>	

## 14.6.10 OTN:STIMuli:TX&lt;Pt&gt;:JUSTification:BURSt

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:BURSt <frames>
<b>Description</b>	This command specifies the number of count to move the pointer in the direction over a time.
<b>Parameters</b>	<Pt> = Port number  <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=100, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:JUST:BURS 1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:BURSt?
<b>Description</b>	This query returns the number of count to move the pointer in the direction over a time.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:JUST:BURS? → 1
<b>Note</b>	

## 14.6.11 OTN:STIMuli:TX&lt;Pt&gt;:JUSTification:MOVement

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:MOVement <count>
<b>Description</b>	This command sets the OTN pointer movement sequence.
<b>Parameters</b>	<Pt> = Port number  <count> = <CHARACTER PROGRAM DATA> POS1: Positive (+1) POS2: Positive (+2) POS3: Positive (+3) NEG1: Negative (-1) NEG2: Negative (-2) <i>DEFault = POS1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:JUST:MOV POS1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JUSTification:MOVement?
<b>Description</b>	This query returns the OTN pointer movement sequence.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<count> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:JUST:MOV? → POS1
<b>Note</b>	

#### 14.6.12 OTN:STIMuli:TX<Pt>:JMOVE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:JMOVE
<b>Description</b>	This command moves OTN pointer to instruct pointer.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:JMOV
<b>Note</b>	

#### 14.6.13 OTN:STIMuli:TX<Pt>:FREQUENCY:OFFSet

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FREQUENCY:OFFSet <offset>
<b>Description</b>	This command sets the frequency offset for the clock source. Unit: ppm.
<b>Parameters</b>	<Pt> = Port number <offset> = <NUMERIC PROGRAM DATA> MT1000A: <i>MINimum=-50, MAXimum=50, DEFault=0</i> MT1100A: <i>MINimum=-200.0, MAXimum=200.0, DEFault = 0.0</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FREQ:OFFS 0
<b>Note</b>	The offset is applied to the internal clock source only.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FREQUENCY:OFFSet?
<b>Description</b>	This query returns the frequency offset for the clock source. Unit: ppm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	MT1000A: <offset> = <NR1 NUMERIC RESPONSE DATA> MT1100A: <offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MT1000A: OTN:STIM:TX1:FREQ:OFFS? → 0 MT1100A: OTN:STIM:TX1:FREQ:OFFS? → 0.0
<b>Note</b>	

#### 14.6.14 OTN:STIMuli:TX<Pt>:PAYLoad:OFFSet<stage>

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:PAYLoad:OFFSet<stage> <offset>
<b>Description</b>	This command sets the payload offset.
<b>Parameters</b>	<Pt> = Port number <stage> = Multiplexing stage (1-4) <offset> = <NUMERIC PROGRAM DATA> <i>MINimum=-150, MAXimum=150, DEFault=0</i> ODU2/ODU1: -65.6 to 65.6 step 0.1ppm ODTU12: -113.6 to 83.3 step 0.1ppm ODTU01: -131.3 to 65.0 step 0.1ppm ODTUk.xx (GMP): -150.0 to 150.0 step 0.1ppm ODU3: -65.6 to 65.6 step 0.1ppm ODTU23: -95.8 to 101.1 step 0.1ppm ODTU13: -96.3 to 101.3 step 0.1ppm <i>DEFault = 0</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:PAYL:OFFS1 0
<b>Note</b>	This parameter is defined at each multiplexing stage where GMP or AMP is used.



<b>Syntax</b>	OTN:STIMuli:TX<Pt>:PAYLoad:OFFSet<stage>?
<b>Description</b>	This query returns the payload offset.
<b>Parameter</b>	<Pt> = Port number <stage> = Multiplexing stage (1-4)
<b>Response</b>	<offset> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:PAYL:OFFS1? → 0
<b>Note</b>	

#### 14.6.15 OTN:STIMuli:TX<Pt>:GMP:AEINsert:LEVel

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:LEVel <stage>
<b>Description</b>	This command sets the multiplexing stage to insert the error. It can be select those have GMP on the current mapping path.
<b>Parameters</b>	<Pt> = Port number <stage> = <CHARACTER PROGRAM DATA> ODU2: ODU2 ODU1: ODU1 ODU0: ODU0 ODU3: ODU3 ODU3E2: ODU3e2 ODU4: ODU4 <i>DEFault = ODU2</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:LEV ODU2
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:LEVel?
<b>Description</b>	This query returns the multiplexing stage to insert the error.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<stage> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:LEV? → ODU2
<b>Note</b>	

#### 14.6.16 OTN:STIMuli:TX<Pt>:GMP:AEINsert:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:TYPE <aerrortype>
<b>Description</b>	This command sets the method to insert errors.
<b>Parameters</b>	<Pt> = Port number <aerrortype> = <CHARACTER PROGRAM DATA> CRC8: CRC8 Error CRC5: CRC5 Error JC1: Invalid JC1 JC2: Invalid JC2 JC1JC2: Invalid JC1&JC2 <i>DEFault = CRC8</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:TYPE CRC8
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:TYPE?
<b>Description</b>	This query returns the method to insert errors.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<aerrortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:TYPE? → CRC8
<b>Note</b>	

## 14.6.17 OTN:STIMuli:TX&lt;Pt&gt;:GMP:AEINsert:INSert

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:INSert <insertion>
<b>Description</b>	This command sets the stimuli error insertion mode.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> SINGle
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:INS SING
<b>Note</b>	Currently only one insertion mode is available.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:INSert?
<b>Description</b>	This query returns the stimuli error insertion mode.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:INS? → SING
<b>Note</b>	

## 14.6.18 OTN:STIMuli:TX&lt;Pt&gt;:GMP:AEINsert:EBITs

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:EBITs <insertion>
<b>Description</b>	This command sets 16-bit value to specify which bits are affected. For some error items, only the lower bits are effective (for example, CRC5 will use lower 5 bits.) UPPer bits of the specified value will be ignored in such a case.
<b>Parameters</b>	<Pt> = Port number <insertion> = <NUMERIC PROGRAM DATA> <i>MINimum</i> =#B000000000000000, <i>MAXimum</i> =#B1111111111111111, <i>DE-Fault</i> =#B1111111111111111
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:EBIT #B1001000001 This command add error into bit 0, 3 and 9.
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GMP:AEINsert:EBITs?
<b>Description</b>	This query returns the 16-bit value to specify which bits are affected.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GMP:AEIN:EBIT? → #B1001000001000000
<b>Note</b>	

## 14.6.19 OTN:STIMuli:TX&lt;Pt&gt;:GFP:AEINsert:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:TYPE <aerrortype>
<b>Description</b>	This command sets the error type of GFP-T and GFP-F.
<b>Parameters</b>	<Pt> = Port number <aerrortype> = <CHARACTER PROGRAM DATA> OFF: Off CHEC: cHEC THEC: tHEC SCRC: Super block CRC (only GFP-T) EHEC: eHEC (only GFP-F) FCSE: FCS error (only GFP-F) CMFSIGNAL: CMF Signal (only GFP-F) CMFSYNC: CMF Sync (only GFP-F) <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:TYPE OFF
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:TYPE?
<b>Description</b>	This query returns the error type of GFP.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<aerrortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:TYPE? → OFF
<b>Note</b>	

## 14.6.20 OTN:STIMuli:TX&lt;Pt&gt;:GFP:AEINsert:INSert

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:INSert <insertion>
<b>Description</b>	This command sets the insertion mode of GFP Error.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> SINGle BURSt ALL <i>DEFault = SINGle</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:INS SING
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:INSert?
<b>Description</b>	This query returns the insertion mode of GFP Error.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:INS? → SING
<b>Note</b>	

## 14.6.21 OTN:STIMuli:TX&lt;Pt&gt;:GFP:AEINsert:EBITs

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:EBITs <insertion>
<b>Description</b>	This command sets the 16-bit value to specify which bits are affected. For some error items, only the lower bits are effective (for example, CRC5 will use lower 5 bits.) UPPER bits of the specified value will be ignored in such a case.
<b>Parameters</b>	<Pt> = Port number <insertion> = <NUMERIC PROGRAM DATA> <i>MINimum=#B000000000000000, MAXimum=#B111111111111111, DE-Fault=#B111111111111111</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:EBIT #B1001000001
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:EBITs?
<b>Description</b>	This query returns the 16-bit value to specify which bits are affected.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:EBIT? → #B1001000001000000
<b>Note</b>	

## 14.6.22 OTN:STIMuli:TX&lt;Pt&gt;:GFP:AEINsert:BURSt

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:BURSt <frames>
<b>Description</b>	This command sets the alarm/error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=4300000, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:BURS 1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:BURSt?
<b>Description</b>	This query returns the alarm/error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:BURS? → 1
<b>Note</b>	

## 14.6.23 OTN:STIMuli:TX&lt;Pt&gt;:GFP:AEINsert:CMF:INTerval

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:CMF:INTerval <interval>
<b>Description</b>	This command sets the interval time of CMF insertion. Unit: ms.
<b>Parameters</b>	<Pt> = Port number <interval> = <NUMERIC PROGRAM DATA> <i>MINimum=10, MAXimum=2560, DEFault=10</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:CMF:INT 10
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:GFP:AEINsert:CMF:INTerval?
<b>Description</b>	This query returns the interval time of CMF insertion. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interval> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:GFP:AEIN:CMF:INT? → 10
<b>Note</b>	

## 14.6.24 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:TYPE <aerrortype>
<b>Description</b>	This command sets the error type inserted to FEC.
<b>Parameters</b>	<Pt> = Port number <aerrortype> = <CHARACTER PROGRAM DATA> OFF: Off 0182: 0.182 Poisson UNCORRECT: Uncorretcable Error CORRECT: Correctable Error <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:TYPE 0182
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:TYPE?
<b>Description</b>	This query returns the error type inserted to FEC.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<aerrortype> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:TYPE? → 0182
<b>Note</b>	

## 14.6.25 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:INSert

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:INSert?
<b>Description</b>	This query returns the insertion method of FEC error.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA> SINGLE RATE
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:INS? → RATE
<b>Note</b>	

## 14.6.26 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:RMANtissa

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:RMANtissa <mantissa>
<b>Description</b>	This command sets the magnitude of the rate to insert errors.
<b>Parameters</b>	<Pt> = Port number <mantissa> = <NUMERIC PROGRAM DATA> 0.1-9.9 step 0.1 <i>MINimum=0.1, MAXimum=9.9, DEFault=1.0</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:RMAN 1.0
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:RMANtissa?
<b>Description</b>	This query returns the magnitude of the rate to insert errors.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mantissa> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:RMAN? → 1.0
<b>Note</b>	

## 14.6.27 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:REXPnent

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:REXPnent <exponent>
<b>Description</b>	This command sets the exponential value of the rate to insert errors.
<b>Parameters</b>	<Pt> = Port number <exponent> = <CHARACTER PROGRAM DATA> R1E2: 1.0E-2 R1E3: 1.0E-3 R1E4: 1.0E-4 R1E5: 1.0E-5 R1E6: 1.0E-6 R1E7: 1.0E-7 R1E8: 1.0E-8 R1E9: 1.0E-9 R1E10: 1.0E-10 <i>DEFault = R1E9</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:REXP R1E9
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:REXPnent?
<b>Description</b>	This query returns the exponential value of the rate to insert errors.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<exponent> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:REXP? → R1E9
<b>Note</b>	

## 14.6.28 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:EFAS

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:EFAS <insertion>
<b>Description</b>	This command specifies whether to include the error over the whole frame or exclude FAS fields.
<b>Parameters</b>	<Pt> = Port number <insertion> = <BOOLEAN PROGRAM DATA> ON: Includes FAS OFF: Excludes FAS <i>DEFault = OFF</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:EFAS OFF
<b>Note</b>	Available only when the error item is set to O.182 and the insertion mode is Rate. It takes effect when the rate is greater than or equal to 2.0E-3.

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:EFAS?
<b>Description</b>	This query returns status of FAS fields (to include the error over the whole frame or exclude FAS fields)
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:EFAS? → 0
<b>Note</b>	

## 14.6.29 OTN:STIMuli:TX&lt;Pt&gt;:FEC:AEINsert:SUBRow

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:SUBRow <row>
<b>Description</b>	This command specifies the subrow inserting the alarm or the error.
<b>Parameters</b>	<Pt> = Port number <row> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=16, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:SUBR 1
<b>Note</b>	

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:FEC:AEINsert:SUBRow?
<b>Description</b>	This query returns the subrow inserting the alarm or the error.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<row> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:FEC:AEIN:SUBR? → 1
<b>Note</b>	

## 14.6.30 OTN:STIMuli:TX&lt;Pt&gt;:LLD:AEINsert:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:TYPE <type>
<b>Description</b>	This command sets the type of LLD alarm/error insertion.
<b>Parameter</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> NONE: No alarm or error ALARM: Insert alarm ERROR: Insert error <i>DEFault = NONE</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:TYPE ALARM
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:TYPE?
<b>Description</b>	This query returns the type of LLD alarm/error insertion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<row> = <CHARACTER PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:TYPE? → ALARM
<b>Note</b>	This command can be used on 40/100G

## 14.6.31 OTN:STIMuli:TX&lt;Pt&gt;:LLD:AEINsert:ALARm

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ALARm <type>
<b>Description</b>	This command sets the type of the Alarm.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> OOFLLD: OOF/LOF OOR: OOR/LOR <i>DEFault = OOFLLD</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:ALAR OOFLLD
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ALARm?
<b>Description</b>	This query returns the type of the Alarm.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<row> = <CHARACTER PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:ALAR? → OOFLLD
<b>Note</b>	This command can be used on 40/100G

## 14.6.32 OTN:STIMuli:TX&lt;Pt&gt;:LLD:AEINsert:ERRor

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ERRor <type>
<b>Description</b>	This command sets the type of the Error.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> FASLLD: FAS-LLD MFASLLD: MFAS-LLD LLMLLD: LLM-LLD <i>DEFault = FASLLD</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:ERR FASLLD
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:ERRor?
<b>Description</b>	This query returns the type of the Error.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<CHARACTER PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:ERR? → FASLLD
<b>Note</b>	This command can be used on 40/100G

## 14.6.33 OTN:STIMuli:TX&lt;Pt&gt;:LLD:AEINsert:INSert

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:INSert <insertion>
<b>Description</b>	This command sets the mode of the insertion.
<b>Parameters</b>	<Pt> = Port number <insertion> = <CHARACTER PROGRAM DATA> BURSt ALternate ALL <i>DEFault = ALL</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:INS ALL
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:INSert?
<b>Description</b>	This query returns the mode of the insertion.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<insertion> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:INS? → ALL
<b>Note</b>	This command can be used on 40/100G

## 14.6.34 OTN:STIMuli:TX&lt;Pt&gt;:LLD:AEINsert:BURSt

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:BURSt <frames>
<b>Description</b>	This command sets the alarm/error burst length to generate.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> 1 to 215000 step 1
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:BURS 1
<b>Note</b>	This command can be used on 40/100G



<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:BURSt?
<b>Description</b>	This query returns the alarm/error burst length to generate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NUMERIC PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:BURS? → 1
<b>Note</b>	This command can be used on 40/100G

#### 14.6.35 OTN:STIMuli:TX<Pt>:LLD:AEINsert:AERRor

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:AERRor <frames>
<b>Description</b>	This command sets the alternate alarm/error length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> 0 to 215000 step 1
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:AERR 0
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:AERRor?
<b>Description</b>	This query returns the alternate alarm/error length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:AERR? → 0
<b>Note</b>	This command can be used on 40/100G

#### 14.6.36 OTN:STIMuli:TX<Pt>:LLD:AEINsert:NORMal

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:NORMal <frames>
<b>Description</b>	This command sets the alternate normal length.
<b>Parameters</b>	<Pt> = Port number <frames> = <NUMERIC PROGRAM DATA> 1 to 215000 step 1
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:NORM 1
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:NORMal?
<b>Description</b>	This command returns the alternate normal length.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frames> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:NORM? → 1
<b>Note</b>	This command can be used on 40/100G

#### 14.6.37 OTN:STIMuli:TX<Pt>:LLD:AEINsert:LANE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:LANE <lane>
<b>Description</b>	This command sets the lane On/Off that bit corresponds lane.
<b>Parameters</b>	<Pt> = Port number <lane> = <NUMERIC PROGRAM DATA> <i>MINimum</i> =#B0000000000000000000, <i>MAXimum</i> =#B1111111111111111111, <i>DE-Fault</i> =#B1000000000000000000
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:LANE #B1001000001 This command add error into lane 0, 3 and 9.
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:AEINsert:LANE?
<b>Description</b>	This command returns the lane On/Off that bit corresponds lane.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:AEIN:LANE? → #B10010000010000000000
<b>Note</b>	This command can be used on 40/100G

#### 14.6.38 OTN:STIMuli:TX<Pt>:LLD:SKEW:LANE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:LANE <lane>
<b>Description</b>	This command sets lane On/Off of the Tx Lane.
<b>Parameters</b>	<Pt> = Port number <lane> = <NUMERIC PROGRAM DATA> <i>MINimum</i> =#B0000000000000000000, <i>MAXimum</i> =#B11111111111111111111, <i>DE-Fault</i> =#B10000000000000000000
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:LANE #B1001000001 This command add skew into lane 0, 3 and 9.
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:LANE?
<b>Description</b>	This command returns lane On/Off of the Tx Lane.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lane> = <BINARY NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:LANE? → #B10010000010000000000
<b>Note</b>	This command can be used on 40/100G

#### 14.6.39 OTN:STIMuli:TX<Pt>:LLD:SKEW:BIT

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:BIT <bit>
<b>Description</b>	This command sets the number of skew bit.
<b>Parameters</b>	<Pt> = Port number <bit> = <NUMERIC PROGRAM DATA> 0 to 32000 step 1
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:BIT 0
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:BIT?
<b>Description</b>	This command returns the number of skew bit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<NUMERIC PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:BIT? → 0
<b>Note</b>	This command can be used on 40/100G

## 14.6.40 OTN:STIMuli:TX&lt;Pt&gt;:LLD:SKEW:TYPE

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:TYPE <type>
<b>Description</b>	This command sets type of the insert lane.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> TXLANE: Tx Lane PHYSICALLANE: Physical Lane <i>DEFault = TXLANE</i>
<b>Response</b>	None
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:TYPE TXLANE
<b>Note</b>	This command can be used on 40/100G

<b>Syntax</b>	OTN:STIMuli:TX<Pt>:LLD:SKEW:TYPE?
<b>Description</b>	This command returns type of the insert lane.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<CHARACTER PROGRAM DATA>
<b>Example</b>	OTN:STIM:TX1:LLD:SKEW:TYPE? → TXLANE
<b>Note</b>	This command can be used on 40/100G

## 14.7 Tributary Scan

### 14.7.1 OTN:TSCan:START

<b>Syntax</b>	OTN:TSCan:START
<b>Description</b>	This command starts the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	OTN:TSC:STAR
<b>Note</b>	

### 14.7.2 OTN:TSCan:STOP

<b>Syntax</b>	OTN:TSCan:STOP
<b>Description</b>	This command stops the tributary scan test.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	OTN:TSC:STOP
<b>Note</b>	

### 14.7.3 OTN:TSCan:RX<Pt>:ODU2:NUMBER?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU2:NUMBER?
<b>Description</b>	This query returns the number of ODU2/ODU2e.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TSC:RX1:ODU2:NUMB? → 1
<b>Note</b>	

### 14.7.4 OTN:TSCan:RX<Pt>:ODU2:GET?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU2:GET?
<b>Description</b>	This query returns the detailed alarm and error information from a ODU2/ODU2e.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The values are presented in ascending order, meaning that ODU2 #1 is the rst on the list. 0: No alarms or errors. 1: Alarms or errors present.
<b>Example</b>	OTN:TSC:RX1:ODU2:GET? → 0
<b>Note</b>	

### 14.7.5 OTN:TSCan:RX<Pt>:ODU2:DETAILED?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU2:DETAILED? <number>
<b>Description</b>	
<b>Parameter</b>	<Pt> = Port number <number> = ODU2 number MINimum=1, MAXimum=1
<b>Response</b>	<selected> = <STRING RESPONSE DAT> RXng {ODU2 Order}, separated by one space character. RXn = RX1 or RX2 ODU2-order = ODU2#1 (<alarmerrors>) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	OTN:TSC:RX1:ODU2:DET? 1 → "RX1 OTU2#1", ("PM-BDI", "ODU-AIS")
<b>Note</b>	

## 14.7.6 OTN:TSCan:RX&lt;Pt&gt;:ODU1:NUMBer?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU1:NUMBer?
<b>Description</b>	Description This query returns the number of ODU1/ODU1e.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TSC:RX1:ODU1:NUMB? → 4
<b>Note</b>	

## 14.7.7 OTN:TSCan:RX&lt;Pt&gt;:ODU1:GET?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU1:GET?
<b>Description</b>	This query returns the state of ODU1/ODU1e.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The values are presented in ascending order, meaning that ODU1 #1 is the rst on the list. 0: No alarms or errors. 1: Alarms or errors present.
<b>Example</b>	OTN:TSC:RX1:ODU1:GET? → 1
<b>Note</b>	

## 14.7.8 OTN:TSCan:RX&lt;Pt&gt;:ODU1:SCANning

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU1:SCANning <number>
<b>Description</b>	This command sets the ODU1/ODU1e for scanning.
<b>Parameters</b>	<Pt> = Port number <number> = High Order number MINimum=1, MAXimum=4 <i>MINimum=1, MAXimum=4, DEFault=1</i>
<b>Response</b>	None
<b>Example</b>	OTN:TSC:RX1:ODU1:SCAN 2
<b>Note</b>	

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU1:SCANning?
<b>Description</b>	This query returns the ODU1/ODU1e for scanning.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = High Order number (1-4)
<b>Example</b>	OTN:TSC:RX1:ODU1:SCAN? → 2
<b>Note</b>	

## 14.7.9 OTN:TSCan:RX&lt;Pt&gt;:ODU1:DETAiled?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU1:DETAiled? <number>
<b>Description</b>	This query returns the detailed alarm and error information from a ODU1/ODU1e.
<b>Parameter</b>	<Pt> = Port number <number> = ODU1 number MINimum=1, MAXimum=1
<b>Response</b>	<selected> = <STRING RESPONSE DATA> {RXng {ODU2 Order}, separated by one space character. RXn = RX1 or RX2 ODU2-order = ODU2#1 (<alarmerrors>) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	OTN:TSC:RX1:ODU1:DET? 1 → "RX1 OTU1#1", ("PM-BDI", "ODU-AIS")
<b>Note</b>	

## 14.7.10 OTN:TSCan:RX&lt;Pt&gt;:ODU0:NUMBer?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU0:NUMBer?
<b>Description</b>	This query returns the number of ODU0.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:TSC:RX1:ODU0:NUMB? → 2
<b>Note</b>	

## 14.7.11 OTN:TSCan:RX&lt;Pt&gt;:ODU0:GET?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU0:GET?
<b>Description</b>	This query returns the state of ODU0.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA> The values are presented in ascending order, meaning that ODU0 #1 is the rst on the list. 0: No alarms or errors. 1: Alarms or errors present.
<b>Example</b>	OTN:TSC:RX1:ODU0:GET? → (0,1,1,0)
<b>Note</b>	

## 14.7.12 OTN:TSCan:RX&lt;Pt&gt;:ODU0:DETAiled?

<b>Syntax</b>	OTN:TSCan:RX<Pt>:ODU0:DETAiled? <number>
<b>Description</b>	This query returns the detailed alarm and error information from a ODU0.
<b>Parameter</b>	<Pt> = Port number <number> = ODU0 number MINimum=1, MAXimum=1
<b>Response</b>	<selected> = <STRING RESPONSE DATA> {RXng {ODU0 Order}, separated by one space character. RXn = RX1 or RX2 ODU0-order = ODU0#1 ( <alarmerrors> ) = <STRING RESPONSE DATA> List of alarms and errors.
<b>Example</b>	OTN:TSC:RX1:ODU0:DET? 1 → "RX1 OTU2#:ODU1#1:ODU0#1", ("PM-BDI", "ODU-AIS")
<b>Note</b>	

## 14.8 APS

### 14.8.1 OTN:APS:RX<Pt>:BEVent

<b>Syntax</b>	OTN:APS:RX<Pt>:BEVent <event>
<b>Description</b>	This command sets the time reference begin (start) event.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;event&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>ANYERROR: Any errors          LOS: Loss of Signal          OTUAIS: OTU-AIS          LOF: Loss of Frame          OOF: Out of Frame          LOM: LOM          OOM: OOM          SMBIAE: SM-BIAE          SMBDI: SM-BDI          SMIAE: SM-IAE          ODUAIS: ODU-AIS          ODUOCI: ODU-OCI          ODULCK: ODU-LCK          PMBDI: PM-BDI          FAS: FAS          MFAS: MFAS          SMBIP8: SM-BIP8          SMBEI: SM-BEI          PMBIP8: PM-BIP8          PMBEI: PM-BEI          PERRor: Pattern error          LOFLLD: LOF-OTL          OOFLLD: OOF-OTL          LORLLD: LOR-OTL          OORLLD: OOR-OTL          FASLLD: FAS-OTL          MFASLLD: MFAS-OTL          LLMLLD: LLM-OTL</p> <p><i>DEFault = LOF</i></p>
<b>Response</b>	None
<b>Example</b>	OTN:APS:RX1:BEV LOF
<b>Note</b>	

<b>Syntax</b>	OTN:APS:RX<Pt>:BEVent?
<b>Description</b>	This query returns the time reference begin (start) event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:BEV? → LOF
<b>Note</b>	

## 14.8.2 OTN:APS:RX&lt;Pt&gt;:EEVent

<b>Syntax</b>	OTN:APS:RX<Pt>:EEVent <event>
<b>Description</b>	This command sets the time reference end (stop) event.
<b>Parameters</b>	<Pt> = Port number <event> = <CHARACTER PROGRAM DATA> ANYERROR: Any errors LOS: Loss of Signal OTUAIS: OTU-AIS LOF: Loss of Frame OOF: Out of Frame LOM: LOM OOM: OOM SMBIAE: SM-BIAE SMBDI: SM-BDI SMIAE: SM-IAE ODUAIS: ODU-AIS ODUOCI: ODU-OCI ODULCK: ODU-LCK PMBDI: PM-BDI FAS: FAS MFAS: MFAS SMBIP8: SM-BIP8 SMBEI: SM-BEI PMBIP8: PM-BIP8 PMBEI: PM-BEI PERRor: Pattern error LOFLLD: LOF-OTL OOFLLD: OOF-OTL LORLLD: LOR-OTL OORLLD: OOR-OTL FASLLD: FAS-OTL MFASLLD: MFAS-OTL LLMLLD: LLM-OTL <i>DEFault = LOF</i>
<b>Response</b>	None
<b>Example</b>	OTN:APS:RX1:EEV LOF
<b>Note</b>	

<b>Syntax</b>	OTN:APS:RX<Pt>:EEVent?
<b>Description</b>	This query returns the time reference end (stop) event.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<event> = <CHARACTER RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:EEV? → LOF
<b>Note</b>	

## 14.8.3 OTN:APS:RX&lt;Pt&gt;:PERiod

<b>Syntax</b>	OTN:APS:RX<Pt>:PERiod <period>
<b>Description</b>	This command sets the period that no error/alarm specified by the end event should not be detected.
<b>Parameters</b>	<Pt> = Port number <period> = <NUMERIC PROGRAM DATA> 1,10,100,200,300,400,500,600,700,800,900,1000 Unit ms <i>DEFault = 1</i>
<b>Response</b>	None
<b>Example</b>	OTN:APS:RX1:PER 1
<b>Note</b>	



<b>Syntax</b>	OTN:APS:RX<Pt>:PERiod?
<b>Description</b>	This query returns the period that no error/alarm specified by the end event should not be detected.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<period> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:PER? → 1
<b>Note</b>	

#### 14.8.4 OTN:APS:RX<Pt>:MLIMit

<b>Syntax</b>	OTN:APS:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: ms.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.000, MAXimum = 10000.000, DEFault = 50.000</i>
<b>Response</b>	None
<b>Example</b>	OTN:APS:RX1:MLIM 50.000
<b>Note</b>	

<b>Syntax</b>	OTN:APS:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:MLIM? → 50.000
<b>Note</b>	

#### 14.8.5 OTN:APS:START

<b>Syntax</b>	OTN:APS:START
<b>Description</b>	This command starts the APS (Automatic Protection Switching).
<b>Parameter</b>	None
<b>Response</b>	None
<b>Example</b>	OTN:APS:STAR
<b>Note</b>	

#### 14.8.6 OTN:APS:STOP

<b>Syntax</b>	OTN:APS:STOP
<b>Description</b>	This command stops the APS (Automatic Protection Switching).
<b>Parameter</b>	None
<b>Response</b>	None
<b>Example</b>	OTN:APS:STOP
<b>Note</b>	

#### 14.8.7 OTN:APS:RX<Pt>:NUMBER?

<b>Syntax</b>	OTN:APS:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of times an APS Protocol event has occurred.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:NUMB? → 17
<b>Note</b>	

## 14.8.8 OTN:APS:RX&lt;Pt&gt;:MTIME?

<b>Syntax</b>	OTN:APS:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	OTN:APS:RX1:MTIM? → 4.000,0
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

## 14.8.9 OTN:APS:RX&lt;Pt&gt;:LTIME?

<b>Syntax</b>	OTN:APS:RX<Pt>:LTIME?
<b>Description</b>	This query returns the least (minimum) time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:LTIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

## 14.8.10 OTN:APS:RX&lt;Pt&gt;:ATIME?

<b>Syntax</b>	OTN:APS:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:ATIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 10000 ms.

## 14.8.11 OTN:APS:RX&lt;Pt&gt;:CTIME?

<b>Syntax</b>	OTN:APS:RX<Pt>:CTIME?
<b>Description</b>	This query returns the current time of the reference event occurrences. Unit: ms.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:APS:RX1:CTIM? → 4.000
<b>Note</b>	The maximum measurable time is 10000 ms. The maximum measurable time will be responded if the result exceeds 99999.999 ms.

## 14.9 RTD

This section document commands for the Round Trip Delay application. Commands for general RTD settings are described in section 16.1 on page 837.

### 14.9.1 OTN:RTD:RX<Pt>:MLIMit

<b>Syntax</b>	OTN:RTD:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit. Unit: us.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0, MAXimum = 1000000.0, DEFault = MAXimum</i>
<b>Response</b>	None.
<b>Example</b>	OTN:RTD:RX1:MLIM 0.0
<b>Note</b>	

<b>Syntax</b>	OTN:RTD:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RTD:RX1:MLIM? → 0.0
<b>Note</b>	

### 14.9.2 OTN:RTD:RX<Pt>:NUMBER?

<b>Syntax</b>	OTN:RTD:RX<Pt>:NUMBER?
<b>Description</b>	This query returns the number of the RTD data.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<number> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RTD:RX1:NUMB? → 2
<b>Note</b>	

### 14.9.3 OTN:RTD:RX<Pt>:ATIME?

<b>Syntax</b>	OTN:RTD:RX<Pt>:ATIME?
<b>Description</b>	This query returns the average time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<avg> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RTD:RX1:ATIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

### 14.9.4 OTN:RTD:RX<Pt>:MTIME?

<b>Syntax</b>	OTN:RTD:RX<Pt>:MTIME?
<b>Description</b>	This query returns the maximum time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA> <limit exceeded> = <NR1 NUMERIC RESPONSE DATA> Returns 1, if the reference maximum limit has been exceeded.
<b>Example</b>	OTN:RTD:RX1:MTIM? → 1.0,0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

**14.9.5 OTN:RTD:RX<Pt>:LTIMe?**

<b>Syntax</b>	OTN:RTD:RX<Pt>:LTIMe?
<b>Description</b>	This query returns the least (minimum) time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RTD:RX1:LTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds the maximum measurable time.

**14.9.6 OTN:RTD:RX<Pt>:CTIMe?**

<b>Syntax</b>	OTN:RTD:RX<Pt>:CTIMe?
<b>Description</b>	This query returns the current time of RTD. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<min> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	OTN:RTD:RX1:CTIM? → 1.0
<b>Note</b>	The maximum measurable time will be responded if the result exceeds 99999999.9 us.

---

## Chapter 15

# Pluggable Module

### 15.1 Status

#### 15.1.1 PMODule:STATus:PORT<Pt>:PRESent?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:PRESent?
<b>Description</b>	This query returns if a pluggable module is present and ready.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<present> = <STRING RESPONSE DATA> "OK": Module is present and ready. "N/A": Port off, module not present or not ready.
<b>Example</b>	PMOD:STAT:PORT1:PRES? → "OK"
<b>Note</b>	

#### 15.1.2 PMODule:STATus:PORT<Pt>:VENDor?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:VENDor?
<b>Description</b>	This query returns the pluggable module vendor name.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<vendor> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:VEND? → "COMPANY"
<b>Note</b>	

#### 15.1.3 PMODule:STATus:PORT<Pt>:WAVelength?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:WAVelength?
<b>Description</b>	This query returns the pluggable module laser wavelength.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<wavelength> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:WAV? → "1310 nm"
<b>Note</b>	

#### 15.1.4 PMODule:STATus:PORT<Pt>:BRATe?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:BRATe?
<b>Description</b>	This query returns the pluggable module bit rate.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<bitrate> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:BRAT? → "2500 Mbps"
<b>Note</b>	

## 15.1.5 PMODule:STATus:PORT&lt;Pt&gt;:COMPLiance?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:COMPLiance?
<b>Description</b>	This query returns the pluggable module specification compliance.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<compliance> ,<compliance>* = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:COMP? → "10G Base-LR", "VSR2000-3R2", "VSR2000-3R2F"
<b>Note</b>	

## 15.1.6 PMODule:STATus:PORT&lt;Pt&gt;:PNUMber?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:PNUMber?
<b>Description</b>	This query returns the vendor part number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<partnumber> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:PNUM? → "ABC123"
<b>Note</b>	

## 15.1.7 PMODule:STATus:PORT&lt;Pt&gt;:REVision?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:REVision?
<b>Description</b>	This query returns the vendor revision level for part number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<revision> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:REV? → "1A"
<b>Note</b>	

## 15.1.8 PMODule:STATus:PORT&lt;Pt&gt;:SNUMber?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:SNUMber?
<b>Description</b>	This query returns the vendor serial number.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<serialnumber> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:SNUM? → "ABC123"
<b>Note</b>	

## 15.1.9 PMODule:STATus:PORT&lt;Pt&gt;:DATE?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:DATE?
<b>Description</b>	This query returns the vendor date code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<date> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:DATE? → "2000-01-01"
<b>Note</b>	

## 15.1.10 PMODule:STATus:PORT&lt;Pt&gt;:LOT?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:LOT?
<b>Description</b>	This query returns the vendor specific lot code.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<lot> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:LOT? → ""
<b>Note</b>	

**15.1.11 PMODule:STATus:PORT<Pt>:TPOWer?**

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:TPOWer?
<b>Description</b>	This query returns the transmitter power.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<total_power>{,<lane_n_power>}* = <STRING RESPONSE DATA> <lane_n_power> will be responded when the optical module has multiple lanes.
<b>Example</b>	PMOD:STAT:PORT1:TPOW? → "-1.00dBm"
<b>Note</b>	

**15.1.12 PMODule:STATus:PORT<Pt>:RPOWer?**

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:RPOWer?
<b>Description</b>	This query returns the receiver power.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<total_power>{,<lane_n_power>}* = <STRING RESPONSE DATA> <lane_n_power> will be responded when the optical module has multiple lanes.
<b>Example</b>	PMOD:STAT:PORT1:RPOW? → "-40.00dBm"
<b>Note</b>	

**15.1.13 PMODule:STATus:PORT<Pt>:STATus?**

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:STATus?
<b>Description</b>	This query returns the Status of module.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<status> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:STAT? → "Data Ready"
<b>Note</b>	

**15.1.14 PMODule:STATus:PORT<Pt>:GALarm?**

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:GALarm?
<b>Description</b>	This query returns the Global Alarm of selected module.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<galarm> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:GAL? → "0"
<b>Note</b>	This command can be used on 40/100G

**15.1.15 PMODule:STATus:PORT<Pt>:PALarm?**

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:PALarm?
<b>Description</b>	This query returns the programmable alarm of selected module.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<palarm> = <STRING RESPONSE DATA>
<b>Example</b>	PMOD:STAT:PORT1:PAL? → "OK"
<b>Note</b>	This command can be used on 40/100G

## 15.1.16 PMODule:STATus:PORT&lt;Pt&gt;:AESummary[:EVENT]?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:AESummary[:EVENT]?
<b>Description</b>	This query returns the pluggable module alarms and errors summary event register. The content of this event register is summarized in DB10 of the STATus:INTerface:PORT<Pt>:CONDition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 - DB16 = NOT USED
<b>Example</b>	PMOD:STAT:PORT1:AES? → 1
<b>Note</b>	

## 15.1.17 PMODule:STATus:PORT&lt;Pt&gt;:AESummary:CONDition?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:AESummary:CONDition?
<b>Description</b>	This query returns the pluggable module alarms and errors summary condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Alarm summary DB2 - DB16 = NOT USED
<b>Example</b>	PMOD:STAT:PORT1:AES:COND?
<b>Note</b>	

## 15.1.18 PMODule:STATus:PORT&lt;Pt&gt;:ALARm[:EVENT]?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:ALARm[:EVENT]?
<b>Description</b>	This query returns the alarms event register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Module is no present DB2 (2) = NOT USED DB3 (4) = Global Alarm (CFP/CFP2) DB4 (8) = Programmable alarm 1 (CFP/CFP2) DB5 (16) = Programmable alarm 2 (CFP/CFP2) DB6 (32) = Programmable alarm 3 (CFP/CFP2) DB7 - DB16 = NOT USED
<b>Example</b>	PMOD:STAT:PORT1:ALAR?
<b>Note</b>	

## 15.1.19 PMODule:STATus:PORT&lt;Pt&gt;:ALARm:CONDition?

<b>Syntax</b>	PMODule:STATus:PORT<Pt>:ALARm:CONDition?
<b>Description</b>	This query returns the alarms condition register.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<register> = <NR1 NUMERIC RESPONSE DATA> DB1 (1) = Module is not present DB2 (2) = NOT USED DB3 (4) = Global Alarm (CFP/CFP2) DB4 (8) = Programmable alarm 1 (CFP/CFP2) DB5 (16) = Programmable alarm 2 (CFP/CFP2) DB6 (32) = Programmable alarm 3 (CFP/CFP2) DB7 - DB16 = NOT USED
<b>Example</b>	PMOD:STAT:PORT1:ALAR:COND?
<b>Note</b>	



## 15.2 MDIO

### 15.2.1 PMODule:PORT<Pt>:MDIO:WRITE

<b>Syntax</b>	PMODule:PORT<Pt>:MDIO:WRITE <addr>,<data>[,<trans>]
<b>Description</b>	MDIO write access.
<b>Parameters</b>	<Pt> = Port number <addr> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <data> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <trans> = <NUMERIC PROGRAM DATA> 0 : TX 1 : RX <i>DEFault = 0</i>
<b>Example</b>	PMOD:PORT1:MDIO:WRIT #H1234,#HFFFF
<b>Note</b>	This command can be used on V3.00 or later

### 15.2.2 PMODule:PORT<Pt>:MDIO:READ?

<b>Syntax</b>	PMODule:PORT<Pt>:MDIO:READ? <addr>[,<trans>]
<b>Description</b>	MDIO read access.
<b>Parameter</b>	<Pt> = Port number <addr> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <trans> = <NUMERIC PROGRAM DATA> 0 : TX 1 : RX <i>DEFault = 0</i>
<b>Response</b>	<register> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	PMOD:PORT1:MDIO:READ? #H1234,0 → #HFFFF
<b>Note</b>	This command can be used on V3.00 or later

## 15.3 I2C

### 15.3.1 PMODule:PORT<Pt>:I2C:WRITE

<b>Syntax</b>	PMODule:PORT<Pt>:I2C:WRITE <page>,<addr>,<data>
<b>Description</b>	I2C write access.
<b>Parameters</b>	<Pt> = Port number <page> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H00, MAXimum=#HFF, DEFault=#H00</i> <addr> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <data> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <trans> = <NUMERIC PROGRAM DATA> 0 : TX 1 : RX <i>DEFault = 0</i>
<b>Example</b>	PMOD:PORT1:I2C:WRIT #H00,12,#HFF
<b>Note</b>	This command can be used on V7.02 or later

### 15.3.2 PMODule:PORT<Pt>:I2C:READ?

<b>Syntax</b>	PMODule:PORT<Pt>:I2C:READ? <page>,<addr>
<b>Description</b>	I2C read access.
<b>Parameter</b>	<Pt> = Port number <addr> = <HEXADECIMAL NUMERIC PROGRAM DATA> <i>MINimum=#H0000, MAXimum=#HFFFF, DEFault=#H0000</i> <trans> = <NUMERIC PROGRAM DATA> 0 : TX 1 : RX <i>DEFault = 0</i>
<b>Response</b>	<register> = <HEXADECIMAL NUMERIC RESPONSE DATA>
<b>Example</b>	PMOD:PORT1:I2C:READ? #H00,12 → #HFFFF
<b>Note</b>	This command can be used on V7.02 or later

## 15.4 Tx reference clock output

### 15.4.1 PMODule:TOUTput:PORT<Pt>[:ENABLE]

<b>Syntax</b>	PMODule:TOUTput:PORT<Pt>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables Tx reference clock output.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	PMOD:TOUT:PORT1 ON
<b>Note</b>	Tx reference clock output can be enabled only one port on the same module. This command can be used on MT1100A

<b>Syntax</b>	PMODule:TOUTput:PORT<Pt>[:ENABLE]?
<b>Description</b>	This query returns the state of the Tx reference clock output.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	PMOD:TOUT:PORT1? → 1
<b>Note</b>	This command can be used on MT1100A

### 15.4.2 PMODule:TOUTput:PORT<Pt>:FREQuency

<b>Syntax</b>	PMODule:TOUTput:PORT<Pt>:FREQuency <frequency>
<b>Description</b>	This command sets the Tx reference clock output frequency on this module.
<b>Parameters</b>	<Pt> = Port number <frequency> = <CHARACTER PROGRAM DATA> DIV16: 1/16 (Tx clock frequency divided by 16) DIV64: 1/64 (Tx clock frequency divided by 64) <i>DEFault = DIV16</i>
<b>Response</b>	None.
<b>Example</b>	PMOD:TOUT:PORT1:FREQ DIV16
<b>Note</b>	This setting applies to all ports on the same module. This command can be used on MT1100A

<b>Syntax</b>	PMODule:TOUTput:PORT<Pt>:FREQuency?
<b>Description</b>	This query returns the Tx reference clock output frequency on this module.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frequency> = <CHARACTER RESPONSE DATA>
<b>Example</b>	PMOD:TOUT:PORT1:FREQ? → DIV16
<b>Note</b>	This command can be used on MT1100A

## 15.4.3 PModule:TOUTput:PORT&lt;Pt&gt;:SYNC:FREQuency

<b>Syntax</b>	PModule:TOUTput:PORT<Pt>:SYNC:FREQuency <frequency>
<b>Description</b>	This command sets the sync clock output frequency on this module.
<b>Parameters</b>	<Pt> = Port number <frequency> = <CHARACTER PROGRAM DATA> Off DIV8: 1/8 (Sync clock frequency divided by 8) DIV16: 1/16 (Sync clock frequency divided by 64) <i>DEFault = DIV16</i>
<b>Response</b>	None.
<b>Example</b>	PMOD:TOUT:PORT1:SYNC:FREQ DIV8
<b>Note</b>	This command can be used on MU110013A. This command can be used when interface type is CFP2 or QSFP28 Adpt..

<b>Syntax</b>	PModule:TOUTput:PORT<Pt>:SYNC:FREQuency?
<b>Description</b>	This query returns the sync clock output frequency on this module.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<frequency> = <CHARACTER RESPONSE DATA>
<b>Example</b>	PMOD:TOUT:PORT1:SYNC:FREQ? → DIV8
<b>Note</b>	This command can be used on MU110013A.



---

## Chapter 16

# Common Application Settings

### 16.1 RTD

The following commands are valid for all Round Trip Delay applications unless otherwise noted.

#### 16.1.1 RTD:MODE

<b>Syntax</b>	RTD:MODE <mode>
<b>Description</b>	This command sets the measurement mode.
<b>Parameters</b>	<mode> = <CHARACTER PROGRAM DATA> SINGle REPeat <i>DEFault = REPeat</i>
<b>Response</b>	None.
<b>Example</b>	RTD:MODE REP
<b>Note</b>	

<b>Syntax</b>	RTD:MODE?
<b>Description</b>	This query returns the measurement mode.
<b>Parameter</b>	None.
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	RTD:MODE? → REP
<b>Note</b>	

#### 16.1.2 RTD:PERiod

<b>Syntax</b>	RTD:PERiod <period>
<b>Description</b>	This command sets the measurement period.
<b>Parameters</b>	<period> = <CHARACTER PROGRAM DATA> MS500: 500 milli seconds SEC1: 1 second SEC2: 2 seconds SEC5: 5 seconds SEC10: 10 seconds <i>DEFault = SEC1</i>
<b>Response</b>	None.
<b>Example</b>	RTD:PER SEC1
<b>Note</b>	

<b>Syntax</b>	RTD:PERiod?
<b>Description</b>	This query returns the measurement period.
<b>Parameter</b>	None.
<b>Response</b>	<period> = <CHARACTER RESPONSE DATA>
<b>Example</b>	RTD:PER? → SEC1
<b>Note</b>	

### 16.1.3 RTD:IFMData

<b>Syntax</b>	RTD:IFMData <ignore>
<b>Description</b>	
<b>Parameters</b>	<ignore> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	RTD:IFMD OFF
<b>Note</b>	

<b>Syntax</b>	RTD:IFMData?
<b>Description</b>	
<b>Parameter</b>	None.
<b>Response</b>	<ignore> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	RTD:IFMD? → 0
<b>Note</b>	

### 16.1.4 RTD:PDH:RX<Pt>:MLIMit

<b>Syntax</b>	RTD:PDH:RX<Pt>:MLIMit <max>
<b>Description</b>	This command sets the time reference maximum limit for all PDH interfaces. Unit: us.
<b>Parameters</b>	<Pt> = Port number <max> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.0, MAXimum = 1000000.0, DEFault = MAXimum</i>
<b>Response</b>	None.
<b>Example</b>	RTD:PDH:RX1:MLIM 0.0
<b>Note</b>	This command is not valid for a RTD_OTN application.

<b>Syntax</b>	RTD:PDH:RX<Pt>:MLIMit?
<b>Description</b>	This query returns the time reference maximum limit for all PDH interfaces. Unit: us.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<max> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	RTD:PDH:RX1:MLIM? → 0.0
<b>Note</b>	This command is not valid for a RTD_OTN application.

## 16.2 Hierarchy

### 16.2.1 HIERarchy:PORT<Pt>:OTN:TX

<b>Syntax</b>	HIERarchy:PORT<Pt>:OTN:TX <enable>
<b>Description</b>	This command enables or disables the OTN Tx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:OTN:TX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:OTN:TX?
<b>Description</b>	This query returns whether or not OTN Tx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:OTN:TX? → 1
<b>Note</b>	

### 16.2.2 HIERarchy:PORT<Pt>:OTN:RX

<b>Syntax</b>	HIERarchy:PORT<Pt>:OTN:RX <enable>
<b>Description</b>	This command enables or disables the OTN Rx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:OTN:RX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:OTN:RX?
<b>Description</b>	This query returns whether or not OTN Rx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:OTN:RX? → 1
<b>Note</b>	

### 16.2.3 HIERarchy:PORT<Pt>:SDH:TX

<b>Syntax</b>	HIERarchy:PORT<Pt>:SDH:TX <enable>
<b>Description</b>	This command enables or disables the SDH Tx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:SDH:TX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:SDH:TX?
<b>Description</b>	This query returns whether or not SDH Tx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:SDH:TX? → 1
<b>Note</b>	

## 16.2.4 HIERarchy:PORT&lt;Pt&gt;:SDH:RX

<b>Syntax</b>	HIERarchy:PORT<Pt>:SDH:RX <enable>
<b>Description</b>	This command enables or disables the SDH Rx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:SDH:RX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:SDH:RX?
<b>Description</b>	This query returns whether or not SDH Rx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:SDH:RX? → 1
<b>Note</b>	

## 16.2.5 HIERarchy:PORT&lt;Pt&gt;:PDH:TX

<b>Syntax</b>	HIERarchy:PORT<Pt>:PDH:TX <enable>
<b>Description</b>	This command enables or disables the PDH Tx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:PDH:TX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:PDH:TX?
<b>Description</b>	This query returns whether or not PDH Tx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:PDH:TX? → 1
<b>Note</b>	

## 16.2.6 HIERarchy:PORT&lt;Pt&gt;:PDH:RX

<b>Syntax</b>	HIERarchy:PORT<Pt>:PDH:RX <enable>
<b>Description</b>	This command enables or disables the PDH Rx hierarchy.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	HIER:PORT1:PDH:RX ON
<b>Note</b>	

<b>Syntax</b>	HIERarchy:PORT<Pt>:PDH:RX?
<b>Description</b>	This query returns whether or not PDH Rx hierarchy is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	HIER:PORT1:PDH:RX? → 1
<b>Note</b>	



---

# Chapter 17

## Measurement

### 17.1 Application, Start and Stop

#### 17.1.1 MEASurement:APPLication?

<b>Syntax</b>	MEASurement:APPLication?
<b>Description</b>	This query returns the application server type.
<b>Parameter</b>	None.
<b>Response</b>	<application> = <CHARACTER RESPONSE DATA> TP-APS-OTN: OTN Automatic Protection Switching application. TP-APS-SDHPDH: SDH/PDH Automatic Protection Switching application. TP-APS-SDHPDH-OTN: SDH/PDH over OTN Automatic Protection Switching application. TP-BERT-CPRI: CPRI Bit Error Rate Test application. TP-BERT-CPRI-OTN: CPRI over OTN Bit Error Rate Test application. TP-BERT-ETH: Ethernet Bit Error Rate Test application. TP-BERT-ETH-OTN: Ethernet over OTN Bit Error Rate Test application. TP-BERT-FC: Fibre Channel Bit Error Rate Test application. TP-BERT-FC-OTN: Fibre Channel over OTN Bit Error Rate Test application. TP-BERT-OTN: OTN Bit Error Rate Test application. TP-BERT-SDHPDH: PDH/SDH Bit Error Rate Test application. TP-BERT-SDHPDH-OTN: PDH/SDH over OTN Bit Error Rate Test application. TP-CABLE-ETH: Ethernet cable test application. TP-CHSTAT-ETH: Ethernet channel statistics application. TP-MONGEN-ETH: Ethernet monitor/generate application. TP-MONGEN-ETH-OTN: Ethernet over OTN monitor/generate application. TP-NOFRAME-DEVICE: No frame device test (Unframed Bit Error Rate Test) application. TP-PASS-CPRI: CPRI pass-through application. TP-PASS-ETH: Ethernet pass-through application. TP-PING-ETH: Ethernet ICMP ping application. TP-REFL-ETH: Ethernet reflector application. TP-REFL-ETH-OTN: Ethernet over OTN reflector application. TP-REFL-FC: Fibre Channel reflector application. TP-REFL-FC-OTN: Fibre Channel over OTN reflector application. TP-RFC-ETH: Ethernet RFC-2544 test application. TP-RFC-ETH-OTN: Ethernet over OTN RFC-2544 test application. TP-RFC6349-ETH: Ethernet RFC-6349 test application. TP-RTD-OTN: OTN Round Trip Delay test application. TP-RTD-SDHPDH: SDH/PDH Round Trip Delay test application. TP-RTD-SDHPDH-OTN: SDH/PDH Round Trip Delay test application. TP-SAT-ETH: Ethernet Service Activation Test application. TP-SAT-ETH-OTN: Ethernet over OTN Service Activation Test application. TP-TRACE-ETH: Ethernet trace-route application. TP-SYNCTEST-ETH: Ethernet sync test application.
<b>Example</b>	MEAS:APPL? → TP-BERT-ETH
<b>Note</b>	

### 17.1.2 MEASurement:START

<b>Syntax</b>	MEASurement:START
<b>Description</b>	This command starts a measurement. Same as pressing the START button on the GUI.
<b>Parameter</b>	None
<b>Response</b>	None.
<b>Example</b>	MEAS:STAR
<b>Note</b>	

### 17.1.3 MEASurement:STOP

<b>Syntax</b>	MEASurement:STOP
<b>Description</b>	This command stops an ongoing measurement. Same as pressing the STOP button on the GUI.
<b>Parameter</b>	None.
<b>Response</b>	None.
<b>Example</b>	MEAS:STOP
<b>Note</b>	

## 17.2 Setup

### 17.2.1 MEASurement:SETup:PORT<Pt>:TERMinology

<b>Syntax</b>	MEASurement:SETup:PORT<Pt>:TERMinology <mode>
<b>Description</b>	This command sets the SDH/SONET terminology.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> SONet SDH <i>DEFault = SDH</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PORT1:TERM SDH
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PORT<Pt>:TERMinology?
<b>Description</b>	This query returns the SDH/SONET terminology.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PORT1:TERM? → SDH
<b>Note</b>	

### 17.2.2 MEASurement:SETup:SElect

<b>Syntax</b>	MEASurement:SETup:SElect <interval>
<b>Description</b>	This command selects which interval to fetch. After setting this command, the :IFETch on the respective interfaces should be performed.
<b>Parameter</b>	<interval> = <CHARACTER PROGRAM DATA> TOTal: Total CURRent: Current Or the index number of the interval. With the first index number being 0. <i>DEFault = TOTal</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:SEL 5
<b>Note</b>	Use MEAS:INFO:IMIN? and MEAS:INFO:IMAX? to get the minimum and maximum interval number. This setting is not stored as part of a settings- or result file.

<b>Syntax</b>	MEASurement:SETup:SElect?
<b>Description</b>	This query returns the selected interval.
<b>Parameter</b>	None.
<b>Response</b>	<interval> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:SEL? → 5
<b>Note</b>	

### 17.2.3 MEASurement:SETup:ILENgtH

<b>Syntax</b>	MEASurement:SETup:ILENgtH <length>
<b>Description</b>	This command sets the interval length.
<b>Parameter</b>	<length> = <CHARACTER PROGRAM DATA> 1S: 1 second 2S: 2 seconds 5S: 5 seconds 10S: 10 seconds 15S: 15 seconds 30S: 30 seconds 1M: 1 minute 5M: 5 minutes 10M: 10 minutes 15M: 15 minutes 30M: 30 minutes 1H: 1 hour 2H: 2 hours 4H: 4 hours 6H: 6 hours 12H: 12 hours NONE: No intervals <i>DEFault = 5S</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:ILEN 1S
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:ILENgtH?
<b>Description</b>	This query returns the interval length.
<b>Parameter</b>	None.
<b>Response</b>	<action> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:ILEN? → 1S
<b>Note</b>	

### 17.2.4 MEASurement:SETup:STARt

<b>Syntax</b>	MEASurement:SETup:STARt <action>
<b>Description</b>	This command sets how the measurement should start.
<b>Parameter</b>	<action> = <CHARACTER PROGRAM DATA> IMMediate: Start measurement immediate. SAT: Start measurement at a specific time. <i>DEFault = IMMediate</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:STAR SAT
<b>Note</b>	Use the MEASurement:SETup:STAT command to set the specific start time.

<b>Syntax</b>	MEASurement:SETup:STARt?
<b>Description</b>	This query returns how the measurement starts.
<b>Parameter</b>	None.
<b>Response</b>	<action> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:STAR? → SAT
<b>Note</b>	

### 17.2.5 MEASurement:SETup:STAT

<b>Syntax</b>	MEASurement:SETup:STAT <year>,<month>,<day>,<hour>,<minute>,<second>
<b>Description</b>	This command sets the start time for the MEASurement:SETup:STARt SAT command.
<b>Parameters</b>	<year> = <NUMERIC PROGRAM DATA> <i>MINimum = 1997, MAXimum = 2036</i> <month> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 12</i> <day> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 31</i> <hour> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 23</i> <minute> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i> <second> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:STAT 2015,7,16,10,11,39
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:STAT?
<b>Description</b>	This query returns the start time for the MEASurement:SETup:STARt SAT command
<b>Parameter</b>	None.
<b>Response</b>	<year> = <NR1 NUMERIC RESPONSE DATA> <month> = <NR1 NUMERIC RESPONSE DATA> <day> = <NR1 NUMERIC RESPONSE DATA> <hour> = <NR1 NUMERIC RESPONSE DATA> <minute> = <NR1 NUMERIC RESPONSE DATA> <second> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:STAT? → 2015,7,16,10,11,39
<b>Note</b>	If the SAT parameter is not set in the MEASurement:SETup:STARt command, this query returns NaN (section 1.6.1).

### 17.2.6 MEASurement:SETup:STOP

<b>Syntax</b>	MEASurement:SETup:STOP <action>
<b>Description</b>	This command sets how the measurement should stop.
<b>Parameter</b>	<action> = <CHARACTER PROGRAM DATA> MANual: Manual stop the measurement. SAT: Stop measurement at a specific time. DURation: Stop measurement after a specific duration. <i>DEFault = MANual</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:STOP DUR
<b>Note</b>	To set the specific stop time, use the MEASurement:SETup:SPAT command.

<b>Syntax</b>	MEASurement:SETup:STOP?
<b>Description</b>	This query returns how the measurement stops.
<b>Parameter</b>	None.
<b>Response</b>	<action> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:STOP? → DUR
<b>Note</b>	

### 17.2.7 MEASurement:SETup:SPAT

<b>Syntax</b>	MEASurement:SETup:SPAT <year>,<month>,<day>,<hour>,<minute>,<second>
<b>Description</b>	This command sets the stop time for the MEASurement:SETup:STOP SAT command
<b>Parameters</b>	<year> = <NUMERIC PROGRAM DATA> <i>MINimum = 1997, MAXimum = 2036</i> <month> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 12</i> <day> = <NUMERIC PROGRAM DATA> <i>MINimum = 1, MAXimum = 31</i> <hour> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 23</i> <minute> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i> <second> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 59</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:SPAT 2015,7,16,10,12,39
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:SPAT?
<b>Description</b>	This query returns the stop time for the MEASurement:SETup:STOP SAT command
<b>Parameter</b>	None.
<b>Response</b>	<year> = <NR1 NUMERIC RESPONSE DATA> <month> = <NR1 NUMERIC RESPONSE DATA> <day> = <NR1 NUMERIC RESPONSE DATA> <hour> = <NR1 NUMERIC RESPONSE DATA> <minute> = <NR1 NUMERIC RESPONSE DATA> <second> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:SPAT? → 2015,7,16,10,12,39
<b>Note</b>	If the SAT parameter is not set in the MEASurement:SETup:STOP command, this query returns NaN (section 1.6.1).

### 17.2.8 MEASurement:SETup:SDURation

<b>Syntax</b>	MEASurement:SETup:SDURation <days>,<hours>,<minutes>,<seconds>
<b>Description</b>	This command sets the duration time for the MEASurement:SETup:STOP DUR command.
<b>Parameters</b>	<days> = <NUMERIC PROGRAM DATA> <hours> = <NUMERIC PROGRAM DATA> <minutes> = <NUMERIC PROGRAM DATA> <seconds> = <NUMERIC PROGRAM DATA>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:SDUR 16,0,0,0
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:SDURation?
<b>Description</b>	This query return the duration time for the MEASurement:SETup:STOP DUR command
<b>Parameter</b>	None.
<b>Response</b>	<days> = <NR1 NUMERIC RESPONSE DATA> <hours> = <NR1 NUMERIC RESPONSE DATA> <minutes> = <NR1 NUMERIC RESPONSE DATA> <seconds> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:SDUR? → 16,0,0,0
<b>Note</b>	If not defined or the DUR parameter is not set in the MEASurement:SETup:STOP command, this query returns NaN (section 1.6.1).

### 17.2.9 MEASurement:SETup:MALLocation

<b>Syntax</b>	MEASurement:SETup:MALLocation <mode>
<b>Description</b>	This command sets the memory allocation.
<b>Parameter</b>	<mode> = <CHARACTER PROGRAM DATA> CONTinuous: When storage space runs out old intervals will be overwritten. ALL: Uses all available storage space and then stops the measurement. <i>DEFault = CONTinuous</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:MALL CONT
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:MALLocation?
<b>Description</b>	This query returns the type of memory allocation.
<b>Parameter</b>	None.
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:MALL? → CONT
<b>Note</b>	

### 17.2.10 MEASurement:SETup:PERFormance:TMBPs:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:TMBPs:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for 2 Mbps and V-Series.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G821: G.821 G826: G.826 M2100: M.2100 G821E: G.821 (expired revision) <i>DEFault = M2100</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:TMBP:PAR G826
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:TMBPs:PARAmeter?
<b>Description</b>	This query returns the performance parameter for 2 Mbps and V-Series.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:TMBP:PAR? → G826
<b>Note</b>	

### 17.2.11 MEASurement:SETup:PERFormance:T1:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:T1:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for 2 Mbps and V-Series.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G821: G.821 G826: G.826 M2100: M.2100 G821E: G.821 (expired revision) <i>DEFault = M2100</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:T1:PAR G826
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:T1:PARAmeter?
<b>Description</b>	This query returns the performance parameter for 2 Mbps and V-Series.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:T1:PAR? → G826
<b>Note</b>	

### 17.2.12 MEASurement:SETup:PERFormance:E3:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:E3:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for E3.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 M2100: M.2100 <i>DEFault = M2100</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:E3:PAR M2100
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:E3:PARAmeter?
<b>Description</b>	This query returns the performance parameter for E3.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:E3:PAR? → M2100
<b>Note</b>	

### 17.2.13 MEASurement:SETup:PERFormance:T3:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:T3:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for E3.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 M2100: M.2100 <i>DEFault = M2100</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:T3:PAR M2100
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:T3:PARAmeter?
<b>Description</b>	This query returns the performance parameter for E3.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:T3:PAR? → M2100
<b>Note</b>	

#### 17.2.14 MEASurement:SETup:PERFormance:E4:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:E4:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for E4.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 M2100: M.2100 <i>DEFault = M2100</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:E4:PAR M2100
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:E4:PARAmeter?
<b>Description</b>	This query returns the performance parameter for E4.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:E4:PAR? → M2100
<b>Note</b>	

#### 17.2.15 MEASurement:SETup:PERFormance:SDH:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for SDH.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 G828: G.828+G.829 M2101: M.2101.1(M.2100) <i>DEFault = M2101</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:PAR M2101
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:PARAmeter?
<b>Description</b>	This query returns the performance parameter for SDH.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:PAR? → M2101
<b>Note</b>	

#### 17.2.16 MEASurement:SETup:PERFormance:SDH:MUX

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:MUX <value>
<b>Description</b>	This command sets the MUX allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:MUX 10.00
<b>Note</b>	



<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:MUX?
<b>Description</b>	This query returns the MUX allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:MUX? → 10.00
<b>Note</b>	

### 17.2.17 MEASurement:SETup:PERFormance:SDH:VC4

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC4 <value>
<b>Description</b>	This command sets the VC4 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:VC4 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC4?
<b>Description</b>	This query returns the VC4 Allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:VC4? → 10.00
<b>Note</b>	

### 17.2.18 MEASurement:SETup:PERFormance:SDH:VC3

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC3 <value>
<b>Description</b>	This command sets the VC3 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:VC3 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC3?
<b>Description</b>	This query returns the VC3 allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:VC3? → 10.00
<b>Note</b>	

### 17.2.19 MEASurement:SETup:PERFormance:SDH:VC12

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC12 <value>
<b>Description</b>	This command sets the VC12 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:VC12 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:VC12?
<b>Description</b>	This query returns the VC12 allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:VC12? → 10.00
<b>Note</b>	

### 17.2.20 MEASurement:SETup:PERFormance:SDH:TPERiod

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:TPERiod <period>
<b>Description</b>	This command sets the evaluation item for SDH.
<b>Parameter</b>	<period> = <CHARACTER PROGRAM DATA> 15M: 15 minutes 1H: 1 hour 2H: 2 hours 24H: 24 hours 7D: 7 days <i>DEFault = 15M</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SDH:TPER 1H
<b>Note</b>	Only valid when the SDH performance parameter is M.2101.1.

<b>Syntax</b>	MEASurement:SETup:PERFormance:SDH:TPERiod?
<b>Description</b>	This query returns the evaluation item for SDH.
<b>Parameter</b>	None.
<b>Response</b>	<period> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SDH:TPER? → 1H
<b>Note</b>	

### 17.2.21 MEASurement:SETup:PERFormance:SONet:PARAmeter

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for SDH.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 G828: G.828+G.829 M2101: M.2101.1(M.2100) <i>DEFault = M2101</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:PAR M2101
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:PARAmeter?
<b>Description</b>	This query returns the performance parameter for SONET.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:PAR? → M2101
<b>Note</b>	

**17.2.22 MEASurement:SETup:PERFormance:SONet:MUX**

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:MUX <value>
<b>Description</b>	This command sets the MUX allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:MUX 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:MUX?
<b>Description</b>	This query returns the MUX allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:MUX? → 10.00
<b>Note</b>	

**17.2.23 MEASurement:SETup:PERFormance:SONet:STS3**

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:STS3 <value>
<b>Description</b>	This command sets the STS3 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:STS3 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:STS3?
<b>Description</b>	This query returns the STS3 Allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:STS3? → 10.00
<b>Note</b>	

**17.2.24 MEASurement:SETup:PERFormance:SONet:STS1**

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:STS1 <value>
<b>Description</b>	This command sets the STS1 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:STS1 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERFormance:SONet:STS1?
<b>Description</b>	This query returns the STS1 allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:STS1? → 10.00
<b>Note</b>	

**17.2.25 MEASurement:SETup:PERformance:SONet:VT2**

<b>Syntax</b>	MEASurement:SETup:PERformance:SONet:VT2 <value>
<b>Description</b>	This command sets the VC12 allocation in percentage.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:VT2 10.00
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:PERformance:SONet:VT2?
<b>Description</b>	This query returns the VT2 allocation in percentage.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:VT2? → 10.00
<b>Note</b>	

**17.2.26 MEASurement:SETup:PERformance:SONet:TPERiod**

<b>Syntax</b>	MEASurement:SETup:PERformance:SONet:TPERiod <period>
<b>Description</b>	This command sets the evaluation item for SONET.
<b>Parameter</b>	<period> = <CHARACTER PROGRAM DATA> 15M: 15 minutes 1H: 1 hour 2H: 2 hours 24H: 24 hours 7D: 7 days <i>DEFault = 15M</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:SON:TPER 1H
<b>Note</b>	Only valid when the SDH performance parameter is M.2101.1.

<b>Syntax</b>	MEASurement:SETup:PERformance:SONet:TPERiod?
<b>Description</b>	This query returns the evaluation item for SONET.
<b>Parameter</b>	None.
<b>Response</b>	<period> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:SON:TPER? → 1H
<b>Note</b>	

**17.2.27 MEASurement:SETup:PERformance:WAN:PARAmeter**

<b>Syntax</b>	MEASurement:SETup:PERformance:WAN:PARAmeter <param>
<b>Description</b>	This command sets the performance parameter for 10G WAN.
<b>Parameter</b>	<param> = <CHARACTER PROGRAM DATA> G826: G.826 G828: G.828+G.829 M2101: M.2101.1(M.2100) <i>DEFault = G826</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:PERF:WAN:PAR M2101
<b>Note</b>	This command can be used on V2.00 or later

<b>Syntax</b>	MEASurement:SETup:PERFormance:WAN:PARAmeter?
<b>Description</b>	This query returns the performance parameter for 10G WAN.
<b>Parameter</b>	None.
<b>Response</b>	<param> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:PERF:WAN:PAR? → M2101
<b>Note</b>	This command can be used on V2.00 or later

### 17.2.28 MEASurement:SETup:EVALuation:RX<Pt>[:ENABLE]

<b>Syntax</b>	MEASurement:SETup:EVALuation:RX<Pt>[:ENABLE] <enable>
<b>Description</b>	This command enables/disables the transport evaluation.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	MEAS:SET:EVAL:RX ON
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:RX<Pt>[:ENABLE]?
<b>Description</b>	This query returns whether or not the transport evaluation is enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <NR1 NUMERIC RESPONSE DATA>
<b>Examples</b>	MEAS:SET:EVAL:RX? → 1
<b>Note</b>	

### 17.2.29 MEASurement:SETup:EVALuation:RX<Pt>:INTerface

<b>Syntax</b>	MEASurement:SETup:EVALuation:RX<Pt>:INTerface <interface>
<b>Description</b>	This command sets the transport evaluation interface type.
<b>Parameters</b>	<Pt> = Port number <interface> = <CHARACTER PROGRAM DATA> E1 E3 DS1 DS3 E4 SDH OTN CPRI The selectable interface type varies depending on the interface configuration.
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:RX:INT SDH
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:RX<Pt>:INTerface?
<b>Description</b>	This query returns the transport evaluation interface type.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<interface> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:RX:INT? → SDH
<b>Note</b>	

### 17.2.30 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM <item>
<b>Description</b>	This commands sets the evaluation item for CPRI.

continued on next page...

...continued from previous page

<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any Alarm or Error ALARm: Alarm ERRor: Error <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM ANY
<b>Note</b>	None.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM?
<b>Description</b>	This query returns the evaluation item for CPRI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM? → ANY
<b>Note</b>	

### 17.2.31 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ALARm

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ALARm <item>
<b>Description</b>	This commands sets the evaluation alarm item for CPRI.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> SLOS: Optical Loss of signal OPL: SLOS LOS: Loss of Signal LOF: Loss of Frame PSL: PSL L1LOS: Remote LOS L1LOF: Remote LOF RAI: RAI SDI: SDI <i>DEFault = SLOS</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM:ALAR SLOS
<b>Note</b>	None.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ALARm?
<b>Description</b>	This query returns the evaluation alarm item for CPRI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM:ALAR? → LOS
<b>Note</b>	

### 17.2.32 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ERRor

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ERRor <item>
<b>Description</b>	This commands sets the evaluation errors item for CPRI.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> LCV: LCV SHV: SHV

continued on next page...

... continued from previous page

	K307: K30.7 PATT: Pattern Error <i>DEFault = LCV</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM:ERR LCV
<b>Note</b>	None.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:ITEM:ERRor?
<b>Description</b>	This query returns the evaluation errors item for CPRI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:ITEM:ERR? → LCV
<b>Note</b>	

### 17.2.33 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:TYPE <type>
<b>Description</b>	This commands sets the evaluation type for CPRI.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:TYPE CNT
<b>Note</b>	None.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for CPRI.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:TYPE? → CNT
<b>Note</b>	

### 17.2.34 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the count for the CPRI PASS limit. <Pt> = Port number
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT, ESCount or SESCount. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:PASS?
<b>Description</b>	This query returns the count for the CPRI PASS limit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:CNT:PASS? → 10
<b>Note</b>	

**17.2.35 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the count for the CPRI fail limit.
<b>Parameter</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT, ESCount or SESCount. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the count for the CPRI fail limit.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:CNT:FAIL? → 10
<b>Note</b>	

**17.2.36 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the CPRI pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:RAT:PASS 0.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the CPRI pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:RAT:PASS? → 1.00E-01
<b>Note</b>	

**17.2.37 MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the CPRI fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:RAT:FAIL 0.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:CPRI:PORT<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the CPRI fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:CPRI:PORT1:RAT:FAIL? → 1.00E-01
<b>Note</b>	



## 17.2.38 MEASurement:SETup:EVALuation:TMBPs:RX&lt;Pt&gt;:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for 2 Mbps.
<b>Parameter</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm PATtern: Payload Pattern FAS: FAS CRC: CRC-4 EBIT: E-bit <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:ITEM PATT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:ITEM?
<b>Description</b>	This query the evaluation item for 2 Mbps.
<b>Parameter</b>	None.
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:ITEM? → PATT
<b>Note</b>	

## 17.2.39 MEASurement:SETup:EVALuation:TMBPs:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for 2 Mbps.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Error Count RATio: Error Ratio EPCT: Error percentage ESCount: ES error count ESRatio: ES error ratio ESPct: ES error percentage SESCount: SES error count SESPct: SES error percentage HRPct: HR% HRPBis: HR% BIS <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:TYPE ERAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for 2 Mbps.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:TYPE? → ERAT
<b>Note</b>	

**17.2.40 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the 2Mbps pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT, ESCount or SESCount. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the 2Mbps pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:CNT:PASS? → 10
<b>Note</b>	

**17.2.41 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the 2Mbps fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT, ESCount or SESCount. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the 2Mbps fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:CNT:FAIL? → 10
<b>Note</b>	

**17.2.42 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the 2Mbps pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio or ESRatio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the 2Mbps pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	

**17.2.43 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the 2Mbps fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio or ESRatio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the 2Mbps fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

**17.2.44 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:PASS <value>
<b>Description</b>	This command sets the percentage for the 2 Mbps pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:PCT:PASS 10
<b>Note</b>	This setting applies when :TYPE is EPCT, ESPct or SESPct. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:PASS?
<b>Description</b>	This query returns the percentage for the 2 Mbps pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:PCT:PASS? → 10
<b>Note</b>	

**17.2.45 MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:FAIL <value>
<b>Description</b>	This command sets the percentage for the 2 Mbps fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:PCT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is EPCT, ESPct or SESPct. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:PCT:FAIL?
<b>Description</b>	This query returns the percentage for the 2 Mbps fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:PCT:FAIL? → 10
<b>Note</b>	

## 17.2.46 MEASurement:SETup:EVALuation:TMBPs:RX&lt;Pt&gt;:HREFerence

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:HREFerence <percent>
<b>Description</b>	This command sets the HR%.
<b>Parameter</b>	<Pt> = Port number <percent> = <NUMERIC PROGRAM DATA> <i>MINimum=0.00, MAXimum=100.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:HREF 10.00
<b>Note</b>	This setting applies when :TYPE is HRPcT or HRPBis. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:TMBPs:RX<Pt>:HREFerence?
<b>Description</b>	This query return the HR%.
<b>Parameter</b>	None.
<b>Response</b>	<percent> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:TMBP:RX1:HREF? → 10.00
<b>Note</b>	

## 17.2.47 MEASurement:SETup:EVALuation:E3:RX&lt;Pt&gt;:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for E3.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm NSIGnal: No signal AIS: Alarm Indication Signal NFRame: No frame DISTant: Distant NSYNc: No sync FASWords: FAS words FASBits: FAS bits CODE: Code PATtern: Pattern PSLips: Pattern slips BLOCK: Block <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:ITEM NSIG
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:ITEM?
<b>Description</b>	This query returns the evaluation item for E3.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:ITEM? → NSIG
<b>Note</b>	

## 17.2.48 MEASurement:SETup:EVALuation:E3:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for E3.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:TYPE RAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for E3.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:TYPE? → RAT
<b>Note</b>	

## 17.2.49 MEASurement:SETup:EVALuation:E3:RX&lt;Pt&gt;:CNT:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the E3 pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the E3 pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:CNT:PASS? → 10
<b>Note</b>	

## 17.2.50 MEASurement:SETup:EVALuation:E3:RX&lt;Pt&gt;:CNT:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the E3 fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the E3 fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:CNT:FAIL? → 10
<b>Note</b>	

**17.2.51 MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the E3 pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the E3 pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	

**17.2.52 MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the E3 fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E3:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the E3 fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E3:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

## 17.2.53 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for E4.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm NSIGnal: No signal AIS: Alarm Indication Signal NFRame: No frame DISTant: Distant NSYNc: No sync FASWords: FAS words FASBits: FAS bits CODE: Code PATtern: Pattern PSLips: Pattern slips PBLock: Pattern block FBLock: Frame block <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:ITEM NSIG
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:ITEM?
<b>Description</b>	This query returns the evaluation item for E4.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:ITEM? → NSIG
<b>Note</b>	

## 17.2.54 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for E4.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:TYPE RAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for E4.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:TYPE? → RAT
<b>Note</b>	

## 17.2.55 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:CNT:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the E4 pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the E4 pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:CNT:PASS? → 10
<b>Note</b>	

## 17.2.56 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:CNT:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the E4 fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the E4 fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:CNT:FAIL? → 10
<b>Note</b>	

## 17.2.57 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:RATio:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the E4 pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the E4 pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	



## 17.2.58 MEASurement:SETup:EVALuation:E4:RX&lt;Pt&gt;:RATio:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the E4 fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:E4:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the E4 fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:E4:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

## 17.2.59 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm ALARm: An alarm defined by MEAS:SET:EVAL:SDH:RX<Pt>:ITEM:ALAR ERRor: An error defined by MEAS:SET:EVAL:SDH:RX<Pt>:ITEM:ERR <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM ALAR
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM?
<b>Description</b>	This query the evaluation item for 2 Mbps.
<b>Parameter</b>	None.
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM? → PATT
<b>Note</b>	

## 17.2.60 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:ITEM:ALARm

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ALARm <item>
<b>Description</b>	This commands sets the evaluation item for SDH.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> LOS: LOS LOF: LOF OOF: OOF MSAIS: MS-AIS MSRDI: MS-RDI AUAIS: AU-AIS AULOP: AU-LOP HPTIM: HP-TIM HPPLM: HP-PLM HPUNEQ: HP-UNEQ HPRDI: HP-RDI TUAIS: TU-AIS TULOP: TU-LOP TULOM: TU-LOM LPTIM: LP-TIM LPUNEQ: LP-UNEQ LPRDI: LP-RDI LSS: LSS LPPLM: LP-PLM TCUNEQ: TC-UNEQ TCLTC: TC-LTC TCTIM: TC-TIM TCAIS: TC-AIS TCRDI: TC-RDI TCODI: TC-ODI GAIS: G-AIS <i>DEFault = LOS</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM:ALAR LOS
<b>Note</b>	This setting applies when :ITEM is ALARm. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ALARm?
<b>Description</b>	This query returns the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM:ALAR? → LOS
<b>Note</b>	

## 17.2.61 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:ITEM:ERRor

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ERRor <item>
<b>Description</b>	This commands sets the evaluation item for SDH.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> A1A2: A1A2 B1: B1-BIP B2: B2-BIP MSREI: MS-REI B3: B3-BIP HPREI: HP-REI V5LP: V5/LP-B3 LPREI: LP-REI TUNDF: TU-NDF AUNDF: AU-NDF APS: Switch APS TUMN: TU-MVT-Negative TUMP: TU-MVT-Positive AUMN: AU-MVT-Negative AUMP: AU-MVT-Positive TCIEC: TC-IEC TCBIP: TC-BIP-2 TCREI: TC-REI TCOEI: TC-OEI <i>DEFault = A1A2</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM:ERR A1A2
<b>Note</b>	This setting applies when :ITEM is ERRor. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:ITEM:ERRor?
<b>Description</b>	This query returns the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:ITEM:ERR? → A1A2
<b>Note</b>	

## 17.2.62 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for SDH.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:TYPE RAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for SDH.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:TYPE? → RAT
<b>Note</b>	

## 17.2.63 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:CNT:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the SDH pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the SDH pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:CNT:PASS? → 10
<b>Note</b>	

## 17.2.64 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:CNT:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the SDH fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the SDH fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:CNT:FAIL? → 10
<b>Note</b>	

## 17.2.65 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:RATio:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the SDH pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the SDH pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	

## 17.2.66 MEASurement:SETup:EVALuation:SDH:RX&lt;Pt&gt;:RATio:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the SDH fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SDH:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the SDH fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SDH:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

## 17.2.67 MEASurement:SETup:EVALuation:SONet:RX&lt;Pt&gt;:ITEM

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm ALARm: An alarm defined by MEAS:SET:EVAL:SON:RX<Pt>:ITEM:ALAR ERRor: An error defined by MEAS:SET:EVAL:SON:RX<Pt>:ITEM:ERR <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM ALAR
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM?
<b>Description</b>	This query the evaluation item for 2 Mbps.
<b>Parameter</b>	None.
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM? → PATT
<b>Note</b>	

## 17.2.68 MEASurement:SETup:EVALuation:SONet:RX&lt;Pt&gt;:ITEM:ALARm

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ALARm <item>
<b>Description</b>	This commands sets the evaluation item for SDH.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> LOS: LOS LOF: LOF OOF: OOF AISL: MS-AIS RDIL: MS-RDI AISP: AU-AIS LOPP: AU-LOP TIMP: HP-TIM PLMP: HP-PLM UNEQP: HP-UNEQ RDIP: HP-RDI AISV: TU-AIS LOPV: TU-LOP LOMV: TU-LOM TIMV: LP-TIM UNEQV: LP-UNEQ RDIV: LP-RDI LSS: LSS PLMV: LP-PLM TCUNEQ: TC-UNEQ TCLTC: TC-LTC TCTIM: TC-TIM TCAIS: TC-AIS TCRDI: TC-RDI TCODI: TC-ODI GAIS: G-AIS <i>DEFault = LOS</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM:ALAR LOS
<b>Note</b>	This setting applies when :ITEM is ALARm. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ALARm?
<b>Description</b>	This query returns the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM:ALAR? → LOS
<b>Note</b>	

## 17.2.69 MEASurement:SETup:EVALuation:SONet:RX&lt;Pt&gt;:ITEM:ERRor

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ERRor <item>
<b>Description</b>	This commands sets the evaluation item for SDH.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> A1A2: A1A2 B1: B1-BIP B2: B2-BIP REIL: MS-REI B3: B3-BIP REIP: HP-REI V5LP: V5/LP-B3 REIV: LP-REI VTNDF: TU-NDF STSNDF:AU-NDF APS: Switch APS TUMN: TU-MVT-Negative TUMP: TU-MVT-Positive AUMN: AU-MVT-Negative AUMP: AU-MVT-Positive TCIEC: TC-IEC TCBIP: TC-BIP-2 TCREI: TC-REI TCOEI: TC-OEI <i>DEFault = A1A2</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM:ERR A1A2
<b>Note</b>	This setting applies when :ITEM is ERRor. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:ITEM:ERRor?
<b>Description</b>	This query returns the evaluation item for SDH.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:ITEM:ERR? → A1A2
<b>Note</b>	

## 17.2.70 MEASurement:SETup:EVALuation:SONet:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for SDH.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:TYPE RAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for SDH.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:TYPE? → RAT
<b>Note</b>	

**17.2.71 MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the SDH pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the SDH pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:CNT:PASS? → 10
<b>Note</b>	

**17.2.72 MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the SDH fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the SDH fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:CNT:FAIL? → 10
<b>Note</b>	

**17.2.73 MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:PASS**

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the SDH pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the SDH pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	



**17.2.74 MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:FAIL**

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the SDH fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:SONet:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the SDH fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:SON:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

**17.2.75 MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM**

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM <item>
<b>Description</b>	This command sets the evaluation item for OTN.
<b>Parameter</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> ANY: Any error or alarm AL1: An alarm at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ALAR AL2: An alarm at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ALAR AL3: An alarm at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ALAR EL1: An error at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ERR EL2: An error at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ERR EL3: An error at level 1 defined by MEAS:SET:EVAL:OTN:RX<Pt>:ITEM:ERR <i>DEFault = ANY</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM PATT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM?
<b>Description</b>	This query the evaluation item for 2 Mbps.
<b>Parameter</b>	None.
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM? → PATT
<b>Note</b>	

**17.2.76 MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ALARm**

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ALARm <item>
<b>Description</b>	This commands sets the evaluation item for OTN.
<b>Parameters</b>	<Pt> = Port number <item> = <CHARACTER PROGRAM DATA> LOS: LOS OTU AIS: OTU-AIS LOF: LOF LOFLOM: LOFLOM OOF: OOF LOM: LOM OOM: OOM

continued on next page...

... continued from previous page

	SMTIM: SM-TIM SMBIAE: SM-BIAE SMBDI: SM-BDI SMIAE: SM-IAE ODU AIS: ODU-AIS ODULCK: ODU-LCK ODUOCI: ODU-OCI PMTIM: PM-TIM PMBDI: PM-BDI TCM1TIM: TCM1-TIM TCM1BIAE: TCM1-BIAE TCM1BDI: TCM1-BDI TCM1IAE: TCM1-IAE TCM1LTC: TCM1-LTC TCM2TIM: TCM2-TIM TCM2BIAE: TCM2-BIAE TCM2BDI: TCM2-BDI TCM2IAE: TCM2-IAE TCM2LTC: TCM2-LTC TCM3TIM: TCM3-TIM TCM3BIAE: TCM3-BIAE TCM3BDI: TCM3-BDI TCM3IAE: TCM3-IAE TCM3LTC: TCM3-LTC TCM4TIM: TCM4-TIM TCM4BIAE: TCM4-BIAE TCM4BDI: TCM4-BDI TCM4IAE: TCM4-IAE TCM4LTC: TCM4-LTC TCM5TIM: TCM5-TIM TCM5BIAE: TCM5-BIAE TCM5BDI: TCM5-BDI TCM5IAE: TCM5-IAE TCM5LTC: TCM5-LTC TCM6TIM: TCM6-TIM TCM6BIAE: TCM6-BIAE TCM6BDI: TCM6-BDI TCM6IAE: TCM6-IAE TCM6LTC: TCM6-LTC PLM: PLM MSIM: MSIM AISC: CI-AIS CSF: CSF LSS: LSS <i>DEFault = LOS</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM:ALAR LOS
<b>Note</b>	This setting applies when :ITEM is AL1, AL2 or AL3. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ALARm?
<b>Description</b>	This query returns the evaluation item for OTN.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM:ALAR? → LOS
<b>Note</b>	

## 17.2.77 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:ITEM:ERRor

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ERRor <item>
<b>Description</b>	This commands sets the evaluation item for OTN.
<b>Parameters</b>	<p>&lt;Pt&gt; = Port number</p> <p>&lt;item&gt; = &lt;CHARACTER PROGRAM DATA&gt;</p> <p>FAS: FAS  MFAS: MFAS  SMBIP: SM-BIP8  SMBEI: SM-BEI  FCE: FCE  FUEB: FUEB  PMBIP: PM-BIP8  PMBEI: PM-BEI  TCM1BIP: TCM1-BIP8  TCM1BEI: TCM1-BEI  TCM2BIP: TCM2-BIP8  TCM2BEI: TCM2-BEI  TCM3BIP: TCM3-BIP8  TCM3BEI: TCM3-BEI  TCM4BIP: TCM4-BIP8  TCM4BEI: TCM4-BEI  TCM5BIP: TCM5-BIP8  TCM5BEI: TCM5-BEI  TCM6BIP: TCM6-BIP8  TCM6BEI: TCM6-BEI  CHECCO: ECTABLE  CHECUNCO: cHEC-UNCORRECTABLE  THECCOR: tHEC-CORRECTABLE  THECUNCO: tHEC-UNCORRECTABLE  IGFPFRAME: INVALID-GFP-FRAME  SBLOCKCRC: SUPERBLOCK-CRC  CSFSIGNAL: CSF-SIGNAL  CSFSYNC: CSF-SYNC  CRC8: CRC8  CRC5: CRC5  FCS: FCS</p> <p><i>DEFault = FAS</i></p>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM:ERR FAS
<b>Note</b>	This setting applies when :ITEM is EL1, EL2 or EL3. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:ITEM:ERRor?
<b>Description</b>	This query returns the evaluation item for OTN.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<item> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:ITEM:ERR? → LOS
<b>Note</b>	

## 17.2.78 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:TYPE

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:TYPE <type>
<b>Description</b>	This command sets the evaluation type for OTN.
<b>Parameters</b>	<Pt> = Port number <type> = <CHARACTER PROGRAM DATA> CNT: Count RATio: Ratio <i>DEFault = CNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:TYPE RAT
<b>Note</b>	Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:TYPE?
<b>Description</b>	This query returns the evaluation type for OTN.
<b>Parameter</b>	None.
<b>Response</b>	<type> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:TYPE? → RAT
<b>Note</b>	

## 17.2.79 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:CNT:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:PASS <value>
<b>Description</b>	This command sets the error count for the OTN pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:CNT:PASS 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:PASS?
<b>Description</b>	This query returns the error count for the OTN pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:CNT:PASS? → 10
<b>Note</b>	

## 17.2.80 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:CNT:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:FAIL <value>
<b>Description</b>	This command sets the error count for the OTN fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=100000, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:CNT:FAIL 10
<b>Note</b>	This setting applies when :TYPE is CNT. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:CNT:FAIL?
<b>Description</b>	This query returns the error count for the OTN fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:CNT:FAIL? → 10
<b>Note</b>	

## 17.2.81 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:RATio:PASS

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:PASS <value>
<b>Description</b>	This command sets the ratio for the OTN pass limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:RAT:PASS 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:PASS?
<b>Description</b>	This query returns the ratio for the OTN pass limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:RAT:PASS? → 1.00E-01
<b>Note</b>	

## 17.2.82 MEASurement:SETup:EVALuation:OTN:RX&lt;Pt&gt;:RATio:FAIL

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:FAIL <value>
<b>Description</b>	This command sets the ratio for the OTN fail limit.
<b>Parameter</b>	<value> = <NUMERIC PROGRAM DATA> <i>MINimum=0, MAXimum=1.00, DEFault=0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:RAT:FAIL 10.00
<b>Note</b>	This setting applies when :TYPE is RATio. Command is valid for BERT applications only.

<b>Syntax</b>	MEASurement:SETup:EVALuation:OTN:RX<Pt>:RATio:FAIL?
<b>Description</b>	This query returns the ratio for the OTN fail limit.
<b>Parameter</b>	None.
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:OTN:RX1:RAT:FAIL? → 1.00E-01
<b>Note</b>	

## 17.2.83 MEASurement:SETup:EVALuation:BER:OBAMeasuring

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:OBAMeasuring <enable>
<b>Description</b>	This command enables/disables only show BER alarms when measuring.
<b>Parameters</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:OBAM ON
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:OBAMeasuring?
<b>Description</b>	This query returns if BER alarms should only be shown when measuring.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:OBAM? → 1
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

## 17.2.84 MEASurement:SETup:EVALuation:BER:IAFFilter

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:IAFFilter <enable>
<b>Description</b>	This command enables/disables include addresses in frame filter on receiver.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = ON</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:IAFF OFF
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:IAFFilter?
<b>Description</b>	This query returns if include addresses in frame filter on receiver is enabled/disabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:IAFF? → 0
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

## 17.2.85 MEASurement:SETup:EVALuation:BER:CLFrames

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:CLFrames <enable>
<b>Description</b>	This command enables/disables count lost frames as pattern errors.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:CLF ON
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:CLFrames?
<b>Description</b>	This query return if count lost frames as pattern errors is enabled/disabled.
<b>Parameter</b>	None.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:CLF? → 1
<b>Note</b>	This setting applies to all ports. This only applies to Ethernet and Fibre Channel.

## 17.2.86 MEASurement:SETup:EVALuation:BER:PORT&lt;Pt&gt;:PTHResholds[:ENABLE]

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds[:ENABLE] <enable>
<b>Description</b>	This command enables/disables BER Pattern error thresholds.
<b>Parameters</b>	<Pt> = Port number <enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Examples</b>	MEAS:SET:EVAL:BER:PORT1:PTHR ON
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds[:ENABLE]?
<b>Description</b>	This query returns whether or not Pattern error thresholds are enabled.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Examples</b>	MEAS:SET:EVAL:BER:PORT1:PTHR? → 1
<b>Note</b>	

## 17.2.87 MEASurement:SETup:EVALuation:BER:PORT&lt;Pt&gt;:PTHResholds:MODE

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:MODE <mode>
<b>Description</b>	This command sets the Pattern errors threshold mode.
<b>Parameters</b>	<Pt> = Port number <mode> = <CHARACTER PROGRAM DATA> COUNT: Count RATE: Rate PERCENT: Rate Percent <i>DEFault = COUNT</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:MODE COUNT
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:MODE?
<b>Description</b>	This query return the Pattern errors threshold mode.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<mode> = <CHARACTER RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:MODE? COUNT
<b>Note</b>	

## 17.2.88 MEASurement:SETup:EVALuation:BER:PORT&lt;Pt&gt;:PTHResholds:COUNT

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:COUNT <value>
<b>Description</b>	This command sets the Pattern errors threshold count value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0, MAXimum = 4294967295, DEFault = 0</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:COUN 100
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:COUNT?
<b>Description</b>	This query return the Pattern errors threshold count value.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:COUN? → 100
<b>Note</b>	

## 17.2.89 MEASurement:SETup:EVALuation:BER:PORT&lt;Pt&gt;:PTHResholds:RATIo

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:RATIo <ratio>
<b>Description</b>	This command sets the Pattern errors threshold ratio value.
<b>Parameters</b>	<Pt> = Port number <ratio> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00, MAXimum = 1.00, DEFault = 0.00</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:RAT 1.50E-01
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:RATio?
<b>Description</b>	This query return the Pattern errors threshold ratio value.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR3 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:RAT? → 1.50E-01
<b>Note</b>	

### 17.2.90 MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:PERCent

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:PERCent <value>
<b>Description</b>	This command sets the Pattern errors threshold percentage value.
<b>Parameters</b>	<Pt> = Port number <value> = <NUMERIC PROGRAM DATA> <i>MINimum = 0.00000, MAXimum = 100.00000, DEFault = 0.00000</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:PERC 10.00000
<b>Note</b>	

<b>Syntax</b>	MEASurement:SETup:EVALuation:BER:PORT<Pt>:PTHResholds:PERCent?
<b>Description</b>	This query return the Pattern errors threshold percentage value.
<b>Parameters</b>	<Pt> = Port number
<b>Response</b>	<value> = <NR2 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:SET:EVAL:BER:PORT1:PTHR:PERC? → 10.00000
<b>Note</b>	

### 17.2.91 MEASurement:SETup:POINtermovement:SDH:MODE

<b>Syntax</b>	MEASurement:SETup:POINtermovement:SDH:MODE <enable>
<b>Description</b>	This command enables/disables pointer movement measurement.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:POIN:SDH:MODE ON
<b>Note</b>	This setting applies to all ports.

<b>Syntax</b>	MEASurement:SETup:POINtermovement:SDH:MODE?
<b>Description</b>	This query return if pointer movement is enabled/disabled.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	MEAS:SET:POIN:SDH:MODE? → 1
<b>Note</b>	This setting applies to all ports.

### 17.2.92 MEASurement:SETup:POINtermovement:SONet:MODE

<b>Syntax</b>	MEASurement:SETup:POINtermovement:SONet:MODE <enable>
<b>Description</b>	This command enables/disables pointer movement measurement.
<b>Parameter</b>	<enable> = <BOOLEAN PROGRAM DATA> <i>DEFault = OFF</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:SET:POIN:SON:MODE ON
<b>Note</b>	This setting applies to all ports.



<b>Syntax</b>	MEASurement:SETup:POINtermovement:SONet:MODE?
<b>Description</b>	This query return if pointer movement is enabled/disabled.
<b>Response</b>	<enable> = <BOOLEAN RESPONSE DATA>
<b>Example</b>	MEAS:SET:POIN:SON:MODE? → 1
<b>Note</b>	This setting applies to all ports.

## 17.3 Information

### 17.3.1 MEASurement:INFO:TBEGin?

<b>Syntax</b>	MEASurement:INFO:TBEGin?
<b>Description</b>	This query returns the start time of the measurement.
<b>Parameter</b>	None.
<b>Response</b>	<datetime> = <STRING RESPONSE DATA> Format: YYYY-MM-DD HH:MM:SS
<b>Example</b>	MEAS:INFO:TBEG? → "2014-07-17 11:26:11"
<b>Note</b>	Only possible if a measurement is in the memory.

### 17.3.2 MEASurement:INFO:TEND?

<b>Syntax</b>	MEASurement:INFO:TEND?
<b>Description</b>	This query returns the stop time of the measurement.
<b>Parameter</b>	None.
<b>Response</b>	<datetime> = <STRING RESPONSE DATA> Format: YYYY-MM-DD HH:MM:SS
<b>Example</b>	MEAS:INFO:TEND? → "2014-07-17 11:26:21"
<b>Note</b>	Only possible if a measurement is in the memory and a measurement is not running.

### 17.3.3 MEASurement:INFO:MDURATION?

<b>Syntax</b>	MEASurement:INFO:MDURATION?
<b>Description</b>	This query returns the measurement duration.
<b>Parameter</b>	None.
<b>Response</b>	<duration> = <STRING RESPONSE DATA> Format: DD-HH:MM:SS
<b>Example</b>	MEAS:INFO:MDUR? → "01-00:03:23"
<b>Note</b>	Only possible if a measurement is in the memory.

### 17.3.4 MEASurement:INFO:STATus<Pt>?

<b>Syntax</b>	MEASurement:INFO:STATus<Pt>?
<b>Description</b>	This query returns the alarm/error status of all active interfaces and the state of the evaluation limits.
<b>Parameter</b>	<Pt> = Port number
<b>Response</b>	<status> = <STRING RESPONSE DATA> "No Trouble" "Alarms" "Errors" "Alarms and Errors" "N/A": Data not available <state> = <STRING RESPONSE DATA> "Disabled / Not Supported" "Below Limits" "Within Limits" "Exceed Limits" "N/A": Data not available
<b>Example</b>	MEAS:INFO:STAT1? → "Errors","Within Limits"
<b>Note</b>	Only possible if a measurement is in the memory.

### 17.3.5 MEASurement:INFO:IMIN?

<b>Syntax</b>	MEASurement:INFO:IMIN?
<b>Description</b>	This query returns the minimum index of statistics intervals.
<b>Parameter</b>	None
<b>Response</b>	<intervalindex> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:INFO:IMIN? → 0
<b>Note</b>	If no intervals are available the NaN (section 1.6.1) is returned.

### 17.3.6 MEASurement:INFO:IMAX?

<b>Syntax</b>	MEASurement:INFO:IMAX?
<b>Description</b>	This query returns the maximum index of statistics intervals.
<b>Parameter</b>	None
<b>Response</b>	<intervalindex> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:INFO:IMAX? → 16
<b>Note</b>	If no intervals are available the NaN (section 1.6.1) is returned.

## 17.4 Event Log

### 17.4.1 MEASurement:ELOG:MINimum?

<b>Syntax</b>	MEASurement:ELOG:MINimum?
<b>Description</b>	This query returns the first index present in the event log.
<b>Parameter</b>	None
<b>Response</b>	<index> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:ELOG:MIN? → 1
<b>Note</b>	

### 17.4.2 MEASurement:ELOG:MAXimum?

<b>Syntax</b>	MEASurement:ELOG:MAXimum?
<b>Description</b>	This query returns the last or the latest index present in the event log.
<b>Parameter</b>	None
<b>Response</b>	<index> = <NR1 NUMERIC RESPONSE DATA>
<b>Example</b>	MEAS:ELOG:MAX? → 321
<b>Note</b>	

### 17.4.3 MEASurement:ELOG:FETCh?

<b>Syntax</b>	MEASurement:ELOG:FETCh? [<index>[,<count> ] ]
<b>Description</b>	This query returns a number of log entries starting from the specified index.
<b>Parameters</b>	<index> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=64000, DEFault=1</i> <count> = <NUMERIC PROGRAM DATA> <i>MINimum=1, MAXimum=400, DEFault=20</i>
<b>Response</b>	The result is returned as a list of result items. A result item has the format: (<index>,<dateTime>,<portNo>,<type>,<source>,<description>,<countDuration>) The <portNo> field is '0' when the event is not related to a specific port. The <countDuration> is an error counter for errors and a duration in seconds for alarms.
<b>Example</b>	MEAS:ELOG:FETC? → (1,"2015-01-09 16:20:45",0,"Test","SYST","Started",0), (2,"2015-01-09 16:20:47",1,"Error","ETH","Pattern errors",5), (3,"2015-01-09 16:20:50",0,"Test","SYST","Stopped",0)
<b>Note</b>	The Cable Test and the No Frame (MT1100A) applications have no event log feature.

#### 17.4.4 MEASurement:ELOG:FETCh:NEXt?

<b>Syntax</b>	MEASurement:ELOG:FETCh:NEXt?
<b>Description</b>	This query returns a number of log entries starting from where the previous :FETCh or :FETCh:NEXt stopped.
<b>Parameters</b>	None
<b>Response</b>	The response is similar to the response of the MEASurement:ELOG:FETCh? command.
<b>Example</b>	MEAS:ELOG:FETC:NEXt? 1
<b>Note</b>	

#### 17.4.5 MEASurement:ELOG:EXPort

<b>Syntax</b>	MEASurement:ELOG:EXPort <file> [<delimiter>]
<b>Description</b>	This command writes the complete event log to the specified file in a CSV format. The file can be written to the internal disk or to a connected USB memory device. The specified delimiter is used as field delimiter. Lines are terminated with CR-LF (0x0d,0x10).
<b>Parameters</b>	<file> = <STRING PROGRAM DATA> The path and name of the file to store the data. <delimiter> = <CHARACTER PROGRAM DATA> COMMa: Use ',' as field separator. SEMicolon: Use ';' as field separator. TABulator: Use a tabulator character (0x09) as field separator. <i>DEFault = COMMa</i>
<b>Response</b>	None.
<b>Example</b>	MEAS:ELOG:EXP "Internal/my-log-data.csv"
<b>Note</b>	Files must be saved to the Internal/ directory or a sub-directory hereof. When a USB storage device is mounted, files are stored via the Usb/ directory.

## 17.5 Result

#### 17.5.1 MEASurement:RESult:SUMMery?

<b>Syntax</b>	MEASurement:RESult:SUMMery?
<b>Description</b>	This query returns the measurement result.
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> Pass Trouble Warning N/A
<b>Example</b>	MEAS:RES:SUMM? → Pass
<b>Note</b>	

#### 17.5.2 MEASurement:RESult:SUMMery:STATistics:PORT<Pt>?

<b>Syntax</b>	MEASurement:RESult:SUMMery:STATistics:PORT<Pt>?
<b>Description</b>	This query returns the measurement result of statistics.
<b>Response</b>	<result> = <CHARACTER RESPONSE DATA> Pass Trouble Warning N/A
<b>Example</b>	MEAS:RES:SUMM:STAT:PORT1? → PASS
<b>Note</b>	



---

# Appendix A

## Example Scripts

This chapter shows various example scripts for all interfaces which are remote controllable.

### A.1 Hints

To ensure that the instrument always start from a well defined state, it is in general a good idea to begin all scripts with the following command. It will terminate all application servers (virtual instruments).

```
*RST
```

## A.2 2 Mbps BERT

This example runs a BER test. It requires an unbalanced cable to be connected from TX1 to RX1. It configures TX1 and sets RX1 to follow TX1. TX2 and RX2 are switched off. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-4}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last query is `TMBP:RX1:IFET? (PATT) → (1024,0.0001)`

```
*RST
INST:STAR TP-BERT-SDHPDH,1-PORT1

TMBP:TX1 ON
TMBP:TX1:CONN UNB; DINS OFF; CSO INT; FOFF 0; CODE HDB3; PCMF ON; CRC4 ON
TMBP:TX1:SAB #B11111,#B11111,#B11111,#B11111
TMBP:TX1:PATT PRBS11; PINV OFF; PTSL (1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16)
TMBP:TX1:UTSL #B01010101
TMBP:TX1:CAS OFF

TMBP:RX1:ENAB ON; FOLL TX

TMBP:STIM:TX1:ERR PATT; EINS B04; EBL 1
SYST:WAIT:DUR 3

MEAS:SET:ILEN 5S; STAR IMM; STOP DUR; SDUR 0,0,0,10
MEAS:STAR
SYST:WAIT:IDLE

MEAS:SET:SEL TOT
TMBP:RX1:IFET? (PATT)
MEAS:SET:SEL 0
TMBP:RX1:IFET? (PATT)
MEAS:SET:SEL 1
TMBP:RX1:IFET? (PATT)

SYST:ERR?
INST:TERM
```

## A.3 2 Mbps Status & Stimuli

This example demonstrates status and stimuli. It requires 2mbps interface and a loopback cable from TX1 to RX1. The functionality is as following:

- reset to factory default, enable device dependent status and clear status
- setup interface and read status
- clear status, set AIS alarm and read status
- clear status, insert one pattern error and read status

Input script		Output
<pre> *RST INST:STAR TP-BERT-SDHPDH,1-PORT1  STAT:PRES STAT:PORT:ENAB 1-PORT1,1; PTR 1-PORT1,1; NTR 1-PORT1,0  TMBP:TX1 ON; RX1 ON TMBP:RX1:FOLL TX SYST:WAIT:DUR 3 *CLS  *STB?; STAT:PORT:EVEN? 1-PORT1; COND? 1-PORT1 STAT:INT:PORT1:EVEN?; COND? TMBP:STAT:RX1:AES:EVEN?; COND? TMBP:STAT:RX1:ALAR:EVEN?; COND?  TMBP:STIM:TX1:ALAR AIS SYST:WAIT:DUR 2  *STB?; STAT:PORT:EVEN? 1-PORT1; COND? 1-PORT1 STAT:INT:PORT1:EVEN?; COND? TMBP:STAT:RX1:AES:EVEN?; COND? TMBP:STAT:RX1:ALAR:EVEN?; COND? TMBP:STIM:TX1:ALAR NAL SYST:WAIT:DUR 2 *CLS  TMBP:STIM:TX1:EINS MAN; EBL 1; ERR PATT SYST:STIM:INS SYST:WAIT:DUR 3  STAT:INT:PORT1:EVEN?; COND? TMBP:STAT:RX1:AES:EVEN?; COND? TMBP:STAT:RX1:ERR:EVEN?; COND?  SYST:ERR? INST:TERM </pre>	→	<pre> 0;0;0 0;0 0;0 0;0  1;1;1 1;1 1;1 64;64  1;1 2;2 2;0  0,"No error" </pre>

## A.4 E3 BERT

This example runs a BER test. It requires a cable to be connected from TX1 to RX1. It configures TX1 and sets RX1 to follow TX1. TX2 and RX2 are switched off. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-3}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last query is `TMBP:RX1:IFET? (PATT) → (343680,0.001)`

```
*RST
INST:STAR TP-BERT-SDHPDH,1-PORT1

*CLS
STAT:PRES

E3:TX1:ENAB ON
E3:TX1:CSO INT
E3:TX1:FOFF 0
E3:TX1:PCMF OFF
E3:TX1:PATT PRBS11
E3:TX1:PINV ON

E3:RX1:ENAB ON
E3:RX1:FOLL TX

E3:STIM:TX1:ERR PATT
E3:STIM:TX1:EINS B03
E3:STIM:TX1:EBL 1

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
E3:RX1:IFET? (PATT)
```



## A.5 E4 BERT

This example runs a BER test. It requires a cable to be connected from TX1 to RX1. It configures TX1 and sets RX1 to follow TX. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-3}$ . A Statistics measurement is set to run for 11 seconds and it finally reads the measured pattern errors and pattern slips from the total interval.

The expected execution of the last two queries are E4:RX<Rx>:IFET? (PATT) → (1392640,0.001)

```
*RST
INST:STAR TP-BERT-SDHPDH,1-PORT1,1-PORT2

*CLS
STAT:PRES

E4:TX:ENAB ON
E4:TX:CSO INT
E4:TX:FOFF 0
E4:TX:PCMF OFF
E4:TX:PATT PRBS11
E4:TX:PINV ON

E4:RX1:ENAB ON
E4:RX1:FOLL TX

E4:RX2:ENAB ON
E4:RX2:FOLL TX

E4:STIM:TX:ERR PATT
E4:STIM:TX:EINS B03
E4:STIM:TX:EBL 1

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 11
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
E4:RX1:IFET? (PATT,PSL)
E4:RX2:IFET? (PATT,PSL)

SYST:ERR?
INST:TERM
```

## A.6 SDH BERT

This example runs a BER test. It requires a cable to be connected from TX1 to RX1. It configures TX1 and sets RX1 to follow TX. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-7}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last two queries are SDH:RX<Rx>:IFET? (ERRPRBS) → (150,1E-07)

```
*RST
INST:STAR TP-BERT-SDHPDH,1-PORT1,1-PORT2

SDH:TX:ELEC NORM

SDH:RX1:INT ELEC
SDH:RX1:FOLL TX

SDH:RX2:INT ELEC
SDH:RX2:FOLL TX

SDH:STIM:TX:ERR PRBS
SDH:STIM:TX:EINS B07
SDH:STIM:TX:EBL 1

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
SDH:RX1:IFET? (ERRPRBS)
SDH:RX2:IFET? (ERRPRBS)

SYST:ERR?
INST:TERM
```

## A.7 Ethernet BERT

This example runs a BER test. It requires a cable from Port 1 to Port 2 (PORT1 to PORT2). It configures PORT1 and set PORT2 to follow PORT1. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-7}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last two queries are approximately `ETH:PORT<Pt>:IFET? (BPE) → (20,1E-07)`.

```
*RST
INST:STAR TP-BERT-ETH,1-PORT1,1-PORT2

ETH:PORT1:MODE ANEG
ETH:PORT2:MODE ANEG
ETH:PORT1:ANEG (100MF)
ETH:PORT2:ANEG (100MF)
SYST:WAIT:DUR 4

ETH:FOLL:STR ON
ETH:FOLL:TRAF ON

ETH:PORT1:STR1:PAYL PRBS11

ETH:PORT1:TRAF:DMOD CONT
ETH:PORT1:TRAF:STR1:LL:PROF CONS
ETH:PORT1:TRAF:STR1:LL 100 PCT

ETH:PORT1:STIM:ERR PRBS
ETH:PORT2:STIM:ERR PRBS
ETH:PORT1:STIM:EINS BE7
ETH:PORT2:STIM:EINS BE7

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10

ETH:PORT1:TRAF:GEN:STAR
ETH:PORT2:TRAF:GEN:STAR
SYST:WAIT:DUR 2

MEAS:STAR
SYST:WAIT:IDLE

ETH:PORT1:TRAF:GEN:STOP
ETH:PORT2:TRAF:GEN:STOP

MEAS:SET:SEL TOT
ETH:PORT1:IFET? (BPE)
ETH:PORT2:IFET? (BPE)

SYST:ERR?
INST:TERM
```

## A.8 Fibre Channel BERT

This example runs a BER test. It requires a cable from PORT1 to PORT2. It configures PORT1 and set PORT2 to follow PORT1. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-7}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last two queries are approximately `FCH:PORT<Pt>:IFET? (PERR) → (567,1E-07)`.

```
*RST
INST:STAR TP-BERT-FC,1-PORT1,1-PORT2

FCH:PORT1:MODE FC400
FCH:PORT2:MODE FC400

FCH:PORT1:TOP PTP; :FCH:PORT1:PTP:LOG ON
FCH:PORT2:TOP PTP; :FCH:PORT2:PTP:LOG ON
FCH:PORT1:DEST:LOG
SYST:WAIT:DUR 2

FCH:PORT2:FOLL:FRAM 1
FCH:PORT1:FRAM:FRAM FT1
FCH:PORT1:FRAM:CONT PRBS23

FCH:PORT2:FOLL:GEN 1; STR 1
FCH:PORT1:TRAF:STR:LL 50.0

FCH:PORT1:STIM:ERR BIT; EINS BE7; EBL 1
FCH:PORT2:STIM:ERR BIT; EINS BE7; EBL 1

FCH:TRAF:GEN:STAR
SYST:WAIT:DUR 2

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
FCH:PORT1:IFET? (BPE)
FCH:PORT2:IFET? (BPE)

SYST:ERR?

INST:TERM
```

## A.9 OTN BERT

This example runs a BER test. It requires a cable to be connected from TX1 to RX1. It configures TX1 and sets RX1 to follow TX. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-7}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last two queries are OTN:RX<Rx>:IFET? (PRBSBIT) → (9995,1E-07)

```
*RST
INST:STAR TP-BERT-OTN,1-PORT1,1-PORT2

OTN:TX1:ENAB NORM
OTN:TX1:MAPP:OUTP OTU2
OTN:TX1:MAPP:CSIG PRBS

OTN:TX2:FOLL TX1

OTN:RX1:INT SFP
OTN:RX1:FOLL TX

OTN:RX2:INT SFP
OTN:RX2:FOLL TX

OTN:STIM:TX1:TYPE AEIN
OTN:STIM:TX1:AEIN:LEV ODU2
OTN:STIM:TX1:AEIN:TYPE PRBSBIT
OTN:STIM:TX1:AEIN:INS RATE
OTN:STIM:TX1:AEIN:RATE R1E7

OTN:STIM:TX2:TYPE AEIN
OTN:STIM:TX2:AEIN:LEV ODU2
OTN:STIM:TX2:AEIN:TYPE PRBSBIT
OTN:STIM:TX2:AEIN:INS RATE
OTN:STIM:TX2:AEIN:RATE R1E7

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
OTN:RX1:IFET? (PRBSBIT)
OTN:RX2:IFET? (PRBSBIT)

SYST:ERR?
INST:TERM
```

## A.10 CPRI BERT

This example runs a BER test. It requires a cable from PORT1 to PORT2. It configures PORT1 and set PORT2 to follow PORT1. Stimuli is set to generate pattern errors with a rate of  $1 \cdot 10^{-4}$ . A Statistics measurement is set to run for 10 seconds and it finally reads the measured pattern errors from the total interval.

The expected execution of the last two queries are approximately `CPRI:PORT<Pt>:IFET? (PE) → (7372800,0.0001)`.

```
*RST
INST:STAR TP-BERT-CPRI,1-PORT1,1-PORT2

CPRI:PORT1:MODE NORM
CPRI:PORT2:MODE NORM

CPRI:PORT1:LRAT 9830M
CPRI:PORT2:LRAT 9830M

CPRI:PORT1:CONT LINK
CPRI:PORT2:CONT LINK
SYST:WAIT:DUR 2

CPRI:PORT2:SET:FOLL ON
CPRI:PORT1:PATT PRBS15

CPRI:PORT1:STIM:ERR PE; EINS B04
CPRI:PORT2:STIM:ERR PE; EINS B04

MEAS:SET:ILEN 5S
MEAS:SET:STAR IMM
MEAS:SET:STOP DUR
MEAS:SET:SDUR 0, 0, 0, 10
MEAS:STAR

SYST:WAIT:IDLE

MEAS:SET:SEL TOT
CPRI:PORT1:IFET? (PE)
CPRI:PORT2:IFET? (PE)

SYST:ERR?

INST:TERM
```

---

# Abbreviations

AISL	Line Alarm Indication Signal
AISP	STS Path Alarm Indication Signal
AISV	Virtual Tributary Alarm Indication Signal
ALS	Alarm Seconds
AMI	Alternate Mark Inversion
APS	Automatic Protection Switching
ARP	Address Resolution Protocol
AU	Administrative Unit
AU-AIS	Administrative Unit Alarm Indication Signal
AU-LOP	Administrative Unit Loss Of Pointer
AU-NDF	Administrative Unit New Data Flag
AVT	Available Time
B-TAG	Backbone VLAN tag
B8ZS	Bipolar 8-zero substitution ( <i>code with a maximum of 7 consecutive zeroes</i> )
BBE	Background Block Error
BDP	Bandwidth Delay Product
BER	Bit Error Ratio
BERT	Bit Error Rate Test
BIS	Bringing Into Service
BPV	Bipolar Violation
C-bits	Bit stuffing control bits
CAS	Channel Associated Signaling
CCM	Continuity Check Message
CRC	Cyclic Redundancy Check
DEI	Drop Eligible Indicator
DM1	One-way delay measurement
DMM	Delay Measurement Message
DNS	Domain Name System
DSCP	Differentiated Services Code Point
EFS	Error Free Seconds

EoMPLS	Ethernet over MPLS
ES	Errored Second
ESF	Extended superframe
ESMC	Ethernet Synchronization Messaging Channel
EXM	Experimental OAM Message
EXZ	Excessive Zeroes
F-bits	Framing bits
FDL	Facility Data Link
fps	frames per second
HDB3	High Density Bipolar 3 ( <i>code with a maximum of 3 consecutive zeroes</i> )
HP	High-order Path
HP-PLM	High-order Path Payload Label Mismatch
HP-RDI	High-order Path Remote Defect Indicator
HP-REI	High-order Path Remote Error Indication
HP-TIM	High-order Path Trace Identifier Mismatch
HP-UNEQ	High-order Path Unequipped
HR	Hypothetical Reference allocation
IEEE	Institute of Electrical and Electronic Engineers
IFG	InterFrame Gap
ILA	In-Lane Alignment
IP	Internet Protocol
ISDN	Integrated Services Digital Network
LAN	Local Area Network
LBM	Loop-back Message
LBR	Loop-back Response
LFS	Link Fault Signaling
LMM	Loss Measurement Message
LMP	Link Management Protocol
LOF	Loss Of Frame
LOMV	Virtual Tributary Loss Of Multiframe
LOPP	STS Path Loss Of Pointer
LOPV	Virtual Tributary Loss Of Pointer
LOR	Loss Of Recovery
LOS	Loss Of Signal
LP	Low-order Path
LP-PLM	Low-order Path Payload Label Mismatch



---

LP-RDI	Low-order Path Remote Defect Indicator
LP-REI	Low-order Path Remote Error Indication
LP-TIM	Low-order Path Trace Identifier Mismatch
LP-UNEQ	Low-order Path Unequipped
LSS	Loss of Signal Synchronization
LTM	Link Trace Message
MAC	Media Access Control
Mbps	Mega bit per second
MCC	Maintenance Communications Channel
ME	Maintenance Entity
MEG	Maintenance Entity Group
MEP	Management End Point
MF	Multi Frame
MFAS	Multi Frame Alignment Signal
MiM	MAC-in-MAC
MPLS	Multiprotocol Label Switching
MS	Multiplex Section
MS-AIS	Multiplex Section Alarm Indication Signal
MS-RDI	Multiplex Section Remote Defect Indication
MS-REI	Multiplex Section Remote Error Indication
MSS	Maximum Segment Size
MTU	Maximum Transmission Unit
MUX	Multiplex
NDF	New Data Flag
NFAS	Non Frame Alignment Signal
NTP	Network Time Protocol
OAM	Operation, Administration and Maintenance
OC-N	Optical Carrier at level N (N = 1, 3, 12, 24, 48, 192 or 768)
OLA	Out of Lane Alignment
OOF	Out Of Frame
OOR	Out Of Recovery
OUI	Organizationally Unique Identifier
P-bits	Parity bits
PBB	Provider Backbone Bridges, known as MAC-in-MAC (MiM)
PCP	Priority Code Point
PDH	Plesiochronous Digital Hierarchy

PLMP	High-order Path Payload Label Mismatch
PLMV	Low-order Path Payload Label Mismatch
POH	Path Overhead
ppb	parts per billion
PRBS	Pseudo Random Binary Sequence
QL	Quality Level
QRSS	Quasi Random Signal Source
RAI	Remote Alarm Indication
RDI	Remote Defect Indication
RDIL	Line Remote Defect Indication
RDIP	High-order Path Remote Defect Indicator
RDIV	Low-order Path Remote Defect Indicator
REI	Remote Error Indication
REIL	Line Remote Error Indication
REIP	STS Path Remote Error Indication
REIV	Virtual Tributary Remote Error Indication
RPM	Real-time Performance Monitoring
RTT	Round-Trip Time
Rx	Receiver
SDH	Synchronous Digital Hierarchy
SES	Severely Errored Second
SF	Superframe
SID	Backbone Service Instance Identifier
SLM	Synthetic (frame-) Loss Measurement
SOH	Section Overhead
SONET	Synchronous Optical NETWORK
SSF	Server Signal Fail
STAT	Status
STL	Synchronous Transport Lane
STM	Synchronous Transport Module
STS	Synchronous Transport Signal
TAI	Time, Atomic International
TC	Tandem Connection
TC-AIS	Tandem Connection Alarm Indication Signal
TC-BIP2	Tandem Connection Bit Interleaved Parity-2
TC-IEC	Tandem Connection Incoming Error Count

---

TC-LTC	Tandem Connection Loss of Tandem Connection
TC-ODI	Tandem Connection Outgoing Defect Indicator
TC-OEI	Tandem Connection Outgoing Error Indication
TC-RDI	Tandem Connection Remote Defect Indicator
TC-REI	Tandem Connection Remote Error Indication
TC-TIM	Tandem Connection Trace Identifier Mismatch
TC-UNEQ	Tandem Connection Unequipped
TCM	Tandem Connection Monitoring
TCP	Transmission Control Protocol
TIM	Trace Identifier Mismatch
TIMP	High-order Path Trace Identifier Mismatch
TIMV	Low-order Path Trace Identifier Mismatch
TLV	Type, Length, Value encoding
TOH	Transport Overhead
TP	Tributary Port
TRAU	Transcoder and Rate Adaptation Unit
TS	Tributary Slot
TTL	Time To Live (hop limit)
TU	Tributary Unit
TU-AIS	Tributary Unit Alarm Indication Signal
TU-LOM	Tributary Unit Loss Of Multiframe
TU-LOP	Tributary Unit Loss Of Pointer
TU-NDF	Tributary Unit New Data Flag
TUG	Tributary Unit Group
Tx	Transmitter
UAT	Unavailable Time
UCA	Use Customer Address
UDP	User Datagram Protocol
UNAV	Unavailable
UNEQP	High-order Path Unequipped
UNEQV	Low-order Path Unequipped
UTC	Universal Time Coordinated
VC	Virtual Container
VLAN	Virtual Local Area Network
VSM	Vendor Specific OAM Message
VT	Virtual Tributary
WAN	Wide Area Network
WWN	Worldwide Name