

FP11-F

FP11F FLTG PNT PRT C
CKFPCDO

AH-F638D-MC
FICHE 1 OF 2

APR 1982
COPYRIGHT © 79-82
MADE IN USA

00000000

FP11-F

FP11F FLTG PNT PRT C
CKFPCDO

AH-F638D-MC
FICHE 2 OF 2

APR 1982
COPYRIGHT © 79-82
MADE IN USA

DIS0080

1
2
3
4
5
6
7
8
9
10
11
12 .REM &
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39

IDENTIFICATION

PRODUCT CODE: AC-F636D-MC
PRODUCT NAME: CKFPCDO FP11F FLTG PNT PRT C
PRODUCT DATE: OCTOBER, 1981
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: ANTHONY VEZZA, DAN MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1979, 1982 BY DIGITAL EQUIPMENT CORPORATION

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

HISTORY

NO CHANGES TO THE 11/34 FLOATING POINT DIAGNOSTIC PART 'A' WERE FOUND TO BE NEEDED TO ADAPT IT FOR USE ON THE 11/44.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'B' VERSION COVER THE 11/44:

1. TEST 22 - PROCESSOR LOOKS TO SEE IF APT IS CONTROLLING THE TEST, AND IF IT IS, CHECKS TO SEE IF THE USER HAS SELECTED THIS TEST BY CHECKING BIT 7 IN THE SWITCH REGISTER. IT HAS ALSO BEEN CHANGED SO THAT IF BIT 7 IS *ONE*, THE CODE WILL SELECT THE TEST.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'C' VERSION COVER THE 11/44:

1. TEST 76 - CHECKS THAT FP PROCESSOR DOESN'T ACCESS D-SPACE UNTIL CONDITIONS WARRANT.
2. TEST 77 TO 106 - CHECKS THAT SR1 MATCHES WHAT ACTUALLY HAPPENED TO THE REGISTER OF THE INSTRUCTION, AND THAT THE VALUE OF AUTO INCREMENT/DECREMENT WAS PROPER.

THE FOLLOWING WAS ADDED TO THE 'C' VERSION TO FURTHER INTENSIFY THE TEST:

1. TEST 77 - A BYTE TABLE OF EXPECTED DATA FOR SR1 CHECKS TO MAKE SURE THAT THE VALUE OF THE INCREMENT/DECREMENT IS PROPER FOR THAT INSTRUCTION.

ALL THREE PARTS WERE RE-RELEASED WITH A NEW SYSMAC THAT CHECKS BIT 0 OF THE CPU ERROR REGISTER (POWER MONITOR BIT). THE ADDITIONS WERE MADE IN THE SCOPE ROUTINE, EXECUTED AT THE BEGINNING OF EACH TEST, AND THE ERROR CALL ROUTINE. IF THE BIT BECOMES SET, AN ERROR IS CALLED FROM THE SCOPE ROUTINE. THE BIT IS CLEARED, AND THE TEST IS CONTINUED. IF THE BIT BECOMES SET IN THE MIDDLE OF A TEST, AND AN ERROR OCCURS FOR ANY REASON, THE ERROR ROUTINE WILL CALL *TWO* ERRORS. THE POWER MONITOR BIT ERROR FIRST, THEN THE ERROR ORIGINALLY CALLED. IN ADDITION, THE SREAD ROUTINE NOW CHECKS FOR A RANDOMLY INPUTED '^Q BEFORE A '^S IS TYPED. THIS BECAME NECESSARY WITH CERTAIN DATA CONNECTIONS OF SOME SYSTEMS.

THE FOLLOWING WAS ADDED TO THE 'D' VERSION: (Labeled by ':DPM002' in comments)

IN TEST 74 (TESTING 'STEXP'), IN EACH LOCATION WHERE THE CODE GOES TO CHECK THE 'STEXP' INSTRUCTION IN THE SUBROUTINE, IT NOW DOES THAT SECTION 3 TIMES IN ORDER TO CHECK THE ADDITIONAL MODES 2 AND 4 (AUTO INCREMENT/DECREMENT). A TABLE WAS ADDED CONSISTING OF THREE 3-WORD DATA GROUPS. THE FIRST AND LAST GROUPS PROVIDE THE DATA TO LOAD AND CHECK THE PROPER PRE AND POST VALUES RESPECTIVELY OF R0 USED IN EXECUTING THE INSTRUCTION. THE SECOND GROUP IS THE OP CODES OF THE THREE MODES OF THE INSTRUCTION. THE 'STEXP' OP CODE IS PLACED IN THE FLOW JUST BEFORE EXECUTION.

98 IN TESTS 76 THROUGH 114, LOOP ON ERROR ADDRESS LOAD TO \$LPERR WAS ADDED JUST
99 BEFORE EACH TEST INSTRUCTION.

100 IN THE END-OF-PASS SECTION, THE EOP MESSAGE IS PRINTED EVERY 1000 PASSES
101 BECAUSE EXECUTION TIME PER PASS IS SO SHORT.

102 IN THE \$TYP0CS ROUTINE, IT NO LONGER PRINTS SPACE CHARACTERS AHEAD OF NON-
103 ZERO DIGITS.
104
105

106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155

CONTENTS

1. ABSTRACT
2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
3. LOADING PROCEDURE
4. STARTING PROCEDURE
 - 4.1 CONTROL SWITCH SETTINGS
 - 4.2 STARTING ADDRESS
 - 4.3 PROGRAM AND OPERATOR INTERACTION
5. OPERATING PROCEDURE
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.3 OPERATOR ACTION
6. ERRORS
 - 6.1 SUMMARY
 - 6.2 ERROR RECOVERY
7. RESTRICTIONS
 - 7.1 STARTING RESTRICTIONS
 - 7.2 OPERATING RESTRICTIONS
8. MISCELLANEOUS
 - 8.1 EXECUTION TIMES
 - 8.2 STACK POINTER
 - 8.3 PASS COUNT
 - 8.4 T-BIT TRAPPING
 - 8.5 SOFTWARE SWITCH REGISTER
 - 8.6 INTERRUPTS TESTS
 - 8.7 ACT, APT AND XXDP COMPATIBILITY
9. PROGRAM DESCRIPTION
 - 9.1 CKFPCDO
10. LISTING
 - 10.1 CKFPCDO

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

1.

ABSTRACT

THE THREE PROGRAMS:

CKFPACO CKFPBBO CKFPCDO

ARE DESIGN TO DETECT AND REPORT LOGIC FAULTS IN THE PDP 11/44 FP11-F FLOATING POINT PROCESSOR. THE DESIGN IS AN ATTEMPT TO REACH ALL ROM STATES, TAKE ALL BRANCH MICRO TESTS (BUT'S) AND VERIFY ALL THE LOGIC. THEY CONSIST OF 161 (OCT) INDIVIDUAL TESTS SEQUENCED TO DETECT AND ATTEMPT TO IDENTIFY FAULTS WITH A MINIMUM HARDWARE OR SOFTWARE LEVEL. THE TESTS ARE PARTITIONED INTO THREE STAND-ALONE PROGRAMS DESCRIBED BELOW.

NOTE THAT ERROR REPORTS IN THESE PROGRAMS ARE BASED UPON THE KNOWLEDGE THAT ALL PREVIOUS TESTS HAVE BEEN RUN AND IN MOST CASE THAT THERE IS ONLY A SINGLE POINT FAULT IN THE FP11-F. IF THE PROGRAMS OR TESTS ARE NOT RUN IN ORDER THEN ERROR MESSAGES MAY NOT BE ACCURATE.

A. CKFPACO

CKFPACO TESTS:

LDFPS
STFPS
CFCC
SETF, SETD, SETI AND SETL
STST
LDF AND LDD (ALL SOURCE MODES)
STD (MODE 0 AND 1)
ADDF, ADDD AND SUBD (MOST CONDITIONS)

B. CKFPBBO

CKFPBBO TESTS:

ADDF, ADDD AND SUBD (ALL CONDITIONS NOT TESTED IN CKFPACO)
CMPD AND CMPF
DIVD AND DIVF
MULD AND MULF
MOOD AND MODF

C. CKFPCDO

CKFPCDO TESTS:

S1F AND STD (ALL MODES)
STCFD AND STCDF
CLRD AND CLRF
NEGF AND NEGD

214 ABSF AND ABS
215 TSTF AND TSTD
216 NEGF, ABSF AND TSTF (ALL SOURCE MODES)
217 NEGF, ABSF AND TSTF (ALL SOURCE MODES)
218 LDFPS (ALL SOURCE MODES)
219 LDCIF AND LDCLF
220 LDCID AND LDCLD
221 LDEXP
222 STFPS (ALL DESTINATION MODES)
223 STCFL AND STCFI
224 STCDL AND STCDI
225 STEXP
226 STST
227 I AND D SPACE TESTS (ALL MODES AND REGS 0 AND 7)
228 AUTO INCREMENT/DECLMENT CHECK - SR1 (ALL MODES AND REGS 1 AND 7)
229
230

231 2. REQUIREMENTS
232 -----

233 2.1 EQUIPMENT
234 A PDP 11/44 WITH CONSOLE AND AN FP11-F FLOATING
235 POINT PROCESSOR. NOTE THAT A SPECIAL INTERRUPTS TEST
236 MODULE IS BEING DESIGNED FOR USE IN THE MANUFACTURING
237 ENVIRONMENT. WHEN THIS DEVICE IS PRESENT THE
238 PROGRAM CKFPBBO WILL MAKE USE OF IT TO TEST THE FPP
239 INTERRUPT ON BUS REQUEST FUNCTIONS.
240

241 2.2 STORAGE
242
243 ALL THREE PROGRAM REQUIRE A MEMORY SYSTEM OF AT
244 LEAST 16K TO LOAD AND RUN.
245

246 2.3 PRELIMINARY PROGRAMS
247
248 THESE THREE DIAGNOSTICS WILL ASSUME THAT THE PDP
249 11/44 CENTRAL PROCESSOR IS FAULTLESS, THEREFORE WHEN
250 IN DOUBT RUN THE PDP 11/44 PROCESSOR DIAGNOSTICS
251 BEFORE THESE FP11-F DIAGNOSTICS.
252

253 3. LOADING PROCEDURE
254 -----
255

256 THE PROGRAMS WILL BE SUPPLIED ON THE USUAL
257 DIAGNOSTIC MEDIA. REFER TO THE XXDP OPERATING
258 MANUAL FOR FURTHER INFORMATION.
259

260 4. STARTING PROCEDURE
261 -----
262

263 4.1 CONTROL SWITCH SETTINGS
264
265 SEE SECTION 5.1
266

267 4.2 PROGRAM AND OPERATOR ACTION
268
269
270

- 271 1. LOAD PROGRAM INTO MEMORY
272 2. LOAD ADDRESS 200
273 3. SET CONSOLE SWITCHES (IF CONSOLE IS PRESENT)
274 4. PRESS START.
275 ON FIRST PASS, THE PROGRAM
276 WILL IDENTIFY ITSELF. NOTE THAT IF THERE IS
277 NO PHYSICAL CONSOLE THE PROGRAM WILL REQUEST
278 THE OPERATOR FOR INITIAL VALUE FOR THE
279 SOFTWARE SWITCH REGISTER (SEE SECTION 8.5).
280 OF RUNNING UNDER ACT, APT OR CHAIN THIS DOES
281 NOT APPLY.
282 5. THE PROGRAM WILL LOOP AND AN END OF PASS AND
283 ERROR SUMMARY WILL BE TYPED AT THE END OF
284 EVERY PASS.

285 5. OPERATING PROCEDURE

288 5.1 OPERATIONAL SWITCH SETTINGS

291 THE SWITCH SETTING ARE:

	OCTAL	
SW<15>=1...	100000	HALT ON ERROR
SW<14>=1...	40000	LOOP ON CURRENT TEST
SW<13>=1...	20000	INHIBIT ERROR TYPE OUTS
SW<12>=1...	10000	INHIBIT T-BIT TRAPPING
SW<11>=1...	4000	INHIBIT ITERATIONS
SW<10>=1...	2000	RING TTY BELL ON ERROR
SW<9>=1....	1000	LOOP ON ERROR
SW<8>=1....	400	LOOP ON TEST SPECIFIED IN SW<6> THROUGH SW<0>
SW<7>=1....	200	PRINT ERROR SUMMARY EVEN IF SW<13>=1. THIS APPLIES ONLY TO PROGRAM CKFPACO.
SW<7>=1....	200	SELECT CORRECT INTERRUPT TEST IN PROGRAM CKFPB80.

310 6. ERRORS

313 6.1 SUMMARIES

314 IN PROGRAM CKFPACO TESTS 1 AND 11 HAVE A SPECIAL
315 ERROR SUMMARY FEATURE. THESE TWO TEST RUN MANY
316 TEST PATTERNS THROUGH THE LOGIC. AFTER AN ERROR
317 IS ENCOUNTERED, ONLY THE FIRST FIVE ERRORS ARE
318 REPORTED (TYPED ON THE TTY). EVERY ERROR THOUGH IS
319 LOGGED AND AN ERROR SUMMARY IS PRINTED WHEN THE
320 TEST IS COMPLETE. NOTE THAT IF SW<13>=1 THIS
321 SUMMARY WILL NOT BE TYPED UNLESS SW<7>=1. IN OTHER
322 WORDS TO GET JUST AN ERROR SUMMARY FROM EITHER OF
323 THESE TWO TESTS 1 AND 11 IN PROGRAM CKFPACO BOTH
324 SWITCHES 13 AND 7 MUST = 1.

327 6. ERROR RECOVERY

328
329 SW<15:9>=0... MOST ERRORS WILL CAUSE EXECUTION TO
330 GO TO THE START OF THE NEXT TEST
331 AFTER THE MESSAGE IS TYPED. A FEW
332 TESTS ARE IN SECTIONS. IN THESE
333 TESTS AN ERROR WILL CAUSE EXECUTION
334 TO GO TO THE NEXT SECTION AFTER THE
335 MESSAGE IS TYPED.
336 SW<15>=1.. THE PROGRAM WILL HALT AFTER TYPING
337 THE ERROR MESSAGE. PRESSING THE
338 CONSOLE CONTINUE WILL CAUSE THE
339 PROGRAM TO CONTINUE AS IF SW<15>=0.
340
341 7. RESTRICTIONS
342 -----
343
344 NONE
345
346
347 8. MISCELLANEOUS
348 -----
349
350 8.1 EXECUTION TIMES
351 LESS THAN 10 SECONDS FOR EACH PROGRAM ON ANY PASS.
352
353 8.2 STACK POINTER
354
355 THE STACK POINTER IS INITIALIZED TO 1100 IN EACH OF
356 THE THREE PROGRAMS.
357
358 8.3 PASS COUNT
359 THE PROGRAM MAKES ONE PASS FOR EACH END OF PASS
360 MESSAGE TYPED. THE END OF PASS MESSAGE DESCRIBES
361 THE TOTAL NUMBER OF PASSES COMPLETED AND THE TOTAL
362 NUMBER OF ERRORS SINCE THE LAST END OF PASS MESSAGE.
363
364 8.4 T-BIT TRAPPING
365
366 IF SW<12>=0 EACH PROGRAM WILL RUN WITH TRACE TRAPS
367 ON EVERY OTHER PASS. FIRST PASS WILL NOT ENABLE
368 TRACE TRAPS. NOTE SW<12>=1 DISABLES T-BIT TRAPS.
369
370
371 8.5 SOFTWARE SWITCH REGISTER
372
373 IF THE USER DESIRES, A SOFTWARE SWITCH REGISTER CAN
374 BE EXAMINED OR MODIFIED AT ANY TIME BY THE USER IF
375 HE TYPES CNTRL/G WHILE THE PROGRAM IS RUNNING. THIS
376 CNTRL/G WILL CAUSE THE CONTENTS OF THE SOFTWARE
377 SWITCH REGISTER TO BE TYPED ON THE TTY AND ASK THE
378 USER FOR A NEW VALUE. WHEN THE USER TYPES A VALUE
379 AND CARRIAGE RETURN THEN THE PROGRAM WILL RESUME
380 TESTING AT THE SAME POINT AT WHICH IT LEFT OFF WHEN
381 THE USER TYPED CNTRL/G. NOTE THAT WHEN NOT RUNNING
382 UNDER ACT, APT OR CHAIN THE USER WILL BE ASKED
383 FOR A SOFTWARE SWITCH REGISTER VALUE AFTER LOADING
384 ADDRESS 200 AND STARTING THE PROGRAM THE FIRST TIME

385 THE PROGRAM IS RUN AFTER LOADING ONLY IF THE
386 CONSOLE SWITCH REGISTER CONTAINS 177777.

389 8.6 INTERRUPTS TEST

391 IN PROGRAM CKFPBBO THERE IS A SPECIAL TEST FOR
392 CHECKING THE CORRECT FLOWS OF THE FPP. THIS TEST
393 CAN BE RUN ONLY IF A SPECIAL TEST MODULE IS IN THE
394 SYSTEM. THIS MODULE WILL PROBABLY ONLY BE USED IN
395 MANUFACTURING. IF THIS MODULE IS NOT IN THE SYSTEM
396 THIS TEST WILL AUTOMATICALLY BE DESELECTED. IF THIS
397 TEST MODULE IS ON THE SYSTEM AND SW<7>=1 THIS TEST
398 WILL BE RUN. IF SW<7>=0, THIS TEST WILL BE
399 DESELECTED.

402 8.7 ACT, APT AND XXDP COMPATIBILITY

403 THESE PROGRAMS ARE FULLY COMPATIBLE WITH:
404 APT
405 ACT
406 XXDP MONITOR AND CHAIN PROGRAMS.

412 9. PROGRAM DESCRIPTION

420 TEST 1 STF WITH ILLEGAL ACCUMULATOR TEST

421 -----
422 THIS IS A TEST OF THE ST INSTRUCTION USING ILLEGAL
423 ACCUMULATOR 7, MODE 0.

426 TEST 2 FDST MODE 1, FLOATING MODE, TEST

427 -----
428 THIS IS A TEST OF THE STF INSTRUCTION USING FDST
429 MODE 1.

432 TEST 3 FDST MODE 2 TEST

433 -----
434 THIS IS A TEST OF BOTH STF AND STD WITH FDST MODE 2.

437 TEST 4 FDST MODE 2, WITH GR7, TEST

438 -----
439 THIS IS A TEST OF STF WITH GR7 MODE 2 OR IMMEDIATE
440 MODE.
441

442
443 TEST 5 FDST MODE 4 TEST
444 -----
445 THIS IS A TEST OF STD WITH FDST MODE 4.
446
447 TEST 6 FDST MODE 3 TEST
448 -----
449 THIS IS A TEST OF FDST MODE 3 USING STD.
450
451 TEST 7 FDST MODE 5 TEST
452 -----
453 THIS IS A TEST OF FDST MODE 5 USING STD.
454
455 TEST 10 FDST MODE 6, INDEX MODE, TEST
456 -----
457 THIS IS A TEST OF FDST MODE 6, INDEX MODE, USING
458 STD.
459
460 TEST 11 FDST MODE 7, INDEX DEFERRED MODE, TEST
461 -----
462 THIS IS A TEST OF FDST MODE 7, INDEX DEFERRED MODE,
463 USING STD.
464
465 TEST 12 STCFD TEST
466 -----
467 THIS IS A TEST OF THE STCFD INSTRUCTION.
468
469 TEST 13 STCDF TEST
470 -----
471 THIS IS A TEST OF THE STCDF INSTRUCTION.
472
473 TEST 14 STCFD WITH ILLEGAL ACCUMULATOR TEST
474 -----
475 THIS TEST STCFD WITH ILLEGAL AC 6.
476
477 TEST 15 CLR D TEST
478 -----
479 THIS IS A TEST OF THE CRLF AND CLR D INSTRUCTIONS.
480
481 TEST 16 CLR D WITH ILLEGAL ACCUMULATOR TEST
482 -----
483 THIS IS A TEST OF CLR D WITH ILLEGAL AC7.
484
485 TEST 17 NEGF, ABSF AND TSTF SOURCE MODE 0 WITH ILLEGAL AC7, TEST
486 -----
487 THIS IS A TEST OF THE SPECIAL DEST FLOWS USING THE
488
489
490
491
492
493
494
495
496
497
498

499 NEGD INST WITH MODE ZERO AND ILLEGAL AC7.
500
501 TEST 20 NEGF, ABSF AND TSTF SOURCE MODE 0 TEST
502 -----
503
504 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
505 THE NEGD INSTRUCTION IS USED TO TEST MODE 0
506
507 TEST 21 NEGF, ABSF AND TSTF SOURCE MODE 1 TEST
508 -----
509
510 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
511 THE NEGD INSTRUCTION IS USED TO TEST MODE 1
512
513 TEST 22 NEGF, ABSF AND TSTF SOURCE MODE 2 TEST
514 -----
515
516 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
517 THE ABSD INSTRUCTION IS USED TO TEST MODE 2
518
519 TEST 23 NEGF, ABSF AND TSTF SOURCE MODE 4 TEST
520 -----
521
522 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
523 THE ABSD INSTRUCTION IS USED TO TEST MODE 4
524
525 TEST 24 NEGF, ABSF AND TSTF SOURCE MODE 3 TEST
526 -----
527
528 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
529 THE ABSD INSTRUCTION IS USED TO TEST MODE 3
530
531 TEST 25 NEGF, ABSF AND TSTF SOURCE MODE 5 TEST
532 -----
533
534 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
535 THE NEGD INSTRUCTION IS USED TO TEST MODE 5
536
537 TEST 26 NEGF, ABSF AND TSTF SOURCE MODE 6 TEST
538 -----
539
540 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
541 THE ABSD INSTRUCTION IS USED TO TEST MODE 6
542
543 TEST 27 NEGF, ABSF AND TSTF SOURCE MODE 7 TEST
544 -----
545
546 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
547 THE ABSD INSTRUCTION IS USED TO TEST MODE 6
548
549 TEST 30 NEGF, ABSF AND TSTF SOURCE MODE 6, GR7, TEST
550 -----
551
552 THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
553 THE NEGD INSTRUCTION IS USED TO TEST MODE 6
554
555 TEST 31 NEGF, ABSF AND TSTF SOURCE MODE 7, GR7, TEST

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

THIS IS A TEST THE NEGF, ABSF AND TSTF SOURCE FLOWS.
THE ABSD INSTRUCTION IS USED TO TEST MODE 7

TEST 32 SPECIAL DEST, MODE 0, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 0 USING THE NEGD INSTR.

TEST 33 SPECIAL DEST, MODE 1, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 1 USING THE NEGD INSTR.

TEST 34 SPECIAL DEST, MODE 2, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 2 USING THE NEGD INSTR.

TEST 35 SPECIAL DEST, MODE 4, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 4 USING THE NEGD INSTR.

TEST 36 SPECIAL DEST, MODE 3, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 3 USING THE NEGD INSTR.

TEST 37 SPECIAL DEST, MODE 5, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 5 USING THE NEGD INSTR.

TEST 40 SPECIAL DEST, FLOATING MODE 2, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 2 USING THE NEGF INSTR.

TEST 41 SPECIAL DEST, MODE2, GR7 (IMMEDIATE), TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 2(IMMEDIATE) USING THE NEGD INSTR.

TEST 42 SPECIAL DEST, MODE 6, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 6 USING THE NEGD INSTR.

613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669

TEST 43 SPECIAL DEST, MODE 7, TEST

THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION
FLOWS MODE 7 USING THE NEGD INSTR.
TEST 44 NEGD, ABSD AND TSTD TEST

THIS IS A TEST OF THE NEGD ABSD AND TSTD
INSTRUCTIONS.
TEST 45 SOURCE MODES, MODE 1 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 1 USING THE LDFPS
INSTRUCTION.
TEST 46 SOURCE MODES, MODE 2 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 2 USING THE LDFPS
INSTRUCTION.
TEST 47 SOURCE MODES, MODE 4 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 4 USING THE LDFPS
INSTRUCTION.
TEST 50 SOURCE MODES, MODE 3 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 3 USING THE LDFPS
INSTRUCTION.
TEST 51 SOURCE MODES, MODE 5 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 5 USING THE LDFPS
INSTRUCTION.
TEST 52 SOURCE MODES, MODE 6 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 6 USING THE LDFPS
INSTRUCTION.
TEST 53 SOURCE MODES, MODE 7 (FL=0), TEST

THIS IS A TEST OF SOURCE MODE 7 USING THE LDFPS
INSTRUCTION
TEST 54 SOURCE MODES, MODE 2 GR7 (FL=1), TEST

670
671 THIS IS A TEST OF THE LDCLD WITH IMMEDIATE
672 ADDRESSING MODE
673
674 TEST 55 SOURCE MODES, MODE 2 (FL=1), TEST
675 -----
676 THIS IS A TEST OF THE LDCLD INSTRUCTION WITH MODE 2.
677
678 TEST 56 LDCIF AND LDCLF TEST
679 -----
680
681 THIS IS A TEST OF THE LDCIF AND THE LDCLF
682 INSTRUCTIONS.
683
684 TEST 57 LDCID AND LDCLD TEST
685 -----
686
687 THIS IS A TEST OF LDCID AND LDCLD
688
689 TEST 60 LDEXP TEST
690 -----
691
692 THIS IS A TEST OF THE LDEXP INST A SUBROUTINE IS
693 USED TO SET UP OPERANDS, EXECUTE THE LDEXP INST AND
694 CHECK THE RESULTS.
695
696 TEST 61 DESTINATION MODES, MODE 1 (FL=0), TEST
697 -----
698
699 THIS IS A TEST OF DESTINATION MODE 1 USING THE STFPS
700 INSTRUCTION
701
702 TEST 62 DESTINATION MODES, MODE 2 (FL=0), TEST
703 -----
704
705 THIS IS A TEST OF DESTINATION MODE 2 USING THE STFPS
706 INSTRUCTION
707
708 TEST 63 DESTINATION MODES, MODE 4 (FL=0), TEST
709 -----
710
711 THIS IS A TEST OF DESTINATION MODE 4 USING THE STFPS
712 INSTRUCTION
713
714 TEST 64 DESTINATION MODES, MODE 3 (FL=0), TEST
715 -----
716
717 THIS IS A TEST OF DESTINATION MODE 3 USING THE STFPS
718 INSTRUCTION
719
720 TEST 65 DESTINATION MODES, MODE 5 (FL=0), TEST
721 -----
722
723 THIS IS A TEST OF DESTINATION MODE 5 USING THE STFPS
724 INSTRUCTION
725
726 TEST 66 DESTINATION MODES, MODE 6 (FL=0), TEST

727
728
729
730
731
732
733
734

THIS IS A TEST OF DESTINATION MODE 6 USING THE STFPS
INSTRUCTION

TEST 67 DESTINATION MODES, MODE 7 (FL=0), TEST

736 THIS IS A TEST OF DESTINATION MODE 7 USING THE STFPS
737 INSTRUCTION
738
739 TEST 70 DESTINATION MODES, MODE 2 (FL=1), TEST
740 -----
741
742 THIS IS A TEST OF DESTINATION MODE 2 USING STCOL
743 WITH REGISTER 0
744
745 TEST 71 DESTINATION MODES, MODE 4 (FL=1), TEST
746 -----
747
748 THIS IS A TEST OF DESTINATION MODE 4 USING STCDL
749 WITH REGISTER 0
750
751 TEST 72 STCDI AND STCDL TEST
752 -----
753
754 THIS IS A TEST OF THE STCDI AND STCDL INSTRUCTIONS.
755 NOTE THAT A SUBROUTINE, STCSUB, IS USED TO SET UP
756 THE OPERANDS, EXECUTE THE STC INSTRUCTION AND CHECK
757 THE RESULT.
758
759 TEST 73 STCFL AND STCFI TEST
760 -----
761
762 THIS IS A TEST OF STCFL AND STCFI. IT MAKES USE OF
763 THE SAME SUBROUTINE, STCSUB, WHICH WAS USED TO TEST
764 STCDL AND STCDI.
765
766 TEST 74 STEXP TEST
767 -----
768
769 THIS IS A TEST OF THE STEXP INSTRUCTION
770
771 TEST 75 STST TEST
772 -----
773
774 THIS IS A TEST OF THE STST INSTRUCTION. FIRST AN
775 ILLEGAL FPS OP CODE (INSTRUCTION) IS USED TO ENTER
776 AN ERROR CONDITION IN THE FEC AND FEA. THE STST IS
777 EXECUTED AND THE FEC AND FEA ARE CHECKED
778
779 TEST 76 D-SPACE NON-ACCESS TEST
780 -----
781
782 THIS IS A TEST THAT ENABLES D-SPACE, BUT MAKES IT
783 NON-RESIDENT, CAUSING A MEMORY MANAGEMENT TRAP
784 SHOULD IT BE ACCESSED DURING AN INSTRUCTION THAT
785 WILL NOT NORMALLY ACCESS D-SPACE.
786
787 TEST 77 AUTO INCREMENT/DECREMENT TEST
788 -----
789
790 THIS IS A TEST THAT ENABLES D-SPACE, BUT MAKES IT
791 NON-RESIDENT IN THE AREA OF THE TEST, FORCING A
792 MEMORY MANAGEMENT TRAP FOR EVERY FPP INSTRUCTION IN

793 THE TEST. SR1 IS THEN EXAMINED FOR PROPER CONTENTS.
794 SHOULD THE FPP INSTRUCTION FAIL TO ABORT, THE NEXT
795 INSTRUCTION IS AN IOT TRAP, AND CALLS AN ERROR TO
796 ANNOUNCE THE FPP INSTRUCTION'S FAILING TO CAUSE AN
797 ABORT, NOT ALLOWING PROPER EXAMINATION OF SR1.

798

799

800

801

802

803

804

000444

10.

LISTING
-----8

805

PROGNUM=3

806

.LIST ME

807

.NLIST MD

808

.NLIST MC

809

.NLIST CND

810

.NLIST BEX

1974 .MCALL .HEADER,.SWRHI,.EQUAT,.SETUP,.SCATCH,.SACT11
 1975 .MCALL .SSAVE,.\$CMTAG
 1976 .MCALL .\$TYPDEC,.STRAP,.\$POWER,.SAPTHDR,.SAPTBLS
 1977 .MCALL .SAPTYPE,.\$READ
 1978 .MCALL .EQUIV ;REMOVE FOR PDP-10
 1979 .TITLE CKFPCDO FP11F FLTG PNT PRT C
 :*COPYRIGHT (C) 1981
 :*DIGITAL EQUIPMENT CORP.
 :*MAYNARD, MASS. 01754
 :*
 :*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
 :*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.
 :*
 000001 \$TN=1
 160000 \$SWR=160000 ;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYPOUT
 1980
 1981
 1982 000244 FPVECT=244
 1983 000250 MMVECT=250
 1984 177400 \$SWR=177400
 1985 000200 \$SWRMSK=200
 1986 000011 TAB=11
 1987 000015 CRLF=15
 1988
 1989 .SBttl BASIC DEFINITIONS
 :*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
 001100 STACK= 1100
 104000 ERROR=EMT
 000004 SCOPE=IOT
 :*MISCELLANEOUS DEFINITIONS
 000011 HT= 11 ;CODE FOR HORIZONTAL TAB
 000012 LF= 12 ;CODE FOR LINE FEED
 000015 CR= 15 ;CODE FOR CARRIAGE RETURN
 000200 CRLF= 200 ;CODE FOR CARRIAGE RETURN-LINE FEED
 177776 PS= 177776 ;PROCESSOR STATUS WORD
 177776 PSW=PS
 177774 STKLMT= 177774 ;STACK LIMIT REGISTER
 177772 PIRQ= 177772 ;PROGRAM INTERRUPT REQUEST REGISTER
 177570 DSWR= 177570 ;HARDWARE SWITCH REGISTER
 177570 DDISP= 177570 ;HARDWARE DISPLAY REGISTER
 :*GENERAL PURPOSE REGISTER DEFINITIONS
 000000 R0= %0 ;GENERAL REGISTER
 000001 R1= %1 ;GENERAL REGISTER
 000002 R2= %2 ;GENERAL REGISTER
 000003 R3= %3 ;GENERAL REGISTER
 000004 R4= %4 ;GENERAL REGISTER
 000005 R5= %5 ;GENERAL REGISTER
 000006 R6= %6 ;GENERAL REGISTER
 000007 R7= %7 ;GENERAL REGISTER
 000008 SP= %6 ;STACK POINTER
 000007 PC= %7 ;PROGRAM COUNTER
 :*PRIORITY LEVEL DEFINITIONS
 000000 PR0= 0 ;PRIORITY LEVEL 0
 000040 PR1= 40 ;PRIORITY LEVEL 1
 000100 PR2= 100 ;PRIORITY LEVEL 2
 000140 PR3= 140 ;PRIORITY LEVEL 3

BASIC DEFINITIONS

000200 PR4= 200 ;:PRIORITY LEVEL 4
000240 PR5= 240 ;:PRIORITY LEVEL 5
000300 PR6= 300 ;:PRIORITY LEVEL 6
000340 PR7= 340 ;:PRIORITY LEVEL 7
;*''SWITCH REGISTFR'' SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00
;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01

BASIC DEFINITIONS

000001		BIT0=BIT00
000004	ERRVEC=	*BASIC "CPU" TRAP VECTOR ADDRESSES
000010	RESVEC=	4 : TIME OUT AND OTHER ERRORS
000014	TBITVEC=	10 : RESERVED AND ILLEGAL INSTRUCTIONS
000014	TRTVEC=	14 : "T" BIT
000014	BPTVEC=	14 : TRACE TRAP
000020	IOTVEC=	20 : BREAKPOINT TRAP (BPT)
000024	PWRVEC=	24 : INPUT/OUTPUT TRAP (IOT) **SCOPE**
000030	EMTVEC=	30 : POWER FAIL
000034	TRAPVEC=	34 : EMULATOR TRAP (EMT) **ERROR**
000060	TKVEC=	60 : "TRAP" TRAP
000064	TPVEC=	64 : TTY KEYBOARD VECTOR
000240	PIRQVEC=	240 : TTY PRINTER VECTOR
		PROGRAM INTERRUPT REQUEST VECTOR
1990		.SBTTL FPP REGISTER DEFINITIONS
1991	000000	AC0 =%0
1992	000001	AC1 =%1
1993	000002	AC2 =%2
1994	000003	AC3 =%3
1995	000004	AC4 =%4
1996	000005	AC5 =%5
1997	000006	AC6 =%6
1998	000007	AC7 =%7
1999	172300	KIPDRO =172300
2000	172302	KIPDR1 =172302
2001	172304	KIPDR2 =172304
2002	172306	KIPDR3 =172306
2003	172310	KIPDR4 =172310
2004	172316	KIPDR7 =172316
2005	172340	KIPAR0 =172340
2006	172342	KIPAR1 =172342
2007	172344	KIPAR2 =172344
2008	172346	KIPAR3 =172346
2009	172350	KIPAR4 =172350
2010	172356	KIPAR7 =172356
2011	172320	KDPDRO =172320
2012	172322	KDPDR1 =172322
2013	172324	KDPDR2 =172324
2014	172326	KDPDR3 =172326
2015	172330	KDPDR4 =172330
2016	172336	KDPDR7 =172336
2017	172360	KDPAR0 =172360
2018	172362	KDPAR1 =172362
2019	172364	KDPAR2 =172364
2020	172366	KDPAR3 =172366
2021	172370	KDPAR4 =172370
2022	172376	KDPAR7 =172376
2023	177572	MMR0 =177572
2024	177574	SR1 =177574
2025	177576	MMR2 =177576
2026	172516	MMR3 =172516
2027	117760	DATA =117760
2028	000020	IOTRAP =000020
2029		
2031		
2032		
	000000	.SBTTL TRAP CATCHER
		.=0

;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

000174 000000
000176 000000
000200 000137 006116

.=174
DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER
.SBTLL STARTING ADDRESS(ES)
JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM

COMMON TAGS

2033

.SBTTL COMMON TAGS

;*****
;★THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;★USED IN THE PROGRAM.

.=1100

001100	001100	\$CMTAG:	.WORD	0	;;START OF COMMON TAGS
001100	000000	\$TSTNM:	.BYTE	0	;:CONTAINS THE TEST NUMBER
001102	000	\$ERFLG:	.BYTE	0	;:CONTAINS ERROR FLAG
001103	000	\$ICNT:	.WORD	0	;:CONTAINS SUBTEST ITERATION COUNT
001104	000000	\$LPADR:	.WORD	0	;:CONTAINS SCOPE LOOP ADDRESS
001106	000000	\$LPERR:	.WORD	0	;:CONTAINS SCOPE RETURN FOR ERRORS
001110	000000	\$ERTTL:	.WORD	0	;:CONTAINS TOTAL ERRORS DETECTED
001112	000000	\$ITEMB:	.BYTE	0	;:CONTAINS ITEM CONTROL BYTE
001114	000	\$ERMAX:	.BYTE	1	;:CONTAINS MAX. ERRORS PER TEST
001115	001	\$ERRPC:	.WORD	0	;:CONTAINS PC OF LAST ERROR INSTRUCTION
001116	000000	\$GDADR:	.WORD	0	;:CONTAINS ADDRESS OF 'GOOD' DATA
001120	000000	\$BDADR:	.WORD	0	;:CONTAINS ADDRESS OF 'BAD' DATA
001122	000000	\$GDDAT:	.WORD	0	;:CONTAINS 'GOOD' DATA
001124	000000	\$BDDAT:	.WORD	0	;:CONTAINS 'BAD' DATA
001126	000000		.WORD	0	;:RESERVED--NOT TO BE USED
001130	000000		.WORD	0	
001132	000000		.WORD	0	
001134	000	\$AUTOB:	.BYTE	0	;:AUTOMATIC MODE INDICATOR
001135	000	\$INTAG:	.BYTE	0	;:INTERRUPT MODE INDICATOR
001136	000000		.WORD	0	
001140	177570	SWR:	.WORD	DSWR	;:ADDRESS OF SWITCH REGISTER
001142	177570	DISPLAY:	.WORD	DDISP	;:ADDRESS OF DISPLAY REGISTER
001144	177560	\$TKS:	177560		;:TTY KBD STATUS
001145	177562	\$TKB:	177562		;:TTY KBD BUFFER
001150	177564	\$TPS:	177564		;:TTY PRINTER STATUS REG. ADDRESS
001152	177566	\$TPB:	177566		;:TTY PRINTER BUFFER REG. ADDRESS
001154	000	\$NULL:	.BYTE	0	;:CONTAINS NULL CHARACTER FOR FILLS
001155	002	\$FILLS:	.BYTE	2	;:CONTAINS # OF FILLER CHARACTERS REQUIRED
001156	012	\$FILLC:	.BYTE	12	;:INSERT FILL CHARS. AFTER A 'LINE FEED'
001157	000	\$TPFLG:	.BYTE	0	;:'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001160	000000	\$REGAD:	.WORD	0	;:CONTAINS THE ADDRESS FROM ;:WHICH (\$REGO) WAS OBTAINED
	000024		.REPT	\$CM3	
001162	000000	\$REG0:	.WORD	0	;:CONTAINS ((SREGAD)+0)
001164	000000	\$REG1:	.WORD	0	;:CONTAINS ((SREGAD)+2)
001166	000000	\$REG2:	.WORD	0	;:CONTAINS ((SREGAD)+4)
001170	000000	\$REG3:	.WORD	0	;:CONTAINS ((SREGAD)+6)
001172	000000	\$REG4:	.WORD	0	;:CONTAINS ((SREGAD)+10)
001174	000000	\$REG5:	.WORD	0	;:CONTAINS ((SREGAD)+12)
001176	000000	\$REG6:	.WORD	0	;:CONTAINS ((SREGAD)+14)
001200	000000	\$REG7:	.WORD	0	;:CONTAINS ((SREGAD)+16)
001202	000000	\$REG10:	.WORD	0	;:CONTAINS ((SREGAD)+20)
001204	000000	\$REG11:	.WORD	0	;:CONTAINS ((SREGAD)+22)
001206	000000	\$REG12:	.WORD	0	;:CONTAINS ((SREGAD)+24)
001210	000000	\$REG13:	.WORD	0	;:CONTAINS ((SREGAD)+26)
001212	000000	\$REG14:	.WORD	0	;:CONTAINS ((SREGAD)+30)
001214	000000	\$REG15:	.WORD	0	;:CONTAINS ((SREGAD)+32)
001216	000000	\$REG16:	.WORD	0	;:CONTAINS ((SREGAD)+34)
001220	000000	\$REG17:	.WORD	0	;:CONTAINS ((SREGAD)+36)
001222	000000	\$REG20:	.WORD	0	;:CONTAINS ((SREGAD)+40)
001224	000000	\$REG21:	.WORD	0	;:CONTAINS ((SREGAD)+42)
001226	000000	\$REG22:	.WORD	0	;:CONTAINS ((SREGAD)+44)

001230	000000		\$REG23: .WORD 0	;;CONTAINS ((\$REGAD)+46)
001232	000000		.REPT 24	
001234	000000		\$TMP0: .WORD 0	;;USER DEFINED
001236	000000		\$TMP1: .WORD 0	;;USER DEFINED
001238	000000		\$TMP2: .WORD 0	;;USER DEFINED
001240	000000		\$TMP3: .WORD 0	;;USER DEFINED
001242	000000		\$TMP4: .WORD 0	;;USER DEFINED
001244	000000		\$TMP5: .WORD 0	;;USER DEFINED
001246	000000		\$TMP6: .WORD 0	;;USER DEFINED
001250	000000		\$TMP7: .WORD 0	;;USER DEFINED
001252	000000		\$TMP10: .WORD 0	;;USER DEFINED
001254	000000		\$TMP11: .WORD 0	;;USER DEFINED
001256	000000		\$TMP12: .WORD 0	;;USER DEFINED
001260	000000		\$TMP13: .WORD 0	;;USER DEFINED
001262	000000		\$TMP14: .WORD 0	;;USER DEFINED
001264	000000		\$TMP15: .WORD 0	;;USER DEFINED
001266	000000		\$TMP16: .WORD 0	;;USER DEFINED
001270	000000		\$TMP17: .WORD 0	;;USER DEFINED
001272	000000		\$TMP20: .WORD 0	;;USER DEFINED
001274	000000		\$TMP21: .WORD 0	;;USER DEFINED
001276	000000		\$TMP22: .WORD 0	;;USER DEFINED
001300	000000		\$TMP23: .WORD 0	;;USER DEFINED
001302	000000		\$TIMES: 0	;;MAX. NUMBER OF ITERATIONS
001304	000000		\$ESCAPE: 0	;;ESCAPE ON ERROR ADDRESS
001306	207	377	\$BELL: .ASCIZ <207><377><377>	;;CODE FOR BELL
001312	077		\$QUES: .ASCII /?/	;;QUESTION MARK
001313	015		\$CRLF: .ASCII <15>	;;CARRIAGE RETURN
001314	012	000	\$LF: .ASCIZ <12>	;;LINE FEED
*****.SBTTL APT MAILBOX-ETABLE*****				
*****.EVEN*****				
001316	000000		\$MAIL: .WORD	;;APT MAILBOX
001316	000000		\$MSGTY: .WORD AMSGTY	;;MESSAGE TYPE CODE
001320	000000		\$FATAL: .WORD AFATAL	;;FATAL ERROR NUMBER
001322	000000		\$TESTN: .WORD ATESTN	;;TEST NUMBER
001324	000000		\$PASS: .WORD APASS	;;PASS COUNT
001326	000000		\$DEVCT: .WORD ADEVCT	;;DEVICE COUNT
001330	000000		\$UNIT: .WORD AUNIT	;;I/O UNIT NUMBER
001332	000000		\$MSGAD: .WORD AMSGAD	;;MESSAGE ADDRESS
001334	000000		\$MSGLG: .WORD AMSGLG	;;MESSAGE LENGTH
001336	000		\$ETABLE: .WORD	;;APT ENVIRONMENT TABLE
001336	000		\$ENV: .BYTE AENV	;;ENVIRONMENT BYTE
001337	000		\$ENVM: .BYTE AENVM	;;ENVIRONMENT MODE BITS
001340	000000		\$SWREG: .WORD ASWREG	;;APT SWITCH REGISTER
001342	000000		\$USR: .WORD AUSR	;;USER SWITCHES
001344	000000		\$CPUOP: .WORD ACPUOP	;;CPU TYPE,OPTIONS BITS 15-11=CPU TYPE 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05 11/70=06,PDQ=07,Q=10
BIT 10=REAL TIME CLOCK				
BIT 9=FLOATING POINT PROCESSOR				
BIT 8=MEMORY MANAGEMENT				
001346	000		\$MAMS1: .BYTE AMAMS1	;;HIGH ADDRESS,M.S. BYTE
001347	000		\$MTYP1: .BYTE AMTYP1	;;MEM. TYPE,BLK#1 MEM. TYPE BYTE -- (HIGH BYTE) 900 NSEC CORE=001

**
300 NSEC BIPOLAR=002
500 NSEC MOS=003

001350 000000	\$MADR1: .WORD	AMADR1	;:HIGH ADDRESS,BLK#1 MEM.LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
001352 000	\$MAMS2: .BYTE	AMAMS2	;:HIGH ADDRESS,M.S. BYTE
001353 000	\$MTYP2: .BYTE	AMTYP2	;:MEM.TYPE,BLK#2
001354 000000	\$MADR2: .WORD	AMADR2	;:MEM.LAST ADDRESS,BLK#2
001356 000	\$MAMS3: .BYTE	AMAMS3	;:HIGH ADDRESS,M.S.BYTE
001357 000	\$MTYP3: .BYTE	AMTYP3	;:MEM.TYPE,BLK#3
001360 000000	\$MADR3: .WORD	AMADR3	;:MEM.LAST ADDRESS,BLK#3
001362 000	\$MAMS4: .BYTE	AMAMS4	;:HIGH ADDRESS,M.S.BYTE
001363 000	\$MTYP4: .BYTE	AMTYP4	;:MEM.TYPE,BLK#4
001364 000000	\$MADR4: .WORD	AMADR4	;:MEM.LAST ADDRESS,BLK#4
001366 000000	SVECT1: .WORD	AVECT1	;:INTERRUPT VECTOR#1,BUS PRIORITY#1
001370 000000	SVECT2: .WORD	AVECT2	;:INTERRUPT VECTOR#2BUS PRIORITY#2
001372 000000	SBASE: .WORD	ABASE	;:BASE ADDRESS OF EQUIPMENT UNDER TEST
001374 000000	SDEVM: .WORD	ADEVM	;:DEVICE MAP
001376 000000	SCDW1: .WORD	ACDW1	;:CONTROLLER DESCRIPTION WORD#1
001400 000000	SCDW2: .WORD	ACDW2	;:CONTROLLER DESCRIPTION WORD#2
001402 000000	SDDW0: .WORD	ADDW0	;:DEVICE DESCRIPTOR WORD#0
001404 000000	SDDW1: .WORD	ADDW1	;:DEVICE DESCRIPTOR WORD#1
001406 000000	SDDW2: .WORD	ADDW2	;:DEVICE DESCRIPTOR WORD#2
001410 000000	SDDW3: .WORD	ADDW3	;:DEVICE DESCRIPTOR WORD#3
001412 000000	SDDW4: .WORD	ADDW4	;:DEVICE DESCRIPTOR WORD#4
001414 000000	SDDW5: .WORD	ADDW5	;:DEVICE DESCRIPTOR WORD#5
001416 000000	SDDW6: .WORD	ADDW6	;:DEVICE DESCRIPTOR WORD#6
001420 000000	SDDW7: .WORD	ADDW7	;:DEVICE DESCRIPTOR WORD#7
001422 000000	SDDW8: .WORD	ADDW8	;:DEVICE DESCRIPTOR WORD#8
001424 000000	SDDW9: .WORD	ADDW9	;:DEVICE DESCRIPTOR WORD#9
001426 000000	SDDW10: .WORD	ADCW10	;:DEVICE DESCRIPTOR WORD#10
001430 000000	SDDW11: .WORD	ADDW11	;:DEVICE DESCRIPTOR WORD#11
001432 000000	SDDW12: .WORD	ADDW12	;:DEVICE DESCRIPTOR WORD#12
001434 000000	SDDW13: .WORD	ADDW13	;:DEVICE DESCRIPTOR WORD#13
001436 000000	SDDW14: .WORD	ADDW14	;:DEVICE DESCRIPTOR WORD#14
001440 000000	SDDW15: .WORD	ADDW15	;:DEVICE DESCRIPTOR WORD#15
001442	SETEND:		

.SBTTL ERROR POINTER TABLE
 :*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 :*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 :*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 :*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 :*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
 :* EM ::POINTS TO THE ERROR MESSAGE
 :* DH ::POINTS TO THE DATA HEADER
 :* DT ::POINTS TO THE DATA
 :* DF ::POINTS TO THE DATA FORMAT

SERRTB:				.REPT	MNUMBER	
2037	001442	000444	071204	.WORD	EM1,DH1,DT1,DF1	:ITEM 1
2039	001442	052346	071204	.WORD	EM2,DH2,DT2,DF2	:ITEM 2
	001452	052422	071274	.WORD	EM3,DH3,DT3,DF3	:ITEM 3
	001462	052452	071340	.WORD	EM4,DH4,DT4,DF4	:ITEM 4
	001472	052502	071404	.WORD	EM5,DH5,DT5,DF5	:ITEM 5
	001502	052563	071447	.WORD	EM6,DH6,DT6,DF6	:ITEM 6
	001512	052574	071447	.WORD	EM7,DH7,DT7,DF7	:ITEM 7
	001522	052737	071404	.WORD	EM10,DH10,DT10,DF10	:ITEM 10
	001532	052761	071447	.WORD	EM11,DH11,DT11,DF11	:ITEM 11
	001542	052774	071404	.WORD	EM12,DH12,DT12,DF12	:ITEM 12
	001552	053024	071447	.WORD	EM13,DH13,DT13,DF13	:ITEM 13
	001562	053036	071460	.WORD	EM14,DH14,DT14,DF14	:ITEM 14
	001572	053036	071460	.WORD	EM15,DH15,DT15,DF15	:ITEM 15
	001602	053104	071447	.WORD	EM16,DH16,DT16,DF16	:ITEM 16
	001612	053116	071520	.WORD	EM17,DH17,DT17,DF17	:ITEM 17
	001622	053142	071460	.WORD	EM20,DH20,DT20,DF20	:ITEM 20
	001632	053166	071404	.WORD	EM21,DH21,DT21,DF21	:ITEM 21
	001642	053204	071447	.WORD	EM22,DH22,DT22,DF22	:ITEM 22
	001652	053204	071447	.WORD	EM23,DH23,DT23,DF23	:ITEM 23
	001662	053216	071460	.WORD	EM24,DH24,DT24,DF24	:ITEM 24
	001672	053243	071404	.WORD	EM25,DH25,DT25,DF25	:ITEM 25
	001702	053260	071447	.WORD	EM26,DH26,DT26,DF26	:ITEM 26
	001712	053272	071460	.WORD	EM27,DH27,DT27,DF27	:ITEM 27
	001722	053317	071404	.WORD	EM30,DH30,DT30,DF30	:ITEM 30
	001732	053334	071447	.WORD	EM31,DH31,DT31,DF31	:ITEM 31
	001742	053346	071460	.WORD	EM32,DH32,DT32,DF32	:ITEM 32
	001752	053372	071404	.WORD	EM33,DH33,DT33,DF33	:ITEM 33
	001762	053410	071447	.WORD	EM34,DH34,DT34,DF34	:ITEM 34
	001772	053422	071460	.WORD	EM35,DH35,DT35,DF35	:ITEM 35
	002002	053447	071404	.WORD	EM36,DH36,DT36,DF36	:ITEM 36
	002012	053464	071447	.WORD	EM37,DH37,DT37,DF37	:ITEM 37
	002022	053476	071563	.WORD	EM40,DH40,DT40,DF40	:ITEM 40
	002032	053556	071563	.WORD	EM41,DH41,DT41,DF41	:ITEM 41
	002042	053556	071626	.WORD	EM42,DH42,DT42,DF42	:ITEM 42
	002052	053476	071563	.WORD	EM43,DH43,DT43,DF43	:ITEM 43
	002062	053556	071563	.WORD	EM44,DH44,DT44,DF44	:ITEM 44
	002072	053476	071563	.WORD	EM45,DH45,DT45,DF45	:ITEM 45
	002102	053476	071563	.WORD	EM46,DH46,DT46,DF46	:ITEM 46
	002112	053556	071563	.WORD	EM47,DH47,DT47,DF47	:ITEM 47
	002122	053476	071563	.WORD	EM50,DH50,DT50,DF50	:ITEM 50
	002132	053476	071563	.WORD	EM51,DH51,DT51,DF51	:ITEM 51
	002142	054235	071563	.WORD	EM52,DH52,DT52,DF52	:ITEM 52
	002152	054274	071563	.WORD	EM53,DH53,DT53,DF53	:ITEM 53
	002162	054274	071626	.WORD	EM54,DH54,DT54,DF54	:ITEM 54
	002172	054235	071563	.WORD	EM55,DH55,DT55,DF55	:ITEM 55
	002202	054235	071563	.WORD		

002212	054274	071563	073312	.WORD	EM56,DH56,DT56,DF56	:ITEM 56
002222	054274	071563	073312	.WORD	EM57,DH57,DT57,DF57	:ITEM 57
002232	054235	071563	073312	.WORD	EM60,DH60,DT60,DF60	:ITEM 60
002242	054274	071563	073312	.WORD	EM61,DH61,DT61,DF61	:ITEM 61
002252	054771	071274	073270	.WORD	EM62,DH62,DT62,DF62	:ITEM 62
002262	055067	071340	073270	.WORD	EM63,DH63,DT63,DF63	:ITEM 63
002272	055104	071447	073230	.WORD	EM64,DH64,DT64,DF64	:ITEM 64
002302	055154	071274	073270	.WORD	EM65,DH65,DT65,DF65	:ITEM 65
002312	055200	071404	073206	.WORD	EM66,DH66,DT66,DF66	:ITEM 66
002322	055226	071274	073206	.WORD	EM67,DH67,DT67,DF67	:ITEM 67
002332	055310	071340	073206	.WORD	EM70,DH70,DT70,DF70	:ITEM 70
002342	055333	071447	073432	.WORD	EM71,DH71,DT71,DF71	:ITEM 71
002352	055350	071274	073206	.WORD	EM72,DH72,DT72,DF72	:ITEM 72
002362	055364	071447	073466	.WORD	EM73,DH73,DT73,DF73	:ITEM 73
002372	055400	071404	073206	.WORD	EM74,DH74,DT74,DF74	:ITEM 74
002402	055414	071274	073142	.WORD	EM75,DH75,DT75,DF75	:ITEM 75
002412	055430	071460	073256	.WORD	EM76,DH76,DT76,DF76	:ITEM 76
002422	055503	071447	073466	.WORD	EM77,DH77,DT77,DF77	:ITEM 77
002432	055516	071404	073206	.WORD	EM100,DH100,DT100,DF100	:ITEM 100
002442	055532	071274	073142	.WORD	EM101,DH101,DT101,DF101	:ITEM 101
002452	055546	071460	073256	.WORD	EM102,DH102,DT102,DF102	:ITEM 102
002462	055571	071447	073466	.WORD	EM103,DH103,DT103,DF103	:ITEM 103
002472	055604	071404	073206	.WORD	EM104,DH104,DT104,DF104	:ITEM 104
002502	055620	071274	073142	.WORD	EM105,DH105,DT105,DF105	:ITEM 105
002512	055634	071460	073256	.WORD	EM106,DH106,DT106,DF106	:ITEM 106
002522	055660	071460	073256	.WORD	EM107,DH107,DT107,DF107	:ITEM 107
002532	055674	071447	073466	.WORD	EM110,DH110,DT110,DF110	:ITEM 110
002542	055710	071404	073206	.WORD	EM111,DH111,DT111,DF111	:ITEM 111
002552	055724	071274	073142	.WORD	EM112,DH112,DT112,DF112	:ITEM 112
002562	055740	071460	073256	.WORD	EM113,DH113,DT113,DF113	:ITEM 113
002572	055764	071447	073466	.WORD	EM114,DH114,DT114,DF114	:ITEM 114
002602	056000	071404	073206	.WORD	EM115,DH115,DT115,DF115	:ITEM 115
002612	056014	071274	073142	.WORD	EM116,DH116,DT116,DF116	:ITEM 116
002622	056030	071460	073256	.WORD	EM117,DH117,DT117,DF117	:ITEM 117
002632	056053	071447	073466	.WORD	EM120,DH120,DT120,DF120	:ITEM 120
002642	056066	071404	073206	.WORD	EM121,DH121,DT121,DF121	:ITEM 121
002652	056102	071274	073142	.WORD	EM122,DH122,DT122,DF122	:ITEM 122
002662	056116	071460	073256	.WORD	EM123,DH123,DT123,DF123	:ITEM 123
002672	056142	071447	073466	.WORD	EM124,DH124,DT124,DF124	:ITEM 124
002702	056156	071404	073206	.WORD	EM125,DH125,DT125,DF125	:ITEM 125
002712	056172	071274	073142	.WORD	EM126,DH126,DT126,DF126	:ITEM 126
002722	056206	071460	073256	.WORD	EM127,DH127,DT127,DF127	:ITEM 127
002732	056232	071447	073466	.WORD	EM130,DH130,DT130,DF130	:ITEM 130
002742	056246	071274	073142	.WORD	EM131,DH131,DT131,DF131	:ITEM 131
002752	056262	071460	073256	.WORD	EM132,DH132,DT132,DF132	:ITEM 132
002762	056307	071447	073466	.WORD	EM133,DH133,DT133,DF133	:ITEM 133
002772	056322	071274	073142	.WORD	EM134,DH134,DT134,DF134	:ITEM 134
003002	056336	071447	073230	.WORD	EM135,DH135,DT135,DF135	:ITEM 135
003012	056406	071447	073230	.WORD	EM136,DH136,DT136,DF136	:ITEM 136
003022	056422	071274	073270	.WORD	EM137,DH137,DT137,DF137	:ITEM 137
003032	056436	071447	073230	.WORD	EM140,DH140,DT140,DF140	:ITEM 140
003042	056452	071404	073206	.WORD	EM141,DH141,DT141,DF141	:ITEM 141
003052	056510	071274	073206	.WORD	EM142,DH142,DT142,DF142	:ITEM 142
003062	056524	071447	073230	.WORD	EM143,DH143,DT143,DF143	:ITEM 143
003072	056540	071404	073206	.WORD	EM144,DH144,DT144,DF144	:ITEM 144
003102	056556	071274	073206	.WORD	EM145,DH145,DT145,DF145	:ITEM 145
003112	056572	071447	073230	.WORD	EM146,DH146,DT146,DF146	:ITEM 146

ERROR POINTER TABLE

003122	056606	071404	073206	.WORD	EM147,DH147,DT147,DF147	:ITEM 147
003132	056626	071274	073206	.WORD	EM150,DH150,DT150,DF150	:ITEM 150
003142	056642	071447	073230	.WORD	EM151,DH151,DT151,DF151	:ITEM 151
003152	056656	071404	073206	.WORD	EM152,DH152,DT152,DF152	:ITEM 152
003162	056676	071274	073206	.WORD	EM153,DH153,DT153,DF153	:ITEM 153
003172	056712	071447	073230	.WORD	EM154,DH154,DT154,DF154	:ITEM 154
003202	056726	071404	073206	.WORD	EM155,DH155,DT155,DF155	:ITEM 155
003212	056746	071274	073206	.WORD	EM156,DH156,DT156,DF156	:ITEM 156
003222	056762	071447	073230	.WORD	EM157,DH157,DT157,DF157	:ITEM 157
003232	057005	071404	073206	.WORD	EM160,DH160,DT160,DF160	:ITEM 160
003242	057053	071274	073206	.WORD	EM161,DH161,DT161,DF161	:ITEM 161
003252	057066	071447	073230	.WORD	EM162,DH162,DT162,DF162	:ITEM 162
003262	057112	" 274	073206	.WORD	EM163,DH163,DT163,DF163	:ITEM 163
003272	057126	071520	073206	.WORD	EM164,DH164,DT164,DF164	:ITEM 164
003302	057156	071563	073312	.WORD	EM165,DH165,DT165,DF165	:ITEM 165
003312	057172	071563	073312	.WORD	EM166,DH166,DT166,DF166	:ITEM 166
003322	057206	071563	073312	.WORD	EM167,DH167,DT167,DF167	:ITEM 167
003332	057222	071563	073312	.WORD	EM170,DH170,DT170,DF170	:ITEM 170
003342	057236	071563	073312	.WORD	EM171,DH171,DT171,DF171	:ITEM 171
003352	057252	071563	073312	.WORD	EM172,DH172,DT172,DF172	:ITEM 172
003362	057266	071626	073356	.WORD	EM173,DH173,DT173,DF173	:ITEM 173
003372	057302	071626	073356	.WORD	EM174,DH174,DT174,DF174	:ITEM 174
003402	057316	071626	073356	.WORD	EM175,DH175,DT175,DF175	:ITEM 175
003412	057332	071274	073206	.WORD	EM176,DH176,DT176,DF176	:ITEM 176
003422	057354	071677	073422	.WORD	EM177,DH177,DT177,DF177	:ITEM 177
003432	057410	071563	073312	.WORD	EM200,DH200,DT200,DF200	:ITEM 200
003442	057463	071563	073312	.WORD	EM201,DH201,DT201,DF201	:ITEM 201
003452	057534	071563	073312	.WORD	EM202,DH202,DT202,DF202	:ITEM 202
003462	057606	071563	073312	.WORD	EM203,DH203,DT203,DF203	:ITEM 203
003472	057730	071563	073312	.WORD	EM204,DH204,DT204,DF204	:ITEM 204
003502	060003	071563	073312	.WORD	EM205,DH205,DT205,DF205	:ITEM 205
003512	060054	071563	073312	.WORD	EM206,DH206,DT206,DF206	:ITEM 206
003522	060126	071563	073312	.WORD	EM207,DH207,DT207,DF207	:ITEM 207
003532	060200	071563	073312	.WORD	EM210,DH210,DT210,DF210	:ITEM 210
003542	060252	071563	073312	.WORD	EM211,DH211,DT211,DF211	:ITEM 211
003552	060331	071563	073312	.WORD	EM212,DH212,DT212,DF212	:ITEM 212
003562	060402	071563	073312	.WORD	EM213,DH213,DT213,DF213	:ITEM 213
003572	060513	071563	073312	.WORD	EM214,DH214,DT214,DF214	:ITEM 214
003602	060600	071520	073206	.WORD	EM215,DH215,DT215,DF215	:ITEM 215
003612	060735	071447	073230	.WORD	EM216,DH216,DT216,DF216	:ITEM 216
003622	060750	071404	073206	.WORD	EM217,DH217,DT217,DF217	:ITEM 217
003632	060770	071274	073206	.WORD	EM220,DH220,DT220,DF220	:ITEM 220
003642	061004	071520	073206	.WORD	EM221,DH221,DT221,DF221	:ITEM 221
003652	061054	071447	073230	.WORD	EM222,DH222,DT222,DF222	:ITEM 222
003662	061070	071404	073206	.WORD	EM223,DH223,DT223,DF223	:ITEM 223
003672	061110	071274	073206	.WORD	EM224,DH224,DT224,DF224	:ITEM 224
003702	061124	071404	073206	.WORD	EM225,DH225,DT225,DF225	:ITEM 225
003712	061147	071274	073206	.WORD	EM226,DH226,DT226,DF226	:ITEM 226
003722	061160	071726	073256	.WORD	EM227,DH227,DT227,DF227	:ITEM 227
003732	061211	071404	073206	.WORD	EM230,DH230,DT230,DF230	:ITEM 230
003742	061234	071274	073206	.WORD	EM231,DH231,DT231,DF231	:ITEM 231
003752	061246	071726	073256	.WORD	E.1232,DH232,DT232,DF232	:ITEM 232
003762	061260	071404	073206	.WORD	EM233,DH233,DT233,DF233	:ITEM 233
003772	061304	071274	073206	.WORD	EM234,DH234,DT234,DF234	:ITEM 234
004002	061316	071726	073256	.WORD	EM235,DH235,DT235,DF235	:ITEM 235
004012	061330	071404	073206	.WORD	EM236,DH236,DT236,DF236	:ITEM 236
004022	061355	071274	073206	.WORD	EM237,DH237,DT237,DF237	:ITEM 237

004032	061366	071726	073256	.WORD	EM240,DH240,DT240,DF240	;ITEM 240
004042	061400	071404	073206	.WORD	EM241,DH241,DT241,DF241	;ITEM 241
004052	061425	071274	073206	.WORD	EM242,DH242,DT242,DF242	;ITEM 242
004062	061436	071726	073256	.WORD	EM243,DH243,DT243,DF243	;ITEM 243
004072	061450	071404	073206	.WORD	EM244,DH244,DT244,DF244	;ITEM 244
004102	061474	071274	073206	.WORD	EM245,DH245,DT245,DF245	;ITEM 245
004112	061506	071520	073206	.WORD	EM246,DH246,DT246,DF246	;ITEM 246
004122	061557	071726	073256	.WORD	EM247,DH247,DT247,DF247	;ITEM 247
004132	061570	071404	073206	.WORD	EM250,DH250,DT250,DF250	;ITEM 250
004142	061615	071274	073206	.WORD	EM251,DH251,DT251,DF251	;ITEM 251
004152	061506	071520	073206	.WORD	EM252,DH252,DT252,DF252	;ITEM 252
004162	061642	071726	073256	.WORD	EM253,DH253,DT253,DF253	;ITEM 253
004172	061506	071520	073206	.WORD	EM254,DH254,DT254,DF254	;ITEM 254
004202	061672	071726	073256	.WORD	EM255,DH255,DT255,DF255	;ITEM 255
004212	061716	071404	073206	.WORD	EM256,DH256,DT256,DF256	;ITEM 256
004222	061744	071274	073206	.WORD	EM257,DH257,DT257,DF257	;ITEM 257
004232	061756	071563	073312	.WORD	EM260,DH260,DT260,DF260	;ITEM 260
004242	062014	071563	073312	.WORD	EM261,DH261,DT261,DF261	;ITEM 261
004252	062026	071563	073312	.WORD	EM262,DH262,DT262,DF262	;ITEM 262
004262	062114	071563	073312	.WORD	EM263,DH263,DT263,DF263	;ITEM 263
004272	062141	071563	073312	.WORD	EM264,DH264,DT264,DF264	;ITEM 264
004302	062226	071563	073312	.WORD	EM265,DH265,DT265,DF265	;ITEM 265
004312	062277	071563	073312	.WORD	EM266,DH266,DT266,DF266	;ITEM 266
004322	062353	071563	073312	.WORD	EM267,DH267,DT267,DF267	;ITEM 267
004332	062440	071563	073312	.WORD	EM270,DH270,DT270,DF270	;ITEM 270
004342	062472	071563	073312	.WORD	EM271,DH271,DT271,DF271	;ITEM 271
004352	062531	071563	073312	.WORD	EM272,DH272,DT272,DF272	;ITEM 272
004362	062601	071563	073312	.WORD	EM273,DH273,DT273,DF273	;ITEM 273
004372	062636	071563	073312	.WORD	EM274,DH274,DT274,DF274	;ITEM 274
004402	062650	071563	073312	.WORD	EM275,DH275,DT275,DF275	;ITEM 275
004412	062733	071563	073312	.WORD	EM276,DH276,DT276,DF276	;ITEM 276
004422	063020	071563	073312	.WORD	EM277,DH277,DT277,DF277	;ITEM 277
004432	063065	071563	073312	.WORD	EM300,DH300,DT300,DF300	;ITEM 300
004442	063162	071563	073522	.WORD	EM301,DH301,DT301,DF301	;ITEM 301
004452	063207	071563	073522	.WORD	EM302,DH302,DT302,DF302	;ITEM 302
004462	063220	071626	073574	.WORD	EM303,DH303,DT303,DF303	;ITEM 303
004472	063232	071563	073522	.WORD	EM304,DH304,DT304,DF304	;ITEM 304
004502	063312	071563	073522	.WORD	EM305,DH305,DT305,DF305	;ITEM 305
004512	063406	071563	073522	.WORD	EM306,DH306,DT306,DF306	;ITEM 306
004522	063514	071563	073522	.WORD	EM307,DH307,DT307,DF307	;ITEM 307
004532	063564	071563	073522	.WORD	EM310,DH310,DT310,DF310	;ITEM 310
004542	063640	071563	073522	.WORD	EM311,DH311,DT311,DF311	;ITEM 311
004552	063710	071563	073522	.WORD	EM312,DH312,DT312,DF312	;ITEM 312
004562	063760	071563	073522	.WORD	EM313,DH313,DT313,DF313	;ITEM 313
004572	064030	071563	073522	.WORD	EM314,DH314,DT314,DF314	;ITEM 314
004602	064100	071563	073522	.WORD	EM315,DH315,DT315,DF315	;ITEM 315
004612	064150	071563	073522	.WORD	EM316,DH316,DT316,DF316	;ITEM 316
004622	064220	071563	073522	.WORD	EM317,DH317,DT317,DF317	;ITEM 317
004632	064270	071563	073522	.WORD	EM320,DH320,DT320,DF320	;ITEM 320
004642	064340	071563	073522	.WORD	EM321,DH321,DT321,DF321	;ITEM 321
004652	064410	071563	073646	.WORD	EM322,DH322,DT322,DF322	;ITEM 322
004662	064446	071563	073646	.WORD	EM323,DH323,DT323,DF323	;ITEM 323
004672	064460	071626	073712	.WORD	EM324,DH324,DT324,DF324	;ITEM 324
004702	064472	071563	073646	.WORD	EM325,DH325,DT325,DF325	;ITEM 325
004712	064472	071563	073646	.WORD	EM326,DH326,DT326,DF326	;ITEM 326
004722	064616	071563	073646	.WORD	EM327,DH327,DT327,DF327	;ITEM 327
004732	064666	071563	073646	.WORD	EM330,DH330,DT330,DF330	;ITEM 330

004742	064742	071563	073646	.WORD	EM331,DH331,DT331,DF331	;ITEM 331
004752	065012	071563	073646	.WORD	EM332,DH332,DT332,DF332	;ITEM 332
004762	064446	071563	073646	.WORD	EM333,DH333,DT333,DF333	;ITEM 333
004772	065110	071563	073646	.WORD	EM334,DH334,DT334,DF334	;ITEM 334
005002	065173	071563	073646	.WORD	EM335,DH335,DT335,DF335	;ITEM 335
005012	065242	071563	073646	.WORD	EM336,DH336,DT336,DF336	;ITEM 336
005022	065277	071563	073646	.WORD	EM337,DH337,DT337,DF337	;ITEM 337
005032	065353	071563	073646	.WORD	EM340,DH340,DT340,DF340	;ITEM 340
005042	065422	071563	073646	.WORD	EM341,DH341,DT341,DF341	;ITEM 341
005052	065472	071563	073646	.WORD	EM342,DH342,DT342,DF342	;ITEM 342
005062	065542	071563	073646	.WORD	EM343,DH343,DT343,DF343	;ITEM 343
005072	065617	071563	073646	.WORD	EM344,DH344,DT344,DF344	;ITEM 344
005102	065724	071563	073646	.WORD	EM345,DH345,DT345,DF345	;ITEM 345
005112	065774	071563	073646	.WORD	EM346,DH346,DT346,DF346	;ITEM 346
005122	066073	071563	073646	.WORD	EM347,DH347,DT347,DF347	;ITEM 347
005132	066117	071563	073646	.WORD	EM350,DH350,DT350,DF350	;ITEM 350
005142	066130	071460	073256	.WORD	EM351,DH351,DT351,DF351	;ITEM 351
005152	066232	071563	073646	.WORD	EM352,DH352,DT352,DF352	;ITEM 352
005162	066302	071563	073646	.WORD	EM353,DH353,DT353,DF353	;ITEM 353
005172	066352	071563	073646	.WORD	EM354,DH354,DT354,DF354	;ITEM 354
005202	066422	071563	073646	.WORD	EM355,DH355,DT355,DF355	;ITEM 355
005212	066472	071404	073142	.WORD	EM356,DH356,DT356,DF356	;ITEM 356
005222	066576	071746	073164	.WORD	EM357,DH357,DT357,DF357	;ITEM 357
005232	066632	071460	073256	.WORD	EM360,DH360,DT360,DF360	;ITEM 360
005242	066722	071274	073522	.WORD	EM361,DH361,DT361,DF361	;ITEM 361
005252	066740	072012	073756	.WORD	EM362,DH362,DT362,DF362	;ITEM 362
005262	067050	072034	073774	.WORD	EM363,DH363,DT363,DF363	;ITEM 363
005272	067116	072074	074016	.WORD	EM364,DH364,DT364,DF364	;ITEM 364
005302	067216	072143	073256	.WORD	EM365,DH365,DT365,DF365	;ITEM 365
005312	067301	072154	074030	.WORD	EM366,DH366,DT366,DF366	;ITEM 366
005322	067364	072206	074076	.WORD	EM367,DH367,DT367,DF367	;ITEM 367
005332	067447	072253	074122	.WORD	EM370,DH370,DT370,DF370	;ITEM 370
005342	067503	072316	074166	.WORD	EM371,DH371,DT371,DF371	;ITEM 371
005352	000000	000000	000000	.WORD	EM372,DH372,DT372,DF372	;ITEM 372
005362	000000	000000	000000	.WORD	EM373,DH373,DT373,DF373	;ITEM 373
005372	000000	000000	000000	.WORD	EM374,DH374,DT374,DF374	;ITEM 374
005402	000000	000000	000000	.WORD	EM375,DH375,DT375,DF375	;ITEM 375
005412	000000	000000	000000	.WORD	EM376,DH376,DT376,DF376	;ITEM 376
005422	000000	000000	000000	.WORD	EM377,DH377,DT377,DF377	;ITEM 377
005432	000000	000000	000000	.WORD	EM400,DH400,DT400,DF400	;ITEM 400
005442	067633	071404	073206	.WORD	EM401,DH401,DT401,DF401	;ITEM 401
005452	067655	071274	073206	.WORD	EM402,DH402,DT402,DF402	;ITEM 402
005462	067666	071460	073256	.WORD	EM403,DH403,DT403,DF403	;ITEM 403
005472	070016	071726	073256	.WORD	EM404,DH404,DT404,DF404	;ITEM 404
005502	070030	071404	073206	.WORD	EM405,DH405,DT405,DF405	;ITEM 405
005512	070044	071274	073206	.WORD	EM406,DH406,DT406,DF406	;ITEM 406
005522	070060	071460	073256	.WORD	EM407,DH407,DT407,DF407	;ITEM 407
005532	070130	071726	073256	.WORD	EM410,DH410,DT410,DF410	;ITEM 410
005542	070144	071404	073206	.WORD	EM411,DH411,DT411,DF411	;ITEM 411
005552	070170	071274	073206	.WORD	EM412,DH412,DT412,DF412	;ITEM 412
005562	070202	071460	073256	.WORD	EM413,DH413,DT413,DF413	;ITEM 413
005572	070252	071726	073256	.WORD	EM414,DH414,DT414,DF414	;ITEM 414
005602	070264	071404	073206	.WORD	EM415,DH415,DT415,DF415	;ITEM 415
005612	070311	071274	073206	.WORD	EM416,DH416,DT416,DF416	;ITEM 416
005622	070322	071460	073256	.WORD	EM417,DH417,DT417,DF417	;ITEM 417
005632	070366	071726	073256	.WORD	EM420,DH420,DT420,DF420	;ITEM 420
005642	070400	071404	073206	.WORD	EM421,DH421,DT421,DF421	;ITEM 421

ERROR POINTER TABLE

005652	070425	071274	073206	.WORD	EM422,DH422,DT422,DF422	:ITEM 422
005662	070436	071460	073256	.WORD	EM423,DH423,DT423,DF423	:ITEM 423
005672	070450	071726	073256	.WORD	EM424,DH424,DT424,DF424	:ITEM 424
005702	070462	071404	073206	.WORD	EM425,DH425,DT425,DF425	:ITEM 425
005712	070506	071274	073206	.WORD	EM426,DH426,DT426,DF426	:ITEM 426
005722	070520	071460	073256	.WORD	EM427,DH427,DT427,DF427	:ITEM 427
005732	070572	071726	073256	.WORD	EM430,DH430,DT430,DF430	:ITEM 430
005742	070604	071460	073256	.WORD	EM431,DH431,DT431,DF431	:ITEM 431
005752	070632	071404	073206	.WORD	EM432,DH432,DT432,DF432	:ITEM 432
005762	070657	071274	073206	.WORD	EM433,DH433,DT433,DF433	:ITEM 433
005772	070670	071460	073256	.WORD	EM434,DH434,DT434,DF434	:ITEM 434
006002	070740	071726	073256	.WORD	EM435,DH435,DT435,DF435	:ITEM 435
006012	070752	071460	073256	.WORD	EM436,DH436,DT436,DF436	:ITEM 436
006022	071000	071404	073206	.WORD	EM437,DH437,DT437,DF437	:ITEM 437
006032	071022	071404	073206	.WORD	EM440,DH440,DT440,DF440	:ITEM 440
006042	071044	072412	074210	.WORD	EM441,DH441,DT441,DF441	:ITEM 441
006052	071044	072143	074226	.WORD	EM442,DH442,DT442,DF442	:ITEM 442
006062	071044	072143	074226	.WORD	EM443,DH443,DT443,DF443	:ITEM 443
006072	071171	071340	073206	.WORD	EM444,DH444,DT444,DF444	:ITEM 444

2040

2041

2042

.SBTTL ACT11 HOOKS

;*****
;HOOKS REQUIRED BY ACT11

\$SVPC=. :SAVE PC

.=46

\$SENDAD :;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP

.=52

.WORD 0 :;2)SET LOC.52 TO ZERO

.=SSVPC :; RESTORE PC

2043

.SBTTL APT PARAMETER BLOCK

;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

;*****

.SX=. :SAVE CURRENT LOCATION

.=24 :SET POWER FAIL TO POINT TO START OF PROGRAM

200 :FOR APT START UP

.=44 :POINT TO APT INDIRECT ADDRESS PNTR.

\$APTHDR :POINT TO APT HEADER BLOCK

.=.SX :RESET LOCATION COUNTER

;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC

;INTERFACE SPEC.

\$APTHD:

SHIBTS: .WORD 0 :;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.

\$MBADR: .WORD \$MAIL :;ADDRESS OF APT MAILBOX (BITS 0-15)

STSTM: .WORD 10 :;RUN TIM OF LONGEST TEST

SPASTM: .WORD 40 :;RUN TIME IN SECs. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)

SUNITM: .WORD 0 :;ADDITIONAL RUN TIME (SECs) OF A PASS FOR EACH ADDITIONAL UNIT

.WORD SETEND-\$MAIL/2 :;LENGTH MAILBOX-ETABLE(WORDS)

2044

2045

2046 006116

START:

.SBTTL INITIALIZE THE COMMON TAGS

;CLEAR THE COMMON TAGS (\$CMTAG) AREA

MOV #\$CMTAG,R6 :;FIRST LOCATION TO BE CLEARED

CLR (R6)+ :;CLEAR MEMORY LOCATION

006116 012706 001100
006122 005026

```

006124 022706 001140      CMP    #SWR,R6 ;:DONE?
006130 001374             BNE    #-6          ;:LOOP BACK IF NO
006132 012706 001100      MOV    #STACK,SP   ;:SETUP THE STACK POINTER
                            ::INITIALIZE A FEW VECTORS
006136 012737 046170 000020  MOV    #SSCOPE,2#IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
006144 012737 000340 000022  MOV    #340,2#IOTVEC+2 ;:LEVEL 7
006152 012737 046514 000030  MOV    #SError,2#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
006160 012737 000340 000032  MOV    #340,2#EMTVEC+2 ;:LEVEL 7
006166 012737 050704 000034  MOV    #STRAP,2#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
006174 012737 000340 000036  MOV    #340,2#TRAPVEC+2;LEVEL 7
006202 012737 050766 000024  MOV    #SPWRDN,2#PWRVEC ;:POWER FAILURE VECTOR
006210 012737 000340 000026  MOV    #340,2#PWRVEC+2 ;:LEVEL 7
006216 013737 045464 045452  MOV    SENDCT,SEOPCT ;:SETUP END-OF-PROGRAM COUNTER
006224 005037 001302             CLR    STIMES    ;:INITIALIZE NUMBER OF ITERATIONS
006230 005037 001304             CLR    SESCAPE   ;:CLEAR THE ESCAPE ON ERROR ADDRESS
006234 112737 000001 001115  MOV    #1,SERMAX  ;:ALLOW ONE ERROR PER TEST
                            ::INITIALIZE THE "T-BIT" TRAP VECTOR. THEN LOAD LOCATION '$RTRN', IN
                            ::THE "END-OF-PASS" (SEOP) ROUTINE, WITH A 'RTI' OR 'RTT'.
006242 012737 046150 000014  MOV    #SRTRN,2#TBITVEC ;:SET 'T' BIT VECTOR TO SRTRN
006250 012737 000340 000016  MOV    #340,2#TBITVEC+2 ;:LEVEL 7
006256 012737 045210 046150  MOV    #RTI,$RTRN  ;:SET SRTRN TO A RTI
006264 012737 006312 000010  MOV    #65$,2#RESVEC ;:TRY TO DO A RTT
006272 005046             CLR    -(SP)     ;:DUMMY PS
006274 012746 006302             MOV    #64$,-(SP) ;:AND PC
006300 000006             RTT    RTT        ;:TRY THE RTT
006302 012737 000006 046150 64$:  MOV    #RTT,$RTRN ;:RTT IS LEGAL--SET SRTRN TO A RTT
006310 000402             BR    66$       ;:RTT ILLEGAL--CLEAN OFF THE STACK
006312 062706 000010             ADD    #10,SP    ;:RESTORE TRAP CATCHER
006316 012737 000012 000010 66$:  MOV    #RESVEC+2,2#RESVEC
006324 005037 046156             CLR    STBIT    ;:CLEAR 'T' BIT SWITCH
006330 012737 006330 001106  MOV    #.,$LPADR  ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
006336 012737 006336 001110  MOV    #.,$LPERR  ;:SETUP THE ERROR LOOP ADDRESS
                            ::SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
                            ::EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
006344 013746 0000C4             MOV    #ERRVEC,-(SP) ;:AVE ERROR VECTOR
006350 012737 006404 000004  MOV    #67$,2#ERRVEC ;:SET UP ERROR VECTOR
006356 012737 177570 001140  MOV    #DSWR,SWR   ;:SETUP FOR A HARDWARE SWICH REGISTER
006364 012737 177570 001142  MOV    #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
006372 022777 177777 172540  CMP    #-1,2#SWR   ;:TRY TO REFERENCE HARDWARE SWR
006400 001C12             BNE    69$       ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
                            ;:AND THE HARDWARE SWR IS NOT = -1
006402 000403             BR    68$       ;:BRANCH IF NO TIMEOUT
006404 012716 006412             MOV    #68$,(SP) ;:SET UP FOR TRAP RETURN
006410 000002             RTI    RTI        ;:POINT TO SOFTWARE SWR
006412 012737 000176 001140 68$:  MOV    #SWREG,SWR   ;:POINT TO SOFTWARE SWR
006420 012737 000174 001142 68$:  MOV    #DISPREG,DISPLAY ;:RESTORE ERROR VECTOR
006426 012637 000004             MOV    (SP)+,2#ERRVEC ;:CLEAR PASS COUNT
006432 005037 001324             CLR    SPASS    ;:TEST USER SIZE UNDER APT
006436 132737 000200 001337  BITB   #APTSIZE,SE'VM ;:YES, USE NON-APT SWITCH
006444 001403             BEQ    70$       ;:NO, USE APT SWITCH REGISTER
006446 012737 001340 001140  MOV    #SSWREG,SWR
006454                         70$:  .SBTTL TYPE PROGRAM NAME
                            ;:TYPE THE NAME OF THE PROGRAM IF FIRST PASS
006454 005227 177777             INC    #-1        ;:FIRST TIME?
006460 001047             BNE    71$       ;:BRANCH IF NO
006462 022737 046104 000042  CMP    #SENDAD,2#42  ;:ACT-11?

```

```

006470 001443      BEQ    71$      ;:BRANCH IF YES
006472 104401 006540      TYPE   72$      ;:TYPE ASCIZ STRING
                                .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
006476 005737 000042      TST    74$      ;:ARE WE RUNNING UNDER XXDP/ACT?
006502 001012      BNE    73$      ;:BRANCH IF YES
006504 123727 001336 000001      CMPB   $ENV,#1      ;:ARE WE RUNNING UNDER APT?
006512 001406      BEQ    73$      ;:BRANCH IF YES
006514 023727 001140 000176      CMP    SWR,#SWREG      ;:SOFTWARE SWITCH REG SELECTED?
006522 001005      BNE    74$      ;:BRANCH IF NO
006524 104405      GTSWR
006526 000403      BR     74$      ;:GET SOFT-SWR SETTINGS
006530 112737 000001 001134 73$: MOVB   #1,SAUTOB      ;:SET AUTO-MODE INDICATOR
006536 000420      74$:
                                ;:72$: BR     71$      ;:GET OVER THE ASCIZ
                                ;:71$: .ASCIZ <CRLF>*CKFPCD0 FP11F FLTG PNT PRT C*<CRLF>
096600
2048 006600 104401 006606      TYPE   76$      ;:TYPE ASCIZ STRING
006604 000434      BR     75$      ;:GET OVER THE ASCIZ
                                ;:76$: .ASCIZ !EOP MESSAGE WILL PRINT EVERY 1000 PASSES (15 SECONDS);<CRLF>
006676
2049 006676 104401 006704      75$:
006702 000426      TYPE   78$      ;:TYPE ASCIZ STRING
                                ;:78$: .ASCIZ !HIT ANY KEY TO ENABLE/DISABLE EOP MESSAGES;<CRLF>
006760
2050 006760 005037 046164      77$:
2051 006764      LOOP: CLR    EPENDS      ;CLR EOP FLAG INITIALLY ENABLING EOP'S ;DPM002

```

2057

SBTTL TEST # 1 - STF WITH ILLEGAL ACCUMULATOR TEST

 *TEST 1 STF WITH ILLEGAL ACCUMULATOR TEST
 *
 *THIS IS A TEST OF THE ST INSTRUCTION USING ILLEGAL ACCUMULATOR 7, MODE 0.
 *

006764 000004	006766 012737	006774 001110	TST1: SCOPE			
2058 006766 012737	005000		1000\$: MOV CLR R0	#1000\$, \$LPERR :SET UP THE LOOP ON ERROR ADDRESS.	;DPM002	:SET THE FPS.
2059 006774 005000			LDFPS	RO		
2060			MOV	#200\$, FPVECT	:SET UP FOR FP TRAPS.	
2061 006776 170100			MOV	#1\$, \$TMP2		
2062 007000 012737	007036	000244				
2063 007006 012737	007014	001236				
2064						
2065 007014 174007			1\$: STF	AC0, AC7	:THIS TEST INSTRUCTION SHOULD	
2066					:CAUSE A TRAP.	
2067						
2068					:REPORT FAILURE OF USE OF ILLEGAL ACCUMULATOR 7 TO CAUSE AN FPP TRAP.	
2069						
2070 007016 170200			210\$: STFPS	RO	:GET FPS.	
2071 007020 010037	001240		MOV	RO, \$TMP3		
2072 007024 170300			STST	RO	:GET FEC.	
2073 007026 010037	001242		MOV	RO, \$TMP4		
2074 007032 104001			ERROR	+1	:STF WITH ILLEGAL ACCUMULATOR, MODE	
2075					:0, DIDN'T TRAP. ST 765 TO ST 53?.	
2076 007034 000434			BR	240\$		
2077						
2078					:TRAP TO 200\$. HERE, WHEN THE EXPECTED ERROR OCCURS.	
2079 007036 011600			200\$: MOV	(SP), RO	:MAKE SURE THE ERROR OCCURRED	
2080 007040 022700	007016		CMP	#210\$, RO	:AT THE CORRECT ADDRESS.	
2081 007044 001402			BEQ	220\$:BRANCH IF TRAP ADDRESS CORRECT.	
2082 007046 000137	051732		JMP	FPSPUR	:IF INCORRECT GO REPORT SPURIOUS	
2083					:FP TRAP.	
2084						
2085 007052 170204			220\$: STFPS	R4	:GET FPS.	
2086 007054 170305			STST	R5	:GET FEC.	
2087 007056 010437	001240		MOV	R4, \$TMP3	:SAVE DATA INCASE OF ERROR.	
2088 007062 010537	001242		MOV	R5, \$TMP4		
2089 007066 012702	100000		MOV	#100000, R2	:EXPECTED FPS	
2090 007072 012703	000002		MOV	#2, R3	:EXPECTED FEC	
2091 007076 010237	001244		MOV	R2, \$TMP5		
2092 007102 010337	001246		MOV	R3, \$TMP6		
2093 007106 022626			CMP	(SP)+, (SP)+	:RESET THE STACK.	
2094						
2095 007110 020204			CMP	R2, R4	:WAS FPS CORRECT?	
2096 007112 001402			BEQ	230\$:BRANCH IF YES.	
2097					:OTHERWISE REPORT FPS INCORRECTLY	
2098 007114 104002			ERROR	+2	:SET AFTER USE OF ILLEGAL ACC.	
2099 007116 000403			BR	240\$		
2100						
2101 007120 020305			230\$: CMP	R3, R5	:WAS THE FEC CORRECT?	
2102 007122 001401			BEQ	240\$:BRANCH IF CORRECT.	
2103					:OTHERWISE REPORT INCORRECT FEC	
2104 007124 104003			ERROR	+3	:AFTER USE OF ILLEGAL ACC.	
2105						
2106 007126			240\$:			

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 10-3
TEST # 1 - STF WITH ILLEGAL ACCUMULATOR TEST

SEQUENCE 34

007126 104412

RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

2112

SBTTL TEST # 2 - FDST MODE 1, FLOATING MODE, TEST

TEST 2 FDST MODE 1, FLOATING MODE, TEST
*
THIS IS A TEST OF THE STF INSTRUCTION USING FDST MODE 1.

007130 000004 012737 007140 001110 TST2: SCOPE
 2113 007132 012700 177777 1000\$: MOV #1000\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.
 2114 007140 012700 007274 1000\$: MOV #-1,R0 ;SET UP A BACKGROUND PATTERN IN THE
 2115 007144 012701 000014 1000\$: MOV #200\$,R1 ;INPUT BUFFER.
 2116 007150 012702 000014 210\$: MOV #14,R2
 2117 007154 010021 000200 MOV R0,(R1)+
 2118 007156 077202 S0B R2,210\$
 2119
 2120 007160 012700 000200 MOV #200,R0 ;SET FD MODE.
 2121 007164 170100 LDFPS R0
 2122 007166 012700 007324 MOV #220\$,R0 ;PUT TEST DATA INTO ACO.
 2123 007172 172410 LDD (R0),AC0
 2124
 2125 007174 012700 007310 MOV #230\$,R0 ;FDST ADDRESS.
 2126 007200 005002 CLR R2 ;CLEAR THE FPS.
 2127 007202 170102 LDFPS R2
 2128 007204 012737 007216 001236 MOV #240\$,STMP2
 2129 007212 010037 001240 MOV R0,STMP3
 2130
 2131 007216 174010 240\$: STF ACO,(R0) ;TEST INSTRUCTION.
 2132
 2133 007220 022700 007310 CMP #230\$,R0 ;WAS R0 MODIFIED DURING EXECUTION?
 2134 007224 001404 BEQ 245\$;BRANCH IF R0 NOT MODIFIED, CORRECT.
 2135
 2136 007226 010037 001242 MOV R0,STMP4 ;OTHERWISE REPORT ERROR, R0 MODIFIED.
 2137 007232 104004 ERROR +4
 2138 007234 000456 BR 250\$;GO TO NEXT TEST.
 2139
 2140 007236 012700 007310 245\$: MOV #230\$,R0 ;CHECK THE DATA IN THE OUTPUT BUFFER.
 2141 007242 012701 007324 MOV #220\$,R1
 2142 007246 022021 CMP (R0)+,(R1)+
 2143 007250 001031 BNE 260\$;BRANCH IF INCORRECT.
 2144 007252 022011 CMP (R0)+,(R1)
 2145 007254 001027 BNE 260\$;BRANCH IF INCORRECT.
 2146 007256 022720 177777 CMP #-1,(R0)+ ;WAS FLOATING MODE USED?
 2147 007262 001034 BNE 270\$;BRANCH IF NOT.
 2148 007264 022710 177777 CMP #-1,(R0)
 2149 007270 001031 BNE 270\$
 2150 007272 000437 BR 250\$;GO TO NEXT TEST.
 2151
 2152 007274 177777 177777 177777 200\$: .WORD -1,-1,-1,-1,-1,-1
 2153
 2154 007310 177777 177777 177777 230\$: .WORD -1,-1,-1,-1,-1,-1
 2155
 2156 007324 123456 023456 220\$: .WORD 123456,23456
 2157 007330 034567 045671 .WORD 34567,45671
 2158
 2159 ;REPORT DATA IN OUT PUT BUFFER INCORRECT.
 2160 007334 012737 007324 001242 260\$: MOV #220\$,STMP4
 2161 007342 012737 007310 001240 MOV #230\$,STMP3

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 11-1 K 3
TEST # 2 - FDST MODE 1, FLOATING MODE, TEST

SEQUENCE 36

2162 007350 104005 ERROR +5 ;BAD DATA.
2163 007352 000407 BR 250\$
2164
2165 :REPORT FLOATING MODE NOT USED, BUT FD FAILED.
2166 007354 012737 007324 001242 270\$: MOV #220\$,STMP4
2167 007362 ('2737 007310 001240 MOV #230\$,STMP3
2168 007370 104006 ERROR +6 ;ST 707 TO 245 INTO 244 (BUT FD).
2169
2170 007372 007372 104412 250\$: RSETUP
;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

2176

.SBTTL TEST # 3 - FDST MODE 2 TEST

:***** TEST 3 FDST MODE 2 TEST *****

: THIS IS A TEST OF BOTH STF AND STD WITH FDST MODE 2.

2177 007374 000004				TEST3: SCOPE
2178 007376 012737 001110	007404	177777		:FIRST TEST STF.
2179 007404 012700	007542			1000\$: MOV #1000\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.
2180 007410 012701	000014			1000\$: MOV #-1,R0 ;SET UP THE OUTPUT BUFFER.
2181 007414 012702				MOV #200\$,R1
2182 007420 010021				MOV #14,R2
2183 007422 077202				MOV R0,(R1)+
2184				SOB R2,210\$
2185 007424 012700	000200			MOV #200,R0 ;SET FD MODE.
2186 007430 170100				LDFPS R0
2187 007432 012700	007572			MOV #220\$,R0 ;SETUP ACO.
2188 007436 172410				LDD (R0),AC0
2189				
2190 007440 012700	007556			MOV #230\$,R0 ;FDST ADDRESS.
2191 007444 005002				CLR R2
2192 007446 170102				LDFPS R2
2193 007450 012737	007456	001236		MOV #240\$,STMP2 ;SET FPS.
2194				
2195 007456 174020			240\$: STF	AC0,(R0)+ ;TEST INSTRUCTION.
2196				
2197 007460 022700	007562			CMP #230\$+4,R0 ;WAS R0 INCREMENTED BY 4 PROPERLY?
2198				
2199 007464 001407				BEQ 250\$;BRANCH IF R0 CORRECT.
2200 007466 010037	001242			MOV R0,STMP4 ;REPORT R0 INCORRECT AFTER FDST MODE 2.
2201 007472 012737	007562	001240		MOV #230\$+4,STMP3
2202 007500 104007				ERROR +7 ;BAD CONSTANT USED OR DIDN'T GO 527 TO 642
2203 007502 000530				BR 260\$
2204 007504 012700	007556		250\$: MOV #230\$,R0	;WAS THE OUTPUT DATA CORRECT?
2205 007510 012701	007572		MOV #220\$,R1	
2206 007514 022021			CMP (R0)+,(R1)+	
2207 007516 001031			BNE 270\$;BRANCH IF INCORRECT.
2208 007520 022021			CMP (R0)+,(R1)+	
2209 007522 001027			BNE 270\$;BRANCH IF INCORRECT.
2210 007524 022027	177777		CMP (R0)+,-1	;SEE IF ANY OTHER DATA BUFFER WORDS WERE MODIFIED.
2211 007530 001024			BNE 270\$;BRANCH IF INCORRECT.
2212 007532 022027	177777		CMP (R0)+,-1	
2213 007536 001021			BNE 270\$;BRANCH IF INCORRECT.
2214 007540 000433			BR 280\$	
2215 007542 177777	177777	177777	200\$: .WORD -1,-1,-1,-1,-1,-1	
2216 007556 177777	177777	177777	230\$: .WORD -1,-1,-1,-1,-1,-1	
2217 007572 076543			220\$: 76543	
2218 007574 065432			65432	
2219 007576 054321			54321	
2220 007600 043210			43210	
2221				;REPORT OUTPUT DATA INCORRECT:
2222 007602 012737	007572	001240	270\$: MOV #220\$,STMP3	
2223 007610 012737	007556	001242	MOV #230\$,STMP4	
2224 007616 104010			ERROR +10	
2225 007620 000461			BR 260\$;BAD DATA

2226
 2227
 2228
 2229 007622 012737 007630 001110 ;NOW TEST STD MODE 2.
 2230 007630 012700 007542 280\$: MOV #280\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.
 2231 007634 010001 000014 280\$: MOV #200\$,R0 ;SET UP DEFAULT INPUT DATA BUFFER.
 2232 007636 012702 000014 290\$: MOV R0,R1
 2233 007642 010021 000200 290\$: MOV #14,R2
 2234 007644 077202 000200 290\$: MOV R0,(R1)+
 2235 007646 012700 000200 290\$: SOB R2,290\$
 2236 007652 170100 000200 290\$: MOV #200,R0
 2237 007654 012700 007572 290\$: LDFPS R0
 2238 007660 172410 001236 290\$: MOV #220\$,R0
 2239 007662 012700 007556 300\$: LDD (R0),AC0
 2240 007666 012737 007674 300\$: MOV #230\$,R0
 2241 007674 174020 001236 300\$: MOV #300\$,STMP2
 2242 007676 022700 007566 300\$: STD AC0,(R0)+ ;TEST INSTRUCTION.
 2243 007702 001407 001240 300\$: CMP #230\$+10,R0 ;WAS R0 INCREMENTED BY 10 CORRECTLY?
 2244 007704 010037 001242 300\$: BEQ 310\$;BRANCH IF CORRECT.
 2245 007710 012737 007566 300\$: MOV R0,STMP4
 2246 007716 104011 001240 300\$: MOV #230\$+10,STMP3 ;REPORT R0 INCORRECTLY INCREMENTED.
 2247 007720 000421 001240 300\$: ERROR +11 ;DO NOT INCREM BY 10 BAD CONSTANT
 2248 007722 012700 007556 310\$: BR 260\$;DID THE DATA REACH THE OUTPUT BUFFER CORRECTLY?
 2249 007726 012701 007572 310\$: MOV #230\$,R0
 2250 007732 012702 000004 310\$: MOV #220\$,R1
 2251 007736 022021 310\$: MOV #4,R2
 2252 007740 001002 310\$: CMP (R0)+,(R1)+
 2253 007742 077203 310\$: BNE 320\$;BRANCH IF INCORRECT.
 2254 007744 000407 310\$: SOB R2,310\$
 2255 007746 012737 007572 001240 :REPORT DATA INCORRECT.
 2256 007746 012737 007572 001240 320\$: BR 260\$;BAD DATA
 2257 007754 012737 007556 001242 320\$: MOV #220\$,STMP3
 2258 007762 104012 320\$: MOV #230\$,STMP4
 2259 007764 000407 320\$: ERROR +12 ;GO INITIALIZE THE FPS AND STACK; AND
 007764 104412 320\$: RSETUP ;SEE IF THE USER HAS EXPRESSED
 ;THE DESIRE TO CHANGE THE SOFTWARE
 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
 ;THE USER TYPED CONTROL G?).
 ;DPM002

2265 .SBTTL TEST # 4 - FDST MODE 2, WITH GR7, TEST
 :*****
 :*TEST 4 FDST MODE 2, WITH GR7, TEST
 :*
 :*THIS IS A TEST OF STF WITH GR7 MODE 2 OR IMMEDIATE MODE.
 :*
 :*****

007766	000004		TST4: SCOPE		
2266 007770	012737	007776 001110	200\$: MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
2267 007776	012700	010054	MOV #210\$,R0	;SET UP THE DATA BUFFER FOLLOWING THE TEST INSTRUCTION.	
2268 010002	012701	010122	MOV #220\$,R1		
2269 010006	012702	000004	MOV #4,R2		
2270 010012	012021		MOV (R0)++, (R1)++		
2271 010014	077202		S0B R2,1\$		
2272 010016	012700	000200	MOV #200\$,R0	;ENTER FLOATING DOUBLE MODE.	
2273 010022	170100		LDFPS R0		
2274 010024	012700	010132	MOV #230\$,R0	;SET UP ACO.	
2275 010030	172410		LDD (R0),AC0		
2276 010032	012737	010152 000004	MOV #240\$,ERRVECT	;SET UP FOR AN ODD ADDRESS.	
2277 010040	012737	010052 001236	MOV #250\$,STMP2		
2278 010046	005001		CLR R1		
2279 010050	005004		CLR R4		
2280			;THIS IS THE TEST INSTRUCTION. IT SHOULD MODIFY THE FIRST LOCATION		
2281			;AFTER IT TO BE AN INCREMENT R4, INC R4, INSTRUCTION INSTEAD		
2282			;OF AN INCREMENT R1 INSTRUCTION. THE INCREMENT R4 SHOULD NOT BE		
2283			;EXECUTED SINCE THE PC SHOULD BE INCREMENTED BY TWO DURING IMMEDIATE		
2284			;MODE ADDRESSING. THUS AFTER THE EXECUTION OF THE NEXT 5 INSTRUCTIONS		
2285			;R1 SHOULD CONTAIN 3 AND R4 SHOULD CONTAIN 0.		
2286 010052	174027		250\$: STD ACO,(R7)++	;TEST INSTRUCTION.	
2287 010054	005201		210\$: INC R1	;THE STD INSTRUCTION SHOULD CHANGE THIS TO INC R4.	
2288 010056	005201		INC R1		
2289 010060	005201		INC R1		
2290 010062	005201		INC R1		
2291 010064	012700	0101.2	MOV #260\$,R0	;SEE IF THE DATA WAS OUTPUT CORRECTLY.	
2292 010070	012702	010054	MOV #210\$,R2		
2293 010074	012703	000004	MOV #4,R3		
2294 010100	022022		280\$: CMP (R0)++, (R2)++		
2295 010102	001051		BNE 270\$;BRANCH IF INCORRECT.	
2296 010104	077303		S0B R3,280\$		
2297 010106	005704		TST R4	;MAKE SURE R4 IS 0.	
2298 010110	001056		BNE 290\$;BRANCH IF R4 IS INCORRECT.	
2299 010112	022701	000003	CMP #3,R1	;SEE IF R1 IS CORRECT.	
2300 010116	001053		BNE 290\$;BRANCH IF R1 IS INCORRECT.	
2301 010120	000474		BR 300\$		
2302			;THESE ARE TEST DATA PATTERNS USED TO SET UP THE OUTPUT BUFFER AT 210\$.		
2303 010122	005201		220\$: INC R1		
2304 010124	005201		INC R1		
2305 010126	005201		INC R1		
2306 010130	005201		INC R1		
2307			;THIS IS THE DATA PUT IN ACO BEFORE EXECUTION OF THE STD.		
2308 010132	005204		230\$: INC R4		
2309 010134	005204		INC R4		
2310 010136	005204		INC R4		
2311 010140	005204		INC R4		
2312			;THIS IS THE EXPECTED DATA AT 210\$ AFTER EXECUTION OF THE STD.		
2313 010142	005204		260\$: INC R4		
2314 010144	005201		INC R1		

2315 010146 005201		INC R1
2316 010150 005201		INC R1
2317		:IF A FAILURE IN THE FDST FLOWS RESULTS IN AN ODD ADDRESS TRAP THROUGH
2318		:4 TO HERE:
2319 010152 011602	000001	240\$: MOV (SP), R2 ;SEE IF THE TRAP WAS BECAUSE OF AN ODD ADDRESS.
2320 010154 032702	010056	BIT #1, R2
2321 010160 001005		BNE 310\$;BRANCH IF YES.
2322 010162 020227		CMP R2, #210\$+2 ;SEE IF THE TRAP OCCURRED AT THE TEST INSTRUCTION.
2323 010166 001412		BEQ 320\$;BRANCH IF YES.
2324 010170 000137	051774	JMP CPSPUR ;OTHERWISE REPORT A SPURIOUS TRAP THROUGH VECTOR 4.
2325		:REPORT A FAILURE IN THE FDST FLOWS RESULTED IN AN ODD ADDRESS TRAP.
2326 010174 010237	001236	310\$: MOV R2, \$TMP2
2327 010200 012737	010056 001240	MOV #210\$+2, \$TMP3
2328 010206 022626		CMP (SP)+, (SP)+
2329 010210 104013		ERROR +13 ;BAD CONSTANT #2 + PC ODD ADDR.
2330 010212 000437		BR 300\$
2331 010214 010237	001236	320\$: MOV R2, \$TMP2
2332 010220 022626		CMP (SP)+, (SP)+
2333 010222 104014		ERROR +14 ;ODD ADDRESS TRAP
2334 010224 000432		BR 300\$;WRONG MODE USED.
2335		
2336		:REPORT DATA INCORRECT:
2337 010226 012737	010054 001240	270\$: MOV #210\$, \$TMP3
2338 010234 012737	010142 001242	MOV #260\$, \$TMP4
2339 010242 104015		ERROR +15 ;BAD DATA BUT GR7 FAIL
2340 010244 000422		BR 300\$
2341		
2342		:REPORT PC INCORRECT MODIFIED DURING THE EXECUTION OF FDST IMMEDIATE
2343		:MODE. THE PC SHOULD HAVE BEEN INCREMENTED BY 2 BUT IT WASN'T.
2344		:USE R1 AND R4 TO COMPUTE THE ACTUAL ACTION THAT WAS TAKEN ON THE PC.
2345 010246 012737	010056 001240	290\$: MOV #210\$+2, \$TMP3
2346 010254 005704		TST R4 ;IS R4 CLEAR.
2347 010256 001404		BEQ 100\$
2348 010260 012737	010054 001242	MOV #210\$, \$TMP4
2349 010266 000410		BR 110\$
2350 010270 012702	010056	100\$: MOV #210\$+2, R2
2351 010274 062701	177775	ADD #-3, R1
2352 010300 006301		ASL R1
2353 010302 160102		SUB R1, R2
2354 010304 010237	001242	MOV R2, \$TMP4
2355 010310 104016		ERROR +16 ;BAD CONSTANT PC+
2356 010312 010312	104412	300\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
		;SEE IF THE USER HAS EXPRESSED
		;THE DESIRE TO CHANGE THE SOFTWARE
		;VIRTUAL CONSOLE SWITCH REGISTER (HAS
		;THE USER TYPED CONTROL G?).

2362

.SBTTL TEST # 5 - FDST MODE 4 TEST

;***** TEST 5 FDST MODE 4 TEST *****

;* THIS IS A TEST OF STD WITH FDST MODE 4.

010314	000004		TST5: SCOPE			
2363 010316	012737	010324	001110	200\$: MOV	#200\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.
2364 010324	012700	177777		MOV	#-1, R0	;SET UP THE OUTPUT BUFFER.
2365 010330	012701	010460		MOV	#210\$, R1	
2366 010334	012702	000010		MOV	#10, R2	
2367 010340	010021			MOV	R0, (R1)+	
2368 010342	077202			SOB	R2, 1\$	
2369 010344	012700	000200		MOV	#200\$, R0	;ENTER FLOATING DOUBLE MODE.
2370 010350	170100			LDFPS	R0	
2371 010352	012700	010500		MOV	#220\$, R0	;SET UP ACO.
2372 010356	172410			LDD	(R0), ACO	
2373 010360	012737	010520	000004	MOV	#240\$, ERRVECT	;SET UP FOR A TRAP TO 4.
2374 010366	012737	010400	001236	MOV	#230\$, STMP2	
2375 010374	012700	010470		MOV	#250\$, R0	;SET UP THE DESTINATION ADDRESS.
2376						
2377 010400	174040		230\$: STD	AC0, -(R0)		;TEST INSTRUCTION.
2378 010402	005201		INC	R1		
2379 010404	020027	010400	CMP	R0, #210\$;SEE IF R0 WAS DECREMENTED PROPERLY.
2380 010410	001060		BNE	260\$;BRANCH IF R0 IS INCORRECT.
2381 010412	012700	010460	MOV	#210\$, R0		;WAS THE OUTPUT DATA CORRECT?
2382 010416	012701	010500	MOV	#220\$, R1		
2383 010422	012702	000004	MOV	#4, R2		
2384 010426	022021		CMP	(R0)+, (R1)+		
2385 010430	001057		BNE	270\$;BRANCH IF INCORRECT.
2386 010432	077203		SOB	R2, 110\$		
2387 010434	012700	177777	MOV	#-1, R0		;IS THE REST OF THE OUTPUT BUFFER CORRECT, -1?
2388 010440	012701	010470	MOV	#250\$, R1		
2389 010444	012702	000004	MOV	#4, R2		
2390 010450	020021		CMP	R0, (R1)+		
2391 010452	001056		BNE	280\$;BRANCH IF INCORRECT.
2392 010454	077203		SOB	R2, 120\$		
2393 010456	000463		BR	290\$		
2394						
2395						
2396 010460	177777		210\$: THIS IS THE OUTPUT DATA BUFFER.			
2397 010462	177777		-1			
2398 010464	177777		-1			
2399 010466	177777		-1			
2400 010470	177777		250\$: -1			
2401 010472	177777		-1			
2402 010474	177777		-1			
2403 010476	177777		-1			
2404						
2405						
2406 010500	147250		THIS IS THE TEST DATA LOADED INTO ACO:			
2407 010502	036147		220\$: 147250			
2408 010504	025036		36147			
2409 010506	147250		25036			
2410 010510	177777		147250			
2411 010512	177777		300\$: -1			

2412 010514 177777 -1
 2413 010516 177777 -1
 2414
 2415 :IF AN ODD ADDRESS TRAP OCCURS COME HERE:
 2416 010520 011600 240\$: MOV (SP), R0 ;SEE IF THE TRAP ACCURRED ON THE TEST INSTRUCTION.
 2417 010522 020027 010402 CMP R0, #230\$+2
 2418 010526 001405 BEQ 310\$;BRANCH IF YES.
 2419 010530 020027 010404 CMP R0, #230\$+4
 2420 010534 001402 BEQ 310\$;BRANCH IF YES.
 2421 010536 000137 051774 JMP CPSPUR ;OTHERWISE GO REPORT A SPURIOUS TRAP THROUGH 4.
 2422 :REPORT FAILURE IN FDST FLOWS RESULTED IN AN ODD ADDRESS.
 2423 010542 010037 001236 310\$: MOV R0, STMP2
 2424 010546 104017 ERROR +17 ;FDST FORK X ODD AD RES.
 2425 010550 000426 BR 290\$
 2426
 2427 :REPORT R0 INCORRECTLY DECREMENTED.
 2428 010552 010037 001242 260\$: MOV R0, STMP4
 2429 010556 012737 010460 001240 MOV #210\$, STMP3
 2430 010564 104020 ERROR +20 ;R0 NOT DECRE PROP
 2431 010566 000417 BR 290\$
 2432
 2433 :REPORT OUTPUT DATA INCORRECT:
 2434 010570 012737 010460 001240 270\$: MOV #210\$, STMP3
 2435 010576 012737 010500 001242 MOV #220\$, STMP4
 2436 010604 104021 ERROR +21 ;BAD DATA
 2437 010606 000407 BR 290\$
 2438 010610 012737 010470 001242 280\$: MOV #250\$, STMP4
 2439 010616 012737 010510 001240 MOV #300\$, STMP3
 2440 010624 104022 ERROR +22 ;DATA BAD OUTSIDE TARGET AREA
 2441 010626 010626 290\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
 010626 104412 ;SEE IF THE USER HAS EXPRESSED
 ;THE DESIRE TO CHANGE THE SOFTWARE
 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
 ;THE USER TYPED CONTROL G?).

2447

SBTTL TEST # 6 - FDST MODE 3 TEST

*: TEST 6 FDST MODE 3 TEST

*: THIS IS A TEST OF FDST MODE 3 USING STD.

TST6: SCOPE

200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.

;DPM002

MOV #210\$,R1 ;SET UP THE OUTPUT DATA BUFFER.

MOV #-1,R0

MOV #12,R2

MOV R0,(R1)+

S0B R2,1\$

MOV #210\$,220\$

MOV #200,R0

;ENTER DOUBLE FLOATING MODE.

LDFPS R0

MOV #230\$,R0

;SET UP ACO.

LDD (R0),AC0

MOV #240\$,ERRVECT

;SET UP FOR TRAPS TO 4.

MOV 250\$,STMP2

MOV #220\$,R0

;SET UP THE DESTINATION ADDRESS.

250\$: STD ACO,A(R0)+

;TEST INSTRUCTION.

CMP R0,#220\$+2

;SEE IF R0 WAS INCREMENTED CORRECTLY.

BNE 260\$

;BRANCH IF INCORRECT.

MOV #210\$,R1

;CHECK THE OUTPUT DATA BUFFER.

MOV #230\$,R2

MOV #4,R3

270\$: CMP (R1)+,(R2)+

;BRANCH IF NOT CORRECT.

BNE 280\$

S0B R3,270\$

BR 300\$

;THIS IS THE OUTPUT DATA BUFFER:

210\$: -1

-1

-1

-1

-1

-1

220\$: 210\$

-1

-1

-1

230\$: 101213

141516

71727

37475

;TRAP THROUGH VECTOR 4 TO HERE.

240\$: MOV (SP),R2

;SEE IF THE TRAP ADDRESS IS THAT OF THE TEST INSTRUCTION.

CMP R2,#250\$+2

BEQ 290\$

;BRANCH IF YES.

CMP R2,#250\$+4

BEQ 290\$

;BRANCH IF YES.

2490

2491

2492 011012 011602 010724

2493 011014 020227

2494 011020 001405 010726

2495 011022 020227 010726

2496 011026 001402

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 15-4
TEST # 6 - FDST MODE 3 TEST

SEQUENCE 44

2497 011030 000137 051774 JMP CPSPUR ;OTHERWISE GO REPORT A SPURIOUS TRAP TO 4.
2498
2499 :REPORT A FAILURE IN THE FDST FLOWS RESULTED IN AN ODD ADDRESS TRAP.
2500 011034 010237 001236 290\$: MOV R2,\$TMP2
2501 011040 022626 CMP (SP)+,(SP)+
2502 011042 104025 ERROR +23 ;BET FDST X ODD ADR
2503 011044 000416 BR 300\$
2504
2505 :REPORT RO INCORRECT:
2506 011046 010037 001242 260\$: MOV RO,\$TMP4
2507 011052 012737 010774 001240 MOV #220\$+2,\$TMP3
2508 011060 104024 ERROR +24 ;RO NOT INCREMENT PROPERLY
2509 011062 000407 BR 300\$
2510
2511 :REPORT INCORRECT OUTPUT DATA:
2512 011064 012737 010756 001240 280\$: MOV #210\$,TMP3
2513 011072 012737 011002 001242 MOV #230\$,TMP4
2514 011100 104025 ERROR +25 ;BAD DATA
2515 011102 011102 300\$: RSETUP
011102 104412 :GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

2521

.SBTTL TEST # 7 - FDST MODE 5 TEST

;***** TEST 7 FDST MODE 5 TEST *****

;* THIS IS A TEST OF FDST MODE 5 USING STD.

;***** TSTY: SCOPE *****

011104 000004	012737 011114 001110	MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
2522 011106 012701 011232	200\$: MOV #210\$,R1 ;SET UP THE OUTPUT DATA BUFFER.		
2523 011114 012700 177777	MOV #1,R0		
2524 011120 012702 000012	MOV #12,R2		
2525 011124 010021	MOV R0,(R1)+		
2526 011130 077202	S0B R2,1\$		
2527 011132 012737 011232 011244	MOV #210\$,220\$		
2528 011134 012700 000200	MOV #200,R0	:ENTER DOUBLE FLOATING MODE.	
2529 011142 170100	LDFPS R0		
2530 011146 012700 011256	MOV #230\$,R0	:SET UP AC0.	
2531 011150 011154 172410	LDD (R0),AC0		
2533 011156 012737 011266 000004	MOV #240\$,ERRVECT	:GET READY FOR ANY TRAPS TO 4.	
2534 011164 013737 011176 001236	MOV 250\$,TMP2		
2535 011172 012700 011246	MOV #260\$,R0	:SET UP THE DESTINATION ADDRESS.	
2536 011176 174050	STD AC0,a-(R0)	:TEST INSTRUCTION.	
2537 011200 020027 011244	CMP R0,#260\$-2	:WAS R0 DECREMENTED PROPERLY?	
2538 011204 001046	BNE 270\$:BRANCH IF R0 IS INCORRECT.	
2539 011206 012701 011232	MOV #210\$,R1	:WAS THE DATA OUTPUT CORRECTLY?	
2540 011212 012702 011256	MOV #230\$,R2		
2541 011216 012703 000004	MOV #4,R3		
2542 011222 022122	CMP (R1)+,(R2)+		
2543 011224 001045	BNE 310\$:BRANCH IF DATA IS INCORRECT.	
2544 011226 077303	S0B R3,280\$		
2545 011230 000452	BR 290\$		
2546			
2547 011232 177777	;THIS IS THE OUTPUT DATA BUFFER		
2548 011234 177777	210\$: -1		
2549 011236 177777	-1		
2550 011240 177777	-1		
2551 011242 177777	-1		
2552 011244 011232	220\$: 210\$		
2553 011246 177777	260\$: -1		
2554 011250 177777	-1		
2555 011252 177777	-1		
2556 011254 177777	-1		
2557 011256 020212	230\$: 20212		
2558 011260 023242	23242		
2559 011262 026273	2627,		
2560 011264 031323	031323		
2561			
2562			
2563 011266 011602	;IF A TRAP TO 4 OCCURS COME HERE.		
2564 011270 020227 011200	240\$: MOV (SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	
2565 011274 001405	CMP R2,#250\$+2		
2566 011276 020227 011202	BEQ 300\$;BRANCH IF YES.	
2567 011302 001402	CMP R2,#250\$+4		
2568 011304 000137 051774	BEQ 300\$;BRANCH IF YES.	
2569	JMP CPSPUR	;OTHERWISE REPORT A SPURIOUS TRAP TO 4.	
2570	;REPORT FAILURE OF FDST RESULTED IN AN ODD ADDRESS TRAP TO 4.		

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE H 4
TEST # 7 - FDST MODE 5 TEST

SEQUENCE 46

2571 011310 010237 001236 300\$: MOV R2,\$TMP2
2572 011314 022626 CMP (SP)+,(SP)+
2573 011316 104026 ERROR +26 :BET FDST X ODD ADR
2574 011320 000416 BR 290\$
2575
2576 :REPORT RO INCORRECT.
2577 011322 010037 001242 270\$: MOV RO,\$IMP4
2578 011326 012737 011250 001240 MOV #260\$+2,\$TMP3
2579 011334 104027 ERROR +27 ;RO NOT INCREMENT PROPERLY
2580 011336 000407 BR 290\$
2581
2582 :REPORT BAD DATA.
2583 011340 012737 011232 001242 310\$: MOV #210\$,TMP4
2584 011346 012737 011256 001240 MOV #230\$,TMP3
2585 011354 104030 ERROR +30 ;BAD DATA
2586 011356 104412 290\$: RSETUP
;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

2592

.SBTTL TEST # 10 - FDST MODE 6, INDEX MODE, TEST

TEST 10 FDST MODE 6, INDEX MODE, TEST

THIS IS A TEST OF FDST MODE 6, INDEX MODE, USING STD.

011360	000004		TST10:	SCOPE				
2593				.DSABL	AMA			
2594	011362	012767	011370	167520	200\$:	MOV #200\$,SLPERR	;DISABLE MODE 6 TO MODE 3 CONVERSIONS	
2595	011370	012700	000200			MOV #200,R0	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
2596	011374	170100				LDFPS R0	;ENTER DOUBLE FLOATING MODE.	
2597	011376	012701	011506			MOV #210\$,R1	;SET UP THE OUT PUT DATA BUFFER.	
2598	011402	012700	177777			MOV #1,R0		
2599	011406	012702	000004			MOV #4,R2		
2600	011412	010021			1\$:	MOV R0,(R1)+		
2601	011414	077202				S0B R2,1\$		
2602	011416	012767	011526	166360		MOV #220\$,ERRVECT	;SET UP VECTOR 4 INCASE OF ERROR.	
2603	011424	012700	011516			MOV #230\$,R0	;SET UP AC0.	
2604	011430	172410				LDD (R0),AC0		
2605	011432	012767	011450	167576		MOV #240\$,TMP2		
2606	011440	012700	003605			MOV #210\$-5701,R0	;SET UP THE DESTINATION ADDRESS.	
2607	011444	012701	000001			MOV #1,R1		
2608	011450	174060	005701		240\$:	STD AC0,5701(R0)	;TEST INSTRUCTION.	
2609								
2610	011454	020027	003605			CMP R0,#210\$-5701	;SEE IF R0 WAS MODIFIED.	
2611	011460	001040				BNE 250\$;BRANCH IF INCORRECT.	
2612	011462	012702	011506			MOV #210\$,R2	;WAS THE OUTPUT DATA CORRECT.	
2613	011466	012703	011516			MOV #230\$,R3		
2614	011472	012704	000004			MOV #4,R4		
2615	011476	022223			2\$:	CMP (R2)+,(R3)+		
2616	011500	001037				BNE 260\$;BRANCH IF INCORRECT DATA.	
2617	011502	077403				S0B R4,2\$		
2618	011504	000444				BR 270\$		
2619	011506	177777			210\$:	-1		
2620	011510	177777				-1		
2621	011512	177777				-1		
2622	011514	177777				-1		
2623	011516	030313			230\$:	30313		
2624	011520	023334				23334		
2625	011522	035363				35363		
2626	011524	074041				74041		
2627								
2628						:COME HERE AFTER A TRAP THROUGH VECTOR 4.		
2629	011526	011602			220\$:	MOV (SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTR.	
2630	011530	020227	011452			CMP R2,#240\$+2		
2631	011534	001405				BEQ 280\$;BRANCH IF YES.	
2632	011536	020227	011454			CMP R2,#240\$+4		
2633	011542	001402				BEQ 280\$;BRANCH IF YES.	
2634	011544	000167	040162			JMP FPSPUR	;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.	
2635						OF FDST RESULTED IN AN ODD ADDRESS TRAP TO 4.		
2636	011550	010267	167462		280\$:	MOV R2,TMP2		
2637	011554	022626				CMP (SP)+,(SP)+		
2638	011556	104031				ERROR +31	;FDST FORK X ODD ADD	
2639	011560	000416				BR 270\$		
2640								
2641						:REPORT R0 MODIFIED.		

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE J 4
TEST # 10 - FDST MODE 6, INDEX MODE, TEST

SEQUENCE 48

2642 011562 010067 167454 250\$: MOV R0,\$TMP4
2643 011566 012767 003605 167444 MOV #210\$-5701,\$TMP3
2644 011574 104032 ERROR +32 ;R0 MODIFIED.
2645 011576 000407 BR 270\$
2646
2647 :REPORT INCORRECT DATA.
2648 011600 012767 011506 167432 260\$: MOV #210\$,\$TMP3
2649 011606 012767 011516 167426 MOV #230\$,\$TMP4
2650 011614 104033 ERROR +33 ;BAD DATA
2651 011616 104412 270\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
011616 104412 .ENABL AMA ;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).
;REENABLE MODE 6 TO MODE 3 CONVERSIONS

2658

K 4
113 30-OCT-81 11:15 PAGE 18
MODE, TEST

SBTTL TEST # 11 - FDST MODE 7, INDEX DEFERRED MODE, TEST

TEST 11 FDST MODE 7, INDEX DEFERRED MODE, TEST
*
THIS IS A TEST OF FDST MODE 7, INDEX DEFERRED MODE, USING ST

011620	000004				TST11: SCOPE				
2659	011622	012737	011630	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.		
2660	011630	012700	000200		200\$: MOV	#200,R0	;ENTER DOUBLE FLOATING MODE.		:DPM002
2661	011634	170100			200\$: LDFPS	R0			
2662	011636	012701	011754		MOV	#210\$,R1	;SET UP THE OUTPUT DATA BUFFER.		
2663	011642	012700	177777		MOV	#-1,R0			
2664	011646	012702	000004		MOV	#4,R2			
2665	011652	010021			MOV	R0,(R1)+			
2666	011654	077202			SOB	R2,100\$			
2667	011656	012737	012004	000004	MOV	#220\$,ERRVECT	;SET UP FOR TRAPS TO 4.		
2668	011664	012700	011764		MOV	#230\$,R0	;SET UP ACO.		
2669	011670	172410			LDD	(R0),AC0			
2670	011672	012737	011716	001236	MOV	#240\$,STMP2			
2671	011700	012700	004073		MOV	#250\$-5701,R0	;SET UP THE DESTINATION ADDRESS.		
2672	011704	012701	000001		MOV	#1,R1			
2673	011710	012737	011754	011774	MOV	#210\$,250\$			
2674	011716	174070	005701		240\$: STD	AC0,25701(R0)	;TEST INSTRUCTION.		
2675					CMP	R0,#250\$-5701	;IS R0 CORRECT?		
2676	011722	020027	004073		BNE	260\$;BRANCH IF INCORRECT.		
2677	011726	001044			MOV	#210\$,R2	;WAS THE DATA OUTPUT CORRECTLY?		
2678	011730	012702	011754		MOV	#230\$,R3			
2679	011734	012703	011764		MOV	#4,R4			
2680	011740	012704	000004		110\$: CMP	(R2)+,(R3)+			
2681	011744	022223			BNE	270\$			
2682	011746	001043			SOB	R4,110\$;BRANCH IF DATA IS INCORRECT.		
2683	011750	077403			BR	280\$			
2684	011752	000450			210\$: -1				
2685	011754	177777			-1				
2686	011756	177777			-1				
2687	011760	177777			-1				
2688	011762	177777			-1				
2689	011764	041424			230\$: 41424				
2690	011766	034445			34445				
2691	011770	046475			46475				
2692	011772	051525			051525				
2693	011774	177777			250\$: -1				
2694	011776	177777			-1				
2695	012000	177777			-1				
2696	012002	177777			-1				
2697									
2698									
2699	012004	011602			:TRAP THROUGH 4 TO HERE.				
2700	012006	020227	011720		220\$: MOV	(SP),R2			
2701	012012	001405			CMP	R2,#240\$+2			
2702	012014	020227	011722		BEQ	290\$			
2703	012020	001402			CMP	R2,#240\$+4			
2704	012022	000137	051732		BEQ	290\$			
2705					JMP	FPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.			
2706	012026	010237	001236		REPORT FAILURE	OF FDST FORK RESULTED IN AN ODD ADDRESS TRAP TO 4.			
2707	012032	022626			290\$: MOV	R2,STMP2			
					CMP	(SP)+,(SP)+			

L-4
CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 18-1
TEST # 11 - FDST MODE 7, INDEX DEFERRED MODE, TEST

SEQUENCE 50

```

2708 012034 104034           ERROR    +34      ;FDST FORK X ODD ADD
2709 012036 000416           BR       280$ 
2710
2711
2712 012040 010037 001242   :REPORT  RO MODIFIED.
2713 012044 012737 004053   260$:   MOV     RO,$TMP4
2714 012052 104035           MOV     #210$-5701,$TMP3
2715 012054 000407           ERROR   +35      ;RO MODIFIED!
2716
2717
2718 012056 012737 011754 001240   :REPORT  DATA INCORRECT
2719 012064 012737 011764 001242   270$:   MOV     #210$,TMP3
2720 012072 104036           MOV     #230$,TMP4
2721 012074 012074 104412   280$:   ERROR   +36      ;BAD DATA
2722 012074 104412           RSETUP
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
2999

```

2727

SBTTL TEST # 12 - STCFD TEST
TEST 12 STCFD TEST
THIS IS A TEST OF THE STCFD INSTRUCTION.

2728	012076	000004				IST12: SCOPE			
2729	012100	012737	012106	001110		:AC=0			
2730	012106	004737	012462			200S: MOV #200\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
2731	012112	000000				JSR PC, 1000\$			
2732	012114	000000				1\$: 0 ;AC			
2733	012116	000000				0			
2734	012120	000000				0			
2735	012122	000000				2\$: 0	:RES		
2736	012124	000000				0			
2737	012126	000000				0			
2738	012130	000000				0			
2739	012132	000000				3\$: 0	:ERROR RES.		
2740	012134	000000				0			
2741	012136	177777				-1			
2742	012140	177777				-1			
2743	012142	047000				4\$: 47000	:FPS BEFORE EXECUTION.		
2744	012144	047004				47004	:FPS AFTER EXECUTION.		
2745	012146	177777				-1	:FEC		
2746	012150	147004				147004	:ERROR FPS.		
2747	012152	104042				5\$: ERROR +42	:FDFL<---FDLXST 767		
2748	012154	000401				BR 6\$			
2749	012156	104043				ERROR +43	:BUT EZBT X ST560 TO 061 INTO 261		
2750	012160					6\$: :			
2751						:			
2752	012160	012737	012166	001110		MOV #210\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
2753	012166	004737	012462			JSR PC, 1000\$			
2754	012172	017203				210S: 17203 ;AC			
2755	012174	142536				17203			
2756	012176	047506				142536			
2757	012200	172031				47506			
2758	012202	017203				172031			
2759	012204	142536				17203	:RES		
2760	012206	000000				142536			
2761	012210	000000				0			
2762	012212	017203				0			
2763	012214	142536				17203	:ERROR RES.		
2764	012216	047506				142536			
2765	012220	172031				47506			
2766	012222	040000				172031			
2767	012224	040000				40000	:FPS BEFORE EXECUTION.		
2768	012226	177777				40000	:FPS AFTER EXECUTION.		
2769	012230	177777				-1	:FEC		
2770	012232	104044				-1	:ERROR FPS.		
2771	012234	000401				15\$: ERROR +44	:X11(1,0)<---0 X ST766		
2772	012236	104040				BR 16\$			
2773	012240					ERROR +40			
2774						:			
2775	012240	012737	012246	001110		MOV #220\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
2776	012246	004737	012462			JSR PC, 1000\$			

CKFPCDO FP11F FITG PNT PRT C
TEST # 12 - STLF D TEST

MACRO M113 30-OCT-81 11:15 PAGE N⁴ 19-1

SEQUENCE 52

2777 012252 050717	21\$:	50717	:AC	
2778 012254 027374		27374		
2779 012256 075767		75767		
2780 012260 077071		77071		
2781 012262 050717	22\$:	50717	:RES	
2782 012264 027374		27374		
2783 012266 000000		0		
2784 012270 000000		0		
2785 012272 000000	23\$:	0	:ERROR RES.	
2786 012274 000000		0		
2787 012276 000000		0		
2788 012300 000900		0		
2789 012302 047000	24\$:	47000	:FPS BEFORE EXECUTION.	
2790 012304 047000		47000	:FPS AFTER EXECUTION.	
2791 012306 177777		-1	:FEC	
2792 012310 174002		174002	:ERROR FPS.	
2793 012312 104045	25\$:	ERROR +45	:BUT OPIC X ST251	
2794 012314 000401		BR 26\$		
2795 012316 104046		ERROR +46	:BUT EZBT X ST421	
2796 012320	26\$:	:		
2797		;		
2798 012320 012737 012326 001110	230\$:	MOV #230\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
2799 012326 004737 012462	31\$:	JSR PC, 1000\$		
2800 012332 020212		20212	:AC	
2801 012334 032425		32425		
2802 012336 026272		26272		
2803 012340 002123		02123		
2804 012342 020212	32\$:	20212	:RES	
2805 012344 032425		32425		
2806 012346 000000		0		
2807 012350 000000		0		
2808 012352 020212	33\$:	20212	:ERROR RES.	
2809 012354 032425		32425		
2810 012356 100000		100000		
2811 012360 000000		0		
2812 012362 040000	34\$:	40000	:FPS BEFORE EXECUTION.	
2813 012364 040000		40000	:FPS AFTER EXECUTION.	
2814 012366 177777		-1	:FEC	
2815 012370 177777		-1	:ERROR FPS.	
2816 012372 104047	35\$:	ERROR +47	:BUT FD IN ROUND X ST113	
2817 012374 000401		BR 36\$		
2818 012376 104040		ERROR 40		
2819 012400	36\$:	:		
2820		;		
2821 012400 012737 012406 001110	240\$:	MOV #2,0\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
2822 012406 004737 012462	41\$:	JSR PC, 1000\$		
2823 012412 121314		121314	:AC	
2824 012414 151617		151617		
2825 012416 101112		101112		
2826 012420 131415		131415		
2827 012422 121314	42\$:	121314	:RES	
2828 012424 151617		151617		
2829 012426 000000		0		
2830 012430 000000		0		
2831 012432 021314	43\$:	21314	:ERROR RES.	
2832 012434 151617		151617		
2833 012436 000000		0		

CKFPCDO FP11F FLTG PNT PRT C
TEST # 12 - STCFD TEST

MACRO M1113 30-OCT-81 11:15 PAGE 19-2

B 5

SEQUENCE 53

2834 012440 000000			0	
2835 012442 040000		44S:	40000	:FPS BEFORE EXECUTION.
2836 012444 040010			40010	:FPS AFTER EXECUTION.
2837 012446 177777			-1	:FEC
2838 012450 177777			-1	:ERROR FPS.
2839 012452 104050		45S:	ERROR +50	:BUT ENBT X ST567 OR BAD SIGN ST460
2840 012454 000401			BR 46S	
2841 012456 104040			ERROR +40	
2842 012460 000535		46S:	BR 250S	

2843 ;THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 2844 THE STCFD INSTRUCTION AND CHECK THE RESULTS. A CALL
 2845 TO IT IS MADE THUS:

2847	JSR	PC,1000\$	
2848	ACARG:	.WORD X,X,X,X	;AC OPERAND
2849	RES:	.WORD X,X,X,X	;EXPECTED RESULT
2850	ERRES:	.WORD X,X,X,X	;ERROR RESULT
2851	FPSB:	.WORD X	;FPS BEFORE EXECUTION
2852	FPSA:	.WORD X	;FPS AFTER EXECUTION
2853	FLC:	.WORD X	;EXPECTED FEC
2854	ERFPS:	.WORD X	;ERROR FPS.
2855	ERR1:	ERROR +X	;DATA ERROR.
2856		BR CONT	
2857	ERR2:	ERROR +X	;FPS ERROR.
2858	CONT:		;RETURN ADDRESS

2859

2860 ;THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 2861 THE STCFD INSTRUCTION IS EXECUTED.
 2862 THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 2863 COMPARED WITH FPSA IF THIS TOO IS CORRECT 1000\$ RETURNS CONTROL
 2864 TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD 1000\$
 2865 COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN 1000\$ WILL RETURN
 2866 TO THE ERROR CALL AT ERR2, OTHERWISE 1000\$ ITSELF
 2867 REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 2868 STCFD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 2869 ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 2870 THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN 1000\$
 2871 WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
 2872 RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND 1000\$ WILL
 2873 REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.

2874

2875 012462 012601	1000\$:	MOV (SP)+,R1	;PICK UP THE POINTER TO THE OPERANDS.
2876 012464 012700	MOV #200,R0	;ENTER DOUBLE FLOATING MODE.	
2877 012470 170100	LDFPS R0		
2878 012472 010100	MOV R1,R0	;LOAD ACO.	
2879 012474 172410	LDL (R0),ACO		
2880 012476 012700	MOV #-1,R0		
2881 012502 012702	MOV #245\$,R2		
2882 012506 012703	MOV #4,R3		
2883 012512 010022	MOV R0,(R2)+		
2884 012514 077302	SOB R3,51\$		
2885 012516 016100	MOV 30(R1),R0	;LOAD THE FPS.	
2886 012522 170100	LDFPS R0		
2887 012524 012737	MOV #52\$,STMP2		
2888 012532 012700	MOV #245\$,R0		
2889 012536 176010	51\$: STCFD ACO,(R0)	;SET UP THE DESTINATION ADDRESS.	
		52\$: STCFD AC0,(R0)	;TEST INSTRUCTION.
2890			
2891 012540 170204	STFPS R4	;GET THE FPS.	
2892 012542 170305	STST R5	;GET THE FEC.	
2893 012544 010102	MOV R1,R2	;SAVE THE DATA IN CASE C ^E ERROR.	
2894 012546 010237	MOV R2,STMP3		
2895 012552 062702	ADD #10,R2		
2896 012556 010237	MOV R2,STMP5		
2897 012562 012737	MOV #245\$,STMP4		
2898 012570 010437	MOV R4,STMP7		
2899 012574 016137	MOV 32(R1),STMP10		

CKFPCDO FP11F FLTG PNT PRT C
TEST # 13 - STCDF TEST

MACRO M1113 30-OCT-81 11:15 PAGE 21-5

SEQUENCE 57

3004 013132	077777	21\$:	77777	:AC0			
3005 013134	177777		-1				
3006 013136	100000		100000				
3007 013140	000000		0				
3008 013142	000000	22\$:	0	:RES			
3009 013144	000000		0				
3010 013146	177777		-1				
3011 013150	177777		-1				
3012 013152	077777	23\$:	77777	:ERROR RES.			
3013 013154	177777		-1				
3014 013156	177777		-1				
3015 013160	177777		-1				
3016 013162	040200	24\$:	40200	:FPS BEFORE EXECUTION.			
3017 013164	040206		40206	:FPS AFTER EXECUTION.			
3018 013166	177777		-1	:FEC			
3019 013170	040204		40204	:ERROR FPS.			
3020 013172	104055	25\$:	ERROR	+55			
3021 013174	000401		BR	26\$			
3022 013176	104056		ERROR	+56			
3023 013200		26\$:	:				
3024							
3025 013200	012737	013206	001110	230\$:	MOV #230\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	
3026 013206	004737	013342		31\$:	JSR PC,1000\$;DPM002
3027 013212	077777				77777	:AC0	
3028 013214	177777				-1		
3029 013216	100000				100000		
3030 013220	000000				0		
3031 013222	000000			32\$:	0	:RES	
3032 013224	000000				0		
3033 013226	177777				-1		
3034 013230	177777			33\$:	77777	:ERROR RES.	
3035 013232	077777				-1		
3036 013234	177777				-1		
3037 013236	177777				-1		
3038 013240	177777			34\$:	40200	:FPS BEFORE EXECUTION.	
3039 013242	040200				40206	:FPS AFTER EXECUTION.	
3040 013244	040206				-1	:FEC	
3041 013246	177777				140206	:ERROR FPS.	
3042 013250	140206			35\$:	ERROR	+55	
3043 013252	104055				BR	36\$	
3044 013254	000401				ERROR	+57	
3045 013256	104057			36\$:	:		
3046 013260							
3047							
3048 013260	012737	013266	001110	240\$:	MOV #240\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	
3049 013266	004737	013342		41\$:	JSR PC,1000\$;DPM002
3050 013272	177777				177777	:AC0	
3051 013274	177777				-1		
3052 013276	100000				100000		
3053 013300	000000				0		
3054 013302	100000			42\$:	100000	:RES	
3055 013304	000000				0		
3056 013306	177777				-1		
3057 013310	177777				-1		
3058 013312	000000			43\$:	0	:ERROR RES.	
3059 013314	000000				0		
3060 013316	177777				-1		

3061 013320 177777			
3062 013322 047200	44\$: -1	47200	;FPS BEFORE EXECUTION.
3063 013324 147216		147216	;FPS AFTER EXECUTION.
3064 013326 000010		10	;FEC
3065 013330 047206		47206	;ERROR FPS.
3066 013332 104060	45\$: ERROR	+60	;BUT FIV ST262 FAIL TO 103 INT 123
3067 013334 000401		BR 46\$	
3068 013336 104061	46\$: ERROR	+61	;BUT FLAG ST 147 X TO ST 361 INTO 365
3069 013340 000535		BR 250\$	

3070 :THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 3071 :THE STCDF INSTRUCTION AND CHECK THE RESULTS. A CALL
 3072 :TO IT IS MADE THUS:

3074	JSR	PC,1000\$		
3075	ACARG:	.WORD	X,X,X,X	:AC OPERAND
3076	RES:	.WORD	X,X,X,X	:EXPECTED RESULT
3077	ERRES:	.WORD	X,X,X,X	:ERROR RESULT
3078	FPSB:	.WORD	X	:FPS BEFORE EXECUTION
3079	FPSA:	.WORD	X	:FPS AFTER EXECUTION
3080	FEC:	.WORD	X	:EXPECTED FEC
3081	ERFPS:	.WORD	X	:ERROR FPS.
3082	ERR1:	ERROR	+X	:DATA ERROR.
3083		BR	CONT	
3084	ERR2:	ERROR	+X	:FPS ERROR.
3085	CONT:			:RETURN ADDRESS

3086

3087 :THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 3088 :THE STCDF INSTRUCTION IS EXECUTED.
 3089 :THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 3090 :COMPARED WITH FPSA IF THIS TOO IS CORRECT STCFDS RETURNS CONTROL
 3091 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STCFDS
 3092 :COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STCFDS WILL RETURN
 3093 :TO THE ERROR CALL AT ERR2, OTHERWISE STCFDS ITSELF
 3094 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 3095 :STCDF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 3096 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 3097 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STCFDS
 3098 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
 3099 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STCFDS WILL
 3100 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.

3101

3102	013342	012601	1000\$:	MOV	(SP)+,R1	:PICK UP THE POINTER TO THE OPERANDS.	
3103	013344	012700		MOV	#200,RO	:ENTER DOUBLE FLOATING MODE.	
3104	013350	170100		LDFPS	RO		
3105	013352	010100		MOV	R1,RO	:LOAD ACO.	
3106	013354	172410		LDD	(R0),ACO		
3107	013356	012700	177777	MOV	#-1,RO	:FILL THE OUTPUT BUFFER WITH -1'S.	
3108	013362	012702	013624	MOV	#260\$,R2		
3109	013366	012703	000004	MOV	#6,R3		
3110	013372	010022		51\$:	MOV	RO,(R2)+	
3111	013374	077302			S08	R3,51\$	
3112	013376	016100	000030		MOV	30(R1),RO	:LOAD THE FPS.
3113	013402	170100		LDFPS	RO		
3114	013404	012737	013416	001236	MOV	#52\$,STMP2	
3115	013412	012700	013624		MOV	#260\$,RO	:SET UP THE DESTINATION ADDRESS.
3116	013416	176010		52\$:	STCDF	ACO,(RO)	:TEST INSTRUCTION.
3117							
3118	013420	170204		STFPS	R4	:GET THE FPS.	
3119	013422	170305		STST	R5	:GET THE FEC.	
3120	013424	010102		MOV	R1,R2	:SAVE THE DATA IN CASE OF ERROR.	
3121	013426	010237	001240	MOV	R2,STMP3		
3122	013432	062702	000010	ADD	#10,R2		
3123	013436	010237	001244	MOV	R2,STMP5		
3124	013442	012737	013624	MOV	#260\$,STMP4		
3125	013450	010437	001250	MOV	R4,STMP7		
3126	013454	016137	000032	001252	MOV	32(R1),STMP10	

3127
 3128 013462 010102 012702 000010 53\$: MOV R1,R2 ;CHECK THE RESULT.
 3129 013464 062702 012703 013624 ADD #10,R2
 3130 013470 012700 000004 MOV #260\$,R3
 3131 013474 012700 000004 MOV #4,R0
 3132 013500 022223 CMP (R2)+,(R3)+
 3133 013502 001014 BNE 65\$;BRANCH IF INCORRECT.
 3134 013504 077003 SOB R0,53\$
 3135
 3136 013506 016102 000032 MOV 32(R1),R2
 3137 013512 020204 CMP R2,R4 :IS THE FPS CORRECT?
 3138 013514 001025 BNE 70\$;BRANCH IF FPS INCORRECT.
 3139 013516 005702 TST R2 ;IF EXPECTED FPS IS NEGATIVE, THEN
 3140 013520 100003 BPL 54\$;GO AHEAD AND CHECK THE FEC.
 3141 013522 026105 000034 CMP 34(R1),R5
 3142 013526 001027 BNE 75\$;BRANCH IF FEC IS INCORRECT.
 3143 013530 000161 000046 JMP 46(R1) ;RETURN.
 3144
 3145 :RESULT INCORRECT:
 3146 013534 010102 000020 65\$: MOV R1,R2 ;SEE IF ERROR WAS ANTICIPATED.
 3147 013536 062702 000020 ADD #20,R2
 3148 013542 012703 013624 MOV #260\$,R3
 3149 013546 012700 000004 MOV #4,R0
 3150 013552 022223 CMP (R2)+,(R3)+
 3151 013554 001003 BNE 67\$;BRANCH IF NOT ANTICIPATED.
 3152 013556 077003 SOB R0,66\$
 3153 013560 000161 000040 JMP 40(R1) ;IF ERROR WAS ANTICIPATED RETURN.
 3154 :OTHERWISE REPORT RESULT INCORRECT HERE.
 3155 013564
 3156 013564 104051 67\$: 68\$: ERROR +51 ;DATA ERROR
 3157 013566 000760 BR 54\$
 3158
 3159 :FPS INCORRECT:
 3160 013570 020461 000034 70\$: CMP R4,34(R1) ;WAS THE ERROR ANTICIPATED.
 3161 013574 001002 BNE 71\$;BRANCH IF NOT ANTICIPATED.
 3162 013576 000161 000044 JMP 44(R1) ;IF IT WAS ANTICIPATED RETURN.
 3163
 3164 :THE FPS ERROR WAS NOT ANTICIPATED SO REPORT FPS INCORRECT HERE.
 3165 013602 71\$: 72\$: ERROR +52 ;FPS X
 3166 013602 104052 BR 54\$
 3167 013604 000751
 3168
 3169 :REPORT FEC INCORRECT:
 3170 013606 016137 000036 001256 75\$: MOV 36(R1),\$TMP12
 3171 013614 010537 001254 MOV R5,\$TMP11
 3172 013620 104053 76\$: ERROR +53 ;FEC X
 3173 013622 000742 BR 54\$
 3174 013624 177777 177777 260\$: .WORD -1,-1,-1,-1
 3175 013634 013634 250\$: RSETUP
 3176 104412
 3177 :GO INITIALIZE THE FPS AND STACK; AND
 3178 :SEE IF THE USER HAS EXPRESSED
 3179 :THE DESIRE TO CHANGE THE SOFTWARE
 3180 :VIRTUAL CONSOLE SWITCH REGISTER (HAS
 3181 :THE USER TYPED CONTROL G?).
 3182

3181

.SBTTL TEST # 14 - STCFD WITH ILLEGAL ACCUMULATOR TEST

:***** TEST 14 STCFD WITH ILLEGAL ACCUMULATOR TEST

:* THIS TEST STCFD WITH ILLEGAL AC 6.

:*

:*****

013636 000004

TST14: SCOPE

3182 3183 013640 012737 013646 001110 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002

3184 013646 012700 040000 200\$: MOV #40000,RO ;DISSABLE INTERRUPTS.

3185 013652 170100 LDFPS R0

3186 013654 012737 013662 001236 210\$: MOV #210\$,STMP2 ;THIS TEST INSTRUCTION SHOULD CAUSE AN ERROR.

3187 013662 176006 STCFD AC0,AC6

3188 3189 013664 170204 STFPS R4 ;GET FPS.

3190 013666 170305 STST R5 ;GET FEC.

3191 013670 020427 CMP R4,#140000 ;IS FPS CORRECT?

3192 013674 001004 BNE 220\$;BRANCH IF INCORRECT FPS.

3193 013676 022705 CMP #2,R5 ;IS FEC CORRECT?

3194 013702 001010 BNE 230\$;BRANCH IF INCORRECT.

3195 013704 000415 BR 240\$

3196 3197 :REPORT FPS INCORRECT AFTER USE OF ILLEGAL ACCUMULATOR.

3198 013706 010437 001242 220\$: MOV R4,STMP4

3199 013712 012737 140000 001240 MOV #140000,STMP3

3200 013720 104062 ERROR +62 ;BUT FDST ST767 X TO 567 INTO 577

3201 013722 000406 BR 240\$

3202 3203 :REPORT FEC INCORRECT AFTER USE OF ILLEGAL ACCUMULATOR.

3204 013724 010537 001242 230\$: MOV R5,STMP4

3205 013730 012737 000002 001240 MOV #2,STMP3

3206 013736 104063 ERROR +63 ;FEC<---2 ST577 X

3207 013740 013740 104412 240\$: RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

3213

SBTTL TEST # 15 - CLRD TEST

*TEST 15 CLRD TEST
*
*THIS IS A TEST OF THE CRLF AND CLRD INSTRUCTIONS.

3214	013742	000004			IST15: SCOPE			
3215	013744	012737	013752	001110	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	
3216	013752	012700	014136		MOV	#210\$,R0	:SET UP OUTPUT BUFFER	
3217	013756	012701	014126		MOV	#220\$,R1		
3218	013762	012702	000004		MOV	#4,R2		
3219	013766	012021			1\$: MOV	(R0)+,(R1)+		
3220	013770	077202			SOB	R2,1\$		
3221	013772	012700	014126		MOV	#220\$,R0	:SET UP DESTINATION OPERAND ADDRESS.	
3222	013776	012701	000213		MOV	#213,R1	:SET UP FPS.	
3223	014002	170101			LDFPS	R1		
3224	014004	012737	014012	001236	MOV	#2\$,STMP2		
3225	014012	170410			CLRD	(R0)	:TEST INSTRUCTION.	
3226	014014	170205			STFPS	R5		
3227	014016	012702	000004		MOV	#4,R2	:GET FPS.	
3228	014022	012701	014126		MOV	#220\$,R1	:SEE IF RESULT CLEAR, 0.	
3229	014026	005721			TST	(R1)+		
3230	014030	001010			BNE	230\$:BRANCH IF RESULT INCORRECT, NOT 0.	
3231	014032	077203			SOB	R2,3\$		
3232	014034	022705	000204		CMP	#204,R5	:SEE IF FPS IS CORRECT.	
3233	014040	001014			BNE	240\$:BRANCH IF INCORRECT.	
3234	014042	020027	014126		CMP	R0,#220\$:SEE IF R0 IS CORRECT.	
3235	014046	001020			BNE	250\$:BRANCH IF R0 IS INCORRECT.	
3236	014050	000442			BR	260\$		
3237								
3238					:RESULT NOT 0, REPORT ERROR.			
3239	014052	012737	014126	001240	230\$: MOV	#220\$,STMP3		
3240	014060	012737	014146	001242	MOV	#270\$,STMP4		
3241	014066	104064			ERROR	+64	:BAD DATA = 0 X 11+ZERO ST770 X	
3242	014070	000432			BR	260\$		
3243								
3244					:REPORT FPS INCORRECT:			
3245	014072	010437	001242		MOV	R4,STMP4		
3246	014076	012737	000204	001240	MOV	#204,STMP3		
3247	014104	104065			ERROR	+65		
3248	014106	000423			BR	260\$:BAD FPS	
3249								
3250					:REPORT R0 INCORRECT.			
3251	014110	010037	001242		MOV	R0,STMP4		
3252	014114	012737	014126	001240	MOV	#220\$,STMP3		
3253	014122	104066			ERROR	+66		
3254	014124	000414			BR	260\$		
3255								
3256					:THIS IS THE TEST DATA BUFFER, OUTPUT DATA BUFFER.			
3257	014126	073475			220\$: 73475			
3258	014130	067707			67707			
3259	014132	127347			127347			
3260	014134	056770			56770			
3261	014136	073475			:THIS IS THE DATA USED TO SET UP THE OUTPUT BUFFER.			
3262					210\$: 73475			

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE { 5
TEST # 15 - CLRD TEST

SEQUENCE 63

3263 014140 067707
3264 014142 127347
3265 014144 056770
3266
3267 014146 000000
3268 014150 000000
3269 014152 000000
3270 014154 000000
3271 014156 104412

67707

127347

56770

:THIS IS THE EXPECTED DATA, RESULT:

270\$: 0

0

0

0

260\$: RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

3277

.SBTTL TEST # 16 - CLR D WITH ILLEGAL ACCUMULATOR TEST

*:TEST 16 CLR D WITH ILLEGAL ACCUMULATOR TEST
*:THIS IS A TEST OF CLR D WITH ILLEGAL AC7.

014160 000004 TST16: SCOPE
3278 014162 012737 014170 001110 200S: MOV #200\$,SLPERR :SET UP THE LOOP ON ERROR ADDRESS. :DPM002
3279 014170 012700 040200 001236 MOV #40200,R0 ;SET UP THE FPS, NO INTERRUPTS AND FD-1.
3280 014174 170100 LDFPS R0
3281 014176 012737 014204 001236 MOV #210\$,STMP2
3282 014204 170407 CLRD AC7 ;TEST INSTRUCTION.
3283
3284 014206 170204 STFPS R4 ;GET FPS.
3285 014210 170305 STST R5 ;GET FEC.
3286 014212 020427 140200 CMP R4,#140200 ;IS THE FPS CORRECT?
3287 014216 001004 BNE 220\$;BRANCH IF FPS IS INCORRECT.
3288 014220 022705 000002 CMP #2,R5 ;IS THE FEC CORRECT?
3289 014224 001010 BNE 230\$;BRANCH IF FEC IS INCORRECT.
3290 014226 000415 BR 240\$
3291
3292 :REPORT INCORRECT FPS:
3293 014230 010437 001242 220S: MOV R4,STMP4
3294 014234 012737 140200 001240 MOV #140200,STMP3
3295 014242 104067 ERROR +67 ;BUT FDST ST 700X TO 607 INTO 677
3296 014244 000406 BR 240\$
3297
3298 :REPORT INCORRECT FEC:
3299 014246 010537 001242 230S: MOV R5,STMP4
3300 014252 012737 000002 001240 MOV #2,STMP3
3301 014260 104070 ERROR +70 ;FEC<--2 ST 677 X
3302 014262 014412 240S: RSETUP
:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

3311

.SBTTL TEST # 17 - NEGF, ABSF & TSTF SRC MD 0 WITH ILLGL AC7
 :*****
 :*TEST 17 NEGF, ABSF & TSTF SRC MD 0 WITH ILLGL AC7
 :*
 :*THIS IS A TEST OF THE SPECIAL
 :*DEST FLOWS USING THE NEGD INST
 :*WITH MODE ZERO AND ILLEGAL
 :*AC7.
 :*
 :*****

014264	000004				TST17: SCOPE			
3312 014266	012737	014274	001110		200S: MOV #200\$,\$LPERR	;SET UP THE LOOP ON ERROR ADDRESS.		:DP#002
3313 014274	012700	040200			MOV #40200,R0	;SET UP THE FPS, FID=1 AND FD=1.		
3314 014300	170100				LDFPS R0			
3315 014302	012737	014310	001236		MOV #210\$,STMP2			
3316								
3317 014310	170707				210\$: NEG D AC7	;TEST INSTRUCTION.		
3318								
3319 014312	170204				STFPS R4	;GET FPS.		
3320 014314	170305				STST R5	;GET FEC.		
3321								
3322 014316	022704	140200			CMP #140200,R4	;IS FPS CORRECT?		
3323 014322	001004				BNE 220\$;BRANCH IF FPS IS INCORRECT.		
3324 014324	022705	000002			CMP #2,R5	;IS FEC CORRECT?		
3325 014330	001010				BNE 230\$;BRANCH IF FEC IS INCORRECT.		
3326 014332	000416				BR 240\$			
3327								
3328					:REPORT INCORRECT FPS:			
3329 014334	012737	140200	001240		220\$: MOV #140200,STMP3			
3330 014342	010437	001242			MOV R4,STMP4			
3331 014346	104176				ERROR +1\$6			
3332 014350	000407				BR 240\$:FPS BAD		
3333								
3334					:REPORT FEC INCORRECT:			
3335 014352	012737	000002	001240		230\$: MOV #2,STMP3			
3336 014360	010537	001242			MOV R5,STMP4			
3337 014364	104377				ERROR +3\$7			
3338 014366	000044				.WORD 44	:FEC BAD		
3339 014370	014370	104412			240\$: RSETUP			
						:GO INITIALIZE THE FPS AND STACK; AND		
						:SEE IF THE USER HAS EXPRESSED		
						:THE DESIRE TO CHANGE THE SOFTWARE		
						:VIRTUAL CONSOLE SWITCH REGISTER (HAS		
						:THE USER TYPED CONTROL G?).		

3347

.SBTTL TEST # 20 - NEGF, ABSF & TSTF SRC MODE 0 TEST

TEST 20 NEGFB, ABSFB & TSTFB SRC MODE 0 TEST

*THIS IS A TEST THE NEGF, ABSF AND TSTF
*SOURCE FLOWS. THE NEGD INSTRUCTION
*IS USED TO TEST MODE 0

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 27-1
TEST # 20 - NEGF, ABSF & TSTF SRC MODE 0 TEST

SEQUENCE 67

3395	014560	111213		111213
3396	014562	000000	220\$:	0
3397	014564	000000		0
3398	014566	000000		0
3399	014570	000000		0
3400				
3401	014572	177777	240\$:	-1
3402	014574	177777		-1
3403	014576	177777		-1
3404	014600	177777		-1
3405	014602	000000	280\$:	0
3406	014604	000000		0
3407	014606	161710		161710
3408	014610	111213		111213
3409				
3410	014612		270\$:	RSETUP
	014612	104412		:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).

3411

.SBTTL TEST # 21 - NEGF, ABSF & TSTF SRC MODE 1

TEST 21 NEGF, ABSF & TSTF SRC MODE 1*
*THIS IS A TEST THE NEGF, ABSF AND TSTF
*SOURCE FLOWS. THE NEGD INSTRUCTION
*IS USED TO TEST MODE 1
*

014614 000004	014616 012737 014624 001110	TST21: SCOPE			
3412 014616 012737 014624 001110	200\$: MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.			
3413 014624 012700 014732	MOV #210\$,R0	;SET UP THE DATA BUFFER.			
3414 014630 012701 014762	MOV #220\$,R1				
3415 014634 012702 000004	MOV #4,R2				
3416 014640 012021	MOV (R0)+,(R1)+				
3417 014642 077202	S08 R2,1\$				
3418 014644 012700 000200	MOV #200,R0	:SET FD MODE.			
3419 014650 170100	LDFPS R0				
3420 014652 012700 014762	MOV #220\$,R0	:SET UP THE OPERAND ADDRESS.			
3421 014656 012737 014672 001236	MOV #230\$,\$TMP2				
3422 014664 012737 014772 000004	MOV #240\$,ERRVECT	:SET UP VECTOR 4 IN CASE OF ERROR.			
3423 014672 170710	NEGD (R0)	;TEST INSTRUCTION.			
3424					
3425 014674 170205	STFPS R5	:GET FPS.			
3426 014676 012701 014762	MOV #220\$,R1	;SEE IF RESULT IS CORRECT.			
3427 014702 012702 000004	MOV #4,R2				
3428 014706 005721	TST (R1)+				
3429 014710 001046	BNE 250\$:BRANCH IF NOT CORRECT.			
3430 014712 077203	S08 R2,2\$				
3431					
3432 014714 020027 014762	CMP R0,#220\$:IS R0 CORRECT?			
3433 014720 001055	BNE 260\$:BRANCH IF NOT CORRECT.			
3434 014722 022705 000204	CMP #204,R5	:IS THE FPS CORRECT?			
3435 014726 001061	BNE 270\$:BRANCH IF NOT CORRECT.			
3436 014730 000466	BR 280\$				
3437					
3438		:THESE ARE TEST DATA TABLES AND A BUFFER.			
3439 014732 000177	210\$: 177				
3440 014734 167574		167574			
3441 014736 137271		137271			
3442 014740 107675		107675			
3443 014742 000000	214\$: 0				
3444 014744 000000		0			
3445 014746 000000		0			
3446 014750 000000		0			
3447 014752 177777		-1			
3448 014754 177777		-1			
3449 014756 177777		-1			
3450 014760 177777	220\$: -1				
3451 014762 177777		-1			
3452 014764 177777		-1			
3453 014766 177777		-1			
3454 014770 177777		-1			
3455					
3456		:IF A TRAP TO 4 OCCURS COME HERE:			
3457 014772 011602 014674	240\$: MOV (SP),R2	:SEE IF THE TRAP OCCURRED ON THE TEST INSTR.			
3458 014774 020227	CMP R2,#230\$+2				

3488

SBTTL TEST # 22 - NEGF, ABSF & TSTF SRC MODE 2 TEST

 TEST 22 NEGF, ABSF & TSTF SRC MODE 2 TEST

*THIS IS A TEST THE NEGF, ABSF AND TSTF
 *SOURCE FLOWS. THE ABSD INSTRUCTION
 *IS USED TO TEST MODE 2

TST22: SCOPE

3489 015110 000004	015112 012737	015120 001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
3490 015120 012700	015226		MOV	#210\$,R0	;SET UP THE DATA BUFFER.	
3491 015124 012701	015256		MOV	#220\$,R1		
3492 015130 012702	000004		MOV	#4,R2		
3493 015134 012021			MOV	(R0)+,(R1)+		
3494 015136 077202			S0B	R2,1\$		
3495 015140 012700	000200		MOV	#200,R0	;SET FD.	
3496 015144 170100			LDFPS	R0		
3497 015146 012700	015256	001236	MOV	#220\$,R0	;SET UP THE OPERAND ADDRESS.	
3498 015152 012737	015166		MOV	#230\$,STMP2		
3499 015160 012737	015266	000004	MOV	#240\$,ERRVECT	;SET UP VECTOR 4 IN CASE OF AN ERROR.	
3500						
3501 015166 170620			230\$: ABSD	(R0)+	;TEST INSTRUCTION.	
3502						
3503 015170 170205			STFPS	R5	;GET FPS.	
3504 015172 012701	015256		MOV	#220\$,R1	;CHECK RESULT.	
3505 015176 012702	000004		MOV	#4,R2		
3506 015202 005721			TST	(R1)+		
3507 015204 001046			BNE	250\$;BRANCH IF INCORRECT.	
3508 015206 077203			S0B	R2,2\$		
3509						
3510 015210 020027	015266		CMP	R0,#220\$+10	;IS R0 CORRECT?	
3511 015214 001055			BNE	260\$;BRANCH IF INCORRECT.	
3512 015216 022705	000204		CMP	#204,RS	;IS THE FPS CORRECT?	
3513 015222 001061			BNE	270\$;BRANCH IF INCORRECT.	
3514 015224 000466			BR	280\$		
3515						
3516			;THESE ARE TEST DATA TABLES AND DATA BUFFER.			
3517 015226 000177			210\$: 177			
3518 015230 167574			167574			
3519 015232 137271			137271			
3520 015234 107675			107675			
3521 015236 000000			290\$: 0			
3522 015240 000000			0			
3523 015242 000000			0			
3524 015244 000000			0			
3525 015246 177777			-1			
3526 015250 177777			-1			
3527 015252 177777			-1			
3528 015254 177777			-1			
3529 015256 177777			-1			
3530 015260 177777			-1			
3531 015262 177777			-1			
3532 015264 177777			-1			
3533						
3534			;IF A TRAP TO 4 OCCURS COME HERE.			
3535 015266 011602			240\$: MOV	(SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	

3536	015270	020227	015170		CMP	R2,#230\$+2	
3537	015274	001405			BEQ	3\$;BRANCH IF YES.
3538	015276	020227	015172		CMP	R2,#230\$+4	
3539	015302	001402			BEQ	3\$;BRANCH IF YES.
3540	015304	000137	051774		JMP	(PSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.	
3541				:REPORT	AN FDST	FLOW FAILURE RESULTED IN A TRAP TO 4.	
3542	015310	022626		:SS:	CMP	(SP)+,(SP)+	
3543	015312	010237	001236		MOV	R2,STMP2	
3544	015316	104076			ERROR	+76	;ODD ADRES
3545	015320	000430			BR	280\$;BUT FDSTX IN ST 771
3546							
3547				:REPORT	RESULT	INCORRECT:	
3548	015322	012737	015236	001240	:250\$:	MOV	#290\$,STMP3
3549	015330	012737	015226	001242		MOV	#210\$,STMP4
3550	015336	012737	015256	001244		MOV	#220\$,STMP5
3551	015344	104077			ERROR	+77	;BAD DATA X11*0 ST 312X
3552	015346	000415			BR	280\$	
3553							
3554				:REPORT	RO	INCORRECT:	
3555	015350	012737	015262	001240	:260\$:	MOV	#220\$+4,STMP3
3556	015356	010037		001242		MOV	RO,STMP4
3557	015362	104100			ERROR	+100	;RO BADX
3558	015364	000406			BR	280\$	
3559							
3560				:REPORT	FPS	INCORRECT:	
3561	015366	010537	001240		:270\$:	MOV	R5,STMP3
3562	015372	012737	000204	001244		MOV	#204,STMP5
3563	015400	104101			ERROR	+101	;FPS X
3564							
3565	015402				280\$:	RSE TUP	
	015402	104412					:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).

3566

.SBTTL TEST # 23 - NEGF, ABSF & TSTF SRC MODE 4 TEST

;*:***** TEST 23 NEGF, ABSF & TSTF SRC MODE 4 TEST

;*: THIS IS A TEST THE NEGF, ABSF AND TSTF
 ;*: SOURCE FLOWS. THE ABSD INSTRUCTION
 ;*: IS USED TO TEST MODE 4

;*:***** TST23: SCOPE

3567 015404 000004	015406 012737 015414 001110	200\$: MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	.DPM002
3568 015414 012700 015522		MOV #210\$,R0	:SET UP THE DATA BUFFER.	
3569 015420 012701 015542		MOV #220\$,R1		
3570 015424 012702 000004		MOV #4,R2		
3571 015430 012021		MOV (R0)+,(R1)+		
3572 015432 077202		SOB R2,1\$		
3573 015434 012700 000200		MOV #200,R0	:SET FD.	
3574 015440 170100		LDFPS R0		
3575 015442 012700 015552	001236	MOV #230\$,R0	:SET UP THE OPERAND ADDRESS.	
3576 015446 012737 015462		MOV #240\$,\$TMP2		
3577 015454 012737 015562	000004	MOV #250\$,ERRVECT	:SET UP VECTOR 4 IN CASE OF AN ERROR.	
3578				
3579 015462 170640		240\$: ABSD -(R0)	:TEST INSTRUCTION.	
3580				
3581 015464 170205		STFPS R5	:GET FPS.	
3582 015466 012701 015542	000004	MOV #220\$,R1	:CHECK RESULT.	
3583 015472 012702		MOV #4,R2		
3584 015476 005721		TST (R1)+		
3585 015500 001046		BNE 260\$:BRANCH IF INCORRECT.	
3586 015502 077203		SOB R2,2\$		
3587				
3588 015504 020027 015542		CMP R0,#220\$:IS R0 CORRECT?	
3589 015510 001055	000204	BNE 270\$:BRANCH IF INCORRECT.	
3590 015512 022705		CMP #204,R5	:IS THE FPS CORRECT?	
3591 015516 001061		BNE 280\$:BRANCH IF INCORRECT.	
3592 015520 000466		BR 290\$		
3593				
3594		;THESE ARE TEST DATA TABLES AND DATA BUFFER.		
3595 015522 000177		210\$: 177		
3596 015524 117273		117273		
3597 015526 147576		147576		
3598 015530 177071		177071		
3599 015532 000000		300\$: 0		
3600 015534 000000		0		
3601 015536 000000		0		
3602 015540 000000		0		
3603 015542 177777		220\$: -1		
3604 015544 177777		-1		
3605 015546 177777		-1		
3606 015550 177777		-1		
3607 015552 177777		230\$: -1		
3608 015554 177777		-1		
3609 015556 177777		-1		
3610 015560 177777		-1		
3611				
3612		;IF A TRAP TO 4 OCCURS COME HERE.		
3613 015562 011602		250\$: MOV (SP),R2	:SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	

3644

.SBTTL TEST # 24 - NEGF, ABSF & TSTF SRC MODE 3 TEST

:*****
: TEST 24 NEGF, ABSF & TSTF SRC MODE 3 TEST

:
: THIS IS A TEST THE NEGF, ABSF AND TSTF
: SOURCE FLOWS. THE ABSD INSTRUCTION
: IS USED TO TEST MODE 3

:*****
: TST24: SCOPE

3645 015700 000004	015702 012737 015710 001110	200\$: MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
3646 015710 012700 016016	016016	MOV #210\$,R0	;SET UP THE DATA BUFFER.	
3647 015714 012701 016046		MOV #220\$,R1		
3648 015720 012702 000010		MOV #10,R2		
3649 015724 012021		MOV (R0)+,(R1)+		
3650 015726 077202		S0B R2,1\$		
3651 015730 012700 000200		MOV #200,R0	;SET FD.	
3652 015734 170100		LDFPS R0		
3653 015736 012700 016056	001236	MOV #230\$,R0	;SET UP THE OPERAND ADDRESS.	
3654 015742 012737 015756	016066	MOV #240\$,STMP2		
3655 015750 012737 016066	000004	MOV #250\$,ERRVECT	;SET UP VECTOR 4 IN CASE OF AN ERROR.	
3656				
3657 015756 170630		240\$: ABSD a(R0)+	;TEST INSTRUCTION.	
3658				
3659 015760 170205		STFPS R5	;GET FPS.	
3660 015762 012701 016046	000004	MOV #220\$,R1	;CHECK RESULT.	
3661 015766 012702		MOV #4,R2		
3662 015772 005721		TST (R1)+		
3663 015774 001052		BNE 260\$;BRANCH IF INCORRECT.	
3664 015776 077203		S0B R2,2\$		
3665 016000 020027 016060		CMP R0,#230\$+2	;IS R0 CORRECT?	
3666 016004 001061		BNE 270\$;BRANCH IF INCORRECT.	
3667 016006 022705 000204		CMP #204,R5	;IS THE FPS CORRECT?	
3668 016012 001065		BNE 280\$;BRANCH IF INCORRECT.	
3669 016014 000472		BR 290\$		
3670				
3671		;THESE ARE TEST DATA TABLES AND DATA BUFFER.		
3672 016016 000177		210\$: 177		
3673 016020 147576		147576		
3674 016022 177071		177071		
3675 016024 107576 016046 177777	000000 000000	300\$: 107576,220\$,-1,-1,-1		
3676 016036 000000	000000	220\$: 0,0,0,0		
3677 016046 177777		-1		
3678 016050 177777		-1		
3679 016052 177777		-1		
3680 016054 177777		-1		
3681 016056 177777		230\$: -1		
3682 016060 177777		-1		
3683 016062 177777		-1		
3684 016064 177777		-1		
3685				
3686		;IF A TRAP TO 4 OCCURS COME HERE.		
3687 016066 011602 015760	020227	250\$: MOV (SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	
3688 016070 020227 015762	001405	CMP R2,#240\$+2		
3689 016074 001405	020227	BEQ 3\$;BRANCH IF YES.	
3690 016076 001402	015762	CMP R2,#240\$+4		
3691 016102		BEQ 3\$;BRANCH IF YES.	

CKFPCD0 FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 31-1
TEST # 24 - NEGF, ABSF & TSTF SRC MODE 3 TEST

K 6
SEQUENCE 75

3692 016104 000137 051774 :REPORT JMP CPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.
3693 :REPORT AN FDST FLOW FAILURE RESULTED IN A TRAP TO 4.
3694 016110 022626 :REPORT CMP (SP)+, (SP)+
3695 016112 010237 001236 :REPORT MOV R2, STMP2
3696 016116 104106 :REPORT ERROR +106 ;ODD ADRES
3697 016120 000430 :REPORT BR 290\$;BUT FDSTX IN ST 771
3698
3699 :REPORT RESULT INCORRECT:
3700 016122 012737 016036 001240 260\$: :REPORT MOV #300\$, STMP3
3701 016130 012737 016016 001242 :REPORT MOV #210\$, STMP4
3702 016136 012737 016046 001244 :REPORT MOV #220\$, STMP5
3703 016144 104110 :REPORT ERROR +110 ;BAD DATA X11*0 ST 3127
3704 016145 000415 :REPORT BR 290\$
3705
3706 :REPORT RO INCORRECT:
3707 016150 012737 016060 001240 270\$: :REPORT MOV #230\$+2, STMP3
3708 016156 010037 001242 :REPORT MOV RO, STMP4
3709 016162 104111 :REPORT ERROR +111 ;RO INCORRECT.
3710 016164 000406 :REPORT BR 290\$
3711 :REPORT FPS INCORRECT:
3712 016166 010537 001240 280\$: :REPORT MOV R5, STMP3
3713 016172 012737 000204 001244 :REPORT MOV #204, STMP5
3714 016200 104112 :REPORT ERROR +112 ;FPSX
3715
3716 016202 016202 104412 290\$: :REPORT RSETUP
:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

3717

.SBTTL TEST # 25 - NEGF, ABSF & TSTF SRC MODE 5 TEST

;***** TEST 25 NEGF, ABSF & TSTF SRC MODE 5 TEST *****

;* THIS IS A TEST THE NEGF, ABSF AND TSTF
 ;* SOURCE FLOWS. THE NEGD INSTRUCTION
 ;* IS USED TO TEST MODE 5

;*****

016204	000004			TST25: SCOPE				
3718 016206	012737	016214	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.		
3719 016214	012700	016322		MOV	#210\$,R0	;SET UP THE DATA BUFFER.	:DPM002	
3720 016220	012701	01635?		MOV	#220\$,R1			
3721 016224	012702	000010		MOV	#10,R2			
3722 016230	012021			MOV	(R0) + , (R1) +			
3723 016232	077202			S0B	R2,1\$			
3724 016234	012700	000200		MOV	#200,R0	;SET FD.		
3725 016240	170100			LDFPS	R0			
3726 016242	012700	016364		MOV	#230\$+2,R0	;SET UP THE OPERAND ADDRESS.		
3727 016246	012737	016262	001236	MOV	#240\$,STMP2			
3728 016254	012737	016372	000004	MOV	#250\$,ERRVECT	;SET UP VECTOR 4 IN CASE OF AN ERROR.		
3729								
3730 016262	170750			240\$: NEGD	a-(R0)	;TEST INSTRUCTION.		
3731								
3732 016264	170205			STFPS	R5	;GET FPS.		
3733 016266	012701	016352		MOV	#220\$,R1	;CHECK RESULT.		
3734 016272	012702	000004		MOV	#4,R2			
3735 016276	005721			TST	(R1) +			
3736 016300	001052			BNE	260\$;BRANCH IF INCORRECT.		
3737 016302	077203			S0B	R2,2\$			
3738 016304	020027	016362		CMP	R0,#230\$;IS R0 CORRECT?		
3739 016310	001061			BNE	270\$;BRANCH IF INCORRECT.		
3740 016312	022705	000204		CMP	#204,R5	;IS THE FPS CORRECT?		
3741 016316	001065			BNE	280\$;BRANCH IF INCORRECT.		
3742 016320	000472			BR	290\$			
3743								
3744				;THESE ARE TEST DATA TABLES AND DATA BUFFER.				
3745 016322	000176			210\$: 176				
3746 016324	177074			177074				
3747 016326	127374			127374				
3748 016330	157677	016352	177777	300\$: 157677,220\$,-1,-1,-1				
3749 016342	000000			0				
3750 016344	000000			0				
3751 016346	000000			0				
3752 016350	000000			0				
3753 016352	177777			220\$: -1				
3754 016354	177777			-1				
3755 016356	177777			-1				
3756 016360	177777			-1				
3757 016362	177777			230\$: -1				
3758 016364	177777			-1				
3759 016366	177777			-1				
3760 016370	177777			-1				
3761								
3762				;IF A TRAP TO 4 OCCURS COME HERE.				
3763 016372	011602			250\$: MOV	(SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.		
3764 016374	020227	016264		CMP	R2,#240\$+2			

3765 016400 001405				BEQ	3\$:BRANCH IF YES.
3766 016402 020227	016266			CMP	R2,#240\$+4	
3767 016406 001402	-			BEO	3\$:BRANCH IF YES.
3768 016410 000137	051774			JMP	CPSPUR	; OTHERWISE GO REPORT SPURIOUS TRAP TO 4.
3769					FLOW FAILURE RESULTED IN A TRAP TO 4.	
3770 016414 022626				:REPORT	AN FDST	
3771 016416 010237	001236			3\$:	(SP)+, (SP)+	
3772 016422 104113				MOV	R2,\$TMP2	
3773 016424 000430				ERROR	+113	:ODD ADRES
				BR	290\$; BUT FDSTX IN ST 771
3774						
3775						
3776 016426 012737	016342	001240		:REPORT	RESULT INCORRECT:	
3777 016434 012737	016322	001242		260\$:	MOV #300\$, \$TMP3	
3778 016442 012737	016352	001244			MOV #210\$, \$TMP4	
3779 016450 104114					MOV #220\$, \$TMP5	
3780 016452 000415				ERROR	+114	;BAD DATA X11*0 ST 3127
3781				BR	290\$	
3782						
3783 016454 012737	016362	001240		:REPORT	RO INCORRECT:	
3784 016462 010037	001242			270\$:	MOV #230\$, \$TMP3	
3785 016466 104115					MOV RO, \$TMP4	
3786 016470 000406				ERROR	+115	:RO BADX
3787				BR	290\$	
3788 016472 010537	001240			:REPORT	FPS INCORRECT:	
3789 016476 012737	000204	001244		280\$:	MOV R5, \$TMP3	
3790 016504 104116					MOV #204, \$TMP5	
3791				ERROR	+116	:FPSX
3792 016506						
016506 104412				290\$:	RSETUP	
						:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).

3793

.SBTTL TEST # 26 - NEGF, ABSF AND TSTF SRC MODE 6 TEST

:*****
 :TEST 26 NEGF, ABSF AND TSTF SRC MODE 6 TEST

:*
 :*THIS IS A TEST THE NEGF, ABSF AND TSTF
 :*SOURCE FLOWS. THE ABSD INSTRUCTION
 :*IS USED TO TEST MODE 5

:*****

3794 016510 000004	162370	TST26: SCOPE		
3795 016512 012767 016520	016630	.DSABL	AMA	:DISABLE MODE 6 TO MODE 3 CONVERSIONS
3796 016520 012700	016630	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.
3797 016524 012701	016652	MOV	#210\$,R0	:SET UP THE DATA BUFFER.
3798 016530 012702	000004	MOV	#220\$,R1	
3799 016534 012021		MOV	#4,R2	
3800 016536 077202		(R0)+,(R1)+		
3801 016540 012700	000200	S0B	R2,1\$	
3802 016544 170100		MOV	#200,R0	:SET FD.
3803 016546 012700	016643	LDFPS	R0	
3804 016552 012767	016566	MOV	#220\$-7,R0	:SET UP THE OPERAND ADDRESS.
3805 016560 012767	016672	MOV	#230\$,SIMP2	
3806		MOV	#240\$,ERRVECT	:SET UP VECTOR 4 IN CASE OF AN ERROR.
3807 016546 170660	000007	230\$: ABSD	7(R0)	:TEST INSTRUCTION.
3808		STFPS	R5	
3809 016572 170205		MOV	#220\$,R1	:GET FPS.
3810 016574 012701	016652	MOV	#4,R2	:CHECK RESULT.
3811 016600 012702	000004	2\$: TST	(R1)+	
3812 016604 005721		BNE	250\$:BRANCH IF INCORRECT.
3813 016606 001047		S0B	R2,2\$	
3814 016610 077203		CMP	R0,#220\$-7	:IS R0 CORRECT?
3815 016612 020027	016643	BNE	260\$:BRANCH IF INCORRECT.
3816 016616 001056		CMP	#204,R5	:IS THE FPS CORRECT?
3817 016620 022705	000204	BNE	270\$:BRANCH IF INCORRECT.
3818 016624 001062		BR	280\$	
3819 016626 000467				
3820				
3821				:THESE ARE TEST DATA TABLES AND DATA BUFFER.
3822 016630 000177		210\$: 177		
3823 016632 161524		161524		
3824 016634 131273		131273		
3825 016636 107174	000000	107174.		
3826 016642 000000		290\$: 0		
3827 016644 000000		0		
3828 016646 000000		0		
3829 016650 000000		0		
3830 016652 177777		220\$: -1		
3831 016654 177777		-1		
3832 016656 177777		-1		
3833 016660 177777		-1		
3834 016662 177777		-1		
3835 016664 177777		-1		
3836 016666 177777		-1		
3837 016670 177777		-1		
3838				
3839				:IF A TRAP TO 4 OCCURS COME HERE.
3840 016672 011602		240\$: MOV (SP),R2		:SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.

3841 016674 020227	016570	CMP R2,#230\$+2	
3842 016700 001405		BEQ 3\$;BRANCH IF YES.
3843 016702 020227	016572	CMP R2,#230\$+4	
3844 016706 001402		BEQ 3\$;BRANCH IF YES.
3845 016710 000167	033060	JMP CPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.	
3846		AN FDST FLOW FAILURE RESULTED IN A TRAP TO 4.	
3847 016714 022626		CMP (SP)+,(SP)+	
3848 016716 010267	162314	MOV R2,\$TMP2	
3849 016722 104117		ERROR +117	;ODD ADRES
3850 016724 000422		BR 270\$;BUT FDSTX IN ST 771
3851			
3852			
3853 016726 012767	016642 162304	:REPORT 250\$: RESULT INCORRECT:	
3854 016734 012767	016630 162300	MOV #290\$,TMP3	
3855 016742 012767	016652 162274	MOV #210\$,TMP4	
3856 016750 104120		MOV #220\$,TMP5	
3857 016752 000407		ERROR +120	;BAD DATA X11*0 ST 3127
3858		BR 270\$	
3859			
3860 016754 012767	016643 162256	:REPORT 260\$: RO INCORRECT:	
3861 016762 010067	162254	MOV #220\$-7,TMP3	
3862 016766 104124		MOV RO,TMP4	
3863 016770 000400		ERROR +124	;RO BADX
3864		BR 270\$	
3865 016772 010567	162242	:REPORT 270\$: FPS INCORRECT:	
3866 016776 012767	000204 162240	MOV R5,TMP3	
3867 017004 104122		MOV #204,TMP5	
3868 017006 017006	104412	ERROR +122	;FPSX
		RSETUP	
3869		.ENABL AMA	:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?). ;REENABLE MODE 6 TO MODE 3 CONVERSIONS

3870

.SBTTL TEST # 27 - NEGF, ABSF AND TSTF SRC MODE 7 TEST

;***** TEST 27 NEGF, ABSF AND TSTF SRC MODE 7 TEST

;*THIS IS A TEST THE NEGF, ABSF AND TSTF
;*SOURCE FLOWS. THE ABSD INSTRUCTION
;*IS USED TO TEST MODE 6

;*****

017010 000004			TST27: SCOPE				
3871 017012 012737	017020	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.		
3872 017020 012700	017130			#210\$,R0	;SET UP THE DATA BUFFER.		:DPM002
3873 017024 012701	017160			MOV #220\$,R1			
3874 017030 012702	000010			MOV #10,R2			
3875 017034 012021			1\$: MOV	(R0)+,(R1)+			
3876 017036 077202				SOB R2,1\$			
3877 017040 012700	000200			MOV #200,R0	;SET FD.		
3878 017044 170100				LDFPS R0			
3879 017046 012700	017161			MOV #230\$-7,R0	;SET UP THE OPERAND ADDRESS.		
3880 017052 012737	017066	001236		MOV #240\$,\$IMP2			
3881 017060 012737	017200	000004		MOV #250\$,ERRVECT	;SET UP VECTOR 4 IN CASE OF AN ERROR.		
3882							
3883 017066 170770	000007		240\$: NEGD	#7(R0)	;TEST INSTRUCTION.		
3884							
3885 017072 170205				STFPS R5	;GET FPS.		
3886 017074 012701	017160			MOV #220\$,R1	;CHECK RESULT.		
3887 017100 012702	000004			MOV #4,R2			
3888 017104 005721			2\$: TST	(R1)+			
3889 017106 001052				BNE 260\$;BRANCH IF INCORRECT.		
3890 017110 077203				SOB R2,2\$			
3891 017112 020027	017161			CMP R0,#230\$-7	;IS R0 CORRECT?		
3892 017116 001061				BNE 270\$;BRANCH IF INCORRECT.		
3893 017120 022705	000204			CMP #204,R5	;IS THE FPS CORRECT?		
3894 017124 001065				BNE 280\$;BRANCH IF INCORRECT.		
3895 017126 000472				BR 290\$			
3896							
3897					:THESE ARE TEST DATA TABLES AND DATA BUFFER.		
3898 017130 000177			210\$: 177				
3899 017132 167574				167574			
3900 017134 137271				137271			
3901 017136 107675	017160	177777		107675,220\$,-1,-1,-1			
3902 017150 000000			300\$: 0				
3903 017152 000000				0			
3904 017154 000000				0			
3905 017156 000000				0			
3906 017160 177777			220\$: -1				
3907 017162 177777				-1			
3908 017164 177777				-1			
3909 017166 177777				-1			
3910 017170 177777			230\$: -1				
3911 017172 177777				-1			
3912 017174 177777				-1			
3913 017176 177777				-1			
3914							
3915					:IF A TRAP TO 4 OCCURS COME HERE.		
3916 017200 011602			250\$: MOV (SP),R2		;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.		
3917 017202 020227	017070		CMP R2,#240\$+2				

3918 017206 001405			BEQ	3\$:BRANCH IF YES.
3919 017210 020227	017072		CMP	R2,#240\$+4	
3920 017214 001402			BEQ	3\$:BRANCH IF YES.
3921 017216 000137	051774		JMP	CPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.	
3922		:REPORT	AN FDST	FLOW FAILURE RESULTED IN A TRAP TO 4.	
3923 017222 022626		3\$:	CMP	(SP)+,(SP)+	
3924 017224 010237	001236		MOV	R2,\$TMP2	
3925 017230 104123			ERROR	+123	:ODD ADRES
3926 017232 000430			BR	290\$:BUT FDSTX IN ST 771
3927					
3928					
3929 017234 012737	017150 001240	:REPORT	RESULT	INCORRECT:	
3930 017242 012737	017130 001242	260\$:	MOV	#300\$,TMP3	
3931 017250 012737	017160 001244		MOV	#210\$,TMP4	
3932 017256 104124			MOV	#220\$,TMP5	
3933 017260 000415			ERROR	+124	:BAD DATA X11*0 ST 3127
3934			BR	290\$	
3935					
3936 017262 012737	017161 001240	:REPORT	RO	INCORRECT:	
3937 017270 010037	001242	270\$:	MOV	#230\$-7,\$TMP3	
3938 017274 104125			MOV	RO,\$TMP4	
3939 017276 000406			ERROR	+125	:RO BADX
3940			BR	290\$	
3941 017300 010537	001240	:PORT	FPS	INCORRECT:	
3942 017304 012737	000204 001244	280\$:	MOV	R5,\$TMP3	
3943 017312 104126			MOV	#204,\$TMP5	
3944			ERROR	+126	:FPSX
3945 017314		290\$:	RSETUP		
017314 104412					:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).

3946

.SBTTL TEST # 30 - NEGF, ABSF AND TSTF SRC MODE 6, GR7

* TEST 30 NEGF, ABSF AND TSTF SRC MODE 6, GR7*
* THIS IS A TEST THE NEGF, ABSF AND TSTF
* SOURCE FLOWS. THE NEGD INSTRUCTION
* IS USED TO TEST MODE 6

017316	000004	TST30:	SCOPE				
3947			.DSABL	AMA	:DISABLE MODE 6 TO MODE 3 CONVERSIONS		
3948	017320	012767	017326	161562	MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
3949	017326	012700	017424		MOV #210\$,R0	;SET UP THE DATA BUFFER.	
3950	017332	012701	017444		MOV #220\$,R1		
3951	017336	012702	000004		MOV #4,R2		
3952	017342	012021			MOV (R0)+,(R1)+		
3953	017344	077202			S0B R2,1\$		
3954	017346	012700	000200		MOV #200,R0	:SET FD.	
3955	017352	170100			LDFPS R0		
3956	017354	012767	017370	161654	MOV #230\$,STMP2		
3957	017362	012767	017464	160414	MOV #240\$,ERRVECT	:SET UP VECTOR 4 IN CASE OF AN ERROR.	
3958							
3959	017370	170767	000050		230\$: NEG D 220\$:TEST INSTRUCTION.	
3960							
3961	017374	170205			STFPS R5	:GET FPS.	
3962	017376	012701	017444		MOV #220\$,R1	:CHECK RESULT.	
3963	017402	012702	000004		MOV #4,R2		
3964	017406	005721			TST (R1)+		
3965	017410	001043			BNE 250\$:BRANCH IF INCORRECT.	
3966	017412	077203			S0B R2,2\$		
3967	017414	022705	000204		CMP #204,R5	:IS THE FPS CORRECT?	
3968	017420	001052			BNE 260\$:BRANCH IF INCORRECT.	
3969	017422	000457			BR 270\$		
3970							
3971					:THESE ARE TEST DATA TABLES AND DATA BUFFER.		
3972	017424	000127			210\$: 127		
3973	017426	137475			137475		
3974	017430	147372			147372		
3975	017432	117057			117057		
3976	017434	000000			280\$: 0		
3977	017436	000000			0		
3978	017440	000000			0		
3979	017442	000000			0		
3980	017444	177777			220\$: -1		
3981	017446	177777			-1		
3982	017450	177777			-1		
3983	017452	177777			-1		
3984	017454	177777			-1		
3985	017456	177777			-1		
3986	017460	177777			-1		
3987	017462	177777			-1		
3988							
3989					:IF A TRAP TO 4 OCCURS COME HERE.		
3990	017464	011602			240\$: MOV (SP),R2	:SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	
3991	017466	020227	017372		CMP R2,#230\$+2		
3992	017472	001405			BEQ 35	:BRANCH IF YES.	
3993	017474	020227	017374		CMP R2,#230\$+4		

```

3994 017500 001402      BEQ    3$          :BRANCH IF YES.
3995 017502 000167 032266  JMP    CPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.
3996      :REPORT AN FDST FLOW FAILURE RESULTED IN A TRAP TO 4.
3997 017506 022626      3$:   CMP    (SP)+,(SP)+
3998 017510 010267 161522  MOV    R2,$TMP2
3999 017514 104127      ERROR   +127        :ODD ADRES
4000 017516 000421      BR     270$        :BUT FDSTX IN ST 771
4001
4002
4003 017520 012767 017434 161512 250$: REPORT RESULT INCORRECT:
4004 017526 012767 017424 161506  MOV    #280$,TMP3
4005 017534 012767 017444 161502  MOV    #210$,TMP4
4006 017542 104130      ERROR   +130        ;BAD DATA X11*0 ST 3127
4007 017544 000406      BR     270$        ;FPS INCORRECT:
4008
4009 017546 010567 161466 161464 260$: REPORT FPS INCORRECT:
4010 017552 012767 000204 161464  MOV    R5,$TMP3
4011 017560 104131      MOV    #204,$TMP5
4012
4013 017562 017562 104412 270$: REPORT RSETUP
4014      .ENABL AMA          ERROR   +131        ;FPSX
                                         :GO INITIALIZE THE FPS AND STACK; AND
                                         :SEE IF THE USER HAS EXPRESSED
                                         :THE DESIRE TO CHANGE THE SOFTWARE
                                         :VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                         :THE USER TYPED CONTROL G?).
                                         :REENABLE MODE 6 TO MODE 3 CONVERSIONS

```

4015

.SBTTL TEST # 31 - NEGF, ABSF AND TSTF SRC MODE 7, GR7

;***** TEST 31 NEGF, ABSF AND TSTF SRC MODE 7, GR7 *****

;*THIS IS A TEST THE NEGF, ABSF AND TSTF
;*SOURCE FLOWS. THE ABSD INSTRUCTION
;*IS USED TO TEST MODE 7

;*****

017564	000004			TST31: SCOPE				
4016	017566	012737	017574	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4017	017574	012700	017672		200\$: MOV	#210\$,R0	;SET UP THE DATA BUFFER.	
4018	017600	012701	017722		200\$: MOV	#220\$,R1		
4019	017604	012702	000010		1\$: MOV	#10,R2		
4020	017610	012021			1\$: MOV	(R0)+,(R1)+		
4021	017612	077202			1\$: S0B	R2,1\$		
4022	017614	012700	000200		1\$: MOV	#200,R0	;SET FD.	
4023	017620	170100			1\$: LDFPS	R0		
4024	017622	012737	017636	001236	1\$: MOV	#230\$,STMP2		
4025	017630	012737	017742	000004	1\$: MOV	#240\$,ERRVECT	;SET UP VECTOR 4 IN CASE OF AN ERROR.	
4026					230\$: ABSD	#250\$;TEST INSTRUCTION.	
4027	017636	170677	000070		230\$: STFPS	R5	;GET FPS.	
4028					230\$: MOV	#220\$,R1	;CHECK RESULT.	
4029	017642	170205			230\$: MOV	#4,R2		
4030	017644	012701	017722		230\$: TST	(R1)+		
4031	017650	012702	000004		230\$: BNE	260\$;BRANCH IF INCORRECT.	
4032	017654	005721			230\$: S0B	R2,2\$		
4033	017656	001047			230\$: CMP	#204,R5	;IS THE FPS CORRECT?	
4034	017660	077203			230\$: BNE	270\$;BRANCH IF INCORRECT.	
4035	017662	022705		000204	230\$: BR	280\$		
4036	017666	001056						
4037	017670	000463						
4038								
4039							;THESE ARE TEST DATA TABLES AND DATA BUFFER.	
4040	017672	000137			210\$: 137			
4041	017674	045607			210\$: 045607			
4042	017676	101230			210\$: 101230			
4043	017700	045607	017722	177777	290\$: 45607,220\$,-1,-1,-1			
4044	017712	000000			290\$: 0			
4045	017714	000000			290\$: 0			
4046	017716	000000			290\$: 0			
4047	017720	000000			290\$: 0			
4048	017722	177777			220\$: -1			
4049	017724	177777			220\$: -1			
4050	017726	177777			220\$: -1			
4051	017730	177777			220\$: -1			
4052	017732	177777			250\$: -1			
4053	017734	177777			250\$: -1			
4054	017736	177777			250\$: -1			
4055	017740	177777			250\$: -1			
4056								
4057							;IF A TRAP TO 4 OCCURS COME HERE.	
4058	017742	011602			240\$: MOV	(SP),R2	;SEE IF THE TRAP OCCURRED ON THE TEST INSTRUCTION.	
4059	017744	020227	017640		240\$: CMP	R2,#230\$+2		
4060	017750	001405			240\$: BEQ	3\$;BRANCH IF YES.	
4061	017752	020227	017642		240\$: CMP	R2,#230\$+4		
4062	017756	001402			240\$: BEQ	3\$;BRANCH IF YES.	

4063 017760 000137 051774 :REPORT JMP CPSPUR ;OTHERWISE GO REPORT SPURIOUS TRAP TO 4.
4064 :REPORT AN FDST FLOW FAILURE RESULTED IN A TRAP TO 4.
4065 017764 022626 38: CMP (SP)+, (SP)+
4066 017766 010237 001236 MOV R2, STMP2
4067 017772 104132 ERROR +132 :ODD ADRES
4068 017774 000421 BR 280\$;BUT FDSTX IN ST 771
4069
4070 :REPORT RESULT INCORRECT:
4071 017776 012737 017712 001240 260\$: MOV #290\$, STMP3
4072 020004 012737 017672 001242 MOV #210\$, STMP4
4073 020012 012737 017722 001244 MOV #220\$, STMP5
4074 020020 104133 ERROR +133 ;BAD DATA X11*0 ST 3127
4075 020022 000406 BR 280\$
4076 :REPORT FPS INCORRECT:
4077 020024 010537 001240 270\$: MOV R5, STMP3
4078 020030 012737 000204 001244 MOV #204\$, STMP5
4079 020036 104134 ERROR +134 ;FPSX
4080
4081 020040 020040 104412 280\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4088

.SBTTL TEST # 32 - SPECIAL DEST. MODE 0, TEST

TEST 32 SPECIAL DEST. MODE 0, TEST

THIS IS A TEST OF THE NECC ADSS AND ECIS

;*THIS IS A TEST OF THE NEG7 ABSF AND TSIF DESTINATION FLOWS
;*MODE 0 USING THE NEG7D INSTR

• MODE 0 USING THE NEED INSTANT

1

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 37-1
TEST # 32 - SPECIAL DEST. MODE 0. TEST

SEQUENCE 87

4137 020230 000406 BR 270\$
4138
4139 :REPORT FPS INCORRECT:
4140 020232 010537 001242 260\$: MOV R5,\$TMP4
4141 020236 012737 000210 001240 MOV #210,\$TMP3
4142 020244 104137 ERROR +137 ;FPSX
4143
4144 020246 270\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
020246 104412 :SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4145 .SBTTL TEST # 33 - SPECIAL DEST. MODE 1, TEST

 *TEST 33 SPECIAL DEST. MODE 1, TEST
 *
 *THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
 *MODE 1 USING THE NEGD INSTR.
 *
 *
 020250 000004
 4146 020252 012737 020260 001110 1\$33: SCOPE
 4147 020260 012701 020370 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 4148 020264 012700 020400
 4149 020270 012702 000004
 4150 020274 012021
 4151 020276 077202
 4152 020300 012700 020370
 4153 020304 042710 100000
 4154 020310 012737 020324 001236 1\$: MOV #210\$,R1 ;SET UP THE DATA BUFFER.
 4155 020316 012701 000200
 4156 020322 170101
 4157
 4158 020324 170710 230\$: NEGD (R0) ;TEST INSTRUCTION.
 4159 020326 170205 STFPS R5 ;GET FPS.
 4160 020330 012701 020370 MOV #210\$,R1 ;IS THE RESULT CORRECT.
 4161 020334 012702 020400
 4162 020340 012703 000004
 4163 020344 022122 2\$: CMP (R1)+,(R2)+
 4164 020346 001020 BNE 240\$;BRANCH IF INCORRECT.
 4165 020350 077303 SOB R3,2\$
 4166 020352 022700 020370 CMP #210\$,R0 ;IS R0 CORRECT.
 4167 020356 001024 BNE 250\$;BRANCH IF INCORRECT.
 4168 020360 022705 000210 CMP #210,R5 ;IS THE FPS CORRECT?
 4169 020364 001030 BNE 260\$;BRANCH IF INCORRECT.
 4170 020366 000435 BR 270\$
 4171
 4172 ;THESE ARE DATA TABLES AND A DATA BUFFER.
 4173 020370 023245 210\$: 023245
 4174 020372 026720 26720
 4175 020374 122324 122324
 4176 020376 052672 52672
 4177 020400 123245 220\$: 123245
 4178 020402 026720 26720
 4179 020404 122324 122324
 4180 020406 052672 52672
 4181
 4182 :REPORT RESULT INCORRECT:
 4183 020410 012737 020370 001240 240\$: MOV #210\$,STMP3
 4184 020416 012737 020400 001242 MOV #220\$,STMP4
 4185 020424 104140 ERROR +140 ;BAD DATA
 4186 020426 000415 BR 270\$
 4187
 4188 :REPORT R0 INCORRECT:
 4189 020430 012737 020370 001240 250\$: MOV #210\$,STMP3
 4190 020436 010037 001242 MOV R0,STMP4
 4191 020442 104141 ERROR +141 ;SPEC DESTX
 4192 020444 000406 BR 270\$;R0X
 4193

CKFPCD0 FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 38-1
TEST # 33 - SPECIAL DEST. MODE 1, TEST

SEQUENCE 89

4194 :REPORT FPS INCORRECT:
4195 020466 012737 000210 001240 260\$: MOV #210,\$TMP3
4196 020454 010537 001242 MOV R5,\$TMP4
4197 020460 104142 ERROR +142
4198
4199 020462 020462 104412 270\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

4200

SBTTL TEST # 34 - SPECIAL DEST. MODE 2, TEST

*TEST 34 SPECIAL DEST. MODE 2, TEST
*
*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
*MODE 2 USING THE NEGD INSTR.

4201	020466	01277	020474	001110	TST34:	SCOPE				
4202	020474	012701	020604		200\$:	MOV #200\$,SLPERR	;SET UP THE LOOP ON FRROR ADDRESS.			:DPM002
4203	020500	012700	020614			MOV #210\$,R1	;SET UP THE DATA BUFFER.			
4204	020504	012702	000004			MOV #220\$,R0				
4205	020510	012021			1\$:	MOV #4,R2				
4206	020512	077202				MOV (R0)+,(R1)+				
4207	020514	012700	020604			SUB R2,1\$				
4208	020520	042710	100000	001236		MOV #210\$,R0				
4209	020524	012737	020540			BIC #100000,(R0)	;MAKE OPERAND POSITIVE.			
4210	020532	012701	000200			MOV #230\$,STMP2				
4211	020536	170101				MOV #200,R1				
4212						LDFPS R1	;SET FD.			
4213	020540	170720			230\$:	NEGD (R0)+				
4214							;TEST INSTRUCTION.			
4215	020542	170205				STFPS R5				
4216	020544	012701	020604			MOV #210\$,R1				
4217	020550	012702	020614			MOV #220\$,R2				
4218	020554	012703	000004			MOV #4,R3				
4219	020560	022122			2\$:	CMP (R1)+,(R2)+				
4220	020562	001020				BNE 240\$				
4221	020564	077303				SUB R3,2\$				
4222	020566	022700	020614			CMP #210\$+10,R0				
4223	020572	001024				BNE 250\$				
4224	020574	022705	000210			CMP #210,R5				
4225	020600	001030				BNE 260\$				
4226	020602	000435				BR 270\$				
4227							;BRANCH IF INCORRECT.			
4228							:IS R0 CORRECT.			
4229	020604	023245					;BRANCH IF INCORRECT.			
4230	020606	026720					:IS THE FPS CORRECT?			
4231	020610	122324					:IS THE DATA TABLES AND A DATA BUFFER.			
4232	020612	052672								
4233	020614	123245								
4234	020616	026720								
4235	020620	122324								
4236	020622	052672								
4237										
4238										
4239	020624	012737	020604	001240		REPNT RESULT INCORRECT:				
4240	020632	012737	020614	001242		240\$:	MOV #210\$,STMP3			
4241	020640	104143				MOV #220\$,STMP4				
4242	020642	000415				ERROR +143				
4243						BR 270\$				
4244							;BAD DATA			
4245	020644	012737	020614	001240		REPORT R0 INCORRECT:				
4246	020652	010037	001242			250\$:	MOV #210\$+10,STMP3			
4247	020655	104144				MOV R0,STMP4				
4248	020660	000406				ERROR +144				
						BR 270\$				
							;SPEC DESTX R0X			

CKFPCDU FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 39-1
TEST # 34 - SPECIAL DEST. MODE 2, TEST

N 7
SEQUENCE 91

4249
4250
4251 020662 012737 000210 001240 :REPORT FPS INCORRECT:
4252 020670 010537 001242 260\$: MOV #210,\$TMP3
4253 020674 104145 MOV R5,\$TMP4
4254
4255 020676 270\$: RSETUP :GO INITIALIZE THE FPS AND STACK, AND
020676 104412 :SEE IF THE USER HAS EXPRESSED
 :THE DESIRE TO CHANGE THE SOFTWARE
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS
 :THE USER TYPED CONTROL G?).

TEST # 35 - SPECIAL DEST, MODE 4, TEST

4256

.SBTTL TEST # 35 - SPECIAL DEST, MODE 4, TEST

```
*****  
;*TEST 35      SPECIAL DEST, MODE 4, TEST  
;  
;*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS  
;*MODE 4 USING THE NEGD INSTR.  
;
```

TST35: SCOPE

4257 020700 000004 020702 012737 020710 001110 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.

;DPM002

4258 020710 012701 021022 MOV #210\$,R1 ;SET UP THE DATA BUFFER.

4259 020714 012700 021042 MOV #220\$,R0

4260 020720 012702 000004 MOV #4,R2

4261 020724 012021 1\$: MOV (R0)+,(R1)+

4262 020726 077202 S0B R2,1\$

4263 020730 012700 021032 MOV #210\$+10,R0

4264 020734 042760 100000 BIC #100000,-10(R0) ;MAKE OPERAND POSITIVE.

4265 020742 012737 020756 001236 MOV #230\$,STMP2

4266 020750 012701 000200 MOV #200,R1 ;SET FD.

4267 020754 170101 LDFPS R1

4268

4269 020756 170740 230\$: NEGD -(R0) ;TEST INSTRUCTION.

4270

4271 020760 170205 STFPS R5 ;GET FPS.

4272 020762 012701 021022 MOV #210\$,R1 ;IS THE RESULT CORRECT.

4273 020766 012702 021042 MOV #220\$,R2

4274 020772 012703 000004 MOV #4,R3

4275 020776 022122 2\$: CMP (R1)+,(R2)+

4276 021006 001024 BNE 240\$;BRANCH IF INCORRECT.

4277 021002 077303 S0B R3,2\$

4278 021004 022700 021022 CMP #210\$,R0

4279 021010 001030 BNE 250\$;IS R0 CORRECT.

4280 021012 022705 000210 CMP #210,R5 ;BRANCH IF INCORRECT.

4281 021016 001034 BNE 260\$;IS THE FPS CORRECT?

4282 021020 000441 BR 270\$;BRANCH IF INCORRECT.

4283

4284 :THESE ARE DATA TABLES AND A DATA BUFFER.

4285 021022 023245 210\$: 023245

4286 021024 026720 26720

4287 021026 122324 122324

4288 021030 052672 52672

4289 021032 177777 177777 220\$: WORD -1,-1,-1,-1

4290 021042 123245 123245

4291 021044 026720 26720

4292 021046 122324 122324

4293 021050 052672 52672

4294

4295 :REPORT RESULT INCORRECT:

4296 021052 012737 021022 001240 240\$: MOV #210\$,STMP3

4297 021060 012737 021042 001242 MOV #220\$,STMP4

4298 021066 104146 ERROR +146 ;BAD DATA

4299 021070 000415 BR 270\$

4300

4301 :REPORT R0 INCORRECT:

4302 021072 012737 021022 001240 250\$: MOV #210\$,STMP3

4303 021100 010037 001242 MOV R0,STMP4

4304 021104 104147 ERROR +147 ;SPEC DESTX R0X

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 40-1
TEST # 35 - SPECIAL DEST. MODE 4, TEST

C 8
SEQUENCE 93

4305 021106 000406

BR 270\$

4306

4307

4308 021110 012737 000210 001240 260\$: :REPORT FPS INCORRECT:
4309 021116 010537 001242 MOV #210, \$TMP3
4310 021122 104150 MOV R5, \$TMP4
4311 ERROR +150

4312

021124 021124 104412

270\$:

RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

4313

.SBTTL TEST # 36 - SPECIAL DEST, MODE 3, TEST
 :*****
 :TEST 36 SPECIAL DEST, MODE 3, TEST
 :*
 :*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
 :*MODE 3 USING THE NEGD INSTR.
 :*

021126 000004
 4314 021130 012737 021136 001110 TST36: SCOPE
 4315 021136 012701 021254 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 4316 021142 012700 021264
 4317 021146 012702 000004
 4318 021152 012021 1\$: MOV (R0)+,(R1)+
 4319 021154 077202 SOB R2,1\$
 4320 021156 012700 021274 MOV #230\$,R0
 4321 021162 012710 021254 MOV #210\$,R0
 4322 021166 042737 100000 021254 BIC #100000,210\$;MAKE THE OPERAND POSITIVE.
 4323 021174 012737 021210 001236 MOV #240\$,STMP2
 4324 021202 012701 000200 MOV #200,R1
 4325 021206 170101 LDFPS R1 ;SET FD.
 4326
 4327 021210 170730 240\$: NEGD a(R0)+ ;TEST INSTRUCTION.
 4328
 4329 021212 170205 STFPS R5 ;GET FPS.
 4330 021214 012701 021254 MOV #210\$,R1 ;IS THE RESULT CORRECT.
 4331 021220 012702 021264
 4332 021224 012703 000004
 4333 021230 022122 2\$: CMP (R1)+,(R2)+
 4334 021232 001021 BNE 250\$;BRANCH IF INCORRECT.
 4335 021234 077303 SOB R3,2\$
 4336 021236 022700 021276 CMP #230\$+2,R0 ;IS R0 CORRECT.
 4337 021242 001025 BNE 260\$;BRANCH IF INCORRECT.
 4338 021244 022705 000210 CMP #210,R5 ;IS THE FPS CORRECT?
 4339 021250 001031 BNE 270\$;BRANCH IF INCORRECT.
 4340 021252 000436 BR 280\$
 4341
 4342 :THESE ARE DATA TABLES AND A DATA BUFFER.
 4343 021254 023245 210\$: 023245
 4344 021256 026720 26720
 4345 021260 122324 122324
 4346 021262 052672 52672
 4347 021264 123245 220\$: 123245
 4348 021266 026720 26720
 4349 021270 123324 123324
 4350 021272 052672 52672
 4351 021274 021254 230\$: 210\$
 4352
 4353 :REPORT RESULT INCORRECT:
 4354 021276 012737 021254 001240 250\$: MOV #210\$,STMP3
 4355 021304 012737 021264 001242 MOV #220\$,STMP4
 4356 021312 104150 ERROR +150 ;BAD DATA
 4357 021314 000415 BR 280\$
 4358
 4359 :REPORT R0 INCORRECT:
 4360 021316 012737 021276 001240 260\$: MOV #230\$+2,STMP3
 4361 021324 010037 001242 MOV R0,STMP4

(KFFCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE E 8
TEST # 36 - SPECIAL DEST, MODE 3, TEST

8

4362 021330 104152
4363 021332 000406

ERROR +152 :SPEC DESTX ROX
BR 280\$

4364

4365

4366

4360
4367

4368

4369

4370

4310

:REPORT FPS INCORRECT:
270S: MOV #210, STMP3
MOV R5, STMP4
ERROR +153

280\$:

RSE TUP

:SPEC DESTX ROX

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4371

.SBTTL TEST # 37 - SPECIAL DEST, MODE 5, TEST
 :*****
 :*TEST 37 SPECIAL DEST, MODE 5, TEST
 :*
 :*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
 :*MODE 5 USING THE NEGD INSTR.
 :*

021352 000004
 4372 021354 012737 021362 001110 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 4373 021362 012701 021502 000004 1\$: MOV #210\$,R1 ;SET UP THE DATA BUFFER.
 4374 021366 012700 021512
 4375 021372 012702 000004
 4376 021376 012021
 4377 021400 077202
 4378 021402 012700 021524 17776 240\$: NEG D #-(R0) ;TEST INSTRUCTION.
 4379 021406 012760 021502 000004 200\$: MOV #210\$,-2(R0)
 4380 021414 042737 100000 021502 BIC #100000,210\$;MAKE THE OPERAND POSITIVE.
 4381 021422 012737 021436 001236 MOV #240\$,STMP2
 4382 021430 012701 000200 MOV #200,R1 ;SET FD.
 4383 021434 170101 LDFPS R1
 4384
 4385 021436 170750
 4386
 4387 021440 170205 240\$: STFPS R5 ;GET FPS.
 4388 021442 012701 021502 MOV #210\$,R1 ;IS THE RESULT CORRECT.
 4389 021446 012702 021512
 4390 021452 012703 000004 2\$: MOV #220\$,R2
 4391 021456 022122 CMP #4,R3
 4392 021460 001021 BNE 250\$;BRANCH IF INCORRECT.
 4393 021462 077303 S0B R3,2\$
 4394 021464 022700 021522 CMP #250\$,R0 ;IS R0 CORRECT.
 4395 021470 001025 BNE 260\$;BRANCH IF INCORRECT.
 4396 021472 022705 000210 CMP #210,R5 ;IS THE FPS CORRECT?
 4397 021476 001031 BNE 270\$;BRANCH IF INCORRECT.
 4398 021500 000436 BR 280\$
 4399
 4400 :THESE ARE DATA TABLES AND A DATA BUFFER.
 4401 021502 023245 210\$: 023245
 4402 021504 026720 26720
 4403 021506 122324 122324
 4404 021510 052672 52672
 4405 021512 123245 220\$: 123245
 4406 021514 026270 26270
 4407 021516 122324 122324
 4408 021520 052672 52672
 4409 021522 021502 230\$: 210\$
 4410
 4411 :REPORT RESULT INCORRECT:
 4412 021524 012737 021502 001240 250\$: MOV #210\$,STMP3
 4413 021532 012737 021512 001242 MOV #220\$,STMP4
 4414 021540 104154 ERROR +154 ;BAD DATA
 4415 021542 000415 BR 280\$
 4416
 4417 :REPORT R0 INCORRECT:
 4418 021544 012737 021522 001240 260\$: MOV #230\$,STMP3
 4419 021552 010037 001242 MOV R0,STMP4

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 42-1 G 8
TEST # 37 - SPECIAL DEST, MODE 5, TEST

SEQUENCE 97

4420 021556 104155 ERROR +155 ;SPEC DESTX ROX
4421 021560 000406 BR 280\$
4422
4423 :REPORT FPS INCORRECT:
4424 021562 012737 000210 001240 270\$: MOV #210,\$IMP3
4425 021570 010537 001242 MOV R5,\$IMP4
4426 021574 104156 ERROR +156
4427
4428 021576 021576 104412 280\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4429

.SBTTL TEST # 40 - SPECIAL DEST. FLOATING MODE 2, TEST
 ;*****
 ;TEST 40 SPECIAL DEST. FLOATING MODE 2, TEST
 ;*
 ;THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
 ;MODE 2 USING THE NEGF INSTR.
 ;*

4430 021600 000004	021602 012737	021610 001110	TST40: SCOPE				
4431 021610 012701	021720		200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
4432 021614 012700	021730		MOV	#210\$,R1	;SET UP THE DATA BUFFER.		
4433 021620 012702	000004		MOV	#220\$,R0			
4434 021624 012021			MOV	#4,R2			
4435 021626 077202			MOV	(R0)+,(R1)+			
4436 021630 012700	021720		S0B	R2,1\$			
4437 021634 042710	100000		MOV	#210\$,R0			
4438 021640 012737	021654	001236	BIC	#100000,(R0)	;MAKE OPERAND POSITIVE.		
4439 021646 01<701	000000		MOV	#230\$,STMP2			
4440 021652 170101			MOV	#000,R1	;SET FD.		
4441			LDFPS	R1			
4442 021654 170720			230\$: NEGF	(R0)+	;TEST INSTRUCTION.		
4443			STFPS	R5	;GET FPS.		
4444 021656 170205			MOV	#210\$,R1	;IS THE RESULT CORRECT.		
4445 021660 012701	021720		MOV	#220\$,R2			
4446 021664 012702	021730		MOV	#4,R3			
4447 021670 012703	000004		CMP	(R1)+,(R2)+			
4448 021674 022122			BNE	240\$;BRANCH IF INCORRECT.		
4449 021676 001020			S0B	R3,2\$			
4450 021700 077303			CMP	#210\$+4,R0	,IS R0 CORRECT.		
4451 021702 022700	021724		BNE	250\$;BRANCH IF INCORRECT.		
4452 021706 001024			CMP	#010,R5	;IS THE FPS CORRECT?		
4453 021710 022705	000010		BNE	260\$;BRANCH IF INCORRECT.		
4454 021714 001030			BR	270\$			
4455 021716 000435							
4456							
4457					:THESE ARE DATA TABLES AND A DATA BUFFER.		
4458 021720 023245			210\$: 023245				
4459 021722 026720				26720			
4460 021724 122324				122324			
4461 021726 052672				52672			
4462 021730 123245			220\$: 123245				
4463 021732 026720				26720			
4464 021734 122324				122324			
4465 021736 052672				52672			
4466							
4467					:REPORT RESULT INCORRECT:		
4468 021740 012737	021720 001240		240\$: MOV	#210\$,STMP3			
4469 021746 012737	021730 001242		MOV	#220\$,STMP4			
4470 021754 104150			ERROR	+150	;BAD DATA		
4471 021756 000415			BR	270\$			
4472							
4473					:REPORT R0 INCORRECT:		
4474 021760 012737	021724 001240		250\$: MOV	#210\$+4,STMP3			
4475 021766 010037	001242		MOV	R0,STMP4			
4476 021772 104160			ERROR	+160	;SPEC DESTX R0X		
4477 021774 000406			BR	270\$			

4478

4479

4480 021776 012737 000010 001240 :REPORT FPS INCORRECT:
4481 022004 010537 001242 260\$: MOV #010,\$TMP3
4482 022010 104161 MOV R5,\$TMP4
4483
4484 022012 022012 104412 270\$: RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

4485

SBTTL TEST # 41 - SPECIAL DEST, MODE2, GR7

*TEST 41 SPECIAL DEST, MODE2, GR7*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
*MODE 2(IMMEDIATE) USING THE NEGD INSTR.

022014 000004
4486 022016 012737 022024 001110 TST41: SCOPE
4487 022024 012700 022150 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
4488 022030 012701 022076
4489 022034 012702 000004
4490 022040 012021 1\$: MOV (R0)+(R1)+
4491 022042 077202 S0B R2,1\$
4492 022044 012700 022076 MOV #220\$,R0
4493 022050 042737 100000 022076 BIC #100000,220\$;MAKE THE OPERAND POSITIVE.
4494 022056 012737 022074 001236 MOV #230\$,SIMP2
4495 022064 012701 000200 MOV #200,R1 ;SET FD.
4496 022070 170101 LDFPS R1
4497 022072 005001 CLR R1
4498
4499 022074 170727 230\$: NEGD (R7)+ ;TEST INSTRUCTION.
4500 022076 005201 005201 220\$: 5201,5201,5201,5201 ;NOTE THAT AFTER EXECUTING THIS INSTRUCTION R1 SHOULD CONTAIN 3.
4501
4502 022106 170205 STFPS R5 ;GET FPS.
4503 022110 012703 022076 MOV #220\$,R3 ;IS THE RESULT CORRECT.
4504 022114 012702 022150 MOV #210\$,R2
4505 022120 012704 000004 MOV #4,R4
4506 022124 022322 2\$: CMP (R3)+(R2)+
4507 022126 001014 BNE 240\$;BRANCH IF INCORRECT.
4508 022130 077403 S0B R4,2\$
4509 022132 022701 000003 CMP #3,R1 ;WAS R1 INCREMENTED CORRECTLY.
4510 022136 001027 BNE 250\$;BRANCH IF INCORRECT.
4511 022140 022705 000210 CMP #210,R5 ;IS THE FPS CORRECT?
4512 022144 001015 BNE 260\$;BRANCH IF INCORRECT.
4513 022146 000436 BR 270\$
4514
4515 ;THESE ARE DATA TABLF.
4516 022150 105201 210\$: 105201
4517 022152 005201 5201
4518 022154 005201 5201
4519 022156 005201 5201
4520
4521 ;REPORT RESULT INCORRECT:
4522 022160 012737 022076 001240 240\$: MOV #220\$,SIMP3
4523 022166 012737 022150 001242 MOV #210\$,SIMP4
4524 022174 104162 ERROR +162 ;BAD DATA
4525 022176 000422 BR 270\$
4526
4527 ;REPORT FPS INCORRECT:
4528 022200 012737 000210 001240 260\$: MOV #210,SIMP3
4529 022206 010537 001242 MOV R5,SIMP4
4530 022212 104163 ERROR +163 ;FPS
4531 022214 000413 BR 270\$
4532
4533 ;REPORT PC INCORRECTLY INCREMENTED DURING EXECUTION.

4534 022216 162701 000003	250S:	SUB	#3,R1
4535 022222 006301		ASL	R1
4536 022224 012702 022100		MOV	#220S+2,R2
4537 022230 010237 001240		MOV	R2,\$TMP\$
4538 022234 160102		SUB	R1,R2
4539 022236 010237 001242		MOV	R2,\$TMP4
4540 022242 104164		ERROR	+164
			;PC BAD CONSTAND B GR7X
4541			
4542 022244 104412	270S:	RSETUP	:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).
022244			

4543

.SBTTL TEST # 42 - SPECIAL DEST, MODE 6, TEST

*TEST 42 SPECIAL DEST, MODE 6, TEST

*THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
*MODE 6 USING THE NEGD INSTR.

022246	000004		TST42: SCOPE			
4544			.DSABL	AMA	:DISABLE MODE 6 TO MODE 3 CONVERSIONS	
4545	022250	012767	022256	156632	MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.
4546	022256	012701	022400		MOV #210\$,R1	:SET UP THE DATA BUFFER.
4547	022262	012700	022410		MOV #220\$,R0	
4548	022266	012702	000004		MOV #4,R2	
4549	022272	012021			MOV (R0)+,(R1)+	
4550	022274	077202			SOB R2,1\$	
4551	022276	012700	015177		MOV #210\$-5201,R0	
4552	022302	042767	100000	000070	BIC #100000,210\$:MAKE OPERAND POSITIVE.
4553	022310	012767	022326	156720	MOV #230\$,STMP2	
4554	022316	012701	000200		MOV #200,R1	:SET FD.
4555	022322	170101			LDFPS R1	
4556						
4557	022324	005001			CLR R1	
4558	022326	170760	005201		NEGD 5201(R0)	:TEST INSTRUCTION.
4559	022332	170205			STFPS R5	:GET FPS.
4560	022334	005701			TST R1	
4561	022336	001030			BNE 240\$:WAS THE PC CORRECT AFTER EXECUTION?
4562	022340	012701	022400		MOV #210\$,R1	:IS THE RESULT CORRECT.
4563	022344	012702	022410		MOV #220\$,R2	
4564	022350	012703	000004		MOV #4,R3	
4565	022354	022122			CMP (R1)+,(R2)+	
4566	022356	001030			BNE 250\$:BRANCH IF INCORRECT.
4567	022360	077303			SOB R3,2\$	
4568	022362	022700	015177		CMP #210\$-5201,R0	:IS R0 CORRECT.
4569	022366	001034			BNE 260\$:BRANCH IF INCORRECT.
4570	022370	022705	000210		CMP #210,R5	:IS THE FPS CORRECT?
4571	022374	001040			BNE 270\$:BRANCH IF INCORRECT.
4572	022376	000445			BR 280\$	
4573						
4574					THESE ARE DATA TABLES AND A DATA BUFFER.	
4575	022400	023245		210\$: 023245		
4576	022402	026720			26720	
4577	022404	122324			122324	
4578	022406	052672			52672	
4579	022410	123245		220\$: 123245		
4580	022412	026720			26720	
4581	022414	122324			122324	
4582	022416	052672			52672	
4583						
4584						
4585					REPORT PC INCORRECT AFTER EXECUTION.	
4586	022420	012767	022330	156614	240\$: MOV #230\$+2,STMP4	
4587	022426	012767	022332	156604	MOV #230\$+4,STMP3	
4588	022434	104215			ERROR +215	:PC NOT INCREMENTED BY 2.
4589	022436	000425			BR 280\$	
4590						
4591					REPORT RESULT INCORRECT:	

KFPCD0 FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 45-1
TEST # 42 - SPECIAL DEST. MODE 6, TEST

M 8
SEQUENCE 103

4592 022440 012767 022400 156572 250\$: MOV #210\$,STMP3
4593 022446 012767 022410 156566 MOV #220\$,STMP4
4594 022454 104216 ERROR +216 :BAD DATA
4595 022456 000415 BR 280\$
4596
4597 :REPORT R0 INCORRECT:
4598 022460 012767 015177 156552 260\$: MOV #210\$-5201,STMP3
4599 022466 010067 156550 MOV R0,STMP4
4600 022472 104217 ERROR +217 :SPEC DESTX R0X
4601 022474 000406 BR 280\$
4602
4603
4604 :REPORT FPS INCORRECT:
4605 022476 012767 000210 156534 270\$: MOV #210,STMP3
4606 022504 010567 156532 MOV R5,STMP4
4607 022510 104220 ERROR +220
4608
4609 022512 022512 104412 280\$: RSETJP :GO INITIALIZE THE FPS AND STACK; AND
4610 .ENABL AMA :SEE IF THE USER HAS EXPRESSED
THE DESIRE TO CHANGE THE SOFTWARE
VIRTUAL CONSOLE SWITCH REGISTER (HAS
THE USER TYPED CONTROL G?).
:REENABLE MODE 6 TO MODE 3 CONVERSIONS

4611

.SBTTL TEST # 43 - SPECIAL DEST. MODE 7, TEST
 :*****
 :TEST 43 SPECIAL DEST. MODE 7, TEST
 :
 :THIS IS A TEST OF THE NEGF ABSF AND TSTF DESTINATION FLOWS
 :MODE 7 USING THE NEG'D INSTR.
 :*****

4612 022514 000004	022516 012737 022524	001110	TST43: SCOPE			
4613 022524 012701 022654			200\$: MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		
4614 022530 012700 022664			MOV #210\$,R1	:SET UP THE DATA BUFFER.		:DPM002
4615 022534 012702 000004			MOV #220\$,R0			
4616 022540 012021			MOV #4,R2			
4617 022542 077202			MOV (R0)+,(R1)+			
4618 022544 012700 015473			S0B R2,1\$			
4619 022550 012760 022654	005201		MOV #230\$-5201,R0			
4620 022556 042737 100000	022654		MOV #210\$,5201(R0)			
4621 022564 012737 022602	001236		BIC #100000,210\$:MAKE THE OPERAND POSITIVE.		
4622 022572 012701 000200			MOV #240\$,STMP2			
4623 022576 170101			MOV #200,R1			
4624			LDFPS R1	:SET FD.		
4625 022600 005001						
4626 022602 170770 005201			240\$: CLR R1			
4627			NEGD @5201(R0)	:TEST INSTRUCTION.		
4628 022606 170205			STFPS R5			
4629 022610 005701			TST R1	:GET FPS.		
4630 022612 001031			BNE 250\$:WAS THE PC CORRECT AFTER EXECUTION?		
4631 022614 012701 022654			MOV #210\$,R1			
4632 022620 012702 022664			MOV #220\$,R2			
4633 022624 012703 000004			MOV #4,R3			
4634 022630 022122			CMP (R1)+,(R2)+			
4635 022632 001031			BNE 260\$:IS THE RESULT CORRECT.		
4636 022634 077303			S0B R3,2\$			
4637 022636 022700 015473			CMP #230\$-5201,R0	:BRANCH IF INCORRECT.		
4638 022642 001035			BNE 270\$:IS RO CORRECT.		
4639 022644 022705 000210			CMP #210\$,RS	:BRANCH IF INCORRECT.		
4640 022650 001041			BNE 280\$:IS THE FPS CORRECT?		
4641 022652 000446			BR 290\$:BRANCH IF INCORRECT.		
4642						
4643						
4644 022654 023245			210\$: THESE ARE DATA TABLES AND A DATA BUFFER.			
4645 022656 026720			023245			
4646 022660 122324			26720			
4647 022662 052672			122324			
4648 022664 123245			52672			
4649 022666 026720			123245			
4650 022670 123324			26720			
4651 022672 052672			123324			
4652 022674 022654			52672			
4653			230\$: 210\$			
4654						
4655 022676 013737 022604 001242			REPORT PC INCORRECT AFTER EXECUTION.			
4656 022704 013737 022606 001240			250\$: MOV 240\$+2,STMP4			
4657 022712 104221			MOV 240\$+4,STMP3			
4658 022714 000425			ERROR +221	:PC NOT INCREMENTED BY 2.		
4659			BR 290\$			

4660 :REPORT RESULT INCORRECT:
4661 022716 012737 022654 001240 260\$: MOV #210\$,STMP3
4662 022724 012737 022664 001242 MOV #220\$,STMP4
4663 022732 104222 ERROR +222 ;BAD DATA
4664 022734 000415 BR 290\$
4665
4666 :REPORT RO INCORRECT:
4667 022736 012737 015473 001240 270\$: MOV #230\$-5201,STMP3
4668 022744 010037 001242 MOV RO,STMP4
4669 022750 104223 ERROR +223 ;SPEC DESTX ROX
4670 022752 000406 BR 290\$
4671
4672 :REPORT FPS INCORRECT:
4673 022754 012737 000210 001240 280\$: MOV #210,STMP3
4674 022762 010537 001242 MOV R5,STMP4
4675 022766 104224 ERROR +224
4676
4677 022770 022770 104412 290\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

4683

.SBTTL TEST # 44 - NEGD, ABSD AND TSTD TEST

;*****
;*TEST 44 NEGD, ABSD AND TSTD TEST;*THIS IS A TEST OF THE NEGD ABSD AND TSTD INSTRUCTIONS.
;*

4684	022772	000004		TST44: SCOPE			
4685	022774	012737	023002	001110	:TEST NEGD WITH POS NONZERO OPERAND		
4686	023002	004737	023702		200\$: MOV #200\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4687	023006	000000			1\$: JSR PC,1000\$		
4688	023010	016341			2\$: 0	;FLAG=NEGD.	
4689	023012	055772			55772	;OPERAND.	
4690	023014	021133			21133		
4691	023016	055447			55447		
4692	023020	116341			3\$: 116341	;RESULT.	
4693	023022	055772			55772		
4694	023024	021133			21133		
4695	023026	055447			55447		
4696	023030	016341			4\$: 16341	;ERROR RES.	
4697	023032	055772			55772		
4698	023034	021133			21133		
4699	023036	055447			55447		
4700	023040	000207			5\$: 207	:FPS BEFORE EXECUTION.	
4701	023042	000210			210	:FPS AFTER EXECUTION.	
4702	023044	000200			200	:ERROR FPS.	
4703	023046	177777			-1	:FEC	
4704	023050	104200			6\$: ERROR +200	:E10<---E10*200X ST 336	
4705	023052	000401			BR 7\$		
4706	023054	104201			ERROR +201	;BUT ENBT ST 336X WENT TO 053 INTO 453	
4707	023056				7\$: TEST NEGD WITH NEG OPERAND.		
4709	023056	012737	023064	001110	210\$: MOV #210\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4710	023064	004737	023702		11\$: JSR PC,1000\$		
4711	023070	000000			12\$: 0	;FLAG=NEGD.	
4712	023072	152525			152525	;OPERAND.	
4713	023074	053545			53545		
4714	023076	055565			55565		
4715	023100	057505			57505		
4716	023102	052525			13\$: 52525	;RESULT.	
4717	023104	053545			53545		
4718	023106	055565			55565		
4719	023110	057505			57505		
4720	023112	152525			14\$: 152525	;ERROR RES.	
4721	023114	053545			53545		
4722	023116	055565			55565		
4723	023120	057505			57505		
4724	023122	000217			15\$: 217	:FPS BEFORE EXECUTION.	
4725	023124	000200			200	:FPS AFTER EXECUTION.	
4726	023126	000210			210	:ERROR FPS.	
4727	023130	177777			-1	:FEC	
4728	023132	104200			16\$: ERROR +200	:E10<---E10*200X S336	
4729	023134	000401			BR 17\$		
4730	023136	104202			ERROR +202	;BUT ENBT X ST336 TO 453 INTO 053	
4731	023140				17\$: TEST ABSD WITH POSITIVE OPERAND		
4732							

4733 023140 012737 023146 001110		MOV #220\$, \$LPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4734 023146 004737 023702	220\$: JSR PC,1000\$			
4735 023152 000001	21\$: 1		;FLAG=ABSD.	
4736 023154 060705	22\$: 60705		;OPERAND.	
4737 023156 124735		124735		
4738 023160 060124		60124		
4739 023162 073560		73560		
4740 023164 060705	23\$: 60705		;RESULT.	
4741 023166 124735		124735		
4742 023170 060124		60124		
4743 023172 073560		73560		
4744 023174 160705	24\$: 160705		;ERROR RES.	
4745 023176 124735		124735		
4746 023200 060124		60124		
4747 023202 073560		73560		
4748 023204 000217	25\$: 217		;FPS BEFORE EXECUTION.	
4749 023206 000200		200	;FPS AFTER EXECUTION.	
4750 023210 000210		210	;ERROR FPS.	
4751 023212 177777		-1	;EITHER BUT OP1B	
4752 023214 104203	26\$: ERROR +203		;BUT ST 055 TO 336 INTO 335	
4753 023216 000401	BR 27\$			
4754 023220 104203	ERROR +203		;OR BUT ENBT ST 335 TO 452 INTO 052	
4755 023222	27\$: :TEST ABSD WITH NEG. OPERAND			
4756 023222 012737 023230 001110	MOV #230\$, \$LPERR		;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4758 023230 004737 023702	230\$: JSR PC,1000\$			
4759 023234 000001	31\$: 1		;FLAG=ABSD.	
4760 023236 154345	32\$: 154345		;OPERAND.	
4761 023240 076567		76567		
4762 023242 032123		32123		
4763 023244 043234		43234		
4764 023246 054345	33\$: 54345		;RESULT.	
4765 023250 076567		76567		
4766 023252 032123		32123		
4767 023254 043234		43234		
4768 023256 154345	34\$: 154345		;ERROR RES.	
4769 023260 076567		76567		
4770 023262 032123		32123		
4771 023264 043234		43234		
4772 023266 000217	35\$: 217		;FPS BEFORE EXECUTION.	
4773 023270 000200		200	;FPS AFTER EXECUTION.	
4774 023272 177777		-1	;ERROR FPS.	
4775 023274 177777		-1		
4776 023276 104204	36\$: ERROR +204		;E10*E10*200X ST 452	
4777 023300 000401	BR 37\$			
4778 023302 104171	ERROR +171			
4779 023304	37\$: :TEST WITH POSITIVE OP			
4780 023304 012737 023312 001110	MOV #240\$, \$LPERR		;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
4782 023312 004737 023702	240\$: JSR PC,1000\$			
4783 023316 000002	41\$: 2		;FLAG=TSTD.	
4784 023320 012321	42\$: 12321		;OPERAND.	
4785 023322 045654		45654		
4786 023324 070107		70107		
4787 023326 034543		34543		
4788 023330 012321	43\$: 12321		;RESULT.	
4789 023332 045654		45654		

4790 023334	070107		70107		
4791 023336	034543		34543		
4792 023340	112321	44\$:	112321	:ERROR RES.	
4793 023342	045654		45654		
4794 023344	070107		70107		
4795 023346	034543		34543		
4796 023350	000217	45\$:	217	:FPS BEFORE EXECUTION.	
4797 023352	000200		200	:FPS AFTER EXECUTION.	
4798 023354	000210		210	:ERROR FPS.	
4799 023356	177777		-1		
4800 023360	104205	46\$:	ERROR +205	:BUT (OP1B) X ST044 TO 336 INTO 334	
4801 023362	000401		BR 47\$		
4802 023364	104206		ERROR +206	:BUT ENBT ST 334 TO 453 INTO 053	
4803 023366		47\$:	:TEST TSTD WITH NEG OP		
4805 023366	012737	023374	001110	MOV #250\$, \$LPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
4806 023374	004737	023702		JSR PC,1000\$	
4807 023400	000002		51\$:	2	:FLAG=TSTD.
4808 023402	123765		52\$:	123765	:OPERAND.
4809 023404	023407			23407	
4810 023406	034510			34510	
4811 023410	045621			45621	
4812 023412	123765	53\$:	123765	:RESULT.	
4813 023414	023407			23407	
4814 023416	034510			34510	
4815 023420	045621			45621	
4816 023422	023765	54\$:	23765	:ERROR RES.	
4817 023424	023407			23407	
4818 023426	034510			34510	
4819 023430	045621			45621	
4820 023432	000207	55\$:	207	:FPS BEFORE EXECUTION.	
4821 023434	000210			210	:FPS AFTER EXECUTION.
4822 023436	000200			200	:ERROR FPS.
4823 023440	177777			-1	
4824 023442	104207	56\$:	ERROR +207	:BUT OP81 ST 055 TO 335 INTO 334	
4825 023444	000401			BR 57\$	
4826 023446	104210			ERROR +210	:BUT ENBT ST 334 TO 053 INTO 453
4827 023450		57\$:	:TEST TSTD 0 OP		
4829 023450	012737	023456	001110	MOV #260\$, \$LPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
4830 023456	004737	023702		JSR PC,1000\$	
4831 023462	000002		61\$:	2	:FLAG=TSTD.
4832 023464	000175		62\$:	175	:OPERAND.
4833 023466	176737			176737	
4834 023470	071727			71727	
4835 023472	037574			37574	
4836 023474	000175	63\$:	175	:RESULT.	
4837 023476	176737			176737	
4838 023500	071727			71727	
4839 023502	037574			37574	
4840 023504	000000	64\$:	0	:ERROR RES.	
4841 023506	000000			0	
4842 023510	000000			0	
4843 023512	000000			0	
4844 023514	000200	65\$:	200	:FPS BEFORE EXECUTION.	
4845 023516	000204			204	:FPS AFTER EXECUTION.
4846 023520	000214			214	:ERROR FPS.

```

4847 023522 177777
4848 023524 104211
4849 023526 000401
4850 023530 104212
4851 023532
4852
4853 023532 012737 023540 001110
4854 023540 004737 023702
4855 023544 000002
4856 023546 100123
4857 023550 021012
4858 023552 034565
4859 023554 043210
4860 023556 100123
4861 023560 021012
4862 023562 034565
4863 023564 043210
4864 023566 000000
4865 023570 000000
4866 023572 000000
4867 023574 000000
4868 023576 040203
4869 023600 040214
4870 023602 140214
4871 023604 177777
4872 023606 104211
4873 023610 000401
4874 023612 104213
4875 023614
4876
4877 023614 012737 023622 001110
4878 023622 004737 023702
4879 023626 000002
4880 023630 100137
4881 023632 024613
4882 023634 057024
4883 023636 060137
4884 023640 100137
4885 023642 024613
4886 023644 057024
4887 023646 060137
4888 023650 000000
4889 023652 000000
4890 023654 000000
4891 023656 000000
4892 023660 044200
4893 023662 144214
4894 023664 044214
4895 023666 000014
4896 023670 104211
4897 023672 000401
4898 023674 104214
4899 023676
4900 023676 000137 024316

       -1
       ERROR +211
       BR    67$ 
       ERROR +212
       67$: :TEST TSTD -0 OP FIUV=0
              MOV   #270$,SLPERR
              JSR   PC,1000$ ;SET UP THE LOOP ON ERROR ADDRESS.      ;DPM002
       270$: ;TEST TSTD -0 OP FIUV=0
              MOV   #270$,SLPERR
              JSR   PC,1000$ ;SET UP THE LOOP ON ERROR ADDRESS.      ;DPM002
       71$: 2 ;FLAG=TSTD.
       72$: 100123 ;OPERAND.
       21012
       34565
       43210
       100123 ;RESULT.
       21012
       34565
       43210
       0 ;ERROR RES.
       0
       0
       0
       0
       40203 ;FPS BEFORE EXECUTION.
       040214 ;FPS AFTER EXECUTION.
       140214 ;ERROR FPS.
       -1
       75$: 40203 ;FPS BEFORE EXECUTION.
       040214 ;FPS AFTER EXECUTION.
       140214 ;ERROR FPS.
       -1
       76$: ERROR +211 ;+
       BR    77$ ;BUT FIUV ST 257 TO 355 INTO 255
       ERROR +213
       77$: :TEST TSTD -0 OP FIUV=1
              MOV   #280$,SLPERR
              JSR   PC,1000$ ;SET UP THE LOOP ON ERROR ADDRESS.      ;DPM002
       280$: ;TEST TSTD -0 OP FIUV=1
              MOV   #280$,SLPERR
              JSR   PC,1000$ ;SET UP THE LOOP ON ERROR ADDRESS.      ;DPM002
       81$: 2 ;FLAG=TSTD.
       82$: 100137 ;OPERAND.
       24613
       57024
       60137
       100137 ;RESULT.
       24613
       57024
       60137
       0 ;ERROR RES.
       0
       0
       0
       0
       83$: 100137 ;FPS BEFORE EXECUTION.
       24613 ;FPS AFTER EXECUTION.
       57024 ;ERROR FPS.
       60137 ;FPS BEFORE EXECUTION.
       144200 ;FPS AFTER EXECUTION.
       144214 ;ERROR FPS.
       044214
       14
       84$: 14 ;+
       85$: 44200 ;+
       144214 ;+
       044214 ;+
       14 ;+
       86$: ERROR +211 ;+
       BR    87$ ;BUT FIUV ST 257 TO 255 INTO 355
       ERROR +214
       87$: JMP   290$ ;BUT FIUV ST 257 TO 255 INTO 355

```

4901 :THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
4902 :THE EITHER A TSTD, AN ABSD OR A NEGD INSTRUCTION AND CHECK THE RESULTS. A CALL
4903 :TO IT IS MADE THUS:

```

4905     JSR    PC,1000$  

4906     FLAG: .WORD   X           ;INSTRUCTION TYPE FLAG.  

4907     ACARG: .WORD   X,X,X,X  ;OPERAND  

4908     RES:   .WORD   X,X,X,X  ;EXPECTED RESULT  

4909     ERRES: .WORD   X,X,X,X ;ERROR RESULT  

4910     FPSB:  .WORD   X           ;FPS BEFORE EXECUTION  

4911     FPSA:  .WORD   X           ;FPS AFTER EXECUTION  

4912     FEC:   .WORD   X           ;EXPECTED FEC  

4913     ERFPS: .WORD   X           ;ERROR FPS.  

4914     ERR1:  ERROR  +X          ;DATA ERROR.  

4915     ERR2:  ERROR  +X          ;FPS ERROR.  

4916     BR    CONT  

4917     CONT:  ERROR  +X          ;RETURN ADDRESS  

4918

```

4919 :THE OPERAND IS SET UP IN NATBF1. THEN
4920 :THE EITHER THE TSTD, NEGD OR ABSD INSTRUCTION IS EXECUTED.
4921 :1000\$ USES THE FIRST OPERAND AS A FLAG TO DETERMINE WHICH INSTRUCTION
4922 :IS TO BE EXECUTED: 0 = NEGD, 1 = ABSD, 2 = TSTD.
4923 :THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
4924 :COMPARED WITH FPSA. IF THIS IS CORRECT 1000\$ RETURNS CONTROL
4925 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD 1000\$
4926 :COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN 1000\$ WILL RETURN
4927 :TO THE ERROR CALL AT ERR2, OTHERWISE 1000\$ ITSELF
4928 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
4929 :INSTRUCTION IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
4930 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
4931 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN 1000\$
4932 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
4933 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND 1000\$ WILL
4934 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
4935
4936

4937 023702 012601	1000\$. MOV (SP)+,R1	:GET A POINTER TO THE ARGUMENTS
4938 023704 010102	MOV R1,R2	:COPY THE OPERAND.
4939 023706 062702 000002	ADD #2,R2	
4940 023712 012703 024304	MOV #1200\$,R3	
4941 023716 012704 000004	MOV #4,R4	
4942 023722 012223	MOV (R2)+,(R3)+	
4943 023724 077402	SOB R4,91\$	
4944 023726 016100 000032	MOV 32(R1),R0	:LOAD THE FPS.
4945 023732 170100	LDFPS R0	
4946 023734 012700 024304	MOV #1200\$,R0	:SET UP THE OPERAND ADDRESS.
4947 023740 011102	MOV (R1),R2	:GET THE FLAG TO DETERMINE WHICH
4948 023742 006302	ASL R2	:INSTRUCTION TO EXECUTE.
4949 023744 006302	ASL R2	:0 = NEGD, 1 = ABSD, 2 = TSTD
4950 023746 012703 023762	MOV #1210\$,R3	
4951 023752 060203	ADD R2,R3	
4952 023754 010337 001236	MOV R3,\$TMP2	
4953 023760 000113	JMP (R3)	:GO EXECUTE THE INSTRUCTION.
4954 023762 170710	NEGD (R0)	
4955 023764 000403	BR 92\$	
4956 023766 170610	ABSD (R0)	
4957 023770 000401	BR 92\$	

```

4958 023772 170510          TSTD   (R0)
4959
4960 023774 170204          92$:   STFPS  R4      ;GET THE FPS.
4961 023776 170305          STST   R5      ;GET THE FEC.
4962 024000 010102          MOV    R1,R2
4963 024002 062702 000002          ADD    #2,R2
4964 024006 010237 001240          MOV    R2,$TMP3
4965 024012 062702 000010          ADD    #10,R2
4966 024016 010237 001244          MOV    R2,$TMP5
4967 024022 012737 024304 001242          MOV    #1200$, $TMP4
4968 024030 010437 001250          MOV    R4,$TMP7
4969 024034 016137 000034 001252          MOV    34(R1),$TMP10
4970 024042 010100          MOV    R1,R0      ;WAS THE RESULT CORRECT?
4971 024044 062700 000012          ADD    #12,R0
4972 024050 012702 024304          MOV    #1200$, R2
4973 024054 012703 000004          MOV    #4,R3
4974 024060 022022          93$:   CMP    (R0)+,(R2)+      ;BRANCH IF INCORRECT.
4975 024062 001014          BNE    100$      ;WAS THE FPS CORRECT?
4976 024064 077303          S0B    R3,93$      ;BRANCH IF INCORRECT.
4977 024066 026104 000034          CMP    34(R1),R4      ;IF THE EXPECTED FPS WAS NEGATIVE CHECK THE FEC.
4978 024072 001032          BNE    105$      ;WAS THE FEC CORRECT.
4979 024074 005761 000034          TST    34(R1)
4980 024100 100003          BPL    94$      ;BRANCH IF INCORRECT.
4981 024102 026105 000040          CMP    40(R1),RS      ;RETURN.
4982 024106 001037          BNE    110$      ;WAS THE FEC CORRECT.
4983 024110 000161 000050          94$:   JMP    50(R1)      ;BRANCH IF INCORRECT.
4984
4985 :THE RESULT WAS INCORRECT BUT WAS THIS FAILURE ANTICIPATED?
4986 :SEE IF THE RESULT WAS ANTICIPATED:
4987 024114          100$:   MOV    (R1),R5
4988 024114 011105          ASL    R5
4989 024116 006305          ASL    R5
4990 024120 006305          ADD    #1220$,R5
4991 024122 062705 024234          MOV    R1,R0
4992 024126 010100          ADD    #22,R0
4993 024130 062700 000022          MOV    #1200$,R2
4994 024134 012702 024304          MOV    #4,R3
4995 024140 012703 000004          101$:   CMP    (R0)+,(R2)+      ;BRANCH IF NOT ANTICIPATED.
4996 024144 022022          BNE    102$      ;THE ERROR WAS ANTICIPATED SO RETURN.
4997 024146 001003          S0B    R3,101$      ;THE ERROR WAS NOT ANTICIPATED SO REPORT IT HERE.
4998 024150 077303          5000:   JMP    42(R1)      ;GO TO THE PROPER ERROR CALL.
5001 024152 000161 000042          5002:   JMP    (R5)      ;THE FPS WAS INCORRECT.
5003:   102$:   JMP    (R5)      ;WAS THIS ERROR ANTICIPATED?
5004 024156 000115          5005:   BNE    106$      ;BRANCH IF NOT ANTICIPATED.
5006
5007 024160 026105 000036          5008:   CMP    36(R1),RS      ;THE FPS ERROR WAS ANTICIPATED SO RETURN.
5009 024164 001002          BNE    106$      ;THE FPS FAILURE WAS NOT ANTICIPATED SO REPORT IT HERE.
5010
5011 024166 000161 000046          5012:   JMP    46(R1)
5013
5014 024172 011102          5013:   MOV    (R1),R2

```

5015 024174 006302 ASL R2
5016 024176 006302 ASL R2
5017 024200 062702 024252 ADD #1230\$,R2
5018 024204 000112 JMP (R2) ;GO TO THE PROPER ERROR CALL.
5019
5020 :REPORT THAT THE FEC WAS INCORRECT.
5021 024206 016137 000040 001256 110\$: MOV 40(R1),\$TMP12
5022 024214 010537 001254 MOV R5,\$TMP11
5023 024220 011102 MOV (R1),R2
5024 024222 006302 ASL R2
5025 024224 006302 ASL R2
5026 024226 062702 024266 ADD #1240\$,R2
5027 024232 000112 JMP (R2) ;GO TO THE PROPER ERROR CALL.
5028
5029 :THESE ARE THE ERROR CALLS FOR EACH INDIVIDUAL INSTRUCTION AND CONDITION.
5030 024234 104165 1220\$: ERROR +165 ;NEGD BAD DATA
5031 024236 000403 BR 1250\$
5032 024240 104166 ERROR +166 ;ABSD BAD DATA
5033 024242 000401 BR 1250\$
5034 024244 104167 ERROR +167 ;TSTD BAD DATA
5035 024246 000161 000050 1250\$: JMP 50(R1)
5036
5037 :FPS INCORRECT:
5038 024252 104170 1230\$: ERROR +170 ;NEGD FPSX
5039 024254 000774 BR 1250\$
5040 024256 104171 ERROR +171 ;ABSD FPSX
5041 024260 000772 BR 1250\$
5042 024262 104172 ERROR +172 ;TSTD FPSX
5043 024264 000770 BR 1250\$
5044
5045 :FEC INCORRECT:
5046 024266 104173 1240\$: ERROR +173 ;NEGD FECX
5047 024270 000766 BR 1250\$
5048 024272 104174 ERROR +174 ;ABSD FECX
5049 024274 000764 BR 1250\$
5050 024276 104175 ERROR +175 ;TSTD FECX
5051 024300 000762 BR 1250\$
5052
5053 024302 177777 .WORD -1
5054 024304 177777 177777 177777 1200\$: .WORD -1,-1,-1,-1,-1
5055
5056 024316 024316 104412 290\$: RSETUP
;GO INITIALIZE THE FPS AND STACK; AND
;SEF IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

5063 .SBTTL TEST # 45 - SOURCE MODES, MODE 1 (FL=0), TEST

 *TEST 45 SOURCE MODES, MODE 1 (FL=0), TEST
 *
 * THIS IS A TEST OF SOURCE MODE 1
 * USING THE LDFPS INSTR
 *

024320	000004			TST45: SCOPE			
5064 024322	012737	024330	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
5065 024330	012700	024406		MOV	#210\$,R0	;SET UP TEST DATA IN BUFFER.	
5066 024334	012710	147517		MOV	#147517,(R0)		
5067 024340	012737	147517	001240	MOV	#147517,STMP3	;SAVE DATA IN CASE OF ERROR.	
5068 024346	012737	024362	001236	MOV	#220\$,STMP2		
5069 024354	012737	024446	000004	MOV	#230\$,ERRVECT	;SET UP FOR TRAPS TO 4.	
5070 024362	170110			220\$: LDFPS	(R0)	;TEST INSTRUCTION.	
5071				STFPS	R5	;GET FPS	
5072 024364	170205			CMP	R0,#210\$;IS R0 CORRECT?	
5073				BNE	240\$;BR IF NOT.	
5074 024366	020027	024406		CMP	#147517,R5	;IS FPS CORRECT?	
5075 024372	001007			BNE	250\$		
5076 024374	022705	147517		BR	260\$;BR IF NOT.	
5077 024400	001013						
5078 024402	000436						
5079							
5080							
5081 024404	177777						
5082 024406	147517						
5083 024410	177777						
5084							
5085							
5086 024412	012737	024406	001240	240\$: REPORT	R0 INCORRECT.		
5087 024420	010037	001242		MOV	#210\$,STMP3		
5088 024424	104225			MOV	R0,STMP4		
5089 024426	000424			ERROR	+225		
5090				BR	260\$;R0 BAD BUT FSRC FAILED	
5091							
5092 024430	012737	147517	001240	250\$: REPORT	FPS INCORRECT.		
5093 024436	010537	001242		MOV	#147517,STMP3	;REPORT :PS INCORRECT.	
5094 024442	104226			MOV	R5,STMP4		
5095 024444	000415			ERROR	+226		
5096				BR	260\$		
5097							
5098							
5099							
5100 024446							
5101 024446	011602						
5102 024450	020227	024364		MOV	(SP),R2		
5103 024454	001405			CMP	R2,#220\$+2		
5104 024456	020227	024366		BEQ	1\$		
5105 024462	001402			CMP	R2,#220\$+4		
5106 024464	000137	051774		BEQ	1\$		
5107 024470	022626			JMP	CPSPUR		
5108 024472	010237	001236		1\$: CMP	(SP)+,(SP)+		
5109 024476	104227			MOV	R2,STMP2		
5110				ERROR	+227	;ODD ADRES	
5111 024500				260\$:			

024500 104412

RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

```

5112          SBTTL TEST # 46 - SOURCE MODES, MODE 2 (FL=0), TEST
***** TEST 46 SOURCE MODES, MODE 2 (FL=0), TEST *****
* THIS IS A TEST OF SOURCE MODE 2
* USING THE LDFPS INSTR
***** TST46: SCOPE *****

5113 024502 000004      200$: MOV #200$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5114 024504 012737 024512 001110      MOV #210$,R0 ;SET UP TEST DATA IN BUFFER.
5115 024512 012700 024570
5116 024516 012710 145212
5117 024522 012737 145212 001240      MOV #145212,(R0) ;SAVE DATA IN CASE OF ERROR.
5118 024530 012737 024544 001236      MOV #220$,STMP3
5119 024536 012737 024630 000004      MOV #230$,ERRVECT ;SET UP FOR TRAPS TO 4.
5120 024544 170120      220$: LDFPS (R0)+ ;TEST INSTRUCTION.
5121
5122 024546 170205      STFPS R5 ;GET FPS
5123
5124 024550 020027 024572      CMP R0,#210$+2 ;IS R0 CORRECT?
5125 024554 001007      BNE 240$ ;BR IF NOT.
5126 024556 022705 145212      CMP #145212,RS ;IS THE FPS CORRECT?
5127 024562 001013      BNE 250$ ;BR IF NOT.
5128 024564 000436      BR 260$ ;TEST BUFFER AND DATA:
5129
5130
5131 024566 177777      210$: .WORD -1
5132 024570 177777
5133 024572 177777
5134
5135
5136
5137 024574 012737 024572 001240      :REPORT R0 INCORRECT.
5138 024602 010037 001242      240$: MOV #210$+2,STMP3
5139 024606 104230      MOV R0,STMP4
5140 024610 000424      ERROR +230 ;R0 BAD BUT FSRC FAILED
5141      BR 260$ ;REPORT FPS INCORRECT.
5142
5143 024612 012737 145212 001240      250$: MOV #145212,STMP3 ;REPORT FPS INCORRECT.
5144 024620 010537 001242
5145 024624 104231
5146 024626 000415
5147
5148
5149
5150
5151
5152 024630
5153 024630 011602      :TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING
5154 024632 020227 024546      :EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT
5155 024636 001405      :FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO 4 HANDLING.
5156 024640 020227 024550      230$: MOV (SP),R2
5157 024644 001402      CMP R2,#220$+2
5158 024646 000137 051774      BEQ 1$ ;CPSPUR
5159 024652 022626      1$: CMP (SP)+,(SP)+ ;R2,STMP2
5160 024654 010237 001236

```

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 50-1
TEST # 46 - SOURCE MODES, MODE 2 (FL=0), TEST

SEQUENCE

5161 024660 104232
5162
5163 024662 024662 104412

ERROR +232

:ODD ADRES
:BUT FDSTX IN ST 771

260\$:

RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

5164

.SBTTL TEST # 47 - SOURCE MODES, MODE 4 (FL=0), TEST

::***** TEST 47 SOURCE MODES, MODE 4 (FL=0), TEST

:: THIS IS A TEST OF SOURCE MODE 4
 :: USING THE LDFPS INSTR

5165	024664	000004			TST47: SCOPE				
5166	024666	012737	024674	001110	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
5167	024674	012700	024764		200\$: MOV	#210\$+2,R0	:SET UP THE TEST DATA BUFFER.		
5168	024700	012760	105252	177776	200\$: MOV	#105252,-2(R0)			
5169	024706	012737	105252	001240	200\$: MOV	#105252,\$TMP3	:SAVE DATA IN CASE OF ERROR.		
5170	024714	012737	024730	001236	200\$: MOV	#220\$,TMP2			
5171	024722	012737	025030	000004	200\$: MOV	#230\$,ERRVEC			
5172	024730	170140			220\$: LDFPS	-(R0)			
5173	024732	170205			220\$: STFPS	R5			
5174	024734	020027	024762		220\$: CMP	R0,#210\$			
5175	024740	001015			220\$: BNE	240\$			
5176	024742	022705	105252		220\$: CMP	#105252,R5			
5177	024746	001021			220\$: BNE	250\$			
5178	024750	000444			220\$: BR	260\$			
5179	024752	177777	177777	177777	210\$: -1,-1,-1,-1				
5180	024762	177777			210\$: -1				
5181	024764	177777	177777	177777	210\$: -1,-1,-1,-1				
5182									
5183	024774	012737	024762	001240	240\$: MOV	#210\$,TMP3			
5184	025002	010037	001242		240\$: MOV	R0,\$TMP4			
5185	025006	104233			240\$: ERROR	+233	:R0 BAD BUT FSRC FAILED		
5186	025010	000424			240\$: BR	260\$			
87	025012	012737	105252	001240	250\$: MOV	#105252,\$TMP3	:REPORT FPS INCORRECT.		
88	025020	010537	001242		250\$: MOV	R5,\$TMP4			
5189	025024	104234			250\$: ERROR	+234			
5190	025026	000415			250\$: BR	260\$			
5191	025030	011602			250\$: MOV	(SP),R2			
5192	025032	020227	024732		250\$: CMP	R2,#220\$+2			
5193	025036	001405			250\$: BEQ	1\$			
5194	025040	020227	024734		250\$: CMP	R2,#220\$+4			
5195	025044	001402			250\$: BEQ	1\$			
5196	025046	000137	051774		250\$: JMP	CPSPUR			
5197	025052	022626			250\$: CMP	(SP)+,(SP)+			
5198	025054	010237	001236		250\$: MOV	R2,\$TMP2			
5199	025060	104235			250\$: ERROR	+235	:DDD ADRES		
5200	025062	025062	104412		260\$: RSETUP		:GO INITIALIZE THE FPS AND STACK; AND :SEE IF THE USER HAS EXPRESSED :THE DESIRE TO CHANGE THE SOFTWARE :VIRTUAL CONSOLE SWITCH REGISTER (HAS :THE USER TYPED CONTROL G?).		

5201

.SBTTL TEST # 50 - SOURCE MODES, MODE 3 (FL=0), TEST

;***** TEST 50 SOURCE MODES, MODE 3 (FL=0), TEST

;* THIS IS A TEST OF SOURCE MODE 3
;* USING THE LDFPS INSTR

;***** TST50: SCOPE

5202 025064 000004	025066 012737 025074 001110	200\$: MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
5203 025074 012700 025176		MOV #210\$,R0		
5204 025100 012710 025166		MOV #220\$, (R0)		
5205 025104 012737 103456 025166		MOV #103456,220\$		
5206 025112 012737 103456 001240		MOV #103456,\$TMP3		
5207 025120 012737 025134 001236		MOV #230\$, \$TMP2		
5208 025126 012737 025244 000004		MOV #240\$,ERRVECT	;SET UP FOR TRAPS TO 4.	
5209 025134 170130		LDFPS @R0)+	;TEST INSTRUCTION.	
5210 025136 170205		STFPS R5	;GET THE FPS.	
5211 025140 020027 025200		CMP R0,#210\$+2	;IS R0 CORRECT?	
5212 025144 001021		BNE 250\$;BR IF NOT.	
5213 025146 022705 103456		CMP #103456,R5	;IS THE FPS CORRECT?	
5214 025152 001025		BNE 260\$;BR IF NOT.	
5215 025154 000450		BR 270\$		
5216				
5217				
5218			:TEST BUFFER AND DATA:	
5219 025156 177777 177777 177777		-1,-1,-1,-1		
5220 025166 177777		220\$: -1		
5221 025170 177777 177777 177777		-1,-1,-1		
5222 025176 025166 177777 177777		210\$: 220\$,-1,-1,-1.		
5223				
5224				
5225			:REPORT R0 INCORRECT.	
5226 025210 012737 025200 001240		250\$: MOV #210\$+2,\$TMP3		
5227 025216 010037 001242		MOV R0,\$TMP4		
5228 025222 104236		ERROR +236		:R0 BAD BUT FSRC FAILED
5229 025224 000424		BR 270\$		
5230				
5231			:REPORT FPS INCORRECT.	
5232 025226 012737 103456 001240		260\$: MOV #103456,\$TMP5	;REPORT FPS INCORRECT.	
5233 025234 010537 001242		MOV R5,\$TMP4		
5234 025240 104237		ERROR +237		
5235 025242 C00415		BR 270\$		
5236			:TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING	
5237			:EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT .	
5238			:FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO 4 HANDLING.	
5239 025244 011602		340\$: MOV (SP),R2		
5240 025246 020227 025136		CMP R2,#230\$+2		
5241 025252 001405		BEQ 1\$		
5242 025254 020227 025140		CMP R2,#230\$+4		
5243 025260 001402		BEQ 1\$		
5244 025262 000137 051774		JMP CPSPUR		
5245 025266 022626		CMP (SP)+(SP)+		
5246 025270 010237 001236		MOV R2,\$TMP2		
5247 025274 104240		ERROR +240		:DDD ADRES
5248 025276 025276 104412		270\$: RSETUP		:GO INITIALIZE THE FPS AND STACK; AND

;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

5249

.SBTTL TEST # 51 - SOURCE MODES, MODE 5 (FL=0), TEST

:*****
:TEST 51 SOURCE MODES, MODE 5 (FL=0), TEST: THIS IS A TEST OF SOURCE MODE 5
: USING THE LDFPS INSTR:*****
TST51: SCOPE

5250 025300 000004	025302 012737 025310 001110	200\$: MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
5251 025310 012700 025410	025314 012760 025376 177776	MOV #210\$+2,R0	;SET UP THE TEST DATA BUFFER.	

5252 025314 012760 025376
 5253 025322 012737 045412 025376
 5254 025330 012737 045412 001240
 5255 025336 012737 025352 001236
 5256 025344 012737 025452 000004

230\$: LDFPS a-(R0)	;SET UP FOR TRAPS TO 4.
STFPS R5	;TEST INSTRUCTION.
CMP R0,#210\$;GET THE FPS.
BNE 250\$;IS R0 CORRECT?
CMP #45412,R5	;BR IF NOT.
BNE 260\$;IS THE FPS CORRECT?
BR 270\$;BR IF NOT.

5264

5265

5266 :TEST BUFFER AND DATA:

5267 025374 177777	-1
5268 025376 177777	-1
5269 025400 177777 177777 177777	-1,-1,-1
5270 025406 025376 177777 177777	220\$,-1,-1,-1

5271

5272

5273 :REPORT R0 INCORRECT.

5274 025416 012737 025406 001240	250\$: MOV #210\$,STMP3
5275 025424 010037 001242	MOV R0,STMP4
5276 025430 104241	ERROR +241
5277 025432 000424	BR 270\$

;R0 BAD BUT FSRC FAILED

5278 :REPORT FPS INCORRECT.

5280 025434 012737 045412 001240	260\$: MOV #45412,\$TMP3
5281 025442 010537 001242	MOV R5,\$TMP4
5282 025446 104242	ERROR +242
5283 025450 000415	BR 270\$

;REPORT FPS INCORRECT.

5284 :TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING
 5285 :EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT
 5286 :FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO 4 HANDLING.

5287 025452 011602	240\$: MOV (SP),R2
5288 025454 020227	CMP R2,#230\$+2
5289 025460 001405	BEQ 1\$
5290 025462 020227	CMP R2,#230\$+4
5291 025466 001402	BEQ 1\$
5292 025470 000137	JMP CPSPUR
5293 025474 022626	CMP (SP)+,(SP)+
5294 025476 010237	MOV R2,\$TMP2
5295 025502 104243	ERROR +243
5296 025504 104412	RSETP

1\$: ;ODD ADRES

270\$: ;GO INITIALIZE THE FPS AND STACK; AND

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE E 10
TEST # 51 - SOURCE MODES, MODE 5 (FL=0), TEST

SEQUENCE '21

;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

5297

.SBTTL TEST # 52 - SOURCE MODES, MODE 6 (FL=0), TEST

*: TEST 52 SOURCE MODES, MODE 6 (FL=0), TEST
*
*: THIS IS A TEST OF SOURCE MODE 6
*: USING THE LDFPS INSTR

025506 000004 TST52: SCOPE
5298 025510 012767 025515 153372 .DISABLE AMA ;DISABLE MODE 6 TO MODE 3 CONVERSIONS
5299 025510 012767 025515 153372 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5300 025516 012700 020405 153372 MOV #210\$-5201,R0 ;SET UP THE TEST DATA BUFFER.
5301 025522 012767 046543 000056 MOV #46543,210\$
5302 025530 012767 046543 153502 MOV #46543,\$TMP3 ;SAVE DATA IN CASE OF ERROR.
5303 025536 012767 025554 153472 MOV #220\$,TMP2
5304 025544 005001 CLR R1
5305 025546 012767 025674 152230 MOV #230\$,ERRVECT ;SET UP FOR TRAPS TO 4.
5306 025554 170160 005201 220\$: LDFPS 5201(R0) ;TEST INSTRUCTION.
5307 025560 170204 STFPS R4 ;GET THE FPS.
5308 025562 005701 TST R1 ;WAS PC CORRECT AFTER EXECUTION?
5309 025564 001033 BNE 240\$;BR IF NOT.
5310 025566 020027 020405 CMP R0 #210\$-5201 ;IS R0 CORRECT?
5311 025572 001012 BNE 250\$;BR IF NOT.
5312 025574 022704 046543 CMP #46543,R4 ;IS THE FPS CORRECT?
5313 025600 001016 BNE 260\$;BR IF NOT.
5314 025602 000451 BR 270\$
5315
5316
5317 :TEST BUFFER AND DATA:
5318 025604 177777 210\$: -1
5319 025606 177777 177777 177777 210\$: -1,-1,-1,-1
5320 025616 177777 -1
5321
5322 :REPORT R0 INCORRECT.
5323 025620 012767 020405 153412 250\$: MOV #210\$-5201,\$TMP3
5324 025626 010067 153410 MOV R0,\$TMP4
5325 025632 104244 ERROR +244 ;R0 BAD BUT FSRC FAILED
5326 025634 000434 BR 270\$
5327
5328 :REPORT FPS INCORRECT.
5329 025636 012767 046543 153374 260\$: MOV #46543,\$TMP3 ;REPORT FPS INCORRECT.
5330 025644 010467 153372 MOV R4,\$TMP4
5331 025650 104245 ERROR +245
5332 025652 000425 BR 270\$
5333
5334 :REPORT PC INCORRECT AFTER INSTRUCTION.
5335 025654 012767 025560 153356 240\$: MOV #220\$+4,\$TMP3
5336 025662 012767 025556 153352 MOV #220\$+2,\$TMP4
5337 025670 104246 ERROR +246 ;PC X
5338 025672 000415 BR 270\$
5339 :TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING
5340 :EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT
5341 :FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO ~ HANDLING.
5342 025674 011602 230\$: MOV (SP),R2
5343 025676 020227 025556 CMP R2,#220\$+2
5344 025702 001405 BEQ 1\$
5345 025704 020227 025560 CMP R2,#220\$+4

CKFPCD0 P11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 54-1 G 10
TEST # 52 - SOURCE MODES, MODE 6 (FL=0), TEST

SEQUENCE 123

5346 025710 001402
5347 025712 000167 024056
5348 025716 022626
5349 025720 010267 153312
5350 025724 104247
5351 025726 104412

1\$: BEQ 1\$
JMP CPSPUR
CMP (SP)+, (SP)+
MOV R2, \$TMP2
ERROR +247 ;ODD ADRES

270\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

.ENABL AMA ;REENABLE MODE 6 TO MODE 7 CONVERSIONS

5352

5353

SBTTL TEST # 53 - SOURCE MODES, MODE 7 (FL=0), TEST

TEST 53 SOURCE MODES, MODE 7 (FL=0), TEST
*
* THIS IS A TEST OF SOURCE MODE 7
* USING THE LDFPS INSTR

025730 000004 TST53: SCOPE
 5354 025732 012737 025740 001110 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.
 5355 025740 012700 020645 005201 200\$: MOV #210\$-5201,R0 ;SET UP THE TEST DATA BUFFER.
 5356 025744 012760 026036 005201 200\$: MOV #220\$,5201(R0)
 5357 025752 012737 004547 026036 200\$: MOV #4547,220\$
 5358 025760 012737 004547 001240 200\$: MOV #4547,STMP3 ;SAVE DATA IN CASE OF ERROR.
 5359 025766 012737 026004 001236 200\$: MOV #230\$,STMP2
 5360 025774 005001 026132 000004 230\$: CLR R1
 5361 025776 012737 026132 000004 230\$: MOV #240\$,ERRVECT ;SET UP FOR TRAPS TO 4.
 5362 026004 170170 005201 026004 230\$: LDFPS a5201(R0) ;TEST INSTRUCTION.
 5363 026010 170204 026004 005701 230\$: STFPS R4 ;GET THE FPS.
 5364 026012 005701 026004 001036 230\$: TST R1 ;WAS PC CORRECT AFTER EXECUTION?
 5365 026014 001036 026004 001015 230\$: BNE 250\$;BR IF NOT.
 5366 026016 020027 020645 001015 230\$: CMP R0,#210\$-5201 ;IS R0 CORRECT?
 5367 026022 001015 022704 004547 230\$: BNE 260\$;BR IF NOT.
 5368 026024 022704 004547 001021 230\$: CMP #4547,R4 ;IS THE FPS CORRECT?
 5369 026030 001021 022704 000454 230\$: BNE 270\$;BR IF NOT.
 5370 026032 000454 022704 000454 230\$: BR 280\$
 5371
 5372
 5373 :TEST BUFFER AND DATA:
 5374 026034 177777 177777 177777 177777 220\$: -1
 5375 026036 177777 177777 177777 177777 220\$: .WORD -1,-1,-1,-1
 5376 026046 177777 177777 177777 177777 210\$: .WORD -1,-1,-1,-1
 5377
 5378 :REPORT R0 INCORRECT.
 5379 026056 012737 020645 001240 260\$: MOV #210\$-5201,STMP3
 5380 026064 010037 001242 001240 260\$: MOV R0,STMP4
 5381 026070 104250 001242 001240 260\$: ERROR +250 ;R0 BAD BUT FSRC FAILED
 5382 026072 000434 001240 260\$: BR 280\$
 5383
 5384 :REPORT FPS INCORRECT.
 5385 026074 012737 004547 001240 270\$: MOV #4547,STMP3 ;REPORT FPS INCORRECT.
 5386 026102 010437 001242 001240 270\$: MOV R4,STMP4
 5387 026106 104251 001242 001240 270\$: ERROR +251
 5388 026110 000425 001240 270\$: BR 280\$
 5389
 5390 :REPORT PC INCORRECT AFTER INSTRUCTION.
 5391 026112 012737 026010 001240 250\$: MOV #230\$+4,STMP3
 5392 026120 012737 026006 001242 250\$: MOV #230\$+2,STMP4
 5393 026126 104252 001242 001240 250\$: ERROR +252 ;PC X
 5394 026130 000415 001240 250\$: BR 280\$
 5395 :TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING
 5396 :EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT
 5397 :FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO 4 HANDLING.
 5398 026132 011602 026006 026006 240\$: MOV (SP),R2
 5399 026134 020227 001405 026006 240\$: CMP R2,#230\$+2
 5400 026140 020227 026010 001405 240\$: BEQ 1\$
 5401 026142 020227 026010 001405 240\$: CMP R2,#230\$+4

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 55-1
TEST # 53 - SOURCE MODES, MODE 7 (FL=0), TEST

I 10
SEQUENCE 125

5402 026146 001402
5403 026150 000137 051774
5404 026154 022626
5405 026156 010237 001236
5406 026162 104253
5407 026164 026164 104412
5408

BEQ 1\$
JMP CPSPUR
1\$: CMP (SP)+, (SP)+
MOV R2, \$TMP2
ERROR +253 :DDD ADDRESS
280\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
.ENABL AMA :SEE IF THE USER HAS EXPRESSED
THE DESIRE TO CHANGE THE SOFTWARE
VIRTUAL CONSOLE SWITCH REGISTER (HAS
THE USER TYPED CONTROL G?).

5415

.SBTTL TEST # 54 - SOURCE MODES, MODE 2 GR7 (FL=1), TEST

;TEST 54 SOURCE MODES, MODE 2 GR7 (FL=1), TEST

;* THIS IS A TEST OF THE LDCLD WITH
;* IMMEDIATE ADDRESSING MODE
;*

026166 000004			TST54: SCOPE			
5416 026170 012737	026176 001110	200\$:	MOV #200\$,SLPERR	,SET UP THE LOOP ON ERROR ADDRESS.	:DPM002	
5417 026176 012737	026222 001236		MOV #210\$,STMP2	:SAVE DATA IN CASE OF ERROR.		
5418 026204 012737	026274 000004		MOV #220\$,ERRVECT	:SET UP FOR TRAPS TO 4.		
5419 026212 012700	000300		MOV #300,R0			
5420 026216 170100			LDFPS R0			
5421 026220 005001			CLR R1			
5422						
5423 026222 177027		210\$:	LDCLD (R7)+,AC0	;TEST INSTRUCTION.		
5424 026224 005201			5201			
5425 026226 005201			5201			
5426 026230 005201			5201			
5427 026232 005201			5201			
5428						
5429 026234 020127 000003			CMP BE0 R1 #3	:WAS PC CORRECT AFTER EXECUTION?		
5430 026240 001421			230\$:BR IF YES.		
5431						
5432						
5433				:REPORT PC INCORRECT AFTER INSTRUCTION.		
5434 026242 012704 026220	000003		MOV #210\$+4,R4			
5435 026246 162701			SUB #3,R1			
5436 026252 006301			ASL R1			
5437 026254 160104			SUB R1,R4			
5438 026256 010437 001242			MOV R4,STMP4			
5439 026262 012737 026226	U01240		MOV #210\$+4,STMP3			
5440 026270 104254			ERROR +254	;BAD CONSTANT		
5441 026272 000404			BR 230\$			
5442				:TRAP HERE THROUGH VECTOR FOUR. SEE IF THE TRAP WAS DURING		
5443				:EXECUTION OF THE FPS INSTRUCTION BEING TESTED. IF SO REPORT		
5444				:FAILURE. OTHERWISE GO TO THE SPURIOUS TRAP TO 4 HANDLING.		
5445 026274 011637 001236		220\$:	MOV (SP),STMP2			
5446 026300 022626			CMP (SP)+,(SP)+			
5447 026302 104255			ERROR +255	;BAD CONSTANT ODD ADD		
5448						
5449 026304 026304 104412		230\$:	RSETUP	:GO INITIALIZE THE FPS AND STACK: AND		
				:SEE IF THE USER HAS EXPRESSED		
				:THE DESIRE TO CHANGE THE SOFTWARE		
				:VIRTUAL CONSOLE SWITCH REGISTER (HAS		
				:THE USER TYPED CONTROL G?).		

5456

.SBTTL TEST # 55 - SOURCE MODES, MODE 2 (FL=1), TEST

***** TEST 55 SOURCE MODES, MODE 2 (FL=1), TEST *****

*** THIS IS A TEST OF THE LDCLD INSTR
*** WITH MODE 2.

026306	000004			TST55: SCOPE				
5457 026310	012737	0263*4	001110	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		
5458 026316	013737	0263	001236	MOV	210\$,STMP2	:SAVE DATA IN CASE OF ERROR.	:DPM002	
5459 026324	012700	00030(MOV	#300,R0			
5460 026330	170100			LDFPS	R0			
5461 026332	012700	026426		MOV	#220\$,R0	:SET UP THE TEST DATA BUFFER.		
5462 026336	177020			LDCLD	(R0)+,AC0	:TEST INSTRUCTION.		
5463				STFPS	R4	:GET THE FPS.		
5464 026340	170204			MOV	#230\$,R1	:GET THE RESULT.		
5465 026342	012701	026436		MOV	#200,R2			
5466 026346	012702	000200		LDFPS	R2			
5467 026352	170102			STD	AC0,(R1)			
5468 026354	174011			CMP	R0,#220\$+4	:IS R0 CORRECT?		
5469 026356	020027	026432		BEO	240\$			
5470 026362	001407			:REPORT	R0 INCORRECT.			
5471				MOV	R0,STMP4			
5472 026364	010037	001242		MOV	#220\$+4,STMP3			
5473 026370	012737	026432	001240	ERROR	+256	:BAD CONST		
5474 026376	104256			BR	250\$			
5475 026400	000422			240\$: CMP	#300,R4 :IS THE FPS CORRECT?			
5476				BEO	250\$			
5477 026402	022704	000300		:REPORT	FPS INCORRECT.			
5478 026406	001417			MOV	R4,STMP4			
5479				MOV	#300,STMP3			
5480				ERROR	+257	:FPS X		
5481 026410	010437	001242		BR	250\$			
5482 026414	012737	000300	001240	:TEST BUFFER AND DATA:				
5483 026422	104257			220\$: .WORD	01234,67076,54321,012345			
5484 026424	000410			230\$: -1,-1,-1,-1				
5485				250\$:	RSETUP	:GO INITIALIZE THE FPS AND STACK; AND		
5486						:SEE IF THE USER HAS EXPRESSED		
5487 026426	001234	067076	054321			:THE DESIRE TO CHANGE THE SOFTWARE		
5488 026436	177777	177777	177777			:VIRTUAL CONSOLE SWITCH REGISTER (HAS		
5489						:THE USER TYPED CONTROL G?).		
5490 026446								
026446	104412							

5697

.SATTL TEST # 56 - LDCIF AND LDCLF TEST

TEST 56 LBCF AND LDCF TEST

* THIS IS A TEST OF THE LDCIF AND
* THE LDCLF INSTRUCTIONS.

5566 026642 047600 000000	33\$: WORD 47600,0	:ANTICIPATED ERRONEOUS RESULT.
5567 026646 000017	34\$: 17	:FPS BEFORE EXECUTION.
5568 026650 000006	0	:FPS AFTER EXECUTION.
5569 026652 177777	-1	:ANTICIPATED ERRONEOUS FPS.
5570 026654 104264	35\$: ERROR +264	:ST 107 BAD
5571 026656 000401	BR 36\$:CONSTANT 231 !NSD
5572 026660 104261	ERROR +261	:215
5573 026662	36\$: :OPERAND=1, FL=0	
5574 026662 012737 026670 001110	MOV #240\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5575 026670 004737 027724	240\$: JSR PC 1000\$:GO EXECUTE THE INSTRUCTION.
5576 026674 000001 000000	41\$: .WORD 1,0	:FSRC OPERAND.
5577 026700 040200 000000	42\$: .WORD 40200,0	:EXPECTED RESULT.
5578 026704 044200 000000	43\$: .WORD 44200,0	:ANTICIPATED ERRONEOUS RESULT.
5579 026710 000017	44\$: 17	:FPS BEFORE EXECUTION.
5580 026712 000000	0	:FPS AFTER EXECUTION.
5581 026714 177777	-1	:ANTICIPATED ERRONEOUS FPS.
5582 026716 104264	45\$: ERROR +264	:REPORT RESULT INCORRECT.
5583 026720 000401	BR 46\$	
5584 026722 104261	ERROR +261	:REPORT FPS INCORRECT.
5585 026724	46\$: :OPERAND=	
5586 026724 012737 026732 001110	PATTERN FL=0	
5587 026732 004737 027724	MOV #250\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5588 026736 000252 000000	250\$: JSR PC 1000\$:GO EXECUTE THE INSTRUCTION.
5589 026742 042052 000000	51\$: .WORD 252,0	:FSRC OPERAND.
5590 026746 046052 000000	52\$: .WORD 42052,0	:EXPECTED RESULT.
5591 026752 000000	53\$: .WORD 46052,0	:ANTICIPATED ERRONEOUS RESULT.
5592 026754 000000	54\$: 0	:FPS BEFORE EXECUTION.
5593 026756 177777	0	:FPS AFTER EXECUTION.
5594 026760 104264	-1	:ANTICIPATED ERRONEOUS FPS.
5595 026762 000401	55\$: ERROR +264	:REPORT RESULT INCORRECT.
5596 026764 104261	BR 56\$	
5597 026766	56\$: ERROR +261	:REPORT FPS INCORRECT.
5598 026766 012737 026774 001110	56\$: :OPERAND=-40000 FL=0	
5599 026774 004737 027724	MOV #260\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5600 027000 140000 000000	260\$: JSR PC 1000\$:GO EXECUTE THE INSTRUCTION.
5601 027004 143600 000000	61\$: .WORD -40000,0	:FSRC OPERAND.
5602 027010 043600 000000	62\$: .WORD 143600,0	:EXPECTED RESULT.
5603 027014 000007	63\$: .WORD 43600,0	:ANTICIPATED ERRONEOUS RESULT.
5604 027016 000010	64\$: 7	:FPS BEFORE EXECUTION.
5605 027020 177777	10	:FPS AFTER EXECUTION.
5606 027022 104265	-1	:ANTICIPATED ERRONEOUS FPS.
5607 027024 000401	65\$: ERROR +265	:SET SIGN) ST 146
5608 027026 104261	BR 66\$	
5609 027030	ERROR +261	:REPORT FPS INCORRECT.
5610 027030 012737 027036 001110	66\$: :OPERAND=-1 FL=0	
5611 027036 004737 027724	MOV #270\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5612 027042 177777 000000	270\$: JSR PC 1000\$:GO EXECUTE THE INSTRUCTION.
5613 027045 140200 000000	71\$: .WORD -1,0	:FSRC OPERAND.
5614 027052 144000 000400	72\$: .WORD 140200,0	:EXPECTED RESULT.
5615 027052	73\$: .WORD 144000,400	:ANTICIPATED ERRONEOUS RESULT.

5603 027056 000000		74\$: 0	:FPS BEFORE EXECUTION.	
5604 027060 000010		10	:FPS AFTER EXECUTION.	
5605 027062 177777		-1	:ANTICIPATED ERRONEOUS FPS.	
5606 027064 104266		75\$: ERROR +266	:ST 372 TO 152 INTO	
5607 027066 000612		BR 6\$:112 (BUF XNBT)	
5608 027070 104261		ERROR +261	:REPORT FPS INCORRECT.	
5609 027072		76\$:		
5610				
5611		:OPERAND=PATTERN	FL=0	
5612 027072 012737 027100 001110		MOV #280\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002	
5613 027100 004737 027724		280\$: JSR PC 1000\$:GO EXECUTE THE INSTRUCTION.	
5614 027104 125252 000000		81\$: .WORD 125252,0	:FSRC OPERAND.	
5615 027110 143652 126000		82\$: .WORD 143652,126000	:EXPECTED RESULT.	
5616 027114 043652 126000		83\$: .WORD 43652,126000	:ANTICIPATED ERRONEOUS RESULT.	
5617 027120 000007		84\$: 7	:FPS BEFORE EXECUTION.	
5618 027122 000010		10	:FPS AFTER EXECUTION.	
5619 027124 177777		-1	:ANTICIPATED ERRONEOUS FPS.	
5620 027126 104265		85\$: ERROR +265	:REPORT RESULT INCORRECT.	
5621 027130 000401		BR 86\$		
5622 027132 104261		ERROR +261	:REPORT FPS INCORRECT.	
5623 027134		86\$:		
5624				
5625		:OPERAND	POS FL-1	
5626 027134 012737 027142 001110		MOV #290\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002	
5627 027142 004737 027724		290\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5628 027146 040000 000000		91\$: .WORD 40000,0	:FSRC OPERAND.	
5629 027152 047600 000000		92\$: .WORD 47600,0	:EXPECTED RESULT.	
5630 027156 043600 000000		93\$: .WORD 43600,0	:ANTICIPATED ERRONEOUS RESULT.	
5631 027162 000117		94\$: 117	:FPS BEFORE EXECUTION.	
5632 027164 000100		100	:FPS AFTER EXECUTION.	
5633 027166 177777		-1	:ANTICIPATED ERRONEOUS FPS.	
5634 027170 104267		95\$: ERROR +267	:ST 107 CONSTANT	
5635 027172 000401		BR 96\$:BAD 237 INST 217	
5636 027174 104261		ERROR +261	:REPORT FPS INCORRECT.	
5637 027176		96\$:		
5638				
5639		:OPERAND=1	FL=1	
5640 027176 012737 027204 001110		MOV #300\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002	
5641 027204 004737 027724		300\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5642 027210 000000 000001		101\$: .WORD 0,1	:FSRC OPERAND.	
5643 027214 040200 000000		102\$: .WORD 40200,0	:EXPECTED RESULT.	
5644 027220 034200 000000		103\$: .WORD 34200,0	:ANTICIPATED ERRONEOUS RESULT.	
5645 027224 000100		104\$: 100	:FPS BEFORE EXECUTION.	
5646 027226 000100		100	:FPS AFTER EXECUTION.	
5647 027230 177777		-1	:ANTICIPATED ERRONEOUS FPS.	
5648 027232 104267		105\$: ERROR +267	:REPORT RESULT INCORRECT.	
5649 027234 000401		BR 106\$		
5650 027236 104261		ERROR +261	:REPORT FPS INCORRECT.	
5651 027240		106\$:		
5652				
5653		:OPERAND=	PATTERN FL=1	
5654 027240 012737 027246 001110		MOV #310\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. :DPM002	
5655 027246 004737 027724		310\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5656 027252 000000 000252		111\$: .WORD 0,252	:FSRC OPERAND.	
5657 027256 042052 000000		112\$: .WORD 42052,0	:EXPECTED RESULT.	
5658 027262 035052 000000		113\$: .WORD 36052,0	:ANTICIPATED ERRONEOUS RESULT.	
5659 027266 000111		114\$: 111	:FPS BEFORE EXECUTION.	

5660	027270	000100		100		:FPS AFTER EXECUTION.	
5661	027272	177777		-1		:ANTICIPATED ERRONEOUS FPS.	
5662	027274	104267		115\$: ERROR	+267	:REPORT RESULT INCORRECT.	
5663	027276	000401		BR	116\$		
5664	027300	104261		ERROR	+261	:REPORT FPS INCORRECT.	
5665	027302			116\$:			
5666							
5667				:OPERAND=-40000.0	FL=1		
5668	027302	012737	027310	001110	MOV #320\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002	
5669	027310	004737	027724		320\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5670	027314	140000	000000		121\$: .WORD -40000.0	:FSRC OPERAND.	
5671	027320	147600	000000		122\$: .WORD 147600.0	:EXPECTED RESULT.	
5672	027324	047600	000000		123\$: .WORD 47600.0	:ANTICIPATED ERRONEOUS RESULT	
5673	027330	000107			124\$: 107	:FPS BEFORE EXECUTION.	
5674	027332	000110			110	:FPS AFTER EXECUTION.	
5675	027334	177777			-1	:ANTICIPATED ERRONEOUS FPS.	
5676	027336	104265			125\$: ERROR	+265 :SET SIGN	
5677	027340	000401			BR	126\$	
5678	027342	104261			ERROR	+261	:REPORT FPS INCORRECT.
5679	027344				126\$:		
5680							
5681				:OPERAND=-1,-1	FL=1		
5682	027344	012737	027352	001110	MOV #330\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002	
5683	027352	004737	027724		330\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5684	027356	177777	177777		131\$: .WORD -1,-1	:FSRC OPERAND.	
5685	027362	140200	000000		132\$: .WORD 140200.0	:EXPECTED RESULT.	
5686	027366	150000	000000		133\$: .WORD 150000.0	:ANTICIPATED ERRONEOUS RESULT.	
5687	027372	000100			134\$: 100	:FPS BEFORE EXECUTION.	
5688	027374	000110			110	:FPS AFTER EXECUTION.	
5689	027376	177777			-1	:ANTICIPATED ERRONEOUS FPS.	
5690	027400	104266			135\$: ERROR	+266 :(BUT XMBT)	
5691	027402	000401			BR	136\$	
5692	027404	104261			ERROR	+261	:REPORT FPS INCORRECT.
5693	027406				136\$:		
5694							
5695				:OPERAND=-PATTERN	FL=1,	ROUND MODE	
5696	027406	012737	027414	001110	MOV #340\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002	
5697	027414	004737	027724		340\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5698	027420	125252	125252		141\$: .WORD 125252,125252	:FSRC OPERAND.	
5699	027424	147652	125253		142\$: .WORD 147652,125253	:EXPECTED RESULT.	
5700	027430	047652	125253		143\$: .WORD 47652,125253	:ANTICIPATED ERRONEOUS RESULT.	
5701	027434	J00105			144\$: 105	:FPS BEFORE EXECUTION.	
5702	027436	000110			110	:FPS AFTER EXECUTION.	
5703	027440	177777			-1	:ANTICIPATED FRNONEOUS FPS.	
5704	027442	104265			145\$: ERROR	+265 :REPORT RESULT INCORRECT.	
5705	027444	000401			BR	146\$	
5706	027446	104261			ERROR	+261	:REPORT FPS INCORRECT.
5707	027450				146\$:		
5708							
5709				:OPERAND=77777,177500	FL=1,	ROUND MODE	
5710	027450	012737	027456	001110	MOV #350\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002	
5711	027456	004737	027724		350\$: JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
5712	027462	077777	177500		151\$: .WORD 77777,177500	:FSRC OPERAND.	
5713	027466	047777	177777		152\$: .WORD 47777,177777	:EXPECTED RESULT.	
5714	027472	047777	177776		153\$: .WORD 47777,177776	:ANTICIPATED ERRONEOUS RESULT.	
5715	027476	000117			154\$: 117	:FPS BEFORE EXECUTION.	
5716	027500	000100			100	:FPS AFTER EXECUTION.	

5717 027502 177777					-1		:ANTICIPATED ERRONEOUS FPS.
5718 027504 104270					155\$: ERROR	+270	;ST 631 INTO RND
5719 027506 000401					BR	156\$	
5720 027510 104261					ERROR	+261	;REPORT FPS INCORRECT.
5721 027512					156\$:		
5722							
5723							ROUND MODE
5724 027512 012737 027520 001110					:OPERAND=40000,000100	FL=1,	:SET UP THE LOOP ON ERROR ADDRESS.
					MOV	#360\$, SLPERR	;DPM002
5725 027520 004737 027724					360\$: JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5726 027524 040000 000100					161\$: .WORD	40000,100	:FSRC OPERAND.
5727 027530 047600 000001					162\$: .WORD	47600,1	:EXPECTED RESULT.
5728 027534 047600 000000					163\$: .WORD	47600,0	:ANTICIPATED ERRONEOUS RESULT.
5729 027540 000102					164\$: 102		:FPS BEFORE EXECUTION.
5730 027542 000100					100		:FPS AFTER EXECUTION.
5731 027544 177777					-1		:ANTICIPATED ERRONEOUS FPS.
5732 027546 104270					165\$: ERROR	+270	;REPORT RESULT INCORRECT.
5733 027550 000401					BR	166\$	
5734 027552 104261					ERROR	+261	;REPORT FPS INCORRECT.
5735 027554					166\$:		
5736							
5737							TRUNC MODE
5738 027554 012737 027562 001110					:OPERAND=40000,000100	FL=1,	:SET UP THE LOOP ON ERROR ADDRESS.
					MOV	#370\$, SLPERR	;DPM002
5739 027562 004737 027724					370\$: JSR	PC, 1000\$:GO EXECUTE VHE INSTRUCTION.
5740 027566 040000 000100					171\$: .WORD	40000,100	:FSRC OPERAND.
5741 027572 047600 000000					172\$: .WORD	47600,0	:EXPECTED RESULT.
5742 027576 047600 000001					173\$: .WORD	47600,1	:ANTICIPATED ERRONEOUS RESULT.
5743 027602 000157					174\$: 157		:FPS BEFORE EXECUTION.
5744 027604 000140					140		:FPS AFTER EXECUTION.
5745 027606 177777					-1		:ANTICIPATED ERRONEOUS FPS.
5746 027610 104271					175\$: ERROR	+271	;ST 631 ... INTO TRNC
5747 027612 000401					BR	176\$	
5748 027614 104261					ERROR	+261	;REPORT FPS INCORRECT.
5749 027616					176\$:		
5750							FL=0
5751 027616 012737 027624 001110					:OPERAND=100000,0 (MOST NEG #)		:SET UP THE LOOP ON ERROR ADDRESS.
					MOV	#380\$, SLPERR	;DPM002
5752 027624 004737 027724					380\$: JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5753 027630 100000 000000					181\$: .WORD	100000,0	:FSRC OPERAND.
5754 027634 144000 000000					182\$: .WORD	144000,0	:EXPECTED RESULT.
5755 027640 143600 000000					183\$: .WORD	143600,0	:ANTICIPATED ERRONEOUS RESULT.
5756 027644 000007					184\$: 7		:FPS BEFORE EXECUTION.
5757 027646 000010					10		:FPS AFTER EXECUTION.
5758 027650 177777					-1		:ANTICIPATED ERRONEOUS FPS.
5759 027652 104272					185\$: ERROR	+272	;ST 630 RH=R14+1
5760 027654 000401					BR	186\$	
5761 027656 104261					ERROR	+261	;REPORT FPS INCORRECT.
5762 027660					186\$:		
5763							
5764							:OPERAND=100000,0
5765 027660 012737 027666 001110					FL=1		:SET UP THE LOOP ON ERROR ADDRESS.
					MOV	#390\$, SLPERR	;DPM002
5766 027666 004737 027724					390\$: JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5767 027672 100000 000000					191\$: .WORD	100000,0	:FSRC OPERAND.
5768 027676 150000 000000					192\$: .WORD	150000,0	:EXPECTED RESULT.
5769 027702 147600 000000					193\$: .WORD	147600,0	:ANTICIPATED ERRONEOUS RESULT.
5770 027706 000107					194\$: 107		:FPS BEFORE EXECUTION.
5771 027710 000110					110		:FPS AFTER EXECUTION.
5772 027712 177777					-1		:ANTICIPATED ERRONEOUS FPS.
5773 027714 104272					195\$: ERROR	+272	;REPORT RESULT INCORRECT.

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 58-5
TEST # 56 - LDCIF AND LDCLF TEST

5774 027716 000401
5775 027720 104261
5776 027722 000506

196\$: BR 196\$
196\$: ERROR +261
196\$: BR 400\$

D 11
;REPORT FPS INCORRECT.

SEQUENCE 133

5777 :THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 5778 :THE LDCIF OR LDCLF INSTRUCTION AND CHECK THE RESULTS. A CALL
 5779 :TO IT IS MADE THUS:

5781	JSR	PC,1000\$	
5782	ACARG:	.WORD X,X	:AC OPERAND
5783	RES:	.WORD X,X	:EXPECTED RESULT
5784	ERRES:	.WORD X,X	:ERROR RESULT
5785	FPSB:	.WORD X	:FPS BEFORE EXECUTION
5786	FPSA:	.WORD X	:FPS AFTER EXECUTION
5787	ERFPS:	.WORD X	:ERROR FPS
5788	ERR1:	ERROR +X	:DATA ERROR
5789		BR CONT	
5790	ERR2:	ERROR +X	:FPS ERROR
5791	CONT:		:RETURN ADDRESS

5792

5793 :THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 5794 :THE LDCIF OR LDCLF INSTRUCTION IS EXECUTED.

5795 :THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 5796 :COMPARED WITH FPSA IF THIS TOO IS CORRECT 1000\$ RETURNS CONTROL
 5797 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD 1000\$ WILL
 5798 :COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN 1000\$ WILL RETURN
 5799 :TO THE ERROR CALL AT ERR2, OTHERWISE 1000\$ ITSELF
 5800 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 5801 :LDCIF OR LDCLF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 5802 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 5803 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN 1000\$
 5804 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
 5805 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND 1000\$
 5806 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.

5807

5808	027724	012601		1000\$: MOV (SP)+,R1	:GET A POINTER TO THE ARGUMENTS.
5809	027726	016100	000014	MOV 14(R1),R0	:SET THE FPS.
5810	027732	170100		LDFPS R0	
5811	027734	012737	026464	MOV #1\$,STMP2	
5812	027742	010100		MOV R1,R0	
5813					
5814	027744	177010		1001\$: LDCIF (R0),ACO	:TEST INSTRUCTION LDCIF OR LDCLF.
5815					
5816	027746	170204		STFPS R4	:GET FPS.
5817	027750	012700	030130	MOV #1200\$,R0	:GET THE RESULT.
5818	027754	012702	000200	MOV #200,R2	
5819	027760	170102		LDFPS R2	
5820	C27762	174010		STD ACO,(R0)	
5821					
5822	027764	012702	030130	MOV #1200\$,R2	:SEE IF THE RESULT WAS CORRECT.
5823	027770	010237	001242	MOV R2,STMP4	
5824	027774	010137	001240	MOV R1,STMP3	
5825	030000	010103		MOV R1,R3	
5826	030002	062703	000004	ADD #4,R3	
5827	030006	010337	001244	MOV R3,STMP5	
5828	030012	010437	001250	MOV R4,STMP7	
5829	030016	016137	000016	MOV 16(R1),STMP10	
5830	030024	010100		MOV R1,R0	
5831	030026	062700	000004	ADD #4,R0	
5832	030032	012703	000002	MOV #2,R3	
5833	030036	022022		1002\$: CMP (R0)+,(R2)+	

```

5834 030040 001006          BNE    1010$      ;BR IF INCORRECT.
5835 030042 077303          S0B    R3,1002$ 
5836
5837 030044 026104 000016          CMP    16(R1),R4      ;SEE IF THE FPS WAS CORRECT.
5838 030050 001020          BNE    1015$      ;BR IF INCORRECT.
5839 030052 000161 000030          JMP    30(R1)     ;RETURN.
5840
5841
5842 030056 012702 030130          1003$: RESULT IN CORRECT SO SEE IF THE FAILURE WAS ANTICIPATED.
5843 030062 010100          1010$: MOV   #1200$,R2
5844 030064 062700 000010          MOV   R1,R0
5845 030070 012703 000002          ADD   #10,R0
5846 030074 022022          1011$: MOV   #2,R3
5847 030076 001003          CMP   (R0)+(R2)+ 
5848 030100 077303          BNE   1013$ 
5849 030102 000161 000022          S0B   R3,1011$ 
5850
5851
5852 030106          1013$: :THE FAILURE WAS NOT ANTICIPATED SO REPORT THE ERROR HERE.
5853
5854 030106 104260          1014$: ERROR +260      ;BAD RES
5855 030110 000760          BR    1003$ 
5856
5857
5858
5859 030112 026104 000020          1015$: :THE FPS WAS INCORRECT SO SEE IF IT WAS ANTICIPATED.
5860 030116 001002          CMP   20(R1),R4
5861 030120 000161 000026          BNE   1016$ 
5862
5863
5864 030124          1016$: :FPS ERROR NOT ANTICIPATED SO REPORT IT HERE.
5865 030124 104261          1017$: ERROR +261      ;BAD FPS
5866 030126 000751          BR    1003$ 
5867
5868
5869 030130 000000 000000 000000 :DATA BUFFER:
5870
5871 030140          1200$: .WORD 0,0,0,0
5872 030140 104412          400$: RSETUP
5873
5874
5875
5876
5877
5878
5879
5880
5881
5882
5883
5884
5885
5886
5887
5888
5889
5890
5891
5892
5893
5894
5895
5896
5897
5898
5899
5900
5901
5902
5903
5904
5905
5906
5907
5908
5909
5910
5911
5912
5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924
5925
5926
5927
5928
5929
5930
5931
5932
5933
5934
5935
5936
5937
5938
5939
5940
5941
5942
5943
5944
5945
5946
5947
5948
5949
5950
5951
5952
5953
5954
5955
5956
5957
5958
5959
5960
5961
5962
5963
5964
5965
5966
5967
5968
5969
5970
5971
5972
5973
5974
5975
5976
5977
5978
5979
5980
5981
5982
5983
5984
5985
5986
5987
5988
5989
5990
5991
5992
5993
5994
5995
5996
5997
5998
5999
5999

```

5877

.SBTTL TEST # 57 - LDCID AND LDCLD TEST

:*****
:TEST 57 LDCID AND LDCLD TEST

:*** THIS IS A TEST OF LDCID AND LDCLD

:***
:*****

5878	030142	000004		TST57: SCOPE			
5879	030144	012737	030152	001110	:OPERAND=0	FL=0, FD=1	
5880	030152	004737	031012		200\$: MOV	#200\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5881	030156	000000	000000		1\$: JSR	PC,1000\$:GO EXECUTE THE INSTRUCTION.
5882	030162	000000	000000	000000	15\$: .WORD	0,0	:FSRC OPERAND.
5883	030172	177777	177777	177777	25\$: .WORD	0,0,0,0	:EXPECTED RESULT.
5884	030202	000213			35\$: .WORD	-1,-1,-1,-1	:ANTICIPATED ERRONEOUS RESULT.
5885	030204	000204			45\$: 213		:FPS BEFORE EXECUTION.
5886	030206	177777				204	:FPS AFTER EXECUTION.
5887	030210	104273			55\$: ERROR	+273	:ANTICIPATED ERRONEOUS FPS.
5888	030212	000401				BR 6\$:REPORT RESULT INCORRECT.
5889	030214	104274				ERROR +274	:REPORT FPS INCORRECT.
5890	030216				65\$: :OPERAND=0	FL=0, FD=1	
5891	030216	012737	030224	001110	210\$: MOV	#210\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5893	030224	004737	031012		11\$: JSR	PC,1000\$:GO EXECUTE THE INSTRUCTION.
5894	030230	000000	177777		12\$: .WORD	0,-1	:FSRC OPERAND.
5895	030234	000000	000000	000000	13\$: .WORD	0,0,0,0	:EXPECTED RESULT.
5896	030244	004177	177400	000000	14\$: .WORD	4177,177400,0,0	:ANTICIPATED ERRONEOUS RESULT.
5897	030254	000200				200	:FPS BEFORE EXECUTION.
5898	030256	000204				204	:FPS AFTER EXECUTION.
5899	030260	177777				-1	:ANTICIPATED ERRONEOUS FPS.
5900	030262	104275			15\$: ERROR	+275	: (BUT FL)S+277
5901	030264	000401				BR 16\$: TO 300 INTO 301
5902	030266	104274				ERROR +274	:REPORT FPS INCORRECT.
5903	030270				16\$: :OPERAND=0	FL=1 FD=1	
5904					220\$: MOV	#220\$, SLPERR	
5905					220\$: JSR	PC,1000\$:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5906	030270	012737	030276	001110	21\$: .WORD	0,0	:GO EXECUTE THE INSTRUCTION.
5907	030276	004737	031012		22\$: .WORD	0,0,0,0	:FSRC OPERAND.
5908	030302	000000	000000		23\$: .WORD	-1,-1,-1,-1	:EXPECTED RESULT.
5909	030306	000000	000000	000000	24\$: 211		:ANTICIPATED ERRONEOUS RESULT.
5910	030316	177777	177777	177777		204	:FPS BEFORE EXECUTION.
5911	030326	000211				-1	:FPS AFTER EXECUTION.
5912	030330	000204			25\$: ERROR	+273	:ANTICIPATED ERRONEOUS FPS.
5913	030332	177777				BR 26\$:REPORT RESULT INCORRECT.
5914	030334	104273				ERROR +274	:REPORT FPS INCORRECT.
5915	030336	000401			26\$: :OPERAND=40000	FL=0 FD=1	
5916	030340	104274			230\$: MOV	#230\$, SLPERR	
5917	030342				230\$: JSR	PC,1000\$:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5918					31\$: .WORD	40000,0	:GO EXECUTE THE INSTRUCTION.
5919					32\$: .WORD	43600,0,0,0	:FSRC OPERAND.
5920	030342	012737	030350	001110	33\$: .WORD	47600,0,0,0	:EXPECTED RESULT.
5921	030350	004737	031012		34\$: .WORD	217	:ANTICIPATED ERRONEOUS RESULT.
5922	030354	040000	000000			200	:FPS BEFORE EXECUTION.
5923	030360	043600	000000	000000			:FPS AFTER EXECUTION.
5924	030370	047600	000000	000000			
5925	030400	000217					
5926	030402	000200					

5927 030406 177777							:ANTICIPATED ERRONEOUS FPS.	
5928 030406 104276				35\$:	-1	ERROR	+276	:ST 107 BAD CONST
5929 030410 000401					BR	36\$		
5930 030412 104274					ERROR	+274		:REPORT FPS INCORRECT.
5931 030414				36\$:				
5932								
5933								
5934 030414 012737 030422 001110					:OPERAND=-40000	FL=0	FD=1	
5935 030422 004737 031012				240\$:	MOV	#240\$, SLPERR		:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5936 030426 140000 000000				241\$:	JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5937 030432 143600 000000 000000				41\$:	.WORD	-40000,0		:FSRC OPERAND.
5938 030442 043600 000000 000000				42\$:	.WORD	143600,0,0,0		:EXPECTED RESULT.
5939 030452 000200				43\$:	.WORD	43600,0,0,0		:ANTICIPATED ERRONEOUS RESULT.
5940 030454 000210				44\$:	200			:FPS BEFORE EXECUTION.
5941 030456 177777					210			:FPS AFTER EXECUTION.
5942 030460 104277				45\$:	ERROR	+277		:ANTICIPATED ERRONEOUS FPS.
5943 030462 000401					BR	46\$:SET SIGN) ST 176
5944 030464 104274					ERROR	+274		:REPORT FPS INCORRECT.
5945 030466				46\$:				
5946								
5947								
5948 030466 012737 030474 001110					:OPERAND=40000,0	FL=1	FD=1	
5949 030474 004737 031012				250\$:	MOV	#250\$, SLPERR		:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5950 030500 040000 000000				251\$:	JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5951 030504 047600 000000 000000				51\$:	.WORD	40000,0		:FSRC OPERAND.
5952 030514 043600 000000 000000				52\$:	.WORD	47600,0,0,0		:EXPECTED RESULT.
5953 030524 000317				53\$:	.WORD	43600,0,0,0		:ANTICIPATED ERRONEOUS RESULT.
5954 030526 000300				54\$:	317			:FPS BEFORE EXECUTION.
5955 030530 177777					300			:FPS AFTER EXECUTION.
5956 030532 104300				55\$:	ERROR	+300		:ANTICIPATED ERRONEOUS FPS.
5957 030534 000401					BR	56\$:ST 107 BAD CONS
5958 030536 104274					ERROR	+274		:REPORT FPS INCORRECT.
5959 030540				56\$:				
5960								
5961								
5962 030540 012737 030546 001110					:OPERAND=0,1	FL=1	FD=1	
5963 030546 004737 031012				260\$:	MOV	#260\$, SLPERR		:SET UP THE LOOP ON ERPOR ADDRESS. :DPM002
5964 030552 000000 000001				261\$:	JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5965 030556 040200 000000 000000				61\$:	.WORD	0,1		:FSRC OPERAND.
5966 030566 034200 000000 000000				62\$:	.WORD	40200,0,0,0		:EXPECTED RESULT.
5967 030576 000300				63\$:	.WORD	34200,0,0,0		:ANTICIPATED ERRONEOUS RESULT.
5968 030600 000300				64\$:	300			:FPS BEFORE EXECUTION.
5969 030602 177777					300			:FPS AFTER EXECUTION.
5970 030604 104300				65\$:	ERROR	+300		:ANTICIPATED ERRONEOUS FPS.
5971 030606 000401					BR	66\$:REPORT FPS INCORRECT.
5972 030610 104274					ERROR	+274		:REPORT FPS INCORRECT.
5973 030612				66\$:				
5974								
5975								
5976 030612 012737 030620 001110					:OPERAND=77777,177777	FL=1	FD=1	
5977 030620 004737 031012				270\$:	MOV	#270\$, SLPERR		:SET UP THE LOOP ON ERROR ADDRESS. :DPM002
5978 030624 077777 177777				271\$:	JSR	PC, 1000\$:GO EXECUTE THE INSTRUCTION.
5979 030630 047777 177777 177000				71\$:	.WORD	77777,177777		:FSRC OPERAND.
5980 030640 177777 177777 177777				72\$:	.WORD	47777,177777,177000,0		:EXPECTED RESULT.
5981 030650 000317				73\$:	.WORD	-1,-1,-1,-1		:ANTICIPATED ERRONEOUS RESULT.
5982 030652 000300				74\$:	317			:FPS BEFORE EXECUTION.
5983 030654 177777					300			:FPS AFTER EXECUTION.
					-1			:ANTICIPATED ERRONEOUS FPS.

5984 030656 104273	75\$:	ERROR	+273	:REPORT RESULT INCORRECT.
5985 030660 000401		BR	76\$	
5986 030662 104274		ERROR	+274	:REPORT FPS INCORRECT.
5987 030664	76\$:			
5988				
5989		:OPERAND=PATTERN	FL=1	FD=1
5990				
5991 030664 012737 030672 001110	280\$:	MOV	#280\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
5992 030672 004737 031012	JSR	PC,1000\$:GO EXECUTE THE INSTRUCTION.
5993 030676 177777 177526	81\$:	.WORD	-1,-252	:FSRC OPERAND.
5994 030702 142052 000000 000000	82\$:	.WORD	142052,0,0,0	:EXPECTED RESULT.
5995 030712 136052 000000 000000	83\$:	.WORD	136052,0,0,0	:ANTICIPATED ERRONEOUS RESULT.
5996 030722 000307	84\$:	307		:FPS BEFORE EXECUTION.
5997 030724 000310		310		:FPS AFTER EXECUTION.
5998 030726 177777		-1		:ANTICIPATED ERRONEOUS FPS.
5999 030730 104300	85\$:	ERROR	+300	:REPORT RESULT INCORRECT.
6000 030732 000401		BR	86\$	
6001 030734 104274		ERROR	+274	:REPORT FPS INCORRECT.
6002 030736	86\$:			
6003				
6004		:OPERAND=PATTERN	FL=1	FD=1 FT=1
6005 030736 012737 030744 001110	290\$:	MOV	#290\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
6006 030744 004737 031012	JSR	PC,1000\$:GO EXECUTE THE INSTRUCTION.
6007 030750 012345 067012	91\$:	.WORD	12345,67012	:FSRC OPERAND.
6008 030754 047247 025560 050000	92\$:	.WORD	47247,025560,050000,0	:EXPECTED RESULT.
6009 030764 177777 177777 177777	93\$:	.WORD	-1,-1,-1,-1	:ANTICIPATED ERRONEOUS RESULT.
6010 030774 000352	94\$:	352		:FPS BEFORE EXECUTION.
6011 030776 000340		340		:FPS AFTER EXECUTION.
6012 031000 177777		-1		:ANTICIPATED ERRONEOUS FPS.
6013 031002 104273	95\$:	ERROR	+273	:REPORT RESULT INCORRECT.
6014 031004 000401		BR	96\$	
6015 031006 104274		ERROR	+274	:REPORT FPS INCORRECT.
6016 031010 000506	96\$:	BR	300\$	

6017 :THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 6018 :THE LDCID OR LDCLD INSTRUCTION AND CHECK THE RESULTS. A CALL
 6019 :TO IT IS MADE THUS:

6021	JSR	PC,1000\$	
6022	ACARG:	.WORD X,X	:AC OPERAND
6023	RES:	.WORD X,X,X,X	:EXPECTED RESULT
6024	ERRES:	.WORD X,X,X,X	:ERROR RESULT
6025	FPSB:	.WORD X	:FPS BEFORE EXECUTION
6026	FPSA:	.WORD X	:FPS AFTER EXECUTION
6027	ERFPS:	.WORD X	:ERROR FPS.
6028	ERR1:	ERROR +X	:DATA ERROR.
6029		BR CONT	
6030	ERR2:	ERROR +X	:FPS ERROR.
6031	CONT:		:RETURN ADDRESS
6032			
6033	:THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN		
6034	:THE LDCID OR LDCLD INSTRUCTION IS EXECUTED.		
6035	:THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS		
6036	:COMPARED WITH FPSA IF THIS TOO IS CORRECT 1000\$ RETURNS CONTROL		
6037	:TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD 1000\$		
6038	:COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN 1000\$ WILL RETURN		
6039	:TO THE ERROR CALL AT ERR2. OTHERWISE 1000\$ ITSELF		
6040	:REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE		
6041	:LDCID OR LDCLD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE		
6042	:ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN		
6043	:THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN 1000\$		
6044	:WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE		
6045	:RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND 1000\$ WILL		
6046	:REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.		
6047			
6048	031012	012601	
6049	031014	016100	000024
6050	031020	170100	
6051	031022	012737	031032 001236
6052	031030	010100	
6053	031032	177010	
6054			
6055	031034	170204	
6056	031036	012700	031216
6057	031042	012702	000200
6058	031046	170102	
6059	031050	174010	
6060			
6061			:SEE IF THE RESULT IS CORRECT.
6062	031052	012702	031216
6063	031056	010237	001242
6064	031062	010137	001240
6065	031066	010103	
6066	031070	062703	000004
6067	031074	010337	001244
6068	031100	010437	001250
6069	031104	016137	000026 001252
6070	031112	010100	
6071	031114	062700	000004
6072	031120	012703	000002
6073	031124	022022	

1000\$: MOV (SP)+,R1 :GET A POINTER TO THE ARGUMENTS.
 1000\$: MOV 24(R1),R0 :SET THE FPS.
 101\$: LDCID (R0),ACO :TEST INSTRUCTION, LDCID OR LDCLD.
 STFPS R4 :GET FPS.
 MOV #1200\$,R0 :GET THE RESULT.
 102\$: CMP (R0)+,(R2)+

6118

.SBTTL TEST # 60 - LDEXP TEST

.TEST 60 LDEXP TEST

* THIS IS A TEST OF THE LDEXP INST
 * A SUBROUTINE IS USED TO SET UP
 * OPERANDS, EXECUTE THE LDEXP INST AND
 * CHECK THE RESULTS.

031230	000004	TST60: SCOPE					
6119	031232	012737	031240	001110	: NON-ZERO RES. VALID EXPON=210 (EXCESS 200)=10		
6120	031240	004737	032674	034567	200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002	
6121	031244	012345	067012	034567	1\$: JSR PC 1000\$;GO EXECUTE THE INSTRUCTION.		
6122	031254	000010			2\$: .WORD 12345,67012,34567,012345 ;AC0 OPERAND.		
6123	031256	042145	067012	034567	3\$: .WORD 10		
6124	031256	042145	067012	034567	4\$: .WORD 42145,67012,34567,012345	:EXPECTED RESULT.	
6125	031266	002145	067012	034567	4\$: .WORD 2145,67012,34567,012345	:ANTICIPATED ERRONEOUS RESULT.	
6126	031276	047217			5\$: 47217	:FPS BEFORE EXECUTION.	
6127	031300	047200			47200	:FPS AFTER EXECUTION.	
6128	031302	147200			147200	:ANTICIPATED ERRONEOUS FPS.	
6129	031304	177777			-1	:EXPECTED FEC.	
6130	031306	104304			6\$: ERROR +304	:E12+E12+200 BAD	
6131	031310	000400			BR 7\$:ST 624	
6132	031312	104305			7\$: ERROR +305	:REPORT FPS INCORRECT.	
6133						:ST 625 INTO 304	
6134					.NON-ZERO	RES NEG.	
6135	031314	012737	031322	001110	210\$: MOV #210\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002	
6136	031322	004737	032674		210\$: JSR PC 1000\$;EXPON=377		
6137	031326	123456	070123	045670	11\$: .WORD 123456,70123,45670,123456	:AC0 OPERAND.	
6138	031336	000177			12\$: .WORD 177	:EXPONENT OPERAND.	
6139	031340	177656	070123	045670	13\$: .WORD 177656,70123,45670,123456	:EXPECTED RESULT.	
6140	031350	137656	070123	045670	14\$: .WORD 137656,70123,45670,123456	:ANTICIPATED ERRONEOUS RESULT.	
6141	031360	047207			15\$: 47207	:FPS BEFORE EXECUTION.	
6142	031362	047210			47210	:FPS AFTER EXECUTION.	
6143	031364	147210			147210	:ANTICIPATED ERRONEOUS FPS.	
6144	031365	177777			-1	:EXPECTED FEC.	
6145	031370	104304			16\$: ERROR +304	:REPORT RESULT INCORRECT.	
6146	031372	000401			BR 17\$		
6147	031374	104305			ERROR +305	:REPORT FPS INCORRECT.	
6148	031376				17\$:		
6149							
6150					.NON-ZERO	RES EXP=256=(56)REAL	
6151	031376	012737	031404	001110	220\$: MOV #220\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.	;DPM002	
6152	031404	004737	032674		220\$: JSR PC 1000\$;GO EXECUTE THE INSTRUCTION.		
6153	031410	073261	057645	043323	21\$: .WORD 73261,057645,43323,101760	:AC0 OPERAND.	
6154	031420	000056			22\$: .WORD 56	:EXPONENT OPERAND.	
6155	031422	053461	057645	043323	23\$: .WORD 53461,057645,43323,101760	:EXPECTED RESULT.	
6156	031432	177777	177777	177777	24\$: .WORD -1,-1,-1,-1	:ANTICIPATED ERRONEOUS RESULT.	
6157	031442	047200			25\$: 47200	:FPS BEFORE EXECUTION.	
6158	031444	047200			47200	:FPS AFTER EXECUTION.	
6159	031446	147200			147200	:ANTICIPATED ERRONEOUS FPS.	
6160	031450	177777			-1	:EXPECTED FEC.	
6161	031452	104301			26\$: ERROR +301	:REPORT RESULT INCORRECT.	
6162	031454	000401			BR 27\$		
6163	031455	104305			ERROR +305	:REPORT FPS INCORRECT.	
6164	031460				27\$: :		

6165
 6166
 6167 031460 012737 031466 001110 ;EXP=27 (EXCESS 200)=-151 (OCT)
 6168 031466 004737 032674 062720 230\$: MOV #230\$ SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6169 031472 012223 024252 062720 31\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6170 031502 177627 32\$: .WORD 12223,24252,62720,21222 ;AC0 OPERAND.
 6171 031504 005623 024252 062720 33\$: .WORD -151 ;EXPONENT OPERAND.
 6172 031514 177777 177777 177777 34\$: .WORD 5623,24252,62720,21222 ;EXPECTED RESULT.
 6173 031524 047200 35\$: .WORD -1,-1,-1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 6174 031526 047200 47200 ;FPS BEFORE EXECUTION.
 6175 031530 147200 47200 ;FPS AFTER EXECUTION.
 6176 031532 177777 147200 ;ANTICIPATED ERRONEOUS FPS.
 6177 031534 104301 36\$: -1 ;EXPECTED FEC.
 6178 031536 000401 36\$: ERROR +301 ;REPORT RESULT INCORRECT.
 6179 031540 104306 37\$: BR 37\$
 6180 031542 37\$: ERROR +306 ;(BUT EZBT) ST 544 TO 504 INTO 704 0 (BUT EXBT) ST 704 INTO
 6181
 6182 ;EXP=0 (EXCESS 200)=-200 (OCT), POSITIVE FRAC
 6183 ;FIU=1
 6184 031542 012737 031550 001110 240\$: MOV #240\$ SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6185 031550 004737 032674 035363 41\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6186 031554 030131 032334 035363 41\$: .WORD 30131,32334,35363,73031 ;AC0 OPERAND.
 6187 031564 177600 42\$: .WORD -200 ;EXPONENT OPERAND.
 6188 031566 000131 032334 035363 43\$: .WORD 00131,32334,35363,73031 ;EXPECTED RESULT.
 6189 031576 000000 000000 000000 44\$: .WORD 0,0,0,0 ;ANTICIPATED ERRONEOUS RESULT.
 6190 031606 042200 45\$: 42200 ;FPS BEFORE EXECUTION.
 6191 031610 142204 142204 ;FPS AFTER EXECUTION.
 6192 031612 042202 42202 ;ANTICIPATED ERRONEOUS FPS.
 6193 031614 000012 12 ;EXPECTED FEC.
 6194 031616 104307 46\$: ERROR +307 ;(BUT EXBT) ST 704 TO 64 INST 264
 6195 031620 000401 47\$: BR 47\$
 6196 031622 104310 47\$: ERROR +310 ;(BUT FIU) ST 264 X
 6197 031624 47\$:
 6198
 6199 ;EXP=0 (EXCESS 200)=-200 (OCT), NEG FRACT, FIU=1
 6200 031624 012737 031632 001110 250\$: MOV #250\$ SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6201 031632 004737 032674 045464 51\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6202 031636 140414 024344 045464 51\$: .WORD 140414,24344,45464,74045 ;AC0 OPERAND.
 6203 031646 177600 52\$: .WORD -200 ;EXPONENT OPERAND.
 6204 031650 100014 024344 045464 53\$: .WORD 100014,24344,45464,74045 ;-0 ;EXPECTED RESULT.
 6205 031660 000000 000000 000000 54\$: .WORD 0,0,0,0 ;ANTICIPATED ERRONEOUS RESULT.
 6206 031670 042200 55\$: 42200 ;FPS BEFORE EXECUTION.
 6207 031672 142214 142214 ;FPS AFTER EXECUTION.
 6208 031674 042214 42214 ;ANTICIPATED ERRONEOUS FPS.
 6209 031676 000012 12 ;EXPECTED FEC.
 6210 031700 104307 56\$: ERROR +307 ;REPORT RESULT INCORRECT.
 6211 031702 000401 57\$: BR 57\$
 6212 031704 104310 57\$: ERROR +310 ;REPORT FPS INCORRECT.
 6213 031706 57\$:
 6214
 6215 ;EXP=0 (EXCESS 200)=-200 (OCT), POS FRAC, FIU=0
 6216
 6217 031706 012737 031714 001110 260\$: MOV #260\$ SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6218 031714 004737 032674 005675 61\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6219 031720 051525 035455 005675 61\$: .WORD 51525,35455,5675,05152 ;AC0 OPERAND.
 6220 031730 177600 62\$: .WORD -200 ;EXPONENT OPERAND.
 6221 031732 000000 000000 000000 63\$: .WORD 0,0,0,0 ;EXPECTED RESULT.

6222 031742 000125 035455 005675 64\$: .WORD 00125,35455,5675,05152 ;ANTICIPATED ERRONEOUS RESULT.
 6223 031752 045200 45200 :FPS BEFORE EXECUTION.
 6224 031754 045204 45204 :FPS AFTER EXECUTION.
 6225 031756 145204 145204 :ANTICIPATED ERRONEOUS FPS.
 6226 031760 177777 -1 :EXPECTED FEC.
 6227 031762 104311 66\$: ERROR +311 : (BUT FIU) ST 264 X ;REPORT RESULT INCORRECT.
 6228 031764 000401 BR 67\$
 6229 031766 104302 ERROR +302 :REPORT FPS INCORRECT.
 6230 031770 67\$:
 6231
 6232 :EXP=-1605 (EXCESS 200)=-1605 (OCT), FIU=1
 6233 031770 012737 031776 001110 MOV #270\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6234 031776 004737 032674 270\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6235 032002 061626 062636 046566 71\$: .WORD 61626,62636,46566,67606 ;AC0 OPERAND.
 6236 032012 176173 72\$: .WORD -1605 ;EXPONENT OPERAND.
 6237 032014 076626 062636 046566 73\$: .WORD 76626,62636,46566,67606 ;EXPECTED RESULT.
 6238 032024 000000 000000 000000 74\$: .WORD 0,0,0,0 ;ANTICIPATED ERRONEOUS RESULT.
 6239 032034 042200 75\$: 42200 :FPS BEFORE EXECUTION.
 6240 032036 142200 142200 :FPS AFTER EXECUTION.
 6241 032040 042204 42204 :ANTICIPATED ERRONEOUS FPS.
 6242 032042 000012 12 :EXPECTED FEC.
 6243 032044 104312 76\$: ERROR +312 : (BUT EZBT) ST 544 TO 704 INTO 504
 6244 032046 000401 BR 77\$
 6245 032050 104302 ERROR +302 :REPORT FPS INCORRECT.
 6246 032052 77\$:
 6247 :EXP=-17416 (EXCESS 200)=-17616 (OCT), FIU=0
 6248 032052 012737 032060 001110 MOV #280\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6249 032060 004737 032674 280\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6250 032064 071727 037475 076777 81\$: .WORD 71727,37475,76777,17273 ;AC0 OPERAND.
 6251 032074 160162 82\$: .WORD -17616 ;EXPONENT OPERAND.
 6252 032076 000000 000000 000000 83\$: .WORD 0,0,0,0 ;EXPECTED RESULT.
 6253 032106 074527 037475 076777 84\$: .WORD 74527,37475,76777,17273 ;ANTICIPATED ERRONEOUS RESULT.
 6254 032116 045200 85\$: 45200 :FPS BEFORE EXECUTION.
 6255 032120 045204 45204 :FPS AFTER EXECUTION.
 6256 032122 145200 145200 :ANTICIPATED ERRONEOUS FPS.
 6257 032124 177777 -1 :EXPECTED FEC.
 6258 032126 104313 86\$: ERROR +313 : (BUT FIU) ST 504
 6259 032130 000401 BR 87\$
 6260 032132 104302 ERROR +302 :REPORT FPS INCORRECT.
 6261 032134 87\$:
 6262
 6263 :EXP=-1601 (EXCESS 200)=-2001 (OCT), FIU=1
 6264 032134 012737 032142 001110 MOV #290\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6265 032142 004737 032674 290\$: JSR PC,1000\$;GO EXECUTE THE INSTRUCTION.
 6266 032146 001020 030405 006070 91\$: .WORD 01020,30405,06070,00102 ;AC0 OPERAND.
 6267 032156 175777 92\$: .WORD -2001 ;EXPONENT OPERAND.
 6268 032160 037620 030405 006070 93\$: .WORD 37620,30405,06070,00102 ;EXPECTED RESULT.
 6269 032170 000000 000000 000000 94\$: .WORD 0,0,0,0 ;ANTICIPATED ERRONEOUS RESULT.
 6270 032200 042200 95\$: 42200 :FPS BEFORE EXECUTION.
 6271 032202 142200 142200 :FPS AFTER EXECUTION.
 6272 032204 042204 42204 :ANTICIPATED ERRONEOUS FPS.
 6273 032206 000012 12 :EXPECTED FEC.
 6274 032210 104312 96\$: ERROR +312 : (BUT FIU) ST 504
 6275 032212 000401 BR 97\$
 6276 032214 104302 ERROR +302 :REPORT FPS INCORRECT.
 6277 032216 97\$:
 6278

6279 :EXP=1206 (EXCESS 200)=1006 (OCT) FIV =1
 6280 032216 012737 032224 001110 MOV #300\$, SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6281 032224 004737 032674 300\$: JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.
 6282 032230 012131 014151 016171 101\$: .WORD 12131, 14151, 16171, 10111 ;AC0 OPERAND.
 6283 032240 001006 014151 016171 102\$: .WORD 1006 ;EXPONENT OPERAND.
 6284 032245 041531 014151 016171 103\$: .WORD 41531, 14151, 16171, 10111 ;EXPECTED RESULT.
 6285 032252 000000 000000 000000 104\$: .WORD 0, 0, 0, 0 ;ANTICIPATED ERRONEOUS RESULT.
 6286 032262 041200 105\$: 41200 ;FPS BEFORE EXECUTION.
 6287 032264 141202 141202 ;FPS AFTER EXECUTION.
 6288 032266 041204 41204 ;ANTICIPATED ERRONEOUS FPS.
 6289 032270 000010 10: ;EXPECTED FEC.
 6290 032272 104314 106\$: ERROR +314 ;(BUT FIV) ST 104
 6291 032274 000401 BR 107\$: ;REPORT FPS INCORRECT.
 6292 032276 104302 107\$: ERROR +302 ;REPORT FPS INCORRECT.
 6293 032300
 6294
 6295 :EXP=16315 (EXCESS 200)=16115 (OCT) FIV=0
 6296 032300 012737 032306 001110 MOV #310\$, SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6297 032306 004737 032674 310\$: JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.
 6298 032312 027262 025242 023222 111\$: .WORD 27262, 25242, 23222, 21202 ;AC0 OPERAND.
 6299 032322 016115 112\$: .WORD 16115 ;EXPONENT OPERAND.
 6300 032324 000000 000000 000000 113\$: .WORD 0, 0, 0, 0 ;EXPECTED RESULT.
 6301 032334 063262 025242 023222 114\$: .WORD 63262, 25242, 23222, 21202 ;ANTICIPATED ERRONEOUS RESULT.
 6302 032344 046200 115\$: 46200 ;FPS BEFORE EXECUTION.
 6303 032346 046206 46206 ;FPS AFTER EXECUTION.
 6304 032350 146202 146202 ;ANTICIPATED ERRONEOUS FPS.
 6305 032352 177777 -1 ;EXPECTED FEC.
 6306 032354 104315 116\$: ERROR +315 ;(BUT FIV) ST 104
 6307 032356 000401 BR 117\$: ;REPORT FPS INCORRECT.
 6308 032360 104302 117\$: ERROR +302 ;REPORT FPS INCORRECT.
 6309 032362
 6310
 6311 :EXP=11011 (EXCESS 200)=10611 (OCT) FIV=1
 6312
 6313 032362 012737 032370 001110 MOV #320\$, SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6314 032370 004737 032674 320\$: JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.
 6315 032374 030313 032333 034353 121\$: .WORD 30313, 32333, 34353, 36373 ;AC0 OPERAND.
 6316 032404 010611 122\$: .WORD 10611 ;EXPONENT OPERAND.
 6317 032406 002313 032333 034353 123\$: .WORD 2313, 32333, 34353, 36373 ;EXPECTED RESULT.
 6318 032416 000000 000000 000000 124\$: .WORD 0, 0, 0, 0 ;ANTICIPATED ERRONEOUS RESULT.
 6319 032426 041200 125\$: 41200 ;FPS BEFORE EXECUTION.
 6320 032430 141202 141202 ;FPS AFTER EXECUTION.
 6321 032432 041204 41204 ;ANTICIPATED ERRONEOUS FPS.
 6322 032434 000010 10 ;EXPECTED FEC.
 6323 032436 104316 126\$: ERROR +316 ;(BUT FIV) ST 144
 6324 032440 000401 BR 127\$: ;REPORT FPS INCORRECT.
 6325 032442 104302 127\$: ERROR +302 ;REPORT FPS INCORRECT.
 6326 032444
 6327
 6328 :EXP=17123 (EXCESS 200)=16723 (OCT) FIV=0
 6329
 6330 032444 012737 032452 001110 MOV #330\$, SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 6331 032452 004737 032674 330\$: JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.
 6332 032456 040414 042434 044454 131\$: .WORD 40414, 42434, 44454, 46474 ;AC0 OPERAND.
 6333 032466 016723 132\$: .WORD 16723 ;EXPONENT OPERAND.
 6334 032470 000000 000000 000000 133\$: .WORD 0, 0, 0, 0 ;EXPECTED RESULT.
 6335 032500 024614 042434 044454 134\$: .WORD 24614, 42434, 44454, 46474 ;ANTICIPATED ERRONEOUS RESULT.

6336 032510 046200	135\$:	46200	:FPS BEFORE EXECUTION.	
6337 032512 046206		46206	:FPS AFTER EXECUTION.	
6338 032514 146202		146202	:ANTICIPATED ERRONEOUS FPS.	
6339 032516 177777		-1	:EXPECTED FEC.	
6340 032520 104317	136\$:	ERROR +317	: (BUT FIV) ST 144	
6341 032522 000401		BR 137\$		
6342 032524 104302		ERROR +302	:REPORT FPS INCORRECT.	
6343 032526	137\$:			
6344				
6345		;EXP= 254 (OCT)= 454 (EXCESS 200)	FIV=1	
6346				
6347 032526 012737 032534 001110	340\$:	MOV #340\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
6348 032534 004737 032674		JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
6349 032540 050515 052535 054555	141\$:	.WORD 50515, 52535, 54555, 56575	:AC0 OPERAND.	
6350 032550 000254	142\$:	.WORD 254	:EXPONENT OPERAND.	
6351 032552 013115 052535 054555	143\$:	.WORD 13115, 52535, 54555, 56575	:EXPECTED RESULT.	
6352 032562 000000 000000 000000	144\$:	.WORD 0, 0, 0, 0	:ANTICIPATED ERRONEOUS RESULT.	
6353 032572 041200	145\$:	41200	:FPS BEFORE EXECUTION.	
6354 032574 141202		41202	:FPS AFTER EXECUTION.	
6355 032576 041204		41204	:ANTICIPATED ERRONEOUS FPS.	
6356 032600 000010		10	:EXPECTED FEC.	
6357 032602 104320	146\$:	ERROR +320	: (BUT FIV) ST 344	
6358 032604 000401		BR 147\$		
6359 032606 104302		ERROR +302	:REPORT FPS INCORRECT.	
6360 032610	147\$:			
6361				
6362		;EXP= 313 (OCT)= 513 (EXCESS 200) FIV=0		
6363				
6364 032610 012737 032616 001110	350\$:	MOV #350\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
6365 032616 004737 032674		JSR PC, 1000\$:GO EXECUTE THE INSTRUCTION.	
6366 032622 060616 062636 064656	151\$:	.WORD 60616, 62636, 64656, 66676	:AC0 OPERAND.	
6367 032632 000313	152\$:	.WORD 313	:EXPONENT OPERAND.	
5368 032634 000000 000000 000000	153\$:	.WORD 0, 0, 0, 0	:EXPECTED RESULT.	
6369 032644 022616 062636 064656	154\$:	.WORD 22616, 62636, 64656, 66676	:ANTICIPATED ERRONEOUS RESULT.	
6370 032654 046200	155\$:	46200	:FPS BEFORE EXECUTION.	
6371 032656 046206		46206	:FPS AFTER EXECUTION.	
6372 032660 146202		146202	:ANTICIPATED ERRONEOUS FPS.	
6373 032662 177777		-1	:EXPECTED FEC.	
6374 032664 104321	156\$:	ERROR +321	: (BUT FIV) ST 344	
6375 032666 000401		BR 157\$		
6376 032670 104302		ERROR +302	:REPORT FPS INCORRECT.	
6377 032672 000540	157\$:	BR 360\$		

6379 ;THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 6380 ;THE LDEXP INSTRUCTION AND CHECK THE RESULTS. A CALL
 6381 ;TO IT IS MADE THUS:

6382	JSR	PC,1000\$	
6383	ACARG:	.WORD X,X,X,X	:AC OPERAND
6384	EXP:	.WORD X	:EXPONENT
6385	RES:	.WORD X,X,X,X	:EXPECTED RESULT
6386	ERRES:	.WORD X,X,X,X	:ERROR RESULT
6387	FPSB:	.WORD X	:FPS BEFORE EXECUTION
6388	FPSA:	.WORD X	:FPS AFTER EXECUTION
6389	ERFPS:	.WORD X	:ERROR FPS.
6390	FEC:	.WORD X	:EXPECTED FEC
6391	ERR1:	ERROR +X	:DATA ERROR.
6392	BR	CONT	
6393	ERR2:	ERROR +X	:FPS ERROR.
6394	CONT:		:RETURN ADDRESS
6395			
6396			
6397			
6398			
6399			
6400			
6401			
6402			
6403			
6404			
6405			
6406			
6407			
6408			
6409			
6410			
6411			
6412	032674 012601	1000\$:	MOV (SP)+,R1 :GET A POINTER TO THE ARGUMENTS.
6413	032676 012700	MOV #200,RO :LOAD THE ACO OPERAND.	
6414	032702 170100	LDFPS RO	
6415	032704 010100	MOV R1,RO	
6416	032706 172410	LDD (R0),ACO	
6417	032710 012737	MOV #161\$,STMP2	
6418	032716 016100	MOV 32(R1),RO	:SET UP THE FPS.
6419	032722 170100	LDFPS RO	
6420	032724 010100	MOV R1,RO	
6421	032726 062700	ADD #10,RO	
6422			
6423	032732 176410	161\$: LDEXP (R0),ACO	:TEST INSTRUCTION.
6424			
6425	032734 170204	STFPS R4	:GET THE FPS.
6426	032736 170305	STST R5	:GET THE FEC.
6427	032740 012700	MOV #200,RO	:GET THE RESULT.
6428	032744 170100	LDFPS RO	
6429	032746 012700	MOV #1200\$,RO	
6430	032752 174010	STD AC0,(R0)	
6431	032754 010437	MOV R4,\$TMP7	
6432	032760 016137	MOV 34(R1),STMP10	
6433	032766 010537	MOV R5,\$TMP11	
6434	032772 016137	MOV 40(R1),STMP12	
6435	033000 010102	MOV R1,R2	

6436	033002	010237	001240		MOV	R2,\$TMP3	
6437	033006	062702	000010		ADD	#10,R2	
6438	033012	011237	001242		MOV	(R2),\$TMP4	
6439	033016	062702	000002		ADD	#2,R2	
6440	033022	010237	001244		MOV	R2,\$TMP5	
6441	033026	012737	033164	001246	MOV	#1200\$,TMP6	
6442	033034	012702	033164		MOV	#1200\$,R2	;SEE IF THE RESULT WAS CORRECT.
6443	033040	010103			MOV	R1,R3	
6444	033042	062703	000012		ADD	#12,R3	
6445	033046	012700	00C004		MOV	#4,R0	
6446	033052	022223		162\$:	CMP	(R2)+(R3)+	
6447	033054	001014			BNE	170\$;BRANCH IF NOT CORRECT.
6448	033056	077003			SQB	R0,162\$	
6449	033060	020461	000034		CMP	R4,34(R1)	;SEE IF THE FPS WAS CORRECT.
6450	033064	001026			BNE	175\$;BRANCH IF NOT CORRECT.
6451	033066	005761	000034		TST	34(R1)	
6452	033072	100003			BPL	163\$	
6453	033074	020561	000040		CMP	R5,40(R1)	;SEE IF THE FEC WAS CORRECT.
6454	033100	001027			BNE	180\$;BRANCH IF NOT CORRECT.
6455					JMP	50(R1)	;RETURN.
6456	033102	000161	000050				
6457							
6458							:THE RESULT WAS INCORRECT SO SEE IF THE FAILURE WAS ANTICIPATED.
6459	033106	012702	033164		170\$:	MOV	#1200\$,R2
6460	033112	010103				MOV	R1,R3
6461	033114	062703	000022			ADD	#22,R3
6462	033120	012700	000004			MOV	#4,R0
6463	033124	022223		171\$:	CMP	(R2)+(R3)+	
6464	033126	001003			BNE	172\$	
6465	033130	077003			SQB	R0,171\$	
6466	033132	000161	000042			JMP	42(R1)
6467							
6468							:THE ERROR WAS NOT ANTICIPATED SO REPORT IT HERE.
6469	033136				172\$:		
6470	033136	104301			173\$:	ERROR	+301
6471	033140	000760				BR	163\$
6472							
6473							:SEE IF THE FPS ERROR WAS ANTICIPATED.
6474	033142	026104	000036		175\$:	CMP	36(R1),R4
6475	033146	001002				BNE	176\$
6476	033150	000161	000046			JMP	46(R1)
6477	033154				176\$:		
6478							:THE FPS WAS NOT ANTICIPATED SO REPORT IT HERE.
6479	033154	104302			177\$:	ERROR	+302
6480	033156	000751				BR	163\$
6481							
6482							
6483	033160				180\$:		
6484							:REPORT FEC INCORRECT.
6485	033160	104303			181\$:	ERROR	+303
6486	033162	000747				BR	163\$
6487							
6488							
6489	033164	000000	000000	000000			:DATA BUFFER:
6490					1200\$:	.WORD	0,0,0,0
6491	033174				360\$:	RSETUP	
	033174	104412					:GO INITIALIZE THE FPS AND STACK; AND

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 63-2
TEST # 60 - LDEXP TEST

F 12

SEQUENCE 148

:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

6498

.SBTTL TEST # 61 - DESTINATION MODES, MODE 1 (FL=0), TEST

 ;TEST 61 DESTINATION MODES, MODE 1 (FL=0), TEST
 ;
 ; THIS IS A TEST OF DESTINATION MODE 1 USING
 ; THE STFPS INSTRUCTION
 ;*****

033176	000004			TST61: SCOPE			
6499 033200	012737	033206	001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002
6500 033206	012700	033304		200\$: MOV	#210\$,R0	;SET UP THE DATA BUFFER.	
6501 033212	012701	000006			MOV #6,R1		
6502 033216	012720	177777		1\$: MOV	#-1,(R0)+		
6503 033222	077103				S0B R1,1\$		
6504 033224	012700	102345			MOV #102345,R0		
6505 033230	012737	033252	001236		MOV #220\$,STMP2		
6506 033236	012737	033404	000004		MOV #230\$,ERRVECT	;SET UP FOR TRAPS TO 4.	
6507 033244	170100			LDFPS	R0	;SET UP FPS.	
6508 033246	012700	033310			MOV #240\$,R0		
6509							
6510 033252	170210			220\$: STFPS	(R0)	;TEST INSTRUCTION.	
6511 033254	020027	033310			CMP R0,#240\$;IS R0 CORRECT?	
6512 033260	001017				BNE 250\$;BRANCH IF NOT CORRECT.	
6513 033262	023727	033310	102345		CMP 240\$,#102345	;IS RESULT CORRECT?	
6514 033270	001023				BNE 260\$;BRANCH IF NOT CORRECT.	
6515 033272	023727	033312	177777		CMP 240\$+2,#-1	;IS THE RESULT CORRECT?	
6516 033300	001030				BNE 270\$;BRANCH IF NOT CORRECT.	
6517 033302	000453				BR 280\$		
6518							
6519							
6520 033304	177777	177777				;TEST DATA BUFFER:	
6521 033310	177777	177777	177777	210\$: .WORD	-1,-1		
6522				240\$: .WORD	-1,-1,-1,-1		
6523							
6524 033320	010037	001242				;REPORT R0 INCORRECT.	
6525 033324	012737	033310	001240	250\$: MOV	R0,STMP4		
6526 033332	104377				MOV #240\$,STMP3		
6527 033334	000001				ERROR +377		
6528 033336	000435				.WORD 1		
6529							
6530							
6531 033340	012737	102345	001240			;REPORT RESULT INCORRECT.	
6532 033346	013737	033310	001242	260\$: MOV	#102345,STMP3		; ST 634
6533 033354	104377				MOV 240\$,STMP4		
6534 033356	000002				ERROR +377		
6535 033360	000424				.WORD 2		;BAD DATA
6536							
6537							
6538							
6539 033362	012737	177777	001240			;REPORT RESULT INCORRECT.	
6540 033370	013737	033312	001242	270\$: MOV	#-1,STMP3		
6541 033376	104377				MOV 240\$+2,STMP4		
6542 033400	000003				ERROR +377		
6543 033402	000413				.WORD 3		
							;ST 357 TO 416 ;(BUT GR7,FL)

6544

;INTO 417

6545

6546

6547

6548

6549 033404 011604

:IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
:DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
:TO THE SPURIOUS TRAP TO 4 HANDLER.

6550 033406 020427 033254

230\$: MOV (SP), R4
CMP R4, #220\$+2
BEQ 2\$
JMP CPSPUR

6551 033412 001402

6552 033414 000137 051774

6553

6554 033420 011637 001236

6555 033424 022626

6556 033426 104377

033430 000004

6557

6558

6559 033432 104412

2\$: MOV (SP), \$TMP2
CMP (SP)+, (SP)+
ERROR +377
.WORD 4

; (BUT FDST)+ ST634

280\$: RSETUP

:GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

6560

.SBTTL TEST # 62 - DESTINATION MODES, MODE 2 (FL=0), TEST

* TEST 62 DESTINATION MODES, MODE 2 (FL=0), TEST
*
* THIS IS A TEST OF DESTINATION MODE 2 USING
* THE STFPS INSTRUCTION

033434	000004			TST62: SCOPE				
6561 033436	012737	033444	001110	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		
6562 033444	012700	033542		MOV	#210\$,R0	:SET UP THE DATA BUFFER.	:DPM002	
6563 033450	012701	000006		MOV	#6,R1			
6564 033454	012720	177777		1\$: MOV	#-1,(R0)+			
6565 033460	077103			S08	R1,\$			
6566 033462	012700	105412		MOV	#105412,R0			
6567 033466	012737	033510	001236	MOV	#220\$,\$TMP2			
6568 033474	012737	033642	000004	MOV	#230\$,ERRVECT	:SET UP FOR TRAPS TO VECTOR 4.		
6569 033502	170100			LDFPS	R0	:SET UP FPS.		
6570 033504	012700	033546		MOV	#240\$,R0			
6571								
6572 033510	170220			220\$: STFPS	(R0)+	:TEST INSTRUCTION.		
6573 033512	020027	033550		CMP	R0,#240\$+2	:IS R0 CORRECT?		
6574 033516	001017			BNE	250\$:BRANCH IF NOT CORRECT.		
6575 033520	023727	033546	105412	CMP	240\$,#105412	:IS THE RESULT CORRECT?		
6576 033526	001023			BNE	260\$:BRANCH IF NOT CORRECT.		
6577 033530	023727	033550	177777	CMP	240\$+2,#-1	:IS THE RESULT CORRECT?		
6578 033536	001030			BNE	270\$:BRANCH IF NOT CORRECT.		
6579 033540	000453			BR	280\$			
6580								
6581								
6582 033542	177777	177777				:TEST DATA BUFFER:		
6583 033546	177777	177777	177777	210\$: .WORD	-1,-1			
6584				240\$: .WORD	-1,-1,-1,-1			
6585								
6586 033556	010037	001242				:REPORT R0 INCORRECT.		
6587 033562	012737	033550	001240	250\$: MOV	R0,\$TMP4			
6588 033570	104377			MOV	#240\$+2,\$TMP3			
033572	000005			ERROR	+377			
6589				.WORD	5			
6590 033574	000435			BR	280\$:R0 BAD (BUT : FDST)X		
6591								
6592								
6593 033576	012737	105412	001240			:REPORT RESULT INCORRECT.		
6594 033604	013737	033546	001242	260\$: MOV	#105412,\$TMP3		: ST 634	
6595 033612	104377			MOV	<-0\$,TMP4			
033614	000006			ERROR	+377			
6596				.WORD	6			
6597 033616	000424			BR	280\$:BAD DATA		
6598								
6599								
6600								
6601 033620	012737	177777	001240			:REPORT RESULT INCORRECT.		
6602 033626	013737	033550	001242	270\$: MOV	#-1,\$TMP3			
6603 033634	104377			MOV	#240\$+2,\$TMP4			
033636	000007			ERROR	+377			
6604				.WORD	7			
6605 033640	000413			BR	280\$: (BUT GR7,FL) : ST 357 TO 416		

6606 ;INTO 417
6607
6608 :IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6609 :DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6610 :TO THE SPURIOUS TRAP TO 4 HANDLER.
6611 033642 011604 230\$: MOV (SP), R4
6612 033644 020427 033512 CMP R4, #220\$+2
6613 033650 001402 BEQ 2\$
6614 033652 000137 051774 JMP CPSPUR
6615
6616 033656 011637 001236 2\$: MOV (SP), \$TMP2
6617 033662 022626 CMP (SP)+, (SP)+
6618 033664 104377 ERROR +377
033666 000010 .WORD 10
6619 ;(BUT FDST)+ ST634
6620
6621 033670 280\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
03670 104412 :SEE IF THE USER HAS EXPRESSED
 :THE DESIRE TO CHANGE THE SOFTWARE
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS
 :THE USER TYPED CONTROL G?).

```

6622 .SBTTL TEST # 63 - DESTINATION MODES, MODE 4 (FL=0), TEST
      **** TEST 63 DESTINATION MODES, MODE 4 (FL=0), TEST ****
      * THIS IS A TEST OF DESTINATION MODE 4 USING
      * THE STFPS INSTRUCTION
      ****

033672 000004
6623 033674 012737 033702 001110 TST63: SCOPE
6624 033702 012700 034000 200$: MOV #200$,SLPERR :SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
6625 033706 012701 000006
6626 033712 012720 177777 1$: MOV #105555,RO :SET UP THE DATA BUFFER.
6627 033716 077103
6628 033720 012700 105555
6629 033724 012737 033746 001236
6630 033732 012737 034100 000004
6631 033740 170100
6632 033742 012700 034006
6633
6634 033746 170240 220$: STFPS -(R0) :TEST INSTRUCTION.
6635 033750 020027 034004 CMP R0,#240$ :IS R0 CORRECT?
6636 033754 001017 BNE 250$ :BRANCH IF NOT CORRECT.
6637 033756 023727 034004 105555 CMP 240$,#105555 :IS THE RESULT CORRECT?
6638 033764 001023 BNE 260$ :BRANCH IF NOT CORRECT.
6639 033766 023727 034006 177777 CMP 240$+2,#-1 :IS THE RESULT CORRECT?
6640 033774 001030 BNE 270$ :BRANCH IF NOT CORRECT.
6641 033776 000453 BR 280$ :BRANCH IF NOT CORRECT.

6642
6643 :TEST DATA BUFFER:
6644 034000 177777 177777 210$: .WORD -1,-1
6645 034004 177777 177777 240$: .WORD -1,-1,-1,-1
6646
6647 :REPORT R0 INCORRECT.
6648 034014 010037 001242 250$: MOV R0,$TMP4
6649 034020 012737 034004 001240 MOV #240$,TMP3
6650 034026 104377 ERROR +377
6651 034030 000011 .WORD 11
6652 034032 000435 BR 280$ :R0 BAD (BUT :FDST)X
6653
6654 :REPORT RESULT INCORRECT.
6655 034034 012737 105555 001240 260$: MOV #105555,$TMP3 : ST 634
6656 034042 013737 034004 001242 MOV 240$,TMP4
6657 034050 104377 ERROR +377
6658 034052 000012 .WORD 12 :BAD DATA
6659 034054 000424 BR 280$
6660
6661
6662 :REPORT RESULT INCORRECT.
6663 034056 012737 177777 001240 270$: MOV #-1,$TMP3
6664 034064 013737 034006 001242 MOV 240$+2,$TMP4
6665 034072 104377 ERROR +377
6666 034074 000013 .WORD 13 : (BUT GR7,FL)
6667 034076 000413 BR 280$ :ST 357 TO 416

```

6668
6669
6670 :IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6671 :DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6672 :TO THE SPURIOUS TRAP TO 4 HANDLER.
6673 034100 011604 230\$: MOV (SP), R4
6674 034102 020427 033750 CMP R4, #220\$+2
6675 034106 001402 BEQ 2\$
6676 034110 000137 051774 JMP CPSPUR
6677
6678 034114 011637 001236 2\$: MOV (SP), \$TMP2
6679 034120 022626 CMP (SP)+, (SP)+
6680 034122 104377 ERROR +377
034124 000014 .WORD 14
6681
6682 034126 104412 280\$: RSETUP : (BUT FDST)+ ST634
034126 104412 :GO INITIALIZE THE FPS AND STACK; AND
:SEE IF THE USER HAS EXPRESSED
:THE DESIRE TO CHANGE THE SOFTWARE
:VIRTUAL CONSOLE SWITCH REGISTER (HAS
:THE USER TYPED CONTROL G?).

6683 .SBTTL TEST # 64 - DESTINATION MODES, MODE 3 (FL=0), TEST

 * TEST 64 DESTINATION MODES, MODE 3 (FL=0), TEST
 *
 * THIS IS A TEST OF DESTINATION MODE 3 USING
 * THE STFPS INSTRUCTION

034130 000004	034132 012737 034140 001110	TST64: SCOPE				
6684 034132 012737 034140 001110	200\$: MOV #200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.				:DPM002
6685 034140 012700 034242	MOV #210\$,R0	;SET UP THE DATA BUFFER.				
6686 034144 012701 000010	MOV #10,R1					
6687 034150 012720 177777	1\$: MOV #-1,(R0)+					
6688 034154 077103	S0B R1,1\$					
6689 034156 012700 106653	MOV #106653,R0					
6690 034162 012737 034210 001236	MOV #220\$,\$TMP2					
6691 034177 012737 034346 000004	MOV #230\$,ERRVECT	;SET UP FOR TRAPS TO VECTOR 4.				
6692 034176 170100	LDFPS R0	;SET UP FPS.				
6693 034200 012700 034256	MOV #240\$,R0					
6694 034204 012710 034246	MOV #250\$,,(R0)					
6695						
6696 034210 170230	220\$: STFPS a(R0)+	;TEST INSTRUCTION.				
6697 034212 020027 034260	CMP R0,#240\$+2	;IS R0 CORRECT?				
6698 034216 001021	BNE 260\$;BRANCH IF NOT CORRECT.				
6699 034220 023727 034246 106653	CMP 250\$,#106653	;IS THE RESULT CORRECT?				
6700 034226 001025	BNE 270\$;BRANCH IF NOT CORRECT.				
6701 034230 023727 034256 034246	CMP 240\$,#250\$;IS THE RESULT CORRECT?				
6702 034236 001032	BNE 280\$;BRANCH IF NOT CORRECT.				
6703 034240 000455	BR 290\$					
6704						
6705						
6706 034242 177777 177777	210\$: .WORD -1,-1	;TEST DATA BUFFER:				
6707 034246 177777 177777 177777	250\$: .WORD -1,-1,-1,-1					
6708 034256 177777 177777	240\$: .WORD -1,-1					
6709						
6710						
6711 034262 010037 001242	260\$: REPORT R0 INCORRECT.					
6712 034266 012737 034260 001240	MOV R0,\$TMP4					
6713 034274 104377	MOV #240\$+2,\$TMP3					
034276 000015	ERROR +377					
6714						
6715 034300 000435	.WORD 15					
6716						
6717						
6718 034302 012737 106653 001240	270\$: REPORT RESULT INCORRECT.					
6719 034310 013737 034246 001242	MOV #106653,\$TMP3					: ST 634
6720 034316 104377	MOV 250\$,TMP4					
034320 000016	ERROR +377					
6721						
6722 034322 000424	.WORD 16					:BAD DATA
6723						
6724						
6725						
6726 034324 012737 034256 001240	280\$: REPORT RESULT INCORRECT.					
6727 034332 013737 034250 001242	MOV #240\$,TMP3					: (BUT FDST)
6728 034340 104377	MOV 250\$+2,TMP4					
034342 000017	ERROR +377					
	.WORD 17					

6729 034344 000413 BR 290\$
6730
6731
6732 ;IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6733 ;DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6734 ;TO THE SPURIOUS TRAP TO 4 HANDLER.
6735 034346 011604 230\$: MOV (SP), R4
6736 034350 020427 034212 CMP R4, #220\$+2
6737 034354 001402 BEQ 2\$
6738 034356 000137 051774 JMP CPSPUR
6739
6740 034352 011637 001236 2\$: MOV (SP), \$TMP2
6741 034366 022626 CMP (SP)+, (SP)+
6742 034370 104377 ERROR +377
6743 034372 000020 .WORD 20 ;(BUT FDST)+ ST634
6744 034374 104412 290\$: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

6745

.S9TTL TEST # 65 - DESTINATION MODES, MODE 5 (FL=0), TEST

TEST 65 DESTINATION MODES, MODE 5 (FL=0), TEST
*
* THIS IS A TEST OF DESTINATION MODE 5 USING
* THE STFPS INSTRUCTION

6746 034376 000004	034400 012737 034406 001110	TST65: SCOPE				
6747 034406 012700 034512	012700 034512 000006	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		
6748 034412 012701	012701 177777	200\$: MOV	#210\$,R0	:SET UP THE DATA BUFFER.	:DPM002	
6749 034416 012720	012720 004301	1\$: MOV	#6,R1			
6750 034422 077103	077103 004301	1\$: MOV	#-1,(R0)+			
6751 034424 012700	012700 004301	1\$: MOV	S08 R1,1\$			
6752 034430 012737	012737 034460 001236	1\$: MOV	#004301,R0			
6753 034436 012737	012737 034616 000004	1\$: MOV	#220\$,STMP2			
6754 034444 170100	012700 034530	1\$: LDPS	#230\$,ERRVECT	:SET UP FOR TRAPS TO VECTOR 4.		
6755 034446 012760	012760 034516 177776	1\$: MOV	R0 #240\$+2,R0	:SET UP FPS.		
6756 034452		1\$: MOV	#250\$,-2(R0)			
6757						
6758 034460 170250	020027 034526	220\$: STFPS	a-(R0)	:TEST INSTRUCTION.		
6759 034462 020027	034526	220\$: CMP	R0,#240\$:IS R0 CORRECT?		
6760 034466 001021		220\$: BNE	260\$:BRANCH IF NOT CORRECT.		
6761 034470 023727	034516 004301	220\$: CMP	250\$,#004301	:IS THE RESULT CORRECT?		
6762 034476 001025		220\$: BNE	270\$:BRANCH IF NOT CORRECT.		
6763 034500 023727	034526 034516	220\$: CMP	240\$,#250\$:IS THE RESULT CORRECT?		
6764 034506 001032		220\$: BNE	280\$:BRANCH IF NOT CORRECT.		
6765 034510 000455		220\$: BR	290\$			
6766						
6767						
6768 034512 177777	177777 177777	:TEST DATA BUFFER:				
6769 034516 177777	177777 177777	210\$: .WORD	-1,-1			
6770 034526 177777	177777 177777	250\$: .WORD	-1,-1,-1,-1			
6771						
6772						
6773 034532 010037	001242	:REPORT R0 INCORRECT.				
6774 034536 012737	034526 001240	260\$: MOV	R0,STMP4			
6775 034544 104377		260\$: MOV	#240\$,STMP3			
034546 000021		260\$: ERROR	+377			
6776		260\$: .WORD	21			
6777 034550 000435		BR 290\$:RC BAD (BUT FDST)X		
6778						
6779						
6780 034552 012737	004301 001240	:REPORT RESULT INCORRECT.				
6781 034560 013737	034516 001242	270\$: MOV	#004301,STMP3		: ST 634	
6782 034566 104377		270\$: MOV	250\$,STMP4			
034570 000022		270\$: ERROR	+377			
6783		270\$: .WORD	22			
6784 034572 000424		BR 290\$:BAD DATA		
6785						
6786						
6787						
6788 034574 012737	034526 001240	:REPORT RESULT INCORRECT.				
6789 034602 013737	034520 001242	280\$: MOV	#240\$,STMP3			
6790 034610 104377		280\$: MOV	250\$+2,STMP4		:BUT FDST)	
034612 000023		280\$: ERROR	+377			
		280\$: .WORD	23			

6791
6792 034614 000413 BR 290\$;(BUT GR7,FL)
6793 ;ST 357 TO 416
6794 ;INTO 417
6795 ;IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6796 ;DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6797 ;TO THE SPURIOUS TRAP TO 4 HANDLER.
6798 034616 011604 230\$: MOV (SP), R4
6799 034620 020427 034462 CMP R4, #220\$+2
6800 034624 001402 BEQ 2\$
6801 034626 000137 051774 JMP CPSPUR
6802
6803 034632 011637 001236 2\$: MOV (SP), \$TMP2
6804 034636 022626 CMP (SP)+, (SP)+
6805 034640 104377 ERROR +377
034642 000024 .WORD 24
6806 ;(BUT FDST)+ ST634
6807 034644 104412 290\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
034644 ;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

6808 .SBTTL TEST # 66 - DESTINATION MODES, MODE 6 (FL=0), TEST
 :*****
 :* TEST 66 DESTINATION MODES, MODE 6 (FL=0), TEST
 :*
 :* THIS IS A TEST OF DESTINATION MODE 6 USING
 :* THE STFPS INSTRUCTION
 :*
 :*****

6809 034646 000004	TST66: SCOPE			
6810 034650 012767 034656 144232	.DSABL	AMA	:DISABLE MODE 6 TO MODE 3 CONVERSIONS	
6811 034656 012700 034766	MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	
6812 034662 012701 000006	MOV	#210\$,R0	:SET UP THE DATA BUFFER.	:DPM002
6813 034666 012720 177777	MOV	#6,R1		
6814 034672 077103	MOV	#-1,(R0)+		
6815 034674 012700 102514	S0B	R1,IS		
6816 034700 012767 034724 144330	MOV	#102514,R0		
6817 034706 012767 035066 143070	MOV	#220\$,\$TMP2		
6818 034714 170100	LDFPS	#230\$,ERRVECT	:SET UP FOR TRAPS TO VECTOR 4.	
6819 034716 005001	CLR	R0	:SET UP FPS.	
6820 034720 012700 027571	MOV	R1		
		#240\$-5201,R0		
6821				
6822 034724 170260 005201	220\$: STFPS	5201(R0)	:TEST INSTRUCTION.	
6823 034730 020127 000000	CMP	R1,#0	:WAS PC CORRECT AFTER EXECUTION?	
6824 034734 001070	BNE	250\$:BRANCH IF NOT CORRECT.	
6825 034736 020027 027571	CMP	R0,#240\$-5201	:IS R0 CORRECT?	
6826 034742 001017	BNE	260\$:BRANCH IF NOT CORRECT.	
6827 034744 026727 000022 102514	CMP	240\$,#102514	:IS THE RESULT CORRECT?	
6828 034752 001023	BNE	270\$:BRANCH IF NOT CORRECT.	
6829 034754 026727 000014 177777	CMP	240\$+2,#-1	:IS THE RESULT CORRECT?	
6830 034762 001030	BNE	280\$:BRANCH IF NOT CORRECT.	
6831 034764 000456	BR	290\$		
6832				
6833			:TEST DATA BUFFER:	
6834 034766 177777 177777	210\$: .WORD	-1,-1		
6835 034772 177777 177777 177777	240\$: .WORD	-1,-1,-1,-1		
6836				
6837			:REPORT R0 INCORRECT.	
6838 035002 010067 144234	260\$: MOV	R0,\$TMP4		
6839 035006 012767 027571 144224	MOV	#240\$-5201,\$TMP3		
6840 035014 104377	ERROR	+377		
035016 000025	.WORD	25		
6841				
6842 035020 000440	BR	290\$:R0 BAD	
6843				
6844			:REPORT RESULT INCORRECT.	
6845 035022 012767 102534 144210	270\$: MOV	#102534,\$TMP3		
6846 035030 016767 177736 144204	MOV	240\$,TMP4		
6847 035036 104377	ERROR	+377		
035040 000026	.WORD	26		
6848				
6849 035042 000427	BR	290\$:BAD DATA	
6850				
6851				
6852			:REPORT RESULT INCORRECT.	
6853 035044 012767 177777 144166	280\$: MOV	#-1,\$TMP3		
6854 035052 016767 177716 144162	MOV	240\$+2,\$TMP4		

```

6855 035060 104377           ERROR    +377
6856 035062 000027           .WORD    27
6857 035064 000416           BR       290S
6858                                         ;(BUT GR7,FL)
6859                                         ;ST 357 TO 416
6860                                         ;INTO 417
6861
6862 :IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6863 035066 011604           :DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6864 035070 020427           TO THE SPURIOUS TRAP TO 4 HANDLER.
6865 035074 001402           230S:   MOV     (SP),R4
6866 035076 000167           CMP     R4,#220S+2
6867                                         BEQ     2S
6868 035102 011667           JMP     CPSPUR
6869 035106 022626           2$:    MOV     (SP),$TMP2
6870 035110 104377           CMP     (SP)+,(SP) +
6871 035112 000030           ERROR   +377
6872 035114 000402           .WORD   30
6873                                         ;(BUT FDST)+ ST634
6874
6875 035116
6876 035116 104377           ;REPORT PC NOT INCREMENTED BY 2 DURING EXECUTION.
6877 035120 000031           250S:   ERROR   +377
6878 035122
6879 035122 104412           .WORD   31
6880                                         ;PC NOT INCREMENTED BY 2
6881
6882 290S:   RSETUP
6883                                         ;GO INITIALIZE THE FPS AND STACK; AND
6884                                         ;SEE IF THE USER HAS EXPRESSED
6885                                         ;THE DESIRE TO CHANGE THE SOFTWARE
6886                                         ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
6887                                         ;THE USER TYPED CONTROL G?).
6888                                         ;RESET MODE 6 TO MODE 3 CONVERSIONS
6889 .ENABL  AMA

```

6880

SBTTL TEST # 67 - DESTINATION MODES, MODE 7 (FL=0), TEST

TEST 67 DESTINATION MODES, MODE 7 (FL=0), TEST
* THIS IS A TEST OF DESTINATION MODE 7 USING
* THE STFPS INSTRUCTION

035124 000004 035126 012737 035134 001110 TST67: SCOPE
 6881 035126 012737 035134 001110 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS.
 6882 035134 012700 035252 000010 200\$: MOV #210\$,R0 ;SET UP THE DATA BUFFER.
 6883 035140 012701 000010 1\$: MOV #10,R1
 6884 035144 012720 177777 1\$: MOV #-1,(R0)+
 6885 035150 077103 S0B R1,1\$
 6886 035152 012700 103747 MOV #103747,R0
 6887 035156 012737 035210 001236 MOV #220\$,STMP2
 6888 035164 012737 035356 000004 MOV #230\$,ERRVECT ;SET UP FOR TRAPS TO VECTOR 4.
 6889 035172 170100 LDFPS R0 ;SET UP FPS.
 6890 035174 005001 CLR R1
 6891 035176 012700 030065 MOV #240\$-5201,R0
 6892 035202 012760 035256 005201 MOV #250\$,5201(R0)
 6893
 6894 035210 170270 005201 220\$: STFPS @5201(R0) ;TEST INSTRUCTION.
 6895 035214 022701 000000 CMP #0,R1 ;WAS PC CORRECT AFTER EXECUTION?
 6896 035220 001072 BNE 260\$;BRANCH IF NOT CORRECT.
 6897 035222 020027 030065 CMP R0,#240\$-5201 ;IS R0 CORRECT?
 6898 035226 001021 BNE 270\$;BRANCH IF NOT CORRECT.
 6899 035230 023727 035256 103747 CMP 250\$,#103747 ;IS THE RESULT CORRECT?
 6900 035236 001025 BNE 280\$;BRANCH IF NOT CORRECT.
 6901 035240 023727 035260 177777 CMP 250\$+2,#-1 ;IS THE RESULT CORRECT?
 6902 035246 001032 BNE 290\$;BRANCH IF NOT CORRECT.
 6903 035250 000460 BR 300\$;
 6904
 6905 :TEST DATA BUFFER:
 6906 035252 177777 177777 210\$: .WORD -1,-1
 6907 035256 177777 177777 250\$: .WORD -1,-1,-1,-1
 6908 035266 177777 177777 240\$: .WORD -1,-1
 6909
 6910 :REPORT R0 INCORRECT.
 6911 035272 010037 001242 270\$: MOV R0,STMP4
 6912 035276 012737 030065 001240 MOV #240\$-5201,STMP3
 6913 035304 104377 ERROR +377
 035306 000032 .WORD 32 ;
 6914 :R0 BAD
 6915 035310 000440 BR 300\$
 6916
 6917
 6918 :REPORT RESULT INCORRECT.
 6919 035312 012737 103747 001240 280\$: MOV #103747,STMP3
 6920 035320 013737 035256 001242 MOV 250\$,STMP4
 6921 035326 104377 ERROR +377
 035330 000033 .WORD 33 ;BAD DATA
 6922
 6923 035332 000427 BR 300\$
 6924
 6925
 6926 ;REPORT RESULT INCORRECT.

6927 035334 012737 177777 001240 290\$: MOV #-1,\$TMP3
6928 035342 013737 035260 001242 MOV 250\$+2,\$TMP4
6929 035350 104377 ERROR +377
035352 000034 .WORD 34
6930 :
6931 035354 000416 BR 300\$: (BUT GR7,FL)
6932 : ST 357 TO 416
6933 : INTO 417
6934 :
6935 : IF A TRAP TO VECTOR 4 OCCURS COME HERE TO SEE IF THE TRAP OCCURRED
6936 : DURING EXECUTION OF THE FPP INSTRUCTION BEING TESTED, IF NOT GO
6937 035356 011604 035212 230\$: MOV (SP),R4
6938 035360 020427 035212 CMP R4,#220\$+2
6939 035364 001402 BEQ 2\$
6940 035366 000137 051774 JMP CPSPUR
6941 035372 011637 001236 2\$: MOV (SP),\$TMP2
6942 035376 022626 CMP (SP)+,(SP)+
6943 035400 104377 ERROR +377
035402 000035 .WORD 35
6944 : (BUT FSDT)+ ST634
6945 035404 000402 BR 300\$
6946 :
6947 : REPORT PC NOT INCREMENTED BY 2 DURING EXECUTION.
6948 035406 035406 104377 260\$: ERROR +377
035410 000036 .WORD 36
6949 : PC NOT
6950 : INCREMENTED
6951 035412 035412 104412 300\$: RSETUP : GO INITIALIZE THE FPS AND STACK; AND
: SEE IF THE USER HAS EXPRESSED
: THE DESIRE TO CHANGE THE SOFTWARE
: VIRTUAL CONSOLE SWITCH REGISTER (HAS
: THE USER TYPED CONTROL G?).

6958 .SBTTL TEST # 70 - DESTINATION MODES, MODE 2 (FL=1), TEST
 :*****
 :TEST 70 DESTINATION MODES, MODE 2 (FL=1), TEST
 :
 : THIS IS A TEST OF DESTINATION MODE
 : 2 USING STCOL WITH REGISTER 0
 :*****

035414 000004	035416 012737	035424 001110	TST70: SCOPE			
6959 035416 012737	035424 001110	200\$: MOV	#200\$,SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.	:DPM002	
6960 035424 012700	000300	MOV	#300,RO	;SET UP FPS.		
6961 035430 170100		LDFPS	RO			
6962 035432 012700	035502	MOV	#210\$,RO	;SET UP THE ACO OPERAND.		
6963 035435 172410		LDD	(RO),ACO			
6964 035440 012737	035452 001236	MOV	#220\$,STMP2			
6965 035446 012700	035514	MOV	#230\$,RO			
6966						
6967 035452 175420		220\$: STCDL	ACO,(RO)+	;TEST INSTRUCTION.		
6968						
6969 035454 020027	035520	CMP	RO,#230\$+4	;IS RO CORRECT?		
6970 035460 001420		BEQ	240\$;BRANCH IF CORRECT.		
6971						
6972			:REPORT RO INCORRECT.			
6973 035462 010037	001242 001240	MOV	RO,STMP4			
6974 035466 012737	035520	MOV	#230\$+4,STMP3			
6975 035474 104377		ERROR	+377			
6976 035476 00003?		.WORD	37			
6977 035500 000410				:RO NOT INCR BY 4		
6978						
6979 035502 000000	000000 000000	TEST DATA BUFFER:				
6980 035512 177777		210\$: .WORD	0,0,0,0			
6981 035514 177777	177777	-1				
6982						
6983 035522 035522	104412	230\$: .WORD	-1,-1,-1			
		240\$: RSETUP				
				:GO INITIALIZE THE FPS AND STACK; AND		
				:SEE IF THE USER HAS EXPRESSED		
				:THE DESIRE TO CHANGE THE SOFTWARE		
				:VIRTUAL CONSOLE SWITCH REGISTER (HAS		
				:THE USER TYPED CONTROL G?).		

6990

.SBTTL TEST # 71 - DESTINATION MODES, MODE 4 (FL=1), TEST

 *TEST 71 DESTINATION MODES, MODE 4 (FL=1), TEST
 *
 * THIS IS A TEST OF DESTINATION MODE
 * 4 USING STCDL WITH REGISTER 0

6991	035524	000004		TST71: SCOPE			
6992	035526	012737	035534	001110	200\$: MOV	#200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.
6993	035534	012700	000300		200\$: MOV	#300,RO	:SET UP FPS.
6994	035540	170100			200\$: LDFPS	RO	
6995	035542	012700	035612		200\$: MOV	#210\$,RO	:SET UP THE ACO OPERAND.
6996	035546	172410			200\$: LDD	(RO),ACO	
6997	035550	012737	035562	001236	220\$: MOV	#220\$,\$TMP2	
6998	035556	012700	035630		220\$: MOV	#230\$+4,RO	
6999	035562	175440			220\$: STCDL	ACO,-(RO)	:TEST INSTRUCTION.
7000					220\$: CMP	RO,#230\$	
7001	035564	020027	035624		220\$: BEQ	240\$:IS RO CORRECT?
7002	035570	001420					
7003							
7004							
7005	035572	010037	001242				
7006	035576	012737	035624	001240			
7007	035604	104377					
	035606	000040					
7008							
7009	035610	000410					
7010							
7011	035612	000000	000000	000000	210\$: TEST DATA BUFFER:		
7012	035622	177777			210\$: .WORD	0,0,0,0	
7013	035624	177777	177777	177777	230\$: .WORD	-1	
7014					230\$: .WORD	-1,-1,-1	
7015	035632				240\$: RSETUP		
	035632	104412					

:REPORT RO INCORRECT.
 :MOV RO,\$TMP4
 :MOV #230\$,TMP3
 :ERROR +377
 :WORD 40
 :RO NOT DECR BY 4
 :TEST DATA BUFFER:
 :.WORD 0,0,0,0
 :-1
 :.WORD -1,-1,-1
 :GO INITIALIZE THE FPS AND STACK; AND
 :SEE IF THE USER HAS EXPRESSED
 :THE DESIRE TO CHANGE THE SOFTWARE
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS
 :THE USER TYPED CONTROL G?).

7025

.SBTTL TEST # 72 - STCDI AND STCDL TEST

***** TEST 72 STCDI AND STCDL TEST *****

* THIS IS A TEST OF THE STCDI AND
 * STCDL INSTRUCTIONS. NOTE THAT A
 * SUBROUTINE, STCSUB, IS USED TO
 * SET UP THE OPERANDS, EXECUTE THE STC
 * INSTRUCTION AND CHECK THE RESULT.

TST72: SCOPE

:FIRST TEST STC WITH EXP=100 (EXCESS 200)

7026 035634 000004	200\$: MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
7027 035636 012737 035644 001110	JSR PC,STCSUB	:GO EXECUTE THE INSTRUCTION.	
7028 035644 004737 037110	1\$: .WORD 20000,0,0,0	:AC0 OPERAND.	
7029 035650 020000 000000 000000	2\$: .WORD 0,0	:EXPECTED RESULT.	
7030 035660 000000 000000	3\$: .WORD -1,-1	:ERROR RES.	
7031 035664 177777 177777	4\$: 40300	:FPS BEFORE EXECUTION.	
7032 035670 040300	40304	:FPS AFTER EXECUTION.	
7033 035672 040304	140304	:ANTICIPATED ERRONEOUS FPS.	
7034 035674 40304	-1	:REPORT RESULT INCORRECT.	
7035 035676 177777	5\$: ERROR +322	:RESULT INCORP.	
7036 035700 104322	BR 6\$		
7037 035702 000401	ERROR +325	:EITHER (BUT FLAG)	
7038 035704 104325		:ST 662	
7039 035706		:OR CLEAR FLAG	
7040		:ST 774	
7041			
7042			
7043			
7044 035706 012737 035714 001110	:EXP=0 (OCT) 210\$: MOV #210\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
7045 035714 004737 037110	JSR PC,STCSUB	:GO EXECUTE THE INSTRUCTION.	
7046 035720 040000 000000 000000	11\$: .WORD 40000,0,0,0	:AC ;AC0 OPERAND.	
7047 035730 000000 000000	12\$: .WORD 0,0	:EXPECTED RESULT.	
7048 035734 177777 177777	13\$: .WORD -1,-1	:ANTICIPATED ERRONEOUS RESULT.	
7049 035740 040313	14\$: 40313	:FPS BEFORE EXECUTION.	
7050 035742 040304	40304	:FPS AFTER EXECUTION.	
7051 035744 140304	140304	:ANTICIPATED ERRONEOUS FPS.	
7052 035746 177777	-1	:EXPECTED FEC.	
7053 035750 104322	15\$: ERROR +322	:REPORT RESULT INCORRECT.	
7054 035752 000401	BR 16\$		
7055 035754 104326	ERROR +326	:REPORT FPS INCORRECT.	
7056 035756	16\$:		
7057			
7058			
7059 035756 012737 035764 001110	:EXP=37 (OCT) 220\$: MOV #220\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	;DPM002
7060 035764 004737 037110	JSR PC,STCSUB	:GO EXECUTE THE INSTRUCTION.	
7061 035770 047667 075757 157737	21\$: .WORD 47667,75757,157737,167773	:AC0 OPERAND.	
7062 036000 055675 173757	22\$: .WORD 55675,173757	:EXPECTED RESULT.	
7063 036004 122102 004021	23\$: .WORD 122102,004021	:ANTICIPATED ERRONEOUS RESULT.	
7064 036010 040717	24\$: 40717	:FPS BEFORE EXECUTION.	
7065 036012 040700	40700	:FPS AFTER EXECUTION.	
7066 036014 140705	140705	:ANTICIPATED ERRONEOUS FPS.	
7067 036016 177777	-1	:EXPECTED FEC.	
7068 036020 104327	25\$: ERROR +327	:(BUT ENBT) ST 632	
7069 036022 000401	BR 26\$		
7070 036024 104326	ERROR +326	:REPORT FPS INCORRECT.	

7071 036026 26\$: ;EXP=40 (OCT) FL=1 FIC=1
 7072 ;MOV #230\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 7073 ;JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7074 036026 012737 036034 001110 230\$: .WORD 50000,0,0,0 ;AC0 OPERAND.
 7075 036034 004737 037110 000000 31\$: .WORD 0,0 ;EXPECTED RESULT.
 7076 036040 050000 000000 000000 32\$: .WORD -1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7077 036050 000000 000000 000000 33\$: .WORD 40700 ;FPS BEFORE EXECUTION.
 7078 036054 177777 177777 34\$: .WORD 140705 ;FPS AFTER EXECUTION.
 7079 036060 040700 35\$: .WORD 40705 ;ANTICIPATED ERRONEOUS FPS.
 7080 036062 140705 ;EXPECTED FEC.
 7081 036064 040705 ;REPORT RESULT INCORRECT.
 7082 036066 000006 ;(BUT FIC) ST 004
 7083 036070 104322 35\$: ERROR +322 ;TO 305 INTO ;REPORT FPS INCORRECT.
 7084 036072 000401 BR 36\$
 7085 036074 104330 ERROR +330 ;315
 7086 ;36\$: ;
 7087 036076 ;
 7088 ;
 7089 ;
 7090 036076 012737 036104 001110 ;EXP=40 (OCT) FL=1 FIC=0 ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 7091 036104 004737 037110 240\$: .WORD #240\$,SLPERR ;GO EXECUTE THE INSTRUCTION.
 7092 036110 050000 000000 000000 41\$: .WORD 50000,0,0,0 ;AC0 OPERAND.
 7093 036120 000000 000000 000000 42\$: .WORD 0,0 ;EXPECTED RESULT.
 7094 036124 177777 177777 43\$: .WORD -1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7095 036130 040312 44\$: .WORD 40312 ;FPS BEFORE EXECUTION.
 7096 036132 040305 40305 ;FPS AFTER EXECUTION.
 7097 036134 140305 140305 ;ANTICIPATED ERRONEOUS FPS.
 7098 036136 177777 ;EXPECTED FEC.
 7099 036140 104322 45\$: .WORD 40700 ;REPORT RESULT INCORRECT.
 7100 036142 000401 BR 46\$
 7101 036144 104331 ERROR +331 ;(BUT FIC) ST 004 TO ;315 INTO 305
 7102 036146 46\$: ;
 7103 ;
 7104 ;
 7105 036146 012737 036154 001110 ;EXP=30 (OCT) FL=1 FIC=1 ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 7106 036154 004737 037110 250\$: .WORD #250\$,SLPERR ;GO EXECUTE THE INSTRUCTION.
 7107 036160 046000 000001 000000 51\$: .WORD 46000,1,0,0 ;AC0 OPERAND.
 7108 036170 000200 000001 000000 52\$: .WORD 200,1 ;EXPECTED RESULT.
 7109 036174 177777 177777 53\$: .WORD -1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7110 036200 040700 54\$: .WORD 40700 ;FPS BEFORE EXECUTION.
 7111 036202 040700 40700 ;FPS AFTER EXECUTION.
 7112 036204 177777 -1 ;ANTICIPATED ERRONEOUS FPS.
 7113 036206 177777 ;EXPECTED FEC.
 7114 036210 104322 55\$: .WORD 40700 ;REPORT RESULT INCORRECT.
 7115 036212 000401 BR 56\$
 7116 036214 104323 ERROR +323 ;REPORT FPS INCORRECT.
 7117 036216 56\$: ;
 7118 ;
 7119 ;
 7120 036216 012737 036224 001110 ;EXP=27 (OCT) FL=1 FIC=1 ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
 7121 036224 004737 037110 260\$: .WORD #260\$,SLPERR ;GO EXECUTE THE INSTRUCTION.
 7122 036230 045600 000001 000000 61\$: .WORD 45600,1,0,0 ;AC0 OPERAND.
 7123 036240 000100 000000 000000 62\$: .WORD 100,0 ;EXPECTED RESULT.
 7124 036244 177777 177777 63\$: .WORD -1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7125 036250 040707 64\$: .WORD 40707 ;FPS BEFORE EXECUTION.
 7126 036252 040700 40700 ;FPS AFTER EXECUTION.
 7127 036254 177777 -1 ;ANTICIPATED ERRONEOUS FPS.

TEST # 72 - STCDI AND STCDL TEST

7128 036256 177777
 7129 036260 104322
 7130 036262 000401
 7131 036264 104323
 7132 036266
 7133
 7134
 7135 036266 012737 036274 001110 :EXP=17 (OCT) FL=0 FIC=1
 7136 036274 004737 037110 000000 MOV #270\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
 7137 036300 043600 000000 000000 JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7138 036310 040000 177777 000000 .WORD 43600,0,0,0 ;AC0 OPERAND.
 7139 036314 000000 177777 000000 .WORD 40000,-1 ;EXPECTED RESULT.
 7140 036320 040600 000000 000000 .WORD 0,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7141 036322 040600 000000 000000 40600 ;FPS BEFORE EXECUTION.
 7142 036324 140604 000000 000000 140604 ;FPS AFTER EXECUTION.
 7143 036326 177777 000000 000000 -1 ;ANTICIPATED ERRONEOUS FPS.
 7144 036330 104332 000000 000000 :EXP=18 (OCT) FL=0 FIC=1
 7145 036332 000401 000000 000000 MOV #280\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
 7146 036334 104333 000000 000000 JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7147 036336 000000 000000 .WORD 44000,0,0,0 ;AC0 OPERAND.
 7148
 7149
 7150 036336 012737 036344 001110 :EXP=20 (OCT) FL=0 FIC=1
 7151 036344 004737 037110 000000 MOV #280\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
 7152 036350 044000 000000 000000 JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7153 036360 000000 177777 000000 .WORD 44000,0,0,0 ;AC0 OPERAND.
 7154 036364 177777 177777 000000 .WORD 0,-1 ;EXPECTED RESULT.
 7155 036370 040600 000000 000000 .WORD -1,-1 ;ANTICIPATED ERRONEOUS RESULT.
 7156 036372 140605 000000 000000 40600 ;FPS BEFORE EXECUTION.
 7157 036374 040600 000000 000000 140605 ;FPS AFTER EXECUTION.
 7158 036376 000006 000000 000000 40600 ;ANTICIPATED ERRONEOUS FPS.
 7159 036400 104322 000000 000000 :EXP=19 (OCT) FL=0 FIC=1
 7160 036402 000401 000000 000000 85\$: ERROR +322 ;REPORT RESULT INCORRECT.
 7161 036404 104334 000000 000000 BR 86\$
 7162 036406 000000 000000 ERROR +334 ;BAD CONSTANT ST 066
 7163
 7164 :EXP=10 (OCT). AC NEGATIVE, FL=0, FIC=1
 7165 036406 012737 036414 001110 MOV #290\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
 7166 036414 004737 037110 000000 JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7167 036420 142000 000000 000000 .WORD 142000,0,0,0 ;AC0 OPERAND.
 7168 036430 177600 177777 000000 .WORD 177600,-1 ;EXPECTED RESULT.
 7169 036434 000200 000000 000000 .WORD 200,0 ;ANTICIPATED ERRONEOUS RESULT.
 7170 036440 040600 000000 000000 40600 ;FPS BEFORE EXECUTION.
 7171 036442 040610 000000 000000 40610 ;FPS AFTER EXECUTION.
 7172 036444 040600 000000 000000 40600 ;ANTICIPATED ERRONEOUS FPS.
 7173 036446 177777 000000 000000 -1 :EXP=21 (OCT) FL=0 FIC=1
 7174 036450 104335 000000 000000 95\$: ERROR +335 ;(BUT ENBT) ST 632
 7175 036452 000401 000000 000000 BR 96\$
 7176 036454 104336 000000 000000 ERROR +336 ;(SET FN) ST 473
 7177 036456 000000 000000 96\$: :EXP=37 (OCT), FL=1, FIC=1, AC NEG.
 7178
 7179
 7180 036456 012737 036464 001110 MOV #300\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. :DPM002
 7181 036464 004737 037110 000000 JSR PC,STCSUB ;GO EXECUTE THE INSTRUCTION.
 7182 036470 147600 000000 000000 .WORD 147600,0,0,0 ;AC0 OPERAND.
 7183 036500 140000 000000 000000 .WORD 140000,0 ;EXPECTED RESULT.
 7184 036504 137777 000000 000000 .WORD 137777,0 ;ANTICIPATED ERRONEOUS RESULT.

M 13

7185 036510 040700	104\$: 40700	:FPS BEFORE EXECUTION.
7186 036512 040710	40710	:FPS AFTER EXECUTION.
7187 036514 177777	-1	:ANTICIPATED ERRONEOUS FPS.
7188 036516 177777	-1	:EXPECTED FEC.
7189 036520 104337	105\$: ERROR +337	: (BUT COUT) ST 375
7190 036522 000401	BR 106\$: ST 275 TO 074
7191 036524 104323	ERROR +323	: INTO 274
7192 036526	106\$:	
7193		
7194		
7195 036526 012737 036534 001110	: EXP=37 (OCT), MOV #310\$, \$LPERR	: AC NEG, :Sr. UP THE LOOP ON ERROR ADDRESS. ;DPM002
7196 036534 004737 037110	JSR PC, STCSUB	: GO EXECUTE THE INSTRUCTION.
7197 036540 147600 000000 001000	111\$: .WORD 147600, 0, 1000, 0	: ACO OPERAND.
7198 036550 137777 177777	112\$: .WORD 137777, 177777	: EXPECTED RESULT.
7199 036554 140000 177777	113\$: .WORD 140000, 177777	: ANTICIPATED ERRONEOUS RESULT.
7200 036560 040707	114\$: 40707	:FPS BEFORE EXECUTION.
7201 036562 040710	40710	:FPS AFTER EXECUTION.
7202 036564 177777	-1	:ANTICIPATED ERRONEOUS FPS.
7203 036566 177777	-1	:EXPECTED FEC.
7204 036570 104340	115\$: ERROR +340	: (BUT COUT) ST 375
7205 036572 000401	BR 116\$: TO 274 INTO 074
7206 036574 104323	ERROR +323	: REPORT FPS INCORRECT.
7207 036576	116\$:	
7208		
7209		
7210 036576 012737 036604 001110	: EXP=41 (OCT), MOV #320\$, \$LPERR	: AC NEG, FL=1, FIC=1 :SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7211 036604 004737 037110	JSR PC, STCSUB	: GO EXECUTE THE INSTRUCTION.
7212 036610 150200 000000 000000	121\$: .WORD 150200, 0, 0, 0	: ACO OPERAND.
7213 036620 000000 000000	122\$: .WORD 0, 0	: EXPECTED RESULT.
7214 036624 177777 177777	123\$: .WORD -1, -1	: ANTICIPATED ERRONEOUS RESULT.
7215 036630 040700	124\$: 40700	:FPS BEFORE EXECUTION.
7216 036632 140705	140705	:FPS AFTER EXECUTION.
7217 036634 177777	-1	:ANTICIPATED ERRONEOUS FPS.
7218 036636 000006	6	:EXPECTED FEC.
7219 036640 104322	125\$: ERROR +322	:REPORT RESULT INCORRECT.
7220 036642 000401	BR 126\$	
7221 036644 104341	ERROR +341	: (BUT EZBT) ST 377
7222 036646	126\$:	
7223		
7224 036646 012737 036654 001110	: EXP=40 (OCT), MOV #330\$, \$LPERR	: AC NEG, FL=1, FIC=1 :SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7225 036654 004737 037110	JSR PC, STCSUB	: GO EXECUTE THE INSTRUCTION.
7226 036660 150000 000001 000000	131\$: .WORD 150000, 1, 0, 0	: ACO OPERAND.
7227 036670 000000 000000	132\$: .WORD 0, 0	: EXPECTED RESULT.
7228 036674 100000 177600	133\$: .WORD 100000, -200	: ANTICIPATED ERRONEOUS RESULT.
7229 036700 040700	134\$: 40700	:FPS BEFORE EXECUTION.
7230 036702 140705	140705	:FPS AFTER EXECUTION.
7231 036704 040700	40700	:ANTICIPATED ERRONEOUS FPS.
7232 036706 000006	6	:EXPECTED FEC.
7233 036710 104342	135\$: ERROR +342	: (BUT COUT) ST 360
7234 036712 000401	BR 136\$: TO 654 INTO 454
7235 036714 104323	ERROR +323	: REPORT FPS INCORRECT.
7236 036716	136\$:	
7237		
7238		
7239 036716 012737 036724 001110	: EXP=40, AC NEGATIVE, FL=1, FIC=1 MOV #340\$, \$LPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7240 036724 004737 037110	JSR PC, STCSUB	:GO EXECUTE THE INSTRUCTION.
7241 036730 150001 000000 000000	141\$: .WORD 150001, 0, 0, 0	:ACO OPERAND.

TE

7242 036740 000000 000000	142\$:	.WORD	0 0	:EXPECTED RESULT.
7243 036744 077400 000000	143\$:	.WORD	77400.0	:ANTICIPATED ERRONEOUS RESULT.
7244 036750 040700	144\$:	40700		:FPS BEFORE EXECUTION.
7245 036752 140705		140705		:FPS AFTER EXECUTION.
7246 036754 177777		-1		:ANTICIPATED ERRONEOUS FPS.
7247 036756 000006		6		:EXPECTED FEC.
7248 036760 104343	145\$:	ERROR	+343	:REPORT RESULT INCORRECT.
7249 036762 000401		BR	146\$	
7250 036764 104323		ERROR	+323	:REPORT FPS INCORRECT.
7251 036766	146\$:			
7252				
7253		:EXP 40 (OCT), AC MOST NEG LONG INT, FL=1		
7254		:FIC=1		
7255 036766 012737 036774 001110	350\$:	MOV	#350\$, \$LPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7256 036774 004737 037110	351\$:	JSR	PC, STCSUB	:GO EXECUTE THE INSTRUCTION.
7257 037000 150000 000000 000000	151\$:	.WORD	150000, 0, 0, 0	:AC0 OPERAND.
7258 037010 100000 000000	152\$:	.WORD	100000, 0	:EXPECTED RESULT.
7259 037014 000000 000000	153\$:	.WORD	0, 0	:ANTICIPATED ERRONEOUS RESULT.
7260 037020 040700	154\$:	40700		:FPS BEFORE EXECUTION.
7261 037022 040710		40710		:FPS AFTER EXECUTION.
7262 037024 140705		140705		:ANTICIPATED ERRONEOUS FPS.
7263 037026 177777		-1		:EXPECTED FEC.
7264 037030 104344	155\$:	ERROR	+344	: (BUT NBIT) ST 654
7265 037032 000401		BR	156\$: OR (BUT COUT) ST 454
7266 037034 104323		ERROR	+323	:REPORT FPS INCORRECT.
7267 037036	156\$:			
7268				
7269		:EXP=20, AC = MOST NEG INTEGER, FL=0, FIC=1		
7270				
7271 037036 012737 037044 001110	360\$:	MOV	#360\$, \$LPERR	:SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7272 037044 004737 037110	361\$:	JSR	PC, STCSUB	:GO EXECUTE THE INSTRUCTION.
7273 037050 144000 000001 000000	161\$:	.WORD	144000, 1, 0, 0	:AC0 OPERAND.
7274 037060 100000 177777	162\$:	.WORD	100000, -1	:EXPECTED RESULT.
7275 037064 100000 177400	163\$:	.WORD	100000, 177400	:ANTICIPATED ERRONEOUS RESULT.
7276 037070 040600	164\$:	40600		:FPS BEFORE EXECUTION.
7277 037072 040610		40610		:FPS AFTER EXECUTION.
7278 037074 140605		140605		:ANTICIPATED ERRONEOUS FPS.
7279 037076 177777		-1		:EXPECTED FEC.
7280 037100 104345	165\$:	ERROR	+345	: (BUT FL) ST 633
7281 037102 000401		BR	166\$: TO 655 INTO 654
7282 037104 104323		ERROR	+323	:REPORT FPS INCORRECT.
7283				
7284 037106 000534	166\$:	BR	WWCDONE	

TEST # 72 - STCDI AND STCDL TEST

7285 :THIS SUBROUTINE, STCSUB, IS USED TO SET UP THE OPERANDS, EXECUTE
 7286 :THE STCDI OR STCDL INSTRUCTION AND CHECK THE RESULTS. A CALL
 7287 :TO IT IS MADE THUS:

7289	JSR	PC,STCSUB	
7290	ACARG:	.WORD X,X,X,X	:AC OPERAND
7291	RES:	.WORD X,X	:EXPECTED RESULT
7292	ERRES:	.WORD X,X	:ERROR RESULT
7293	FPSB:	.WORD X	:FPS BEFORE EXECUTION
7294	FPSA:	.WORD X	:FPS AFTER EXECUTION
7295	ERFPS:	.WORD X	:ERROR FPS.
7296	FEC:	.WORD X	:EXPECTED FEC
7297	ERR1:	ERROR +X	:DATA ERROR.
7298		BR CONT	
7299	ERR2:	ERROR +X	:FPS ERROR.
7300	CONT:		:RETURN ADDRESS
7301			
7302	:THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN		
7303	:THE STCDI OR STCDL INSTRUCTION IS EXECUTED.		
7304	:THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS		
7305	:COMPARED WITH FPSA IF THIS TOO IS CORRECT STCSUB RETURNS CONTROL		
7306	:TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD STCSUB		
7307	:COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN STCSUB WILL RETURN		
7308	:TO THE ERROR CALL AT ERR2, OTHERWISE STCSUB ITSELF		
7309	:REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE		
7310	:STCDI OR STCDL IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE		
7311	:ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN		
7312	:THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN STCSUB		
7313	:WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE		
7314	:RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND STCSUB WILL		
7315	:REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.		
7316			
7317	037110	012601	
7318	037112	012700	000200
7319	037116	170100	
7320	037120	010100	
7321	037122	172410	
7322	037124	012702	037370
7323	037130	012700	000004
7324	037134	012722	177777
7325	037140	077003	
7326	037142	016100	000020
7327	037146	170100	
7328	037150	012737	037162 001236
7329	037156	012700	037370
7330	037162	175410	
7331			
7332	037164	170204	
7333	037166	170305	
7334	037170	010102	
7335	037172	010237	001240
7336	037176	062702	000010
7337	037202	010237	001244
7338	037206	012737	037370 001242
7339	037214	010437	001250
7340	037220	016137	000022 001252
7341	037226	010102	

STCSUB: MOV (SP)+,R1 :GET A POINTER TO THE ARGUMENTS.
 MOV #200,R0 :SET UP THE ACO OPERAND.
 LDFPS R0
 MOV R1,R0
 LDD (R0) ACO
 MOV #1200\$,R2 :INITIALIZE THE OUT PUT BUFFER.
 MOV #4,R0
 MOV #-1,(R2)+
 1\$: MOV SOB R0,IS
 MOV 20(R1),R0 :SET THE FPS.
 LDFPS R0
 MOV #25,\$TMP2
 MOV #1200\$,R0
 STCDL ACO,(R0) :TEST INSTRUCTION.
 STFPS R4 :GET THE FPS.
 STST R5 :GET THE FEC.
 MOV R1,R2
 MOV R2,\$TMP3
 ADD #10,R2
 MOV R2,\$TMP5
 MOV #1200\$,TMP4
 MOV R4,\$TMP7
 MOV 22(R1),\$TMP10
 MOV R1,R2

7342 037230 062702 000010 ADD #10,R2
7343 037234 012700 037370 MOV #1200\$,R0 ;SEE IF THE RESULT IS CORRECT.
7344 037240 012703 000002 MOV #2,R3
7345 037244 022022 CMP (R0)+,(R2)+
7346 037246 001014 BNE 15\$
7347 037250 077303 S0B R3,3\$
7348 037252 016102 MOV 22(R1),R2
7349 037256 020204 CMP R2,R4 ;SEE IF THE FPS IS CORRECT.
7350 037260 001025 BNE 20\$;BRANCH IF INCORRECT.
7351 037262 005702 TST R2
7352 037264 100003 BPL 4\$
7353 037266 026105 CMP 26(R1),R5 ;SEE IF THE FEC IS CORRECT.
7354 037272 001027 BNE 25\$;BRANCH IF INCORRECT.
7355
7356 037274 000161 000036 4\$. JMP 36(R1) ;RETURN.
7357
7358 :DATA ERROR.
7359 037300 010102 15\$: :SEE IF THE FAILURE WAS ANTICIPATED.
7360 037302 062702 000014 MOV R1,R2
7361 037306 012700 037370 ADD #14,R2
7362 037312 012703 000002 MOV #1200\$,R0
7363 037316 022022 MOV #2,R3
7364 037320 001003 16\$: CMP (R0)+,(R2)+
7365 037322 077303 BNE 17\$
7366 037324 000161 S0B R3,16\$
7367 037330 JMP 30(R1)
7368 17\$: :FAILURE WAS NOT ANTICIPATED SO REPORT INCORRECT PESULT HERE.
7369 037330 104322 18\$: ERROR +322 ;DATA BAD
7370 037332 000760 BR 4\$
7371
7372 :FPS INCORRECT. SO SEE IF FAILURE WAS ANTICIPATED.
7373 037334 020461 000024 20\$: CMP R4,24(R1)
7374 037340 001002 BNE 21\$
7375 037342 000161 JMP 34(R1)
7376 037346 17\$: :NOT ANTICIPATED SO REPORT BAD FPS HERE.
7377 037346 104323 22\$: ERROR +323 ;FPS BAD
7379 037350 000751 BR 4\$
7380
7381 :REPORT INCORRECT FEC.
7382 037352 016137 000026 001256 25\$: MOV 26(R1),\$TMP12
7383 037360 010537 001254 MOV R5,\$TMP11
7384 037364 104324 26\$: ERROR +324
7385 037366 000742 BR 4\$
7386
7387 :DATA BUFFER:
7388 037370 177777 177777 177777 1200\$: .WORD -1,-1,-1,-1
7389
7390 037400 037400 104412 WWCDONE: RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

7398

.SBTTL TEST # 73 - STCFL AND STCFI TEST

***** TEST 73 STCFL AND STCFI TEST *****

* THIS IS A TEST OF STCFL AND STCFI. I
* MAKES USE OF THE SAME SUBROUTINE, STC
* WHICH WAS USED TO TEST STCDL AND STCD

037402	000004		TST73: SCOPE :EXponent=37, FL=1		
7399			MOV #200\$,SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.	
7400	037404	012737	037412	001110	;DPM002
7401	037412	004737	037110		JSR PC,STCSUB :GO EXECUTE THE INSTRUCTION.
7402	037416	047777	177777	177777	.WORD 47777,-1,-1,-1 :AC0 OPERAND.
7403	037426	077777	177600		.WORD 77777,177600 :EXPECTED RESULT.
7404	037432	077777	177777		.WORD 77777,177777 :ANTICIPATED ERRONEOUS RESULT.
7405	037436	040100			40100 :FPS BEFORE EXECUTION.
7406	037440	040100			40100 :FPS AFTER EXECUTION.
7407	037442	177777			-1 :ANTICIPATED ERRONEOUS FPS.
7408	037444	177777			-1 :EXPECTED FEC.
7409	037446	104346			5\$: ERROR +346 ;X11(1,0)+0 ST 773X
7410	037450	000401			BR 6\$
7411	037452	104323			ERROR +323 :REPORT FPS INCORRECT.
7412	037454	037454			6\$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
		104412			:SEE IF THE USER HAS EXPRESSED
					:THE DESIRE TO CHANGE THE SOFTWARE
					:VIRTUAL CONSOLE SWITCH REGISTER (HAS
					:THE USER TYPED CONTROL G?).

7419

.SBTTL TEST # 74 - STEXP TEST

;*****
;*TEST 74 STEXP TEST;* THIS IS A TEST OF THE STEXP
;* INSTRUCTION
;*

TST74: SCOPE

7420 037456 000004		: EXP = 100 (EXCESS 200)			
7421 037460 012737 037472 001110		MOV #200\$, SLPERR	;SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
7422 037466 012703 040372 000000	200\$:	MOV #1200\$, R3	;SETUP DATA TABLE POINTER		:DPM002
7423 037472 004737 040106 000000	1\$:	JSR PC, 1000\$			
7424 037476 020000 000000 000000	2\$:	.WORD 20000, 0, 0, 0	:AC		
7425 037506 177700 000000 000000	3\$:	-100	:EXP RES		
7426 037510 052525 000000 000000	4\$:	52525	:ERROR EXP.		
7427 037512 040000 000000 000000	5\$:	40000	:FPSB		
7428 037514 040010 000000 000000	6\$:	40010	:FPSA		
7429 037516 040000 000000 000000	7\$:	40000	:ERROR FPS		
7430 037520 104347 000000 000000	8\$:	ERROR +347	:BAD EXP		
7431 037522 000401 000000 000000	9\$:	BR 6\$			
7432 037524 104352 000000 000000	10\$:	ERROR +352	:+(BUT ENBT) ST 376		
7433 037526 005723 022703 040400	11\$:	TST (R3)+	:ADVANCE POINTER		:DPM002
7434 037530 022703 001356 000000	12\$:	CMP #1200\$+6, R3	:HAVE WE TESTED ALL 3 STATES?		:DPM002
7435 037534 001356 000000 000000	13\$:	BNE 200\$:BRANCH IF NOT		:DPM002
7436					
7437					
7438 037536 012737 037550 001110	14\$:	: EXP = 200 (EXCESS 200)			
7439 037544 012703 040372 000000	15\$:	MOV #210\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
7440 037550 004737 040106 000000	16\$:	MOV #1200\$, R3	;SETUP DATA TABLE POINTER		:DPM002
7441 037554 040000 000000 000000	17\$:	JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.		
7442 037564 000000 000000 000000	18\$:	.WORD 40000, 0, 0, 0	:AC0 OPERAND.		
7443 037566 052525 000000 000000	19\$:	0	:EXPECTED EXPONENT RESULT.		
7444 037570 040000 000000 000000	20\$:	52525	:ANTICIPATED ERRONEOUS RESULT.		
7445 037572 040004 000000 000000	21\$:	40000	:FPS BEFORE EXECUTION.		
7446 037574 040000 000000 000000	22\$:	40004	:FPS AFTER EXECUTION.		
7447 037576 104347 000000 000000	23\$:	40000	:ANTICIPATED ERRONEOUS FPS.		
7448 037600 000401 000000 000000	24\$:	ERROR +347	:REPORT RESULT INCORRECT.		
7449 037602 104353 000000 000000	25\$:	BR 16\$			
7450					
7451 037604 005723 022703 040400	26\$:	ERROR +353	:+(BUT EZBT) ST 071		
7452 037606 022703 001356 000000	27\$:	TST (R3)+	:TO 072 INT 272		
7453 037612 001356 000000 000000	28\$:	CMP #1200\$+6, R3	:ADVANCE POINTER		:DPM002
7454					
7455					
7456					
7457					
7458 037614 012737 037626 001110	29\$:	: EXP = 201 (EXCESS 200)			
7459 037622 012703 040372 000000	30\$:	MOV #220\$, SLPERR	:SET UP THE LOOP ON ERROR ADDRESS.		:DPM002
7460 037626 004737 040106 000000	31\$:	MOV #1200\$, R3	;SETUP DATA TABLE POINTER		:DPM002
7461 037632 040200 000000 000000	32\$:	JSR PC, 1000\$;GO EXECUTE THE INSTRUCTION.		
7462 037642 000001 000000 000000	33\$:	.WORD 40200, 0, 0, 0	:AC0 OPERAND.		
7463 037644 052525 000000 000000	34\$:	1	:EXPECTED EXPONENT RESULT.		
7464 037646 040000 000000 000000	35\$:	52525	:ANTICIPATED ERRONEOUS RESULT.		
7465 037650 040000 000000 000000	36\$:	40000	:FPS BEFORE EXECUTION.		
7466 037652 040004 000000 000000	37\$:	40004	:FPS AFTER EXECUTION.		
7467 037654 104347 000000 000000	38\$:	ERROR +347	:ANTICIPATED ERRONEOUS FPS.		
			:REPORT RESULT INCORRECT.		

7468 037656 000401
 7469 037660 104354
 7470 037662 005723
 7471 037664 022703 040400
 7472 037670 001356

26\$: BR 26\$
 ERROR +354
 TST (R3)+
 CMP #1200\$+6,R3
 BNE 220\$
 ;(BUT EZBT) ST 071 TO 272 INTO 072
 ;ADVANCE POINTER
 ;HAVE WE TESTED ALL 3 STATES?
 ;BRANCH IF NOT

;DPM002
 ;DPM002
 ;DPM002

7473
 7474
 7475 : EXP = 375 (EXCESS 200)
 7476

7477 037672 012737 037704 001110
 7478 037700 012703 040372
 7479 037704 004737 040106 000000 000000
 7480 037710 077200 000000 000000
 7481 037720 000175
 7482 037722 052525
 7483 037724 040000
 7484 037726 040000
 7485 037730 040010
 7486 037732 104347
 7487 037734 000401
 7488 037736 104355
 7489 037740 005723 040400
 7490 037742 022703
 7491 037746 001356

MOV #230\$,SLPERR
 MOV #1200\$,R3
 JSR PC,1000\$
 WORD 77200,0,0,0
 31\$: 175
 32\$: 52525
 33\$: 40000
 34\$: 40000
 40010
 35\$: ERROR +347
 BR 36\$
 ERROR +355
 TST (R3)+
 CMP #1200\$+6,R3
 BNE 230\$
 ;SET UP THE LOOP ON ERROR ADDRESS.
 ;SETUP DATA TABLE POINTER
 ;GO EXECUTE THE INSTRUCTION.
 ;AC0 OPERAND.
 ;EXPECTED EXPONENT RESULT.
 ;ANTICIPATED ERRONEOUS RESULT.
 ;FPS BEFORE EXECUTION.
 ;FPS AFTER EXECUTION.
 ;ANTICIPATED ERRONEOUS FPS.
 ;REPORT RESULT INCORRECT.
 ;(BUT ENBT) ST 376 TO 471 INTO 071
 ;ADVANCE POINTER
 ;HAVE WE TESTED ALL 3 STATES?
 ;BRANCH IF NOT

;DPM002
 ;DPM002
 ;DPM002
 ;DPM002
 ;DPM002

7492
 7493
 7494 : EXP = 1 (EXCESS 200)
 7495

7496 037750 012737 037762 001110
 7497 037756 012703 040372
 7498 037762 004737 040106 000200 000000
 7499 037766 177601
 7500 040000 052525
 7501 040002 040000
 7503 040004 040010
 7504 040006 040000
 7505 040010 104347
 7506 040012 000401
 7507 040014 104352
 7508 040016 005723 040400
 7509 040020 022703
 7510 040024 001356

MOV #240\$,SLPERR
 MOV #1200\$,R3
 JSR PC,1000\$
 WORD 200,0,0,0
 41\$: -177
 42\$: 52525
 43\$: 40000
 44\$: 40010
 40000
 45\$: ERROR +347
 BR 46\$
 ERROR +352
 TST (R3)+
 CMP #1200\$+6,R3
 BNE 240\$
 ;SET UP THE LOOP ON ERROR ADDRESS.
 ;SETUP DATA TABLE POINTER
 ;GO EXECUTE THE INSTRUCTION.
 ;AC0 OPERAND.
 ;EXPECTED EXPONENT RESULT.
 ;ANTICIPATED ERRONEOUS RESULT.
 ;FPS BEFORE EXECUTION.
 ;FPS AFTER EXECUTION.
 ;ANTICIPATED ERRONEOUS FPS.
 ;REPORT RESULT INCORRECT.
 ;REPORT FPS INCORRECT.
 ;ADVANCE POINTER
 ;HAVE WE TESTED ALL 3 STATES?
 ;BRANCH IF NOT

;DPM002
 ;DPM002
 ;DPM002
 ;DPM002
 ;DPM002

7511
 7512
 7513 : EXP = 156 (EXCESS 200)
 7514

7515 040026 012737 040040 001110
 7516 040034 012703 040372
 7517 040040 004737 040106 033400 000000
 7518 040044 177756
 7519 040054 052525
 7520 040056 047707
 7521 040060 047710
 7522 040062 177777
 7523 040064 104347
 7524 040066 104347

MOV #250\$,SLPERR
 MOV #1200\$,R3
 JSR PC,1000\$
 WORD 33400,0,0,0
 51\$: -22
 52\$: 52525
 53\$: 47707
 54\$: 47710
 -1
 55\$: ERROR +347
 ;SET UP THE LOOP ON ERROR ADDRESS.
 ;SETUP DATA TABLE POINTER
 ;GO EXECUTE THE INSTRUCTION.
 ;AC0 OPERAND.
 ;EXPECTED EXPONENT RESULT.
 ;ANTICIPATED ERRONEOUS RESULT.
 ;FPS BEFORE EXECUTION.
 ;FPS AFTER EXECUTION.
 ;ANTICIPATED ERRONEOUS FPS.
 ;REPORT RESULT INCORRECT.

;DPM002
 ;DPM002
 ;DPM002

CKFPCD0 FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 76-2 G 14
TEST # 74 - STEXP TEST

SEQUENCE 175

7525 040070 000401	BR	56\$		
7526 040072 104350	ERROR	+350	;REPORT FPS INCORRECT.	
7527				
7528 040074 005723	56\$:	TST	(R3)+	
7529 040076 022703 040400	CMP	#1200\$+6,R3	;ADVANCE POINTER	:DPM002
7530 040102 001356	BNE	250\$;HAVE WE TESTED ALL 3 STATES?	:DPM002
7531 040104 000543	BR	260\$;BRANCH IF NOT	:DPM002

7532 ;THIS SUBROUTINE, 1000\$, IS USED TO SET UP THE OPERANDS, EXECUTE
 7533 ;THE STEXP INSTRUCTION AND CHECK THE RESULTS. A CALL
 7534 ;TO IT IS MADE THUS:

```

 7536      JSR    PC,1000$          ;AC OPERAND
 7537      ACARG: .WORD  X,X,X,X   ;EXPECTED RESULT
 7538      RES:    .WORD  X         ;ERROR RESULT
 7539      ERRES:  .WORD  X         ;FPS BEFORE EXECUTION
 7540      FPSB:   .WORD  X         ;FPS AFTER EXECUTION
 7541      FPSA:   .WORD  X         ;ERROR FPS.
 7542      ERFPS:  .WORD  X         ;DATA ERROR.
 7543      ERR1:   ERROR +X        ;FPS ERROR.
 7544      BR     CONT
 7545      ERR2:   ERROR +X        ;RETURN ADDRESS
 7546
 7547
 7548 :THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
 7549 :THE STEXP INSTRUCTION IS EXECUTED.
 7550 :THE RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
 7551 :COMPARED WITH FPSA IF THIS TOO IS CORRECT 1000$ RETURNS CONTROL
 7552 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD 1000$
 7553 :COMPARE IT TO ERROR FPS. IF THIS MATCHES THEN 1000$ WILL RETURN
 7554 :TO THE ERROR CALL AT ERR2, OTHERWISE 1000$ ITSELF
 7555 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
 7556 :STEXP IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
 7557 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
 7558 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN 1000$
 7559 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR1. OTHERWISE THE
 7560 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND 1000$ WILL
 7561 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
 7562
 7563 040106 012601      1000$: MOV   (SP)+,R1      :GET A POINTER TO THE ARGUMENTS.
 7564 040110 010102      MOV   R1,R2
 7565 040112 010237 001240      MOV   R2,$TMP3
 7566 040116 062702 000010      ADD   #10,R2
 7567 040122 012237 001244      MOV   (R2)+,$TMP5
 7568 040126 012737 040200 001236      MOV   #61$, $TMP2
 7569 040134 012737 123456 040360      MOV   #123456,1210$
 7570 040142 012737 076543 040362      MOV   #76543,1210$+2
 7571 040150 012700 000200      MOV   #200,R0
 7572 040154 170100      LDFPS R0
 7573 040156 010100      MOV   R1,R0      :SET UP THE ACO OPERAND.
 7574 040160 172410      LDD   (R0),ACO
 7575 040162 016100 000016      MOV   16(R1),R0      :SET THE FPS.
 7576 040166 170100      LDFPS R0
 7577 040170 011300      MOV   (R3),R0      :SETUP R0 FROM THE TABLE :DPM002
 7578 040172 016337 000006 040200      MOV   6(R3),61$      :MOVE TEST INSTRUCTION TO ITS POSITION :DPM002
 7579 040200 000000      61$: WORD  0          :LOCATION FOR TEST INSTRUCTION. :DPM002
 7580 040202 170204      STFPS R4
 7581 040204 026300 000014      CMP   14(R3),R0      :GET FPS. :DPM002
 7582 040210 001411      BEQ   101$      :SEE IF R0 WAS PROPER :DPM002
 7583 040212 013737 040200 001260      MOV   61$, $TMP13 :BRANCH IF OK :DPM002
 7584 040220 016337 000014 001240      MOV   14(R3),$TMP3 :MOVE OP CODE OF FAILING INST TO $TMP13 :DPM002
 7585 040226 010037 001242      MOV   R0,$TMP4      :MOVE EXPECTED DATA TO $TMP3 :DPM002
 7586 040232 104371      ERROR +371      :MOVE RECEIVED DATA TO $TMP4 :DPM002
 7587
 7588      ;*****
```

1 16

```

7589 : IF THIS FAILURE OCCURED, IS M7095 ECO #10 IN?
7590 :*****101$: MOV R4,$TMP7
7591 040234 010437 001250 001252 MOV 16(R1),$TMP10
7592 040240 016137 000016 001242 MOV 1210$, $TMP4
7593 040246 013737 040360 001242 CMP 10(R1),1210$ :WAS RESULT CORRECT?
7594 040254 026137 000010 040360 BEQ 65$ :BRANCH IF CORRECT.
7595 040262 001411 000012 040360 CMP 12(R1),1210$ :OTHERWISE SEE IF THE FAILURE WAS ANTICIPATED.
7596 040264 026137 000012 040360 BNE 62$ :JMP 22(R1)
7597 040272 001002 000022
7598 040274 000161 000022

7599 :IF NOT ANTICIPATED REPORT ERROR HERE.
7600 :62$: 63$: ERROR +347 :EXP BAD
7601 040300 104347 000030 000030 JMP 30(R1)
7602 040300 000161 000020 000020
7603 040302 000161 000030 000030
7604 :65$: CMP R4,16(R1) :SEE IF THE FPS IS CORRECT.
7605 040306 020461 000016 000016 BEQ 70$ :BRANCH IF CORRECT.
7606 040312 001407 000020 000020
7607 040314 020461 000020 000020
7608 040320 001002 000026 000026
7609 040322 000161 000026 000026
7610 :FPS ERROR WAS NOT ANTICIPATED SO REPORT ERROR HERE.
7611 :66$: 67$: ERROR +350 :FPS BAD
7612 040326 104350 000764 000764 BR 64$
7613 040326 000764 000764
7614 040330 000764 000764
7615 :70$: ;SEE IF MORE THAN ONE WORD WAS WRITTEN IN THE OUTPUT BUFFER.
7616 :71$: 040332 022737 076543 040362 CMP #76543,1210$+2
7617 040340 001760 001760 BEQ 64$ :FDFL+0 ST 347X
7618 040342 104351 104351
7619 040344 000756 000756
7620 :72$: .WORD -1,-1,-1,-1,-1
7621 040346 177777 177777 177777 177777 .WORD -1,-1,-1,-1,-1
7622 040360 177777 177777 177777 177777 1210$: .WORD 1210$,1210$,1210$+2 :DATA FOR R0 LOAD :DPM002
7623 040372 040360 040360 040362 040362 1200$: STEXP A0,(R0) :TEST INSTRUCTION (NOT EXECUTED HERE) :DPM002
7624 040400 175010 175010 STEXP A0,(R0)+ :TEST INSTRUCTION (NOT EXECUTED HERE) :DPM002
7625 040402 175020 175020 STEXP A0,-(R0) :TEST INSTRUCTION (NOT EXECUTED HERE) :DPM002
7626 040404 175040 175040 .WORD 1210$,1210$+2,1210$ :EXPECTED R0 END VALUE :DPM002
7627 040406 040360 040362 040360
7628 040414 040414 104412 104412 260$: RSETUP :GO INITIALIZE THE FPS AND STACK; AND
    :SEE IF THE USER HAS EXPRESSED
    :THE DESIRE TO CHANGE THE SOFTWARE
    :VIRTUAL CONSOLE SWITCH REGISTER (HAS
    :THE USER TYPED CONTROL G?).

```

7641

.SBTTL TEST # 75 - STST TEST

TEST 75 STST TEST

- * THIS IS A TEST OF THE STST
- * INSTRUCTION. FIRST AN ILLEGAL FPS OP CODE
- * (INSTRUCTION) IS USED TO ENTER AN
- * ERROR CONDITION IN THE FEC AND
- * FEA. THE STST IS EXECUTED AND
- * THE FEC AND FEA ARE CHECKED

040416 000004
 7642 040420 012737 040426 001110 TST75: SCOPE ;SET UP THE LOOP ON ERROR ADDRESS.
 7643 040426 012700 040000 200\$: MOV #200\$,SLPERR ;SET FPS. FID=1.
 7644 040432 170100 LDFPS R0 ;DPM002
 7645 040434 170003 .WORD 170003 ;ILLEGAL FPP
 7646 ;OP CODE
 7647 040436 012700 040612 MOV #220\$,R0 ;SET UP THE OUTPUT BUFFER.
 7648 040442 012710 177777 MOV #-1,(R0)
 7649 040446 012760 177777 000002 MOV #-1,2(R0)
 7650 040454 012737 040462 001236 MOV #230\$,STMP2
 7651 040462 170310 230\$: STST (R0) ;GET FEC AND
 7652 ;FEA ;GET FPS.
 7653 040464 170204 STFPS R4
 7654 040466 012700 040612 MOV #220\$,R0
 7655 040472 011037 001240 MOV (R0),\$TMP3
 7656 040476 016037 000002 001242 MOV 2(R0),\$TMP4
 7657 040504 012737 000002 001244 MOV #2,\$TMP5
 7658 040512 012737 040434 001246 MOV #210\$,STMP6
 7659 040520 010437 001250 MOV R4,\$TMP7
 7660 040524 012737 140000 001252 MOV #140000,\$TMP10
 7661
 7662 040532 022710 000002 CMP #2,(R0) ;SEE IF FEC IS CORRECT.
 7663 040536 001010 BNE 240\$;BRANCH IF INCORRECT.
 7664 040540 022760 040434 000002 CMP #210\$,2(R0) ;SEE IF FEA, ADDRESS, IS CORRECT.
 7665 040546 001006 BNE 250\$;BRANCH IF INCORRECT.
 7666 040550 022704 1'0000 CMP #140000,R4 ;SEE IF FPS IS CORRECT.
 7667 040554 001013 BNE 260\$;BRANCH IF INCORRECT.
 7668 040556 000422 BR 270\$
 7669
 7670 ;REPORT FEC INCORRECT
 7671 040560 104356 240\$: ERROR +356 ;STST BAD
 7672 040562 000420 BR 270\$;FECX
 7673
 7674 ;REPORT FEA INCORRECT
 7675 040564 022760 177777 000002 250\$: CMP #-1,2(R0)
 7676 040572 001402 BEQ 280\$;STST BAD FEA
 7677 040574 104357 ERROR +357
 7678 040576 000412 BR 270\$;SET FD FL ST 636
 7679 040600 104360 280\$: ERROR +360
 7680 040602 000410 BR 270\$
 7681
 7682 ;REPORT FPS INCORRECT
 7683 040604 104361 260\$: ERROR +361 ;FPS X AFTER ST ST
 7684 040606 000406 BR 270\$
 7685

CKFPCD0 FP11F FLTG PNT PRT C
TEST # 75 - STST TEST

MACRO M1113 30-OCT-81 11:15 PAGE 78-1 K 14

SEQUENCE 179

7686
7687 040610 177777
7688 040612 177777 177777 177777
7689 040622 177777
7690
7691 040624

:DATA BUFFER:
-1
.WORD -1,-1,-1,-1
-1

270\$:

040624 104412

RSETUP

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

7692				.SBTTL	SETUP FOR TESTS		
7693	040626	005037	177572	CLR	MMR0	;6 THROUGH 104	
7694	040632	170127	040000	LDFPS	#40000	;MAKE SURE MEMORY MANAGEMENT IS OFF.	
7695	040636	012700	077406	MOV	#77406,R0	;LOAD FPS STATUS.	
7696	040642	012701	077400	MOV	#77400,R1	;LOAD R0 WITH 77406	
7697	040646	010037	172320	MOV	R0,KDPDR0	;LOAD R1 WITH 77400	
7698	040652	010137	172322	MOV	R1,KDPDR1	;MAKE KDPDR0 RESIDENT.	
7699	040656	010137	172324	MOV	R1,KDPDR2	;MAKE KDPDR1 NON-RESIDENT.	
7700	040662	010037	172326	MOV	R0,KDPDR3	;MAKE KDPDR2 NON-RESIDENT.	
7701	040666	010037	172330	MOV	R0,KDPDR4	;MAKE KDPDR3 RESIDENT FOR ADDRESSES 60000-77756.	
7702	040672	010037	172336	MOV	R0,KDPDR7	;MAKE KDPDR4 RESIDENT FOR ADDRESSES 77760-77776.	
7703						;MAKE KDPDR7 RESIDENT (I/O PAGE).	
7704	040676	005037	172360	CLR	KDPAR0	;MAP D-PAGE 0 FOR 0-4K.	
7705	040702	012737	000200	MOV	#200,KDPAR1	;MAP D-PAGE 1 FOR 4-8K.	
7706	040710	012737	000400	MOV	#400,KDPAR2	;MAP D-PAGE 2 FOR 8-12K.	
7707	040716	012737	000600	MOV	#600,KDPAR3	;MAP D-PAGE 3 FOR ACCESSING ADDRESSES 60000-77756.	
7708	040724	012737	000600	MOV	#600,KDPAR4	;MAP D-PAGE 4 FOR ACCESSING ADDRESSES 77760-77776.	
7709	040732	012737	177600	MOV	#177600,KDPAR7	;MAP D-PAGE 7 FOR I/O PAGE.	
7710							
7711	040740	010037	172300	MOV	R0,KIPDR0	;MAKE KIPDR0 RESIDENT.	
7712	040744	010037	172302	MOV	R0,KIPDR1	;MAKE KIPDR1 RESIDENT.	
7713	040750	010037	172304	MOV	R0,KIPDR2	;MAKE KIPDR2 RESIDENT.	
7714	040754	010137	172306	MOV	R1,KIPDR3	;MAKE KIPDR3 NON-RESIDENT FOR USING ADDRESSES 60000-77756.	
7715	040760	010137	172310	MOV	R1,KIPDR4	;MAKE KIPDR4 NON-RESIDENT FOR USING ADDRESSES 77760-77776.	
7716	040764	010037	172316	MOV	R0,KIPDR7	;MAKE KIPDR7 RESIDENT (I/O PAGE).	
7717							
7718	040770	005037	172340	CLR	KIPAR0	;MAP I-PAGE 0 FOR 0-4K.	
7719	040774	012737	000200	MOV	#200,KIPAR1	;MAP I-PAGE 1 FOR 4-8K.	
7720	041002	012737	000400	MOV	#400,KIPAR2	;MAP I-PAGE 2 FOR 8-12K.	
7721	041010	012737	000600	MOV	#600,KIPAR3	;MAP I-PAGE 3 FOR ACCESSING ADDRESSES 60000-77756.	
7722	041016	012737	000600	MOV	#600,KIPAR4	;MAP I-PAGE 4 FOR ACCESSING ADDRESSES 77760-77776.	
7723	041024	012737	177600	MOV	#177600,KIPAR7	;MAP I-PAGE 7 FOR I/O PAGE.	
7724							
7725	041032	013737	000250	001262	MOV	MMVECT,\$TMP14	;MOVE MM TRAP VECTOR TO TMP14 FOR TEMP STORAGE.
7726	041040	012701	117760	MOV	#DATA,R1	;SET UP R1.	
7727	041044	012702	117770	MOV	#DATA+10,R2	;SET UP R2.	
7728	041050	012703	117772	MOV	#DATA+12,R3	;SET UP R3.	
7729	041054	012737	041714	000250	MOV	#TRAPV,MMVECT	;SET UP FOR FP TRAPS FOR THIS TEST.
7730	041062	012737	000340	000252	MOV	#340,MMVECT+2	
7731	041070	012737	000024	172516	MOV	#24,MMR3	
7732	041076	012737	117760	077770	MOV	#DATA,77770	;TURN ON 22-BIT KERNEL D-SPACE. ;SET UP ADDRESS POINTER.

7746

.SBTTL TEST # 76 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 1

TEST 76 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 1

/* THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
MEMORY MANAGEMENT TRAP/ABORT.
****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.
*/

041104 000004
7747 041106 012737 041114 001110 TST76: SCOPE
7748
7749 041114 170000 200\$: MOV #200\$,SLPERR ;SET UP THE LOOP ON ERROR ADDRESS. ;DPM002
7750 041116 010100 CFCC ;* THIS INSTRUCTION WILL TEST FOR A WORST-CASE HARDWARE PROBLEM.
7751 041120 004737 042430 MOV R1,R0 ;* TEST INSTRUCTION WHICH SHOULD ALWAYS INVOKE D-SPACE.
7752 041124 170410 JSR PC,SETERL ;SETTING UP R0.
7753 041126 004737 042430 CLRF (R0) ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7754 041132 177010 JSR PC,SETERL ;TESTING BLOCKS 27-K AND 27-R.
7755 041134 004737 042430 LDCIF (R0),AC0 ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7756 041140 172410 JSR PC,SETERL ;TESTING BLOCKS 28-F AND 28-P.
7757 041142 004737 042430 LDF (R0),AC0 ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7758 041146 170310 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7759 041150 004737 042430 STST (R0) ;TESTING BLOCKS 33-E AND 33-P.
7760 041154 005037 177572 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
CLR MMRO ;TURN OFF MEMORY MANAGEMENT.

7761

.SBTTL TEST # 77 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 2

 * TEST 77 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 2
 *
 * THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
 * INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
 * MEMORY MANAGEMENT TRAP/ABORT.
 * ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
 * THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
 * AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
 * INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
 * DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
 * INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.
 *

041160	000004		TST77: SCOPE	
7762	041162	010100	MOV R1,R0	:SETTING UP R0.
7763	041164	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7764	041170	170520	TSTF (R0)+	:TESTING BLOCK 21-AA.
7765	041172	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7766	041176	170527	TSTF #1000	:TESTING BLOCK 21-AA.
7767				
7768	041202	010100	MOV R1,R0	:CORRECTING R0.
7769	041204	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7770	041210	170420	CLRF (R0)+	:TESTING BLOCKS 27-K AND 27-R.
7771				:**NOTE**: THE LOCATION AFTER THE CLRF, AND STST MODE 2 REG 7 INSTRUCTIONS
7772				:*WILL* BE CHANGED ON SUBSEQUENT PASSES, BUT IS **NOT** INCORRECT. THE
7773				:ACTUAL CONTENTS OF THOSE LOCATIONS IS IMMATERIAL, AS THIS TEST INSURES
7774				:THAT THE INSTRUCTION DOES EXECUTE WITHOUT ACCESSING THAT LOCATION AS
7775				:A D-SPACE ACCESS.
7776	041212	170427	CLRF #1000	:TESTING BLOCKS 27-K AND 27-R.
7777				
7778	041216	010100	MOV R1,R0	:CORRECTING R0.
7779	041220	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7780	041224	177020	LDCIF (R0)+,AC0	:TESTING BLOCKS 28-F AND 28-P.
7781	041226	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7782	041232	177027	LDCIF #1000,AC0	:TESTING BLOCKS 28-F AND 28-P.
7783				
7784	041236	010100	MOV R1,R0	:CORRECTING R0.B
7785	041240	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7786	041244	172420	LDF (R0)+,AC0	:TESTING BLOCKS 4-NN, 4-X, 4-Z AND 4-BB.
7787	041246	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7788	041252	172427	LDF #1000,AC0	:TESTING BLOCKS 4-NN, 4-X, 4-Z AND 4-BB.
7789				
7790	041256	010100	MOV R1,R0	:CORRECTING R0.
7791	041260	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7792	041264	170320	STST (R0)+	:TESTING BLOCKS 33-J AND 33-P.
7793	041266	004737	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7794	041272	170327	STST #1000	:TESTING BLOCKS 33-J AND 33-P.
7795	041276	005037	CLR MMRO	:TURN OFF MEMORY MANAGEMENT.

7796

SBTTL TEST # 100 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 3

TEST 100 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 3

* THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
* INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
* MEMORY MANAGEMENT TRAP/ABORT.
* ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
* AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
* INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
* DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
* INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.

			TST100: SCOPE		
7797	041302	000004		MOV R2,R0	:SETTING UP R0.
7798	041304	010200		JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7799	041306	004737	042430	TSTF @(R0)+	:TESTING BLOCK 21-N.
7800	041312	170530		JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7801	041314	004737	042430	TSTF DATA	:TESTING BLOCK 21-N.
7802	041320	170537	117760		
7803	041324	010200		MOV R2,R0	:CORRECTING R0.
7804	041326	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7805	041332	170430		CLRF @(R0)+	:TESTING BLOCKS 27-U, 27-T AND 27-R.
7806	041334	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7807	041340	170437	117760	CLRF DATA	:TESTING BLOCKS 27-U, 27-T AND 27-R.
7808					
7809	041346	010200		MOV R2,R0	:CORRECTING R0.
7810	041346	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7811	041352	177030		LDCIF @(R0)+,AC0	:TESTING BLOCKS 28-L, 28-N AND 28-P.
7812	041354	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7813	041360	177037	117760	LDCIF DATA,AC0	:TESTING BLOCKS 28-L, 28-N AND 28-P.
7814					
7815	041364	010200		MOV R2,R0	:CORRECTING R0.
7816	041366	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7817	041372	172430		LDF @(R0)+,AC0	:TESTING BLOCKS 4-R, 4-T, 4-X, 4-Z AND 4-BB.
7818	041374	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7819	041400	172437	117760	LDF DATA,AC0	:TESTING BLOCKS 4-R, 4-T, 4-X, 4-Z AND 4-BB.
7820					
7821	041404	010200		MOV R2,R0	:CORRECTING R0.
7822	041406	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7823	041412	170330		STST @(R0)+	:TESTING BLOCKS 33-L, 33-N AND 33-P.
7824	041414	004737	042430	JSR PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7825	041420	170337	117760	STST DATA	:TESTING BLOCKS 33-L, 33-N AND 33-P.
7826	041424	005037	177572	CLR MMRO	:TURN OFF MEMORY MANAGEMENT.

7827

.SBTTL TEST # 101 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 4

;*****
*TEST 101 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 4

* THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
* INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
* MEMORY MANAGEMENT TRAP/ABORT.
* ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
* AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
* INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
* DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
* INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.

;*****
*TST101: SCOPE

MOV	R2,R0	:SETTING UP R0.
JSR	PC,SETERL	:GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
LDF	-(R0),AC0	:TESTING BLOCKS 4-J, 4-X, 4-Z AND 4-BB.
CLR	MMR0	:TURN OFF MEMORY MANAGEMENT.

041430	000004
7828 041432	010200
7829 041434	004737 042430
7830 041440	172440
7831 041442	005037 177572

7832

.SBTTL TEST # 102 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 5

* TEST 102 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 5
*
* THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
* INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
* MEMORY MANAGEMENT TRAP/ABORT.
* ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
* AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
* INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
* DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
* INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.
*

041446	000004		
7833	041450	010300	
7834	041452	004737	042430
7835	041456	170550	
7836			
7837	041460	010300	
7838	041462	004737	042430
7839	041466	170450	
7840			
7841	041470	010300	
7842	041472	004737	042430
7843	041476	177050	
7844			
7845	041500	010300	
7846	041502	004737	042430
7847	041506	172450	
7848			
7849	041510	010300	
7850	041512	004737	042430
7851	041516	170350	
7852	041520	005037	177572

TST102: SCOPE
MOV R3,R0 :SETTING UP R0.
JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
TSTF a-(R0) :TESTING BLOCK 21-U.

MOV R3,R0 :CORRECTING R0.
JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
CLRF a-(R0) :TESTING BLOCKS 27-X, 27-T AND 27-R.

MOV R3,R0 :CORRECTING R0.
JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
LDCIF a-(R0),AC0 :TESTING BLOCKS 28-S, 28-N AND 28-P.

MOV R3,R0 :CORRECTING R0.
JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
LDF a-(R0),AC0 :TESTING BLOCKS 4-U, 4-T, 4-X, 4-Z AND 4-BB.

MOV R3,R0 :CORRECTING R0.
JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
STST a-(R0) :TESTING BLOCKS 33-S, 33-N AND 33-P.
CLR MMRO :TURN OFF MEMORY MANAGEMENT.

7853

.SBTTL TEST # 103 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 6

:TEST 103 ABLE D-SPACE & SEE I-SPACE FORCED, MODE 6
:
: THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
: INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
: MEMORY MANAGEMENT TRAP/ABORT.
: ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
: THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
: AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
: INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
: DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
: INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.
:

041524 000004

7854
7855 041526 004767 000676
7856 041532 170567 056222
7857 041536 004767 000666
7858 041542 170467 056212
7859 041546 004767 000656
7860 041552 177067 056202
7861 041556 004767 000646
7862 041562 172467 056172
7863 041566 004767 000636
7864 041572 170367 056162
7865 041576 005067 135770
7866

TST103: SCOPE

.DSABL AMA ;DISABLE MODE 6 TO MODE 3 CONVERSION
JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
TSTF DATA ;TESTING BLOCK 21-0.
JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
CLRF DATA ;TESTING BLOCKS 27-DD, 27-T AND 27-R.
JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
LDCIF DATA,AC0 ;TESTING BLOCKS 28-T, 28-N AND 28-P.
JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
LDF DATA,AC0 ;TESTING BLOCKS 4-DD, 4-T, 4-X, 4-Z AND 4-BB.
JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
STST DATA ;TESTING BLOCKS 33-T, 33-N AND 33-P.
CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
.ENABL AMA ;REENABLE MODE 6 TO MODE 3 CONVERSION

7867

.SBTTL TEST # 104 - ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 7

:TEST 104 ENABLE D-SPACE & SEE I-SPACE FORCED, MODE 7
:
*: THIS IS A TEST THAT WILL ENABLE D-SPACE AND MAKE IT RESIDENT SO THAT AN
*: INSTRUCTION THAT ACCESSES I-SPACE WHEN IT NORMALLY SHOULDN'T WILL CAUSE A
*: MEMORY MANAGEMENT TRAP/ABORT.
*: *****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS*****
*: THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO FLOWS
*: AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD BE EASIER.
*: INSTRUCTION GROUPS ISOLATED BY BLANK LINES ARE TO BE EXECUTED TOGETHER
*: DUE TO PROPER SETUP PURPOSES. I.E. THE LOCATION OR ADDRESS HAS TO BE
*: INITIALIZED PROPERLY BEFORE THE INSTRUCTION CAN BE ACCOMPLISHED.
:

041602	000004		
7868	041604	010200	MOV R2,R0 ;SETTING UP R0.
7869	041606	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7870	041612	170470	CLRF @0(R0) ;TESTING BLOCKS 27-GG, 27-JJ, 27-T AND 27-R.
7871	041616	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7872	041622	170477	CLRF @DATA+10 ;TESTING BLOCKS 27-GG, 27-JJ, 27-T AND 27-R.
7873	041626	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7874	041632	177070	LDCIF @0(R0),AC0 ;TESTING BLOCKS 28-W, 28-Z, 28-N AND 28-P.
7875	041636	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7876	041642	177077	LL^IF @DATA+10,AC0 ;TESTING BLOCKS 28-W, 28-Z, 28-N AND 28-P.
7877	041646	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7878	041652	172470	LDF @0(R0),AC0 ;TESTING BLOCKS 4-GG, 4-JJ, 4-T, 4-X 4-Z AND 4-BB.
7879	041656	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7880	041662	172477	LDF @DATA+10,AC0 ;TESTING BLOCKS 4-GG, 4-JJ, 4-T, 4-X 4-Z AND 4-BB.
7881	041666	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7882	041672	170370	STST @0(R0) ;TESTING BLOCKS 33-W, 33-Z, 33-N AN 33-P.
7883	041676	004737	JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
7884	041702	170377	STST @DATA+10 ;TESTING BLOCKS 33-W, 33-Z, 33-N AN 33-P.
7885	041706	005037	CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
7886			
7887	041712	000431	BR ENDTST ;BRANCH TO END OF TEST ROUTINE.

7888					.SBTTL	TRAP HANDLER FOR UNEXPECTED MEMORY MANAGEMENT ABORTS
7889	041714	042737	000001	177572	TRAPV:	BIC #1,MMR0 ;TURN OFF MEMORY MANAGEMENT.
7890	041722	013737	177572	001240	MOV	MMR0,\$TMP3 ;TRANSFER MMR0 TO TMP3 FOR ERROR PRINTING.
7891	041730	005237	001240		INC	\$TMP3 ;REPLACE BIT CLEARED TURNING OFF MEMORY MANAGEMENT.
7892	041734	013737	177576	001236	MOV	MMR2,\$TMP2 ;MOVE THE TRAP INSTRUCTION ADDRESS TO TMP13.
7893	041742	005037	177572		CLR	MMR0 ;CLEAR ERROR BITS.
7894	041746	012637	001266		MOV	(SP)+,\$TMP16 ;POP STACK AND SAVE 1ST CONTENTS.
7895	041752	012637	001270		MOV	(SP)+,\$TMP17 ;POP STACK AGAIN AND SAVE 2ND CONTENTS.
7896	041756	104362			ERROR	+362 ;FPP TRAP/ABORT ERROR CALL.
7897	041760	013746	001270		MOV	\$TMP17,-(SP) ;PUSH 2ND SAVED CONTENTS BACK ON STACK.
7898	041764	013746	001266		MOV	\$TMP16,-(SP) ;PUSH 1ST SAVED CONTENTS BACK ON STACK.
7899	041770	005237	177572		INC	MMR0 ;TURN ON MEMORY MANAGEMENT.
7900	041774	000002			RTI	;RETURN FROM INTERRUPT.

7901 041776 005037 177572	ENDTST: CLR	MMR0	: TURN OFF MEMORY MANAGEMENT.
7902 042002 013737 001262	MOV	STMP14,MMVECT	: RESTORE MMVECT TO ITS ORIGINAL CONTENTS.
7903 042010 042010 104412	IDONE: RSETUP		
			: GO INITIALIZE THE FPS AND STACK; AND : SEE IF THE USER HAS EXPRESSED : THE DESIRE TO CHANGE THE SOFTWARE : VIRTUAL CONSOLE SWITCH REGISTER (HAS : THE USER TYPED CONTROL G?).
7904 042012 005037 177572	CLR	MMR0	: MAKE SURE MEMORY MANAGEMENT IS OFF.
7905 042016 170127 040000	LDFPS	#40000	: LOAD FLOATING POINT STATUS.
7906 042022 005037 001272	CLR	STMP20	: CLEAR THE TEMPORARY LOCATION.
7907 042026 012737 000252	MOV	#252,STORE	: CLEAR UPPER BYTE - ALTERNATING BITS IN LOWER BYTE.
7908 042034 012737 125252	MOV	#125252,STORE+2	: MOVE ALTERNATING BITS TO 2ND WORD.
7909 042042 012737 125252	MOV	#125252,STORE+4	: MOVE ALTERNATING BITS TO 3RD WORD.
7910 042050 012737 125252	MOV	#125252,STORE+6	: MOVE ALTERNATING BITS TO 4TH WORD.
7911 042056 172437 045232	LDF	STORE,AC0	: LOAD AC0.
7912 042062 172537 045232	LDF	STORE,AC1	: LOAD AC1.
7913 042066 172637 045232	LDF	STORE,AC2	: LOAD AC2.
7914 042072 172737 045232	LDF	STORE,AC3	: LOAD AC3.
7915 042076 012700 045232	MOV	#STORE,RO	: MOVE ADDRESS OF STORE TO RO.
7916 042102 012701 000030	MOV	#30,R1	: MOVE LOOP COUNTER (CLEARING 30 WORDS) TO R1.
7917 042106 005020	15: CLR (R0)+	R1,1\$: CLEAR THE WORD.
7918 042110 077102	SOB		: SUBTRACT 1 FROM R1 AND BRANCH IF NOT 0.
7919 042112 174037 045232	STF	AC0,STORE	: STORE AC0.
7920 042116 174137 045242	STF	AC1,STORE+10	: STORE AC1.
7921 042122 174237 045252	STF	AC2,STORE+20	: STORE AC2.
7922 042126 174337 045262	STF	AC3,STORE+30	: STORE AC3.
7923			
7924 042132 012737 077406	MOV	#77406,KDPDRO	: MAKE KDPDRO RESIDENT.
7925 042140 012737 077406	MOV	#77406,KDPDR1	: MAKE KDPDR1 RESIDENT.
7926 042146 012737 077400	MOV	#77400,KDPDR2	: MAKE KDPDR2 NON-RESIDENT.
7927 042154 012737 077406	MOV	#77406,KDPDR3	: MAKE KDPDR3 RESIDENT.
7928 042162 012737 077406	MOV	#77406,KDPDR7	: MAKE KDPDR7 RESIDENT.
7929			
7930 042170 012737 077406	MOV	#77406,KIPDRO	: MAKE KIPDRO RESIDENT.
7931 042176 012737 077406	MOV	#77406,KIPDR1	: MAKE KIPDR1 RESIDENT.
7932 042204 012737 077406	MOV	#77406,KIPDR2	: MAKE KIPDR2 RESIDENT.
7933 042212 012737 077406	MOV	#77406,KIPDR3	: MAKE KIPDR3 RESIDENT.
7934 042220 012737 077406	MOV	#77406,KIPDR7	: MAKE KIPDR7 RESIDENT.
7935			
7936 042226 005037 172360	CLR	KDPAR0	: MAP D-PAGE 0 FOR 0-4K.
7937 042232 012737 000200	MOV	#200,KDPAR1	: MAP D-PAGE 1 FOR 4-8K.
7938 042240 012737 000400	MOV	#400,KDPAR2	: MAP D-PAGE 2 FOR 8-12K.
7939 042246 012737 000600	MOV	#600,KDPAR3	: MAP D-PAGE 3 FOR 12-16K.
7940 042254 012737 177600	MOV	#177600,KDPAR7	: MAP D-PAGE 7 FOR /O PAGE.
7941			
7942 042262 005037 172340	CLR	KIPAR0	: MAP I-PAGE 0 FOR 0-4K.
7943 042266 012737 000200	MOV	#200,KIPAR1	: MAP I-PAGE 1 FOR 4-8K.
7944 042274 012737 000400	MOV	#400,KIPAR2	: MAP I-PAGE 2 FOR 8-12K.
7945 042302 012737 000600	MOV	#600,KIPAR3	: MAP I-PAGE 3 FOR 12-16K.
7946 042310 012737 177600	MOV	#177600,KIPAR7	: MAP I-PAGE 7 FOR I/O PAGE.
7947			
7948 042316 012705 045312	MOV	#BYTABL,R5	: SET UP BYTE TABLE POINTER R5.
7949 042322 013737 000250	MOV	MMVECT,STMP14	: TEMPORARILY STORE THE MMVECT VALUE.
7950 042330 012737 044054	MOV	#TRPV,MMVEC1	: SET UP FOR FP TRAPS FOR THIS TEST.
7951 042336 012737 000340	MOV	#340,MMVECT+2	
7952 042344 013737 000020	MOV	IOTRAP,SAVIOT	: STORE THE IOTRAP VALUE IN SAVIOT

7953 042352 012737 000340 000022	MOV	#340,IOTRAP+2	
7954			
7955 042360 012737 000024 172516	MOV	#24,MMR3	:TURN ON 22-BIT KERNEL D-SPACE.
7956 042366 012737 045216 045226	MOV	#NODAT,NODAT+10	:SET UP ADDRESS POINTER.
7957 042374 012700 045216	MOV	#NODAT,R0	:SET UP R0.
7958 042400 012702 045226	MOV	#NODAT+10,R2	:SET UP R2.
7959 042404 012703 045230	MOV	#NODAT+12,R3	:SET UP R3.
7960 042410 010037 045272	MOV	R0,STORE+40	:STORE R0.
7961 042414 010237 045274	MOV	R2,STORE+42	:STORE R2.
7962 042420 010337 045276	MOV	R3,STORE+44	:STORE R3.
7963 042424 000410	BR	TST105	:BRANCH OVER LOCATION SAVIOT AND SETERL SUBROUTINE
7964			
7965 042426 000000	SAVIOT: .WORD	0	:LOCATION TO SAVE THE SCOPE VECTOR ADDRESS
7966			
7967 042430 005037 177572	SETERL: CLR	MMR0	:TURN OFF MEMORY MANAGEMENT
7968 042434 011637 001110	MOV	(SP),SLPERR	:MOVE RETURN ADDRESS TO SLPERR
7969 042440 005237 177572	INC	MMR0	:TURN MEMORY MANAGEMENT BACK ON
7970 042444 000207	RTS	PC	:RETURN

7983

.SBTTL TEST # 105 - AUTO INCREMENT/DECREMENT TEST, MODE 0

TEST 105 AUTO INCREMENT/DECREMENT TEST, MODE 0
*
* THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
* ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
* D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
* CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
* FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
* BE EASIER.

042446 000004

TST105: SCOPE

7984
7985 :* THE FOLLOWING TESTS ARE FOR MODE 0 REG 1 (THESE SHOULD *NOT* ABORT).
7986
7987 042450 012737 044006 000020 MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
7988 042456 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7989 042462 170501 TSTF R1 ;FDST-NOTCLR PAGE 21.
7990 042464 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7991 042470 170401 CLRF R1 ;FDST MODES PAGE 27.
7992 042472 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7993 042476 177001 LDCIF R1,AC0 ;SOURCE MODES PAGE 28.
7994 042500 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7995 042504 172401 LDF R1,AC0 ;FSRC MODES PAGE 4.
7996 042506 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
7997 042512 170301 STST R1 ;DEST MODES PAGE 33.
7998 042514 005037 177572 CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
7999 042520 172437 045232 LDF STORE,AC0 ;RESTORE AC0.
8000 042524 172537 045232 LDF STORE,AC1 ;RESTORE AC1.
8001 042530 010046 MOV R0,-(SP) ;SAVE R0 FOR NEXT TEST
8002 042532 010246 MOV R2,-(SP) ;SAVE R2 FOR NEXT TEST
8003 042534 013737 042426 000020 MOV SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR

8004

.SBTTL TEST # 106 - AUTO INCREMENT/DECREMENT TEST, MODE 1

 TEST 106 AUTO INCREMENT/DECREMENT TEST, MODE 1
 *
 * THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 * ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 * D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 * CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 ****ALL REFERENCES TO MICRO-1 LOWS REFER TO *FP11-F-2 REV A* FLOWS****
 * THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 * FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 * BE EASIER.

 TST106: SCOPE
 8005 042542 000004
 8006 042544 012602
 8007 042546 012600
 8008 042550 012737 044006 000020
 8009 042556 010001
 8010 042560 010004
 8011 042562 004737 042430
 8012 042566 170511
 8013 042570 000004
 8014 042572 004737 042430
 8015 042576 170411
 8016 042600 000004
 8017 042602 004737 042430
 8018 042606 177011
 8019 042610 000004
 8020 042612 004737 042430
 8021 042616 172411
 8022 042620 000004
 8023 042622 004737 042430
 8024 042626 170311
 8025 042630 000004
 8026 042632 005037 177572
 8027 042636 010046
 8028 042640 010246
 8028 042642 013737 042426 000020
 MODE1:
 MOV (SP)+,R2 ;RESTORE R2 FOR THIS TEST
 MOV (SP)+,R0 ;RESTORE R0 FOR THIS TEST
 MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
 MOV R0,R1 ;SET UP R1.
 MOV R0,R4 ;MOVE 'START' VALUE INTO R4.
 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 TSTF (R1) ;FDST-NOTCLR PAGE 21.
 IOT ;FORCE A TRAP.
 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 CLRF (R1) ;FDST MODES PAGE 27.
 IOT ;FORCE A TRAP.
 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 LDCIF (R1),AC0 ;SOURCE MODES PAGE 28.
 IOT ;FORCE A TRAP.
 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 LDF (R1),AC0 ;FSRC MODES PAGE 4.
 IOT ;FORCE A TRAP.
 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 STST (R1) ;DEST MODES PAGE 33.
 IOT ;FORCE A TRAP.
 CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
 MOV R0,-(SP) ;SAVE R0 FOR NEXT TEST
 MOV R2,-(SP) ;SAVE R2 FOR NEXT TEST
 MOV SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR

8029

.SBTTL TEST # 107 - AUTO INCREMENT/DECREMENT TEST, MODE 2

 :*TEST 107 AUTO INCREMENT/DECREMENT TEST, MODE 2
 :*
 :* THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 :* ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 :* D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 :* CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 :* ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
 :* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 :* FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 :* BE EASIER.
 :*
 :*****
 TST107: SCOPE
 8030 042650 000004 042652 012737 044006 000020 MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
 8031 042660 012602 MOV (SP)+,R2 :RESTORE R2 FOR THIS TEST
 8032 042662 012600 MOV (SP)+,R0 :RESTORE R0 FOR THIS TEST
 8033 042664 010001 MOV R0,R1 :CORRECT R1
 8034 042666 004737 042430 JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8035 042672 170521 TSTF (R1)+ :FDST-NOTCLR PAGE 21.
 8036 042674 000004 LABEL1: IOT :FORCE A TRAP.
 8037
 8038 042676 004737 042430 JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8039 042702 010001 MOV R0,R1 :CORRECT R1.
 8040 042704 170421 CLRF (R1)+ :FDST MODES PAGE 27.
 8041 042706 000004 IOT :FORCE A TRAP.
 8042
 8043 042710 004737 042430 JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8044 042714 010001 MOV R0,R1 :CORRECT R1.
 8045 042716 177021 LDCIF (R1)+,AC0 :SOURCE MODES PAGE 28.
 8046 042720 000004 IOT :FORCE A TRAP.
 8047
 8048 042722 004737 042430 JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8049 042726 010001 MOV R0,R1 :CORRECT R1.
 8050 042730 172421 LDF (R1)+,AC0 :FSRC MODES PAGE 4.
 8051 042732 000004 IOT :FORCE A TRAP.
 8052
 8053 042734 004737 042430 JSR PC,SETERL :GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8054 042740 010001 MOV R0,R1 :CORRECT R1.
 8055 042742 170321 STST (R1)+ :DEST MODES PAGE 33.
 8056 042744 000004 IOT :FORCE A TRAP.
 8057 042746 005037 177572 CLR MMRO :TURN OFF MEMORY MANAGEMENT.
 8058 042752 013737 042426 000020 MOV SAVIOT,IOTRAP :RESTORE SCOPE TRAP VECTOR
 8059 042760 010046 MOV R0,-(SP) :SAVE R0 FOR NEXT TEST
 8060 042762 010246 MOV R2,-(SP) :SAVE R2 FOR NEXT TEST

8061

.SBTTL TEST # 110 - AUTO INCREMENT/DECREMENT TEST, MODE 3
 :*****
 :TEST 110 AUTO INCREMENT/DECREMENT TEST, MODE 3
 :
 : THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 : ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 : D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 : CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 : ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
 : THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 : FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 : BE EASIER.
 :
 :*****
 TST110: SCOPE
 8062 042764 000004 042766 012737 044006 000020 MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
 8063 042774 012602 MOV (SP)+,R2 ;RESTORE R2 FOR THIS TEST
 8064 042776 012600 MOV (SP)+,R0 ;RESTORE R0 FOR THIS TEST
 8065 043000 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8066 043004 010201 MOV R2,R1 ;SET UP R1 FOR MODE 3.
 8067 043006 010204 MOV R2,R4 ;MOVE 'START' VALUE INTO R4.
 8068 043010 170531 TSTF @R1+ ;FDST-NOTCLR PAGE 21.
 8069 043012 000004 IOT ;FORCE A TRAP.
 8070 043014 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8071 043020 170537 045216 TSTF NODAT ;FORCE A TRAP.
 8072 043024 000004 IOT ;FORCE A TRAP.
 8073
 8074 043026 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8075 043032 010201 MOV R2,R1 ;CORRECT R1.
 8076 043034 170431 CLRF @R1+ ;FDST MODES PAGE 27.
 8077 043036 000004 IOT ;FORCE A TRAP.
 8078 043040 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8079 043044 170437 045216 CLRF NODAT ;FORCE A TRAP.
 8080 043050 000004 IOT ;FORCE A TRAP.
 8081
 8082 043052 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8083 043056 010201 MOV R2,R1 ;CORRECT R1.
 8084 043060 177031 LDCIF @R1+,AC0 ;SOURCE MODES PAGE 28.
 8085 043062 000004 IOT ;FORCE A TRAP.
 8086 043064 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8087 043070 177037 045216 LDCIF NODAT,AC0 ;FORCE A TRAP.
 8088 043074 000004 IOT ;FORCE A TRAP.
 8089
 8090 043076 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8091 043102 010201 MOV R2,R1 ;CORRECT R1.
 8092 043104 172431 LDF @R1+,AC0 ;FSRC MODES PAGE 4.
 8093 043106 000004 IOT ;FORCE A TRAP.
 8094 043110 004737 042430 JSR PC,SETERL ;GO SET ERROR LUOP TO ADRS OF NEXT INST ;DPM002
 8095 043114 172437 045216 LDF NODAT,AC0 ;FORCE A TRAP.
 8096 043120 000004 IOT ;FORCE A TRAP.
 8097
 8098 043122 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8099 043126 010201 MOV R2,R1 ;CORRECT R1.
 8100 043130 170331 STST @R1+ ;DEST MODES PAGE 33.
 8101 043132 000004 IOT ;FORCE A TRAP.
 8102 043134 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 8103 043140 170337 045216 STST NODAT

CKFPCDO FP11F FLTG PNT PRT C MACRO M1113 30-OCT-81 11:15 PAGE 93-1
TEST # 110 - AUTO INCREMENT/DECREMENT TEST, MODE 3

N 15
SEQUENCE 195

8104 043144 000004	IOT	:FORCE A TRAP.
8105 043146 005037 177572	CLR	MMR0 :TURN OFF MEMORY MANAGEMENT.
8106 043152 010046	MOV	R0,-(SP) :SAVE R0 FOR NEXT TEST
8107 043154 010246	MOV	R2,-(SP) :SAVE R2 FOR NEXT TEST
8108 043156 013737 042426 000020	MOV	SAVIOT,IOTRAP :RESTORE SCOPE TRAP VECTOR

8109

.SBTTL TEST # 111 - AUTO INCREMENT/DECREMENT TEST, MODE 4

*:TEST 111 AUTO INCREMENT/DECREMENT TEST, MODE 4
*:
*: THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
*: ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
*: D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
*: CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
*****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS*****
*: THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
*: FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
*: BE EASIER.
*:

TST111: SCOPE
8110 043164 000004 043166 012737 044006 000020 MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
8111 043174 012602 MOV (SP)+,R2 ;RESTORE R2 FOR THIS TEST
8112 043176 012600 MOV (SP)+,R0 ;RESTORE R0 FOR THIS TEST
8113 043200 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8114 043204 010201 MOV R2,R1 ;SET UP R1 FOR MODE 4.
8115 043206 170541 TSTF -(R1) ;FDST-NOTCLR PAGE 21.
8116 043210 000004 IOT ;FORCE A TRAP.
8117
8118 043212 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8119 043216 010201 MOV R2,R1 ;CORRECT R1.
8120 043220 170441 CLRF -(R1) ;FDST MODES PAGE 27.
8121 043222 000004 IOT ;FORCE A TRAP.
8122
8123 043224 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8124 043230 010201 MOV R2,R1 ;CORRECT R1.
8125 043232 177041 LDCIF -(R1),AC0 ;SOURCE MODES PAGE 28.
8126 043234 000004 IOT ;FORCE A TRAP.
8127
8128 043236 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8129 043242 010201 MOV R2,R1 ;CORRECT R1.
8130 043244 172441 LDF -(R1),AC0 ;FSRC MODES PAGE 4.
8131 043246 000004 IOT ;FORCE A TRAP.
8132
8133 043250 004737 042430 JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8134 043254 010201 MOV R2,R1 ;CORRECT R1.
8135 043256 170341 STST -(R1) ;DEST MODES PAGE 33.
8136 043260 000004 IOT ;FORCE A TRAP.
8137 043262 005037 177572 CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
8138 043266 010046 MOV R0,-(SP) ;SAVE R0 FOR NEXT TEST
8139 043270 010246 MOV R2,-(SP) ;SAVE R2 FOR NEXT TEST
8140 043272 013737 042426 000020 MOV SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR

8141

SBTTL TEST # 112 - AUTO INCREMENT/DECREMENT TEST, MODE 5

*****TEST 112 AUTO INCREMENT/DECREMENT TEST, MODE 5*****

*** THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 *** ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 *** D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 *** CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 *** ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS***
 *** THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 *** FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 *** BE EASIER.

*****TST112: SCOPE*****

8142 043300 000004	043302 012737 044006 000020	MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
8143 043310 012602		MOV (SP)+,R2 ;RESTORE R2 FOR THIS TEST
8144 043312 012600		MOV (SP)+,R0 ;RESTORE R0 FOR THIS TEST
8145 043314 004737 042430		JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
8146 043320 010301		MOV R3,R1 ;SET UP R1 FOR MODE 5.
8147 043322 010304		MOV R3,R4 ;MOVE 'START' VALUE INTO R4.
8148 043324 170551		TSTF a-(R1) ;FDST-NOTCLR PAGE 21.
8149 043326 000004		IOT ;FORCE A TRAP.
8150		
8151 043330 004737 042430		JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
8152 043334 010301		MOV R3,R1 ;CORRECT R1.
8153 043336 170451		CLRF a-(R1) ;FDST MODES PAGE 27.
8154 043340 000004		IOT ;FORCE A TRAP.
8155		
8156 043342 004737 042430		JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
8157 043346 010301		MOV R3,R1 ;CORRECT R1.
8158 043350 177051		LDCIF a-(R1),AC0 ;SOURCE MODES PAGE 28.
8159 043352 000004		IOT ;FORCE A TRAP.
8160		
8161 043354 004737 042430		JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
8162 043360 010301		MOV R3,R1 ;CORRECT R1.
8163 043362 172451		LDF a-(R1),AC0 ;FSRC MODES PAGE 4.
8164 043364 000004		IOT ;FORCE A TRAP.
8165		
8166 043366 004737 042430		JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST :DPM002
8167 043372 010301		MOV R3,R1 ;CORRECT R1.
8168 043374 170351		STST a-(R1) ;DEST MODES PAGE 33.
8169 043376 000004		IOT ;FORCE A TRAP.
8170 043400 005037 177572	042426 C00020	CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
8171 043404 013737		MOV SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR

8172

.SBTTL TEST # 113 - AUTO INCREMENT/DECREMENT TEST, MODE 6

 :TEST 113 AUTO INCREMENT/DECREMENT TEST, MODE 6

:
 : THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 : *ONLY* WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 : D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 : CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 : ****ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS****
 : THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 : FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 : BE EASIER.

8173	043412	000004	TST113: SCOPE	
8174	043414	012767	044006	134376
8175	043422	004767	177002	
8176	043426	010301		
8177	043430	010304		
8178	043432	170561	000000	
8179	043436	000004		
8180	043440	004767	176764	
8181	043444	170567	001546	
8182	043450	000004		
8183	043452	004767	176752	
8184	043456	170461	000000	
8185	043462	000004		
8186	043464	004767	176740	
8187	043470	170467	001522	
8188	043474	000004		
8189	043476	004767	176726	
8190	043502	177061	000000	
8191	043506	000004		
8192	043510	004767	176714	
8193	043514	177067	001476	
8194	043520	000004		
8195	043522	004767	176702	
8196	043526	172461	000000	
8197	043532	000004		
8198	043534	004767	176670	
8199	043540	172467	001452	
8200	043544	000004		
8201	043546	004767	176656	
8202	043552	170361	000000	
8203	043556	000004		
8204	043560	004767	176644	
8205	043564	170367	001426	
8206	043570	000004		
8207	043572	005067	133774	
8208	043576	010246		
8209	043600	016767	176622	134212
8210				

.DSABL AMA ;DISABLE MODE 6 TO MODE 3 CONVERSIONS
 .MOV #FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .MOV R3,R1 ;SET UP R1 FOR MODE 6.
 .MOV R3,R4 ;MOVE 'START' VALUE INTO R4.
 .TSTF 0(R1) ;FDST-NOTCLR PAGE 21.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .TSTF NODAT ;FDST-NOTCLR PAGE 21.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .CLRF 0(R1) ;FDST MODES PAGE 27.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .CLRF NODAT ;FDST MODES PAGE 27.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .LDCIF 0(R1),AC0 ;SOURCE MODES PAGE 28.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .LDCIF NODAT,AC0 ;SOURCE MODES PAGE 28.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .LDF 0(R1),AC0 ;FSRC MODES PAGE 4.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .LDF NODAT,AC0 ;FSRC MODES PAGE 4.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .STST 0(R1) ;DEST MODES PAGE 33.
 .IOT ;FORCE A TRAP.
 .JSR PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
 .STST NODAT ;DEST MODES PAGE 33.
 .IOT ;FORCE A TRAP.
 .CLR MMRO ;TURN OFF MEMORY MANAGEMENT.
 .MOV R2,-(SP) ;SAVE R2 FOR NEXT TEST
 .MOV SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR
 .ENABL AMA ;REENABLE MODE 6 TO MODE 3 CONVERSIONS

8211

.SBTTL TEST # 114 - AUTO INCREMENT/DECREMENT TEST, MODE 7
 :*****
 :TEST 114 AUTO INCREMENT/DECREMENT TEST, MODE 7
 :*
 :* THIS TEST INSURES THAT AUTO INCREMENT/DECREMENT WORKS PROPERLY AND
 :* ONLY WHEN IT IS SUPPOSED TO. THIS IS DONE BY ENABLING 22-BIT KERNEL
 :* D-SPACE, BUT MAKING IT NON-RESIDENT, FORCING A MEMORY MANAGEMENT TRAP
 :* CONDITION. THIS ENABLES EXAMINING OF SR1 FOR PROPER CONTENTS.
 :* ALL REFERENCES TO MICRO-FLOWS REFER TO *FP11-F-2 REV A* FLOWS*****
 :* THE COMMENTS FOR EACH TEST LINE ARE WRITTEN SO YOU CAN GO TO THE MICRO
 :* FLOW AND PINPOINT THE PROBLEM AREA. FROM THERE, HARDWARE ANALYSIS SHOULD
 :* BE EASIER.
 :*

043606	000004			TST114: SCOPE	
8212 043610	012737	044006	000020	MOV	#FALTRP,IOTRAP;SET UP FOR FAILURE OF TRAPS FOR THIS TEST.
8213 043616	012602			MOV	(SP)+,R2 ;RESTORE R2 FOR THIS TEST
8214 043620	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8215 043624	010201			MOV	R2,R1 ;SET UP R1 FOR MODE 7.
8216 043626	010204			MOV	R2,R4 ;MOVE 'START' VALUE TO R4.
8217 043630	170571	000000		TSTF	@0(R1) ;FDST-NOTCLR PAGE 21.
8218 043634	000004			IOT	;FORCE A TRAP.
8219 043636	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8220 043642	170577	001360		TSTF	@NODAT+10 ;FDST-NOTCLR PAGE 21.
8221 043646	000004			IOT	;FORCE A TRAP.
8222 043650	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8223 043654	170471	000000		CLRF	@0(R1) ;FDST MODES PAGE 27.
8224 043660	000004			IOT	;FORCE A TRAP.
8225 043662	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8226 043666	170477	001334		CLRF	@NODAT+10 ;FDST MODES PAGE 27.
8227 043672	000004			IOT	;FORCE A TRAP.
8228 043674	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ,DPM002
8229 043700	177071	000000		LDCIF	@0(R1),AC0 ;SOURCE MODES PAGE 28.
8230 043704	000004			IOT	;FORCE A TRAP.
8231 043706	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8232 043712	177077	001310		LDCIF	@NODAT+10,AC0 ;SOURCE MODES PAGE 28.
8233 043716	000004			IOT	;FORCE A TRAP.
8234 043720	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8235 043724	172471	000000		LDF	@0(R1),AC0 ;FSRC MODES PAGE 4.
8236 043730	000004			IOT	;FORCE A TRAP.
8237 043732	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8238 043736	172477	001264		LDF	@NODAT+10,AC0 ;FSRC MODES PAGE 4.
8239 043742	000004			IOT	;FORCE A TRAP.
8240 043744	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8241 043750	170371	000000		STST	@0(R1) ;DEST MODES PAGE 33.
8242 043754	000004			IOT	;FORCE A TRAP.
8243 043756	004737	042430		JSR	PC,SETERL ;GO SET ERROR LOOP TO ADRS OF NEXT INST ;DPM002
8244 043762	170377	001240		STST	@NODAT+10, ;DEST MODES PAGE 33.
8245 043766	000004			IOT	;FORCE A TRAP.
8246 043770	005037	177572		CLR	MMRO ;TURN OFF MEMORY MANAGEMENT.
8247 043774	013737	042426	000020	MOV	SAVIOT,IOTRAP ;RESTORE SCOPE TRAP VECTOR
8248 044002	000137	045376		JMP	ENDTES ;JUMP TO END TEST.

8249 044006 005037 177572 FALTRP: CLR MMRO :TURN OFF MEMORY MANAGEMENT.
8250 044012 011637 001260 MOV (SP),\$TMP13 :MOVE NEXT INSTRUCTION ADDRESS TO \$TMP13.
8251
8252 :THIS NEXT SECTION NOW CORRECTS THE CONTENTS OF \$TMP13 SO THAT IT POINTS
8253 :TO THE PREVIOUS FPP INSTRUCTION. IT DOES THIS BY SUBTRACTING 2 FROM THE
8254 :ADDRESS IN \$TMP13, REPLACING THE 170000 THAT THE BIC INSTRUCTION USES,
8255 :AND BIT CLEARING THE INSTRUCTION WITH 170000. IF THE INSTRUCTION THAT
8256 :\$TMP13 IS POINTING TO IS NOT AN FPP INSTRUCTION, THE 170000 WILL NOT
8257 :CLEAR, SATISFYING THE NEXT BRANCH. THE ADDRESS IS AGAIN CORRECTED,
8258 :AND THE TESTING PROCESS STARTS OVER. THIS CONTINUES UNTIL \$TMP13 IS
8259 :POINTING TO AN FPP INSTRUCTION, AND NORMALLY WILL NOT BE EXECUTED MORE
8260 :THAN THREE TIMES BEFORE FINDING THE INSTRUCTION.
8261 044016 162737 000002 001260 1\$: SUB #2,\$TMP13 :SUBTRACT 2 FROM \$TMP13.
8262 044024 012737 170000 044036 MCV #170000,2\$+4 :SET UP BIC DATA LOCATION.
8263 044032 047727 135222 170000 2\$: BIC @\$TMP13,#170000 :TEST TO SEE IF FPP INSTRUCTION.
8264 044040 001366 BNE 1\$:BRANCH BACK FOR ANOTHER TRY IF NOT.
8265 044042 012737 000364 001272 MOV #364,\$TMP20 :MOVE FAILURE TO ABORT ERROR TO \$TMP20.
8266 044050 000137 045104 JMP MULTER :JUMP TO MULTIPLE ERROR HANDLER.

8267 044054	013737	177574	001236	TRPV:	MOV	SR1,\$TMP2	:MOVE SR1 TO TMP2 FOR TESTING.
8268 044062	012737	177576	001260		MOV	MMR2,\$TMP13	:TRANSFER ADDRESS OF INST. CAUSING TRAP TO TMP13.
8269 044070	005037	177572			CLR	MMR0	:TURN OFF MEMORY MANAGEMENT.
8270 044074	112737	000365	001272		MOVB	#365,\$TMP20	:MOVE 365, THE MODE 0 ERROR, TO LOWER BYTE IN ERROR POINTER.
8271 044102	022737	042556	001260		CMP	#MODE1,\$TMP13	:SEE IF INSTRUCTION CAUSING TRAP IS BEFORE MODE 1 (MODE 0).
8272 044110	002402				BLT	1\$:BRANCH AROUND MODE 0 ERROR JUMP IF NOT.
8273 044112	000137	045104			JMP	MULTER	:JUMP TO ERROR NEST.
8274 044116	017737	135136	001266	1\$:	MOV	@\$TMP13,\$TMP16	:MOVE INSTRUCTION CAUSING TRAP TO TMP16.
8275 044124	112737	000363	001272		MOVB	#363,\$TMP20	:MOVE 363, SR1 WRONG ERROR, TO LOWER BYTE IN ERROR POINTER.
8276 044132	005037	001240			CLR	\$TMP3	:CLEAR CALCULATED LOCATION.
8277 044136	012737	044330	001244		MOV	#65\$,TMP5	:MOVE NEXT CHECK ADDRESS TO TMP5.
8278 044144	022737	042674	001260		CMP	#LABEL1,\$TMP13	:SEE IF TRAP IS BEFORE MODE 2 REG 1 CLRF INST.
8279 044152	100053				BPL	61\$:BRANCH TO SR1=0 TEST IF SO.
8280 044154	012737	000060	044166		MOV	#60,200\$:SET UP BIC DATA POSITION.
8281 044162	043727	001266		2\$:	BIC	\$TMP16,(PC)+	:TEST TO SEE IF MODE 6 OR 7 INSTRUCTION.
8282 044166	000060			200\$:	WORD	60	:LOCATION TO HOLD 60
8283 044170	001444				BEQ	61\$:BRANCH DIRECTLY TO BYTE TABLE TESTING IF SO.
8284							:THIS NEXT ROUTINE DETERMINES WHICH REGISTER WAS IN THE INSTRUCTION, AND
8285							:LOADS THE START AND END VALUES OF EITHER R1 OR R7 (PROGRAM COUNTER) INTO
8286							:TMP17 AND TMP3 RESPECTIVELY. THEY ARE THEN SUBTRACTED TO FIND THE
8287							:DIFFERENCE THAT ACTUALLY OCCURRED. IF NO DIFFERENCE WAS FOUND, THE TEST
8288							:FOR ZERO IN SR1 IS ACCOMPLISHED. IF A DIFFERENCE IS FOUND, THE DIFFERENCE
8289							:IS SHIFTED LEFT 3 PLACES, THE TOP BYTE IS CLEARED, AND THE REGISTER
8290							:OF THE INSTRUCTION IS ADDED. TMP3 NOW CONTAINS WHAT SHOULD APPEAR
8291							:IN SR1, ACCORDING TO WHAT ACTUALLY HAPPENED TO THE REGISTER.
8292 044172	042737	177770	001266	4\$:	BIC	#177770,\$TMP16	:BIT CLEAR THE INSTRUCTION, LEAVING THE REG EXPOSED.
8293 044200	023727	001266	000007		CMP	\$TMP16,#7	:COMPARE REGISTER TO DETERMINE IF IT IS REG 7.
8294 044206	001405				BEQ	5\$:BRANCH TO THE REG 7 SETUP IF EQUAL TO REG 7.
8295 044210	010437	001270			MOV	R4,\$TMP17	:MOVE THE START VALUE TO TMP17.
8296 044214	010137	001240			MOV	R1,\$TMP3	:MOVE THE END VALUE TO TMP3.
8297 044220	000410				BR	6\$:BRANCH TO CONTINUE.
8298 044222	013737	001260	001270	5\$:	MOV	\$TMP13,\$TMP17	:MOVE THE START VALUE TO TMP17.
8299 044230	062737	000002	001270		ADD	#2,\$TMP17	:ADD 2 TO START VALUE FOR NORMAL INCREMENTING.
8300 044236	011637	001240			MOV	(SP),\$TMP3	:MOVE THE END VALUE TO TMP3.
8301 044242	163737	001270	001240	6\$:	SUB	\$TMP17,\$TMP3	:FIND THE DIFFERENCE THAT OCCURED.
8302 044250	001414				BEQ	61\$:BRANCH TO TEST FOR SR1=0 IF NO DIFFERENCE.
8303 044252	006337	001240			ASL	\$TMP3	:ARITHMETIC SHIFT LEFT TMP3 3
8304 044256	006337	001240			ASL	\$TMP3	:PLACES TO PUT DIFFERENCE FOUND
8305 044262	006337	001240			ASL	\$TMP3	:IN BITS 3 THROUGH 7.
8306 044266	042737	177400	001240		BIC	#177400,\$TMP3	:BIT CLEAR UPPER BYTE OF TMP3.
8307 044274	063737	001266	001240	61\$:	ADD	\$TMP16,\$TMP3	:ADD THE REGISTER THAT WAS CHANGED, AND
8308 044302	111537	001276			MOVB	(R5),\$TMP22	:MOVE EXPECTED DATA TO TMP22.
8309 044306	123725	001236			CMPB	\$TMP2,(R5)+	:COMPARE SR1 WITH TABLE DATA.
8310 044312	001004				BNE	62\$:BRANCH TO ERROR JUMP IF WRONG.
8311 044314	005305				DEC	R5	:CORRECT R5 BEFORE NEXT COMPARE.
8312 044316	123725	001240			CMPB	\$TMP3,(R5)+	:COMPARE CALCULATED WITH TABLE DATA.
8313 044322	001402				BEQ	65\$:BRANCH AROUND ERROR JUMP IF OK.
8314 044324	000137	045002		62\$:	JMP	7\$:JUMP TO ERROR REPORT IF INCORRECT.
8315 044330	132737	000001	001273	65\$:	BITB	#1,\$TMP20+1	:TEST TO SEE IF BIT 8 IS SET.
8316 044336	001402				BEQ	66\$:BRANCH AROUND AC SKIP JUMP IF NOT.
8317 044340	000137	045166			JMP	RETURN	:JUMP TO RETURN - AC TESTS ARE TO BE SKIPPED.
8318 044344	112737	000366	001272	66\$:	MOVB	#366,\$TMP20	:MOVE 366, AC LOAD ERROR, TO ERROR POINTER.
8319 044352	010037	045310			MOV	R0,STORE+56	:STORE R0 FOR USE LATER IN THIS ROUTINE.
8320 044356	005037	001236			CLR	\$TMP2	:MOVE A '0' IN 'AC CHANGED' LOCATION.
8321 044362	012737	044426	001244		MOV	#101\$,TMP5	:MOVE RETURN TO TMP5.
8322 044370	173437	045232			CMPF	STORE,AC0	:SEE IF AC0 WAS CHANGED.
8323 044374	170000				CFCC		:COPY FPP CONDITION CODES TO CPU CODES.

8324	044376	001413			BEQ	101\$:BRANCH TO NEXT TEST IF OK.	
8325	044400	174037	045300		STF	AC0,STORE+46	:STORE ACTUAL AC0 FOR ERROR PRINTING.	
8326	044404	012700	045232		MOV	#STORE,RO	:MOVE ADDRESS OF EXPECTED AC0 TO RO.	
8327							:THE NEXT TWO INSTRUCTIONS TRY TO RESTORE THE ACCUMULATOR AND CHECK THE ACCUMULATOR	
8328							:TO MAKE SURE IT WAS RESTORED PROPERLY FOR THE NEXT RUN THROUGH THIS TRAP HANDLER.	
8329							:IT IS *IMPORTANT* TO REALIZE THAT IF THE "CMPF" FINDS A DIFFERENCE, THAT THE	
8330							:*FLOATING*POINT*STATUS* IS BEING CHANGED MISTAKENLY. AN ERROR IN THE MICRUC 'DE	
8331							:HAS BEEN FOUND TO CAUSE THIS, SO CHECK THE REVISION OF THE ROM/PROM SET IN THE	
8332							:FPP YOU HAVE. IF YOU DO HAVE WHAT *SEEMS* TO BE THE LATEST REV, A NEW REV WI.	
8333							:BE COMMING OUT TO CORRECT THIS PROBLEM. THIS SAME 'LDF/CMPF' SET OF RESTORE/	
8334							:CHECK INSTRUCTIONS IS ACCOMPLISHED FOR EACH ACCUMULATOR CHECK. IT IS ALSO	
8335							:IMPORTANT TO NOTE THAT IF AN ACCUMULATOR FAILS TO RESTORE PROPERLY, SUBSEQUENT	
8336							:PASSES THROUGH THE TRAP HANDLER WILL SKIP THE ACCUMULATOR CHECKS DUE TO THE	
8337							:BIT TEST #400 ABOVE. FOR EXAMPLE, IF AC0 FAILS TO LOAD PROPERLY, AC1 THROUGH	
8338							:AC3 WILL STILL BE CHECKED. AS SOON AS ANOTHER FPP INSTRUCTION TRAPS IN THE	
8339							:MAIN TEST, ALL *FURTHER* AC0-AC3 CHECKS WILL BE SKIPPED.	
8340	044410	172437	045232		LDF	STORE,AC0	:RESTORE AC0.	
8341	044414	173437	045232		CMPF	STORE,AC0	:SEE IF IT WAS RESTORED PROPERLY.	
8342	044420	170000			CFCC		:COPY FPP CONDITION CODES TO CPU CODES.	
8343	044422	001567			BEQ	7\$:BRANCH TO ERROR CALL IF OK.	
8344	044424	000476			BR	113\$:BRANCH TO ERROR SETUP ROUTINE.	
8345	044426	012737	000001	001236	101\$:	MOV	#1,\$TMP2	:PUT A '1' IN 'AC CHANGED' LOCATION.
8346	044434	012737	044500	001244		MOV	#102\$,TMP5	:MOVE RETURN TO TMP5.
8347	044442	173537	045242		CMPF	STORE+10,AC1	:SEE IF AC1 WAS CHANGED.	
8348	044446	170000			CFCC		:COPY FPP CONDITION CODES TO CPU CODES.	
8349	044450	001413			BEQ	102\$:BRANCH TO NEXT TEST IF OK.	
8350	044452	174137	045300		STF	AC1,STORE+46	:STORE ACTUAL AC1 FOR ERROR PRINTING.	
8351	044456	012700	045242		MOV	#STORE+10,RO	:MOVE ADDRESS OF EXPECTED AC1 TO RO.	
8352	044462	172537	045242		LDF	STORE+10,AC1	:RESTORE AC1.	
8353	044466	173537	045242		CMPF	STORE+10,AC1	:SEE IF IT WAS RESTORED PROPERLY.	
8354	044472	170000			CFCC		:COPY FPP CONDITION CODES TO CPU CODES.	
8355	044474	001542			BEQ	7\$:BRANCH TO NEXT TEST IF OK.	
8356	044476	000451			BR	113\$:BRANCH TO ERROR CALL IF OK.	
8357	044500	012737	000002	001236	102\$:	MOV	#2,\$TMP2	:BRANCH TO ERROR SETUP ROUTINE.
8358	044506	012737	044552	001244		MOV	#103\$,TMP5	:PUT A '2' IN 'AC CHANGED' LOCATION.
8359	044514	173637	045252		CMPF	STORE+20,AC2	:MOVE RETURN TO TMP5.	
8360	044520	170000			CFCC		:SEE IF AC2 WAS CHANGED.	
8361	044522	001413			BEQ	103\$:COPY FPP CONDITION CODES TO CPU CODES.	
8362	044524	174237	045300		STF	AC2,STORE+46	:BRANCH TO NEXT TEST IF OK.	
8363	044530	012700	045252		MOV	#STORE+20,RO	:STORE ACTUAL AC2 FOR ERROR PRINTING.	
8364	044534	172637	045252		LDF	STORE+20,AC2	:MOVE ADDRESS OF EXPECTED AC2 TO RO.	
8365	044540	173637	045252		CMPF	STORE+20,AC2	:RESTORE AC2.	
8366	044544	170000			CFCC		:SEE IF IT WAS RESTORED PROPERLY.	
8367	044546	001515			BEQ	7\$:COPY FPP CONDITION CODES TO CPU CODES.	
8368	044550	000424			BR	113\$:BRANCH TO ERROR CALL IF OK.	
8369	044552	012737	000003	001236	103\$:	MOV	#3,\$TMP2	:BRANCH TO ERROR SETUP ROUTINE.
8370	044560	012737	044632	001244		MOV	#100\$,TMP5	:PUT A '3' IN 'AC CHANGED' LOCATION.
8371	044566	173737	045262		CMPF	STORE+30,AC3	:MOVE RETURN TO TMP5.	
8372	044572	170000			CFCC		:SEE IF AC3 WAS CHANGED.	
8373	044574	001416			BEQ	100\$:COPY FPP CONDITION CODES TO CPU CODES.	
8374	044576	174337	045300		STF	AC3,STORE+46	:BRANCH TO NEXT TEST IF OK.	
8375	044602	012700	045262		MOV	#STORE+30,RO	:STORE ACTUAL AC3 FOR ERROR PRINTING.	
8376	044606	172737	045262		LDF	STORE+30,AC3	:MOVE ADDRESS OF EXPECTED AC3 TO RO.	
8377	044612	173737	045262		CMPF	STORE+30,AC3	:RESTORE AC3.	
8378	044616	170000			CFCC		:SEE IF IT WAS RESTORED PROPERLY.	
8379	044620	001470			BEQ	7\$:COPY FPP CONDITION CODES TO CPU CODES.	
8380	044622	012737	000770	001272	113\$:	MOV	#770,\$TMP20	:BRANCH TO ERROR CALL IF OK.
							:MOVE 370 FOR AC LOAD FAILURE, & SET BIT 8 OF ERROR POINTER.	

8381	044630	000464				BR	7\$:BRANCH TO ERROR CALL.
8382	044632	005037	001236			CLR	\$TMP2	:CLEAR 'REGISTER CHANGED' LOCATION.
8383	044636	112737	000367	001272	100\$:	MOV	#367,\$TMP20	:MOVE 367, GENERAL REGISTER CHANGED ERROR, TO POINTER.
8384	044644	012737	044700	001244		MOV	#120\$,TMP5	:MOVE RETURN TO TMP5.
8385	044652	023700	045272			CMP	STORE+40,R0	:SEE IF R0 WAS CHANGED.
8386	044656	001410				BEQ	120\$:BRANCH TO NEXT TEST IF OK.
8387	044660	010037	001246			MOV	R0,\$TMP6	:MOVE ACTUAL R0 TO LOCATION FOR ERROR PRINTING.
8388	044664	013737	045272	001240		MOV	STORE+40,\$TMP3	:MOVE EXPECTED TO LOCATION FOR ERROR PRINTING.
8389	044672	013700	045272			MOV	STORE+40,R0	:RESTORE R0.
8390	044676	000441				BR	7\$:BRANCH TO ERROR CALL.
8391	044700	012737	000002	001236	120\$:	MOV	#2,\$TMP2	:PUT A '2' IN 'REGISTER CHANGED' LOCATION.
8392	044706	012737	044742	001244		MOV	#130\$,TMP5	:MOVE RETURN TO TMP5.
8393	044714	025702	045274			CMP	STORE+42,R2	:SEE IF R2 WAS CHANGED.
8394	044720	001410				BEQ	130\$:BRANCH TO NEXT TEST IF OK.
8395	044722	010237	001246			MOV	R2,\$TMP6	:MOVE ACTUAL R2 TO LOCATION FOR ERROR PRINTING.
8396	044726	013737	045274	001240		MOV	STORE+42,\$TMP3	:MOVE EXPECTED TO LOCATION FOR ERROR PRINTING.
8397	044734	013702	045274			MOV	STORE+42,R2	:RESTORE R2.
8398	044740	000420				BR	7\$:BRANCH TO ERROR CALL.
8399	044742	012737	000003	001260	130\$:	MOV	#3,\$TMP13	:PUT A '3' IN 'REGISTER CHANGED' LOCATION.
8400	044750	012737	045166	001244		MOV	#RETURN,\$TMP5	:MOVE RETURN TO TMP5.
8401	044756	023703	045276			CMP	STORE+44,R3	:SEE IF R3 WAS CHANGED.
8402	044762	001501				BEQ	RETURN	:BRANCH TO RETURN IF OK.
8403	044764	010337	001246			MOV	R3,\$TMP6	:MOVE ACTUAL R3 TO LOCATION FOR ERROR PRINTING.
8404	044770	013737	045276	001240		MOV	STORE+44,\$TMP3	:MOVE EXPECTED TO LOCATION FOR ERROR PRINTING.
8405	044776	013703	045276			MOV	STORE+44,R3	:RESTORE R3.
8406	045002	116537	177777	045374	7\$:	MOV	-1(R5),EXPCTD	:MOVE DATA FROM TABLE FOR POSSIBLE USE :DPM001
8407	045010	122737	000370	001272		CMPB	#370,\$TMP20	:TEST TO SEE IF AC INFO NEEDS TO BE STORED.
8408	045016	001404				BEQ	71\$:BRANCH TO INFO STORE ROUTINE IF SO.
8409	045020	122737	000366	001272		CMPB	#366,\$TMP20	:TEST TO SEE IF AC INFO NEEDS TO BE STORED.
8410	045026	001026				BNE	MULTER	:SKIP AC INFO ROUTINE IF NOT.
8411	045030	012037	001240		71\$:	MOV	(R0)+,\$TMP3	:MOVE 1ST WORD OF ACTUAL AC DATA TO TMP3.
8412	045034	012037	001242			MOV	(R0)+,\$TMP4	:MOVE 2ND WORD OF ACTUAL AC DATA TO TMP4.
8413	045040	012037	001246			MOV	(R0)+,\$TMP6	:MOVE 3RD WORD OF ACTUAL AC DATA TO TMP6.
8414	045044	012037	001250			MOV	(R0)+,\$TMP7	:MOVE 4TH WORD OF ACTUAL AC DATA TO TMP7.
8415	045050	013700	045310			MOV	STORE+56,R0	:RESTORE R0 TO WHAT IT HAD AT BEGINNING OF TRAP.
8416	045054	013737	045300	001252		MOV	STORE+46,\$TMP10	:MOVE 1ST WORD OF EXPECTED AC DATA TO TMP10.
8417	045062	013737	045302	001254		MOV	STORE+50,\$TMP11	:MOVE 2ND WORD OF EXPECTED AC DATA TO TMP11.
8418	045070	013737	045304	001256		MOV	STORE+52,\$TMP12	:MOVE 3RD WORD OF EXPECTED AC DATA TO TMP12.
8419	045076	013737	045306	001274		MOV	STORE+54,\$TMP21	:MOVE 4TH WORD OF EXPECTED AC DATA TO TMP21.
8420	045104	012637	001266			MOV	(SP)+,\$TMP16	:SAVE 1ST CONTENTS OF STACK AND POP IT ONCE.
8421	045110	012637	001270			MOV	(SP)+,\$TMP17	:SAVE 2ND CONTENTS OF STACK AND POP IT AGAIN.
8422	045114	142737	000377	045130		BICB	#377,74\$:CLEAR OUT LAST ERROR OFFSET FROM ERROR INSTRUCTION.
8423	045122	153737	001272	045130		BISB	\$TMP20,74\$:PUT ERROR NUMBER TO BE ACCOMPLISHED IN ERROR INSTRUCTION.
8424						:THIS	ERROR IS DEFINED BY THE CONTENTS OF THE LOWER BYTE OF LOCATION [1272]	
8425	045130	104000			74\$:	ERROR	+0	
8426	045132	013746	001270			MOV	\$TMP17,-(SP)	:PUSH 2ND CONTENTS BACK ON THE STACK.
8427	045136	013746	001266			MOV	\$TMP16,-(SP)	:PUSH 1ST CONTENTS BACK ON THE STACK.
8428	045142	022737	000364	001272		CMP	#364,\$TMP20	:SEE IF RETURN ROUTINE IS TO BE SKIPPED.
8429	045150	001417				BEQ	RTI	:BRANCH TO RTI IF SO.
8430	045152	022737	000365	001272		CMP	#365,\$TMP20	:SEE IF RETURN ROUTINE IS TO BE SKIPPED.
8431	045160	001413				BEQ	RTI	:BRANCH TO RTI IF SO.
8432	045162	000177	134056			JMP	@TMP5	:JUMP TO CONTINUE CHECKING.
8433	045166	022776	000004	000000	RETURN:	CMP	#4,@0(SP)	:SEE IF INSTRUCTION IS THE IOT.
8434	045174	001403				BEQ	9\$:BRANCH IF THE IOT HAS BEEN FOUND.
8435	045176	062716	000002			ADD	#2,(SP)	:CORRECT PC RETURN.
8436	045202	000771				BR	RETURN	:BRANCH BACK FOR ANOTHER TRY.
8437	045204	062716	000002		9\$:	ADD	#2,(SP)	:CORRECT PC RETURN TO POINT AFTER IOT FOUND.

8469
8470 045420
8471
8472

8474

.SBTTL END OF PASS ROUTINE

```

;***** INCREMENT THE PASS NUMBER ($PASS)
;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;*IF SW12=1 INHIBIT TRACE TRAP
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO LOOP
$EOP:

045420 000004          SCOPE
045422 005037 001102    CLR   $STSTNM      ::ZERO THE TEST NUMBER
045426 005037 001302    CLR   $TIMES       ::ZERO THE NUMBER OF ITERATIONS
045432 005237 001324    INC   $PASS        ::INCREMENT THE PASS NUMBER
045436 100004            BPL   1000$        ::BRANCH IF STILL PLUS
045440 005037 001324    CLR   $PASS         ::CLEAR THE PASS COUNTER
045444 005237 046166    INC   $PASS2        ::INCREMENT OVERFLOW PASS COUNTER
045450 005327            DEC   (PC)+       ::LOOP?
045452 000001            $EOPCT: .WORD 1      ;NO
045454 003402            BLE   999$        ;:YES
045456 000137 046114    JMP   $DOAGN       ::RESTORE COUNTER
045462 012737            999$: MOV   (PC)+,a(PC)+ ;::RESTORE COUNTER
045464 000001            $SENDCT: .WORD 1      ;::RESTORE COUNTER
045466 045452            $EOPCT
045470 005737 001112    TST   SERTTL       ::SEE IF ANY ERRORS THIS PASS
045474 001007            BNE   5000$        ::BRANCH IF SO TO PRINT THE EOP
045476 005737 046164    TST   EPENDS       ::SEE IF EOP MSGS ARE DISABLED
045502 001120            BNE   $GET42       ::BRANCH IF SO
045504 032737 000777 001324 5000$: BIT   #777,$PASS     ::PRINT EOP EVERY 1000TH PASS
045512 001114            BNE   $GET42       ::BRANCH IF NOT MULTIPLE OF 1000
045514
045514 104401 045522    TYPE  ,65$        ::TYPE ASCIZ STRING
045520 000407            BR   64$          ::GET OVER THE ASCIZ
045540 005737 046166    ::65$: .ASCIZ <12><15>/END PASS # /
045540 005737 046166    64$: TST   $PASS2       ::SEE IF OVERFLOW HAS NON-ZERO VALUE
045544 001440            BEQ   4900$        ::BRANCH IF ZERO
045546 013746 046166    MOV   $PASS2,-(SP)  ::SAVE $PASS2 FOR TYPEOUT
045552 104403            TYPOS
045554 006               .BYTE 6          ::TYPE 6 DIGITS
045555 000               .BYTE 0          ::SUPPRESS LEADING ZEROS
045556 005737 001324    TST   $PASS        ::SEE IF PASS COUNT IS ZERO
045562 001007            BNE   3000$        ::BRANCH IF NOT
045564 104401 045572    TYPE  ,67$        ::TYPE ASCIZ STRING
045570 000403            BR   66$          ::GET OVER THE ASCIZ
045600
045600 000426            ::67$: .ASCIZ :000000:
045602 012737 070000 001244 3000$: BR   4910$        ::GO TEST SERTTL
045610 033737 001244 001324 4000$: MOV   #70000,$TMP5  ::CHECK 5TH OCTAL DIGIT FIRST
045612 001013            BIT   $TMP5,$PASS   ::CHECK TO SEE IF OCTAL DIGIT IS ZERO
045616 104401 045626    TYPE  ,69$        ::BRANCH OUT IF ZERO
045620 000401            BR   68$          ::TYPE ASCIZ STRING
045624
045630 006237 001244    ::69$: .ASCIZ :01:
045630 006237 001244    68$:  . ASR   $TMP5      ::GET OVER THE ASCIZ
045634 006237 001244    . ASR   $TMP5      ::SHIFT THE THREE BITS RIGHT 3 PLACES

```

045640 006237 001244		ASR	\$TMP5	: ;BRANCH BACK TO CHECK SPASS	:DPM002
045644 000761		BR	4000\$:DPM002
045646					
045646 013746 001324	4900\$:	MOV	\$PASS,-(S?)	;:SAVE SPASS FOR TYPEOUT	
				;:TYPE PASS NUMBER IN OCTAL	
				;:GO TYPE--OCTAL ASCII	
045652 104403		TYPOS	6	;:TYPE 6 DIGITS	
045654 006		.BYTE	0	;:SUPPRESS LEADING ZEROS	
045655 000		.BYTE			
045656 005737 001112	4910\$:	TST	\$ERTTL	;:SEE IF ANY ERRORS THIS PASS	
045662 001426		BEQ	5001\$;:BRANCH AROUND REPORT IF NONE	:DPM002
045664 104401 045672		TYPE	71\$;:TYPE ASCIZ STRING	:DPM002
045670 000415		BR	70\$;:GET OVER THE ASCIZ	
		.ASC'Z	/ TOTAL ERRORS THIS PASS /		
045724					
045724 013746 001112	70\$:	MOV	\$ERTTL,-(SP)	;:SAVE SERTTL FOR TYPEOUT	
				;:TOTAL NUMBER OF ERRORS IN OCTAL	
045730 104403		TYPOS	6	;:GO TYPE--OCTAL ASCII	
045732 006		.BYTE	0	;:TYPE 6 DIGITS	
045733 000		.BYTE		;:SUPPRESS LEADING ZEROS	
045734 005037 001112	5001\$:	CLR	\$ERTTL	;:CLEAR ERROR TOTAL	
045740 104401 001313		TYPE	\$CRLF	;:TYPE CARRIAGE RETURN, LINE FEED	
045744 105777 133174	\$GET42:	TSTB	ASTKS	;:IS A CHARACTER WAITING?	
045750 100042		BPL	\$GT42C	;:BRANCH IF NOT	:DPM002
045752 013737 001146 001244		MOV	STKB,\$TMP5	;:WASTE THE CHARACTER, CLEARING READY	:DPM002
045760 005737 046164		TST	EPENDS	;:SEE WHICH STATE ENABLE/DISABLE IS IN	:DPM002
045764 001017		BNE	\$DISAB	;:BRANCH IF EOP'S DISABLED	:DPM002
045766 005237 046164		INC	EPENDS	;:SET FLAG DISABLING PRINTOUTS	:DPM002
045772 104401 046000		TYPE	65\$;:TYPE ASCIZ STRING	
045776 000411		BR	64\$;:GET OVER THE ASCIZ	
		.ASCIZ	<CRLF>!EOP'S DISABLED!<CRLF>		
046022					
046022 000415	64\$:	BR	\$GT42C	;:BRANCH OVER ENABLE ROUTINE	:DPM002
046024 005037 046164	\$DISAB:	CLR	EPENDS	;:CLEAR FLAG ENABLING PRINTOUTS	:DPM002
046030 104401 046036		TYPE	65\$;:TYPE ASCIZ STRING	
046034 000410		BR	64\$;:GET OVER THE ASCIZ	
		.ASCIZ	<CRLF>!EOP'S ENABLED!<CRLF>		
046056					
046056 013700 000042	64\$:	\$GT42C:	2#42,RO	;:GET MONITOR ADDRESS	
046062 001414		MOV	\$DOAGN	;:BRANCH IF NO MONITOR	
046064 005046		BEQ	- (SP)	;:INSURE THE 'T' BIT IS CLEAR	
046066 012746 046074		CLR		;:SETUP FOR AN RTI OR RTT	
046072 000426		MOV	#\$CLR.T,-(SP)	;:GO DO AN RTI OR RTT TO LOAD THE PSW	
		BR	\$RTRN	;:WITH A CLEARED 'T' BIT	
046074					
046074 013700 000042	\$CLR.T:	MOV	2#42,RO	;:INSURE RO CONTAINS THE MONITORS	
046100 001405		BEQ	\$DOAGN	;:RETURN ADDRESS	
046102 000005		RESET		;:CLEAR THE WORLD	
046104 004710	\$SENDAD:	JSR	PC,(RO)	;:GO TO MONITOR	
046106 000240		NOP		;:SAVE ROOM	
046110 000240		NOP		;:FOR	
046112 000240		NOP		;:ACT11	
046114					
046114 104400	\$DOAGN:	TRAP		;:PUSH OLD PSW AND PC ON STACK	
046116 042716 000020		BIC	#20,(SP)	;:CLEAR THE 'T' BIT	
046122 032777 010000 133010		BIT	#BIT12,ASWR	;:RUN WITH TRACE TRAP?	
046132 001005		BNE	1\$;:BR IF NO	
046132 005137 046156		COM	\$T@J	;:IS IT TIME FOR TRACE TRAP	

046136	100:02		BMI	1\$;;BR IF NO	
046140	052716	000020	BIS	#20,(SP)	;;SET TRACE TRAP	
046144	012746	046152	1\$: MOV	#\$LOOP,-(SP)	;;JUMP TO START OF TEST	
046150	000002		\$RTRN:	RTI	;;RETURN--THIS IS CHANGED TO ;;AN 'RTT' IF 'RTT' IS A LEGAL ;;INSTRUCTION	
046152			\$LOOP:			
046152	000137		JMP	a(PC)+	;;RETURN	
046154	006764		SRTNAD:	.WORD	LOOP	
046156	000000		\$TBIT:	.WORD	0	
046160	377	377	000	SENULL: .BYTE	-1,-1,0	;;'T' BIT STATE INDICATOR ;;NULL CHARACTER STRING
046164	000000		EPENDS: .WORD	0	LOCATION FOR EOP PRINT FLAG	
046166	000000		\$PASS2: .WORD	0	LOCATION FOR PASS COUNT OVERFLOW :DPM002 ;DPM002	

8476

.SBTTL SCOPE HANDLER ROUTINE

```
*****  
;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
;*AND LOAD THE TEST NUMBER($STSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)  
;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>  
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
;*SW14=1      LOOP ON TEST  
;*SW11=1      INHIBIT ITERATIONS  
;*SW09=1      LOOP ON ERROR  
;*SW08=1      LOOP ON TEST IN SWR<7:0>  
;*CALL        SCOPE          ;;SCOPE=IOT
```

046170				SSCOPE:	
046170	104406			CKSWR	;;TEST FOR CHANGE IN SOFT-SWR
046172	032777	040000	132740	1\$: BIT	;;LOOP ON PRESENT TEST?
046200	001134			BNE \$OVER	;;YES IF SW14=1
046202	000416			:#####START OF CODE FOR THE XOR TESTER#####	
046204	013746	000004		\$XTSTR: BR	6\$: ;;;IF RUNNING ON THE "XOR" TESTER CHANGE
046210	012737	046230	000004	MOV #5\$,ERRVEC	;;THIS INSTRUCTION TO A "NOP" (NOP=240)
046216	005737	177060		TST 177060	;;SAVE THE CONTENTS OF THE ERROR VECTOR
046222	012637	000004		MOV (SP)+,ERRVEC	;;SET FOR TIMEOUT
046226	000503			BR \$SVLAD	;;RESTORE THE ERROR VECTOR
046230	022626			CMP (SP)+,(SP)+	;;GO TO THE NEXT TEST
046232	012637	000004		MOV (SP)+,ERRVEC	;;CLEAR THE STACK AFTER A TIME OUT
046236	000443			BR 7\$;;RESTORE THE ERROR VECTOR
046240				:#####END OF CODE FOR THE XOR TESTER#####	;;LOOP ON THE PRESENT TEST
046240	032777	000400	132672	BIT #BIT08,@SWR	;;LOOP ON SPEC. TEST?
046246	001404			BEQ 2\$;;BR IF NO
046250	127737	132664	001102	CMPB @SWR,\$STSTNM	;;ON THE RIGHT TEST? SWR<7:0>
046256	001505			BEQ \$OVER	;;BR IF YES
046260	013737	177766	046506	2\$: MOV 177766,CPSAVE	MOVE CPU ERR REG VALUE TO LOC FOR TST ;DPM001
046266	032737	000001	046506	BIT #BIT00,CPSAVE	SEE IF THE POWER MONITOR BIT IS ON ;DPM001
046274	001411			BEQ 2000\$	BRANCH TO CONTINUE ROUTINE IF CLEAR ;DPM001
046276	042737	000001	177766	BIC #BIT00,177766	CLEAR THE BIT FOUND TO BE SET ;DPM001
046304	012737	177777	001320	MOV #-1,\$FATAL	MOVE -1 TO \$FATAL INDICATING PWR MON ER ;DPM001
046312	104177			ERROR +177	CALL SPECIAL POWER FAIL BIT ERROR CALL ;DPM001
046314	105037	001103		CLRB SERFLG	CLEAR ERROR FLAG FOR CHECK BELOW ;DPM001
046320	105737	001103		2000\$: TSTB SERFLG	;;HAS AN ERROR OCCURRED?
046324	001421			BEQ 3\$;;BR IF NO
046326	123737	001115	001103	CMPB SERMAX,SERFLG	;;MAX. ERRORS FOR THIS TEST OCCURRED?
046334	101015			BHI 3\$;;BR IF NO
046336	032777	001000	132574	BIT #BIT09,@SWR	;;LOOP ON ERROR?
046344	001404			BEQ 4\$;;BR IF NO
046346	013737	001110	001106	7\$: MOV \$LPERR,\$LPADR	;;SET LOOP ADDRESS TO LAST SCOPE
046354	000446			BR \$OVER	
046356	105037	001103		CLRB SERFLG	;;ZERO THE ERROR FLAG
046362	005037	001302		CLR \$TIMES	;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
046366	000415			BR 1\$;;ESCAPE TO THE NEXT TEST
046370	032777	004000	132542	3\$: BIT #BIT11,@SWR	;;INHIBIT ITERATIONS?
046376	001011			BNE 1\$;;BR IF YES
046400	005737	001324		TST \$PASS	;;IF FIRST PASS OF PROGRAM
046404	001406			BEQ 1\$;;INHIBIT ITERATIONS
046406	005237	001104		INC \$ICNT	;;INCREMENT ITERATION COUNT

SCOPE HANDLER ROUTINE

046412	023737	001302	001104	CMP	\$TIMES,\$ICNT	;:CHECK THE NUMBER OF ITERATIONS MADE
046420	002024			BGE	\$OVER	;:BR IF MORE ITERATION REQUIRED
046422	012737	000001	001104	1\$:	MOV #1,\$ICNT	;:REINITIALIZE THE ITERATION COUNTER
046430	013737	046510	001302	SSVLAD:	MOV \$MXCNT,\$TIMES	;:SET NUMBER OF ITERATIONS TO DO
046436	105237	001102		INC8	\$TSTNM	;:COUNT TEST NUMBERS
046442	113737	001102	001322	MOVB	\$TSTNM,\$TESTN	;:SET TEST NUMBER IN APT MAILBOX
046450	011637	001106		MOV	(SP),\$LPADR	;:SAVE SCOPE LOOP ADDRESS
046454	011637	001110		MOV	(SP),\$LPERR	;:SAVE ERROR LOOP ADDRESS
046460	005037	001304		CLR	\$ESCAPE	;:CLEAR THE ESCAPE FROM ERROR ADDRESS
046464	112737	000001	001115	MOV	#1,\$ERMAX	;:ONLY ALLOW ONE(1) ERROR ON NEXT TEST
046472	013777	001102	132442	\$OVER:	MOV \$TSTNM,@DISPLAY	;:DISPLAY TEST NUMBER
046500	013716	001106		MOV	SLPADR,(SP)	;:FUDGE RETURN ADDRESS
046504	000002			RTI		;:FIXES PS
046506	000000			CPSAVE:	WORD 0	;:LOCATION TO SAVE CPU ERR REG CONTENTS :DPM001
046510	000001			SMXCNT:	i	;:MAX. NUMBER OF ITERATIONS

8478

.SBTTL ERROR HANDLER ROUTINE

```

;*****THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;*AND GO TO ERTYPE ON ERROR
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW15=1      HALT ON ERROR
;*SW13=1      INHIBIT ERROR TYPEOUTS
;*SW10=1      BELL ON ERROR
;*SW09=1      LOOP ON ERROR
;*CALL        ;*   ERROR N    ;;ERROR=EMT AND N=ERROR ITEM NUMBER

046512 000000           IBSAVE: .WORD 0          ;LOC'N TO HOLD SERRPC DURING DUAL ERR :DPM001
046514
046514 104406           $ERROR: CKSWR          ;TEST FOR CHANGE IN SOFT-SWR
046516 105237 001103       7$: INCB SERFLG        ;SET THE ERROR FLAG
046522 001775             BEQ 7$              ;DON'T LET THE FLAG GO TO ZERO
046524 013777 001102 132410     MOV STSTNM,@DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
046532 032777 002000 132400     BIT #BIT10,@SWR   ;BELL ON ERROR?
046540 001402             BEQ 1$              ;NO - SKIP
046542 104401 001306           TYPE,$BELL        ;RING BELL
046546 005237 001112           1$: INC $ERTTL       ;COUNT THE NUMBER OF ERRORS
046552 011637 001116           MOV (SP),SERRPC   ;GET ADDRESS OF ERROR INSTRUCTION
046556 162737 000002 001116     SUB #2,SERRPC
046564 117737 132326 001114     MOVB @SERRPC,$ITEMB ;STRIP AND SAVE THE ERROR ITEM CODE
046572 122737 000177 001114     CMPB #177,$ITEMB  ;SEE IF PWR MON ERROR CALL
046600 001421             BEQ 1000$          ;BRANCH IF SO TO CALL THE ERROR :DPM001
046602 013737 177766 046506     MOV 177766,CPSAVE ;MOVE CPU ERR REG TO CPSAVE FOR TEST :DPM001
046610 032737 000001 046506     BIT #BIT00,CPSAVE ;SEE IF POWER MONITOR BIT IS SET :DPM001
046616 001412             BEQ 1000$          ;BRANCH IF OK :DPM001
046620 042737 000001 177766     BIC #BIT00,177766 ;CLEAR THE BIT FOUND SET :DPM001
046626 013737 001116 046512     MOV SERRPC,IBSAVE  ;SAVE SERROR :DPM001
046634 104177             ERROR +177         ;CALL POWER MONITOR BIT ERROR :DPM001
046636 013737 046512 001116     MOV IBSAVE,SERRPC ;RESTORE $ERROR :DPM001
046644
046644 032777 020000 132266     1000$: BIT #BIT13,@SWR   ;SKIP TYPEOUT IF SET
046652 001004             BNE 20$              ;SKIP TYPEOUTS
046654 004737 051152           JSR PC,ERTYPE      ;GO TO USER ERROR ROUTINE
046660 104401 001313           TYPE,$CRLF
046664
046664 122737 000001 001336     20$: CMPB #APTENV,$ENV ;RUNNING IN APT MODE
046672 001023             BNE 21$              ;NO, SKIP APT ERROR REPORT
046674 005037 046736           CLR 21$            ;CLEAR ANY PREVIOUS NUMBER FROM 21$ :DPM001
046700 113737 001114 046736     MOVB $ITEMB,21$   ;SET ITEM NUMBER AS ERROR NUMBER
046706 122737 000377 001114     CMPB #377,$ITEMB ;SEE IF ITEM # IS OVER 400 :DPM001
046714 001006             BNE 900$          ;BRANCH IF NOT :DPM001
046716 012737 000400 046736     MOV #400,21$    ;MOVE BASE OF 400 TO 21$ :DPM001
046724 067737 132166 046736     ADD @SERRPC,21$  ;ADD NUMBER OVER 400 TO 21$ :DPM001
046732 004737 050006           900$: JSR PC,$ATY4   ;REPORT FATAL ERROR TO APT
046736 000               21$: .BYTE 0
046737 000               .BYTE 0
046740 000777             22$: BR 22$            ;APT ERROR LOOP
046742 005737 046512           2$: TST IBSAVE    ;SEE IF POWER FAIL ERROR CALL :DPM001
046746 001005             BNE 3$              ;BRANCH IF NOT - HALT NOT ALLOWED :DPM001
046750 005777 132164           TST @SWR          ;HALT ON ERROR

```

ERROR HANDLER ROUTINE

046754	100002		BPL	3\$;; SKIP IF CONTINUE
046756	000000		HALT		;; HALT ON ERROR!
046760	104406		CKSWR		;; TEST FOR CHANGE IN SOFT-SWR
046762	032777	001000 132150	3\$: BIT	#BIT09,@SWR	;; LOOP ON ERROR SWITCH SET?
046770	001405		BEQ	4\$;; BR IF NO
046772	005737	046512	TST	IBSAVE	;; SEE IF ERROR IS PWR MONITOR BIT ERROR :DPM001
046776	001002		BNE	4\$;; BRANCH IF SO - DON'T FUDGE RETURN :DPM001
047000	013716	001110	MOV	SLPERR,(SP)	;; FUDGE RETURN FOR LOOPING
047004	005737	001304	TST	SESCAPE	;; CHECK FOR AN ESCAPE ADDRESS
047010	001405		BEQ	5\$;; BR IF NONE
047012	005737	046512	TST	IBSAVE	;; SEE IF ERROR IS PWR MONITOR BIT ERROR :DPM001
047016	001002		BNE	5\$;; BRANCH IF SO - DON'T FUDGE RETURN :DPM001
047020	013716	001304	MOV	SESCAPE,(SP)	;; FUDGE RETURN ADDRESS FOR ESCAPE
047024	022737	046104 000042	CMP	#SENDAD,42	;; ACT-11 AUTO-ACCEPT?
047032	001001		BNE	6\$;; BRANCH IF NO
047034	000000		HALT		;; YES
047036	032777	001000 132074	6\$: BIT	#BIT09,@SWR	
047044	001013		BNE	ERM10	
047046	011637	001162	MOV	(SP),\$REG0	;; SEE IF ERROR #377
047052	062737	177776 001162	ADD	#-2,\$REG0	
047060	122777	000377 132074	CMPB	#377,@REG0	
047066	001002		BNE	ERM10	
047070	062716	000002	ADD	#2,(SP)	
047074	000002		ERM10:	RTI	

8480

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

;*****

;*SAVE R0-R5

;*CALL:

;* SAVREG

;*UPON RETURN FROM \$SAVREG THE STACK WILL LOOK LIKE:

*

;*TOP---(+16)

;* +2---(+18)

;* +4---R5

;* +6---R4

;* +8---R3

;*+10---R2

;*+12---R1

;*+14---R0

\$SAVREG:

047076	010046	MOV	R0,-(SP)	;: PUSH R0 ON STACK
047100	010146	MOV	R1,-(SP)	;: PUSH R1 ON STACK
047102	010246	MOV	R2,-(SP)	;: PUSH R2 ON STACK
047104	010346	MOV	R3,-(SP)	;: PUSH R3 ON STACK
047106	010446	MOV	R4,-(SP)	;: PUSH R4 ON STACK
047110	010546	MOV	R5,-(SP)	;: PUSH R5 ON STACK
047112	016646	MOV	22(SP),-(SP)	;: SAVE PS OF MAIN FLOW
047116	016646	MOV	22(SP),-(SP)	;: SAVE PC OF MAIN FLOW
047122	016646	MOV	22(SP),-(SP)	;: SAVE PS OF CALL
047126	016646	MOV	22(SP),-(SP)	;: SAVE PC OF CALL
047132	000002	RTI		

;*:RESTORE R0-R5

;*CALL:

;* RESREG

\$RESREG:

047134	012666	000022	MOV	(SP)+,22(SP)	;: RESTORE PC OF CALL
047140	012666	000022	MOV	(SP)+,22(SP)	;: RESTORE PS OF CALL
047144	012666	000022	MOV	(SP)+,22(SP)	;: RESTORE PC OF MAIN FLOW
047150	012666	000022	MOV	(SP)+,22(SP)	;: RESTORE PS OF MAIN FLOW
047154	012605		MOV	(SP)+,R5	;: POP STACK INTO R5
047156	012604		MOV	(SP)+,R4	;: POP STACK INTO R4
047160	012603		MOV	(SP)+,R3	;: POP STACK INTO R3
047162	012602		MOV	(SP)+,R2	;: POP STACK INTO R2
047164	012601		MOV	(SP)+,R1	;: POP STACK INTO R1
047166	012600		MOV	(SP)+,R0	;: POP STACK INTO R0
047170	000002		RTI		

TYPE ROUTINE

8482

.SBTTL TYPE ROUTINE

 :*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 :*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 :*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 :*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 :*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

:
 :*CALL::*) USING A TRAP INSTRUCTION
 :* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING:OR
 :* TYPE
 :* MESADR

047172	000000		EOASCII: .WORD 0	;LOC TO HOLD ADRS OF TERMINATOR BYTE ;DPM001
047174	105737	001157	\$TYPE: TSTB \$TPFLG	;IS THERE A TERMINAL?
047200	100002		BPL 1\$;;BR IF YES
047202	000000		HALT	;;HALT HERE IF NO TERMINAL
047204	000432		BR 3\$;;LEAVE
047206	010046		MOV R0,-(SP)	;;SAVE R0
047210	017600	000002	MOV @2(SP),R0	;;GET ADDRESS OF ASCIZ STRING
047214	122737	000001	CMPB #APTEV,\$ENV	;;RUNNING IN APT MODE
047222	001011		BNE 62\$;;NO, GO CHECK FOR APT CONSOLE
047224	132737	000100	BITB #APTSPOOL,\$ENVVM	;;SPOOL MESSAGE TO APT
047232	001405		BEQ 62\$;;NO, GO CHECK FOR CONSOLE
047234	010037	047244	MOV R0,61\$;;SETUP MESSAGE ADDRESS FOR APT
047240	004737	047776	JSR PC,\$ATY3	;;SPOOL MESSAGE TO APT
047244	000000		.WORD 0	;;MESSAGE ADDRESS
047246	132737	000040	61\$: BITB #APTCSUP,\$ENVVM	;;APT CONSOLE SUPPRESSED
047254	001005		BNE 60\$;;YES, SKIP TYPE OUT
047256	112046		2\$: MOVB (R0)+,-(SP)	;;PUSH CHARACTER TO BE TYPED ONTO STACK
047260	001007		BNE 4\$;;BR IF IT ISN'T THE TERMINATOR
047262	005726		TST (SP)+	;;IF TERMINATOR POP IT OFF THE STACK
047264	010037	047172	MOV R0,EOASCII	;;SAVE ADRS OF TERMINATOR - POSSIBLY USED;DPM001
047270	012600		MOV (SP)+,R0	;;RESTORE R0
047272	062716	000002	ADD #2,(SP)	;;ADJUST RETURN PC
047276	000002		RTI	;;RETURN
047300	122716	000011	CMPB #HT,(SP)	;;BRANCH IF <HT>
047304	001430		BEQ 8\$	
047306	122716	000200	CMPB #CRLF,(SP)	;;BRANCH IF NOT <CRLF>
047312	001006		BNE 5\$	
047314	005726		TST (SP)+	;;POP <CR><LF> EQUIV
047316	104401		TYPE	;;TYPE A CR AND LF
047320	001313		\$CRLF	
047322	105037	047530	CLRB \$CHARCNT	;;CLEAR CHARACTER COUNT
047326	000753		BR 2\$;;GET NEXT CHARACTER
047330	004737	047412	5\$: JSR PC,\$TYPEC	;;GO TYPE THIS CHARACTER
047334	123726	001156	6\$: CMPB \$FILLC,(SP)+	;;IS IT TIME FOR FILLER CHARS.?
047340	001346		BNE 2\$;;IF NO GO GET NEXT CHAR.
047342	013746	001154	MOV \$NULL,-(SP)	;;GET # OF FILLER CHARS. NEEDED ;;AND THE NULL CHAR.
047346	105366	000001	7\$: DECB 1(SP)	;;DOES A NULL NEED TO BE TYPED?
047352	002770		BLT 6\$;;BR IF NO--GO POP THE NULL OFF OF STACK
047354	004737	047412	JSR PC,\$TYPEC	;;GO TYPE A NULL
047360	105337	047530	DECB \$CHARCNT	;;DO NOT COUNT AS A COUNT

047364	000770		BR	7\$;;LOOP	
;HORIZONTAL TAB PROCESSOR						
047366	112716	000040	8\$: 047372	MOV _B #',(SP)	;;REPLACE TAB WITH SPACE	
	004737	047412	JSR \$TYPEC	;TYPE A SPACE		
047376	132737	000007	04730	BITB #7,\$CHARCNT	;;BRANCH IF NOT AT	
047404	001372			BNE 9\$;;TAB STOP	
047406	005726			TST (SP)+	;;POP SPACE OFF STACK	
047410	000722			BR 2\$;;GET NEXT CHARACTER	
047412						
047412	105777	131526		\$TYPEC: TSTB a\$TKS	;;CHAR IN KYBD BUFFER?	:MJD001
047416	100022			BPL 10\$;;BR IF NOT	:MJD001
047420	017746	131522		MOV a\$TKB,-(SP)	;;GET CHAR	:MJD001
047424	042716	177600		BIC #177600,(SP)	;;STRIP EXTRANEous BITS	:MJD001
047430	122716	000023		CMPB #\$XOFF,(SP)	;;WAS CHAR XOFF	:MJD001
047434	001012			BNE 102\$;;BR IF NOT	:MJD001
047436	105777	131502			;;WAIT FOR CHAR	:MJD001
047442	100375					:MJD001
047444	117716	131476			;;GET CHAR	:MJD001
047450	042716	177600			;;STRIP IT	:MJD001
047454	122716	000021			;;WAS IT XON?	:MJD001
047460	001366				;;BR IF NOT	:MJD001
047462	005726				;;FIX STACK	:MJD001
047464	105777	131460				:MJD001
047470	100375				;;WAIT UNTIL PRINTER IS READY	
047472	116677	000002	131452			:MJD001
047500	122766	000015	000002		;;LOAD CHAR TO BE TYPED INTO DATA REG.	
047506	001003				;;IS CHARACTER A CARRIAGE RETURN?	
047510	105037	047530			;;BRANCH IF NO	
047514	000406				;;YES--CLEAR CHARACTER COUNT	
047516	122766	000012	000002	1\$: CMPB #LF,2(SP)	;;EXIT	
047524	001402			BEQ \$TYPEX	;;IS CHARACTER A LINE FEED?	
047526	105227			INC _B (PC)+	;;BRANCH IF YES	
047530	000000				;;COUNT THE CHARACTER	
047532	000207				;;CHARACTER COUNT STORAGE	
				\$CHARCNT:.WORD 0		
				\$TYPEX: RTS PC		

8484

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```
*****  
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT  
*OCTAL (ASCII) NUMBER AND TYPE IT.  
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE  
*CALL:  
*      MOV    NUM,-(SP)      ;:NUMBER TO BE TYPED  
*      TYPOS  N             ;:CALL FOR TYPEOUT  
*      .BYTE   N             ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE  
*      .BYTE   M             ;:M=1 OR 0  
*                                ;:1=TYPE LEADING ZEROS  
*                                ;:0=SUPPRESS LEADING ZEROS  
*  
*STYPOS---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST  
*STYPOS OR $TYPOC  
*CALL:  
*      MOV    NUM,-(SP)      ;:NUMBER TO BE TYPED  
*      TYPOS  N             ;:CALL FOR TYPEOUT  
*  
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER  
*CALL:  
*      MOV    NUM,-(SP)      ;:NUMBER TO BE TYPED  
*      TYPOC  N             ;:CALL FOR TYPEOUT  
  
047534 017646 000000 047765 STYPOS: MOV  a(SP),-(SP)      ;:PICKUP THE MODE  
047540 116637 000001 047765 MOVB 1(SP),$0FILL      ;:LOAD ZERO FILL SWITCH  
047546 112637 047767 MOVB (SP)+,$0MODE+1      ;:NUMBER OF DIGITS TO TYPE  
047552 062716 000002 ADD  #2,(SP)      ;:ADJUST RETURN ADDRESS  
047556 000406 BR   STYPOS  
047560 112737 000001 047765 STYPOC: MOVB  #1,$0FILL      ;:SET THE ZERO FILL SWITCH  
047566 112737 000006 047767 MOVB  #6,$0MODE+1      ;:SET FOR SIX(6) DIGITS  
047574 112737 000005 047764 STYPON: MOVB  #5,$0CNT      ;:SET THE ITERATION COUNT  
047602 010346 MOV  R3,-(SP)      ;:SAVE R3  
047604 010446 MOV  R4,-(SP)      ;:SAVE R4  
047606 010546 MOV  R5,-(SP)      ;:SAVE R5  
047610 113704 047767 MOVB  $0MODE+1,R4      ;:GET THE NUMBER OF DIGITS TO TYPE  
047614 005404 NEG  R4  
047616 062704 000C06 ADD  #6,R4      ;:SUBTRACT IT FOR MAX. ALLOWED  
047622 110437 047766 MOVB  R4,$0MODE      ;:SAVE IT FOR USE  
047626 113704 047765 MOVB  $0FILL,R4      ;:GET THE ZERO FILL SWITCH  
047632 016605 000012 MOV  12(SP),R5      ;:PICKUP THE INPUT NUMBER  
047636 005003 CLR  R3  
047640 006105 1$: ROL  R5      ;:CLEAR THE OUTPUT WORD  
047642 000404 BR   3$      ;:ROTATE MSB INTO 'C'  
047644 006105 2$: ROL  R5      ;:GO DO MSB  
047646 006105 ROL  R5      ;:FORM THIS DIGIT  
047650 006105  
047652 010503  
047654 006103 3$: MOV  R5,R3      ;:GET LSB OF THIS DIGIT  
047656 105337 047766 DEC8  $0MODE      ;:TYPE THIS DIGIT?  
047662 100021 BPL  7$      ;:BR IF NO  
047664 042703 177770 BIC  #177770,R3      ;:GET RID OF JUNK  
047670 001002 BNE  4$      ;:TEST FOR 0  
047672 005704 TST  R4      ;:SUPPRESS THIS 0?  
047674 001403 BEQ  5$      ;:BR IF YES  
047676 005204 4$: INC  R4      ;:DON'T SUPPRESS ANYMORE 0'S
```

047700	052703	000060		BIS	#'0,R3	;MAKE THIS DIGIT ASCII	
047704	052703	000040		BIS	#' ,R3	;MAKE ASCII IF NOT ALREADY	
047710	122703	000040		CMPB	#' ,R3	;IS THIS A SPACE CHARACTER?	
047714	001404			BEQ	7\$;BRANCH IF SO - DON'T TYPE	:DPM002
047716	110337	047762		MOVB	R3,8\$;SAVE FOR TYPING	:DPM002
047722	104401	047762		TYPE	,8\$;GO TYPE THIS DIGIT	
047726	105337	047764		DEC8	\$OCNT	;COUNT BY 1	
047732	003344			BGT	2\$;BR IF MORE TO DO	
047734	002402			BLT	6\$;BR IF DONE	
047736	005204			INC	R4	;INSURE LAST DIGIT ISN'T A BLANK	
047740	000741			BR	2\$;GO DO THE LAST DIGIT	
047742	012605			MOV	(SP)+,R5	;RESTORE R5	
047744	012604			MOV	(SP)+,R4	;RESTORE R4	
047746	012603			MOV	(SP)+,R3	;RESTORE R3	
047750	016666	000002 000004		MOV	2(SP),4(SP)	;SET THE STACK FOR RETURNING	
047756	012616			MOV	(SP)+,(SP)		
047760	000002			RTI		;RETURN	
047762	000			8\$: .BYTE	0	;STORAGE FOR ASCII DIGIT	
047763	000			.BYTE	0	;TERMINATOR FOR TYPE ROUTINE	
047764	000			\$OCNT: .BYTE	0	;OCTAL DIGIT COUNTER	
047765	000			\$OFILL: .BYTE	0	;ZERO FILL SWITCH	
047766	000000			\$OMODE: .WORD	0	;NUMBER OF DIGITS TO TYPE	

8486

.SBTTL APT COMMUNICATIONS ROUTINE

```

047770 112737 000001 050234 $ATY1: MOVB #1,$FFLG      ;:TO REPORT FATAL ERROR
047776 112737 000001 050232 $ATY3: MOVB #1,$MFLG      ;:TO TYPE A MESSAGE
050004 000403          BR $ATYC
050006 112737 000001 050234 $ATY4: MOVB #1,$FFLG      ;:TO ONLY REPORT FATAL ERROR
050014          $ATYC:
050014 010046          MOV R0,-(SP)
050016 010146          MOV R1,-(SP)
050020 105737 050232 TSTB $MFLG
050024 001450          BEQ $S
050026 122737 000001 001336 CMPB #APTEVN,$ENV
050034 001031          BNE 3$ 
050036 132737 000100 001337 BITB #APTSPOOL,$ENVVM
050044 001425          BEQ 3$ 
050046 017600 000004          MOV @4(SP),R0
050052 062766 000002 000004 1$: ADD #2,4(SP)
050060 005737 001316          TST $MSGTYPE
050064 001375          BNE 1$ 
050066 016037 001332          MOV R0,$MSGAD
050072 105720          TSTB (R0)+ 
050074 001376          BNE 2$ 
050076 163700 001332          SUB $MSGAD,R0
050102 006200          ASR R0
050104 010037 001334          MOV R0,$MSGLGT
050110 012737 000004 001316          MOV #4,$MSGTYPE
050116 000413          BR $S
050120 017637 000004 050144 3$: MOV @4(SP),4$ 
050126 062766 000002 000004          ADD #2,4(SP)
050134 013746 177776          MOV 177776,-(SP)
050140 004737 047174          JSR PC,$TYPE
050144 000000          .WORD 0
050146 105737 050234          4$: 
050146          5$: 
050146 001416          10$: TSTB $FFLG
050152 001416          BEQ 12$ 
050154 005737 001336          TST $ENV
050160 001413          BEQ 12$ 
050162 005737 001316          TST $MSGTYPE
050166 001375          BNE 11$ 
050170 017637 000004 001320          MOV @4(SP),$FATAL
050176 062766 000002 000004          ADD #2,4(SP)
050204 005237 001316          INC $MSGTYPE
050210 105037 050234          12$: CLR B $FFLG
050214 105037 050233          CLR B $LFLG
050220 105037 050232          CLR B $MFLG
050224 012601          MOV (SP)+,R1
050226 012600          MOV (SP)+,R0
050230 000207          RTS PC
050232 000          $MFLG: .BYTE 0
050233 000          $LFLG: .BYTE 0
050234 000          $FFLG: .BYTE 0
                           EVEN
000200          APTSIZE=200
000001          APTEVN=001
000100          APTSPPOOL=100
000040          APTCSUP=040

```

TTY INPUT ROUTINE

8488

.SBTTL TTY INPUT ROUTINE
 .ENABL LSB
 .:*****
 .:SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
 .:ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
 .:SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
 .:WHEN OPERATING IN TTY FLAG MODE.

050236	022737	000176	001140	\$CKSWR:	CMP #SWREG,SWR	;;IS THE SOFT-SWR SELECTED?
050244	001074				BNE 15\$;;BRANCH IF NO
050246	105777	130672			TSTB @\$TKS	;;CHAR THERE?
050252	100071				BPL 15\$;;IF NO, DON'T WAIT AROUND
050254	117746	130666			MOV# \$TKB,-(SP)	;;SAVE THE CHAR
050260	042716	177600			BIC #^C177,(SP)	;;STRIP-OFF THE ASCII
050264	022726	000007			CMP #7,(SP)+	;;IS IT A CONTROL G?
050270	001062				BNE 15\$;;NO, RETURN TO USER
050272	123727	001134	000001		CMPB \$AUTOB,#1	;;ARE WE RUNNING IN AUTO-MODE?
050300	001456				BEQ 15\$;;BRANCH IF YES
050302	104401	050655		\$GTWR:	TYPE,\$CNTLG	;;ECHO THE CONTROL-G (^G)
050306	104401	050662			TYPE,\$MSWR	;;TYPE CURRENT CONTENTS
050312	013746	000176			MOV SWREG,-(SP)	;;SAVE SWREG FOR TYPEOUT
050316	104402				TYPOC	;;GO TYPE--OCTAL ASCII(ALL DIGITS)
050320	104401	050673			TYPE,\$MNEW	;;PROMPT FOR NEW SWR
050324	005046				CLR -(SP)	;;CLEAR COUNTER
050326	005046				CLR -(SP)	;;THE NEW SWR
050330	105777	130610			19\$: TSTB @\$TKS	;;CHAR THERE?
050334	100375				BPL 7\$;;IF NOT TRY AGAIN
050336	117746	130604			MOV# \$TKB,-(SP)	;;PICK UP CHAR
050342	042716	177600			BIC #^C177,(SP)	;;MAKE IT 7-BIT ASCII
050346	021627	000025			CMP (SP),#25	;;IS IT A CONTROL-U?
050352	001005				BNE 10\$;;BRANCH IF NOT
050354	104401	050650			TYPE,\$CNTLU	;;YES, ECHO CONTROL-U (^U)
050360	062706	000006		20\$:	ADD #6,SP	;;IGNORE PREVIOUS INPUT
050364	000757				BR 19\$;;LET'S TRY IT AGAIN
050366	021627	000015			CMP (SP),#15	;;IS IT A <CR>?
050372	001022				BNE 16\$;;BRANCH IF NO
050374	005766	000004			TST 4(SP)	;;YES, IS IT THE FIRST CHAR?
050400	001403				BEQ 11\$;;BRANCH IF YES
050402	016677	000002	130530		MOV 2(SP),@SWR	;;SAVE NEW SWR
050410	062706	000006		11\$:	ADD #6,SP	;;CLEAR UP STACK
050414	104401	001313			TYPE,\$CRLF	;;ECHO <CR> AND <LF>
050420	123727	001135	000001		CMPB \$INTAG,#1	;;RE-ENABLE TTY KBD INTERRUPTS?
050426	001003				BNE 15\$;;BRANCH IF NOT
050430	012777	000100	130506		MOV #100,@\$TKS	;;RE-ENABLE TTY KBD INTERRUPTS
050436	000002				RTI	;;RETURN
050440	004737	047412		15\$:	JSR PC,\$TYPEC	;;ECHO CHAR
050444	021627	000060			CMP (SP),#60	;;CHAR < 0?
050450	002420				BLT 18\$;;BRANCH IF YES
050452	021627	000067			CMP (SP),#67	;;CHAR > ??
050456	003015				BGT 18\$;;BRANCH IF YES
050460	042726	000060			BIC #60,(SP)+	;;STRIP-OFF ASCII
050464	005766	000002			TST 2(SP)	;;IS THIS THE FIRST CHAR
050470	001403				BEQ 17\$;;BRANCH IF YES
050472	006316				ASL (SP)	;;NO, SHIFT PRESENT
050474	006316				ASL (SP)	;;CHAR OVER TO MAKE
050476	006316				ASL (SP)	;;ROOM FOR NEW ONE.
050500	005266	000002		17\$:	INC 2(SP)	;;KEEP COUNT OF CHAR

050504	056616	177776		BIS	-2(SP), (SP)	;;SET IN NEW CHAR	
050510	000707			BR	7\$;;GET THE NEXT ONE	
050512	104401	001312		18\$: TYPE	\$QUES	;;TYPE ?<CR><LF>	
050516	000720			BR	20\$;;SIMULATE CONTROL-U	
				.DSABL	LSB		
				*****THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY*****			
				;*CALL:			
				.* RDCHR		;;INPUT A SINGLE CHARACTER FROM THE TTY	
				.* RETURN HERE		;;CHARACTER IS ON THE STACK	
				.*		;;WITH PARITY BIT STRIPPED OFF	
				.			
050520	011646			\$RDCHR:	MOV (SP), -(SP)	;;PUSH DOWN THE PC	
050522	016666	000004	000002		MOV 4(SP), 2(SP)	;;SAVE THE PS	
050530	105777	130410		1\$: TSTB	@STKS	;;WAIT FOR	
050534	100375			BPL	1\$;;A CHARACTER	
050536	117766	130404	000004	MOV B	@STKB, 4(SP)	;;READ THE TTY	
050544	042766	177600	000004	BIC	#^C<177>, 4(SP)	;;GET RID OF JUNK IF ANY	
050552	026627	000004	000023	CMP	4(SP), #23	;;IS IT A CONTROL-S?	
050560	001013			BNE	3\$;;BRANCH IF NO	
050562	105777	130356		2\$: TSTB	@STKS	;;WAIT FOR A CHARACTER	
050566	100375			BPL	2\$;;LOOP UNTIL ITS THERE	
050570	117746	130352		MOV B	@STKB, -(SP)	;;GET CHARACTER	
050574	042716	177600		BIC	#^C177, (SP)	;;MAKE IT 7-BIT ASCII	
050600	022627	000021		CMP	(SP)+, #21	;;IS IT A CONTROL-Q?	
050604	001366			BNE	2\$;;IF NOT DISCARD IT	
050606	000750			BR	1\$;;YES, RESUME	
050610	026627	000004	000021	3\$: CMP	4(SP), #\$XON	;;IS IT A RANDOM XON?	
050616	001744			BEQ	1\$;;BRANCH IF YES	
050620	026627	000004	000140	CMP	4(SP), #140	;;IS IT 'UPPER CASE?	
050626	002407			BLT	4\$;;BRANCH IF YES	
050630	026627	000004	000175	CMP	4(SP), #175	;;IS IT A SPECIAL CHAR?	
050636	003003			BGT	4\$;;BRANCH IF YES	
050640	042766	000040	000004	BIC	#40, 4(SP)	;;MAKE IT UPPER CASE	
050646	000002			4\$: RTI		;;GO BACK TO USER	
050650	136	125	015	\$CNTLU:	.ASCII /^U/<15><12>	;;CONTROL 'U'	
050655	136	107	015	\$CNTLG:	.ASCII /^G/<15><12>	;;CONTROL 'G'	
050662	015	012	123	\$MSWR:	.ASCII <15><12>/SWR = /		
050673	040	040	116	\$MNEW:	.ASCII / NEW = /		

8490

.SBTTL TRAP DECODER

;*****
;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;*GO TO THAT ROUTINE.

050704 010046			STRAP: MOV R0,-(SP) ;:SAVE R0
050706 016600	000002		MOV 2(SP),R0 ;:GET TRAP ADDRESS
050712 005740			TST -(R0) ;:BACKUP BY 2
050714 111000			MOVS (R0),R0 ;:GET RIGHT BYTE OF TRAP
050716 006300			ASL R0 ;:POSITION FOR INDEXING
050720 016000	050740		MOV \$TRPAD(R0),R0 ;:INDEX TO TABLE
050724 000200			RTS R0 ;:GO TO ROUTINE
;:THIS IS USF TO HANDLE THE "GETPRI" MACRO			
050726 011646			\$TRAP2: MOV (SP),-(SP) ;:MOVE THE PC DOWN
050730 016666	000004	000002	MOV 4(SP),2(SP) ;:MOVE THE PSW DOWN
050736 000002			RTI ;:RESTORE THE PSW

.SBTTL TRAP TABLE

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;*BY THE "TRAP" INSTRUCTION.

ROUTINE

050740 050726	WORD \$TRAP2		
050742 047174	\$TYPE ;:CALL=TYPE	TRAP+1(104401)	TTY TYPEOUT ROUTINE
050744 047560	\$TYPOC ;:CALL=TYPOC	TRAP+2(104402)	TYPE OCTAL NUMBER (WITH LEADING ZEROS)
050746 047534	\$TYPOS ;:CALL=TYPOS	TRAP+3(104403)	TYPE OCTAL NUMBER (NO LEADING ZEROS)
050750 047574	\$TYPON ;:CALL=TYPON	TRAP+4(104404)	TYPE OCTAL NUMBER (AS PER LAST CALL)
050752 050306	\$GTSWR ;:CALL=GTSWR	TRAP+5(104405)	GET SOFT-SWR SETTING
050754 050236	\$CKSWR ;:CALL=CKSWR	TRAP+6(104406)	TEST FOR CHANGE IN SOFT-SWR
050756 050520	\$RDCHR ;:CALL=RDCHR	TRAP+7(104407)	TTY TYPEIN CHARACTER ROUTINE
050760 047076	\$SAVREG ;:CALL=SAVREG	TRAP+10(104410)	SAVE R0-R5 ROUTINE
050762 047134	\$RESREG ;:CALL=RESREG	TRAP+11(104411)	RESTORE R0-R5 ROUTINE
8491 050764 052050	.RSET ;:CALL=RSETUP	TRAP+12(104412)	ROUTINE TO INITIALIZE AT END OF EACH TEST
8492	\$TERM=-\$TRPAD		

8494

.SBTTL POWER DOWN AND UP ROUTINES

:*****:POWER DOWN ROUTINE:*****:

050766	012737	051144	000024	\$PWRDN: MOV #\$ILLUP, ^a PWRVEC ;;SET FOR FAST UP
050774	012737	000340	000026	MOV #340, ^a PWRVEC+2 ;;PRIO:7
051002	010046			MOV R0,-(SP) ;;PUSH R0 ON STACK
051004	010146			MOV R1,-(SP) ;;PUSH R1 ON STACK
051006	010246			MOV R2,-(SP) ;;PUSH R2 ON STACK
051010	010346			MOV R3,-(SP) ;;PUSH R3 ON STACK
051012	010446			MOV R4,-(SP) ;;PUSH R4 ON STACK
051014	010546			MOV R5,-(SP) ;;PUSH R5 ON STACK
051016	017746	130116		MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
051022	010637	051150		MOV SP,\$\$AVR6 ;;SAVE SP
051026	012737	051040	000024	MOV #SPWRUP, ^a PWRVEC ;;SET UP VECTOR
051034	000000			HALT
051036	000776			BR .-2 ;;HANG UP

:*****:POWER UP ROUTINE:*****:

051040	012737	051144	000024	\$PWRUP: MOV #\$ILLUP, ^a PWRVEC ;;SET FOR FAST DOWN
051046	013706	051150		MOV \$\$AVR6,SP ;;GET SP
051052	005037	051150		CLR \$\$AVR6 ;;WAIT LOOP FOR THE TTY
051056	005237	051150		1\$: INC \$\$AVR6 ;;WAIT FOR THE INC
051062	001375			BNE 1\$;;OF WORD
051064	012677	130050		MOV (SP)+,@SWR ;;POP STACK INTO @SWR
051070	012605			MOV (SP)+,R5 ;;POP STACK INTO R5
051072	012604			MOV (SP)+,R4 ;;POP STACK INTO R4
051074	012603			MOV (SP)+,R3 ;;POP STACK INTO R3
051076	012602			MOV (SP)+,R2 ;;POP STACK INTO R2
051100	012601			MOV (SP)+,R1 ;;POP STACK INTO R1
051102	012600			MOV (SP)+,R0 ;;POP STACK INTO R0
051104	012737	050766	000024	MOV #SPWRDN, ^a PWRVEC ;;SET UP THE POWER DOWN VECTOR
051112	012737	000340	000026	MOV #340, ^a PWRVEC+2 ;;PRIO:7
051120	104401			TYPE
051122	052120			SPWRMG: .WORD POWERM ;;REPORT THE POWER FAILURE
051124	012716			MOV (PC)+,(SP) ;;POWER FAIL MESSAGE POINTER
051126	006116			SPWRAD: .WORD START ;;RESTART AT START
051130	042766	000020	000002	BIC #20,2(SP) ;;RESTART ADDRESS
051136	005037	046156		CLR \$BIT ;;CLEAR 'T' BIT
051142	000002			RTI ;;CLEAR THE 'T' BIT FLAG
051144	000000			\$ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
051146	000776			BR .-2 ;;BEFORE THE POWER DOWN WAS COMPLETE
051150	000000			SSAVR6: 0 ;;PUT THE SP HERE

```

8496
8497
8498

8499
8500
8501
8502
8503
8504
8505 051152 104401          ERTYPE: TYPE           ;TYPE A CRLF
8506 051154 001313          .WORD    SCRLF
8507 051156 113737 001102 001232      MOV     STSTNM,$TMP0
8508 051164 042737 177400 001232      BIC     #177400,$TMP0
8509 051172 013737 001116 001234      MOV     SERRPC,$TMP1
8510 051200 010046          MOV     R0,-(SP)      ;GET PC OF CALL
8511 051202 117700 130026          MOV     @TMP1,R0      ;SAVE R0
8512 051206 042700 177400          BIC     #177400,R0      ;GET THE ITEM NUMBER.
8513 051212 001006          BNE    21$          ;TYPE A CRLF
8514 051214 013746 001116          MOV     $ERRPC,-(SP)   ;MOVE ERROR PC TO STACK FOR PRINTING
8515 051220 104402          TYPLOC   20$          ;GO TYPE THE ERROR PC
8516 051222 104401 001313          TYPE    SCRLF      ;TYPE A <CRLF>
8517 051226 000561          BR     ERT5         ;BRANCH TO EXIT
8518 051230 022700 000377          21$:   CMP     #377,R0
8519 051234 001004          BNE    20$          ;SAVE THE ERROR # FOR POSSIBLE USE      ;DPM001
8520 051236 017600 000004          MOV     @4(SP),R0
8521 051242 062700 000400          ADD     #400,R0
8522 051246 010037 051576          20$:   MOV     R0,ERRNUM
8523 051252 005300          DEC     R0          ;OTHERWISE MAKE R0 AN
8524 051254 006300          ASL     R0          ;INDEX FOR THE TABLE.
8525 051256 006300          ASL     R0
8526 051260 006300          ASL     R0
8527 051262 062700 001442          22$:   ADD     #$ERRTB,R0
8528 051266 012037 051276          MOV     (R0)+,2$      ;PICK UP THE ADDRESS
8529 051272 001406          BEQ    3$          ;OF THE EM, ERROR MESSAGE
8530 051274 104401          TYPE    2$          ;TYPE
8531 051276 000000          .WORD   0
8532 051300 004737 051600          JSR    PC,PASCIZ   ;GO CHECK FOR AND PRINT ANY ADDTL ASCIZ ;DPM001
8533 051304 104401 001313          TYPE    SCRLF
8534 051310 012037 051320          MOV     (R0)+,4$      ;GET THE DH,DATA HEADER
8535 051314 001406          BEQ    5$          ;TYPE
8536 051316 104401          TYPE    4$          ;TYPE
8537 051320 000000          .WORD   0
8538 051322 004737 051600          JSR    PC,PASCIZ   ;GO CHECK FOR AND PRINT ANY ADDTL ASCIZ ;DPM001
8539 051326 104401          TYPE    5$          ;TYPE
8540 051330 001313          .WORD   SCRLF
8541 051332 010146          MOV     R1,-(SP)      ;SAVE R1,R2 AND R3
8542 051334 010246          MOV     R2,-(SP)
8543 051336 010346          MOV     R3,-(SP)
8544 051340 012001          MOV     (R0)+,R1      ;GET THE ADDRESS OF THE DATA TABLE.
8545 051342 001506          BEQ    ERT4        ;RETURN IF NO DATA.
8546 051344 011000          MOV     (R0),RC      ;GET A POINTER TO THE DATA FORMAT TABLE.
8547 051346 105710          ERT1:  TSTB   (R0)      ;FORMAT ZERO?
8548 051350 001003          BNE    7$          ;FORMAT ZERO SO TYPE
8549 051352 013146          MOV     @R1+,-(SP)   ;AN OCTAL NUMBER.
8550 051354 104402          TYPLOC   7$          ;FORMAT ZERO SO TYPE
8551 051356 000473          BR     ERT2

```

8552 051360	122710	000002	7\$: CMPB #2,(R0)	;FORMAT TWO?
8553 051364	001010		BNE 9\$	
8554 051366	013102		MOV a(R1)+,R2	;FORMAT TWO SO TYPE TWO
8555 051370	012246		MOV (R2),-(SP)	;OCTAL NUMBERS.
8556 051372	104402		TYPOC	
8557 051374	104401		TYPE	
3558 051376	052164		.WORD	SPACE
8559 051400	011246		MOV	(R2),-(SP)
8560 051402	104402		TYPOC	
8561 051404	000460		BR	ERT2
8562 051406	122710	000003	9\$: CMPB #3,(R0)	;FORMAT THREE?
8563 051412	001011		BNE 10\$	
8564 051414	013102		MOV a(R1)+,R2	;FORMAT THREE SO TYPE 4 OCTAL NUMBERS.
8565 051416	012703	000004	MOV #4,R3	;LOOP COUNTER
8566 051422	012246		MOV (R2),-(SP)	;MOVE DATA TO THE STACK
8567 051424	104402		TYPOC	;TYPE AN OCTAL NUMBER
8568 051426	104401		TYPE	;TYPE A SPACE
8569 051430	052164		.WORD	SPACE
8570 051432	077305		SQB R3,90\$;SUBTRACT 1 AND BRANCH IF NOT DONE YET ;DPM001
8571 051434	000444		BR ERT2	;EXIT
8572 051436	122710	000004	10\$: CMPB #4,(R0)	;FORMAT FOUR?
8573 051442	001004		BNE 11\$	
8574 051444	013146		MOV a(R1),-(SP)	;FORMAT FOUR SO TYPE
8575 051446	104403		TYPOS	;AN OCTAL NUMBER
8576 051450	016		.BYTE	;SUPPRESSING LEADING ZEROES.
8577 051451	000		.BYTE	16
8578 051452	000435		BR	0
8579 051454	122710	000005	11\$: CMPB #5,(R0)	;FORMAT FIVE?
8580 051460	001005		BNE 13\$	
8581 051462	012137	051470	MOV (R1),.12\$;FORMAT FIVE SO TYPE AN
8582 051466	104401		TYPE	;ASCIZ STRING.
8583 051470	000000		.WORD	0
8584 051472	000427		BR	ERT3
8585 051474	122710	000011	13\$: CMPB #11,(R0)	;FORMAT ELEVEN?
8586 051500	001005		BNE 15\$	
8587 051502	013137	051510	MOV a(R1),.14\$;FORMAT ELEVEN SO PICK
8588 051506	104401		TYPE	;A POINTER TO AN ASCIZ
8589 051510	000000		.WORD	;STRING.
8590 051512	000417		BR	ERT3
8591 051514	122710	000012	14\$: CMPB #12,(R0)	;FORMAT TWELVE?
8592 051520	001011		BNE 17\$	
8593 051522	013102		MOV a(R1),.R2	;FORMAT TWELVE SO TYPE
8594 051524	012703	000006	MOV #6,R3	;TYPE SIX OCTAL NUMBERS
8595 051530	012246		MOV (R2),-(SP)	
8596 051532	104402		TYPOC	
8597 051534	104401		TYPE	
8598 051536	052164		.WORD	SPACE
8599 051540	077305		SQB R3,16\$	
8600 051542	000401		BR	ERT2
8601 051544	000000		17\$: HALT	;UNDEFINED FORMAT FOR DATA?????
8602 051546	104401		ERT2: TYPE	;PRINT A TAB AFTER TYPING A DATA TABLE ENTRY
8603 051550	052167		.WORD	;OF ALL FORMATS EXCEPT ASCIZ, FORMATS 5 OR 11
8604 051552	005200		STAB	;POINT TO THE NEXT FORMAT
8605 051554	005711		INC R0	
8606 051556	001273		TST (R1)	;END OF DATA TABLE.
8607 051560	104401		BNE ERT1	
8608 051562	001313		TYPE .WORD	\$CRLF
				;DONE.

CKFPCDO FP11F FLTG PNT PRT C
ERROR TYPE OUT ROUTINE

MACRO M1113 30-OCT-81 11:15 PAGE 110-2

D 2
SEQUENCE 224

8609 051564 012603	MOV (SP)+,R3	:RESTORE R1,R2 AND R3
8610 051566 012602	MOV (SP)+,R2	
8611 051570 012601	MOV (SP)+,R1	
8612 051572 012600	ERTS: MOV (SP)+,R0	:RESTORE R0.
8613 051574 000207	RTS PC	;AND RETURN.
8614		
8615 051576 000000	ERRNUM: .WORD 0	:LOCATION TO HOLD CURRENT ERROR NUMBER ;DPM001

8616			.SBTTL	SUBROUTINE TO LOOK FOR ANY ADDITIONAL MSGS TO PRINT		
8617	051600	010446	MOV R4,-(SP)	;SAVE R4	;DPM001	
8618	051602	013704	MOV EDASCII,R4	;MOVE END OF ASCII ADDRESS TO R4	;DPM001	
8619	051606	122714	CMPB #377,(R4)	;SEE IF ADD'L MSGS NEED TO BE PRINTED	;DPM001	
8620	051612	001013	BNE 4\$;BRANCH IF NOT	;DPM001	
8621	051614	005204	INC R4	;INCREMENT TO NEXT BYTE	;DPM001	
8622	051616	032704	BIT #BIT00,R4	;SEE IF ODD ADDRESS	;DPM001	
8623	051622	001401	BEQ 2\$;BRANCH IF NOT	;DPM001	
8624	051624	005204	INC R4	;POINT TO WORD ADDRESS	;DPM001	
8625	051626	012437	051636	2\$: MOV (R4)+,3\$;MOVE ADDRESS TO LOCATION FOR TYPING	;DPM001
8626	051632	001763	BEQ 1\$;GO CHK FOR MORE MSG ADRS'S IF NO MORE	;DPM001	
8627	051634	104401	TYPE .WORD 0	;TYPE THE MESSAGE, ADDRESS IN NEXT WORD	;DPM001	
8628	051636	000000	BR 2\$;LOCATION FOR MESSAGE ADDRESS	;DPM001	
8629	051640	000772	CMPB #376,(R4)	;BRANCH BACK TO LOAD OTHER MESSAGES	;DPM001	
8630	051642	122714	000376	4\$: BNE 11\$;SEE IF SPECIFIC MSGS NEED PRINTING	;DPM001
8631	051646	001027	INC R4	;BRANCH TO EXIT IF NOT	;DPM001	
8632	051650	005204	BIT #BIT00,R4	;INCREMENT TO NEXT BYTE	;DPM001	
8633	051652	032704	BEQ 5\$;SEE IF ODD ADDRESS	;DPM001	
8634	051656	001401	INC R4	;BRANCH IF NOT	;DPM001	
8635	051660	005204	CLR -(SP)	;POINT TO WORD ADDRESS	;DPM001	
8636	051662	005046	INC (SP)	;CLEAR COUNTER LOCATION ON STACK	;DPM001	
8637	051664	005216	5\$: CMP ERRNUM,(R4)+	;INCREMENT COUNTER	;DPM001	
8638	051666	023724	BNE 6\$;SEE IF ITEM NUMBER MATCHES ERROR	;DPM001	
8639	051672	001374	TST (R4)+	;BRANCH IF NOT TO SEARCH AGAIN	;DPM001	
8640	051674	005724	BNE 7\$;SEE IF AT TERMINATOR YET	;DPM001	
8641	051676	001376	TST -(R4)	;BRANCH BACK UNTIL IT IS	;DPM001	
8642	051700	005744	TST (R4)+	;PUT R4 AT THE TERMINATOR	;DPM001	
8643	051702	005724	DEC (SP)	;POINT R4 TO NEXT ADDRESS	;DPM001	
8644	051704	005316	BNE 8\$;SEE IF COUNTER DOWN TO ZERO YET	;DPM001	
8645	051706	001375	TST (SP)+	;BRANCH BACK IF NOT TO ADVANCE R4	;DPM001	
8646	051710	005726	MOV (R4),10\$;POP COUNTER OFF STACK	;DPM001	
8647	051712	011437	BEQ 11\$;MOVE ADDRESS TO LOCATION TO TYPE	;DPM001	
8648	051716	001403	TYPE .WORD 0	;BRANCH IF NO EXTRA MESSAGE TO PRINT	;DPM001	
8649	051720	104401	BP 1\$;TYPE THE ASCII MESSAGE	;DPM001	
8650	051722	000000	MOV (SP)+,R4	;LOCATION FOR ASCII MESSAGE ADDRESS	;DPM001	
8651	051724	000726	RTS PC	;GO BACK TO MAKE SURE NO MORE MSGS	;DPM001	
8652	051726	012604		;RESTORE R4	;DPM001	
8653	051730	000207		;EXIT	;DPM001	

8654
8655

.SBTTL FPP SPURIOUS TRAP TO 244 HANDLER

8656
8657
8658
8659

;*****
;*THIS ROUTINE HANDLES UNEXPECTED TRAPS TO THE FPP TRAP VECTOR AT 244.
;*THE LAST FPP INSTRUCTION EXECUTED AND ITS ADDRESS HAS BEEN RECORDED
;*THESE ALONG WITH THE FEC, FPS AND PC OF TRAP ARE REPORTED.
;*

8660 051732 042737 000001 177572 FPSPUR: BIC #BIT00,MMR0 :MAKE SURE MEMORY MANAGEMENT IS OFF :DPM001

8661 051740 011637 001236 MOV (SP),\$TMP2 :SAVE PC OF TRAP.

8662 051744 022626 CMP (SP)+,(SP)+ :RESTORE SP.

8663 051746 170200 STFPS R0 :GET FPS

8664 051750 010037 001240 MOV R0,\$TMP3 :MOVE IT TO \$TMP3

8665 051754 170300 STST R0 :GET FEC

8666 051756 010037 001242 MOV R0,\$TMP4 :MOVE IT TO \$TMP4

8667 051762 104377 ERROR +377 :CALL ERROR

8668 051764 000041 WORD 41 :ERROR #41

8669 051766 104412 RSETUP :GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

8670 051770 000137 045420 JMP SEOP :JUMP TO SEOP

8671 .SBTTL CPU SPURIOUS TRAP TO 4 HANDLER
8672 ;*****
8673 ;*THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 4.
8674 ;*
8675 051774 042737 000001 177572 CPSPUR: BIC #BIT00,MMR0 ;MAKE SURE MEMORY MANAGEMENT IS OFF ;DPM001
8676 052002 011637 001236 MOV (SP),\$TMP2 ;SAVE PC OF TRAP.
8677 052006 022626 CMP (SP)+,(SP)+ ;CLEAN STACK
8678 052010 104377 ERROR +377 ;CALL ERROR
8679 052012 000042 WORD 42 ;ERROR #442
8680 052014 104412 RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).
8681 052016 000137 045420 JMP \$EOP ;JUMP TO \$EOP

8682 .SBTTL CPU SPURIOUS TRAP TO 10 HANDLER
8683 ;*****
8684 ;*THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 10.
8685 ;*
8686 052022 042737 000001 177572 CPTWO: BIC #BIT00,MMR0 ;MAKE SURE MEMORY MANAGEMENT IS OFF ;DPM001
8687 052030 011637 001236 MOV (SP),\$TMP2 ;SAVE PC OF TRAP.
8688 052034 022626 CMP (SP)+,(SP)+ ;CLEAN STACK
8689 052036 104377 1\$: ERROR +377 ;CALL ERROR
8690 052040 000043 .WORD 43 ;ERROR #443
8691 052042 104412 RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
 ;SEE IF THE USER HAS EXPRESSED
 ;THE DESIRE TO CHANGE THE SOFTWARE
 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
 ;THE USER TYPED CONTROL G?).
8692 052044 000137 045420 JMP \$EOP ;JUMP TO \$EOP

8693
8694

.SBTTL FLAG RESET AND CONSOLE TEST ROUTINE

8695
8696
8697
8698
8699
8700
8701

;*****
;*THIS ROUTINE WILL BE CALLED AT THE END OF EACH TEST TO
;*RESET THE STACK, CLEAR THE FPS AND SEE IF THE USER HAS TYPED
;* CONTROL G ON THE TERMINAL. IF THE USER HAS TYPED CONTROL G AND
;*THERE IS NO PHYSICAL CONSOLE SWITCH REGISTER THEN THE CONTENTS
;*OF THE SOFTWARE SWITCH REGISTER WILL BE TYPED IN OCTAL ON THE
;*TELETYPE AND THE USER CAN MODIFY IT.
;*

8702 052050 023727 001140 177570 .RSET: CMP SWR,#177570 ;SEE IF THERE IS A PHYSICAL CONSOLE SWITCH REGISTER.
8703 052056 001001 BNE 1\$;BRANCH IF NOT
8704 052060 104406 CKSWR ;OTHERWISE TYPE THE CONTENTS OF THE PROGRAM VIRTUAL
8705 ;SWITCH REGISTER AND GIVE THE USER CHANCE TO MODIFY IT
8706 052062 012737 051732 000244 1\$: MOV #FPSPUR,FPVECT
8707 052070 012737 051774 000004 MOV #CPSPUR,ERRVECT
8708 052076 012737 052022 000010 MOV #CPTWO,10
8709 052104 011600 MOV (SP),R0 ;SAVE RETURN ADDRESS.
8710 052106 012706 001100 MOV #STACK,SP ;RESET THE STACK POINTER.
8711 052112 005004 CLR R4 ;CLEAR THE FPS.
8712 052114 170104 LDFPS R4
8713 052116 000110 JMP (R0) ;RETURN.

CKFPCDO FP11F FLTG PNT PRT C

J 2
MACRO M1113 30-OCT-81 11:15 PAGE 116

SEQUENCE 230

SPECIAL MESSAGES

8714				.SBTTL	SPECIAL MESSAGES
8715	052120	200	120	117 POWERM:	.ASCIZ <CRLF>'POWER FAILURE. PROGRAM RESTARTING.'
8716	052164	040	040	000 SPACE:	.ASCIZ '
8717	052167	011	000	\$TAB:	.ASCIZ <TAB>
8718	052171	107	117	124 MS1:	.ASCIZ 'GOT RESULT:'<TAB><TAB>
8719	052207	105	130	120 MS2:	.ASCIZ 'EXPECTED RESULT:'<TAB>
8720	052231	101	103	040 MS3:	.ASCIZ 'AC OPERAND:'<TAB><TAB>
8721	052247	123	117	125 MS4:	.ASCIZ 'SOURCE OPERAND: '<TAB>
8722		052231		MS10=MS3	
8723	052271	105	130	120 MS11:	.ASCIZ 'EXONENT OPERAND:'<TAB>
8724	052314	114	117	101 MS20:	.ASCIZ '>LOADED:'<TAB><TAB>
8725	052326	124	122	111 MS21:	.ASCIZ '>TRIED TO LOAD:'<TAB>

8726					.SBTTL	ERROR MESSAGES
8746 052346	123	000		EM1:	.ASCIZ	'S!
8747 052350	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
					.EVEN	
					.WORD	EM1B,EM1C,EM1D,0
8748 052352	052362	052373	052412	EM1B:	.ASCIZ	TF A,AC7!
8749 052362	124	106	040	EM1C:	.ASCIZ	DID NOT TRAP.!
8750 052373	040	104	111	EM1D:	.ASCIZ	FID=0.!
8751 052412	040	106	111	EM2:	.ASCIZ	'S!
8752 052422	123	000			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
8753 052424	377				.EVEN	
					.WORD	EM1B,EM2B,EM1D,0
8754 052426	052362	052436	052412	EM2B:	.ASCIZ	'. FPS BAD. !
8755 052436	056	040	106	EM3:	.ASCIZ	'S!
8756 052452	123	000			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
8757 052454	377				.EVEN	
					.WORD	EM1B,EM3B,EM1D,0
8758 052456	052362	052466	052412	EM3B:	.ASCIZ	'. FEC BAD. !
8759 052466	056	040	106	EM4:	.ASCIZ	'S!
8760 052502	123	000			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
8761 052504	377				.EVEN	
					.WORD	EM4A,EM4B,EM4C,EM4D,0
8762 052506	052520	052531	052543	EM4A:	.ASCIZ	TF A,(R)!
8763 052520	124	106	040	EM4B:	.ASCIZ	. RO BAD. !
8764 052531	056	040	122	EM4C:	.ASCIZ	. FDST!
8765 052543	056	040	106	EM4D:	.ASCIZ	FAILED.!
8766 052552	040	106	101	EM5:	.ASCIZ	'S!
8767 052563	123	000			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
8768 052565	377				.EVEN	
					.WORD	EM4A,EM4D,0
8769 052566	052520	052552	000000	EM6:	.ASCIZ	'S!
8770 052574	123	000			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
8771 052576	377				.EVEN	
8772 052600	052520	052543	052552	EM6C:	.WORD	EM4A,EM4C,EM4D,EM6C
8773 052610	052610				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
					.EVEN	
8774 052612	052653	052650	052662	IFD:	.WORD	CRBUT,IFD,PRST,N7,NO,N7,WENTTO,N2,N4,N5,INSTOF,N2,N4,N4,0
8775 052650	106	104	000		.ASCIZ	!FD!
8775 052653	200	050	102	CRBUT:	.ASCIZ	<CRLF> (BUT :
8776 052662	051	040	123	PRST:	.ASCIZ) ST
8777 052670	040	127	105	WENTTO:	.ASCIZ	WENT TO :
8778 052702	040	111	116	INSTOF:	.ASCIZ	INSTEAD OF :
8779 052717	060	000		NO:	.ASCIZ	0
8780 052721	061	000		N1:	.ASCIZ	1
8781 052723	062	000		N2:	.ASCIZ	2
8782 052725	063	000		N3:	.ASCIZ	3
8783 052727	064	000		N4:	.ASCIZ	4
8784 052731	065	000		N5:	.ASCIZ	5
8785 052733	066	000		N6:	.ASCIZ	6
8786 052735	067	000		N7:	.ASCIZ	7
8787 052737	123	000		EM7:	.ASCIZ	'S!
8788 052741	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
					.EVEN	
8789 052742	052520	052756	052531	EM7B:	.WORD	EM4A,EM7B,EM4B,EM4C,EM4D,0
8790 052756	053	056	000	EM10:	.ASCIZ	+'!
8791 052761	123	000			.ASCIZ	'S!

8792 052763	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8793 052764	052520	052756	052552	.EVEN		
8794 052774	123	000		.WORD	EM4A,EM7B,EM4D,0	
8795 052776	377			.ASCIZ	:S:	
				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		
8796 053000	053012	052531	052543	.WORD	EM11B,EM4B,EM4C,EM4D,0	
8797 053012	124	104	040	.ASCIZ	:TD A,(R)+!	
8798 053024	123	000		.ASCIZ	:S:	
8799 053026	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8800 053030	053012	052552	000000	.EVEN		
8801 053036	123	000		.WORD	EM11B,EM4D,0	
8802 053040	377			.ASCIZ	:S:	
				.BYTF	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		
8803 053042	053050	053060	000000	.WORD	EM13A,EM13B,0	
8804 053050	124	104	040	.ASCIZ	:TD A,#N!	
8805 053060	040	124	122	.ASCIZ	: TRAP TO 4 IN FDST.:	
8806	053036			EM14=EM13		
8807 053104	123	000		.ASCIZ	:S:	
8808 053106	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8809 053110	053050	052552	000000	.EVEN		
8810 053116	120	103	040	.WORD	EM13A,EM4D,0	
8811 053135	377			.ASCIZ	:PC BAD AFTER S!	
				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		
8812 053136	053050	000000		.WORD	EM13A,0	
8813 053142	123	000		.ASCIZ	:S:	
8814 053144	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8815 053146	053154	053060	000000	.EVEN		
8816 053154	124	104	040	.WORD	EM17B,EM13B,0	
8817 053166	123	000		.ASCIZ	:TD A,-(R)!	
8818 053170	377			.ASCIZ	:S:	
				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		
8819 053172	053154	052531	052543	.WORD	EM17B,EM4B,EM4C,EM4D,0	
8820 053204	123	000		.ASCIZ	:S:	
8821 053206	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8822 053210	053154	052552	000000	.EVEN		
8823 053204	053204			.WORD	EM17B,EM4D,0	
8824 053216	123	000		.ASCIZ	:S:	
8825 053220	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8826 053222	053230	053060	000000	.EVEN		
8827 053230	124	104	040	.WORD	EM23B,EM13B,0	
8828 053243	123	000		.ASCIZ	:TD A,@(R)+!	
8829 053245	377			.ASCIZ	:S:	
				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		
8830 053246	053230	052531	052543	.WORD	EM23B,EM4B,EM4C,EM4D,0	
8831 053260	123	000		.ASCIZ	:S:	
8832 053262	377			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8833 053264	053230	052552	000000	.EVEN		
8834 053272	123	000		.WORD	EM23B,EM4D,0	
8835 053274	377			.ASCIZ	:S:	
				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
				.EVEN		

ERROR MESSAGES

8836 053276	053304	053060	000000		.WORD	EM268, EM138, 0
8837 053304	124	104	040		.ASCIZ	:TD A,B-(R):
8838 053317	123	000		EM27:	.ASCIZ	:S:
8839 053321	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8840 053322	053304	052531	052543		.WORD	EM268, EM4B, EM4C, EM4D, 0
8841 053334	123	000		EM30:	.ASCIZ	:S:
8842 053336	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8843 053340	053304	052552	000000		.WORD	EM268, EM4D, 0
8844 053346	123	000		EM31:	.ASCIZ	:S:
8845 053350	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8846 053352	053360	053060	000000		.WORD	EM31B, EM138, 0
8847 053360	124	104	040	EM31B:	.ASCIZ	:TD A,N(R):
8848 053372	123	000		EM32:	.ASCIZ	:S:
8849 053374	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8850 053376	053360	052531	052543		.WORD	EM31B, EM4B, EM4C, EM4D, 0
8851 053410	123	000		EM33:	.ASCIZ	:S:
8852 053412	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8853 053414	053360	052552	000000		.WORD	EM31B, EM4D, 0
8854 053422	123	000		EM34:	.ASCIZ	:S:
8855 053424	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8856 053426	053434	053060	000000		.WORD	EM34B, EM138, 0
8857 053434	124	104	040	EM34B:	.ASCIZ	:TD A,BN(R):
8858 053447	123	000		EM35:	.ASCIZ	:S:
8859 053451	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8860 053452	053434	052531	052543		.WORD	EM34B, EM4B, EM4C, EM4D, 0
8861 053464	123	000		EM36:	.ASCIZ	:S:
8862 053466	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8863 053470	053434	052552	000000		.WORD	EM34B, EM4D, 0
8864 053476	123	124	103	EM37:	.ASCIZ	:STCFD A,(R) FAILED.:
8865 053522	376				.BYTE	376 ;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW
8866 053524	000037	000042	000044		.WORD	37, 42, 44, 45, 47, 50, 0
8867 053542	000000	053616	053731		.WORD	0, EM42B, EM44B, EM45B, EM47B, EM50B
8868 053556	123	124	103	EM40:	.ASCIZ	:STCFD A,(R):
8869 053572	376				.BYTE	376 ;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW
8870 053574	000040	000041	000043		.WORD	40, 41, 43, 46, 0
8871 053606	052436	052466	053652		.WORD	EM2B, EM3B, EM43B, EM46B
8872	053556				EM41=EM40	
8873	053476				EM42=EM37	
8874 053616	200	111	116	EM42B:	.ASCIZ	<CRLF>: INVERT FDFL ST 767 FAILED.:
8875	053556				EM43=EM40	
8876 053652	056	040	106	EM43B:	.ASCIZ	: FPS BAD.:
8877 053665	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8878 053666	052653	053724	052662		.WORD	CRBUT, IEZBT, PRST, N5, N6, NO, WENTTO, NO, N6, N1, INSTOF, N2, N6, N1, 0
8879 053724	105	132	102	IEZBT:	.ASCIZ	:EZBT:
8880 053731	053476	200	114	EM44=EM37	.ASCIZ	
			117	EM44B:	.ASCIZ	<CRLF>: LOW ORDER BITS OF X11 DID NOT GET 0 ST 766.:

8881	053476				EM45=EM37		
8882	054006	200	050	102	EM45B: .ASCIZ <CRLF>:(BUT OP1C) ST 251 FAILED.'		
8883		053556			EM46=EM40		
8884	054041	056	040	106	EM46B: .ASCIZ !		
8885	054054	377			.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
					.EVEN		
					.WORD		
					CRBUT,IEZBT,PRST,N4,N2,N1,WENTTO,N2,N6,N2,INSTOF,N0,N6,N2,0		
8886	054056	052653	053724	052662	EM47=EM37		
8887	054114	053476			EM47B: .ASCIZ !		
8888	054116	060	000		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
		377			.EVEN		
					.WORD		
					CRBUT,IFD,PRST,N1,N1,N3,WENTTO,N4,N1,N5,INSTOF,N4,N1,N4,0		
8889	054120	052653	052650	052662	EM50=EM37		
8890	054156	053476			EM50B: .ASCIZ !		
8891	054171	040	123	111	.BYTE 377 ;SIGN BAD.		
		377			.WORD		
					CRBUT,IENBT,PRST,N5,N6,N7,WENTTO,N0,N6,N0,INSTOF,N4,N6,N0,0		
8892	054230	105	116	102	IENBT: .ASCIZ !		
8893	054235	123	124	103	EM51: .ASCIZ !		
8894	054251	376			.BYTE 376 ;STCDF A,(R):		
					.EVEN		
					.WORD		
					CRBUT,IBKOUT,PRST,N4,N0,N0,WENTTO,N7,N6,N6,INSTOF,N7,N6,N7,0		
8895	054252	000051	000054	000055	EM52: .WORD	51,54,55,60,0	
8896	054264	052552	054336	054402	.WORD	EM4D,EM54B,EM55B,EM60B	
8897	054274	123	124	104	.ASCIZ	!STD A,(R):	
8898	054306	376			.BYTE 376 ;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW		
					.EVEN		
					.WORD		
					EM2B,EM3B,EM56B,EM57B,EM61B		
8899	054310	000052	000053	000056	EM53=EM52		
8900	054324	052436	052466	054473	EM54=EM51		
8901		054274			EM54B: .ASCIZ ! FAILED.:<CRLF>:INVERT FDFL ST 767 FAILED.:!		
8902		054235			EM55=EM51		
8903	054336	040	106	101	EM55B: .ASCIZ <CRLF>:ROUND ERROR, OR:		
8904		054235			377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
8905	054402	200	122	117	EM55B: .BYTE		
8906	054423	377			.EVEN		
					.WORD		
					CRBUT,IBKOUT,PRST,N4,N0,N0,WENTTO,N7,N6,N6,INSTOF,N7,N6,N7,0		
					IBKOUT: .ASCIZ !BREAKOUT!		
8907	054462	102	122	105	EM56=EM52		
8908		054274			EM56B: .ASCIZ ! FPS BAD.:		
8909	054473	056	040	106	.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
8910	054506	377			.EVEN		
					.WORD		
					CRBUT,IEZBT,PRST,N4,N2,N1,WENTTO,N0,N6,N2,INSTOF,N2,N6,N2,0		
8911		054510	052653	053724	EM57=EM52		
8912	054546	040	106	120	EM57B: .ASCIZ ! FPS BAD. FIV=0.:		
8913	054567	377			.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
					.EVEN		
					.WORD		
					CRBUT,IFIV,PRST,N2,N6,N2,WENTTO,N1,N2,N3,INSTOF,N1,N0,N3,0		
8914	054626	106	111	126	IFIV: .ASCIZ !FIV:		
8915		054235			EM60=EM51		
8916	054632	040	106	101	EM60B: .ASCIZ ! FAILED. FIV=1.:		
8917	054652	377			.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
					.EVEN		
					.WORD		
					CRBUT,IFIV,PRST,N2,N6,N2,WENTTO,N1,N0,N3,INSTOF,N1,N2,N3,0		
8918	054654	052653	054626	052662	EM61=EM52		
8919	054712	054274			EM61B: .ASCIZ ! FPS BAD.:		
8920	054725	056	040	106	.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN		
		377			.EVEN		

ERROR MESSAGES

8921 054726	052653	054764	052662		.WORD	CRBUT,IFLAG,PRST,N1,N4,N7,WENTTO,N3,N6,N1,INSTOF,N3,N6,N5,0
054764	106	114	101	IFLAG:	.ASCIZ	:FLAG
8922 054771	123	124	103	EM62:	.ASCIZ	:STCF
8923 054776	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8924 055000	055010	052436	055020		.WORD	EM62A,EM2B,EM62B,0
055010	104	040	101	EM62A:	.ASCIZ	:D,A,AC6!
8926 055020	040	000		EM62B:	.ASCIZ	
8927 055022	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
055024	052653	055062	052662		.WORD	CRBUT,IFDST,PRST,N7,N6,N7,WENTTO,N5,N6,N7,INSTOF,N5,N7,N7,0
8928 055062	106	104	123	JST:	.ASCIZ	:FDST
8929 055067	123	124	103	JST:	.ASCIZ	:STCF
8930 055074	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8931 055076	055010	052466	000000		.WORD	EM62A,EM3B,0
8932 055104	103	114	122	EM64:	.ASCIZ	:CLRD (R) FAILED:<CRLF>:ZERO X11 AT ST 770!
8933 055147	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8934 055150	052552	000000			.WORD	EM4D,0
8938 055154				EM65:	.ASCIZ	:CLRD (R). FPS BAD.!
055154	103	114	122		.BYTE	0
8939 055177	000			EM66:	.ASCIZ	:CLR!
8940 055200	103	114	122		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8941 055204	377				.EVEN	
8942 055206	055220	052531	052543		.WORD	EM66B,EM4B,EM4C,EM4D,0
8943 055220	104	040	050	EM67:	.ASCIZ	:D (R)!
8944 055226					.ASCIZ	:CLRD AC7. FPS BAD.!
055226	103	114	122		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8945 055251	377				.EVEN	
055252	052653	055062	052662		.WORD	CRBUT,IFDST,PRST,N7,N7,NO,WENTTO,N6,NO,N7,INSTOF,N6,N1,N7,0
8946 055310				EM70:	.ASCIZ	:CLRD AC7. FEC BAD.!
055310	103	114	122		.ASCIZ	:NEGF A!
8947 055333	116	105	107	EM71:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
8948 055342	377				.EVEN	
8949 055344	052552	000000			.WORD	EM4D,0
8950 055350	116	105		EM72:	.ASCIZ	:NEGF A!
8951 055357	377		107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8952 055360	052436	000000			.WORD	EM2B,0
8953 055364	116	105		EM73:	.ASCIZ	:NEGF!
8954 055370	377		107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8955 055372	055220	052552	000000		.WORD	EM66B,EM4D,0
8956 055400	116	105		EM74:	.ASCIZ	:NEGF!
8957 055404	377		107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8958 055406	055220	052531	000000		.WORD	EM66B,EM4B,0
8959 055414	116	105		EM75:	.ASCIZ	:NEGF!
8960 055420	377		107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN						
8961 055422	055220	052436	000000		.WORD	EM66B,EM2B,0
8962 055430	101	102	123	EM76:	.ASCIZ	:ABS!
8963 055434	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN

8964 055436	055444	055453	000000		.EVEN		
8965 055444	104	040	050	EM76A:	.WORD	EM76A, EM76B, 0	
8966 055453	040	124	122	EM76B:	.ASCIZ	:D (R)+;	
8967 055503	101	102	123	EM77:	.ASCIZ	TRAP TO 4 IN SRC MODE.;	
8968 055507	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8969 055510	055444	052552	000000	EM100:	.EVEN		
8970 055516	101	102	123		.WORD	EM76A, EM4D, 0	
8971 055522	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8972 055524	055444	052531	000000	EM101:	.EVEN		
8973 055532	101	102	123		.WORD	EM76A, EM4B, 0	
8974 055536	377				.ASCIZ	:ABS!	
					.BYTEF	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8975 055540	055444	052436	000000	EM102:	.EVEN		
8976 055546	101	102	123		.WORD	EM76A, EM2B, 0	
8977 055552	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8978 055554	055562	055453	000000	EM102B:	.EVEN		
8979 055562	104	040	055		.WORD	EM102B, EM76B, 0	
8980 055571	101	102	123		.ASCIZ	:D -(R)!	
8981 055575	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8982 055576	055562	052552	000000	EM104:	.EVEN		
8983 055604	101	102	123		.WORD	EM102B, EM4D, 0	
8984 055610	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8985 055612	055562	052531	000000	EM105:	.EVEN		
8986 055620	101	102	123		.WORD	EM102B, EM4B, 0	
8987 055624	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8988 055626	055562	052436	000000	EM106:	.EVEN		
8989 055634	101	102	123		.WORD	EM102B, EM2B, 0	
8990 055640	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8991 055642	055650	055453	000000	EM106B:	.EVEN		
8992 055650	104	040	100		.WORD	EM106B, EM76B, 0	
8993 055660	116	105	107		.ASCIZ	:D @ (R)+;	
8994 055664	377				.ASCIZ	:NEG!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8995 055666	055220	055453	000000	EM110:	.EVEN		
8996 055674	101	102	123		.WORD	EM66B, EM76B, 0	
8997 055700	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
8998 055702	055650	052552	000000	EM111:	.EVEN		
8999 055710	101	102	123		.WORD	EM106B, EM4D, 0	
9000 055714	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
9001 055716	055650	052531	000000	EM112:	.EVEN		
9002 055724	101	102	123		.WORD	EM106B, EM4B, 0	
9003 055730	377				.ASCIZ	:ABS!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
9004 055732	055650	052436	000000	EM113:	.EVEN		
9005 055740	116	105	107		.WORD	EM106B, EM2B, 0	
9006 055744	377				.ASCIZ	:NEG!	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
					.EVEN		

ERROR MESSAGES

9007 055746	055754	055453	000000		.WORD	EM113B,EM76B,0
9008 055754	104	040	100	EM113B:	.ASCIZ	:D @-(R)
9009 055764	116	105	107	EM114:	.ASCIZ	:NEG!
9010 055770	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9011 055772	055754	052552	000000	EM115:	.WORD	EM113B,EM4D,0
9012 056000	116	105	107		.ASCIZ	:NEG!
9013 056004	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9014 056006	055754	052531	000000	EM116:	.WORD	EM113B,EM4B,0
9015 056014	116	105	107		.ASCIZ	:NEG!
9016 056020	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9017 056022	055754	052436	000000	EM117:	.WORD	EM113B,EM2B,0
9018 056030	101	102	123		.ASCIZ	:ABS!
9019 056034	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9020 056036	056044	055453	000000	EM117B:	.WORD	EM117B,EM76B,0
9021 056044	104	040	116		.ASCIZ	:D N(R)
9022 056053	101	102	123	EM120:	.ASCIZ	:ABS!
9023 056057	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9024 056060	056044	052552	000000	EM121:	.WORD	EM117B,EM4D,0
9025 056066	101	102	123		.ASCIZ	:ABS!
9026 056072	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9027 056074	056044	052531	000000	EM122:	.WORD	EM117B,EM4B,0
9028 056102	101	102	123		.ASCIZ	:ABS!
9029 056106	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9030 056110	056044	052436	000000	EM123:	.WORD	EM117B,EM2B,0
9031 056116	116	105	107		.ASCIZ	:NEG!
9032 056122	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9033 056124	056132	055453	000000	EM123B:	.WORD	EM123B,EM76B,0
9034 056132	104	040	100		.ASCIZ	:D @N(R)
9035 056142	116	105	107	EM124:	.ASCIZ	:NEG!
9036 056146	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9037 056150	056132	052552	000000	EM125:	.WORD	EM123B,EM4D,0
9038 056156	116	105	107		.ASCIZ	:NEG!
9039 056162	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9040 056164	056132	052531	000000	EM126:	.WORD	EM123B,EM4B,0
9041 056172	116	105	107		.ASCIZ	:NEG!
9042 056176	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9043 056200	056132	052436	000000	EM127:	.WORD	EM123B,EM2B,0
9044 056206	116	105	107		.ASCIZ	:NEG!
9045 056212	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9046 056214	056222	055453	000000	EM127B:	.WORD	EM127B,EM76B,0
9047 056222	104	040	116		.ASCIZ	:D N(R?)
9048 056232	116	105	107	EM130:	.ASCIZ	:NEG!
9049 056236	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9050 056240	056222	052552	000000		.WORD	EM127B,EM4D,0

9051 056246 116 105 107 EM131: .ASCIZ 'NEG'
9052 056252 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM127B,EM2B,0
9053 056254 056222 052436 000000
9054 056262 101 102 123 EM132: .ASCIZ 'ABS'
9055 056266 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM132B,EM76B,0
9056 056270 056276 055453 000000
9057 056276 104 040 100 EM132B: .ASCIZ 'D @N(R7)'
9058 056307 101 102 123 EM133: .ASCIZ 'ABS'
9059 056313 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM132B,EM4D,0
9060 056314 056276 052552 000000
9061 056322 101 102 123 EM134: .ASCIZ 'ABS'
9062 056326 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM132B,EM2B,0
9063 056330 056276 052436 000000
9064 056336 116 105 107 EM135: .ASCIZ 'NEGD A FAILED.'<CRLF>'XOR SIGN BIT ST 336'
9065 056401 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM4D,0
9066 056402 052552 000000
9067 056406 116 105 107 EM136: .ASCIZ 'NEGD A'
9068 056415 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM4D,0
9069 056416 052436 000000
9070 056422 116 105 107 EM137: .ASCIZ 'NEGD A'
9071 056431 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM2B,0
9072 056432 052436 000000
9073 056436 116 105 107 EM140: .ASCIZ 'NEG'
9074 056442 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM66B,EM4D,0
9075 056444 055220 052552 000000
9076 056452 116 105 107 EM141: .ASCIZ 'NEG'
9077 056456 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM66B,EM4B,EM141C,EM4D,0
9078 056460 055220 052531 056472
9079 056472 040 123 120 EM141C: .ASCIZ 'SPECIAL DEST'
9080 056510 116 105 107 EM142: .ASCIZ 'NEG'
9081 056514 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM66B,EM2B,0
9082 056516 055220 052436 000000
9083 056524 116 105 107 EM143: .ASCIZ 'NEG'
9084 056530 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM76A,EM4D,0
9085 056532 055444 052552 000000
9086 056540 116 105 107 EM144: .ASCIZ 'NEG'
9087 056544 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM76A,EM4B,EM141C,0
9088 056546 055444 052531 056472
9089 056556 116 105 107 EM145: .ASCIZ 'NEG'
9090 056562 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM76A,EM2B,0
9091 056564 055444 052436 000000
9092 056572 116 105 107 EM146: .ASCIZ 'NEG'
9093 056576 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN

ERROR MESSAGES

9094 05660C	055562	052552	000000		.WORD	EM102B,EM4D,0
9095 056606	116	105	107	EM147:	.ASCIZ	:NEG!
9096 056612	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9097 056614	055562	052531	056472	EM150:	.EVEN	
9098 056626	116	105	107		.WORD	EM102B,EM4B,EM141C,EM4D,0
9099 056632	377				.ASCIZ	:NEG!
9100 056634	055562	052436	000000	EM151:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9101 056642	116	105	107		.EVEN	
9102 056646	377				.WORD	EM102B,EM2B,0
9103 056650	055650	052552	000000	EM152:	.ASCIZ	:NEG!
9104 056656	116	105	107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9105 056662	377				.EVEN	
9106 056664	055650	052531	056472	EM153:	.WORD	EM106B,EM4D,0
9107 056676	116	105	107		.ASCIZ	:NEG!
9108 056702	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9109 056704	055650	052436	000000	EM154:	.EVEN	
9110 056712	116	105	107		.WORD	EM106B,EM2B,0
9111 056716	377				.ASCIZ	:NEG!
9112 056720	055754	052552	000000	EM155:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9113 056726	116	105	107		.EVEN	
9114 056732	377				.WORD	EM113B,EM4D,0
9115 056734	055754	052531	056472	EM156:	.ASCIZ	:NEG!
9116 056746	116	105	107		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9117 056752	377				.EVEN	
9118 056754	055754	052436	000000	EM157:	.WORD	EM113B,EM2B,0
9119 056762	116	105	107		.ASCIZ	:NEG!
9120 056766	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9121 056770	056776	052552	000000	EM157B:	.EVEN	
9122 056776	106	040	050		.WORD	EM157B,EM4D,0
9123 057005	116	105	107	EM160:	.ASCIZ	:F (R)+;
9124 057011	377				.ASCIZ	:NEG!
9125 057012	056776	052531	057026	EM160B:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9126 057026	056	040	102		.EVEN	
9127 057053	116	105	107	EM161:	.WORD	EM157B,EM4B,EM160B,EM141C,EM4D,0
9128 057057	377				.ASCIZ	:. BAD CONSTANT USED.!
9129 057060	056776	052436	000000	EM161:	.BYTE	:NEG!
9130 057066	116	105	107		.EVEN	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9131 057072	377				.WORD	EM157B,EM2B,0
9132 057074	057102	052552	000000	EM162:	.ASCIZ	:NEG!
9133 057102	104	040	050	EM162B:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9134 057112	116	105	107		.EVEN	
9135 057116	377			EM163:	.WORD	EM162B,EM4D,0
9136 057120	057102	052436	000000		.ASCIZ	:D (R7)+;
9137 057126	120	103	040	EM164:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
					.EVEN	
					.WORD	EM162B,EM2B,0
					.ASCIZ	:PC BAD AFTER NEG!

9138 057147 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9139 057150 057102 057026 000000 .WORD EM162B,EM160B,0
9140 057156 116 105 107 .WORD :NEG:
9141 057162 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9142 057164 055220 052552 000000 .WORD EM66B,EM4D,0
9143 057172 101 102 123 .WORD :ABS:
9144 057176 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9145 057200 055220 052552 000000 .WORD EM66B,EM4D,0
9146 057206 124 123 124 .WORD :TST:
9147 057212 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9148 057214 055220 052552 000000 .WORD EM66B,EM4D,0
9149 057222 116 105 107 .WORD :NEG:
9150 057226 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9151 057230 055220 052436 000000 .WORD EM66B,EM2B,0
9152 057236 101 102 123 .WORD :ABS:
9153 057242 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9154 057244 055220 052436 000000 .WORD EM66B,EM2B,0
9155 057252 124 123 124 .WORD :TST:
9156 057256 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9157 057260 055220 052436 000000 .WORD EM66B,EM2B,0
9158 057266 116 105 107 .WORD :NEG:
9159 057272 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9160 057274 055220 052466 000000 .WORD EM66B,EM3B,0
9161 057302 101 102 123 .WORD :ABS:
9162 057306 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9163 057310 055220 052466 000000 .WORD EM66B,EM3B,0
9164 057316 124 123 124 .WORD :TST:
9165 057322 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9166 057324 055220 052466 000000 .WORD EM66B,EM3B,0
9167 057332 116 105 107 .WORD :NEG:
9168 057336 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9169 057340 057346 052436 000000 .WORD EM176B,EM2B,0
9170 057346 106 040 101 .WORD :IF AC?:
9171 057354 120 117 127 .WORD :POWER MONITOR BIT FOUND SET:
9172 057410 116 105 107 .WORD :NEG:
9173 057414 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9174 057416 055220 052552 057426 .WORD EM66B,EM4D,EM200C,0
9175 057426 200 130 117 .WORD <CRLF>:XOR SIGN BIT FAILED ST 336.:
9176 057463 116 105 107 .WORD :NEG:
9177 057467 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9178 057470 055220 052436 .WORD EM66B,EM2B
9179 057474 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
057476 052653 054230 052662 .WORD CRBUT,IENBT,PRST,N3,N3,N6,WENTTO,NO,N5,N3,INSTOF,N4,N5,N3,0

9180 057534 116 105 107 EM202: .ASCIZ !NEG:
9181 057540 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM2B
9182 057542 055220 052436 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9183 057546 377 .WORD
.BYTE
.EVEN
.WORD
.ASCIZ CRBUT,IENBT,PRST,N3,N3,N6,WENTTO,N4,N5,N3,INSTOF,NO,NS,N3,0
9184 05550 052653 054230 052662 101 102 123 EM203: .BYTE !ABS:
9185 057606 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM4D
9186 057614 055220 052552 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9187 057620 377 .EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ CRBUT,IOP1B,PRST,NO,N5,N5,WENTTO,N3,N3,N6,INSTOF,N3,N3,N5,OR
9188 057622 052653 057723 052662 054 040 117 OR: .WORD CRBUT,IENBT,PRST,N3,N3,N5,WENTTO,N4,N5,N2,INSTOF,NO,NS,N2,0
9189 057716 117 120 061 IOP1B: .ASCIZ , OR:
9190 057723 101 102 123 EM204: .ASCIZ IOP1B:
9191 057730 377 .ASCIZ !ABS:
9192 057734 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.ASCIZ EM66B,EM4D,EM204C,0
9193 057736 055220 052552 057746 200 130 117 EM204C: .ASCIZ <CRLF>!XOR SIGN BIT FAILED ST 452.:
9194 057746 124 123 124 EM205: .ASCIZ !TST:
9195 060003 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM4D
9196 060007 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9197 060010 055220 052552 060016 052653 057723 052662 124 123 124 EM206: .WORD CRBUT,IOP1B,PRST,NO,N5,N5,WENTTO,N3,N3,N6,INSTOF,N3,N3,N4,0
9199 060054 377 .ASCIZ !TST:
9200 060060 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM2B
9201 060062 377 055220 052436 060066 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9202 060066 377 .EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ CRBUT,IENBT,PRST,N3,N3,N4,WENTTO,N4,N5,N3,INSTOF,NO,NS,N3,0
9203 060070 052653 054230 052662 060126 124 123 124 EM207: .WORD !TST:
9204 060132 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM4D
9205 060134 055220 052552 060140 377 052653 057723 052662 124 123 124 EM210: .WORD CRBUT,IOP1B,PRST,NO,N5,N7,WENTTO,N3,N3,N5,INSTOF,N3,N3,N4,0
9207 060200 124 123 124 EM210: .ASCIZ !TST:
9208 060204 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM4D
9209 060206 055220 052552 060214 052653 054230 052662 124 123 124 EM211: .WORD CRBUT,IENBT,PRST,N3,N3,N4,WENTTO,NO,NS,N3,INSTOF,N4,N5,N3,0
9211 060252 124 123 124 EM211: .ASCIZ !TST:
9212 060256 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
.WORD
.BYTE
.EVEN
.WORD
.ASCIZ EM66B,EM4D,CRBUT,IOP1B,PRST,N2,NS,NS,WENTTO,N3132,INSTOF,N3,N1,NO,0
9213 060260 055220 052552 052653 063 061 061 N3132: .WORD !311 OR 312:
9214 060316 124 123 124 EM212: .ASCIZ !TST:
9215 060331 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9216 060335 377 .EVEN

ERROR MESSAGES

9217 060336	055220	052436		.EVEN	EM66B,EM2B	
9218 060342	377			.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
9219 060344	052653	054230	052662	EM213:	.WORD	CRBUT,IENBT,PRST,N3,N1,NO,WENTTO,N4,NO,INSTOF,NO,NO,N2,0
9220 060402	124	123	124		.ASCIZ	:TST!
9221 060406	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9222 060410	055220	052436	060460		.EVEN	
9223 060420	377				.WORD	EM66B,EM2B,EM213C,EM213D
9224 060422	052653	060506	052662		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9225 060460	040	106	111	EM213C:	.ASCIZ	CRBUT,IFIUV,PRST,N2,N5,N7,WENTTO,N3,N5,NS,INSTOF,N2,N5,NS,0
9226 060470	054	040	117	EM213D:	.ASCIZ	:FIUV=0!
9227 060506	106	111	125	IFIUV:	.ASCIZ	,OPERAND=-0.!
9228 060513	124	123	124	EM214:	.ASCIZ	:FIUV!
9229 060517	377				.BYTE	:TST!
9230 060520	055220	052436	060570		.EVEN	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9231 060530	377				.WORD	EM66B,EM2B,EM214B,EM213D
9232 060532	052653	060506	052662		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9233 060570	040	106	111	EM214B:	.ASCIZ	CRBUT,IFIUV,PRST,N2,N5,N7,WENTTO,N2,N5,NS,INSTOF,N3,N5,NS,0
9234 060600	120	000		EM215:	.ASCIZ	:FIUV=1!
9235 060602	377				.BYTE	:P!
9236 060604	060647	060635	060664		.EVEN	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9237 060624	067	064	066	N746T2:	.ASCIZ	PCBAD,NEGDNR,BADCON,N746T2,BUTIN,EM141C,EM4D,0
9238 060635	116	105	107		.ASCIZ	:746 746.!
9239 060647	103	040	102	NEGDNR:	.ASCIZ	:NEGD N(R)!
9240 060664	056	040	102	PCBAD:	.ASCIZ	:C BAD AFTER :
9241 060711	056	000		BADCON:	.ASCIZ	:.. BAD CONSTANT USED :
9242 060713	200	117	122	PERIOD:	.ASCIZ	:..
9243 060735	116	105	107	BUTIN:	.ASCIZ	<CRLF>;OR (BUT FDST) IN:
9244 060741	377			EM216:	.ASCIZ	:NEG!
9245 060742	056044	052552	000000		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9246 060750	116	105	107	EM217:	.EVEN	EM117B,EM4D,0
9247 060754	377				.WORD	:NEG!
9248 060756	056044	052531	056472		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9249 060770	116	105	107	EM220:	.EVEN	EM117B,EM4B,EM141C,EM4D,0
9250 060774	377				.WORD	:NEG!
9251 060776	056044	052436	000000	EM221:	.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9252 061004	120	000			.EVEN	EM117B,EM28,0
9253 061006	377				.WORD	:P!
9254 061010	060647	061041	060664		.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9255 061030	067	064	067	N747T2:	.ASCIZ	PCBAD,NEGDAR,BADCON,N747T2,BUTIN,EM141C,EM4D,0
9256 061041	116	105	107		.ASCIZ	:747 747.!
9257 061041	116	105	107	NEGDAR:	.ASCIZ	:NEGD A(R)!
9258 061054	116	105	107	EM222:	.ASCIZ	:NEG!
9259 061060	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9260 061062	056132	052552	000000	EM223:	.EVEN	EM123B,EM4D,0
9261 061070	116	105	107		.WORD	:NEG!
9262 061074	377				.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN

9264 061076 056132 052531 056472 .EVEN
 9265 061110 116 105 107 .WORD EM224: .WORD EM123B,EM4B,EM141C,EM4D,0
 9266 061114 377 .ASCIZ ;NEG:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9267 061116 056132 052436 000000 .EVEN
 9268 061124 114 000 .WORD EM225: .WORD EM123B,EM2B,0
 9269 061126 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9270 061130 061136 052531 000000 .EVEN
 9271 061136 104 106 120 .WORD EM225B: .WORD EM225B,EM4B,0
 9272 061147 114 000 .ASCIZ ;DFPS (R):
 9273 061151 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9274 061152 061136 052436 000000 .EVEN
 9275 061160 114 000 .WORD EM227: .WORD EM225B,EM2B,0
 9276 061162 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9277 061164 061136 061172 000000 .EVEN
 9278 061172 040 124 122 .WORD EM227B: .WORD EM225B,EM227B,0
 9279 061211 114 000 .ASCIZ ;TRAPPED TO 4.:
 9280 061213 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9281 061214 061222 052531 000000 .EVEN
 9282 061222 104 106 120 .WORD EM230B: .WORD EM230B,EM4B,0
 9283 061234 114 000 .ASCIZ ;DFPS (R)+:
 9284 061236 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9285 061240 061222 052436 000000 .EVEN
 9286 061246 114 000 .WORD EM232: .WORD EM230B,EM2B,0
 9287 061250 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9288 061252 061222 061172 000000 .EVEN
 9289 061260 114 000 .WORD EM233: .WORD EM230B,EM227B,0
 9290 061262 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9291 061264 061272 052531 000000 .EVEN
 9292 061272 104 106 120 .WORD EM233B: .WORD EM233B,EM4B,0
 9293 061304 114 000 .ASCIZ ;DFPS -(R):
 9294 061306 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9295 061310 061272 052436 000000 .EVEN
 9296 061316 114 000 .WORD EM235: .WORD EM233B,EM2B,0
 9297 061320 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9298 061322 061272 061172 000000 .EVEN
 9299 061330 114 000 .WORD EM236: .WORD EM233B,EM227B,0
 9300 061332 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9301 061334 061342 052531 000000 .EVEN
 9302 061342 104 106 120 .WORD EM236B: .WORD EM236B,EM4B,0
 9303 061355 114 000 .ASCIZ ;DFPS @R+:
 9304 061357 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9305 061360 061342 052436 000000 .EVEN
 9306 061366 114 000 .WORD EM240: .WORD EM236B,EM2B,0
 9307 061370 377 .ASCIZ ;L:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN

9308 061372	061342	061172	000000		.EVEN	.WORD	EM236B,EM227B,0
9309 061400	114	000		EM241:	.ASCIZ	:L:	
9310 061402	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9311 061404	061412	052531	000000	EM241B:	.WORD	EM241B,EM4B,0	
9312 061412	104	106	120		.ASCIZ	:DFPS A-(R):	
9313 061425	114	000		EM242:	.ASCIZ	:L:	
9314 061427	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9315 061430	061412	052436	000000	EM243:	.EVEN	.WORD	EM241B,EM2B,0
9316 061436	114	000			.ASCIZ	:L:	
9317 061440	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9318 061442	061412	061172	000000	EM244:	.EVEN	.WORD	EM241B,EM227B,0
9319 061450	114	000			.ASCIZ	:L:	
9320 061452	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9321 061454	061462	052531	000000	EM244B:	.EVEN	.WORD	EM244B,EM4B,0
9322 061462	104	106	120		.ASCIZ	:DFPS N(R):	
9323 061474	114	000		EM245:	.ASCIZ	:L:	
9324 061476	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9325 061500	061462	052436	000000	EM246:	.EVEN	.WORD	EM244B,EM2B,0
9326 061506	120	103	040		.ASCIZ	:IPC BAD AFTER :	
9327 061524	376				.BYTE	376	;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW
9328 061526	000246	000252	000254		.WORD	246,252,254,0	
9329 061536	061544	061626	061654	EM246B:	.WORD	EM246B,EM252B,EM254B	
9330 061544	114	104	106		.ASCIZ	:LDFPS N(R):	
9331 061557	114	000		EM247:	.ASCIZ	:L:	
9332 061561	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9333 061562	061462	061172	000000	EM250:	.EVEN	.WORD	EM244B,EM227B,0
9334 061570	114	000			.ASCIZ	:L:	
9335 061572	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9336 061574	061602	052531	000000	EM250B:	.EVEN	.WORD	EM250B,EM4B,0
9337 061602	104	106	120		.ASCIZ	:DFPS BN(R):	
9338 061615	114	000		EM251:	.ASCIZ	:L:	
9339 061617	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9340 061620	061602	052436	000000		.EVEN	.WORD	EM250B,EM2B,0
9341 061506	114	104	106	EM252=EM246	.WORD	EM250B,EM2B,0	
9342 061626	114	000		EM252B:	.ASCIZ	:LDFPS BN(R):	
9343 061642	114			EM253:	.ASCIZ	:L:	
9344 061644	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9345 061646	061602	061172	000000	EM254=EM246	.EVEN	.WORD	EM250B,EM227B,0
9346 061506	114	104	103	EM254B:	.ASCIZ	:LDCLD (R7)+,A:	
9347 061654	114	104	103	EM255:	.ASCIZ	:LDCLD (R7)+,A:	
9348 061672	114	104	103		.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9349 061710	377				.EVEN	.WORD	EM227B,0
9350 061712	061172	000000		EM256:	.ASCIZ	:L:	
9351 061716	114	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9352 061720	377						

9353 061722 061730 052531 000000 .EVEN
9354 061730 104 103 114 EM256B: .WORD EM256B,EM4B,0
9355 061744 114 000 .ASCIZ :DCLD (R)+,A:
9356 061746 377 .BYTE :L:
.EVEN
9357 061750 061730 052436 000000 EM260: .WORD EM256B,EM2B,0
9358 061756 114 000 .ASCIZ :L:
9359 061760 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9360 061762 061770 052552 000000 EM260B: .WORD EM260B,EM4D,0
9361 061770 104 103 111 .ASCIZ :DCIF OR LDCLF (R),A:
9362 062014 114 000 .ASCIZ :L:
9363 062015 377 .BYTF 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9364 062020 061770 052436 000000 EM262: .WORD EM260B,EM2B,0
9365 062026 114 000 .ASCIZ :L:
9366 062030 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9367 062032 062101 052552 .WORD EM262B,EM4D
9368 062036 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
062040 052653 062076 052662 .WORD CRBUT,IFL,PRST,N2,N7,N7,WENTTO,N3,N0,N0,INSTOF,N3,N0,N1,0
9369 062076 106 114 000 IFL: .ASCIZ :FL:
9370 062101 104 103 111 EM262B: .ASCIZ :DCIF (R),A:
9371 062114 114 000 EM263: .ASCIZ :L:
9372 062116 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9373 062120 062126 052436 000000 EM263B: .WORD EM263B,EM2B,0
9374 062126 104 103 114 .ASCIZ :DCLF (R),A:
9375 062141 114 000 EM264: .ASCIZ :L:
9376 062143 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9377 062144 062101 052552 062154 EM264C: .WORD EM262B,EM4D,EM264C,0
9378 062154 200 125 123 EM265: .ASCIZ <CRLF>USED CONSTANT 237 INSTEAD OF 217 ST 107.:
9379 062226 114 000 .ASCIZ :L:
9380 062230 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9381 062232 061770 052552 062242 EM265C: .WORD EM260B,EM4D,EM265C,0
9382 062242 200 123 105 .ASCIZ <CRLF>SET SIGN BIT FAILED ST 146.:
9383 062277 114 000 EM266: .ASCIZ :L:
9384 062301 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9385 062302 061770 052552 .WORD EM260B,EM4D
9386 062306 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
062310 052653 062346 052662 IXNBT: .WORD CRBUT,IXNBT,PRST,N3,N7,N2,WENTTO,N1,N5,N2,INSTOF,N1,N1,N2,0
9387 062346 130 116 102 .ASCIZ :XNBT:
9388 062353 114 000 EM267: .ASCIZ :L:
9389 062355 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
.EVEN
9390 062356 062126 052552 062366 EM267C: .WORD EM263B,EM4D,EM267C,0
9391 062366 200 125 123 EM270: .ASCIZ <CRLF>USED CONSTANT 217 INSTEAD OF 237 ST 107.:
9392 062440 114 000 .ASCIZ :L:
9393 062442 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9394 062444 062126 052552 062454 .WORD EM263B,EM4D,EM270C,0

ERROR MESSAGES

9395 062454 040 122 117 EM270C: .ASCIZ | ROUND ERROR.:
 9396 062472 114 000 117 EM271: .ASCIZ | L:
 9397 062474 377 000 117 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 .ASCIZ
 .ASCIZ
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9398 062476 062126 052552 062506 EM271C: .WORD EM263B,EM4D,EM271C,0
 9399 062506 040 124 122 EM271C: .ASCIZ | TRUNCATION ERROR..
 9400 062531 114 000 117 EM272: .ASCIZ | L:
 9401 062533 377 000 117 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 .ASCIZ
 <CRLF>|R14 NOT INCREMENTED ST 630..
 9402 062534 061770 052552 062544 EM272C: .ASCIZ
 9403 062544 200 122 061 EM272C: .ASCIZ | L:
 9404 062601 114 000 117 EM273: .ASCIZ
 9405 062603 377 000 117 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 .ASCIZ
 .ASCIZ
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9406 062604 062612 052552 000000 EM273B: .WORD EM273B,EM4D,0
 9407 062612 104 103 111 EM273B: .ASCIZ | DCID OR LDCLD (R),A:
 9408 062636 114 000 111 EM274: .ASCIZ | L:
 9409 062640 377 000 111 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 EM273B,EM2B,0
 9410 062642 062612 052436 000000 EM275: .ASCIZ | L:
 9411 062650 114 000 111 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9412 062652 377 000 111 .EVEN
 .WORD
 EM275B,EM4D
 9413 062654 062720 052552 000000 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9414 062660 377 000 111 .WORD
 .BYTE
 .ASCIZ
 .ASCIZ
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 CRBUT,IFL,PRST,N2,N7,N7,WENTTO,N3,NO,NO,INSTOF,N3,NO,N1,0
 9415 062662 052653 062076 052662 EM275B: .ASCIZ | DCID (R),A:
 9416 062720 104 103 111 EM276: .ASCIZ | L:
 9417 062733 114 000 111 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9418 062735 377 000 111 .EVEN
 .WORD
 EM275B,EM4D,EM276C,0
 9419 062746 200 125 123 EM276C: .ASCIZ | <CRLF>|USED CONSTANT 237 INSTEAD OF 217 ST 107.:
 9420 063020 114 000 123 EM277: .ASCIZ | L:
 9421 063022 377 000 123 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 EM275B,EM4D,EM277C,0
 9422 063024 062720 052552 063034 EM277C: .ASCIZ | <CRLF>|SET SIGN FAILED ST 146.:
 9423 063034 200 123 105 EM300: .ASCIZ | LDCLD (R),A:
 9424 063065 114 104 103 EM300: .ASCIZ | L:
 9425 063101 377 103 103 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 EM4D,EM300C,0
 9426 063102 052552 063110 000000 EM300C: .ASCIZ | <CRLF>|USED CONSTANT 217 INSTEAD OF 237 ST 107.:
 9427 063110 200 125 123 EM301: .ASCIZ | L:
 9428 063162 114 000 123 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9429 063164 377 000 123 .EVEN
 .WORD
 EM4D,EM300C,0
 9430 063166 063174 052552 000000 EM301B: .ASCIZ | <CRLF>|USED CONSTANT 217 INSTEAD OF 237 ST 107.:
 9431 063174 104 105 130 EM301B: .ASCIZ | DEXP (R),A:
 9432 063207 114 000 130 EM301B: .ASCIZ | L:
 9433 063211 377 000 130 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 .EVEN
 .WORD
 EM301B,EM2B,0
 9434 063212 063174 052436 000000 EM303: .ASCIZ | L:
 9435 063220 114 000 111 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9436 063222 377 000 111 .EVEN
 .WORD
 EM301B,EM38,0
 9437 063224 063174 052466 000000 EM304: .ASCIZ | L:
 9438 063232 114 000 111

ERROR MESSAGES

9439 063234	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9440 063236	063174	052552	063246		.EVEN		
9441 063246	200	105	130		.WORD	EM301B,EM4D,EM304C,0	
9442 063312	114	000			.ASCIZ	<CRLF> EXCESS 200 CALCULATION ST 624 BAD.:	
9443 063314	377				.ASCIZ	:L:	
9444 063316	063174	052436	063326		.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9445 063326	200	050	102		.EVEN		
9446 063406	114	000			.WORD	EM301B,EM2B,EM305C,0	
9447 063410	377				.ASCIZ	<CRLF> (BUT EM8T,EZBT,XNBT) ST 625 DID NOT GO TO 304.:	
9448 063412	063174	052436			.ASCIZ	:L:	
9449 063416	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9450 063420	052653	053724	052662		.EVEN		
9451 063456	052653	053724	052662		.WORD	CRBUT,IEZBT,PRST,N5,N4,N4,WENTTO,N5,NO,N4,INSTOF,N7,NO,N4,OR	
9452 063514	114	000			.WORD	CRBUT,IEZBT,PRST,N7,NO,N4,WENTTO,N2,N6,N4,INSTOF,NO,N6,N4,0	
9453 063516	377				.ASCIZ	:L:	
9454 063520	063174	052552			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9455 063524	377				.EVEN		
9456 063526	052653	053724	052662		.WORD	EM301B,EM4D	
9457 063564	114	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9458 063566	377				.EVEN		
9459 063570	063174	052436			.WORD	CRBUT,IEZBT,PRST,N7,NO,N4,WENTTO,NO,N6,N4,INSTOF,N2,N6,N4,0	
9460 063574	377				.BYTE	:L:	
9461 063576	052653	063634	052662		.EVEN	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9462 063634	106	111	125		.WORD	EM301B,EM4D	
9463 063640	114	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9464 063642	377				.EVEN		
9465 063644	063174	052552			.WORD	CRBUT,IFIU,PRST,N2,N6,N4,WENTTO,N1,N1,N5,INSTOF,N1,N5,N5,0	
9466 063650	377				.BYTE	:FIU:	
9467 063652	052653	063634	052662		.EVEN	:L:	
9468 063710	114	000			.WORD	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9469 063712	377				.ASCIZ	CRBUT,IFIU,PRST,N2,N6,N4,WENTTO,N1,N5,N5,INSTOF,N1,N1,N5,0	
9470 063714	063174	052552			.BYTE	:L:	
9471 063720	377				.EVEN	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9472 063722	052653	053724	052662		.WORD	EM301B,EM4D	
9473 063760	114	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9474 063762	377				.EVEN		
9475 063772	052653	063634	052662		.WORD	CRBUT,IFIU,PRST,N5,NO,N4,WENTTO,N1,N5,N5,INSTOF,N1,N1,N5,0	
9476 064030	114	000			.BYTE	:L:	
9477 064032	377				.EVEN	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
9478 064034	063174	052552			.WORD	EM301B,EM4D	

ERROR MESSAGES

9475 064040	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9476 064042	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N1, N0, N4, WENTTO, N1, N1, N6, INSTOF, N1, N3, N6, 0
9476 064100	114	000	EM315: .ASCIZ ':L:'
9477 064102	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9478 064104	063174	052552	.EVEN .WORD EM301B, EM4D
9479 064110	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9480 064112	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N1, N0, N4, WENTTO, N1, N3, N6, INSTOF, N1, N1, N6, 0
9480 064150	114	000	EM316: .ASCIZ ':L:'
9481 064152	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9482 064154	063174	052552	.EVEN .WORD EM301B, EM4D
9483 064160	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9484 064162	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N1, N4, N4, WENTTO, N1, N1, N6, INSTOF, N1, N3, N6, 0
9484 064220	114	000	EM317: .ASCIZ ':L:'
9485 064222	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9486 064224	063174	052552	.EVEN .WORD EM301B, EM4D
9487 064230	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9488 064232	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N1, N4, N4, WENTTO, N1, N3, N6, INSTOF, N1, N1, N6, 0
9488 064270	114	000	EM320: .ASCIZ ':L:'
9489 064272	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9490 064274	063174	052552	.EVEN .WORD EM301B, EM4D
9491 064300	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9492 064302	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N3, N4, N4, WENTTO, N1, N1, N6, INSTOF, N1, N3, N6, 0
9492 064340	114	000	EM321: .ASCIZ ':L:'
9493 064342	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9494 064344	063174	052552	.EVEN .WORD EM301B, EM4D
9495 064350	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9496 064352	052653	054626	.EVEN .WORD CRBUT, IFIV, PRST, N3, N4, N4, WENTTO, N1, N3, N6, INSTOF, N1, N1, N6, 0
9496 064410	123	000	EM322: .ASCIZ ':S:'
9497 064412	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9498 064414	064422	052552	.WORD EM322B, EM4D, 0
9499 064422	124	103	.ASCIZ :TCDI OR STCDL (R), A!
9500 064446	123	000	EM323: .ASCIZ ':S:'
9501 064450	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9502 064452	064422	052436	.EVEN .WORD EM322B, EM2B, 0
9503 064460	123	000	EM324: .ASCIZ ':S:'
9504 064462	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9505 064464	064422	052466	.EVEN .WORD EM322B, EM3B, 0
9506 064472	123	000	EM325: .ASCIZ ':S:'
9507 064474	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9508 064476	064506	052436	.EVEN .WORD EM325B, EM2B, EM325C, 0
9509 064506	124	103	EM325B: .ASCIZ :TCDL (R), A!
9510 064521	200	103	EM325C: .ASCIZ <CRLF>:CLEAR FLAG ST 774 FAILED, OR:

ERROR MESSAGES

9511 064557 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 064560 052653 054764 052662 .EVEN WORD CRBUT,IFLAG,PRST,N6,N6,N2,WENTTO,N3,N6,N5,INSTOF,N3,N6,N1,0
 9512 064472 EM326=EM325
 9513 064616 123 000 EM327: .ASCIZ :S:
 9514 064620 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9515 064622 064506 052552 .EVEN WORD EM325B,EM4D
 9516 064626 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 064630 052653 054230 052662 EM330: .WORD CRBUT,IENBT,PRST,N6,N3,N2,WENTTO,N4,N7,N3,INSTOF,N0,N7,N3,0
 9517 064666 123 000 .ASCIZ :S:
 9518 064670 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9519 064672 064506 052436 .EVEN WORD EM325B,EM2B
 9520 064676 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 064700 052653 064736 052662 IFIC: .WORD CRBUT,IFIC,PRST,N0,N0,N4,WENTTO,N3,N0,N5,INSTOF,N3,N1,N5,0
 9521 064736 106 111 103 IFIC: .ASCIZ :IFIC:
 9522 064742 123 000 EM331: .ASCIZ :S:
 9523 064744 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9524 064746 064506 052436 .EVEN WORD EM325B,EM2B
 9525 064752 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 064754 052653 064736 052662 EM332: .WORD CRBUT,IFIC,PRST,N0,N0,N4,WENTTO,N3,N1,N5,INSTOF,N3,N0,N5,0
 9526 065012 123 000 .ASCIZ :S:
 9527 065014 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9528 065016 065026 052552 065041 EM332B: .WORD EM332B,EM4D,EM332C,0
 9529 065026 124 103 104 .ASCIZ :TCDI (R),A:
 9530 065041 200 125 123 EM332C: .ASCIZ <CRLF>;USED CONSTANT 37 INSTEAD OF 17 ST 66.:
 9531 064446 EM333=EM323
 9532 065110 123 000 EM334: .ASCIZ :S:
 9533 065112 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9534 065114 065026 052436 065124 EM334C: .WORD EM332B,EM2B,EM334C,0
 9535 065124 200 125 123 EM335: .ASCIZ <CRLF>;USED CONSTANT 37 INSTEAD OF 17 ST 66.:
 9536 065173 123 000 .ASCIZ :S:
 9537 065175 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9538 065176 065026 052552 .EVEN WORD EM332B,EM4D
 9539 065202 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 065204 052653 054230 052662 EM336: .WORD CRBUT,IENBT,PRST,N6,N3,N2,WENTTO,N0,N7,N3,INSTOF,N4,N7,N3,0
 9540 065242 123 000 .ASCIZ :S:
 9541 065244 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9542 065246 065026 052436 065260 EM336C: .WORD EM332B,EM2B,EM336C,EM4D,0
 9543 065260 200 123 105 EM337: .ASCIZ <CRLF>;SET FN ST 473:
 9544 065277 123 000 .ASCIZ :S:
 9545 065301 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9546 065302 064506 052552 .EVEN WORD EM325B,EM4D
 9547 065306 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 065310 052653 065346 052662 .WORD CRBUT,ICOUT,PRST,N2,N7,N5,WENTTO,N0,N7,N4,INSTOF,N2,N7,N4,0

9548 065346 103 117 125 ICOUT: .ASCIZ |COUT:
9549 065353 123 000 EM340: .ASCIZ |S!
9550 065355 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9551 065356 064506 052552 .WORD EM325B,EM4D
9552 065362 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9553 065364 052653 065346 052662 EM341: .WORD CRBUT,ICOUT,PRST,N2,N7,N5,WENTTO,N2,N7,N4,INSTOF,N0,N7,N4,0
9554 065422 123 000 .ASCIZ |S!
9554 065424 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9555 065426 064506 052436 .WORD EM325B,EM2B
9556 065432 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9557 065434 052653 053724 052662 EM342: .WORD CRBUT,IEZBT,PRST,N3,N7,N7,WENTTO,N6,N3,N3,INSTOF,N4,N3,N3,0
9558 065472 123 000 .ASCIZ |S!
9558 065474 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9559 065476 064506 052552 .WORD EM325B,EM4D
9560 065502 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9561 065504 052653 065346 052662 EM343: .WORD CRBUT,ICOUT,PRST,N3,N6,N0,WENTTO,N6,N5,N4,INSTOF,N4,N5,N4,0
9562 065542 123 000 .ASCIZ |S!
9562 065544 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9563 065546 064506 052552 .WORD EM325B,EM4D
9564 065552 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9565 065554 052653 065612 052662 INBIT: .WORD CRBUT,INBIT,PRST,N6,N5,N4,WENTTO,N5,N3,N1,INSTOF,N4,N3,N1,0
9566 065612 116 102 111 .ASCIZ |INBIT:
9566 065617 123 000 EM344: .ASCIZ |S!
9567 065621 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9568 065622 064506 052552 .WORD EM325B,EM4D
9569 065626 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9570 065630 052653 065346 052662 EM345: .WORD CRBUT,ICOUT,PRST,N3,N6,N0,WENTTO,N4,N5,N4,INSTOF,N6,N5,N4,OR
9570 065666 052653 065612 052662 .WORD CRBUT,INBIT,PRST,N6,N5,N4,WENTTO,N4,N3,N1,INSTOF,N5,N3,N1,0
9571 065724 123 000 .ASCIZ |S!
9572 065726 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9573 065730 065026 052552 .WORD EM332B,EM4D
9574 065734 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9575 065736 052653 062076 052662 EM346: .WORD CRBUT,IFL,PRST,N6,N3,N3,WENTTO,N6,N5,N5,INSTOF,N6,N5,N4,0
9575 065774 123 124 103 .ASCIZ |STCFL (R),A!
9576 066010 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9577 066012 052552 066020 000000 EM346C: .WORD EM4D,EM346C,0
9578 066020 200 132 105 EM347: .ASCIZ <CRLF>|ZERO LOW ORDER PART OF X11 FAILED ST 773.:
9579 066073 123 000 EM347: .ASCIZ |S!
9580 066075 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9581 066076 066104 052552 000000 EM347B: .WORD EM347B,EM4D,0
9582 066104 124 105 130 EM347B: .ASCIZ |TEXP A,(R)
9583 066117 123 000 EM350: .ASCIZ |S!
9584 066121 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN

9585 066122 066104 052436 000000 .EVEN
 9586 066130 115 117 122 EM351: .WORD EM347B,EM2B,0
 9587 066153 127 122 111 .ASCII MORE THAN ONE WORD :
 9588 066224 377 .ASCIZ WRITTEN BY STEXP A,(R).:<CRLF>:ZERO FDFL ST 347:
 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9589 066226 052552 000000 .EVEN
 9590 066232 123 000 EM352: .WORD EM4D,0
 9591 066234 377 .ASCII IS:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9592 066236 066104 052436 .EVEN
 9593 066242 377 .WORD EM347B,EM2B
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9594 066244 052653 054230 052662 .EVEN
 9595 066302 123 000 EM353: .WORD CRBUT,IENBT,PRST,N3,N7,N6,WENTTO,NO,N7,N1,INSTOF,N4,N7,N1,0
 9595 066304 377 .ASCII IS:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9596 066306 066104 052436 .EVEN
 9597 066312 377 .WORD EM347B,EM2B
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9598 066314 052653 053724 052662 .EVEN
 9599 066352 123 000 EM354: .WORD CRBUT,IEZBT,PRST,NO,N7,N1,WENTTO,NO,N7,N2,INSTOF,N2,N7,N2,0
 9599 066354 377 .ASCII IS:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9600 066356 066104 052436 .EVEN
 9601 066357 377 .WORD EM347B,EM2B
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9602 066364 052653 053724 052662 .EVEN
 9603 066422 123 000 EM355: .WORD CRBUT,IEZBT,PRST,NO,N7,N1,WENTTO,N2,N7,N2,INSTOF,NO,N7,N2,0
 9603 066424 377 .ASCII IS:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9604 066426 066104 052436 .EVEN
 9605 066432 377 .WORD EM347B,EM2B
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9606 066434 052653 054230 052662 .EVEN
 9606 066472 123 124 EM356: .WORD CRBUT,IENBT,PRST,N3,N7,N6,WENTTO,N4,N7,N1,INSTOF,NO,N7,N1,0
 9607 066521 377 .ASCII ISTST (R) GOT BAD FEC.:<CRLF>
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9608 066522 066526 000000 .EVEN
 9609 066526 101 106 124 EM356B: .WORD EM356B,0
 9610 066576 123 124 123 .ASCII AFTER EXECUTING AN ILLEGAL FPP OP CODE.:
 9611 066625 377 .ASCII ISTST (R) GOT BAD FEA.:<CRLF>
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9612 066626 066526 000000 .EVEN
 9613 066632 117 116 114 EM360: .WORD EM356B,0
 9614 066675 123 105 124 .ASCII ONLY ONE WORD WRITTEN BY STST (R). :
 9615 066715 377 .ASCII SET FDFL ST 636:
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9616 066716 052552 000000 .EVEN
 9617 066722 123 124 123 EM361: .WORD EM4D,0
 9618 066733 377 .ASCII ISTST (R):
 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9619 066734 052436 000000 .EVEN
 9620 066740 116 117 116 EM362: .WORD EM2B,0
 9621 067006 111 115 120 .ASCII NON-RESIDENT MEMORY MANAGEMENT TRAP - :
 9622 067050 104 111 106 EM363: .ASCII IMPROPER D-SPACE ACCESS ATTEMPTED:
 9623 067116 106 120 120 EM364: .ASCII DIFFERENCE BETWEEN SR1 AND CALCULATED:
 .ASCII IFPP INSTRUCTION FAILED TO ABORT, NOT :

9624 067163 101 114 114 .ASCIZ ALLOWNG EXAMINATION OF SR1:
9625 067216 115 117 104 EM365: .ASCIZ MODE Q INSTRUCTION ABORTED WHEN IT SHOULD NOT HAVE:
9626 067301 106 120 120 EM366: .ASCIZ FPP ACCUMULATOR WAS CHANGED IN THE EXPECTED ABORT:
9627 067364 107 105 116 EM367: .ASCIZ GENERAL REGISTER WAS CHANGED IN THE EXPECTED ABORT:
9628 067447 106 120 120 EM370: .ASCIZ FPP UNABLE TO RESTORE AN AC:
9629 067503 123 124 105 EM371: .ASCII STEXP AUTO INCREMENTED/DECREMENTED R0 INCORRECTLY!<CRLF>
9630 067565 115 067 060 EM372: .ASCIZ M7095 ECO # 10 MIGHT NOT BE INSTALLED:
9631 000000 EM373=0
9632 000000 EM374=0
9633 000000 EM375=0
9634 000000 EM376=0
9635 000000 EM377=0
9636 000000 EM400=0
9637 000000 EM401: .ASCIZ ;S:
9638 067633 123 000 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9639 067635 377 EM401B: .EVEN
9640 067636 067644 052531 000000 .WORD EM401B,EM4B,0
9641 067644 124 106 120 EM402: .ASCIZ ;TFPS (R):
9642 067655 123 000 EM402: .ASCIZ ;S:
9643 067657 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9644 067660 067644 052552 000000 EM403: .WORD EM401B,EM4D,0
9645 067666 115 000 .ASCIZ ;M:
9646 067670 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9647 067672 067746 070005 060711 .WORD EM403B,EM403C,PERIOD
9648 067700 052653 067736 052662 .WORD CRBUT,IGR7FL,PRST,N3,N5,N7,WENTTO,N4,N1,N6,INSTOF,N4,N1,N7,0
9649 067736 107 122 067 IGR7FL: .ASCIZ ;GR7,-FL:
9650 067746 117 122 105 EM403B: .ASCIZ ;MORE THAN ONE WORD WRITTEN BY S:
9651 070005 124 106 120 EM403C: .ASCIZ ;TFPS (R):
9652 070016 123 000 EM404: .ASCIZ ;S:
9653 070020 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9654 070022 067644 061172 000000 EM405: .WORD EM401B,EM227B,0
9655 070030 123 000 .ASCIZ ;S:
9656 070032 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9657 070034 070005 052756 052531 EM406: .WORD EM403C,EM7B,EM4B,0
9658 070044 123 000 .ASCIZ ;S:
9659 070046 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9660 070050 070005 052756 052552 EM407: .WORD EM403C,EM7B,EM4D,0
9661 070060 115 000 .ASCIZ ;M:
9662 070062 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9663 070064 067746 070005 052756 .WORD EM403B,EM403C,EM7B
9664 070072 052653 067736 052662 .WORD CRBUT,IGR7FL,PRST,N3,N5,N7,WENTTO,N4,N1,N6,INSTOF,N4,N1,N7,0
9665 070130 123 000 EM410: .ASCIZ ;S:
9666 070132 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9667 070134 070005 052756 061172 EM411: .WORD EM403C,EM7B,EM227B,0
9668 070144 123 000 .ASCIZ ;S:
9669 070146 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9670 070150 070156 052531 000000 EM411B: .WORD EM411B,EM4B,0
9671 070156 124 106 EM411B: .ASCIZ ;TFPS -(R):

ERROR MESSAGES

9672 070170	123	000		EM412:	.ASCIZ	'S'	
9673 070172	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9674 070174	070156	052552	000000		.EVEN		
9675 070202	115	000			.WORD	EM411B,EM4D,0	
9676 070204	377			EM413:	.ASCIZ	'M'	
9677 070206	067746	070156	060711		.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9678 070214	052653	067736	052662		.EVEN		
9679 070252	123	000		EM414:	.WORD	EM403B,EM411B,PERIOD	
9680 070254	377				.WORD	CRBUT,IGR7FL,PRST,N3,N5,N7,WENTTO,N4,N1,N6,INSTOF,N4,N1,N7,0	
9681 070256	070156	061172	000000	EM415:	.ASCIZ	'S'	
9682 070264	123	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9683 070266	377				.EVEN		
9684 070270	070276	052531	000000	EM415B:	.WORD	EM415B,EM4B,0	
9685 070276	124	106	120		.ASCIZ	TFPS @(R)+	
9686 070311	123	000		EM416:	.ASCIZ	'S'	
9687 070313	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9688 070314	070276	052552	000000	EM417:	.EVEN		
9689 070322	123	000			.WORD	EM415B,EM4D,0	
9690 070324	377				.ASCIZ	'S'	
9691 070326	070276	070334	000000	EM417B:	.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9692 070334	040	104	111		.WORD	EM415B,EM417B,0	
9693 070366	123	000		EM420:	.ASCIZ	I DID NOT DEFER THE WRITE.	
9694 070370	377				.ASCIZ	'S'	
9695 070372	070276	061172	000000	EM421:	.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9696 070400	123	000			.EVEN		
9697 070402	377				.WORD	EM415B,EM227B,0	
9698 070404	070412	052531	000000	EM421B:	.ASCIZ	'S'	
9699 070412	124	106	120		.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9700 070425	123	000		EM422:	.WORD	EM421B,EM4B,0	
9701 070427	377				.ASCIZ	TFPS @-(R)	
9702 070430	070412	052552	000000	EM423:	.ASCIZ	'S'	
9703 070436	123	000			.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9704 070440	377				.EVEN		
9705 070442	070412	070334	000000	EM424:	.WORD	EM421B,EM4D,0	
9706 070450	123	000			.ASCIZ	'S'	
9707 070452	377				.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9708 070454	070412	061172	000000	EM425:	.EVEN		
9709 070462	123	000			.WORD	EM421B,EM227B,0	
9710 070464	377				.ASCIZ	'S'	
9711 070466	070474	052531	000000	EM425B:	.BYTE	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9712 070474	124	106	120		.WORD	EM425B,EM4B,0	
9713 070506	123	000		EM426:	.ASCIZ	TFPS N(R)	
9714 070510	377				.BYTE	'S'	
9715 070512	070474	052552	000000		.EVEN	377	;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
					.WORD		EM425B,EM4D,0

9716 070520 115 000 EM427: .ASCIZ !M:
 9717 070522 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9718 070524 067746 070474 060711 .EVEN
 9719 070532 377 .WORD EM403B,EM425B,PERIOD
 9720 070534 052653 067736 052662 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9721 070572 123 000 EM430: .EVEN
 9722 070574 377 .WORD CRBUT,IGR7FL,PRST,N3,N5,N7,WENTTO,N4,N1,N6,INSTOF,N4,N1,N7,0
 9723 070576 070474 061172 000000 .ASCIZ !S:
 9724 070604 120 103 040 EM431: .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9725 070623 377 .EVEN
 9726 070624 070474 057026 000000 EM432: .WORD EM425B,EM160B,0
 9727 070632 123 000 .ASCIZ !S:
 9728 070634 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9729 070636 070644 052531 000000 EM432B: .WORD EM432B,EM4B,0
 9730 070644 124 106 120 EM433: .ASCIZ !TPS &N(R):
 9731 070657 123 000 .ASCIZ !S:
 9732 070661 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9733 070662 070644 052552 000000 EM434: .WORD EM432B,EM4D,0
 9734 070670 115 000 .ASCIZ !M:
 9735 070672 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9736 070674 067746 070644 060711 EM435: .WORD EM403B,EM432B,PERIOD
 9737 070702 052653 067736 052662 .WORD CRBUT,IGR7FL,PRST,N3,N5,N7,WENTTO,N4,N1,N6,INSTOF,N4,N1,N7,0
 9738 070740 123 000 .ASCIZ !S:
 9739 070742 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9740 070744 070644 061172 000000 EM436: .WORD EM432B,EM227B,0
 9741 070752 120 103 040 .ASCIZ !PC BAD AFTER S:
 9742 070771 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9743 070772 070644 057026 000000 EM437: .WORD EM432B,EM160B,0
 9744 071000 123 124 103 .ASCIZ !STCDL A,(R)+:
 9745 071015 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9746 071016 052531 000000 .WORD EM4B,0
 9747 071022 123 124 103 EM440: .ASCIZ !STCDL A,-(R):
 9748 071037 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9749 071040 052531 000000 .EVEN
 9750 071044 125 116 105 EM441: .WORD EM4B,0
 9751 071060 376 .ASCIZ !UNEXPECTED:
 9752 071062 000441 000442 000443 EM441B: .BYTE 376 ;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW
 9753 071072 071100 071147 071147 .WORD 441,442,443,0
 9754 071100 106 120 120 .WORD EM441B,EM442B,EM442B
 9755 071105 377 .ASCIZ !FPP:
 9756 071106 071112 000000 EM441B: .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9757 071112 124 122 101 TRAPTO: .WORD TRAPTO,0
 9758 071123 376 .ASCIZ !TRAP TO:
 9759 071124 000000 .BYTE 376 ;FLAGS 'ERTYPE' TO PRINT ERR # SPECIFIC ASCIZ MSGS, ADRS 3 LINES DOW

9758 071124 000441 000442 000443 .WORD 441,442,443,0
9759 071134 071142 071162 071165 .WORD N244,N04,N10
9760 071142 062 064 064 N244:.ASCIZ 1244.!
9761 071044 EM442=EM441
9762 071147 103 120 125 EM442B:.ASCIZ :CPU:
9763 071154 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9764 071156 071112 000000 .WORD TRAPTO,0
9765 071162 064 056 000 N04:.ASCIZ 14.!
9766 071044 EM443=EM441
9767 071165 061 060 056 N10:.ASCIZ 110.!
9768 071171 116 105 107 EM444:.ASCIZ :NEG:
9769 071175 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9770 071176 057346 052466 000000 .WORD EM176B,EM3B,0

DATA TABLE HEADERS

9771 .SBTTL DATA TABLE HEADERS
 9772 071204 040 000 DH1: .ASCIZ ;
 9773 071206 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9774 071210 071220 071252 071261 DH1B: .WORD DH1B,DH1C,DH1D,0
 9775 071220 040 124 105 DH1C: .ASCIZ TEST.:<TAB>:PC OF CALL.:<TAB>:PC OF :
 9776 071252 105 122 122 DH1D: .ASCIZ ERROR.:
 9777 071261 011 106 120 DH2: .ASCIZ <TAB>:FPS.:<TAB>:FEC.:
 9778 071274 040 000 DH2: .ASCIZ ;
 9779 071276 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9780 071300 071220 071252 071310 DH2B: .WORD DH1B,DH1C,DH2B,0
 9781 071310 011 107 117 DH3: .ASCIZ <TAB>:GOT FPS.:<TAB>:EXPECTED FPS.:
 9782 071340 040 000 DH3: .ASCIZ ;
 9783 071342 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9784 071344 071220 071252 071354 DH3B: .WORD DH1B,DH1C,DH3B,0
 9785 071354 011 107 117 DH4: .ASCIZ <TAB>:GOT FEC.:<TAB>:EXPECTED FEC.:
 9786 071404 040 000 DH4: .ASCIZ ;
 9787 071406 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9788 071410 071220 071252 071420 DH4B: .WORD DH1B,DH1C,DH4B,0
 9789 071420 011 107 117 DH5: .ASCIZ <TAB>:GOT RO.:<TAB>:EXPECTED RO.:
 9790 071447 040 000 DH5: .ASCIZ ;
 9791 071451 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9792 071452 071220 071252 000000 DH6=DH5 .WORD DH1B,DH1C,0
 9793 071447 DH7=DH4
 9794 071404 DH10=DH5
 9795 071447 DH11=DH4
 9796 071404 DH12=DH5
 9797 071447 DH13: .ASCIZ TEST.:<TAB>:PC OF CALL.:<TAB>:PC OF TRAP.:
 9798 071460 040 124 DH14=DH13
 9799 071460 DH15=DH5
 9800 071447 DH16: .ASCIZ ;
 9801 071520 040 000 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
 9802 071522 377 DH1B,DH1C,DH16B,0
 9803 071524 071220 071252 071534 DH16B: .ASCIZ <TAB>:GOT PC.:<TAB>:EXPECTED PC.:
 9804 071534 011 107 117 DH17=DH13
 9805 071460 DH20=DH4
 9806 071404 DH21=DH5
 9807 071447 DH22=DH5
 9808 071447 DH23=DH13
 9809 071460 DH24=DH4
 9810 071404 DH25=DH5
 9811 071447 DH26=DH13
 9812 071460 DH27=DH4
 9813 071404 DH30=DH5
 9814 071447 DH31=DH13
 9815 071460 DH32=DH4
 9816 071404 DH33=DH5
 9817 071447 DH34=DH13
 9818 071460 DH35=DH4
 9819 071404 DH36=DH5
 9820 071447 DH37: .ASCIZ ::
 9821 071563 040 000

9822 071565 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9823 071566 071220 071252 071576 .WORD DH1B,DH1C,DH37B,0
9824 071576 011 107 117 DH37B:.ASCIZ <TAB>!GOT FPS.!<TAB>!EXPECTED FPS.
9825 071563 DH40=DH37
9826 071626 040 000 DH41:.ASCIZ ::
9827 071630 377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9828 071632 071220 071252 071642 .WORD DH1B,DH1C,DH41B,0
9829 071642 011 106 120 DH41B:.ASCIZ <TAB>!FPS.!<TAB>!GOT FEC. EXPECTED FEC.
9830 071563 DH42=DH37
9831 071563 DH43=DH37
9832 071563 DH44=DH37
9833 071563 DH45=DH37
9834 071563 DH46=DH37
9835 071563 DH47=DH37
9836 071563 DH50=DH37
9837 071563 DH51=DH37
9838 071563 DH52=DH37
9839 071626 DH53=DH41
9840 071563 DH54=DH37
9841 071563 DH55=DH37
9842 071563 DH56=DH37
9843 071563 DH57=DH37
9844 071563 DH60=DH37
9845 071563 DH61=DH37
9846 071274 DH62=DH2
9847 071340 DH63=DH3
9848 071447 DH64=DH5
9849 071274 DH65=DH2
9850 071404 DH66=DH4
9851 071274 DH67=DH2
9852 071340 DH70=DH3
9853 071274 DH176=DH2
9854 071677 124 105 123 DH177:.ASCIZ !TESTNO ERR PC CPUERR:
9855 071447 DH71=DH5
9856 071274 DH72=DH2
9857 071460 DH107=DH13
9858 071447 DH73=DH5
9859 071404 DH74=DH4
9860 071274 DH75=DH2
9861 071460 DH76=DH107
9862 071447 DH77=DH5
9863 071404 DH100=DH4
9864 071274 DH101=DH2
9865 071460 DH102=DH107
9866 071447 DH103=DH5
9867 071404 DH104=DH4
9868 071274 DH105=DH2
9869 071460 DH106=DH107
9870 071447 DH110=DH5
9871 071404 DH111=DH4
9872 071274 DH112=DH2
9873 071460 DH113=DH107
9874 071447 DH114=DH5
9875 071404 DH115=DH4
9876 071274 DH116=DH2

DATA TABLE HEADERS

9877	071460	DH117=DH107
9878	071447	DH120=DH5
9879	071404	DH121=DH4
9880	071274	DH122=DH2
9881	071460	DH123=DH107
9882	071447	DH124=DH5
9883	071404	DH125=DH4
9884	071274	DH126=DH2
9885	071460	DH127=DH107
9886	071447	DH130=DH5
9887	071274	DH131=DH2
9888	071460	DH132=DH107
9889	071447	DH133=DH5
9890	071274	DH134=DH2
9891	071447	DH135=DH5
9892	071447	DH136=DH5
9893	071274	DH137=DH2
9894	071447	DH140=DH5
9895	071404	DH141=DH4
9896	071274	DH142=DH2
9897	071447	DH143=DH5
9898	071404	DH144=DH4
9899	071274	DH145=DH2
9900	071447	DH146=DH5
9901	071404	DH147=DH4
9902	071274	DH150=DH2
9903	071447	DH151=DH5
9904	071404	DH152=DH4
9905	071274	DH153=DH2
9906	071447	DH154=DH5
9907	071404	DH155=DH4
9908	071274	DH156=DH2
9909	071447	DH157=DH5
9910	071404	DH160=DH4
9911	071274	DH161=DH2
9912	071447	DH162=DH5
9913	071274	DH163=DH2
9914	071520	DH164=DH16
9915	071563	DH165=DH37
9916	071563	DH166=DH37
9917	071563	DH167=DH37
9918	071563	DH170=DH37
9919	071563	DH171=DH37
9920	071563	DH172=DH37
9921	071626	DH173=DH41
9922	071626	DH174=DH41
9923	071626	DH175=DH41
9924	071563	DH200=DH37
9925	071563	DH201=DH37
9926	071563	DH202=DH37
9927	071563	DH203=DH37
9928	071563	DH204=DH37
9929	071563	DH205=DH37
9930	071563	DH206=DH37
9931	071563	DH207=DH37
9932	071563	DH210=DH37
9933	071563	DH211=DH37

DATA TABLE HEADERS

9934	071563	DH212=DH37
9935	071563	DH213=DH37
9936	071563	DH214=DH37
9937	071520	DH215=DH16
9938	071447	DH216=DH5
9939	071404	DH217=DH4
9940	071274	DH220=DH2
9941	071520	DH221=DH16
9942	071447	DH222=DH5
9943	071404	DH223=DH4
9944	071274	DH224=DH2
9945	071404	DH225=DH4
9946	071274	DH226=DH2
9947	071726	040 000 DH227: .ASCIZ ; ;
9948	071730	377 .BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN
9949	071732	071220 071740 000000 .WORD DH18,DH2278,0
9950	071740	124 122 101 DH2278: .ASCIZ ;TRAP.;
9951	071404	DH230=DH4
9952	071274	DH231=DH2
9953	071726	DH232=DH227
9954	071404	DH233=DH4
9955	071274	DH234=DH2
9956	071726	DH235=DH227
9957	071404	DH236=DH4
9958	071274	DH237=DH2
9959	071726	DH240=DH227
9960	071404	DH241=DH4
9961	071274	DH242=DH2
9962	071726	DH243=DH227
9963	071404	DH244=DH4
9964	071274	DH245=DH2
9965	071520	DH246=DH16
9966	071726	DH247=DH227
9967	071404	DH250=DH4
9968	071274	DH251=DH2
9969	071520	DH252=DH16
9970	071726	DH253=DH227
9971	071520	DH254=DH16
9972	071726	DH255=DH227
9973	071404	DH256=DH4
9974	071274	DH257=DH2
9975	071563	DH260=DH37
9976	071563	DH261=DH37
9977	071563	DH262=DH37
9978	071563	DH263=DH37
9979	071563	DH264=DH37
9980	071563	DH265=DH37
9981	071563	DH266=DH37
9982	071563	DH267=DH37
9983	071563	DH270=DH37
9984	071563	DH271=DH37
9985	071563	DH272=DH37
9986	071563	DH273=DH37
9987	071563	DH274=DH37
9988	071563	DH275=DH37
9989	071563	DH276=DH37

DATA TABLE HEADERS

9990	071563		DH277=DH37		
9991	071563		DH300=DH37		
9992	071563		DH301=DH37		
9993	071563		DH302=DH37		
9994	071626		DH303=DH41		
9995	071563		DH304=DH37		
9996	071563		DH305=DH37		
9997	071563		DH306=DH37		
9998	071563		DH307=DH37		
9999	071563		DH310=DH37		
10000	071563		DH311=DH37		
10001	071563		DH312=DH37		
10002	071563		DH313=DH37		
10003	071563		DH314=DH37		
10004	071563		DH315=DH37		
10005	071563		DH316=DH37		
10006	071563		DH317=DH37		
10007	071563		DH320=DH37		
10008	071563		DH321=DH37		
10009	071563		DH322=DH37		
10010	071563		DH323=DH37		
10011	071626		DH324=DH41		
10012	071563		DH325=DH37		
10013	071563		DH326=DH37		
10014	071563		DH327=DH37		
10015	071563		DH330=DH37		
10016	071563		DH331=DH37		
10017	071563		DH332=DH37		
10018	071563		DH333=DH37		
10019	071563		DH334=DH37		
10020	071563		DH335=DH37		
10021	071563		DH336=DH37		
10022	071563		DH337=DH37		
10023	071563		DH340=DH37		
10024	071563		DH341=DH37		
10025	071563		DH342=DH37		
10026	071563		DH343=DH37		
10027	071563		DH344=DH37		
10028	071563		DH345=DH37		
10029	071563		DH346=DH37		
10030	071563		DH347=DH37		
10031	071563		DH350=DH37		
10032	071460		DH351=DH13		
10033	071563		DH352=DH37		
10034	071563		DH353=DH37		
10035	071563		DH354=DH37		
10036	071563		DH355=DH37		
10037	071404		DH356=DH11		
10038	071746	040	000	DH357: .ASCIZ ::	
10039	071750	377		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN	
				.EVEN	
				.WORD DH1B,DH1C,DH357B,0	
10040	071752	071220	071252	071762	DH357B: .ASCIZ <TAB>!GOT FEA.!<TAB>!EXPECTED FEA.!;
10041	071762	011	10?	117	DH360=DH13
10042	071460				DH361=DH2
10043	071274				DH362: .ASCIZ ::
10044	072012	040	000		.BYTE 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10045	072014	377			

DATA TABLE HEADERS

10046	072016	071220	071252	072026	.EVEN	DH1B,DH1C,DH362B,0
10047	072026	011	115	115	.WORD	<TAB>:MMR0:
10048	072034	040	000		.ASCIZ	
10049	072036	377			.DH363:	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10050	072040	071220	071252	072050	.EVEN	
10051	072050	011	123	122	.WORD	DH1B,DH1C,DH363B,0
10052	072074	040	000		.ASCIZ	<TAB>:SR1:<TAB>:CALCD:<TAB>:EXPECTED:
10053	072076	377			.ASCIZ	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10054	072100	071220	072106	000000	.EVEN	
10055	072106	111	116	123	.WORD	DH1B,DH364B,0
10056	072143	040	000		.ASCIZ	:INSTRUCTION FAILING TO ABORT:
10057	072145	377			.DH365:	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10058	072146	071220	071252	000000	.EVEN	
10059	072154	040	000		.WORD	DH1B,DH1C,0
10060	072156	377			.ASCIZ	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10061	072160	071220	071252	072170	.EVEN	
10062	072170	011	101	103	.WORD	DH1B,DH1C,DH366B,0
10063	072206	040	000		.ASCIZ	<TAB>:AC #: CHANGED:
10064	072210	377			.DH367:	
					.BYTE	377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS. ADDRESSES 2 LINES DOWN
10065	072212	071220	071252	072222	.EVEN	
10066	072222	011	122	105	.WORD	DH1B,DH1C,DH367B,0
10067	072253	040	040	124	.ASCIZ	<TAB>:REG #:<TAB>:RECEIVED:<TAB>:EXPECTED:
10068	072316	040	040	124	.DH370:	: TEST:<TAB>:PC OF CALL:<TAB>:AC #:<TAB>:PC OF ERROR:
10069	072356	105	130	120	.DH371:	: TEST:<TAB>:PC OF CALL:<TAB>:STEXP OP CODE:<TAB>
					.ASCII	: EXPCTD RECVD PC OF ERROR:
10070		000000			DH372=0	
10071		000000			DH373=0	
10072		000000			DH374=0	
10073		000000			DH375=0	
10074		000000			DH376=0	
10075		000000			DH377=0	
10076		000000			DH400=0	
10077		071404			DH401=DH4	
10078		071274			DH402=DH2	
10079		071460			DH403=DH13	
10080		071726			DH404=DH227	
10081		071404			DH405=DH4	
10082		071274			DH406=DH2	
10083		071460			DH407=DH13	
10084		071726			DH410=DH227	
10085		071404			DH411=DH4	
10086		071274			DH412=DH2	
10087		071460			DH413=DH13	
10088		071726			DH414=DH227	
10089		071404			DH415=DH4	
10090		071274			DH416=DH2	
10091		071460			DH417=DH13	
10092		071726			DH420=DH227	
10093		071404			DH421=DH4	
10094		071274			DH422=DH2	
10095		071460			DH423=DH13	
10096		071726			DH424=DH227	

CKFPCDO FP11F FLTG PNT PRT C

MACRO M1113 30-OCT-81 11:15 PAGE 118-6

C 5

SEQUENCE 262

DATA TABLE HEADERS

10097	071404	DH425=DH4			
10098	071274	DH426=DH2			
10099	071460	DH427=DH13			
10100	071726	DH430=DH227			
10101	071460	DH431=DH13			
10102	071404	DH432=DH4			
10103	071274	DH433=DH2			
10104	071460	DH434=DH13			
10105	071726	DH435=DH227			
10106	071460	DH436=DH13			
10107	071404	DH437=DH4			
10108	071404	DH440=DH4			
10109	072412	040	000	DH441: .ASCIZ ::	
10110	072414	377		.BYTF 377 ;FLAGS 'ERTYPE' TO PRINT ADDT'L ASCIZ MSGS, ADDRESSES 2 LINES DOWN	
				.EVEN	
10111	072416	071220	071252	072426	.WORD DH1B,DH1C,DH441B,0
10112	072426	011	106	105	DH441B: .ASCIZ <TAB>IFEC.!DH442=DH365
10113	072143				DH443=DH442
10114	072143				DH444=DH3
10115	071340				

FORMAT SPECIFICATIONS FOR THE DATA TABLES						
10116					.SBTTL	FORMAT SPECIFICATIONS FOR THE DATA TABLES
10117	072434	004	000	005	DF1:	.BYTE 4,0,5,0,5,0,0
10118	072443	004	000	005	DF2:	.BYTE 4,0,5,0,5,0,5,0
10119		072443			DF3=DF2	
10120		072443			DF4=DF2	
10121	072453	004	000	005	DF5:	.BYTE 4,0,5,0,5,5,2,5,5,2
10122	072465	004	000	005	DF6:	.BYTE 4,0,5,0
10123		072443			DF7=DF4	
10124		072453			DF10=DF5	
10125		072443			DF11=DF4	
10126	072471	004	000	005	DF12:	.BYTE 4,0,5,0,5,5,3,5,5,3
10127		072465			DF13=DF6	
10128		072465			DF14=DF6	
10129		072471			DF15=DF12	
10130		072443			DF16=DF2	
10131		072465			DF17=DF6	
10132		072443			DF20=DF2	
10133		072471			DF21=DF12	
10134		072471			DF22=DF12	
10135		072465			DF23=DF6	
10136		072443			DF24=DF2	
10137		072471			UF25=DF12	
10138		072465			DF26=DF6	
10139		072443			DF27=DF2	
10140		072471			DF30=DF12	
10141		072465			DF31=DF6	
10142		072443			DF32=DF2	
10143		072471			DF33=DF12	
10144		072465			DF34=DF6	
10145		072443			DF35=DF2	
10146		072471			DF36=DF12	
10147	072503	004	000	005	DF37:	.BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,3,5,5,3
10148		072503			DF40=DF37	
10149	072524	004	000	005	DF41:	.BYTE 4,0,5,0,5,0,0,0,0,5,5,3,5,5,3,5,5,3
10150		072503			DF42=DF37	
10151		072503			DF43=DF37	
10152		072503			DF44=DF37	
10153		072503			DF45=DF37	
10154		072503			DF46=DF37	
10155		072503			DF47=DF37	
10156		072503			DF50=DF37	
10157		072503			DF51=DF37	
10158		072503			DF52=DF37	
10159		072503			DF53=DF37	
10160		072503			DF54=DF37	
10161		072503			DF55=DF37	
10162		072503			DF56=DF37	
10163		072503			DF57=DF37	
10164		072503			DF60=DF37	
10165		072503			DF61=DF37	
10166		072443			DF62=DF2	
10167		072443			DF63=DF2	
10168		072453			DF64=DF5	
10169		072443			DF65=DF2	
10170		072443			DF66=DF2	
10171		072443			DF67=DF2	
10172		072443			DF70=DF2	

10173	072443				DF176=DF2
10174	072545	004	000	000	DF177: .BYTE 4,0,0
10175	072550	004	000	005	DF71: .BYTE 4,0,5,0,5,5,3,5,5,3,5,5,3
10176	072443				DF72=DF2
10177	072465				DF107=DF6
10178	072550				DF73=DF71
10179	072443				DF74=DF2
10180	072443				DF75=DF2
10181	072465				DF76=DF6
10182	072550				DF77=DF71
10183	072443				DF100=DF2
10184	072443				DF101=DF2
10185	072465				DF102=DF6
10186	072550				DF103=DF71
10187	072443				DF104=DF2
10188	072443				DF105=DF2
10189	072465				DF106=DF6
10190	072550				DF110=DF71
10191	072443				DF111=DF2
10192	072443				DF112=DF2
10193	072465				DF113=DF6
10194	072550				DF114=DF71
10195	072443				DF115=DF2
10196	072443				DF116=DF2
10197	072465				DF117=DF6
10198	072550				DF120=DF71
10199	072443				DF121=DF2
10200	072443				DF122=DF2
10201	072465				DF123=DF6
10202	072550				DF124=DF71
10203	072443				DF125=DF2
10204	072443				DF126=DF2
10205	072465				DF127=DF6
10206	072550				DF130=DF71
10207	072443				DF131=DF2
10208	072465				DF132=DF6
10209	072550				DF133=DF71
10210	072443				DF134=DF2
10211	072471				DF135=DF12
10212	072471				DF136=DF12
10213	072443				DF137=DF2
10214	072471				DF140=DF12
10215	072443				DF141=DF2
10216	072443				DF142=DF2
10217	072471				DF143=DF12
10218	072443				DF144=DF2
10219	072443				DF145=DF2
10220	072471				DF146=DF12
10221	072443				DF147=DF2
10222	072443				DF150=DF2
10223	072471				DF151=DF12
10224	072443				DF152=DF2
10225	072443				DF153=DF2
10226	072471				DF154=DF12
10227	072443				DF155=DF2
10228	072443				DF156=DF2
10229	072471				DF157=DF12

10230	072443		DF160=DF2
10231	072443		DF161=DF2
10232	072471		DF162=DF12
10233	072443		DF163=DF2
10234	072443		DF164=DF2
10235	072443		DF215=DF2
10236	072471		DF216=DF12
10237	072443		DF217=DF2
10238	072443		DF220=DF2
10239	072443		DF221=DF2
10240	072471		DF222=DF12
10241	072443		DF223=DF2
10242	072443		DF224=DF2
10243	072503		DF165=DF37
10244	072503		DF166=DF37
10245	072503		DF167=DF37
10246	072503		DF170=DF37
10247	072503		DF171=DF37
10248	072503		DF172=DF37
10249	072524		DF173=DF41
10250	072524		DF174=DF41
10251	072524		DF175=DF41
10252	072503		DF200=DF37
10253	072503		DF201=DF37
10254	072503		DF202=DF37
10255	072503		DF203=DF37
10256	072503		DF204=DF37
10257	072503		DF205=DF37
10258	072503		DF206=DF37
10259	072503		DF207=DF37
10260	072503		DF210=DF37
10261	072503		DF211=DF37
10262	072503		DF212=DF37
10263	072503		DF213=DF37
10264	072503		DF214=DF37
10265	072565	004	000 005 DF225: .BYTE 4,0,5,0,5,0,5,0
10266	072565		DF226=DF225
10267	072575	004	000 005 DF227: .BYTE 4,0,5,0
10268	072565		DF230=DF225
10269	072565		DF231=DF225
10270	072575		DF232=DF227
10271	072565		DF233=DF225
10272	072565		DF234=DF225
10273	072575		DF235=DF227
10274	072565		DF236=DF225
10275	072565		DF237=DF225
10276	072575		DF240=DF227
10277	072565		DF241=DF225
10278	072565		DF242=DF225
10279	072575		DF243=DF227
10280	072565		DF244=DF225
10281	072565		DF245=DF225
10282	072565		DF246=DF225
10283	072575		DF247=DF227
10284	072565		DF250=DF225
10285	072565		DF251=DF225
10286	072565		DF252=DF225

10287	072575			DF253=DF227	
10288	072565			DF254=DF225	
10289	072575			DF255=DF227	
10290	072565			DF256=DF225	
10291	072565			DF257=DF225	
10292	072601	004	000	005	DF260: .BYTE 4,0,5,0,5,0,5,0,5,5,2,5,5,2,5,5,2
10293	072601				DF261=DF260
10294	072601				DF262=DF260
10295	072601				DF263=DF260
10296	072601				DF264=DF260
10297	072601				DF265=DF260
10298	072601				DF266=DF260
10299	072601				DF267=DF260
10300	072601				DF270=DF260
10301	072601				DF271=DF260
10302	072601				DF272=DF260
10303	072622	004	000	005	DF273: .BYTE 4,0,5,0,5,0,5,0,5,5,2,5,5,3,5,5,3
10304	072622				DF274=DF273
10305	072622				DF275=DF273
10306	072622				DF276=DF273
10307	072622				DF277=DF273
10308	072622				DF300=DF273
10309	072643	004	000	005	DF301: .BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,0,5,5,3,5,5,3
10310	072643				DF302=DF301
10311	072667	004	000	005	DF303: .BYTE 4,0,5,0,5,0,0,0,5,5,3,5,5,0,5,5,3,5,5,3
10312	072643				DF304=DF301
10313	072643				DF305=DF301
10314	072643				DF306=DF301
10315	072643				DF307=DF301
10316	072643				DF310=DF301
10317	072643				DF311=DF301
10318	072643				DF312=DF301
10319	072643				DF313=DF301
10320	072643				DF314=DF301
10321	072643				DF315=DF301
10322	072643				DF316=DF301
10323	072643				DF317=DF301
10324	072643				DF320=DF301
10325	072643				DF321=DF301
10326	072713	004	000	005	DF322: .BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,2,5,5,2
10327	072713				DF323=DF322
10328	072734	004	000	005	DF324: .BYTE 4,0,5,0,5,0,0,0,5,5,3,5,5,2,5,5,2
10329	072713				DF325=DF322
10330	072713				DF326=DF322
10331	072713				DF327=DF322
10332	072713				DF330=DF322
10333	072713				DF331=DF322
10334	072713				DF332=DF322
10335	072713				DF333=DF322
10336	072713				DF334=DF322
10337	072713				DF335=DF322
10338	072713				DF336=DF322
10339	072713				DF337=DF322
10340	072713				DF340=DF322
10341	072713				DF341=DF322
10342	072713				DF342=DF322
10343	072713				DF343=DF322

10344	072713				DF344=DF322
10345	072713				DF345=DF322
10346	072713				DF346=DF322
10347	072755	004	000	005	DF347: .BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,0,5,5,0
10348	072755				DF350=DF347
10349	072755				DF351=DF227
10350	072755				DF352=DF347
10351	072755				DF353=DF347
10352	072755				DF354=DF347
10353	072755				DF355=DF347
10354	072565				DF356=DF225
10355	072565				DF357=DF225
10356	072575				DF360=DF227
10357	072776	004	000	005	DF361: .BYTF 4,0,5,0,5,0,5,0,5,5,0,5,5,0,5,5,0
10358	073022	004	000	005	DF362: .BYTE 4,0,5,0,5,0
10359	073030	004	000	005	DF363: .BYTE 4,0,5,0,5,0,0,0
10360		072465			DF364=DF6
10361		072465			DF365=DF6
10362	073040	004	000	005	DF366: .BYTE 4,0,5,0,5,0,5,5,0,0,0,0,0,5,5,0,0,0
10363	073062	004	000	005	DF367: .BYTE 4,0,5,0,5,0,0,0
10364	073072	004	000	005	DF370: .BYTE 4,0,5,0,0,5,5,0,0,0,0,0,5,5,0,0,0,0
10365		073062			DF371=DF367
10366		000000			DF372=0
10367		000000			DF373=0
10368		000000			DF374=0
10369		000000			DF375=0
10370		000000			DF376=0
10371		000000			DF377=0
10372		000000			DF400=0
10373		072565			DF401=DF225
10374		072565			DF402=DF225
10375		072575			DF403=DF227
10376		072575			DF404=DF227
10377		072565			DF405=DF225
10378		072565			DF406=DF225
10379		072575			DF407=DF227
10380		072575			DF410=DF227
10381		072565			DF411=DF225
10382		072565			DF412=DF225
10383		072575			DF413=DF227
10384		072575			DF414=DF227
10385		072565			DF415=DF225
10386		072565			DF416=DF225
10387		072575			DF417=DF227
10388		072575			DF420=DF227
10389		072565			DF421=DF225
10390		072565			DF422=DF225
10391		072575			DF423=DF227
10392		072575			DF424=DF227
10393		072565			DF425=DF225
10394		072565			DF426=DF225
10395		072575			DF427=DF227
10396		072575			DF430=DF227
10397		072575			DF431=DF227
10398		072565			DF432=DF225
10399		072565			DF433=DF225
10400		072575			DF434=DF227

10401	072575	DF435=DF227			
10402	072575	DF436=DF227			
10403	072565	DF437=DF225			
10404	072565	DF440=DF225			
10405	073113	004	000	005	DF441: .BYTE 4,0,5,0,5,0
10406	073113				DF442=DF441
10407	073113				DF443=DF441
10408	072443				DF444=DF2
10409					.EVEN

10410 .SBTTL ERROR MESSAGE DATA TABLES
10411 073122 001232 001234 052167 DT1: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,\$TMP4,0
10412 073142 001232 001234 052167 DT2: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,\$TAB,\$TMP5,0
10413 073164 001232 001234 052167 DT3: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP6,0
10414 073206 001232 001234 052167 DT4: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP3,0
10415 073230 001232 001234 052167 DT5: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF,MS1,\$TMP3
10416 073246 001313 052207 001242 .WORD SCRLF,MS2,\$TMP4,0
10417 073256 001232 001234 052167 DT6: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,0
10418 073206 DT7=DT4
10419 073230 DT10=DT5
10420 073206 DT11=DT4
10421 073230 DT12=DT5
10422 073256 DT13=DT6
10423 073256 DT14=DT6
10424 073230 DT15=DT5
10425 073270 001232 001234 052167 DT16: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP3,0
10426 073256 DT17=DT6
10427 073270 DT20=DT16
10428 073230 DT21=DT5
10429 073230 DT22=DT5
10430 073256 DT23=DT6
10431 073270 DT24=DT16
10432 073230 DT25=DT5
10433 073256 DT26=DT6
10434 073270 DT27=DT16
10435 073230 DT30=DT5
10436 073256 DT31=DT6
10437 073270 DT32=DT16
10438 073230 DT33=DT5
10439 073256 DT34=DT6
10440 073270 DT35=DT16
10441 073230 DT36=DT5
10442 073312 001232 001234 052167 DT37: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP7,\$TAB,\$TMP10,\$CRLF
10443 073334 052247 001240 001313 .WORD MS4,\$TMP3,\$CRLF,MS1,\$TMP4,\$CRLF,MS2,\$TMP5,0
10444 073312 DT40=DT37
10445 073356 001232 001234 052167 DT41: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP7,\$TMP11,\$TMP12
10446 073376 001313 052247 001240 .WORD \$CRLF,MS4,\$TMP3,\$CRLF,MS1,\$TMP4,\$CRLF,MS2,\$TMP5,0
10447 073312 DT42=DT37
10448 073312 DT43=DT37
10449 073312 DT44=DT37
10450 073312 DT45=DT37
10451 073312 DT46=DT37
10452 073312 DT47=DT37
10453 073312 DT50=DT37
10454 073312 DT51=DT37
10455 073312 DT52=DT37
10456 073356 DT53=DT41
10457 073312 DT54=DT37
10458 073312 DT55=DT37
10459 073312 DT56=DT37
10460 073312 DT57=DT37
10461 073312 DT60=DT37
10462 073312 DT61=DT37
10463 073270 DT62=DT16
10464 073270 DT63=DT16
10465 073230 DT64=DT5
10466 073270 DT65=DT16

10467	073206		DT66=DT4
10468	073206		DT67=DT4
10469	073206		DT70=DT4
10470	073206		DT176=DT4
10471	073422	001232	001116 046506 DT177: .WORD \$TMO, SERRPC, CPSAVE, 0
10472	073432	001232	001234 052167 DT71: .WORD \$TMO, STMP1, \$TAB, STMP2, \$CRLF, MS3, STMP3, \$CRLF, MS
10473	073454	001244	001313 052207 .WORD \$TMO, \$CRLF, MS2, STMP4, 0
10474	073206		DT72=DT4
10475	073256		DT107=DT6
10476	073466	001232	001234 052167 DT73: .WORD \$TMO, STMP1, \$TAB, STMP2, \$CRLF, MS4, STMP4
10477	073504	001313	052171 001244 .WORD \$CRLF, MS1, STMP5, \$CRLF, MS2, STMP3, 0
10478	073206		DT74=DT4
10479	073142		DT75=DT2
10480	073256		DT76=DT6
10481	073466		DT77=DT73
10482	073206		DT100=DT4
10483	073142		DT101=DT2
10484	073256		DT102=DT6
10485	073466		DT103=DT73
10486	073206		DT104=DT4
10487	073142		DT105=DT2
10488	073256		DT106=DT6
10489	073466		DT110=DT73
10490	073206		DT111=DT4
10491	073142		DT112=DT2
10492	073256		DT113=DT6
10493	073466		DT114=DT73
10494	073206		DT115=DT4
10495	073142		DT116=DT2
10496	073256		DT117=DT6
10497	073466		DT120=DT73
10498	073206		DT121=DT4
10499	073142		DT122=DT2
10500	073256		DT123=DT6
10501	073466		DT124=DT73
10502	073206		DT125=DT4
10503	073142		DT126=DT2
10504	073256		DT127=DT6
10505	073466		DT130=DT73
10506	073142		DT131=DT2
10507	073256		DT132=DT6
10508	073466		DT133=DT73
10509	073142		DT134=DT2
10510	073230		DT135=DT5
10511	073230		DT136=DT5
10512	073270		DT137=DT16
10513	073230		DT140=DT5
10514	073206		DT141=DT4
10515	073206		DT142=DT4
10516	073230		DT143=DT5
10517	073206		DT144=DT4
10518	073206		DT145=DT4
10519	073230		DT146=DT5
10520	073206		DT147=DT4
10521	073206		DT150=DT4
10522	073230		DT151=DT5
10523	073206		DT152=DT4

10524	073206	DT153=DT4
10525	073230	DT154=DT5
10526	073206	DT155=DT4
10527	073206	DT156=DT4
10528	073230	DT157=DT5
10529	073206	DT160=DT4
10530	073206	DT161=DT4
10531	073230	DT162=DT5
10532	073206	DT163=DT4
10533	073206	DT164=DT4
10534	073206	DT215=DT4
10535	073230	DT216=DT5
10536	073206	DT217=DT4
10537	073206	DT220=DT4
10538	073206	DT221=DT4
10539	073230	DT222=DT5
10540	073206	DT223=DT4
10541	073206	DT224=DT4
10542	073312	DT165=DT37
10543	073312	DT166=DT37
10544	073312	DT167=DT37
10545	073312	DT170=DT37
10546	073312	DT171=DT37
10547	073312	DT172=DT37
10548	073356	DT173=DT41
10549	073356	DT174=DT41
10550	073356	DT175=DT41
10551	073312	DT200=DT37
10552	073312	DT201=DT37
10553	073312	DT202=DT37
10554	073312	DT203=DT37
10555	073312	DT204=DT37
10556	073312	DT205=DT37
10557	073312	DT206=DT37
10558	073312	DT207=DT37
10559	073312	DT210=DT37
10560	073312	DT211=DT37
10561	073312	DT212=DT37
10562	073312	DT213=DT37
10563	073312	DT214=DT37
10564	073206	DT225=DT4
10565	073206	DT226=DT4
10566	073256	DT227=DT6
10567	073206	DT230=DT4
10568	073206	DT231=DT4
10569	073256	DT232=DT6
10570	073206	DT233=DT4
10571	073206	DT234=DT4
10572	073256	DT235=DT6
10573	073206	DT236=DT4
10574	073206	DT237=DT4
10575	073256	DT240=DT6
10576	073206	DT241=DT4
10577	073206	DT242=DT4
10578	073256	DT243=DT6
10579	073206	DT244=DT4
10580	073206	DT245=DT4

10581	073206				DT246=DT4
10582	073256				DT247=DT6
10583	073206				DT250=DT4
10584	073206				DT251=DT4
10585	073206				DT252=DT4
10586	073256				DT253=DT6
10587	073206				DT254=DT4
10588	073256				DT255=DT6
10589	073206				DT256=DT4
10590	073206				DT257=DT4
10591	073312				DT260=DT37
10592	073312				DT261=DT37
10593	073312				DT262=DT37
10594	073312				DT263=DT37
10595	073312				DT264=DT37
10596	073312				DT265=DT37
10597	073312				DT266=DT37
10598	073312				DT267=DT37
10599	073312				DT270=DT37
10600	073312				DT271=DT37
10601	073312				DT272=DT37
10602	073312				DT273=DT37
10603	073312				DT274=DT37
10604	073312				DT275=DT37
10605	073312				DT276=DT37
10606	073312				DT277=DT37
10607	073312				DT300=DT37
10608	073522	001232	001234	052167	DT301: .WORD STMP0,STMP1,STAB,STMP2,STAB,STMP7,STAB,STMP10
10609	073542	001313	052231	001240	.WORD SCRLF,MS10,STMP3,SCRLF,MS11,STMP4
10610	073556	001313	052171	001246	.WORD SCRLF,MS1,STMP6,SCRLF,MS2,STMP5,0
10611	073522				DT302=DT301
10612	073574	001232	001234	052167	DT303: .WORD STMP0,STMP1,STAB,STMP2,STAB,STMP7,STMP11,STMP12
10613	073614	001313	052231	001240	.WORD SCRLF,MS10,STMP3,SCRLF,MS11,STMP4
10614	073630	001313	052171	001246	.WORD SCRLF,MS1,STMP6,SCRLF,MS2,STMP5,0
10615	073522				DT304=DT301
10616	073522				DT305=DT301
10617	073522				DT306=DT301
10618	073522				DT307=DT301
10619	073522				DT310=DT301
10620	073522				DT311=DT301
10621	073522				DT312=DT301
10622	073522				DT313=DT301
10623	073522				DT314=DT301
10624	073522				DT315=DT301
10625	073522				DT316=DT301
10626	073522				DT317=DT301
10627	073522				DT320=DT301
10628	073522				DT321=DT301
10629	073646	001232	001234	052167	DT322: .WORD STMP0,STMP1,STAB,STMP2,STAB,STMP7,STAB,STMP10
10630	073666	001313	052231	001240	.WORD SCRLF,MS10,STMP3,SCRLF,MS1,STMP4,SCRLF,MS2,STMP5,0
10631	073646				DT323=DT322
10632	073712	001232	001234	052167	DT324: .WORD STMP0,STMP1,STAB,STMP2,STAB,STMP7,STMP11,STMP12
10633	073732	001313	052231	001240	.WORD SCRLF,MS10,STMP3,SCRLF,MS1,STMP4,SCRLF,MS2,STMP5,0
10634	073646				DT325=DT322
10635	073646				DT326=DT322
10636	073646				DT327=DT322
10637	073646				DT330=DT322

10638	073646			DT331=DT322	
10639	073646			DT332=DT322	
10640	073646			DT333=DT322	
10641	073646			DT334=DT322	
10642	073646			DT335=DT322	
10643	073646			DT336=DT322	
10644	073646			DT337=DT322	
10645	073646			DT340=DT322	
10646	073646			DT341=DT322	
10647	073646			DT342=DT322	
10648	073646			DT343=DT322	
10649	073646			DT344=DT322	
10650	073646			DT345=DT322	
10651	073646			DT346=DT322	
10652	073646			DT347=DT322	
10653	073646			DT350=DT322	
10654	073256			DT351=DT6	
10655	073646			DT352=DT322	
10656	073646			DT353=DT322	
10657	073646			DT354=DT322	
10658	073646			DT355=DT322	
10659	073142			DT356=DT2	
10660	073164			DT357=DT3	
10661	073256			DT360=DT6	
10662	073522			DT361=DT302	
10663	073756	001232	001234	052167	DT362: .WORD STMP0,STMP1,\$TAB,STMP2,STAB,STMP3,0
10664	073774	001232	001234	052167	DT363: .WORD STMP0,STMP1,\$TAB,STMP13,STAB,STMP2,STMP3,EXPCTD,0
10665	074016	001232	001234	052167	DT364: .WORD STMP0,STMP1,\$TAB,STMP13,0
10666		073256			DT365=DT6
10667	074030	001232	001234	052167	DT366: .WORD STMP0,STMP1,\$TAB,STMP13,STAB,STMP2
10668	074044	001313	052207	001240	.WORD SCRLF,MS2,STMP3,STMP4,STMP6,STMP7
10669	074060	001313	052171	001252	.WORD SCRLF,MS1,STMP10,STMP11,STMP12,STMP21,0
10670	074076	001232	001234	052167	DT367: .WORD STMP0,STMP1,\$TAB,STMP2,STMP13,STAB,STMP6,\$TAB,STMP3,0
10671	074122	001232	001234	052167	DT370: .WORD STMP0,STMP1,\$TAB,STMP2,STMP13
10672	074134	001313	052326	001240	.WORD SCRLF,MS21,STMP3,STMP4,STMP6,STMP7
10673	074150	001313	052314	001252	.WORD SCRLF,MS20,STMP10,STMP11,STMP12,STMP21,0
10674	074156	001232	001234	052167	DT371: .WORD STMP0,STMP1,\$TAB,STMP13,STAB,STMP3,STMP4,STMP2,0
10675		000000			DT372=0
10676		000000			DT373=0
10677		000000			DT374=0
10678		000000			DT375=0
10679		000000			DT376=0
10680		000000			DT377=0
10681		000000			DT400=0
10682		073206			DT401=DT4
10683		073206			DT402=DT4
10684		073256			DT403=DT6
10685		073256			DT404=DT6
10686		073206			DT405=DT4
10687		073206			DT406=DT4
10688		073256			DT407=DT6
10689		073256			DT410=DT6
10690		073206			DT411=DT4
10691		073206			DT412=DT4
10692		073256			DT413=DT6
10693		073256			DT414=DT6
10694		073206			DT415=DT4

10695	073206		DT416=DT4
10696	073256		DT417=DT6
10697	073256		DT420=DT6
10698	073206		DT421=DT4
10699	073206		DT422=DT4
10700	073256		DT423=DT6
10701	073256		DT424=DT6
10702	073206		DT425=DT4
10703	073206		DT426=DT4
10704	073256		DT427=DT6
10705	073256		DT430=DT6
10706	073256		DT431=DT6
10707	073206		DT432=DT4
10708	073206		DT433=DT4
10709	073256		DT434=DT6
10710	073256		DT435=DT6
10711	073256		DT436=DT6
10712	073206		DT437=DT4
10713	073206		DT440=DT4
10714	074210	001232	001234 052167 DT441: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,0
10715	074226	001232	001234 052167 DT442: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,0
10716		074226	DT443=DT442
10717		073206	DT444=DT4
10718		000001	.END

SYMBOL TABLE

ABASE = 000000	AUSWR = 000000	DF113 = 072465	DF176 = 072443	DF26 = 072465
ACDW1 = 000000	AVECT1= 000000	DF114 = 072550	DF177 = 072545	DF260 = 072601
ACDW2 = 000000	AVECT2= 000000	DF115 = 072443	DF2 = 072443	DF261 = 072601
ACPUOP= 000000	BADCON 060664	DF116 = 072443	DF20 = 072443	DF262 = 072601
AC0 = 2000000	BIT0 = 000001	DF117 = 072465	DF200 = 072503	DF263 = 072601
AC1 = 2000001	BIT00 = 000001	DF118 = 072471	DF201 = 072503	DF264 = 072601
AC2 = 2000002	BIT01 = 000002	DF119 = 072550	DF202 = 072503	DF265 = 072601
AC3 = 2000003	BIT02 = 000004	DF120 = 072443	DF203 = 072503	DF266 = 072601
AC4 = 2000004	BIT03 = 000010	DF121 = 072443	DF204 = 072503	DF267 = 072601
AC5 = 2000005	BIT04 = 000020	DF122 = 072443	DF205 = 072503	DF27 = 072443
AC6 = 2000006	BIT05 = 000040	DF123 = 072465	DF206 = 072503	DF270 = 072601
AC7 = 2000007	BIT06 = 000100	DF124 = 072550	DF207 = 072503	DF271 = 072601
ADDW0 = 000000	BIT07 = 000200	DF125 = 072443	DF21 = 072471	DF272 = 072601
ADDW1 = 000000	BIT08 = 000400	DF126 = 072443	DF210 = 072503	DF273 = 072622
ADDW10= 000000	BIT09 = 001000	DF127 = 072465	DF211 = 072503	DF274 = 072622
ADDW11= 000000	BIT1 = 000002	DF130 = 072550	DF212 = 072503	DF275 = 072622
ADDW12= 000000	BIT10 = 002000	DF131 = 072443	DF213 = 072503	DF276 = 072622
ADDW13= 000000	BIT11 = 004000	DF132 = 072465	DF214 = 072503	DF277 = 072622
ADDW14= 000000	BIT12 = 010000	DF133 = 072550	DF215 = 072443	DF3 = 072443
ADDW15= 000000	BIT13 = 020000	DF134 = 072443	DF216 = 072471	DF30 = 072471
ADDW2 = 000000	BIT14 = 040000	DF135 = 072471	DF217 = 072443	DF300 = 072622
ADDW3 = 000000	BIT15 = 100000	DF136 = 072471	DF22 = 072471	DF301 = 072643
ADDW4 = 000000	BIT2 = 000004	DF137 = 072443	DF220 = 072443	DF302 = 072643
ADDW5 = 000000	BIT3 = 000010	DF14 = 072465	DF221 = 072443	DF303 = 072667
ADDW6 = 000000	BIT4 = 000020	DF140 = 072471	DF222 = 072471	DF304 = 072643
ADDW7 = 000000	BIT5 = 000040	DF141 = 072443	DF223 = 072443	DF305 = 072643
ADDW8 = 000000	BIT6 = 000100	DF142 = 072443	DF224 = 072443	DF306 = 072643
ADDW9 = 000000	BIT7 = 000200	DF143 = 072471	DF225 = 072565	DF307 = 072643
ADEVCT= 000000	BIT8 = 000400	DF144 = 072443	DF226 = 072565	DF31 = 072465
ADEVM = 000000	BIT9 = 001000	DF145 = 072443	DF227 = 072575	DF310 = 072643
AENV = 000000	BPTVEC= 000014	DF146 = 072471	DF23 = 072465	DF311 = 072643
AENVM = 000000	BUTIN 060713	DF147 = 072443	DF230 = 072565	DF312 = 072643
AFATAL= 000000	BYTABL 045312	DF15 = 072471	DF231 = 072565	DF313 = 072643
AMADR1= 000000	CKSWR = 104406	DF150 = 072443	DF232 = 072575	DF314 = 072643
AMADR2= 000000	CNT = 000445	DF151 = 072471	DF233 = 072565	DF315 = 072643
AMADR3= 000000	CPSAVE 046506	DF152 = 072443	DF234 = 072565	DF316 = 072643
AMADR4= 000000	CPSPUR 051774	DF153 = 072443	DF235 = 072575	DF317 = 072643
AMAMS1= 000000	CPTWO 052022	DF154 = 072471	DF236 = 072565	DF32 = 072443
AMAMS2= 000000	CR = 000015	DF155 = 072443	DF237 = 072565	DF320 = 072643
AMAMS3= 000000	CRBUT 052653	DF156 = 072443	DF24 = 072443	DF321 = 072643
AMAMS4= 000000	CRLF = 000200	DF157 = 072471	DF240 = 072575	DF322 = 072713
AMSGAD= 000000	DATA = 117760	DF158 = 072443	DF241 = 072565	DF323 = 072713
AMSGLG= 000000	DDISP = 177570	DF159 = 072443	DF242 = 072565	DF324 = 072734
AMSGTY= 000000	DF1 = 072434	DF160 = 072443	DF243 = 072575	DF325 = 072713
AMTYP1= 000000	DF10 = 072453	DF161 = 072443	DF244 = 072565	DF326 = 072713
AMTYP2= 000000	DF100 = 072443	DF162 = 072471	DF245 = 072565	DF327 = 072713
AMTYP3= 000000	DF101 = 072443	DF163 = 072443	DF246 = 072565	DF33 = 072471
AMTYP4= 000000	DF102 = 072465	DF164 = 072443	DF247 = 072575	DF330 = 072713
APASS = 000000	DF103 = 072550	DF165 = 072503	DF248 = 072565	DF331 = 072713
APRIOR= 000000	DF104 = 072443	DF166 = 072503	DF249 = 072565	DF332 = 072713
APTCSU= 000040	DF105 = 072443	DF167 = 072503	DF250 = 072565	DF333 = 072713
APTEVN= 000001	DF106 = 072465	DF168 = 072465	DF251 = 072565	DF334 = 072713
APTSIZ= 000200	DF107 = 072465	DF169 = 072503	DF252 = 072565	DF335 = 072713
APTSP0= 000100	DF11 = 072443	DF170 = 072503	DF253 = 072575	DF336 = 072713
ASWREG= 000000	DF110 = 072550	DF171 = 072503	DF254 = 072565	DF337 = 072713
ATESTN= 000000	DF111 = 072443	DF172 = 072503	DF255 = 072575	DF338 = 072713
AUNIT - 000000	DF112 = 072443	DF173 = 072524	DF256 = 072565	DF339 = 072465
		DF174 = 072524	DF257 = 072565	DF340 = 072713
		DF175 = 072524		

SYMBOL TABLE

DF341 = 072713	DF423 = 072575	DH102 = 071460	DH164 = 071520	DH244 = 071404
DF342 = 072713	DF424 = 072575	DH103 = 071447	DH165 = 071563	DH245 = 071274
DF343 = 072713	DF425 = 072565	DH104 = 071404	DH166 = 071563	DH246 = 071520
DF344 = 072713	DF426 = 072565	DH105 = 071274	DH167 = 071563	DH247 = 071726
DF345 = 072713	DF427 = 072575	DH106 = 071460	DH17 = 071460	DH25 = 071447
DF346 = 072713	DF43 = 072503	DH107 = 071460	DH170 = 071563	DH250 = 071404
DF347 = 072755	DF430 = 072575	DH11 = 071404	DH171 = 071563	DH251 = 071274
DF35 = 072443	DF431 = 072575	DH110 = 071447	DH172 = 071563	DH252 = 071520
DF350 = 072755	DF432 = 072565	DH111 = 071404	DH173 = 071626	DH253 = 071726
DF351 = 072575	DF433 = 072565	DH112 = 071274	DH174 = 071626	DH254 = 071520
DF352 = 072755	DF434 = 072575	DH113 = 071460	DH175 = 071626	DH255 = 071726
DF353 = 072755	DF435 = 072575	DH114 = 071447	DH176 = 071274	DH256 = 071404
DF354 = 072755	DF436 = 072575	DH115 = 071404	DH177 = 071677	DH257 = 071274
DF355 = 072755	DF437 = 072565	DH116 = 071274	DH2 = 071274	DH26 = 071460
DF356 = 072565	DF44 = 072503	DH117 = 071460	DH28 = 071310	DH260 = 071563
DF357 = 072565	DF440 = 072565	DH12 = 071447	DH20 = 071404	DH261 = 071563
DF36 = 072471	DF441 = 073113	DH120 = 071447	DH200 = 071563	DH262 = 071563
DF360 = 072575	DF442 = 073113	DH121 = 071404	DH201 = 071563	DH263 = 071563
DF361 = 072776	DF443 = 073113	DH122 = 071274	DH202 = 071563	DH264 = 071563
DF362 = 073022	DF444 = 072443	DH123 = 071460	DH203 = 071563	DH265 = 071563
DF363 = 073030	DF45 = 072503	DH124 = 071447	DH204 = 071563	DH266 = 071563
DF364 = 072465	DF46 = 072503	DH125 = 071404	DH205 = 071563	DH267 = 071563
DF365 = 072465	DF47 = 072503	DH126 = 071274	DH206 = 071563	DH27 = 071404
DF366 = 073040	DF5 = 072453	DH127 = 071460	DH207 = 071563	DH270 = 071563
DF367 = 073062	DF50 = 072503	DH13 = 071460	DH21 = 071447	DH271 = 071563
DF37 = 072503	DF51 = 072503	DH130 = 071447	DH210 = 071563	DH272 = 071563
DF370 = 073072	DF52 = 072503	DH131 = 071274	DH211 = 071563	DH273 = 071563
DF371 = 073062	DF53 = 072503	DH132 = 071460	DH212 = 071563	DH274 = 071563
DF372 = 000000	DF54 = 072503	DH133 = 071447	DH213 = 071563	DH275 = 071563
DF373 = 000000	DF55 = 072503	DH134 = 071274	DH214 = 071563	DH276 = 071563
DF374 = 000000	DF56 = 072503	DH135 = 071447	DH215 = 071520	DH277 = 071563
DF375 = 000000	DF57 = 072503	DH136 = 071447	DH216 = 071447	DH3 = 071340
DF376 = 000000	DF6 = 072465	DH137 = 071274	DH217 = 071404	DH3B = 071354
DF377 = 000000	DF60 = 072503	DH14 = 071460	DH22 = 071447	DH30 = 071447
DF4 = 072443	DF61 = 072503	DH140 = 071447	DH220 = 071274	DH300 = 071563
DF40 = 072503	DF62 = 072443	DH141 = 071404	DH221 = 071520	DH301 = 071563
DF400 = 000000	DF63 = 072443	DH142 = 071274	DH222 = 071447	DH302 = 071563
DF401 = 072565	DF64 = 072453	DH143 = 071447	DH223 = 071404	DH303 = 071626
DF402 = 072565	DF65 = 072443	DH144 = 071404	DH224 = 071274	DH304 = 071563
DF403 = 072575	DF66 = 072443	DH145 = 071274	DH225 = 071404	DH305 = 071563
DF404 = 072575	DF67 = 072443	DH146 = 071447	DH226 = 071274	DH306 = 071563
DF405 = 072565	DF7 = 072443	DH147 = 071404	DH227 = 071726	DH307 = 071563
DF406 = 072565	DF70 = 072443	DH15 = 071447	DH227B = 071740	DH31 = 071460
DF407 = 072575	DF71 = 072550	DH150 = 071274	DH23 = 071460	DH310 = 071563
DF41 = 072524	DF72 = 072443	DH151 = 071447	DH230 = 071404	DH311 = 071563
DF410 = 072575	DF73 = 072550	DH152 = 071404	DH231 = 071274	DH312 = 071563
DF411 = 072565	DF74 = 072443	DH153 = 071274	DH232 = 071726	DH313 = 071563
DF412 = 072565	DF75 = 072443	DH154 = 071447	DH233 = 071404	DH314 = 071563
DF413 = 072575	DF76 = 072465	DH155 = 071404	DH234 = 071274	DH315 = 071563
DF414 = 072575	DF77 = 072550	DH156 = 071274	DH235 = 071726	DH316 = 071563
DF415 = 072565	DH1 = 071204	DH157 = 071447	DH236 = 071404	DH317 = 071563
DF416 = 072565	DH18 = 071220	DH16 = 071520	DH237 = 071274	DH32 = 071404
DF417 = 072575	DH1C = 071252	DH16B = 071534	DH24 = 071404	DH320 = 071563
DF42 = 072503	DH1D = 071261	DH160 = 071404	DH240 = 071726	DH321 = 071563
DF420 = 072575	DH10 = 071447	DH161 = 071274	DH241 = 071404	DH322 = 071563
DF421 = 072565	DH100 = 071404	DH162 = 071447	DH242 = 071274	DH323 = 071563
DF422 = 072565	DH101 = 071274	DH163 = 071274	DH243 = 071726	DH324 = 071626

SYMBOL TABLE

DH325 = 071563	DH40 = 071563	DH60 = 071563	DT137 = 073270	DT220 = 073206
DH326 = 071563	DH400 = 000000	DH61 = 071563	DT14 = 073256	DT221 = 073206
DH327 = 071563	DH401 = 071404	DH62 = 071274	DT140 = 073230	DT222 = 073230
DH33 = 071447	DH402 = 071274	DH63 = 071340	DT141 = 073206	DT223 = 073206
DH330 = 071563	DH403 = 071460	DH64 = 071447	DT142 = 073206	DT224 = 073206
DH331 = 071563	DH404 = 071726	DH65 = 071274	DT143 = 073230	DT225 = 073206
DH332 = 071563	DH405 = 071404	DH66 = 071404	DT144 = 073206	DT226 = 073206
DH333 = 071563	DH406 = 071274	DH67 = 071274	DT145 = 073206	DT227 = 073256
DH334 = 071563	DH407 = 071460	DH7 = 071404	DT146 = 073230	DT23 = 073256
DH335 = 071563	DH41 = 071626	DH70 = 071340	DT147 = 073206	DT230 = 073206
DH336 = 071563	DH418 = 071642	DH71 = 071447	DT15 = 073230	DT231 = 073206
DH337 = 071563	DH410 = 071726	DH72 = 071274	DT150 = 073206	DT232 = 073256
DH34 = 071460	DH411 = 071404	DH73 = 071447	DT151 = 073230	DT233 = 073206
DH340 = 071563	DH412 = 071274	DH74 = 071404	DT152 = 073206	DT234 = 073206
DH341 = 071563	DH413 = 071460	DH75 = 071274	DT153 = 073206	DT235 = 073256
DH342 = 071563	DH414 = 071726	DH76 = 071460	DT154 = 073230	DT236 = 073206
DH343 = 071563	DH415 = 071404	DH77 = 071447	DT155 = 073206	DT237 = 073206
DH344 = 071563	DH416 = 071274	DIDONE 045416	DT156 = 073206	DT24 = 073270
DH345 = 071563	DH417 = 071460	DISPLA 001142	DT157 = 073230	DT240 = 073256
DH346 = 071563	DH42 = 071563	DISPRE 000174	DT16 = 073270	DT241 = 073206
DH347 = 071563	DH420 = 071726	DSWR = 177570	DT160 = 073206	DT242 = 073206
DH35 = 071404	DH421 = 071404	DT1 = 073122	DT161 = 073206	DT243 = 073256
DH350 = 071563	DH422 = 071274	DT10 = - 073230	DT162 = 073230	DT244 = 073206
DH351 = 071460	DH423 = 071460	DT100 = 073206	DT163 = 073206	DT245 = 073206
DH352 = 071563	DH424 = 071726	DT101 = 073142	DT164 = 073206	DT246 = 073206
DH353 = 071563	DH425 = 071404	DT102 = 073256	DT165 = 073312	DT247 = 073256
DH354 = 071563	DH426 = 071274	DT103 = 073466	DT166 = 073312	DT25 = 073230
DH355 = 071553	DH427 = 071460	DT104 = 073206	DT167 = 073312	DT250 = 073206
DH356 = 071404	DH43 = 071563	DT105 = 073142	DT17 = 073256	DT251 = 073206
DH357 = 071746	DH430 = 071726	DT106 = 073256	DT170 = 073312	DT252 = 073206
DH3578 = 071762	DH431 = 071460	DT107 = 073256	DT171 = 073312	DT253 = 073256
DH36 = 071447	DH432 = 071404	DT11 = 073206	DT172 = 073312	DT254 = 073206
DH360 = 071460	DH433 = 071274	DT110 = 073466	DT173 = 073356	DT255 = 073256
DH361 = 071274	DH434 = 071460	DT111 = 073206	DT174 = 073356	DT256 = 073206
DH362 = 072012	DH435 = 071726	DT112 = 073142	DT175 = 073356	DT257 = 073206
DH3628 = 072026	DH436 = 071460	DT113 = 073256	DT176 = 073206	DT26 = 073256
DH363 = 072034	DH437 = 071404	DT114 = 073466	DT177 = 073422	DT260 = 073312
DH3638 = 072050	DH44 = 071563	DT115 = 073206	DT2 = 073142	DT261 = 073312
DH364 = 072074	DH440 = 071404	DT116 = 073142	DT20 = 073270	DT262 = 073312
DH3648 = 072106	DH441 = 072412	DT117 = 073256	DT200 = 073312	DT263 = 073312
DH365 = 072143	DH4418 = 072426	DT12 = 073230	DT201 = 073312	DT264 = 073312
DH366 = 072154	DH442 = 072143	DT120 = 073466	DT202 = 073312	DT265 = 073312
DH3668 = 072170	DH443 = 072143	DT121 = 073206	DT203 = 073312	DT266 = 073312
DH367 = 072206	DH444 = 071340	DT122 = 073142	DT204 = 073312	DT267 = 073312
DH3678 = 072222	DH45 = 071563	DT123 = 073256	DT205 = 073312	DT27 = 073270
DH37 = 071563	DH46 = 071563	DT124 = 073466	DT206 = 073312	DT270 = 073312
DH378 = 071576	DH47 = 071563	DT125 = 073206	DT207 = 073312	DT271 = 073312
DH370 = 072253	DH5 = 071447	DT126 = 073142	DT21 = 073230	DT272 = 073312
DH371 = 072316	DH50 = 071563	DT127 = 073256	DT210 = 073312	DT273 = 073312
DH372 = 000000	DH51 = 071563	DT128 = 073256	DT211 = 073312	DT274 = 073312
DH373 = 000000	DH52 = 071563	DT130 = 073466	DT212 = 073312	DT275 = 073312
DH374 = 000000	DH53 = 071626	DT131 = 073142	DT213 = 073312	DT276 = 073312
DH375 = 000000	DH54 = 071563	DT132 = 073256	DT214 = 073312	DT277 = 073312
DH376 = 000000	DH55 = 071563	DT133 = 073466	DT215 = 073206	DT3 = 073164
DH377 = J000000	DH56 = 071563	DT134 = 073142	DT216 = 073230	DT30 = 073230
DH4 = 071404	DH57 = 071563	DT135 = 073230	DT217 = 073206	DT300 = 073312
DH4B = 071420	DH6 = 071447	DT136 = 073230	DT22 = 073230	DT301 = 073522

DT302 = 073522	DT365 = 073256	DT47 = 073312	EM120 056053	EM172 057252
DT303 = 073574	DT366 = 074030	DT5 = 073230	EM121 056066	EM173 057266
DT304 = 073522	DT367 = 074076	DT50 = 073312	EM122 056102	EM174 057302
DT305 = 073522	DT37 = 073312	DT51 = 073312	EM123 056116	EM175 057316
DT306 = 073522	DT370 = 074122	DT52 = 073312	EM123B 056132	EM176 057332
DT307 = 073522	DT371 = 074166	DT53 = 073356	EM124 056142	EM176B 057346
DT31 = 073256	DT372 = 000000	DT54 = 073312	EM125 056156	EM177 057354
DT310 = 073522	DT373 = 000000	DT55 = 073312	EM126 056172	EM2 052422
DT311 = 073522	DT374 = 000000	DT56 = 073312	EM127 056206	EM28 052436
DT312 = 073522	DT375 = 000000	DT57 = 073312	EM127B 056222	EM20 053166
DT313 = 073522	DT376 = 000000	DT6 = 073256	EM13 053036	EM200 057410
DT314 = 073522	DT377 = 000000	DT60 = 073312	EM13A 053050	EM200C 057426
DT315 = 073522	DT4 = 073206	DT61 = 073312	EM138 053060	EM201 057463
DT316 = 073522	DT40 = 073312	DT62 = 073270	EM130 056232	EM202 057534
DT317 = 073522	DT400 = 000000	DT63 = 073270	EM131 056246	EM203 057606
DT32 = 073270	DT401 = 073206	DT64 = 073230	EM132 056262	EM204 057730
DT320 = 073522	DT402 = 073206	DT65 = 073270	EM132B 056276	EM204C 057746
DT321 = 073522	DT403 = 073256	DT66 = 073206	EM133 056307	EM205 060003
DT322 = 073646	DT404 = 073256	DT67 = 073206	EM134 056322	EM206 060054
DT323 = 073646	DT405 = 073206	DT7 = 073206	EM135 056336	EM207 060126
DT324 = 073712	DT406 = 073206	DT70 = 073206	EM136 056406	EM21 053204
DT325 = 073646	DT407 = 073256	DT71 = 073432	EM137 = 056422	EM210 060200
DT326 = 073646	DT41 = 073356	DT72 = 073206	EM14 = 053036	EM211 060252
DT327 = 073646	DT410 = 073256	DT73 = 073466	EM140 056436	EM212 060331
DT33 = 073230	DT411 = 073206	DT74 = 073206	EM141 056452	EM213 060402
DT330 = 073646	DT412 = 073206	DT75 = 073142	EM141C 056472	EM213C 060460
DT331 = 073646	DT413 = 073256	DT76 = 073256	EM142 056510	EM213D 060470
DT332 = 073646	DT414 = 073256	DT77 = 073466	EM143 056524	EM214 060513
DT333 = 073646	DT415 = 073206	EMTVEC= 000030	EM144 056540	EM214B 060570
DT334 = 073646	DT416 = 073206	EM1 052346	EM145 056556	EM215 060600
DT335 = 073646	DT417 = 073256	EM18 052362	EM146 056572	EM216 060735
DT336 = 073646	DT42 = 073312	EM1C 052373	EM147 056606	EM217 060750
DT337 = 073646	DT420 = 073256	EM1D 052412	EM15 053104	EM22 = 053204
DT34 = 073256	DT421 = 073206	EM10 052761	EM150 056626	EM220 060770
DT340 = 073646	DT422 = 073206	EM100 055516	EM151 056642	EM221 061004
DT341 = 073646	DT423 = 073256	EM101 055532	EM152 056656	EM222 061054
DT342 = 073646	DT424 = 073256	EM102 055546	EM153 056676	EM223 061070
DT345 = 073646	DT425 = 073206	EM102B 055562	EM154 056712	EM224 061110
DT344 = 073646	DT426 = 073206	EM103 055571	EM155 056726	EM225 061124
DT345 = 073646	DT427 = 073256	EM104 055604	EM156 056746	EM225B 061136
DT346 = 073646	DT43 = 073312	EM105 055620	EM157 056762	EM226 061147
DT347 = 073646	DT430 = 073256	EM106 055634	EM157B 056776	EM227 061160
DT35 = 073270	DT431 = 073256	EM106B 055650	EM16 053116	EM227B 061172
DT350 = 073646	DT432 = 073206	EM107 055660	EM160 057005	EM23 053216
DT351 = 073256	DT433 = 073206	EM11 052774	EM160B 057026	EM23B 053230
DT352 = 073646	DT434 = 073256	EM118 053012	EM161 057053	EM230 061211
DT353 = 073646	DT435 = 073256	EM110 055674	EM162 057066	EM230B 061222
DT354 = 073646	DT436 = 073256	EM111 055710	EM162B 057102	EM231 061234
DT355 = 073646	DT437 = 073206	EM112 055724	EM163 057112	EM232 061246
DT356 = 073142	DT44 = 073312	EM113 055740	EM164 057126	EM233 061260
DT357 = 073164	DT440 = 073206	EM113B 055754	EM165 057156	EM233B 061272
DT36 = 073230	DT441 = 074210	EM114 055764	EM166 057172	EM234 061304
DT360 = 073256	DT442 = 074226	EM115 056000	EM167 057206	EM235 061316
DT361 = 073522	DT443 = 074226	EM116 056014	EM17 053142	EM236 061330
DT362 = 073756	DT444 = 073206	EM117 056030	EM17B 053154	EM236B 061342
DT363 = 073774	DT45 = 073312	EM117B 056044	EM170 057222	EM237 061355
DT364 = 074016	DT46 = 073312	EM12 053024	EM171 057236	EM24 053243

EM240	061366	EM38	052466	EM346	065774	EM415B	070276	EM6C	052610
EM241	061400	EM30	053334	EM346C	066020	EM416	070311	EM60	= 054235
EM241B	061412	EM300	063065	EM347	066073	EM417	070322	EM608	= 054632
EM242	061425	EM300C	063110	EM347B	066104	EM417B	070334	EM61	= 054274
EM243	061436	EM301	063162	EM35	053447	EM42	= 053476	EM61B	= 054712
EM244	061450	EM301B	063174	EM350	066117	EM42B	053616	EM62	054771
EM244B	061462	EM302	063207	EM351	066130	EM420	070366	EM62A	055010
EM245	061474	EM303	063220	EM352	066232	EM421	070400	EM62B	055020
EM246	061506	EM304	063232	EM353	066302	EM421B	070412	EM63	055067
EM246B	061544	EM304C	063246	EM354	066352	EM422	070425	EM64	055104
EM247	061557	EM305	063312	EM355	066422	EM423	070436	EM65	055154
EM25	053260	EM305C	063326	EM356	066472	EM424	070450	EM66	055200
EM250	061570	EM306	063406	EM356B	066526	EM425	070462	EM66B	055220
EM250B	061602	EM307	063514	EM357	066576	EM425B	070474	EM67	055226
EM251	061615	EM31	053346	EM36	053464	EM426	070506	EM7	052737
EM252	= 061506	EM31B	053360	EM360	066632	EM427	070520	EM7B	052756
EM252B	061626	EM310	063564	EM361	066722	EM43	= 053556	EM70	055310
EM253	061642	EM311	063640	EM362	066740	EM43B	053652	EM71	055333
EM254	= 061506	EM312	063710	EM363	067050	EM430	070572	EM72	055350
EM254B	061654	EM313	063760	EM364	067116	EM431	070604	EM73	055364
EM255	061672	EM314	064030	EM365	067216	EM432	070632	EM74	055400
EM256	061716	EM315	064100	EM366	067301	EM432B	070644	EM75	055414
EM256B	061730	EM316	064150	EM367	067364	EM433	070657	EM76	055430
EM257	061744	EM317	064220	EM37	053476	EM434	070670	EM76A	055444
EM26	053272	EM32	053372	EM370	067447	EM435	070740	EM76B	055453
EM26B	053304	EM320	064270	EM371	067503	EM436	070752	EM77	055503
EM260	061756	EM321	064340	EM372	= 000000	EM437	071000	ENDTES	045376
EM260B	061770	EM322	064410	EM373	= 000000	EM44	= 053476	ENDTST	041776
EM261	062014	EM322B	064422	EM374	= 000000	EM44B	053731	EOASCII	047172
EM262	062026	EM323	064446	EM375	= 000000	EM440	071022	EPENDS	046164
EM262B	062101	EM324	064460	EM376	= 000000	EM441	071044	ERM10	047074
EM263	062114	EM325	064472	EM377	= 000000	EM441B	071100	ERRNUM	051576
EM263B	062126	EM325B	064506	EM4	052502	EM442	= 071044	ERROR	= 104000
EM264	062141	EM325C	064521	EM4A	052520	EM442B	071147	ERRVEC	= 000004
EM264C	062154	EM326	= 064472	EM4B	052531	EM443	= 071044	ERTYPE	051152
EM265	062226	EM327	064616	EM4C	052543	EM444	071171	ERT1	051346
EM265C	062242	EM33	053410	EM4D	052552	EM45	= 053476	ERT2	051546
EM266	062277	EM330	064666	EM40	053556	EM45B	054006	ERT3	051552
EM267	062353	EM331	064742	EM400	= 000000	EM46	= 053556	ERT4	051560
EM267C	062366	EM332	065012	EM401	067633	EM46B	054041	ERT5	051572
EM27	053317	EM332B	065026	EM401B	067644	EM47	= 053476	EXPCTD	045374
EM270	062440	EM332C	065041	EM402	067655	EM47B	054114	FALTRP	044006
EM270C	062454	EM333	= 064446	EM403	067666	EM5	052563	FPSPUR	051732
EM271	062472	EM334	065110	EM403B	067746	EM50	= 053476	FPVECT	= 000244
EM271C	062506	EM334C	065124	EM403C	070005	EM50B	054156	GTSWR	= 104405
EM272	062531	EM335	065173	EM404	070016	EM51	054235	HT	= 000011
EM272C	062544	EM336	065242	EM405	070030	EM52	054274	IBKOUT	054462
EM273	062601	EM336C	065260	EM406	070044	EM53	= 054274	IBSAVE	046512
EM273B	062612	EM337	065277	EM407	070060	EM54	= 054235	ICOUT	065346
EM274	062636	EM34	053422	EM41	= 053556	EM54B	054336	IDONE	042010
EM275	062650	EM34B	053434	EM410	070130	EM55	= 054235	IENBT	054230
EM275B	062720	EM340	065353	EM411	070144	EM55B	054402	IEZBT	053724
EM276	062733	EM341	065422	EM411B	070156	EM56	= 054274	IFD	052650
EM276C	062746	EM342	065472	EM412	070170	EM56B	054473	IFDST	055062
EM277	063020	EM343	065542	EM413	070202	EM57	= 054274	IFIC	064736
EM277C	063034	EM344	065617	EM414	070252	EM57B	054546	IFIU	063634
EM3	052452	EM345	065724	EM415	070264	EM6	052574	IFIUV	060506

IFIV	054626	N1	052721	SW03	= 000010	TST22	015110	SAPTHD	006102
IFL	062076	N10	071165	SW04	- 000020	TST23	015404	SATYC	050014
IFLAG	054764	N2	052723	SW05	= 000040	TST24	015700	SATY1	047770
IGR7FL	067736	N244	071142	SW06	= 000100	TST25	016204	SATY3	047776
INBIT	065612	N3	052725	SW07	= 000200	TST26	016510	SATY4	050006
INSTOF	052702	N3132	060316	SW08	= 000400	TST27	017010	SAUTOB	001134
IOP18	057723	N4	052727	SW09	= 001000	TST3	007374	SBASE	001372
IOTRAP=	000020	N5	052731	SW1	= 000002	TST30	017316	SBDADR	001122
IOTVEC=	000020	N6	052733	SW10	= 002000	TST31	017564	SBDAT	001126
IXNBT	062346	N7	052735	SW11	= 004000	TST32	020042	SBELL	001306
KDPAR0=	172360	N746T2	060624	SW12	= 010000	TST33	020250	SCDW1	001376
KDPAR1=	172362	N747T2	061030	SW13	= 020000	TST34	020464	SCDW2	001400
KDPAR2=	172364	OR	057716	SW14	= 040000	TST35	020700	SCHARC	047530
KDPAR3=	172366	PASCIZ	051600	SW15	= 100000	TST36	021126	SCKSWR	050236
KDPAR4=	172370	PCBAD	060647	SW2	= 000004	TST37	021352	SCLR.T	046074
KDPAR7=	172376	PERIOD	060711	SW3	= 000010	TST4	007766	SCMTAG	001100
KDPDR0=	172320	PIRQ	= 177772	SW4	= 000020	TST40	021600	SCM1	= 000024
KDPDR1=	172322	PIROVE	= 000240	SW5	= 000040	TST41	022014	SCM2	= 000050
KDPDR2=	172324	POWERM	052120	SW6	= 000100	TST42	022246	SCM3	= 000024
KDPDR3=	172326	PROGNU	= 000003	SW7	= 000200	TST43	022514	SCM4	= 000024
KDPDR4=	172330	PRST	052662	SW8	= 000400	TST44	022772	SCNTLG	050655
KDPDR7=	172336	PRO	= 000000	SW9	= 001000	TST45	024320	SCNTLU	050650
KIPAR0=	172340	PR1	= 000040	TAB	= 000011	TST46	024502	SCPUP	001344
KIPAR1=	172342	PR2	= 000100	TBITVE	= 000014	TST47	024664	SCRLF	001313
KIPAR2=	172344	PR3	= 000140	TKVEC	= 000060	TST5	010314	SDDW0	001402
KIPAR3=	172346	PR4	= 000200	TPVEC	= 000064	TST50	025064	SDDW1	001404
KIPAR4=	172350	PR5	= 000240	TRAPTO	071112	TST51	025300	SDDW10	001426
KIPAR7=	172356	PR6	= 000300	TRAPV	041714	TST52	025506	SDDW11	001430
KIPDR0=	172300	PR7	= 000340	TRAPVE	= 000034	TST53	025730	SDDW12	001432
KIPDR1=	172302	PS	= 177776	TRPV	044054	TST54	026166	SDDW13	001434
KIPDR2=	172304	PSW	= 177776	TRTVEC	= 000014	TST55	026306	SDDW14	001436
KIPDR3=	172306	PWRVEC	= 000024	TST1	006764	TST56	026450	SDDW15	001440
KIPDR4=	172310	RDCHR	= 104407	TST10	011360	TST57	030142	SDDW2	001406
KIPDR7=	172316	RESREG	= 104411	TST100	041302	TST6	010630	SDDW3	001410
LABEL1	042674	RESVEC	= 000010	TST101	041430	TST60	031230	SDDW4	001412
LF	= 000012	RETURN	045166	TST102	041446	TST61	033176	SDDW5	001414
LOOP	006764	RSETUP	= 104412	TST103	041524	TST62	033434	SDDW6	001416
MAR0	= 177572	RTI	= 045210	TST104	041602	TST63	033672	SDDW7	001420
MAR2	= 177576	R6	= %000006	TST105	042446	TST64	034130	SDDW8	001422
MAR3	= 172516	R7	= %000007	TST106	042542	TST65	034376	SDDW9	001424
MMVECT=	000250	SAVIOT	042426	TST107	042650	TST66	034646	SDEVCT	001326
MINUMBE=	000444	SAVREG	= 104410	TST11	011620	TST67	035124	SDEVM	001374
MODE1	042556	SCOPE	= 000004	TST110	042764	TST7	011104	SDISAB	046024
MS1	052171	SETERL	042430	TST111	043164	TST70	035414	SDOAGN	046114
MS10	= 052231	SPACE	052164	TST112	043300	TST71	035524	SENDAD	046104
MS11	052271	SR1	= 177574	TST113	043412	TST72	035634	SENDCT	045464
MS2	052207	STACK	= 001100	TST114	043606	TST73	037402	SENLL	046160
MS20	052314	START	= 006116	TST115	045420	TST74	037456	SENV	001336
MS21	052326	STCSUB	037110	TST12	012076	TST75	040416	SENVM	001337
MS3	052231	STKLMT	= 177774	TST13	012756	TST76	041104	SEOP	045420
MS4	052247	STORE	045232	TST14	013636	TST77	041160	SEOPCT	045452
MULTER	045104	SWR	= 001140	TST15	013742	TYPE	= 104401	SERFLG	001103
NEGDAR	061041	SWREG	= 000176	TST16	014160	TYPOC	= 104402	SERMAX	001115
NEGDNR	060635	SW0	= 000001	TST17	014264	TYPON	= 104404	SERROR	046514
NODAT	045216	SW00	= 000001	TST2	007130	TYPOS	= 104403	SERRPC	001116
NO	052717	SW01	= 000002	TST20	014372	WENTTO	052670	SERRTB	001442
NO4	071162	SW02	= 000004	TST21	014614	WWCDON	037400	SERTIL	001112

SYMBOL TABLE

\$ESCAP	001304	\$MAMS3	001356	\$REG0	001162	\$SWR =	177400	\$TNP7	001250
\$ETABL	001336	\$MAMS4	001362	\$REG1	001164	\$SWREG	001340	\$TN =	000115
\$ETEND	001442	\$MBADR	006104	\$REG10	001202	\$SWRMK=	000000	\$TPB	001152
\$FATAL	001320	\$MFLG	050232	\$REG11	001204	\$SWRMS=	000200	\$TPFLG	001157
\$FFLG	050234	\$MNEW	050673	\$REG12	001206	\$TAB	052167	\$TPS	001150
\$FILLC	001156	\$MSGAD	001332	\$REG13	001210	\$TBIT	046156	\$TRAP	050704
\$FILLS	001155	\$MSGLG	001334	\$REG14	001212	\$TERM =	000026	\$TRAP2	050726
\$GDADR	001120	\$MSGTY	001316	\$REG15	001214	\$TESTN	001322	\$TRP =	000013
\$GDDAT	001124	\$MSWR	050662	\$REG16	001216	\$TIMES	001302	\$TRPAD	050740
\$GE142	045744	\$MTYP1	001347	\$REG17	001220	\$TKB	001146	\$STM	006106
\$GTUSR	050306	\$MTYP2	001353	\$REG2	001166	\$TKS	001144	\$STSTM	001102
\$GT42C	046056	\$MTYP3	001357	\$REG20	001222	\$TMP0	001232	\$TYPE	047174
\$HD =	000003	\$MTYP4	001363	\$REG21	001224	\$TMP1	001234	\$TYPEC	047412
\$HIBTS	006102	\$MXCNT	046510	\$REG22	001226	\$TMP10	001252	\$TYPEX	047532
\$ICNT	001104	\$NULL	001154	\$REG23	001230	\$TMP11	001254	\$TYPLOC	047560
\$ILLUP	051144	\$NWTST=	000001	\$REG3	001170	\$TMP12	001256	\$TYPON	047574
\$INTAG	001135	\$OCNT	047764	\$REG4	001172	\$TMP13	001260	\$TYPPOS	047534
\$ITEMB	001114	\$OMODE	047766	\$REG5	001174	\$TMP14	001262	\$UNIT	001330
\$LF	001314	\$OVER	046472	\$REG6	001176	\$TMP15	001264	\$UNITM	006112
\$LFLG	050233	\$PASS	001324	\$REG7	001200	\$TMP16	001266	\$USWR	001342
\$LOOP	046152	\$PASS2	046166	\$RESRE	047134	\$TMP17	001270	\$VECT1	001366
\$LPADR	001106	\$PASTM	006110	\$RTNAD	046154	\$TMP2	001236	\$VECT2	001370
\$LPERR	001110	\$PWRRAD	051126	\$RTRN	046150	\$TMP20	001272	\$XOFF =	000023
\$MADR1	001350	\$PWRRDN	050766	\$SAVRE	047076	\$TMP21	001274	\$XON =	000021
\$MADR2	001354	\$PWRRMG	051122	\$SAVR6	051150	\$TMP22	001276	\$XTSTR	046202
\$MADR3	001360	\$PWRRUP	051040	\$SCOPE	046170	\$TMP23	001300	\$SGET4=	000001
\$MADR4	001364	\$QUES	001312	\$SETUP=	000137	\$TMP3	001240	\$SOFILL	047765
\$MAIL	001316	\$RDCHR	050520	\$STUP =	177777	\$TMP4	001242	.RSET	052050
\$MAMS1	001346	\$RDSZ	= 000001	\$SVLAD	046436	\$TMP5	001244	.SX =	006102
\$MAMS2	001352	\$REGAD	001160	\$SVPC =	006102	\$TMP6	001246		

. ABS. 074240 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 60768 WORDS (238 PAGES)

DYNAMIC MEMORY: 20034 WORDS (77 PAGES)

ELAPSED TIME: 00:17:12

CKFPCD.BIN,CKFPCD/CR/-SP/NL:TOC=CKFPCD.MLB/ML,CKFPCD.P11