

CMQ11-K

CSS CMQ11-K CD RD DIA AH-S947A-MC
CVCMAAO FICHE 1 OF 1

MAR 1982
COPYRIGHT © 1981
MADE IN USA



.REM

IDENTIFICATION

PRODUCT CODE: AC-S945A-MC

PRODUCT NAME: CVCMAAO CSS CMQ11K CD RD DIA

DATE: 1 JULY 1981

MAINTAINER: COMPUTER SPECIAL SYSTEMS

AUTHORS: RICK FADDEN
RAYMOND SHOOP
R. J. COLLINS
J. M. DUPRE

COPYRIGHT 1981 DIGITAL EQUIPMENT CORPORATION
MAYNARD, MASS

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED IN SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BY PROVIDED IN WRITING BY DEC.

1. ABSTRACT

THIS TEST IS TO BE USED AS A CARD READER DIAGNOSTIC FOR THE LSI-11 WITH THE CMQ11-K CARD READER. IT TESTS ALL LOGIC FUNCTIONS OF THE CARD READER, AND INCLUDES AN EXERCISER FOR PUNCH ALPHANUMERIC, PUNCH BINARY, AND MARKSENSE BINARY TEST DECKS. A SEPARATE STARTING ADDRESS ALLOWS THE ERROR SENSING FUNCTIONS OF THE READER TO BE CHECKED. ANOTHER STARTING ADDRESS TESTS SPECIAL DECKS WHICH HAVE ALL COLUMNS AND CARDS PUNCHED OR MARKED IDENTICALLY, TO AID IN DIAGNOSING SPECIAL PROBLEMS.

2. REQUIREMENTS

2.1 EQUIPMENT

LSI-11 STANDARD COMPUTER
CR11 CARD CONTROLLER
MARKSENSE CARD READER

2.2 TEST DECKS

MAINDEC-11-DZCMF-CA	ALPHANUMERIC TEST DECK
MAINDEC-11-DZCMF-CB	BINARY TEST DECK
MAINDEC-11-DZCMF-C01	80-COLUMN MARKSENSE TEST DECK
MAINDEC-11-DZCMF-C02	40-COLUMN MARKSENSE TEST DECK
SPARE CARDS FOR THE ERROR FUNCTION TEST	

2.3 STORAGE

THE ROUTINE USES MEMORY 0 TO 16202.

3. LOADING PROCEDURE

PROCEDURE FOR NORMAL ABSOLUTE TAPES SHOULD BE FOLLOWED.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

BASIC SWITCH REGISTER SETTINGS ARE:

SW15=1 ---HALT ON ERROR
SW14=1 ---SCOPE LOOP
SW13=1 ---INHIBIT PRINT OUT
SW12=1 ---INHIBIT TRACE TRAPPING
SW11=1 ---INHIBIT SUB-PROGRAM ITERATION
(NOTE THAT IF SW11 IS SET, THE CARD COUNT
WILL BE ALTERED, CAUSING FAILURES IN THE
DATA TEST SECTION.)
SW07=1 ---LOOP THRU THE INSTRUCTION TEST PORTION
(NOTE THAT THE PROGRAM MAY HANG LEGITIMATELY
WHEN THE INPUT HOPPER GOES EMPTY IF SW7 IS SET)
SW06=1 ---RETURN TO THE BEGINNING OF THE INSTRUCTION TEST
WHEN CONTINUING FROM ONE DECK TO ANOTHER
SW05=1 ---HALT BETWEEN TEST DECKS
(SEE 5.2.1 FOR EXPLANATION OF SW5=0)
SW04=1 ---RUN THE PUNCHED BINARY TEST DECK (UNLESS SW03 IS SET)
SW02=1 ---40 COLUMN CARD DECK
SW02=0 OR DOWN-80 COLUMN CARD DECK
SW03=1 ---RUN THE MARKSENSE BINARY TEST DECK

COMPUTERS WITHOUT A HARDWARE SWITCH REGISTER HAVE A SOFTWARE
SWITCH REGISTER LOCATION IN MEMORY CALLED "SWREG" (LOCATION 176).
THIS LOCATION CAN BE CHANGED TO REFLECT THE DESIRED SWITCH SETTINGS
BY TYPING CONTROL G.

4.2 STARTING ADDRESSES

200 = INSTRUCTION AND DATA TEST
210 = PICK SUBTEST LOOP
220 = ERROR FUNCTION TEST
240 = SINGLE SUBTEST LOOP
250 = READ SINGLE DATA PATTERN TEST

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 INSTRUCTION AND DATA RELIABILITY TEST (SA 200)

LOAD PROGRAM INTO MEMORY.
LOAD ONE TEST DECK IN THE CARD READER INPUT HOPPER.
PRESS RESET ON THE CARD READER, WAIT FOR RESET LIGHT.
THE PROGRAM WILL PRINT THE CURRENT CONTENTS OF THE SOFTWARE
SWITCH REGISTER AND WILL WAIT FOR NEW INPUT.
SET THE SOFTWARE SWITCH REGISTER TO DESIRED SETTING.
LOAD ADDRESS.
SET SWITCHES (SEE 4.1)--ALL DOWN FOR WORST CASE, ALPHA TEST DECK.
PRESS START.
WHEN THE INPUT HOPPER IS EMPTY THE PROGRAM WILL HANG WAITING
FOR AN INTERRUPT FROM THE CARD READER. LOAD ONE OR MORE
TEST DECKS INTO THE INPUT HOPPER. PRESSING 'RESET'
ON THE CARD READER SHOULD CAUSE PROGRAM EXECUTION
TO RESUME.
THIS ENTIRE SEQUENCE IS NECESSARY TO RUN THE FULL TEST ON THE CARD
READER.

4.3.2 PICK SUBTEST LOOP (SA 210)

LOAD CARDS (SPARE CARDS OR A TEST DECK) INTO THE INPUT HOPPER.
PRESS 'RESET' ON THE CARD READER, WAIT FOR THE RESET LIGHT.
LOAD THE STARTING ADDRESS.
PRESS START
AT THE HALT - LOAD SWITCH REGISTER WITH MOTION DELAY SIZE.

4.3.3 ERROR FUNCTION TEST (SA 220)

LOAD A FEW SPARE CARDS INTO THE INPUT HOPPER
PRESS 'RESET' ON THE CARD READER, WAIT FOR RESET LIGHT.
LOAD THE STARTING ADDRESS, THEN SET THE DESIRED SWITCH OPTIONS.
PRESS START.
FOLLOW THE INSTRUCTIONS AS THEY ARE PRINTED OUT.

4.3.4 SINGLE SUBTEST LOOP (SA 240)

LOAD CARDS (SPARE CARDS OR A TEST DECK) INTO THE INPUT HOPPER.
PRESS 'RESET' ON THE CARD READER, WAIT FOR RESET LIGHT.
LOAD THE STARTING ADDRESS.
PRESS START.
AT THE 1ST HALT, LOAD THE STARTING ADDRESS OF THE DESIRED TEST
(ADDRESS OF THE SCOPE INSTRUCTION AT THE BEGINNING OF
THE TEST.)
PRESS CONTINUE.
AT THE 2ND HALT SET THE SWITCH REGISTER OPTIONS (BIT 11 MUST=0).
PRESS CONTINUE.

4.3.5 SINGLE DATA PATTERN TEST (SA 250)

A SPECIAL DECK (1 OR MORE CARDS) MUST BE PUNCHED OR MARKED TO RUN THIS TEST. ANY DATA PATTERN MAY BE USED, BUT IT MUST BE IDENTICAL IN ALL 80 COLUMNS OF ALL THE CARDS (I.E. ONLY ONE PIECE OF DATA).

LOAD THIS PREPARED DECK INTO THE INPUT HOPPER.
PRESS CARD READER 'RESET', WAIT FOR RESET LIGHT.

LOAD SA 250.

PRESS START.

AT THE INITIAL HALT SET THE CARD IMAGE OF THE DATA PATTERN USED IN SW11-SW00.

PRESS CONTINUE.

WHEN THE CARD READER RUNS OUT OF CARDS IT WILL RING THE BELL.

RELOADING THE DECK AND PRESSING 'RESET' ON THE CARD READER WILL CONTINUE THE TEST.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

5.1.1 AT SA 200 (INSTRUCTION AND DATA RELIABILITY TEST)

SEE 4.1

5.1.2 AT SA 210 (PICK SUBTEST LOOP)

AT THE HALT - LOAD THE DELAY BETWEEN CARD MOTION IN THE SWITCH REGISTER.

5.1.3 AT SA 220 (ERROR FUNCTION TEST FOR CMQ11-K)

SW14=1 TO LOOP THRU THE CURRENT SUBTEST
SW15=1 TO HALT ON ERROR

5.1.4 AT SA 240 (SINGLE SUBTEST LOOP)

1ST HALT - LOAD STARTING ADDRESS OF DESIRED TEST
2ND HALT - SET SR OPTIONS (BIT 11 MUST=0)
SEE 4.1 FOR SR OPTIONS
NOTE THAT T-BIT IS NOT SET WHEN USING THIS STARTING POINT.

5.1.5 AT SA 250 (SINGLE DATA PATTERN TEST)

AT THE HALT-LOAD THE CARD-IMAGE OF THE DATA PATTERN IN SW11-SW00.

5.2 SUBROUTINE ABSTRACTS

5.2.1 BEGIN SA 200

THE INSTRUCTION TESTS ARE RUN FIRST, FOLLOWED BY THE DATA RELIABILITY TESTS ON THE REMAINING CARDS IN THE FIRST TEST DECK. AT THE END OF THE DECK THE BELL WILL RING. IF SW5=1, THE PROGRAM WILL PRINT THE CURRENT CONTENTS OF THE SOFTWARE SWITCH REGISTER AND WILL WAIT FOR THE NEW INPUT. IF YOU DO NOT DESIRE TO CHANGE THE CONTENTS OF THE SOFTWARE SWITCH REGISTER, HIT CARRIAGE RETURN TO CONTINUE.

IF SW5=0, PROGRAM ACTION DEPENDS ON THE NUMBER OF TEST DECKS LOADED. IF THERE ARE STILL CARDS IN THE INPUT HOPPER THE PROGRAM WILL RUN THE DATA RELIABILITY TEST ON THE ENTIRE DECK. IF THE INPUT HOPPER IS EMPTY AT THE END OF THESE TESTS, IT WAITS FOR THE CARD READER TO BE PUT BACK ON LINE. FURTHER CHECKS ARE MADE OF THE OFF-LINE TO ON-LINE OPERATIONS, AND THEN THE DATA RELIABILITY TEST IS RUN ON THE ENTIRE DECK. IF SW5=1, HITTING CARRIAGE RETURN WILL RESUME PROGRAM OPERATION AFTER PRINTING THE CURRENT CONTENTS OF SOFTWARE SWITCH REGISTER.

5.2.2 SCOPE

THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST IN THE INSTRUCTION SECTION. IT RECORDS THE STARTING ADDRESS OF EACH SUB-TEST AS IT IS BEING ENTERED. IF A SCOPE LOOP IS REQUESTED, IT WILL JUMP TO THE START OF THE SUBTEST THAT THE SCOPE LOOP IS REQUESTED FOR. IF SCOPE LOOP IS NOT REQUESTED, THERE WILL BE 1 ITERATION ON THAT SUBTEST BEFORE THE NEXT SUBTEST IS ENTERED. SWITCH 11 ON A 1 INHIBITS ITERATION OF SUBTESTS.

5.2.3 HLT

THIS SUBROUTINE PRINTS OUT THE LOCATION COUNTER AT THE TIME OF FAILURE, AND THE CONTENTS OF THE PROCESSOR STATUS REGISTER. NOTE THAT THE LOCATION COUNTER WILL BE THE ADDRESS OF THE HLT PLUS TWO.

5.2.4 TTRAP

THIS ROUTINE ALLOWS THE TRACE BIT TO BE SET AFTER THE FIRST LOOP OF THE PROGRAM. THE TRACE BIT WILL BE SET ON ALTERNATE LOOPS OF THE INSTRUCTION AND DATA TEST UNLESS SW12 IS SET. THE FIRST INSTRUCTION EXECUTED UPON TRAPPING IS AN 'RTI' (OR 'RTT') WHICH RETURNS TO THE INTERRUPTED SEQUENCE. THIS CONTINUES UNTIL THE END OF THE PROGRAM LOOP IS REACHED.

5.2.5 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0 DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS AND INTERRUPTS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

EACH VECTOR ENTRANCE ADDRESS IS LOADED WITH THE ADDRESS OF THE NEXT LOCATION. THE NEXT LOCATION IS LOADED WITH A HALT (000000). THUS AN ILLEGAL TRAP OR INTERRUPT WILL CAUSE A HALT AT THE TRAP LOCATION PLUS TWO.

IF A HALT OCCURS IN THE TRAP OR INTERRUPT AREA, EXAMINE REGISTER SIX. IT WILL CONTAIN THE CURRENT STACK ADDRESS. THE CONTENTS OF THE CURRENT STACK ADDRESS IS THE VALUE OF THE LOCATION COUNTER WHEN THE TRAP OR INTERRUPT OCCURRED.

5.2.6 ERCM11 (ERROR FUNCTION TEST)

THIS TEST CHECKS OPERATION OF THE VARIOUS ERROR SENSING FEATURES OF THE MARKSENSE CARD READER. CARD READER OFF-LINE, INPUT HOPPER EMPTY, AND OUTPUT STACKER FULL ARE CHECKED.

5.2.7 TESTX (SINGLE TEST LOOP)

THIS ROUTINE ALLOWS A SINGLE SUBTEST TO BE RUN CONTINUOUSLY FOR SCOPE LOOP PURPOSES. WHILE A SCOPE LOOP SWITCH OPTION EXISTS, IT REQUIRES THAT YOU ARE WITHIN THE TEST IN WHICH YOU WISH TO LOOP. IN SOME CASES (SUCH AS WITH INTERMITTENT FAILURES) THAT'S NOT EASY TO DO. THIS SUBROUTINE ALLOWS YOU TO LOAD THE ADDRESS OF ANY TEST FROM TEST0 THRU TEST24 AND TESTA THRU TESTG AT THE HALT AND THEN GO DIRECTLY TO THAT TEST.

5.2.8 CKSAME (SINGLE DATA PATTERN TEST)

THIS TEST IS DESIGNED TO AID IN THE DIAGNOSIS OF DIFFICULT DATA ERROR PROBLEMS AND FACILITATE SOME CARD READER ADJUSTMENTS. IT CONTINUOUSLY READS CARDS WHICH HAVE ALL COLUMNS PUNCHED OR MARKED IDENTICALLY (AND ALL CARDS MUST BE IDENTICAL), CHECKING THE DATA AGAINST A PATTERN SET UP ON THE SWITCHES INITIALLY. ANY ERRORS ARE PRINTED OUT, ALONG WITH A COUNT OF THE TOTAL NUMBER OF CARDS READ AND THE TOTAL NUMBER OF DATA ERRORS WHICH HAVE OCCURRED SINCE THE TEST WAS STARTED.

6. ERRORS

6.1 ERROR PRINTOUT

6.1.1 STANDARD PRINTOUT

PRINTOUTS ARE IN A TWO-WORD FORMAT. THE FIRST IS THE PC+2 OF THE DETECTED ERROR. THE SECOND IS THE CONTENTS OF THE PROCESSOR STATUS REGISTER WHEN THE ERROR WAS DETECTED.

6.1.2 DATA ERROR PRINTOUT

THE HEADING IS PRINTED OUT ONCE PER TEST DECK. THE COLUMNS HAVE THE FOLLOWING SIGNIFICANCE:

DECK -EITHER PUNCHED ALPHANUMERIC, PUNCHED BINARY, 80 COLUMN OR 40 COLUMN MARKSENSE DECK, DEPENDING ON SWITCHES 3 AND 4
CARD -THE CARD NUMBER WHERE THE FAILURE OCCURRED <DEC.>
COLUMN -THE COLUMN NUMBER WHERE THE FAILURE OCCURRED <DEC.>
PATTERN -THE CORRECT CARD IMAGE DATA THAT SHOULD HAVE BEEN READ
READ1 -THE CARD IMAGE DATA IS READ TWICE. THIS IS WHAT WAS READ THE FIRST TIME FROM CRB1
READ2 -THIS IS WHAT WAS IN CRB1 AFTER A BRIEF TIMING LOOP. IT SHOULD BE THE SAME AS THE PREVIOUS READING.
CODED -THIS IS WHAT THE DATA SHOULD BE IN ENCODED FORM
READ -THIS IS WHAT WAS READ BY ADDRESSING THE ENCODED BUFFER

DATA ERRORS NOT TRACED TO CARD READER HARDWARE INCLUDE:

- A. SW03 AND SW04 NOT SET TO TYPE OF DECK USED
- B. CARD MISSING
- C. DAMAGED CARD
- D. ALPHA OR BINARY TEST DECK NOT IN PROPER SEQUENCE

6.1.3 SINGLE DATA PATTERN PRINTOUT

THE SINGLE DATA PATTERN TEST PRINTS OUT A HEADING WITH EACH ERROR PRINTOUT. THE COLUMNS HAVE THE FOLLOWING SIGNIFICANCE:

COLUMN -THE COLUMN NUMBER WHERE THE FAILURE OCCURRED.
READ1 -DATA IS READ TWICE. THIS IS THE FIRST READING.
READ2 -THIS IS WHAT WAS READ THE SECOND TIME.
CARDS -THE TOTAL NUMBER OF CARDS (IN OCTAL) THAT HAVE BEEN RUN SINCE THE TEST WAS STARTED.
ERRORS -THE TOTAL NUMBER OF ERRORS DETECTED (IN OCTAL) SINCE THE TEST WAS STARTED.

6.2 ERROR RECOVERY

IN GENERAL, TEST FAILURES WILL PRINTOUT AN ERROR MESSAGE AND CONTINUE. IF THE "HALT ON ERROR" SWITCH IS SET, HITTING CONTINUE WILL RECOVER. IF THE PROGRAM HANGS UP IN A LOOP, THE ERROR IS LIKELY TO BE A SIGNAL WHICH WAS NEVER RECEIVED. IF A HALT OCCURS IN THE TRAP AND VECTOR AREA THE PROGRAM MUST BE RESTARTED. IF THE PROGRAM HALTS IN THE MAIN FLOW, CONSULT THE LISTING IF NO MESSAGE IS TYPED OUT.

.ENABL ABS,AMA
.NLIST MD,MC,CND

.LIST SEQ,BIN,LOC,ME

.TITLE CMQ11-K CARD READER TEST YM-Z110A-AA

:10 AUGUST 1976

:R. J. COLLINS

:COPYRIGHT 1973,1974,1975,1976,1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754

541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
569
570
571 000014
572 000016
573
574 000030
575 000032
576 000034
577 000036

177570
000240
104000
104400
000006
000000
000001
000002
000003
000004
000005
000006
000007

HSR=177570
NOP=240
HLT=EMT
SCOPE=TRAP
RTT=6
ADINT=%0
COUNT=%1
R2=%2
CRS=%3
CRB1=%4
R5=%5
SP=%6
PC=%7

:CONTAINS ADDRESS OF INTERRUPT VECTOR
:USED FOR TIMING, ETC.
:SCRATCH
:CONTAINS ADDRESS OF CARD READ STATUS REGISTER
:CONTAINS ADDRESS OF CARD READER BUFFER (12 BIT DATA)
:SCRATCH
:STACK POINTER
:PROGRAM COUNTER

:LOAD TRAP CATCHER INTO LOCATIONS 0 THRU 377
:LOAD TRAP VECTORS FOR HLT AND SCOPE ROUTINES

.=14
TRTRAP
340
.=30
PRINT
340
SCOPEC
340


```
579 ;LOAD STARTING ADDRESS AREA
580 000174      =174
581
582
583 000174 000000  DISPREG: 0
584 000176 000000  SWREG: 0
585
586 000200 012706 001000  MOV #STACK,SP
587 000204 000137 001242  JMP BEGIN ;NORMAL STARTING ADDRESS FOR CARD READER
588 000210 012706 001000  MOV #STACK,SP
589 000214 000137 010624  JMP DELAY ;PICK DELAY TEST
590 000220 012706 001000  MOV #STACK,SP
591 000224 000137 007142  JMP ERCM11 ;STARTING ADDRESS FOR CMQ11-K ERROR FUNCTION TEST
592 000240 000240      =240
593 000240 012706 001000  MOV #STACK,SP
594 000244 000137 010134  JMP TESTX ;STARTING ADDRESS FOR LOOP WHICH CONTINUALLY RUNS
595 ;ANY SINGLE SUBTEST
596 000250 012706 001000  MOV #STACK,SP
597 000254 000137 010222  JMP CKSAME ;STARTING ADDRESS OF TEST TO READ A SINGLE DATA
598
599
600 ;PATTERN CONTINUOUSLY
601 ;LOAD POINTERS AND GENERAL STORAGE
602 001000 001000      =1000
603 001000 000000  STACK: 0 ;STACK POINTER INITIALIZED TO POINT HERE
604 001012 001012      =.+10 ;IN CASE OF STACK OVERFLOW
605 001012 000000  INTFLG: 0 ;CONTAINS LEVEL THAT INTERRUPT IS FOUND AT
606 001014 000230  INTVC: 230 ;ADDRESS OF CARD READER INTERRUPT VECTOR
607 001016 000000  KBCSR:
608 001016 177560  TKS: 177560 ;ADDRESS OF KEYBOARD CSR
609 001020 000000  KBUF:
610 001020 177562  TKB: 177562 ;ADDRESS OF KEYBOARD BUFFER
611 001022 000000  TCSR:
612 001022 177564  TPS: 177564 ;ADDRESS OF TELETYPE STATUS REGISTER
613 001024 000000  TDBR:
614 001024 177566  TPB: 177566 ;ADDRESS OF TELETYPE DATA BUFFER
615 001026 177160  KCRS: 177160 ;ADDRESS OF CARD READER STATUS REGISTER
616 001030 177162  KCRB1: 177162 ;ADDRESS OF CARD READER DATA BUFFER
617 001032 177164  CRB2: 177164 ;ADDRESS TO READ ENCODED DATA
618 001034 177570  SWR: .WORD DSWR ;ADDRESS OF SWITCH REGISTER
619 001036 177570  DISPLAY: .WORD DDISP ;ADDRESS OF DISPLAY REG
620 001040 000000  APASS: .WORD 0 ;PASS COUNT
621 001042 000000  ASWREG: .WORD 0 ;APT SWITCH REG
622 001044 000000  AENVN: .WORD 0 ;ENVIRONMENT REGISTER
623 001046 000000  AUTOB: .WORD 0 ;AUTOMATIC MODE INDICATOR
624 001050 000000  INTAG: .WORD 0 ;INTERRUPT MODE INDICATOR
625 000004  ERRVEC=4
626 177570  DSWR=177570 ;HARDWARE SWITCH REGISTER
627 177570  DDISP=177570 ;HARDWARE DISPLAY REGISTER
628 001052 000002  TRTRAP: RTI ;RETURN FROM TRACE LOOP (CHANGED TO RTT FOR AN 11/45)
629 001054 000000  TRFLG: 0 ;TOGGLED TO SWITCH BETWEEN TRACE TRAPPING AND NORMAL FLO
630 001056 000000  PROC: 0 ;STORES PROCESSOR STATUS WHEN TRACE TRAP MUST BE CLEARED
631 ;IN A SUBTEST
632 001060 000000  ERFLG: 0 ;SET TO ZERO TO OUTPUT DATA ERROR HEADING
633 001062 177772  PIRQ: 177772 ;ADDRESS OF PDP 11/45 PIRQ REGISTER
```



```

635
636
637 001064 012737 000001 011460 :INITIALIZE CSR AND DBR POINTERS
        SETUP: MOV #1,ITMAX ;SET ITERATION MAXIMUM TO 1 ITERATION
638 001072 013703 001026          MOV KCRS,CRS ;SET UP REGISTER POINTERS
639 001076 013704 001030          MOV KCRB1,CRB1
640 001102 013700 001014          MOV INTVC,ADINT ;LOAD ADDRESS OF INTERRUPT VECTOR
641 001106 005037 001012          CLR INTFLG ;INITIALIZE INTERRUPT FLAG
642 001112 005037 001054          CLR TRFLG ;INITIALIZE TRACE FLAG
643 001116 012737 001144 000010 MOV #TRET,@#10 ;SETUP RESERVED ADDRESS TRAP RETURN
644 001124 005037 000012          CLR @#12
645 001130 006705          6705 ;EXTEND R5
646 001132 000240          NOP
647 001134 012737 000006 001052 MOV #RTT,@#TRTRAP ;IF NO TRAP THIS IS AN 11/45 OR 11/40
648 001142 000404          BR .+12
649 001144 012737 000002 001052 TRET: MOV #RTI,@#TRTRAP ;IF TRAP, NOT AN 11/45 OR 11/40
650 001152 022626          CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
651 001154 012737 000012 000010 MOV #12,@#10
652 001162 004737 012520          JSR PC,SWRCK
653 001166 012737 000200 011246 MOV #200,PRIOR
654 001174 106437 011246          MTPS PRIOR
655 001200 012737 000050 006426 MOV #40.,COLSIZ ;SETUP FOR 40 OR 80
656 001206 012737 000047 006430 MOV #39.,COLM1
657 001214 032777 000004 005210 BIT #4,@SR ;SR2=1 FOR 40 COL.
658 001222 001006          BNE 1$
659 001224 062737 000050 006430 ADD #40.,COLM1
660 001232 062737 000050 006426 ADD #40.,COLSIZ
661 001240 000207          1$: RTS ;RETURN
662
663 001242 004737 001064          BEGIN: JSR %7,SETUP ;INITIALIZE POINTERS AND FLAGS
664 001246 004737 011544          JSR PC,CRLF ;
665 001252 004737 011702          JSR PC,GTSWR ;
666 001256 005037 006412          CLR DECCYC ;COUNTS # OF TIMES THROUGH DECK
667 001262 000443          BR TEST ;GO TO INSTRUCTION TESTS
668 001264 012746 000340          RESTRT: MOV #340,-(SP) ;PUSH STATUS ON STACK
669 001270 012746 001372          MOV #TEST,-(SP) ;PUSH PC ON STACK
670 001274 000005          RESET
671 001276 004737 011544          JSR PC,CRLF ;
672 001302 004737 011702          JSR PC,GTSWR ;
673 001306 005037 006412          CLR DECCYC ;
674 001312 012737 000050 006426 MOV #40.,COLSIZ ;SETUP FOR 40 OR 80
675 001320 012737 000047 006430 MOV #39.,COLM1 ;
676 001326 032777 000004 005076 BIT #4,@SR ;
677 001334 001006          BNE 1$ ;
678 001336 062737 000050 006426 ADD #40.,COLSIZ ;
679 001344 062737 000050 006430 ADD #40.,COLM1 ;
680 001352          1$:
681 001352 005737 001054          TST TRFLG ;CHECK FLAG
682 001356 100004          BPL PSSET ;IF IT IS POSITIVE, CLEAR T BIT
683 001360 032777 010000 005044 BIT #10000,@SR ;TRACE TRAPPING INHIBITED?
684 001366 001000          BNE PSSET ;BRANCH IF YES
685 001370 000002          PSSET: RTI
686          ;TEST FOR CORRECT INITIALIZATION OF STATUS REGISTER
687 001372 012737 001402 011464 TEST: MOV #TEST1A,RETURN ;SETUP SCOPE LOOP RETURN ADDRESS
688 001400 104400          TEST1: SCOPE ;SO ALL TESTS START WITH SCOPE
689 001402 004737 011022          TEST1A: JSR %7,CKBIT8 ;CHECK FOR OFF-LINE SET
690 001406 004737 010722          JSR %7,CLRTR ;STORE PROCESSOR STATUS AND CLEAR TRACE BIT

```



```
747 001606 052713 040000      CONT2: BIS      #40000,@CRS      ;DATO TO STATUS REGISTER SHOULD CLEAR
748 001612 032713 040000      BIT      #40000,@CRS      ;CARD DONE
749 001616 001401              BEQ      .+4              ;BRANCH IF IT DID
750 001620 104000              HLT                      ;DATO DIDN'T CLEAR CARD DONE
751
752 001622 104400
753
754
755 001624 004737 011022      TEST3: SCOPE
756 001630 005013              ;BUSY (BIT 9) SHOULD BE SET BY READING A CARD
757 001632 005213              ;IT SHOULD REMAIN SET UNTIL CARD DONE SETS, WHICH SHOULD CLEAR IT
758 001634 032713 001000      JSR      %7,CKBIT8      ;CHECK FOR OFF-LINE SET
759 001640 001002              CLR      @CRS           ;INITIALIZE STATUS REGISTER
760 001642 104000              INC      @CRS           ;READ A CARD
761 001644 000417              BIT      #1000,@CRS     ;CHECK BUSY
762 001646 032713 040000      BNE     LOOP3           ;BRANCH IF SET
763 001652 001010              HLT                      ;READING A CARD DIDN'T SET BUSY
764 001654 032713 001000      BR      TEST4
765 001660 001372              LOOP3: BIT      #40000,@CRS ;CHECK CARD DONE
766 001662 032713 040000      BNE     DONE3           ;BRANCH IF SET
767 001666 001006              BIT      #1000,@CRS     ;CHECK BUSY
768 001670 104000              BNE     LOOP3           ;BRANCH IF STILL SET
769 001672 000404              BIT      #40000,@CRS     ;CHECK CARD DONE
770 001674 032713 001000      BNE     TEST4           ;GO TO NEXT TEST IF SET
771 001700 001401              HLT                      ;BUSY CLEARED BEFORE CARD DONE SET
772 001702 104000              BR      TEST4
773
774 001704 104400      DONE3: BIT      #1000,@CRS ;CHECK BUSY
775
776
777
778
779
780 001706 004737 010674      TEST4: SCOPE
781 001712 005001              ;A TIMING ERROR SHOULD OCCUR IF DATA IS NOT READ AND NEW DATA COMES IN
782 001714 005213              ;A TIMING ERROR SHOULD SET THE SPECIAL CONDITION BIT WHEN CARD DONE OCCURS
783 001716 032713 140200      ;COLUMN READY SHOULD BE CLEARED BY THE TIMING ERROR AND PREVENTED FROM RESETTNG
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
```

```
JSR      %7,INIT          ;INIT STATUS REGISTER
CLR      COUNT            ;INITIALIZE COUNTER
INC      @CRS             ;INITIATE READ
LOOP4:  BIT      #140200, @CRS ;WAIT FOR SPECIAL CONDITION, CARD DONE,
;OR COLUMN READY
BEQ      LOOP4            ;LOOP IF NONE OCCURRED
BIT      #140000, @CRS     ;SPECIAL CONDITION OR CARD DONE?
BNE     CK4               ;YES, BRANCH
INC      COUNT            ;NO, COUNT COLUMN READYS
LOOP4B: TSTB             ;WAIT FOR COLUMN READY TO CLEAR
BPL     LOOP4             ;IF CLEAR, RETURN TO LOOP4
BIT      #140000, @CRS     ;CHECK FOR SPECIAL CONDITION OR CARD DONE
BNE     CK4               ;BRANCH IF EITHER SET
BR      LOOP4B            ;OTHERWISE, CHECK AGAIN
CK4:    BIT      #40000, @CRS ;CHECK CARD DONE
BNE     .+6               ;BRANCH IF SET
HLT                      ;SPECIAL CONDITION SET BEFORE CARD DONE
BR      CONT4
TST      @CRS             ;CHECK SPECIAL CONDITION
BMI     .+4               ;BRANCH IF SET
HLT                      ;SPECIAL CONDITION WASN'T SET
CONT4:  BIT      #4000, @CRS ;CHECK TIMING ERROR
BNE     .+4               ;BRANCH IF SET
```



```
1699 006724 001375          BNE      -4          ;LOOP UNTIL CLEAR
1700 006726 106460 000002    MTPS     2(ADINT)
1701 006732 104000          HLT
1702 006734 000'03          BR       SRVC2A     ;NO INTERRUPT OCCURRED
1703 006736 004737 010726    SRVC2: JSR      %7,BELL ;BRANCH AROUND
1704 006742 022626          CMP      (SP)+,(SP)+ ;RING BELL
1705 006744 032713 002000    SRVC2A: BIT     #2000,@CRS ;RESTORE STACK POINTER
1706 006750 001001          BNE      +4         ;CHECK BIT 10
1707 006752 104000          HLT      ;BRANCH IF SET
1708 006754 032713 000400    BIT     #400,@CRS  ;BIT 10 NOT SET
1709 006760 001401          BEQ     +4         ;CHECK BIT 8
1710 006762 104000          HLT      ;BRANCH IF NOT SET
1711 006764 032713 030000    BIT     #30000,@CRS ;BIT 8 WAS SET
1712 006770 001401          BEQ     +4         ;CHECK BITS 12 AND 13
1713 006772 104000          HLT      ;BRANCH IF NOT SET
1714 006774 005013          CLR     @CRS       ;BIT 12 AND/OR 13 STILL SET IN CRS
1715 006776 032713 002000    BIT     #2000,@CRS ;DATO TO CRS
1716 007002 001401          BEQ     +4         ;CHECK BIT 10
1717 007004 104000          HLT      ;BRANCH IF NOT SET
1718 007006 022626          CMP     (SP)+,(SP)+ ;DATO DIDN'T CLEAR ON-LINE BIT
1719 007010 000137 006172    JMP     DECKCK     ;RESTORE STACK FROM INITIAL INTERRUPT
1720
1721                          ;RESTART
1722 007014 023737 006424 006420 ;WHEN INTERRUPT SERVICE WAS ENTERED, OFF-LINE (BIT 8) WAS SET
1723 007022 001406          OFFSET: CMP     DEKSIZ,CDCNT ;LAST CARD?
1724 007024 104000          BEQ     OFFS1     ;YES-BRANCH
1725 007026 004737 011022    HLT
1726 007032 004737 006302    JSR     %7,CKBIT8 ;NO,OFF-LINE SET BUT NOT 8OTH CARD
1727 007036 000002          JSR     %7,NXCRD
1728 007040 032777 000010 177364 OFFS1: RTI
1729 007046 001402          BIT     #10,@SR   ;MARKSENSE?
1730 007050 000137 006446    BEQ     1$        ;NO
1731 007054 023737 006426 006422 1$: JMP     ALLDON    ;YES
1732 007062 001002          CMP     COLSIZ,CLCNT ;LAST COLUMN?
1733 007064 000137 006446    BNE     +6        ;NO-SKIP OVER
1734 007070 104000          JMP     ALLDON    ;YES-GO RUN END OF DECK ROUTINE
1735 007072 004737 010726    HLT      ;OFF-LINE SET BEFORE LAST COLUMN OF LAST CARD
1736 007076 032777 000040 177326 JSR     %7,BELL
1737 007104 001403          BIT     #40,@SR
1738 007106 000000          BEQ     OFFS2
1739 007110 000137 006172    HALT    ;HALT AT END OF DECK SET
1740 007114 106737 011246    JMP     DECKCK    ;START NEW DECK
1741 007120 052737 000200 011246 OFFS2: MFPS     PRIOR
1742 007126 106437 011246    BIS     #200,PRIOR
1743 007132 106760 000002    MTPS     PRIOR
1744 007136 000137 006666    MFPS     2(ADINT)
1745                          JMP     ALWAIT
1746                          ;SETUP FOR ERROR FUNCTION TEST
1747 007142 004737 001064    ERCM11: JSR     %7,SETUP ;INITIALIZE REGISTERS
1748 007146 004737 011626    JSR     PC,CKSWR
1749 007152 012737 007162 011464 MOV     #TESTA+2,RETURN ;SETUP SCOPE LOOP RETURN ADDRESS
1750
1751                          ;THE CARD READER GOING OFF-LINE SHOULD SET SPECIAL CONDITION (BIT 15) AND OFF-LINE (BIT
1752 007160 104400          TESTA: SCOPE
1753 007162 005037 011460    CLR     ITMAX     ;RUN EACH ERROR TEST ONCE ONLY
1754 007166 004737 010674    JSR     %7,INIT   ;INITIALIZE STATUS REGISTER
```



```

1755 007172 012702 013645      MOV      #MSG25,R2
1756 007176 004737 011466      JSR      %7,TOUT      ;'PRESS CARD READER 'HALT' AND WAIT FOR THE RESET LIGHT
1757 007202 012702 013000      MOV      #MSG3,R2
1758 007206 004737 011466      JSR      PC,TOUT      ;TO LIGHT''
1759 007212 012702 012725      MOV      #MSG2,R2
1760 007216 004737 011466      JSR      %7,TOUT      ;''THEN HIT 'CONTINUE' ON THE CONSOLE''
1761 007222 004737 011544      JSR      %7,CRLF      ;MOVE MESSAGE UP ON TTY
1762 007226 004737 011544      JSR      %7,CRLF
1763 007232 004737 011544      JSR      %7,CRLF
1764 007236 004737 011544      JSR      %7,CRLF
1765 007242 004737 011612      JSR      PC,TTSTAL    ;WAIT FOR TTI
1766 007246 032713 000400      BIT      #400,@CRS    ;CHECK BIT 8
1767 007252 001001                BNE      .+4          ;BRANCH IF SET
1768 007254 104000                HLT
1769 007256 005713                TST      @CRS        ;OFF-LINE (BIT 8) WASN'T SET
1770 007260 100401                BMI      .+4          ;CHECK BIT 15
1771 007262 104000                HLT                ;BRANCH IF SET
1772 007264 012702 012632      MOV      #MSG1,R2    ;BIT 15 WASN'T SET
1773 007270 004737 011466      JSR      %7,TOUT      ;'PRESS CARD READER 'RESET' AND WAIT FOR THE RESET LIGHT
1774 007274 012702 013013      MOV      #MSG24,R2
1775 007300 004737 011466      JSR      PC,TOUT      ;TO GO OUT''
1776 007304 012702 012725      MOV      #MSG2,R2
1777 007310 004737 011466      JSR      %7,TOUT      ;''THEN HIT 'CONTINUE' ON THE CONSOLE''
1778 007314 004737 011544      JSR      %7,CRLF      ;MOVE MESSAGE UP ON TTY
1779 007320 004737 011544      JSR      %7,CRLF
1780 007324 004737 011544      JSR      %7,CRLF
1781 007330 004737 011544      JSR      %7,CRLF
1782 007334 004737 011612      JSR      PC,TTSTAL    ;WAIT FOR TTI
1783
1784
1785      ;INPUT HOPPER EMPTY SHOULD SET SPECIAL CONDITION
1786      ;IN THE PDI CARD READER IT SHOULD ALSO SET CARD SUPPLY ERROR
1786 007340 104400                TESTB: SCOPE
1787 007342 004737 010674      JSR      %7,INIT      ;INITIALIZE STATUS REGISTER
1788 007346 012702 013062      MOV      #MSG5,R2    ;'REMOVE ALL CARDS FROM THE INPUT HOPPER''
1789 007352 004737 011466      JSR      %7,TOUT
1790 007356 012702 012725      MOV      #MSG2,R2    ;''THEN HIT 'CONTINUE' ON THE CONSOLE''
1791 007362 004737 011466      JSR      %7,TOUT
1792 007366 004737 011544      JSR      %7,CRLF      ;MOVE MESSAGE UP ON TTY
1793 007372 004737 011544      JSR      %7,CRLF
1794 007376 004737 011544      JSR      %7,CRLF
1795 007402 004737 011544      JSR      %7,CRLF
1796 007406 004737 011612      JSR      PC,TTSTAL    ;WAIT FOR TTI
1797 007412 032713 000400      BIT      #400,@CRS    ;CHECK BIT8
1798 007416 001001                BNE      .+4          ;BRANCH IF SET
1799 007420 104000                HLT                ;OFF-LINE (BIT 8) WASN'T SET
1800 007422 005713                TST      @CRS        ;CHECK SPECIAL CONDITION BIT
1801 007424 100401                BMI      .+4          ;BRANCH IF SET
1802 007426 104000                HLT                ;SPECIAL CONDITION NOT SET
1803 007430 032713 020000      BIT      #20000,@CRS ;YES, TEST BIT 13
1804 007434 001001                BNE      .+4          ;CONTINUE IF SET
1805 007436 104000                HLT                ;CARD SUPPLY ERROR WASN'T SET
1806 007440 012702 013133      RESETB: MOV      #MSG6,R2 ;'RESTORE CARDS IN INPUT HOPPER''
1807 007444 004737 011466      JSR      %7,TOUT
1808 007450 012702 012632      MOV      #MSG1,R2    ;'PRESS CARD READER 'RESET' AND WAIT FOR THE RESET LIGHT
1809 007454 004737 011466      JSR      %7,TOUT
1810 007460 012702 013013      MOV      #MSG24,R2

```


2369 012424 005204
 2370 012426 000736
 2371 012430 012605
 2372 012432 012604
 2373 012434 012603
 2374 012436 000207
 2375 012440 000
 2376 012441 057
 2377 012442 000
 2378 012443 057
 2379 012444 000
 2380 012445 000
 2381 012446 000000
 2382
 2383
 2384
 2385 012450 105777 166346
 2386 012454 100375
 2387 012456 116677 000002 166340
 2388 012464 122766 000015 000002
 2389 012472 001003
 2390 012474 105037 012514
 2391 012500 000406
 2392 012502 122766 012212 000002
 2393 012510 001402
 2394 012512 105227
 2395 012514 000000
 2396 012516 000207
 2397
 2398
 2399
 2400 012520 013746 000004
 2401 012524 012737 012560 000004
 2402 012532 012737 177570 006432
 2403 012540 012737 177570 001036
 2404 012546 022777 177777 173656
 2405 012554 001012
 2406
 2407 012556 000403
 2408 012560 012716 012566
 2409 012564 000002
 2410 012566 012737 000176 006432
 2411 012574 012737 000174 001036
 2412 012602 012637 000004
 2413 012606 005037 001040
 2414 012612 132737 000200 001044
 2415 012620 001403
 2416 012622 012737 001042 006432
 2417 012630 000207
 2418
 2419
 2420 012632 040057 051120 051505
 012640 020123 040503 042122
 012646 051040 040505 042504
 012654 020122 051047 051505
 012662 052105 020047 047101

```

      INC      R4      ;INSURE LAST DIGIT IS NOT A BLANK
      BR      A2
A6:   MOV      (SP)+,R5 ;RESTORE R5
      MOV      (SP)+,R4 ;RESTORE R4
      MOV      (SP)+,R3 ;RESTORE R3
      RTS      PC
      .BYTE   0
A11:  .BYTE   057
A8:   .BYTE   0      ;STORAGE FOR ASCII DIGIT
      .BYTE   057    ;TERMINATOR FOR TYPE ROUTINE
CNT0: .BYTE   0      ;OCTAL DIGIT COUNTER
FILL0: .BYTE   0     ;ZERO FILL SWITCH
MODE0: .WORD  0     ;NUMBER OF DIGIT TO TYPE
      :
      :
      :
TYPEC: TSTB    @TPS   ;WAIT UNTIL THE PRINTER IS READY
      BPL     TYPEC
      MOVB    2(SP),@TPB ;LOAD CHARACTER TO BE TYPED INTO DATA RE
      CMPB    #15,2(SP) ;IS CHAR CARRIAGE RETURN?
      BNE     B1
      CLRB    CHARCNT ;YES CLEAR CHAR COUNT
      BR     TYPEX ;EXIT
B1:   CMPB    #LF,2(SP) ;IS CHAR LINE FEED?
      BEQ    TYPEX ;BRANCH IF YES
      INCB    (PC)+ ;COUNT THE CHARS
CHARCNT: .WORD  0 ;CHARACTER COUNT SPACE
TYPEX:  RTS     PC

;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
SWRCK: MOV     @#ERRVEC,-(SP) ;SAVE ERROR VECTOR
      MOV     #RT1,@#ERRVEC ;SET UP ERROR VECTOR
      MOV     #DSWR,SR ;SET UP FOR HARDWARE SWR
      MOV     #DDISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
      CMP     #-1,@SR ;TRY TO REFERENCE HARDWARE SWR
      BNE     RT3 ;BRANCH IF NO TIME OUT TRAP OCCURED
      ;AND THE HARDWARE SWR IS NOT = -1
      ;BRANCH IF NO TIME OUT
RT1:  MOV     #RT2,(SP) ;SET UP FOR TRAP RETURN
      RTI
RT2:  MOV     #SWREG,SR ;POINT TO SOFTWARE SWR
      MOV     #DISPREG,DISPLAY
RT3:  MOV     (SP)+,@#ERRVEC ;RESTORE ERROR VECTOR
      CLR     APASS ;CLEAR PASS COUNT
      BITB   #200,AENVM ;TEST USER SIZE UNDER APT
      BEQ    RT4 ;YES,USE NON-APT SWITCH
      MOV     #ASWREG,SR ;NO,USE APT SWITCH REGISTER
RT4:  RTS     PC

MSG1: .ASCII ;/ @PRESS CARD READER 'RESET' AND WAIT FOR THE 'RESET' LIGHT/;

```

CMQ11
 CVCMAA
 AENV
 ALCN
 ALLD
 ALLO
 ALPC
 ALPC
 ALPE
 ALPT
 ALWA
 APAS
 ASWR
 AUTO
 A1
 A11
 A2
 A3
 A4
 A5
 A6
 A7
 A8
 BEGI
 BELL
 BINCI
 BINCI
 BINEI
 B.CK
 B1
 CARD
 CDCN
 CHAR
 CKBI
 CKCO
 CKCR
 CKDO
 CKFA
 CKHL
 CKLO
 CKLP
 CKLP
 CKNO
 CKSA
 CKSI
 CKSI
 CKSW
 CK4
 CK5
 CK9
 CLCN
 CLRT
 CNTC
 CNTE
 CNTE
 CNTL
 CNTL

	012670	020104	040527	052111		
	012676	043040	051117	052040		
	012704	042510	023440	042522		
	012712	042523	023524	046040		
	012720	043511	052110	057		
2421	012725	057	052100	042510	MSG2:	.ASCII ;/@THEN HIT ANY KEY ON THE CONSOLE TERMINAL/;
	012732	020116	044510	020124		
	012740	047101	020131	042513		
	012746	020131	047117	052040		
	012754	042510	041440	047117		
	012762	047523	042514	052040		
	012770	051105	044515	040516		
	012776	027514				
2422	013000	040057	047524	046040	MSG3:	.ASCII ;/@TO LIGHT/;
	013006	043511	052110	057		
2423	013013	057	052100	020117	MSG24:	.ASCII ;/@TO GO OUT/;
	013020	047507	047440	052125		
	013026	057				
2424	013027	057	052100	042510	MSG4:	.ASCII ;/@THE INTERRUPT LEVEL WAS /;
	013034	044440	052116	051105		
	013042	052522	052120	046040		
	013050	053105	046105	053440		
	013056	051501	027440			
2425	013062	040057	042522	047515	MSG5:	.ASCII ;/@REMOVE ALL CARDS FROM THE INPUT HOPPER/;
	013070	042526	040440	046114		
	013076	041440	051101	051504		
	013104	043040	047522	020115		
	013112	044124	020105	047111		
	013120	052520	020124	047510		
	013126	050120	051105	057		
2426	013133	057	051100	051505	MSG6:	.ASCII ;/@RESTORE CARDS IN THE INPUT HOPPER/;
	013140	047524	042522	041440		
	013146	051101	051504	044440		
	013154	020116	044124	020105		
	013162	047111	052520	020124		
	013170	047510	050120	051105		
	013176	057				
2427	013177	057	051100	044501	MSG7:	.ASCII ;/@RAISE THE OUTPUT HOPPER STACK HEIGHT ARM/;
	013204	042523	052040	042510		
	013212	047440	052125	052520		
	013220	020124	047510	050120		
	013226	051105	051440	040524		
	013234	045503	044040	044505		
	013242	044107	020124	051101		
	013250	027515				
2428	013252	040057	042504	045503	MSG13:	.ASCII ;/@DECK CARD COLUMN PATTERN READ1 READ2 CODED READ/;
	013260	020040	041440	051101		
	013266	020104	047503	052514		
	013274	047115	050040	052101		
	013302	042524	047122	051040		
	013310	040505	030504	051040		
	013316	040505	031104	020040		
	013324	047503	042504	020104		
	013332	051040	040505	027504		
2429	013340	040057	046101	044120	MSG14:	.ASCII ;/@ALPHA /;
	013346	020101	057			

CMQ1
CVCMA
CNT0
CNT2
CNT2
CNT2
CNT2
CNT2
CNT2
CNT2
CNT2
COLM
COLS
CONT
CONT
CONT
CONT
CONT
CONT
CRB2
CRLF
C.CO
C.WA
DATE
DATM
DATS
DATS
DATS
DATS
DAT1
DAT2
DBRC
DCNT
DDIS
DECC
DECK
DECK
DECO
DECP
DECP
DEC1
DEC2
DEKS
DELA
DIGC
DIGI
DISP
DISP
DLAY
DLAY
DONE

2430	013351	057	041100	047111	MSG15: .ASCII ;/@BINARY/;
	013356	051101	027531		
2431	013362	040057	042522	042515	MSG17: .ASCII ;/@REMEDY THE ERROR CONDITION AND PRESS ANY KEY ON THE CONSOLE TERMINAL@
	013370	054504	052040	042510	
	013376	042440	051122	051117	
	013404	041440	047117	044504	
	013412	044524	047117	040440	
	013420	042116	050040	042522	
	013426	051523	040440	054516	
	013434	045440	054505	047440	
	013442	020116	044124	020105	
	013450	047503	051516	046117	
	013456	020105	042524	046522	
	013464	047111	046101	027500	
2432	013472	040057	044502	020124	MSG18: .ASCII ;/@BIT 8 WAS SET/;
	013500	020070	040527	020123	
	013506	042523	027524		
2433	013512	040057	047503	052514	MSG19: .ASCII ;/@COLUMN READ1 READ2 CARDS ERRORS/;
	013520	047115	051040	040505	
	013526	030504	051040	040505	
	013534	031104	020040	040503	
	013542	042122	020123	051105	
	013550	047522	051522	057	
2434	013555	057	046500	020113	MSG20: .ASCII ;/@MK SEN/;
	013562	042523	027516		
2435	013566	040057	046102	047101	MSG21: .ASCII ;/@BLANK/;
	013574	027513			
2436	013576	040057	046111	042514	MSG22: .ASCII ;/@ILLEGAL DECK SEQ. PROCEDURE/;
	013604	040507	020114	042504	
	013612	045503	051440	050505	
	013620	020056	051120	041517	
	013626	042105	051125	027505	
2437	013634	040057	030064	041440	MSG23: .ASCII ;/@40 COL/;
	013642	046117	057		
2438	013645	057	050100	042522	MSG25: .ASCII ;/@PRESS CARD READER 'HALT' AND WAIT FOR THE 'RESET' LIGHT/;
	013652	051523	041440	051101	
	013660	020104	042522	042101	
	013666	051105	023440	040510	
	013674	052114	020047	047101	
	013702	020104	040527	052111	
	013710	043040	051117	052040	
	013716	042510	023440	042522	
	013724	042523	023524	046040	
	013732	043511	052110	057	
2439	013737	057	050100	040514	MSG26: .ASCII ;/@PLACE PRESSURE ON CARDS IN THE INPUT HOPPER/;
	013744	042503	050040	042522	
	013752	051523	051125	020105	
	013760	047117	041440	051101	
	013766	051504	044440	020116	
	013774	044124	020105	047111	
	014002	052520	020124	047510	
	014010	050120	051105	057	
2440	014015	057	052100	020117	MSG27: .ASCII ;/@TO INHIBIT A NORMAL FEED/;
	014022	047111	044510	044502	
	014030	020124	020101	047516	
	014036	046522	046101	043040	

CMQ1
CVCMAA
DONE
DSWR
D.1
D.2
END
ENDC
END2
ERCM
ERFL
ERRV
ERR6
ERSE
ER1
FADJ
FAIL
FCNT
FIL
FLAG
FPRI
FTES
GTSW
HLT

HSR
INIT

INTA
INTF
INTV
ITCN
ITMA
KBCS
KBUF
KCRB
KCRS
K10
K11
K14
K15
K16
K17
K18
K19
K20
K7
K9
LACN
LAST
LAST
LAST

2491	014230	002040	2040	:21	M	11 4
2492	014232	000104	104			
2493	014234	002020	2020	:22	N	11 5
2494	014236	000105	105			
2495	014240	002010	2010	:23	O	11 6
2496	014242	000106	106			
2497	014244	002004	2004	:24	P	11 7
2498	014246	000107	107			
2499	014250	002002	2002	:25	Q	11 8
2500	014252	000110	110			
2501	014254	002001	2001	:26	R	11 9
2502	014256	000120	120			
2503	014260	002202	2202	:27	:	11 8 2
2504	014262	000112	112			
2505	014264	002102	2102	:28	\$	11 8 3
2506	014266	000113	113			
2507	014270	002042	2042	:29	*	11 8 4
2508	014272	000114	114			
2509	014274	002022	2022	:30)	11 8 5
2510	014276	000115	115			
2511	014300	002012	2012	:31	:	11 8 6
2512	014302	000116	116			
2513	014304	002006	2006	:32	BLANK	11 8 7
2514	014306	000117	117			
2515	014310	001000	ALPCD2: 1000	:33	0	0
2516	014312	000040	40			
2517	014314	001400	1400	:34	/	0 1
2518	014316	000041	41			
2519	014320	001200	1200	:35	S	0 2
2520	014322	000042	42			
2521	014324	001100	1100	:36	T	0 3
2522	014326	000043	43			
2523	014330	001040	1040	:37	U	0 4
2524	014332	000044	44			
2525	014334	001020	1020	:38	V	0 5
2526	014336	000045	45			
2527	014340	001010	1010	:39	W	0 6
2528	014342	000046	46			
2529	014344	001004	1004	:40	X	0 7
2530	014346	000047	47			
2531	014350	001002	1002	:41	Y	0 8
2532	014352	000050	50			
2533	014354	001001	1001	:42	Z	0 9
2534	014356	000060	60			
2535	014360	001202	1202	:43		0 8 2
2536	014362	000052	52			
2537	014364	001102	1102	:44	,	0 8 3
2538	014366	000053	53			
2539	014370	001042	1042	:45	%	0 8 4
2540	014372	000054	54			
2541	014374	001022	1022	:46	-	0 8 5
2542	014376	000055	55			
2543	014400	001012	1012	:47	>	0 8 6
2544	014402	000056	56			
2545	014404	001006	1006	:48	?	0 8 7
2546	014406	000057	57			

2603	014570	004042	4042		:77	<	12 8 4
2604	014572	000214	214				
2605	014574	004022	4022		:78	(12 8 5
2606	014576	000215	215				
2607	014600	004012	4012		:79	+	12 8 6
2608	014602	000216	216				
2609	014604	004006	4006		:80	1	12 8 7
2610	014606	000217	ALPEND: 217				
2611							
2612							
2613	014610	005225	BINCD: 5225		:1		
2614	014612	000267	267				
2615	014614	005737	5737		:2		
2616	014616	000277	277				
2617	014620	000552	0552		:3		
2618	014622	000017	17				
2619	014624	005245	5245		:4		
2620	014626	000267	267				
2621	014630	005717	5717		:5		
2622	014632	000277	277				
2623	014634	002552	2552		:6		
2624	014636	000117	117				
2625	014640	006245	6245		:7		
2626	014642	000327	327				
2627	014644	004717	4717		:8		
2628	014646	000237	237				
2629	014650	002552	2552		:9		
2630	014652	000117	117				
2631	014654	006245	6245		:10		
2632	014656	000327	327				
2633	014660	004727	4727		:11		
2634	014662	000237	237				
2635	014664	002562	2562		:12		
2636	014666	000117	117				
2637	014670	006245	6245		:13		
2638	014672	000327	327				
2639	014674	005327	5327		:14		
2640	014676	000277	277				
2641	014700	003162	3162		:15		
2642	014702	000157	157				
2643	014704	006245	6245		:16		
2644	014706	000327	327				
2645	014710	005327	5327		:17		
2646	014712	000277	277				
2647	014714	003172	3172		:18		
2648	014716	000157	157				
2649	014720	006251	6251		:19		
2650	014722	000326	326				
2651	014724	005323	5323		:20		
2652	014726	000277	277				
2653	014730	003572	3572		:21		
2654	014732	000157	157				
2655	014734	006451	6451		:22		
2656	014736	000327	327				
2657	014740	005123	5123		:23		
2658	014742	000277	277				

CMQ11
CVCMAA
TYP
TYP
TYP
TYP
T2IN
T2IN
WAIT
XLOO
ZERO
.
AB
ERR
CVC
RUN
RUN
COR

2659	014744	003572	3572	:24
2660	014746	000157	157	
2661	014750	006451	6451	:25
2662	014752	000327	327	
2663	014754	005125	5125	:26
2664	014756	000267	267	
2665	014760	003574	3574	:27
2666	014762	000147	147	
2667	014764	006451	6451	:28
2668	014766	000327	327	
2669	014770	005225	5225	:29
2670	014772	000267	267	
2671	014774	003674	3674	:30
2672	014776	000147	147	
2673	015000	002451	2451	:31
2674	015002	000127	127	
2675	015004	001225	1225	:32
2676	015006	000067	67	
2677	015010	003676	3676	:33
2678	015012	000157	157	
2679	015014	002452	2452	:34
2680	015016	000117	117	
2681	015020	001224	1224	:35
2682	015022	000047	47	
2683	015024	003736	3736	:36
2684	015026	000157	157	
2685	015030	002512	2512	:37
2686	015032	000117	117	
2687	015034	005224	5224	:38
2688	015036	000247	247	
2689	015040	005736	5736	:39
2690	015042	000257	257	
2691	015044	000512	0512	:40
2692	015046	000017	17	
2693	015050	005225	5225	:41
2694	015052	000267	267	
2695	015054	005737	5737	:42
2696	015056	000277	277	
2697	015060	000552	0552	:43
2698	015062	000017	17	
2699	015064	005245	5245	:44
2700	015066	000267	267	
2701	015070	005717	5717	:45
2702	015072	000277	277	
2703	015074	002552	2552	:46
2704	015076	000117	117	
2705	015100	006245	6245	:47
2706	015102	000327	327	
2707	015104	004717	4717	:48
2708	015106	000237	237	
2709	015110	002552	2552	:49
2710	015112	000117	117	
2711	015114	006245	6245	:50
2712	015116	000327	327	
2713	015120	004727	4727	:51
2714	015122	000237	237	

BINCD2:

2715	015124	002562	2562	:52
2716	015126	000117	117	
2717	015130	006245	6245	:53
2718	015132	000327	327	
2719	015134	005327	5327	:54
2720	015136	000277	277	
2721	015140	003162	3162	:55
2722	015142	000157	157	
2723	015144	006245	6245	:56
2724	015146	000327	327	
2725	015150	005327	5327	:57
2726	015152	000277	277	
2727	015154	003172	3172	:58
2728	015156	000157	157	
2729	015160	006251	6251	:59
2730	015162	000326	326	
2731	015164	005323	5323	:60
2732	015166	000277	277	
2733	015170	003572	3572	:61
2734	015172	000157	157	
2735	015174	006451	6451	:62
2736	015176	000327	327	
2737	015200	005123	5123	:63
2738	015202	000277	277	
2739	015204	003572	3572	:64
2740	015206	000157	157	
2741	015210	006451	6451	:65
2742	015212	000327	327	
2743	015214	005125	5125	:66
2744	015216	000267	267	
2745	015220	003574	3574	:67
2746	015222	000147	147	
2747	015224	006451	6451	:68
2748	015226	000327	327	
2749	015230	005225	5225	:69
2750	015232	000267	267	
2751	015234	003674	3674	:70
2752	015236	000147	147	
2753	015240	002451	2451	:71
2754	015242	000127	127	
2755	015244	001225	1225	:72
2756	015246	000067	67	
2757	015250	003676	3676	:73
2758	015252	000157	157	
2759	015254	002452	2452	:74
2760	015256	000117	117	
2761	015260	001224	1224	:75
2762	015262	000047	47	
2763	015264	003736	3736	:76
2764	015266	000157	157	
2765	015270	002512	2512	:77
2766	015272	000117	117	
2767	015274	005224	5224	:78
2768	015276	000247	247	
2769	015300	005736	5736	:79
2770	015302	000257	257	

2771 015304 000512
2772 015306 000017
2773
2774
2775
2776
2777 015310 005252
2778 015312 000256
2779 015314 002525
2780 015316 000127
2781 015320 007777
2782 015322 000377
2783 015324 004000
2784 015326 000200
2785 015330 002000
2786 015332 000100
2787 015334 001000
2788 015336 000040
2789 015340 000400
2790 015342 000001
2791 015344 000200
2792 015346 000002
2793 015350 000100
2794 015352 000003
2795 015354 000040
2796 015356 000004
2797 015360 000020
2798 015362 000005
2799 015364 000010
2800 015366 000006
2801 015370 000004
2802 015372 000007
2803 015374 000002
2804 015376 000010
2805 015400 000001
2806 015402 000020
2807 015404 000002
2808 015406 000010
2809 015410 000004
2810 015412 000007
2811 015414 000010
2812 015416 000006
2813 015420 000020
2814 015422 000005
2815 015424 000040
2816 015426 000004
2817 015430 000100
2818 015432 000003
2819 015434 000200
2820 015436 000002
2821 015440 000400
2822 015442 000001
2823 015444 001000
2824 015446 000040
2825 015450 002000
2826 015452 000100

BINEND: 0512 :80
17

:MARK SENSE CARD TABLE

MRKCD: 5252 ;1
256
2525 ;2
127
7777 ;3
377
4000 ;4
200
2000 ;5
100
1000 ;6
40
400 ;7
1
200 ;8
2
100 ;9
3
40 ;10
4
20 ;11
5
10 ;12
6
4 ;13
7
2 ;14
10
1 ;15
20
2 ;16
10
4 ;17
7
10 ;18
6
20 ;19
5
40 ;20
4
100 ;21
3
200 ;22
2
400 ;23
1
1000 ;24
40
2000 ;25
100

2827	015454	004000	4000	:26
2828	015456	000200	200	
2829	015460	004000	4000	:27
2830	015462	000200	200	
2831	015464	004000	4000	:28
2832	015466	000200	200	
2833	015470	004000	4000	:29
2834	015472	000200	200	
2835	015474	002000	2000	:30
2836	015476	000100	100	
2837	015500	002000	2000	:31
2838	015502	000100	100	
2839	015504	002000	2000	:32
2840	015506	000100	100	
2841	015510	002000	2000	:33
2842	015512	000100	100	
2843	015514	001000	1000	:34
2844	015516	000040	40	
2845	015520	001000	1000	:35
2846	015522	000040	40	
2847	015524	001000	1000	:36
2848	015526	000040	40	
2849	015530	001000	1000	:37
2850	015532	000040	40	
2851	015534	000400	400	:38
2852	015536	000001	1	
2853	015540	000400	400	:39
2854	015542	000001	1	
2855	015544	000400	400	:40
2856	015546	000001	1	
2857	015550	000400	400	:41
2858	015552	000001	1	
2859	015554	000200	200	:42
2860	015556	000002	2	
2861	015560	000200	200	:43
2862	015562	000002	2	
2863	015564	000200	200	:44
2864	015566	000002	2	
2865	015570	000200	200	:45
2866	015572	000002	2	
2867	015574	000100	100	:46
2868	015576	000003	3	
2869	015600	000100	100	:47
2870	015602	000003	3	
2871	015604	000100	100	:48
2872	015606	000003	3	
2873	015610	000100	100	:49
2874	015612	000003	3	
2875	015614	000040	40	:50
2876	015616	000004	4	
2877	015620	000040	40	:51
2878	015622	000004	4	
2879	015624	000040	40	:52
2880	015626	000004	4	
2881	015630	000040	40	:53
2882	015632	000004	4	

MKND40:

2883	015634	000020	20	:54
2884	015636	000005	5	
2885	015640	000020	20	:55
2886	015642	000005	5	
2887	015644	000020	20	:56
2888	015646	000005	5	
2889	015650	000020	20	:57
2890	015652	000005	5	
2891	015654	000010	10	:58
2892	015656	000005	6	
2893	015660	000010	10	:59
2894	015662	000006	6	
2895	015664	000010	10	:60
2896	015666	000006	6	
2897	015670	000010	10	:61
2898	015672	000006	6	
2899	015674	000004	4	:62
2900	015676	000007	7	
2901	015700	000004	4	:63
2902	015702	000007	7	
2903	015704	000004	4	:64
2904	015706	000007	7	
2905	015710	000004	4	:65
2906	015712	000007	7	
2907	015714	000002	2	:66
2908	015716	000010	10	
2909	015720	000002	2	:67
2910	015722	000010	10	
2911	015724	000002	2	:68
2912	015726	000010	10	
2913	015730	000002	2	:69
2914	015732	000010	10	
2915	015734	000001	1	:70
2916	015736	000020	20	
2917	015740	000001	1	:71
2918	015742	000020	20	
2919	015744	000001	1	:72
2920	015746	000020	20	
2921	015750	000001	1	:73
2922	015752	000020	20	
2923	015754	000000	0	:74
2924	015756	000000	0	
2925	015760	000000	0	:75
2926	015762	000000	0	
2927	015764	000000	0	:76
2928	015766	000000	0	
2929	015770	000000	0	:77
2930	015772	000000	0	
2931	015774	000000	0	:78
2932	015776	000000	0	
2933	016000	007777	7777	:79
2934	016002	000377	377	
2935	016004	004001	4001	:80
2936	016006	000220		
2937				
2938				

MRKEND: 220 ;END MARK SENSE TABLE
;PRINT DECIMAL VALUE IN R2

2939	016010	012737	177773	016164	DECPR:	MOV	#-5,DIGCNT
2940	016016	012737	016172	016170		MOV	#DECPNT+2,DECPNT
2941	016024	012737	000040	016166		MOV	#40,ZERO
2942	016032	012737	177777	016162	TYPT1:	MOV	#-1,DIGIT
2943	016040	005237	016162		TYPT2:	INC	DIGIT
2944	016044	167702	000120			SUB	@DECPNT,%2
2945	016050	100373				BPL	TYPT2
2946	016052	067702	000112			ADD	@DECPNT,%2
2947	016056	004737	016102			JSR	%7,DECOUT
2948	016062	005237	016164			INC	DIGCNT
2949	016066	001001				BNE	TYPT3
2950	016070	000207				RTS	%7
2951	016072	062737	000002	016170	TYPT3:	ADD	#2,DECPNT
2952	016100	000754				BR	TYPT1
2953	016102	005737	016162		DECOUT:	TST	DIGIT
2954	016106	001010				BNE	DEC1
2955	016110	022737	177777	016164		CMP	#-1,DIGCNT
2956	016116	001404				BEQ	DEC1
2957	016120	013737	016166	016162		MOV	ZERO,DIGIT
2958	016126	000406				BR	DEC2
2959	016130	012737	000060	016166	DEC1:	MOV	#60,ZERO
2960	016136	052737	000060	016162		BIS	#60,DIGIT
2961	016144	105777	162652		DEC2:	TSTB	@TCSR
2962	016150	100375				BPL	.-4
2963	016152	013777	016162	162644		MOV	DIGIT,@TDBR
2964	016160	000207				RTS	%7
2965	016162	000000			DIGIT:	0	
2966	016164	000000			DIGCNT:	0	
2967	016166	000040			ZERO:	40	
2968	016170	016172			DECPNT:	+.2	
2969	016172	023420				10000.	
2970	016174	001750				1000.	
2971	016176	000144				100.	
2972	016200	000012				10.	
2973	016202	000001				1.	
2974							
2975		000001				.END	

