

DUP-11

DUP-11 DCLT
CZDCLB0

AH-S975B-MC
FICHE 1 OF 2

OCT 1983
COPYRIGHT © 82-83
MADE IN USA



A large grid of approximately 15 columns and 15 rows of small, illegible data tables. Each cell in the grid contains a small table with multiple columns and rows of text, likely representing individual data points or small reports. The text is too small to be read accurately.



DUP-11

DUP-11 DCLT
CZDCLB0

AH-5975B-MC
FICHE 2 OF 2

OCT 1983
COPYRIGHT © 82-83
MADE IN USA



Microfilm strip containing multiple frames of data, likely a list or index, with columns of text and numbers.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 2

1

.TITLE CZDCLB DUP-11 DATA COMM. LINK TEST

.REM 8

IDENTIFICATION

PRODUCT CODE: AC-S974B-MC
PRODUCT NAME: CZDCLB0 DUP-11 DCLT
PRODUCT DATE: JUNE 1983
MAINTAINER: MERRIMACK DIAGNOSTIC ENGINEERING
AUTHOR: ERNIE COOPER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 3

REVISION HISTORY:

REV ---	DATE ----	AUTHOR -----	REASON -----
A	24-MAR-82	ERNIE COOPER	ORIGINAL ISSUE, DCLT FOR THE DUP-11
**JPB B	29-JUN-83	JOHN BEIKE	DTR WAS NOT BEING SET WHILE IN MODEM LOCAL LOOP-BACK WHICH CAUSED CTS NEVER TO COME TRUE. FIX: SET DTR WITH RTS.

TABLE OF CONTENTS

- 1.0 GENERAL INFORMATION
 - 1.1 PROGRAM ABSTRACT
 - 1.2 SYSTEM REQUIREMENTS
 - 1.3 RELATED DOCUMENTS AND STANDARDS
 - 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
 - 1.5 ASSUMPTIONS - RESTRICTIONS
- 2.0 OPERATING INSTRUCTIONS
 - 2.1 COMMANDS
 - 2.2 SWITCHES
 - 2.3 FLAGS
 - 2.4 HARDWARE QUESTIONS
 - 2.5 DATA COMM. LINK TEST COMMANDS
 - 2.5.1 MESSAGE COMMANDS
 - 2.5.2 STATISTICAL COMMANDS
 - 2.5.3 RUN COMMANDS
 - 2.5.4 DEFAULTS
 - 2.5.5 PRINT COMMANDS
 - 2.5.6 MISC COMMANDS
 - 2.6 QUICK STARTUP PROCEDURE
- 3.0 ERROR INFORMATION
 - 3.1 TYPES OF ERROR MESSAGES
 - 3.2 SPECIFIC ERROR MESSAGES
 - 3.2.1 COMMAND LINE INTERPRETER ERRORS
 - 3.2.2 DCLT ERRORS
 - 3.2.3 DEVICE ERRORS
- 4.0 PERFORMANCE AND PROGRESS REPORTS
 - 4.1 PRINTING EVENT LOG
 - 4.2 OPERATOR STATUS MESSAGES
 - 4.3 PRINTING DDCMP STATISTICAL AND ERROR LOG
- 5.0 DEVICE INFORMATION TABLES

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 5

6.0 MODE AND MESSAGE DESCRIPTIONS

6.1 MODE DESCRIPTIONS

- 6.1.1 TRANSMIT MODE
- 6.1.2 RECEIVE MODE
- 6.1.3 PASSIVE MODE
- 6.1.4 ACTIVE MODE
- 6.1.5 DOWN-LINE LOAD MODE
- 6.1.6 TALK MODE
- 6.1.7 LISTEN MODE
- 6.1.8 MAINTENANCE MODE

6.2 MESSAGE DESCRIPTIONS

7.0 OTHER INFORMATION

7.1 INTERFACING TO AN "ITEP" NODE

7.2 TROUBLESHOOTING HINTS

- 7.2.1 INTERNAL LOOP AT EACH NODE
- 7.2.2 TRANSMIT ON ONE NODE-RECEIVE ON THE OTHER
- 7.2.3 ONE NODE ACTIVE-THE OTHER NODE PASSIVE
- 7.2.4 BOTH NODES ACTIVE
- 7.2.5 TALK AND LISTEN NODES FOR COMMUNICATIONS

7.3 EXAMPLE OF COMMANDS

- 7.3.1 MESSAGES COMMANDS
- 7.3.2 STATISTICAL COMMANDS
- 7.3.3 RUN COMMANDS
- 7.3.4 PRINT COMMANDS
- 7.3.5 EXIT COMMAND

7.4 THINGS TO WATCH OUT FOR

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DCLT (DATA COMMUNICATION LINK TEST) PROGRAM IS MEANT TO PROVIDE FIELD SERVICE WITH A TOOL TO MAINTAIN DUP-11 COMMUNICATION LINKS. THIS PROGRAM ALLOWS THE DUP-11 TO COMMUNICATE WITH OTHER SYNCHRONOUS (INCLUDING DDCMP) DEVICES ON POINT TO POINT OR MULTIDROP NETWORKS. THIS DCLT PROGRAM WILL PROVIDE THE COVERAGE NECESSARY TO DETECT FAILURES TO THE COMPUTER EQUIPMENT, THE COMMUNICATION LINK, OR THE MODEM.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL (CHQUS?.SEQ WHERE ? IS REV. LEVEL OF THE MANUAL). THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

IN ORDER TO RUN THE DUP DCLT PROGRAM, THE FOLLOWING MINIMUM HARDWARE IS REQUIRED:

- A PDP-11 CPU
- MINIMUM OF 24K WORDS OF MEMORY
- A WORKING CLOCK
- A CONSOLE TERMINAL
- ANY XXDP+ SUPPORTED LOAD MEDIA
- DUP11-DA: M7867 MODULE
 - BC05C-25 CABLE
 - BC02-1D CABLE
 - H325 TEST CONNECTOR

1.3 RELATED DOCUMENTS AND STANDARDS

- XXDP+ USER'S MANUAL (CHQUS?.SEQ WHERE ? IS THE REV. LEVEL OF THE MANUAL - "C" IS THE CURRENT REV.).

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 7

1.4 DIAGNOSTIC HIERARCY PREREQUISITES

THE GOAL OF THE DATA COMM. LINK TEST PROGRAM IS TO TEST THE COMMUNICATION LINK AND THEREFORE ASSUMES THAT THE CPU'S, CLOCKS, DUP-11 AND THE DEVICES AT THE OTHER END OF THE LINK HAVE ALREADY BEEN TESTED.

IF A WORKING CLOCK IS NOT FOUND, THE PROGRAM WILL CONTINUE BUT ANY OF THE PROGRAM THAT TIMES THE DEVICE WILL HANG IF THE DEVICE TIMES OUT. ALSO, THE EVENT LOG WILL CONTAIN A ZERO EVENT TIME FOR ALL EVENTS LOGGED.

IT IS NOT THE INTENTION OF A DATA COMM. LINK TEST PROGRAM TO TEST THE DUP-11'S, BUT TO TEST THE COMMUNICATION LINK TO WHICH THEY ARE CONNECTED.

SOME OF THE DIAGNOSTICS THAT COULD BE RUN IF THE DUP-11 LOOKS BAD:

DZDPEXX CONFIDENCE TEST
DZDPBXX BASIC TRANSMITTER TESTS
DZDPCXX RECEIVER, MODEM CONTROL AND INTERRUPT TEST
DZDPDXX DATA AND FUNCTION TESTS
DXDPBXX DECX11 MODULE

XX= LATEST REVISION

1.5 ASSUMPTIONS - RESTRICTIONS

IT IS ASSUMED THAT THE COMMUNICATIONS DEVICE HAS BEEN TESTED USING THE PREREQUISITE DIAGNOSTICS. THE OPERATOR SHOULD HAVE READ THE USER DOCUMENTATION PORTION OF THE LISTING TO FAMILIARIZE HIMSELF WITH THE COMMANDS AND CAPABILITIES AVAILABLE UNDER THE DIAGNOSTIC SUPERVISOR AND DCLT.

THIS DIAGNOSTIC DOES NOT RUN THE DUP-11 IN BIT STUFF MODE. IT IS ASSUMED THAT IF THE LINK WORKS IN CHAR MODE THE LINK WILL WORK IN BIT STUFF MODE.

THE DUP-11 IS NOT A DMA DEVICE AND THUS MUST RELY ON THE SOFTWARE FOR SERVICE.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 8

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 9

USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBE*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	'BELL' ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 10

ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN 'PRELOADED' USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

THE DUP-11 DATA COMM. LINK TEST PROGRAM WILL NOT USE MORE THAN ONE UNIT. FOR THE DUP-11, THE HARDWARE INFORMATION REQUESTED WILL BE:

UNITS (D) ? 1<CR>

UNIT 0
FULL DUPLEX OPERATION : (L) Y ?
DEVICE CSR ADDRESS : (0) 160170 ?
INTERRUPT VECTOR ADDRESS: (0) 300 ?
REMOTE NODE "ITEP" : (L) N ?
IS THIS A MULTIPOINT NETWORK: (L) N ?

THE FULL DUPLEX QUESTION SHOULD BE ANSWERED "Y" WHEN USING FULL DUPLEX MODEMS, OR NULL MODEM, OR MODEM ELIMINATORS. ANSWER "N" FOR HALF DUPLEX MODEMS.

REMOTE NODE ITEP SHOULD BE ANSWERED "Y" IF OTHER NODE IS RUNNING SOFTWARE THAT IS USING "ITEP" FORMATS (I.E. PDP-11 RUNNING ITEP).

IF OTHER NODE IS USING ITEP, THE ABOVE 'MULTIPOINT NETWORK' QUESTION WILL NOT APPEAR.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 11

IF TO THE 'MULTIPOINT NETWORK' QUESTION, YOU RESPOND WITH 'Y'
THEN

ADDRESS THIS STATION: (D) 1 ?

WILL BE DISPLAYED. INPUT THE DECIMAL TRIBUTARY ADDRESS (1-255)
OF THIS DUP-11.

2.5 DATA COMM. LINK TEST COMMANDS

THE 'DCLT>' COMMAND LEVEL FOLLOWS THE ANSWERING OF THE HARDWARE P-TABLE
QUESTIONS. THESE COMMANDS CAN BE TYPED WHEN THE 'DCLT> (A) ?' PROMPT
IS PRINTED.

MESSAGE COMMANDS AVAILABLE:

YOU ONLY HAVE TO TYPE ENOUGH CHARACTERS TO UNIQUELY SPECIFY A COMMAND.

THE COMMAND LINE IS INTERPRETED FROM LEFT TO RIGHT. THEREFORE,
IF A QUALIFIER ON THE COMMAND LINE IS RELATED OR EFFECTS A QUALIFIER
TO THE LEFT ON THE COMMAND LINE, THE QUALIFIER FARTHEREST TO THE RIGHT
TAKES PRECEDENCE SINCE IT IS INTERPRETED LAST. (I.E. IF /CHECK.....
.../NOCHECK APPEAR ON THE SAME LINE, NOCHECK WILL BE INDICATED IN THE
PARAMETERS WORD.)

REFER TO SECTION 6.0 FOR A DESCRIPTION OF THE DIFFERENT MODES OF
OPERATION AND THE TYPES OF MESSAGES AVAILABLE.

2.5.1 MESSAGE COMMANDS

COMMAND	DESCRIPTION
CLEAR EXPECTLIST	ZEROES THE EXPECTLIST (00'S) AND THEN PUTS DEFAULT ITP MSG IN SO NOT REALLY EMPTY
CLEAR TRANSMITLIST	FILLS TRANSMITLIST (000'S) AND THEN PUTS DEFAULT ITP MSG IN SO NOT REALLY EMPTY

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 12

SET EXPECTMSG=TYPE/QUAL DEFINE A MESSAGE TO BE PUT ON
THE EXPECTED LIST

WHERE: "TYPE" IS:
=ONES
=ZEROES
=1ALT
=OALT
=ITEP
=CCITT
=ALPHA
='A-Z,0-9,SPACES OR TABS IN QUOTES'

WHERE THE OPTIONAL "QUAL" IS:

/SIZE=NNN MAKE THE MESSAGE 'NNN' BYTES
LONG. (DEFAULT VALUE IS
SIZE OF MESSAGE SPEC'D BY
OPERATOR OR DEFAULTS.)

/COPY=NN COPY THIS MESSAGE INTO THE
BUFFER 'NN' TIMES (DEFAULT
IS 0 = PUT THE MESSAGE IN
ONLY ONCE)

NOTE: SET'S ADD MESSAGES TO THE LIST IN THE ORDER THEY'RE
DEFINED. 'NNN' IS A DECIMAL NUMBER. THE FIRST SET
OVERWRITES THE DEFAULT ITEP MESSAGE PLACED THERE BY
INITIALIZATION OR A "CLEAR" COMMAND.

SEE SECTION 6.2 FOR A DESCRIPTION OF THE PRE-DEFINED
MESSAGES THAT ARE AVAILABLE. (ZEROS,ONES ...)

SET TRANSMITMSG=TYPE/QUAL DEFINE A MESSAGE TO BE PUT ON
THE TRANSMIT LIST
(SEE DESCRIPT FOR SET EXP)

SET EXPECT=TRANSMIT MAKES A COPY OF THE TRANSMIT
LIST IN THE EXPECT LIST.

SHOW EXPECTLIST LISTS THE MESSAGE SIZE AND TYPE
FOR THE MESSAGES IN THE
EXPECT LIST

SHOW TRANSMITLIST LISTS THE MESSAGE SIZE AND TYPE
FOR THE MESSAGES IN THE
TRANSMIT LIST

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 13

2.5.2 STATISTICAL COMMANDS

COMMAND

DESCRIPTION

PRINT

TAKES THE OPERATOR TO THE REPORT LEVEL 'RPT>'. FROM HERE YOU CAN EXAMINE THE EVENT LOG OR IF '/PROTOCOL' IS SELECTED, THE DDCMP STATISTICAL AND ERROR COUNTERS.

DUMP SSSSSS-EEEEEE/B

PRINTS THE CONTENTS OF THE MEMORY LOCATIONS BETWEEN OCTAL ADDRESSES 'SSSSSS' AND 'EEEEEE' WHERE 'SSSSSS' IS THE START ADDRESS AND '-EEEEEE' IS THE END ADDRESS.

WHERE '/B' IS OPTIONAL:
DEFAULT IS PRINT WORDS
'/B' CAUSES PRINT BYTES

IF '-EEEEEE' IS NOT SPECIFIED THEN THE CONTENTS OF 'SSSSSS' IS PRINTED IN WORD FORMAT.
IS PRINTED IN WORD FORMAT.

NOTE: THE DUMP COMMAND IS USEFUL FOR EXAMINING MESSAGE DATA. STARTING ADDRESSES CAN BE FOUND BY LOOKING IN THE EVENT LOG.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 14

2.5.3 RUN COMMAND

COMMAND	DESCRIPTION																								
RUN MODE=MTYPE/QUAL	STARTS DCLT EXECUTING IN THE MODE SPECIFIED																								
<p>NOTE: MODE=ACTIVE IS NOT DEFAULT, A MODE=MTYPE MUST BE TYPED ----- EACH TIME A RUN IS TYPED</p> <p>WHERE THE 'MTYPE' IS ANY ONE OF THE FOLLOWING:</p> <table border="0"> <tr> <td>=ACTIVE</td> <td>(FORCES /NOECHO ,NO LOOPING)</td> </tr> <tr> <td>=PASSIVE</td> <td>(FORCES NO LOOPING)</td> </tr> <tr> <td>=RECEIVE</td> <td>(FORCES /NOECHO ,NO LOOPING)</td> </tr> <tr> <td>=LISTEN</td> <td>(FORCES /NOECHO ,NO LOOPING, /NOCHECK)</td> </tr> <tr> <td>=TRANSMIT</td> <td>(FORCES /NOECHO ,NO LOOPING, /NOCHECK)</td> </tr> <tr> <td>=TALK</td> <td>(FORCES /NOECHO ,NO LOOPING, /NOCHECK)</td> </tr> <tr> <td>=DOWNLINELOAD</td> <td>(DOWN-LINE-LOADING IS NOT SUPPORTED FOR DUP-11 TO DUP-11 LINKS).</td> </tr> </table> <p>(FORCING NO LOOPING MEANS IT MUST BE SPECIFIED AS A QUALIFIER ANY TIME ITS DESIRED, THERE IS NO DEFAULT)</p> <p>AND OPTIONAL 'QUAL' IS ANY COMBINATION OF THE FOLLOWING:</p> <table border="0"> <tr> <td>/CHECK/NOCHECK</td> <td>ENABLES/DISABLES CHECKING OF RECEIVED DATA AGAINST THE EXPECTED DATA</td> </tr> </table> <p>NOTE: IF BOTH NODES IN ACTIVE AND "/NOCHECK" IS USED, ----- END-OF-PASS IS DEFINED AS RECEIVING 1 MESSAGE AND COMPLETING THE TRANSMIT LIST. WITH NO DATA CHECKING, THERE IS NO WAY FOR DCLT TO KNOW HOW MANY MESSAGES IT SHOULD EXPECT TO RECEIVE.</p> <table border="0"> <tr> <td>/STATUS/NOSTATUS</td> <td>ENABLES/DISABLES PRINTING OF PROGRAM STATUS MESSAGES TO THE OPERATOR</td> </tr> <tr> <td>/ECHO/NOECHO</td> <td>ENABLES/DISABLES THE RETRANSMISSION OF THE DATA RECEIVED IN PASSIVE MODE. (IGNORED IN MODES OTHER THAN PASSIVE)</td> </tr> <tr> <td>/MODEM/NOMODEM/</td> <td>ENABLES/DISABLES THE REPORTING OF MODEM STATUS INTERRUPT CHANGES.</td> </tr> <tr> <td>/LOOP=LTYPE</td> <td>SPECIFIES WHICH, IF ANY, TYPE OF MAINTENANCE LOOPBACK IS BEING USED. (IGNORED IN MODES OTHER THAN ACTIVE) MUST BE SPECIFIED EACH TIME ELSE NO</td> </tr> </table>		=ACTIVE	(FORCES /NOECHO ,NO LOOPING)	=PASSIVE	(FORCES NO LOOPING)	=RECEIVE	(FORCES /NOECHO ,NO LOOPING)	=LISTEN	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)	=TRANSMIT	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)	=TALK	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)	=DOWNLINELOAD	(DOWN-LINE-LOADING IS NOT SUPPORTED FOR DUP-11 TO DUP-11 LINKS).	/CHECK/NOCHECK	ENABLES/DISABLES CHECKING OF RECEIVED DATA AGAINST THE EXPECTED DATA	/STATUS/NOSTATUS	ENABLES/DISABLES PRINTING OF PROGRAM STATUS MESSAGES TO THE OPERATOR	/ECHO/NOECHO	ENABLES/DISABLES THE RETRANSMISSION OF THE DATA RECEIVED IN PASSIVE MODE. (IGNORED IN MODES OTHER THAN PASSIVE)	/MODEM/NOMODEM/	ENABLES/DISABLES THE REPORTING OF MODEM STATUS INTERRUPT CHANGES.	/LOOP=LTYPE	SPECIFIES WHICH, IF ANY, TYPE OF MAINTENANCE LOOPBACK IS BEING USED. (IGNORED IN MODES OTHER THAN ACTIVE) MUST BE SPECIFIED EACH TIME ELSE NO
=ACTIVE	(FORCES /NOECHO ,NO LOOPING)																								
=PASSIVE	(FORCES NO LOOPING)																								
=RECEIVE	(FORCES /NOECHO ,NO LOOPING)																								
=LISTEN	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)																								
=TRANSMIT	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)																								
=TALK	(FORCES /NOECHO ,NO LOOPING, /NOCHECK)																								
=DOWNLINELOAD	(DOWN-LINE-LOADING IS NOT SUPPORTED FOR DUP-11 TO DUP-11 LINKS).																								
/CHECK/NOCHECK	ENABLES/DISABLES CHECKING OF RECEIVED DATA AGAINST THE EXPECTED DATA																								
/STATUS/NOSTATUS	ENABLES/DISABLES PRINTING OF PROGRAM STATUS MESSAGES TO THE OPERATOR																								
/ECHO/NOECHO	ENABLES/DISABLES THE RETRANSMISSION OF THE DATA RECEIVED IN PASSIVE MODE. (IGNORED IN MODES OTHER THAN PASSIVE)																								
/MODEM/NOMODEM/	ENABLES/DISABLES THE REPORTING OF MODEM STATUS INTERRUPT CHANGES.																								
/LOOP=LTYPE	SPECIFIES WHICH, IF ANY, TYPE OF MAINTENANCE LOOPBACK IS BEING USED. (IGNORED IN MODES OTHER THAN ACTIVE) MUST BE SPECIFIED EACH TIME ELSE NO																								

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 15

LOOP IS USED.

'LTYPE' IS:

=INTERNALTTL LOOPS DATA INTERNAL TO USYNRT
 =CABLE USE THIS FOR TESTING WITH H325
 TURNARROUND CONNECTOR ON END OF CABLE.

NOTE: THIS SKIPS OVER THE CHECK
 FOR MODEM READY WHEN DTR IS SET.

=LOCALMODEM NOT SUPPORTED BY DUP-11
 =REMOTEMODEM ..

/PASS=NN SPECIFIES NUMBER OF ITERATIONS TO MAKE BEFORE
 END-OF-PASS. DEFAULT VALUE OF 1
 WILL BE USED ON ANY RUN THAT A /PASS=N
 IS NOT ADDED TO THE 'RUN ...' COMMAND.
 IF A '-1' IS TYPED, THEN THE PROGRAM
 RUN UNTIL A ^C IS TYPED.

/PROTOCOL ENABLES SUBSET OF DDCMP PROTOCOL- THE DUP-11
 CAN NOW COMMUNICATE WITH OTHER 'INTELLIGENT'
 SYNCHRONOUS DEVICES THAT SUPPORT DDCMP IN
 THEIR MICROCODE. (DMR,DMC,DMV OR DMP).

THIS SWITCH IS NOT SUPPORTED BY ALL DCLT'S.

/NOPROTOCOL DISABLES PROTOCOL- THE DUP-11 CAN COMMUNICATE
 ONLY WITH ANOTHER DUP-11 OR DPV-11 RUNNING
 DCLT OR ITEP.

NOTE: SEE SECTION 6.1 FOR A DESCRIPTION
 ----- OF THE 'RUN MODES' AND 'LOOP MODES'

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 16

2.5.4 DEFAULTS

IF NO 'SET'S' THEN THE DEFAULT IS SAME AS IF TYPED:

SET TRANSMITMSG=ITEP/SIZE=58/COPY=0
SET EXPECTMSG=ITEP/SIZE=58/COPY=0

THE DEFAULT COPY AND SIZE FOR EACH OF THE MESSAGE TYPES:

ONES - /SIZE=64/COPY=0
ZEROS - /SIZE=64/COPY=0
OALT - /SIZE=64/COPY=0
1ALT - /SIZE=64/COPY=0
CCITT - /SIZE=64/COPY=0
ALPHA - /SIZE=65/COPY=0
ITEP - /SIZE=58/COPY=0
OPER. SPEC'D - /SIZE=LENGTH-OF-TEXT-TYPED-BETWEEN-QUOTES/COPY=0

FOR THE RUN COMMAND THE DEFAULTS ARE:

RUN MODE=ACTIVE/NOSTATUS/CHECK/NOECHO/NOMODEM/PASS=1/NOPROTOCOL

NOTE: MODE=ACTIVE IS NOT, DEFAULT, A MODE=MTYPE MUST BE TYPED
----- EACH TIME A RUN IS TYPED

IF THE DCLT PROGRAM IS RUN IN UNATTENDED MODE (UAM FLAG=1 OR CHAINED),
THE DEFAULTS ARE AS IF THESE SETUP AND RUN COMMANDS WERE TYPED:

SET TRANS=ITEP
SET EXPECT=ITEP
RUN MODE=ACTIVE/LOOP=INTERNAL/NOSTAT/NOECHO/NOMODEM/CHECK
/PASS=1/NOPROTOCOL

OTHER NOTES:

^C ALWAYS RETURNS YOU TO 'DR>' (THE SUPERVISOR)
<CR> IS SEEN AS A COMMAND TERMINATOR
'RUBOUT' DELETE LAST CHAR. TYPED IN COMMAND STRING

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 17

2.5.5 PRINT COMMAND

THE PRINT COMMAND TAKES YOU TO THE REPORT LEVEL 'RPT>'.
THE COMMANDS AVAILABLE IN RPT> ARE ...

<u>COMMAND</u>	<u>DESCRIPTION</u>
HELP OR ?	PRINTS HELP INFORMATION FOR RPT>
EXIT	RETURNS YOU TO THE LEVEL THAT YOU ENTERED FROM. (DCLT> OR DR>)
LOG	PRINTS THE DCLT EVENT LOG
COUNTERS/FULL	PRINTS THE ENTIRE DDCMP STATISTICAL AND ERROR LOG. SEE SECTION 4.3
COUNTERS/ERRORS	PRINTS ONLY THE DDCMP ERROR LOCATIONS OF THE LOG.
COUNTERS/OFFSET=NN	PRINTS A SINGLE LOCATION OF THE LOG AS SPECIFIED BY THE OCTAL WORD OFFSET VALUE(NN).

NOTE:: THE DDCMP COUNTERS WILL BE VALID ONLY WITH PROTOCOL ENABLED(/PROTOCOL).

2.5.6 MISC COMMANDS

<u>COMMANDS</u>	<u>DESCRIPTION</u>
EXIT	FROM THE DCLT> LEVEL RETURNS YOU TO DR>
HELP OR ?	PRINTS HELP INFORMATION

2.6 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE 'R NAME', WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE 'START'

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 18

5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS. THE NUMBER OF UNITS THAT DCLT CAN USE IS ALWAYS "1".

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS. THESE DEFAULTS ARE DESCRIBED IN SECTION 2.3.

7. AFTER THE 'DCLT> (A) ?' PROMPT, TYPE 'RUN MODE=ACTIVE<CR>'

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING THE DEFAULT TRANSMIT AND EXPECTED MESSAGES. THE DEFAULT PASS COUNT AND 'RUN' QUALIFIERS ARE ALSO BEING USED. THESE DEFAULTS ARE DESCRIBED IN SECTION 2.5.3.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBE" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

3.2.1 COMMAND LINE INTERPRETER ERRORS

ERROR MESSAGE:	MEANING
-----	-----
?ILL CMD-BAD SYNTAX?	A COMMAND WITH AN ILLEGAL CHAR WAS TYPED - RETYPE THE COMMAND. THE VALID COMMANDS AND THEIR SYNTAX ARE SHOWN IN SECTION 2.5.
?INCMPLTE CMD?	A REQUIRED PART OF A COMMAND WAS LEFT OUT.
?NUM TOO BIG?	THE VALUE OF A NUMERIC STRING IN THE COMMAND LINE WAS LARGER THAN 65535 OR 177777 OCTAL. (> 16 BITS).
?BAD RADIX?	A '8' OR '9' WAS TYPED WHEN AN OCTAL STRING WAS EXPECTED. PROBABLY OCCURRED WHEN TYPING A 'DUMP' COMMAND WHERE

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 20

OCTAL ADDRESSES ARE EXPECTED.

- ? 'LOOP' VALID ONLY IN ACTIVE? THE '/LOOP=..' SWITCH WAS TYPED IN A RUN COMMAND BUT THE MODE WAS NOT SET TO ACTIVE. MAINTENANCE LOOP IS ONLY POSSIBLE IF THE MODE OF OPERATION IS ACTIVE.
- ? 'ECHO' VALID ONLY IN PASSIVE? THE '/ECHO' SWITCH WAS TYPED IN A RUN COMMAND BUT THE MODE WAS NOT SET TO PASSIVE. ECHOING OF RECEIVED DATA IS ONLY POSSIBLE IF THE MODE OF OPERATION IS PASSIVE.
- ? ILL CHR- 'A-Z,0-9,SP,TAB' ONLY? A CHARACTER TYPED WITHIN QUOTES WHEN TRYING TO DEFINE THE CONTENTS OF A TRANSMIT OR EXPECT MESSAGE WAS NOT A 'A-Z,0-9,SPACE OR TAB'. RETYPE THE COMMAND WITH ONLY THESE CHARACTERS BETWEEN QUOTES.
- ? 'SIZE=0' NOT VALID? A MESSAGE ZERO BYTES LONG CAN NOT BE BUILT. RETYPE THE COMMAND WITH A '/SIZE=NNN'. IF NO '/SIZE=' IS TYPED A DEFAULT SIZE WILL BE USED.
- ? TRANSMIT AND EXPECT LIST MUST BE IDENTICAL FOR LOOP?
IF RUN COMMAND WITH '/LOOP/CH' IS TYPED THE TRANSMIT LIST AND EXPECT LIST MUST BE EQUAL. IF THEY ARE NOT THIS ERROR WILL BE DISPLAYED. USE 'SE E=T' COMMAND.

3.2.2 DCLT OR DEVICE ERROR MESSAGES:

CLOCK NOT FOUND

THIS MEANS THAT NO CLOCK WAS FOUND ON THE SYSTEM THE DIAGNOSTIC WILL STILL RUN BUT NONE OF THE TIME OUT CONDITIONS WILL OCCUR

BAD CLOCK - PROGRAM WILL HANG ON 'TIMEOUT'!!

THIS MEANS THAT THE CLOCK FOUND ON THE SYSTEM DID NOT INTERRUPT WHEN ASKED TO DO A 'TICK'.

THE PROGRAM WILL STILL RUN, BUT ANY OF THE PROGRAM THAT TIMES THE DEVICE WILL HANG IF THE DEVICE TIMES OUT. ALSO, THE EVENT LOG WILL CONTAIN A ZERO EVENT TIME FOR ALL EVENTS LOGGED.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 21

MAX. CHAR. MSG COUNT EXCEEDED - MSG. NOT BUILT !!

THIS MEANS THAT THE TRANSMIT OR EXPECT BUFFER IS FULL. NO MORE MESSAGES CAN BE ADDED TO THAT BUFFER.

BUFFER FULL - MSG. NOT BUILT !!

THIS MEANS THAT THE LAST MESSAGE YOU TRIED TO ADD TO EITHER THE TRANSMIT OR EXPECT BUFFER CAUSED THE TOTAL NUMBER OF MESSAGES TO BE EXCEEDED. NO MORE MESSAGES CAN BE ADDED TO THAT BUFFER. THE LIMIT IS DETERMINED BY THE SIZE OF THE MESSAGE POINTER TABLE.

CHAR. COUNT EXCEEDS BUFF LIMIT - MSG TRUNCATED

THIS MEANS THAT THE LAST MESSAGE YOU TRIED TO ADD TO THE TRANSMIT OR EXPECT BUFFER CAUSED THE TOTAL CHAR. COUNT FOR THAT BUFFER TO EXCEED THE LIMIT. THE MESSAGE WAS TRUNCATED TO COMPLETELY FILL THE BUFFER. NO MORE MESSAGES CAN BE ADDED TO THAT BUFFER.

3.2.3 DEVICE ERROR MESSAGE

DATA COMPARISON DATA ERROR
BYTE # IN MSG=XXX EXPTD=YYY

RECVD=ZZZ

XXX= OFFSET OF THAT BYTE FROM THE START OF THE COMPARE OR EXPECT MESSAGE.
YYY= THE CONTENTS OF THAT BYTE IN THE EXPECTED MESSAGE
ZZZ= THE CONTENTS OF THAT BYTE IN THE RECEIVED MESSAGE

UP TO FIVE OF THESE ERRORS WILL BE PRINTED PER MESSAGE COMPARED. ONLY THE FIRST FIVE MISMATCHES WILL BE INDIVIDUALLY REPORTED, BUT TOTAL NUMBER OF MISMATCHES IS REPORTED BY ANOTHER ERROR.

PRINTING THE EVENT LOG AND USING THE DCLT 'DUMP' COMMAND WILL ALLOW YOU TO FIND THE ADDRESS OF THE MESSAGE AND EXAMINE IT.

DATA COMPARISON DATA ERROR
TOTAL MISMATCHES IN MSG = NNN

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 22

THIS MEANS THAT WHEN THE MESSAGE RECEIVED WAS COMPARED AGAINST THE MESSAGE THAT WAS EXPECTED, SOME OF THE CHARS. WERE NOT THE SAME.

DATA COMPARISON LENGTH ERROR
COMPARE COUNT= XXX RECEIVE COUNT= ZZZ

XXX= NUMBER OF BYTES IN THE COMPARE MESSAGE

ZZZ= NUMBER OF BYTES IN THE RECEIVED MESSAGE

THIS MEANS THAT THE MESSAGE RECEIVED WAS A DIFFENT LENGTH THEN THE MESSAGE THAT WAS EXPECTED.

MODEM STATUS CHANGES FOR THIS PASS WERE..
HARD CHANGES=XXXXX GLITCHES=XXXXX

WHERE XXXXX IS A 5 DIGIT DECIMAL NUMBER THIS MSG IS ONLY PRINTED IF NUMBER OF EITHER HARD CHANGES OR GLITCHES IS GREATER THAN 0. A HARD CHANGE IS ONE WHERE THE DUP WAS ABLE TO LATCH UP A DIFFERENCE IN THE MODEM STATUS. A GLITCH IS WHEN A MODEM STATUS INTERRUPT OCCURS BUT THE DUP CANNOT FIND A DIFFERENCE IN STATUS BIT.

* NOTE * - IN THE FOLLOWING ERROR DESCRIPTIONS XXXXX
***** REFERS TO THE OCTAL CONTENTS OF THE DEVICE REGISTERS SPECIFIED.

MASTER RESET DID NOT WORK
RXCSR TXCSR
XXXXXX XXXXXXXX

THIS MEANS THAT AFTER A MASTER RESET WAS ISSUED TO DUP THE RXCSR REGISTER WAS NON ZERO.

NO CLEAR TO SEND FROM MODEM
RXCSR TXCSR
XXXXXXX XXXXXXXX

WHEN REQUEST TO SEND (RTS) IS SET, MODEM DOES NOT RESPOND WITH CLEAR TO SEND(CTS).

TIME OUT WAITING FOR RX OR TX TO COMPLETE
RXCSR TXCSR
XXXXXXX XXXXXXXX

THIS USUALLY MEANS AN OPEN COMMUNICATION LINK.

MODEM DID NOT RETURN MODEM READY
RXCSR TXCSR
XXXXXXX XXXXXXXX

WHEN THE DTR SIGNAL WAS SET, DATA SET READY WAS NOT RETURNED

CRC IN ERROR
RXDBUF RXCSR

A CRC ERROR WAS DETECTED BY THE DUP ON AN INCOMING MESSAGE.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 23

XXXXXX

XXXXXX

RECEIVER OVERRUN
RXDBUF RXCSR
XXXXXXX XXXXXXX

THE RECEIVER WASN'T SERVICED
FAST ENOUGH (SOFTWARE)--
CAUSING A CHARACTER TO BE LOST.

TIMED OUT IN START, STACK ACK SEQ
RDATA SDATA
XXXXXXX XXXXXXX

THIS USUALLY MEANS THAT THE DUP
IS UNABLE TO ESTABLISH A
CONNECTION WITH THE OTHER
DEVICE BEING TESTED. THE VALUES
IN RDATA AND SDATA SHOW THE
RECEIVED (RDATA) AND TRANSMITTED
(SDATA). SEE DDCMP SPEC. FOR
FURTHER EXPLANATION OF STARTUP
SEQUENCE.

4.0 PERFORMANCE AND PROGRESS REPORTS

DCLT USES IT'S OWN METHOD FOR DETERMINING AN 'END OF PASS'
WHICH IS CALLED A 'DCLT END OF PASS'. THE NUMBER OF 'DCLT PASSES'
TO BE RUN IS SPECIFIED BY THE '/PASS=XXX' SWITCH ON THE DCLT
RUN COMMAND. THE TOTAL NUMBER OF 'DCLT ERRORS' IS REPORTED
WHEN 'X' NUMBER OF 'DCLT PASSES' ARE COMPLETED.

4.1 PRINTING OF EVENT LOG

SIGNIFICANT EVENTS OR CHECK-POINTS WILL BE LOGGED IN A
'CIRCULAR QUEUE' STORAGE AREA CALLED THE EVENT LOG. THE LAST
'N' EVENTS ARE KEPT LOGGED AND CAN BE LISTED ON THE OPERATORS
CONSOLE BY GIVING A 'PRINT' COMMAND AT THE 'DR>' (DIAGNOSTIC SUPERVISOR)
OR 'DCLT>' (DCLT) LEVEL. THIS WILL TAKE YOU TO THE RPT> LEVEL. NOW
INPUT THE 'LOG' COMMAND. THE EVENTS ARE PRINTED IN A 'LAST-IN
FIRST-OUT' ORDER.

EVENT TIME IS TYPED OUT AS MMM:SS:TT (LIKE 254:36:07) WHERE MMM,SS,TT
REPRESENT THE NUMBER OF MINUTES, SECONDS, CLOCK TICKS SINCE THE LAST
START OR RESTART. IT SHOULD BE NOTED THAT THE TIMES ARE
RELATIVE SINCE WHILE THE PROCESSOR IS RUNNING AT PRIORITY 7
THE CLOCK CAN'T INTERRUPT TO KEEP TIME. THIS IS THE CASE
WHILE THE PROGRAM IS FETCHING DCLT COMMANDS FROM THE OPERATOR.
IT SHOULD ALSO BE NOTED THAT THERE ARE ONLY 8 BITS AVAILABLE TO STORE
RELATIVE MINUTES SO 'TIME' WILL WRAP TO 000:00:00 AFTER 256:59:59.

A START OR RESTART COMMAND AT THE 'DR>' LEVEL INITIALIZES THE EVENT
LOG. THEREFORE IT IS WISE TO DO A 'PRINT' AT THE 'DR>' LEVEL
BEFORE GIVING A 'START' OR 'RESTART'.

THE TYPES OF EVENTS KEPT IN THE EVENT LOG ARE:

TRANSMIT MESSAGE QUEUED:
EVENT TIME, ADDRESS OF 1ST BYTE OF MESSAGE,
TOTAL NO. OF BYTES, MODEM STATUS AT THAT TIME.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 24

TRANSMIT MESSAGE COMPLETED:

EVENT TIME, ADDRESS OF 1ST BYTE OF MESSAGE,
TOTAL NO. OF BYTES, MODEM STATUS AT THAT TIME.

RECEIVE SPACE QUEUED:

EVENT TIME, ADDRESS OF 1ST BYTE OF MESSAGE,
TOTAL NO. OF BYTES, MODEM STATUS AT THAT TIME.

RECEIVE MESSAGE COMPLETED:

EVENT TIME, ADDRESS OF 1ST BYTE OF MESSAGE,
TOTAL NO. OF BYTES, MODEM STATUS AT THAT TIME.

DATA COMPARISON STARTED:

EVENT TIME, ADDRESS OF 1ST BYTE OF RECEIVED MSG.,
TOTAL NO. OF BYTES IN RCV. MSG., TOTAL NO. OF BYTES
IN EXPECT MSG.

DATA COMPARISON DATA ERROR:

EVENT TIME, ADDRESS OF 1ST BYTE OF RECEIVED MSG.,
TOTAL NO. OF BYTES IN RCV. MSG., TOTAL NO. OF
COMPARISON FAILURES

DATA COMPARISON LENGTH ERROR:

EVENT TIME, ADDRESS OF 1ST BYTE OF RECEIVED MSG.,
TOTAL NO. OF BYTES IN RCV. MSG., TOTAL NO. OF BYTES
IN EXPECT MSG.

DEVICE INIT AND SETUP:

EVENT TIME, MODE OF OPERATION, TYPE OF MAINTENANCE
LOOP, 'DCLT' PASS COUNT, 'RUN' PARAMETERS

DEVICE ERROR:

EVENT TIME, DEVICE ERROR MESSAGE, CONTENTS OF TWO
REGISTERS RELATING TO THE ERROR.

END OF PASS:

^C ABORT:

EVENT TIME, 'DCLT' PASS COUNT, 'DCLT' ERROR COUNT,
AND THE 'STRT-TO'(COUNT OF START TIME OUTS).

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 25

4.2 OPERATOR STATUS MESSAGES

THE "/STATUS, /NOSTATUS" QUALIFIERS FOR THE DCLT 'RUN' COMMAND ENABLES/DISABLES THE PRINTING OF PROGRAM STATUS MESSAGES TO THE OPERATOR. THESE MESSAGES ARE INTENDED TO TELL THE OPERATOR WHAT THE DCLT PROGRAM IS CURRENTLY DOING. BELOW ARE THE MESSAGES THAT MIGHT BE PRINTED AND THEIR MEANING:

MESSAGE	MEANING
-----	-----
TXQ	DEVICE IS ABOUT START TRANSMITING A MESSAGE
TXC	TRANSMISSION OF MESSAGE COMPLETED
RXQ	DEVICE HAS QUEUED SPACE TO RECEIVE/ COMPLETED RECEIVE
ERR	DEVICE ERROR HAS OCCURRED
INI	DEVICE ABOUT TO BE INITIALIZED
MSC	ABNORMAL MODEM STATUS CHANGE
CMP	ABOUT TO DO DATA CHECKING OF RECVD VS. EXPTD DATA
CML	LENGTH ERROR OCCURRED DURING DATA COMPARISON
CMD	DATA ERROR OCCURRED DURING DATA COMPARISON
EOP	END OF PASS

NOTE:: BECAUSE THE DUP IS AN INTERRUPT DRIVEN DEVICE, IT IS BEST TO DISABLE STATUS TO PREVENT OVERRUN ERRORS.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 26

4.3 PRINTING DDCMP STATISTICAL AND ERROR LOG

IF YOU ARE RUNNING THIS PROGRAM WITH DDCMP PROTOCOL ENABLED, YOU CAN EXAMINE (VIA "RPT>" COMMAND) DDCMP STATISTICAL AND ERROR COUNTERS TO GET A BETTER UNDERSTANDING OF WHAT IS HAPPENING ON THE LINK. FOR A FULL DESCRIPTION OF THESE COUNTERS SEE (DIGITAL DATA COMMUNICATION MESSAGE PROTOCOL) SPECIFICATION VERSION 4.1.

BELOW IS A BRIEF DESCRIPTION OF EACH COUNTER. THE MOST IMPORTANT OF THESE ARE DATA MESSAGES SENT/RECEIVED AND DATA ERRORS IN/OUT.

OCTAL #	MESSAGE	MEANING
000000	STATUS FLAGS	USED ONLY IN SOFTWARE DEVELOPMENT.
000000	DATA MSGS TX	# MESSAGES TX'ED DURING THE TEST. RESET TO ZERO AT START OR RESTART. LATCHES AT -1.
000000	DATA MSGS RX	# MESSAGES RX'ED DURING THE TEST. RESET TO ZERO AT START OR RESTART. LATCHES AT -1.
000	HIGHEST MSG TX	MODULO 255 COUNTER. HIGHEST MESSAGE # SENT AND ACK'ED BY REMOTE STATION.
000	HIGHEST MSG ACK	MODULO 255 COUNTER. HIGHEST MESSAGE # RX'D BY REMOTE NODE. (WITH NO ERRORS)
000	NEXT MSG # TO TX	MODULO 255 COUNTER. ALWAYS 1 GREATER THEN CURRENT MESSAGE NUMBER BEING SENT.
000	LAST MSG # TX'ED	MODULO 255 COUNTER. ALWAYS SAME AS HIGHEST # SENT.
000	HIGHEST MSG# RX	NUMBER OF LAST MESSAGE RX'ED AND ACK'ED.
000	TRIB ADDR	IF MULTIPOINT THEN ADDRESS THIS STATION.
000	REMOTE TIME OUTS	MODULO 255 COUNTER. REPLY RECEIVED AND ACK'ED.
000	GLOBAL CRC ERRORS	IF MULTIPOINT NETWORK-CRC ERRORS DETECTED.
000	NAK REASON	REASON FOR SENDING LAST NAK.
000	SEL THRESH ERRS	HALF/DUPLEX ONLY. SELECT TIME OUTS.
000	RX THRESH ERRS	INCREMENTED WHEN ERROR DETECTED IN INCOMING MESSAGE. (MODULO 8 COUNTER) RESET WHEN GOOD MESSAGE RECEIVED.
000	TX THRESH ERRS	INCREMENTED WHEN NAK RECEIVED. RESET WHEN ACK RECEIVED. (MODULO 8 COUNTER)

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 27

000	DATA ERRORS OUT	NAKS RECEIVED BECAUSE OF HEADER CRC ERROR OR DATA CRC ERRORS OR MESSAGE NOT RECEIVED AT ALL(REP). INDICATES NOISE ON TRANSMIT LINE.
000	DATA ERRORS IN	NAKS SENT BECAUSE HEADER CRC ERROR OR DATA CRC ERROR DETECTED IN INCOMING MESSAGE. MESSAGE TAKING NOISE HITS.
000	LOCAL BUFFER ERRS	EITHER NO BUFFER WAS AVAILABLE FOR INCOMING MESSAGE OR BUFFER THAT WAS AVAILABLE WAS TOO SMALL FOR INCOMING MESSAGE. USUALLY A SOFTWARE SPEED PROBLEM.
000	REMOTE BUFFER ERRS	SAME AS LOCAL BUT BUFFER PROBLEMS AT REMOTE STATION.
000	REMOTE STA ERRS	RX OVERRUN ERRORS(RX WASN'T SERVICED FAST ENOUGH) OR IF FORMAT ERROR A CRC EXISTED AND WASN'T DETECTED BY HARDWARE.
000	LOCAL STA ERRS	SAME AS REMOTE STATION ERRORS.
000	TX / RX THRESH ERR	OVERFLOW FROM RX OR TX THRESHOLD COUNTERS. INDICATES A PERSISTENT LINK PROBLEM THAT ISN'T CORRECTED AFTER 7 RETRIES.

5.0 DEVICE INFORMATION TABLES

THIS IS THE DEFAULT HARDWARE P-TABLE. THE VALUES AND SIZE ARE USED AS A "TEMPLATE" FOR CREATING ACTUAL P-TABLE ENTRIES AND THE DEFAULT VALUES PROVIDED FOR THE OPERATOR. SEE SECTION 2.4 FOR AN EXAMPLE OF THE HARDWARE QUESTIONS.

THE NUMBERS IN BRACKETS (I.E. [10]) INDICATES THE OFFSET OF THE WORD INTO THE HARDWARE P-TABLE. THE OFFSETS MUST MATCH THE P-TABLE OFFSETS USED IN THE HARDWARE PARAMETER CODING SECTION WHERE THE "GET PARAMETER" CALLS ARE USED TO FILL THE P-TABLE.

.WORD	1	:[0] FULL OR HALF DUPLEX FLAG (BIT0=1 IF FULL)
.WORD	160170	:[2] CSR ADDRESS
.WORD	300	:[4] INTERRUPT VECTOR
.WORD	240	:[6] INTERRUPT PRIORITY
.WORD	0	:[10] PT-PT=0 MULTIPOINT=1
.WORD	1	:[12] TRIB ADDRESS THIS STATION
.WORD	0	:[14] REMOTE NODE "ITEP"

6.0 MODE AND MESSAGE DESCRIPTIONS

6.1 MODE DESCRIPTIONS

THE FOLLOWING MODE DESCRIPTIONS REFER TO MESSAGE LISTS BEING TRANSMITTED AND RECEIVED BUT BE AWARE THAT OTHER DATA IS ALSO SENT AND RECEIVED. IF "/PROTOCOL" IS SELECTED THE DATA IS ENCLOSED IN A DDCMP ENVELOPE AND CONTROL MESSAGE WILL ALSO APPEAR ON THE LINK.

6.1.1 TRANSMIT MODE

A LIST OF MESSAGES IS TRANSMITTED WITHOUT EXPECTING ANY DATA TO BE RECEIVED. HOWEVER WITH "/PROTOCOL" ENABLED EACH MESSAGE SENT MUST BE ACKNOWLEDGED(ACK).

6.1.2 RECEIVE MODE

SPACE IS QUEUED FOR THE DEVICE TO RECEIVE MESSAGES. AFTER RECEIVING AN "EXPECTED" NUMBER OF MESSAGES, THE DATA RECEIVED CAN BE COMPARED AGAINST A LIST OF "EXPECT TO RECEIVE" MESSAGES IF DATA-CHECKING IS ENABLED.

6.1.3 PASSIVE MODE

THEN EVERY TIME A MESSAGE IS RECEIVED, A MESSAGE IS TRANSMITTED.

CZDCLB DUP-11 DATA COMM. LINK TEST MACY11 30A(1052) 20-JUL-83 13:19 PAGE 29
CZDCLB.P11 19-JUL-83 17:12

DATA CHECKING CAN BE DONE ON THE RECEIVED DATA. THE "/ECHO, /NOECHO"
ENABLES/DISABLES THE RETRANSMISSION OF THE DATA RECEIVED.

6.1.4 ACTIVE MODE -----

A LIST OF MESSAGES IS TRANSMITTED AND MESSAGES ARE RECEIVED.
AFTER RECEIVING AN "EXPECTED" NUMBER OF MESSAGES, THE DATA RECEIVED
CAN BE COMPARED AGAINST A LIST OF "EXPECT TO RECEIVE" MESSAGES
IF DATA-CHECKING IS ENABLED.

NOTE: IF BOTH ENDS OF THE LINK ARE IN ACTIVE MODE, THEN THE
LINK MUST BE A FULL DUPLEX LINK!

6.1.5 DOWN-LINE-LOAD -----

DOWN-LINE-LOADING IS NOT SUPPORTED IN THE SOFTWARE FOR DUP-11
TO DUP-11 LINKS. HOWEVER IT IS POSSIBLE TO "REQUEST SECONDARY
LOAD" FROM A HOST STATION(IF SUPPORTED) IF THERE IS A DUP(M9312)
DECNET BOOTSTRAP MODULE IN YOUR MACHINE.
SEE BOOTSTRAP OPERATOR'S MANUAL.

6.1.6 TALK MODE -----

THE "TALK" END OF THE LINK TRANSMITS OPERATOR-TYPED MESSAGES
UNTIL A "EXIT" MESSAGE IS TYPED. AT THAT POINT, THE NODE GOES
INTO "LISTEN" MODE. AN "EXIT MESSAGE" IS A MESSAGE WHOSE FIRST
FOUR CHARACTERS ARE "EXIT". SINCE ONLY THE FIRST FOUR CHARACTERS
NEED TO BE "EXIT", MORE CHARACTERS CAN BE ADDED SO THAT A MESSAGE
MAY BE SENT AND THE MODE SWITCHED ALL AT ONCE. FOR EXAMPLE:

TLK> EXIT ALL OF THIS LINE IS SENT THEN MODE SWITCHED

6.1.7 LISTEN MODE -----

THE "LISTEN" END OF THE LINK PRINTS ALL OF THE MESSAGES
RECEIVED BY THE DEVICE ON THE OPERATOR'S CONSOLE. IF THE MESSAGE
RECEIVED IS AN "EXIT" MESSAGE, THEN THE NODE ENTERS "TALK" MODE.
AN "EXIT MESSAGE" IS A MESSAGE WHOSE FIRST FOUR CHARACTERS ARE "EXIT".

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 30

6.1.8 MAINTENANCE 'LOOP' MODES

REMEMBER THAT THE WHENEVER A 'RUN' COMMAND IS TYPED, THE DEFAULT IS NO LOOPBACK AND THAT A LOOP MODE MUST BE SPECIFIED BY A '/LOOP=..' IF A LOOP MODE IS DESIRED.
LOOP MODES ARE ONLY VALID IF THE MODE TO RUN IS ACTIVE !

INTERNALTTL

LOOPS DATA INTERNAL TO THE USYNRT

THE FOLLOWING TABLE SUMMARIZES THE MODES THAT CAN BE RUN TOGETHER WHEN THE DCLT PROGRAM IS RUNNING ON TWO PROCESSORS (ONE AT EACH END OF THE LINK):

HALF DUPLEX START	STATION A 'HOST' NODE	"/LOOP" ALLOWED?	STATION B 'REMOTE' NODE	DUPLEX
B	TALK	NO	LISTEN*, RECEIVE	HALF OR FULL
A	LISTEN	NO	TALK*, TRANSMIT	HALF OR FULL
B	TRANSMIT	NO	RECEIVE*, LISTEN	HALF OR FULL
A	RECEIVE	NO	TRANSMIT*, TALK	HALF OR FULL
A	PASSIVE	NO	ACTIVE*	HALF OR FULL
-NA-	ACTIVE	YES	ACTIVE*	FULL
B	ACTIVE	YES	PASSIVE*	HALF OR FULL
-NA-	DOWNLINELOAD	** DOWN-LINE-LOADING IS NOT SUPPORTED FOR DUP-11		

*= MOST LIKELY TO BE IN THAT MODE

NOTE: H/D START COLUMN INDICATES WHICH NODE TO START FIRST ON A HALF DUPLEX LINK

IF PROTOCOL IS ENABLED, THE H/D START COLUMN CAN BE IGNORED.

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 31

6.2 MESSAGE DESCRIPTIONS

NAME	DESCRIPTION
ZEROES	MESSAGE OF ALL 0'S (00000000,00000000,00000000,....)
ONES	MESSAGE OF ALL 1'S (11111111,11111111,11111111,....)
1ALT	MESSAGE OF ALTERNATING 1'S (10101010,10101010,....)
0ALT	MESSAGE OF ALTERNATING 0'S (01010101,01010101,....)
CCITT	"CCITT" 512-BIT (VS. 511 BITS) TEST PATTERN
ITEP	"INTERPROCESSOR TEST PROGRAM'S (ITEP)" MESSAGE 1(DP1:) (<177><177>/SA THE QUICK BROWN FOX JUMPED OVER THE LAZY DOG.<15><12><001><177><177><177><177>)
ALPHA	ALPHA-NUMERICS (OR FUTURE COMM TURNAROUND MSG) (#\$!' (AMPERSAND)'()*+,-.0123456789:;<=>?@ABCDEFGHIJK LMNOPQRSTUVWXYZ/[\] ^ _ `)
OPERATOR-SPECIFIED	"A-Z,0-9,SPACES,TABS" THESE ARE THE CHARACTERS THAT CAN BE TYPED BETWEEN QUOTATION MARKS ("..") TO SPECIFY A UNIQUE MESSAGE.

7.0 OTHER INFORMATION

7.1 INTERFACING TO AN "ITEP" NODE

THESE ARE THE RULES WHEN USING ITEP/WITH A DUV TO TALK TO A DUP USING DCLT.

ITEP NODE	DCLT NODE
-----------	-----------

ANSWER ALL QUESTION TO THE SET SWITCHES PROMPT.	ANSWER ALL QUESTIONS TO THE DCLT> PROMPT.
---	---

FOR ONE WAY OUT... SET SWITCHES TO 1221	CLEAR EXPECTED SET E=ITEP/S=56 RUN MODE=REC/STATUS/CHECK/NOPROTOCOL
--	---

NOTE: DUV ITEP SENDS ONLY 56 CHARS

FOR ONE WAY IN..... SET SWITCHES TO1222	RUN MODE=TRA/STATUS/NOPROTOCOL
---	--------------------------------

FOR EXTERNAL LOOPBACK.... SET SWITCHES.....1224	CLEAR EXPECTED SET EXP=ITEP/S=56 RUN MODE=ACTIVE/STATUS/CHECK/NOPROTOCOL
--	--

FOR INTERNAL LOOPBACK..... SET SWITICHES.....1260	CLEAR EXPECTED SET EXP=ITEP/S=56 RUN MODE=ACTIVE/STATUS/CHECK/NOPR
--	--

NOTE: DO NOT USE SWITCH 8 WITH ITEP GOING TO DCLT
THE ONLY MESG. DCLT SUPPORTS IS MSG 1.
DCLT IGNORES CRC ERRORS WHEN REC DATA FROM ITEP
BECAUSE ITPE SENDS NO CRC.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 33

7.2 TROUBLESHOOTING HINTS

LISTED BELOW ARE SOME SETUPS THAT COULD BE USED FOR ISOLATING FAULTS. THESE ARE BY NO MEANS THE ONLY WAYS DCLT CAN BE USED !!!!!!!
DCLT IS MEANT TO BE A VERY FLEXIBLE TOOL! THIS SECTION IS MEANT TO GIVE SOMEONE NOT TOO FAMILIAR WITH DCLT A PLACE TO START.

HINT::: IF THIS DOCUMENT IS TOO LARGE TO CONSUME, GET A COPY OF DEC'S COMMUNICATION OPTIONS MINI REFERENCE GUIDE(EK-CM1N1-RM-001).

REMEMBER, IF YOU ARE HAVING TROUBLE WITH RX OVERRUN ERRORS OR MISSED MESSAGES, OR DATA CHECK ERRORS-- DISABLE STATUS(/NOSTATUS). THE CPU IS HAVING A HARD TIME SERVICING BOTH THE TTY AND DUP.

EVEN IF YOU ARE CHECKING OUT DUP-11 TO DUP-11 LINKS, IT IS A GOOD IDEA TO ENABLE PROTOCOL(/PROTOCOL). BY EXAMINING THE DDCMP STATISTICAL AND ERROR LOG, YOU WILL GET A COMPLETE PICTURE OF WHAT IS HAPPENING ON THE LINK. NOISY COMM LINKS WILL BE DETECTED BETTER IF LARGE MESSAGES(512 CHARS) ARE SENT.

BOTH NODES MUST EITHER ENABLE('/PROTOCOL') OR DISABLE('/NOPROTOCOL').

NOTE: IF BOTH NODES IN ACTIVE AND '/NOCHECK' IS USED,
----- END-OF-PASS IS DEFINED AS RECEIVING 1 MESSAGE AND COMPLETING THE TRANSMIT LIST. WITH NO DATA CHECKING, THERE IS NO WAY FOR DCLT TO KNOW HOW MANY MESSAGES IT SHOULD EXPECT TO RECEIVE.

7.2.1 INTERNAL LOOP AT EACH NODE

RUN EACH END OF THE LINK IN ACTIVE MODE WITH LOOP=INTERNAL. TRANSMIT TWO OR THREE MESSAGES WITH NO DATA CHECKING. STATUS PRINTING COULD BE TURNED OFF IF ON, BUT SEEING THE SEQUENCE OF EVENTS MIGHT BE INFORMATIVE.

A POSSIBLE COMMAND SEQUENCE IS:

```
C E
C T
SE T=ONES/S=20/C=2
R M=A/LO=I/NOCH/STAT/NPR
```

WHAT THE ABOVE COMMAND SEQUENCE MEANS:

THE 'C E' AND THE 'C T' INITIALIZES THE 'EXPECT' LIST AND THE 'TRANSMIT LIST'. THE 'SE T=ONES/S=20/C=2' SETS THE TRANSMIT LIST TO CONTAIN 3 MESSAGES. THE MESSAGES CONTAIN DATA OF ALL ONES AND EACH ONE IS 20 BYTES IN LENGTH. THE 'R M=A/LO=I/NOCH/STAT' SETS THE MODE TO RUN IN TO BE ACTIVE AND LOOP TYPE TO BE INTERNAL TTL. THE PROGRAM WILL NOT BE CHECKING DATA SO THERE WAS NO NEED TO SET UP AN EXPECT LIST. THE PROGRAM WILL BE PRINTING STATUS MESSAGES.

CZDCLB DUP-11 DATA COMM. LINK TEST MACY11 30A(1052) 20-JUL-83 13:19 PAGE 34
 CZDCLB.P11 19-JUL-83 17:12

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND
 IF THINGS ARE RUNNING CORRECTLY :

```
INI RXQ TXQ RXQ TXC TXQ RXQ TXC
TXQ RXQ TXC EOP
MODE=ACTIVE/LOOP=INTERNAL/PASS=00000
/STATUS/NOCHECK/NOECHO/NOMODEM/NOPROTOCOL
DCLT> (A) ?
```

THIS GIVES YOU A IDEA IF THE COMM. DEVICE CAN EVEN TRANSMIT AND RECEIVE. ANY ERRORS REPORTED WILL PROBABLY BE DUE TO INCORRECT DEVICE ADDRESSES BEING USED OR A FAULTY DEVICE. CHECK ADDRESSES WITH "DISPLAY" AND RUN THE PREREQUISITE DIAGNOSTICS FOR THE COMM. DEVICE.

NOW TRY RUNNING EACH NODE THE SAME WAY WITH DATA CHECKING ENABLED. A POSSIBLE COMMAND SEQUENCE IS:

```
SE E=T
R M=A/LO=1/CH/PAS=3/PR
```

WHAT THIS SEQUENCE MEANS:

THIS SEQUENCE IS SIMILAR TO THE ONE ABOVE . THE "SE E=T" MAKES A COPY OF THE TRANSMIT LIST IN THE EXPECT LIST. THE EXPECT LIST NOW CONTAINS 3 MESSAGES. THE MESSAGES WILL HAVE ALL ONES FOR DATA AND BE 20 BYTES EACH IN LENGTH. THE RUN COMMAND IS THE SAME WITH THE ADDITION OF TWO SWITCHES "/CH/PAS=3". THE "CH" SWITCH TELLS THE PROGRAM TO CHECK THE RECEIVED DATA AGAINST THE "EXPECTED LIST". THE "PAS=3" SWITCH TELLS THE PROGRAM TO RUN 3 PASSES BEFORE RETURNING TO THE DCLT> PROMPT. ON NON-DDCMP LINKS, THE "/PROTOCOL" SWITCH IS OPTIONAL.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 35

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND
IF THINGS ARE RUNNING CORRECTLY :

```
INI RXQ TXQ TXC RXQ TXQ TXC RXQ
TXQ TXC CMP CMP CMP EOP RXQ TXQ
TXC RXQ TXQ TXC RXQ TXQ TXC CMP
CMP CMP EOP RXQ TXQ TXC RXQ TXQ
TXC RXQ TXQ TXC CMP CMP CMP EOP
MODE=ACTIVE/LOOP=INTERNAL/PASS=00000
/STATUS/CHECK/NOECHO/NOMODEM/PROTOCOL
```

IF A CABLE TURNAROUND CONNECTOR IS AVAILABLE, PUT IT ON THE END OF
THE CABLE JUST BEFORE THE MODEM AND RUN IN ACTIVE MODE WITH THE
"/LOOP=CABLE" SWITCH.

POSSIBLE COMMAND SEQUENCE IS:

```
R M=A/L=C/CH/PAS=3
```

WHAT THIS SEQUENCE MEANS:

THIS SEQUENCE HAS THE "/LO=C". THIS INFORMS THE SOFTWARE
NOT TO CHECK FOR DATA SET READY SIGNAL FROM THE MODEM.
ALSO A CLOCK SIGNAL IS FURNISHED BY THE DUP.

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND
IF THINGS ARE RUNNING CORRECTLY :

```
INI RXQ TXQ TXC RXQ TXQ TXC RXQ
TXQ TXC CMP CMP CMP EOP RXQ TXQ
TXC RXQ TXQ TXC RXQ TXQ TXC CMP
CMP CMP EOP RXQ TXQ TXC RXQ TXQ
TXC RXQ TXQ TXC CMP CMP CMP EOP
MODE=ACTIVE/LOOP=CABLE/PASS=00000
/STATUS/CHECK/NOECHO/NOMODEM/PROTOCOL
DCLT> (A) ?
```

7.2.2 TRANSMIT ON ONE NODE RECEIVE ON THE OTHER

NOW TRY TRANSMITTING FROM ONE END AND RECEIVING ON THE
OTHER. MAYBE WITH NO DATA CHECKING AT FIRST TO ESTABLISH
IF THE LINK IS WORKING. POSSIBLE COMMAND SEQUENCES ARE:

NODE A	NODE B
-----	-----
C E	C E
C T	C T
R M=TR/NOCH/PAS=3/NPR	R M=R/NOCH/PAS=3/NPR

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 36

WHAT THIS SEQUENCE MEANS:

THE "C E " AND "C T" INITIALIZE BOTH THE TRANSMIT AND EXPECT LISTS. THE "R M=TR/PAS=3" SETS THE RUN MODE OF NODE A TO BE TRANSMIT AND THE PASS COUNT IS SET TO 3. THE "R M=R/NOCH/PAS=3" SETS THE RUN MODE OF NODE B TO RECEIVE WITH NO DATA CHECKING AND THE PASS COUNT IS SET TO THREE. PROTOCOL CAN BE OPTIONAL BUT IT MUST BE ENABLE OR DISABLE ON BOTH ENDS.

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND IF THINGS ARE RUNNING CORRECTLY :

FOR NODE A:

```
INI TXQ TXC EOP TXQ TXC EOP TXQ
TXC EOP
MODE=TRANSMIT/PASS=00000
/STATUS/NOCHECK/NOECHO/NOMODEM/NOPROTOCOL
DCLT> (A) ?
```

FOR NODE B:

```
INI RXQ EOP RXQ EOP RXQ EOP
MODE=RECEIVE/PASS=00000
/STATUS/NOCHECK/NOECHO/NOMODEM/NOPROTOCOL
DCLT> (A) ?
```

NOW TRY DOING DATA CHECKING ON THE MESSAGE(S) BEING TRANSMITTED. POSSIBLE COMMAND SEQUENCES ARE:

R M=TR/PAS=3

R M=R/CH/PAS=3

WHAT THIS SEQUENCE MEANS:

THE CHANGE IN THE RUN COMMAND IS FROM "NOCH" TO "CH". THE "CH" ENABLES DATA CHECKING.

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND IF THINGS ARE RUNNING CORRECTLY:

NODE A: IS THE SAME AS ABOVE.

NODE B:

```
INI RXQ CMP EOP RXQ CMP EOP RXQ CMP EOP
MODE=RECEIVE/PASS=00000
/STATUS/CHECK/NOECHO/NOMODEM/PROTOCOL
DCLT> (A)?
```

NOW RUN THRU THE SEQUENCE AGAIN WITH NODE A RECEIVING AND NODE B TRANSMITTING TO CHECK OUT THE OPPOSITE DIRECTION OF DATA FLOW.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 37

7.2.3 ONE NODE ACTIVE THE OTHER NODE PASSIVE

NOW TRY RUNNING ONE NODE IN ACTIVE MODE WHILE THE OTHER
END RUNS IN PASSIVE. DATA CHECKING SHOULD BE TURNED OFF
IF THE MESSAGE LISTS ARE NOT THE SAME.
POSSIBLE COMMAND SEQUENCES ARE:

NODE A	NODE B
-----	-----
C E	C E
C T	C T
SE T=CCITT/S=10/C=2	SE T=1ALT/S=20/C=2
R M=ACT/NOCH/PAS=3	R M=P/NOCH/PAS=3

WHAT THIS SEQUENCE MEANS:

THE EXECUTION OF THIS SEQUENCE CAUSES THE FOLLOWING
THINGS TO HAPPEN ON NODE A. THE TRANSMIT AND EXPECT
LISTS ARE INITIALIZED THEN THE TRANSMIT LIST IS SET
TO 3 MESSAGES OF 10 BYTES EACH. THE DATA USED IN THE
TRANSMIT MESSAGES IS THE CCITT PATTERN. THEN NODE A
IS RUN IN ACTIVE MODE WITH DATA CHECKING DISABLED AND
THE PASS COUNT SET TO THREE. NOTE STATUS WOULD STILL BE
PRINTED IF THE PREVIOUS SEQUENCES HAD BEEN RUN.
IF YOU ARE RUNNING FROM LOAD TIME YOU WOULD HAVE
TO ADD A '/STA TO THE RUN COMMAND LINE.

NODE B: THE TRANSMIT AND EXPECT LISTS ARE INITIALIZED
THEN THE TRANSMIT LIST IS SET TO 3 MESSAGES OF
20 BYTES EACH. THE DATA FOR EACH MESSAGE IS ALTERNATING
1'S AND 0'S. THE NODE IS THEN RUN IN PASSIVE MODE WITH
DATA CHECKING DISABLED AND THE PASS COUNT SET TO 3.

WHAT YOU SHOULD SEE AFTER ENTERING THE RUN COMMAND
IF THINGS ARE RUNNING CORRECTLY :

FOR NODE A:

```
INI RXQ TXQ TXC RXQ TXQ TXC RXQ
TXQ TXC EOP RXQ TXQ TXC RXQ TXQ
TXC RXQ TXQ TXC EOP RXQ TXQ TXC
RXQ TXQ TXC RXQ TXQ TXC EOP
MODE=ACTIVE/PASS=00000
/STATUS/NOCHECK/NOECHO/NOMODEM/NOPROTOCL
DCLT> (A) ?
```

FOR NODE B:

```
INI RXQ TXQ TXC RXQ TXQ TXC RXQ
TXQ TXC EOP RXQ TXQ TXC RXQ TXQ
TXC EOP RXQ TXQ TXC RXQ TXQ TXC
RXQ TXQ TXC EOP
MODE=PASSIVE/PASS=00000
/STATUS/NOCHECK/NOECHO/NOMODEM/NOPROTOCOL
DCLT> (A) ?
```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 38

NOW USE DATA CHECKING WITH THE "EXPECT MESSAGE LISTS" SET
UP APPROPRIATELY. ANOTHER VARIATION IS TO HAVE LARGE SIZE
MESSAGES ON ONE SIDE WITH SMALL MESSAGES ON THE OTHER.

THEN REVERSE THE SETUP SO THAT THE NODE RUNNING IN ACTIVE
IS RUNNING IN PASSIVE AND VICE VERSA.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 41

WHAT YOU WOULD SEE IS

MSG: TYPE=ALPHA/SIZE=35

MSG: TYPE=ALPHA/SIZE=35

MSG: TYPE=ALPHA/SIZE=35

MSG: TYPE=ALPHA/SIZE=35

MODE=ACTIVE/PASS=00001

/NOSTATUS/CHECK/NOECHO/NOMODEM/NOPROTOCOL

DCLT> (A) ?

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 48
DISPATCH TABLE

.SBTTL DISPATCH TABLE

:++
: THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
: IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
:--

2099		
2100		
2101		
2102		
2103		
2104		
2105		
2106	002122	
2107	002122	000001
2108	002124	
2109	002124	026342
2110		

DISPATCH 1

	.WORD	1
LSDISPATCH::		
	.WORD	T1

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 49
DEFAULT HARDWARE P-TABLE

.SBTTL DEFAULT HARDWARE P-TABLE

:++
: THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
: THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
: IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
: AND IS USED AS A 'TEMPLATE' FOR BUILDING THE P-TABLES.
:--

2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149

002126
002126 000010
002130
002130

002130 000001

002132 160170
002134 000300
002136 000240
002140 000000
002142 000001
002144 000000
002146 000000

002150
002150

BGNHW DFPTBL

L10000-LSHW/2
LSHW::
DFPTBL::

:INDEPENDENT SECTION
: THE NUMBERS IN BRACKETS ARE THE OFFSET VALUES USED IN THE PARAMETER
: CODING SECTION.

.WORD 1 ;[0] FULL OR HALF DUPLEX FLAG (BIT0=1 IF FULL)

:DEVICE DEPENDENT SECTION
: ADDING OR REMOVING WORDS FROM THIS TABLE EFFECTS THE 'GET' CALLS IN
: THE HARDWARE PARAMETER CODING SECTION BY CHANGING 'OFFSETS'

.WORD 160170 ;[2] CSR ADDRESS
.WORD 300 ;[4] INTERRUPT VECTOR
.WORD 240 ;[6] INTERRUPT PRIORITY (5)
.WORD 0 ;[10] MULTI POINT =1 PT TO PT = 0
.WORD 1 ;[12] TRIB ADDRESS THIS STATION
.WORD 0 ;[14] OTHER NODE 'ITEP'
.WORD 0 ;[16] SPARE

ENDHW

L10000:

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 51
GLOBAL EQUATES SECTION

```
2206
2207
2208
2209      000340
2210      000300
2211      000240
2212      000200
2213      000140
2214      000100
2215      000040
2216      000000
2217
2218
2219
2220      000004
2221      000010
2222      000020
2223      000040
2224      000100
2225      000200
2226      000400
2227      001000
2228      002000
2229      004000
2230      010000
2231      020000
2232      040000
2233      100000
2234
```

```

:
: PRIORITY LEVEL DEFINITIONS
:
PRI07== 340
PRI06== 300
PRI05== 240
PRI04== 200
PRI03== 140
PRI02== 100
PRI01== 40
PRI00== 0
:
: OPERATOR FLAG BITS
:
EVL==      4
LOT==     10
ADR==     20
IDU==     40
ISR==    100
UAM==    200
BOE==    400
PNT==   1000
PRI==   2000
IXE==   4000
IBE==  10000
IER==  20000
LOE==  40000
HOE== 100000
```


CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 55
GLOBAL EQUATES SECTION

2403	010000	DCD=	BIT12	:DATA CARRIER DETECT (CIRCUIT CF)
2404	000004	RTS=	BIT2	:REQUEST TO SEND (CIRCUIT CA)
2405	040000	RI=	BIT14	:RING INDICATOR (CIRCUIT CE)
2406	004000	SRD=	BIT11	:SECONDARY RECEIVE DATA
2407				
2408				
2409				
2410				
2411				
2412	000002	; DEVICE SIGNALS		:DATA TERMINAL READY
2413	000010	DTR=	BIT1	:HALF DUPLEX MODE
2414	000020	HDPLX=	BIT3	:RECEIVER ENABLE
2415	000040	RXENA=	BIT4	:DATA SET CHANGE ENABLE
2416	000100	DSITEN=	BIT5	:REC INT. ENABLE
2417	000200	RINTEN=	BIT6	:REC DATA READY
2418	004000	RXDONE=	BIT7	:REC ACTIVE
2419	000400	RXACT=	BIT11	:MASTER RESET
2420	001000	RESET=	BIT8	:TX ACTIVE
2421	000200	TXACT=	BIT9	:TX BUFFER EMPTY
2422	004000	TXDONE=	BIT7	:TTL LOOP BIT (INTERNAL)
2423	010000	TTL=	BIT11	:CABLE LOOP (TURN AROUND)
2424	000020	CABLOP=	BIT12	:TX ENABLE
2425	000100	SEND=	BIT4	:TX INT ENABLE
2426	000400	TINTEN=	BIT6	:TX START OF MSG.
2427	001000	TSOM=	BIT8	:TX END OF MSG.
2428	100000	TEOM=	BIT9	:TX ERROR
2429	100000	TERR=	BIT15	:REC OVER RUN
2430	010000	RERR=	BIT15	:CRC CHAR OK
2431	100000	CRCOK=	BIT12	:DATA SET CHANGE A
2432	000400	DSCA=	BIT15	:SYNC STRIP
2433	000226	STRIP=	BIT8	:SYNC WORD
2434		SYN=	226	

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 58
 DEFAULT MESSAGE DEFINITIONS AND TABLES

2534
 2535
 2536
 2537
 2538
 2539
 2540 002644 000
 2541 002645 201
 2542 002646
 2543 002646 000000
 2544 002650 001
 2545 002651 001
 2546 002652 001
 2547 002653
 2548 002654
 2549 002654 000006
 2550
 2551
 2552 002656 000
 2553 002657 201
 2554 002660
 2555 002660 000000
 2556 002662 001
 2557 002663 001
 2558 002664 001
 2559 002666
 2560

.....
 : THE FOLLOWING IS THE AREA USED TO TRANSMIT AND REC THE :
 : HEADER MSGS. AND THE START,STACK ACK SEQUENCES. :
 : :

:: THE TRANSMIT HEADER MESSAGE WILL BE STORED HERE
 HDMMSG: .BYTE 0 ;FILLER
 HDMID: .BYTE 201 ;MESSAGE TYPE WILL BE STORED HERE
 HDMTYP: ;IF CONTROL MESSAGE, TYPE IS STORED HERE
 HDMCC: .WORD 0 ;CHAR COUNT GOES HERE
 HDMREP: .BYTE 1 ;RESPONSE NUMBER
 HDMNUM: .BYTE 1 ;MSG. NUMBER
 HDMADR: .BYTE 1 ;ADDR TO.
 HSMSE:
 HDMC: .EVEN
 .WORD 6 ;CHARACTER COUNT OF HEADER

:: THE RECEIVED HEADER WILL BE STORED HERE
 RHDMSG: .BYTE 0
 RHDID: .BYTE 201 ;MESSAGE TYPE GOES HERE
 RHD TYP: ;IF CONTROL MESSAGE, TYPE GOES HERE
 RHD M C C: .WORD 0 ;BYTE COUNT GOES HERE
 RHDREP: .BYTE 1 ;RESP NUM
 RHDNUM: .BYTE 1 ;MSG NUM
 RHDADR: .BYTE 1 ;ADDRESS OF TRIB
 .EVEN

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 60
DEFAULT MESSAGE DEFINITIONS AND TABLES

2617 003136 000000
2618 003140 000000
2619 003142 000000
2620 003144 000000
2621 003146 000
2622 003147 000
2623

PSACT: .WORD 0
PSCNT: .WORD 0
PSNUM: .WORD 0
PSRADX: .WORD 0
PSNNUF: .BYTE 0
PSGDBD: .BYTE 0

:LOC. TO HOLD ADDR. OF ACTION ROUTINE
:LOC. TO BE A COUNTER LOCATION
:LOC. TO HOLD NUMERIC VALUE FROM PARSE
:LOC. TO HOLD RADIX USED(L) AND +/- (HI BYTE)
:RETURN =0 IF ENOUGH OF COMMAND FOUND
:RETURN CODE 0 IF NO ERROR FOUND

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 62
MESSAGE BUFFERS AND POINTER TABLES

2680 006552 000000
2681 006554 000
2682 006555 000
2683 006556 000000
2684

CONTIN: .WORD 0 :WORD FOR CONTROL IN
GOOD: .BYTE 0 :BYTE TO HOLD EXPECTED MESSAGE DATA BYTE FOR ERR REPORT
BAD: .BYTE 0 :BYTE TO HOLD RECEIVED MESSAGE DATA BYTE FOR ERR REPORT
DATAWORD: .WORD 0 :STORAGE LOCATION FOR TRANSMIT DATA

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 97
DUMP BYTES OR WORDS

3938 023250 003005
3939 023252 005203
3940 023254 022703 000010
3941 023260 001725
3942 023262 000736
3943
3944 023264 000207
3945

BGT DUMEX
INC R3
CMP #8,R3
BEQ DUM4
BR DUM3
DUMEX: RTS PC

:IF DONE EXIT
:ELSE BUMP R3
:HAVE WE PRINTED 8 ACCROSS
:IF SO GO BACK TO 4
:ELSE GO BACK AND PRINT ANOTHER
:BYTE OR WORD
:RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 98
UPDATE TOTAL CHAR. COUNT SUBROUTINE

3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986
3987

.SBTTL UPDATE TOTAL CHAR. COUNT SUBROUTINE

```

:++
: FUNCTIONAL DESCRIPTION:
:   UPDATES TOTAL CHAR. COUNT TOTCC BASED ON CURCC.
:   LAST MESSAGE IS TRUNCATED TO FIT INTO THE
:   BUFFER IF TOTAL CHAR. COUNT EXCEEDS 'BUFLIM' A MESSAGE
:   IS PRINTED TELLING THE OPERATOR THE TRUNCATION OCCURED.
    
```

```

: INPUTS:
:   CURCC= CHAR. COUNT OF MESSAGE BEING ADDED
:   TOTCC= TOTAL CHAR COUNT OF BUFFER ITS BEING ADDED TO
    
```

```

: OUTPUTS:
:   MESSAGE TO OPERATOR IF MESSAGE TRUNCATED TO FIT
    
```

```

: FUNCTIONAL SIDE EFFECTS:
:   LOCATION "TEMP" USED FOR CALCULATIONS
    
```

```

: CALLING SEQUENCE:
:   JSR     PC,ADCC           ;UPDATED TOTAL CHAR. COUNT
:--
    
```

```

ADDCC: ADD     CURCC,TOTCC      ;ADD CURRENT TO TOTAL
        CMP     #BUFLIM,TOTCC  ; COMPARE TO 'BUFLIM'
        BHIS   ADDC1          ;IF NOT MORE THEN 'BUFLIM' EXIT
    
```

```

; PRINT MESSAGE AND TRUNCATE COUNT
    
```

```

PRINTF #MSGTRU
    
```

```

MOV     #MSGTRU,-(SP)
MOV     #1,-(SP)
MOV     SP,R0
TRAP   C$PNTF
ADD     #4,SP
    
```

```

SUB     CURCC,TOTCC          ;SUB CURRENT FROM TOTAL
MOV     #BUFLIM,TEMP        ;MOV 'BUFLIM' TO TEMP
SUB     TOTCC,TEMP          ;SUB TOTAL FROM 'BUFLIM'
MOV     TEMP,CURCC         ;AND ESTABLISH NEW CURRENT
ADD     CURCC,TOTCC        ;ADD 'ADJUSTED CURRENT' TO TOTAL CHAR. CNT.
ADDCC1: RTS                ;RETURN TO CALLER
        PC
    
```

```

023266 063737 006520 006530
023274 022737 001000 006530
023302 103027
023304
023304 012746 014424
023310 012746 000001
023314 010600
023316 104417
023320 062706 000004
023324 163737 006520 006530
023332 012737 001000 006534
023340 163737 006530 006534
023346 013737 006534 006520
023354 063737 006520 006530
023362 000207
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 99
BUILD MESSAGE BUFFERS SUBROUTINE

3988
3989
3990
3991
3992
3993
3994
3995
3996
3997
3998
3999
4000
4001
4002
4003
4004
4005
4006
4007
4008
4009
4010
4011
4012 023364
4013 023364 010246
4014 023366 010346
4015 023370 013702 006524
4016
4017 023374 013722 006526
4018 023400 013722 006520
4019 023404 010237 006524
4020 023410 013702 006516
4021 023414 006302
4022 023416 013737 006526 006534
4023 023424 063737 006520 006534
4024 023432 013703 006526
4025 023436 016237 002150 006540
4026 023444 016204 002172
4027 023450 060437 006540
4028 023454 112423
4029 023456 020337 006534
4030 023462 001404
4031 023464 020437 006540
4032 023470 001762
4033 023472 000770
4034 023474 063737 006520 006526
4035 023502 012603
4036 023504 012602
4037 023506 000207
4038

.SBTTL BUILD MESSAGE BUFFERS SUBROUTINE

++
FUNCTIONAL DESCRIPTION:
BLDBUF-- BUILD POINTER TABLE AND BUFFERS

THIS SUBROUTINE ADDS A MESSAGE TO THE TRANSMIT OR EXPECT LIST
USING THE POINTER, BYTE COUNT, AND ADDRESS PASSED TO IT.

INPUTS:

CURCC= CHAR. COUNT OF MESSAGE TO BE ADDED
CURADD= ADDRESS OF MESSAGE TO BE ADDED
CPTR= ADDRESS OF POINTER TABLE WORD WHERE MESSAGE POINTERS ARE
TO BE BUILT
MSGTYP= VALUE TO USE AS AN INDEX TO FIND SOURCE OF MESSAGE DATA
INDEX INTO DMSGCT() AND DMSGAD().

OUTPUTS:

A MESSAGE ADDED TO EITHER TXBUF OR CMPBUF
APPROPRIATE POINTERS IN PTRTAB POINTER TABLE

CALLING SEQUENCE:

JSR PC,BLDBUF ;BUILD MESSAGE IN BUFFER AND ADD PTRS.

BLDBUF:

MOV R2,-(SP) ;SAVE R2 AND R3 ON THE STACK
MOV R3,-(SP)
MOV CPTR,R2

BLDB1:

MOV CURADD,(R2)+ ;PUT CURRENT ADD ON POINTER TAB
MOV CURCC,(R2)+ ;PUT CURRENT CC ON POINTER TAB
MOV R2,CPTR ;PUT UPDATED R2 BACK TO CURRENT POINT
MOV MSGTYP,R2 ;GET MESSAGE TYPE TO USE AS INDEX
ASL R2 ;DOUBLE FOR WORD INDEX
MOV CURADD,TEMP ;MOVE CURRENT ADD TO TEMP
ADD CURCC,TEMP ;ADD CHAR COUNT TO IT TO GET END
MOV CURADD,R3 ;SET R3 TO CURRENT START ADD

BLDB2:

MOV DMSGCT(R2),TEMP2 ;GET BYTE COUNT
MOV DMSGAD(R2),R4 ;PUT STARTING FROM ADD IN R4
ADD R4,TEMP2 ;ADD IT TO TEMP2 TO GET END OF FROM

BLDB3:

MOVB (R4)+,(R3)+ ;MOV BYTE FROM PATTERN TO BUFFER
CMP R3,TEMP ;ALL DONE?
BEQ BLDBEX ;IF SO EXIT
CMP R4,TEMP2 ;IS PATTERN COUNT EXPIRED
BEQ BLDB2 ;IF SO GO START AGAIN
BR BLDB3 ;IF NOT GET ANOTHER BYTE

BLDBEX:

ADD CURCC,CURADD ;BUMP CURADD
MOV (SP)+,R3 ;RESTORE R3 AND R2
MOV (SP)+,R2
RTS PC ;RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 100
CREATE FACSIMILE OF TX BUFFER AND MESSAGE LIST

4039
4040
4041
4042
4043
4044
4045
4046
4047
4048
4049
4050
4051
4052
4053
4054
4055
4056
4057
4058
4059
4060
4061
4062
4063
4064
4065
4066
4067
4068
4069
4070
4071
4072
4073
4074
4075
4076
4077
4078
4079
4080
4081
4082
4083
4084
4085
4086
4087
4088
4089
4090
4091
4092
4093
4094

.SBTTL CREATE FACSIMILE OF TX BUFFER AND MESSAGE LIST

..++
..FUNCTIONAL DESCRIPTION:

FACSIMILE: THIS ROUTINE IS USED TO CREATE A FACSIMILE OF THE
OF THE TRANSMIT LIST AND TRANSMIT BUFFER IN THE
EXPECTED LIST AND EXPECTED BUFFER. THE ROUTINE IS
NORMALLY CALLED WHEN USER COMMAND "SET E [EXPECT]=
T [TRANSMIT] IS ENTERED.

CALLING SEQUENCE: JSR PC,FACSIMILE

DEFINITIONS CMPBUF = EXPECTED DATA BUFFER HOLDS MAX 512 BYTES
TXBUF = TRANSMIT DATA BUFFER HOLDS MAX 512 BYTES
TTOTCC = NUMBER OF BYTES IN TXBUF
PTRTAB = TOP OF MESSAGE LIST POINTER TABLE
CTOTCC = NUMBER OF BYTES IN EXPECT MESSAGE
CMPTOT = NUMBER OF EXPECTED MESSAGES
CMPPTR = EXPECTED MESSAGE LIST POINTER
TXPTR = TRANSMIT MESSAGE LIST POINTER
TXMTOT = NUMBER OF TRANSMIT MESSAGES
CCURAD = STORAGE ADDRESS OF MESSAGE IN CMPBUF
MSGLIN = MAXIMUM NUMBER OF MESSAGES THAT CAN BE STORED

BEGIN FACSIMILE ROUTINE
(*COPY TXBUF ==> CMPBUF*)

..SAVE R1
..INIT R1
..REPEAT
....[CMPBUF]R1=[TXBUF]R1
....R1=R1+1
..UNTIL R1 = BUFLIM

(*NOW CALCULATE EXPECT LIST MESSAGE POINTER*)
..CMPPTR = PTRTAB + (2 * MSGLIM)

(*NOW PRIME THE WHILE - DO LOOP*)

..TXPTR = PTRTAB
..CCURAD = CMPBUF
..TXPTR = TXPTR + 2
..CTOTCC = [TXPTR]
..CMPTOT = 0
..WHILE TXMTOT <> CMPTOT DO
....[CMPPTR] = CCURAD
....CMPPTR = CMPPTR + 2
....[CMPPTR] = CTOTCC
....TXPTR = TXPTR + 4
....CCURAD = CCURAD + CTOTCC
....CTOTCC = [TXPTR]
....CMPPTR = CMPPTR + 2
....CMPTOT = CMPTOT + 1
..END WHILE DO
..CTOTCC = TTOTCC
END FACSIMILE ROUTINE

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 101
CREATE FACSIMILE OF TX BUFFER AND MESSAGE LIST

```

4095 023510
4096
4097 023510 010146
4098 023512 005001
4099 023514 116161 003150 005150 10$:
4100 023522 005201
4101 023524 020127 001000
4102 023530 001371
4103
4104 023532 012701 000017 20$:
4105 023536 006301
4106 023540 006301
4107 023542 012737 006150 006444
4108 023550 060137 006444
4109 023554 005001
4110
4111
4112 023556 012737 006150 006442
4113 023564 012737 005150 006452
4114 023572 062737 000002 006442
4115 023600 017737 162636 006450
4116 023606 005037 006446
4117
4118
4119 023612 023737 006462 006446 30$:
4120 023620 001430
4121 023622 013777 006452 162614
4122 023630 062737 000002 006444
4123 023636 013777 006450 162600
4124 023644 062737 000004 006442
4125 023652 063737 006450 006452
4126 023660 017737 162556 006450
4127 023666 062737 000002 006444
4128 023674 005237 006446
4129 023700 000744
4130
4131 023702 013737 006464 006450 40$:
4132
4133
4134 023710 012601
4135 023712 000207
4136
4137

FACSIMILE:

MOV R1,-(SP) ;SAVE R1
CLR R1 ;INIT R1
MOVB TXBUF(R1),CMPBUF(R1) ;COPY TX BUFFER TO EXPECTED BUFFER
INC R1 ;BUMP INDEX
CMP R1,#BUFLIM ;ALL DATA COPIED ?
BNE 10$ ;NO,BRANCH

MOV #MSGLIM,R1 ;MESSAGE LIMIT
ASL R1 ;MULTIPLY BY 2
ASL R1 ;MULTIPLY BY 2
MOV #PTRTAB,CMPPTR ;TOP OF POINTER TABLE
ADD R1,CMPPTR ;START OF EXPECTED POINTER TABLE
CLR R1 ;INIT R1

;SET UP WHILE - DO LOOP
MOV #PTRTAB, TXPTR ;TX POINTER NOW AT TOP OF TABLE
MOV #CMPBUF,CCURAD ;TRANSFER ADDRESS OF 1ST MESSAGE
ADD #2, TXPTR ;BUMP POINTER
MOV @TXPTR,CTOTCC ;BYTE COUNTER 1ST MESSAGE
CLR CMPTOT ;INIT EXPECTED MESSAGE COUNT

;WHILE TX MESSAGE TOTAL <> EXPECTED MESSAGE TOTAL DO
CMP TXMTOT,CMPTOT ;ALL MESSAGES COPIED ?
BEQ 40$ ;YES,BRANCH
MOV CCURAD,@CMPPTR ;TRANSFER ADDRESS OF MESSAGE
ADD #2,CMPPTR ;BUMP POINTER
MOV CTOTCC,@CMPPTR ;BYTE COUNT OF MESSAGE
ADD #4, TXPTR ;BUMP TX MESSAGE POINTER
ADD CTOTCC,CCURAD ;CALC. TRANSFER ADDRESS
MOV @TXPTR,CTOTCC ;BYTE COUNT NEXT MESSAGE
ADD #2,CMPPTR ;BUMP POINTER
INC CMPTOT ;INCREMENT MESSAGE COUNT
BR 30$ ;DO IT AGAIN

;END WHILE - DO
MOV TTOTCC,CTOTCC ;COPY TOTAL CHARACTER COUNT

;END ROUTINE
MOV (SP)+,R1 ;RESTORE R1
RTS PC ;RETURN

```


CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 108
TRAVERSE COMMAND LINE SUBROUTINES

```

4444
4445
4446
4447 025246 010401          TRVSTR: MOV      R4,R1          ;POINT R1 TO CMD STRING
4448 025250 010305          MOV      R3,R5
4449 025252 062705 000006  ADD      #6,R5          ;POINT R5 TO MATCH STRING FROM CLI NODE
4450 025256 005037 003140  CLR      PSCNT         ;CLEAR CHAR MATCH COUNT
4451 025262 105715          2$:  TSTB     (R5)        ;SEE IF END OF MATCH STRING YET
4452 025264 001411          BEQ      10$          ;BR IF YES
4453 025266 105711          TSTB     (R1)        ;SEE IF END OF CMD LINE YET
4454 025270 001407          BEQ      10$          ;BR IF YES
4455 025272 121115          CMPB     (R1),(R5)    ;SEE IF CHARACTERS MATCH
4456 025274 001005          BNE      10$          ;BR IF NO
4457 025276 005237 003140  INC      PSCNT        ;MATCH -INCREMENT MATCH COUNT
4458 025302 005201          INC      R1          ;UPDATE STRING POINTERS
4459 025304 005205          INC      R5
4460 025306 000765          BR       2$          ;BR TO CONTINUE CHECKING CHARS.
4461
4462 025310 005737 003140  10$:  TST      PSCNT        ;WHEN DONE SEE IF ANY MATCHES FOUND
4463 025314 001406          BEQ      15$          ;BR IF NO, GO TAKE THE MISS BRANCH
4464 025316 010104          MOV      R1,R4        ;POINT CMD POINTER TO END OF STRING &
4465 025320 004737 024366  JSR      PC,TRVACT    ;IF A MATCH FOUND, GO DO MATCH ACTION
4466 025324 066303 000004  ADD      4(R3),R3     ;UPDATE R3 TO NEXT NODE (NO BRANCH)
4467 025330 000207          RTS      PC          ; (NO RETURN THRU TRVNOB SINCE DIFFERNT
4468                                     ; DISPLACEMENT DUE TO MATCH STRING)
4469 025332 000137 024406  15$:  JMP      TRVBRC     ; GO TAKE BRANCH
4470
4471                                     ; (PARSED OK), -1 IF ILL CMD.....
4472 -----
4473

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 109
REPORT CODING SECTION

.SBTTL REPORT CODING SECTION

:++
: THE REPORT CODING SECTION CONTAINS THE
: 'PRINTS' CALLS THAT GENERATE STATISTICAL REPORTS.
:--

4474
4475
4476
4477
4478
4479
4480
4481
4482
4483
4484
4485
4486
4487
4488
4489
4490
4491
4492
4493
4494

025336
025336

025336 004737 020612

025342
025342
025342 104425

BGNRPT

LSRPT::

JSR PC,REPORT

:CALL SUBROUTINE TO DUMP EVENT LOG
: AND BASE TABLE

ENDRPT

L10010: TRAP CSRPT

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 110
PROTECTION TABLE

.SBTTL PROTECTION TABLE

:++
: THIS TABLE IS USED BY THE RUNTIME SERVICES
: TO PROTECT THE LOAD MEDIA.
:--

4495
4496
4497
4498
4499
4500
4501
4502 025344
4503 025344
4504
4505 025344 177777
4506 025346 177777
4507 025350 177777
4508
4509 025352
4510

BGNPROT

LSPROT::

-1
-1
-1

:OFFSET INTO P-TABLE FOR CSR ADDRESS
:OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
:OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 114
INITIALIZE SECTION

4679	026216	062706	000010			ADD	#10,SP
4680							
4681	026222			SETPRI	#PRI00	;SET THE 'RUN' PRIORITY TO 0	
4682	026222	012700	000000			MOV	#PRI00,RO
4683	026226	104441				TRAP	C\$SPRI
4684	026230			EXIT	INIT		
4685	026230	104432				TRAP	C\$EXIT
4686	026232	000002				.WORD	L10012-.
4687							
4688							
4689				.EVEN			
4690							
4691	026234			ENDINIT			
4692	026234					L10012:	
4693	026234	104411				TRAP	C\$INIT

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 115
AUTODROP SECTION

.SBTTL AUTODROP SECTION

:+
: THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
: THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
: SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
: DROPPED FROM TESTING.
:--

4694
4695
4696
4697
4698
4699
4700
4701
4702
4703 026236
4704 026236
4705
4706
4707 026236
4708 026236
4709 026236 104461

BGNAUTO

LSAUTO::

ENDAUTO

L10013: TRAP CSAUTO

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 116
 CLEANUP CODING SECTION

.SBTTL CLEANUP CODING SECTION

```

    :++
    : THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
    : AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
    :--
    
```

```

4710
4711
4712
4713
4714
4715
4716
4717 026240          BGNCLN
4718 026240
4719
4720 026240 005077 160356          CLR      @CLKCSR      :DISABLE CLOCK
4721 026244          SETPRI     #PRI07      :SET PROCESSOR PRIORITY BACK TO 7
4722 026244 012700 000340          :                    MOV     #PRI07,R0
4723 026250 104441          :                    TRAP   C$SPRI
4724 026252 022737 000057 003010   CMP      #EXIT,KEYWD1  :'EXIT' COMMAND ?
4725 026260 001416          BEQ      EXITCLN       :YES,BRANCH
4726
4727          :;LOG ^C ABORT IN EVENT LOG
4728 026262 012737 000026 006534   MOV     #ABO,TEMP      :EVENT TYPE
4729 026270 013737 006502 006544   MOV     OPVAR,TEMP4    :START TIME-OUTS
4730 026276 013737 006504 006540   MOV     PSCNT,TEMP2    :PASSES
4731 026304 013737 006506 006542   MOV     ERRCNT,TEMP3   :ERRORS
4732 026312 004737 020506          JSR     PC,LOG$5       :GO LOG IT
4733 026316          EXITCLN:BRESET    :CLEAR ALL BEFORE END
4734 026316 104433          :                    TRAP   C$RESET
4735
4736 026320          EXIT      CLN
4737 026320 104432          :                    TRAP   C$EXIT
4738 026322 000002          :                    .WORD  L10014-.
4739
4740
4741          .EVEN
4742
4743 026324          ENDCLN
4744 026324
4745 026324 104412          L10014:   TRAP   C$CLEAN
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 117
 DROP UNIT SECTION

.SBTTL DROP UNIT SECTION

```

:++
: THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
: TO NO LONGER BE TESTED.
:--
    
```

```

4746
4747
4748
4749
4750
4751
4752
4753 026326          BGNDU
4754 026326          LSDU::
4755
4756
4757 026326          EXIT  DU
4758 026326 000167   .WORD  JSJMP
4759 026330 000000   .WORD  L10015-2-.
4760
4761
4762
4763
4764 026332          .EVEN
4765 026332          ENDDU
4766 026332 104453   L10015: TRAP  C$DU
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 118
 ADD UNIT SECTION

4767
 4768
 4769
 4770
 4771
 4772
 4773
 4774
 4775 026334
 4776 026334
 4777
 4778
 4779 026334
 4780 026334 000167
 4781 026336 000000
 4782
 4783
 4784
 4785
 4786 026340
 4787 026340
 4788 026340 104452
 4789
 4790

.SBTTL ADD UNIT SECTION

:+
 : THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
 : TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
 : TO THE TEST CYCLE.
 :--

BGNAU

LSAU::

EXIT AU

.WORD JSJMP
 .WORD L10016-2-

.EVEN

ENDAU

L10016: TRAP CSAU

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 125
ACTION TABLE AND ROUTINES

5098 030106 000700
5099 030110 000246
5100 030112 001572
5101 030114 000236
5102 030116 001272
5103

.WORD	ACTDMQ-10\$:DUMP WORD
.WORD	ACTPRT-10\$:PRINT
.WORD	ACTMOS-10\$:MODEM STATUS
.WORD	ACTEXT-10\$:EXIT ROUTINE
.WORD	ACTSEX-10\$:SET EX=TR

CZDCLB DUP-11 DATA COMM. LINK TEST MACY11 30A(1052) 20-JUL-83 13:19 PAGE 130
 CZDCLB.P11 19-JUL-83 17:12 ACTION TABLE AND ROUTINES

5303	031312	012737	000003	006570	ACTATV: MOV	#ACT,MODTYP	:MODE = ACTIVE
5304	031320	000432			BR	ACTM2X	
5305							
5306	031322	012737	000002	006570	ACTPAS: MOV	#PAS,MODTYP	:MODE = PASSIVE
5307	031330	105037	003146		CLRB	PSNNUF	:CLEAR NOT-ENOUGH FLAG
5308	031334	005037	006572		CLR	MLTYP	:CLEAR MAINT LOOP TYPE
5309	031340	000207			RTS	PC	
5310							
5311	031342	005037	006570		ACTREC: CLR	MODTYP	:MODE = RECEIVE
5312	031346	000417			BR	ACTM2X	
5313							
5314	031350	012737	000006	006570	ACTLIS: MOV	#LIS,MODTYP	:MODE = LISTEN
5315	031356	000413			BR	ACTM2X	
5316							
5317	031360	012737	000004	006570	ACTDLL: MOV	#DOW,MODTYP	:MODE = DOWNLINE LOAD
5318	031366	000407			BR	ACTM2X	
5319							
5320	031370	012737	000001	006570	ACTTRA: MOV	#TRA,MODTYP	:MODE = TRANSMIT
5321	031376	000403			BR	ACTM2X	
5322							
5323	031400	012737	000005	006570	ACTTAL: MOV	#TAL,MODTYP	:MODE = TALK
5324							
5325	031406	042737	000004	006576	ACTM2X: BIC	#ECHOB,PARAM	:DISABLE /ECHO (ALL BUT PASSIVE MODE)
5326	031414	105037	003146		CLRB	PSNNUF	:CLEAR NOT-ENOUGH FLAG
5327	031420	005037	006572		CLR	MLTYP	:CLEAR MAINT LOOP TYPE
5328	031424	000207			RTS	PC	
5329							

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 132
ACTION TABLE AND ROUTINES

5386	031704	005037	006572
5387	031710		
5388	031710	012746	011720
5389	031714	012746	000001
5390	031720	010600	
5391	031722	104417	
5392	031724	062706	000004
5393	031730	105037	003146
5394	031734	000207	
5395			

CLR MLTYP
PRINTF #CLIBDL

;CLEAR ANY LOOP TYPE THAT MAY HAVE GOT SET

MOV	#CLIBDL,-(SP)
MOV	#1,-(SP)
MOV	SP,R0
TRAP	CSPNTF
ADD	#4,SP

ACTLXX: CLRB PSNUF
RTS PC

;CLEAR NOT-ENOUGH FLAG

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 134
RECEIVE MODE SECTION

5446
5447
5448
5449
5450
5451
5452
5453
5454
5455
5456
5457
5458
5459
5460
5461
5462
5463
5464
5465
5466
5467
5468

.SBTTL RECEIVE MODE SECTION

..++
: FUNCTIONAL DESCRIPTION:
: RECEIVE-ONLY (OR ONE-WAY-IN) ROUTINE
: IN THIS MODE OF TESTING THE DEVICE'S RECEIVER IS ENABLED IN EXPECTATION
: OF RECEIVING A MESSAGE. AFTER RECEIVING AN 'EXPECTED' NUMBER OF
: MESSAGES, THE DATA RECEIVED CAN BE COMPARED AGAINST A LIST OF 'EXPECT
: TO RECEIVE' MESSAGES IF DATA-CHECKING IS ENABLED.

: SUBORDINATE ROUTINES USED:
: "ALLTR"

: CALLING SEQUENCE:
: JMP @MODE(R2) ;DISPATCH TO MODE BASED ON MODE TYPE IN R2

:--

032210
032210 013737 006440 006522
032216 013737 006476 006474
032224 052737 000104 006602
032232 005037 006524
032236 000137 032400

RXONLY:
RXON2: MOV RXPTR,CPTRR
MOV RXMTOT,DVRCT ;SET UP MESSAGE COUNT
BIS #QRX+#ERX,FLAG ;SET UP RX QUE
CLR CPTR ;CLEAR THE TX POINTER
JMP ALLTR ;GO RX.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 135
TRANSMIT MODE SECTION

5469
5470
5471
5472
5473
5474
5475
5476
5477
5478
5479
5480
5481
5482
5483
5484
5485
5486
5487
5488
5489
5490

.SBTTL TRANSMIT MODE SECTION

..++
: FUNCTIONAL DESCRIPTION:
: TRANSMIT-ONLY (OR ONE-WAY-OUT) ROUTINE
: IN THIS MODE OF TESTING A LIST OF MESSAGES IS TRANSMITTED WITHOUT
: EXPECTING ANY DATA TO BE RECEIVED. A REPETITION COUNT CAN BE
: SPECIFIED TO REPETITIVELY TRANSMIT THE LIST.

: SUBORDINATE ROUTINES USED:
: 'ALLTR'

: CALLING SEQUENCE:
: JMP @MODE(R2) ;DISPATCH TO MODE BASED ON MODE TYPE IN R2

:--

032242	042737	000002	006576	TXONLY: BIC	#DATCKB,PARAM	:SET NOCHECK
032250	013737	006442	006524	TXON2: MOV	TXPTR,CPTR	
032256	013737	006462	006460	MOV	TXMTOT,DVTCT	:COPY COUNTER FOR THIS PASS
032264	052737	000210	006602	BIS	#QTX+#ETX,FLAG	:SET THE QUE TX FLAG
032272	005037	006522		CLR	CPTR	:CLEAR RX POINTER
032276	000137	032400		JMP	ALLTR	:GO TX.

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 137
ACTIVE MODE SECTION

.SBTTL ACTIVE MODE SECTION

```

:++
: FUNCTIONAL DESCRIPTION:
: ACTIVE MODE SECTION
: IN THIS MODE OF TESTING A LIST OF MESSAGES IS TRANSMITTED AND
: MESSAGES ARE EXPECTED TO BE RECEIVED. RECEIVED DATA CAN BE COMPARED
: AGAINST 'EXPECTED' DATA IF DATA-CHECKING IS ENABLED.
: NOTE: IF BOTH ENDS OF THE LINK ARE IN ACTIVE MODE, THEN THE
: LINK MUST BE A FULL DUPLEX LINK!

```

: SUBORDINATE ROUTINES USED:

:"ALLTR"

: CALLING SEQUENCE:

```

:--
: JMP @MODE(R2) ;DISPATCH TO MODE BASED ON MODE TYPE IN R2

```

5516
5517
5518
5519
5520
5521
5522
5523
5524
5525
5526
5527
5528
5529
5530
5531
5532
5533
5534
5535 032336 013737 006462 006460
5536 032344 013737 006442 006524
5537 032352 013737 006476 006474
5538 032360 013737 006440 006522
5539 032366 052737 000314 006602
5540 032374 000137 032400
5541
5542
5543

```

ALCK: MOV TXMTOT,DVTCT ;# OF MESSAGES TO TRANSMIT(DEVICE TX COUNT)
      MOV TXPTR,CPTR ;SETUP TX MESSAGE LIST POINTER
      MOV RXMTOT,DVRCT ;# OF MESSAGES TO RECEIVE(DEVICE RX COUNT)
      MOV RXPTR,CPTRR ;SETUP RX MESSAGE LIST POINTER
      BIS #QRX+#QTX+#ETX+#ERX,FLAG
      JMP ALLTR

```


CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 149
LISTEN MODE SECTION

6006 034264 022737 052111 002522
6007 034272 001305
6008 034274 012737 000005 006570
6009 034302 000137 032142
6010
6011

CMP #'IT,OPBUF+2 ;IF FIRST HALF OK CHECK NEXT PART
BNE LISCKA ;IF NOT EXIT THE GO BACK
MOV #TAL,MODTYP ;CHANGE MODE TO TALK
JMP GTRX2 ;RETURN TO DISPATCHER

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 153
DEVICE INIT SUBROUTINE

6180 035130 004737 037010
6181 035134 042737 173777 006602
6182 035142 052737 002000 006602
6183 035150 000207
6184
6185

DVINEX: JSR PC,CLRTS ;CLEAR RTS IF NESC
BIC #173777,FLAG ;CLEAR FLAG WORD
BIS #INOV,FLAG ;SET THE INITT OVER FLAG
RTS PC ;RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 154
DEVICE GET MODEM STATUS SUBROUTINE

.SBTTL DEVICE GET MODEM STATUS SUBROUTINE

```

:++
: FUNCTIONAL DESCRIPTION:
:   'DVMODS' GET MODEM STATUS
:
: IMPLICIT INPUTS:
:   THE BIT POSITION AND AVAILABILITY OF THE MODEM SIGNALS CTS,DSR,...RI,..
:   FOUND IN THE DEPENDENT PORTION OF THE GLOBAL EQUATES SECTION.
:
: OUTPUTS:
:   CURRENT MODEM SIGNAL VALUES IN 'MODS'
:
: CALLING SEQUENCE:
:   JSR PC,DVMODS
:--

```

6186
6187
6188
6189
6190
6191
6192
6193
6194
6195
6196
6197
6198
6199
6200
6201
6202
6203
6204
6205
6206
6207
6208
6209
6210
6211

```

035152 017737 154272 007556 DVMODS: MOV @RXCSR,MODS ;READ MODEM STATUS
035160 042737 104761 007556 DVMEX: BIC #104761,MODS ;CLEAR BITS NOT RELATING TO MODEM
035166 000207 RTS PC ;RETURN TO CALLER

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 155
DEVICE QUEUE RECEIVE SPACE SUBROUTINE

.SBTTL DEVICE QUEUE RECEIVE SPACE SUBROUTINE

+++
FUNCTIONAL DESCRIPTION:
DVRXQ - THIS SUBROUTINE QUEUES THE RECIEVER BUFFER SPACE TO THE
DEVICE, THEN CLEARS THE QRX BIT OF THE FLAG WORD.
INPUTS:
DVRXA = ADDRESS OF RX BUFFER SPACE
DVRCC = BYTE CHAR COUNT OF RX BUFFER
QRX FLAG BIT = SET BY CALLING ROUTINE
OUTPUTS:
QRX FLAG BIT = CLEARED BY ROUTINE
CALLING SEQUENCE:
JSR PC,DVRXQ

6212
6213
6214
6215
6216
6217
6218
6219
6220
6221
6222
6223
6224
6225
6226
6227
6228
6229
6230
6231
6232
6233
6234
6235
6236
6237
6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249
6250

035170			
035170	032737	000004	006602
035176	001434		
035200	042737	000444	006602
035206	005737	011522	
035212	001415		
035214	052737	000440	006602
035222	013737	006470	011510
035230	012737	000072	011512
035236	012737	000070	006472
035244	000406		
035246	012737	002657	011510
035254	013737	002654	011512
035262	052777	000560	154160
035270	000207		

DVRXQ: BIT #QRX,FLAG ;ARE WE RECEIVING ?
BEQ DVREX ;NO,BRANCH
BIC #QRX+#BCC+#RXM,FLAG ;CLEAR FLAG FOR RX
TST RNODE ;ITEP MODE ?
BEQ DVRX2 ;NO,BRANCH
BIS #RXM+#BCC,FLAG ;GET JUST THE DATA NO CRC.
MOV DVRXA,RMSGPT ;RECEIVE DATA BUFFER ADDRESS
MOV #72,RMSGCC ;SET UP RX TO GET ITEP MSG.
MOV #70,DVRCC
BR DVRX3

;ENABLE RX, RX INTERRUPTS,AND DATA SET INTERRUPTS

DVRX2: MOV #RHDMRG+1,RMSGPT ;SETUP RX BUFFER ADDRESS
MOV HDMC,RMSGCC ;SETUP CHARACTER COUNT
DVRX3: BIS #RINTEN!RXENA!#DSITEN!#STRIP,@RXCSR ;ENABLE RECEIVER
DVREX: RTS PC ;RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST MACY11 30A(1052) 20-JUL-83 13:19 PAGE 159
 CZDCLB.P11 19-JUL-83 17:12 DEVICE INTERRUPT SERVICE ROUTINES

```

6405 035630 013737 011472 006542 RXIN2:  MOV    CMODS,TEMP3
6406 035636 013737 007556 006544      MOV    MODS,TEMP4
6407 035644 023737 006544 006542      CMP    TEMP4,TEMP3      ;COMPARE OLD TO CURRENT
6408 035652 001406                BEQ    10$               ;INC GLITCH COUNT
6409 035654 005237 011520                INC    MHRCNT            ;INC HARD COUNT
6410 035660 012737 016717 006540      MOV    #HRDMSG,TEMP2    ;SET UP HARD MESG.
6411 035666 000405                BR     RXIN1
6412 035670 005237 011516                10$:  INC    MGLCNT       ;INC GLITCH COUNT
6413 035674 012737 016671 006540      MOV    #GLMSG,TEMP2     ;SET UP GLITCH
6414 035702 004737 020336      RXIN1: JSR    PC,LOGMSC    ;GO LOG MODEM STATUS CHANGE
6415 035706 013737 011472 007556      MOV    CMODS,MODS       ;MOVE CURRENT TO OLD
6416
6417      ;
6418      ;TEST FOR DATA
6419 035714 032737 000200 011474      RXIN21: BIT   #RXDONE,IRXCSR ;RX DONE ?
6420 035722 001540                BEQ   RXINEX            ;NO,BRANCH
6421 035724 017737 153524 011476      MOV    @RXDBUF,IRXDBUF  ;READ DATA
6422 035732 032737 100000 011476      BIT   #RERR,IRXDBUF    ;OVERRUN ERROR ?
6423 035740 001055                BNE   RXIN3            ;YES,BRANCH
6424
6425      ;
6426      ;GET HERE WITH GOOD DATA
6427 035742 013702 011510                RXIN4: MOV    RMSGPT,R2    ;SET RX MESSAGE POINTER
6428 035746 113722 011476                MOVB  IRXDBUF,(R2)+     ;STORE DATA AWAY
6429 035752 010237 011510                MOV    R2,RMSGPT       ;SAVE UPDATED MESSAGE POINTER
6430
6431
6432 035756 005337 011512                DEC   RMSGCC            ;ALL DATA RECEIVED ?
6433 035762 001120                BNE   RXINEX            ;NO,BRANCH
6434 035764 032737 000400 006602      BIT   #BCC,FLAG        ;CHECK CRC ?
6435 035772 001426                BEQ   RXIN6            ;YES,BRANCH
6436 035774 032737 010000 011476      BIT   #CRCOK,IRXDBUF   ;CRC GOOD ?
6437 036002 001056                BNE   RXIN5            ;YES,BRANCH
6438 036004 013737 011476 006542      MOV    IRXDBUF,TEMP3    ;SET UP TO
6439 036012 013737 011474 006544      MOV    IRXCSR,TEMP4     ;:LOG AND
6440 036020 012737 017205 006540      MOV    #DVEM3,TEMP2    ;:PRINT CRC ERROR
6441 036026 004737 020162      JSR    PC,LGDVE         ;LOG ERROR
6442 036032 005237 006506      INC    ERRCNT           ;BUMP COUNT
6443 036036                ERRSOFT 8,DVEM3,ERR13  ;PRINT ERROR TO USER
6444 036036 104457
6445 036040 000010
6446 036042 017205
6447 036044 017636
6448
6449 036046 000463                BR     RXIN8           ;DISABLE INTERRUPTS AND EXIT
6450
6451      ;: IN ORDER TO CHECK CRC, WE MUST READ 2 MORE CHARACTERS(CRC)
6452 036050 052737 000400 006602      RXIN6: BIS   #BCC,FLAG    ;SET CRC ALREADY CHECKED FLAG
6453 036056 012737 000002 011512      MOV    #2,RMSGCC       ;COUNT TWO CHARACTERS
6454 036064 012737 011514 011510      MOV    #BCCW,RMSGPT    ;CRC STORAGE ADDRESS
6455 036072 000454                BR     RXINEX          ;EXIT
6456
6457
6458 036074                RXIN3: ;LOG OVERRUN ERROR
6459
6460 036074 012737 017246 006540      MOV    #DVEM4,TEMP2
    
```

TRAP CSERSOFT
 .WORD 8
 .WORD DVEM3
 .WORD ERR13

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 160
DEVICE INTERRUPT SERVICE ROUTINES

6461	036102	013737	011476	006542
6462	036110	013737	011474	006544
6463	036116	004737	020162	
6464	036122	005237	006506	
6465	036126			
6466	036126	104457		
6467	036130	000011		
6468	036132	017246		
6469	036134	017636		
6470	036136	000424		
6471				
6472	036140	032737	000040	006602
6473	036146	001020		
6474	036150	052737	000040	006602
6475	036156	042737	000400	006602
6476	036164	013737	006470	011510
6477	036172	013737	002660	011512
6478	036200	013737	002660	006472
6479	036206	000406		
6480				
6481	036210	052737	000004	006602
6482				
6483	036216	042777	000120	153224
6484				
6485	036224	012602		
6486	036226			
6487	036226			
6488	036226	000002		

```

MOV IRXDBUF,TEMP3
MOV IRXCSR,TEMP4
JSR PC,LGDVE
INC ERRCNT
ERRSOFT 9,DVEM4,ERR13

TRAP CSERSOFT
.WORD 9
.WORD DVEM4
.WORD ERR13

BR RXIN7

RXIN5: BIT #RXM,FLAG ;IS THE RX M BODY BIT SET
       BNE RXIN7 ;IF YES THEN ALL DONE
       BIS #RXM,FLAG
       BIC #BCC,FLAG ;CLEAR BCC AND SET RXM
       MOV DVRXA,RMSGPT ;MOVE ADDRESS TO POINTER
       MOV RHDACC,RMSGCC ;MOVE THE CHAR COUNT IN
       MOV RHDACC,DVRCC ;SET THE CC TO AMOUNT IN HEADER
       BR RXINEX ;AND FINISH.

RXIN7: BIS #QRX,FLAG ;SET MESSAGE RECEIVED IN FLAG

RXIN8: BIC #RINTEN+RXENA,@RXCSR ;CLEAR INTAND RX ENABLE

RXINEX: MOV (SP)+,R2 ;RESTORE R2
        ENDSRV

```

L10020: RTI

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 161
DEVICE TRANSMIT INTERRUPT ROUTINE

6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499
6500
6501
6502
6503
6504
6505
6506
6507
6508
6509
6510
6511
6512
6513
6514
6515
6516
6517
6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544

.SBTTL DEVICE TRANSMIT INTERRUPT ROUTINE

:+
: FUNCTIONAL DESCRIPTION:
: DEVICE TRANSMIT INT. ROUTINE

WHEN A TRANSMIT BUFFER EMPTY CAUSES AN INTERRUPT TO OCCUR
THE PROGRAM COMES TO THIS ROUTINE.
IF THE SYNC COUNT 'SYNCC' IS NON ZERO TSOM IS SET
A SYNC CHAR IS LOADED TO TXDBUF AND THE SYNC COUNT IS
DECREMENTED.

IF THE SYNC COUNT IS ZERO TSOM AND TEOM ARE RESET
AND THE 'PAD' BIT IN FLAG WORD IS CHECKED IF IT IS
SET THEN A PAD(377) CHAR IS LOADED TO TXDBUF AND TX
INTERRUPT ENABLE IS CLEARD.

IF THE SYNC COUNT IS ZERO AND THE 'PAD' FLAG IS
CLEAR THEN A BYTE IS PUT IN TXDBUF FROM THE ADDRESS
IN MSGPTR AND THE MSG COUNT IS DECREMENTED

IF THE MSG COUNT GOES TO ZERO THE 'TXM' BIT IS
CHECKED IF IT IS SET THE 'PAD' FLAG IS SET
IF IT IS CLEAR THEN IT GETS SET AND MSGPTR IS
LOADED WITH THE ADDRESS OF TXBUFF AND THE MSG
COUNT IS LOADED WITH THE COUNT OF THE MSG TO
BE TRANSMITTED.

INPUTS:
MSGPTR - IS SET TO THE ADDRESS OF THE MSG OR HEADER TO BE TX'D
MSGCC - IS SET TO THE COUNT OF MSG TO BE TX'D

OUTPUTS:
QTX - THIS BIT IS SET WHEN MSG IS TX'D OK.

036230		BGNSRV	DVTXI		DVTXI::
036230		MOV	R2, -(SP)		:SAVE R2
036230 010246		TST	SYNCC		:ANY SYNCs TO SEND
036232 005737 011504		BEQ	TXIN1		:IF NOT GO TO 1
036236 001406		MOV	SYNCC, @TXDBUF		:ELSE SET TSOM AND SYNC WORD
036240 013777 011506 153212		DEC	SYNCC		:DEC SYNC COUNT
036246 005337 011504		BNE	TXINEX		:IF NOT ZERO EXIT
036252 001065		BIT	#PAD, FLAG	TXIN1:	:IS THE PAD BIT SET
036254 032737 001000 006602		BEQ	TXIN2		:GO TO 2 IF NOT SET
036262 001414		MOV	#377, @TXDBUF		:LOAD FF TO TX DATA REG.
036264 012777 000377 153166		BIC	#TINTEN!SEND, @TXCSR		:CLEAR TX INT ENABLE
036272 042777 000120 153156		INC	TXREADY		:TELL PROTOCOL MODULE WE'RE DONE
036300 005237 037126		BIS	#QTX, FLAG		:SET THE TX COMPLETE
036304 052737 000010 006602		BR	TXINEX		:AND EXIT
036312 000445		TST	MSGCC	TXIN2:	:ALL DATA SENT ?
036314 005737 011502		BEQ	TXIN4		:YES, BRANCH
036320 001416		CLR	DATAWORD		:BE SURE ITS CLEAR
036322 005037 006556		MOV	MSGPTR, R2		:LOAD R2 WITH TX BUFFER POINTER ADDR.
036326 013702 011500		MOVB	(R2)+, DATAWORD		:PUT DATA IN LOW BYTE
036332 112237 006556		MOV	R2, MSGPTR		:RESTORE UPDATED POINTER
036336 010237 011500					

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 162
 DEVICE TRANSMIT INTERRUPT ROUTINE

6545	036342	013777	006556	153110		MOV	DATAWORD,@TXDBUF	;HI BYTE TSOM=0.. LO BYTE = DATA
6546	036350	005337	011502			DEC	MSGCC	;BUMP CHAR COUNT
6547	036354	000424				BR	TXINEX	:
6548	036356	012777	001000	153074	TXIN4:	MOV	#TEOM,@TXDBUF	;SEND CRC CHARACTER
6549	036364	032737	000020	006602		BIT	#TXM,FLAG	;IS THIS THE END OF DATA MSG.
6550	036372	001012				BNE	TXIN3	;IF SO SET THE PAD BIT
6551	036374	052737	000020	006602		BIS	#TXM,FLAG	;IF NOT MUST BE END OF HEADER
6552	036402	013737	006454	011500		MOV	DVTXA,MSGPTR	;SO SET UP MSGPTR FOR MSG
6553	036410	013737	006456	011502		MOV	DVTCC,MSGCC	;AND THE CC FOR MSG.
6554	036416	000403				BR	TXINEX	:
6555	036420	052737	001000	006602	TXIN3:	BIS	#PAD,FLAG	;SET THE PAD BIT
6556								
6557	036426	012602			TXINEX:	MOV	(SP)+,R2	;RESTORE R2
6558	036430					ENDSRV		
6559	036430							
6560	036430	000002						

L10021: RTI

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 163
DEVICE TRANSMIT CONTROL MSG

DEVICE TRANSMIT CONTROL MSG

6561
6562
6563
6564
6565
6566
6567
6568
6569
6570
6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609
6610
6611
6612
6613
6614
6615
6616

.SBTTL

..++

FUNCTIONAL DESCRIPTION:
THIS ROUTINE DOES THE FOLLOWING
QUES A RX SPACE AT RHMSG+1
QUES A TX MSG FROM HDMSG+1
CHECKS FOR A TIMER EXPIRED
IF EXPIRED RETURN TO CALLER
ELSE CHECK FOR A TX MSG COMPLETED
IF TX COMPLETED CHECK FOR RX COMPLETED
ELSE RECHECK TIMER AND TX COMPLETED UNTIL
EITHER TX COMPLETE OR TIME OUT
IF TX COMPLETE AND RX NOT COMPLETE THEN
REQUE TX MSG.
ELSE IF RX COMPLETE RETURN.

INPUTS:
TXM - SET IN FLAG WORD
HDMSG+2 - TYPE OF CONTROL MSG..

SUBORDINATE ROUTINES USED:
"CLRRTS" - CLEAR REQUEST TO SEND IF HALF DUP.

CALLING SEQUENCE:
JSR PC,DVIN31

RETURN:
RETURN TO CALLER IF SOMETHING RX'D OR TIMER OUT.

..--

DVIN31: BIC	#QRX!#BCC,FLAG	:	CLEAR RX COMPLETE & CRC ALREADY CHECK
MOV	#RHMSG+1,RMSGPT	:	SET UP POINTER
MOV	HDMC,RMSGCC	:	AND CC
BIS	#RINTEN!RXENA!DSITEN!STRIP,@RXCSR	:	TURN ON RX
:		:	SET UP TRANSMITTER TO SEND
DVIN32: JSR	PC,CTSSR	:	SET RTS
BIC	#QTX!PAD,FLAG	:	CLEAR TX COMPT FLAG.
MOV	#HDMSG+1,MSGPTR	:	MOVE THE CURRENT POINTER TO MSGPTR.
MOV	HDMC,MSGCC	:	
MOV	#8.,SYNCC	:	SET UP SYNC COUNT
BIS	#SEND!TINTEN,@TXCSR	:	TURN ON TX
:		:	NOW WAIT FOR TIME OUT OR TX COMPLETE
DVIN35: BREAK			
TST	TIMERS	:	IS IT TIMED OUT
BEQ	DVIN34	:	IF YES EXIT
BIT	#QTX,FLAG	:	IS TX DONE
BEQ	DVIN35	:	IF NOT GO BACK AND CK TIME OUT
JSR	PC,CLRRTS	:	CLEAR RTS IF HALF DUPLEX
MOV	#2000,TEMP1	:	WAIT FOR RX TO COMPLETE
		TRAP	CSBRK

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 164
DEVICE TRANSMIT CONTROL MSG

6617 036556 005337 006536
6618 036562 001375
6619 036564 032737 000004 006602
6620 036572 001733
6621 036574 000207
6622

DVIN36: DEC
 BNE
 BIT
 BEQ
DVIN34: RTS

TEMP1
DVIN36
#QRX, FLAG
DVIN32
PC

:BUMP COUNTER
:DO IT AGAIN
:DID WE RX ANYTHING
:IF NOT RETRANSMIT LAST
:RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 165
DEVICE RTS TO CTS DELAY

6623
6624
6625
6626
6627
6628
6629
6630
6631
6632
6633
6634
6635
6636
6637
6638
6639
6640
6641
6642
6643
6644
6645
6646
6647
6648
6649
6650
6651
6652
6653
6654
6655
6656
6657
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678

```

.SBTTL                DEVICE RTS TO CTS DELAY
:++
:  FUNCTIONAL DESCRIPTION:
:  CTSSR--THIS ROUTINE SETS DATA TERMINAL READY AND
:  REQUEST TO SEND TO THE MODEM AND CHECKS FOR
:  CLEAR TO SEND TO COME BACK.
:  IF CTS DOES NOT COME BACK BEFORE TIMER EXPIRES
:  AND ERROR IS REPORTED AND WE TRY AGAIN.
:  THE ROUTINE IS SKIPPED IF INTERNAL LOOP IS SET.
:
:  OUTPUTS:
:
:  SUBORDINATE ROUTINES USED:
:  CALLING SEQUENCE:  'LGDVE' - LOG DEVICE ERROR
:                     JSR PC,CTSSR
:--

```

```

036576 022737 000001 006572 CTSSR: CMP #1,MLTYP ;IS THIS TTL LOOP
036604 001500 BEQ DVTXR9 ;BR IF YES
;SET DTR,RTS AND WAIT FOR CTS
036606 032737 004000 006602 DVTXR3: BIT #FIRST,FLAG
036614 001014 BNE CTSS3 ;IF NOT FIRST TIME SKIP DELY
036616 012737 177777 006534 CTSS4: MOV #-1,TEMP
036624 005237 006534 CTSS4: INC TEMP
036630 104422 BREAK TRAP CSBRK
036632 005737 006534 TST TEMP
036636 001372 BNE CTSS4 ;IF NOT ZERO GO BACK
036640 052737 004000 006602 CTSS3: BIS #FIRST,FLAG ;SET FIRST FLAG.
036646 012737 001000 006642 CTSS3: MOV #1000,TIMER1 ;SET UP TIMER FOR 1000 TICKS
036654 005737 006574 CTSS3: TST FHDPLX ;FULL DUPLEX ?
036660 001012 BNE CTSS7 ;YES,BRANCH
036662 004737 035152 10$: CALL DVMOD; ;GET MODEM STATUS
036666 032737 010000 007556 CTSS3: BIT #DCD,;10DS ;CARRIER DETECTED?
036674 001404 BEQ CTSS7 ;NO,BRANCH
036676 005737 006642 CTSS3: TST TIMER1 ;TIME DONE ?
036702 001417 BEQ DVTXR4 ;YES,BRANCH
036704 000766 BR 10$ ;TRY AGAIN
036706 052777 000006 152534 CTSS7: BIS #DTR!RTS,@RXCSR ;SET REQUEST TO SEND AND
;DATA YERMINAL READY **JPB
036714 012737 001750 006642 DVTXR2: MOV #1000.,TIMER1 ;SET UP TIMER
036722 104422 DVTXR2: BREAK TRAP CSBRK
036724 032777 020000 152516 CTSS7: BIT #CTS,@RXCSR ;IS CLEAR TO SEND BACK
036732 001025 BNE DVTXR1 ;BR. IF CTS IS SET
036734 005737 006642 CTSS7: TST TIMER1 ;ELSE TEST IF TIME EXPIRED
036740 001370 BNE DVTXR2 ;BR IF TIME NOT EXPRIED.
;SET ERROR FOR NO CTS

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 166
DEVICE RTS TO CTS DELAY

```

6679
6680 036742 012737 017026 006540 DVTXR4: MOV #DVEM1,TEMP2
6681 036750 017737 152474 006542     MOV @RXCSR,TEMP3
6682 036756 017737 152474 006544     MOV @TXCSR,TEMP4
6683 036764 004737 020162           JSR PC,LGDVE
6684 036770 005237 006506           INC  ERRCNT
6685 036774                                ERRSOFT 6,DVEM1,ERR13
6686 036774 104457
6687 036776 000006
6688 037000 017026
6689 037002 017636
6690 037004 000700
6691 037006
6692 037006 000207
        BR      DVTXR3          ;THEN TRY TO SET RTS AGAIN
DVTXR1:
DVTXR9: RTS    PC              ;
    TRAP    CSERSOFT
    .WORD   6
    .WORD   DVEM1
    .WORD   ERR13
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 167
DEVICE CLEAR REQUEST TO SEND

6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712

037010
037010 005737 037132
037014 001003
037016 005737 006574
037022 001012
037024 017737 152426 006540
037032 032737 001000 006540
037040 001371
037042 042777 000004 152400
037050 000207

.SBTTL DEVICE CLEAR REQUEST TO SEND
:++
: FUNCTIONAL DESCRIPTION:
: THIS ROUTINE CLEARS REQUEST TO SEND IF
: IN HALF DUPLEX MODE OR MULTI-POINT.(WITH PROTOCOL)
: CALLING SEQUENCE:
: JSR PC,CLRRTS
:--

CLRRTS: TST MPPTP :MULTI-POINT ?
 BNE 20\$:YES,BRANCH
 TST FHDPLX :IS THIS FULL DUPLEX
 BNE DVTR5 :BRANCH IF YES
20\$: MOV @TXCSR,TEMP2 :GET RX STATUS
 BIT #TXACT,TEMP2 :ALL DATA SENT ?
 BNE 20\$:NO,WAIT
 BIC #RTS,@RXCSR :CLEAR REQUEST TO SEND
DVTR5: RTS PC :RETURN TO CALLER

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 168
 DEVICE CLEAR REQUEST TO SEND

6713
 6714
 6715
 6716
 6717
 6718
 6719
 6720
 6721
 6722
 6723
 6724
 6725
 6726
 6727 037052 000000
 6728
 6729
 6730
 6731
 6732
 6733
 6734
 6735
 6736
 6737
 6738
 6739
 6740 037054 000000
 6741 037056 000000
 6742
 6743 037060 000
 6744
 6745 037061 000
 6746
 6747
 6748 037062 000
 6749 037063 000
 6750
 6751 037064 000
 6752 037065 000
 6753
 6754
 6755 037066 000
 6756 037067 000
 6757
 6758 037070 000
 6759 037071 000
 6760
 6761 037072 000
 6762 037073 000

```

.SBTTL  DDCMP PROTOCOL MODULE
:*****
; DCLT  DDCMP PROTOCOL MODULE

.EVEN
;; LOCAL STORAGE

;; TABLE OF STATISTICS AND ERRORS
;;; NOTE: KEEP THE VARIABLES TOGETHER AND IN SEQUENCE
;;; OTHERWISE THE RPT> ROUTINE WILL PRINT WRONG INFO.

PRSTAT: .WORD 0                ;STATUS FLAGS
                                ;BIT0 = BCCOK
                                ;BIT1 = BCCBAD
                                ;BIT2 = SNAK
                                ;BIT3 = SACK
                                ;BIT4 = SDATA
                                ;SPARE
                                ;BIT6 = RXD
                                ;BIT7 = SPARE
                                ;BIT8 = NAKRX
                                ;BIT9 = MYDATA
                                ;BIT10 = SSTACK
                                ;BIT11 = SSTART
                                ;TOTAL DATA MESSAGES TRANSMITTED(16 BIT COUNTER)
                                ;TOTAL DATA MESSAGES RECEIVED(16 BIT COUNTER)

TMESTX: .WORD 0
TMESRX: .WORD 0

N:      .BYTE 0                ;# OF HIGHEST SEQUENTIAL DATA MESSAGE TRANS
                                ;: MMITTED BY THIS STATION
A:      .BYTE 0                ;# OF THE HIGHEST SEQUENTIAL DATA MESSAGE
                                ;: THAT HAS BEEN ACKNOWLEDGE TO THIS STATION

T:      .BYTE 0                ;# OF THE NEXT DATA MESSAGE TO BE TRANSMITTED
X:      .BYTE 0                ;LAST MESSAGE NUMBER TRANSMITTED

R:      .BYTE 0                ;LAST MESSAGE RECEIVED
TRIBN:  .BYTE 0                ;TRIB ADDRESS  PT TO PT = 1

;; ERROR COUNTERS
REMTMO: .BYTE 0                ;REMOTE REPLY TIMEOUTS(ACKS SENT NUM=R)
GLOBCC: .BYTE 0                ;GLOBAL CRC ERRORS

REANAK: .BYTE 0                ;REASON FOR LAST NAK SENT
SELTHER:.BYTE 0                ;SELECTION THRESHOLD ERROR

RXTHER: .BYTE 0                ;RECEIVE THRESHOLD ERRORS
TXTHER: .BYTE 0                ;TRANSMIT THRESHOLD ERRORS
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 169
DDCMP PROTOCOL MODULE

6763					
6764					
6765	037074	000	DEROUT: .BYTE 0		:DATA ERRORS OUTBOUND (NAKS RECEIVED
6766	037075	000	OUTMASK: .BYTE 0		: REASONS = 1,2,OR 3)
6767					: MASK VALUES -- BIT0 = HEADER CRC ERROR
6768					: -- BIT1 = DATA FIELD CRC ERROR
6769					: -- BIT2 = REP RESPONSE NUM<>R
6770					:
6771	037076	000	DERIN: .BYTE 0		:DATA ERRORS INBOUND (NAKS TRANSMITTED
6772	037077	000	INMASK: .BYTE 0		: REASONS = 1,2,OR 3)
6773					: MASK VALUES -- BIT0 = HEADER CRC ERROR
6774					: -- BIT1 = DATA FIELD CRC ERROR
6775					: -- BIT2 = REP RESPONSE NUM<>R
6776					:
6777	037100	000	LBUFER: .BYTE 0		:LOCAL BUFFER ERRORS (NAKS SENT
6778	037101	000	LBMASK: .BYTE 0		: REASONS = 8. OR 16.)
6779					: MASK VALUES -- BIT0 = BUFFER NOT AVAILABLE
6780					: -- BIT1 = MESSAGE TOO LONG
6781					:
6782	037102	000	RBUFER: .BYTE 0		:REMOTE BUFFER ERRORS (NAKS RECEIVED
6783	037103	000	RBMASK: .BYTE 0		: REASONS 8. OR 16.)
6784					: MASK VALUES -- BIT0 = BUFFER NOT AVAILBLE
6785					: -- BIT1 = MESSAGE TOO LONG
6786					:
6787	037104	000	RMSTER: .BYTE 0		:REMOTE STATION ERRORS (NAKS RECEIVED
6788	037105	000	RMMASK: .BYTE 0		: REASON 9. OR 17.)
6789					: MASK VALUES-- BIT0 = RECEIVER OVERRUN
6790					: BIT1 = FORMAT ERROR
6791					:
6792	037106	000	LOSTER: .BYTE 0		:LOCAL STATION ERRORS (NAKS SENT
6793	037107	000	LSMASK: .BYTE 0		: REASON 9. OR 17.)
6794					: MASK VALUES -- BIT0 = RECEIVER OVERRUN
6795					: -- BIT1 = FORMAT ERROR
6796					:
6797	037110	000000	RXTXTE: .WORD 0		:RX AND TX THRESHOLD ERRORS (OVERFLOWS)
6798	037112	000	SPARE0: .BYTE 0		
6799	037113	000	SPARE1: .BYTE 0		
6800	037114	000000	PROEND: .WORD 0		:END OF PROTOCOL COUNTERS
6801	037116	000000	IMFLAG: .WORD 0		: IMAGE OF MAIN CODE FLAG WORD
6802	037120	000000	RXPRC: .WORD 0		: -1 = MESSAGE RX'ED & 'ACK' SENT
6803	037122	000000	TXPRC: .WORD 0		: -1 = MESSAGE TX'ED & 'ACK' RECEIVED
6804	037124	000000	ASTRT: .WORD 0		: -1 = STACK SENT
6805	037126	000000	TXREADY: .WORD 0		: 1 = READY TO SEND ANOTHER MESSAGE
6806	037130	000000	PRUN: .WORD 0		: 1 = PROTOCOL RUNNING. USED IN THIS MODULE
6807	037132	000000	MPPTP: .WORD 0		: 1 = MULTI POINT NETWORK
6808	037134	000000	SELECT: .WORD 0		: 1 = THIS STATION CAN NOW TRANSMIT (HALF/DUPLEX)
6809	037136	000000	IMPRSTAT: .WORD 0		: COPY OF PROTOCOL STATUS WORD
6810	037140	000000	PRFLAG: .WORD 0		: USED TO COMMUNICATE WITH RX INTER. ROUTINE
6811	037142	000000	HDXMTP: .WORD 0		: 1 = HALF DUPLEX OR MULTI-POINT
6812	037144	000000	PRTEMP: .WORD 0		: TEMPORARY WORK LOCATION
6813	037146	000000	TURNON: .WORD 0		: 1 = RECEIVER IS ALREADY ON
6814	037150	000000	TIMEOUT: .WORD 0		: 20 = PRINT 'TX OR RX NOT COMPLETE'
6815					

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 170
DDCMP PROTOCOL MODULE

6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866

000001
000002
000003
000010
000011
000020
000021

000004
000001
000002
000002
000001

000201
000144
000005

000001
000002
000003
000006
000007

000001
000002
000004
000010
000020
000100
000400
001000
002000
004000

:: NAK REASONS VALUES AS USED IN NAK CONTROL MESSAGES

HEADBCC = 1 :HEADER BCC ERROR
DATABCC = 2 :DATA BCC ERROR
REPRESENT = 3 :REP RESPONSE
BUFFNA = 10 :BUFFER TEMPORARILY NOT AVAILABLE
RXOVRUN = 11 :RECEIVER OVERRUN
MESLONG = 20 :MESSAGE TOO LONG
FORMERR = 21 :HEADER FORMAT ERROR

:: ADDITIONAL NAK BIT MASKS AS USED IN COUNTERS

REPMSK = BIT2 :REPLY RESPONSE
RXOVMSK= BIT0 :RECEIVER OVERRUN
FMTMSK = BIT1 :FORMAT ERROR
MTLMSK = BIT1 :MESSAGE TOO LONG
BNAMSK = BIT0 :BUFFER NOT AVAILABLE

:: MESSAGE TYPE DEFINITIONS

SOH = 201 :DATA MESSAGE
MAINT = 144 :MAINTENANCE MESSAGE
ENQ = 5 :CONTROL MESSAGE

:: SUBTYPES OF CONTROL MESSAGES

ACK = 1 :ACKNOWLEDGE MESSAGE
NAK = 2 :NEGATIVE ACKNOWLEDGE MESSAGE
REP = 3 :REPLY TO MESSAGE NUMBER
STRT = 6 :START MESSAGE
STACK = 7 :START ACKNOWLEDGE MESSAGE

:: STATUS WORD BIT DEFINITIONS

BCCOK = BIT0 :BCC CHECKED GOOD
BCCBAD = BIT1 :BCC CHECKED BAD
SACK = BIT2 :SEND ACK
SNAK = BIT3 :SEND NAK
SDATA = BIT4 :SEND DATA
RXD = BIT6 :RECEIVER DONE
NAKRX = BIT8 :NAK RECEIVED
MYDATA = BIT9 :MY DATA
SSTACK = BIT10 :SEND START ACKNOWLEDGE
SSTART = BIT11 :SEND START

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 171
DDCMP PROTOCOL MODULE

6867
6868
6869
6870
6871
6872
6873
6874
6875
6876 037152 037262
6877 037154 037311
6878 037156 037347
6879 037160 037403
6880 037162 037475
6881 037164 037561
6882 037166 037641
6883 037170 037725
6884 037172 040007
6885 037174 040071
6886 037176 040166
6887 037200 040262
6888 037202 040360
6889 037204 040456
6890 037206 040544
6891 037210 040631
6892
6893
6894
6895
6896
6897
6898
6899 037212 021642
6900 037214 021642
6901 037216 021642
6902 037220 021670
6903 037222 021670
6904 037224 021670
6905 037226 021670
6906 037230 021670
6907 037232 021670
6908 037234 021726
6909 037236 021726
6910 037240 021726
6911 037242 021726
6912 037244 021726
6913 037246 021726
6914 037250 021642
6915
6916 037252 000000
6917 037254 000000
6918 037256 000000
6919 037260 000000
6920

```
*****
: THE BELOW TABLES AND ASCIZ MESSAGES ARE USED IN DCLT
: REPORTING OF ERROR COUNTERS. THEY MUST REMAIN IN THE
: CURRENT SEQUENCE ELSE WE'LL BE REPORTING ERRONEOUS
: DATA.
*****
```

```
STALST: .WORD STA0A      :POINTER FOR OFFSET 0 ASCII
        .WORD STA1A      :POINTER FOR OFFSET 1 ASCII
        .WORD STA2A      :POINTER FOR OFFSET 2 ASCII
        .WORD STA3A      :POINTER FOR OFFSET 3 ASCII
        .WORD STA4A      :POINTER FOR OFFSET 4 ASCII
        .WORD STA5A      :POINTER FOR OFFSET 5 ASCII
        .WORD STA6A      :POINTER FOR OFFSET 6 ASCII
        .WORD STA7A      :POINTER FOR OFFSET 7 ASCII
        .WORD STA10A     :POINTER FOR OFFSET 10 ASCII
        .WORD STA11A     :POINTER FOR OFFSET 11 ASCII
        .WORD STA12A     :POINTER FOR OFFSET 12 ASCII
        .WORD STA13A     :POINTER FOR OFFSET 13 ASCII
        .WORD STA14A     :POINTER FOR OFFSET 14 ASCII
        .WORD STA15A     :POINTER FOR OFFSET 15 ASCII
        .WORD STA16A     :POINTER FOR OFFSET 16 ASCII
        .WORD STA17A     :POINTER FOR OFFSET 17 ASCII
```

```
:TABLE FOR PRINT ROUTINES
:PRIW: WORD ROUTINE
:PRIWB: BYTE/BYTE ROUTINE
:PRIBS: BYTE SPECIAL ROUTINE
```

```
STAIND: .WORD PRIW
        .WORD PRIW
        .WORD PRIW
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIWB
        .WORD PRIBS
        .WORD PRIBS
        .WORD PRIBS
        .WORD PRIBS
        .WORD PRIBS
        .WORD PRIBS
        .WORD PRIW
```

```
LAST: .WORD 0      :LAST MESSAGE TO PRINT
FIR: .WORD 0      :FIRST MESSAGE TO PRINT
MES: .WORD 0      :HOLDS MESSAGE
MESDATA: .WORD 0  :DATA PART OF MESSAGE
```

6921
6922
6923
6924
6925
6926

: THE BELOW ASCII MESSAGES USED IN 'RPT>' LEVEL OF DCLT
:

037262	047045	047445	022466	.NLIST BEX	
037311	045	022516	033117	STA0A: .ASCII	/XN%06%S2%ASTATUS FLAGS/
037347	045	022516	033117	STA1A: .ASCII	/XN%06%S2%ADATA MSGS. TX'MITTD/
037403	045	022516	031517	STA2A: .ASCII	/XN%06%S2%ADATA MSGS. RX'CVD/
037475	045	022516	031517	STA3A: .ASCII	/XN%03%S5%AHIGHEST MSG # TX'D%N%03%S5%AHIGHEST MSG # ACK'D/
037561	045	022516	031517	STA4A: .ASCII	/XN%03%S5%ANEXT MSG # TO TX%N%03%S5%ALAST MSG # TX'D/
037641	045	022516	031517	STA5A: .ASCII	/XN%03%S5%AHIGHEST MSG # RX'D%N%03%S5%ATRIB ADDR/
037725	045	022516	031517	STA6A: .ASCII	/XN%03%S5%AREMOTE TIME OUTS%N%03%S5%AGLOBAL CRC ERRS/
040007	045	022516	031517	STA7A: .ASCII	/XN%03%S5%ANAK REASON%N%03%S5%ASELECT THRESH. ERRS/
040071	045	022516	031517	STA10A: .ASCII	/XN%03%S5%ARX THRESH ERRS%N%03%S5%ATX THRESH. ERRS/
040166	047045	047445	022463	STA11A: .ASCII	/XN%03%S5%ADATA ERRORS OUT%N%S8%AHBCC %01%A BCC %01%A REP %01/
040262	047045	047445	022463	STA12A: .ASCII	/XN%03%S5%ADATA ERRORS IN%N%S8%AHBCC %01%A BCC %01%A REP %01/
040360	047045	047445	022463	STA13A: .ASCII	/XN%03%S5%ALOCAL BUFFER ERRS%N%S8% NO BUFF %01%A TOO BIG %01/
040456	047045	047445	022463	STA14A: .ASCII	/XN%03%S5%AREMOTE BUFFER ERRS%N%S8% NO BUFF %01%A TOO BIG %01/
040544	047045	047445	022463	STA15A: .ASCII	/XN%03%S5%AREMOTE STA ERRS%N%S8%AQVRN %01%A FORMAT %01/
040631	045	022516	033117	STA16A: .ASCII	/XN%03%S5%ALOCAL STA ERRS%N%S8%AQVRN %01%A FORMAT %01/
				STA17A: .ASCII	/XN%06%S2%ATX & RX THRESHOLD ERRORS(OVERFLOW)/

.EVEN

.LIST BEX

6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 173
DDCMP PROTOCOL MODULE

6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994

```
*****
: PROTOCOL ROUTINE:
:
: DESCRIPTION: IF THE USER SPECIFIES THE '/PROTOCOL' SWITCH THIS
: ROUTINE WILL BE CALLED. THIS ROUTINE DECIDES IF
: WE ARE TRANSMITTING AND/OR RECEIVING AND CALLS
: THE NECESSARY ROUTINES.
: THIS CODE WAS WRITTEN ONLY TO BE USED WITH DCLT.
:
:*****
```

```

040706 013737 006602 037116 PROTOC: MOV     FLAG,IMFLAG    ;SAVE COPY OF MAIN CODE 'FLAG' VARIABLE
040714 012737 000001 037126      MOV     #1,TXREADY    ;INIT TRANSMITTER DONE FLAG
040722 005037 037120          CLR     RXPRC         ;INIT RX PROCOTOL DONE
040726 005037 037122          CLR     TXPRC         ;INIT TX PROCOTOL DONE
040732 005037 037150          CLR     TIMEOUT       ;INIT PRINT TIMER
040736 032737 000100 006576      BIT     #PRORUN,PARAM ;PROTOCOL RUNNING ?
040744 001067          BNE     7$           ;YES,BRANCH

:: PROTOCOL NOT RUNNING -- SO FIRE UP THE LINK
   SETVEC  INVEC,#PRRXI,#PRIOS    ;LOAD RX PROTOCOL INTERRUPT ROUTINE
                                         MOV     #PRIOS,-(SP)
                                         MOV     #PRRXI,-(SP)
                                         MOV     INVEC,-(SP)
                                         MOV     #3,-(SP)
                                         TRAP   CSSVEC
                                         ADD     #10,SP

040746          012746 000240          CLR     HDXMTP        ;INIT HALF DUPLEX/MULTI-POINT FLAG
040752          012746 044510          TST     FHDPLX        ;HALF DUPLEX ?
040756          013746 011462          BEQ     2$           ;YES,BRANCH
040762          012746 000003          TST     MPPTP         ;MULTI POINT ?
040766          104437          BEQ     3$           ;NO,BRANCH
040770          062706 000010          MOV     #1,HDXMTP     ;SET HALF DUPLEX/MULTI-POINT
040774          005037 037142          2$:  MOV     #30,.TIMERS ;30 SECONDS TO START
041000          005737 006574          3$:  MOV     #1,SELECT    ;INIT SELECT
041004          001403          CLR     TURNON        ;INIT YET ANOTHER FLAG
041006          005737 037132          CLR     PRUN          ;INIT ANOTHER FLAG
041012          001403          CLR     ASTRT         ;INIT 'STACK SENT' FLAG
041014          012737 000001 037142 2$:  CLR     PRSTAT        ;INIT STATUS WORD
041022          012737 000036 006646 3$:  JSR     PC,PROINT     ;INIT PROTOCOL COUNTERS AND VARIABLES
041030          012737 000001 037134          TST     MPPTP         ;MULTI - POINT MODE ?
041036          005037 037146          BNE     4$           ;YES,BRANCH
041042          005037 037130          BIS     #SSTART,PRSTAT ;TELL TX ROUTINE TO SEND 'START'
041046          005037 037124          JSR     PC,TXPROTO    ;GO SEND IT
041052          005037 037052          JSR     PC,RXPROTO    ;GO WAIT FOR 'STACK' OR 'START'
041056          004737 041734          BIT     #PRORUN,PARAM ;DID PROTOCOL START ?
041062          005737 037132          BEQ     3$           ;NO,TRY AGAIN
041066          001005          MOV     #1,PRUN       ;THIS FLAG USED IN RXPROTO ROUTINE
041070          052737 004000 037052          4$:  JSR     PC,PROINT     ;INIT PROTOCOL COUNTERS AND VARIABLES
041076          004737 045336          TST     HDXMTP        ;HALF DUPLEX OR MULTI - POINT?
041102          004737 042104          5$:  JSR     PC,PROINT     ;INIT PROTOCOL COUNTERS AND VARIABLES
041106          032737 000100 006576          BIT     #PRORUN,PARAM ;DID PROTOCOL START ?
041114          001742          BEQ     3$           ;NO,TRY AGAIN
041116          012737 000001 037130          MOV     #1,PRUN       ;THIS FLAG USED IN RXPROTO ROUTINE

:: IF HALF DUPLEX OR MULTI POINT, WE MUST MANAGE THE LINK DIFFERENTLY
041124          012737 000003 006646          6$:  MOV     #3,.TIMERS    ;SET UP TIMER
041132          005737 037142          TST     HDXMTP        ;HALF DUPLEX OR MULTI - POINT?

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 174
DDCMP PROTOCOL MODULE

```

6995 041136 001076             BNE      PROHDX             ;YES,BRANCH
6996
6997
6998 041140 022737 000003 006570  ;; IF FULL DUPLEX AND ACTIVE MODE-- JUMP
6999 041146 001440             CMP      #ACT,MODTYP       ;ACTIVE MODE?
7000                               BEQ      200$              ;YES, BRANCH
7001
7002                               ;; PROTOCOL IS RUNNING -- LINK IS HOT SO SEND DATA
7003 041150 032737 000010 037116 10$: BIT      #QTX,IMFLAG       ;TRANSMITTING A MESSAGE ?
7004 041156 001414             BEQ      100$              ;NO,BRANCH
7005 041160 052737 000020 037052 20$: BIS      #SDATA,PRSTAT     ;SEND DATA FLAG
7006 041166 004737 045336     CALL     TXPROTO           ;GO SEND THE MESSAGE
7007 041172 004737 042104     CALL     RXPROTO           ;CHECK THE REPLY
7008 041176 005737 037122     TST     TXPRC             ;MESSAGE TRANSMITTED & 'ACK'ED'?
7009 041202 001766             BEQ      20$              ;NO,BRANCH
7010 041204 005237 037054     INC     TMESTX            ;BUMP 'TOTAL MESSAGES TRANSMITTED' COUNTER
7011
7012 041210 005737 037120     100$: TST     RXPRC        ;RECEIVE PROTOCOL FINISHED ?
7013 041214 001011             BNE     110$             ;YES,BRANCH
7014 041216 032737 000004 037116  BIT     #QRX,IMFLAG       ;RECEIVING A MESSAGE ?
7015 041224 001002             BNE     105$             ;YES,BRANCH
7016 041226 000137 041674     JMP     PROTEX           ;EXIT
7017
7018
7019 041232 004737 042104     105$: CALL    RXPROTO       ;GO PROCESS INCOMING MESSAGE
7020 041236 000764             BR      100$             ;SEE IF RECEIVE PROTOCOL COMPLETE
7021 041240 005237 037056     110$: INC     TMESRX       ;BUMP 'TOTAL MESSAGES RECEIVED' COUNTER
7022 041244 000137 041674     JMP     PROTEX           ;EXIT
7023
7024
7025                               ;; ACTIVE MODE (FULL DUPLEX AND POINT TO POINT LINKS)
7026
7027 041250 004737 042000 037052 200$: CALL    RXON            ;TURN ON RECEIVER
7028 041254 052737 000020 210$: BIS      #SDATA,PRSTAT     ;SEND DATA FLAG
7029 041262 004737 045336     CALL    TXPROTO           ;DO SEND DATA MESSAGE
7030 041266 004737 042104     215$: CALL    RXPROTO           ;GO PROCESS INCOMING MESSAGE
7031 041272 005737 037122     TST     TXPRC             ;TX PROTOCOL DONE ?
7032 041276 001766             BEQ     210$             ;NO,BRANCH
7033 041300 005737 037120     TST     RXPRC             ;RX PROTOCOL DONE ?
7034 041304 001770             BEQ     215$             ;NO,BRANCH
7035 041306 005237 037056     INC     TMESRX           ;BUMP 'TOTAL MESSAGES RECEIVED'
7036 041312 005237 037054     INC     TMESTX           ;BUMP 'TOTAL MESSAGE SENT' COUNTER
7037
7038                               ;; TXREADY SET IN TX INTERRUPT ROUTINE
7039 041316 005737 037126 220$: TST     TXREADY       ;MESSAGE SENT ?
7040 041322 001775             BEQ     220$             ;NO,BRANCH
7041 041324 004737 042000     CALL    RXON            ;TURN ON RECEIVER
7042 041330 000137 041674     JMP     PROTEX           ;EXIT
7043
7044
7045                               ::: THIS ROUTINE(PROHDX) IS USE IN HALF-DUPLEX PT-PT & MTP
7046
7047 041334
7048 041334 005737 006574     PROHDX: 10$: TST     FHDPLX        ;FULL DUPLEX ?
7049 041340 001072             BNE     PROFDX           ;YES,BRANCH
7050 041342 032737 000010 037116  BIT     #QTX,IMFLAG       ;TRANSMITTING ?

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 175
DDCMP PROTOCOL MODULE

```

7051 041350 001424                BEQ    100$    ;NO,BRANCH
7052 041352 005737 037134         20$:  TST    SELECT  ;DO WE HAVE THE SELECT BIT ?
7053 041356 001005                BNE    30$    ;YES,BRANCH
7054 041360 004737 042000         CALL  RXON    ;TURN ON RX
7055 041364 004737 042110         25$:  CALL  RXWAIT ;TURN ON RX AND WAIT FOR SELECT BIT
7056 041370 000770                BR     20$    ;DID WE GET THE SELECT BIT ?
7057 041372 052737 000020 037052 30$:  BIS    #SDATA,PRSTAT ;SEND DATA FLAG
7058 041400 004737 045336         CALL  TXPROTO ;GO SENT IT
7059 041404 004737 042104         CALL  RXPROTO ;CHECK REPLY
7060 041410 005737 037122         TST    TXPRC  ;TX PROTOCOL DONE ?
7061 041414 001756                BEQ    20$    ;NO,BRANCH
7062 041416 005237 037054         INC    TMESTX ;BUMP TOTAL MESSAGES SENT
7063 041422 012737 000001 037122 100$:  MOV    #1,TXPRC ;SET TX PROTOCOL DONE
7064 041430 005737 037120         103$: TST    RXPRC  ;RX PROTOCOL DONE ?
7065 041434 001026                BNE    150$   ;YES,BRANCH
7066 041436 032737 000004 037116   BIT    #QRX,IMFLAG ;RECEIVING ?
7067 041444 001002                BNE    110$   ;YES,BRANCH
7068 041446 000137 041674         JMP    PROTEX ;EXIT
7069                  ;:WAS THE BALL TOSSED BACK IN OUR COURT ?
7070 041452 005737 037134         110$: TST    SELECT  ;HAVE WE RECEIVED THE SELECT BIT YET?
7071 041456 001005                BNE    130$   ;YES,BRANCH
7072 041460 004737 042000         CALL  RXON    ;TURN ON RECEIVER
7073 041464 004737 042110         115$: CALL  RXWAIT ;PROCESS DATA
7074 041470 000757                BR     103$   ;TRY AGAIN
7075 041472 052737 000004 037052 130$:  BIS    #SACK,PRSTAT ;SEND ACK TO TURN THE LINE AROUND
7076 041500 004737 045336         CALL  TXPROTO ;SEND IT
7077 041504 004737 042104         CALL  RXPROTO ;GO RECEIVE THE PENDING MESSAGE
7078 041510 000747                BR     103$   ;BRANCH
7079 041512 005237 037056         150$: INC    TMESRX ;BUMP 'RECIEVED MESSAGE COUNTER'
7080 041516 004737 042000         CALL  RXON    ;TURN ON RX
7081 041522 000137 041674         JMP    PROTEX ;EXIT
7082
7083                  ;:THIS ROUTINE(PROFDX:) USED WITH FULL DUPLEX-MULTI POINT LINKS
7084
7085 041526 032737 000010 037116  PROFDX: BIT    #QTX,IMFLAG ;TRANSMITTING ?
7086 041534 001003                BNE    10$    ;YES,BRANCH
7087 041536 012737 00C001 037122   MOV    #1,TXPRC ;SET TRANSMIT PROTOCOL COMPLETE
7088 041544 005737 037120         10$:  TST    RXPRC  ;WAS THE 1ST MESSAGE RX'ED DURING STARTUP?
7089 041550 001015                BNE    30$    ;YES,BRANCH
7090 041552 032737 000004 037116   BIT    #QRX,IMFLAG ;RECEIVING ?
7091 041560 001004                BNE    20$    ;YES,BRANCH
7092 041562 012737 000001 037120   MOV    #1,RXPRC ;SET RECEIVE PROTOCOL COMPLETE
7093 041570 000410                BR     100$   ;BRANCH
7094 041572 004737 042104         20$:  CALL  RXPROTO ;PROCESS INCOMING MESSAGE
7095 041576 005737 037120         TST    RXPRC  ;DONE ?
7096 041602 001773                BEQ    20$    ;NO,BRANCH
7097 041604 005237 037056         30$:  INC    TMESRX ;BUMP RX MESSAGE COUNT
7098 041610 000400                BR     100$   ;BRANCH
7099
7100 041612 005737 037122         100$: TST    TXPRC  ;ANYTHING TO SEND ?
7101 041616 001024                BNE    135$   ;NO,BRANCH
7102
7103 041620 005737 037134         120$: TST    SELECT  ;DO WE HAVE PERMISSION TO SEND ?
7104 041624 001005                BNE    130$   ;YES,BRANCH
7105 041626 004737 042000         CALL  RXON    ;TURN ON TX
7106 041632 004737 042110         125$: CALL  RXWAIT ;WAIT ON SELECT BIT

```


CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 178
DDCMP PROTOCOL MODULE

7175
7176
7177
7178
7179
7180
7181
7182
7183
7184
7185
7186
7187
7188
7189
7190
7191
7192
7193
7194
7195
7196
7197
7198
7199
7200
7201
7202
7203
7204
7205
7206
7207
7208
7209
7210
7211
7212
7213
7214
7215
7216
7217
7218
7219

042104
042104 004737 042000

042110
042110
042110 104422
042112 105737 002657
042116 001007
042120 005737 006646
042124 001371
042126 004737 043732
042132 000137 043730

042136 123727 002657 000005
042144 001003
042146 052737 000040 037140

042154 032737 000003 037052
042162 001021
042164 005737 006646
042170 001004
042172 004737 043732
042176 000137 042104

```

*****
RECEIVER PROTOCOL ROUTINE:

DESCRIPTION: THIS ROUTINE WILL PROCESS AN INCOMING MESSAGE
AND DETERMINE IF IT'S A VALID CONTROL OR DATA
MESSAGE. IF AN ERROR IS DETECTED THE APPROPRIATE
ERROR COUNTERS WILL BE UPDATED BY THE ERROR
ROUTINE.

SUBORDINATE ROUTINES USED: 'TXPROTO'
'ERROR PROCESSOR'
*****

RXPROTO:
CALL      RXON              ;TURN ON RECEIVER

;; WAIT FOR FIRST CHARACTER TO APPEAR IN RX BUFFER
RXWAIT:
20$:      BREAK              ;CHECK FOR ^C                                TRAP      CSBRK

TSTB     RHD MID            ;FIRST CHARACTER READ ?
BNE      30$                ;YES, BRANCH
TST      TIMERS             ;60 SECONDS ELAPSED ?
BNE      20$                ;NO, BRANCH
JSR      PC,ERRPRC         ;CALL ERROR PROCESSOR
JMP      RXPREX            ;EXIT

;; IF A CONTROL MESSAGE THEN TELL RX INTR. TO PROCESS HEADER ONLY
30$:     CMPB     RHD MID,#ENQ ;CONTROL MESSAGE ?
BNE      40$                ;NO, BRANCH
BIS      #RXM,PRFLAG        ;PROCESS HEADER ONLY

;; WAIT FOR CRC TO BE CHECKED
40$:     BIT      #BCCOK!BCCBAD,PRSTAT ;CRC CHECKED ?
BNE      50$                ;YES, BRANCH
TST      TIMERS             ;60 SECONDS ELAPSED ?
BNE      45$                ;NO, BRANCH
JSR      PC,ERRPRC         ;GO PROCESS ERROR
JMP      RXPROTO           ;TRY AGAIN

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 179
DDCMP PROTOCOL MODULE

```

7220
7221
7222
7223 042202 032737 000010 037052 45$:   BIT      #SNAK,PRSTAT  ;RX OVERRUN ?
7224 042210 001761                BEQ      40$           ;NO, BRANCH
7225 042212 004737 043732          JSR     PC,ERRPRC    ;GO PROCESS ERROR
7226 042216 004737 045336          JSR     PC,TXPROTO   ;GO SEND NAK
7227 042222 000137 042104          JMP     RXPROTO      ;TRY AGAIN
7228
7229 50$:   BIT      #BCCBAD,PRSTAT ;CRC ERROR ?
7230 042226 032737 000002 037052 BEQ      60$           ;NO, BRANCH
7231 042234 001430                BIS     #SNAK,PRSTAT ;SET SNAK (SEND NAK)
7232 042236 052737 000010 037052 BISB    #HEADBCC,INMASK ;SET THE MASK
7233 042244 152737 000001 037077 MOV     #HEADBCC,REANAK ;NAK REASON = 1
7234 042252 112737 000001 037070 INC     DERIN         ;LOG DATA ERROR INBOUND
7235 042260 105237 037076          BNE     55$           ;BRANCH IF NOT OVERFLOW
7236 042264 001003                MOV     #377,DERIN   ;LATCH COUNTER AT 255.
7237 042266 112737 000377 037076 55$:   JSR     PC,ERRPRC    ;GO PROCESS ERROR
7238 042274 004737 043732          MOV     #1,SELECT   ;IF HALF/DUPLEX, WE ASSUME S-BIT WAS SET
7239 042300 012737 000001 037134 JSR     PC,TXPROTO   ;GO SEND NAK
7240 042306 004737 045336          JMP     RXPROTO      ;TRY AGAIN
7241 042312 000137 042104
7242
7243 60$:   CMP     TRIBN,RHDADR     ;MESSAGE- IS IT FOR ME ?
7244 042316 123737 037065 002664 BEQ     70$           ;MY ADDRESS ?
7245 042324 001422                BEQ     70$           ;YES, BRANCH
7246
7247 62$:   BIC     #MYDATA,PRSTAT   ;MESSAGE NOT FOR ME
7248 042326 042737 001000 037052 BIT     #RXD,PRSTAT   ;RECEIVER DONE ?
7249 042334 032737 000100 037052 BNE     65$           ;YES, BRANCH
7250 042342 001003                TST     TIMERS       ;HAVE WE DAWDLED LONG ENOUGH ?
7251 042344 005737 006646          BNE     62$           ;NO, BRANCH
7252 042350 001366
7253
7254 65$:   BIT     #BCCOK,PRSTAT    ;DATA CRC OK ?
7255 042352 032737 000001 037052 BNE     67$           ;YES, BRANCH
7256 042360 001002                INC     GLOBCC       ;LOG GLOBAL CRC ERROR
7257 042362 105237 037067 67$:   JMP     RXPROTO      ;GO RE-QUE BUFFER
7258
7259
7260 70$:   CLRB    RXTHER          ;INIT RX THRESHOLD ERROR COUNTER
7261 042372 105037 037072 70$:   CMP     #ENQ,RHDMID   ;CONTROL MESSAGE ?
7262 042376 122737 000005 002657 BEQ     75$           ;YES, BRANCH
7263 042404 001402                JMP     200$         ;GO PROCESS DATA MESSAGE
7264 042406 000137 043256
7265
7266 75$:   CMP     #NAK,RHDTYP     ;NAK?
7267 042412 122737 000002 002660 BNE     90$           ;NO, BRANCH
7268 042420 001022                BIT     #PRORUN,PARAM ;PROTOCOL RUNNING ?
7269 042422 032737 000100 006576 BNE     80$           ;YES, BRANCH
7270 042430 001002                JMP     RXPROTO      ;IGNORE THIS MESSAGE
7271 042432 000137 042104 80$:   BIS     #NAKRX,PRSTAT ;FLAG NAK RECEIVED
7272 042436 052737 000400 037052 JSR     PC,ERRPRC    ;GO LOG NAK REASON
7273 042444 004737 043732          BIS     #SDATA,PRSTAT ;SEND DATA
7274 042450 052737 000020 037052
7275
    
```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 180
DDCMP PROTOCOL MODULE

7276 042456 004737 045336
7277 042462 000137 042104

JSR PC,TXPROTO
JMP RXPROTO

:GO RE-TRANSMIT PREVIOUS MESSAGE
:GO RE-QUE RX

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 181
DDCMP PROTOCOL MODULE

```

7278
7279
7280
7281 042466 122737 000001 002660 90$: CMPB #ACK,RHD TYP ;ACK ?
7282 042474 001057 BNE 100$ ;NO,BRANCH
7283 042476 032737 000100 006576 BIT #PRORUN,PARAM ;PROTOCOL RUNNING ?
7284 042504 001004 BNE 93$ ;YES,BRANCH
7285 042506 052737 000100 006576 BIS #PRORUN,PARAM ;TELL THE WORLD THAT LINK HAS STARTED
7286 042514 000445 BR 97$ ;EXIT
7287 042516 123737 037062 002662 93$: CMPB T,RHDREP ;CORRECT MESSAGE # ACKNOWLEDGED ?
7288 042524 001405 BEQ 95$ ;YES,BRANCH
7289 042526 005737 037142 TST HDXMTF ;HALF DUPLEX/MULTI -POINT ?
7290 042532 001036 BNE 97$ ;YES,BRANCH
7291 042534 000137 042104 JMP RXPROTO ;TRY AGAIN
7292 042540 105037 037073 95$: CLRB TXTHER ;INIT. TX THRESHOLD COUNTER
7293 042544 113737 037062 037060 MOVB T,N ;HIGHEST SEQUENTIAL MESSAGE # SENT
7294 042552 113737 037062 037063 MOVB T,X ;HIGHEST MESSAGE # SENT
7295 042560 113737 002662 037061 MOVB RHDREP,A ;HIGHEST MESSAGE # ACKNOWLEDGED TO THIS STATION
7296 042566 105237 037062 INCB T ;# OF NEXT DATA MESSAGE TO BE TRANSMITTED
7297 042572 012737 177777 037122 MOV #-1,TXPRC ;TRANSMIT PROTOCOL COMPLETE
7298 042600 022737 000003 006570 CMP #ACT,MODTYP ;ACTIVE MODE ?
7299 042606 001010 BNE 97$ ;NO,BRANCH
7300 042610 005737 037120 TST RXPRC ;RX PROTOCOL COMPLETE?
7301 042614 001005 BNE 97$ ;YES,BRANCH
7302 042616 005737 006574 TST FHDPLX ;HALF DUPLEX?
7303 042622 001402 BEQ 97$ ;YES,BRANCH
7304 042624 000137 042104 JMP RXPROTO ;GO PROCESS INCOMING MESSAGE
7305
7306 042630 000137 043730 97$: JMP RXPREX ;EXIT
7307
7308
7309 042634 122737 000003 002660 100$: CMPB #REP,RHD TYP ;REP ?
7310 042642 001054 BNE 150$ ;NO,BRANCH
7311
7312
7313 042644 032737 000100 006576 110$: BIT #PRORUN,PARAM ;PROTOCOL RUNNING ?
7314 042652 001002 BNE 110$ ;YES,BRANCH
7315 042654 000137 042104 JMP RXPROTO ;IGNORE MESSAGE- TRY AGAIN
7316 042660 123737 002663 037064 110$: CMPB RHDNUM,R ;HAVE WE RECEIVED THIS MESSAGE ?
7317 042666 001015 BNE 120$ ;NO, BRANCH
7318 042670 052737 000004 037052 BIS #SACK,PRSTAT ;SET SEND ACK
7319 042676 105237 037066 INCB REMTMO ;BUMP REMOTE TIME OUT COUNTER
7320 042702 001003 BNE 115$ ;BRANCH IF NOT OVERFLOW
7321 042704 112737 000377 037066 MOVB #377,REMTMO ;LATCH COUNTER AT 255.
7322 042712 004737 045336 115$: JSR PC,TXPROTO ;GO SEND ACK
7323 042716 000137 042104 JMP RXPROTO ;TRY AGAIN
7324
7325
7326 042722 052737 000010 037052 120$: BIS #SNAK,PRSTAT ;SET SEND NAK
7327 042730 112737 000003 037070 MOVB #REPSNT,REANAK ;SET REASON FOR NAK
7328 042736 105237 037076 INCB DERIN ;BUMP DATA ERROR INBOUND
7329 042742 001003 BNE 125$ ;BRANCH IF NOT OVERFLOW
7330 042744 112737 000377 037076 MOVB #377,DERIN ;LATCH AT 255.
7331 042752 152737 000004 037077 125$: BISB #REPMSK,INMASK ;ERROR REASON IS REMOTE TIME OUT
7332 042760 004737 045336 JSR PC,ERPPRC ;PROCESS NAK
7333 042764 004737 045336 JSR PC,TXPROTO ;GO SEND NAK

```

M 14

SEQ 181

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 182
DDCMP PROTOCOL MODULE

7334 042770 000137 042104

JMP RXPROTO

;TRY AGAIN

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 183
DDCMP PROTOCOL MODULE

```

7335
7336
7337
7338 042774 122737 000006 002660 150$: CMPB #STRT,RHD TYP ;START ?
7339 043002 001071 BNE 170$ ;NO,BRANCH
7340 043004 032737 000100 006576 BIT #PRORUN,PARAM ;PROTOCOL RUNNING ?
7341 043012 001007 BNE 160$ ;YES,BRANCH
7342 043014 052737 002000 037052 BIS #SSTACK,PRSTAT ;SEND START ACKNOWLEDGE
7343 043022 004737 045336 JSR PC,TXPROTO ;GO SEND STACK
7344 043026 000137 042104 JMP RXPROTO ;GO TO RX ROUTINE AND EXPECT ACK OR DATA
7345 ;: IF DMV OR DMP.
7346
7347 043032 052737 000200 006576 160$: BIS #ABORT,PARAM ;TELL MAIN CODE TO ABORT!!
7348 043040 012737 177777 037120 MOV #-1,RXPRC ;RECEIVE PROTOCOL DONE
7349 043046 012737 177777 037122 MOV #-1,TXPRC ;TRANSMIT PROTOCOL DONE
7350 043054 PRINTF #165$ ;FATAL ERROR
7351 043054 012746 043100 MOV #165$,-(SP)
7352 043060 012746 000001 MOV #1,-(SP)
7353 043064 010600 MOV SP,R0
7354 043066 104417 TRAP C$PNTF
7355 043070 062706 000004 ADD #4,SP
7356 043074 000137 043730 JMP RXPREX ;EXIT
7357
7358 043100 047045 040445 052123 .NLIST BEX
165$: .ASCIZ /%N%ASTART RECEIVED WITH PROTOCOL RUNNING--ABORTING!!/
.EVEN
.LIST BEX
7359
7360 ;: IS IT A STACK ? IF SO SEND AN 'ACK'
7361
7362 043166 122737 000007 002660 170$: CMPB #STACK,RHD TYP ;STACK ?
7363 043174 001012 BNE 180$ ;NO, BRANCH
7364 043176 052737 000004 037052 BIS #SACK,PRSTAT ;TELL TX ROUTINE TO SEND ACK
7365 043204 004737 045336 JSR PC,TXPROTO ;SEND ACK
7366 043210 052737 000100 006576 BIS #PRORUN,PARAM ;SET 'PROTOCOL RUNNING' FLAG
7367 043216 000137 043730 JMP RXPREX ;EXIT
7368
7369
7370 ;: IF WE GOT TO HERE, WE HAVE A STRANGE PROBLEM !
7371 043222 052737 000010 037052 180$: BIS #SNAK,PRSTAT ;SET SEND NAK FLAG
7372 043230 105237 037106 INCB LOSTER ;LOCAL STATION ERROR
7373 043234 152737 000021 037107 BISB #FORMERR,LSMASK ;FORMAT ERROR
7374 043242 004737 043732 JSR PC,ERRPRC ;PROCESS ERROR
7375 043246 004737 045336 JSR PC,TXPROTO ;SEND NAK
7376 043252 000137 042104 JMP RXPROTO ;TRY AGAIN
7377 ;: END OF CONTROL MESSAGE PROCESSOR
7378
7379
7380

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 184
DDCMP PROTOCOL MODULE

```

7381
7382
7383
7384
7385
7386 043256 005737 037120          200$:   TST      RXPRC      :ALREADY PROCESSED A MESSAGE?
7387 043262 001432                BEQ      215$          :NO,BRANCH
7388 043264 042737 001000 037052   BIC      #MYDATA,PRSTAT :TELL RX INTERRUPT NOT TO STORE THIS
7389 043272 005737 037122          TST      TXPRC      :TX PROTOCOL DONE ?
7390 043276 001037                BNE      220$          :YES,BRANCH
7391                                     :: SEE IF IMPLICIT ACK IMBEDDED IN THIS MESSAGE
7392 043300 123737 037062 002662   CMPB    T,RHDREP      :RESP=MESSAGE SENT?
7393 043306 001033                BNE      220$          :NO,BRANCH
7394 043310 113737 037062 037060   MOVB    T,N          :HIGHEST # SENT
7395 043316 113737 037062 037063   MOVB    T,X          :
7396 043324 113737 037062 037061   MOVB    T,A          :HIGHEST MESSAGE ACK'ED
7397 043332 105237 037062          INCB    T           :NEXT MESSAGE TO SEND
7398 043336 012737 177777 037122   MOV     #-1,TXPRC    :TX PROTOCOL DONE
7399 043344 000137 043730          JMP     RXPREX      :EXIT
7400                                     ::CHECK SEQUENCE OF MESSAGE
7401 043350 105237 037064          215$:   INCB    R           :EXPECTED #?
7402 043354 123737 037064 002663   CMPB    R,RHDNUM     :CORRECT MESSAGE #?
7403 043362 001423                BEQ     300$          :YES,PROCESS IT
7404 043364 105337 037064          DECB    R           :SUBTRACT 1
7405 043370 042737 001000 037052   BIC     #MYDATA,PRSTAT :JUST COUNT OUT MESSAGE-DON'T PUT IN BUFFER
7406 043376 032737 000100 037052 220$:   BIT     #RXD,PRSTAT  :WAIT FOR DONE
7407 043404 001003                BNE     250$          :BRANCH
7408 043406 005737 006646          TST     TIMERS      :TIME OUT?
7409 043412 001371                BNE     220$          :NO,BRANCH
7410
7411                                     ::SEND AN "ACK"
7412 043414 052737 000004 037052 250$:   BIS     #SACK,PRSTAT  :SEND ACK
7413 043422 004737 045336          CALL    TXPROTO     :GO SEND IT
7414 043426 000137 042104          JMP     RXPROTO     :TRY AGAIN
7415
7416                                     :: IS DATA PART OF MESSAGE COMPLETE ?
7417 043432 032737 000100 037052 300$:   BIT     #RXD,PRSTAT  :MESSAGE COMPLETE ?
7418 043440 001021                BNE     330$          :YES,BRANCH
7419
7420                                     :: IS THE LINE DEAD ?
7421 043442 005737 006646          TST     TIMERS      :TIMED-OUT ?
7422 043446 001004                BNE     305$          :NO,BRANCH
7423 043450 004737 043732          JSR     PC,ERRPRC   :GO PROCESS TIMER ERROR
7424 043454 000137 042104          JMP     RXPROTO     :TRY AGAIN
7425
7426                                     :: CHECK FOR RECEIVER OVERRUN OR BUFFER PROBLEM
7427 043460 032737 000010 037052 305$:   BIT     #SNAK,PRSTAT :DID RX INTERRUPT SET THIS ?
7428 043466 001761                BEQ     300$          :NO,BRANCH
7429
7430                                     ::RX ERROR SEND A NAK AND TRY AGAIN
7431 043470 004737 043732          JSR     PC,ERRPRC   :GO PROCESS ERROR
7432 043474 004737 045336          JSR     PC,TXPROTO  :SEND NAK
7433 043500 000137 042104          JMP     RXPROTO     :TRY AGAIN
7434
7435                                     ::CHECK FOR DATA CRC ERROR
7436 043504 032737 000001 037052 330$:   BIT     #BCCOK,PRSTAT :DATA CRC GOOD ?

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 185
DDCMP PROTOCOL MODULE

```

7437 043512 001022          BNE    400$      :YES,BRANCH
7438
7439
7440 043514 052737 000010 037052  :: LOG CRC ERROR AND SEND A NAK
7441 043522 105237 037076          BIS    #SNAK,PRSTAT :SET SEND NAK FLAG
7442 043526 001003          INCB   DERIN         :BUMP DATA ERROR INBOUND COUNTER
7443 043530 112737 000377 037076  BNE    340$         :BRANCH IF NOT OVERFLOW
7444 043536 152737 000002 037077 340$: MOVB  #377,DERIN     :LATCH AT 255.
7445 043544 004737 043732          BISB  #DATABCC,INMASK :SET DATA CRC BIT
7446 043550 004737 045336          JSR   PC,ERRPRC      :GO PROCESS ERROR
7447 043554 000137 042104          JSR   PC,TXPROTO     :GO SEND NAK
7448                      JMP    RXPROTO       :TRY AGAIN
7449
7450
7451 043560 032737 000100 006576  :: WE HAVE A GOOD MESSAGE !!! SO ACKNOWLEDGE IT
7452 043566 001007          400$: BIT    #PRORUN,PARAM :PROTOCOL RUNNING?
7453 043570 005737 037124          BNE    420$         :YES,BRANCH
7454 043574 001001          TST   ASTRT         :DID WE SEND A STACK?
7455 043576 000454          BNE    415$         :YES,BRANCH
7456                      BR     RXPREX         :EXIT
7457
7458 043600 052737 000100 006576  :: NOTE: DMV/DPM WILL SEND 'START - STACK - DATA' FOR STARTUP SEQUENCE
7459                      415$: BIS    #PRORUN,PARAM :SET PROTOCOL RUNNING
7460
7461 043606 123737 037062 002662  :: CHECK FOR AN IMPLICIT 'ACK'
7462 043614 001016          420$: CMPB  T,RHDREP   :RESP = MESSAGE SENT ?
7463 043616 113737 037062 037060  BNE    450$         :NO,BRANCH
7464 043624 113737 037062 037063  MOVB  T,N           :HIGHEST SEQ MESSAGE # SENT
7465 043632 113737 037062 037061  MOVB  T,X           :HIGHEST MESSAGE SENT
7466 043640 105237 037062          MOVB  T,A           :HIGHEST MESSAGE 'ACK'ED'
7467 043644 012737 177777 037122  INCB  T             :NEXT MESSAGE # TO TRANSMIT
7468 043652 052737 000004 037052 450$: MOV  #-1,TXPRC     :SET TRANSMIT PROTOCOL COMPLETE
7469 043660 004737 045336          BIS  #SACK,PRSTAT  :SET SEND ACK FLAG
7470 043664 012737 177777 037120  JSR  PC,TXPROTO     :SEND ACK
7471 043672 005737 037130          MOV  #-1,RXPRC     :RECEIVE MESSAGE PROTOCOL FINISHED
7472 043676 001414          TST  PRUN          :PROTOCOL RUNNING ?
7473 043700 005737 037142          BEQ  RXPREX        :NO,BRANCH
7474 043704 001011          TST  HDXMTP        :FULL DUPLEX PT-PT?
7475 043706 022737 000003 006570  BNE  RXPREX        :NO,BRANCH
7476 043714 001005          CMP  #ACT,MODTYP   :ACTIVE MODE ?
7477 043716 005737 037122          BNE  RXPREX        :NO,BRANCH
7478 043722 001002          TST  TXPRC         :TRANSMIT PROTOCOL COMPLETE ?
7479 043724 000137 042104          BNE  RXPREX        :YES,BRANCH
7480                      JMP  RXPROTO       :GO PROCESS MESSAGE
7481 043730 000207          RXPRES: RETURN     :DONE !!
7482

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 186
DDCMP PROTOCOL MODULE

7483
7484
7485
7486
7487
7488
7489
7490
7491
7492
7493
7494
7495
7496
7497
7498
7499
7500
7501
7502
7503
7504
7505
7506
7507
7508
7509
7510
7511
7512
7513
7514
7515
7516
7517
7518
7519
7520
7521
7522
7523
7524
7525
7526
7527
7528
7529
7530
7531
7532
7533
7534
7535
7536
7537
7538

043732 005737 006646
043736 001075
043740 032737 000100 006576
043746 001034

043750 005037 006542
043754 005037 006544
043760 012737 017313 006540
043766 113737 002660 006542
043774 113737 002646 006544
044002 004737 020162
044006 005237 006506
044012 104457
044014 000012
044016 017313
044020 017636
044022 005237 006502
044026 012737 000036 006646
044034 000137 044506

044040 005237 037150
044044 022737 000024 037150
044052 001023
044054 012737 017110 006540
044062 017737 145362 006542
044070 017737 145362 006544
044076 004737 020162
044102 005237 006506
044106 104457
044110 000007

ERROR PROCESSING ROUTINE (ERRPRC):

DESCRIPTION: THIS ROUTINE IS USED TO PROCESS INBOUND AND
OUTBOUND ERRORS. ALSO THE 60 SECOND 'WATCHDOG'
TIMER IS CHECKED.

THE MAJORITY OF THE CODE IS USED IN PROCESSING
OUTBOUND ERRORS (NAKS RECEIVED). THE NAK REASON
TYPE IS DETERMINED AND THE APPROPRIATE ERROR
COUNTER IN INCREMENTED. IF THE TRANSMIT THRESHOLD
COUNTER (TXTHER) REACHES 7, IT IS CLEARED
AND THE CUMULATIVE RECEIVE/TRANSMIT THRESHOLD
ERROR (RXTXTE) COUNTER IS BUMPED.

:::CHECK THE WATCHDOG TIMER
ERRPRC: TST TIMERS ;60 SECONDS ELAPSED
BNE 10\$;NO BRANCH
BIT #PRORUN,PARAM ;PROTOCOL RUNNING ?
BNE 7\$;YES BRANCH

::: INFORM USER OF 'START - STACK' TIMEOUT
CLR TEMP3 ;INIT IT
CLR TEMP4 ;INIT IT
MOV #DVEM5,TEMP2 ;'TIME OUT IN START-STACK SEQUENCE''
MOVB RDMCC,TEMP3 ;RECEIVED DATA
MOVB HDMCC,TEMP4 ;TRANSMITTED DATA
JSR PC,LGDVE ;LOG TIME OUT IN EVENT LOG
INC ERRCNT ;BUMP ERROR COUNT
ERRSOFT 10.,DVEM5,ERR13 ;PRINT ERROR

TRAP CSERSOFT
.WORD 10
.WORD DVEM5
.WORD ERR13

INC OPVAR ;BUMP ERROR COUNTER
MOV #30.,TIMERS ;RE-INIT TIMER
JMP ERREXT ;EXIT

::: INFORM USER OF 'DATA MESSAGE' TIMEOUT
7\$: INC TIMEOUT ;BUMP COUNTER
CMP #20.,TIMEOUT ;60 SECONDS ?
BNE 9\$;NO BRANCH
MOV #DVEM2,TEMP2 ;'TIME OUT WAITING FOR RX OR TX TO COMPLETE''
MOV @RXCSR,TEMP3 ;RECEIVER ADDRESS
MOV @TXCSR,TEMP4 ;TRANSMIT ADDRESS
JSR PC,LGDVE ;LOG ERROR
INC ERRCNT ;BUMP ERROR COUNT
ERRSOFT 7,DVEM2,ERR13 ;PRINT ERROR

TRAP CSERSOFT
.WORD 7

CZDCLB DUP-11 DATA COMM. LINK TEST
 CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 187
 DDCMP PROTOCOL MODULE

```

7539 044112 017110                      .WORD DVEM2
7540 044114 017636                      .WORD ERR13
7541 044116 005037 037150              CLR   TIMEOUT      ;INIT TIMEOUT
7542                                     ;
7543 044122 012737 000003 006646 9$:  MOV   #3.,TIMERS   ;SET UP TIMER
7544 044130 000566                          BR    ERREXT       ;EXIT
7545                                     ;
7546                                     ;
7547                                     ;
7548 044132 032737 000400 037052 10$:  ;:IF A 'NAK' RECEIVED THEN PROCESS IT
7549 044140 001542                          BIT   #NAKRX,PRSTAT ;NAK RECEIVED?
7550                                     BEQ   100$          ;NO,BRANCH
7551                                     ;
7552                                     ;:IF TRANSMIT THRESHOLD COUNTER = 7 THEN BUMP CUMULATIVE TXRX COUNTER
7553 044142 122737 000007 037073          CMPB  #7,TXTHR      ;THRESHOLD REACHED?
7554 044150 001403                          BEQ   20$          ;YES,BRANCH
7555 044152 105237 037073                  INCB  TXTHR        ;BUMP TRANSMIT THRESHOLD
7556 044156 000404                          BR    30$          ;BRANCH
7557 044160 005237 037110 20$:          INC   RXTXTE       ;BUMP TRANSMIT/RECEIVE THRESHOLD COUNTER
7558 044164 105037 037073                  CLRB  TXTHR        ;SET TRANSMIT COUNTER TO ZERO
7559                                     ;
7560                                     ;:
7561                                     ;:DETERMINE THE 'NAK' REASON
7562 044170 042737 140000 002660 30$:  ;:HEADER CRC ERROR ?
7563 044176 122737 000001 002661          BIC   #BIT15!BIT14,RHDTYP ;CLEAR SELECT & QS FLAG
7564 044204 001012                          CMPB  #HEADBCC,RHDTYP+1 ;HEADER CRC ERROR?
7565 044206 105237 037074                  BNE   35$          ;NO,BRANCH
7566 044212 001003                          INCB  DEROUT       ;LOG ERROR
7567 044214 112737 000377 037074          BNE   32$          ;BRANCH IF NOT OVERFLOW
7568 044222 152737 000001 037075 32$:  MOVB  #377,DEROUT  ;LATCH AT 255.
7569 044230 000526                          BISB  #HEADBCC,OUTMASK ;SET MASK
7570                                     BR    ERREXT       ;EXIT
7571                                     ;
7572 044232 122737 000002 002661 35$:  ;:DATA CRC ERROR ?
7573 044240 001012                          CMPB  #DATABCC,RHDTYP+1 ;DATA CRC ERROR ?
7574 044242 105237 037074                  BNE   40$          ;NO,BRANCH
7575 044246 001003                          INCB  DEROUT       ;LOG ERROR
7576 044250 112737 000377 037074          BNE   37$          ;BRANCH IF NOT OVERFLOW
7577 044256 152737 000002 037075 37$:  MOVB  #377,DEROUT  ;LATCH AT 255.
7578 044264 000510                          BISB  #DATABCC,OUTMASK ;SET MASK
7579                                     BR    ERREXT       ;EXIT
7580                                     ;
7581 044266 122737 000010 002661 40$:  ;:REMOTE STATION BUFFER NOT AVAILABLE?
7582 044274 001012                          CMPB  #BUFFNA,RHDTYP+1 ;BUFFER NOT AVAILABLE?
7583 044276 105237 037102                  BNE   45$          ;NO,BRANCH
7584 044302 001003                          INCB  RBUFER       ;LOG ERROR
7585 044304 112737 000377 037102          BNE   43$          ;BRANCH IF NOT OVERFLOW
7586 044312 152737 000001 037103 43$:  MOVB  #377,RBUFER  ;LATCH AT 255.
7587 044320 000472                          BISB  #BNAMSK,RBMASK ;SET MASK
7588                                     BR    ERREXT       ;EXIT
7589                                     ;
7590 044322 122737 000011 002661 45$:  ;:REMOTE STATION RECEIVER OVERRUN?
7591 044330 001012                          CMPB  #RXOVRUN,RHDTYP+1 ;RECEIVER OVERRUN?
7592 044332 105237 037104                  BNE   50$          ;NO,BRANCH
7593 044336 001003                          INCB  RMSTER       ;LOG ERROR
7594 044340 112737 000377 037104          BNE   47$          ;BRANCH IF NO OVERFLOW
7594 044340 112737 000377 037104          MOVB  #377,RMSTER  ;LATCH AT 255.

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 188
DDCMP PROTOCOL MODULE

```

7595 044346 152737 000001 037105 47$: BISB #RXOVMSK,RMMASK ;SET MASK
7596 044354 000454 BR ERREXT ;EXIT
7597
7598
7599 044356 122737 000020 002661 50$: CMPB #MESLONG,RHDTYP+1 ;MESSAGE TOO LONG?
7600 044364 001012 BNE 55$ ;NO,BRANCH
7601 044366 105237 037102 INCB RBUFER ;LOG REMOTE STATION BUFFER ERROR
7602 044372 001003 BNE 52$ ;BRANCH IF NO OVERFLOW
7603 044374 112737 000377 037102 MOVB #377,RBUFER ;LATCH AT 255.
7604 044402 152737 000002 037103 52$: BISB #MTLMSK,RBMASK ;SET MASK
7605 044410 000436 BR ERREXT ;EXIT
7606
7607
7608 044412 122737 000021 002661 55$: CMPB #FORMERR,RHDTYP+1 ;REMOTE STATION FORMAT ERROR?
7609 044420 001012 BNE 100$ ;NO,BRANCH
7610 044422 105237 037104 INCB RMSTER ;LOG ERROR
7611 044426 001003 BNE 57$ ;BRANCH IF NO OVERFLOW
7612 044430 112737 000377 037104 MOVB #377,RMSTER ;LATCH AT 255.
7613 044436 152737 000002 037105 57$: BISB #FMTMSK,RMMASK ;SET MASK
7614 044444 000420 BR ERREXT ;EXIT
7615
7616
7617
7618
7619 044446 032737 000010 037052 100$: BIT #SNAK,PRSTAT ;SEND NAK ?
7620 044454 001414 BEQ ERREXT ;NO, BRANCH
7621
7622 044456 122737 000007 037072 CMPB #7,RXTHER ;RECEIVER THRESHOLD = 7?
7623 044464 001403 BEQ 120$ ;YES,BRANCH
7624 044466 105237 037072 INCB RXTHER ;BUMP COUNTER
7625 044472 000405 BR ERREXT ;BRANCH
7626
7627 044474 005237 037110 120$: INC RXTXTE ;BUMP CUMULATIVE COUNTER
7628 044500 105037 037072 CLRB RXTHER ;INIT RECEIVER THRESHOLD COUNTER
7629 044504 000400 BR ERREXT ;EXIT
7630
7631
7632
7633 044506 000207 ERREXT: RETURN
7634

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 189
DDCMP PROTOCOL MODULE

.SBTTL RECEIVER PROTOCOL INTERRUPT ROUTINE

++
FUNCTIONAL DESCRIPTION:
THIS ROUTINE IS USED ONLY WHEN THE "/PROTOCOL" SWITCH IS SPECIFIED BY THE USER.

WHEN A RX INT. OCCURS THIS ROUTINE DECIDES IF IT IS A DATA SET CHANGE OR DATA INTERRUPT. IF IT IS A DATA SET CHANGE INTERRUPT IT PUTS THE STATUS IN "CMODS" AND COMPARES THAT STATUS TO THE OLD STATUS IN "MODS". IF THEY ARE THE SAME THAT MEANS THE INTERRUPT WAS CAUSED BY A GLITCH ON ONE OF THE LINES. IF THEY ARE DIFFERENT THEN A HARD MODEM ERROR HAS OCCURED. IN ANY EVENT THE MODEM STATUS CHANGE IS LOGGED.

IF A DATA INTERRUPT, THE ROUTINE CHECK FOR AN OVERRUN CONDITION AND IF SET

INPUTS:

RMSGPT - ADDRESS OF RX BUFFER
RMSCC - COUNT OF DATA TO BE RXED.

SUBORDINATE ROUTINES USED:

"LOGMSC" - LOG MODEM STATUS CHANGE
"LGDVE" - LOG DEVICE ERROR

7635
7636
7637
7638
7639
7640
7641
7642
7643
7644
7645
7646
7647
7648
7649
7650
7651
7652
7653
7654
7655
7656
7657
7658
7659
7660
7661
7662
7663
7664
7665 044510
7666 044510
7667 044510 010246
7668 044512 017737 144732 011474
7669 044520 032737 000010 006576
7670 044526 001453
7671 044530 032737 002000 037116
7672 044536 001447
7673 044540 032737 004000 037116
7674 044546 001443
7675 044550 005737 011474
7676 044554 100040
7677 044556 013737 011474 011472
7678 044564 042737 104761 011472
7679 044572 013737 011472 006542
7680 044600 013737 007556 006544
7681 044606 023737 006544 006542
7682 044614 001406
7683 044616 005237 011520
7684 044622 012737 016717 006540
7685 044630 000405
7686 044632 005237 011516
7687 044636 012737 016671 006540
7688 044644 004737 020336
7689 044650 013737 011472 007556
7690

BGNSRV PRRXI
PRIN2:
GLINC:
PRIN1:
PRRXI::
;SAVE R2
;MOV RX CSR TO IMAGE
;ANY MODEM CHANGES TO REPORT
;IF NOT IGNORE DS CHANGE.
;IS INIT OVER
;NO THEN IGNORE DS CHANGE.
;FIRST TIME HERE?
;YES,BRANCH
;DATA SET CHANGE ?
;IF DATA SET CHANGE IS NOT SET BR
;MOV THE NEW MODEM STATUS IN
;CLEAR BITS NOT RELATING TO MODEM STATUS
;COMPARE OLD TO CURRENT
;INC GLITCH COUNT
;INC HARD COUNT
;SET UP HARD MESG.
;INC GLITCH COUNT
;SET UP GLITCH
;GO LOG MODEM STATUS CHANGE
;MOVE CURRENT TO OLD

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 190
RECEIVER PROTOCOL INTERRUPT ROUTINE

```

7691      ;;TEST FOR DATA
7692
7693 044656 032737 000200 011474 PRIN21: BIT    #RXDONE,IRXCSR ;RX DONE ?
7694 044664 001002      10$      BNE    10$      ;YES,BRANCH
7695 044666 000137 045332      JMP    PRINEX  ;EXIT
7696 044672 017737 144556 011476 10$:  MOV    @RXDBUF,IRXDBUF ;READ DATA
7697 044700 032737 100000 011476  BIT    #RERR,IRXDBUF ;OVERRUN ERROR ?
7698 044706 001414      BEQ    PRIN4    ;NO,BRANCH
7699
7700      ;;IF AN OVERRUN THEN LOG ERROR,SET NAK REASON,TURN OFF RX & EXIT
7701 044710 052737 000010 037052  BIS    #SNAK,PRSTAT ;TELL MAIN CODE ABOUT OVERRUN ERROR
7702 044716 105237 037106      INCB  LOSTER    ;LOG LOCAL STATION ERROR
7703 044722 152737 000001 037107  BISB  #RXOVMSK,LSMASK ;SET RX OVERRUN MASK BIT
7704 044730 112737 000011 037070  MOVB  #RXOVRUN,REANAK ;SET REASON FOR SENDING NAK
7705 044736 000570      BR    PRIN8    ;GO TURN OFF RX AND EXIT
7706
7707
7708      :::IF IN MULTI-POINT MODE AND NOT MY ADDRESS THEN JUST BUMP CHAR COUNT
7709
7710      ;;STORE AWAY DATA
7711 044740 032737 001000 037052 PRIN4: BIT    #MYDATA,PRSTAT ;STORE THIS DATA ?
7712 044746 001406      BEQ    10$      ;NO,BRANCH
7713 044750 013702 011510      MOV    RMSGPT,R2 ;SET RX MESSAGE POINTER
7714 044754 113722 011476      MOVB  IRXDBUF,(R2)+ ;STORE DATA AWAY
7715 044760 010237 011510      MOV    R2,RMSGPT ;SAVE UPDATED MESSAGE POINTER
7716
7717      ;;DECREMENT CHARACTER COUNT
7718 044764 005337 011512 10$:  DEC    RMSGCC   ;ALL DATA RECEIVED ?
7719 044770 001160      BNE  PRINEX   ;NO,BRANCH
7720 044772 032737 000400 0_7140  BIT    #BCC,PRFLAG ;CHECK CRC ?
7721 045000 001410      BEQ  PRIN6   ;YES,BRANCH
7722 045002 032737 010000 011476  BIT    #CRCOK,IRXDBUF ;CRC GOOD ?
7723 045010 001016      BNE  PRIN5   ;YES,BRANCH
7724 045012 052737 000002 037052  BIS    #BCCBAD,PRSTAT ;TELL MAIN CODE ABOUT CRC ERROR
7725 045020 000537      BR    PRIN8   ;DISABLE INTERRUPTS AND EXIT
7726
7727      :::IN ORDER TO CHECK CRC, WE MUST READ 2 MORE CHARACTERS(CRC)
7728 045022 052737 000400 037140 PRIN6: BIS    #BCC,PRFLAG ;SET CRC ALREADY CHECKED FLAG
7729 045030 012737 000002 011512  MOV    #2,RMSGCC ;COUNT TWO CHARACTERS
7730 045036 012737 011514 011510  MOV    #BCCW,RMSGPT ;CRC STORAGE ADDRESS
7731 045044 000532      BR    PRINEX  ;EXIT
7732
7733 045046 052737 000001 037052 PRIN5: BIS    #BCCOK,PRSTAT ;TELL MAIN CODE CRC HAS BEEN CHECKED
7734 045054 123737 037065 002664  CMPB  TRIBN,RHDADR ;MY MESSAGE
7735 045062 001404      BEQ  5$      ;YES,BRANCH
7736 045064 042737 001000 037052  BIC    #MYDATA,PRSTAT ;DON'T STORE IT
7737 045072 000407      BR    7$      ;BRANCH
7738
7739 045074 032737 100000 002660 5$:  BIT    #BIT15,RHDMCC ;SELECT BIT SET?
7740 045102 001403      BEQ  7$      ;NO,BRANCH
7741 045104 012737 000001 037134  MOV    #1,SELECT ;WE NOW HAVE THE RIGHT TO TRANSMIT,IF HALF-DUPL
7742
7743 045112 032737 000040 037140 7$:  BIT    #RXM,PRFLAG  ;READ DATA MESSAGE ?
7744 045120 001071      BNE  PRIN7    ;NO,BRANCH
7745
7746      ;;SET UP TO READ IN DATA PART OF MESSAGE

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 191
RECEIVER PROTOCOL INTERRUPT ROUTINE

```

7747 045122 042737 000003 037052      BIC      #BCCOK!BCCBAD,PRSTAT ;CLEAR FLAGS (USED IN PROTOCOL CODE)
7748 045130 052737 000040 037140      BIS      #RXM,PRFLAG      ;SET DATA MESSAGE READ FLAG
7749 045136 042737 000400 037140      BIC      #BCC,PRFLAG      ;CLEAR CRC CHECKED FLAG(USED BY THIS ROUTINE)
7750 045144 042737 140000 002660      BIC      #BIT15!BIT14,RHDMCC ;CLEAR SELECT & QS BITS
7751
7752      ;;IS ALLOCATED BUFFER SPACE LARGE ENOUGH FOR MESSAGE?
7753 045152 023727 002660 001000      CMP      RHDMCC,#512.      ;WILL MESSAGE FIT IN ALLOCATED BUFFER?
7754 045160 003414                       BLE      10$               ;YES,BRANCH
7755
7756      ;;MESSAGE TOO LONG !! LOG ERROR
7757 045162 105237 037100      INCB    LBUFFER           ;LOG LOCAL BUFFER ERROR
7758 045166 152737 000002 037101      BISB    #MTLMASK,LBMASK   ;SET MESSAGE TOO LONG BIT
7759 045174 112737 000020 037070      MOVB    #MESLONG,REANAK   ;SET REASON FOR NAK
7760 045202 152737 000010 037052      BISB    #SNAK,PRSTAT      ;SET SEND NAK FLAG
7761 045210 000443      BR      PRIN8             ;TURN OFF RX & EXIT
7762
7763      ;; IF A NEW BUFFER IS AVAILABLE
7764      ;; SET BUFFER AND CHARACTER COUNT FOR MESSAGE
7765 045212 005737 037120      10$:    TST      RXPRC           ;NEW BUFFER AVAILABLE ?
7766 045216 001420      BEQ     15$               ;YES,BRANCH
7767 045220 105237 037100      INCB    LBUFFER           ;LOCAL BUFFER ERROR
7768 045224 001003      BNE     12$               ;OVERFLOW?
7769 045226 012737 000377 037100      MOV     #377,LBUFFER      ;LATCH A 255.
7770 045234 152737 000001 037101      12$:    BISB    #BNAMSK,LBMASK ;SET MASK
7771 045242 112737 000010 037070      MOVB    #BUFFNA,REANAK   ;SET NAK REASON
7772 045250 152737 000010 037052      BISB    #SNAK,PRSTAT      ;SET "SEND NAK FLAG"
7773 045256 000412      BR      PRIN7             ;EXIT
7774
7775 045260 013737 006470 011510      15$:    MOV     DVRXA,RMSGPT ;MESSAGE BUFFER ADDRESS
7776 045266 013737 002660 011512      MOV     RHDMCC,RMSGCC    ;CHARACTER COUNT OF MESSAGE
7777 045274 013737 002660 006472      MOV     RHDMCC,DVRCC    ;TELL MAIN CODE HOW LARGE MESSAGE IS
7778 045302 000413      BR      PRINEX           ;EXIT
7779
7780      ;;MESSAGE COMPLETE
7781 045304 052737 000004 037140      PRIN7:  BIS     #QRX,PRFLAG   ;SET MESSAGE COMPLETE FLAG(USED BY MAIN CODE)
7782 045312 052737 000100 037052      BIS     #RXD,PRSTAT      ;MESSAGE COMPLETE(USED BY PROTOCOL MODULE)
7783
7784 045320 005037 037146      PRIN8:  CLR     TURNON       ;RX NOT ON
7785 045324 042777 000120 144116      BIC     #RINTEN+RXENA,@RXCSR ;TURN OFF RECEIVER
7786
7787 045332 012602      PRINEX: MOV     (SP)+,R2     ;RESTORE R2
7788 045334      ENDSRV
7789 045334
7790 045334 000002      L1002:  RTI
7791
7792
7793

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 192
RECEIVER PROTOCOL INTERRUPT ROUTINE

7794
7795
7796
7797
7798
7799
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849

.SBTTL PROTOCOL TRANSMIT ROUTINE

```

:++
: FUNCTIONAL DESCRIPTION:
: THIS ROUTINE IS USED TO SETUP EITHER CONTROL MESSAGES OR
: DATA MESSAGES FOR TRANSMISSION.
: IF THE SEND ACK(SACK) IS SET AN 'ACK' MESSAGE WILL BE SETUP
: AND TRANSMITTED.
: IF THE SEND NAK(SNAK) IS SET A 'NAK' MESSAGE WILL BE SETUP
: AND TRANSMITTED.
: ELSE A DATA MESSAGE WILL BE SETUP AND SENT.
: IF THE NETWORK IS HALF-DUPLEX THEN REQUEST TO SEND(RTS) WILL
: BE ASSERTED BEFORE TRANSMISSION.

```

```

TXPROT: MOV PRSTAT,IMPRSTAT ;SAVE A COPY OF FLAGS
          BIT #PRORUN,PARAM ;PROTOCOL RUNNING ?
          BEQ 7$ ;NO,BRANCH
          CMP #ACT,MODTYP ;ACTIVE MODE?
          BNE 7$ ;NO,BRANCH
5$: TST TXREADY ;TRANSMITTER READY FOR MESSAGE ?
     BEQ 5$ ;NO,BRANCH

::IF HALF DUPLEX OR MULTI-POINT LINK, WE NEED THE SELECT BIT
::BEFORE WE CAN SEND.
7$: TST HDXMTP ;FULL DUPLEX AND PT TO PT ?
     BEQ 8$ ;YES,BRANCH
6$: TST SELECT ;OK TO SEND ?
     BNE 8$ ;YES,BRANCH
     CALL RXPROTO ;GO WAIT ON SELECT BIT
     BR 6$ ;TRY AGAIN

:: DETERMINE WHAT TO SEND
8$: MOV IMPRSTAT,PRSTAT ;RESTORE ORIGINAL FLAGS
     MOVB TRIBN,HDMADR ;SET TRIB ADDRESS
     BIC #PAD,FLAG ;THIS BIT USED IN TX INTER ROUTINE
     CLR TXREADY ;TRANSMITTER BUSY
     CLR SELECT ;IF HALF DUPLEX/MTP MODE
     BIT #SACK,PRSTAT ;SEND ACK ?
     BNE 10$ ;YES,BRANCH
     BIT #SNAK,PRSTAT ;SEND NAK ?
     BNE 50$ ;YES, BRANCH
     BIT #SSTART,PRSTAT ;SEND START ?
     BNE 60$ ;YES,BRANCH
     BIT #SSTACK,PRSTAT ;SEND START ACKNOWLEDGE ?
     BNE 70$ ;YES,BRANCH
     BIT #SDATA,PRSTAT ;SEND DATA MESSAGE ?
     BNE 100$ ;YES,BRANCH
     HALT ;FATAL ERROR

```

:: SETUP TO SEND AN 'ACK'

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 193
PROTOCOL TRANSMIT ROUTINE

```

7850 045520 052737 000020 006602 10$: BIS #TXM,FLAG ;SEND HEADER ONLY(USED IN TX INTER. ROUTINE)
7851 045526 112737 000005 002645 MOV #ENQ,HDMID ;CONTROL MESSAGE
7852 045534 012737 000001 002646 MOV #ACK,HDMTYP ;ACK CONTROL MESSAGE
7853 045542 052737 140000 002646 BIS #BIT15!BIT14,HDMTYP ;SET SELECT & QS FLAG
7854 045550 005737 037142 TST HDXMTYP ;HALF DUPLEX OR MULTI - POINT
7855 045554 001415 BEQ 20$ ;NO,BRANCH
7856 045556 005737 037122 TST TXPRC ;ANY THING TO SENT ?
7857 045562 001012 BNE 20$ ;NO,BRANCH
7858 045564 032737 000100 006576 BIT #PRORUN,PARAM ;PROTOCOL RUNNING?
7859 045572 001406 BEQ 20$ ;NO,BRANCH
7860 045574 042737 100000 002646 BIC #BIT15,HDMTYP ;CLEAR SELECT BIT
7861 045602 012737 000001 037134 MOV #1,SELECT ;WE HAVE SOMETHING TO SEND, SO KEEP THE LINE
7862 045610 113737 037064 002650 20$: MOV R,HDMREP ;SET RESPONSE NUMBER
7863 045616 105037 002651 CLRB HDMNUM ;FILLER
7864 045622 042737 000004 037052 BIC #SACK,PRSTAT ;CLEAR SEND ACK FLAG
7865 045630 000526 BR 200$ ;GO SEND IT
7866
7867
7868 :: SETUP TO SEND A 'NAK'
7869 045632 052737 000020 006602 50$: BIS #TXM,FLAG ;TELL TX INTERRUPT TO SEND HEADER ONLY
7870 045640 112737 000005 002645 MOV #ENQ,HDMID ;CONTROL MESSAGE
7871 045646 012737 000002 002646 MOV #NAK,HDMTYP ;'NAK'
7872 045654 113737 037070 002647 MOV REANAK,HDMTYP+1 ;REASON FOR NAK
7873 045662 052737 140000 002646 55$: BIS #BIT15!BIT14,HDMTYP ;SET SELECT & QS FLAGS
7874 045670 105037 002651 CLRB HDMNUM ;FILLER
7875 045674 113737 037064 002650 MOV R,HDMREP ;LAST MESSAGE RECEIVED CORRECTLY
7876 045702 042737 000010 037052 BIC #SNAK,PRSTAT ;CLEAR SEND NAK FLAG
7877 045710 000476 BR 200$ ;GO SEND IT
7878
7879
7880 :: SETUP TO SEND START MESSAGE
7881 045712 052737 000020 006602 60$: BIS #TXM,FLAG ;TELL TX INT. ROUTINE TO SEND HEADER ONLY
7882 045720 112737 000005 002645 MOV #ENQ,HDMID ;CONTROL MESSAGE
7883 045726 012737 000006 002646 MOV #STR,HDMTYP ;START MESSAGE
7884 045734 052737 140000 002646 BIS #BIT15!BIT14,HDMTYP ;SET SELECT & QS FLAGS
7885 045742 105037 002650 CLRB HDMREP ;FILLER
7886 045746 105037 002651 CLRB HDMNUM ;FILLER
7887 045752 042737 004000 037052 BIC #SSTART,PRSTAT ;CLEAR SEND START FLAG
7888 045760 000452 BR 200$ ;GO SEND IT
7889
7890 :: SETUP TO SEND STACK MESSAGE
7891 045762 052737 000020 006602 70$: BIS #TXM,FLAG ;TELL TX INT. TO SEND HEADER ONLY
7892 045770 112737 000005 002645 MOV #ENQ,HDMID ;CONTROL MESSAGE
7893 045776 012737 000007 002646 MOV #STACK,HDMTYP ;START ACKNOWLEDGE MESSAGE
7894 046004 052737 140000 002646 BIS #BIT15!BIT14,HDMTYP ;SET SELECT & QS FLAGS
7895 046012 105037 002650 CLRB HDMREP ;FILLER
7896 046016 105037 002651 CLRB HDMNUM ;FILLER
7897 046022 012737 177777 037124 MOV #-1,ASTRT ;START HAS BEEN ACKNOWLEDGED
7898 046030 042737 002000 037052 BIC #SSTACK,PRSTAT ;CLEAR SEND STACK FLAG
7899 046036 000423 BR 200$ ;GO SEND IT
7900
7901
7902 :: SETUP TO SEND DATA
7903 046040 042737 000020 006602 100$: BIC #TXM,FLAG ;TELL TX INTERRUPT TO SEND HEADER + DATA
7904 046046 112737 000201 002645 MOV #SOH,HDMID ;DATA MESSAGE
7905 046054 013737 006456 002646 MOV DVTCC,HDMCC ;CHARACTERS COUNT

```

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 194
PROTOCOL TRANSMIT ROUTINE

```

7906 046062 052737 140000 002646      BIS      #BIT15!BIT14,HDMCC ;SET SELECT & QS FLAGS
7907 046070 113737 037064 002650      MOVB     R,HDMREP      ;LAST MESSAGE RECEIVED CORRECTLY
7908 046076 113737 037062 002651      MOVB     T,HDMNUM      ;THIS MESSAGE NUMBER
7909 046104 000400             BR        200$         ;GO SEND IT
7910
7911      :: GO SET 'REQUEST TO SEND'
7912 046106 004737 036576 200$: JSR      PC,CTSSR      ;GO SET REQUEST TO SEND
7913 046112 052737 004000 037116      BIS      #FIRST,IMFLAG ;TELL THE CTSSR SUBROUTINE TO SKIP DELAY
7914
7915      :: SETUP TO TRANSMIT HEADER PORTION OF MESSAGE
7916 046120 012737 002645 011500 210$: MOV      #HDMID,MSGPTR ;HEADER MESSAGE ADDRESS
7917 046126 012737 000006 011502      MOV      #6,MSGCC      ;CHARACTER COUNT OF HEADER = 6
7918 046134 012737 000020 011504      MOV      #20,SYNCC     ;NUMBER OF SYNCS TO TRANSMIT
7919
7920      :: SEND THE DATA
7921 046142 005737 006574             TST      FHDPLX        ;FULL DUPLEX?
7922 046146 001004             BNE      215$         ;YES, BRANCH
7923 046150 052777 000130 143300      BIS      #SEND!TINTEN!HDPLX,@TXCSR ;ENABLE FOR HALF DUPLEX
7924 046156 000403             BR        217$         ;
7925
7926 046160 052777 000120 143270 215$: BIS      #SEND!#TINTEN,@TXCSR ;TURN ON TRANSMITTER
7927
7928
7929      :: IF ACTIVE MODE, TURN ON TX AND GET OUT IN A HURRY
7930      :: NOTE: START UP SEQUENCE OPERATES LIKE HALF-DUPLEX
7931
7932 046166 005737 037142 217$: TST      HDXMTD        ;FULL DUPLEX PT-PT?
7933 046172 001005             BNE      220$         ;NO, BRANCH
7934 046174 022737 000003 006570      CMP      #ACT,MODTYP   ;ACTIVE MODE ?
7935 046202 001001             BNE      220$         ;NO, BRANCH
7936 046204 000406             BR        TXPREX      ;EXIT
7937
7938 220$: BREAK
7939 046206 104422             TRAP      CSBRK
7940 046210 005737 037126             TST      TXREADY      ;TX FINISHED ?
7941 046214 001774             BEQ      220$         ;NO, BRANCH
7942
7943      :: IF HALF-DUPLEX OR MULTI-POINT REQUEST TO SEND WILL BE DROPPED
7944 046216 004737 037010 230$: JSR      PC,CLRRTS ;DROP RTS IF HALF DUPLEX
7945
7946 046222 000207      TXPREX: RETURN      ;WE ARE DONE !
7947
7948
7949      .EVEN
7950
7951      ENDTST
7952 046224
7953 046224 104401      L10017: TRAP      CSETST
7954
7955
7956
7957

```


CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 196
DEVICE DEPENDENT SECTION

8014 046306 000377
8015 046310
8016
8017 046310
8018
8019

ENDHWL: ENDHRD

.WORD TSHILIM

.EVEN

L10023:

.NLIST BEX

;DEVICE INDEPENDENT QUESTIONS

046310 052506 046114 042040 DPLX: .ASCIZ /FULL DUPLEX OPERATION : /

;DEVICE DEPENDENT QUESTION

046341 104 053105 041511 CSRADR: .ASCIZ /DEVICE CSR ADDRESS : /
046367 111 052116 051105 VECTOR: .ASCIZ /INTERRUPT VECTOR ADDRESS: /
046422 042522 047515 042524 RNODM: .ASCIZ /REMOTE NODE 'ITEP':/
046446 051511 052040 044510 PTPMLP: .ASCIZ /IS THIS A MULTIPOINT NETWORK:/
046504 042101 051104 051505 TRIBNQ: .ASCIZ /ADDRESS THIS STATION: /

.LIST BEX
.EVEN

8020
8021
8022

CZDCLB DUP-11 DATA COMM. LINK TEST
CZDCLB.P11 19-JUL-83 17:12

MACY11 30A(1052) 20-JUL-83 13:19 PAGE 197
DEVICE DEPENDENT SECTION

8023
8024
8025
8026
8027
8028
8029
8030
8031
8032
8033
8034
8035
8036
8037
8038
8039
8040
8041
8042
8043
8044
8045
8046
8047 046532
8048 046532 000030
8049
8050
8051 046612
8052
8053 046612 000000
8054 046614 000000
8055 046616
8056 046616
8057
8058 000001

:.SBTTL SOFTWARE PARAMETER CODING SECTION

:
:++
: THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

: BGNSFT

: ENDSFT

:::::::::::
: TEMPORARY PATCH AREA - FOR DEBUG PURPOSES
: ::::::::::

\$PATCH:
 .BLKW 30

LASTAD

LSLAST::
 ENDMOD

.END

.EVEN
.WORD 0
.WORD 0

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 211
CROSS REFERENCE TABLE -- USER SYMBOLS

NOD104	010654	2880#
NOD105	010672	2881#
NOD106	010676	2882#
NOD107	010710	2883#
NOD11	010000	2804#
NOD110	010714	2885#
NOD111	010730	2886#
NOD112	010734	2888#
NOD113	010750	2889#
NOD114	010754	2892#
NOD115	010760	2895#
NOD116	010774	2896#
NOD117	011000	2897#
NOD12	010012	2805#
NOD120	011016	2898#
NOD121	011022	2899#
NOD122	011036	2900#
NOD123	011042	2901#
NOD124	011056	2902#
NOD125	011062	2903#
NOD126	011076	2904#
NOD127	011102	2905#
NOD13	010016	2806#
NOD130	011116	2906#
NOD131	011122	2907#
NOD132	011136	2908#
NOD133	011142	2909#
NOD134	011162	2910#
NOD135	011166	2912#
NOD136	011172	2913#
NOD137	011176	2914#
NOD14	010032	2807#
NOD140	011202	2915#
NOD141	011206	2916#
NOD142	011212	2917#
NOD143	011216	2918#
NOD144	011220	2921#
NOD145	011224	2922#
NOD146	011230	2923#
NOD147	011244	2924#
NOD15	010036	2808#
NOD150	011250	2925#
NOD151	011264	2926#
NOD152	011270	2929#
NOD153	011274	2930#
NOD154	011300	2931#
NOD155	011304	2934#
NOD156	011310	2937#
NOD157	011332	2938#
NOD16	010052	2809#
NOD160	011336	2939#
NOD161	011352	2940#
NOD162	011356	2941#
NOD163	011400	2942#
NOD164	011404	2943#
NOD165	011426	2944#

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 212
CROSS REFERENCE TABLE -- USER SYMBOLS

NOD166	011432	2947#
NOD167	011436	2948#
NOD17	010056	2810#
NOD170	011442	2949#
NOD171	011446	2954#
NOD172	021032	3460#
NOD173	021036	3461#
NOD174	021042	3462#
NOD175	021044	3463#
NOD176	021060	3464#
NOD177	021062	3465#
NOD2	007724	2797#
NOD20	010062	2811#
NOD200	021076	3466#
NOD201	021100	3467#
NOD202	021112	3468#
NOD203	021114	3469#
NOD204	021134	3470#
NOD205	021140	3471#
NOD206	021144	3472#
NOD207	021160	3473#
NOD21	010074	2812#
NOD210	021162	3474#
NOD211	021176	3475#
NOD212	021200	3476#
NOD213	021216	3477#
NOD214	021222	3478#
NOD215	021226	3479#
NOD216	021230	3480#
NOD217	021232	3481#
NOD22	010100	2813#
NOD23	010112	2814#
NOD24	010116	2815#
NOD25	010120	2819#
NOD26	010124	2820#
NOD27	010140	2821#
NOD3	007726	2798#
NOD30	010144	2822#
NOD31	010162	2823#
NOD32	010166	2824#
NOD33	010204	2825#
NOD34	010210	2826#
NOD35	010226	2827#
NOD36	010232	2828#
NOD37	010250	2829#
NOD4	007742	2799#
NOD40	010254	2830#
NOD41	010300	2831#
NOD42	010304	2832#
NOD43	010310	2833#
NOD44	010326	2834#
NOD45	010332	2835#
NOD46	010344	2836#
NOD47	010350	2840#
NOD5	007744	2800#
NOD50	010354	2841#

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 215
CROSS REFERENCE TABLE -- USER SYMBOLS

OSPOIN= 000001	1959#	1972#	2063											
OSSETU= 000000	1959#	1991	7999											
PAD = 001000	2281#	6105	6254	6496	6519	6565	7779							
PARAM 006576	2663#	3312	3351	3561	4822*	4837*	4841	5166	5299*	5299*	5309*	5327*	5330*	
	5364	5449*	5563	5577	5580	5591	5596	5645	5689	5866*	5897	5934*	5949	
	6084	6361	6914	6944	7122	7223	7235	7237*	7265	7291	7298*	7317*	7401	
	7408*	7456	7617	7760	7805									
PARCSR 011452	2962#	4600*	4601*	6079*										
PAS = 000002	2213#	5270	5300	5616	5633									
PASC = 000042	2336#	2948												
PASMOD= 000030	2326#	2824												
PCADD 006562	2653#													
PCK 014014	3035#	4151												
PCLKCT= 001600	2230#	4539												
PCLKEN= 000111	2229#	4541												
PCPM 014655	3035#													
PEC 014024	3035#	4155												
PLCK 032302	2679	5473#												
PLCK2 032302	5474#													
PLCK3 032316	5476#													
PMS 014033	3035#	4165												
PNCK 014012	3035#	4154												
PNEC 014022	3035#	4158												
PNMS 014031	3035#	4168												
PNPR 014041	3035#	4163												
PNST 014001	3035#	4150												
PNT = 001000 G	2192#													
PPR 014043	3035#	4160												
PRFLAG 037140	6770#	7118*	7165*	7608	7676*	7691	7696*	7697*	7729*					
PRI = 002000 G	2193#													
PRI00 021670	3594#	6860	6861	6862	6863	6864	6865							
PRI01 021726	3607#	6866	6867	6868	6869	6870	6871							
PRI02 045332	7643	7667	7679	7726	7735#									
PRI03 044644	7633	7636#												
PRI04 044572	7627#													
PRI05 044656	7618	7620	7622	7624	7641#									
PRI06 044740	7646	7659#												
PRI07 045046	7671	7681#												
PRI08 045022	7669	7676#												
PRI09 045304	7692	7721	7729#											
PRI10 045320	7653	7673	7709	7732#										
PRI11 021642	3583#	6857	6858	6859	6872									
PRI12 = 000000 G	2181#	4647												
PRI13 = 000040 G	2180#													
PRI14 = 000100 G	2179#													
PRI15 = 000140 G	2178#													
PRI16 = 000200 G	2177#													
PRI17 = 000240 G	2176#	4632	4639	4831	6919									
PRI18 = 000300 G	2175#													
PRI19 = 000340 G	2016	2174#	4687											
PRNT = 000055	2347#	2800	4898	5095										
PROEND 037114	6760#	7099												
PROFDX 041526	7005	7041#												
PROHDX 041334	6951	7003#												
PROINT 041734	6938	7095#												
PRORUN= 000100	2240#	4837	6914	6944	7223	7235	7237	7265	7291	7317	7401	7408	7456	

CZDCLA DUP-11 DATA COMM. LINK TEST
 CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 220
 CROSS REFERENCE TABLE -- USER SYMBOLS

STXC 016550
 STXQ 016537
 SVCGBL= 000000

SVCINS= 000001

3035#	3289											
3035#	3284											
1959#	1978	1987	1989	1991	1993	1995	1997	1999	2001	2003	2005	2007
2009	2011	2013	2015	2017	2019	2021	2024	2027	2029	2031	2035	2035
2037	2039	2041	2043	2045	2047	2049	2051	2053	2055	2057	2059	2061
2073	2087	2088	3011	3021	3037	3054	3067	3081	3101	3120	3219	4448
4468	4484	4669	4683	4719	4741	6358	6489	7614	7919	8001#	8002	
1959#	1979	1980	1981	1982	1983	1984	1985	1986	1988	1990	1992	1994
1996	1998	2000	2002	2004	2006	2008	2010	2012	2014	2016	2018	2020
2022	2023	2025	2026	2028	2030	2032	2034	2036	2038	2040	2042	2044
2046	2048	2050	2052	2054	2056	2058	2060	2062	2072	2074	2086	3012
3014	3022	3027	3039	3040	3041	3042	3043	3044	3045	3046	3047	3048
3051	3056	3057	3058	3059	3060	3061	3064	3069	3070	3071	3072	3073
3074	3075	3078	3083	3084	3085	3086	3087	3088	3089	3092	3103	3104
3105	3106	3107	3108	3109	3112	3122	3123	3124	3125	3126	3127	3128
3129	3132	3135	3136	3245	3360	3361	3362	3363	3364	3368	3369	3370
3371	3372	3406	3407	3408	3409	3410	3417	3418	3419	3420	3421	3422
3423	3424	3434	3435	3436	3437	3438	3444	3445	3446	3447	3448	3503
3504	3505	3506	3507	3508	3550	3551	3552	3553	3554	3564	3565	3566
3567	3568	3584	3585	3586	3587	3588	3589	3595	3596	3597	3598	3599
3600	3601	3602	3603	3620	3621	3622	3623	3624	3625	3626	3627	3628
3629	3630	3631	3632	3649	3650	3651	3652	3653	3672	3673	3674	3675
3676	3682	3683	3684	3685	3686	3687	3688	3689	3690	3697	3698	3699
3700	3701	3702	3703	3711	3712	3713	3714	3715	3716	3718	3719	3720
3721	3722	3723	3724	3744	3745	3746	3747	3748	3749	3750	3751	3758
3759	3760	3761	3762	3763	3764	3765	3773	3774	3775	3776	3777	3778
3779	3780	3790	3791	3792	3793	3794	3795	3799	3800	3801	3802	3803
3819	3820	3821	3822	3823	3839	3840	3841	3842	3843	3877	3878	3879
3880	3881	3882	3887	3888	3889	3890	3891	3892	3893	3896	3897	3898
3899	3900	3901	3941	3942	3943	3944	3945	4136	4137	4138	4139	4140
4141	4142	4143	4144	4172	4173	4174	4175	4176	4177	4178	4179	4180
4181	4323	4324	4325	4326	4327	4366	4367	4368	4369	4370	4459	4491
4495	4496	4498	4500	4501	4503	4505	4506	4508	4511	4512	4514	4522
4523	4524	4526	4532	4533	4534	4536	4545	4547	4552	4553	4554	4555
4556	4557	4558	4559	4564	4565	4566	4567	4568	4586	4587	4588	4590
4622	4623	4624	4625	4626	4627	4632	4633	4634	4635	4636	4637	4639
4640	4641	4642	4643	4644	4647	4648	4650	4651	4658	4674	4687	4688
4699	4702	4703	4710	4723	4724	4731	4745	4746	4753	4783	4784	4785
4786	4787	4825	4826	4827	4828	4829	4831	4832	4833	4834	4835	4836
4845	4847	4851	4852	4861	4862	4863	4864	4865	4866	4867	4868	4878
4879	4880	4881	4882	4887	4888	4889	4890	4891	4911	4912	4924	4925
4926	4927	4928	4929	4939	4940	4941	4942	4943	4944	4965	4966	4967
4968	4969	4970	4981	4982	4983	4984	4985	4986	5081	5082	5083	5084
5085	5086	5153	5154	5155	5156	5157	5158	5159	5200	5201	5202	5203
5204	5230	5231	5232	5233	5234	5303	5304	5305	5306	5307	5352	5353
5354	5355	5356	5369	5370	5371	5372	5373	5713	5714	5715	5716	5731
5732	5733	5734	5744	5745	5746	5747	5787	5788	5789	5790	5839	5840
5841	5842	5843	5872	5873	5874	5875	5876	5877	5878	5879	5936	5937
5938	5939	5940	5963	5964	5965	5966	5967	6020	6031	6032	6033	6034
6069	6070	6071	6072	6075	6114	6137	6138	6139	6140	6278	6290	6291
6292	6293	6408	6409	6410	6411	6430	6431	6432	6433	6452	6524	6574
6617	6634	6648	6649	6650	6651	6919	6920	6921	6922	6923	6924	7153
7302	7303	7304	7305	7306	7468	7469	7470	7471	7486	7487	7488	7489
7738	7886	7900	7918	7925	7926	7927	7935	7936	7937	7938	7940	7941
7942	7943	7945	7946	7947	7949	7951	7952	7953	7955	7957	7958	7959
7960	7961	7963	7998	7999	8000							

CZDCLA DUP-11 DATA COMM. LINK TEST MACY11 30A(1052) 23-MAR-82 16:47 PAGE 222
 CZDCLA.P11 19-MAR-82 18:19 CROSS REFERENCE TABLE -- USER SYMBOLS

TRIBN	037065	4616*	4618*	6713#	7096	7101*	7197	7682	7778					
TRIBNQ	046504	7958	7966#											
TRVACT	024366	4236	4247#	4263	4268	4273	4276	4296	4362	4385	4406	4430		
TRVALN	025160	4225	4389#											
TRVALP	025114	4224	4375#											
TRVBIF	024472	4221	4276#											
TRVBR	024462	4220	4273#											
TRVBRC	024406	4234	4254#	4274	4279	4298	4372	4387	4408	4434				
TRVDEC	024566	4227	4301#											
TRVERR	024424	4218	4263#											
TRVEXI	024444	4219	4268#											
TRVNMA	024606	4302	4305#											
TRVNOB	024416	4259#	4280	4297	4363	4386	4407							
TRVNUM	024600	4223	4304#											
TRVOCT	024600	4226	4303#											
TRVSPA	024514	4222	4282#											
TRVSTR	025246	4228	4412#											
TSOM =	000400	2391#												
TTL =	000001	2220#	4853	6041										
TTL =	004000	2387#	6040	6043										
TTLLOP =	000044	2338#	2937											
TTOTCC	006464	2612#	4096	4795*	4920	4931	4954*	5126*						
TURNON	037146	6773#	6934*	7114	7127*	7732*								
TXACT =	001000	2385#	6670											
TXBUF	003150	2591#	4064	4805	5129									
TXC =	000002	2251#	3290											
TXCSR	011456	2964#	4604*	4605*	6013*	6016*	6027	6040*	6043*	6048*	6065	6110*	6273*	6286
		6499*	6569*	6644	6669	7482	7870*	7873*						
		2965#	4606*	4607*	6493*	6498*	6509*	6512*						
TXDBUF	011460	2386#												
TXDONE =	000200	6495	6502	6511	6518	6521#								
TXINEX	036426	6492	6495#											
TXIN1	036254	6497	6503#											
TXIN2	036314	6514	6519#											
TXIN3	036420	6504	6512#											
TXIN4	036356	2275#	6091	6254	6258	6513	6515	7797	7816	7828	7838	7850		
TXM =	000020	2611#	4084	4811*	4933*	4935	4956*	5121	5125*	5366	5451	5474	5499	
TXMTOT	006462	2678	5449#											
TXONLY	032242	5450#												
TXON2	032250	6763#	6912*	6964	6987	7016	7019*	7043*	7056	7067	7249*	7300*	7339	7348*
TXPRC	037122	7417*	7427	7803										
		7883	7893#											
TXPREX	046222	6942	6962*	6985*	7014*	7032*	7065*	7179	7193	7229	7274	7285	7294	7316
TXPROT	045336	7326	7363*	7382	7396	7419	7759#							
		2602#	4077*	4079*	4080	4089*	4091	4798*	4809	4934*	4948*	4949	4953*	5127*
TXPTR	006442	5128	5378*	5450	5475	5500								
		2250#	3285											
TXQ =	000000	6500*	6765#	6910*	6995	7764	7780*	7887						
TXREAD	037126	6723#	7244*	7501	7503*	7506*								
TXTHER	037073	1979#	1980#	1981#	1982#	1983#	1984#	3039#	3048	3056#	3061	3069#	3075	3083#
TSARGC =	000001	3089	3103#	3109	3122#	3129	3360#	3364	3368#	3372	3406#	3410	3434#	3438
		3444#	3448	3503#	3508	3550#	3554	3564#	3568	3584#	3589	3595#	3603	3620#
		3632	3649#	3653	3672#	3676	3682#	3690	3697#	3703	3711#	3716	3718#	3724
		3744#	3751	3758#	3765	3773#	3780	3790#	3795	3799#	3803	3819#	3823	3839#
		3843	3877#	3882	3887#	3893	3896#	3901	3941#	3945	4136#	4144	4172#	4181
		4323#	4327	4366#	4370	4564#	4568	4783#	4787	4825#	4829	4878#	4882	4887#

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 224
CROSS REFERENCE TABLE -- USER SYMBOLS

TSSINI= 010012	4484#	4650	4657										
TSSMSG= 010006	3037#	3050	3054#	3063	3067#	3077	3081#	3091	3101#	3111	3120#	3131	3135
TSSPRO= 010011	4468#												
TSSRPT= 010010	4448#	4458											
TSSSRV= 010022	3219#	3244	6358#	6451	6489#	6523	7614#	7737					
TSSRES= 010017	4769#	4851	4911	7899									
T1 026342 G	2074	4768#											
UAM = 000200 G	2190#												
UPTABL 032610	5591#												
UPTA1 032676	5597	5604#											
UPTA3 032674	5601	5603#											
UPTA4 032634	5592	5596#											
UPTEX 032746	5603	5615#											
VECTOR 046367	7941	7966#											
X 037063	6710#	7246*	7345*	7414*									
XS = 000220	1962#	2795#	2796#	2797#	2798#	2799#	2800#	2801#	2802#	2803#	2804#	2805#	2806#
	2807#	2808#	2809#	2810#	2811#	2812#	2813#	2814#	2815#	2819#	2820#	2821#	2822#
	2823#	2824#	2825#	2826#	2827#	2828#	2829#	2830#	2831#	2832#	2833#	2834#	2835#
	2836#	2840#	2841#	2842#	2843#	2844#	2849#	2850#	2851#	2852#	2853#	2856#	2857#
	2858#	2859#	2860#	2861#	2862#	2863#	2866#	2867#	2868#	2869#	2870#	2871#	2874#
	2875#	2876#	2877#	2879#	2880#	2881#	2882#	2883#	2885#	2886#	2888#	2889#	2892#
	2895#	2896#	2897#	2898#	2899#	2900#	2901#	2902#	2903#	2904#	2905#	2906#	2907#
	2908#	2909#	2910#	2912#	2913#	2914#	2915#	2916#	2917#	2918#	2921#	2922#	2923#
	2924#	2925#	2926#	2929#	2930#	2931#	2934#	2937#	2938#	2939#	2940#	2941#	2942#
	2943#	2944#	2947#	2948#	2949#	2954#	3460#	3461#	3462#	3463#	3464#	3465#	3466#
	3467#	3468#	3469#	3470#	3471#	3472#	3473#	3474#	3475#	3476#	3477#	3478#	3479#
	3480#	3481#											
XSALWA= 000000	1959#												
XSFALS= 000040	1959#	7955											
XSOFFS= 000400	1959#	7949	7955										
XSTRUE= 000020	1959#	7949											
SPATCH 046532	7993#												
. = 046616	1959#	2484#	2490#	2498#	2513#	2524#	2528#	2562#	2591#	2592#	2593#	2594#	2595#
	2596#	2599#	2703#	2704#	2798#	2802#	2806#	2813#	2820#	2822#	2828#	2830#	2841#
	2843#	2850#	2852#	2868#	2870#	2874#	2876#	2888#	2895#	2897#	2899#	2901#	2903#
	2909#	2923#	2925#	2941#	3014#	3035#	3136	3463#	3465#	3469#	3474#	3476#	4651
	4703	4724	4746	4852	4912	7309#	7949	7955	7994#				

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 227
CROSS REFERENCE TABLE -- MACRO NAMES

ENDMOD	1#	1959#	8002												
ENDMSG	1#	1959#	3049	3062	3076	3090	3110	3130							
ENDPRO	1#	1959#	4474												
ENDPTA	1#	1959#													
ENDRPT	1#	1959#	4457												
ENDSEG	1#	1959#													
ENDSET	1#	1959#													
ENDSFT	1#	1959#													
ENDSRV	1#	1959#	3243	6450	6522	7736									
ENDSUB	1#	1959#													
ENDSW	1#	1959#													
ENDTST	1#	1959#	7898												
EQUALS	1#	1959#	2130												
ERRDF	1#	1959#													
ERRHRD	1#	1959#													
ERROR	1#	1959#													
ERRSF	1#	1959#													
ERRSOF	1#	1959#	5712	5730	5743	5786	6030	6068	6136	6289	6407	6429	6647	7467	7485
ERRTBL	1#	1959#													
ESCAPE	1#	1959#													
EXIT	1#	1959#	3134	4649	4701	4722	4744	4850	4910						
FEQUAL	1#	1959#													
GETBYT	1#	1959#													
GETPRI	1#	1959#													
GETWOR	1#	1959#													
GMANIA	1#	1959#													
GMANID	1#	1959#	3416	4551	4860	5871									
GMANIL	1#	1959#													
GPHARD	1#	1959#	4585												
GPRMA	1#	1959#	7934	7939											
GPRMD	1#	1959#	3417#	3420	4552#	4555	4861#	4864	5872#	5875	7956				
GPRML	1#	1959#	7924	7944	7950										
HEADER	1#	1959#	1977												
INLOOP	1#	1959#													
IOSETU	1#	1959#													
IOSTAR	1#	1959#													
KT11	1#	1959#													
LASTAD	1#	1959#	7997												
MANUAL	1#	1959#	4844												
MEMORY	1#	1959#													
MSBYTE	1#	1959#	1978#	1984	1985	1986									
MSCHEC	1#	1959#	3135#	4650#	4702#	4723#	4745#	4851#	4911#						
MSCNTO	1#	1959#	3420#	4555#	4864#	5875#	7925#	7935#	7940#	7945#	7951#	7957#			
MSCOUN	1#	1959#	3039#	3056#	3069#	3083#	3103#	3122#	3360#	3368#	3406#	3434#	3444#	3503#	3550#
	3564#	3584#	3595#	3620#	3649#	3672#	3682#	3697#	3711#	3718#	3744#	3758#	3773#	3790#	3799#
	3819#	3839#	3877#	3887#	3896#	3941#	4136#	4172#	4323#	4366#	4564#	4783#	4825#	4878#	4887#
	4924#	4939#	4965#	4981#	5081#	5153#	5200#	5230#	5303#	5352#	5369#	5839#	5936#	5963#	7302#
MSDATA	1#	1959#	1978#	1987	1989	1991	1993	1995	1997	1999	2001	2003	2005	2007	2009
	2011	2013	2015	2017#	2019	2021	2024	2027	2029	2031	2033	2035	2037	2039	2041
	2043	2045	2047	2049	2051	2053	2055	2057	2059	2061	3011#	3021#			
MSDECR	1#	1959#	2114#	3050#	3063#	3077#	3091#	3111#	3131#	3244#	4458#	4475#	4657#	4673#	4709#
	4730#	4752#	6451#	6523#	7737#	7899#	7963#	8003#							
MSDEFA	1#	1959#	3420#	4555#	4864#	5875#	7925#	7935#	7940#	7945#	7951#	7957#			
MSENDE	1#	1959#	2114#	3050#	3063#	3077#	3091#	3111#	3131#	3244#	4458#	4657#	4673#	4709#	4730#
	4752#	6451#	6523#	7737#	7899#	7963#	8003#								
MSERRI	1#	1959#	5713#	5731#	5744#	5787#	6031#	6069#	6137#	6290#	6408#	6430#	6648#	7468#	7486#

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 229
CROSS REFERENCE TABLE -- MACRO NAMES

	5231#	5232	5233#	5234	5303#	5304#	5305	5306#	5307	5352#	5353#	5354	5355#	5356	5369#
	5370#	5371	5372#	5373	5713#	5714#	5715#	5716#	5731#	5732#	5733#	5734#	5744#	5745#	5746#
	5747#	5787#	5788#	5789#	5790#	5839#	5840#	5841	5842#	5843	5872#	5873#	5874#	5875#	5876
	5877	5878	5879	5936#	5937#	5938	5939#	5940	5963#	5964#	5965	5966#	5967	6020#	6031#
	6032#	6033#	6034#	6069#	6070#	6071#	6072#	6075#	6114#	6137#	6138#	6139#	6140#	6278#	6290#
	6291#	6292#	6293#	6408#	6409#	6410#	6411#	6430#	6431#	6432#	6433#	6451#	6452	6523#	6524
	6574#	6617#	6634#	6648#	6649#	6650#	6651#	6919#	6920#	6921#	6922#	6923#	6924	7153#	7302#
	7303#	7304	7305#	7306	7468#	7469#	7470#	7471#	7486#	7487#	7488#	7489#	7737#	7738	7886#
	7900#	7918#	7925#	7926	7927	7935#	7936	7937	7938	7940#	7941	7942	7943	7945#	7946
	7947	7949#	7951#	7952	7953	7955#	7957#	7958	7959	7960	7961	7963#	7998#	7999#	8000#
MSGNLS	1#	1959#	3417#	3425	4552#	4560	4861#	4869	5872#	5880					
MSGNSU	1#	1959#													
MSGNTA	1#	1959#	2114#	3050#	3063#	3077#	3091#	3111#	3131#	3244#	4458#	4657#	4673#	4709#	4730#
	4752#	6451#	6523#	7737#	7899#	7963#	7964								
MSGNTE	1#	1959#	4768#												
MSHAPT	1#	1959#	1978#												
MSHNAP	1#	1959#	1978#	2017											
MSINCR	1#	1959#	1961#	2086#	3037#	3047#	3051#	3054#	3060#	3064#	3067#	3074#	3078#	3081#	3088#
	3092#	3101#	3108#	3112#	3120#	3128#	3132#	3219#	3363#	3371#	3409#	3417#	3426	3437#	3447#
	3507#	3553#	3567#	3588#	3602#	3631#	3652#	3675#	3689#	3702#	3715#	3723#	3750#	3764#	3779#
	3794#	3802#	3822#	3842#	3881#	3892#	3900#	3944#	4143#	4180#	4326#	4369#	4448#	4459#	4468#
	4484#	4491#	4496#	4501#	4506#	4512#	4523#	4533#	4545#	4552#	4561	4567#	4587#	4626#	4636#
	4643#	4648#	4650#	4658#	4669#	4674#	4683#	4688#	4699#	4702#	4710#	4719#	4731#	4741#	4753#
	4768#	4769#	4786#	4828#	4835#	4845#	4851#	4861#	4870	4881#	4890#	4911#	4928#	4943#	4969#
	4985#	5085#	5158#	5203#	5233#	5306#	5355#	5372#	5713#	5731#	5744#	5787#	5842#	5872#	5881
	5939#	5966#	6020#	6031#	6069#	6075#	6114#	6137#	6278#	6290#	6358#	6408#	6430#	6489#	6574#
	6617#	6634#	6648#	6923#	7153#	7305#	7468#	7486#	7614#	7886#	7900#	7918#			
MSIOSE	1#	1959#													
MSLDRO	1#	1959#	4495#	4500#	4505#	4511#	4522#	4532#	4586#	4647#	4687#				
MSMASK	1#	1959#													
MSMCHI	1#	1959#													
MSMCLO	1#	1959#													
MSMSK1	1#	1959#													
MSPOP	1#	1959#	2114#	3050#	3063#	3077#	3091#	3111#	3131#	3244#	4458#	4475#	4657#	4673#	4709#
	4730#	4752#	6451#	6523#	7737#	7899#	7963#	8003#							
MSPRIN	1#	1959#	3039#	3056#	3069#	3083#	3103#	3122#	3360#	3368#	3406#	3434#	3444#	3503#	3550#
	3564#	3584#	3595#	3620#	3649#	3672#	3682#	3697#	3711#	3718#	3744#	3758#	3773#	3790#	3799#
	3819#	3839#	3877#	3887#	3896#	3941#	4136#	4172#	4323#	4366#	4564#	4783#	4825#	4878#	4887#
	4924#	4939#	4965#	4981#	5081#	5153#	5200#	5230#	5303#	5352#	5369#	5839#	5936#	5963#	7302#
MSPUSH	1#	1959#	1961#	2086#	3037#	3054#	3067#	3081#	3101#	3120#	3219#	4448#	4468#	4484#	4669#
	4683#	4719#	4741#	4768#	4769	6358#	6489#	7614#	7918#						
MSPUT	1#	1959#	3039#	3056#	3069#	3083#	3103#	3122#	3360#	3368#	3406#	3434#	3444#	3503#	3550#
	3564#	3584#	3595#	3620#	3649#	3672#	3682#	3697#	3711#	3718#	3744#	3758#	3773#	3790#	3799#
	3819#	3839#	3877#	3887#	3896#	3941#	4136#	4172#	4323#	4366#	4564#	4622#	4632#	4637#	4783#
	4825#	4831#	4878#	4887#	4924#	4939#	4965#	4981#	5081#	5153#	5200#	5230#	5303#	5352#	5369#
	5839#	5936#	5963#	6919#	7302#										
MSPUT1	1#	1959#	3039#	3041	3043	3044	3045	3056#	3057	3058	3069#	3070	3071	3072	3083#
	3084	3085	3086	3103#	3104	3105	3106	3122#	3123	3124	3125	3126	3360#	3361	3368#
	3369	3406#	3407	3434#	3435	3444#	3445	3503#	3504	3505	3550#	3551	3564#	3565	3584#
	3585	3586	3595#	3597	3599	3600	3620#	3622	3624	3626	3628	3629	3649#	3650	3672#
	3673	3682#	3683	3684	3685	3686	3687	3697#	3698	3699	3700	3711#	3712	3713	3718#
	3719	3720	3721	3744#	3745	3746	3747	3748	3758#	3759	3760	3761	3762	3773#	3774
	3775	3776	3777	3790#	3791	3792	3799#	3800	3819#	3820	3839#	3840	3877#	3878	3879
	3887#	3889	3890	3896#	3897	3898	3941#	3942	4136#	4137	4138	4139	4140	4141	4172#
	4173	4174	4175	4176	4177	4178	4323#	4324	4366#	4367	4564#	4565	4622#	4623	4624
	4625	4632#	4633	4634	4635	4639#	4640	4641	4642	4783#	4784	4825#	4826	4831#	4832

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 230
CROSS REFERENCE TABLE -- MACRO NAMES

	4833	4834	4878#	4879	4887#	4888	4924#	4925	4926	4939#	4940	4941	4965#	4966	4967
	4981#	4982	4983	5081#	5082	5083	5153#	5154	5155	5156	5200#	5201	5230#	5231	5303#
	5304	5352#	5353	5369#	5370	5839#	5840	5936#	5937	5963#	5964	6919#	6920	6921	6922
	7302#	7303													
MSRADI	1#	1959#	3420#	4555#	4864#	5875#	7925#	7935#	7940#	7945#	7951#	7957#			
MSRBRO	1#	1959#													
MSRNRO	1#	1959#	4522#	4524	4532#	4534	4586#	4588							
MSSETS	1#	1959#	1961#	2086#	3037#	3054#	3067#	3081#	3101#	3120#	3219#	4448#	4468#	4484#	4669#
	4683#	4719#	4741#	4769#	6358#	6489#	7614#	7918#							
MSSTAR	1#	1959#													
MS SVC	1#	1959#	3039#	3047	3050#	3051	3056#	3060	3063#	3064	3069#	3074	3077#	3078	3083#
	3088	3091#	3092	3103#	3108	3111#	3112	3122#	3128	3131#	3132	3135#	3360#	3363	3368#
	3371	3406#	3409	3417#	3434#	3437	3444#	3447	3503#	3507	3550#	3553	3564#	3567	3584#
	3588	3595#	3602	3620#	3631	3649#	3652	3672#	3675	3682#	3689	3697#	3702	3711#	3715
	3718#	3723	3744#	3750	3758#	3764	3773#	3779	3790#	3794	3799#	3802	3819#	3822	3839#
	3842	3877#	3881	3887#	3892	3896#	3900	3941#	3944	4136#	4143	4172#	4180	4323#	4326
	4366#	4369	4458#	4459	4491#	4495#	4496	4500#	4501	4505#	4506	4511#	4512	4522#	4523
	4532#	4533	4545#	4552#	4564#	4567	4586#	4587	4622#	4626	4632#	4636	4639#	4643	4647#
	4648	4650#	4657#	4658	4673#	4674	4687#	4688	4699#	4702#	4709#	4710	4723#	4730#	4731
	4745#	4752#	4753	4783#	4786	4825#	4828	4831#	4835	4845#	4851#	4861#	4878#	4881	4887#
	4890	4911#	4924#	4928	4939#	4943	4965#	4969	4981#	4985	5081#	5085	5153#	5158	5200#
	5203	5230#	5233	5303#	5306	5352#	5355	5369#	5372	5713	5731	5744	5787	5839#	5842
	5872#	5936#	5939	5963#	5966	6020#	6031	6069	6075#	6114#	6137	6278#	6290	6408	6430
	6574#	6617#	6634#	6648	6919#	6923	7153#	7302#	7305	7468	7486	7886#	7899#	7900	7900
MSTLAB	1#	1959#	3047#	3051#	3060#	3064#	3074#	3078#	3088#	3092#	3108#	3112#	3128#	3132#	3363#
	3371#	3409#	3417#	3437#	3447#	3507#	3553#	3567#	3588#	3602#	3631#	3652#	3675#	3689#	3702#
	3715#	3723#	3750#	3764#	3779#	3794#	3802#	3822#	3842#	3881#	3892#	3900#	3944#	4143#	4180#
	4326#	4369#	4459#	4491#	4496#	4501#	4506#	4512#	4523#	4533#	4545#	4552#	4567#	4587#	4626#
	4636#	4643#	4648#	4650#	4658#	4674#	4688#	4699#	4702#	4710#	4731#	4753#	4786#	4828#	4835#
	4845#	4851#	4861#	4881#	4890#	4911#	4928#	4943#	4969#	4985#	5085#	5158#	5203#	5233#	5306#
	5355#	5372#	5713#	5731#	5744#	5787#	5842#	5872#	5939#	5966#	6020#	6031#	6069#	6075#	6114#
	6137#	6278#	6290#	6408#	6430#	6574#	6617#	6634#	6648#	6923#	7153#	7305#	7468#	7486#	7886#
	7900#														
MSTSTL	1#	1959#	3047#	3051#	3060#	3064#	3074#	3078#	3088#	3092#	3108#	3112#	3128#	3132#	3363#
	3371#	3409#	3417#	3437#	3447#	3507#	3553#	3567#	3588#	3602#	3631#	3652#	3675#	3689#	3702#
	3715#	3723#	3750#	3764#	3779#	3794#	3802#	3822#	3842#	3881#	3892#	3900#	3944#	4143#	4180#
	4326#	4369#	4459#	4491#	4496#	4501#	4506#	4512#	4523#	4533#	4545#	4552#	4567#	4587#	4626#
	4636#	4643#	4648#	4650#	4658#	4674#	4688#	4699#	4702#	4710#	4731#	4753#	4786#	4828#	4835#
	4845#	4851#	4861#	4881#	4890#	4911#	4928#	4943#	4969#	4985#	5085#	5158#	5203#	5233#	5306#
	5355#	5372#	5713#	5731#	5744#	5787#	5842#	5872#	5939#	5966#	6020#	6031#	6069#	6075#	6114#
	6137#	6278#	6290#	6408#	6430#	6574#	6617#	6634#	6648#	6923#	7153#	7305#	7468#	7486#	7886#
	7900#														
MSWORD	1#	1959#	2017#	2026	2072#	2074	3135#	3417#	3419	3420#	4552#	4554	4555#	4650#	4702#
	4723#	4745#	4851#	4861#	4863	4864#	4911#	5713#	5714	5715	5716	5731#	5732	5733	5734
	5744#	5745	5746	5747	5787#	5788	5789	5790	5872#	5874	5875#	6031#	6032	6033	6034
	6069#	6070	6071	6072	6137#	6138	6139	6140	6290#	6291	6292	6293	6408#	6409	6410
	6411	6430#	6431	6432	6433	6648#	6649	6650	6651	7468#	7469	7470	7471	7486#	7487
	7488	7489	7925#	7935#	7940#	7945#	7949#	7951#	7955#	7957#	7999	8000			
MSXFER	1#	1959#	7949#	7955#											
NODCL	1965#	2795	2796	2797	2798	2799	2800	2801	2802	2803	2804	2805	2806	2807	2808
	2809	2810	2811	2812	2813	2814	2815	2819	2820	2821	2822	2823	2824	2825	2826
	2827	2828	2829	2830	2831	2832	2833	2834	2835	2836	2840	2841	2842	2843	2844
	2849	2850	2851	2852	2853	2856	2857	2858	2859	2860	2861	2862	2863	2866	2867
	2868	2869	2870	2871	2874	2875	2876	2877	2879	2880	2881	2882	2883	2885	2886
	2888	2889	2892	2895	2896	2897	2898	2899	2900	2901	2902	2903	2904	2905	2906
	2907	2908	2909	2910	2912	2913	2914	2915	2916	2917	2918	2921	2922	2923	2924

CZDCLA DUP-11 DATA COMM. LINK TEST
CZDCLA.P11 19-MAR-82 18:19

MACY11 30A(1052) 23-MAR-82 16:47 PAGE 231
CROSS REFERENCE TABLE -- MACRO NAMES

	2925	2926	2929	2930	2931	2934	2937	2938	2939	2940	2941	2942	2943	2944	2947
	2948	2949	2954	3460	3461	3462	3463	3464	3465	3466	3467	3468	3469	3470	3471
	3472	3473	3474	3475	3476	3477	3478	3479	3480	3481					
OPEN	1#	1959#													
POINTE	1#	1959#	1971												
PRINTB	1#	1959#	3038	3055	3068	3082	3102	3121							
PRINTF	1#	1959#	3359	3367	3405	3433	3443	3502	3563	3876	3886	3895	3940	4322	4365
	4563	4782	4824	4877	4886	4923	4938	4964	4980	5080	5152	5199	5229	5302	5351
	5368	5838	5935	5962	7301										
PRINTS	1#	1959#	3549	3583	3594	3619	3648	3671	3681	3696	3710	3717	3743	3757	3772
	3789	3798	3818	3838	4135	4171									
PRINTX	1#	1959#													
READBU	1#	1959#	4544												
READEF	1#	1959#	4494	4499	4504	4510									
RFLAGS	1#	1959#													
SETPRI	1#	1959#	4646	4686											
SETVEC	1#	1959#	4621	4631	4638	4830	6918								
SLASH	1#	1959#													
STARS	1#	1959#													
SVC	1#	1959#													
XFER	1#	1959#	3135#	4650#	4702#	4723#	4745#	4851#	4911#						
XFERF	1#	1959#	7954												
XFERT	1#	1959#	7948												

. ABS. 046616 000

ERRORS DETECTED: 0

CZDCLA,CZDCLA.LST/CRF/SOL=SVC34R.MLB,CZDCLA.P11

RUN-TIME: 27 34 4 SECONDS

RUN-TIME RATIO: 91/66=1.3

CORE USED: 22K (43 PAGES)