

NCV11

NCV-11 EXER
CZNCDB0

AH-E777B-MC

JAN 1980

COPYRIGHT 78-80

digital

FICHE 1 OF 1

MADE IN USA

The image shows a microfiche card with a grid of frames. The frames contain data, likely in a tabular format, but the text is too small and dark to be legible. The card is oriented vertically and occupies the left portion of the image.

IDENTIFICATION

B 1

SEQ 0001

Product Code: AC-E776B-MC
Product Name: CZNCDBO NCV-11 EXERCISER
Date: AUGUST 1979
MAintainer: Diagnostic Engineering

Copyright (C) 1978, 1979
Digital Equipment Corporation, Maynard, Mass.

This software is furnished under a license for use only on a single computer system and may be copied only with the inclusion of the above copyright notice. This software, or any other copies thereof, may not be provided or otherwise made available to any other person except for use on such system and to one who agrees to these license terms. Title to and ownership of the software shall at all times remain in DEC.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

DEC assumes no responsibility for the use or reliability of its software on equipment which is not supplied by DEC.

0.0 TABLE OF CONTENTS

- 1.0 ABSTRACT
- 2.0 REQUIREMENTS
 - 2.1 Equipment
 - 2.2 Equipment - Optional
 - 2.3 PRELIMINARY PROGRAMS
 - 2.4 Storage
- 3.0 LOADING PROCEDURE
- 4.0 STARTING PROCEDURE
- 5.0 OPERATOR OPTIONS
 - 5.1 OPERATOR KEYBOARD OPTIONS
 - 5.2 OPERATOR SWITCH REGISTER OPTION(S)
- 6.0 RECOMMENDED OPERATOR ACTION
 - 6.1 Camera Setup
 - 6.2 Joystick Setup
- 7.0 MISCELLANEOUS
 - 7.1 Device Bus Address Modifications
 - 7.2 Free Run Mode (Type 'F')
 - 7.3 Error Reporting
 - 7.4 Execution Time
- 8.0 PROGRAM DESCRIPTION
 - 8.1 Data Connection & Display
 - 8.2 Joysti - Mode
- 9.0 LISTING

1.0 ABSTRACT

The 'B' version corrected the 'D' command. It also corrected problems when no VSV01 display was present. This is a self contained program designed to convert data from the GAMMA camera via the NCV11 interface and display it on a VSV01 display. It can be used for camera/interface and joystick setup or for practice in image manipulation. It is meant as a exerciser rather than a diagnostic. TOTAL PROGRAM CONTROL IS ACCOMPLISHED THRU THE CONSOLE KEYBOARD. THE PROGRAM IS NOT CHAINABLE/SCRIPTABLE UNDER XXDP/APT.

2.0 REQUIREMENTS

2.1 Equipment

1. PDP-11 FAMILY OR LSI-11 FAMILY Computer
2. I/O Terminal (i.e., LA36)
3. NCV11 Interface
4. Gamma Camera (OR SUBSTITUTE)

2.2 Equipment - Optional

1. H3060 Joystick
2. VSV01 DISPLAY

2.3 PRELIMINARY PROGRAMS

MAINDEC-11-CZNCC SHOULD HAVE PREVIOUSLY BEEN RUN

2.4 Storage

This program uses all of lower 12K of memory.

3.0 LOADING PROCEDURE

Normal procedure for loading a binary program into memory SHOULD BE followed.

4.0 STARTING PROCEDURE

Loading address 200 and starting will initialize the system, IDENTIFY THE PROGRAM and wait a keyboard command.

5.0 OPERATOR OPTIONS

5.1 OPERATOR KEYBOARD OPTIONS

TYPE 'H'- HELP OPERATOR AND DISPLAY OR TYPE THIS LIST
Type 'N'- Collect new data from camera - clears core matrix FIRST
Type 'C'- Collect data from camera - starts NCV11, previous core matrix data not cleared
TYPE 'X'- SELECT ANOTHER CAMERA CHANNEL
Type 'S'- Stop NCV11 data collection - also terminates free RUN MODE
Type 'Z'- Zoom - Set NCV11 TO GAIN 2
Type 'R'- Regular - SET NCV11 TO GAIN 1 (DEFAULT COND)
Type 'W'- Select VSV01 display using 1st bit map
Type 'M'- Select VSV01 display USING 2nd bit map
Type 'A'- Display ISOTOPE A (default cond)
Type 'B'- Display ISOTOPE B (B GAMMA)
Type 'D'- Display data - display selected ISOTOPE
Type 'L'- Get lower threshold from keyboard (default=0) - all matrix values less than typed value are not displayed
Type 'U'- Get upper threshold from KEYBOARD (default=177777) - All matrix values greater than typed value are NOT DISPLAYED
Type 'F'- Free run mode - collect and display new data continuously - Type 'S' to terminate this mode
TYPE 'X'- SELECT ANOTHER CAMERA CHANNEL
Type 'G'- Initialize everything - start fresh
Type 'J'- Joystick calibration NCV11 - use "Ctrl C" to terminate mode
TYPE 'T'- DISPLAY INTENSITY TEST PATTERN ON SELECTED DISPLAY - THIS FEATURE IS FOR DISPLAY VERIFICATION ONLY
TYPE 'O'- OTHER TERMINAL TO CONTROL THE PROGRAM
Type "Ctrl & C" - Abort whatever - back to keyboard monitor

5.2 OPERATOR SWITCH REGISTER OPTION(S)

NONE

6.0 RECOMMENDED OPERATOR ACTION

6.1 Camera/A017 Setup

1. Place radioactive flood source IN FRONT OF CAMERA DETECTOR, OR USE A WEAK RADIOACTIVE SAMPLE ABOUT 3 FEET FROM A DETECTOR WITH THE COLLIMATOR REMOVED.
2. Collect data (C) and display (D)
3. Adjust the X and Y gain controls ON THE A017 until a round circle* IS SEEN and centered within the box on screen.
4. Increase the circle* size until the edges just begin to TOUCH THE BOX.
5. Collect data for a 3 minute period and observe the image. If there is an artifact on the center of the screen that looks like a right angle bracket, the "Z" delay circuit should be adjusted.
6. IF THE MATRIX AND Z COUNTS EQUAL 0 THEN NO DATA WAS COLLECTED, THEREFORE, NO DISPLAY.

* THIS MAY BE A HEXAGON FOR SOME MAKES OF CAMERA.

6.2 Joystick Setup

1. Select Joystick configuration by typing 'J'.
2. Adjust the Y Pot on the H3060 Joystick so that the HORIZONTAL cross hair provide UNIFORM access within the box drawn on the screen. ADJUST THE X POT ON THE H3060 SO THAT THE VERTICAL CROSS HAIR WILL ALSO BE UNIFORM EXCEPT THAT DUE TO A HARDWARE OFFSET WILL NOT REACH THE RIGHT EDGE AND EXCEED THE LEFT EDGE BY THE SAME AMOUNT. Ideally, a physical center of the Joystick will provide a point approximately centered in the box.
3. Check that when the Joystick interrupt SWITCH is depressed the CROSS HAIRS DO not follow the Joystick.
4. A 'Cntrl C' will return user back to the keyboard monitor.

7.0 MISCELLANEOUS

7.1 Device Bus Address Modifications

NCV11 Modify location 'NCVADR' if base bus address is not
 772760

VSV01 Modify location 'VTVADR' if base bus address (CHARACTER
 GENERATOR) IS NOT 772600
 MODIFY LOCATION 'VTMADR' IF BASE BUS ADDRESS (BIT MAP)
 IS NOT 772620

Note: A restart is required after any of the above address
 modifications.

7.2 Free Run Mode (Type 'F')

Modification of location 'TIME' will alter the data collection
time in the free run mode. The default value of 20(8) provides
about 10 SECONDS ON AN LSI-11 CPU.

7.3 Error Reporting

1. INCORRECT KEYBOARD COMMANDS ARE RESPONDED WITH '?'
2. A MESSAGE WILL BE REPORTED IF ANY SELECTED DEVICE (SEE SECTION 7.1)
DOES NOT RESPOND.

7.4 Execution Time

The EXECUTION TIME is completely dependent upon the user for
whatever option selected.

8.0 PROGRAM DESCRIPTION

8.1 Data Collection & Display

The user may collect data from the gamma camera system via the NCV11 interface and display this data on the VSV01 (bitmap) display. All functions are ENTERED thru the keyboard as defined in section 5.1. When the data collection mode is selected the NCV11 is receiving X & Y data from the gamma camera (looking AT a radioactive source). This information is transformed via THE address maker LOGIC which forms a unique address within a defined matrix relative to the scan position of the camera. The NCV11 preforms an NPR increment to memory to this UNIQUE address. The program selects the address MATRIX 64x64x16 (RESOLUTION 2) OFFSET TO address 20000(8) FOR THE 'A' Isotope, AND FOR THE 'B' ISOTOPE, (CAMERAS EQUIPPED WITH THE DUAL ISOTOPE ATTACHMENT) INFORMATION VIA B GAMMA LOGIC IS STORED STARTING AT ADDRESS 40000 (8). The intensity of each cell (memory location) of the image in memory is adjusted with the upper and lower thresholds and scaled to ONE OF 16 intensity levels. The cell with the highest count represents THE HIGHEST intensity level, therefore appears brightest on the display. At the completion of the image display, the following parameters are displayed:

Lower Threshold -	All values greater than this value are displayed
Upper Threshold -	All values above this value are omitted
CAMERA -	SELECTED CAMERA CHANNEL
PB -	UP/DN INDICATOR OF THE PUSH BUTTON STATE DURING LAST COLLECTION
JB -	UP/DN INDICATOR OF THE JOY BUTTON STATE DURING LAST COLLECTION
Z Count -	32 bit counter of EVENT pulses
Matrix Count -	Total count of the contents of each cell in the 64x64 matrix
Zoom -	Displayed if gain was selected
B-Gamma -	Displayed if 'B' Isotope selected

8.2 Joystick Mode

Selecting the TEST takes advantage of the Joystick mode provided by the NCV11. This mode selects the JOYSTICK inputs and the NCV11 performs like an A/D with the X & Y CONVERTED values available in X-Y holding register. The X and Y data is applied to the display and should conform to the requirements in section 6.2.
 * VSV01 uses the X & Y cross hairs as the DISPLAY indicator.

9.0 LISTING

11	BASIC DEFINITIONS
18	TRAP CATCHER
(1)	STARTING ADDRESS(ES)
21	COMMON TAGS
(1)	ERROR POINTER TABLE
99	MAIN PROGRAM
102	INITIALIZE THE COMMON TAGS
180	KEYBOARD DISPATCH TABLE
209	COMMAND DECODER
374	PROGRAM ROUTINES
646	PROGRAM SUBROUTINES
879	TTY INPUT ROUTINE
881	TYPE ROUTINE
883	BINARY TO OCTAL (ASCII) AND TYPE
885	READ AN OCTAL NUMBER FROM THE TTY
888	TRAP DECODER
(3)	TRAP TABLE
891	POWER DOWN AND UP ROUTINES
893	DISPLAY MESSAGES
907	ASCII MESSAGES

```
1          :DEVELOPED USING SYSMAC.C3
9          .TITLE CZNCDB NCV11 EXERCISER
(1)       :*COPYRIGHT (C) 1979
(1)       :*DIGITAL EQUIPMENT CORP.
(1)       :*MAYNARD, MASS. 01754
(1)       :
(1)       :*PROGRAM BY R.SHOOP
(1)       :
(1)       :*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
(1)       :*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
(1)       :
(1)       000001 $TN=1
(1)       160000 $SWR=160000 ;:HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYPQUT
10        172760          ABASE=172760 ;:DEFAULT NCV11 ADDRESS
11        .SBTTL BASIC DEFINITIONS
(1)
(1)       ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
(1)       001100 STACK= 1100
(1)       .EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL
(1)       .EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL
(1)
(1)       ;*MISCELLANEOUS DEFINITIONS
(1)       000011 HT= 11 ;:CODE FOR HORIZONTAL TAB
(1)       000012 LF= 12 ;:CODE FOR LINE FEED
(1)       000015 CR= 15 ;:CODE FOR CARRIAGE RETURN
(1)       000200 CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
(1)       177776 PS= 177776 ;:PROCESSOR STATUS WORD
(1)       .EQUIV PS,PSW
(1)       177774 STKLMT= 177774 ;:STACK LIMIT REGISTER
(1)       177772 PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
(1)       177570 DSWR= 177570 ;:HARDWARE SWITCH REGISTER
(1)       177570 DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
(1)
(1)       ;*GENERAL PURPOSE REGISTER DEFINITIONS
(1)       000000 R0= %0 ;:GENERAL REGISTER
(1)       000001 R1= %1 ;:GENERAL REGISTER
(1)       000002 R2= %2 ;:GENERAL REGISTER
(1)       000003 R3= %3 ;:GENERAL REGISTER
(1)       000004 R4= %4 ;:GENERAL REGISTER
(1)       000005 R5= %5 ;:GENERAL REGISTER
(1)       000006 R6= %6 ;:GENERAL REGISTER
(1)       000007 R7= %7 ;:GENERAL REGISTER
(1)       000006 SP= %6 ;:STACK POINTER
(1)       000007 PC= %7 ;:PROGRAM COUNTER
(1)
(1)       ;*PRIORITY LEVEL DEFINITIONS
(1)       000000 PR0= 0 ;:PRIORITY LEVEL 0
(1)       000040 PR1= 40 ;:PRIORITY LEVEL 1
(1)       000100 PR2= 100 ;:PRIORITY LEVEL 2
(1)       000140 PR3= 140 ;:PRIORITY LEVEL 3
(1)       000200 PR4= 200 ;:PRIORITY LEVEL 4
(1)       000240 PR5= 240 ;:PRIORITY LEVEL 5
(1)       000300 PR6= 300 ;:PRIORITY LEVEL 6
(1)       000340 PR7= 340 ;:PRIORITY LEVEL 7
(1)
(1)       ;*'SWITCH REGISTER' SWITCH DEFINITIONS
```

```
(1) 100000 SW15= 100000
(1) 040000 SW14= 40000
(1) 020000 SW13= 20000
(1) 010000 SW12= 10000
(1) 004000 SW11= 4000
(1) 002000 SW10= 2000
(1) 001000 SW09= 1000
(1) 000400 SW08= 400
(1) 000200 SW07= 200
(1) 000100 SW06= 100
(1) 000040 SW05= 40
(1) 000020 SW04= 20
(1) 000010 SW03= 10
(1) 000004 SW02= 4
(1) 000002 SW01= 2
(1) 000001 SW00= 1
(1) .EQUIV SW09,SW9
(1) .EQUIV SW08,SW8
(1) .EQUIV SW07,SW7
(1) .EQUIV SW06,SW6
(1) .EQUIV SW05,SW5
(1) .EQUIV SW04,SW4
(1) .EQUIV SW03,SW3
(1) .EQUIV SW02,SW2
(1) .EQUIV SW01,SW1
(1) .EQUIV SW00,SW0
```

;*DATA BIT DEFINITIONS (BIT00 TO BIT15)

```
(1) 100000 BIT15= 100000
(1) 040000 BIT14= 40000
(1) 020000 BIT13= 20000
(1) 010000 BIT12= 10000
(1) 004000 BIT11= 4000
(1) 002000 BIT10= 2000
(1) 001000 BIT09= 1000
(1) 000400 BIT08= 400
(1) 000200 BIT07= 200
(1) 000100 BIT06= 100
(1) 000040 BIT05= 40
(1) 000020 BIT04= 20
(1) 000010 BIT03= 10
(1) 000004 BIT02= 4
(1) 000002 BIT01= 2
(1) 000001 BIT00= 1
(1) .EQUIV BIT09,BIT9
(1) .EQUIV BIT08,BIT8
(1) .EQUIV BIT07,BIT7
(1) .EQUIV BIT06,BIT6
(1) .EQUIV BIT05,BIT5
(1) .EQUIV BIT04,BIT4
(1) .EQUIV BIT03,BIT3
(1) .EQUIV BIT02,BIT2
(1) .EQUIV BIT01,BIT1
(1) .EQUIV BIT00,BIT0
```

;*BASIC 'CPU' TRAP VECTOR ADDRESSES

```
(1) 000004 ERRVEC= 4 ;;TIME OUT AND OTHER ERRORS
(1) 000010 RESVEC= 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
(1) 000014 TBITVEC=14 ;;'T' BIT
(1) 000014 TRTVEC= 14 ;;TRACE TRAP
(1) 000014 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
(1) 000020 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1) 000024 PWRVEC= 24 ;;POWER FAIL
(1) 000030 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
(1) 000034 TRAPVEC=34 ;;'TRAP' TRAP
(1) 000060 TKVEC= 60 ;;TTY KEYBOARD VECTOR
(1) 000064 TPVEC= 64 ;;TTY PRINTER VECTOR
(1) 000240 PIRQVEC=240 ;;PROGRAM INTERRUPT REQUEST VECTOR
```

12
13
14
15
16
17
18

;SOME COMMON PROGRAM VALUES AND EQUATES

```
(1) 020000 MATRIX=20000 ;STARTING ADRS OF MATRIX DATA
(1) .SBTTL TRAP CATCHER
(1) .=0
(1) ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
(1) ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
(1) ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
(1) .=174
(1) 000174 000000 DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
(1) 000176 000000 SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER
(1) .SBTTL STARTING ADDRESS(ES)
(1) 000200 000137 001326 JMP @START ;;JUMP TO STARTING ADDRESS OF PROGRAM
19 000100 000100 -100
20 000100 000104 000340 000002 104,340,RTI ;LSI-11 B EVENT
```

```

21      .SBTTL COMMON TAGS
(1)
(2)      ;:*****
(1)      ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
(1)      ;*USED IN THE PROGRAM.
(1)
(1)      001100      .=1100
(1) 001100      SCMTAG:      ;:START OF COMMON TAGS
(1) 001100      SPASS: .WORD 0      ;:CONTAINS PASS COUNT
(1) 001102      000      $STNM: .BYTE 0      ;:CONTAINS THE TEST NUMBER
(1) 001103      000      $ERFLG: .BYTE 0      ;:CONTAINS ERROR FLAG
(1) 001104      000000     $ICNT: .WORD 0      ;:CONTAINS SUBTEST ITERATION COUNT
(1) 001106      000000     $LPADR: .WORD 0      ;:CONTAINS SCOPE LOOP ADDRESS
(1) 001110      000000     $LPERR: .WORD 0      ;:CONTAINS SCOPE RETURN FOR ERRORS
(1) 001112      000000     $ERTTL: .WORD 0      ;:CONTAINS TOTAL ERRORS DETECTED
(1) 001114      000      $ITEMB: .BYTE 0      ;:CONTAINS ITEM CONTROL BYTE
(1) 001115      001      $ERMAX: .BYTE 1      ;:CONTAINS MAX. ERRORS PER TEST
(1) 001116      000000     $ERRPC: .WORD 0      ;:CONTAINS PC OF LAST ERROR INSTRUCTION
(1) 001120      000000     $GDADR: .WORD 0      ;:CONTAINS ADDRESS OF 'GOOD' DATA
(1) 001122      000000     $BDADR: .WORD 0      ;:CONTAINS ADDRESS OF 'BAD' DATA
(1) 001124      000000     $GDDAT: .WORD 0      ;:CONTAINS 'GOOD' DATA
(1) 001126      000000     $BDDAT: .WORD 0      ;:CONTAINS 'BAD' DATA
(1) 001130      000000     .WORD 0      ;:RESERVED--NOT TO BE USED
(1) 001132      000000     .WORD 0
(1) 001134      000      $AUTOB: .BYTE 0      ;:AUTOMATIC MODE INDICATOR
(1) 001135      000      $INTAG: .BYTE 0      ;:INTERRUPT MODE INDICATOR
(1) 001136      000000     .WORD 0
(1) 001140      177570     SWR: .WORD DSWR      ;:ADDRESS OF SWITCH REGISTER
(1) 001142      177570     DISPLAY: .WORD DDISP      ;:ADDRESS OF DISPLAY REGISTER
(1) 001144      177560     $TKS: 177560      ;:TTY KBD STATUS
(1) 001146      177562     $TKB: 177562      ;:TTY KBD BUFFER
(1) 001150      177564     $TPS: 177564      ;:TTY PRINTER STATUS REG. ADDRESS
(1) 001152      177566     $TPB: 177566      ;:TTY PRINTER BUFFER REG. ADDRESS
(1) 001154      000      $NULL: .BYTE 0      ;:CONTAINS NULL CHARACTER FOR FILLS
(1) 001155      002      $FILLS: .BYTE 2      ;:CONTAINS # OF FILLER CHARACTERS REQUIRED
(1) 001156      012      $FILLC: .BYTE 12      ;:INSERT FILL CHARS. AFTER A 'LINE FEED'
(1) 001157      000      $TPFLG: .BYTE 0      ;:'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
(1) 001160      077      $QUES: .ASCII /?/      ;:QUESTION MARK
(1) 001161      015      $CLRF: .ASCII <15>      ;:CARRIAGE RETURN
(1) 001162      000012     $LF: .ASCII <12>      ;:LINE FEED
(2)      ;:*****

```

```
(1) .SBTTL ERROR POINTER TABLE
- (1)
(1) ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
(1) ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
(1) ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT?
(1) ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
(1) ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
(1)
(1) ;* EM ;:POINTS TO THE ERROR MESSAGE
(1) ;* DH ;:POINTS TO THE DATA HEADER
(1) ;* DT ;:POINTS TO THE DATA
(1) ;* DF ;:POINTS TO THE DATA FORMAT
(1)
(1) 001164 $ERRTB:
22 ;THIS PROGRAM DOES NOT USE THE ABOVE ERROR TABLE
23
24
25
26
27
28
29
30 ;NCV11 BUS ADRS ASSIGNMENTS - MODS ARE TO BE MADE HERE
31
32 001164 172760 NCADR: ABASE
33
34 ;VSV01 BUS ADRS ASSIGNMENTS (CHAR GEN) - MODS ARE TO BE MADE HERE
35
36 001166 172600 VTVADR: 172600
37
38 ;VSV01 BUS ADRS ASSIGNMENTS (BIT MAP) - MODS ARE TO BE MADE HERE
39
40 001170 172620 VTMADR: 172620 ;FIRST MAP 2ND MAP IS 20 HIGHER
41
42 ;COUNTER FOR FREE RUN MODE
43
44 001172 000024 TIME: 20. ;LOOP COUNTER FOR 'F' MODE
45
46 001174 000060 TKVECO: TKVEC ;CONSOLE TERMINAL VECTOR
47 001176 000062 TKVEC1: TKVEC+2 ; ADDRESS AN PRIORITY
```

Line	Address	Value	Label	Description
49				
50	001200	172760	NCCSR:	ABASE ;NCV11 REGISTER ADDRESS POINTERS
51	001202	172762	NCOFF:	ABASE+2 ;NCV11 STATUS CONTROL REGISTER
52	001204	172764	NCWCR:	ABASE+4 ;NCV11 OFFSET REGISTER
53	001206	172766	NCBAR:	ABASE+6 ;NCV11 WORD COUNT REGISTER
54	001210	172770	NCSFR:	ABASE+10 ;NCV11 BUS ADDRESS REGISTER / LOW Z COUNT
55	001212	172772	NCADM:	ABASE+12 ;NCV11 SPECIAL FUNCTION / JOYSTICK STATUS REGISTER
56	001214	172774	NCJOY:	ABASE+14 ;NCV11 ADDRESS MAKER REGISTER
57	001216	172776	NCBAR1:	ABASE+16 ;NCV11 JOYSTICK DATA REGISTER
58				
59	001220	172600	VTVCRG:	172600 ;NCV11 SPARE <SAME AS NCBAR>
60	001222	172602	VTVCHF:	172602 ;VSV01 REGISTER ADDRESS POINTERS (CHARACTER GENERATOR)
61	001224	172604	VTVPOS:	172604 ;CHAR/STATUS
62				
63	001226	172620	VTVCSR:	172620 ;CROSS HAIR POS
64	001230	172622	VTVMAP:	172622 ;CHAR POS
65	001232	172624	VTVPX:	172624 ;VSV01 REGISTER ADDRESS POINTERS (BIT MAP)
66	001234	172626	VTVPX1:	172626 ;COMMAND/STATUS
67	001236	172630	VTVINT:	172630 ;MAP ADRS
68				
69				
70	001240	000000	TEMPO:	0 ;PIXEL WD
71	001242	000000	TEMP1:	0 ;PIXEL BYTE
72	001244	000000	TEMP2:	0 ;INTENSITY LOOK UP
73	001246	000000	DUMMY1:	0 ;COMMON PROGRAM TAGS AND STORAGE LOCATIONS
74	001250	000000	DUMMY2:	0 ;COMMON UTILITY LOC
75	001252	000000	INTLUT:	0 ;COMMON UTILITY LOC
76	001254	006400	VTVSAV:	6400 ;COMMON UTILITY LOC
77	001256	000000	MRXADR:	0 ;OCTAL TEMP LOC.
78	001260	000000	MAPADR:	0 ;OCTAL TEMP LOC.
79	001262	000003	PIXCNT:	3 ;VSV01 SET UP - FULL SCREEN, MONO(BLK/WHT), ENA DISPLAY
80	001264	000000	PIXASM:	0 ;CURRENT CORE ADRS OF CELL BEING DISPLAYED
81	001266	000000	KBUFF:	0 ;CURRENT ADRS OF BIT MAP LD
82	001270	000000	TTYOUT:	0 ;CURRENT PIXEL BYTE COUNT
83	001272	000000	THLO:	0 ;4 PIXELS ASSEMBLED HERE BEFORE BIT MAP LD
84	001274	177777	THHI:	177777 ;CONTAINS KEYBOARD CHAR TYPED
85	001276	000000	COMSAV:	0 ;OUTPUT CHAR TO PRINTER
86	001300	000000	CAMERA:	0 ;LOW THRESHOLD VALUE APPLIED TO MATRIX CELLS
87	001302	000000	GAIN:	0 ;HIGH THRESHOLD VALUE APPLIED TO MATRIX CELLS
88	001304	010000	TOTSIZ:	4096. ;SAVED NCV11 CSR CONTENTS WHEN DISPLAYING
89	001306	000000	CHARCT:	0 ;CAMERA SELECTION IN BITS 8-9
90	001310	000000	CPERL:	0 ;GAIN 1=0, GAIN 2=BIT10
91	001312	000000	ROWCNT:	0 ;TOTAL # OF CELLS IN MATRIX (ISOTOPE A OR B)
92	001314	020000	TABLEX:	MATRIX ;COUNTS TOTAL # OF CELLS IN MATRIX (ISOTOPE A OR B)
93	001316	000000	FREERN:	0 ;CONTAINS LARGEST CELL OF MATRIX WITHIN THRESHOLDS
94	001320	000000	MSELCT:	0 ;COUNTS 64 CELLS EACH ROW OF CORE MATRIX
95	001322	000000	BELLEN:	0 ;CONTAINS STARTING ADRS OF MATRIX OF SELECTED ISOTOPE
96	001324	000000	NOVSV:	0 ;NON-ZERO SAYS COLLECT NEW DATA & DISPLAY IN FREE RUN MO 0 SAYS 1ST BIT MAP, -1 SAYS 2ND BIT MAP(VSVO*) 0 SAYS RING BELL ON NO CONVERT, -1 SAYS DON'T NON-ZERO INDICATES NO VSV01 DISPLAY

```

102 001326 START:
(1) .SBTTL INITIALIZE THE COMMON TAGS
(1) ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
(1) 001326 012706 001100 MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
(1) 001332 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
(1) 001334 022706 001140 CMP #SWR,R6 ;;DONE?
(1) 001340 001374 BNE -6 ;;LOOP BACK IF NO
(1) 001342 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
(1) ;;INITIALIZE A FEW VECTORS
(1) 001346 012737 007432 000034 MOV #STRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
(1) 001354 012737 000340 000036 MOV #340,@TRAPVEC+2;LEVEL 7
(1) 001362 012737 007512 000024 MCV #SPWRDN,@PWVEC ;;POWER FAILURE VECTOR
(1) 001370 012737 000340 000026 MOV #340,@PWVEC+2 ;;LEVEL 7
(2) ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
(2) ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
(2) 001376 013746 000004 MOV @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
(2) 001402 012737 001436 000004 MOV #64$,@ERRVEC ;;SET UP ERROR VECTOR
(2) 001410 012737 177570 001140 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
(2) 001416 012737 177570 001142 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
(2) 001424 022777 177777 177506 CMP #-1,@SWR ;;TRY TO REFERENCE HARDWARE SWR
(2) 001432 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
(2) ;;AND THE HARDWARE SWR IS NOT = -1
(2) 001434 000403 BR 65$ ;;BRANCH IF NO TIMEOUT
(2) 001436 012716 001444 64$: MOV #65$, (SP) ;;SET UP FOR TRAP RETURN
(2) 001442 000002 RTI
(2) 001444 012737 000176 001140 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
(2) 001452 012737 000174 001142 MOV #DISPREG,DISPLAY
(2) 001460 012637 000004 66$: MOV (SP)+,@ERRVEC ;;RESTORE ERROR VECTOR
(1)
103 001464 104401 01012J TYPE ,MSG1 ;GO IDENTIFY PROGRAM
104 001470 004737 004546 JSR PC,SELCTA ;DEFAULT TO VSV01 DISPLAY IF THERE
105 001474 103004 BCC 3$ ;BR IF DISPLAY VSV01 IS THERE
106 001476 005237 001324 INC NOVSV ;SAVE THE FACT NO VSV01 CONNECTED
107 001502 104401 010242 TYPE ,MSG3 ;GO TYPE 'BUS TIMEOUT ER - VSV01 DISPLAY'
108 001506 013700 001164 3$: MOV NCADR,R0 ;GET NCV11 BASE ADRS
109 001512 012701 001200 MOV #NCCSR,R1 ;GET POINTER ADRS
110 001516 010021 NCSET: MOV R0,(R1)+ ;SET UP NCV11 REG ADRS PTRS
111 001520 062700 000002 ADD #2,R0 ;BUMP REG ADRS
112 001524 022701 001220 CMP #VTVCRG,R1 ;ALL SET UP?
113 001530 001372 BNE NCSET ;BR IF NOT
114 001532 012737 001546 000004 MOV #1$,ERRVEC ;SET UP TIMEOUT ADRS
115 001540 005777 177434 TST @NCCSR ;WILL TRAP TO LOC 4 IF NOT THERE
116 001544 000406 BR START1 ;BR IF THERE
117 001546 022626 1$: CMP (SP)+,(SP)+ ;FIX STACK SINCE NO RTI
118 001550 104401 010400 TYPE ,MSG5 ;GO TYPE 'BUS TIMEOUT ER - NCV11'
119 001554 000000 HALT ;NCV11 NOT SEEN AT ASSIGNED BUS ADRS
120 001556 000137 001326 JMP START
121 001562 012737 000006 000004 START1: MOV #ERRVEC+2,@ERRVEC ;RESTORE ERR TRAP LOC TO PT TO 6
122 001570 000005 RESET ;CLR WORLD
123 001572 004737 004766 JSR PC,NCSTP1 ;GO STOP NCV11 & CLR CORE MATRIX
124 001576 012777 020000 177376 MOV #MATRIX,@NCOFF ;SET OFFSET(ADRS 20000)
125 001604 005037 001302 CLR GAIN ;REGULAR GAIN
126 001610 012737 020000 001314 MOV #MATRIX,TABLEX ;ISOTOPE A
127 001616 005037 001272 CLR THLO ;CLEAR LOWER THRESHOLD
128 001622 012737 177777 001274 MOV #177777,THHI ;CEILING THRESHOLD
129 001630 012777 005220 177336 MOV #KBINT,@TKVECO ;SET KEYBOARD INTR RETURN ADRS
  
```

```

130 001636 012777 000340 177332      MOV    #340,@TKVECT  ;SET UP NEW PRIORITY ON INTR
131 001644 012777 000100 177272      MOV    #100,@STKS   ;SET INTR ENABLE
132 001652 104401 010434                TYPE   ,MSG6        ;GO ASK FOR KEYBOARD COMMAND(S)
133
134      ;THIS IS A LIST OF KEYBOARD COMMANDS FOR THE NCV11/DISPLAY/JOYSTICK
135
136      :H      HELP FRAME
137      :D      DISPLAY DATA
138      :E      ERASE THE SCOPE
139      :L      GET LOWER THRESHOLD FROM KEYBOARD & DISPLAY DATA
140      :U      GET UPPER THRESHOLD FROM KEYBOARD & DISPLAY DATA
141      :N      COLLECT NEW DATA FROM CAMERA (CLEAR CORE MATRIX)
142      :C      COLLECT DATA FROM CAMERA
143      :X      CHANGE CAMERA
144      :S      STOP COLLECTION
145      :G      INITIALIZE EVERYTHING
146      :Z      ZOOM - SET GAIN TO 2
147      :R      REGULAR - SET GAIN TO 1
148      :A      DISPLAY ISOTOPE A
149      :B      DISPLAY ISOTOPE B
150      :W      SELECT VSV01 DISPLAY USING 1ST BIT MAP
151      :M      SELECT VSV01 DISPLAY USING 2ND BIT MAP
152      :F      FREE RUN MODE - COLLECT & DISPLAY NEW DATA CONTINUALLY
153      :J      JOYSTICK CALIBRATION
154      :T      DISPLAY INTENSITY TEST IMAGE ON SELECTED DISPLAY
155      :O      OTHER TERMINAL TO CONTROL PROGRAM
156      :CNTRL C ABORT WHATEVER - BACK TO KEYBOARD MONITOR
157
158      ;THIS CODE WILL DISPATCH PROGRAM TO THE PROPER
159      ;ROUTINE VIA THE DISPATCH TABLE 'RTABLE'
160 001656 005037 001316      LISEN: CLR    FREERN    ;KNOCK DOWN FREE RUN MODE IF SET
161 001662 012706 001100      MOV    #STACK,SP    ;RESET STACK PTR
162 001666 005037 001266      CLR    KBUFF        ;INSURE NO KEYBOARD GARBAGE
163 001672 005046                CLR    -(SP)        ;PUSH LEVEL 0 ONTO STACK
164 001674 012746 001702      MOV    #LISN,-(SP)  ;TO BE LSI-11 COMPATABLE
165 001700 000002                RTI                 ;FAKE RTI TO LOWER PRIORITY
166 001702 013700 001266      LISN: MOV    KBUFF,R0 ;LOOK FOR CHAR
167 001706 001775                BEQ    LISN         ;WAIT FOR ONE
168 001710 005037 001266      CLR    KBUFF        ;
169 001714 020027 000101      CMP    R0,#101      ;WAS IT A CHAR?
170 001720 103445                BCS    BOO800       ;NOT A GOOD CHAR
171 001722 042700 177740      BIC    #177740,R0   ;ELIMINATE LOWER CASE
172 001726 020027 000033      CMP    R0,#33       ;IS IT AN ALPHA CHAR?
173 001732 103040                BCC    BOO800       ;BR IF NOT
174 001734 006300                ASL    R0            ;MAKE UP WORD OFFSET
175 001736 005760 001746      TST    RTABLE-2(R0) ;IS IT A LEGAL COMMAND?
176 001742 001434                BEQ    BOO800       ;BR IF NOT
177 001744 000170 001746      JMP    @RTABLE-2(R0);GO DO IT

```

179					
180			.SBTTL	KEYBOARD DISPATCH TABLE	
181					
182	001750	002054	RTABLE:	ROUTA	: 'A' DISPLAY ISOTOPE A
183	001752	002066		ROUTB	: 'B' DISPLAY ISOTOPE B
184	001754	002100		ROUTC	: 'C' COLLECT DATA
185	001756	002110		ROUTD	: 'D' DISPLAY DATA
186	001760	002114		ROUTE	: 'E' ERASE SCOPE
187	001762	002124		ROUTF	: 'F' FREE RUN MODE(COLLECT NEW DATA & DISPLAY CONTINUOUSL
188	001764	002220		ROUTG	: 'G' INITIALIZE EVERYTHING
189	001766	002230		ROUTH	: 'H' HELP THE OPERATOR
190	001770	000000		0	: 'I' BOOBOO
191	001772	002302		ROUTJ	: 'J' GO TO NCV11 JOYSTICK CALIBRATION
192	001774	000000		0	: 'K' BOOBOO
193	001776	002320		ROUTL	: 'L' GET LOWER THRESHOLD FROM KEYBOARD
194	002000	002360		ROUTM	: 'M' SELECT VSV01 DISPLAY USING 2ND BIT MAP
195	002002	002420		ROUTN	: 'N' GET NEW DATA FROM CAMERA
196	002004	002434		ROUTO	: 'O' GET ADDRESS OF OTHER TERMINAL
197	002006	000000		0	: 'P' BOOBOO
198	002010	000000		0	: 'Q' BOOBOO
199	002012	002614		ROUTR	: 'R' REGULAR GAIN =1
200	002014	002632		ROUTS	: 'S' STOP COLLECTION
201	002016	002650		ROUTT	: 'T' DISPLAY INTENSITY TEST IMAGE ON SELECTED DISPLAY
202	002020	002664		ROUTU	: 'U' GET UPPER THRESHOLD FROM KEYBOARD
203	002022	000000		0	: 'V' BOOBOO
204	002024	002724		ROUTW	: 'W' SELECT VSV01 DISPLAY USING 1ST BIT MAP
205	002026	002762		ROUTX	: 'X' CHANGE CAMERA CHANNEL
206	002030	000000		0	: 'Y' BOOBOO
207	002032	003102		ROUTZ	: 'Z' ZOOM - GAIN 2

```

209 .SBTTL COMMAND DECODER
210 ;REPORTS ILLEGAL KEYBOARD CHARACTERS
211
212 002034 012737 000077 001270 BOOB00: MOV #77,TTYOUT ;SET UP '?'
213 002042 004737 005300 JSR PC,TYPO ;TYPE IT
214 002046 004737 005260 JSR PC,TYPCR ;DO A 'CR'
215 002052 000713 BR LISN ;GO LOOK FOR GOOD CHAR
216
217 002054 012737 020000 001314 ROUTA: MOV #MATRIX,TABLEX ;WILL DISPLAY ISOTOPE A
218 002062 000137 003122 JMP CHANGE ;GO DO IT
219 002066 012737 040000 001314 ROUTB: MOV #MATRIX+2000,TABLEX ;WILL DISPLAY ISOTOPE B
220 002074 000137 003122 JMP CHANGE ;GO DO IT
221 002100 004737 004704 ROUTC: JSR PC,NCSTRT ;GO START NCV11
222 002104 000137 001702 JMP LISN ;COLLECT DATA UNTIL KEYBRD COMMAND
223 002110 000137 003122 ROUTD: JMP CHANGE ;GO DISPLAY DATA
224 002114 004737 005020 ROUTE: JSR PC,ERASE ;GO ERASE SCOPE
225 002120 000137 001702 JMP LISN ;GO WAIT ON NEXT COMMAND
226 002124 012737 177777 001316 ROUTF: MOV #-1,FREERN ;SELECT FREE RUN MODE
227 002132 004737 004766 JSR PC,NCSTP1 ;GO STOP NCV11 & CLR CORE MATRIX AREA
228 002136 004737 004704 JSR PC,NCSTRT ;GO START NCV11
229 002142 005000 CLR R0 ;SET UP TIMER
230 002144 013701 001172 MOV TIME,R1 ;SET UP GROSS TIMER VALUE
231 002150 005300 1$: DEC R0 ;COUNT
232 002152 001376 BNE 1$ ;WAIT FOR ZERO
233 002154 042737 000040 001266 BIC #BIT5,KBUFF ;LOOK FOR POSSIBLE STOP KEY - RID LOWER CASE
234 002162 022737 000123 001266 CMP #123,KBUFF ;STOP BEEN STRUCK?
235 002170 001007 BNE 2$ ;BR IF NOT
236 002172 052777 000400 177010 BIS #BIT8,@NCSFR ;STOP NCV11
237 002200 005077 176774 CLR @NCCSR ;ZERO NCV CSR
238 002204 000137 001656 JMP LISEN ;GO AWAIT NEXT COMMAND
239 002210 005301 2$: DEC R1 ;DO LOOP AGAIN?
240 002212 001356 BNE 1$ ;BR IF SO
241 002214 000137 003122 JMP CHANGE ;NOW GO DISPLAY DATA JUST COLLECTED
242 002220 004737 005020 ROUTG: JSR PC,ERASE ;GO ERASE SELECTED DISPLAY
243 002224 000137 001562 JMP START1 ;INITIALIZE AND START FRESH
244 002230 005737 001324 ROUTH: TST NOVSV ;CHECK IF DISPLAY
245 002234 001016 BNE 1$ ;BR IF NO VSV01
246 002236 004737 005020 JSR PC,ERASE ;CLEAR THE SCREEN
247 002242 000240 NOP
248 002244 000240 NOP
249 002246 012777 002000 176750 MOV #2000,@VTVPOS ;POSITION THE READ-OUT
250 002254 004537 005316 JSR R5,VTWRIT ;TELL THE OPERATOR VIA VSV01
251 002260 010640 HELPO
252 002262 004537 005316 JSR R5,VTWRIT
253 002266 011336 HELP1
254 002270 000402 BR 2$
255 002272 104401 011336 1$: TYPE, HELP1 ;NO VSV01 - TELL OPERATOR SHORT LIST
256 002276 000137 001702 2$: JMP LISN
257 002302 005737 001324 ROUTJ: TST NOVSV ;CHECK IF VSV01 PRESENT
258 002306 001402 BEQ 1$ ;BR IF PRESENT
259 002310 000137 001702 JMP LISN ;FORGET IF NO DISPLAY
260 002314 000137 004332 1$: JMP TJOY ;CALB. THE JOYSTICK GO TO IT
261 002320 012746 000340 ROUTL: MOV #340,-(SP) ;PUSH HIGH PSW ON STACK
262 002324 012746 002332 MOV #1$,-(SP) ;PUSH RETURN ADDRESS
263 002330 000002 RTI ;FAKE RTI TO RAISE PSW
264 002332 104401 010161 1$: TYPE ,MSG2 ;ASK FOR OCTAL DATA
  
```

265	002336	104411			RDOCT		:GO GET IT
266	002340	012637	001272		MOV	(SP)+,THLO	:SAVE IT
267	002344	005046			CLR	-(SP)	:PUSH LOW PSW
268	002346	012746	002354		MOV	#2\$,-(SP)	
269	002352	000002			RTI		
270	002354	000137	003122	2\$:	JMP	CHANGE	:GO DISPLAY
271	002360	005737	001324	ROUTM:	TST	NOVSV	:TEST IF VSV01 DETECTED ?
272	002364	001013			BNE	1\$:BR IF NOT
273	002366	012737	177777	001320	MOV	#-1,MSELCT	:SELECT 2ND BIT MAP
274	002374	004737	004546		JSR	PC,SELCTA	:RELOAD ADDRESSES
275	002400	000240			NOP		
276	002402	013700	001226		MOV	VIVCSR,R0	:GET 2ND BIT MAP ADRS
277	002406	042760	000400	177760	BIC	#BIT8,-20(R0)	:TURN OFF 1ST BIT MAP
278	002414	000137	001702	1\$:	JMP	LISN	:GO AWAIT NEXT COMMAND
279	002420	004737	004766	ROUTN:	JSR	PC,NCSTP1	:GO STOP NCV11 & CLR CORE MATRIX
280	002424	004737	004704		JSR	PC,NCSTRT	:START THE NCV11
281	002430	000137	001702		JMP	LISN	:COLLECT DATA & AWAIT NEXT KEYBRD COMMAND
282	002434	012746	000340	ROUTO:	MOV	#340,-(SP)	:RAISE PS
283	002440	012746	002446		MCV	#1\$,-(SP)	
284	002444	000002			RTI		
285	002446	104401	010324	1\$:	TYPE	MSG4	:ASK OPR FOR ADDRESS
286	002452	104411			RDOCT		:GET HIS INPUT
287	002454	012600			MOV	(SP)+,R0	:GET ADDRESS
288	002456	001002			BNE	2\$:BR IF NOT 'CR' OR 0
289	002460	000137	002034		JMP	BOOB00	:FAT FINGER OPERATOR
290	002464	013746	000004	2\$:	MOV	@#ERRVEC,-(SP)	:SAVE LOC 4
291	002470	012737	002576	000004	MOV	#4\$,@#ERRVEC	:SAVE IF WRONG ADDRESS BY OPR.
292	002476	005710			TST	(R0)	:REF. THE NEW CONSOLE ADDR.
293	002500	012701	001144		MOV	#\$TKS,R1	:GET OLD ADDR. POINTER
294	002504	010021			MOV	R0,(R1)+	:LOAD NEW ADDRESS
298	002506	005720			TST	(R0)+	:BUMP ADDRESS
(1)	002510	010021			MOV	R0,(R1)+	:LOAD NEW ADDRESS
(1)	002512	005720			TST	(R0)+	:BUMP ADDRESS
(1)	002514	010021			MOV	R0,(R1)+	:LOAD NEW ADDRESS
(1)	002516	005720			TST	(R0)+	:BUMP ADDRESS
(1)	002520	010021			MOV	R0,(R1)+	:LOAD NEW ADDRESS
299	002522	012637	000004		MOV	(SP)+,@#ERRVEC	:RESTORE LOC 4.
300	002526	104401	010555		TYPE	MSG8	:ASK OPR FOR ADDRESS
301	002532	104411			RDOCT		
302	002534	012600			MOV	(SP)+,R0	:GET VALUE
303	002536	001002			BNE	3\$:BR IF VALID
304	002540	000137	002034		JMP	BOOB00	:BR IF NOT GOOD NUMBER
305	002544	042700	177003	3\$:	BIC	#177003,R0	:MASK OFF OTHER BITS
306	002550	010037	001174		MOV	R0,TKVECO	:SAVE THE VECTOR
307	002554	010037	001176		MOV	R0,TKVEC1	:SAVE THE BR LEVEL
308	002560	062737	000002	001176	ADD	#2,TKVEC1	: ADDRESS
309	002566	005046			CLR	-(SP)	
310	002570	012746	001326		MOV	#START,-(SP)	:LOWER PS AND START PROG AGAIN
311	002574	000002			RTI		
312	002576	022626		4\$:	CMP	(SP)+,(SP)+	:CLEAN STACK
313	002600	012637	000004		MOV	(SP)+,@#ERRVEC	:RESTORE LOC. 4
314	002604	005046			CLR	-(SP)	:LOWER PS
315	002606	012746	002034		MOV	#BOOB00,-(SP)	:RETURN
316	002612	000002			RTI		

318								
319	002614	005037	001302		ROUTR:	CLR	GAIN	:WANT REGULAR GAIN
320	002620	042777	002000	176352		BIC	#BIT'0,@NCCSR	:INSURE REGULAR GAIN
321	002626	000137	001702			JMP	LISN	:LOOK FOR NEXT COMMAND
322	002632	052777	000400	176350	ROUTS:	BIS	#BIT8,@NCSFR	:STOP NCV11
323	002640	005077	176334			CLR	@NCCSR	:ZERO NCV CSR
324	002644	000137	001702			JMP	LISN	:LOOK FOR NEXT COMMAND
325	002650	004737	004744		ROUTT:	JSR	PC,NCSTP	:GO STOP THE NCV1' IF RUNNING
326	002654	004737	005152			JSR	PC,LDIMGE	:GO SET UP TEST CORE IMAGE
327	002660	000137	003122			JMP	CHANGE	:GO DISPLAY IT
328	002664	012746	000340		ROUTU:	MOV	#340,-(SP)	
329	002670	012746	002676			MOV	#1\$,-(SP)	
330	002674	000002				RTI		
331	002676	104401	010161		1\$:	TYPE	,MSG2	:ASK FOR OCTAL DATA
332	002702	104411				RDOCT		:GO GET IT
333	002704	012637	001274			MOV	(SP),,THHI	:SAVE IT
334	002710	005046				CLR	-(SP)	
335	002712	012746	002720			MOV	#2\$,-(SP)	
336	002716	000002				RTI		
337	002720	000137	003122		2\$:	JMP	CHANGE	:GO DISPLAY
338	002724	005737	001324		ROUTW:	TST	NOVSV	:TEST IF VSV01 DETECTED
339	002730	001012				BNE	1\$:BR IF NOT
340	002732	005037	001320			CLR	MSELECT	:SELECT 1ST BIT MAP
341	002736	004737	004546			JSR	PC,SELCTA	:CHANGE ADDRESSES
342	002742	000240				NOP		
343	002744	013700	001226			MOV	VTVCSR,R0	:GET 1ST BIT MAP ADRS
344	002750	042760	000400	000020		BIC	#BIT8,20(R0)	:TURN OFF 2ND BIT MAP
345	002756	000137	001702		1\$:	JMP	LISN	:GO AWAIT NEXT COMMAND
346	002762	012746	000340		ROUTX:	MOV	#340,-(SP)	
347	002766	012746	002774			MOV	#1\$,-(SP)	
348	002772	000002				RTI		
349	002774	104401	010520		1\$:	TYPE	MSG7	:TELL OPERATOR TO SELECT CAMERA
350	003000	104411				RDOCT		:WAIT FOR HIS INPUT
351	003002	012637	003076			MOV	(SP)+,10\$:GET CHAR.
352	003006	000240				NOP		
353	003010	000240				NOP		
354	003012	000240				NOP		
355	003014	042737	177774	003076		BIC	#177774,10\$:MASK OFF BITS
356	003022	005237	003076			INC	10\$	
357	003026	005037	003100			CLR	11\$:CLEAR ACTUAL VALUE
358	003032	005337	003076		2\$:	DEC	10\$	
359	003036	001403				BEQ	3\$	
360	003040	005237	003100			INC	11\$:UPDATE ACUTAL
361	003044	000772				BR	2\$	
362	003046	11_737	003100	001301	3\$:	MOVB	11\$,CAMERA+1	:UPDATE CAMERA SAVE LOC.
363	003054	053777	001300	176116		BIS	CAMERA,@NCCSR	:AND SELECT THAT CAMERA
364	003062	005046				CLR	-(SP)	
365	003064	012746	003072			MOV	#4\$,-(SP)	
366	003070	000002				RTI		
367	003072	000137	003122		4\$:	JMP	CHANGE	:RETURN
368	003076	000000			10\$:	0		
369	003100	000000			11\$:	0		
370	003102	012737	002000	001302	ROUTZ:	MOV	#BIT10,GAIN	:ENABLE GAIN
371	003110	053777	001302	176062		BIS	GAIN,@NCCSR	:SET IT AT NCV CSR
372	003116	000137	001702			JMP	LISN	:GO AWAIT NEXT COMMAND

```

374          .SBTTL PROGRAM ROUTINES
375          ;GO CLEAR SCREEN OF SELECTED DISPLAY
376
377 003122 004737 005020      CHANGE: JSR      PC,ERASE          ;GO ERASE SCOPE
378
379          ;STOP NCV11 AND GET SET TO DISPLAY
380
381 003126 004737 004744          JSR      PC,NCSTP          ;GO STOP NCV11
382
383 003132 005737 001324          TST      NOVSV          ;TEST IF VSV01 DETECTED
384 003136 001402          BEQ      BOX          ;BR IF YES
385 003140 000137 001702          JMP      LISN          ;RETURN IF NOT
386          ;NOW DRAW A BOX AROUND POTENTIAL MATRIX DISPLAY
387          ;AREA ON THE SELECTED DISPLAY
388 003144 012700 001750      BOX:  MOV      #1750,R0          ;SET UP BIT MAP ADRS - TOP LINE
389 003150 012701 073567          MOV      #73567,R1        ;SET UP PIXEL DATA IN R1 - INT 7
390 003154 004737 005060          JSR      PC,DISPY        ;GO LOAD BIT MAP
391 003160 005200          1$:  INC      R0          ;ADVANCE ADRS
392 003162 022700 001770          CMP      #1770,R0        ;TOP LINE DONE?
393 003166 001403          BEQ      2$          ;BR IF SO
394 003170 004737 005072          JSR      PC,DCONT        ;LOAD NEXT PIXEL WD
395 003174 000771          BR       1$          ;NEXT MAP LOAD
396 003176 012700 006010          2$:  MOV      #6010,R0        ;SET UP BIT MAP ADRS - BOT LINE
397 003202 004737 005060          JSR      PC,DISPY        ;GO LOAD BIT MAP
398 003206 005200          3$:  INC      R0          ;ADVANCE ADRS
399 003210 022700 006030          CMP      #6030,R0        ;BOT LINE DONE?
400 003214 001403          BEQ      4$          ;BR IF SO
401 003216 004737 005072          JSR      PC,DCONT        ;LOAD NEXT PIXEL WD
402 003222 000771          BR       3$          ;NEXT MAP LOAD
403 003224 012700 001730          4$:  MOV      #1730,R0        ;SET UP BIT MAP ADRS SIDE LINES
404 003230 062700 000017          5$:  ADD      #17,R0          ;OFFSET NEXT ROW
405 003234 012701 070000          MOV      #70000,R1       ;SET UP PIXEL 3 DATA IN R1 - INT 7
406 003240 022700 006047          CMP      #6047,R0        ;AT BOTTOM OF SCREEN?
407 003244 001411          BEQ      6$          ;GO START VSV01 DISPLAY
408 003246 004737 005060          JSR      PC,DISPY        ;GO LOAD BIT MAP
409 003252 012701 000007          MOV      #7,R1          ;SET UP PIXEL 0 DATA IN R1 - INT 7
410 003256 062700 000021          ADD      #21,R0          ;OFFSET TO RIGHT LINE
411 003262 004737 005060          JSR      PC,DISPY        ;GO LOAD BIT MAP
412 003266 000760          BR       5$          ;DO NEXT ROW
413 003270 013777 001254 175730 6$:  MOV      VIVSAV,@VTVCSR ;START DISPLAY
414 003276 012737 002010 001260          MOV      #2010,MAPADR   ;OFFSET BIT MAP ADRS
415 003304 012737 000003 001262          MOV      #3,PIXCNT      ;SET UP PIXEL BYTE COUNT
416 003312 005037 001264          CLR      PIXASM         ;CLR PIXEL ASSEMBLY WORD
417
418          ;NOW LETS FIND THE LARGEST CELL
419 003316 013737 001304 001306      LARGES: MOV      TOTSIZ,CHARCT ;NUMBER OF ELEMENTS TO CONSIDER
420 003324 017700 175764          MOV      @TABLEX,R0     ;THIS IS FIRST GUESS
421 003330 013701 001314          MOV      TABLEX,R1     ;R1 POINTS TO TABLE
422 003334 020021          1$:  CMP      R0,(R1)+        ;COMPARE GUESS AGAINST NEW
423 003336 103005          BHS     3$          ;GUESS STILL GOOD
424 003340 024137 001274          CMP      -(R1),THHI     ;GUESS SMALLER BUT CHECK NEW
425 003344 101001          BHI     2$          ;HI AGAINST UPPER THRESHOLD
426 003346 011100          MOV      (R1),R0        ;WITHIN BOUNDS. MAKE THIS NEW HI
427 003350 005721          2$:  TST      (R1)+        ;INCREASE REGISTER BY 2
428 003352 005337 001306          3$:  DEC      CHARCT       ;COUNT THIS LAST COMPARISON
429 003356 001366          BNE     1$

```

```

431 ;THE LARGEST CELL WITHIN THE UPPER THRESHOLD IS NOW IN R0
432 ;NOW ACCOUNT FOR LOWER THRESHOLD - BOW OUT IF TOO SMALL
433 003360 163700 001272 SUB THLO,R0 ;SUBTRACT LOWER THRESHOLD
434 003364 101002 BHI 4$ ;BR IF CELL VALUE GREATER THAN LO THRESHOLD
435 003366 000137 003720 JMP PATWRT ;DON'T DISPLAY-ALL VALUES BELOW LO THRESHOLD
436 003372 010037 001310 4$: MOV R0,CPERL ;SAVE LARGEST CELL OF MATRIX
437
438 ;NOW PICK OUT EACH VALUE IN CORE MATRIX AND SCALE TO THE
439 ;PROPER INTENSITY LEVEL. THEN DISPLAY IT ON THE SELECTED DISPLAY
440
441 003376 013737 001314 001256 DMATRIX: MOV TABLEX,MRXADR ;BEGIN AT TOP LEFT ROW
442 003404 062737 017600 001256 ADD #8064.,MRXADR ;OFFSET TO BOTTOM OF CORE MATRIX
443 003412 012737 000100 001312 MOV #64.,ROWCNT ;THERE ARE 64 CELLS PER ROW
444 003420 017702 175632 DISLOP: MOV @MRXADR,R2 ;GET A CELL VALUE FROM MATRIX
445 003424 062737 000002 001256 ADD #2,MRXADR ;BUMP MATRIX ADRS
446 003432 005337 001312 DEC ROWCNT ;COUNT CELL THIS ROW
447 003436 001006 BNE 1$ ;BR IF ROW NOT FINISHED
448 003440 012737 000100 001312 MOV #64.,ROWCNT ;RESET NEXT ROW COUNT
449 003446 162737 000400 001256 SUB #256.,MRXADR ;SET UP FOR NEXT ROW IN MATRIX
450 003454 020237 001274 1$: CMP R2,THHI ;CELL WITHIN HI THRESHOLD?
451 003460 101003 BHI 2$ ;BR IF NOT
452 003462 163702 001272 SUB THLO,R2 ;SUB LOW THRESHOLD
453 003466 101002 BHI SCLCEL ;BR IF CELL ABOVE LOW THRESHOLD
454 003470 005004 2$: CLR R4 ;SET CELL TO LOWEST INTENSITY
455 003472 000423 BR MAPLD
456 003474 013701 001310 SCLCEL: MOV CPERL,R1 ;NOW ESTABLISH THE INTENSITY LEVEL
457 003500 012703 000005 MOV #5,R3 ;SCALE TO 16 LEVELS
458 003504 005004 CLR R4
459 003506 006304 2$: ASL R4 ;MUL BY 2
460 003510 020201 CMP R2,R1 ;COMPARE THIS CELL TO LARGEST
461 003512 103404 BLO 4$ ;BR IF SMALLER
462 003514 005701 TST R1 ;CHECK CASE WHERE 0 DEVISOR
463 003516 001401 BEQ 3$ ;BR IF SO
464 003520 005204 INC R4 ;ACCOUNT FOR GOOD SUBTRACTION
465 003522 160102 3$: SUB R1,R2 ;NO DO THE SUBTRACTION
466 003524 000241 4$: CLC
467 003526 006001 ROR R1 ;MAKE DEVISOR SMALLER
468 003530 005303 DEC R3 ;COUNT POSITION
469 003532 001365 BNE 2$ ;AGAIN IF NOT SCALLED TO 16 LEVELS YET
470 003534 160102 SUB R1,R2 ;ACCOUNT FOR REMAINDER
471 003536 101401 BLOS MAPLD ;BR IF TOO SMALL
472 003540 005204 INC R4 ;ROUND UP

```

```

474                                     ;THIS CODE DISPLAYS EACH SCALED CELL ON THE VSV01 (ONE OF 16 LEVELS)
475
476 003542 013700 001260 MAPLD: MOV MAPADR,R0 ;SET UP BIT MAP ADRS
477 003546 005704 TST R4 ;LOOK FOR NO INTENSITY
478 003550 001401 BEQ 1$ ;BR IF NO INTENSITY
479 003552 005304 DEC R4 ;OFFSET TO 0-17
480 003554 000304 1$: SWAB R4 ;PREPARE FOR PIXEL LOC
481 003556 006304 ASL R4 ;MOVE TO TOP 4 BITS
482 003560 006304 ASL R4
483 003562 006304 ASL R4
484 003564 006304 ASL R4
485 003566 000241 CLC ;NOW ASSEMBLE THIS PIXEL INTO PIXEL WORD
486 003570 006037 001264 ROR PIXASM ;NOW MAKE ROOM IN PIXEL WORD
487 003574 006037 001264 ROR PIXASM
488 003600 006037 001264 ROR PIXASM
489 003604 006037 001264 ROR PIXASM
490 003610 060437 001264 ADD R4,PIXASM ;ADD THIS PIXEL TO OTHERS
491 003614 005737 001262 TST PIXCNT ;ALL 4 PIXELS DONE FOR THIS WORD?
492 003620 001004 BNE 2$ ;BR IF NOT
493 003622 013701 001264 MOV PIXASM,R1 ;LD PIXEL WORD INTO R1
494 003626 004737 005060 JSR PC,DISPY ;LOAD BIT MAP
495 003632 005337 001262 2$: DEC PIXCNT ;COUNT PIXEL
496 003636 100270 BPL DISLOP ;BR IF 4 PIXELS NOT ASSEMBLED YET
497 003640 005037 001264 CLR PIXASM ;CLR PIXEL ASSEMBLY WORD
498 003644 012737 000003 001262 MOV #3,PIXCNT ;RESET PIXEL COUNT
499 003652 005237 001260 INC MAPADR ;ADVANCE MAP ADRS
500 003656 013700 001260 MOV MAPADR,R0 ;LOAD INTO R0
501 003662 022700 005770 CMP #5770,R0 ;HAVE ALL 64 ROWS BEEN DONE?
502 003666 001002 BNE 3$ ;BR IF NOT
503 003670 000137 003720 JMP PATWRT ;NOW GO DISPLAY PARAMETERS
504 003674 042700 177740 3$: BIC #177740,R0 ;SAVE ROW POSITION BITS
505 003700 022700 000030 CMP #30,R0 ;NOW LOOK FOR END OF ROW
506 003704 001003 BNE 4$ ;BR IF NOT AT END
507 003706 062737 000020 001260 ADD #20,MAPADR ;ADVANCE MAP ADRS TO NEXT ROW
508 003714 000137 003420 4$: JMP DISLOP ;GO GET NEXT MATRIX DATUM

```

```

510          ;CODE TO WRITE PARAMETER DATA AT BOTTOM OF SCREEN
511
512 003720 012777 012000 175276 PATWRT: MOV      #12000,@VTVPOS ;VSV01 - SET CHAR POS,LINE 20, LEFT MARGIN
513 003726 004537 005316          JSR      R5,VTWRIT
514 003732 007664          WDO01          ;'CR,LOWER THRESHOLD'
515 003734 004537 005342          JSR      R5,AWRIT ;DISPAY OCTAL
516 003740 001272          THLO
517 003742 004537 005316          JSR      R5,VTWRIT
518 003746 007707          WDO02          ;'CR, UPPER THRESHOLD'
519 003750 004537 005342          JSR      R5,AWRIT ;DISPAY OCTAL
520 003754 001274          THHI
521 003756 113737 001301 001246        MOVB    CAMERA+1,DUMMY1 ;GET CAMERA VALUE
522 003764 062737 000060 001246        ADD     #60,DUMMY1 ;MAKE ASCII
523 003772 113737 001246 010022        MOVB    DUMMY1,CAMOUT ;SAVE FOR READOUT
524          ;TEST THE 'PB' FLAG
525 004000 032777 000040 175202        BIT     #BIT5,@NCSFR ;TEST FOR 'PB' FLAG
526 004006 001007          BNE     1$ ;BR IF SET
527 004010 112737 000125 010036        MOVB    #'U,PBUP ;NO- TELL OPER. IT WAS UP
528 004016 112737 000120 010037        MOVB    #'P,PBUP+1
529 004024 000406          BR     2$
530 004026 112737 000104 010036 1$: MOVB    #'D,PBUP ;TFLL OPER. IT WAS DN
531 004034 112737 000116 010037        MOVB    #'N,PBUP+1
532          ;TEST FOR JOY-STICK BUTTON FLAG
533 004042 032777 000100 175140 2$: BIT     #BIT6,@NCSFR ;TEST FOR 'JOY-BUTTON' FLAG
534 004050 001007          BNE     3$ ;BR IF SET
535 004052 112737 000125 010053        MOVB    #'U,JBUP ;TELL OPER. IT WAS UP
536 004060 112737 000120 010054        MOVB    #'P,JBUP+1
537 004066 000406          BR     4$
538 004070 112737 000104 010053 3$: MOVB    #'D,JBUP ;TELL OPER. IT WAS DN
539 004076 112737 000116 010054        MOVB    #'N,JBUP+1
540 004104 004537 005316          4$: JSR      R5,VTWRIT ;DISPLAY CAMERA VALUE AND BUTTON STATUS
541 004110 010007          WDO07
542 004112 004537 005316          JSR      R5,VTWRIT
543 004116 007735          WDO03          ;'Z COUNT ='
544 004120 017737 175062 001246        MOV     @NCBAR,DUMMY1
545 004126 017737 175052 001250        MOV     @NCWCR,DUMMY2
546 004134 004537 005342          JSR      R5,AWRIT ;DISPALY OCTAL
547 004140 001250          DUMMY2
548 004142 004537 005316          JSR      R5,VTWRIT ;INSERT '-'
549 004146 010634          DASH
550 004150 004537 005342          JSR      R5,AWRIT ;DISPLAY OCTAL
551 004154 001246          DUMMY1
552 004156 004537 005316          JSR      R5,VTWRIT
553 004162 007750          WDO04          ;'MATRIX COUNT-'
554

```

```

556 ;DETERMINE THE # OF COUNTS IN THE MATRIX
557
558 004164 013737 001304 001240      MOV    TOTSIZ,TEMPO
559 004172 005002                    CLR    R2
560 004174 005003                    CLR    R3
561 004176 013701 001314      MOV    TABLEX,R1
562 004202 062103      MXSML:  ADD    (R1)+,R3      ;NOW ADD UP ALL VALUES IN MATRIX
563 004204 005502                    ADC    R2
564 004206 005337 001240      DEC    TEMPO
565 004212 001373                    BNE    MXSML
566 004214 010337 001246      MOV    R3,DUMMY1
567 004220 010237 001250      MOV    R2,DUMMY2
568 004224 004537 005342      JSR    R5,AWRIT      ;TELL OPER. OCTAL
569 004230 001250                    DUMMY2
570 004232 004537 005316      JSR    R5,VTWRIT    ;INSERT DASH
571 004236 010634                    DASH
572 004240 004537 005342      JSR    R5,AWRIT
573 004244 001246                    DUMMY1
574 004246 004537 005316      JSR    R5,VTWRIT
575 004252 011716                    BCRLF
576
577 ;TEST FOR GAIN = 2 AND B GAMMA STATES
578
579 004254 005737 001302      TST    GAIN
580 004260 001403                    BEQ    1$
581 004262 004537 005316      JSR    R5,VTWRIT
582 004266 007767                    W0005      ;'ZOOM'
583 004270 023727 001314 040000 1$:  CMP    TABLEX,#MATRIX+20000 ;ISOTOPE B?
584 004276 001003                    BNE    2$      ;NO
585 004300 004537 005316      JSR    R5,VTWRIT      ;YES
586 004304 007776                    W0006      ;'B-GAMMA'
587 004306 005737 001316      2$:  TST    FREERN      ;IN FREE RUN MODE?
588 004312 001402                    BEQ    3$      ;BR IF NOT
589 004314 000137 002124      JMP    ROUTF      ;YES, GO GET NEW DATA
590 004320 013777 001276 174652 3$:  MOV    COMSAV,@NCCSR ;RESUME THE NCV11
591 004326 000137 001702      JMP    LISN      ;DONE WITH MESSAGES
  
```

```

593 ;THIS CODE DRAWS CROSS HAIRS(VSV01) WITH THE X & Y JOYSTICK DATA
594 ;THE BUG WILL FOLLOW THE JOYSTICK WHEN THE INTERRUPT BAR IS NOT DEPRESSED -
595 ;ALL PARTS WITHIN THE DISPLAYED BOX ON THE SELECTED DISPLAY SHOULD
596 ;BE ACCESSIBLE IN A UNIFORM MANNER
597 ;A CNTRL 'C' WILL GET USER BACK TO KEYBOARD MONITOR
598 004332 004737 005020 TJOY: JSR PC,ERASE ;START FRESH
599
600 ;DRAW A BOX UP ON VSV01 SCREEN FOR NCV11 JOYSTICK CALIBRATION
601 004336 005000 CLR R0 ;SET UP BIT MAP ADRS - TOP LINE
602 004340 012701 073567 MOV #73567,R1 ;SET UP PIXEL DATA IN R1 - INT 7
603 004344 004737 005060 JSR PC,DISPY ;GO LOAD BIT MAP
604 004350 005200 1$: INC R0 ;ADVANCE BIT MAP ADRS
605 004352 022700 000040 CMP #40,R0 ;TOP LINE DONE?
606 004356 001403 BEQ 2$ ;BR IF SO
607 004360 004737 005072 JSR PC,DCONT ;LOAD NEXT PIXEL
608 004364 000771 BR 1$ ;NEXT MAP LOAD
609 004366 012700 007740 2$: MOV #7740,R0 ;SET UP BIT MAP ADRS - BOT LINE
610 004372 004737 005060 JSR PC,DISPY ;GO LOAD BIT MAP
611 004376 005200 3$: INC R0 ;ADVANCE ADRS
612 004400 022700 010000 CMP #10000,R0 ;BOT LINE DONE?
613 004404 001403 BEQ 4$ ;BR IF SO
614 004406 004737 005072 JSR PC,DCONT ;LOAD NEXT PIXEL WORD
615 004412 000771 BR 3$ ;NEXT MAP LOAD
616 004414 012700 000040 4$: MOV #40,R0 ;SET UP BIT MAP ADRS SIDE LINES
617 004420 012701 000007 5$: MOV #7,R1 ;SET UP PIXEL 0 DATA IN R1 - INT 7
618 004424 004737 005060 JSR PC,DISPY ;GO LOAD BIT MAP
619 004430 012701 070000 MOV #70000,R1 ;SET UP PIXEL 3 DATA IN R1 - INT 7
620 004434 062700 000037 ADD #37,R0 ;OFFSET TO RIGHT SIDE LINE
621 004440 004737 005060 JSR PC,DISPY ;GO LOAD BIT MAP
622 004444 005200 INC R0 ;GO TO NEXT ROW ON LEFT
623 004446 022700 007740 CMP #7740,R0 ;TO BOTTOM YET?
624 004452 001362 BNE 5$ ;BR IF NOT
625 004454 013777 001254 174544 MOV VTVSAV,@VTVCSR ;ENABLE BIT MAP
626
627 ;NOW COLLECT ANALOG DATA FROM NCV11 JOYSTICK
628
629 004462 012777 004000 174520 DISBG: MOV #BIT11,@NCSFR ;CLEAR THE DEVICE
630 004470 052777 000001 174512 1$: BIS #BIT0,@NCSFR ;CONVERT JOYSTICK
631 004476 105777 174506 2$: TSTB @NCSFR ;DONE?
632 004502 100375 BPL 2$ ;BR IF NOT
633 004504 017737 174504 001240 MOV @NCJOY,TEMPO ;STORE CONVERSION VALUES
634 004512 000240 NOP
635 004514 000240 NOP
636 004516 000240 NOP
637 004520 004737 005472 JSR PC,XYAVE ;GO AVG LAST 32. X-Y JOYSTICK VALUES
638 004524 032777 000040 174456 BIT #BITS,@NCSFR ;LOOK FOR JOY BOTTON DOWN
639 004532 001356 BNE 1$ ;DON'T MOVE THE BUG
640 004534 000240 NOP
641 004536 000240 NOP
642 004540 004737 005122 JSR PC,DISPY2 ;GO DISPLAY CROSS HAIRS - VSV01
643 004544 000751 BR 1$ ;DO ANOTHER CONVERSION

```

```

648 ;:*****
649 ;ROUTINE SELECTS VSV01 DISPLAY - SETS UP BUS ADRS AND INTENSITY LEVEL
650 ;AND INTENSITY LOOK-UP TABLE - THE CARRY BIT IS SET ON EXIT IF THE
651 ;VSV01 IS NOT SEEN AT THE ASSIGNED BUS ADDRESS
652 ;:*****
653 004546 013700 001166 SELCTA: MOV VTVADR,R0 ;GET VSV01 BASE ADRS
654 004552 012701 001220 MOV #VTVCRG,R1 ;GET PTR ADRS
655 004556 010021 1$: MOV R0,(R1)+ ;SET UP REG ADRS PTRS
656 004560 062700 000002 ADD #2,R0 ;BUMP REG ADRS
657 004564 022701 001226 CMP #VTVCSR,R1 ;CHAR GEN REGS ALL SET UP?
658 004570 001372 BNE 1$ ;BR IF NOT
659 004572 013700 001170 MOV VTMADR,R0 ;GET BASE ADRS OF BIT MAP
660 004576 005737 001320 TST MSELCT ;USING SECOND MAP?
661 004602 001402 BEQ 2$ ;BR IF NOT
662 004604 062700 000020 ADD #20,R0 ;POINT TO 2ND BIT MAP ADRS'S
663 004610 010021 2$: MOV R0,(R1)+ ;CONTINUE TO BIT MAP ADRS'S
664 004612 062700 000002 ADD #2,R0 ;BUMP REG ADRS
665 004616 022701 001240 CMP #VTVINT+2,R1 ;ALL SET UP?
666 004622 001372 BNE 2$ ;BR IF NOT
667 004624 012737 004676 000004 MOV #5$,@ERRVEC ;SET UP BUS TIMEOUT RETURN ADRS IF NO VSV01
668 004632 005777 174362 TST @VTVCRG ;IS CHARACTER GENERATOR THERE?
669 004636 005777 174364 TST @VTVCSR ;IS BIT MAP THERE?
670 004642 013700 001252 MOV INTLUT,R0 ;SET UP ADRS & DATA OF INTENSITY LOOK-UP TABLE
671 004646 010077 174364 3$: MOV R0,@VTVINT ;SET UP TABLE
672 004652 062700 000401 ADD #401,R0 ;ADVANCE ADRS & INTENSITY
673 004656 032700 010000 BIT #10000,R0 ;TABLE LOADED?
674 004662 001771 BEQ 3$ ;BR IF NOT
675 004664 000241 CLC ;ZERO CARRY SAYS VSV01 THERE
676 004666 012737 000006 000004 4$: MOV #FRRVEC+2,@FRRVEC ;RESTORE ER TRAP LOC TO PT TO 6
677 004674 000207 RTS PC ;EXIT
678 004676 022626 5$: CMP (SP)+,(SP)+ ;FIX STACK SINCE NO RTI
679 004700 000261 SEC ;CARRY ON EXIT SAYS NO VSV01
680 004702 000771 BR 4$ ;GO EXIT
681
682 ;:*****
683 ;ROUTINE STARTS NCV11 AT SELECTED GAIN AND CAMERA
684 ;:*****
685 004704 012777 004030 174266 NCSTRT: MOV #4030,@NCCSR ;SET UP ZB ENABLE AND 64*64 WORD MATRIX
686 004712 012777 020000 174262 MOV #MATRIX,@NCOFF ;ENSURE OFFSET REG. IS SET
687 004720 053777 001302 174252 BIS GAIN,@NCCSR ;SET UP GAIN
688 004726 053777 001300 174244 BIS CAMERA,@NCCSR ;SET UP CAMERA
689 004734 052777 000001 174236 BIS #BIT0,@NCCSR ;SET GO BIT
690 004742 000207 RTS PC ;RETURN
691
692 ;:*****
693 ;ROUTINE STOPS NCV11 AND SAVES NCV11 STATUS
694 ;:*****
695 004744 017737 174230 001276 NCSTP: MOV @NCCSR,COMSAV ;SAVE THE INTERFACE ACTION
696 004752 052777 000400 174230 BIS #BIT8,@NCSFR ;DISABLE NPR'S
697 004760 005077 174214 CLR @NCCSR ;ZERO ALL STATUS
698 004764 000207 RTS PC ;RETURN
  
```

```

700 ;:*****
701 ;ROUTINE STOPS NCV11, SAVES STATUS AND CLEARS MATRIX CORE AREA
702 ;:*****
703 004766 004737 004744 NCSTP1: JSR PC,NCSTP ;GO STOP NCV11 AND SAVE STATUS
704 004772 005077 174206 CLR @NCWCR ;CLEAR HIGH WORD
705 004776 005077 174204 CLR @NCBAR ;CLEAR LOW WORD
706 005002 012700 020000 MOV @MATRIX,R0 ;GET SET TO ZERO CORE MATRIX AREA
707 005006 005020 1$: CLR (R0)+ ;ZERO LOC
708 005010 020027 060000 CMP R0,@MATRIX+40000 ;ALL DONE?
709 005014 001374 BNE 1$ ;BR IF MORE
710 005016 000207 RTS PC ;RETURN
711
712 ;:*****
713 ;ROUTINE WILL ERASE DISPLAY
714 ;:*****
715 005020 005737 001324 ERASE: TST NOVSV ;TEST IF VSV01 DETECTED
716 005024 001014 BNE 2$ ;BR IF NOT
717 005026 052777 001000 174172 BIS #1000,@VTVCSR ;ERASE DISPLAY (CLR BIT MAP)
718 005034 105777 174166 1$: TSTB @VTVCSR ;LOOK FOR READY
719 005040 100375 BPL 1$ ;WAIT FOR IT
720 005042 042777 001000 174156 BIC #1000,@VTVCSR ;TURN OFF ERASE DISPLAY
721 005050 012777 002035 174142 MOV #2035,@VTVCRG ;CLR CHAR SCREEN & DISABLE CURSOR
722 005056 000207 2$: RTS PC ;EXIT
723
724 ;:*****
725 ;ROUTINE WILL LOAD BIT MAP (VSV01)
726 ;R0 CONTAINS BIT MAP ADRS AND R1 THE BIT MAP DATA
727 ;:*****
728 005060 042777 000400 174140 DISPY: BIC #400,@VTVCSR ;STOP DISPLAY
729 005066 010077 174136 MOV R0,@VTVMAP ;LOAD BIT MAP ADRS
730 005072 042777 000400 174126 DCONT: BIC #400,@VTVCSR ;AGAIN IF ENTERING HERE
731 005100 105777 174122 1$: TSTB @VTVCSR ;READY?
732 005104 100375 BPL 1$ ;WAIT THEN
733 005106 010177 174120 MOV R1,@VTVPX ;LOAD BIT MAP
734 005112 052777 000400 174106 BIS #400,@VTVCSR ;RESUME DISPLAY
735 005120 000207 RTS PC ;RETURN
736
737 ;:*****
738 ;ROUTINE WILL DISPLAY X & Y CROSS HAIRS ON VSV01
739 ;:*****
740 DISPY2: TST @VTVCRG ;READY?
741 005122 005777 174072 BPL DISPY2 ;WAIT IF NOT
742 005126 100375 COMB TEMPO+1 ;X NEEDS TO BE INVERTED
743 005130 105137 001241 MOV TEMPO,@VTVCHP ;LOAD X & Y CROSS HAIRS
744 005134 013777 001240 174060 BIS #16000,@VTVCRG ;ENABLE THE CROSS HAIRS
745 005142 052777 016000 174050 RTS PC ;RETURN
746 005150 000207

```

```
748
749
750
751
752
753
754
755 005152 012700 000100 LDIMGE: MOV #100,R0 ;COUNT 64 ROWS
756 005156 013701 001314 MOV TABLEX,R1 ;GET SELECTED ISOTOPE
757 005162 012702 000100 MOV #100,R2 ;COUNT 64 DATA POINTS PER ROW
758 005166 012703 000100 MOV #100,R3 ;100 WILL REPRESENT HIGHEST INTENSITY LEVEL(100-0)
759 005172 010321 1$: MOV R3,(R1)+ ;LOAD CORE IMAGE
760 005174 005302 DEC R2 ;DONE ROW?
761 005176 001375 BNE 1$ ;BR IF NOT
762 005200 005300 DEC R0 ;DONE ROWS?
763 005202 001405 BEQ 2$ ;BR IF SO
764 005204 162703 000001 SUB #1,R3 ;LOWER NEXT CELL VALUE
765 005210 012702 000100 MOV #100,R2 ;RESET ROW LENGTH COUNTER
766 005214 000766 BR 1$ ;LOAD THIS ROW IMAGE
767 005216 000207 2$: RTS PC ;RETURN FOR DISPLAY
768
769
770
771
772
773 005220 017737 173722 001266 KBINT: MOV @STKB,KBUFF ;READ KEY BOARD
774 005226 013777 001266 173716 MOV KBUFF,@STPB ;ECHO CHAR.
775 005234 042737 177600 001266 BIC #177600,KBUFF ;RID PARITY
776 005242 022737 000003 001266 CMP #3,KBUFF ;CNTRL 'C'?
777 005250 001002 BNE 1$ ;BR IF NOT
778 005252 000137 001656 JMP LISEN ;ABORT WHATEVER & LOOK FOR NEXT COMMAND
779 005256 000002 1$: RTI
780
781
782
783
784 005260 012737 000015 001270 TYP CR: MOV #15,TTYOUT ;SET UP FOR A 'CR'
785 005266 004737 005300 JSR PC,TYPO
786 005272 012737 000012 001270 MOV #12,TTYOUT ;SET UP FOR LF
787 005300 105777 173644 TYPO: TSTB @STPS ;WAIT FOR LAST CHARACTER
788 005304 100375 BPL TYPO
789 005306 013777 001270 173636 MOV TTYOUT,@STPB ;SEND IT OUT
790 005314 000207 RTS PC
```

```

792
793
794
795
796 005316 012504
797 005320 005777 173674
798 005324 100375
799 005326 105714
800 005330 001403
801 005332 112477 173662
802 005336 000770
803 005340 000205
804
805
806
807
808 005342 012537 005454
809 005346 017737 000102 005454
810 005354 010046
811 005356 012700 005470
812 005362 012737 000006 005460
813 005370 000406
814 005372 006237 005454
815 005376 006237 005454
816 005402 006237 005454
817 005406 013737 005454 005456
818 005414 042737 177770 005456
819 005422 062737 000060 005456
820 005430 113740 005456
821 005434 005337 005460
822 005440 001354
823 005442 012600
824 005444 004537 005316
825 005450 005462
826 005452 000205
827 005454 000000
828 005456 000000
829 005460 000005
830 005462 060 060 060 060 060 060
    005465 060 060
831 005470 000
832 005472
  
```

```

:*****
:THIS SUBROUTINE IS CALLED WITH THE ADDRESS OF A MESSAGE TERM WITH A 0 BYTE
:*****
VTWRIT: MOV      (R5)+,R4          ;GET ADDRESS OF MESSAGE IN R4
1$:     TST      @VTVCRG          ;WAIT FOR READY
        BPL      1$
        TSTB     (R4)             ;TERM ?
        BEQ      2$              ;BR IF YES
        MOVB     (R4)+,@VTVCRG    ;LOAD THE CHARACTER
        BR       1$
2$:     RTS      R5              ;EXIT

:*****
:THIS ROUTINE CONVERTS OCTAL INTO ASCII FOR DISPLAY
:*****
AWRIT:  MOV      (R5)+,10$        ;GET VALUE'S ADDRESS
        MOV      @10$,10$        ;GET ACTUAL VALUE
        MOV      R0,-(SP)        ;SAVE R0
        MOV      #NUMEND,R0      ;LOAD LAST ADDRESS OF OCTAL TYPEOUT
        MOV      #6,12$         ;LOAD LOOP COUNTER
1$:     BR       2$
        ASR      10$            ;SHIFT DATA
        ASR      10$
        ASR      10$
2$:     MOV      10$,11$         ;COPY THE VALUE
        BIC      #177770,11$     ;MASK OFF UNWANTED BITS
        ADD      #60,11$        ;MAKE ASCII OCTAL
        MOVB     11$,-(R0)      ;SAVE THE CHAR.
        DEC      12$           ;FINISHED ?
        BNE     1$
        MOV      (SP)+,R0
        JSR     R5,VTWRIT       ;DISPAY THE OCTAL #
        NUMBEG
        RTS     R5             ;EXIT
10$:    0
11$:    0
12$:    5
NUMBEG: .BYTE 60,60,60,60,60,60
NUMEND: .BYTE 0
        .EVEN
  
```

```

834
835
836
837 005472 010046
838 005474 013700 001240
839 005500 013702 005720
840 005504 010022
841 005506 020227 005720
842 005512 103402
843 005514 012702 005620
844 005520 010237 005720
845 005524 012702 005620
846 005530 004737 005562
847 005534 110046
848 005536 012702 005621
849 005542 004737 005562
850 005546 000300
851 005550 152600
852 005552 010037 001240
853 005556 012600
854 005560 000207
855
856 005562 005000
857 005564 005005
858 005566 152205
859 005570 060500
860 005572 005202
861 005574 020227 005720
862 005600 103771
863 005602 006300
864 005604 006300
865 005606 006300
866 005610 000300
867 005612 042700 177400
868 005616 000207
869
870 005620 000040
875 005720 005720
876 005720 005620

:*****
:THIS ROUTINE AVERAGES THE LAST 32. X-Y JOYSTICK VALUES
:*****
XYAVE: MOV R0,-(SP) ;SAVE R0
MOV TEMPO,R0 ;GET X & Y
MOV XYBUF,R2 ;GET CURRENT BUFFER POINTER
MOV R0,(R2)+ ;SAVE NEW X-Y VALUE
CMP R2,#XYBUFE ;END OF BUFFER?
BLO 1$ ;NO
MOV #XYBUF,R2 ;YES, GO BACK TO BEGINING OF BUFFER
1$: MOV R2,XYBUF ;SAVE NEW BUFFER POINTER
MOV #XYBUF,R2 ;CALC AVE X
JSR PC,10$
MOVB R0,-(SP) ;SAVE IT
MOV #XYBUF+1,R2 ;CALC AVE Y
JSR PC,10$ ;GO DO IT
SWAB R0 ;GET X-Y IN R0
BISB (SP)+,R0 ;GET SAVED X
MOV R0,TEMPO ;PUT IN TEMPO
MOV (SP)+,R0 ;RESTORE R0
RTS PC ;EXIT WITH AVE X-Y IN TEMPO

10$: CLR R0 ;ZERO SUM
11$: CLR R5 ;DC A MOVB TO A REG (UNSIGNED)
BISB (R2)+,R5
ADD R5,R0 ;ADD IT IN
INC R2 ;SKIP OTHER VALUE
CMP R2,#XYBUFE ;END OF BUFFER?
BLO 11$ ;NO
ASL R0 ;DIVIDE BY 32.
ASL R0
ASL R0
SWAB R0
BIC #177400,R0 ;CLR HI BYTE
RTS PC

XYBUF:
XYBUFE-.
XYBUF: XYBUF
  
```



```
(1) 006130 021627 000060      CMP      (SP),#60      ;;CHAR < 0?
(1) 006134 002420              BLT      18$           ;;BRANCH IF YES
(1) 006136 021627 000067      CMP      (SP),#67      ;;CHAR > 7?
(1) 006142 003015              BGT      18$           ;;BRANCH IF YES
(1) 006144 042726 000060      BIC      #60,(SP)+     ;;STRIP-OFF ASCII
(1) 006150 005766 000002      TST      2(SP)         ;;IS THIS THE FIRST CHAR
(1) 006154 001403              BEQ      17$           ;;BRANCH IF YES
(1) 006156 006316              ASL      (SP)          ;;NO, SHIFT PRESENT
(1) 006160 006316              ASL      (SP)          ;;  CHAR OVER TO MAKE
(1) 006162 006316              ASL      (SP)          ;;  ROOM FOR NEW ONE.
(1) 006164 005266 000002      17$: INC      2(SP)         ;;KEEP COUNT OF CHAR
(1) 006170 056616 177776      BIS      -2(SP),(SP)   ;;SET IN NEW CHAR
(1) 006174 000707              BR       7$            ;;GET THE NEXT ONE
(1) 006176 104401 001160      18$: TYPE  $QUES       ;;TYPE ?<CR><LF>
(1) 006202 000720              BR       20$          ;;SIMULATE CONTROL-U
(1)                               .DSABL  LSB
```

```
(1)                               ;:*****
(1)                               ;:THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
(1)                               ;:*CALL:
(1)                               ;:*      RDCHR              ;;INPUT A SINGLE CHARACTER FROM THE TTY
(1)                               ;:*      RETURN HERE         ;;CHARACTER IS ON THE STACK
(1)                               ;:*                               ;;WITH PARITY BIT STRIPPED OFF
(1)                               ;:
```

```
(1) 006204 011646              $RDCHR: MOV      (SP),-(SP)  ;;PUSH DOWN THE PC
(1) 006206 016666 000004 000002 MOV      4(SP),2(SP)    ;;SAVE THE PS
(1) 006214 105777 172724      1$: TSTB   @TKS         ;;WAIT FOR
(1) 006220 100375              BPL      1$            ;;A CHARACTER
(1) 006222 117766 172720 000004 MOVB    @TKB,4(SP)      ;;READ THE TTY
(1) 006230 042766 177600 000004 BIC     #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
(1) 006236 026627 000004 000023 CMP     4(SP),#23      ;;IS IT A CONTROL-S?
(1) 006244 001013              BNE      3$            ;;BRANCH IF NO
(1) 006246 105777 172672      2$: TSTB   @TKS         ;;WAIT FOR A CHARACTER
(1) 006252 100375              BPL      2$            ;;LOOP UNTIL ITS THERE
(1) 006254 117746 172666      MOVB    @TKB,-(SP)    ;;GET CHARACTER
(1) 006260 042716 177600      BIC     #^C177,(SP)  ;;MAKE IT 7-BIT ASCII
(1) 006264 022627 000021      CMP     (SP)+,#21    ;;IS IT A CONTROL-Q?
(1) 006270 001366              BNE      2$            ;;IF NOT DISCARD IT
(1) 006272 000750              BR       1$            ;;YES, RESUME
(1) 006274 026627 000004 000140 3$: CMP     4(SP),#140    ;;IS IT UPPER CASE?
(1) 006302 002407              BLT      4$            ;;BRANCH IF YES
(1) 006304 026627 000004 000175  CMP     4(SP),#175    ;;IS IT A SPECIAL CHAR?
(1) 006312 003003              BGT      4$            ;;BRANCH IF YES
(1) 006314 042766 000040 000004  BIC     #40,4(SP)    ;;MAKE IT UPPER CASE
(1) 006322 000002              4$: RTI                ;;GO BACK TO USER
```

```
(1)                               ;:*****
(1)                               ;:THIS ROUTINE WILL INPUT A STRING FROM THE TTY
(1)                               ;:*CALL:
(1)                               ;:*      RDLIN              ;;INPUT A STRING FROM THE TTY
(1)                               ;:*      RETURN HERE         ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
(1)                               ;:*                               ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
(1)                               ;:
```

```
(1) 006324 010346              $RDLIN: MOV      R3,-(SP)  ;;SAVE R3
(1) 006326 005046              CLR      -(SP)         ;;CLEAR THE RUBOUT KEY
```

```

(1) 006330 012703 006560 1$: MOV #STTYIN,R3 ::GET ADDRESS
(1) 006334 022703 006567 2$: CMP #STTYIN+7,R3 ::BUFFER FULL?
(1) 006340 101456 BLOS 4$ ::BR IF YES
(1) 006342 104407 RDCHR ::GO READ ONE CHARACTER FROM THE TTY
(1) 006344 112613 MOVB (SP)+,(R3) ::GET CHARACTER
(1) 006346 122713 000177 10$: CMPB #177,(R3) ::IS IT A RUBOUT
(1) 006352 001022 BNE 5$ ::BR IF NO
(1) 006354 005716 TST (SP) ::IS THIS THE FIRST RUBOUT?
(1) 006356 001007 BNE 6$ ::BR IF NO
(1) 006360 112737 000134 006556 MOVB #' \,9$ ::TYPE A BACK SLASH
(1) 006366 104401 006556 TYPE ,9$
(1) 006372 012716 177777 MOV #-1,(SP) ::SET THE RUBOUT KEY
(1) 006376 005303 6$: DEC R3 ::BACKUP BY ONE
(1) 006400 020327 006560 CMP R3,#STTYIN ::STACK EMPTY?
(1) 006404 103434 BLO 4$ ::BR IF YES
(1) 006406 111337 006556 MOVB (R3),9$ ::SETUP TO TYPEOUT THE DELETED CHAR.
(1) 006412 104401 006556 TYPE ,9$ ::GO TYPE
(1) 006416 000746 BR 2$ ::GO READ ANOTHER CHAR.
(1) 006420 005716 5$: TST (SP) ::RUBOUT KEY SET?
(1) 006422 001406 BEQ 7$ ::BR IF NO
(1) 006424 112737 000134 006556 MOVB #' \,9$ ::TYPE A BACK SLASH
(1) 006432 104401 006556 TYPE ,9$
(1) 006436 005016 CLR (SP) ::CLEAR THE RUBOUT KEY
(1) 006440 122713 000025 7$: CMPB #25,(R3) ::IS CHARACTER A CTRL U?
(1) 006444 001003 BNE 8$ ::BR IF NO
(1) 006446 104401 006567 TYPE ,SCNTLU ::TYPE A CONTROL 'U'
(1) 006452 000726 BR 1$ ::GO START OVER
(1) 006454 122713 000022 8$: CMPB #22,(R3) ::IS CHARACTER A '^R'?
(1) 006460 001011 BNE 3$ ::BRANCH IF NO
(1) 006462 105013 CLR (R3) ::CLEAR THE CHARACTER
(1) 006464 104401 001161 TYPE ,$CRLF ::TYPE A 'CR' & 'LF'
(1) 006470 104401 006560 TYPE ,STTYIN ::TYPE THE INPUT STRING
(1) 006474 000717 BR 2$ ::GO PICKUP ANOTHER CHACTER
(1) 006476 104401 001160 4$: TYPE ,9QUES ::TYPE A '?'
(1) 006502 000712 BR 1$ ::CLEAR THE BUFFER AND LOOP
(1) 006504 111337 006556 3$: MOVB (R3),9$ ::ECHO THE CHARACTER
(1) 006510 104401 006556 TYPE ,9$
(1) 006514 122723 000015 CMPB #15,(R3)+ ::CHECK FOR RETURN
(1) 006520 001305 BNE 2$ ::LOOP IF NOT RETURN
(1) 006522 105063 177777 CLR -1(R3) ::CLEAR RETURN (THE 15)
(1) 006526 104401 001162 TYPE ,9LF ::TYPE A LINE FEED
(1) 006532 005726 TST (SP)+ ::CLEAN RUBOUT KEY FROM THE STACK
(1) 006534 012603 MOV (SP)+,R3 ::RESTORE R3
(1) 006536 011646 MOV (SP)-,(SP) ::ADJUST THE STACK AND PUT ADDRESS OF THE
(1) 006540 016666 000004 000002 MOV 4(SP),2(SP) :: FIRST ASCII CHARACTER ON IT
(1) 006546 012766 006560 000004 MOV #STTYIN,4(SP)
(1) 006554 000002 RTI ::RETURN
(1) 006556 000 9$: .BYTE 0 ::STORAGE FOR ASCII CHAR. TO TYPE
(1) 006557 000 .BYTE 0 ::TERMINATOR
(1) 006560 000007 $TTYIN: .BLKB 7 ::RESERVE 7 BYTES FOR TTY INPUT
(1) 006567 136 006525 000012 $CNTLU: .ASCIZ /^U/<15><12> ::CONTROL 'U'
(1) 006574 043536 005015 000 $CNTLG: .ASCIZ /^G/<15><12> ::CONTROL 'G'
(1) 006601 015 051412 051127 $MSWR: .ASCIZ <15><12>/SWR - /
(1) 006606 036440 000040 $MNEW: .ASCIZ / NEW = /
(1) 006612 020040 042516 020127
(1) 006620 020075 000

```

```

(1)          006624          .EVEN
880          :*****
881          .SBTTL  TYPE ROUTINE
(1)          :*****
(2)          :*****
(1)          :*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
(1)          :*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
(1)          :*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
(1)          :*NOTE2:          $FILLC CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
(1)          :*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
(1)          :*
(1)          :*CALL:
(1)          :*1) USING A TRAP INSTRUCTION
(1)          :*      TYPE      ,MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
(1)          :*OR
(1)          :*      TYPE
(1)          :*      MESADR
(1)          :*
(1)          $TYPE:  TSTB      $TPFLG          ;; IS THERE A TERMINAL?
(1)          006624 105737 001157      BPL          1$          ;; BR IF YES
(1)          006630 100002          HALT          ;; HALT HERE IF NO TERMINAL
(1)          006632 000000          BR          3$          ;; LEAVE
(1)          006634 000407          1$:  MOV          RO,-(SP)          ;; SAVE RO
(1)          006636 010046          MOV          @2(SP),RO          ;; GET ADDRESS OF ASCIZ STRING
(1)          006640 017600 000002      2$:  MOVB         (RO)+,-(SP)          ;; PUSH CHARACTER TO BE TYPED ONTO STACK
(1)          006644 112046          BNE         4$          ;; BR IF IT ISN'T THE TERMINATOR
(1)          006646 001005          TST         (SP)+          ;; IF TERMINATOR POP IT OFF THE STACK
(1)          006650 005726          60$: MOV          (SP)+,RO          ;; RESTORE RO
(1)          006652 012600          3$:  ADD          #2,(SP)          ;; ADJUST RETURN PC
(1)          006654 062716 000002      RTI
(1)          006660 000002          4$:  CMPB         #HT,(SP)          ;; RETURN
(1)          006662 122716 000011      BEQ         8$          ;; BRANCH IF <HT>
(1)          006666 001430          CMPB         #CRLF,(SP)          ;; BRANCH IF NOT <CRLF>
(1)          006670 122716 000200      BNE         5$          ;;
(1)          006674 001006          TST         (SP)+          ;; POP <CR><LF> EQUIV
(1)          006676 005726          TYPE          ;; TYPE A CR AND LF
(1)          006700 104401          $CRLF
(1)          006702 001161          CLRB        $CHARCNT          ;; CLEAR CHARACTER COUNT
(1)          006704 105037 007040      BR          2$          ;; GET NEXT CHARACTER
(1)          006710 000755          5$:  JSR          PC,$TYPEC          ;; GO TYPE THIS CHARACTER
(1)          006712 004737 006774      6$:  CMPB         $FILLC,(SP)+          ;; IS IT TIME FOR FILLER CHARS.?
(1)          006716 123726 001156      BNE         2$          ;; IF NO GO GET NEXT CHAR.
(1)          006722 001350          MOV          $NULL,-(SP)          ;; GET # OF FILLER CHARS. NEEDED
(1)          006724 013746 001154          ;; AND THE NULL CHAR.
(1)          006730 105366 000001      7$:  DECB         1(SP)          ;; DOES A NULL NEED TO BE TYPED?
(1)          006734 002770          BLT         6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
(1)          006736 004737 006774          JSR          PC,$TYPEC          ;; GO TYPE A NULL
(1)          006742 105337 007040          DECB        $CHARCNT          ;; DO NOT COUNT AS A COUNT
(1)          006746 000770          BR          7$          ;; LOOP
(1)          :
(1)          :HORIZONTAL TAB PROCESSOR
(1)          8$:  MOVB         #' ,(SP)          ;; REPLACE TAB WITH SPACE
(1)          006750 112716 000040      9$:  JSR          PC,$TYPEC          ;; TYPE A SPACE
(1)          006754 004737 006774          BITB        #7,$CHARCNT          ;; BRANCH IF NOT AT
(1)          006760 132737 000007 007040
  
```

```
(1) 006766 001372 BNE 9$ ;;TAB STOP
(1) 006770 005726 TST (SP)+ ;;POP SPACE OFF STACK
(1) 006772 000724 BR 2$ ;;GET NEXT CHARACTER
(1) 006774 105777 172150 $TYPEC: TSTB @$TSP ;;WAIT UNTIL PRINTER IS READY
(1) 007000 100375 BPL $TYPEC
(1) 007002 116677 000002 172142 MOVB 2(SP),@$TPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
(1) 007010 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
(1) 007016 001003 BNE 1$ ;;BRANCH IF NO
(1) 007020 105037 007040 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
(1) 007024 000406 BR $TYPEX ;;EXIT
(1) 007026 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
(1) 007034 001402 BEQ $TYPEX ;;BRANCH IF YES
(1) 007036 105227 INCB (PC)+ ;;COUNT THE CHARACTER
(1) 007040 000000 $CHARCNT: WORD 0 ;;CHARACTER COUNT STORAGE
(1) 007042 000207 $TYPEX: RTS PC
```

```
882 *****
883 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
```

```
(1) *****
(2) *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
(1) *OCTAL (ASCII) NUMBER AND TYPE IT.
(1) *$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
(1) *CALL:
(1) * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
(1) * TYPOS ;;CALL FOR TYPEOUT
(1) * .BYTE N ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
(1) * .BYTE M ;;M-1 OR 0
(1) * ;;1=TYPE LEADING ZEROS
(1) * ;;0=SUPPRESS LEADING ZEROS
(1) *
(1) *$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
(1) *$TYPOS OR $TYPOC
(1) *CALL:
(1) * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
(1) * TYPON ;;CALL FOR TYPEOUT
(1) *
(1) *$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
(1) *CALL:
(1) * MOV NUM,-(SP) ;;NUMBER TO BE TYPED
(1) * TYPOC ;;CALL FOR TYPEOUT
```

```
(1) 007044 017646 000000 $TYPOS: MOV @(SP),-(SP) ;;PICKUP THE MODE
(1) 007050 116637 000001 007267 MOVB 1(SP),$OFILL ;;LOAD ZERO FILL SWITCH
(1) 007056 112637 007271 MOVB (SP)+,$SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
(1) 007062 062716 000002 ADD #2,(SP) ;;ADJUST RETURN ADDRESS
(1) 007066 000406 BR $TYPON
(1) 007070 112737 000001 007267 $TYPOC: MOVB #1,$OFILL ;;SET THE ZERO FILL SWITCH
(1) 007076 112737 000006 007271 MOVB #6,$SOMODE+1 ;;SET FOR SIX(6) DIGITS
(1) 007104 112737 000005 007266 $TYPON: MOVB #5,$SOCNT ;;SET THE ITERATION COUNT
(1) 007112 010346 MOV R3,-(SP) ;;SAVE R3
(1) 007114 010446 MOV R4,-(SP) ;;SAVE R4
(1) 007116 010546 MOV R5,-(SP) ;;SAVE R5
(1) 007120 113704 007271 MOVB $SOMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
(1) 007124 005404 NEG R4
(1) 007126 062704 000006 ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
```

```

(1) 007132 110437 007270      MOVB   R4,$OMODE      ;;SAVE IT FOR USE
(1) 007136 113704 007267      MOVB   $OFILL,R4     ;;GET THE ZERO FILL SWITCH
(1) 007142 016605 000012      MOV    12(SP),R5     ;;PICKUP THE INPUT NUMBER
(1) 007146 005003              CLR    R3             ;;CLEAR THE OUTPUT WORD
(1) 007150 006105      1$:   ROL    R5         ;;ROTATE MSB INTO 'C'
(1) 007152 000404              BR    3$             ;;GO DO MSB
(1) 007154 006105      2$:   ROL    R5         ;;FORM THIS DIGIT
(1) 007156 006105              ROL    R5
(1) 007160 006105              ROL    R5
(1) 007162 010503              MOV    R5,R3
(1) 007164 006103      3$:   ROL    R3         ;;GET LSB OF THIS DIGIT
(1) 007166 105337 007270      DECB  $OMODE         ;;TYPE THIS DIGIT?
(1) 007172 100016              BPL   7$             ;;BR IF NO
(1) 007174 042703 177770      BIC   #177770,R3     ;;GET RID OF JUNK
(1) 007200 001002              BNE   4$             ;;TEST FOR 0
(1) 007202 005704              TST   R4             ;;SUPPRESS THIS 0?
(1) 007204 001403              BEQ   5$             ;;BR IF YES
(1) 007206 005204      4$:   INC    R4         ;;DON'T SUPPRESS ANYMORE 0'S
(1) 007210 052703 000060      BIS   #'0,R3         ;;MAKE THIS DIGIT ASCII
(1) 007214 052703 000040      5$:   BIS   #' ,R3     ;;MAKE ASCII IF NOT ALREADY
(1) 007220 110337 007264      MOVB  R3,8$          ;;SAVE FOR TYPING
(1) 007224 104401 007264      TYPE  ,8$           ;;GO TYPE THIS DIGIT
(1) 007230 105337 007266      7$:   DECB  $OCNT     ;;COUNT BY 1
(1) 007234 003347              BGT   2$             ;;BR IF MORE TO DO
(1) 007236 002402              BLT   6$             ;;BR IF DONE
(1) 007240 005204              INC   R4             ;;INSURE LAST DIGIT ISN'T A BLANK
(1) 007242 000744              BR    2$             ;;GO DO THE LAST DIGIT
(1) 007244 012605      6$:   MOV   (SP)+,R5     ;;RESTORE R5
(1) 007246 012604              MOV   (SP)+,R4     ;;RESTORE R4
(1) 007250 012603              MOV   (SP)+,R3     ;;RESTORE R3
(1) 007252 016666 000002 000004  MOV   2(SP),4(SP)    ;;SET THE STACK FOR RETURNING
(1) 007260 012616              MOV   (SP)+,(SP)
(1) 007262 000002              RTI                    ;;RETURN
(1) 007264 000      8$:   .BYTE  0          ;;STORAGE FOR ASCII DIGIT
(1) 007265 000              .BYTE  0          ;;TERMINATOR FOR TYPE ROUTINE
(1) 007266 000      $OCNT: .BYTE  0          ;;OCTAL DIGIT COUNTER
(1) 007267 000      $OFILL: .BYTE  0          ;;ZERO FILL SWITCH
(1) 007270 000000      $OMODE: .WORD  0          ;;NUMBER OF DIGITS TO TYPE

```

884 *****

885 .SBTTL READ AN OCTAL NUMBER FROM THE TTY

(1) *****

(2) *****

(1) *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND

(1) *CHANGE IT TO BINARY.

(1) *THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL

(1) *OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED

(1) *FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST

(1) *THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.

(1) *CALL:

(1) * RDOCT ;;READ AN OCTAL NUMBER

(1) * RETURN HERE ;;LOW ORDER BITS ARE ON TOP OF THE STACK

(1) * ;;HIGH ORDER BITS ARE IN \$HIOCT

(1) *****

(1) 007272 011646 \$RDOCT: MOV (SP)-,(SP) ;;PROVIDE SPACE FOR THE

(1) 007274 016666 000004 000002 MOV 4(SP),2(SP) ;;INPUT NUMBER

(3) 007302 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK

```

(3) 0C7304 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
(3) 0C7306 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
(1) 007310 104410      1$:  RDLIN              ;;READ AN ASCII LINE
(1) 007312 012600      MOV      (SP)+,R0      ;;GET ADDRESS OF 1ST CHARACTER
(1) 007314 010037 007420  MOV      R0,5$         ;;AND SAVE IT
(1) 007320 005001      CLR      R1            ;;CLEAR DATA WORD
(1) 007322 005002      CLR      R2
(1) 007324 112046      2$:  MOVB      (R0)+,-(SP) ;;PICKUP THIS CHARACTER
(1) 007326 001420      BEQ      3$            ;;IF ZERO GET OUT
(1) 007330 122716 000060  CMPB     #'0,(SP)      ;;MAKE SURE THIS CHARACTER
(1) 007334 003026      BGT      4$            ;;IS AN OCTAL DIGIT
(1) 007336 122716 000067  CMPB     #'7,(SP)
(1) 007342 002423      BLT      4$
(1) 007344 006301      ASL      R1            ;;*2
(1) 007346 006102      ROL      R2
(1) 007350 006301      ASL      R1            ;;*4
(1) 007352 006102      ROL      R2
(1) 007354 006301      ASL      R1            ;;*8
(1) 007356 006102      ROL      R2
(1) 007360 042716 177770  BIC      #'C7,(SP)     ;;STRIP THE ASCII JUNK
(1) 0C7364 062601      ADD     (SP)+,R1       ;;ADD IN THIS DIGIT
(1) 007366 000756      BR       2$           ;;LOOP
(1) 007370 005726      3$:  TST      (SP)+       ;;CLEAN TERMINATOR FROM STACK
(1) 007372 010166 000012  MOV      R1,12(SP)     ;;SAVE THE RESULT
(1) 007376 010237 007430  MOV      R2,$HIOCT
(3) 007402 012602      MOV      (SP)+,R2     ;;POP STACK INTO R2
(3) 007404 012601      MOV      (:P)+,R1     ;;POP STACK INTO R1
(3) 007406 012600      MOV      (SP)+,R0     ;;POP STACK INTO R0
(1) 007410 000002      RTI
(1) 007412 005726      4$:  TST      (SP)+       ;;CLEAN PARTIAL FROM STACK
(1) 007414 105010      CLRB     (R0)         ;;SET A TERMINATOR
(1) 007416 104401      TYPE
(1) 007420 000000      5$:  .WORD    0           ;;TYPE UP THRU THE BAD CHAR.
(1) 007422 104401 001160  TYPE     ,$QUES       ;;'?' 'CR' & 'LF'
(1) 007426 000730      BR       1$           ;;TRY AGAIN
(1) 007430 000000      $HIOCT: .WORD    0    ;;HIGH ORDER BITS GO HERE
  
```



```

890
89
(1)
(2)
(1)
(1) 007512 012737 007656 000024 $PWRDN: MOV # $ILLUP,@#PWRVEC ;;SET FOR FAST UP
(1) 007520 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
(3) 007526 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
(3) 007530 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
(3) 007532 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
(3) 007534 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
(3) 007536 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
(3) 007540 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
(3) 007542 017746 171372 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
(1) 007546 010637 007662 MOV SP,$SAVR6 ;;SAVE SP
(1) 007552 012737 007564 000024 MOV # $PWRUP,@#PWRVEC ;;SET UP VECTOR
(1) 007560 000000 HALT
(1) 007562 000776 BR -2 ;;HANG UP
(1)
(2)
(1)
(1) 007564 012737 007656 000024 $PWRUP: MOV # $ILLUP,@#PWRVEC ;;SET FOR FAST DOWN
(1) 007572 013706 007662 MOV $SAVR6,SP ;;GET SP
(1) 007576 005037 007662 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
(1) 007602 005237 007662 1$: INC $SAVR6 ;;WAIT FOR THE INC
(1) 007606 001375 BNE 1$ ;;OF WORD
(3) 007610 012677 171324 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
(3) 007614 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
(3) 007616 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
(3) 007620 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
(3) 007622 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
(3) 007624 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
(3) 007626 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
(1) 007630 012737 007512 000024 MOV # $PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
(1) 007636 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
(1) 007644 104401 TYPE PWRMSG ;;REPORT THE POWER FAILURE
(1) 007646 010056 $PWRMG: .WORD PWRMSG ;;POWER FAIL MESSAGE POINTER
(1) 007650 012716 $PWRAD: .WORD (PC)+,(SP) ;;RESTART AT START1
(1) 007652 001562 $PWRAD: .WORD START1 ;;RESTART ADDRESS
(1) 007654 000002 $ILLUP: RTI
(1) 007656 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
(1) 007660 000776 BR -2 ;; BEFORE THE POWER DOWN WAS COMPLETE
(1) 007662 000000 $SAVR6: 0 ;;PUT THE SP HERE
    
```

```
893 .SBTTL DISPLAY MESSAGES
894 ;THIS IS THE MESSAGE FOR THE BOTTOM OF THE SCOPE
895 007664 005015 047514 042527 WD001: .ASCIZ <15><12>/LOWER THRESHOLD /
      007672 020122 044124 042522
      007700 044123 046117 020104
      007706 000
896 007707 040 020040 020040 WD002: .ASCIZ / UPPER THRESHOLD /
      007714 050125 042520 020122
      007722 044124 042522 044123
      007730 046117 020104 000
897 007735 015 055012 041440 WD003: .ASCIZ <15><12>/Z COUNT=/
      007742 052517 052116 000075
898 007750 046440 052101 044522 WD004: .ASCIZ / MATRIX COUNT-/
      007756 020130 047503 047125
      007764 036524 000
899 007767 040 055040 047517 WD005: .ASCIZ / ZOOM/
      007774 000115
900 007776 041040 043455 046501 WD006: .ASCIZ / B-GAMMA/
      010004 040515 000
901 010007 015 041412 046501 WD007: .ASCII <15><12>/CAMERA # /
      010014 051105 020101 020043
902 010022 060 CAMOUT: .BYTE 60
903 010023 040 020040 020040 .ASCII / PB IS /
      010030 041120 044440 020123
904 010036 050125 020040 020040 PBUP: .ASCII /UP JB IS /
      010044 045040 020102 051511
      010052 040
905 010053 125 000120 JBUP: .ASCIZ /UP/
906
907 .SBTTL ASCII MESSAGES
908
909 010056 005015 051012 051505 PWRMSG: .ASCIZ <15><12><12>/RESTARTED AFTER POWER FAILURE /
      010064 040524 052122 042105
      010072 040440 052106 051105
      010100 050040 053517 051105
      010106 043040 044501 052514
      010114 042522 000040
910 010120 005015 041412 047132 MSG1: .ASCIZ <15><12><12>/CZNCDB NCV-11 EXERCISER /
      010126 042103 020102 020040
      010134 041516 026526 030461
      010142 042440 042530 041522
      010150 051511 051105 020040
      010156 020040 000
911 010161 015 042412 052116 MSG2: .ASCIZ <15><12>/ENTER THRESHOLD VALUE IN OCTAL - THEN RETURN -/
      010166 051105 052040 051110
      010174 051505 047510 042114
      010202 053040 046101 042525
      010210 044440 020116 041517
      010216 040524 020114 020055
      010224 044124 047105 051040
      010232 052105 051125 020116
      010240 000075
912 010242 005015 052502 020123 MSG3: .ASCIZ <15><12>/BUS TIMEOUT ERROR - NO VSV01 DISPLAY DETECTED /
      010250 044524 042515 052517
      010256 020124 051105 047522
      010264 020122 020055 047516
```

	010272	053040	053123	030460	
	010300	042040	051511	046120	
	010306	054501	042040	052105	
	010314	041505	042524	020104	
	010322	000040			
913	010324	005015	047105	042524	MSG4: .ASCIZ <15><12>/ENTER CONSOLE BUS ADDRESS - THEN RETURN /
	010332	020122	047503	051516	
	010340	046117	020105	052502	
	010346	020123	042101	051104	
	010354	051505	020123	020055	
	010362	044124	047105	051040	
	010370	052105	051125	020116	
	010376	000075			
914	010400	005015	052502	020123	MSG5: .ASCIZ <15><12>/BUS TIMEOUT ERROR - NCV11/
	010406	044524	042515	052517	
	010414	020124	051105	047522	
	010422	020122	020055	041516	
	010430	030526	000061		
915	010434	005015	054524	042520	MSG6: .ASCIZ <15><12>/TYPE 'H' FOR HELP INFO ENTER KEYBOARD COMMAND(S)/
	010442	021040	021110	043040	
	010450	051117	044040	046105	
	010456	020120	047111	047506	
	010464	020040	047105	042524	
	010472	020122	042513	041131	
	010500	040517	042122	041440	
	010506	046517	040515	042116	
	010514	051450	000051		
916	010520	005015	047105	042524	MSG7: .ASCIZ <15><12>/ENTER CAMERA NUMBER 0-3 ? /
	010526	020122	040503	042515	
	010534	040522	047040	046525	
	010542	042502	020122	026460	
	010550	020063	020077	000	
917	010555	015	042412	052116	MSG8: .ASCIZ <15><12>/ENTER CONSOLE VECTOR ADDRESS - THEN RETURN -/
	010562	051105	041440	047117	
	010570	047523	042514	053040	
	010576	041505	047524	020122	
	010604	042101	051104	051505	
	010612	020123	020055	044124	
	010620	047105	051040	052105	
	010626	051125	020116	000075	
918	010634	026440	000040		DASH: .ASCIZ / - /
919	010640	005015	042115	030455	HELPO: .ASCII <15><12>/MD-11-CZNCDB NCV11 EXERCISER/<15><12><12>
	010646	026461	055103	041516	
	010654	026504	020102	041516	
	010662	030526	020061	054105	
	010670	051105	044503	042523	
	010676	006522	005012		
920	010702	020104	020040	020040	.ASCII /D DISPLAY DATA/<15><12>
	010710	042040	051511	046120	
	010716	054501	042040	052101	
	010724	006501	012		
921	010727	105	020040	020040	.ASCII /E ERASE SCOPE/<15><12>
	010734	020040	051105	051501	
	010742	020105	041523	050117	
	010750	006505	012		
922	010753	114	020040	020040	.ASCII /L GET LOWER THRESHOLD/<15><12>

	010760	020040	042507	020124		
	010766	047514	042527	020122		
	010774	044124	042522	044123		
	011002	046117	006504	012		
923	011007	125	020040	020040	.ASCII /U	GET UPPER THRESHOLD/<15><12>
	011014	020040	042507	020124		
	011022	050125	042520	020122		
	011030	044124	042522	044123		
	011036	046117	006504	012		
924	011043	101	020040	020040	.ASCII /A	DISPLAY ISOTOPE A/<15><12>
	011050	020040	044504	050123		
	011056	040514	020131	051511		
	011064	052117	050117	020105		
	011072	006501	012			
925	011075	102	020040	020040	.ASCII /B	DISPLAY ISOTOPE B/<15><12>
	011102	020040	044504	050123		
	011110	040514	020131	051511		
	011116	052117	050117	020105		
	011124	006502	012			
926	011127	127	020040	020040	.ASCII /W	SELECT FIRST BIT MAP/<15><12>
	011134	020040	042523	042514		
	011142	052103	043040	051111		
	011150	052123	041040	052111		
	011156	046440	050101	005015		
927	011164	020115	020040	020040	.ASCII /M	SELECT SECOND BIT MAP/<15><12>
	011172	051440	046105	041505		
	011200	020124	042523	047503		
	011206	042116	041040	052111		
	011214	046440	050101	005015		
928	011222	020106	020040	020040	.ASCII /F	FREE RUN MODE/<15><12>
	011230	043040	042522	020105		
	011236	052522	020116	047515		
	011244	042504	005015			
929	011250	020112	020040	020040	.ASCII /J	JOYSTICK CALIB./<15><12>
	011256	045040	054517	052123		
	011264	041511	020113	040503		
	011272	044514	027102	005015		
930	011300	020124	020040	020040	.ASCII /T	DISPLAY INTENSITY TEST/
	011306	042040	051511	046120		
	011314	054501	044440	052116		
	011322	047105	044523	054524		
	011330	052040	051505	000124		
931	011336	005015	020116	020040	HELP1: .ASCII <15><12>/N	COLLECT NEW DATA/<15><12>
	011344	020040	041440	046117		
	011352	042514	052103	047040		
	011360	053505	042040	052101		
	011366	006501	012			
932	011371	103	020040	020040	.ASCII /C	COLLECT MORE DATA/<15><12>
	011376	020040	047503	046114		
	011404	041505	020124	047515		
	011412	042522	042040	052101		
	011420	006501	012			
933	011423	130	020040	020040	.ASCII /X	CHANGE CAMERA CHANNEL/<15><12>
	011430	020040	044103	047101		
	011436	042507	041440	046501		
	011444	051105	020101	044103		

```
011452 047101 042516 006514
011460      012
934 011461      123 020040 020040      .ASCII /S      STOP COLLECTION/<15><12>
011466 020040 052123 050117
011474 041440 046117 042514
011502 052103 047511 006516
011510      012
935 011511      107 020040 020040      .ASCII /G      INITILIZE/<15><12>
011516 020040 047111 052111
011524 046111 055111 006505
011532      012
936 011533      132 020040 020040      .ASCII /Z      ZOOM GAIN/<15><12>
011540 020040 047532 046517
011546 043440 044501 006516
011554      012
937 011555      122 020040 020040      .ASCII /R      REGULAR GAIN/<15><12>
011562 020040 042522 052507
011570 040514 020122 040507
011576 047111 005015
938 011602 020117 020040 020040      .ASCII /O      OTHER CONSOLE TERMINAL/<15><12>
011610 047440 044124 051105
011616 041440 047117 047523
011624 042514 052040 051105
011632 044515 040516 006514
011640      012
939 011641      110 020040 020040      .ASCII /H      HELP THE OPERATOR AND REPEAT THIS LIST/
011646 020040 042510 050114
011654 052040 042510 047440
011662 042520 040522 047524
011670 020122 047101 020104
011676 042522 042520 052101
011704 052040 044510 020123
011712 044514 052123
940 011716      015      012      000 BCRLF: .BYTE 15,12,0
941
942 ;LOC. 20000 THRU 57776 ARE BUFFER AREA
943
944 000001 .END
```


PIXCNT	001262	79#	415*	491	495*	498*	
PRO	= 000000	11#					
PR1	= 000040	11#					
PR2	= 000100	11#					
PR3	= 000140	11#					
PR4	= 000200	11#					
PR5	= 000240	11#					
PR6	= 000300	11#					
PR7	= 000340	11#					
PS	= 177776	11#					
PSW	= 177776	11#					
PWRMSG	010056	891	909#				
PWRVEC	= 000024	11#	102*	89*			
RDCHR	= 104407	879	888#				
RDLIN	= 104410	885	888#				
RDOCT	= 104411	265	286	301	332	350	888#
RESVEC	= 000010	11#					
ROUTA	002054	182	217#				
ROUTB	002066	183	219#				
ROUTC	002100	184	221#				
ROUTD	002110	185	223#				
ROUTE	002114	186	224#				
ROUTF	002124	187	226#	589			
ROUTG	002220	188	242#				
ROUTH	002230	189	244#				
ROUTJ	002302	191	257#				
ROUTL	002320	193	261#				
ROUTM	002360	194	271#				
ROUTN	002420	195	279#				
ROUTO	002434	196	282#				
ROUTR	002614	199	319#				
ROUTS	002632	200	322#				
ROUTT	002650	201	325#				
ROUTU	002664	202	328#				
ROUTW	002724	204	338#				
ROUTX	002762	205	346#				
ROUTZ	003102	207	370#				
ROWCNT	001312	91#	443*	446*	448*		
RTABLE	001750	175	177	182#			
SCLCEL	003474	453	456#				
SELCTA	004546	104	274	341	653#		
STACK	- 001100	11#	102	161			
START	001326	18	102#	120	310		
START1	001562	116	121#	243	891		
STKLMT	- 177774	11#					
SWR	001140	21#	102*	879*	891*		
SWREG	000176	18#	102	879			
SW0	- 000001	11#					
SW00	= 000001	11#					
SW01	= 000002	11#					
SW02	= 000004	11#					
SW03	= 000010	11#					
SW04	= 000020	11#					
SW05	= 000040	11#					
SW06	= 000100	11#					
SW07	- 000200	11#					

WD002	007707	518	896#			
WD003	007735	543	897#			
WD004	007750	553	898#			
WD005	007767	582	899#			
WD006	007776	586	900#			
WD007	010007	541	901#			
XYAVE	005472	637	837#			
XYBUF	005620	843	845	848	870#	876
XYBUFE=	005720	841	861	875#		
XYBUFP	005720	839	844*	876#		
\$AUTOB	001134	21#	879			
\$BDADR	001122	21#				
\$BDDAT	001126	21#				
\$CHARC	007040	881#*				
\$CKSWR	005722	879#	888			
\$CMTAG	001100	21#	102			
\$CM3 =	000000	21#				
\$CNTLG	006574	879#				
\$CNTLU	006567	879#				
\$CRLF	001161	21#	879	881	885	
\$ERFLG	001103	21#				
\$ERMAX	001115	21#				
\$ERRPC	001116	21#				
\$ERRTB	001164	21#				
\$ERTTL	001112	21#				
\$FILLC	001156	21#	881			
\$FILLS	001155	21#	881			
\$GDADR	001120	21#				
\$GDDAT	001124	21#				
\$GTSWR	005772	879#	888			
\$HD =	000003	9				
\$HIOCT	007430	885#*				
\$ICNT	001104	21#				
\$ILLUP	007656	891#				
\$INTAG	001135	21#	879			
\$ITEMB	001114	21#				
\$LF	001162	21#	879	881	885	
\$LPADR	001106	21#				
\$LPERR	001110	21#				
\$MAIL =	***** U	102	881			
\$MNEW	006612	879#				
\$MSWR	006601	879#				
\$NULL	001154	21#	881			
\$OCNT	007266	883#*				
\$OMODE	007270	883#*				
\$PASS	001100	21#				
\$PWAD	007652	891#				
\$PWADN	007512	102	891#			
\$PWIMG	007646	891#				
\$PWUP	007564	891#				
\$QUES	001160	21#	879	881	885	
\$RDCHR	006204	879#	888			
\$RDDEC-	***** L	888				
\$RDLIN	006324	879#	888			
\$RDOCT	007272	885#	888			
\$RDSZ -	000007	879#				

COMMEN	11#														
ENDCOM	11#														
ERROR	11#														
ESCAPE	11#														
GETPRI	11#														
CETSUR	11#														
MULT	11#														
NEWTST	11#														
POP	11#	885		891											
PUSH	11#	885		891											
REPORT	11#														
SCOPE	11#														
SETPRI	11#														
SETTRA	888#														
SETUP	11#	102													
SKIP	11#														
SLASH	11#														
SPACE	11#														
STARS	11#	21	648	652	682	684	692	694	700	702	712	714	724	727	738
	740	748	754	770	772	781	783	792	794	805	807	834	836	878	879
	880	881	882	883	884	885	887	888	890	891					
SWRSU	11#	102#													
TRMTRP	888#														
TYPBIN	11#														
iYPDEC	11#														
TYPNAM	11#														
TYPNUM	11#														
TYPOCS	11#														
TYPOCT	11#	879													
TYPTXT	11#														
\$\$CMRE	21#														
\$\$CMTM	21#														
\$\$ESCA	11#														
\$\$NEWT	11#														
\$\$SET	888#														
\$\$SKIP	11#														
.EQUAT	6#	11													
.HEADE	6#	9													
.SETUP	6#	101													
.SCATC	6#	18													
.SCMTA	6#	21													
.SPOWE	7#	891													
.SRDOC	7#	885													
.SREAD	7#	879													
.STRAP	7#	888													
.STYPE	7#	881													
.\$TYPO	7#	883													

. ABS. 011721 000 CON RO ABS GBL D

ERRORS DETECTED: 0

CZNCDB,CZNCDB/CRT-CZNCDB
 RUN-TIME: 13 6 .7 SECONDS

CZNCDB NCV11 EXERCISER MACY11 30G(1063) 31-AUG-79 13:08 PAGE 20-1^{N 4}
CZNCDB.P11 31-AUG-79 11:21 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0052

RUN-TIME RATIO: 30/20=1.4
CORE USED: 18K (35 PAGES)