

DL11C/D/E

DL11C/D/E OFFLINE TEST
MD-11-DZDLC-B

EP-DZDLC-B-DL-A
COPYRIGHT © 75-77
FICHE 1 OF 1

AUG 1977
digital
MADE IN USA

Frame 1	Frame 2	Frame 3	Frame 4	Frame 5	Frame 6	Frame 7	Frame 8	Frame 9	Frame 10
...
...
...
...
...
...
...
...
...

DL11C/D/E
MD-11-DZDLC-B

B01

EOF1DZDMORSEQ
PDP10 411

00010000

770720

PDP10 411

HDR1DZDLCBSEQ

00010000

770720

IDENTIFICATION

Product Code: MAINDEC-11-DZDLC-B-D
Product Name: DL11/C,/D, or /E Off Line Test
Date Created: MAY 1977
Maintainer: Diagnostic RELEASE ENGINEERING
Author: E. Crowley/B. Burgess

Copyright (C) 1975, 1977 Digital Equipment Corporation

This software is furnished under a license for use only on a single computer system and may be copied only with the inclusion of the above copyright notice. This software, or any other copies thereof, may not be provided or otherwise made available to any other person except for use on such system and to one who agrees to these license terms. Title to and ownership of the software shall at all times remain in DEC.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

DEC assumes no responsibility for the use or reliability of its software on equipment which is not supplied by DEC.

TABLE OF CONTENTS

1.0	PROGRAM PURPOSE (ABSTRACT)
2.0	SYSTEM REQUIREMENTS
3.0	RELATED DOCUMENTS AND STANDARDS
4.0	DIAGNOSTIC HIERARCHY PREREQUISITES
5.0	LOADING AND STARTING PROCEDURE
6.0	SPECIAL ENVIRONMENTS
7.0	PROGRAM OPTIONS
8.0	EXECUTION TIMES
9.0	ERROR INFORMATION
9.1	Error Reporting
9.2	Error Halts
10.0	PERFORMANCE AND PROGRESS REPORTS
11.0	DEVICE INFORMATION TABLES
12.0	SUBROUTINE SUMMARIES
THRU 12.20	
13.0	MISCELLANEOUS
14.0	USER SELECTION PROGRAMS
14.1	Program #2 Description
14.2	Program #3 Description
14.3	Program #4 Description
14.4	Program #5 Description
15.0	PROGRAM FUNCTIONAL FLOW CHARTS
16.0	PROGRAM LISTING

1.0 PROGRAM PURPOSE (ABSTRACT)

This program has the ability to test the DL11 (Asynchronous Modem Interface), off line. Models able to be tested are C, D, and E only. The use of a modem is not required for testing; however, a special cable connector BCOSC and a special modem test connector H315A is required. This program is capable of the following:

- a. Verification of maintenance bit
- b. Verification that transmitter can cause an interrupt
- c. Verification that receiver 'DONE' can cause an interrupt
- d. Checks that 'REQ TO SEND' asserts 'RING'
- e. Checks that 'SEC XMIT' asserts 'SEC REC' and 'DATA SET INT'
- f. Checks that 'DTR' can assert 'CLR TO SEND' and 'CAR DET'
- g. Verifies that 'DATA SET I.E.' can cause a RECVR INTR
- h. Checks the 'BREAK' feature
- i. Performs null-del-null pattern
- j. Performs binary up count pattern
- k. Performs binary down count pattern
- l. Runs a worse case pattern

Included in the program are special user routines - PRG #2, PRG #3, PRG #4, and PRG #5 (which will be described further into this document).

Note well two(2) points:

1. This program is capable of testing sixteen(16) DL11's and assumes contiguous addressing from 1st device to last.
 - a. If multiple devices are not being tested, thus not requiring a pass thru the program once per device, then the program will default to testing the 1st possible DL11-E device i.e., RCSR address = 775610, and test this device only.
 - b. If multiple device testing is not being conducted, and the device existing is not the default DL11-E, then the user on starting the program will have to set SW(0)=1 to enter the question & answer mode.
2. This program has provision for character length i.e. it assumes data is 8 bits, but also has the ability to handle 5, 6, or 7 bits of data as well.

2.0 SYSTEM REQUIREMENTS

a. Hardware Requirements

PDP-11 family processor with 8K of memory
M7800 DL11 asynchronous line interface module

BCOSC special cable connector
H315A special modem test connector

b. Software Requirements

This program was specifically designed for the 11/40 Front End of the 1080 Console Processor System. In this environment it would be loaded by the TCDP (Dectape) diagnostic monitor. However, any 11/40 user with 8K of memory can run this program to test one(1) or multiple DL11's.

The program has the proper interface code to allow running under the automated manufacturing test line system - ACT11.

3.0 RELATED DOCUMENTS AND STANDARDS

- a. Programming Practices - Document No. 175-003-009-00
- b. PDP11/40 Processor Handbook
- c. DL11 Asynchronous Line Interface Manual
Document No. DEC-11-HDLAA
- d. PDP-11 Maindec SYSMAC' Utility Package
MAINDEC-11-DZQAC-C3
- e. Applicable Circuit Schematic
M7800

4.0 DIAGNOSTIC HIERARCHY PREREQUISITES

Before running this program, the following two(2) diagnostic programs should be run for verification of functionality of the 11-instruction set and memory:

1. MAINDEC-11-DBQEA and,
2. MAINDEC-11-DZQMC

5.0 LOADING AND STARTING PROCEDURE

Load program in memory using ABS loader
Load address 200.

NOTE

In the case of a 1080 system environment
load the program using the TCDP
(dectape) Diagnostic Monitor.

Press start.

- a. There are also three(3) optional start addresses for the program:

204 - selects program #2
210 - selects program #3
214 - selects program #4
220 - selects program #5

6.0 SPECIAL ENVIRONMENTS

If this program is run in Quick Verify Mode under ACT11 the program is done after the first pass.

7.0 PROGRAM OPTIONS

SWITCH	USE
15=1 or up	Halt on error
14=1 or up	Loop on test
13=1 or up	Inhibit error typeouts
12=1 or up	/C or /D model being tested
11=1 or up	Inhibit iterations
10=1 or up	Bell on error
9=1 or up	Loop on error
8=1 or up	Loop on test in SW<7:0>
<7:0>	Holds test no. of test to be looped on. Used in conjunction with SW<8>.
0=1 or up	Used in device table creation (1 to 16 devices) i.e., default device not desired. Also used for character length setting.

!! NOTE BELL !!

If sw<08> is set the user can only 'loop on a test' of the default device i.e. - DL11/E RCSR = 775610. If the user desires to 'loop on a test' of other than the default device he must first patch the five (5) locations labeled

DLRCSR: DLRDBR: DLXCSR: DLXDBR:
DLVECT:

that appear under 'DL11 Definitions' heading at the front of the listing. i.e. - with sw<08> set sw<00> is not functional.

8.0 EXECUTION TIMES

Execution time is dependent on type of memory and

number of DL11's being tested. A representative time for 1 error free pass is:

11/40 - core memory - 1 DL11/E - 20 seconds

9.0 ERROR INFORMATION

9.1 Error Reporting

There are a total of seven(7) types of error reports generated by the program. The key column headings will be described below for clarity -

- DEVADR - This is the address of the receiver control status register for the failing DL11
- REGADR - This is the address of the DL11 register on which testing is being conducted
- WAS - This is what the contents of the register of the DL11 undergoing test was (address is under column '(R2)')
- S/B - This is what the contents of the register of the DL11 undergoing test should be (address is under column '(R2)')
- WASADR - This is what the memory address was (input data buffer address)
- SHBADR - This is what the memory address should be (output data buffer address)
- (REG) - This is the contents of the DL11 receiver data buffer in error (address is under column '(R2)')

9.2 Error Halts

With the 'Halt on Error' switch (SW15) not set there are four(4) programmed 'HALTS' in the program:

- a. In the case of error reporting and there is no terminal to allow the information transfer.
- b. In the power fail routine if the power up sequence was

started before the power down sequence had a chance to complete itself.

- c. In the end of pass routine if multiple device testing is being conducted but no devices are shown as active.
- d. In the case of sw<08> being set.

10.0 PERFORMANCE AND PROGRESS REPORTS

Not applicable.

11.0 DEVICE INFORMATION TABLES

- a. The following is a picture view of a DL11-E Receiver Control Status Register, which will show bit assignments and definitions, to provide a handy reference:

I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
DS	RI	CT	C	R	S			R	RI	DI		S	RT	DT			
I	NG	S	D	A	R			D	EN	EN		X	S	R			
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00		

Bit assignments are defined as follows:

- | | |
|--------------------------|--|
| BIT15 Data Set Interrupt | <ol style="list-style-type: none"> 1. Interrupt sequence initiated when BIT05 set. 2. Sets whenever bits 10, 11, 12 or 14 change state 3. Cleared by INIT or reading RCSR |
| BIT14 Ring | <ol style="list-style-type: none"> 1. When set, indicates a control signal being received from dataset. |
| BIT13 Clear to send | <ol style="list-style-type: none"> 1. When set indicates ON condition; when clear indicates OFF condition. 2. Dependent on state of 'CTS' signal from dataset |
| BIT12 Carrier Detect | <ol style="list-style-type: none"> 1. Sets when data carrier received 2. When clear indicates end of current transmission or an error condition. |

- | | |
|--|--|
| BIT11 Receiver Active | <ol style="list-style-type: none"> 1. When set indicates receiver interface is active. 2. Cleared by INIT or RCVR DONE (BIT07). |
| BIT10 Secondary Receive or Supervisory Received Data | <ol style="list-style-type: none"> 1. Provides receive capability, when set, for reverse channel of remote station. Sets when BIT03 is set. 2. Cleared by INIT |
| BIT07 Receiver Done | <ol style="list-style-type: none"> 1. Sets when character has been received. Will initiate an interrupt providing BIT06 is also set 2. Cleared when RDBR is addressed or BIT00 is set. 3. Also, cleared by INIT |
| BIT06 Receiver Interrupt Enable | <ol style="list-style-type: none"> 1. When set, allows interrupt providing BIT07 is set. 2. Cleared by INIT 3. ***READ/WRITE BIT*** |
| BIT05 Dataset Interrupt Enable | <ol style="list-style-type: none"> 1. When set, allows interrupt providing BIT15 is set. 2. Cleared by INIT 3. ***READ/WRITE BIT*** |
| BIT03 Secondary Transmit or Supervisory Transmitted DATA | <ol style="list-style-type: none"> 1. Provides transmit capability, when set, for reverse channel of remote station. Sets when BIT10 is set. 2. Cleared by INIT 3. ***READ/WRITE BIT*** |
| BIT02 Request to Send | <ol style="list-style-type: none"> 1. Jumper ties this bit to REQ TO SEND in dataset. 2. Required for transmission 3. Cleared by INIT 4. ***READ/WRITE BIT*** |
| BIT01 Data Terminal Ready | <ol style="list-style-type: none"> 1. When set, permits connection to channel. 2. When clear, disconnects interface from channel. 3. MUST be cleared by program 4. ***READ/WRITE BIT*** |

Special Notes on RCSR Register

1. Addresses should fall in the range of 175610 to

176170

2. BIT01 (Data terminal Ready) state is not defined after power-up.
 3. On DL11-C or -D options bits 15, 14, 13, 12, 10, 5, 3, 2, and 1 are not used.
 4. On DL11-C and -D options bit<00> is 'RDR ENB' . On a DL11-E option this bit is unused.
- b. The following is a picture view of a DL11-E transmitter control status register, which will show bit assignments and definitions, to provide a handy reference:




Bit assignments are defined as follows:

- | | |
|------------------------------------|--|
| BIT07 Transmitter Ready | <ol style="list-style-type: none"> 1. Set when XDBR can accept another character. Will initiate an interrupt if BIT06 also set. 2. Also set by INIT 3. Cleared by loading XDBR |
| BIT06 Transmitter Interrupt Enable | <ol style="list-style-type: none"> 1. When set, allows interrupt providing BIT07 is set. 2. Cleared by INIT 3. ***READ/WRITE BIT*** |
| BIT02 Maintenance | <ol style="list-style-type: none"> 1. When set, disables serial line input to receiver & connects XMIT output to receiver input which disconnects external device input. This forces receiver to run at xmitter speed. 2. Cleared by INIT 3. ***READ/WRITE BIT*** |
| BIT00 Break | <ol style="list-style-type: none"> 1. When set, transmits a continuous space to external device 2. Cleared by INIT 3. ***READ/WRITE BIT*** |

!! NOTE !!

DL11-C and -D options are the same.

- c. The following is a picture view of the DL11-E receiver and transmitter data buffer registers, to provide a handy reference.



Bit assignments are defined as follows:

- | | |
|-----------------|--|
| BITS 07-00 Data | 1. Character to be transferred to external device.
2. If character less than 8 bits it must be loaded right justified.
3. ***WRITE ONLY BITS*** |
| BIT 15 Error | 1. ***READ ONLY BIT***
2. Cleared by error removal |
| BIT 14 Overrun | 1. Same as BIT 15
2. RCVR DONE not cleared |
| BIT 13 Framing | 1. Same as BIT 15
2. No valid STOP bit |
| BIT 12 parity | 1. Same as BIT 15
2. Parity other than expected |

NOTE: Bits<15:12> only appear in the rcvr data buffer
DL11-C and -D options are the same.

12.0 SUBROUTINE SUMMARIES

12.1 DLADDR

This routine sets up the following:

- RCSR - Receiver Status Register
- RBUF - Receiver Buffer Register
- XCSR - Transmitter Status Register
- XBUF - Transmitter Buffer Register

The setup is done, initially, in response to user reply to 1st device he wants tested, and thereafter, at the end of a program pass to allow cycling thru all devices for multiple device testing (if required).

12.2 SEOP

This routine is supplied by MAINDEC-11-DZQACC3, the PDP-11 Maindec 'SYSMAC' utility package. This routine is responsible for the following:

- a. Incrementing the pass number (SPASS)
- b. Typing 'END PASS #XXX' (where 'XXX' is a decimal value)

NOTE

If multiple device testing is being conducted, then SPASS is only incremented after testing of all devices has transpired (multiple testing). Therefore, e.g., If 10 devices have been tested then 'END PASS #1' would be typed out; 'END PASS #2' would be typed out after the 10 devices have once again been tested by the program, etc.

- c. Goes to a monitor, if there is one
- d. If there is no monitor transfers control back to beginning of the program.

12.3 SSCOPE

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package.

This routine is entered before and after every subtest to ascertain the following conditions:

- a. Loop on test just executed?
This condition is enabled when SW<14> is set to a '1'.
- b. Loop on test if an error has occurred during the test?
This condition is enabled when SW<09> is set to a '1'.
- c. Loop on test specified by test no. appearing in SWR<7:0>?
This condition is enabled when SW<08> is set to a '1'.
- d. Inhibit subtest iterations?
This condition is enabled when SW<11> is set to a '1'.

12.4 SERROR

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package.

This routine handles the following reactions to an error when an error is encountered:

- a. 'HALT' on Error?
This condition is enabled when SW<15> is set to a '1'.
- b. Ring 'Bell' on Error?
This condition is enabled when SW<10> is set to a '1'.
- c. Loop on Error
This condition is enabled when SW<09> is set to a '1'.
- d. Inhibit Error Typeouts
This condition is enabled when SW<13> is set to a '1'.

NOTE

On encountering an error while executing the program, this routine will transfer control to 'SERRTYP' routine shown below (presumes 'HALT' on error SW<15> not set).

12.5 SERRTYP

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package.

This routine handles the information for error message typeouts as follows:

This routine uses the 'Item Control Byte' (SITEMB) to determine which error is to be reported. It then obtains, from the 'error Table' (SERRTB) the addresses of where the information, for printout, is stored; and causes the appropriate information concerning the error to be printed out.

- Note:
1. The variable 'SITEMB' is supplied by .SCMTAG, a 'SYSMAC' utility package routine.
 2. The 1st address 'SERRTB' for location of 'error table' information is also supplied by .SCMTAG.
 3. If the 'SITEMB' value is zero(0), then only a program counter (PC) is printed out. It has no label, it is a pure number.

12.6 STYPOC

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. This routine is used for all octal typeouts (16 bit values) throughout the program.

12.7 STYPDS

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. This routine is used to type a decimal value at the end of a pass of the program of the form 'END PASS @ XXX' where 'XXX' is the decimal value.

12.8 SRDCHR, SRDLIN, SRDOCT

These routines are supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. Their uses are as follows:

- a. SRDCHR - Handles a single character coming in from the TTY. The character is placed on top of the stack for future use.
- b. SRDLIN - Handles a string of characters coming in from the TTY. The address of the 1st character is placed on top of the stack for future use.
- c. SRDOCT - Handles an octal number coming in from the SRDDEC 104420 TTY decimal @ input TTY. Low order bits are stored on top of the stack; high order bits are stored in location SHIOCT. SHIOCT is supplied by .SCMTAG, a 'SYSMAC' package utility routine.

12.9 STYPE

This routine is supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. This routine is used to type ASCII messages (which must terminate with a 0 byte) as well as all other forms of typed information. The routine is also responsible for inserting a number of fill characters after a line feed.

- Note:
1. SNULL contains the character to be used as fill.
 2. SFILLS contains the number of filler characters req'd.
 3. SFILLC contains the character to fill after.

4. The above three(3) variables are supplied by .SCMTAG, a 'SYSMAC' package utility routine.

12.10 STRAP, STRPAD

These routines are supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. The 'STRAP' routine will strip off the lower byte of a trap instruction and use it to index thru the trap table (STRPAD) for the starting address of the desired routine. Then using the address obtained it will then transfer program control to that routine.

The following table defines all routines in the program called by a 'TRAP' instruction by showing their 'TRAP' equivalences -

STYPE	104400	TTY typeout routine
STYPOC	104402	Type octal # (with leading zeros)
STYPOS	104404	Type octal # (no leading zeros)
STYPOB	104406	Type octal # (per last character method)
STYPOD	104410	Type decimal # (with sign)
SROCHR	104412	TTY character input
SROLIN	104414	TTY string input
SRODOCT	104416	TTY octal # input

12.11 SPWRDN, SPWRUP

These routines are supplied by MAINDEC-11-DZQAC-C3, the PDP-11 Maindec 'SYSMAC' utility package. These routines handle the 'Power Down and Up' sequence. The program may be power failed when running; however, use caution in turning power off/on while the power fail message is being typed - it may cause stack overflow.

NOTE

When power returns the program will automatically start itself over at the beginning.

12.12 XINT, RINT

- XINT - This is the transmitter interrupt service routine for 256(10) byte block transfers.
- RINT - This is the receiver interrupt service routine for 256(10) byte block transfers.

12.13 DELAY, STALL, DATCHK, TIMERX, TIMETX

These routines are all used by programs 2, 3, 4 and 5. Programs 2 through 5 are the 'Special' user interaction routines which will be defined later in this document. The above routine uses are as follows:

- a. DELAY - This routine is used by all the utility programs to wait a no. of milliseconds between character transfers as specified by the user.
- b. STALL - This routine is used by program #4 and will allow a random no. of milliseconds to transpire before a transmission of a character. This routine is activated based on user response.
- c. DATCHK - This routine is used by program #4 and will check for correct expected and received data after character transmission as well as any error bit conditions.
- d. TIMERX + TIMETX -
These two(2) routines are used by program #4 to verify the 'DONE' bit after both transmitter and receiver operations.

12.14 SUERR1, SUER2

These two(2) routines are used throughout the program to set up the error information for 'Error Reporting' before the 'Error Report' call is made. 'Error Report' calls appear throughout the program in the form "ERROR + XX" where 'XX' indicates the particular error table (ERRTB:) entry used by the Error Service Routine.

12.15 PRIME

This routine is used to set up the data buffers on the device under test for each 256(10) byte block transfer.

12.16 CLDLBF

This routine is used in conjunction with routine 'PRIME' to clear input and output buffers before data transfers.

12.17 LDOUT1, LDOUT2, LDOUT3, LDOUT4

The routines are all used for set up and loading purposes as follows:

- a. LDOUT1 - is called to set up the 'null-del-null' pattern
- b. LDOUT2 - is called to load an ascending binary count pattern
- c. LDOUT3 - is called to load a descending binary count pattern
- d. LDOUT4 - is called to load a complementing worse case pattern

12.18 CHKDAT

This routine is used to check for data compare errors in 256(10) byte block transfers.

12.19 BUSERR, RSVERR

These two(2) routines are used to service 'Unexpected' bus error and reserved instruction traps, respectively.

12.20 TRPCOM

This routine is used to set up and report the information concerning 'Unexpected' bus error and reserved instruction traps. This routine is used in conjunction with routines 'BUSERR' and 'RSVERR' described above.

13.0 MISCELLANEOUS

- a. The stack pointer is initially set to 1100.
- b. The parity bit is not covered.

14.0 USER SELECTION PROGRAMS

14.1 Program #2 Description

This utility program will allow the following:

- a. Selection of transmitter data buffer
- b. Selection of a character for continuous transfer

- c. Selection of an expiration time in milliseconds between each transmitter data buffer character transfer
- d. A tight scope loop lock on a specific character

The program relies on user response (via TTY) to specific questions as described below:

- a. What is the transmitter data buffer address?

The user should respond by typing an address in the range 175616 to 176176 and follow it with a 'carriage return' at which time the program will validate what was typed to see if -

1. The value typed is within the correct range
2. The value typed is an 'even' address, so as not to cause a 'Bus timeout' when referenced, and
3. Then checks to see if the device associated with the value typed is indeed present

NOTE

If either of the three(3) above conditions are not met the program will type a question mark (?), reiterate the initial question, and wait for a 'new' user response.

- b. What is the character to be transmitted (octal ASCII e.g., A=101)?

The user should respond by typing an octal ASCII value, for the character desired and follow it with a 'carriage return'.

- c. What is the desired msec. delay (octal e.g., 10=8(10))?

The user should respond by typing an octal value for the desired no. of msec. delay and follow it with a 'carriage return'.

E.G. - If user desired 16 msec. delay between each character transfer he should type '20'.

- d. At this point the program will loop continuously sending the character specified, with the desired msec. delay between each character transmission.

This utility program will allow the following:

- a. Selection of TRANSMITTER data buffer
- b. Selection of a character for continuous transfer
IN MAINTENANCE MODE.
- c. Selection of an expiration time in milliseconds between
each TRANSMITTER data buffer character transfer
- d. A tight scope loop lock on a specific character

The program relies on user response (via TTY) to specific questions as described below:

- a. What is the TRANSMITTER data buffer address?

The user should respond by typing an address in the range 175616 to 176176 and follow it with a 'carriage return' at which time the program will validate what was typed to see if -

1. The value typed is within the correct range
2. The value typed is an 'even' address, so as not to cause a 'Bus timeout' when referenced, and
3. Then checks to see if the device associated with the value typed is indeed present

NOTE

If either of the three(3) above conditions are not met the program will type a question mark (?), reiterate the initial question, and wait for a 'new' user response.

- b. What is the character to be transmitted (octal ASCII e.g., A=101)?

The user should respond by typing an octal ASCII value, for the character desired and follow it with a 'carriage return'.

- c. What is the desired msec. delay (octal e.g., 10=8(10))?

The user should respond by typing an octal value for the desired no. of msec. delay and follow it with a 'carriage return'.

E.G. - If user desired 16 msec. delay between each character transfer he should type '20'.

- d. At this point the program will loop continuously sending the character specified, with the desired msec. delay

between each character transmission.

14.3 Program #4 Description

This utility program will allow the following:

- a. Selection of a transmitter data buffer
- b. Selection of a single character to be sent, received and checked with maintenance bit set.

The program relies on user response (via TTY) to specific questions as described below:

- a. What is the transmitter data buffer address?

The user should respond by typing an address in the range 175616 to 176176 and follow it with a 'carriage return' at which time the program will validate what was typed to see if -

1. The value typed is within the correct range
2. The value typed is an 'even' address, so as not to cause a 'Bus timeout' when referenced, and
3. Then checks to see if the device associated with the value typed is indeed present.

NOTE

If either of the three(3) above conditions are not met the program will type a question mark (?), reiterate the initial question, and wait for a 'new' user response.

- b. Is a random wait time (msec.) desired 1/0=yes/no?

The user should respond as asked and follow it with a 'carriage return'.

- c. What is the character to be transmitted (octal ASCII e.g. A=101)?

The user should respond by typing an octal ASCII value, for the character desired and follow it with a 'carriage return'.

- d. At this point the program will loop continuously sending the character specified, with a random msec. delay between each character transmission. Between each transmission, 'RCVR' & 'XMITTER' done bits will be

verified, as well as checks for correct data and any error bit conditions.

NOTE

If user response to Item b. (directly above) was a '0' or a plain 'carriage return' then there is no delay between character transmissions.

14.4 Program #5 Description

This utility program will allow user parameters for running a binary count in maintenance mode.

The program relies on user response (via TTY) to specific questions as described below:

a. What is the transmitter data buffer address?

The user should respond by typing an address in the range 175616 to 176176 and follow it with a 'carriage return' at which time the program will validate what was typed to see if -

1. The value typed is within the correct range
2. The value typed is an 'even' address, so as not to cause a 'Bus timeout' when referenced, and
3. Then checks to see if the device associated with the value typed is indeed present.

NOTE

If either of the three(3) above conditions are not met the program will type a question mark (?), reiterate the initial question, and wait for a 'new' user response.

b. Is a random wait time (msec.) desired 1/0=yes/no?

The user should respond as asked and follow it with a 'carriage return'.

c. At this point the program will loop continuously sending binary characters, with a random msec. delay between each character transmission. Between each transmission, 'RCVR' & 'XMITTER' done bits will be verified, as well as checks for correct data and any error bit conditions.

NOTE

If user response to Item B. (directly above) was a '0' or a plain 'carriage return' then there is no delay between character transmissions.

15.0 PROGRAM FUNCTIONAL FLOW CHARTS

16.0 PROGRAM LISTING

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

167400

.NLIST CND,MD,MC
.LIST ME,SEQ,BIN
\$SWR=167400
.ENABLE ABS

.TITLE MAINDEC-11-DZDLC-B
;*COPYRIGHT (C) 1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
*
;*PROGRAM BY E. CROWLEY/B. BURGESS
*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
*
\$TN=1

000001

.SBTTL OPERATIONAL SWITCH SETTINGS
*
* SWITCH USE
*-----
* 15 HALT ON ERROR
* 14 LOOP ON TEST
* 13 INHIBIT ERROR TYPEOUTS
* 12 /C OR /D MODEL
* 11 INHIBIT ITERATIONS
* 10 BELL ON ERROR
* 9 LOOP ON ERROR
* 8 LOOP ON TEST IN SWR<7:0>
*
* 0 CREATION OF DEVICE/S TABLE
* OR CHANGE CHARACTER LENGTH

000000

.SBTTL TRAP CATCHER
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
JMP @#BEGIN ;;JUMP TO STARTING ADDRESS OF PROGRAM
JMP @#PRG2 ;;JUMP TO USER PROGRAM NO. 2
JMP @#PRG3 ;;JUMP TO USER PROGRAM NO. 3
JMP @#PRG4 ;;JUMP TO USER PROGRAM NO. 4
JMP @#PRG5 ;;JUMP TO USER PROGRAM NO. 5
.
.=52
.WORD 0 ;:INFORMATION LOCATION FOR ACT11
;:NO POWER FAIL REQUIRED (BIT15=0)
;:IS NOT MEMORY SIZE DEPENDENT (BIT14=0)
;:IS SUITABLE FOR AUTOMATIC OPERATION (BIT13=0)

000174 000174
000176 000000

000200 000137 001446
000204 000137 006344
000210 000137 006604
000214 000137 007054
000220 000137 007446

000052 000052
000000 000000

.SBTTL BASIC DEFINITIONS

.*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***

001100

STACK= 1100

.EQUIV EAT,ERROR ;:BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL

.*MISCELLANEOUS DEFINITIONS

000011

HT= 11 ;:CODE FOR HORIZONTAL TAB

000012

LF= 12 ;:CODE FOR LINE FEED

000015

CR= 15 ;:CODE FOR CARRIAGE RETURN

000200

CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED

177776

PS= 177776 ;:PROCESSOR STATUS WORD

177774

.EQUIV PS,PSW

177772

STKLMT= 177774 ;:STACK LIMIT REGISTER

177570

PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER

177570

DSWR= 177570 ;:HARDWARE SWITCH REGISTER

DDISP= 177570 ;:HARDWARE DISPLAY REGISTER

.*GENERAL PURPOSE REGISTER DEFINITIONS

000000

R0= %0 ;:GENERAL REGISTER

000001

R1= %1 ;:GENERAL REGISTER

000002

R2= %2 ;:GENERAL REGISTER

000003

R3= %3 ;:GENERAL REGISTER

000004

R4= %4 ;:GENERAL REGISTER

000005

R5= %5 ;:GENERAL REGISTER

000006

R6= %6 ;:GENERAL REGISTER

000007

R7= %7 ;:GENERAL REGISTER

000006

SP= %6 ;:STACK POINTER

000007

PC= %7 ;:PROGRAM COUNTER

.*PRIORITY LEVEL DEFINITIONS

000000

PR0= 0 ;:PRIORITY LEVEL 0

000040

PR1= 40 ;:PRIORITY LEVEL 1

000100

PR2= 100 ;:PRIORITY LEVEL 2

000140

PR3= 140 ;:PRIORITY LEVEL 3

000200

PR4= 200 ;:PRIORITY LEVEL 4

000240

PR5= 240 ;:PRIORITY LEVEL 5

000300

PR6= 300 ;:PRIORITY LEVEL 6

000340

PR7= 340 ;:PRIORITY LEVEL 7

.*"SWITCH REGISTER" SWITCH DEFINITIONS

100000

SW15= 100000

040000

SW14= 40000

020000

SW13= 20000

010000

SW12= 10000

004000

SW11= 4000

002000

SW10= 2000

001000

SW09= 1000

000400

SW08= 400

000200

SW07= 200

000100

SW06= 100

000040

SW05= 40

000020

SW04= 20

000010

SW03= 10

000004

SW02= 4

57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112

113 000002
 114 000001
 115
 116
 117
 118
 119
 120
 121
 122
 123
 124
 125
 126
 127 100000
 128 040000
 129 020000
 130 010000
 131 004000
 132 002000
 133 001000
 134 000400
 135 000200
 136 000100
 137 000040
 138 000020
 139 000010
 140 000004
 141 000002
 142 000001
 143
 144
 145
 146
 147
 148
 149
 150
 151
 152
 153
 154
 155 000004
 156 000010
 157 000014
 158 000014
 159 000014
 160 000020
 161 000024
 162 000030
 163 000034
 164 000060
 165 000064
 166 000240
 167

SW01= 2
 SW00= 1
 .EQUIV SW09,SW9
 .EQUIV SW08,SW8
 .EQUIV SW07,SW7
 .EQUIV SW06,SW6
 .EQUIV SW05,SW5
 .EQUIV SW04,SW4
 .EQUIV SW03,SW3
 .EQUIV SW02,SW2
 .EQUIV SW01,SW1
 .EQUIV SW00,SW0

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
 BIT14= 40000
 BIT13= 20000
 BIT12= 10000
 BIT11= 4000
 BIT10= 2000
 BIT09= 1000
 BIT08= 400
 BIT07= 200
 BIT06= 100
 BIT05= 40
 BIT04= 20
 BIT03= 10
 BIT02= 4
 BIT01= 2
 BIT00= 1
 .EQUIV BIT09,BIT9
 .EQUIV BIT08,BIT8
 .EQUIV BIT07,BIT7
 .EQUIV BIT06,BIT6
 .EQUIV BIT05,BIT5
 .EQUIV BIT04,BIT4
 .EQUIV BIT03,BIT3
 .EQUIV BIT02,BIT2
 .EQUIV BIT01,BIT1
 .EQUIV BIT00,BIT0

.*BASIC "CPU" TRAP VECTOR ADDRESSES

ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
 TBITVEC= 14 ;: "T" BIT
 TRTVEC= 14 ;: TRACE TRAP
 BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
 IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
 PWRVEC= 24 ;: POWER FAIL
 EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
 TRAPVEC= 34 ;: "TRAP" TRAP
 TKVEC= 60 ;: TTY KEYBOARD VECTOR
 TPVEC= 64 ;: TTY PRINTER VECTOR
 PIRGVEC= 240 ;: PROGRAM INTERRUPT REQUEST VECTOR

224 001224 000000
225 001226 000000
226 001230 000000
227 001232 000000
228 001234 000000
229 001236 000000
230 001240 000000
231 001242 000000
232 001244 000000
233 001246 177607 000377
234 001252 077
235 001253 015
236 001254 000012
237
238
239
240
241 001256 000000
242
243
244
245
246 001260 000000
247
248 001262 000000
249
250
251 001264 000000
252
253
254
255 001266 000000
256
257
258
259 001270 000000
260
261
262 001272 000000
263
264
265
266 001274 000000
267
268
269
270
271
272
273 001276 000000
274
275
276
277
278 001300 000000
279

STMP11: .WORD 0
STMP12: .WORD 0
STMP13: .WORD 0
STMP14: .WORD 0
STMP15: .WORD 0
STMP16: .WORD 0
STMP17: .WORD 0
STIMES: 0
\$ESCAPE: 0
\$BELL: .ASCIZ <207><377><377>
\$QUES: .ASCII /?/
\$CRLF: .ASCII <15>
\$LF: .ASCIZ <12>

:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: MAX. NUMBER OF ITERATIONS
:: ESCAPE ON ERROR ADDRESS
:: CODE FOR BELL
:: QUESTION MARK
:: CARRIAGE RETURN
:: LINE FEED

; THE FOLLOWING TAG(S) ARE USER SUPPLIED BY CALLING THE MACRO
; 'MORETAGS' AS ONE OF THE ARGUMENTS TO THE SYSMAC ROUTINE .SCMTAG

TABFLG: .WORD 0
DLBASE: .WORD 0
KEEPAD: .WORD 0
BASEADD: .WORD 0
KEEPIV: .WORD 0
BASEIV: .WORD 0
MULTD: .WORD 0
ACTREG: .WORD 0
ROTADD: .WORD 0
LASTADD: .WORD 0

; AN INDICATOR TO SHOW THAT THE
; INFORMATION FOR MULTIPLE DEVICE
; TESTING HAS ALREADY TRANSPIRED
; & 'MAINDEC' NAME HAS BEEN PRINTED
; STORAGE & WORKING LOCATION FOR A DEVICE
; RECEIVER STATUS REGISTER ADDRESS
; STORAGE LOCATION FOR THE 1ST
; DEVICE RCSR FROM WHICH
; 'BASEADD' IS RESTORED AT THE
; END OF A COMPLETE PROGRAM PASS.
; STORAGE LOCATION WHICH HOLDS
; THE RCSR ADDRESS OF THE 'NEXT'
; DEVICE DURING MULTIPLE TESTING
; STORAGE LOCATION FOR THE 1ST
; DEVICE RECEIVER VECTOR FROM
; WHICH 'BASEIV' IS RESTORED AT THE
; END OF A COMPLETE PROGRAM PASS
; STORAGE LOCATION WHICH HOLDS
; THE VECTOR ADDRESS OF THE 'NEXT'
; DEVICE DURING MULTIPLE TESTING
; FLAG TO INDICATE TO 'END OF PASS'
; ROUTINE THAT MULTIPLE DEVICE
; TESTING IS BEING CONDUCTED
; 0=NO, 1=YES
; THIS IS THE DEVICE ACTIVE REGISTER
; A BIT IS SET (STARTING AT
; BIT0) FOR EACH CONTIGUOUS DEVICE
; (A MAX. OF 16) THAT IS TO UNDERGO
; TESTING. THIS LOCATION IS
; AUTOMATICALLY FILLED BASED ON
; USER RESPONSE TO PROGRAM QUESTIONS
; A ROTATING POINTER TO SIGNAL
; THE LAST DEVICE TESTED (IF
; MULTIPLE DEVICE TESTING WAS BEING
; DONE) IF LESS THAN A FULL COMPLE-
; MENT OF DEVICES (16) WAS SELECTED
; STORAGE LOCATION FOR THE
; RCSR ADDRESS OF THE LAST DEVICE

280
281
282 001302 000000
283
284 001304 000000
285
286
287
288
289
290 001306 177740
291
292
293
294
295
296
297

DLPRI: .WORD 0

LESS1: .WORD 0

STLMSK: 177740

;END OF USER SUPPLIED TAG(S)

;TESTED (IF MULTIPLE DEVICE
;TESTING WAS SELECTED BY USER)
;STORAGE LOCATION FOR THE DEVICE
;INTERRUPT PRIORITY LEVEL
;THE PRIORITY LEVEL THE CPU
;MUST BE AT TO ALLOW DEVICE INTERRUPTS.
;THIS WILL BE 1 LEVEL LESS THAN
;THE DEVICE LEVEL (BASED ON &
;CALCULATED FROM USER RESPONSE TO
;DEVICE PRIORITY LEVEL QUESTION)
;THIS MASK IS USED BY THE 'STALL'
;ROUTINE WHICH WAITS A RANDOM NO.
;OF MILLISECONDS. ITS' USE PREVENTS
;A STALL > 37 MSEC. THIS LOCATION
;HOWEVER, CAN BE PATCHED BY THE
;USER TO ALLOW LARGER 'STALLS'.

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (SERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

SERRTB:

;ERROR TABLE ITEM FOR ERROR MESSAGE 1

298
299
300
301
302
303
304
305
306
307
308
309
310
311
312 001310
313
314
315
316 001310 015146 EM1 ;"DL11 REGISTER REFERENCE CAUSED TIMEOUT"
317 001312 015215 DH1 ;" (PC) (PS) (SP) TEST DEVADR REGADR "
318 001314 015274 DT1 ;" (R7) (PSW) (R6) (R0) (R1) (R2) "
319 001316 000000 0 ;PRINT ALL OCTAL

;ERROR TABLE ITEM FOR ERROR MESSAGE 2

320
321
322
323 001320 015312 EM2 ;" DL11 REGISTER ERROR "
324 001322 015336 DH2 ;" (PC) (PS) (SP) TEST DEVADR REGADR WAS S/B "
325 001324 015434 DT2 ;" (R7) (PSW) (R6) (R0) (R1) (R2) (R3) (R4) "
326 001326 000000 0 ;PRINT ALL OCTAL

;ERROR TABLE ITEM FOR ERROR MESSAGE 3

327
328
329
330 001330 015456 EM3 ;" DL11 DATA COMPARE ERROR "
331 001332 015506 DH3 ;" (PC) (PS) (SP) TEST WASADR SHBADR WAS S/B "
332 001334 015604 DT3 ;" (R7) (PSW) (R6) (R0) (R1) (R2) (R3) (R4) "
333 001336 000000 0 ;PRINT ALL OCTAL

;ERROR TABLE ITEM FOR ERROR MESSAGE 4

334
335
336
337 001340 015626 EM4 ;" UNEXPECTED TRAP TO VECTOR AT LOCATION XXX "
338 001342 015700 DH4 ;" (PC) (PS) (SP) TEST "
339 001344 015736 DT4 ;" (R7) (PSW) (R6) (R0) "
340 001346 000000 0 ;PRINT ALL OCTAL

;ERROR TABLE ITEM FOR ERROR MESSAGE 5

341
342
343
344 001350 015750 EM5 ;" DL11 SOFT ERROR (PARITY, FRAMING, OR OVERRUN) "
345 001352 016025 DH5 ;" (PC) (PS) (SP) TEST DEVADR REGADR (REG) "
346 001354 016114 DT5 ;" (R7) (PSW) (R6) (R0) (R1) (R2) (R3) "
347 001356 000000 0

;ERROR TABLE ITEM FOR ERROR MESSAGE 6

348
349
350
351 001360 015146 EM1 ;"DL11 REGISTER REFERENCE CAUSED TIMEOUT"
352 001362 016134 DH6 ;" (PC) (PS) (SP) REGADR"
353 001364 016174 DT6 ;SERRPC, STMP0, SREG6, SREG2

354 001366 000000
355
356
357
358 001370 015750
359 001372 016206
360 001374 016246
361 001376 000000
362
363
364
365 001400 015456
366 001402 016260
367 001404 016326
368 001406 000000
369
370
371
372
373
374 001410 175610
375 001412 175612
376 001414 175614
377 001416 175616
378 001420 000300
379 001422 000000
380 001424 000000
381 001426 000000
382 001430 000000
383 001432 000000
384 001434 000000
385 001436 000000
386 001440 000000
387 001442 000000
388 001444 000000
389
390
391
392
393 001446 000240
394
395
396 001450 012706 001100
397 001454 005026
398 001456 022706 001140
399 001462 001374
400 001464 012706 001100
401
402 001470 012737 010476 000020
403 001476 012737 000340 000022
404 001504 012737 010746 000030
405 001512 012737 000340 000032
406 001520 012737 013066 000034
407 001526 012737 000340 000036
408 001534 012737 013146 000024
409 001542 012737 000340 000026

0 ;PRINT ALL OCTAL
;ERROR TABLE ITEM FOR ERROR MESSAGE 7
EM5 ;" DL11 SOFT ERROR (PARITY FRAMING, OR OVERRUN) "
DH7 ;" (PC) DEVADR REGADR (REG) "
DT7 ;SERRPC,SREG1,SREG2,SREG3
0 ;PRINT ALL OCTAL

;ERROR TABLE ITEM FOR ERROR MESSAGE 10
EM3 ;" DL11 DATA COMPARE ERROR "
DH10 ;" (PC) DEVADR REGADR (REG) S/B "
DT10 ;SERRPC,SREG1,SREG2,SREG3,SREG4
0 ;PRINT ALL OCTAL

;;*****
;DL11 DEFINITIONS
;;*****

DLRCR: 175610 ;CONTAINS ADDRESS OF RCVR CSR
DLRDBR: 175612 ;CONTAINS ADDRESS OF RCVR DBR
DLXCSR: 175614 ;CONTAINS ADDRESS OF XMIT CSR
DLXDBR: 175616 ;CONTAINS ADDRESS OF XMIT DBR
DLVECT: 300 ;CONTAINS VECTOR ADDRESS OF CURRENT DL11
XFLGO: 0 ;FLAG FOR HARD XMIT ERRORS
RFLGO: 0 ;FLAG FOR HARD RCVR ERRORS
RFLG1: 0 ;FLAG FOR SOFT RCVR ERRORS
RTRY: 0 ;COUNTS NO. OF RETRIES ON SOFT ERRORS
OPTR: 0 ;CONTAINS POINTER TO OUTPUT BUFFER
IPTR: 0 ;CONTAINS POINTER TO INPUT BUFFER
LDOUT: 0 ;CONTAINS POINTER TO LOAD BUFFER ROUTINE
TIMR1: 0 ;TIMERS FOR 256. BYTE BLOCK TRANSFERS
TIMR2: 0
INTFLG: 0 ;SOFTWARE INTR. FLAG

BEGIN: NOP ;PROGRAM WILL START HERE
.SBTTL INITIALIZE THE COMMON TAGS
;;CLEAR THE COMMON TAGS (\$CMTAG) AREA
MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
CLR (R6)+ ;;CLEAR MEMORY LOCATION
CMP #SMR,R6 ;;DONE?
BNE -6 ;;LOOP BACK IF NO
MOV #STACK,SP ;;SETUP THE STACK POINTER
;;INITIALIZE A FEW VECTORS
MOV #SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV #340,@IOTVEC+2 ;;LEVEL 7
MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV #340,@EMTVEC+2 ;;LEVEL 7
MOV #TRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV #340,@TRAPVEC+2 ;;LEVEL 7
MOV #SPWRDN,@PWRVEC ;;POWER FAILURE VECTOR
MOV #340,@PWRVEC+2 ;;LEVEL 7

```

410 001550 005067 177466 CLR STIMES ;: INITIALIZE NUMBER OF ITERATIONS
411 001554 005067 177464 CLR SESCAPE ;: CLEAR THE ESCAPE ON ERROR ADDRESS
412 001560 012767 000001 177327 MOV #1, SERMAX ;: ALLOW ONE ERROR PER TEST
413 001566 012767 001566 177312 MOV #., $LPADR ;: INITIALIZE THE LOOP ADDRESS FOR SCOPE
414 001574 012767 001574 177306 MOV #., $LPERR ;: SETUP THE ERROR LOOP ADDRESS
415 ;: SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
416 ;: EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
417 001602 013746 000004 MOV @ERRVEC, -(SP) ;: SAVE ERROR VECTOR
418 001606 012737 001642 000004 MOV #64$, @ERRVEC ;: SET UP ERROR VECTOR
419 001614 012767 177570 177316 MOV #DSMR, SMR ;: SETUP FOR A HARDWARE SWICH REGISTER
420 001622 012767 177570 177312 MOV #DISP, DISPLAY ;: AND A HARDWARE DISPLAY REGISTER
421 001630 022777 177777 177302 CMP # -1, @SMR ;: TRY TO REFERENCE HARDWARE SMR
422 001636 001012 BNE 66$ ;: BRANCH IF NO TIMEOUT TRAP OCCURRED
423 ;: AND THE HARDWARE SMR IS NOT = -1
424 001640 000403 BR 65$ ;: BRANCH IF NO TIMEOUT
425 001642 012716 001650 64$: MOV #65$, (SP) ;: SET UP FOR TRAP RETURN
426 001646 000002 RTI
427 001650 012767 000176 177262 65$: MOV #SWREG, SMR ;: POINT TO SOFTWARE SMR
428 001656 012767 000174 177256 MOV #DISPREG, DISPLAY
429 001664 012637 000004 66$: MOV (SP)+, @ERRVEC ;: RESTORE ERROR VECTOR
430
431 001670 005067 177376 CLR MULTD ;: CLEAR MULTIPLE DEVICE
432 ;: TESTING FLAG
433 001674 005067 177356 CLR TABFLG ;: CLEAR TABLE CREATION FLAG
434 001700 012767 000010 177326 MOV #8., $TMP15 ;: SET CHARACTER LENGTH DESIGNATOR
435 ;: FOR 8 BITS --- THIS IS THE DEFAULT
436 ;: LENGTH ASSUMED BY THE PROGRAM
437 ;: UNLESS THE USER CHANGES IT THRU
438 ;: THE QUESTION AND ANSWER CYCLE
439 ;: INITIATED BY SETTING SW<0> TO A 1
440 001706 012767 000200 177366 MOV #200, DLPRI ;: SET STANDARD PRIORITY LEVEL
441 ;: FOR DEVICE
442 001714 032777 000400 177216 BIT #SW8, @SMR ;: IS THE 'LOOP ON TEST' SWITCH SET?
443 001722 001411 BEQ 1$ ;: BRANCH IF NOT
444
445 ;: IF THE 'LOOP ON TEST' SWITCH WAS SET WE WILL TAKE THE NEXT BRANCH
446 ;: INSTRUCTION THUS BYPASSING TABLE CREATION
447
448 ;: IF THE USER DESIRED TO LOOP ON A TEST OF OTHER THAN THE DEFAULT DEVICE
449 ;: THEN HE SHOULD HAVE PREVIOUSLY FILLED THE FOLLOWING PROGRAM LOCATIONS
450 ;: WITH THE DESIRED DEVICE REGISTER VALUES:
451
452 *****
453 UNDER ;DL11 DEFINITIONS ABOVE
454 *****
455
456 DLRCR: PATCH THE ADDRESS OF THE RCVR CSR
457 DLRDBR: PATCH THE ADDRESS OF THE RCVR DBR
458 DLXCSR: PATCH THE ADDRESS OF THE XMIT CSR
459 DLXDBR: PATCH THE ADDRESS OF THE XMIT DBR
460 DLVECT: PATCH THE VECTOR ADDRESS OF THIS DL11
461
462 001724 104401 016651 TYPE, STIMES ;: PRINT OUT 'MAINDEC' NAME
463 001730 104401 020673 TYPE, FAILSA ;: TYPE FAILSAFE MESSAGE
464 001734 104000 ERROR +0 ;: TYPE OUT THE PC VALUE
465 001736 104401 021251 TYPE, PCMSG ;: FOLLOWED BY =PC

```



```

466 001742 000000          HALT                ;WAIT FOR USER TO RESPOND
467 001744 000443          BR                ONCE                ;GO TO TEST DEVICE PATCHED IN BY USER
468 001746
469
470
471
472
473
474
475
476
477
478
479 001746 012767 175610 177304  MOV    #175610,DLBASE ;1ST POSSIBLE RECEIVER CSR
480 001754 004767 006110        JSR    PC,DLADDR      ;FORM DL ADDRESSES FOR
481                                     ;1ST POSSIBLE DEVICE
482 001760 012767 000300 177432  MOV    #300,DLVECT   ;1ST POSSIBLE INTERRUPT VECTOR
483 001766 005067 177264        CLR    TABFLG        ;CLEAR TABLE CREATION FLAG
484
485 001772 012706 001100        RESTRT: MOV #STACK,SP ;SET UP STACK POINTER
486 001776 012737 015034 000004  MOV    #BUSERR,#ERRVEC ;SET UP BUS ERROR VECTOR
487 002004 012737 000340 000006  MOV    #340,#ERRVEC+2
488 002012 012737 015060 000010  MOV    #RSVERR,#RESVEC ;SET UP RSVD INSTR. VECTOR
489 002020 012737 000340 000012  MOV    #340,#RESVEC+2
490
491
492
493
494
495 002026 105767 177224        ; THIS NEXT SECTION WILL CHECK TO SEE IF MULTIPLE DEVICE TESTING
496 002032 001010                ; WILL TAKE PLACE I.E.-
497                                     ; A) HAS FREE RUNNING DEVICE TABLE ALREADY BEEN CREATED, AND/OR
498                                     ; B) IF IT HAS, DOES USER WISH TO CHANGE IT, OR DO WE TEST DEFAULT DEVICE?
499
500 002034 104401 016651        TSTB   TABFLG        ;HAS TABLE CREATION BEEN PERFORMED?
501                                     BNE    ONCE          ;BRANCH IF YES TO SKIP 'MAINDEC
502                                     ; TITLE' MESSAGE
503                                     ; OTHERWISE, PRINT OUT 'MAINDEC'
504                                     ; NAME
505 002040 105167 177212        COMB   TABFLG        ; IF TABLE CREATION HAS NOT BEEN
506                                     ; PERFORMED, THEN SET FLAG, AND DO SO
507 002044 032777 000001 177066  BIT    #SWO,#SWR     ; THE PROGRAM HAS OBVIOUSLY BEEN
508                                     ; RESTARTED - DOES USER WISH TO
509                                     ; RESELECT VECTOR AND CONTROL REGISTER
510                                     ; ADDRESSES I.E. - CREATE A NEW TABLE?
511                                     ; BRANCH IF YES
512
513 002052 001012                ONCE:  BNE    GO      ;CLEAR OUT BOTH CSR'S
514 002054 005077 177334        CLR    @DLXCSR
515 002060 005077 177324        CLR    @DLRCSR
516 002064 005777 177322        TST   @DLRDBR      ;FLUSH RCVR "DONE" BIT
517 002070 005777 177316        TST   @DLRDBR
518 002074 000167 000670        JMP    TST1
519                                     ; OTHERWISE, GO WITH EXISTING
520                                     ; TABLE OR NOT USE ANY TABLE AT
521                                     ; ALL WHICHEVER THE CASE MAY BE
522                                     ; (DEFAULT CASE IS 1ST POSSIBLE
523                                     ; DEVICE)
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
    
```

522 002104 104411
523
524 002106 012600
525 002110 020027 000010
526 002114 101114
527 002116 020027 000005
528 002122 103511
529 002124 010067 177104
530
531 002130 104401 017315
532
533 002134 104410
534 002136 005726
535 002140 001002
536 002142 000137 002724
537 002146 012700 000300
538 002152 012701 000302
539 002156 012702 000004
540 002162 010110
541 002164 005011
542 002166 060200
543 002170 060201
544 002172 022701 001000
545 002176 002771
546
547
548
549 002200 104401 017422
550
551
552 002204 104410
553
554
555 002206 012600
556 002210 020027 176170
557 002214 101060
558 002216 020027 175610
559 002222 103455
560 002224 132700 000001
561
562 002230 001052
563
564 002232 032700 000007
565
566 002236 001047
567 002240 010067 177014
568
569
570 002244 016767 177010 177010
571 002252 004767 005612
572
573 002256 016767 177000 177000
574 002264 104401 017510
575 002270 104410
576
577

```

RDEEC ;ACCEPT THE ANSWER TYPED BY USER
;CHECK TO SEE IF USER RESPONSE WAS WITHIN LIMITS
MOV (SP)+,RO ;GET THE ANSWER TYPED
CMP RO,#8. ;IS THE NUMBER TOO HIGH?
BHI RETRY ;IF YES - GO TO RETRY SITUATION
CMP RO,#5. ;IS THE NUMBER TOO LOW?
BLO RETRY ;IF YES - GO TO RETRY SITUATION
MOV RO,STMP15 ;THE VALUE TYPED IS OK
;STORE FOR FUTURE USE
TYPE, DEFAULT ;ASK USER IF HE WISHES TO TEST OTHER
;THAN THE DEFAULT DEVICE
RDOCT ;ACCEPT THE ANSWER TYPED BY USER
TST (SP)+ ;LOOK AT THE ANSWER
BNE 1$ ;BRANCH IF REPLY WAS YES
JMP 2$FLUSH ;OTHERWISE, SKIP REST OF INTERROGATION
1$: MOV #300,RO ;START RESTORATION OF TRAPCATCHER
MOV #302,R1 ;AREA FROM LOCATIONS 300 TO 776
MOV #4,R2 ;SO THAT WE CREATE THE MULTIPLE
2$: MOV R1,(RO) ;DEVICES TABLE WITH A CLEAN SLATE
CLR (R1)
ADD R2,RO
ADD R2,R1
CMP #1000,R1
BLT 2$
;THE TRAPCATCHER VECTOR AREA FROM 300 - 776 SHOULD NOW BE RESTORED.
;PROCEED TO FIND OUT THE 1ST DEVICE RECEIVER CONTROL REGISTER
;ADDRESS
FIRSTD: TYPE ,MFIRSTD ;ASK USER FOR THE RECEIVER CONTROL
;REGISTER ADDRESS OF HIS FIRST
;DEVICE
RDOCT ;ACCEPT THE ANSWER TYPED BY USER
;AND STORE ON TOP OF STACK
;CHECK TO SEE IF USER RESPONSE WAS WITHIN LIMITS
MOV (SP)+,RO ;GET THE ANSWER TYPED
CMP RO,#176170 ;IS THE NUMBER TOO HIGH?
BHI RETRYO ;IF YES-GO TO RETRY SITUATION
CMP RO,#175610 ;IS THE NUMBER TOO LOW?
BLO RETRYO ;IF YES - GO TO RETRY SITUATION
BITB #BIT0,RO ;NUMBER IS IN RANGE BUT IS IT
;ON AN EVEN BOUNDARY?
BNE RETRYO ;IF NO - GO TO RETRY SITUATION
;CHECK TO SEE IF USER RESPONSE WAS TRULY A RCVR STATUS REGISTER
BIT #7,RO ;WAS THE LEAST SIGNIFICANT DIGIT OF THE
;USER RESPONSE EQUAL TO A ZERO?
BNE RETRYO ;BRANCH IF NOT
MOV RO,DLBASE ;THE 1ST ADDRESS VALUE TYPED IS OK
;STORE FOR FUTURE USE
;NOW WE ARE READY TO FIND OUT THE DEVICE INTERRUPT VECTOR
MOV DLBASE,KEEPADD ;GET 1ST ADDRESS VALUE
JSR PC,DLADDR ;GO FORM DL ADDRESSES FOR
;1ST DEVICE SELECTED
MOV KEEPADD,BASEADD ;RESTORE 1ST DEVICE ADDRESS
VECT: TYPE ,MVECT ;ASK USER FOR A VECTOR ADDRESS
RDOCT ;ACCEPT THE ANSWER TYPED BY USER
;AND STORE ON TOP OF STACK
;CHECK TO SEE IF USER RESPONSE WAS WITHIN LIMITS

```


578	002272	012600			MOV	(SP)+,RO		;GET THE ANSWER TYPED
579	002274	020027	000776		CMP	RO,#776		;IS THE NUMBER TOO HIGH?
580	002300	101032			BHI	RETRY1		;IF YES - GO TO RETRY SITUATION
581	002302	020027	000300		CMP	RO,#300		;IS THE NUMBER TOO LOW?
582	002306	103427			BLO	RETRY1		;IF YES - GO TO RETRY SITUATION
583	002310	132700	000001		BITB	#BIT0,RO		;NUMBER IS IN RANGE BUT IS IT
584								;ON AN EVEN BOUNDARY?
585	002314	001024			BNE	RETRY1		;IF NO - GO TO RETRY SITUATION
586								;CHECK TO SEE IF THE USER RESPONSE WAS TRULY A RCVR VECTOR ADDRESS
587	002316	032700	000007		BIT	#7,RO		;WAS THE LEAST SIGNIFICANT DIGIT OF THE
588								;USER RESPONSE EQUAL TO A ZERO?
589	002322	001021			BNE	RETRY1		;BRANCH IF NOT
590	002324	010067	177070		MOV	RO,DLVECT		;THE VECTOR VALUE TYPED IS OK
591								;STORE FOR FUTURE USE
592	002330	016767	177064	176730	MOV	DLVECT,KEEP1V		;GET THE FIRST VECTOR VALUE
593	002336	016767	177056	176724	MOV	DLVECT,BASE1V		;SAVE FIRST VECTOR VALUE
594	002344	000414			BR	HOWMANY		;GO TO SEE IF USER WANTS MORE
595								;THAN 1 DEVICE
596	002346	104401	001252		RETRY:	TYPE, \$QUES		;TYPE '?' INDICATING USER TYPED
597								;SOMETHING WRONG FOR CHARACTER LENGTH
598	002352	000167	177522		JMP	GO		;GO BACK TO REISSUE QUESTION
599	002356	104401	001252		RETRY0:	TYPE , \$QUES		;TYPE '?' INDICATING USER TYPE
600								;SOMETHING WRONG FOR 1ST ADDRESS
601	002362	000167	177612		JMP	FIRSTD		;GO BACK TO REISSUE QUESTION
602	002366	104401	001252		RETRY1:	TYPE , \$QUES		;TYPE '?' INDICATING USER TYPED
603								;SOMETHING WRONG FOR VECTOR
604	002372	000167	177666		JMP	VECT		;GO BACK TO REISSUE QUESTION
605	002376	104401	017566		HOWMANY:	TYPE , MULDEV		;ASK USER IF HE WISHES TO RUN
606								;MULTIPLE DEVICES
607	002402	104410			RDOCT			;ACCEPT THE ANSWER TYPED BY USER
608								;AND STORE ON TOP OF STACK
609	002404	012600			MOV	(SP)+,RO		;GET THE ANSWER TYPED
610	002406	005700			TST	RO		;WAS THE ANSWER YES?
611	002410	001003			BNE	1\$;BRANCH IF IT WAS
612	002412	005067	176654		CLR	MULTD		;OTHERWISE, INITIALIZE FLAG TO
613								;INDICATE NON-MULTIPLE DEVICES
614	002416	000402			BR	2\$;SKIP NEXT INSTRUCTION
615	002420	105167	176646		1\$:	COMB MULTD		;INITIALIZE FLAG TO INDICATE
616								;RUNNING OF MULTIPLE DEVICES
617	002424				2\$:			
618	002424	105767	176642		TSTB	MULTD		;ARE THERE MULTIPLE DEVICES ON
619								;THE SYSTEM?
620	002430	100406			BMI	LASTD ;IF SO,		;GO TO ASK NEXT QUESTION
621	002432	005067	176636		CLR	ACTREG		;CLEAR DEVICE ACTIVE FLAG TO
622								;INDICATE NO RUNNING OF MULTIPLE
623								;DEVICES
624	002436	005067	176634		CLR	ROTADD		;CLEAR DEVICE ADDRESS POINTER IN
625								;USE WHEN RUNNING MULTIPLE DEVICES
626	002442	000167	000160		JMP	CONQUES		;SKIP ASKING NEXT QUESTION
627	002446							
628					LASTD:			;WE WILL NOW BEGIN TO SET UP THE DEVICE ACTIVE REGISTER FOR RUNNING
629								;MULTIPLE DL11 DEVICES
630	002446	104401	017653		TYPE	,MLASTD		;ASK USER FOR THE RECEIVER
631								;CONTROL REGISTER ADDRESS OF
632								;HIS LAST DEVICE
633	002452	104410			RDOCT			;ACCEPT THE ANSWER TYPED BY

```

634                                     ;USER AND STORE ON TOP OF STACK
635                                     ;CHECK TO SEE IF THE USER RESPONSE WAS WITHIN LIMITS
636 002454 012600 1$: MOV (SP)+,RO ;GET THE ANSWER TYPED
637 002456 020027 176170 CMP RO,#176170 ;IS THE NUMBER TOO HIGH?
638 002462 101132 BHI RETRY2 ;IF YES - GO TO RETRY SITUATION
639 002464 020027 175610 CMP RO,#175610 ;IS THE NUMBER TOO LOW?
640 002470 103527 BLO RETRY2 ;IF YES - GO TO RETRY SITUATION
641 002472 132700 000001 BITB #BIT0,RO ;NUMBER IS IN RANGE BUT IS IT
642                                     ;ON AN EVEN BOUNDARY?
643 002476 001124 BNE RETRY2 ;IF NOT - GO TO RETRY SITUATION
644                                     ;CHECK TO SEE IF USER RESPONSE WAS TRULY A RCVR STATUS REGISTER
645 002500 032700 000007 BIT #7,RO ;WAS THE LEAST SIGNIFICANT DIGIT OF THE
646                                     ;USER RESPONSE EQUAL TO A ZERO?
647 002504 001121 BNE RETRY2 ;BRANCH IF NOT
648 002506 010067 176566 MOV RO, LASTADD ;THE LAST ADDRESS VALUE TYPED IS OK
649                                     ;STORE FOR FUTURE USE
650                                     ;NOW WE BEGIN TO ACTUALLY INITIALIZE THE DEVICE ACTIVE REGISTER
651                                     ;FROM WHICH THE PROGRAM WILL CYCLE UNTIL ALL DEVICES HAVE BEEN TESTED
652 002512 012767 000001 176556 MOV #1, ROTADD ;SET UP POINTER FOR 'ACTREG'
653 002520 005067 176550 CLR ACTREG ;CLEAR DEVICE ACTIVE REGISTER
654 002524 056767 176546 176542 2$: BIS ROTADD, ACTREG ;MAKE 1ST DEVICE ACTIVE
655 002532 000241 CLC ;CLEAR CARRY BIT FOR POINTER
656                                     ;ROTATION
657 002534 006167 176536 ROL ROTADD ;ARE WE PAST 16 LINE RANGE?
658 002540 103422 BCS 3$ ;BRANCH IF YES
659 002542 062767 000010 176514 ADD #10, BASEADD ;STEP UP BASE ADDRESS
660 002550 026767 176524 176506 CMP LASTADD, BASEADD ;IS THIS THE LAST DEVICE?
661 002556 101362 BHI 2$ ;BRANCH IF NOT
662                                     ;NOTE: IF THIS PATH IS TAKEN IT IS ASSUMED THAT AT LEAST 2 DEVICES
663                                     ;EXIST AND THAT ALL ADDRESSING IS CONTIGUOUS
664 002560 056767 176512 176506 BIS ROTADD, ACTREG ;INDICATE NEXT DEVICE ACTIVE
665 002566 012767 000001 176502 MOV #1, ROTADD ;RESET POINTER FOR 'ACTREG' FOR
666                                     ;LATER USE IN END OF PASS ROUTINE
667 002574 016767 176462 176462 MOV KEEPADD, BASEADD ;RESET 1ST DEVICE RECEIVER
668                                     ;CONTROLLER REGISTER ADDRESS FOR
669                                     ;LATER USE IN END OF PASS ROUTINE
670 002602 000167 000020 JMP CONQUES ;GO TO CONTINUE QUESTIONING OF USER
671 002606
672
673
674
675 002606 016767 176450 176450 3$: MOV KEEPADD, BASEADD ;RESET 1ST DEVICE RECEIVER
676                                     ;CONTROLLER REGISTER ADDRESS
677 002614 104401 017751 TYPE ,MRANGE ;INFORM USER TO CHECK AND RETYPE
678                                     ;THE LAST DEVICE RCSR ADDRESS
679 002620 104410 RDOCT ;ACCEPT THE ANSWER TYPED BY USER
680                                     ;AND STORE ON TOP OF STACK
681 002622 000167 177626 JMP 1$
682 002626
683
684
685
686
687
688 002626 104401 020035 CONQUES: ;IF WE HAVE REACHED THIS PORTION WE KNOW:
689 002632 104410 TYPE ,PLEVEL ;ASK USER FOR PRIORITY LEVEL
        RDOCT ;ACCEPT ANSWER TYPED BY USER AND
    
```



```

690                                     ;STORE ON TOP OF STACK
691 002634 012600                       MOV    (SP)+,RO      ;GET THE ANSWER TYPED
692 002636 020027 000007                 CMP    R0,#7       ;IS THE NUMBER TOO HIGH?
693 002642 101046                         BHI   RETRY3       ;IF YES - GO TO RETRY SITUATION
694 002644 020027 000004                 CMP    R0,#4       ;IS THE NUMBER TOO LOW?
695 002650 103443                         BLO   RETRY3       ;IF YES GO TO RETRY SITUATION
696 002652 010067 176424                 MOV    R0,DLPRI    ;THE PRIORITY TYPED IN IS OK
697                                     ;STORE FOR FUTURE USE
698
699                                     ;THIS SECTION WILL CALCULATE THE PRIORITY LEVEL FOR THE
700                                     ;PROCESSOR BASED ON THE USER RESPONSE FOR PRIORITY LEVEL OF THE
701                                     ;DEVICE
702 002656 006367 176420                   ASL    DLPRI       ;FORM BITS <7-5> OF PSM
703 002662 006367 176414                   ASL    DLPRI
704 002666 006367 176410                   ASL    DLPRI
705 002672 006367 176404                   ASL    DLPRI
706 002676 006367 176400                   ASL    DLPRI
707 002702 016767 176374 176374           MOV    DLPRI,LESS1 ;START TO FORM LEVEL TO ALLOW
708                                     ;INTERRUPTS
709 002710 162767 000001 176366           SUB    #1,LESS1    ;DROP DEVICE LEVEL PRIORITY
710                                     ;BY 1 LEVEL FOR PSM
711 002716 042767 000037 176360           BIC    #37,LESS1   ;MAKE SURE THE T,N,Z,V & C
712                                     ;BITS FOR THE PROCESSOR ARE CLEAR
713 002724 005077 176464                   FLUSH: CLR  DLRCSR  ;CLEAR OUT BOTH CSR'S
714 002730 005077 176454                   CLR  DLRCSR
715 002734 005777 176452                   TST  DLRDBR
716 002740 005777 176446                   TST  DLRDBR
717 002744 000167 000020                   JMP    TST1
718 002750 104401 001252                   RETRY2: TYPE ,SQUES ;BEGIN TESTING
719                                     ;TYPE '?' INDICATING USER TYPED
720 002754 000167 177466                   JMP    LASTD ;GO BACK TO REISSUE QUESTION
721 002760 104401 001252                   RETRY3: TYPE ,SQUES ;TYPE '?' INDICATING USER TYPED
722                                     ;SOMETHING WRONG FOR LAST ADDRESS
723 002764 000167 177636                   JMP    CONQUES     ;SOMETHING WRONG FOR PRIORITY
724                                     ;GO BACK TO REISSUE QUESTION
725
726                                     ;*****
727                                     ;*TEST 1 TEST THAT REFERENCE TO RCSR DOES NOT CAUSE TIMEOUT
728                                     ;*****
729 002770 000004                               †TST1: SCOPE
730 002772 016746 175006 175000           MOV    ERRVEC,-(SP) ;SAVE THE TIMEOUT VECTOR
731 002776 012767 003014 175000           MOV    #1$,ERRVEC  ;GO TO 1$ IF TIMEOUT
732 003004 016702 176400                   MOV    DLRCSR,R2   ;REGADR = RCSR ADR
733 003010 005712                               TST   (R2)         ;USE REGADR ON BUS
734 003012 000407                               BR    3$           ;<GO TO NEXT TEST IF NO TIMEOUT>
735 003014 004767 011112 176216           1$:   JSR    PC,SUERT1 ;GO SET UP ERROR INFO
736 003020 012767 003030 176216           MOV    #2$,SESCAPE ;RETURN TO 2$ AFTER ERROR PRINT
737 003026 104001                               ERROR+1 ;DL REFERENCE CAUSED BUS TIMEOUT
738 003030 022626                               2$:   CMP    (SP)+,(SP)+ ;CLEAN STACK FROM TIMEOUT
739 003032 012667 174746                               3$:   MOV    (SP)+,ERRVEC ;RESTORE TIMEOUT VECTOR
740
741                                     ;*****
742                                     ;*TEST 2 TEST THAT REFERENCE TO XCSR DOES NOT CAUSE TIMEOUT
743                                     ;*****
744 003036 000004                               †TST2: SCOPE
745 003040 016746 174740                   MOV    ERRVEC,-(SP) ;SAVE THE TIMEOUT VECTOR

```

```

746 003044 012767 003062 174732      MOV      #1$,ERRVEC      ;GO TO 1$ IF TIMEOUT
747 003052 016702 176336      MOV      DLXCSR,R2      ;REGADR = XCSR ADR
748 003056 005712              TST      (R2)           ;USE REGADR ON BUS
749 003060 000407              BR       3$             ;<GO TO NEXT TEST IF NO TIMEOUT>
750 003062 004767 011044      1$:     JSR      PC,SUERT1 ;GO SET UP ERROR INFO
751 003066 012767 003076 176150      MOV      #2$,SESCAPE    ;RETURN TO 2$ AFTER ERROR PRINT
752 003074 104001              ERROR+1 ;DL REFERENCE CAUSED BUS TIMEOUT
753 003076 022626      2$:     CMP      (SP)+,(SP)+ ;CLEAN STACK FROM TIMEOUT
754 003100 012667 174700      3$:     MOV      (SP)+,ERRVEC ;RESTORE TIMEOUT VECTOR
755

```

```

*****
;TEST 3      TEST THAT REFERENCE TO RDBR DOES NOT CAUSE TIMEOUT
*****

```

```

759 003104 000004      TST3:   SCOPE
760 003106 016746 174672      MOV      ERRVEC,-(SP)   ;SAVE THE TIMEOUT VECTOR
761 003112 012767 003130 174664      MOV      #1$,ERRVEC    ;GO TO 1$ IF TIMEOUT
762 003120 016702 176266      MOV      DLROBR,R2     ;REGADR = RDBR ADR
763 003124 005712              TST      (R2)           ;USE REGADR ON BUS
764 003126 000407              BR       3$             ;<GO TO NEXT TEST IF NO TIMEOUT>
765 003130 004767 010776      1$:     JSR      PC,SUERT1 ;GO SET UP ERROR INFO
766 003134 012767 003144 176102      MOV      #2$,SESCAPE    ;RETURN TO 2$ AFTER ERROR PRINT
767 003142 104001              ERROR+1 ;DL REFERENCE CAUSED BUS TIMEOUT
768 003144 022626      2$:     CMP      (SP)+,(SP)+ ;CLEAN STACK FROM TIMEOUT
769 003146 012667 174632      3$:     MOV      (SP)+,ERRVEC ;RESTORE TIMEOUT VECTOR
770

```

```

*****
;TEST 4      TEST THAT REFERENCE TO XDBR DOES NOT CAUSE TIMEOUT
*****

```

```

774 003152 000004      TST4:   SCOPE
775 003154 016746 174624      MOV      ERRVEC,-(SP)   ;SAVE THE TIMEOUT VECTOR
776 003160 012767 003176 174616      MOV      #1$,ERRVEC    ;GO TO 1$ IF TIMEOUT
777 003166 016702 176224      MOV      DLXDBR,R2     ;REGADR = XDBR ADR
778 003172 005712              TST      (R2)           ;USE REGADR ON BUS
779 003174 000407              BR       3$             ;<GO TO NEXT TEST IF NO TIMEOUT>
780 003176 004767 010730      1$:     JSR      PC,SUERT1 ;GO SET UP ERROR INFO
781 003202 012767 003212 176034      MOV      #2$,SESCAPE    ;RETURN TO 2$ AFTER ERROR PRINT
782 003210 104001              ERROR+1 ;DL REFERENCE CAUSED BUS TIMEOUT
783 003212 022626      2$:     CMP      (SP)+,(SP)+ ;CLEAN STACK FROM TIMEOUT
784 003214 012667 174564      3$:     MOV      (SP)+,ERRVEC ;RESTORE TIMEOUT VECTOR
785

```

```

*****
;TEST 5      TEST THAT RCSR IS ALL ZEROES ON ENTRY
*****

```

```

789 003220 000004      TST5:   SCOPE
790 003222 005004              CLR      R4             ;RESULT IN RCSR S/B = 0
791 003224 016702 176160      MOV      DLRCR,R2      ;REGADR = RCSR ADR
792 003230 020412              CMP      R4,(R2)        ;[RCSR]=000000 ??
793 003232 001403              BEQ     TST6            ;<BR IF YES>
794 003234 004767 010612      JSR      PC,SUER2      ;GO SET UP ERROR INFO
795 003240 104002              ERROR+2 ;RCSR NOT CLEAR ON START UP
796

```

```

*****
;TEST 6      TEST THAT "READY" BIT IS ONLY BIT SET IN XCSR
*****

```

```

799 003242 000004      TST6:   SCOPE
800 003244 012704 000200      MOV      #200,R4       ;RESULT IN XCSR S/B = 000200
801 003250 016702 176140      MOV      DLXCSR,R2     ;REGADR = XCSR ADR

```


L03

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 16
 DZDLCB.P11 06-MAY-77 10:04 T6 TEST THAT "READY" BIT IS ONLY BIT SET IN XCSR

```

802 003254 020412          CMP      R4,(R2)          ;[XCSR]=000200 ??
803 003256 001403          BEQ      TST7             ;<BR IF YES>
804 003260 004767 010566   JSR      PC,SUER2        ;GO SETUP ERROR INFO
805 003264 104002          ERROR+2                ;[XCSR] INCORRECT ON START UP
806
807 ;*****
808 ;*TEST 7 TEST THAT "MAINT" BIT CAN BE SET AND CLEARED
809 ;*****
809 003266 000004          TST7:  SCOPE
810 003270 012704 000204   MOV      #204,R4          ;RESULT IN XCSR S/B = 000204
811 003274 016702 176114   MOV      DLXCSR,R2        ;REGADR = XCSR ADR
812 003300 052712 000004   BIS      #BIT2,(R2)       ;SET THE "MAINT" BIT
813 003304 020412          CMP      R4,(R2) ;RESULT ;RESULT IN XCSR OK ??
814 003306 001403          BEQ      1$              ;<BR IF YES>
815 003310 004767 010536   JSR      PC,SUER2        ;GO SET UP ERROR INFO
816 003314 104002          ERROR+2                ;MAINT. BIT FAILED TO SET PROPERLY
817 003316 012704 000200   1$:  MOV      #200,R4          ;RESULT IN XCSR S/B = 000200
818 003322 042712 000004   BIC      #BIT2,(R2)       ;NOW CLEAR THE "MAINT" BIT
819 003326 020412          CMP      R4,(R2) ;RESULT ;RESULT IN XCSR OK ??
820 003330 001403          BEQ      TST10           ;<BR IF YES>
821 003332 004767 010514   JSR      PC,SUER2        ;GO SET UP ERROR INFO
822 003336 104002          ERROR+2                ;MAINT BIT FAILED TO CLEAR PROPERLY
823 ;*****
824 ;*TEST 10 TEST THAT XMIT I.E. CAN CAUSE AN INTR
825 ;*****
826 003340 000004          TST10: SCOPE
827 003342 005067 176076   CLR      INTFLG           ;INIT SOFTWARE INTR FLAG
828 003346 016705 176046   MOV      DLVECT,R5        ;GET VECTOR ADDRESS
829 003352 012765 003440 000004  MOV      #2$,(R5)         ;GO TO 4$ ON INTR
830 003360 016765 175716 000006  MOV      DLPRI,6(R5)      ;PRIORITY LEVEL 4
831 003366 005005          CLR      R5              ;INIT INTR. TIMER
832 003370 012704 000200   MOV      #200,R4          ;RESULT IN XCSR S/B = 000200
833 003374 016702 176014   MOV      DLXCSR,R2        ;REGADR = XCSR ADR
834 003400 052712 000100   BIS      #100,(R2)        ;SET INTR. ENABLE BIT 06
835 003404 005767 176034   1$:  TST      INTFLG         ;DID INTR OCCUR YET ??
836 003410 001020          BNE      3$              ;BR IF IT DID
837 003412 005305          DEC      R5              ;COUNT THE TIMER
838 003414 001373          BNE      1$              ;BR IF NO TIMEOUT
839 003416 012704 000300   MOV      #300,R4          ;RESULT IN XCSR S/B = 000300
840 003422 004767 010424   JSR      PC,SUER2        ;GO SETUP ERROR INFO
841 003426 012767 003436 175610  MOV      #4$,SESCAPE      ;RETURN TO 4$ AFTER ERROR PRINT
842 003434 104002          ERROR+2                ;INTR. FAILED
843
844 4$:  BR      TST11            ;<GO TO NEXT TEST>
845 2$:  COM      INTFLG         ;SET THE SOFTWARE FLAG
846 003444 042712 000100   BIC      #100,(R2)        ;TURN OFF I.E. BIT
847 003450 000002          RTI                     ;RETURN CONTROL TO INTR. ROUTINE
848 3$:  CMP      R4,(R2) ;RESULT ;RESULT IN XCSR OK ??
849 003454 001403          BEQ      TST11           ;<BR IF YES>
850 003456 004767 010370   JSR      PC,SUER2        ;GO SET UP ERROR INFO.
851 003462 104002          ERROR+2                ;XMIT INTR. NOT SERVICED PROPERLY
852 ;*****
853 ;*TEST 11 TEST THAT RCVR I.E. BIT CAN BE SET AND CLEARED
854 ;*****
855 003464 000004          TST11: SCOPE
856 003466 012704 000100   MOV      #100,R4          ;RESULT IN RCSR S/B = 000100
857 003472 016702 175712   MOV      DLRCR,R2         ;REGADR = RCSR ADR
  
```



```

914 003754 004767 010072      JSR      PC,SUER2      ;GO SET UP ERROR INFO
915 003760 104002              ERROR+2              ;RCVR INTR NOT SERVICED PROPERLY
916 003762 016701 175424      5S:    MOV      DLDRAR,R1 ;SAVE WAS ADDRESS
917 003766 016702 175424      MOV      DLXDRR,R2    ;SAVE THE S/B ADDRESS
918 003772 004767 010746      JSR      PC,UPMASK    ;GET THE WAS DATA AND
919                               ;GO MASK OFF BITS AS A FUNCTION OF
920                               ;CHARACTER LENGTH ( 5, 6, 7, OR 8 BITS)
921 003776 116703 175230      MOVB     STMP14,R3    ;SET UP FOR ERROR CHECKING
922 004002 110004              MOVB     R0,R4        ;GET THE S/B DATA
923 004004 020403              CMP      R4,R3        ;WAS = S/B ??
924 004006 001403              BEQ     TST13         ;<BR IF YES>
925 004010 004767 010064      JSR      PC,SUERR1    ;GO SET UP THE ERROR INFO
926 004014 104003              ERROR+3              ;DATA COMPARE ERROR
927
928 *****
929 *TEST 13      TEST THAT "REQ TO SEND" ASSERTS "RING"
930 *****
931 TST13:  SCOPE
932        BIT      #SW12,ASWR ;ARE WE TESTING /C OR /D MODEL?
933        BNE     TST14         ;<BRANCH IF YES>
934        MOV     #140004,R4    ;RESULT IN RCSR S/B = 140004
935        MOV     DLRCSR,R2    ;REGADR = RCSR ADR
936        CLR     (R2)         ;INIT THE RCSR TO 000000
937        BIS     #BIT2,(R2)    ;SET "REQ TO SEND"
938        BIT     #BIT15,ADLRCSR ;DID "RING" SET "DATA SET INT" ?
939        BNE     IS          ;<BR IF YES>
940        JSR     PC,SUER2     ;GO SET UP ERROR INFO.
941        ERROR+2              ;"RING" TRANSITION FAILED TO SET "DATA SET INT"
942        ;NOTE: "BIT #BIT15,(R2)" RESETS BIT15
943        MOV     #40004,R4    ;RESULT IN RCSR S/B = 40004
944        CMP     R4,(R2)     ;BOTH "RING" AND "REQ TO SEND" ASSERTED ?
945        BEQ     2S          ;<BR IF YES>
946        JSR     PC,SUER2     ;GO SET UP ERROR INFO.
947        ERROR+2              ;"RING" OR "REQ TO SEND" FAILED TO SET
948        CLR     R4          ;RESULT IN RCSR S/B = 000000
949        BIC     #BIT2,(R2)    ;CLEAR "REQ TO SEND"
950        BIT     #BIT15,ADLRCSR ;DID "DATA SET INT" GET SET ??
951        BEQ     3S          ;<BR IF NOT>
952        JSR     PC,SUER2     ;GO SET UP ERROR INFO
953        ERROR+2              ;CLEARING "RING" SET "DATA SET INT"
954        CMP     R4,(R2)     ;RCSR CONTAIN ALL ZEROES ??
955        BEQ     TST14         ;<BR IF YES>
956        JSR     PC,SUER2     ;GO SET UP ERROR INFO.
957        MOV     .+6,$REG7    ;SAVE THE ERROR PC
958        ERROR+2              ;CLEARING "REQ TO SEND" FAILED TO CLEAR "RING"
959 *****
960 *TEST 14      TEST THAT "SEC XMIT" ASSERTS "SEC REC" AND "DATA SET INT"
961 *****
962 TST14:  SCOPE
963        BIT     #SW12,ASWR    ;ARE WE TESTING /C OR /D MODEL?
964        BNE     TST15         ;<BRANCH IF YES>
965        MOV     DLRCSR,R2    ;REGADR = RCSR ADR
966        CLR     (R2)         ;INIT RCSR TO 000000
967        MOV     #102010,R4   ;CONTENTS OF RCSR S/B = 102010
968        BIS     #BIT3,(R2)    ;SET "SEC XMIT" BIT
969        BIT     #BIT15,ADLRCSR ;DID "DATA SET INT" SET ??
970        BNE     IS          ;<BR IF YES>

```


970	004206	004767	007640		JSR	PC, SUER2	GO SET UP ERROR INFO
971	004212	104002			ERROR+2		"DATA SET INT" FAILED TO SET-NOTE THAT
972							"BIT #BIT15, (R2)" RESETS BIT15
973	004214	012704	002010	1S:	MOV	#2010, R4	RESULT IN RCSR S/B = 2010
974	004220	020412			CMP	R4, (R2)	ARE "SEC XMIT" AND "SEC REC" BOTH SET ?
975	004222	001403			BEQ	2S	<BR IF YES>
976	004224	004767	007622		JSR	PC, SUER2	GO SET UP ERROR INFO
977	004230	104002			ERROR+2		"SEC XMIT" OR "SEC REC" FAILED TO SET
978							OR "DATA SET INT" FAILED TO BE CLEARED
979							WHEN REFERENCING RCSR
980	004232	012704	100000	2S:	MOV	#BIT15, R4	RESULT IN RCSR S/B = 100000
981	004235	042712	000010		BIC	#BIT3, (R2)	CLEAR "SEC XMIT" BIT
982	004242	032777	100000	175140	BIT	#BIT15, DLCSR	DID CLEARING IT SET "DATA SET INT"??
983	004250	001003			BNE	3S	<BR IF YES>
984	004252	004767	007574		JSR	PC, SUER2	GO SET UP ERROR INFO.
985	004256	104002			ERROR+2		CLEARING "SEC XMIT" FAILED TO SET "DATA
986							SET INT. (NOTE THAT REFERENCING RCSR
987							CLEAR "DATA SET INT"
988	004260	005004		3S:	CLR	R4	RESULT IN RCSR S/B = 000000
989	004262	020412			CMP	R4, (R2)	"SEC XMIT" AND "SEC REC" CLEAR ?
990	004264	001403			BEQ	TST15	<BR IF YES>
991	004266	004767	007560		JSR	PC, SUER2	GO SETUP ERROR INFO
992	004272	104002			ERROR+2		"SEC XMIT" OR "SEC REC" FAILED TO CLEAR
993							OR REFERENCING RCSR FAILED TO CLEAR "DATA SET INT"
994							*****
995							TEST 15 TEST THAT "DTR" CAN ASSERT "CLR TO SEND" AND "CAR DET"
996							*****
997	004274	000004		TST15:	SCOPE		
998	004276	032777	010000	174634	BIT	#SM12, DSMR	ARE WE TESTING /C OR /D MODEL?
999	004304	001046			BNE	TST16	<BRANCH IF YES>
1000	004306	016702	175076		MOV	DLCSR, R2	REGADR = RCSR ADR
1001	004312	005012			CLR	(R2)	INIT RCSR TO 000000
1002	004314	012704	130002		MOV	#130002, R4	RESULT IN RCSR S/B = 130002
1003	004320	052712	000002		BIS	#BIT1, (R2)	SET "DTR" BIT
1004	004324	032777	100000	175056	BIT	#BIT15, DLCSR	DID "DATA SET INT" SET ??
1005	004332	001003			BNE	1S	<BR IF YES>
1006	004334	004767	007512		JSR	PC, SUER2	GO SET UP ERROR INFO.
1007	004340	104002			ERROR+2		"DATA SET INT" FAILED TO SET -
1008							NOTE: THE REFERENCE TO RCSR ABOVE WILL
1009							WILL UNCONDITIONALLY CLEAR RCSR BIT 15.
1010	004342	012704	030002	1S:	MOV	#30002, R4	RESULT IN RCSR S/B = 30002
1011	004346	020412			CMP	R4, (R2)	"DTR", "CLR TO SEND", AND "CAR DET" ALLSET
1012	004350	001403			BEQ	2S	<BR IF ALL SET>
1013	004352	004767	007474		JSR	PC, SUER2	GO SET UP ERROR INFO
1014	004356	104002			ERROR+2		"DTR", "CLR TO SEND" OR "CAR DET" FAILED
1015							TO SET OR "DATA SET INT" FAILED TO CLEAR
1016	004360	012704	100000	2S:	MOV	#BIT15, R4	RESULT IN RCSR S/B = 100000
1017	004364	042712	000002		BIC	#BIT1, (R2)	NOW CLEAR "DTR"
1018	004370	032777	100000	175012	BIT	#BIT15, DLCSR	DID "DATA SET INT" SET ??
1019	004376	001003			BNE	3S	<BR IF YES>
1020	004400	004767	007446		JSR	PC, SUER2	GO SETUP ERROR INFO
1021	004404	104002			ERROR+2		"DATA SET INT" FAILED TO SET WHEN "DTR"
1022							WENT TO A ZERO.
1023	004406	005004		3S:	CLR	R4	RESULT IN RCSR S/B = 000000
1024	004410	020412			CMP	R4, (R2)	DID ALL BITS CLEAR??
1025	004412	001403			BEQ	TST16	<BR IF YES>


```

1026 004414 004767 007432      JSR    PC,SUER2      ;GO SET UP ERROR INFO
1027 004420 104002      ERROR+2             ;"DTR" "CLR TO SEND" OR "CAR DET" FAILED
1028                                     ;TO CLEAR PROPERLY
1029                                     ;*****
1030                                     ;*TEST 16      TEST THAT "DATA SET INT ENAB" CAN SET AND CLEAR
1031                                     ;*****
1032 004422 000004      TST16: SCOPE
1033 004424 032777 010000 174506  BIT    #SW12,DSWR      ;ARE WE TESTING /C OR /D MODEL?
1034 004432 001023      BNE    TST17         ;<BRANCH IF YES>
1035 004434 016702 174750  MOV    DLRCR,R2      ;REGADR = RCSR ADR
1036 004440 012704 000040  MOV    #40,R4        ;RESULT IN RCSR S/B = 000040
1037 004444 052712 000040  BIS    #BIT5,(R2)    ;SET THE "DATA SET I.E." BIT
1038 004450 020412      CMP    R4,(R2)      ;DID IT SET OK ??
1039 004452 001403      BEQ    IS           ;<BR IF YES>
1040 004454 004767 007372  JSR    PC,SUER2      ;GO SET UP ERROR INFO
1041 004460 104002      ERROR+2             ;"DAT SET I. E." FAILED TO SET
1042 004462 005004      IS:  CLR    R4        ;MAKE S/B DATA = 000000
1043 004464 042712 000040  BIC    #BIT5,(R2)    ;NOW CLEAR THE "DATA SET I.E." BIT
1044 004470 020412      CMP    R4,(R2)      ;DID IT CLEAR OK ??
1045 004472 001403      BEQ    TST17         ;<BR IF YES>
1046 004474 004767 007352  JSR    PC,SUER2      ;GO SET UP ERROR INFO.
1047 004500 104002      ERROR+2             ;"DATA SET I.E." FAILED TO CLEAR
1048                                     ;*****
1049                                     ;*TEST 17      TEST THE "DATA SET I.E." CAN CAUSE A RCVR INTR
1050                                     ;*****
1051 004502 000004      TST17: SCOPE
1052 004504 032777 010000 174426  BIT    #SW12,DSWR      ;ARE WE TESTING A /C OR /D MODEL?
1053 004512 001054      BNE    TST20         ;<BRANCH IF YES>
1054 004514 016705 174700  MOV    DLVECT,R5     ;GET THE VECTOR ADR
1055 004520 012725 004606  MOV    #35,(R5)+     ;GO TO 35 ON RCVR INTR.
1056 004524 016715 174552  MOV    DLPRI,(R5)    ;AT LEVEL 4
1057 004530 005005      CLR    R5           ;INIT INTR. TIMER
1058 004532 005067 174706  CLR    INTFLG        ;INIT SOFTWARE FLAG
1059 004536 005004      CLR    R4           ;RESULT IN RCSR S/B = 0 AFTER INTR.
1060 004540 016702 174644  MOV    DLRCR,R2      ;REGADR = RCSR ADR
1061 004544 052712 000040  BIS    #BIT5,(R2)    ;SET THE "DATA SET I.E." BIT
1062 004550 052712 000002  BIS    #BIT1,(R2)    ;NOW SET "DTR" TO GEN INTR.
1063 004554 005767 174664  IS:  TST    INTFLG     ;DID INTR OCCUR YET ??
1064 004560 001016      BNE    4$           ;BR IF YES
1065 004562 005305      DEC    R5           ;COUNT THE TIMER
1066 004564 001373      BNE    IS           ;BR IF NO TIMEOUT
1067 004566 004767 007260  JSR    PC,SUER2      ;GO SET UP ERROR INFO
1068 004572 005012      CLR    (R2)         ;TURN IT ALL OFF
1069 004574 012767 004604 174442  MOV    #25,$ESCAPE   ;COME BACK TO 25 IN ALL CASES
1070 004602 104002      ERROR+2             ;"DATA SET" INTR FAILED TO OCCUR
1071 2$:
1072 004604 000417      BR     TST20         ;<GO TO NEXT TEST>
1073 004606 005012      3$:  CLR    (R2)       ;ZERO THE RCSR
1074 004610 005167 174630  COM    INTFLG        ;SET THE SOFTWARE FLAG
1075 004614 000002      RTI                    ;RETURN TO SENDER
1076 004616 032712 100000  4$:  BIT    #BIT15,(R2) ;DID "DATA SET INT" GET SET BY INTR. SERVICE ??
1077 004622 001003      BNE    5$           ;<BR IF YES>
1078 004624 004767 007222  JSR    PC,SUER2      ;GO SET UP ERROR INFO
1079 004630 104002      ERROR+2             ;DATA SET INTR. NOT SERVICED PROPERLY
1080 004632 020412      5$:  CMP    R4,(R2)     ;ALL BITS IN RCSR CLEAR ??
1081 004634 001403      BEQ    TST20         ;<BR IF YES>
    
```

```

1082 004636 004767 007210
1083 004642 104002
1084
1085
1086
1087 004644 000004
1088 004646 032777 010000 174264
1089 004654 001024
1090 004656 012704 000201
1091 004662 016702 174526
1092 004666 052712 000001
1093 004672 020412
1094 004674 001403
1095 004676 004767 007150
1096 004702 104002
1097 004704 012704 000200
1098 004710 042712 000001
1099 004714 020412
1100 004716 001403
1101 004720 004767 007126
1102 004724 104002
1103
1104
1105
1106
1107
1108 004726 000004
1109 004730 012704 000200
1110 004734 016702 174454
1111 004740 052712 000001
1112 004744 000005
1113 004746 020412
1114 004750 001403
1115 004752 004767 007074
1116 004756 104002
1117

```

```

JSR PC,SUER2 ;GO SET UP ERROR INFO
ERROR+2 ;INTR. SERVICE FAILED TO CLEAR RCSR
;*****
;TEST 20 TEST THAT THE "BREAK" BIT CAN BE SET AND CLEARED
;*****
TST20: SCOPE
BIT #SW12,JSWR ;ARE WE TESTING /C OR /D MODEL?
BNE TST21 ;<BRANCH IF YES>
MOV #201,R4 ;RESULT S/B = 201 IN XCSR
MOV DLXCSR,R2 ;SET UP REGADR
BIS #BIT0,(R2) ;SET THE "BREAK" BIT
CMP R4,(R2) ;DID IT SET PROPERLY ??
BEQ IS ;<BR IF YES>
JSR PC,SUER2 ;GO SET UP ERROR INFO.
ERROR+2 ;"BREAK" BIT FAILED TO SET PROPERLY
IS: MOV #200,R4 ;RESULT S/B = 200 IN XCSR
BIC #BIT0,(R2) ;CLEAR THE "BREAK" BIT
CMP R4,(R2) ;DID IT CLEAR PROPERLY ??
BEQ TST21 ;<BR IF YES>
JSR PC,SUER2 ;GO SET UP ERROR INFO
ERROR+2 ;"BREAK" FAILED TO CLEAR PROPERLY

```

```

;*****
;TEST 21 TEST THAT A "RESET" CLEARS THE "BREAK" BIT
;*****
TST21: SCOPE
MOV #200,R4 ;RESULT S/B = 200
MOV DLXCSR,R2 ;SET UP REGADR
BIS #BIT0,(R2) ;SET THE "BREAK" BIT
RESET ;CLEAR IT WITH A "RESET"
CMP R4,(R2) ;DID IT CLEAR ??
BEQ TST22 ;<BR IF YES>
JSR PC,SUER2 ;GO SET UP ERROR INFO.
ERROR+2 ;RESET INSTR. FAILED TO CLEAR "BREAK"

```



```

1118
1119
1120
1121 004760 000004
1122 004762 012767 000001 174252
1123 004770 004767 007212
1124 004774 005067 174430
1125 005000 012767 014362 174430 15:
1126 005006 004767 007222
1127 005012 005767 174404 25:
1128 005016 001040
1129 005020 005767 174400
1130 005024 001053
1131 005026 005767 174374
1132 005032 001065
1133 005034 022767 022260 174372
1134 005042 001003
1135 005044 004767 007456
1136 005050 000500
1137 005052 005367 174362 35:
1138 005056 001355
1139 005060 005367 174356
1140 005064 001352
1141 005066 042777 000100 174314
1142 005074 042777 000104 174312
1143 005102 104401 016342
1144 005106 012767 005116 174130
1145 005114 104000
1146 005116
1147 005116 000455 45:
1148 005120 016701 174264 55:
1149 005124 016702 174264
1150 005130 011203
1151 005132 012704 000204
1152 005136 004767 006736
1153 005142 012767 005152 174074
1154 005150 104002
1155 005152
1156 005152 000437 65:
1157 005154 016701 174230 75:
1158 005160 010102
1159 005162 011203
1160 005164 012704 000200
1161 005170 004767 006704
1162 005174 012767 005204 174042
1163 005202 104002
1164 005204
1165 005204 000422 85:
1166 005206 016701 174176 95:
1167 005212 016702 174174
1168 005216 016703 173762
1169 005222 004767 006652
1170 005226 012767 005236 174010
1171 005234 104005
1172 005236 005267 174166 105:
1173 005242 022767 000003 174160

```

```

*****
#TEST 22 TEST TO TURN AROUND NULL-DEL-NULL PATTERN
*****
TST22: SCOPE
MOV #1,STIMES ;DO 1 ITERATION
JSR PC,SUVEC ;GO SET UP VECTORS
CLR RTRY ;INITIALIZE RETRY FLAG
MOV #LDOUT1,LDOUT ;SET POINTER TO LOAD ROUTINE
JSR PC,PRIME ;GO SET UP BUFFERS AND DEVICE
TST XFLGO ;ANY HARD XMIT ERRORS ??
BNE 5$ ;BR IF YES
TST RFLGO ;ANY HARD RECEIVER ERROR ??
BNE 7$ ;BR IF YES
TST RFLG1 ;ANY SOFT RECEIVER ERRORS ??
BNE 9$ ;BR IF YES
CMP #BUFEND,IPTR ;RECEIVED 256. BYTES ??
BNE 3$ ;BR IF NOT
JSR PC,CHKDAT ;GO CHECK THE DATA BUFFERS
BR TST23 ;<GO TO NEXT TEST>
DEC TIMR1 ;DEC TIMEOUT COUNTER 1
BNE 2$ ;BR IF NO TIMEOUT
DEC TIMR2 ;DEC TIMEOUT COUNTER 2
BNE 2$ ;BR IF NO TIMEOUT
BIC #100,DLRCSR ;TURN OFF THE INTRs.
BIC #104,DLXCSR
TYPE XMSG1 ;GO TYPE TIMEOUT MESSAGE
MOV #4$,SESCAPE ;GO TO 4$ AFTER ERROR PRINT
ERROR ;PRINT ERROR PC
4$: BR TST23 ;<GO TO NEXT TEST>
5$: MOV DLRCSR,R1 ;PUT DEVADR IN R1
MOV DLXCSR,R2 ;PUT REGADR IN R2
MOV (R2),R3 ;GET THE WAS DATA
MOV #204,R4 ;PUT S/B DATA IN R4
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #6$,SESCAPE ;GO TO 6$ AFTER PRINTING ERROR
ERROR+2 ;TRANSMITTER FALSE INTERRUPT
6$: BR TST23 ;<GO TO NEXT TEST>
7$: MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV R1,R2 ;SAVE THE REGADR
MOV (R2),R3 ;GET THE WAS DATA
MOV #200,R4 ;RESULT S/B = 200
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #8$,SESCAPE ;GO TO 8$ AFTER ERROR PRINT
ERROR+2 ;RECEIVER FALSE INTERRUPT
8$: BR TST23 ;<GO TO NEXT TEST>
9$: MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV DLRDBR,R2 ;SAVE REGADR
MOV $TMP1,R3 ;GET CONTENTS OF ERROR RDBR
JSR PC,SUERR1 ;GO SETUP ERROR INFO
MOV #10$,SESCAPE ;GO TO 10$ AFTER ERROR PRINT
ERROR+5 ;REPORT SOFT ERROR (PARITY,FRAMING, OR OVERRUN
10$: INC RTRY ;COUNT ONE TRY
CMP #3,RTRY ;TRIED THREE TIMES

```

F04

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 23
DZDLCB.P11 06-MAY-77 10:04 T22 TEST TO TURN AROUND NULL-DEL-NULL PATTERN

1174 005250 001253

BNE 15

;BR IF NOT


```

1175
1176
1177
1178 005252 000004
1179 005254 012767 000001 173760
1180 005262 004767 006720
1181 005266 005067 174136
1182 005272 012767 014404 174136 1$:
1183 005300 004767 006730
1184 005304 005767 174112 2$:
1185 005310 001040
1186 005312 005767 174106
1187 005316 001053
1188 005320 005767 174102
1189 005324 001065
1190 005326 022767 022260 174100
1191 005334 001003
1192 005336 004767 007164
1193 005342 000500
1194 005344 005367 174070 3$:
1195 005350 001355
1196 005352 005367 174064
1197 005356 001352
1198 005360 042777 000100 174022
1199 005366 042777 000104 174020
1200 005374 104401 016421
1201 005400 012767 005410 173636
1202 005406 104000
1203 005410 4$:
1204 005410 000455
1205 005412 016701 173772 5$:
1206 005416 016702 173772
1207 005422 011203
1208 005424 012704 000204
1209 005430 004767 006444
1210 005434 012767 005444 173602
1211 005442 104002
1212 005444 6$:
1213 005444 000437
1214 005446 016701 173736 7$:
1215 005452 010102
1216 005454 011203
1217 005456 012704 000200
1218 005462 004767 006412
1219 005466 012767 005476 173550
1220 005474 104002
1221 005476 8$:
1222 005476 000422
1223 005500 016701 173704 9$:
1224 005504 016702 173702
1225 005510 016703 173470
1226 005514 004767 006360
1227 005520 012767 005530 173516
1228 005526 104005
1229 005530 005267 173674 10$:
1230 005534 022767 000003 173666

```

```

*****
:TEST 23 TEST TO TURN AROUND BINARY UP COUNT PATTERN
*****
TST23: SCOPE
MOV #1,$TIMES ;DO 1 ITERATION
JSR PC,SUVEC ;GO SET UP VECTORS
CLR RTRY ;INITIALIZE RETRY FLAG
MOV #LDOUT2,LDOUT ;SET POINTER TO LOAD ROUTINE
JSR PC,PRIME ;GO SET UP BUFFERS AND DEVICE
TST XFLGO ;ANY HARD XMIT ERRORS ??
BNE 5$ ;BR IF YES
TST RFLGO ;ANY HARD RECEIVER ERROR ??
BNE 7$ ;BR IF YES
TST RFLG1 ;ANY SOFT RECEIVER ERRORS ??
BNE 9$ ;BR IF YES
CMP #BUFEND,IPTR ;RECEIVED 256. BYTES ??
BNE 3$ ;BR IF NOT
JSR PC,CHKDAT ;GO CHECK THE DATA BUFFERS
BR TST24 ;<GO TO NEXT TEST>
DEC TIMR1 ;DEC TIMEOUT COUNTER 1
BNE 2$ ;BR IF NO TIMEOUT
DEC TIMR2 ;DEC TIMEOUT COUNTER 2
BNE 2$ ;BR IF NO TIMEOUT
BIC #100,$DLRCSR ;TURN OFF THE INTRS.
BIC #104,$DLXCSR
TYPE XMSG2 ;GO TYPE TIMEOUT MESSAGE
MOV #4$,$ESCAPE ;GO TO 4$ AFTER ERROR PRINT
ERROR ;PRINT ERROR PC
4$:
BR TST24 ;<GO TO NEXT TEST>
5$:
MOV DLRCSR,R1 ;PUT DEVADR IN R1
MOV DLXCSR,R2 ;PUT REGADR IN R2
MOV (R2),R3 ;GET THE WAS DATA
MOV #204,R4 ;PUT S/B DATA IN R4
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #6$,$ESCAPE ;GO TO 6$ AFTER PRINTING ERROR
ERROR+2 ;TRANSMITTER FALSE INTERRUPT
6$:
BR TST24 ;<GO TO NEXT TEST>
7$:
MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV R1,R2 ;SAVE THE REGADR
MOV (R2),R3 ;GET THE WAS DATA
MOV #200,R4 ;RESULT S/B = 200
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #8$,$ESCAPE ;GO TO 8$ AFTER ERROR PRINT
ERROR+2 ;RECEIVER FALSE INTERRUPT
8$:
BR TST24 ;<GO TO NEXT TEST>
9$:
MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV DLRDBR,R2 ;SAVE REGADR
MOV $TMP1,R3 ;GET CONTENTS OF ERROR RDBR
JSR PC,SUERR1 ;GO SETUP ERROR INFO
MOV #10$,$ESCAPE ;GO TO 10$ AFTER ERROR PRINT
ERROR+5 ;REPORT SOFT ERROR (PARITY,FRAMING, OR OVERRUN
10$:
INC RTRY ;COUNT ONE TRY
CMP #3,RTRY ;TRIED THREE TIMES

```

H04

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 25
DZDLCB.P11 06-MAY-77 10:04 T23 TEST TO TURN AROUND BINARY UP COUNT PATTERN

1231 005542 001253

BNE 1S

;BR IF NOT


```

1232
1233
1234
1235 005544 000004
1236 005546 012767 000001 173466
1237 005554 004767 006426
1238 005560 005067 173644
1239 005564 012767 014424 173644 1$:
1240 005572 004767 006436
1241 005576 005767 173620 2$:
1242 005602 001040
1243 005604 005767 173614
1244 005610 001053
1245 005612 005767 173610
1246 005616 001065
1247 005620 022767 022260 173606
1248 005626 001003
1249 005630 004767 006672
1250 005634 000500
1251 005636 005367 173576 3$:
1252 005642 001355
1253 005644 005367 173572
1254 005650 001352
1255 005652 042777 000100 173530
1256 005660 042777 000104 173526
1257 005666 104401 016502
1258 005672 012767 005702 173344
1259 005700 104000
1260 005702 4$:
1261 005702 000455
1262 005704 016701 173500 5$:
1263 005710 016702 173500
1264 005714 011203
1265 005716 012704 000204
1266 005722 004767 006152
1267 005726 012767 005736 173310
1268 005734 104002
1269 005736 6$:
1270 005736 000437
1271 005740 016701 173444 7$:
1272 005744 010102
1273 005746 011203
1274 005750 012704 000200
1275 005754 004767 006120
1276 005760 012767 005770 173256
1277 005766 104002
1278 005770 8$:
1279 005770 000422
1280 005772 016701 173412 9$:
1281 005776 016702 173410
1282 006002 016703 173176
1283 006006 004767 006066
1284 006012 012767 006022 173224
1285 006020 104005
1286 006022 005267 173402 10$:
1287 006026 022767 000003 173374

```

```

*****
*TEST 24 TEST TO TURN AROUND BINARY DOWN COUNT PATTERN
*****
TST24: SCOPE
MOV #1,STIMES ;; DO 1 ITERATION
JSR PC,SUVEC ;; GO SET UP VECTORS
CLR RTRY ;; INITIALIZE RETRY FLAG
MOV #LDOUT3,LDOUT ;; SET POINTER TO LOAD ROUTINE
JSR PC,PRIME ;; GO SET UP BUFFERS AND DEVICE
TST XFLGO ;; ANY HARD XMIT ERRORS ??
BNE 5$ ;; BR IF YES
TST RFLGO ;; ANY HARD RECEIVER ERROR ??
BNE 7$ ;; BR IF YES
TST RFLG1 ;; ANY SOFT RECEIVER ERRORS ??
BNE 9$ ;; BR IF YES
CMP #BUFEND,IPTR ;; RECEIVED 256. BYTES ??
BNE 3$ ;; BR IF NOT
JSR PC,CHKDAT ;; GO CHECK THE DATA BUFFERS
BR TST25 ;; <GO TO NEXT TEST>
DEC TIMR1 ;; DEC TIMEOUT COUNTER 1
BNE 2$ ;; BR IF NO TIMEOUT
DEC TIMR2 ;; DEC TIMEOUT COUNTER 2
BNE 2$ ;; BR IF NO TIMEOUT
BIC #100,DLRCSR ;; TURN OFF THE INTRs.
BIC #104,DLXCSR
TYPE XMSG3 ;; GO TYPE TIMEOUT MESSAGE
MOV #4$,SESCAPE ;; GO TO 4$ AFTER ERROR PRINT
ERROR ;; PRINT ERROR PC
4$:
BR TST25 ;; <GO TO NEXT TEST>
5$:
MOV DLRCSR,R1 ;; PUT DEVADR IN R1
MOV DLXCSR,R2 ;; PUT REGADR IN R2
MOV (R2),R3 ;; GET THE WAS DATA
MOV #204,R4 ;; PUT S/B DATA IN R4
JSR PC,SUERR1 ;; GO SET UP ERROR INFO
MOV #6$,SESCAPE ;; GO TO 6$ AFTER PRINTING ERROR
ERROR+2 ;; TRANSMITTER FALSE INTERRUPT
6$:
BR TST25 ;; <GO TO NEXT TEST>
7$:
MOV DLRCSR,R1 ;; SAVE THE DEVADR
MOV R1,R2 ;; SAVE THE REGADR
MOV (R2),R3 ;; GET THE WAS DATA
MOV #200,R4 ;; RESULT S/B = 200
JSR PC,SUERR1 ;; GO SET UP ERROR INFO
MOV #8$,SESCAPE ;; GO TO 8$ AFTER ERROR PRINT
ERROR+2 ;; RECEIVER FALSE INTERRUPT
8$:
BR TST25 ;; <GO TO NEXT TEST>
9$:
MOV DLRCSR,R1 ;; SAVE THE DEVADR
MOV DLRDBR,R2 ;; SAVE REGADR
MOV $TMP1,R3 ;; GET CONTENTS OF ERROR RDBR
JSR PC,SUERR1 ;; GO SETUP ERROR INFO
MOV #10$,SESCAPE ;; GO TO 10$ AFTER ERROR PRINT
ERROR+5 ;; REPORT SOFT ERROR (PARITY,FRAMING, OR OVERRUN)
10$:
INC RTRY ;; COUNT ONE TRY
CMP #3,RTRY ;; TRIED THREE TIMES

```

J04

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 27
DZDLCB.P11 06-MAY-77 10:09 T29 TEST TO TURN AROUND BINARY DOWN COUNT PATTERN

1288 006034 001253

BNE 15 ;BR IF NOT


```

1289
1290
1291
1292 006036 000004
1293 006040 012767 000001 173174
1294 006046 004767 006134
1295 006052 005067 173352
1296 006056 012767 014460 173352 1S:
1297 006064 004767 006144
1298 006070 005767 173326 2S:
1299 006074 001042
1300 006076 005767 173322
1301 006102 001056
1302 006104 005767 173316
1303 006110 001071
1304 006112 022767 022260 173314
1305 006120 001004
1306 006122 004767 006400
1307 006126 000167 002012
1308 006132 005367 173302 3S:
1309 006136 001354
1310 006140 005367 173276
1311 006144 001351
1312 006146 042777 000100 173234
1313 006154 042777 000104 173232
1314 006162 104401 016565
1315 006166 012767 006176 173050
1316 006174 104000
1317 006176 000167 001742 4S:
1318 006202 016701 173202 5S:
1319 006206 016702 173202
1320 006212 011203
1321 006214 012704 000204
1322 006220 004767 005654
1323 006224 012767 006234 173012
1324 006232 104002
1325 006234 000167 001704 6S:
1326 006240 016701 173144 7S:
1327 006244 010102
1328 006246 011203
1329 006250 012704 000200
1330 006254 004767 005620
1331 006260 012767 006270 172756
1332 006266 104002
1333 006270 000167 001650 8S:
1334 006274 016701 173110 9S:
1335 006300 016702 173106
1336 006304 016703 172674
1337 006310 004767 005564
1338 006314 012767 006324 172722
1339 006322 104005
1340 006324 005267 173100 10S:
1341 006330 022767 000003 173072
1342 006336 001247
1343 006340 000167 001600
1344

```

```

*****
*TEST 25 TEST TO TURN AROUND WORST CASE PATTERN
*****
T25: SCOPE
MOV #1,STIMES ;DO 1 ITERATION
JSR PC,SUVEC ;GO SET UP VECTORS
CLR RTRY ;INITIALIZE RETRY FLAG
MOV #LDOUT4,LDOUT ;SET POINTER TO LOAD ROUTINE
JSR PC,PRIME ;GO SET UP BUFFERS AND DEVICE
TST XFLGO ;ANY HARD XMIT ERRORS ??
BNE 5S ;BR IF YES
TST RFLGO ;ANY HARD RECEIVER ERROR ??
BNE 7S ;BR IF YES
TST RFLG1 ;ANY SOFT RECEIVER ERRORS ??
BNE 9S ;BR IF YES
CMP #BUFEND,IPTR ;RECEIVED 256. BYTES ??
BNE 3S ;BR IF NOT
JSR PC,CHKDAT ;GO CHECK THE DATA BUFFERS
JMP SEOP ;GO TO NEXT TEST
DEC TIMR1 ;DEC TIMEOUT COUNTER 1
BNE 2S ;BR IF NO TIMEOUT
DEC TIMR2 ;DEC TIMEOUT COUNTER 2
BNE 2S ;BR IF NO TIMEOUT
BIC #100,DLRCSR ;TURN OFF THE INTRs.
BIC #104,DLXCSR
TYPE XMSG4 ;GO TYPE TIMEOUT MESSAGE
MOV #4S,SESCAPE ;GO TO 4S AFTER ERROR PRINT
ERROR ;PRINT ERROR PC
JMP SEOP ;GO TO NEXT TEST
MOV DLRCSR,R1 ;PUT DEVADR IN R1
MOV DLXCSR,R2 ;PUT REGADR IN R2
MOV (R2),R3 ;GET THE WAS DATA
MOV #204,R4 ;PUT S/B DATA IN R4
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #6S,SESCAPE ;GO TO 6S AFTER PRINTING ERROR
ERROR+2 ;TRANSMITTER FALSE INTERRUPT
JMP SEOP ;GO TO NEXT TEST
MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV R1,R2 ;SAVE THE REGADR
MOV (R2),R3 ;GET THE WAS DATA
MOV #200,R4 ;RESULT S/B = 200
JSR PC,SUERR1 ;GO SET UP ERROR INFO
MOV #8S,SESCAPE ;GO TO 8S AFTER ERROR PRINT
ERROR+2 ;RECEIVER FALSE INTERRUPT
JMP SEOP ;GO TO NEXT TEST
MOV DLRCSR,R1 ;SAVE THE DEVADR
MOV DLRDBR,R2 ;SAVE REGADR
MOV $TMP1,R3 ;GET CONTENTS OF ERROR RDBR
JSR PC,SUERR1 ;GO SETUP ERROR INFO
MOV #10S,SESCAPE ;GO TO 10S AFTER ERROR PRINT
ERROR+5 ;REPORT SOFT ERROR (PARITY,FRAMING, OR OVERRUN)
INC RTRY ;COUNT ONE TRY
CMP #3,RTRY ;TRIED THREE TIMES
BNE 1S ;BR IF NOT
JMP SEOP ;GO TO END OF PASS ROUTINE

```


1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400

```

; THIS IS PROGRAM #2
; THE FOLLOWING USER UTILITY PROGRAM WILL ALLOW:
; A) SELECTION OF A TRANSMITTER DATA BUFFER
; B) SELECTION OF A CHARACTER FOR CONTINUOUS TRANSFER
; C) SELECTION OF AN EXPIRATION TIME IN MILLISECONDS
;    BETWEEN EACH TRANSMITTER DATA BUFFER CHARACTER TRANSFER
; D) A TIGHT SCOPE LOOP LOCK ON A SPECIFIC CHARACTER

PRG2:  MOV    #STACK, SP          ; INITIALIZE THE STACK POINTER
        MOV    #STRAP, #TRAPVEC  ; TRAP VECTOR FOR TRAP CALLS
        MOV    #340, #TRAPVEC+2  ; LEVEL 7
        MOV    #ERROR, #EMTVEC   ; EMT VECTOR FOR ERROR ROUTINE
        MOV    #340, #EMTVEC+2   ; LEVEL 7
        TYPE   ,PRG2M            ; INDICATE THAT USER SELECTED
                                    ; PROGRAM #2
PRG2A: TYPE   ,LINTAD           ; ASK USER FOR THE TRANSMITTER
                                    ; DATA BUFFER ADDRESS OF THE DEVICE
                                    ; HE WISHES TO TEST
                                    ; ACCEPT THE ANSWER TYPED BY USER
                                    ; AND STORE ON TOP OF STACK
; CHECK TO SEE IF THE USER RESPONSE WAS WITHIN LIMITS
        MOV    (SP)+, R2         ; GET THE ANSWER TYPED
        CMP    R2, #176176      ; IS THE NUMBER TOO HIGH?
        BHI   RED01             ; IF YES - GO TO RETRY SITUATION
        CMP    R2, #175616      ; IS THE NUMBER TOO LOW?
        BLO   RED01             ; IF YES - GO TO RETRY SITUATION
        BITB   #BIT0, R2        ; NUMBER IS IN RANGE BUT IS IT
                                    ; ON AN EVEN BOUNDARY?
        BNE   RED01             ; IF NOT GO TO RETRY SITUATION
; CHECK TO SEE IF USER RESPONSE WAS TRULY A XMIT BUFFER REGISTER
        MOV    R2, R3           ; GET THE USER RESPONSE
        BICB   #370, R3         ; MASK OFF LOWER BYTE EXCEPT FOR
                                    ; LEAST SIGNIFICANT DIGIT
        CMPB   #6, R3           ; WAS THE LEAST SIGNIFICANT DIGIT OF THE
                                    ; USER RESPONSE EQUAL TO A SIX?
        BNE   RED01             ; BRANCH IF NOT
        MOV    R2, $TMPD        ; THE TRANSMITTER ADDRESS
                                    ; TYPED IS OK - STORE FOR
                                    ; FUTURE USE
; NOW CHECK TO MAKE SURE THE DEVICE IS PRESENT
        MOV    ERRVEC, -(SP)    ; SAVE THE TIMEOUT VECTOR
        MOV    #2$, ERRVEC      ; SET UP TIMEOUT SERVICE ADDRESS
        TST    (R2)             ; IF PRESENT WE WILL EXECUTE THE
                                    ; NEXT INSTRUCTION - IF NOT
                                    ; WE GO TO 2$:
        BR    4$                ; BRANCH IF PRESENT
2$:    JSR    PC, SUERT2         ; GO SET UP FOR ERROR INFORMATION
        MOV    #3$, $ESCAPE     ; POINT OF RETURN AFTER ERROR REPORT
        ERROR +6                ; XDR REFERENCE CAUSED TIMEOUT
3$:    CMP    (SP)+, (SP)+      ; CLEAN STACK FROM TIMEOUT
        MOV    (SP)+, ERRVEC    ; RESTORE TIMEOUT VECTOR
        BR    RED01             ; GO TO RETRY SITUATION
4$:    MOV    (SP)+, ERRVEC     ; DEVICE REGISTER IS PRESENT!
                                    ; RESTORE TIMEOUT VECTOR
; WE ARE NOW READY FOR THE CHARACTER TO BE TRANSMITTED, AND THE
    
```



```

1401 :DELAY TIME (IN MILLISECONDS) THAT IS TO TRANSPIRE BETWEEN
1402 :SUCCESSIVE CHARACTER TRANSFERS
1403 006524 104401 020403 PRG2B: TYPE ,SELCAR ;ASK USER FOR THE CHARACTER HE
1404 ;WISHES TO TRANSFER
1405 006530 104410 RDOCT ;ACCEPT THE ANSWER TYPED BY
1406 ;USER AND STORE ON TOP OF STACK
1407 006532 012667 172446 MOV (SP)+,STMP1 ;GET THE ANSWER TYPED
1408 ;NOTE: THE USER RESPONSE FOR THE CHARACTER WAS TO BE THE
1409 ; OCTAL ASCII EQUIVALENT OF THE CHARACTER E.G. A=101
1410 006536 104401 020511 TYPE ,SELDLY ;ASK THE USER FOR THE DELAY
1411 ; IN MSEC (OCTAL NO.) BETWEEN
1412 ; CHARACTER TRANSFERS
1413 006542 104410 RDOCT ;ACCEPT THE ANSWER TYPED BY
1414 ;USER AND STORE ON TOP OF STACK
1415 006544 012667 172436 MOV (SP)+,STMP2 ;GET THE ANSWER TYPED
1416 006550 116767 172432 000012 15: MOVB STMP2,25 ;SET THE DELAY COUNT ARGUMENT
1417 ; FOR TIMER ROUTINE
1418 006556 116777 172422 172416 MOVB STMP1,2STMP0 ;LOAD THE TRANSMITTER DATA
1419 ; BUFFER WITH THE CHARACTER
1420 006564 004767 004750 JSR PC,DELAY ;GO OFF TO WAIT THE SPECIFIED

```



```

1477 006750 022626
1478 006752 012667 171026
1479 006756 000432
1480 006760 012667 171020
1481
1482
1483
1484
1485 006764 104401 020403
1486
1487 006770 104410
1488
1489 006772 012667 172206
1490
1491
1492 006776 104401 020511
1493
1494
1495 007002 104410
1496
1497 007004 012667 172176
1498 007010 162702 000002
1499
1500
1501 007014 052712 000004
1502 007020 116767 172162 000012
1503
1504 007026 116777 172152 172146
1505
1506 007034 004767 004500
1507
1508
1509 007040 000000
1510 007042 000764
1511 007044 104401 001252
1512 007050 000167 177570
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522 007054 012706 001100
1523 007060 012737 013066 000034
1524 007066 012737 000340 000036
1525 007074 012737 010746 000030
1526 007102 012737 000340 000032
1527 007110 104401 017010
1528
1529 007114 104401 020322
1530
1531
1532 007120 104410
    
```

```

3S:  CMP      (SP)+,(SP)+      ;CLEAN STACK FROM TIMEOUT
      MOV      (SP)+,ERRVEC    ;RESTORE TIMEOUT VECTOR
      BR       RED02           ;GO TO RETRY SITUATION
4S:  MOV      (SP)+,ERRVEC    ;DEVICE REGISTER IS PRESENT!
      MOV      (SP)+,ERRVEC    ;RESTORE TIMEOUT VECTOR
;WE ARE NOW READY FOR THE CHARACTER TO BE TRANSMITTED, AND THE
;DELAY TIME (IN MILLISECONDS) THAT IS TO TRANSPIRE BETWEEN SUCCESSIVE
;CHARACTER TRANSFERS
PRG3B: TYPE      ,SELCAR      ;ASK USER FOR THE CHARACTER
;HE WISHES TO TRANSFER
      RDOCT                    ;ACCEPT THE ANSWER TYPED BY USER
;AND STORE ON TOP OF STACK
      MOV      (SP)+,STMP1     ;GET THE ANSWER TYPED
;NOTE: THE USER RESPONSE FOR THE CHARACTER WAS TO BE THE
;OCTAL ASCII EQUIVALENT OF THE CHARACTER E.G. B=102
      TYPE      ,SELDLY       ;ASK THE USER FOR THE DELAY
;IN MSEC (OCTAL NO.) BETWEEN
;CHARACTER TRANSFERS
      RDOCT                    ;ACCEPT THE ANSWER TYPED BY
;USER AND STORE ON TOP OF STACK
      MOV      (SP)+,STMP2     ;GET THE ANSWER TYPED
      SUB      #2,R2           ;GET THE CORRESPONDING XCSR
;ADDRESS FOR TRANSMITTER UNDER-
;GOING TEST
1S:  BIS      #BIT2,(R2)       ;SET MAINTENANCE BIT IN XCSR
      MOVB     STMP2,2S        ;SET THE DELAY COUNT ARGUMENT
;FOR TIMER ROUTINE
      MOVB     STMP1,2STMP0    ;LOAD THE TRANSMITTER DATA BUFFER
;WITH THE CHARACTER
      JSR      PC,DELAY        ;GO OFF TO WAIT THE SPECIFIED
;NO. OF MSEC. BEFORE ISSUING
;ANOTHER CHARACTER
2S:  .WORD   0                ;THIS IS WHERE THE DELAY COUNT RESIDES
      BR       1S             ;GO BACK TO ISSUE ANOTHER CHARACTER
RED02: TYPE      ,SQUES       ;TYPE A QUESTION MARK(?)
      JMP      PRG3A          ;REITERATE THE XDBR QUESTION TO
;USER
;THIS IS PROGRAM #4
;THE FOLLOWING USER UTILITY PROGRAM WILL ALLOW:
;A) SELECTION OF A TRANSMITTER DATA BUFFER
;B) SELECTION OF A SINGLE CHARACTER TO BE SENT, RECEIVED
;AND CHECKED WITH MAINTENANCE BIT SET
;
PRG4:  MOV      #STACK,SP      ;INITIALIZE THE STACK POINTER
      MOV      #STRAP,2#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
      MOV      #340,2#TRAPVEC+2 ;LEVEL 7
      MOV      #ERROR,2#EMTVEC  ;EMT VECTOR FOR ERROR ROUTINE
      MOV      #340,2#EMTVEC+2 ;LEVEL 7
      TYPE      ,PRG4M         ;INDICATE THAT USER SELECTED
;PROGRAM #4
PRG4A: TYPE      ,LINTAD      ;ASK USER FOR THE TRANSMITTER
;DATA BUFFER ADDRESS OF THE
;DEVICE HE WISHES TO TEST
      RDOCT                    ;ACCEPT THE ANSWER TYPED BY
    
```



```

1589 007274 101060          BHI  RED03A      ; IF YES - GO TO RETRY SITUATION
1590 007276 020027 000005  CMP  RD, #5.     ; IS THE NUMBER TOO LOW?
1591 007302 103455          BLO  RED03A      ; IF YES - GO TO RETRY SITUATION
1592 007304 010067 171724  MOV  RD, STMP15  ; THE VALUE TYPED IS OK
1593                                     ; STORE FOR FUTURE USE
1594 007310 016767 171666 171672  MOV  STMP0, STMP3 ; GET THE XDBR ADDRESS
1595 007316 162767 000002 171664  SUB  #2, STMP3   ; FORM THE XCSR ADDRESS
1596 007324 005767 171656 15:  TST  STMP2      ; DO WE RANDOM STALL?
1597 007330 001402          BEQ  #25         ; BRANCH IF IT WASN'T DESIRED
1598 007332 004767 004246  JSR  PC, STALL  ; GO STALL RANDOM VALUE OF MSEC.
1599 007336 004767 004352 25:  JSR  PC, TIMETX ; GO WAIT FOR TRANSMITTER DONE
1600                                     ; BIT TO SET
1601 007342 104401 017120          TYPE , XDB      ; TYPE TRANSMITTER DONE BIT MESSAGE
1602 007346 104000          ERROR +0        ; XCSR DONE BIT NEVER SET
1603 007350 052777 000004 171632  BIS  #BIT2, STMP3 ; SET THE MAINTENANCE BIT IN THE
1604                                     ; TRANSMITTER CONTROL STATUS REGISTER
1605 007356 016777 171622 171616  MOV  STMP1, STMP0 ; LOAD TRANSMITTER DATA BUFFER
1606                                     ; WITH SELECTED CHARACTER
1607 007364 004767 004306  JSR  PC, TIMERX  ; GO WAIT FOR RECEIVER DONE BIT
1608                                     ; TO SET
1609 007370 104401 017167          TYPE , RDB      ; TYPE RECEIVER DONE BIT MESSAGE
1610 007374 104000          ERROR +0        ; RCSR DONE BIT NEVER SET
1611 007376 016767 171606 171606  MOV  STMP3, STMP4 ; GET THE TRANSMITTER CONTROL
1612                                     ; STATUS REGISTER ADDRESS
1613 007404 162767 000002 171600  SUB  #2, STMP4   ; FORM THE RECEIVER DATA BUFFER
1614                                     ; ADDRESS
1615 007412 017767 171574 171574  MOV  STMP4, STMP5 ; STORE THE CHARACTER FROM THE
1616                                     ; RECEIVER BUFFER + REST OF CONTENTS
1617 007420 004767 004326  JSR  PC, DATCHK  ; GO TO COMPARE EXPECTED & RECEIVED
1618                                     ; DATA
1619 007424 000737          BR  15          ; GO BACK TO ISSUE ANOTHER CHARACTER
1620 007426 104401 001252  RED03: TYPE , $QUES ; TYPE A QUESTION MARK(?)
1621 007432 000167 177456  JMP  PRG4A      ; REITERATE THE XDBR QUESTION TO USER
1622 007436 104401 001252  RED03A: TYPE, $QUES ; TYPE '?' INDICATING USER TYPED
1623                                     ; SOMETHING WRONG FOR CHARACTER LENGTH
1624 007442 000167 177612  JMP  PRG4C      ; GO BACK TO REISSUE QUESTION
1625
1626 ; THIS IS PROGRAM #5
1627 ; THE FOLLOWING USER UTILITY PROGRAM WILL ALLOW USER PARAMETERS
1628 ; FOR RUNNING A BINARY COUNT IN MAINTENANCE MODE
1629 ;
1630
1631 007446 012706 001100  PRGS: MOV  #STACK, SP ; INITIALIZE THE STACK POINTER
1632 007452 012737 013066 000034  MOV  #STRAP, STMP3 ; TRAP VECTOR FOR TRAP CALLS
1633 007460 012737 000340 000036  MOV  #340, STMP3+2 ; LEVEL 7
1634 007466 012737 010746 000030  MOV  #SERROR, STMP3 ; EMT VECTOR FOR ERROR ROUTINE
1635 007474 012737 000340 000032  MOV  #340, STMP3+2 ; LEVEL 7
1636 007502 104401 017054          TYPE , PRG5M    ; INDICATE THAT USER SELECTED
1637                                     ; PROGRAM #5
1638 007506 104401 020322  PRG5A: TYPE , LINTAD ; ASK USER FOR THE TRANSMITTER DATA
1639                                     ; BUFFER ADDRESS OF THE DEVICE
1640                                     ; HE WISHES TO TEST
1641 007512 104410          RDOCT ; ACCEPT THE ANSWER TYPED BY USER
1642                                     ; AND STORE ON TOP OF STACK
1643 ; CHECK TO SEE IF THE USER RESPONSE WAS WITHIN LIMITS
1644 007514 012602          MOV  (SP)+, R2 ; GET THE ANSWER TYPED

```

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 35
 DZDLCB.P11 06-MAY-77 10:04 T25 TEST TO TURN AROUND WORST CASE PATTERN

1645	007516	020227	176176			CMP	R2,#176176	: IS THE NUMBER TOO HIGH?
1646	007522	101152				BHI	RED04	: IF YES - GO TO RETRY SITUATION
1647	007524	020227	175616			CMP	R2,#175616	: IS THE NUMBER TOO LOW?
1648	007530	103547				BLO	RED04	: IF YES - GO TO RETRY SITUATION
1649	007532	132702	000001			BITB	#BIT0,R2	: NUMBER IS IN RANGE BUT IS IT
1650								: ON AN EVEN BOUNDARY?
1651	007536	001144				BNE	RED04	: IF NOT - GO TO RETRY SITUATION
1652								: ;CHECK TO SEE IF USER RESPONSE WAS TRULY A XMIT BUFFER REGISTER
1653	007540	010203				MOV	R2,R3	: GET THE USER RESPONSE
1654	007542	142703	000370			BICB	#370,R3 ;	: MASK OFF LOWER BYTE EXCEPT FOR
1655								: LEAST SIGNIFICANT DIGIT
1656	007546	122703	000006			CMPB	#6,R3	: WAS THE LEAST SIGNIFICANT DIGIT OF THE
1657								: USER RESPONSE EQUAL TO A SIX?
1658	007552	001136				BNE	RED04	: BRANCH IF NOT
1659	007554	010267	171422			MOV	R2,\$TMP0	: THE TRANSMITTER ADDRESS TYPED
1660								: IS OK - STORE FOR FUTURE USE
1661								: ;NOW CHECK TO MAKE SURE THE DEVICE IS PRESENT
1662	007560	016746	170220			MOV	ERRVEC,-(SP)	: SAVE THE TIMEOUT VECTOR
1663	007564	012767	007576	170212		MOV	#2\$,ERRVEC	: SET UP TIMEOUT SERVICE ADDRESS
1664	007572	005712				TST	(R2)	: IF PRESENT WE WILL EXECUTE THE
1665								: NEXT INSTRUCTION - IF NOT WE
1666								: GO TO 2\$:
1667	007574	000412				BR	4\$: BRANCH IF PRESENT
1668	007576	004767	004356			JSR	PC,SUERT2	: GO SETUP FOR ERROR INFORMATION
1669	007602	012767	007612	171434	2\$:	MOV	#3\$,SESCAPE	: POINT OF RETURN AFTER ERROR REPORT
1670	007610	104006				ERROR	+6	: XDBR REFERENCE CAUSED TIMEOUT
1671	007612	022626			3\$:	CMP	(SP)+,(SP)+	: CLEAN STACK FROM TIMEOUT
1672	007614	012667	170164			MOV	(SP)+,ERRVEC	: RESTORE TIMEOUT VECTOR
1673	007620	000513				BR	RED04	: GO TO RETRY SITUATION
1674	007622	012667	170156		4\$:	MOV	(SP)+,ERRVEC	: DEVICE REGISTER IS PRESENT!
1675								: ASK THE USER IF HE DESIRES SOME
1676								: RANDOM NO. OF MSEC. WAIT TIME
1677								: BEFORE CHECKING XCSR DONE FLAG
1678	007626	104401	017233			PRG5C:	TYPE, LENGTH ;	: ASK USER FOR THE CHARACTER LENGTH
1679								: FOR WHICH HIS DEVICE IS SET
1680	007632	104411				RDOEC		: ACCEPT THE ANSWER TYPED BY USER
1681								: ;CHECK TO SEE IF USER RESPONSE WAS WITHIN LIMITS
1682	007634	012600				MOV	(SP)+,RO	: GET THE ANSWER TYPED
1683	007636	020027	000010			CMP	RO,#8.	: IS THE NUMBER TOO HIGH?
1684	007642	101106				BHI	RED04A	: IF YES - GO TO RETRY SITUATION
1685	007644	020027	000005			CMP	RO,#5.	: IS THE NUMBER TOO LOW?
1686	007650	103503				BLO	RED04A	: IF YES - GO TO RETRY SITUATION
1687	007652	010067	171356			MOV	RO,\$TMP15	: THE VALUE TYPED IS OK
1688								: STORE FOR FUTURE USE
1689	007656	104401	020604			TYPE	,RSTALL	: RANDOM NO. OF MSEC. WAIT TIME
1690	007662	104410				RDOCT		: ACCEPT THE ANSWER TYPED BY USER
1691								: AND STORE ON TOP OF STACK
1692	007664	012667	171316			MOV	(SP)+,\$TMP2	: GET THE ANSWER TYPED
1693								: ;WE ARE NOW READY TO INITIALIZE THE BINARY COUNT AND GET
1694								: THE BINARY CHARACTER
1695								: ;
1696	007670	012767	177777	171326		MOV	#-1,\$TMP11	: SET LEAD IN VARIABLE TO -1
1697	007676	016767	171322	171322	PRG5B:	MOV	\$TMP11,\$TMP12	: STORE PREVIOUS BINARY CHARACTER
1698	007704	005267	171316			INC	\$TMP12	: FLIP BINARY CHARACTER AGAIN
1699	007710	042767	177400	171310		BIC	#177400,\$TMP12	: MASK TO 8 BITS
1700	007716	016767	171304	171300		MOV	\$TMP12,\$TMP11	: STORE BINARY CHARACTER

1757 010142 000207
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767 010144
1768
1769
1770
1771
1772 010144 000004
1773 010146 105767 171120
1774 010152 001501
1775
1776 010154 005767 171114
1777 010160 001011
1778 010162 104401 020110
1779
1780
1781
1782 010166 000000
1783 010170 005067 171076
1784 010174 005067 171056
1785 010200 000167 171566
1786
1787
1788 010204 062767 000010 171052 15:
1789
1790
1791 010212 062767 000010 171050
1792
1793
1794 010220 000241
1795 010222 006167 171050
1796
1797 010226 103431
1798
1799
1800 010230 036767 171042 171036
1801
1802 010236 001767
1803
1804 010240 016767 171020 171012
1805
1806 010246 016767 171016 171144
1807 010254 000240
1808 010256 004767 177606
1809
1810 010252 005067 170614
1811
1812 010266 005077 171122

RTS PC ;RETURN

.SBTTL END OF PASS ROUTINE

: INCREMENT THE PASS NUMBER (SPASS)
: TYPE "END PASS #XXXX" (WHERE XXXX IS A DECIMAL NUMBER)
: IF THERES A MONITOR GO TO IT
: IF THERE ISN'T JUMP TO RESTR

.SEOP:
: THIS NEXT SECTION UP TO THE NEXT LINE OF ASTERISKS WAS
: SUPPLIED BY THE MACRO 'EOPBEG'. THE MACRO NAME APPEARS IN
: THE SOURCE PROGRAM AS ONE OF THE ARGUMENTS TO THE .SEOP
: SYSMAC UTILITY ROUTINE CALL.

SCOPE
TSTB MULTD
BEQ 3S

TST ACTREG
BNF 15
TYPE ,FOULUP

: ARE WE RUNNING MULTIPLE DEVICES?
: BRANCH IF NOT FOR NORMAL
: 'END PASS # XX' TYPEOUT
: ARE ANY DEVICES ACTIVE?
: BRANCH IF YES
: INDICATE SOMETHING WRONG!
: MULTIPLE DEVICES ARE BEING
: RUN SUPPOSEDLY, BUT NONE ARE
: SHOWN ACTIVE
: WAIT FOR A USER RESPONSE
: CLEAR MULTIPLE DEVICE FLAG
: CLEAR TABLE CREATION FLAG
: GET READY TO START ALL OVER
: AGAIN - ALL DEVICES WERE
: DESELECTED SOMEHOW!
: FORM A NEW BASE
: ADDRESS FOR START OF NEXT BLOCK
: OF REGISTERS FOR NEXT DEVICE
: FORM A NEW BASE ADDRESS FOR
: START OF NEXT BLOCK OF VECTORS
: FOR NEXT DEVICE
: CLEAR LAST DEVICE INDICATOR
: UPDATE NEXT POSSIBLE DEVICE ACTIVE
: POINTER
: BRANCH IF THIS WAS THE
: LAST DEVICE TO BE TESTED ON
: THIS PASS
: IS THIS DEVICE TRULY ACTIVE
: (AS PER USER)
: BRANCH IF NOT TO SEE IF NEXT
: ONE POSSIBLE IS
: FORM THE RECEIVER STATUS REGISTER
: ADDRESS OF NEXT DEVICE
: GET NEXT DEVICE RCVR VECTOR

: GO FORM DL ADDRESSES FOR NEXT
: DEVICE SELECTED
: INITIALIZE TEST NO. FOR A PROGRAM
: PASS OVER THE NEXT DEVICE ACTIVE
: CLEAR OUT BOTH CSR'S

HALT
CLR MULTD
CLR TABFLG
JMP RESTR

ADD #10,BASEADD

ADD #10,BASEIV

CLC
ROL ROTADD

BCS 2S

BIT ROTADD,ACTREG

BEQ 1S

MOV BASEADD,DLBASE

MOV BASEIV,DLVECT

NOP
JSR PC,DLADDR

CLR \$STNM

CLR \$DLXCSR


```

1813 010272 005077 171112
1814 010276 005777 171110
1815 010302 005777 171104
1816 010306 000167 172456
1817 010312
1818
1819
1820
1821 010312 012767 000001 170756
1822
1823 010320 016767 170736 170736
1824 010326 016767 170734 170734
1825 010334 016767 170724 170716
1826 010342 016767 170722 171050
1827 010350 000240
1828 010352 004767 177512
1829 010356
1830
1831 010356 005067 170520
1832 010362 005067 170654
1833 010366 005267 170506
1834 010372 042767 100000 170500
1835 010400 005327
1836 010402 000001
1837 010404 003022
1838 010406 012737
1839 010410 000001
1840 010412 010402
1841 010414 104401 010461
1842 010420 016746 170454
1843 010424 104405
1844 010426 104401 010456
1845 010432 013700 000042
1846 010436 001405
1847 010440 000005
1848 010442 004710
1849 010444 000240
1850 010446 000240
1851 010450 000240
1852 010452
1853 010452 000137
1854 010454 001772
1855 010456 377 377 000
1856 010461 015 042412 042116
1857 010466 050040 051501 020123
1858 010474 000043
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868

```

```

CLR 3DLRCSR
TST 3DLRDBR ;FLUSH RCVR "DONE" BIT
TST 3DLRDBR
JMP TST1 ;START TESTING THIS DEVICE

2$:
;IF WE TAKE THIS PATH WE HAVE MADE A CYCLE THRU THE PROGRAM ONCE
;PER DEVICE I.E. - WE HAVE MADE A COMPLETE PASS
;NOW WE NEED TO RESTORE EVERYTHING FOR THE NEXT COMPLETE PASS
MOV #1,ROTADD ;SET UP ROTATING POINTER FOR NEXT
;MULTIPLE PASS
MOV KEEPADD,BASEADD ;RESTORE BASE ADDRESS
MOV KEEPIV,BASEIV ;RESTORE BASE INTERRUPT VECTOR
MOV BASEADD,DLBASE ;RESTORE 1ST DEVICE BASE ADDRESS
MOV BASEIV,DLVECT ;RESTORE 1ST DEVICE VECTOR ADDRESS
NOP
JSR PC,DLADDR ;FORM ADDRESSES FOR 1ST DEVICE

3$:
;*****
CLR $STNM ;ZERO THE TEST NUMBER
CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;INCREMENT THE PASS NUMBER
BIC #10000,$PASS ;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;LOOP?
SEOPCT: .WORD 1
BGT $DOAGN ;YES
MOV (PC)+,(PC)+ ;RESTORE COUNTER
SENDCT: .WORD 1
TYPE SENDMG ;TYPE "END PASS #"
MOV $PASS,-(SP) ;SAVE $PASS FOR TYPEOUT
TYPDS ;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE $ENULL ;TYPE A NULL CHARACTER
SGET42: MOV #42,R0 ;GET MONITOR ADDRESS
BEQ $DOAGN ;BRANCH IF NO MONITOR
RESET ;CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;GO TO MONITOR
NOP ;SAVE ROOM
NOP ;FOR
NOP ;ACT11
$DOAGN: JMP #(PC)+ ;RETURN
SRTNAD: .WORD RESTR
$ENULL: .BYTE -1,-1,0 ;NULL CHARACTER STRING
SENDMG: .ASCIZ <15><12>/END PASS #/

.SBTTL SCOPE HANDLER ROUTINE

;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1 LOOP ON TEST
;SW11=1 INHIBIT ITERATIONS
;SW09=1 LOOP ON ERROR

```

```

1869 ;*SW08=1          LOOP ON TEST IN SWR<7:0>
1870 ;*CALL
1871 ;*          SCOPE          ;;SCOPE=IOT
1872
1873 010476          $SCOPE:
1874 010476 032777 040000 170434 1$: BIT #BIT14,2SWR          ;;LOOP ON PRESENT TEST?
1875 010504 001111          BNE $OVER          ;;YES IF SW14=1
1876          ;*****START OF CODE FOR THE XOR TESTER*****
1877 010506 000416          $XTSTR: BR 6$          ;;IF RUNNING ON THE "XOR" TESTER CHANGE
1878          ;THIS INSTRUCTION TO A "NOP" (NOP=240)
1879 010510 013746 000004          MOV 2$ERRVEC, -(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
1880 010514 012737 010534 000004          MOV 2$5, 2$ERRVEC          ;;SET FOR TIMEOUT
1881 010522 005737 177060          TST 2$177060          ;;TIME OUT ON XOR?
1882 010526 012637 000004          MOV (SP)+, 2$ERRVEC          ;;RESTORE THE ERROR VECTOR
1883 010532 000463          BR $SVLAD          ;;GO TO THE NEXT TEST
1884 010534 022626          5$: CMP (SP)+, (SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
1885 010536 012637 000004          MOV (SP)+, 2$ERRVEC          ;;RESTORE THE ERROR VECTOR
1886 010542 000423          BR 7$          ;;LOOP ON THE PRESENT TEST
1887 010544          6$; *****END OF CODE FOR THE XOR TESTER*****
1888 010544 032777 000400 170366          BIT #BIT08,2SWR          ;;LOOP ON SPEC. TEST?
1889 010552 001404          BEQ 2$          ;;BR IF NO
1890 010554 127767 170360 170320          CMPB 2$SWR, $STSTM          ;;ON THE RIGHT TEST? SWR<7:0>
1891 010562 001462          BEQ $OVER          ;;BR IF YES
1892 010564 105767 170313          2$: TSTB $ERFLG          ;;HAS AN ERROR OCCURRED?
1893 010570 001421          BEQ 3$          ;;BR IF NO
1894 010572 126767 170317 170303          CMPB $SERMAX, $ERFLG          ;;MAX. ERRORS FOR THIS TEST OCCURRED?
1895 010600 101015          BHI 3$          ;;BR IF NO
1896 010602 032777 001000 170330          BIT #BIT09,2SWR          ;;LOOP ON ERROR?
1897 010610 001404          BEQ 4$          ;;BR IF NO
1898 010612 016767 170272 170266          7$: MOV $LPERR, $LPADR          ;;SET LOOP ADDRESS TO LAST SCOPE
1899 010620 000443          BR $OVER
1900 010622 105067 170255          4$: CLRB $ERFLG          ;;ZERO THE ERROR FLAG
1901 010626 005067 170410          CLR $TIMES          ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
1902 010632 000415          BR 1$          ;;ESCAPE TO THE NEXT TEST
1903 010634 032777 004000 170276          3$: BIT #BIT11,2SWR          ;;INHIBIT ITERATIONS?
1904 010642 001011          BNE 1$          ;;BR IF YES
1905 010644 005767 170230          TST $PASS          ;;IF FIRST PASS OF PROGRAM
1906 010650 001406          BEQ 1$          ;;INHIBIT ITERATIONS
1907 010652 005267 170226          INC $ICNT          ;;INCREMENT ITERATION COUNT
1908 010656 026767 170360 170220          CMP $TIMES, $ICNT          ;;CHECK THE NUMBER OF ITERATIONS MADE
1909 010664 002021          BGE $OVER          ;;BR IF MORE ITERATION REQUIRED
1910 010666 012767 000001 170210          1$: MOV #1, $ICNT          ;;REINITIALIZE THE ITERATION COUNTER
1911 010674 016767 000044 170340          MOV $SMXCNT, $TIMES          ;;SET NUMBER OF ITERATIONS TO DO
1912 010702 105267 170174          $SVLAD: INCB $STSTM          ;;COUNT TEST NUMBERS
1913 010706 011667 170174          MOV (SP), $LPADR          ;;SAVE SCOPE LOOP ADDRESS
1914 010712 011667 170172          MOV (SP), $LPERR          ;;SAVE ERROR LOOP ADDRESS
1915 010716 005067 170322          CLR $ESCAPE          ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
1916 010722 112767 000001 170165          MOVB #1, $SERMAX          ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
1917 010730 016777 170146 170204          $OVER: MOV $STSTM, 2$DISPLAY          ;;DISPLAY TEST NUMBER
1918 010736 016716 170144          MOV $LPADR, (SP)          ;;FUDGE RETURN ADDRESS
1919 010742 000002          RTI          ;;FIXES PS
1920 010744 000100          $SMXCNT: 100          ;;MAX. NUMBER OF ITERATIONS
1921
1922 .SBTTL ERROR HANDLER ROUTINE
1923
1924 ;;*****

```



```

1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936 010746
1937 010746 105267 170131
1938 010752 001775
1939 010754 016777 170122 170160
1940 010762 032777 002000 170150
1941 010770 001402
1942 010772 104401 001246
1943 010776 005267 170110
1944 011002 011667 170110
1945 011006 162767 000002 170102
1946 011014 117767 170076 170072
1947 011022 032777 020000 170110
1948 011030 001004
1949 011032 004767 000044
1950 011036 104401 001253
1951 011042
1952 011042 005777 170072
1953 011046 100001
1954 011050 000000
1955 011052 032777 001000 170060
1956 011060 001402
1957 011062 016716 170022
1958 011066 005767 170152
1959 011072 001402
1960 011074 016716 170144
1961 011100
1962 011100 000002
1963
1964
1965
1966
1967
1968
1969
1970
1971 011102
1972 011102 104401 001253
1973 011106 010046
1974 011110 005000
1975 011112 153700 001114
1976 011116 001004
1977
1978 011120 016746 167772
1979
1980 011124 104402

```

```

; *THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
; *SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
; *AND GO TO SERRTYP ON ERROR
; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
; *SW15=1 HALT ON ERROR
; *SW13=1 INHIBIT ERROR TYPEOUTS
; *SW10=1 BELL ON ERROR
; *SW09=1 LOOP ON ERROR
; *CALL
; * ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER

```

```

SERROR:
7S: INCB SERFLG ;; SET THE ERROR FLAG
BEQ 7S ;; DON'T LET THE FLAG GO TO ZERO
MOV STSTNM,DISP ;; DISPLAY TEST NUMBER AND ERROR FLAG
BIT #BIT10,JSWR ;; BELL ON ERROR?
BEQ 1S ;; NO - SKIP
TYPE SBELL ;; RING BELL
1S: INC SERTTL ;; COUNT THE NUMBER OF ERRORS
MOV (SP),SERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
SUB #2,SERRPC
MOVB @SERRPC,SITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
BIT #BIT13,JSWR ;; SKIP TYPEOUT IF SET
BNE 20S ;; SKIP TYPEOUTS
JSR PC,SERRTYP ;; GO TO USER ERROR ROUTINE
TYPE ,SCLF

20S:
2S: TST JSWR ;; HALT ON ERROR
BPL 3S ;; SKIP IF CONTINUE
HALT ;; HALT ON ERROR!
3S: BIT #BIT09,JSWR ;; LOOP ON ERROR SWITCH SET?
BEQ 4S ;; BR IF NO
MOV SLPERR,(SP) ;; FUDGE RETURN FOR LOOPING
4S: TST SESCPE ;; CHECK FOR AN ESCAPE ADDRESS
BEQ 5S ;; BR IF NONE
MOV SESCPE,(SP) ;; FUDGE RETURN ADDRESS FOR ESCAPE
5S:
RTI ;; RETURN

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

```

; *****
; *THIS ROUTINE USES THE "ITEM CONTROL BYTE" (SITEMB) TO DETERMINE WHICH
; *ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (SERRTB),
; *AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

```

SERRTYP:
TYPE SCLF ;; "CARRIAGE RETURN" & "LINE FEED"
MOV RO,-(SP) ;; SAVE RO
CLR RO ;; PICKUP THE ITEM INDEX
BISB @SITEMB,RO
BNE 1S
1S: ;; IF ITEM NUMBER IS ZERO, JUST
MOV SERRPC,-(SP) ;; TYPE THE PC OF THE ERROR
TYPE SERRPC ;; SAVE SERRPC FOR TYPEOUT
TYPE SERRPC ;; ERROR ADDRESS
TYPE SERRPC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)

```

```

1981 011126 000426
1982 011130 005300
1983 011132 006300
1984 011134 006300
1985 011136 006300
1986 011140 062700 001310
1987 011144 012067 000004
1988 011150 001404
1989 011152 104401
1990 011154 000000
1991 011156 104401 001253
1992 011162 012067 000004
1993 011166 001404
1994 011170 104401
1995 011172 000000
1996 011174 104401 001253
1997 011200 011000
1998 011202 001004
1999 011204 012600
2000 011206 104401 001253
2001 011212 000207
2002 011214
2003 011214 013046
2004 011216 104402
2005 011220 005710
2006 011222 001770
2007 011224 104401 011232
2008 011230 000771
2009 011232 020040 000
2010 011236

```

```

BR 6$ ;; GET OUT
1$: DEC R0 ;; ADJUST THE INDEX SO THAT IT WILL
ASL R0 ;; WORK FOR THE ERROR TABLE
ASL R0
ASL R0
ADD #SERRTB,R0 ;; FORM TABLE POINTER
MOV (R0)+,2$ ;; PICKUP "ERROR MESSAGE" POINTER
BEQ 3$ ;; SKIP TYPEOUT IF NO POINTER
TYPE ;; TYPE THE "ERROR MESSAGE"
WORD 0 ;; "ERROR MESSAGE" POINTER GOES HERE
TYPE SCRLF ;; "CARRIAGE RETURN" & "LINE FEED"
3$: MOV (R0)+,4$ ;; PICKUP "DATA HEADER" POINTER
BEQ 5$ ;; SKIP TYPEOUT IF 0
TYPE ;; TYPE THE "DATA HEADER"
WORD 0 ;; "DATA HEADER" POINTER GOES HERE
TYPE SCRLF ;; "CARRIAGE RETURN" & "LINE FEED"
5$: MOV (R0),R0 ;; PICKUP "DATA TABLE" POINTER
BNE 7$ ;; GO TYPE THE DATA
6$: MOV (SP)+,R0 ;; RESTORE R0
TYPE SCRLF ;; "CARRIAGE RETURN" & "LINE FEED"
RTS PC ;; RETURN
7$: MOV 2(R0)+,-(SP) ;; SAVE 2(R0)+ FOR TYPEOUT
TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
TST (R0) ;; IS THERE ANOTHER NUMBER?
BEQ 6$ ;; BR IF NO
TYPE 8$ ;; TYPE TWO(2) SPACES
BR 7$ ;; LOOP
8$: .ASCIZ / / ;; TWO(2) SPACES
.EVEN

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV   NUM,-(SP)   ;; NUMBER TO BE TYPED
*   TYPOS   ;; CALL FOR TYPEOUT
*   .BYTE  N   ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M   ;; M=1 OR 0
*           ;; 1=TYPE LEADING ZEROS
*           ;; 0=SUPPRESS LEADING ZEROS
*
*STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR STYPOC
*CALL:
*   MOV   NUM,-(SP)   ;; NUMBER TO BE TYPED
*   TYPON   ;; CALL FOR TYPEOUT
*
*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV   NUM,-(SP)   ;; NUMBER TO BE TYPED
*   TYPOC   ;; CALL FOR TYPEOUT

```



```

2037 011236 017646 000000          STYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
2038 011242 116667 000001 000211  MOVB     1(SP),SOFILL      ;; LOAD ZERO FILL SWITCH
2039 011250 112667 000207          MOVB     (SP)+,SOMODE+1    ;; NUMBER OF DIGITS TO TYPE
2040 011254 062716 000002          ADD      #2,(SP)          ;; ADJUST RETURN ADDRESS
2041 011260 000406          BR       STYPOS
2042 011262 112767 000001 000171  STYPOC: MOVB     #1,SOFILL      ;; SET THE ZERO FILL SWITCH
2043 011270 112767 000006 000165  MOVB     #6,SOMODE+1      ;; SET FOR SIX(6) DIGITS
2044 011276 112767 000005 000154  STYPON: MOVB     #5,SOCNT      ;; SET THE ITERATION COUNT
2045 011304 010346          MOV      R3,-(SP)        ;; SAVE R3
2046 011306 010446          MOV      R4,-(SP)        ;; SAVE R4
2047 011310 010546          MOV      R5,-(SP)        ;; SAVE R5
2048 011312 116704 000145          MOVB     SOMODE+1,R4      ;; GET THE NUMBER OF DIGITS TO TYPE
2049 011316 005404          NEG      R4
2050 011320 062704 000006          ADD      #6,R4           ;; SUBTRACT IT FOR MAX. ALLOWED
2051 011324 110467 000132          MOVB     R4,SOMODE        ;; SAVE IT FOR USE
2052 011330 116704 000125          MOVB     SOFILL,R4        ;; GET THE ZERO FILL SWITCH
2053 011334 016605 000012          MOV      12(SP),R5       ;; PICKUP THE INPUT NUMBER
2054 011340 005003          CLR      R3              ;; CLEAR THE OUTPUT WORD
2055 011342 006105          1S:    ROL      R5         ;; ROTATE MSB INTO "C"
2056 011344 000404          BR       3S              ;; GO DO MSB
2057 011346 006105          2S:    ROL      R5         ;; FORM THIS DIGIT
2058 011350 006105          ROL      R5
2059 011352 006105          ROL      R5
2060 011354 010503          MOV      R5,R3
2061 011356 006103          3S:    ROL      R3         ;; GET LSB OF THIS DIGIT
2062 011360 105367 000076          DECB     SOMODE           ;; TYPE THIS DIGIT?
2063 011364 100016          BPL      7S              ;; BR IF NO
2064 011366 042703 177770          BIC      #177770,R3      ;; GET RID OF JUNK
2065 011372 001002          BNE      4S              ;; TEST FOR 0
2066 011374 005704          TST      R4              ;; SUPPRESS THIS 0?
2067 011376 001403          BEQ      5S              ;; BR IF YES
2068 011400 005204          4S:    INC      R4         ;; DON'T SUPPRESS ANYMORE 0'S
2069 011402 052703 000060          BIS      #'0,R3         ;; MAKE THIS DIGIT ASCII
2070 011406 052703 000040          5S:    BIS      #' ,R3    ;; MAKE ASCII IF NOT ALREADY
2071 011412 110367 000040          MOVB     R3,#S           ;; SAVE FOR TYPING
2072 011416 104401 011456          TYPE     #S              ;; GO TYPE THIS DIGIT
2073 011422 105367 000032          7S:    DECB     $OCNT      ;; COUNT BY 1
2074 011426 003347          BGT      2S              ;; BR IF MORE TO DO
2075 011430 002402          BLT      6S              ;; BR IF DONE
2076 011432 005204          INC      R4              ;; INSURE LAST DIGIT ISN'T A BLANK
2077 011434 000744          BR       2S              ;; GO DO THE LAST DIGIT
2078 011436 012605          6S:    MOV      (SP)+,R5    ;; RESTORE R5
2079 011440 012604          MOV      (SP)+,R4        ;; RESTORE R4
2080 011442 012603          MOV      (SP)+,R3        ;; RESTORE R3
2081 011444 016666 000002 000004  MOV      2(SP),4(SP)     ;; SET THE STACK FOR RETURNING
2082 011452 012616          MOV      (SP)+,(SP)
2083 011454 000002          RTI
2084 011456 000          8S:    .BYTE    0           ;; RETURN
2085 011457 000          .BYTE    0           ;; STORAGE FOR ASCII DIGIT
2086 011460 000          SOCNT:   .BYTE    0           ;; TERMINATOR FOR TYPE ROUTINE
2087 011461 000          SOFILL:  .BYTE    0           ;; OCTAL DIGIT COUNTER
2088 011462 000000          SOMODE:  .WORD    0           ;; ZERO FILL SWITCH
2089
2090          .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2091
2092          ;;*****

```


M05

MAINDEC-11-DZDLC-3 MACY11 30(1046) 12-JUL-77 10:02 PAGE 43
 DZDLCB.P11 06-MAY-77 10:04

CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148

011464
011464 010046
011466 010146
011470 010246
011472 010346
011474 010546
011476 012746 020200
011502 016605 000020
011506 100004
011510 005405
011512 112766 000055 000001
011520 005000
011522 012703 011700
011526 112723 000040
011532 005002
011534 016001 011670
011540 160105
011542 002402
011544 005202
011546 000774
011550 060105
011552 005702
011554 001002
011556 105716
011560 100407
011562 106316
011564 103003
011566 116663 000001 177777
011574 052702 000060
011600 052702 000040
011604 110223
011606 005720
011610 020027 000010
011614 002746
011616 003002
011620 010502
011622 000764
011624 105726
011626 100003
011630 116663 177777 177776
011636 105013
011640 012605
011642 012603
011644 012602
011646 012601
011650 012600
011652 104401 011700

```

; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
; *REPLACED WITH SPACES.
; *CALL:
; *      MOV      NUM,-(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
; *      TYPDS                    ;; GO TO THE ROUTINE

$TYPDS:
MOV      R0,-(SP)      ;; PUSH R0 ON STACK
MOV      R1,-(SP)      ;; PUSH R1 ON STACK
MOV      R2,-(SP)      ;; PUSH R2 ON STACK
MOV      R3,-(SP)      ;; PUSH R3 ON STACK
MOV      R5,-(SP)      ;; PUSH R5 ON STACK
MOV      #20200,-(SP)   ;; SET BLANK SWITCH AND SIGN
MOV      20(SP),R5     ;; GET THE INPUT NUMBER
BPL      1$            ;; BR IF INPUT IS POS.
NEG      R5            ;; MAKE THE BINARY NUMBER POS.
MOVB    #'-,1(SP)     ;; MAKE THE ASCII NUMBER NEG.
CLR      R0            ;; ZERO THE CONSTANTS INDEX
MOV      #SDBLK,R3    ;; SETUP THE OUTPUT POINTER
MOVB    #' ,(R3)+     ;; SET THE FIRST CHARACTER TO A BLANK
2$:     CLR      R2     ;; CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1 ;; GET THE CONSTANT
3$:     SUB      R1,R5  ;; FORM THIS BCD DIGIT
BLT     4$            ;; BR IF DONE
INC     R2            ;; INCREASE THE BCD DIGIT BY 1
BR      3$

4$:     ADD      R1,R5  ;; ADD BACK THE CONSTANT
TST     R2            ;; CHECK IF BCD DIGIT=0
BNE     5$            ;; FALL THROUGH IF 0
TSTB   (SP)          ;; STILL DOING LEADING 0'S?
BMI     7$            ;; BR IF YES
ASLB   (SP)          ;; MSD?
BCC     6$            ;; BR IF NO
MOVB   1(SP),-1(R3)  ;; YES--SET THE SIGN
6$:     BIS     #'0,R2  ;; MAKE THE BCD DIGIT ASCII
7$:     BIS     #' ,R2  ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+     ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST    (R0)+        ;; JUST INCREMENTING
CMP    R0,#10       ;; CHECK THE TABLE INDEX
BLT    2$           ;; GO DO THE NEXT DIGIT
BGT    8$           ;; GO TO EXIT
MOV    R5,R2        ;; GET THE LSD
BR     6$           ;; GO CHANGE TO ASCII
8$:     TSTB   (SP)+  ;; WAS THE LSD THE FIRST NON-ZERO?
BPL    9$           ;; BR IF NO
MOVB   -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
9$:     CLRB   (R3)   ;; SET THE TERMINATOR
MOV    (SP)+,R5     ;; POP STACK INTO R5
MOV    (SP)+,R3     ;; POP STACK INTO R3
MOV    (SP)+,R2     ;; POP STACK INTO R2
MOV    (SP)+,R1     ;; POP STACK INTO R1
MOV    (SP)+,R0     ;; POP STACK INTO R0
TYPE  ,SDBLK       ;; NOW TYPE THE NUMBER
  
```



```

2149 011656 016666 000002 000004      MOV      2(SP),4(SP)      ;;ADJUST THE STACK
2150 011664 012616      MOV      (SP)+,(SP)      ;;RETURN TO USER
2151 011666 000002      RTI
2152 011670 023420      SDTBL:   10000.
2153 011672 001750      1000.
2154 011674 000144      100.
2155 011676 000012      10.
2156 011700 000004      SDBLK:   .BLKW  4
2157
2158      .SBTTL  TTY INPUT ROUTINE
2159
2160      ;*****
2161      .ENABL  LSB
2162
2163      .DSABL  LSB
2164
2165
2166      ;*****
2167      ;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
2168      ;CALL:
2169      ;      RDCHR          ;; INPUT A SINGLE CHARACTER FROM THE TTY
2170      ;      RETURN HERE   ;; CHARACTER IS ON THE STACK
2171      ;                    ;; WITH PARITY BIT STRIPPED OFF
2172
2173
2174 011710 011646      SRDCHR:  MOV      (SP),-(SP)      ;; PUSH DOWN THE PC
2175 011712 016666 000004 000002      MOV      4(SP),2(SP)      ;; SAVE THE PS
2176 011720 105777 167220      1$:      TSTB     @STKS          ;; WAIT FOR
2177 011724 100375      BPL      1$              ;; A CHARACTER
2178 011726 117766 167214 000004      MOVB     @STKB,4(SP)      ;; READ THE TTY
2179 011734 042766 177600 000004      BIC      #'C<177>,4(SP)   ;; GET RID OF JUNK IF ANY
2180 011742 026627 000004 000023      CMP      4(SP),#23       ;; IS IT A CONTROL-S?
2181 011750 001013      BNE      3$              ;; BRANCH IF NO
2182 011752 105777 167166      2$:      TSTB     @STKS          ;; WAIT FOR A CHARACTER
2183 011756 100375      BPL      2$              ;; LOOP UNTIL ITS THERE
2184 011760 117746 167162      MOVB     @STKB,-(SP)      ;; GET CHARACTER
2185 011764 042716 177600      BIC      #'C177,(SP)      ;; MAKE IT 7-BIT ASCII
2186 011770 022627 000021      CMP      (SP)+,#21       ;; IS IT A CONTROL-Q?
2187 011774 001366      BNE      2$              ;; IF NOT DISCARD IT
2188 011776 000750      BR       1$              ;; YES, RESUME
2189 012000 026627 000004 000140      3$:      CMP      4(SP),#140      ;; IS IT UPPER CASE?
2190 012006 002407      BLT      4$              ;; BRANCH IF YES
2191 012010 026627 000004 000175      CMP      4(SP),#175      ;; IS IT A SPECIAL CHAR?
2192 012016 003003      BGT      4$              ;; BRANCH IF YES
2193 012020 042766 000040 000004      BIC      #40,4(SP)       ;; MAKE IT UPPER CASE
2194 012026 000002      4$:      RTI                    ;; GO BACK TO USER
2195
2196      ;*****
2197      ;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2198      ;CALL:
2199      ;      RDLIN          ;; INPUT A STRING FROM THE TTY
2200      ;      RETURN HERE   ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2201      ;                    ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
2202 012030 010346      SRDLIN:  MOV      R3,-(SP)   ;; SAVE R3
2203 012032 005046      CLR      -(SP)          ;; CLEAR THE RUBOUT KEY
2204 012034 012703 012264      1$:      MOV      @TTYIN,R3      ;; GET ADDRESS

```


2205	012040	022703	012274	2S:	CMP	#STTYIN+8.,R3	:: BUFFER FULL?
2206	012044	101456			BLOS	4S	:: BR IF YES
2207	012046	104406			ROCHR		:: GO READ ONE CHARACTER FROM THE TTY
2208	012050	112613			MOV	(SP)+,(R3)	:: GET CHARACTER
2209	012052	122713	000177	10S:	CMPB	#177,(R3)	:: IS IT A RUBOUT
2210	012056	001022			BNE	5S	:: BR IF NO
2211	012060	005716			TST	(SP)	:: IS THIS THE FIRST RUBOUT?
2212	012062	001007			BNE	6S	:: BR IF NO
2213	012064	112767	000134 000170		MOV	#'\,9S	:: TYPE A BACK SLASH
2214	012072	104401	012262		TYPE	9S	
2215	012076	012716	177777		MOV	#-1,(SP)	:: SET THE RUBOUT KEY
2216	012102	005303		6S:	DEC	R3	:: BACKUP BY ONE
2217	012104	020327	012264		CMP	R3,#STTYIN	:: STACK EMPTY?
2218	012110	103434			BLO	4S	:: BR IF YES
2219	012112	111367	000144		MOV	(R3),9S	:: SETUP TO TYPEOUT THE DELETED CHAR.
2220	012116	104401	012262		TYPE	9S	:: GO TYPE
2221	012122	000746			BR	2S	:: GO READ ANOTHER CHAR.
2222	012124	005716		5S:	TST	(SP)	:: RUBOUT KEY SET?
2223	012126	001406			BEQ	7S	:: BR IF NO
2224	012130	112767	000134 000124		MOV	#'\,9S	:: TYPE A BACK SLASH
2225	012136	104401	012262		TYPE	9S	
2226	012142	005016			CLR	(SP)	:: CLEAR THE RUBOUT KEY
2227	012144	122713	000025	7S:	CMPB	#25,(R3)	:: IS CHARACTER A CTRL U?
2228	012150	001003			BNE	8S	:: BR IF NO
2229	012152	104401	012274		TYPE	SCNTLU	:: TYPE A CONTROL "U"
2230	012156	000726			BR	1S	:: GO START OVER
2231	012160	122713	000022	8S:	CMPB	#22,(R3)	:: IS CHARACTER A "r"?
2232	012164	001011			BNE	3S	:: BRANCH IF NO
2233	012166	105013			CLRB	(R3)	:: CLEAR THE CHARACTER
2234	012170	104401	001253		TYPE	,SCRLF	:: TYPE A "CR" & "LF"
2235	012174	104401	012264		TYPE	STTYIN	:: TYPE THE INPUT STRING
2236	012200	000717			BR	2S	:: GO PICKUP ANOTHER CHARACTER
2237	012202	104401	001252	4S:	TYPE	SQUES	:: TYPE A '?'
2238	012206	000712			BR	1S	:: CLEAR THE BUFFER AND LOOP
2239	012210	111367	000046	3S:	MOV	(R3),9S	:: ECHO THE CHARACTER
2240	012214	104401	012262		TYPE	9S	
2241	012220	122723	000015		CMPB	#15,(R3)+	:: CHECK FOR RETURN
2242	012224	001305			BNE	2S	:: LOOP IF NOT RETURN
2243	012226	105063	177777		CLRB	-1(R3)	:: CLEAR RETURN (THE 15)
2244	012232	104401	001254		TYPE	SLF	:: TYPE A LINE FEED
2245	012236	005726			TST	(SP)+	:: CLEAN RUBOUT KEY FROM THE STACK
2246	012240	012603			MOV	(SP)+,R3	:: RESTORE R3
2247	012242	011646			MOV	(SP)-,(SP)	:: ADJUST THE STACK AND PUT ADDRESS OF THE
2248	012244	016666	000004 000002		MOV	4(SP),2(SP)	:: FIRST ASCII CHARACTER ON IT
2249	012252	012766	012264 000004		MOV	#STTYIN,4(SP)	
2250	012260	000002			RTI		:: RETURN
2251	012262	000		9S:	.BYTE	0	:: STORAGE FOR ASCII CHAR. TO TYPE
2252	012263	000			.BYTE	0	:: TERMINATOR
2253	012264	000010			STTYIN:	.BLKB	8.
2254	012274	052536	005015 000		SCNTLU:	.ASCIZ	/↑U/<15><12>
2255	012301	136	006507 000012		SCNTLG:	.ASCIZ	/↑G/<15><12>
2256	012306	005015	053523 020122		SMSWR:	.ASCIZ	<15><12>/SWR = /
2257	012314	020075	000				
2258	012317	040	047040 053505		SMNEW:	.ASCIZ	/ NEW = /
2259	012324	036440	000040				
2260							


```

2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275 012330 011646
2276 012332 016666 000004 000002
2277 012340 010046
2278 012342 010146
2279 012344 010246
2280 012346 104407
2281 012350 012600
2282 012352 010067 000100
2283 012356 005001
2284 012360 005002
2285 012362 112046
2286 012364 001420
2287 012366 122716 000060
2288 012372 003026
2289 012374 122716 000067
2290 012400 002423
2291 012402 006301
2292 012404 006102
2293 012406 006301
2294 012410 006102
2295 012412 006301
2296 012414 006102
2297 012416 042716 177770
2298 012422 062601
2299 012424 000756
2300 012426 005726
2301 012430 010166 000012
2302 012434 010267 000026
2303 012440 012602
2304 012442 012601
2305 012444 012600
2306 012446 000002
2307 012450 005726
2308 012452 105010
2309 012454 104401
2310 012456 000000
2311 012460 104401 001252
2312 012464 000730
2313 012466 000000
2314
2315
2316

```

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

```

*****
: THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
: CHANGE IT TO BINARY.
: THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
: OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
: FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
: THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.

```

```

:CALL:
: * RDOCT : READ AN OCTAL NUMBER
: * RETURN HERE : LOW ORDER BITS ARE ON TOP OF THE STACK
: * : HIGH ORDER BITS ARE IN SHIOCT

```

```

SRDOCT: MOV (SP), -(SP) : PROVIDE SPACE FOR THE
MOV 4(SP), 2(SP) : INPUT NUMBER
MOV RO, -(SP) : PUSH RO ON STACK
MOV R1, -(SP) : PUSH R1 ON STACK
MOV R2, -(SP) : PUSH R2 ON STACK
1$: RDLIN : READ AN ASCII LINE
MOV (SP)+, RO : GET ADDRESS OF 1ST CHARACTER
MOV RO, 5$ : AND SAVE IT
CLR R1 : CLEAR DATA WORD
CLR R2
2$: MOVB (RO)+, -(SP) : PICKUP THIS CHARACTER
BEQ 3$ : IF ZERO GET OUT
CMPB #'0, (SP) : MAKE SURE THIS CHARACTER
BGT 4$ : IS AN OCTAL DIGIT
CMPB #'7, (SP)
BLT 4$
ASL R1 ;; #2
ROL R2
ASL R1 ;; #4
ROL R2
ASL R1 ;; #8
ROL R2
BIC #'C7, (SP) : STRIP THE ASCII JUNK
ADD (SP)+, R1 : ADD IN THIS DIGIT
BR 2$ : LOOP
3$: TST (SP)+ : CLEAN TERMINATOR FROM STACK
MOV R1, 12(SP) : SAVE THE RESULT
MOV R2, SHIOCT
MOV (SP)+, R2
MOV (SP)+, R1
MOV (SP)+, RO
RTI
4$: TST (SP)+ : CLEAN PARTIAL FROM STACK
CLRB (RO) : SET A TERMINATOR
TYPE : TYPE UP THRU THE BAD CHAR.
5$: .WORD 0
TYPE $QUES : "?" "CR" & "LF"
BR 1$ : TRY AGAIN
SHIOCT: .WORD 0 : HIGH ORDER BITS GO HERE

```

.SBTTL TYPE ROUTINE

2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372

012470 105767 166463
012474 100002
012476 000000
012500 000407
012502 010046
012504 017600 000002
012510 112046
012512 001005
012514 005726
012516 012600
012520 062716 000002
012524 000002
012526 122716 000011
012532 001430
012534 122716 000200
012540 001006
012542 005726
012544 104401
012546 001253
012550 105067 000130
012554 000755
012556 004767 000056
012562 126726 166370
012566 001350
012570 016746 166360
012574 105366 000001
012600 002770
012602 004767 000032
012606 105367 000072
012612 000770

012614 112716 000040
012620 004767 000014
012624 132767 000007 000052
012632 001372
012634 005726
012636 000724
012640 105777 166304

```
*****  
:ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.  
:THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.  
:NOTE1: SNUL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.  
:NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.  
:NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.  
:  
:CALL:  
:1) USING A TRAP INSTRUCTION  
: TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING  
:OR  
: TYPE  
: MESADR  
:  
:STYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?  
 BPL 1$ ;; BR IF YES  
 HALT ;; HALT HERE IF NO TERMINAL  
 BR 3$ ;; LEAVE  
 1$: MOV RO, -(SP) ;; SAVE RO  
 MOV $2(SP), RO ;; GET ADDRESS OF ASCIZ STRING  
 2$: MOVB (RO)+, -(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK  
 BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR  
 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK  
 60$: MOV (SP)+, RO ;; RESTORE RO  
 3$: ADD #2, (SP) ;; ADJUST RETURN PC  
 RTI ;; RETURN  
 4$: CMPB #HT, (SP) ;; BRANCH IF <HT>  
 BEQ 8$  
 CMPB #CRLF, (SP) ;; BRANCH IF NOT <CRLF>  
 BNE 5$  
 TST (SP)+ ;; POP <CR><LF> EQUIV  
 TYPE ;; TYPE A CR AND LF  
 $CRLF  
 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT  
 BR 2$ ;; GET NEXT CHARACTER  
 5$: JSR PC, $TYPEC ;; GO TYPE THIS CHARACTER  
 6$: CMPB $FILLC, (SP)+ ;; IS IT TIME FOR FILLER CHARS.?  
 BNE 2$ ;; IF NO GO GET NEXT CHAR.  
 MOV $NULL, -(SP) ;; GET # OF FILLER CHARS. NEEDED  
 ;; AND THE NULL CHAR.  
 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?  
 BLT 6$ ;; BR IF NO--GO POP THE NULL OFF OF STACK  
 JSR PC, $TYPEC ;; GO TYPE A NULL  
 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT  
 BR 7$ ;; LOOP  
  
;HORIZONTAL TAB PROCESSOR  
  
 8$: MOVB #' (SP) ;; REPLACE TAB WITH SPACE  
 9$: JSR PC, $TYPEC ;; TYPE A SPACE  
 BITB #7, $CHARCNT ;; BRANCH IF NOT AT  
 BNE 9$ ;; TAB STOP  
 TST (SP)+ ;; POP SPACE OFF STACK  
 BR 2$ ;; GET NEXT CHARACTER  
 $TYPEC: TSTB $STPS ;; WAIT UNTIL PRINTER IS READY
```



```

2373 012644 100375          BPL      STYPEC
2374 012646 116677 000002 166276  MOVB    2(SP),2STPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
2375 012654 122766 000015 000002  CMPB    #CR,2(SP)  ;;IS CHARACTER A CARRIAGE RETURN?
2376 012662 001003          BNE     1$         ;;BRANCH IF NO
2377 012664 105067 000014          CLRB    $CHARCNT  ;;YES--CLEAR CHARACTER COUNT
2378 012670 000406          BR      $TYPEX    ;;EXIT
2379 012672 122766 000012 000002 1$:  CMPB    #LF,2(SP)  ;;IS CHARACTER A LINE FEED?
2380 012700 001402          BEQ     $TYPEX    ;;BRANCH IF YES
2381 012702 105227          INCB   (PC)+     ;;COUNT THE CHARACTER
2382 012704 000000          $CHARCNT: WORD  0  ;;CHARACTER COUNT STORAGE
2383 012706 000207          $TYPEX: RTS     PC

```

.SBTTL READ A DECIMAL NUMBER FROM THE TTY

```

2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399

```

```

; *****
; *THIS ROUTINE WILL READ A DECIMAL (ASCII) NUMBER FROM THE TTY AND
; *CHANGE IT TO BINARY. IF TOO MANY CHARACTERS OR ANY ILLEGAL CHARACTERS
; *ARE READ A "?" FOLLOWED BY A CARRIAGE RETURN-LINE FEED WILL BE TYPED.
; *THE COMPLETE NUMBER MUST BE RETYPED. THE INPUT IS TERMINATED BY THE
; *USER TYPING A CARRIAGE RETURN. THE RANGE OF THE INPUT NUMBER IS
; *POSITIVE 32767 TO NEGATIVE 32768.
; *CALL:
; *      RDECC          ;;READ A DECIMAL NUMBER
; *      RETURN HERE   ;;NUMBER IS ON TOP OF THE STACK
;

```

```

2400 012710 011646          $RDECC: MOV    (SP),-(SP)  ;;PROVIDE SPACE FOR
2401 012712 016666 000004 000002  MOV    4(SP),2(SP)  ;;THE INPUT NUMBER
2402 012720 010046          MOV    R0,-(SP)     ;;PUSH R0 ON STACK
2403 012722 010146          MOV    R1,-(SP)     ;;PUSH R1 ON STACK
2404 012724 010246          MOV    R2,-(SP)     ;;PUSH R2 ON STACK
2405 012726 104407 1$:  RDLIN          ;;READ AN ASCII LINE
2406 012730 012600          MOV    (SP)+,R0    ;;ADDRESS OF 1ST CHAR.
2407 012732 010067 000120  MOV    R0,6$        ;;SAVE INCASE OF BAD INPUT
2408 012736 005046          CLR    -(SP)        ;;CLEAR DATA WORD
2409 012740 005002          CLR    R2           ;;SIGN SET POSITIVE
2410 012742 122710 000055  CMPB    #'-,(R0)    ;;SEE IF A MINUS SIGN WAS TYPED
2411 012746 001001          BNE    2$          ;;BR IF NO MINUS SIGN
2412 012750 112002          MOVB   (R0)+,R2    ;;SAVE FOR LATER USE
2413 012752 112001 2$:  MOVB   (R0)+,R1    ;;PICKUP THIS CHARACTER
2414 012754 001424          BEQ    3$          ;;GET OUT IF ZERO
2415 012756 122701 000060  CMPB    #'0,R1     ;;MAKE SURE THIS CHARACTER
2416 012762 003032          BGT    5$          ;;IS A DIGIT BETWEEN 0 & 9
2417 012764 122701 000071  CMPB    #'9,R1
2418 012770 002427          BLT    5$
2419 012772 032716 170000  BIT    #C7777,(SP) ;;DON'T LET NUMBER GET TO BIG
2420 012776 001024          BNE    5$          ;;BR IF NUMBER WOULD OVERFLOW
2421 013000 006316          ASL    (SP)         ;;*2
2422 013002 011646          MOV    (SP),-(SP)  ;;SAVE FOR LATER
2423 013004 006316          ASL    (SP)         ;;*4
2424 013006 006316          ASL    (SP)         ;;*8
2425 013010 062616          ADD    (SP)+,(SP)  ;;*10
2426 013012 102416          BVS    5$          ;;OVERFLOW ISN'T ALLOWED
2427 013014 162701 000060  SUB    #'0,R1      ;;STRIP AWAY THE ASCII JUNK
2428 013020 060116          ADD    R1,(SP)    ;;ADD IN THIS DIGIT

```

2429 013022 102412
2430 013024 000752
2431 013026 005702
2432 013030 001401
2433 013032 005416
2434 013034 012666 000012
2435 013040 012602
2436 013042 012601
2437 013044 012600
2438 013046 000002

BVS 5\$;:OVERFLOW ISN'T ALLOWED
BR 2\$;:LOOP
3\$: TST R2 ;:CHECK IF NUMBER IS NEG
BEQ 4\$;:BR IF NO
NEG (SP) ;:YES--NEGATE THE NUMBER
4\$: MOV (SP)+,12(SP) ;:SAVE THE RESULT
MOV (SP)+,R2 ;:POP STACK INTO R2
MOV (SP)+,R1 ;:POP STACK INTO R1
MOV (SP)+,RO ;:POP STACK INTO RO
RTI ;:RETURN

2440 013050 005726
2441 013052 105010
2442 013054 104401
2443 013056 000000
2444 013060 104401 001252
2445 013064 000720

5\$: TST (SP)+ ;:CLEAN PARTIAL NUMBER FROM STACK
CLRB (RO) ;:SET A TERMINATOR
TYPE ;:TYPE THE INPUT UP TO BAD CHAR.
6\$: .WORD 0 ;:POINTER GOES HERE
TYPE \$QUES ;:?" "CR" &"LF"
BR 1\$;:TRY AGAIN

.SBTTL TRAP DECODER

;:THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;:AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;:OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;:GO TO THAT ROUTINE.

2455 013066 010046
2456 013070 016600 000002
2457 013074 005740
2458 013076 111000
2459 013100 006300
2460 013102 016000 013122
2461 013106 000200

\$TRAP: MOV RO, -(SP) ;:SAVE RO
MOV 2(SP),RO ;:GET TRAP ADDRESS
TST -(RO) ;:BACKUP BY 2
MOVB (RO),RO ;:GET RIGHT BYTE OF TRAP
ASL RO ;:POSITION FOR INDEXING
MOV \$TRPAD(RO),RO ;:INDEX TO TABLE
RTS RO ;:GO TO ROUTINE

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

2466 013110 011646
2467 013112 016666 000004 000002
2468 013120 000002

\$TRAP2: MOV (SP), -(SP) ;:MOVE THE PC DOWN
MOV 4(SP),2(SP) ;:MOVE THE PSW DOWN
RTI ;:RESTORE THE PSW

.SBTTL TRAP TABLE

;:THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;:BY THE "TRAP" INSTRUCTION.

2475 ;
2476 ;
2477 013122 013110
2478 013124 012470
2479 013126 011262
2480 013130 011236
2481 013132 011276
2482 013134 011464
2483
2484

ROUTINE

\$TRPAD: .WORD \$TRAP2
\$TYPE ;:CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
\$TYPOC ;:CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
\$TYPOS ;:CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
\$TYPON ;:CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
\$TYPDS ;:CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)

2485	013136	011710			SRDCHR	::CALL=RDCHR	TRAP+6(104406)	TTY TYPEIN CHARACTER ROUTINE
2486	013140	012030			SRDLIN	::CALL=RDLIN	TRAP+7(104407)	TTY TYPEIN STRING ROUTINE
2487	013142	012330			SRDOCT	::CALL=RD OCT	TRAP+10(104410)	READ AN OCTAL NUMBER FROM TTY
2488	013144	012710			SRDEEC	::CALL=RDDEC	TRAP+11(104411)	READ A DECIMAL NUMBER FROM TTY

.SBTTL POWER DOWN AND UP ROUTINES

::*****

:POWER DOWN ROUTINE

2494	013146	012737	013312	000024	\$PWRDN:	MOV	\$SILLUP, @PWRVEC	::SET FOR FAST UP
2495	013154	012737	000340	000026		MOV	#340, @PWRVEC+2	::PRIO:7
2496	013162	010046				MOV	R0, -(SP)	::PUSH R0 ON STACK
2497	013164	010146				MOV	R1, -(SP)	::PUSH R1 ON STACK
2498	013166	010246				MOV	R2, -(SP)	::PUSH R2 ON STACK
2499	013170	010346				MOV	R3, -(SP)	::PUSH R3 ON STACK
2500	013172	010446				MOV	R4, -(SP)	::PUSH R4 ON STACK
2501	013174	010546				MOV	R5, -(SP)	::PUSH R5 ON STACK
2502	013176	017746	165736			MOV	@SWR, -(SP)	::PUSH @SWR ON STACK
2503	013202	010667	000110			MOV	SP, \$SAVR6	::SAVE SP
2504	013206	012737	013220	000024		MOV	@PWRUP, @PWRVEC	::SET UP VECTOR
2505	013214	000000				HALT		
2506	013216	000776				BR	.-2	::HANG UP

::*****

:POWER UP ROUTINE

2510	013220	012737	013312	000024	\$PWRUP:	MOV	\$SILLUP, @PWRVEC	::SET FOR FAST DOWN
2511	013226	016706	000064			MOV	\$SAVR6, SP	::GET SP
2512	013232	005067	000060			CLR	\$SAVR6	::WAIT LOOP FOR THE TTY
2513	013236	005267	000054		1\$:	INC	\$SAVR6	::WAIT FOR THE INC
2514	013242	001375				BNE	1\$::OF WORD
2515	013244	012677	165670			MOV	(SP)+, @SWR	::POP STACK INTO @SWR
2516	013250	012605				MOV	(SP)+, R5	::POP STACK INTO R5
2517	013252	012604				MOV	(SP)+, R4	::POP STACK INTO R4
2518	013254	012603				MOV	(SP)+, R3	::POP STACK INTO R3
2519	013256	012602				MOV	(SP)+, R2	::POP STACK INTO R2
2520	013260	012601				MOV	(SP)+, R1	::POP STACK INTO R1
2521	013262	012600				MOV	(SP)+, R0	::POP STACK INTO R0
2522	013264	012737	013146	000024		MOV	@PWRDN, @PWRVEC	::SET UP THE POWER DOWN VECTOR
2523	013272	012737	000340	000026		MOV	#340, @PWRVEC+2	::PRIO:7
2524	013300	104401				TYPE		::REPORT THE POWER FAILURE
2525	013302	013320			\$PWRMG:	.WORD	\$POWER	::POWER FAIL MESSAGE POINTER
2526	013304	012716				MOV	(PC)+, (SP)	::RESTART AT RESTR
2527	013306	001772			\$PWRAD:	.WORD	RESTR	::RESTART ADDRESS
2528	013310	000002				RTI		
2529	013312	000000			\$SILLUP:	HALT		::THE POWER UP SEQUENCE WAS STARTED
2530	013314	000776				BR	.-2	::BEFORE THE POWER DOWN WAS COMPLETE
2531	013316	000000			\$SAVR6:	0		::PUT THE SP HERE
2532	013320	005015	047520	042527	\$POWER:	.ASCIZ	<15><12>"POWER"	
2533	013326	000122						
2534						.EVEN		

::*****

:TRANSMIT INTERRUPT SERVICE ROUTINE FOR 256. BYTE BLOCK TRANSFERS

::*****

2540	013330	105777	166060		XINT:	TSTB	@DLXCSR	;"READY" SET ??
------	--------	--------	--------	--	-------	------	---------	-----------------

```

2541 013374 100416          BMI      1$          ;BR IF YES
2542 013376 013767 177776 165636      MOV      2(PSW),STMP0 ;SAVE THE ERROR PSW
2543 013374 010667 165626          MOV      SP,SREG6    ;SAVE THE ERROR STACK POINTER
2544 013350 005167 166046          COM      XFLGO       ;SET XMIT SOFTWARE ERROR FLAG
2545 013354 042777 000100 166026      BIC      #100,2DLRCSR ;TURN OFF THE INTERRUPT ENABLES
2546 013362 042777 000100 166024      BIC      #100,2DLXCSR
2547 013370 000411          BR       2$          ;GO TO EXIT
2548 013372 022767 021660 166032 1$:    CMP      2(DLBUF1),OPTR ;XMITTED 256. BYTES YET ??
2549 013400 001405          BEQ      2$          ;BR IF YES
2550 013402 117777 166024 166006      MOVB    2(OPTR),2DLXDBR ;OUTPUT A BYTE
2551 013410 005267 166016          INC      OPTR        ;UPDATE BUFFER POINTER
2552 013414 000002          RTI       ;RETURN TO MAINLINE TEST

```

```

;*****
;RECEIVER INTERRUPT SERVICE ROUTINE FOR 256. BYTE BLOCK TRANSFERS
;*****

```

```

2558 013416 105777 165766      RINT:    TSTB     2DLRCSR ;"DONE" SET ??
2559 013422 100410          BMI      1$          ;BR IF YES
2560 013424 013767 177776 165550      MOV      2(PSW),STMP0 ;SAVE THE ERROR PSW
2561 013432 010667 165540          MOV      SP,SREG6    ;SAVR THE ERROR STACK POINTER
2562 013436 005167 165762          COM      RFLGO       ;SET HARD RCVR ERROR FLAG
2563 013442 000415          BR       2$          ;GO EXIT
2564 013444 005777 165742          1$:    TST      2DLRDBR  ;ANY SOFT ERRORS ??
2565 013450 100021          BPL      3$          ;BR IF NOT
2566 013452 013767 177776 165522      MOV      2(PSW),STMP0 ;SAVE THE ERROR PSW
2567 013460 010667 165512          MOV      SP,SREG6    ;SAVE THE ERROR STACK POINTER
2568 013464 017767 165722 165512      MOV      2DLRDBR,STMP1 ;SAVE THE ERROR REGISTER IN TMP1
2569 013472 005167 165730          COM      RFLG1       ;SET THE SOFT ERROR FLAG
2570 013476 042777 000100 165710 2$:    BIC      #100,2DLXCSR ;TURN OFF THE INTR. ENABLES
2571 013504 042777 000100 165676      BIC      #100,2DLRCSR
2572 013512 000411          BR       4$          ;GO TO EXIT
2573 013514 022767 022260 165712 3$:    CMP      2(BUFEND),IPTR ;RECEIVED 256. BYTES YET ??
2574 013522 001405          BEQ      4$          ;BR IF YES
2575 013524 117777 165662 165702      MOVB    2DLRDBR,2IPTR ;INPUT A BYTE FROM THE DL11
2576 013532 005267 165676          INC      IPTR        ;UPDATE BUFFER POINTER
2577 013536 000002          RTI       ;RETURN TO MAINLINE TEST

```

```

;THE FOLLOWING ROUTINE IS USED BY THE USER UTILITY PROGRAMS TO WAIT
;A SPECIFIED NO. OF MILLISECONDS BETWEEN CHARACTER TRANSFERS

```

```

2581 013540 017667 000000 000034 DELAY:  MOV      2(R6),DELCNT ;GET THE NO. OF MSEC. DELAY COUNT
2582 013546 062716 000002          ADD      #2,(R6)     ;TYPED IN BY USER
2583 013552 005767 000024          TST      DELCNT     ;SET UP THIS ROUTINE'S EXIT ADDRESS
2584 013556 001410          BEQ      3$          ;IS THE DELAY COUNT ZERO?
2585 013560 012746 000226          1$:    MOV      #226,-(SP) ;BRANCH IF YES
2586 013564 005316          2$:    DEC      (SP)    ;PUSH A 1 MSEC. COUNT TO STACK
2587 013566 001376          BNE      2$          ;DECREMENT THE 1 MSEC. COUNT BY 1
2588 013570 005726          TST      (SP)+      ;BRANCH IF 1 MSEC. NOT EATEN
2589 013572 005367 000004          DEC      DELCNT     ;AWAY YET
2590 013576 001370          BNE      1$          ;RESET STACK AFTER 1 MSEC. TIME UP
2591 013578 000207          RTS      PC         ;DECREMENT THE TOTAL NO. OF
2592 013580 000207          ;MSECS. COUNT
2593 013582 000207          ;BRANCH IF WE HAVE MORE MSECS.
2594 013584 000207          ;TO WAIT
2595 013586 000207          3$:    ;GO BACK TO REISSUE A CHARACTER

```



```

2597 013602 000000 DELCNT: .WORD 0 ;THE NO. OF MSECS. NEEDED TO
2598 ;TRANSPIRE RESIDES HERE
2599 ;THE FOLLOWING ROUTINE IS USED BY USER PROGRAM #4 AND WILL ALLOW
2600 ;A RANDOM NUMBER OF MILLISECONDS BEFORE TRANSMISSION OF CHARACTER
2601
2602 013604 016700 000062 STALL: MOV NUMONE,RO ;GET THE LOW LIMIT
2603 013610 006100 ROL RO ;MULTIPLY BY 4
2604 013612 006100 ROL RO
2605 013614 066700 000054 ADD NUMTWO,RO ;ADD IN THE HIGH LIMIT
2606 013620 010067 000046 MOV RO,NUMONE ;STORE THIS AS NEW LOW LIMIT
2607 013624 006100 ROL RO ;MULTIPLY NEW LOW LIMIT BY 4
2608 013626 006100 ROL RO
2609 013630 066700 000040 ADD NUMTWO,RO ;ADD IN THE HIGH LIMIT
2610 013634 006100 ROL RO ;MULTIPLY BY 4 AGAIN
2611 013636 006100 ROL RO
2612 013640 010067 000030 MOV RO,NUMTWO ;STORE THIS AS NEW HIGH LIMIT
2613 013644 016700 000022 MOV NUMONE,RO ;SAVE THE RANDOMLY GENERATED NO.
2614 013650 046700 165432 BIC STLMSK,RO ;STRIP ALL BUT 1ST 5 BITS SO AS
2615 ;NOT TO ALLOW THE STALL TO BE TOO
2616 ;LARGE
2617 013654 001405 BEQ 2$ ;BRANCH IF RESULT WAS ZERO
2618 013656 010067 000004 MOV RO,1$ ;SET STALL TIME FOR DELAY ROUTINE
2619 013662 004767 177652 JSR PC,DELAY ;GO OFF TO STALL
2620 013666 000000 1$: .WORD 0 ;THIS IS WHERE STALL TIME RESIDES
2621 013670 000207 2$: RTS PC ;RETURN TO ISSUE CHARACTER
2622 013672 001233 NUMONE: 1233 ;LOW LIMIT FOR RANDOM NO.
2623 013674 007622 NUMTWO: 7622 ;HIGH LIMIT FOR RANDOM NO.
2624 ;THE FOLLOWING ROUTINE CHECKS THE 'DONE' BIT FOR BOTH THE RECEIVER
2625 ;AND TRANSMITTER. THIS ROUTINE IS USED BY PROGRAM #4
2626
2627 013676 016767 165306 000044 TIMERX: MOV $TMP3,DUT ;GET THE TRANSMITTER CONTROL
2628 ;STATUS REGISTER ADDRESS
2629 013704 162767 000004 000036 SUB #4,DUT ;FORM THE RECEIVER CONTROL
2630 ;STATUS REGISTER ADDRESS
2631 013712 000403 BR TCONT ;GO TO TIME OUT THE RECEIVERS'
2632 ;DONE BIT
2633 013714 016767 165270 000026 TIMETX: MOV $TMP3,DUT ;GET THE TRANSMITTER CONTROL
2634 ;STATUS REGISTER ADDRESS
2635 013722 005067 165270 TCONT: CLR $TMP6 ;INITIALIZE A TIME COUNT
2636 013726 005267 165264 1$: INC $TMP6 ;INCREMENT THE TIME COUNT
2637 013732 001405 BEQ 2$ ;BRANCH IF TIME COUNTER OVERFLOWED
2638 ;INDICATING DONE BIT NEVER SET
2639 ;WITH PLENTY OF TIME ELAPSED
2640 013734 105777 000010 TSTB @DUT ;SEE IF DONE BIT IS SET YET
2641 013740 100372 BPL 1$ ;WAIT SOME MORE IF IT ISN'T
2642 013742 062716 000006 ADD #6,@R6 ;DONE BIT IS SET - SET UP EXIT
2643 ;RETURN TO SKIP ERROR REPORT
2644 013746 000207 2$: RTS PC ;RETURN TO PROGRAM #4
2645 013750 000000 DUT: .WORD 0 ;THIS IS WHERE THE RCSR OR XCSR
2646 ;ADDRESS RESIDES
2647 ;THIS ROUTINE IS USED BY PROGRAMS #4 & 5, AND WILL CHECK FOR CORRECT
2648 ;EXPECTED AND RECEIVED DATA, IN ADDITION TO ANY ERROR BITS
2649
2650 013752 016767 165236 165236 DATCHK: MOV $TMP5,$TMP6 ;GET THE CONTENTS OF THE RECEIVER
2651 ;BUFFER
2652 013760 016767 165226 165200 MOV $TMP4,$REG2 ;STORE THE ADDRESS OF THE RECEIVER
    
```

```

2653                                     ;DATA BUFFER
2654 013766 016767 165174 165170      MOV   SREG2,SREG1 ;GET THE ADDRESS OF THE RECEIVER
2655                                     ;DATA BUFFER
2656 013774 162767 000002 165162      SUB   #2,SREG1 ;FORM THE ADDRESS OF THE RECEIVER
2657                                     ;STATUS REGISTER FROM IT
2658 014002 016767 165206 165160      MOV   STMP5,SREG3 ;STORE THE CONTENTS OF THE RECEIVER
2659                                     ;DATA BUFFER
2660 014010 032767 170000 165200      BIT   #170000,STMP6 ;ARE ANY ERROR BITS SET?
2661 014016 001013 165200 165200      BNE   1$ ;BRANCH IF YES
2662 014020 004767 000720 165200      JSR   PC,UPMASK ;GO TO MASK OFF BITS AS A FUNCTION OF
2663                                     ;CHARACTER LENGTH( 5, 6, 7, OR 8 BITS)
2664 014024 026767 165164 165200      CMP   STMP5,STMP14 ;WAS RECEIVED CHARACTER THE
2665                                     ;SAME AS THE ONE TRANSMITTED?
2666 014032 001406 165200 165200      BEQ   2$ ;BRANCH IF YES
2667 014034 016767 165172 165130      MOV   STMP14,SREG4 ;STORE WHAT THE CONTENTS OF THE
2668                                     ;RECEIVER DATA BUFFER SHOULD BE
2669 014042 104010 165172 165130      ERROR +10 ;DATA RECEIVED WRONG!
2670 014044 000401 165172 165130      BR    2$ ;GET SET TO RETURN AFTER ERROR REPORT
2671 014046 104007 165172 165130      1$:  ERROR +7 ;ERROR BIT/S SET FROM TRANSMISSION
2672 014050 000207 165172 165130      2$:  RTS   PC ;RETURN TO PROGRAM #4
2673
2674                                     ;*****
2675                                     ;SUBROUTINE TO SETUP ERROR INFORMATION FOR ERROR MESSAGES
2676                                     ;*****
2677

```



```

2678 014052 013767 177776 165122 SUER2:  MOV    @PSW,STMP0    ;SAVE THE (PSW)
2679 014060 016701 165324          MOV    DLRCR,R1      ;PUT DEVADR IN R1
2680 014064 011203          MOV    (R2),R3      ;PUT WAS INFO IN R3
2681 014066 010667 165104          MOV    SP,SREG6     ;SAVE THE (SP)
2682 014072 062767 000002 165076          ADD    #2,SREG6     ;CORRECT FOR CALLING JSR
2683 014100 116700 164776          SUERR1: MOVB   STSTN,R0   ;PUT TEST NO. IN R0
2684 014104 010067 165052          MOV    R0,SREG0     ;SAVE (R0) THRU (R4)
2685 014110 010167 165050          MOV    R1,SREG1
2686 014114 010267 165046          MOV    R2,SREG2
2687 014120 010367 165044          MOV    R3,SREG3
2688 014124 010467 165042          MOV    R4,SREG4
2689 014130 000207          RTS                PC
2690                                     ;RETURN TO CALLING TEST
2691 014132 013767 177776 165042 SUERT1:  MOV    @PSW,STMP0    ;SAVE THE (PSW)
2692 014140 116700 164736          MOVB   STSTN,R0   ;PUT TEST NO. IN R0
2693 014144 016701 165240          MOV    DLRCR,R1      ;PUT DEVADR IN R1
2694 014150 010067 165006          MOV    R0,SREG0     ;SAVE (R0)
2695 014154 010167 165004          MOV    R1,SREG1     ;SAVE (R1)
2696 014160 013767 177776 165016 SUERT2:  MOV    @PSW,STMP1    ;SAVE THE (PSW)
2697 014166 010667 165004          MOV    SP,SREG6     ;SAVE THE (SP)
2698 014172 062767 000002 164776          ADD    #2,SREG6     ;CORRECT FOR CALLING JSR
2699 014200 010267 164762          MOV    R2,SREG2     ;SAVE (R2)
2700 014204 000207          RTS                PC
2701                                     ;RETURN
2702                                     ;SUBROUTINE TO SETUP VECTORS FOR 256. BYTE BLOCK TRANSFER TESTS
2703
2704 014206 016705 165206          SUVEC:  MOV    DLVECT,R5    ;GET FIRST VECTOR ADDRESS
2705 014212 012725 013416          MOV    #RINT,(R5)+  ;SET UP RCVR VECTOR
2706 014216 016725 165060          MOV    DLPRI,(R5)+
2707 014222 012725 013330          MOV    #XINT,(R5)+  ;SET UP XMIT VECTOR
2708 014226 016715 165050          MOV    DLPRI,(R5)
2709 014232 000207          RTS                PC
2710                                     ;RETURN TO CALLER
2711                                     ;SUBROUTINE TO PRIME DATA BUFFERS AND DEVICE FOR 256. BYTE TRANSFER
2712
2713 014234 005077 165154          PRIME:  CLR    @DLXCSR      ;CLEAR XMIT AND RCVR CSR'S
2714 014240 005077 165144          CLR    @DLRCR
2715 014244 005067 165152          CLR    XFLGO        ;INITIALIZE ERROR FLAGS
2716 014250 005067 165150          CLR    RFLGO
2717 014254 005067 165146          CLR    RFLG1
2718 014260 012767 021260 165144          MOV    #DLBUFO,OPTR ;SET UP OUTPUT POINTER
2719 014266 012767 021660 165140          MOV    #DLBUFI,IPTR ;SET UP INPUT POINTER
2720 014274 004767 000044          JSR    PC,CLDLBF    ;GO CLEAR THE BUFFERS
2721 014300 004777 165132          JSR    PC,@LDOUT    ;GO SET UP THE PATTERN
2722 014304 005067 165130          CLR    TIMR1        ;INIT TIMEOUT COUNTERS
2723 014310 012767 000036 165124          MOV    #30,TIMR2
2724 014316 005777 165070          TST    @DLRDBR      ;FLUSH "DONE" BIT IN RCVR CSR
2725 014322 005777 165064          TST    @DLRDBR
2726 014326 052777 000100 165054          BIS    #100,@DLRCR  ;ENABLE RCVR INTR.
2727 014334 052777 000104 165052          BIS    #104,@DLXCSR ;ENABLE XMIT INTR. AND MAINT MODE
2728 014342 000207          RTS                PC
2729
2730
2731
2732
2733

```

```

;THIS ROUTINE IS CALLED TO CLEAR THE INPUT AND OUTPUT BUFFERS

```

```

2734
2735 014344 012705 021260 CLDLBF: MOV #DLBUF0,R5 ;R5 POINTS TO BEGINNING OF BUFFER AREA
2736 014350 005025 1$: CLR (R5)+ ;CLEAR A WORD
2737 014352 022705 022260 CMP #BUFEND,R5 ;DONE ALL WORDS ??
2738 014356 001374 BNE 1$ ;BR IF NOT
2739 014360 000207 RTS PC ;RETURN TO CALLER
2740
2741 ;THIS ROUTINE IS CALLED TO SET UP THE NULL-DEL-NULL PATTERN
2742
2743 014362 012705 021260 LDOUT1: MOV #DLBUF0,R5 ;R5 POINTS TO OUTPUT BUFFER
2744 014366 105025 1$: CLRB (R5)+ ;MOVE A NULL CHAR
2745 014370 112725 000377 MOVB #377,(R5)+ ;MOV A DEL CHAR
2746 014374 022705 021660 CMP #DLBUFI,R5 ;ALL DONE ??
2747 014400 001372 BNE 1$ ;BR IF NOT
2748 014402 000207 RTS PC ;RETURN TO CALLER
2749
2750 ;THIS ROUTINE IS USED TO LOAD AN ASCENDING BINARY COUNT PATTERN
2751
2752 014404 005005 LDOUT2: CLR R5 ;START WITH 000
2753 014406 110565 021260 1$: MOVB R5,DLBUF0(R5) ;LOAD ONE BYTE
2754 014412 005205 INC R5 ;INCREMENT BYTE
2755 014414 022705 000400 CMP #400,R5 ;DONE 000 THRU 377 ??
2756 014420 001372 BNE 1$ ;BR IF NOT
2757 014422 000207 RTS PC ;RETURN TO CALLER
2758
2759 ;THIS ROUTINE IS USED TO LOAD A DESCENDING BINARY COUNT PATTERN
2760
2761 014424 112767 000377 164566 LDOUT3: MOVB #377,$TMP7 ;START WITH A 377 BYTE
2762 014432 012705 021260 MOV #DLBUF0,R5 ;R5 POINTS TO OUTPUT BUFFER
2763 014436 116725 164556 1$: MOVB $TMP7,(R5)+ ;LOAD ONE BYTE
2764 014442 022705 021660 CMP #DLBUFI,R5 ;ALL DONE ??
2765 014446 001403 BEQ 2$ ;BR IF YES
2766 014450 105367 164544 DECB $TMP7 ;GENERATE NEXT BYTE
2767 014454 000770 BR 1$ ;GO MOVE IT
2768 014456 000207 2$: RTS PC ;RETURN TO CALLER
2769
2770 ;THIS ROUTINE LOADS A COMPLEMENTING WORST CASE PATTERN
2771
2772
2773 014460 012705 021260 LDOUT4: MOV #DLBUF0,R5 ;R5 POINTS TO OUTPUT BUFFER
2774 014464 005067 164530 CLR $TMP7 ;INIT. BYTE GENERATOR
2775 014470 116725 164524 1$: MOVB $TMP7,(R5)+ ;MOVE A BYTE
2776 014474 105167 164520 COMB $TMP7 ;COMPLEMENT IT
2777 014500 116725 164514 MOVB $TMP7,(R5)+ ;NOW LOAD THE 1'S COMPLEMENT
2778 014504 105267 164511 INCB $TMP7+1 ;INCREMENT THE BYTE
2779 014510 116767 164505 164502 MOVB $TMP7+1,$TMP7 ;SET UP TO LOAD NEXT TWO
2780 014516 022705 021660 CMP #DLBUFI,R5 ;ALL DONE ??
2781 014522 001362 BNE 1$ ;BR IF NOT
2782 014524 000207 RTS PC ;RETURN TO CALLER
2783
2784 ;THIS ROUTINE CHECKS FOR DATA COMPARE ERRORS IN 256. BYTE BLOCK TRANSFERS
2785
2786 014526 042777 000104 164660 CHKDAT: BIC #104,$DLXCSR ;DISABLE BOTH XMIT AND RCVR INTR. ENAB.
2787 014534 042777 000100 164646 BIC #100,$DLRCSR
2788 014542 012702 021260 MOV #DLBUF0,R2 ;R2 POINTS TO S/B DATA IN OUTPUT BUFFER
2789 014546 004767 000070 JSR PC,MASKING ;GO TO MASK OFF BITS AS A FUNCTION OF
    
```



```

2790
2791 014552 012701 021660      MOV      #DLBUF1,R1      ; CHARACTER LENGTH(5, 6, 7, OR 8 BITS)
2792 014556 122221      1$:      CMPB     (R2)+,(R1)+ ; R1 POINTS TO WAS DATA IN RCVR. BUFFER
2793 014560 001004      BNE      3$           ; DID S/B = WAS ??
2794 014562 022701 022260      2$:      CMP      #BUFEND,R1 ; BR IF NOT
2795 014566 001373      BNE      1$           ; CHECKED ALL BYTES ??
2796 014570 000207      RTS      PC           ; BR IF NOT
2797 014572 013767 177776 164402 3$:      MOV      2$PSW,$TMP0 ; RETURN TO CALLER
2798 014600 010667 164372      MOV      SP,$REG6     ; SAVE THE [PSW]
2799 014604 114204      MOV      -(R2),R4     ; SAVE THE [SP]
2800 014606 042704 177400      BIC      #177400,R4   ; GET THE S/B DATA
2801 014612 114103      MOV      -(R1),R3     ; CLEAR JUNK FROM HI BYTE
2802 014614 042703 177400      BIC      #177400,R3   ; GET THE WAS DATA
2803 014620 004767 177254      JSR      PC,SUERR1    ; CLEAR JUNK FROM HI BYTE
2804 014624 012767 014634 164412 4$:      MOV      #4$,SESCAPE ; GO SET UP ERROR INFO.
2805 014632 104003      ERROR+3 ; RETURN TO 4$ AFTER ERROR PRINT
2806 014634 005202      INC      R2           ; DATA COMPARE ERROR
2807 014636 005201      INC      R1           ; REPOSITION BUFFER POINTERS
2808 014640 000750      BR       2$           ; GO CHECK NEXT BYTE
2809
2810 ; THIS ROUTINE IS USED BY THE PATTERN TESTS
2811 ; IT WILL MASK OFF THE CHARACTER SENT OUT BY THE XMITTER
2812 ; BEFORE THE COMPARISON OF DATA OF WHAT WAS RECEIVED AND WHAT WAS TRANSMITTED
2813 ; IS DONE. THE MASKING IS DONE AS A FUNCTION OF CHARACTER LENGTH WHICH
2814 ; CAN BE EITHER 5, 6, 7, OR 8 BITS .
2815
2816 014642 005005      MASKING:  CLR      R5      ; INITIALIZE TABLE OFFSET
2817 ; FOR PICKING UP MASK WORD
2818 014644 022767 000010 164362      CMP      #8,$TMP15   ; IS THE CHARACTER LENGTH 8 BITS?
2819 014652 001427      BEQ      3$           ; BRANCH IF IT IS
2820 014654 062705 000002      ADD      #2,R5        ; SET UP FOR NEXT MASK WORD
2821 ; IT COULD BE THIS ONE
2822 014660 022767 000007 164346      CMP      #7,$TMP15   ; IS THE CHARACTER LENGTH 7 BITS?
2823 014666 001410      BEQ      1$           ; BRANCH IF IT IS
2824 014670 062705 000002      ADD      #2,R5        ; SET UP FOR NEXT MASK WORD
2825 ; IT COULD BE THIS ONE
2826 014674 022767 000006 164332      CMP      #6,$TMP15   ; IS THE CHARACTER LENGTH 6 BITS?
2827 014702 001402      BEQ      1$           ; BRANCH IF IT IS
2828 014704 062705 000002      ADD      #2,R5        ; SET UP FOR NEXT MASK WORD
2829 ; IT MUST BE THIS ONE!!!!
2830 014710 016505 014734      1$:      MOV      CHARL(R5),R5 ; PICK UP THE MASK WORD
2831 014714 005105      COM      R5           ; FORM THE BITS THAT ARE TO BE MASKED
2832 014716 140522      2$:      BICB     R5,(R2)+    ; MASK A BYTE
2833 014720 022702 021660      CMP      #DLBUF1,R2  ; ARE WE AT THE END OF THE XMITTER
2834 ; OUTPUT BUFFER
2835 014724 001374      BNE      2$           ; BRANCH IF NO TO MASK NEXT BYTE
2836 014726 012702 021260      MOV      #DLBUF0,R2 ; RESTORE R2 BEFORE RETURNING
2837 014732 000207      3$:      RTS      PC           ; RETURN TO MAINLINE CODE
2838 ; TABLE OF MASK WORDS
2839 014734 000377      CHARL:  .WORD   377        ; 8. BITS IN LENGTH
2840 014736 000177      .WORD   177        ; 7. BITS IN LENGTH
2841 014740 000077      .WORD    77        ; 6. BITS IN LENGTH
2842 014742 000037      .WORD    37        ; 5. BITS IN LENGTH
2843
2844 ; THIS ROUTINE IS USED BY PROGRAMS #4 & 5
2845 ; IT WILL MASK OFF THE CHARACTER SENT OUT BY THE TRANSMITTER

```


2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901

;BEFORE THE COMPARISON OF DATA OF WHAT WAS RECEIVED AND WHAT WAS
;TRANSMITTED IS DONE. THE MASKING IS DONE AS A FUNCTION OF CHARACTER
;LENGTH WHICH CAN BE EITHER 5, 6, 7, OR 8 BITS.

```

UPMASK: MOV     STMP1,STMP14 ;PICK UP THE CHARACTER THAT WAS
          ;SENT OUT FROM THE XMITTER
          CLR     R5          ;INITIALIZE TABLE OFFSET
          ;FOR PICKING UP MASK WORD
          CMP     #8.,STMP15 ;IS THE CHARACTER LENGTH 8 BITS?
          BEQ    2$,        ;BRANCH IF IT IS
          ADD     #2,R5      ;SET UP FOR NEXT MASK WORD
          ;IT COULD BE THIS ONE
          CMP     #7.,STMP15 ;IS THE CHARACTER LENGTH 7 BITS?
          BEQ    1$,        ;BRANCH IF IT IS
          ADD     #2,R5      ;SET UP FOR NEXT MASK WORD
          ;IT COULD BE THIS ONE
          CMP     #6.,STMP15 ;IS THE CHARACTER LENGTH 6 BITS?
          BEQ    1$,        ;BRANCH IF IT IS
          ADD     #2,R5      ;SET UP FOR NEXT MASK WORD
          ;IT MUST BE THIS ONE!!!!
1$:      MOV     CHARL(R5),R5 ;PICK UP THE MASK WORD
          COM     R5          ;FORM THE BITS THAT ARE TO BE MASKED
          #ICB   R5,STMP14 ;MASK THE LOW BYTE
2$:      RTS     PC          ;RETURN TO MAINLINE CODE

```

;ROUTINE TO SERVICE BUS ERROR TRAPS

```

BUSERR: MOVB   #60,EM4+46 ;SET UP ERROR MESSAGE
          MOVB   #60,EM4+47
          MOVB   #64,EM4+50
          BR     TRPCOM    ;GO SET UP AND REPORT BUS ERROR

```

;ROUTINE TO SERVICE RSVD INSTRUCTION TRAPS

```

RSVERR: MOVB   #60,EM4+46 ;SET UP ERROR MESSAGE
          MOVB   #61,EM4+47
          MOVB   #60,EM4+50
          BR     TRPCOM    ;GO SET UP AND REPORT RSVD INSTR. ERROR

```

;ROUTINE TO SET UP AND REPORT BUS ERROR AND RSVD INSTR ERRORS

```

TRPCOM: MOV     SP,$REG6    ;SAVE THE TRAP SP
          MOVB   $STNM,R0   ;PUT TEST NO. IN R0
          MOV     R0,$REG0   ;SAVE TEST #
          MOV     2(SP),STMP0 ;SAVE THE ERROR PSW
          MOV     #1$, $ESCAPE ;GO TO 1$ AFTER ERROR PRINT
          MOV     (SP),$REG7 ;SAVE THE ERROR PC
          ERROR+4 ;REPORTED TRAP ERROR
1$:      JMP     @#RESTRT   ;ATTEMPT TO RESTART THE PROGRAM
          ;AND TRY AGAIN

```

;ERROR MESSAGE INFORMATION

; INFORMATION FOR ERROR MESSAGE 1

2902				
2903				
2904	015146	046104	030461	051040
2905	015154	043505	051511	042524
2906	015162	020122	042522	042506
2907	015170	042522	041516	020105
2908	015176	040503	051525	042105
2909	015204	052040	046511	047505
2910	015212	052125	000	
2911	015215	040	050050	024503
2912	015222	020040	020040	050050
2913	015230	024523	020040	020040
2914	015236	051450	024520	020040
2915	015244	020040	042524	052123
2916	015252	020040	042040	053105
2917	015260	042101	020122	051040
2918	015266	043505	042101	000122
2919				

EM1: .ASCIZ 'DL11 REGISTER REFERENCE CAUSED TIMEOUT'

DH1: .ASCIZ ' (PC) (PS) (SP) TEST DEVADR REGADR'

.EVEN

DT1: .WORD \$ERRPC, \$TMPD, \$REG6, \$REG0, \$REG1, \$REG2, 0

2920	015274	001116	001202	001176
2921	015302	001162	001164	001166
2922	015310	000000		
2923				
2924				
2925				

; INFORMATION FOR ERROR MESSAGE 2

2926	015312	046104	030461	051040
2927	015320	043505	051511	042524
2928	015326	020122	051105	047522
2929	015334	000122		
2930	015336	024040	041520	020051
2931	015344	020040	024040	051520
2932	015352	020051	020040	024040
2933	015360	050123	020051	020040
2934	015366	052040	051505	020124
2935	015374	020040	042504	040526
2936	015402	051104	020040	042522
2937	015410	040507	051104	020040
2938	015416	053440	051501	020040
2939	015424	020040	051440	041057
2940	015432	000		

EM2: .ASCIZ 'DL11 REGISTER ERROR'

DH2: .ASCIZ ' (PC) (PS) (SP) TEST DEVADR REGADR WAS S/B'

.EVEN

DT2: .WORD \$ERRPC, \$TMPD, \$REG6, \$REG0, \$REG1, \$REG2, \$REG3, \$REG4, 0

2941		015434		
2942	015434	001116	001202	001176
2943	015442	001162	001164	001166
2944	015450	001170	001172	000000
2945				
2946				
2947				

; INFORMATION FOR MESSAGE 3

2948	015456	046104	030461	042040
2949	015464	052101	020101	047503
2950	015472	050115	051101	020105
2951	015500	051105	047522	000122
2952	015506	024040	041520	020051
2953	015514	020040	024040	051520
2954	015522	020051	020040	024040
2955	015530	050123	020051	020040
2956	015536	052040	051505	020124
2957	015544	020040	040527	040523

EM3: .ASCIZ 'DL11 DATA COMPARE ERROR'

DH3: .ASCIZ ' (PC) (PS) (SP) TEST WASADR SHBADR WAS S/B'

2958	015552	051104	020040	044123
2959	015560	040502	051104	020040
2960	015566	020040	040527	020123
2961	015574	020040	020040	027523
2962	015602	000102		
2963				
2964	015604	001116	001202	001176
2965	015612	001162	001164	001166
2966	015620	001170	001172	000000
2967				
2968				
2969				
2970	015626	047125	054105	042520
2971	015634	052103	042105	052040
2972	015642	040522	020120	047524
2973	015650	053040	041505	047524
2974	015656	020122	052101	046040
2975	015664	041517	052101	047511
2976	015672	020116	020040	000040
2977	015700	024040	041520	020051
2978	015706	020040	024040	051520
2979	015714	020051	020040	024040
2980	015722	050123	020051	020040
2981	015730	052040	051505	000124
2982				
2983	015736	001200	001202	001176
2984	015744	001162	000000	
2985				
2986				
2987				
2988	015750	046104	030461	051440
2989	015756	043117	020124	051105
2990	015764	047522	020122	050050
2991	015772	051101	052111	026131
2992	016000	051106	046501	047111
2993	016006	026107	047440	020122
2994	016014	053117	051105	052522
2995	016022	024516	000	
2996	016025	040	050050	024503
2997	016032	020040	020040	050050
2998	016040	024523	020040	020040
2999	016046	051450	024520	020040
3000	016054	020040	042524	052123
3001	016062	020040	042040	053105
3002	016070	042101	020122	051040
3003	016076	043505	042101	020122
3004	016104	020040	051050	043505
3005	016112	000051		
3006				
3007	016114	001116	001202	001176
3008	016122	001162	001164	001166
3009	016130	001170	000000	
3010				
3011				
3012				
3013	016134	024040	041520	020051

.EVEN
DT3: .WORD \$ERRPC,\$TMPO,\$REG6,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,0

;INFORMATION FOR MESSAGE 4

EM4: .ASCIZ 'UNEXPECTED TRAP TO VECTOR AT LOCATION '

DM4: .ASCIZ ' (PC) (PS) (SP) TEST'

.EVEN
DT4: .WORD \$REG7,\$TMPO,\$REG6,\$REG0,0

;ERROR INFORMATION FOR ERROR MESSAGE 5

EM5: .ASCIZ 'DL11 SOFT ERROR (PARITY,FRAMING, OR OVERRUN)'

DH5: .ASCIZ ' (PC) (PS) (SP) TEST DEVADR REGADR (REG)'

.EVEN
DT5: .WORD \$ERRPC,\$TMPO,\$REG6,\$REG0,\$REG1,\$REG2,\$REG3,0

;INFORMATION FOR ERROR MESSAGE 6

DM6: .ASCIZ ' (PC) (PS) (SP) REGADR'

MAINDEC-11-DZDLC-B MACY11 30(1046) 12-JUL-77 10:02 PAGE 60
 DZDLCB.P11 06-MAY-77 10:04 POWER DOWN AND UP ROUTINES

3014	016142	020040	024040	051520	
3015	016150	020051	020040	024040	
3016	016156	050123	020051	020040	
3017	016164	042522	040507	051104	
3018	016172	000			
3019		016174			.EVEN
3020	016174	001116	001204	001176	DT6: .WORD \$ERRPC,\$TMP1,\$REG6,\$REG2,0
3021	016202	001166	000000		
3022					
3023					;INFORMATION FOR ERROR MESSAGE 7
3024					
3025	016206	024040	041520	020051	DH7: .ASCIZ '(PC) DEVADR REGADR (REG)'
3026	016214	020040	042504	040526	
3027	016222	051104	020040	042522	
3028	016230	040507	051104	020040	
3029	016236	024040	042522	024507	
3030	016244	000			
3031		016246			.EVEN
3032	016246	001116	001164	001166	DT7: .WORD \$ERRPC,\$REG1,\$REG2,\$REG3,0
3033	016254	001170	000000		
3034					
3035					;INFORMATION FOR ERROR MESSAGE 10
3036					
3037	016260	024040	041520	020051	DH10: .ASCIZ '(PC) DEVADR REGADR (REG) S/B'
3038	016266	020040	042504	040526	
3039	016274	051104	020040	042522	
3040	016302	040507	051104	020040	
3041	016310	024040	042522	024507	
3042	016316	020040	020040	027523	
3043	016324	000102			
3044					.EVEN
3045	016326	001116	001164	001166	DT10: .WORD \$ERRPC,\$REG1,\$REG2,\$REG3,\$REG4,0
3046	016334	001170	001172	000000	
3047					;MISCELLANEOUS MESSAGES
3048					
3049	016342	052516	046114	042055	XMSG1: .ASCIZ 'NULL-DEL-NULL SEQUENCE TIMEOUT AT FOLLOWING PC'
3050	016350	046105	047055	046125	
3051	016356	020114	042523	052521	
3052	016364	047105	042503	052040	
3053	016372	046511	047505	052125	
3054	016400	040440	020124	047506	
3055	016406	046114	053517	047111	
3056	016414	020107	041520	000	
3057	016421	102	047111	051101	XMSG2: .ASCIZ 'BINARY UP COUNT SEQUENCE TIMEOUT AT FOLLOWING PC'
3058	016426	020131	050125	041440	
3059	016434	052517	052116	051440	
3060	016442	050505	042525	041516	
3061	016450	020105	044524	042515	
3062	016456	052517	020124	052101	
3063	016464	043040	046117	047514	
3064	016472	044527	043516	050040	
3065	016500	000103			
3066	016502	044502	040516	054522	XMSG3: .ASCIZ 'BINARY DOWN COUNT SEQUENCE TIMEOUT AT FOLLOWING PC'
3067	016510	042040	053517	020116	
3068	016516	047503	047125	020124	
3069	016524	042523	052521	047105	

3070	016532	042503	052040	046511
3071	016540	047505	052125	040440
3072	016546	020124	047506	046114
3073	016554	053517	047111	020107
3074	016562	041520	000	
3075	016565	127	051117	052123
3076	016572	041440	051501	020105
3077	016600	040520	052124	051105
3078	016606	020116	042523	052521
3079	016614	047105	042503	052040
3080	016622	046511	047505	052125
3081	016630	040440	020124	047506
3082	016636	046114	053517	047111
3083	016644	020107	041520	000
3084				
3085	016651	015	046412	044501
3086	016656	042116	041505	030455
3087	016664	026461	055104	046104
3088	016672	026503	006502	000012
3089				
3090	016700	005015	047531	020125
3091	016706	040510	042526	051440
3092	016714	046105	041505	042524
3093	016722	020104	051120	043517
3094	016730	040522	020115	047516
3095	016736	020056	006462	000012
3096	016744	005015	047531	020125
3097	016752	040510	042526	051440
3098	016760	046105	041505	042524
3099	016766	020104	051120	043517
3100	016774	040522	020115	047516
3101	017002	020056	006463	000012
3102	017010	005015	047531	020125
3103	017016	040510	042526	051440
3104	017024	046105	041505	042524
3105	017032	020104	051120	043517
3106	017040	040522	020115	047516
3107	017046	020056	006464	000012
3108	017054	005015	047531	020125
3109	017062	040510	042526	051440
3110	017070	046105	041505	042524
3111	017076	020104	051120	043517
3112	017104	040522	020115	047516
3113	017112	020056	006465	000012
3114	017120	005015	051124	047101
3115	017126	046523	052111	042524
3116	017134	020122	047504	042516
3117	017142	041040	052111	047040
3118	017150	053105	051105	051440
3119	017156	052105	020040	041520
3120	017164	020075	000	
3121	017167	015	051012	041505
3122	017174	044505	042526	020122
3123	017202	047504	042516	041040
3124	017210	052111	047040	053105
3125	017216	051105	051440	052105

XMSG4: .ASCIZ 'WORST CASE PATTERN SEQUENCE TIMEOUT AT FOLLOWING PC'

STMES: .ASCIZ <15><12>'MAINDEC-11-DZDLC-B'<15><12>

PROG2M: .ASCIZ <15><12>'YOU HAVE SELECTED PROGRAM NO. 2'<15><12>

PROG3M: .ASCIZ <15><12>'YOU HAVE SELECTED PROGRAM NO. 3'<15><12>

PROG4M: .ASCIZ <15><12>'YOU HAVE SELECTED PROGRAM NO. 4'<15><12>

PROG5M: .ASCIZ <15><12>'YOU HAVE SELECTED PROGRAM NO. 5'<15><12>

XDB: .ASCIZ <15><12>'TRANSMITTER DONE BIT NEVER SET PC= '

RDB: .ASCIZ <15><12>'RECEIVER DONE BIT NEVER SET PC= '

3126	017224	020040	041520	020075
3127	017232	000		
3128				
3129				
3130	017233	015	053412	040510
3131	017240	020124	051511	052040
3132	017246	042510	041440	040510
3133	017254	040522	052103	051105
3134	017262	046040	047105	052107
3135	017270	020110	032450	033054
3136	017276	033454	047440	020122
3137	017304	020070	044502	051524
3138	017312	037451	000	
3139	017315	015	042012	020117
3140	017322	047531	020125	044527
3141	017330	044123	052040	020117
3142	017336	042524	052123	047440
3143	017344	044124	051105	052040
3144	017352	040510	020116	044124
3145	017360	105		
3146	017361	015	042012	043105
3147	017366	052501	052114	042040
3148	017374	053105	041511	020105
3149	017402	030450	030057	036440
3150	017410	054440	051505	047057
3151	017416	024517	000077	
3152	017422	005015	044127	052101
3153	017430	044440	020123	044124
3154	017436	020105	051461	020124
3155	017444	042522	042503	053111
3156	017452	051105	051440	040524
3157	017460	052524	020123	042522
3158	017466	044507	052123	051105
3159	017474	040440	042104	042522
3160	017502	051523	020077	000040
3161	017510	005015	044127	052101
3162	017516	044440	020123	044124
3163	017524	020105	051461	020124
3164	017532	042522	042503	053111
3165	017540	051105	020123	042526
3166	017546	052103	051117	040440
3167	017554	042104	042522	051523
3168	017562	020077	000040	
3169	017566	005015	047504	054440
3170	017574	052517	053440	047101
3171	017602	020124	047524	052040
3172	017610	051505	020124	052515
3173	017616	052114	050111	042514
3174	017624	042040	053105	041511
3175	017632	051505	030440	030057
3176	017640	054475	051505	047057
3177	017646	037517	020040	000
3178	017653	015	053412	040510
3179	017660	020124	051511	052040
3180	017666	042510	051440	040524
3181	017674	052524	020123	042522

;MESSAGES SEEKING USER RESPONSE

LENGTH: .ASCIZ <15><12>'WHAT IS THE CHARACTER LENGTH (5,6,7 OR 8 BITS)?'

DEFAULT: .ASCII <15><12>'DO YOU WISH TO TEST OTHER THAN THE'

.ASCIZ <15><12>'DEFAULT DEVICE (I/O = YES/NO)?'

MFIRSTD: .ASCIZ <15><12>'WHAT IS THE 1ST RECEIVER STATUS REGISTER ADDRESS? '

MVECT: .ASCIZ <15><12>'WHAT IS THE 1ST RECEIVER'S VECTOR ADDRESS? '

MULDEV: .ASCIZ <15><12>'DO YOU WANT TO TEST MULTIPLE DEVICES I/O=YES/NO? '

MLASTD: .ASCIZ <15><12>'WHAT IS THE STATUS REGISTER ADDRESS OF THE LAST RECEIVER? '

3182	017702	044507	052123	051105
3183	017710	040440	042104	042522
3184	017716	051523	047440	020106
3185	017724	044124	020105	040514
3186	017732	052123	051040	041505
3187	017740	044505	042526	037522
3188	017746	020040	000	
3189	017751	015	051412	046517
3190	017756	052105	044510	043516
3191	017764	053440	047522	043516
3192	017772	040455	051516	042527
3193	020000	020122	044124	020105
3194	020006	040514	052123	050440
3195	020014	042525	052123	047511
3196	020022	020116	043501	044501
3197	020030	020516	020040	000
3198	020035	015	053412	040510
3199	020042	020124	051511	054440
3200	020050	052517	020122	047111
3201	020056	042524	051122	050125
3202	020064	020124	051120	047511
3203	020072	044522	054524	046040
3204	020100	053105	046105	020077
3205	020106	000040		
3206	020110	005015	051120	043517
3207	020116	040522	020115	042504
3208	020124	044526	042503	040440
3209	020132	052103	053111	020105
3210	020140	047514	040503	044524
3211	020146	047117	051440	047510
3212	020154	051527	047040	020117
3213	020162	042504	044526	042503
3214	020170	040440	052103	053111
3215	020176	105		
3216	020177	015	051412	052105
3217	020204	051440	044527	041524
3218	020212	020110	020060	047524
3219	020220	040440	047440	042516
3220	020226	024040	024461	040440
3221	020234	042116		
3222	020236	005015	044510	020124
3223	020244	047503	052116	047111
3224	020252	042525	052040	020117
3225	020260	047507	041040	041501
3226	020266	020113	047524	042040
3227	020274	053105	041511	020105
3228	020302	042523	042514	052103
3229	020310	047511	020116	043501
3230	020316	044501	000116	
3231	020322	005015	044127	052101
3232	020330	044440	020123	044124
3233	020336	020105	051124	047101
3234	020344	046523	052111	042524
3235	020352	020122	040504	040524
3236	020360	041040	043125	042506
3237	020366	020122	042101	051104

MRANGE: .ASCIZ <15><12>'SOMETHING WRONG-ANSWER THE LAST QUESTION AGAIN! '

PLEVEL: .ASCIZ <15><12>'WHAT IS YOUR INTERRUPT PRIORITY LEVEL? '

FOULUP: .ASCII <15><12>'PROGRAM DEVICE ACTIVE LOCATION SHOWS NO DEVICE ACTIVE'

.ASCII <15><12>'SET SWITCH 0 TO A ONE (1) AND'

.ASCIZ <15><12>'HIT CONTINUE TO GO BACK TO DEVICE SELECTION AGAIN'

LINTAD: .ASCIZ <15><12>'WHAT IS THE TRANSMITTER DATA BUFFER ADDRESS? '

3238	020374	051505	037523	020040
3239	020402	000		
3240	020403	015	053412	040510
3241	020410	020124	051511	052040
3242	020416	042510	041440	040510
3243	020424	040522	052103	051105
3244	020432	052040	020117	042502
3245	020440	052040	040522	051516
3246	020446	044515	052124	042105
3247	020454	024040	041517	040524
3248	020462	020114	051501	044503
3249	020470	020111	027105	027107
3250	020476	040440	030475	030460
3251	020504	037451	020040	000
3252	020511	015	053412	040510
3253	020516	020124	051511	052040
3254	020524	042510	042040	051505
3255	020532	051111	042105	046440
3256	020540	042523	027103	042040
3257	020546	046105	054501	024040
3258	020554	041517	040524	020114
3259	020562	027105	027107	030440
3260	020570	036460	024070	030061
3261	020576	024451	020077	000040
3262	020604	005015	051511	040440
3263	020612	051040	047101	047504
3264	020620	020115	040527	052111
3265	020626	052040	046511	020105
3266	020634	046450	042523	027103
3267	020642	020051	042504	044523
3268	020650	042522	020104	030440
3269	020656	030057	054475	051505
3270	020664	047057	037517	020040
3271	020672	000		
3272	020673	015	054412	052517
3273	020700	044040	053101	020105
3274	020706	053523	034122	051440
3275	020714	052105	044440	042116
3276	020722	041511	052101	047111
3277	020730	020107	047514	050117
3278	020736	047440	020116	042524
3279	020744	052123		
3280	020746	005015	040510	042526
3281	020754	054440	052517	046440
3282	020762	042117	043111	042511
3283	020770	020104	044124	020105
3284	020776	051120	050117	051105
3285	021004	046040	041517	052101
3286	021012	047511	051516	043040
3287	021020	051117	052040	042510
3288	021026	005015	042504	044526
3289	021034	042503	052040	040510
3290	021042	020124	047531	020125
3291	021050	040527	052116	052040
3292	021056	020117	042524	052123
3293	021064	077		

SELCAR: .ASCIZ <15><12>'WHAT IS THE CHARACTER TO BE TRANSMITTED (OCTAL ASCII E.G. A=101

SELDLY: .ASCIZ <15><12>'WHAT IS THE DESIRED MSEC. DELAY (OCTAL E.G. 10=8(10))? '

RSTALL: .ASCIZ <15><12>'IS A RANDOM WAIT TIME (MSEC.) DESIRED 1/0=YES/NO? '

FAILSA: .ASCII <15><12>'YOU HAVE SWRB SET INDICATING LOOP ON TEST'

.ASCII <15><12>'HAVE YOU MODIFIED THE PROPER LOCATIONS FOR THE'

.ASCII <15><12>'DEVICE THAT YOU WANT TO TEST?'

```

3294 021065 015 044412 020106 .ASCII <15><12>'IF SO - PRESS THE CONTINUE SWITCH'
3295 021072 047523 026440 050040
3296 021100 042522 051523 052040
3297 021106 042510 041440 047117
3298 021114 044524 052516 020105
3299 021122 053523 052111 044103
3300 021130 005015 043111 047040 .ASCII <15><12>'IF NOT - MODIFY THE PROPER LOCATIONS, THEN'
3301 021136 052117 026440 046440
3302 021144 042117 043111 020131
3303 021152 044124 020105 051120
3304 021160 050117 051105 046040
3305 021166 041517 052101 047511
3306 021174 051516 020054 044124
3307 021202 047105
3308 021204 005015 042522 052123 .ASCIZ <15><12>'RESTART THE PROGRAM AT ADDRESS 200'
3309 021212 051101 020124 044124
3310 021220 020105 051120 043517
3311 021226 040522 020115 052101
3312 021234 040440 042104 042522
3313 021242 051523 031040 030060
3314 021250 000
3315
3316 021251 040 020075 041520 PCMSG: .ASCII ' = PC'
3317 021256 000040 .ASCIZ ', '
3318
3319 .EVEN
3320 ;512. WORDS RESERVED FOR TWO 256. BYTE INPUT/OUTPUT DATA BUFFERS
3321
3322 021260 000400 DLBUF0: .BLKB 256. ;RSVD FOR OUTPUT BUFFER
3323 ;THIS IS THE DATA BEING SENT OUT
3324 ;BY THE TRANSMITTER
3325 021660 000400 DLBUF1: .BLKB 256. ;RSVD FOR INPUT BUFFER
3326 ;THIS IS THE DATA THAT WAS PICKED
3327 ;UP BY THE RECEIVER (I.E. DATA
3328 ;SENT BY THE TRANSMITTER - HOPEFULLY)
3329 022260 000000 BUFEND: 0 ;TAG MARKS END OF BUFFERS
3330
3331 000001 .END
    
```


ACTREG	001274	266#	621*	653*	654*	664*	1776	1800						
BASEAD	001264	252#	573*	659*	660	667*	675*	1788*	1804	1823*	1825			
BASEIV	001270	259#	593*	1791*	1806	1824*	1826							
BEGYN	001446	46	393#											
BIT0 =	000001	152#	560	583	641	1092	1098	1111	1372	1455	1540	1649		
BIT00 =	000001	142#	152											
BIT01 =	000002	141#	151											
BIT02 =	000004	140#	150											
BIT03 =	000010	139#	149											
BIT04 =	000020	138#	148											
BIT05 =	000040	137#	147											
BIT06 =	000100	136#	146											
BIT07 =	000200	135#	145											
BIT08 =	000400	134#	144	1888										
BIT09 =	001000	133#	143	1896	1955									
BIT1 =	000002	151#	1003	1017	1062									
BIT10 =	002000	132#	1940											
BIT11 =	004000	131#	1903											
BIT12 =	010000	130#												
BIT13 =	020000	129#	1947											
BIT14 =	040000	128#	1874											
BIT15 =	100000	127#	937	949	968	980	982	1004	1016	1018	1076			
BIT2 =	000004	150#	812	818	882	893	906	936	948	1501	1603	1712		
BIT3 =	000010	149#	967	981										
BIT4 =	000020	148#												
BIT5 =	000040	147#	1037	1043	1061									
BIT6 =	000100	146#	858	864	881	908								
BIT7 =	000200	145#												
BIT8 =	000400	144#												
BIT9 =	001000	143#												
BPTVEC =	000014	159#												
BUFEND	022260	1133	1190	1247	1304	2573	2737	2794	3329#					
BUSERR	015034	486	2873#											
CHARL	014734	2830	2839#	2866										
CHKDAT	014526	1135	1192	1249	1306	2786#								
CLDLBF	014344	2720	2735#											
CONQUE	002626	626	670	682#	723									
CR =	000015	67#	2375	2385										
CRLF =	000200	68#	2346	2385										
DATCHK	013752	1617	1725	2650#										
DDISP =	177570	74#	196	420										
DEFAULT	017315	531	3139#											
DELAY	013540	1420	1506	2582#	2619									
DELCNT	013602	2582*	2585	2592*	2597#									
DH1	015215	317	2911#											
DH10	016260	366	3037#											
DH2	015336	324	2930#											
DH3	015506	331	2952#											
DH4	015700	338	2977#											
DH5	016025	345	2996#											
DH6	016134	352	3013#											
DH7	016206	359	3025#											
DISPLA	001142	196#	420*	428*	1917*	1939*								
DISPRE	000174	43#	428											
DLADDR	010070	480	571	1743#	1808	1828								
DLBASE	001260	246#	479*	567*	570	1743	1745*	1747	1749*	1751	1753*	1755	1804*	1825*

.SWRHI	48	20	
.SWRLO	48	328	33
.SCATC	48	36	
.SCHTA	48	168	
.SEOP	48	1759	
.SERRO	48	1922	
.SERRT	48	1964	
.SPOWE	48	2490	
.SRDOE	48	2386	
.SRDOC	48	2261	
.SREAO	48	2158	
.SSCOP	48	1859	
.STRAP	48	2447	
.STYPO	48	2090	
.STYPE	48	2315	
.STYPO	48	2012	

. ABS. 022262 000

ERRORS DETECTED: 0

DSKZ:DZDLCB.BIN, DSKZ:DZDLCB.LST/CRF/SOL/NL:TOC=DSKZ:DZDLCB.P11
RUN-TIME: 21 10 1 SECONDS
RUN-TIME RATIO: 314/33=9.4
CORE USED: 25K (49 PAGES)

