

PDP11

FLOAT UTILITY PROGRAM
MD-11-DZFLA-A

EP DZFLA A DL A
COPYRIGHT 1977
FICHE 1 OF 1

MAR 1977
digital
MADE IN USA

B01

EOF1DZDRGDSEQ

00010000

770224

PDP10 411

13HDR1DZFLAASEQ

00010000

770224

45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97

CONTENTS

- 1.0 ABSTRACT
- 2.0 REQUIREMENTS
 - 2.1 EQUIPMENT
- 3.0 LOADING PROCEDURE
 - 3.1 METHOD
- 4.0 STARTING PROCEDURE
 - 4.1 STARTING ADDRESSES
 - 4.2 RESTART ADDRESS
- 5.0 OPERATING PROCEDURE
 - 5.1 OPERATOR ACTION
 - 5.2 'FA' FLOATING ADDRESS OPTION
 - 5.3 'VA' FLOATING VECTOR OPTION
- 6.0 ERRORS
 - 6.1 HALTS, TRAPS, OTHER FAILURES
 - 6.2 INVALID RESPONSES
- 7.0 RESTRICTIONS
- 8.0 MISCELLANEOUS
 - 8.1 TERMINAL ADDRESS MODIFICATION
 - 8.2 RUBOUT FEATURE
 - 8.3 CONTROL/C
 - 8.4 DN11'S AND PAC11'S

99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153

1.0 ABSTRACT

FLOAT IS A UTILITY PROGRAM TO AIDE THE OPERATOR WITH DETERMINING THE ADDRESSES AND VECTOR OF DEVICES IN THE FLOATING ADDRESS OR VECTOR AREAS. THE ADDRESSES AND VECTORS GIVEN ARE COMPLETELY COMPATIBLE WITH ALL DEC STANDARD SOFTWARE.

2.0 REQUIREMENTS

2.1 EQUIPMENT

ANY PDP-11 PROCESSOR WITH 4K OF MEMORY AND A TERMINAL.

3.0 LOADING PROCEDURE

3.1 METHOD

THE PROGRAM IS SUPPLIED ON THE DIAGNOSTIC MEDIA. REFER TO THE XXDP OPERATING MANUAL FOR FURTHER INFORMATION.

4.0 STARTING PROCEDURE

4.1 STARTING ADDRESSES

BY STARTING AT ADDRESS 200(8) OR 204(8) THE RESTART ADDRESS IS INITIALIZED, THE PROGRAM TYPES NAME AND VERSION AND WILL PROMPT OPERATOR TO SET UP TERMINAL FILL COUNT.

4.2 RESTART ADDRESS

LOCATION 204(8) IS THE ONLY VALID RESTART ADDRESS.

5.0 OPERATING PROCEDURE

155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207

5.1 OPERATOR ACTION

WHEN THE PROGRAM IS LOADED AND STARTED THE TITLE AND VERSION ARE TYPED, THEN THE PROMPTS THE OPERATOR WITH:

TERMINAL TYPE (A,L,V)?

TO THIS THE OPERATOR RESPONDS

'A' <CR> IF TERMINAL IS AN ASR33 OR REQUIRES NOFILL.
'L' <CR> IF TERMINAL IS A LA305 OR REQUIRES FILL FOR
A CARRIAGE RETURN.
'V' <CR> IF TERMINAL IS A VT05 @ 300 BAUD OR MORE,
OR REQUIRES FILL FOR A LINE FEED.

AFTER THE TERMINAL FILL HAS BEEN ENTERED OR PROGRAM HAS BEEN RESTARTED THE PROGRAM TYPES.

FLOAT
OPTION:

AT THIS POINT THE PROGRAM IS WAITING FOR A TWO (2) CHARACTER RESPONSE FOLLOWED BY A CARRIAGE RETURN <CR> DEFINING WHICH OPTION IS WANTED. THE VALID RESPONSES ARE:

'FA' IF THE FLOATING ADDRESS OPTION IS DESIRED.
'VA' IF THE FLOATING VECTOR OPTION IS DESIRED.

THE PROGRAM WILL THE ASK:

"HOW MANY OF EACH DOES THE SYSTEM HAVE." AND THEN TYPE A LIST OF DEVICES DEPENDING ON THE "OPTION" SELECTED. THE LIST IS TYPED ONE DEVICE AT A TIME FOLLOWED BY A QUESTION MARK. THE OPERATOR RESPONDS TO EACH QUESTION WITH THE NUMBER OF EACH DEVICE HE HAS IN DECIMAL UNTIL THE LIST IS COMPLETED. (FOR EXCEPTIONS AND CONTROL CHARACTERS SEE MISCELLANEOUS.) AT THE END OF THE LIST THE PROGRAM WILL TYPE THE ADDRESS OR VECTOR INFORMATION BASED ON THE NUMBER SUPPLIED BY THE OPERATOR. (SEE PARA. 5.2 AND 5.3 FOR FORMAT OF DATA.)

5.2 'FA - FLOATING ADDRESS OPTION

THIS OPTION WILL ASK FOR THE DECIMAL NUMBER OF EACH DEVICE IN THE FLOATING ADDRESS RANGE.

AFTER RECEIVING INPUT FOR EACH DEVICE THE PROGRAM WILL TYPE THE DEVICE NAME, THE ADDRESS, THE MODULE NUMBER WITH THE ADDRESSING LOGIC, AND THE JUMPER(S) OR SWITCHES(ES) TO BE CUTOUT OR TURNED OFF IN THE FOLLOWING FORMAT.

209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264

DEVNAM		BOARD	JUMPER(S) TO CUTOUT
ADDRESS 1			J
ADDRESS 2			J,J
DEVNAM		BOARD	SW-SWITCH(ES) IN OFF POSITION
ADDRESS 1			S,S,S
ADDRESS 2			S,S

WHERE:

ADDRESS X = THE ADDRESS OF THE DEVICE
 BOARD = MODULE NUMBER FOR THAT DEVICE THAT
 CONTAINS THE JUMPERS/SWITCHES.
 DEVNAM = ACTUAL DEVICE NAME. (I.E. DJ11)
 J = THE JUMPER TO CUTOUT.
 S = THE SWITCH TO TURN TO THE OFF POSITION.

NOTE: DEVICES ARE LISTED IN ASCENDING ADDRESS ORDER.

5.3 'VA' - VECTOR AND ADDRESS OPTION

THIS OPTION WILL ASK FOR THE DECIMAL NUMBER OF EACH DEVICE IN THE FLOATING VECTOR RANGE.

AFTER RECEIVING INPUT FOR EACH DEVICE THE PROGRAM WILL TYPE THE DEVICE NAME, THE ADDRESSES, AND THE VECTORS IN THE FOLLOWING FORMAT.

DEVNAM		
ADDRESS 1	VECTOR 1	
ADDRESS 2	VECTOR 2	

DEVNAM	
ADDRESS 1	VECTOR 1

WHERE:

DEVNAM = ACTUAL DEVICE NAME. (I.E. DC11)
 ADDRESS X = DEVICE ADDRESS
 VECTOR X = DEVICE VECTOR

NOTE: DEVICES ARE LISTED IN ASCENDING VECTOR ORDER.

266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321

6.0 ERRORS

6.1 HALTS, TRAPS, OTHER FAILURES.

THIS PROGRAM IS NOT INTENDED TO BE A DIAGNOSTIC OR SYSTEM SIZER. IT DOES NO CHECKING OF DEVICE ADDRESSES PRESENT OR PERFORM ANY OTHER DIAGNOSTIC FUNCTIONS. IF PROGRAM HALTS, TRAPS, GETS CAUGHT IN A LOOP RUN CPU, MEMORY AND/OR TERMINAL DIAGNOSTICS.

"DO NOT USE PROGRAM TO TROUBLE SHOOT ANY FAILURES."

6.2 INVALID RESPONSES

6.2.1 INVALID RESPONSE TO 'TERMINAL TYPE (A,L,V)?'. - THE PROGRAM WILL TYPE:

VALID RESPONSES ARE--

'A' - ASR33 OR NO FILL
'L' - LA30S OR FILL FOR <CR>
'V' - VT05B OR FILL FOR <LF>?

AND WAIT FOR RESPONSE.

6.2.2 INVALID RESPONSE TO "OPTION." - THE PROGRAM WILL TYPE:

FA - FLOATING ADDRESSES (DJ, DH, DG, DU, DUP)
VA - VECTORS AND ADDRESSES OF DEVICES IN FLOATING VECTOR AREA.

AND WILL ASK AGAIN "OPTION:".

6.2.3 INVALID RESPONSE WHEN TYPING DEVICE COUNTS. - THE PROGRAM WILL TYPE:

"THAT'S NOT A VALID NUMBER!"

IF AN ALPHA CHARACTER OR NEGATIVE VALUE IS ENTERED.

OR

"THAT'S TOO MANY! ONLY XX ALLOWED!"

IF A NUMBER GREATER THAN THE MAXIMUM ALLOWED FOR THAT DEVICE ON A SINGLE SYSTEM IS SUPPLIED.

323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369

7.0 RESTRICTIONS

NONE

8.0 MISCELLANEOUS

8.1 USING OTHER THAN CONSOLE TERMINAL.

LOCATIONS 700-706 CONTAIN THE ADDRESSES OF THE TERMINAL STATUS BUFFER REGISTERS. TO USE ANOTHER DL11-A JUST CHANGE THESE FOUR (4) LOCATIONS TO THE DESIRED ADDRESSES.

8.2 RUBOUT FEATURE

THE CHARACTERS RUBBED-OUT ARE PROCEEDED AND FOLLOWED WITH A BACKSLASH "".

8.3 CONTROL/C

PROGRAM IS RESTARTED AT 200 WHEN A CNTRL/C IS TYPED WITH PROGRAM WAITING FOR INPUT.

8.4 DN11'S AND PA611'S

8.4.1 THE DN11 CAN HAVE FOUR (4) LINES PER BLOCK - (1 CONTROL MODULE). SPECIFY THE NUMBER OF LINES.

8.4.2 THE PA611'S CAN HAVE TWO (2) READERS/PUNCHES PER CONTROLLER SPECIFY THE NUMBER OF READERS/PUNCHES.
%

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

DZFLAA.LPT/NL:SYM=DZFLAA.P11
RUN-TIME: 4 4 0 SECONDS
RUN-TIME RATIO: 71/9=7.5
CORE USED: 5K (9 PAGES)

EOF1DZFLAASEQ

00010000

770224

J01
PDP10 411