



IDENTIFICATION

Product Code: MAINDEC-11-DZVTH-A  
Product Name: VT61 Exercisor  
Date: 30-JAN-76  
Maintenance: Diagnostic Group  
Author: Paul Nelson

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this manual.

The software described in this document is furnished to the purchaser under a license for use on a single computer system and can be copied (with inclusion of Digital's copyright notice) only for use in such system, except as may otherwise be provided in writing by Digital.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by Digital.

Copyright (C) 1976 by Digital Equipment Corporation.

**Table of Contents**

- 1. Abstract**
- 2. Requirements (Equipment & Memory)**
- 3. Loading Procedure**
- 4. Starting Procedure**
- 5. Operating Procedure**
- 6. Errors-General**
- 7. Restrictions**
- 8. Miscellaneous**
- 9. Program Tests Description**



1. ABSTRACT

This program is an acceptance test for the entire VT61 family of terminals. The functional testing is based upon a set of terminal functions which are common throughout the entire family of vt61 type terminals. The functions and their derived testing is designed to completely check(at the functional level) the terminal micro-processor and associated rams.

There are two distinct modes in which the program can be operated. In "auto" mode all DL11's with operational VT61's will be mapped and all will be tested sequentially. All tests which do not require manual intervention or visual screen observation (Tests 1 thru 20) will be executed for each VT61 repetitively. All errors will be reported on the system console (which is not tested even if it is a VT61).

In Manual mode console entry of the addresses and tests is required. The addresses and tests can be entered in a non-sequential manner and the subsequent execution will follow the entry sequence. This mode must be utilized to enter the keyboard tests, data loop test, and printer controller test. Sequence completion will exit to the re-start point for the manual test.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP 11 family computer with 8K words of memory, a console, and up to 16 VT61's connected to the host computer via DL11-A, B, C or D. VT61 must be in remote; full duplex and at least 300 baud.

3. LOADING PROCEDURE

Procedure for normal binary papertapes should be followed.

#### 4. STARTING PROCEDURE

##### 4.1 CONTROL SWITCH SETTINGS

Standard PDP 11 format

SW15 = 1      Halt on error.  
SW14 = 1      Loop on test  
SW13 = 1      Inhibit error timeouts  
SW11 = 1      Inhibit iterations  
SW10 = 1      Bell on error  
SW9 = 1       Loop on error  
SW8 = 1       Loop on test in SWR<7:0>

##### SPECIAL NOTE

If the computer utilized is a LSI 11 or a computer without a switch register. The program will utilize locations 174 and 175 as a "display" register and a "switch" register respectively. The operator will be responsible for the loading of the "switch" register location prior to starting or restarting the program.

##### 4.2 STARTING ADDRESSES

200 is the starting address of the "Auto" acceptance test  
204 is the starting address on the "Manual" select test.

#### 5. OPERATING PROCEDURE

Following is the operating procedure for the "auto" and "manual" modes of testing.

### 5.1 AUTO ACCEPTANCE MODE (SA = 200).

In this mode the only operator intervention required is SWR option selections such as loop on test (SWR 11), bell on error (SWR C), ect.. The program will, without any external intervention, locate the DL11's with VT61 type units attached and sequentially test all units repetitively with tests 1 thru 20.

### 5.2 MANUAL UNIT/TEST SELECTION MODE (SA = 204)

This mode requires the operator to enter the addresses of the DL11's to be tested (format is 17XXXX, ect, -up to 16 entries). The entries must be separated by commas and terminated with a carriage return. The operator must then, upon program request, enter a list of tests to be executed in the same format as the address entry (i.e. yy,zz,c/r). Preceding the terminating carriage return with a 377 octal will result in the tests being repetitively executed for all addresses entered.

Simply depressing a carriage return when unit addresses are requested will result in the mapping and testing of all good DL11's with operational VT61's attached. However, the test list must still be entered via the console!! When running the exercisor in manual mode a control C (03 octal) will result in the termination of testing at the end of the current subtest.

## 6. ERRORS-GENERAL

### 6.1 NO OPERATIONAL VT61 ATTACHED

If the unit selected (in "manual" mode) or in the mapping operation ("auto" mode) does not result in a unit which is capable of responding to the test the message "NO VT61 RESPONDED TO ESCZ SEQ. AUTO RETRY IN 30 SEC". will be displayed on the console every 30 seconds until the test is stopped or a unit responds.

### 6.2 EXCESSIVE "FATAL" ERRORS FROM UNIT UNDER TEST

If ten fatal errors (incomplete transmit/recieve cycles) occurs the message "TESTING ABORTED-TOO MANY FATAL XBITS" will be displayed and the test will exit to the initial setup sequence of the requested mode. If the test then locates an operational unit, it will begin testing it.

### 5.3 COMMON ERROR MESSAGES

#### a. ESCAPE SEQUENCE ERROR (ERROR 1)

This error message is returned when a specific escape sequence did not elicit the expected response from the unit under test. Message returns test #, error program count and two words which contain up to 4 bytes of the failing escape sequence (i.e. if "TRANSMIT ALL" failed; the ESC, O, V would be displayed in the format BYTE 1+2=015517, BYTE 3+4=000126).

#### b. RECEIVE STATUS ERROR (ERROR 2)

This error message is returned if any of bits 12, 13, or 14 are set in the interface receive buffer register. Data displayed is the address of the CSR (Control and Status Register) of the failing unit. The contents of the aforementioned CSR, the error bits from the receive buffer register, and the character which was stored when the errors were detected.

#### c. SOFTWARE STATUS (VSTAT) ERROR (ERROR 3)

The location tagged "VSTAT" is used by the program to store dynamic conditions relating to the unit under test. The bits which may cause a software status error are:

- BIT 15      SET FOR XOFF, CLEARED FOR XON
- BIT 14      SET WHEN START OF MESSAGE RECEIVED
- BIT 13      SET WHEN END OF MESSAGE RECEIVED
- BIT 12      SET FOR A PERIPHERAL ABORT MESSAGE
- BIT 10      SET WHEN AN INTERFACE ERROR DETECTED
- BIT 7        SET WHEN AN XOFF WAS DETECTED AND THE  
              TRANSMITTER WAS SHUT DOWN BY THE SOFTWARE.
- BIT 1        SET WHEN TRANSMIT COMPLETE

The only bit which will unconditionally cause this error is BIT 12 (Peripheral Abort) all other bits will be set and reset and an error is dependent upon expected conditions (i.e. after a complete transmission bits 1, 13 and 14 must be set and others mentioned reset or an error will be reported). Data displayed is the pass #, the test #, expected status and actual status.

D. VT61 HUNG ERROR (ERROR 11)

This error message is displayed if a complete transmission(s) does not result in a SOM(s), an EOM(s) and transmit done. This error is a fatal error and ten of these errors will result in the test aborting.

7. RESTRICTIONS

- A. It is imperative that both the interface and the VT61 should be placed in full duplex and remote (not local) mode.
- B. Unit to be tested cannot be the console device.
- C. For the automatic test mapping of the D111's, all addresses for the units to be tested must be within the standard DEC addresses and vectors. If this is not the case, the procedure outlined in Section B-B must be followed before testing is begun.

8. MISCELLANEOUS

- A. Execution time for the auto selection tests (test 1-20) with units set to a baud rate of 9600 baud is approximately 90 seconds.
- B. To test a device (D111 with vt61 attached) at non-standard addresses the location "STRTAB" can be modified to contain the lowest of the non-standard addresses and location "ENDTAB" modified to contain the highest non-standard address. All interfaces within the new addresses will be mapped and tested if the proper responses are obtained.
- C. To change the number of fatal errors allowed before testing is aborted, location "ALWCNT" (loaded with 10) can be modified to the desired count.
- D. All tests except Test 1 and Test 23 are run in MAINTENANCE mode, therefore all transmissions from the vt61 are expected to be preceded by a SOM and terminated with a EOM.



## 9. PROGRAM DESCRIPTION

-----

### 9.0 INITIALIZATION

In "Auto" sequence mode this section of the test maps all devices in the pre-determined areas. Devices are then tested for interrupt capability via the "MAINTENANCE" bit and all units which do not or cannot respond are purged from the table. All units are then issued the "ESCAPE Z" sequence and those which do not respond, or do not respond with the proper "IDENT" are purged. All operational units are stored in a table(DLTBL) and tested sequentially.

### 9.1 TEST 1 CHECK ALL COMMON ESCAPE SEQUENCES.

This test issues all escape sequences and insures the VT61 has not failed during an ESC sequence by issuing a ESC Z to force a VT61 response. The purpose of the test is to attempt to insure that subsequent tests will not result in a "hung" unit. Data is not evaluated.

All errors are reported as Escape Sequence failures(Error 1).

### 9.2 TEST 2 CHECK MAINTENANCE MODE.

Routine to insure entering maintenance mode causes SOM and EOM to be appended to all transmits from VT61 under test. Maintenance mode is entered, then an escape Z sequence is issued to the unit and the resulting response from the vt61 is checked for SOM/EOM.

Error 22 will be issued if either component(SOM/EOM) is missing.

### 9.3 TEST 3 CHECK DIRECT CURSOR ADDRESSING

This test insures that the cursor will respond to direct cursor addressing. The unit is reset and the cursor position is verified to be home. The cursor is then moved to row 23 column 80 and the position is again verified.

Cursor positioning errors(ERROR 7) are reported if the positions are incorrect.

#### 9.4 TEST 4 CHECK LINEAR ADDRESSING MODE.

Routine to insure the unit can enter linear addressing mode. 81 characters are issued to the unit under test then the cursor position is read and must be row1, col.0.

An Escape Sequence error (ERROR 1) is issued if the cursor is not at row1,col.0

#### 9.5 TEST 5 CHECK XON/XOFF FROM VT61

Test to insure operation of XON/XOFF commands from VT61. XOFF is forced by transmitting the data on line 23 while simultaneously filling the silo with new data. After sensing the XOFF, the test waits for the transmit to finish and insures XON occurs before the maximum transfer time has elapsed. (30 seconds)

Errors are reported if the format of ERROR 3(VSTAT errors) and will reflect either lack or excess of Bit 15.

#### 9.6 TEST 6 CHECK XON/XOFF TO VT61

Routine to verify operation of XOFF and XON to the VT61. A full screen transmit is initiated and a series of XOFFs and XONs are issued to the terminal sequentially. Errors are reported if a XOFF does not stop, or a XON restart the transmission. Test is ended when EOM is sensed.

Errors are reported(Error 15 for XOFF failure and Error 16 for a XON failure)as specific error messages.

#### 9.7 TEST 7 CHECK RAM AND COMMUNICATIONS PATHS

Routine to test VT61 RAM and the communication paths. This routine issues a series of full screen patterns (77/100, 100/77, 52/125, incrementing, and rev. video incrementing) to the VT61. The full screen is then transmitted to the host and after each iteration received data is checked and all errors (including transmission) are reported.

Errors reported could be ERROR 2 for a Receive Status error, ERROR 4 for data errors and ERROR 5 for a Receive Byte Count error.

#### 9.10 TEST 10 CHECK TRANSMIT AND RECEIVE CHECKSUMS.

Routine to test the ability of the VT61 to calculate and transmit checksums of both transmitted and received data. Subtest "A" transmits a full buffer updating a calculated checksum on each character transmitted. An escape sequence requesting the receiver checksum is embedded at the end of xmit buffer and the received checksum is compared to the calculated. Subtest "B" performs the same type of check on the VT61 transmit checksum, utilizing the data sent to the VT61 in subtest "A", during a full screen transmit.

Error 13 is issued (with calculated and received checksum) if a Receive Checksum error is detected. Error 14 is issued (with same data as ERROR 13) if a VT61 Transmit Checksum error is detected.

#### 9.11 TEST 11 CHECK BASIC CURSOR COMMANDS

Routine to insure basic cursor commands result in correct cursor movement. Commands are issued in the sequence: reset, cursor right, cursor down, cursor left, and cursor up. The read cursor position command is issued after every move cursor command and received position is compared to the expected position and any errors reported.

An Escape Sequence error (Error 1) and a Cursor Positioning error (Error 6) are issued if any functions are detected to fail.

#### 9.12 TEST 12 CHECK READ CHARACTER AT CURSOR

Routine to insure that read character at cursor functions correctly. Command sequence is: reset, A, cursor left, read character at cursor. An error is reported if the character received is not an "A".

An Escape Sequence error (Error 1) and a Data Compare error (Error 4) are issued if a failure is detected.

### 9.13 TEST 13 CHECK REPLACE AND INSERT CHARACTER MODES

Routine to verify operation of replace and insert mode. Initially row 0 is written to 80 incrementing characters; on the first pass (replace mode) a character(172) is replaced at the home position and the characters at row0, col.0 and row1, col.0 are read and verified to be a "172" and a "Null" respectively. On the second pass, insert mode is entered and the resulting insertion (at the home position) is verified. Row0, col.0 should be "172" and row1, col.0 should be "161".

If an error is detected in either mode, the appropriate Escape Sequence error(Error 1) is issued.

### 9.14 TEST 14 CHECK VT61 SCROLL CAPABILITIES.

Routine to insure VT61 will scroll if a line feed is issued from row 23 or a data insert from row 23 col. 79. In subtest "A", row 0 is initially written to a 0 and row 1 A 1. After completion of a line feed (and resulting scroll) row 00, col.00 is expected to contain A 1. In subtest "B", the cursor is placed at row23, col.79 and a data character "A" is entered. The cursor position is then read and should be row23, col.00. The char. at home is verified to be a null.

A Scroll error(Error 23) is issued if either functions fail to elicit the proper response from the unit under test. the ERFOR PC will distinguish between the failing functions.

### 9.15 TEST 15 CHECK ALL SCREEN ADDRESSES.

This test insures that the VT61 cursor can be positioned to every possible row/column position on the screen. This is tested by filling the complete screen (except Row 23, Col.79 which will contain a "Null") with the character "A" and then positioning the cursor (via DCA) to every position and the "A" at that position is replaced with a space(octal 40). The screen is then read to verify that only spaces exist on the screen. All positions containing non-spaces are reported.

All errors detected will be reported as Direct Cursor Address errors(Error 7), and will contain the position the bad data(non-space) was detected at.

#### 9.16 TEST 16 CHECK LINE FEED AND CARRIAGE RETURN

Routine to insure proper operation of carriage return and line feed during normal mode. Initially the cursor is set (via D.C.A.) to row 0, col 20 and a line feed is issued, the cursor position is then read and must be row 1, col 20. A carriage return is then issued and cursor position verified to be row 1, col 0.

An Escape Sequence error (Error 1) and a Cursor positioning error (Error 6) will be issued if an error is detected.

#### 9.17 TEST 17 CHECK ERASE TO END OF SCREEN

Routine to verify proper operation of erase to end-of-screen. Screen is written to 1920 incrementing char. Erase to end of screen is then issued and the entire screen is read verifying that it is all nulls.

If any non-null positions are detected, and Escape Sequence error (Error 1) and a Data error (Error 4) will be issued.

#### 9.20 TEST 20 CHECK SELF TEST, COPIER, AND ISSUE END OF PASS.

SELF TEST (ESC T) is issued to the unit under test and an Self Test error (Error 10) is issued if the unit cannot respond to an "Escape Z" sequence after self test is complete. If self test is successful the screen is written to 23 lines of incrementing characters and 23 lines of incrementing char. in reverse video. The "Ident" is then checked and if a copier is present a copy screen command is issued (NOTE: This command will cause the unit to be "busy" and not respond to any further commands until the screen has been completely copied.)

If the Ident indicates a copier is present and the COPY SCREEN is initiated, but not completed, a "PERIPHERAL ABORT" (Error 20) Error is issued.

\*\*\*END OF AUTO-ACCEPTANCE TESTS\*\*\*

9.21 TEST 21 KEYBOARD ECHO TEST

Routine to echo the keyboard. Keys for tab, bell, carriage and line feed echo a mnemonic, non-display char. echo octal equivalents and display char. echo themselves. (examples- char.. space, ESC, space or 037, space.) A Control C (003) will cause a test exit.

9.22 TEST 22 TEST A LINE PRINTER(PRINTER CONTROLLER MODE)

Routine to utilize the VT61 as a printer controller. After test message is displayed, the test waits for a C/R before actually entering test. A pattern of incrementing, rolling char. will be outputted until a Control C (003) is received.

If the Line Printer is disabled after the initialization of the test, a "PERIPHERAL ABORT" (Error 20) is issued.

9.23 TEST 23 UNIT SIMULATOR TEST

Routine to loop data/commands from the VT61 back to the VT61. Data transmissions resulting from a ESC sequence will also be looped and will enter the screen at the cursor position. This test can be used to simulate, or create, specific screen patterns and operations. A control C (003) exits test.

9.24 TEST 24 PRODUCTION KEYBOARD TEST

Production keyboard test. All keys must be depressed in the sequence indicated on the screen. All errors or mistakes are displayed in octal positional format and the correct key position in the row is displayed in decimal. This test is run in maintenance mode, therefore the keys will echo their position, not their indicated mnemonic. The exceptions are the individual tests for the shift and control functions. These tests are explicitly defined by messages to the operator. 10 errors will cause an automatic exit from test.

146 COMMON TAGS  
188 ERROR POINTER TABLE  
1844 END OF PASS ROUTINE  
3503 SCOPE HANDLER ROUTINE  
3568 ERROR HANDLER ROUTINE  
3613 TYPE ROUTINE  
3691 ERROR MESSAGE TIMEOUT ROUTINE  
3748 BINARY TO OCTAL (ASCII) AND TYPE  
3826 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE  
3894 POWER DOWN AND LP ROUTINES  
3934 TRAP DECODER  
3950 TRAP TABLE

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 1  
DZVTH.P11

SEQ 0012

1  
2  
3

.NLIST MD,MC,CND  
.LIST ME  
.TITLE MAINDEC-11-DZVTH-A





100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112

010000  
004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
000004  
000002  
000001

SW12= 10000  
SW11= 4000  
SW10= 2000  
SW09= 1000  
SW08= 400  
SW07= 200  
SW06= 100  
SW05= 40  
SW04= 20  
SW03= 10  
SW02= 4  
SW01= 2  
SW00= 1  
.EQUIV SW09,SW9  
.EQUIV SW08,SW8  
.EQUIV SW07,SW7  
.EQUIV SW06,SW6  
.EQUIV SW05,SW5  
.EQUIV SW04,SW4  
.EQUIV SW03,SW3  
.EQUIV SW02,SW2  
.EQUIV SW01,SW1  
.EQUIV SW00,SW0

.\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

100000  
040000  
020000  
010000  
004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
000004  
000002  
000001

BIT15= 100000  
BIT14= 40000  
BIT13= 20000  
BIT12= 10000  
BIT11= 4000  
BIT10= 2000  
BIT09= 1000  
BIT08= 400  
BIT07= 200  
BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3

MAINDEC-11-DZVTH-A  
DZVTH.P11

MACY11 27(732)  
BASIC DEFINITIONS

20-SEP-76 10:22 PAGE 3

SEQ 0014

113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125

000004  
000010  
000014  
000014  
000014  
000020  
000024  
000030

.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0

.\*BASIC "CPU" TRAP VECTOR ADDRESSES

ERRVEC= 4 : TIME OUT AND OTHER ERRORS  
RESVEC= 10 : RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC= 14 : "T" BIT  
TRTVEC= 14 : TRACE TRAP  
BPTVEC= 14 : BREAKPOINT TRAP (BPT)  
IOTVEC= 20 : INPUT/OUTPUT TRAP (IOT) \*\*SCOPE\*\*  
PWRVEC= 24 : POWER FAIL  
EMTVEC= 30 : EMULATOR TRAP (EMT) \*\*ERROR\*\*

```

126      000034      TRAPVEC=34      :D02- TRAP
127      000060      TKVEC= 60      :TTY KEYBOARD VECTOR
128      000054      TFVEC= 64      :TTY PRINTER VECTOR
129      000240      PIPQVEC=240   :PROGRAM INTERRUPT REQUEST VECTOR
130
131      .SBTTL TRAP CATCHER
132
133      000000      .=0
134      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
135      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
136      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
137
138      000174      000000      .=174      DISPREG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
139      000176      000000      SWREG: .WORD 0      ;; SOFTWARE SWITCH REGISTER
140
141      000200      000137      002230      START: JMP AUTO      ;USE AUTO SELECTION OF UNITS
142      000204      000137      002262      MSTRT: JMP MANS      ;ALLOW OPERATOR SELECTION OF UNITS/TESTS
MAINDEC-11-DZVTH-A      MACY11 27(732)      20-SEP-76 10:22 PAGE 4
DZVTH.P11      TRAP CATCHER

```

SEQ 0015

```

143      ;*****
144
145      .SBTTL COMMON TAGS
146
147      ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
148      ;*USED IN THE PROGRAM.
149
150      001100      .=1100
151      001100      SCMTAG:      ;START OF COMMON TAGS
152      001100      000000      SPASS: .WORD 0      ;CONTAINS PASS COUNT
153      001102      000      STSTNM: .BYTE 00      ;CONTAINS THE TEST NUMBER
154      001103      000      SERFLG: .BYTE 00      ;CONTAINS ERROR FLAG
155      001104      000000      SICNT: .WORD 00      ;CONTAINS SUBTEST ITERATION COUNT
156      001106      000000      SLPADR: .WORD 00      ;CONTAINS SCOPE LOOP ADDRESS
157      001110      000000      SLPERR: .WORD 00      ;CONTAINS SCOPE RETURN FOR ERRORS
158      001112      000000      SERTTL: .WORD 00      ;CONTAINS TOTAL ERRORS DETECTED
159      001114      000      SITEMB: .BYTE 0      ;CONTAINS ITEM CONTROL BYTE
160      001115      001      SERMAX: .BYTE 1      ;CONTAINS MAX. ERRORS PER TEST
161      001116      000000      SERAPC: .WORD 0      ;CONTAINS PC OF LAST ERROR INSTRUCTION
162      001120      000000      SGOADR: .WORD 0      ;CONTAINS ADDRESS OF 'GOOD' DATA
163      001122      000000      SBDADR: .WORD 0      ;CONTAINS ADDRESS OF 'BAD' DATA
164      001124      000000      SGDDAT: .WORD 0      ;CONTAINS 'GOOD' DATA
165      001126      000000      SBDDAT: .WORD 0      ;CONTAINS 'BAD' DATA
166      001130      000000      .WORD 0      ;RESERVED--NOT TO BE USED
167      001132      000000      .WORD 0
168      001134      000000      .WORD 0
169      001136      177570      SWR: .WORD DSWR      ;ADDRESS OF SWITCH REGISTER
170      001140      177570      DISPLAY: .WORD DDISP      ;ADDRESS OF DISPLAY REGISTER
171      001142      177560      STKS: 177560      ;TTY KBD STATUS
172      001144      177562      STKB: 177562      ;TTY KBD BUFFER
173      001146      177564      STPS: 177564      ;TTY PRINTER STATUS REG. ADDRESS
174      001150      177566      STPB: 177566      ;TTY PRINTER BUFFER REG. ADDRESS
175      001152      000      SNULL: .BYTE 0      ;CONTAINS NULL CHARACTER FOR FILLS
176      001153      002      SFILLS: .BYTE 2      ;CONTAINS # OF FILLER CHARACTERS REQUIRED
177      001154      012      SFILLC: .BYTE 12      ;INSERT FILL CHARS. AFTER A "LINE FEED"
178      001155      000      STPFLG: .BYTE 0      ;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
179      001156      000000      STIMES: 0      ;MAX. NUMBER OF ITERATIONS
180      001160      000000      SESCAPE: 0      ;ESCAPE ON ERROR ADDRESS
181      001162      177637      000377      SBELL: .ASCIZ <207><377><377>      ;CODE FOR BELL
182      001166      077      SQUES: .ASCII '?'      ;QUESTION MARK
183      001167      015      SCRLF: .ASCII <15>      ;CARRIAGE RETURN
184      001170      000012      SLF: .ASCIZ <12>      ;LINE FEED
MAINDEC-11-DZVTH-A      MACY11 27(732)      20-SEP-76 10:22 PAGE 5
DZVTH.P11      COMMON TAGS

```

SEQ 0016

# E02

\*\*\*\*\*

## .SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;:POINTS TO THE ERROR MESSAGE  
;\* DH ;:POINTS TO THE DATA HEADER  
;\* DT ;:POINTS TO THE DATA  
;\* DF ;:POINTS TO THE DATA FORMAT

### SERRTB:

;GENERAL ESCAPE SEQUENCE ERROR MESSAGE

EM1 ;AN ESCAPE SEQUENCE TO VT61 FAILED.  
DH1 ;TEST#,ERROR PC,2 SEQUENCE BYTES,2 SEQUENCE BYTES.  
DT0  
DF0

;RECEIVE STATUS ERROR MESSAGE

EM2 ;RECEIVE STATUS ERROR  
DH2 ;ADDRESS,STATUS ,ERR. BITS,CHAR.  
DT2  
DF0

;RECIEVE SOFTWARE STATUS ERROR MESSAGE.

EM3 ;SFTWARE (SIAT) STATUS ERROR  
DH3 ;PASS#,TEST#,GOOD STATUS,RECEIVED STATUS  
DT4  
DF6

;DATA ERROR

EM4 ;DATA EXPECTED DOES NOT MATCH RECEIVE DATA.  
DH4 ;TEST#,REC.CNT.,EXPECTED DATA, RECEIVE DATA  
DT5  
DF0

;RECEIVE BYTE COUNT ERROR

EM5 ;BYTES EXPECTED DOES NOT EQUAL BYTES RECEIVED.  
DH5 ;BYTES EXPECTED, BYTES RECEIVED  
DT1  
DF2

;GENERAL DIRECT CURSOR ADDRESS FAILURE

EM6 ;CURSOR POSITION ERROR

DH6 ;GD LINE, GD COL., BD LINE, BAD COL.  
DT2  
DF3

185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244

001172

001172 023201  
001174 023266  
001176 001422  
001200 001442

001202 023331  
001204 023361  
001206 001452  
001210 001442

001212 023420  
001214 023461  
001216 001500  
001220 001543

001222 023530  
001224 023574  
001226 001512  
001230 001442

001232 023642  
001234 023721  
001236 001434  
001240 001450

001242 023752

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 6  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0017

245			;DIRECT CURSOR ADDRESS ERROR
246			
247	001252	024052	EM7 ;DIRECT CURSOR ADDRESS ERROR
248	001254	024152	DH10 ;PASS#,TEST#,BD. ROW,BD. COL.
249	001256	001500	DT4
250	001260	001543	DF6
251			
252			
253			;LAST TEST-SELF TEST FAILED
254			
255	001262	024354	EM10 ;VT61 FAILED SELF-TEST FUNCTION
256	001264	024723	DH11 ;CSR, VECTOR
257	001266	001434	DT1
258	001270	001446	DF1
259			
260			;VT61 FAIL/HUNG ERROR MESSAGE
261	001272	024211	EM11 ;LAST TRANSMISSION TO VT61 CAUSED VT61 TO FAIL/HANG
262	001274	024115	DH7 ;PASS#,TEST#,ERROR PC
263	001276	001464	DT3
264	001300	001534	DF4
265			
266			;GENERAL TEST FAILURE-PRECEEDS DATA/POSITION ERROR
267			
268	001302	024277	EM12 ;VT61 UNDERR TEST FAILED-ERROR DATA FOLLOWS
269	001304	024115	DH7 ;PASS#,TEST#,ERROR PC.
270	001306	001464	DT3
271	001310	001534	DF4
272			
273			;RECEIVE CHECKSUM ERROR
274			
275	001312	024530	EM13 ;VT61 RECEIVER CHECKSUM ERROR
276	001314	024415	DH12 ;PASS#,TEST#,GD.CKSUM,BD CKSUM
277	001316	001500	DT4
278	001320	001543	DF6
279			
280			;TRANSMITTER CHECKSUM ERROR
281			
282	001322	024577	EM14 ;VT61 TRANSMITTER CHECKSUM ERROR
283	001324	024415	DH12
284	001326	001500	DT4
285	001330	001543	DF6
286			
287			
288			
289			;XOFF FAILED TO HALT BLOCK XMIT
290			
291	001332	025016	EM15 ;XOFF TO VT61 FAILED TO HALT BLOCK XMIT
292	001334	025533	DH13 ;PASS,TEST,VSTAT
293	001336	001524	DT6
294	001340	001534	DF4
295			
296			;XON FAILED TO RESTART BLOCK XMIT
297			
298	001342	025067	EM16 ;XON TO VT61 FAILED TO RESTART BLOCK XMIT
299	001344	025533	DH13
300	001346	001524	DT6
301	001350	001534	DF4
302			
303			;NO XON AFTER UNIT WAS RESET
304			
305	001352	025142	EM17 ;NO XON AFTER UNIT WAS RESET.

G02 ;PASS#,TEST#,ERROR PC

306	001354	024115				DH7	
307	001356	001524				DT6	
308	001360	001534				DF4	
309							
310							;PERIPHERAL ABORT ERROR
311							
312	001362	025220				EM20	;LAST PERIPHERAL OPERATION ABORTED.
313	001364	025565				DH14	;PASS,TEST,ERROR PC, VSTAT
314	001366	001500				DT4	
315	001370	001543				DF6	
316							
317							;CANT CLEAR PERIPHERAL ABORT FLAG.
318							
319	001372	025264				EM21	;COULD NOT CLEAR LAST ABORT FLAG.
320	001374	025565				DH14	
321	001376	001500				DT4	
322	001400	001543				DF6	
323							
324							;MAINTENANCE MODE DID NOT FORCE A SOM/EOM.
325							
326	001402	025327				EM22	;SOM OR EOM NOT REC. IN MAINT. MODE.
327	001404	023461				DH3	;PASS#,TEST#,EXP.STAT, ACT.STAT
328	001406	001500				DT4	
329	001410	001543				DF6	
330							
331							;LINE FEED OR CURSOR RIGHT AT ROW 23 DID NOT CAUSE A SCROLL.
332							
333	001412	025415				EM23	;NO SCROLL FROM LINE FEED OR CURSOR RIGHT.
334	001414	024115				DH7	
335	001416	001524				DT6	
336	001420	001534				DF4	
337							
338	001422	002226	001116	001124	DT0:	.WORD	TSTNM,\$ERRPC,\$GDDAT,\$BDDAT,0
339	001430	001126	000000				
340	001434	001124	001126	000J00	DT1:	.WORD	\$GDDAT,\$BDDAT,0
341	001442	000	000	000	DF0:	.BYTE	0,0,0,0
342	001445	000					
343	001446	000	000		DF1:	.BYTE	0,0
344							
345	001450	001	001		DF2:	.BYTE	1,1 ;DECIMAL TYPE
346							
347	001452	001120	001124	001122	DT2:	.WORD	\$GDADR,\$GDDAT,\$BDADR,\$BDDAT,0
348	001460	001126	000000				
349	001464	001100	002226	001116	DT3:	.WORD	\$PASS,TSTNM,\$ERRPC,0
350	001472	000000					
351	001474	001	001	001	DF3:	.BYTE	1,1,1,1
352	001477	001					

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 8  
 DZVTH.P11 ERROR POINTER TABLE

SEQ 0019

353	001500	001100	002226	001124	DT4:	.WORD	\$PASS,TSTNM,\$GDDAT,\$BDDAT,0
354	001506	001126	000000				
355	001512	002226	001120	001124	DT5:	.WORD	TSTNM,\$GDADR,\$GDDAT,\$BDDAT,0
356	001520	001126	000000				
357	001524	001100	002226	001120	DT6:	.WORD	\$PASS,TSTNM,\$GDADR,0
358	001532	000000					
359	001534	001	000	000	DF4:	.BYTE	1,0,0
360	001537	000	000	001	DF5:	.BYTE	0,0,1,1
361	001542	001					
362	001543	001	000	000	DF6:	.BYTE	1,0,0,0
363	001546	000					
364		001550				.EVEN	
365							;INSTRUCTION DEFINITIONS
366		022626			POP2SP	=22626	



367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403

024646

PUSH2SP =24646

# H02

\*\*\*\*\*  
;DEFINITION SOFTWARE STATUS(VSTAT) REGISTER BITS  
\*\*\*\*\*

100000	RXOFF	=100000	;SET FOR XOFF. CLEARED FOR XON
040000	RSOM	=040000	;SET FOR SOM (START OF MESSAGE).
020000	REOM	=020000	;SET FOR EOM (END OF MESSAGE).
010000	PABRT	=010000	;SET FOR A PERIPHERAL ABORT.
004000	RSTT	=004000	;SET FOR RECEIVE STATUS ERROR.
002000	CKSUM	=002000	;SET TO CALCULATE 61 REC. CHECKSUM
001000	EPL	=001000	;SET WHEN END OF LINE DETECTED
000400	ESC	=000400	;SET WHEN OCTAL 33 RECEIVED.
000200	XMKIL	=000200	;SET WHEN TRANSMIT KILLED.
000100	TXSUM	=000100	;SET TO CALCULATE 61 XMIT CHECKSUM
000040	REVID	=000040	;SET WHEN REVERSE VIDEO MODE RECEIVED.
000020	COMGP	=000020	;SET TO CONVERT REC. CHAR. BY -137.
000004	CURPOS	=000004	;SET WHEN CURSOR POS. RECEIVED
000002	TRMID	=000002	;SET WHEN TERMINAL I.D. RECEIVED.
000001	XMDNE	=000001	;SET UPON TRANSMIT COMPLETE

\*\*\*\*\*  
;DEFINITION OF DL11 CONTROL BITS  
\*\*\*\*\*

000200	RECDN	=200	
100000	DSCHNG	=100000	
000100	RDENA	=000100	
100000	RERR	=100000	
040000	RORUN	=40000	
020000	RFMER	=20000	
010000	RPAR	=10000	
000200	TRDY	=00200	
000100	TENA	=00100	
000004	MAINT	=00004	
000104	TCOMB	=00104	;COMBINATION INTERRUPT ENABLE AND MAINT.

404  
405 003600  
406 003601  
407  
408  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 ERROR POINTER TABLE

TOTCH =1920. ;TOTAL CHARACTERS ON SCREEN  
TOTC1 =1921. ;TOTAL SCREEN +1  
;\*\*\*\*\*  
;FOLLOW ARE DL11 ADDRESS AND VECTOR STORAGE TABLES  
20-SEP-76 10:22 PAGE 9

SEQ 0020

```

409 ;*****
410 001550 000020 VVECT: .BLKW 20 ;GOOD DL11 VECTOR TABLE
411 001610 000020 DLTBL: .BLKW 20 ;GOOD DL11 ADDRESS TABLE
412 001650 000020 INTAB: .BLKW 20 ;TABLE OF POSSIBLE DL11 ADDRESSES
413
414
415 ;CURRENT POINTERS FOR ADDRESSES AND VECTORS
416 001710 000000 VECPT: .WORD ;VECTOR INDEX
417 001712 000000 DLTPT: .WORD ;ADDRESS INDEX
418 ;ADDRESS TABLES FOR DL11 INTERFACES
419 001714 176500 STRTAB: .WORD 176500 ;DL11A/B
420 001716 175610 .WORD 175610 ;DL11 C/D/E
421 001720 000000 .WORD 0
422 001722 176676 ENDTAB: .WORD 176676 ;DL11 A/B
423 001724 176170 .WORD 176170 ;DL11 C/D/E
424 001726 000000 .WORD 0 ;END OF LIST MARKER
425 ;*****
426 ;VT61 ADDRESSES IN TABLE REFLECT UNIT UNDER TEST
427 ;*****
428 001730 000000 VRCSR: .WORD 0
429 001732 000000 VRBUF: .WORD 0 ;RECEIVE DATA BUFFER
430 001734 000000 VXCSR: .WORD 0 ;XMITTER CSR
431 001736 000000 VXBUF: .WORD 0 ;XMITTER DATA BUFFER
432 001740 000000 VECT: .WORD 0 ;VECTOR FOR UNIT UNDER TEST
433 001742 000000 CRCSR: .WORD 0 ;CONSOLE RECEIVE CSR
434 001744 000000 CRBUF: .WORD 0 ;CONSOLE DATA BUFFER
435
436
437 ;*****
438 ;TABLE OF VT61 COMMAND AND SEQUENCES
439 ;*****
440
441 .BEL =007
442 001746 000007 BEL: .WORD 007 ;BELL
443 000015
444 001750 000015 CARRT: .WORD 015 ;CARRIAGE RETURN
445 000012
446 001752 000012 LNFED: .WORD 012 ;LINE FEED
447 000011
448 001754 000011 TAB: .WORD 011 ;TAB
449 ;*****
450 001756 000001 .WORD 01 ;TABLE DELIMITER (ESCN)
451 ;*****
452
453 .CHOM =110
454 001760 000110 CHOM: .WORD 110 ;HOME CURSOR H
455
456 .CRT =103
457 001762 000103 CRT: .WORD 103 ;CURSOR RIGHT C
458
459 .CDWN =102
460 001764 000102 CDWN: .WORD 102 ;CURSOR DOWN B
461
462 .CLFT =104
463 001766 000104 CLFT: .WORD 104 ;CURSOR LEFT D

```

465		000101	.CUP	=101			
466	001770	000101	CUP:	.WORD	101		;CURSOR UP A
467							
468		000112	.EOS	=112			
469	001772	000112	EOS:	.WORD	112		;ERASE TO END OF SCREEN J
470							
471							
472		000127	.EPNT	=127			
473	001774	000127	EPNT:	.WORD	127		;ENABLE PRINT MODE. W
474		000130	.DPNT	=130			
475	001776	000130	DPNT:	.WORD	130		;DISABLE PRINT MODE X
476							
477							;*****
478	002000	000002		.WORD	2		;TABLE DELIMITER (ESCO)
479							;*****
480							
481							
482		000101	.EMAIN	=101			
483	002002	000101	EMAIN:	.WORD	101		;ENTER MAINTENANCE MODE A
484		000141	.DMAIN	=141			
485	002004	000141	DMAIN:	.WORD	141		;EXIT MAINTENANCE MODE SA
486							
487		000105	.LKKB	=105			
488	002006	000105	LKKB:	.WORD	105		;LOCK KEYBOARD E
489		000145	.UNLKKB	=145			
490	002010	000145	UNLKKB:	.WORD	145		;UNLOCK KEYBOARD SE
491							
492		000103	.DRECT	=103			
493	002012	000103	DRECT:	.WORD	103		;ENABLE LINEAR MODE C
494							
495		000133	.CLRCK	=133			
496	002014	000133	CLRCK:	.WORD	133		;CLEAR RECEIVER CHECKSUM I
497							
498		000134	.CLTCK	=134			
499	002016	000134	CLTCK:	.WORD	134		;CLEAR TRANSMITTER CHECKSUM
500							
501							
502		000112	.EEMP	=112			
503	002020	000112	EEMP:	.WORD	112		;ENABLE REVERSE VIDEO J
504		000152	.DEMP	=152			
505	002022	000152	DEMP:	.WORD	152		;DISABLE REVERSE VIDEO SJ
506							
507		000137	.IABT	=137			
508	002024	000137	IABT:	.WORD	137		;INITIALIZE ABORT FLAG -
509							
510							;*****
511	002026	000003		.WORD	3		;TABLE DELIMITER (ESCAPE P)
512							;*****
513							
514		000131	.EAPNT	=131			
515	002030	000131	EAPNT:	.WORD	131		;ENABLE AUTO PRINT MODE Y
516		000171	.DAPNT	=171			
517	002032	000171	DAPNT:	.WORD	171		;DISABLE AUTO PRINT MODE SY
518							
519		000111	.EINST	=111			
520	002034	000111	EINST:	.WORD	111		;ENABLE INSERT I

757

521 000151 .ERPL =151

K02 ;ENABLE REPLACE SI

```

522 002036 000151 ERPL: .WORD 151
523
524
525 ;*****
526 002040 000004 .WORD 4 ;TABLE DELIMITER (I/O)
527 ;*****
528
529 .DCRAD =054433
530 002042 054433 DCRAD: .WORD 054433 ;DIRECT CURSOR ADDRESSING
531 067467 .R23C79 =067467
532 002044 067467 R23C79: .WORD 067467 ;CURSOR TO LOWER RIGHT
533 002046 000000 .WORD 0
534
535 002050 047433 RCUR: .WORD 047433 ;DIRECT CURSOR ADDRESSING
536 000131 .Y =131
537 000131 .RDCUR =00131
538 002052 000131 RDCUR: .WORD 00131 ;READ CURSOR POSITION Y
539 002054 000000 .WORD 0
540
541 .O =117
542 002056 047433 ESCO: .WORD 047433 ;ESCAPE 0
543 000126 .XMTAL =000126
544 002060 000126 XMTAL: .WORD 000126 ;TRANSMIT ALL V
545 002062 000000 .WORD 0
546
547 002064 047433 .WORD 047433 ;ESCAPE 0
548 000127 .TCUCH =127
549 002066 000127 TCUCH: .WORD 127 ;XMIT CHARACTER AT CURSOR. W
550 002070 000000 .WORD 0
551
552 002072 047433 .WORD 047433 ;ESCAPE 0
553 000135 .TXRCK =135
554 002074 000135 TXRCK: .WORD 135 ;XMIT RECIEVER CHECKSUM I
555 002076 000000 .WORD 0
556
557 002100 047433 .WORD 047433 ;ESCAPE 0
558 000136 .TXTCK =136
559 002102 000136 TXTCK: .WORD 136 ;XMIT TRANSMITTER CHECKSUM
560 002104 000000 .WORD 0
561
562 002106 147433 .WORD 147433 ;ESCAPE 0
563 000140 .RABT =140
564 002110 000140 RABT: .WORD 140 ;READ THE ABORT FLAG. \
565 002112 000000 .WORD 0
566
567 ;*****
568 002114 177777 .WORD -1 ;END OF TABLE TERMINATOR
569 ;*****
570
571 ;*****
572 ;PERIPHERAL COMMANDS
573 ;*****
574
575 .CPYSC =135 ;COPY SCREEN J
576 000136 .ENAC =136 ;ENABLE AUTO COPY MODE ESC ↑

```

MAINDEC-11-DZVTH-A MACY11 27(732)
DZVTH.P11 ERROR POINTER TABLE

20-SEP-76 10:23 PAGE 12

SEQ 0023

```

577 000137 .DISAC =137 ;DISABLE AUTO COPY MODE ESC -
578 000150 .PSCRN =000150 ;PRINT THE SCREEN H/SH
579
580
581 ;*****
582 ;ESCAPE CODE EQUIVALENCES AND IDENTIFIERS

```

\*\*\*\*\*L02\*\*\*\*\*

583					
584					
585		000033	.ESC	=033	;PRIMARY ESCAPE CODE.
586		000120	.P	=120	
587	002116	050033	ESCP:	.WORD 050033	;ESCAPE P
588		000124	.TSTER	=124	
589	002120	000124	TSTER:	.WORD 124	;TEST TERMINAL(ESC O T)
590		002042	ESCYI	=DCRAD	;ESCYI EQUALS DCRAD/DCRADI
591		000057	SLSH	=000057	;SLASH CODE FOR TERMINAL IDENT ESC.
592		000106	CKGP	=106	;ENABLE REC.TO SUB 137 FROM ALL REC DATA
593		000107	NCKGP	=107	;ENABLE NORMAL RECEIVED DATA.
594		000171	CPABRT	=171	;COPIER ABORT
595		000172	PRABRT	=172	;PRINTER ABORT
596		000170	NABRT	=170	;NO ABORT SX
597	002122	000000	IDENT:	.WORD 0	;VT6! IDENT CODE
598		002056	ESCOI	=ESCO	
599		002116	ESCPI	=ESCP	
600		002124	ESCZI	=ESCZ	
601		055033	.ESCZ	=055033	
602	002124	055033	ESCZ:	.WORD 055033	;OCTAL EQUIV. OF ESZ SEQUENCE
603		000122	.RESET	=122	
604	002126	000122	RESET:	.WORD 122	;VT6! INITIALIZE R
605					
606	002130	000033	ESCN:	.WORD 000033	;ESCAPE N-FLAG
607	002132	020041	R01C00:	.WORD 020041	;ROW1,COL. 0
608	002134	032041	R01C20:	.WORD 032041	;ROW01,COLUMN 20
609	002136	020066	R22C00:	.WORD 020066	;ROW22,COL.00
610	002140	020054	R12C00:	.WORD 020054	;ROW 12,COLUMN 00
611		020067	.R23C00	=020067	
612	002142	020067	R23C00:	.WORD 020067	;ROW23,COL.00
613		025440	.R00C11	=025440	
614	002144	025440	R00C11:	.WORD 025440	;ROW,COL.11
615		032040	.R00C20	=032040	
616	002146	032040	R00C20:	.WORD 032040	;ROW 0,COLUMN 20
617	002150	024040	R00C08:	.WORD 024040	;ROW 00,COLUMN 8
618	002152	020040	CUI.ME:	.WORD 020040	;OCTAL EQUIV. OF CURSOR HOME.
619	002154	067440	R00C80:	.WORD 067440	;ROW 0,COLUMN 80.
620	002156	067067	R23C78:	.WORD 067067	;ROW 23,COL. 78.
621		000040	.R00	=40	;ROW 0
622		000041	.R01	=41	;ROW 1
623		000054	.R12	=54	;ROW 12
624		000066	.R22	=66	;ROW 22
625		000067	.R23	=67	;ROW 23
626		000040	.C00	=40	;COLUMN 0
627		000043	.C03	=43	;COL. 3
628		000050	.C08	=50	;COL. 8
629		000053	.C11	=53	;COL. 11
630		000064	.C20	=64	;COL. 20
631		000065	.C21	=65	;COL. 21
632		000110	.C40	=110	;COL. 40

MAINDEC-11-DZVTH-M MACY11 27(732)  
DZVTH.P11 ERROR POINTER TABLE

20-SEP-76 10:22 PAGE 13

SEQ 0024

633		000157	.C79	=157	;COL. 79
634					
635					*****
636					;TEMPORARY STORAGE LOCATIONS AND
637					;SPECIAL RECEIVE CODE EQUIVALENCES.
638					*****
639		000002	SOM	=02	;START OF MESSAGE
640		000004	EOM	=04	;END OF MESSAGE
641		000023	XOFF	=23	;TURN OFF TRANSMISSION
642		000021	XON	=21	;TURN ON TRANSMISSION
643	002160	000000	CHRD:	.WORD 0	;STORAGE FOR SINGLE CH. READ

M02

644 002162 000000  
645 002164 000000  
646 002166 000000  
647 002170 003000  
648 002172 000000  
649 002174 000000  
650 002176 000000  
651 002200 000012  
652 002202 000001  
653 002204 000000  
654 002206 000000  
655 002210 000000  
656 002212 000000  
657 002214 000000  
658 002216 000000  
659 002220 000000  
660 002222 000000  
661 002224 000000  
662 002226 000000

SVER1: .WORD  
SVER2: .WORD  
ZERO: .WORD 0  
TYPE: .WORD 3000  
TSTPTR: .WORD 0  
MODE: .WORD 0  
FTLCNT: .WORD 0  
ALWCNT: .WORD 10.  
ONE: .WORD 1  
TOFDD: .WORD  
BUBCT: .WORD  
TPREG: 0  
PRESC: .WORD  
ESSEQ: .WORD  
DLAY: .WORD  
ROSVE: .WORD  
VSTAT: .WORD 0  
BLKM: .WORD 0  
TSTNM: .WORD 0

; TEMP. STORAGE R1.  
; TEMP. STORAGE R2.  
; MUST BE LEFT AS ZERO.  
; TYPE 6 OCTAL CHAR-NO ZEROS  
; TEST POINTER IN MANUAL SELECT MODE  
; BYTED=TESTING MODE, BYTE1=INTERFACE TYPE  
; COUNT OF INCOMPLETE XMIT.  
; \* OF ALLOWABLE INCOMPLETE XMIT.  
  
; PRIMARY ESC COMMAND  
; SEQUENCE ASSEMBLY AREA  
  
; TEMP STORAGE FOR RO ONLY.  
  
; FLAG LOCATION FOR BLOCK MODE XMIT.  
; DISPLAY STORAGE FOR TEST NUMBER.

\*\*\*\*\*  
; AUTOMATIC SELECTION OF UNITS. TESTS 1 THROUGH 33 WILL BE  
; REPITIVELY EXECUTED FOR ALL UNITS.  
\*\*\*\*\*

670 002230 005037 002174  
671 002234 000137 011604  
672 002240 004037 012122  
673 002244 004037 012242  
674 002250 004037 012620  
675 002254 000137 002502  
676 002260 000767

AUTO: CLR MODE ; ZERO THE MODE SWITCH  
JMP SETA ; DO VECTOR SETUP  
AUTOA: JSR RO, TRPVEC ; GO FIND GOOD DL11S  
JSR RO, CDEV ; CHECK DL11S FOUND  
JSR RO, INITA ; INSURE VT61S ON DL11  
JMP MODCK ; VT61 PRESENT -BEGIN TESTING  
BR AUTOA ; NO VT61 FOUND LOOP IN CHECKING

\*\*\*\*\*  
; MANUAL UNIT AND TEST SELECTION. UNITS CAN BE  
; SELECTED VIA CONSOLE OR AUTO SELECTION CAN  
; BE UTILIZED. TESTS ENTERED VIA CONSOLE WILL  
; BE EXECUTED IN THE ORDER ENTERED.  
\*\*\*\*\*

687 002262 012737 000001 002174  
688 002270 000137 011604  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 ERROR POINTER TABLE

MANS: MOV #1, MODE ; SET MODE TO MANUAL SELECT.  
JMP SETA ; GO SET UP CONSTANTS

20-SEP-76 10:22 PAGE 14

SEQ 0025

689 002274 104400 023051  
690 002300 004037 012122  
691 002304 012703 001650  
692 002310 005002  
693  
694 002312 004037 017406  
695 002316 120127 000054  
696 002322 001002  
697 002324 010223  
698 002326 000770  
699 002330 120137 001752  
700 002334 001022  
701 002336 005702  
702 002340 001411  
703 002342 010223  
704 002344 013723 002166

MANSA: TYPE DMANA  
JSR RO, TRPVEC ; FIND GOOD DL11'S  
MOV #INTAB, R3  
BLDADD: CLR R2  
  
BLDADA: JSR RO, GTNUM ; GET A KEYBOARD INPUT  
CMPB R1, #54 ; CHAR. = COMMA?  
BNE 1\$ ; NO  
MOV R2, (R3)+ ; YES - STORE THIS ADDRESS  
BR BLDADD ; AND LOOK FOR ANOTHER ADDRESS  
1\$: CMPB R1, LNFED ; CHAR. = LINE FEED?  
BNE 3\$ ; NO  
TST R2 ; ANY ENTRIES CREATED?  
BEQ 2\$ ; NO USE AUTO SELECTION OF UNITS  
MOV R2, (R3)+ ; YES STORE LAST ADDRESS,  
MOV ZERO, (R3)+ ; SET ATERMINATOR IN TABLE



N02

```

705 002350 004037 012242 JSR RO,CDEV ;CHECK DL11 ON VT 61 SELECTED
706 002354 005737 001610 TST DLTBL ;ANY DL11S GOOD?
707 002360 001745 DEQ MANSR ;NO-BACK TO SQUARE ONE
708 002362 000412 BR BLDSTST ;YES- GO GET TESTS
709 002364 004037 012242 2$: JSR RO,CDEV ;CHECK DL11'S
710 002370 004037 012220 JSR RO,INITA ;VERIFY DL11 HAVE VT61 ATTACHED
711 002374 000137 002410 JMP BLDSTST ;BEGIN TEST SELECTION
712 002400 000735 BR MANSR ;NO UNIT FOUND-LOOP
713 002402 004037 017342 3$: JSR RO,OCTBIN ;KEEP BUILDING ADDRESS
714 002406 000741 BR BLDADA

```

```

715
716 002410 104400 023151 BLDSTST: TYPE ,DMANB ;TYPE 2ND PART OF MANUAL MESSAGE
717 002414 012703 001650 MOV #INTAB,R3 ;USE INTAB AS TEST # STORAGE.
718 002420 005004 CLR R4 ;CLEAR TEST COUNTER
719 002422 005002 11$: CLR R2 ;CLEAR ASSEMBL WORD
720 002424 004037 017406 10$: JSR RO,GTNUM ;GET A NUMERIC CHAR.
721 002430 120127 000054 CMPB R1,#54 ;CHAR.=COMMA?
722 002434 001006 BNE 1$ ;NO
723 002436 110223 MOVB R2,(R3)+ ;YES STORE A TEST #
724 002440 005204 INC R4 ;AND INCREMENT TEST COUNT.
725 002442 020437 000040 CMP R4,32. ;COUNT =32?
726 002446 001415 BEQ MODCK ;YES ACCEPT NO MORE ENTRIES.
727 002450 000764 BR 11$ ;NO KEEP LOOKING
728 002452 120137 001752 1$: CMPB R1,LFED ;CHAR. = LINE FEED?
729 002456 001006 BNE 2$ ;NO
730 002460 110223 MOVB R2,(R3)+ ;LOAD THE LAST TEST
731 002462 105013 CLRB (R3) ;AND INSERT TEST TABLE TERMINATOR
732 002464 112737 000001 002174 MOVB #1,MODE ;SET MODE SWITCH TO MANUAL
733 002472 000403 BR MODCK ;AND BEGIN TESTING.

```

```

734
735 002474 004037 017342 2$: JSR RO,OCTBIN ;CONVERT CHAR.
736 002500 000751 BR 10$
737
738 ;*****
739 ;THIS ROUTINE LOOKS FOR THE OPERATIONAL MODE REQUESTED AND
740 ;SELECTS THE NEXT UNIT TO BE TESTED.
741
742 ;MODE 0 = ACCEPTANCE TYPE TEST
743 ;MODE 1 = OPERATOR SELECTION OF UNITS AND SEQUENCE OF TESTS.
744 ;*****

```

MAINDEC-11-DZVTH-A MACY11 27(732)  
 DZVTH.P11 ERROR POINTER TABLE

20-SEP-76 10:22 PAGE 15

SEQ 0026

```

745
746 002502 012737 001610 001712 MODCK: MOV #DLTBL,DLTPT ;INITIAL SETUP OF ADDRESS
747 002510 012737 001550 001710 MOV #VVECT,VECPTR ;AND VECTOR POINTERS.
748 002516 012701 001730 MODCA: MOV #VRCR,R1 ;LOAD ADDRESS DESTINATION
749 002522 013702 001712 MOV DLTPT,R2 ;LOAD CURRENT ADDRESS POINTER
750 002526 017703 177156 MOV #VECPTR,R3 ;LOAD CURRENT VECTOR POINTER
751 002532 005712 TST (R2) ;ALL UNITS CHECKED?
752 002534 001013 BNE 1$ ;NO - CONTINUE
753 002536 005737 002174 TST MODE ;CHECK MODE
754 002542 001002 BNE 10$
755 002544 000137 002240 JMP AUTOA ;GO RESTART AUTO MODE
756 002550 105777 177416 10$: TSTB #TSTPTR ;MANUAL LOOP REQUESTED?
757 002554 100001 BPL 2$ ;NO
758 002556 000751 BR MODCK ;YES-RESTART COMPLETE TEST.
759 002560 000137 002274 2$: JMP MANSR ;GO RESTART MANUAL MODE
760 002564 004037 013040 1$: JSR RO,LOAD ;NO-LOAD NEXT ADDRESSES
761 002570 010337 001740 MOV R3,VECT ;STORE VECT. OF UNIT UNDER TEST
762 002574 012723 013746 MOV #INTRC,(R3)+ ;YES - NOW SET UP RECEIVE VECTOR
763 002600 012723 000340 MOV #340,(R3)+ ;AND SET RECEIVER PSW TO 7
764 002604 012723 014670 MOV #INTXM,(R3)+ ;SET IP TRANSMIT VECTOR
765 002610 012723 000340 MOV #340,(R3)+ ;NO S.T PSW TO 7.

```

B03

```

766 002614 005046 CLR -(SP) ;CLEAR THE PSW,LS:11 STYLE.
767 002616 012746 002624 MOV #1005,-(SP)
768 002622 000002 RTI
769 002624 010237 001712 1005: MOV R2,C_TPT ;SAVE ADDRESS POINTER.
770 002630 012737 030327 014632 MOV #RCALB+477,REBUF ;SET UP END OF BUFFER
771 002636 012737 031027 015140 MOV #TCALB+477,TEBUF
772 002644 012737 027630 014630 MOV #RCALB,RBBUF ;INITIALIZE REC.BUFFER.
773 002652 012737 030330 015136 MOV #TCALB,TBBUF ;INITIALIZE TRANSMIT BUFFER.
774 002660 004037 016136 JSR RO,RESPTR ;RESET INTERRUPT POINTERS.
775 002664 005037 002224 CLR BLKM ;CLEAR BLOCK MODE FLAG.
776 002670 005037 020466 CLR XMZER ;CLEAR ZERO TRANSMIT FLAG
777 002674 005037 002222 CLR VSTAT ;CLEAR ALL INTERRUPT FLAGS
778 002700 004037 015326 JSR RO,ZFLAG ;ISSUE ESC Z TO VT61
779 002704 012637 002122 MOV (SP)+,IDENT ;POP STACK INTO IDENT
780 002710 100002 BPL 11$ ;IF IDENT IS -1,CLEAR IT.
781 002712 005037 002122 CLR IDENT
782 002716 11$: MOV (SP)+,CHRD ;;POP STACK INTO CHRD
783 002716 012637 002160 BNE 11$
784 002722 001375 TYPE ,SCRLF
785 002724 104400 001167 TYPE ,DVUNIT ;ISSUE UNIT UNDER TEST MESSAGE
786 002730 104400 024652 MOV VRCSR,-(SP) ;SAVE VRCSR FOR TYPEOUT
787 002734 013746 001730 ;TYPE THE ADDRESS
788 ;GO TYPE--OCTAL ASCII
789 002740 104402 TYPOS ;TYPE 6 DIGIT(S)
790 002742 006 .BYTE 6 ;TYPE LEADING ZEROS
791 002743 001 .BYTE 1 ;SAVE VECPT FOR TYPEOUT
792 002744 017746 176740 MOV #VECPT,-(SP) ;TYPE THE VECTOR
793 ;GO TYPE--OCTAL ASCII
794 002750 104402 TYPOS ;TYPE 6 DIGIT(S)
795 002752 006 .BYTE 6 ;SUPPRESS LEADING ZEROS
796 002753 000 .BYTE 0 ;SAVE IDENT FOR TYPEOUT
797 002754 013746 002122 MOV IDENT,-(SP) ;TYPE THE IDENT
798 ;GO TYPE--OCTAL ASCII
799 002760 104402 TYPOS ;TYPE 6 DIGITS
800 002762 006 .BYTE 6 ;TYPE 6 DIGITS

```

```

801 002763 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
802 002764 104400 001167 TYPE ,SCRLF ;CARRIAGE RETURN AND LINE FEED
803 002770 032737 000001 002122 BIT #BIT00,IDENT ;UNIT HAVE A COPIER?
804 002776 001402 BEQ 20$ ;NO
805 003000 104400 024771 TYPE ,DCOPYR ;YES-ISSUE COPIER MESSAGE
806 003004 032737 000002 002122 20$: BIT #BIT01,IDENT ;UNIT HAVE A PRINTER?
807 003012 001402 BEQ 21$ ;NO
808 003014 104400 024743 TYPE ,DPTR ;YES-ISSUE PRINTER MESSAGE.
809 003020 062737 000002 001710 21$: ADD #2,VECPT ;LEAVE WITH VECPOINT AT NEXT VECTOR.
810 003026 005037 002176 CLR FTLCNT ;CLEAR COUNT OF FATAL XMIT.
811 003032 012737 031030 031030 MOV #RBBUF,ABUFF ;RESET THE REC. DATA POINTER
812 003040 052777 000100 176662 BIS #RDENA,#VRCSR ;SET THE REC. INT. ENABLE FOR TESTS
813 003046 105737 002174 TSTB MODE ;CHECK TESTING MODE
814 003052 001403 BEQ ASTRT ;AUTO MODE
815 003054 012737 001650 002172 MOV #INTAB,TSTPTR ;LOAD THE INITIAL TEST NUMBER
816
817 ;*****
818 ;*****
819 ;THIS TEST ISSUES ALL ESCAPE SEQUENCES AND
820 ;INSURES THE VT61 HAS NOT FAILED DURING AN
821 ;ESC SEQUENCE BY ISSUING A ESC Z TO FORCE A
822 ;VT61 RESPONSE. THE PURPOSE OF THE TEST IS TO ATTEMPT TO
823 ;INSURE THAT SUBSEQUENT TESTS WILL NOT RESULT IN
824 ;A "HUNG" UNIT. DATA IS NOT EVALUATED.
825 ;*****
826 ;*****

```

C03

ASTRT: \*\*\*\*\*

827	003J62								
828									
829	003062	000004							
830	003064	012737	000001	001156					
831	003072	012737	003100	001106					
832									
833	003100	012701	001746						
834	003104	042777	000100	176616					
835	003112	113737	001102	002226					
836	003120	005037	002212						
837	003124	005004							
838	003126								
839	003126	013746	002166						
840	003132	012702	002212						
841	003136	012103							
842	003140	001405							
843	003142	100535							
844	003144	120327	000004						
845	003150	103442							
846	003152	001471							
847	003154	005704							
848	003156	100472							
849	003160	010337	002214						
850	003164								
851	003164	013746	002214						
852	003170	005704							
853	003172	001402							
854	003174	013746	002212						
855									
856	003200	004037	013322						
MAINDEC-11-DZVTH-A				MACY11 27(732)	35:	JSR	RO,TE5C		;GO TRANSMIT THIS SEQUENCE.
DZVTH.P11				ERROR POINTER TABLE	20-SEP-76	10:22	PAGE 17		
857									
858	003204	005704							
859	003206	100007							
860	003210	012737	000054	017074					
861	003216	004037	017032						
862	003222	005777	176504						
863									
864	003226	004037	015326						
865	003232								
866	003232	012637	002160						
867	003236	123737	002160	002122					
868	003244	001045							
869	003246								
870	003246	012637	002160						
871	003252	001375							
872	003254	000724							
873									
874	003256	120327	000001						
875	003262	001407							
876									
877	003264	120327	000002						
878	003270	001412							
879									
880	003272	120327	000003						
881	003276	001413							
882	003300	000716							
883									
884	003302	012704	000001						
885	003306	013737	002130	002212					
886	003314	000710							
887									

SEQ 0028

003

```

888 003316 013737 002056 002212 2S:  MOV ESCC,2#PRESC ;INSERT ESCC
889 003324 000704          BR      GCMD
890
891 003326 013737 002116 002212 3S:  MOV ESCP,2#PRESC ;INSERT ESCP
892 003334 000700          BR      GCMD
893
894 003336 012704 177777          SPTN:  MOV  #-1,R4 ;SET FLAG INDICATING I/O
895 003342 000675          BR      GCMD ;SEQUENCES
896
897 003344 005703          SEQ4:  TST   R3 ;CHECK IF COMMAND = 0
898 003346 001706          BEQ   INXMT ;YES, COMPLETE SEQUENCE ASSEMBLED
899 003350 110322          MOVB  R3,(R2)+ ;NO - KEEP ASSEMBLING
900 003352 000303          SWAB R3 ;POSITION HIGH ORDER BIT
901 003354 110322          MOVB  R3,(R2)+ ;AND ASSEMBLE IT
902 003356 000667          BR      GCMD ;GET ANOTHER BYTE
903
904 003360 004037 015530          TIERR: JSR   RO,CLREG
905 003364 013737 002212 001124          MOV   PRESC,$GDDAT ;AND INSERT IN ERROR
906 003372 000337 001124          SWAB  $GDDAT ;REASSEMBLE FAILING SEQUENCES
907 003376 013737 002214 001126          MOV   ESSEQ,$BDDAT
908 003404 105737 002215          TSTB  ESSEQ+1 ;IF UPPER BYTE IS CLEAR DO NOT SWAP
909 003410 001402          BEQ   IS
910 003412 000337 001126          SWAB  $BDDAT ;MESSAGE 1
911 003416 104001          IS:   ERROR 1 ;ISSUE ERROR MESSAGE
912 003420 005237 002176          INC   FTLCNT ;INCREMENT FATAL XMIT COUNT.
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 18
DZVTH.P11 ERROR POINTER TABLE
913 003424 023737 002176 002200          CMP   FTLCNT,ALWCNT ;FATAL XMITS EXCEEDED ALLOWED?
914 003432 103003          BHIS  FTEXT1 ;YES-EXIT.
915 003434 000704          BR      POPIT ;CLEAR THE STACK AND TRY ANOTHER COMMAND
916 003436
917 003436 012637 002160          ESTEX: MOV   (SP)+,CHRD ;POP STACK INTO CHRD
918 003442 052777 000100 176260          FTEXT1: BIS  #RDENA,#VRCRSR ;SET THE REC. INT. ENABLE FOR TESTS
919
920 ;*****
921 ;ROUTINE TO INSURE ENTERING MAINTENANCE MODE CAUSES SOM AND
922 ;EOM TO BE APPENDED TO ALL TRANSMITS FROM VT61 UNDER TEST.
923 ;MAINTENANCE MODE IS ENTERED, THEN AN ESCAPE Z SEQUENCE
924 ;IS ISSUED TO THE UNIT AND THE RESULTING TRANSMISSION IS
925 ;CHECKED OF SOM/EOM.
926 ;*****
927
928 ;*****
929 TST2:  SCOPE
930 003452 012737 000005 001156          MOV   #5,$TIMES ;DO 5 ITERATIONS
931 003460 012737 003466 001106          MOV   #CKMNT,$LPADR ;SET SCOPE LOOP ADDRESS
932
933 003466 004037 015146          CKMNT: JSR   RO,RESETV ;RESET THE UNIT AND SETMAINT. MODE.
934 003472 112777 000002 011442          MOVB  #SOM,#TBUFF ;ISSUE START OF MESSAGE.
935 003500 004037 016026          JSR   RO,XMIT1
936 003504 113777 002124 011430          MOVB  ESCZ,#TBUFF
937 003512 004037 016026          JSR   RO,XMIT1 ;SEND AN IDENT REQUEST.
938 003516 113777 002125 011416          MOVB  ESCZ+1,#TBUFF
939 003524 004037 016026          JSR   RO,XMIT1
940 003530 112777 000004 011404          MOVB  #EOM,#TBUFF ;ISSUE END OF MESSAGE.
941 003536 004037 016026          JSR   RO,XMIT1
942 003542 003037 002216          CLR   DLAY ;SET UP SOM DELAY OF 100M.S.
943 003546 032737 040000 002222          IS:   BIT   #RSOM,VSTAT ;RECEIVED THE START OF MESSAGE?
944 003554 001003          BNE   CKEOM ;YES-GO LOOK FOR EOM.
945 003556 005337 002216          DEC   DLAY ;NO-RUN TIMEOUT DELAY
946 003562 001371          BNE   IS ;AND KEEP LOOKING.
947
948 003564 012701 000062          CKEOM: MOV   #50.,R1 ;SET MAX DELAY FOR 500 M.S.

```

SEQ 0029

```

94: 003570 032737 020000 002222 1$: BIT #REOM,VSTAT ;RECEIVED END OF MESSAGE?
950 003576 001007 10$: BNE 10$ ;YES-CHECK FOR BOTH RECEIVED.
951 003600 012737 000001 017074 MOV #1,DCOUNT ;DELAY FOR 10 M..S.
952 003606 004037 017032 JSR R0,DELAY
953 003612 005301 DEC R1 ;AND KEEP LOOKING.
954 003614 001365 BNE 1$
955 003616 032737 040000 002222 10$: BIT #RSOM,VSTAT ;RECEIVED SOM?
956 003624 001404 BEQ 2$ ;NO ISSUE ERROR
957 003626 032737 020000 002222 BIT #REOM,VSTAT ;RECEIVED EOM?
958 003634 001007 BNE EXMNT ;YES, NO ERRORS-EXIT.
959 003636 012737 006001 001124 2$: MOV #6001,$GDDAT ;LOAD ERROR WITH EXPECTED
960 003644 013737 002222 001126 MOV VSTAT,$BDDAT ;AND ACTUAL STATUS.
961 003652 104022 ERROR 22
962
963 003654 000240 EXMNT: NOP
964 ;*****
965 ;THIS TEST INSURES THAT THE CURSOR WILL RESPOND
966 ;TO DIRECT CURSOR ADDRESSING. THE UNIT IS RESET AND THE CURSOR
967 ;POSITION IS VERIFIED TO BE HOME. THE CURSOR IS THEN MOVED
968 ;TO POSITION ROW 23 COLUMN 80 AND THE POSITION IS AGAIN
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 19
DZVTH.P11 ERROR POINTER TABLE SEQ 0030
969 ;VERIFIED. ERRORS ARE REPORTED IF THE POSITIONS ARE INCORRECT.
970
971 ;*****
972
973
974 ;*****
975 003656 000004 tst3: SCOPE
976 003660 012737 000005 001156 MOV #5,$TIMES ;;DO 5 ITERATIONS
977 003666 012737 003674 001106 MOV #CURSI,$LPADR ;;SET SCOPE LOOP ADDRESS
978
979 003674 013701 015136 CURSI: MOV TBBUF,R1 ;USE R1 AS XMIT BUFFER POINTER.
980 003700 004037 015146 JSR R0,RESETV ;RESET THE UNIT AND WAIT FOR XON.
981 003704 013721 002056 MOV ESCOI,(R1)+ ;CLFT. RESET, READ CURSOR
982 003710 113721 002052 MOVB RDCUR,(R1)+ ;POSITION, CURSOR LEFT.
983 003714 012737 000003 015144 MOV #3,XMCNT ;XMIT 3 BYTES
984
985 003722 004037 015552 JSR R0,XMREC ;XMIT AND RECEIVE.
986 003726 000402 BR 10$ ;NORMAL EXIT.
987 003730 104011 ERROR 11 ;TRANSMISSION CAUSED VT61 TO FAIL/HANG
988 003732 000446 BR 2$ ;EXIT TEST.
989 003734 013701 027630 10$: MOV RCRLB,R1 ;GET THE CURRENT CURSOR POSITION.
990 003740 020137 002152 CMP R1,CUHME ;CURSOR REALLY HOME?
991 003744 001405 BEQ 1$ ;YES EXIT
992 003746 104012 ERROR 12 ;VT61 FAILURE MESSAGE
993 003750 013746 002152 MOV CUHME,-(SP) ;PUSH CUHME ON STACK
994 003754 004037 016216 JSR R0,CURER ;GO LOAD AND ISSUE CURSOR ERROR
995
996 003760 013701 015136 1$: MOV TBBUF,R1 ;LOAD XMIT BUFFER WITH
997 003764 013721 002042 MOV DCRAD,(R1)+
998 003770 013721 002044 MOV R23C79,(R1)+ ;CURSOR TO ROW 23,COL.79
999 003774 013721 002056 MOV ESCOI,(R1)+ ;READ CURSOR POSITION
1000 004000 013721 002052 MOV RDCUR,(R1)+ ;IT AND CURSOR RIGHT
1001 004004 012737 000007 015144 MOV #7,XMCNT ;XMIT 7 BYTES.
1002 004012 004037 015552 JSR R0,XMREC ;XMIT AND RECEIVE
1003 004016 000402 BR 20$ ;NORMAL EXIT.
1004 004020 104011 ERROR 11 ;TRANSMISSION CAUSED VT61 TO FAIL/HANG
1005 004022 000412 BR 2$ ;EXIT TEST.
1006 004024 012701 027630 20$: MOV #RCRLB,R1
1007
1008 004030 023711 002044 CMP R23C79,(R1) ;CHECK CURSOR POSITION TO LOWER RT.
1009 004034 001405 BEQ 2$ ;OK, EXIT

```

F03

1010 004036 104012  
 1011 004040 013746 002044  
 1012 004044 004037 016216  
 1013 004050 000240  
 1014  
 1015  
 1016  
 1017  
 1018  
 1019  
 1020  
 1021 004052 000004  
 1022 004054 012737 000005 001156  
 1023 004062 012737 004070 001106  
 1024

ERROR 12 ;VT61 FAILURE MESSAGE  
 MOV R23C79, -(SP) ;:PUSH R23C79 ON STACK  
 JSR RC,CURER ;LOAD AND ISSUE CURSOR ERROR .  
 2\$: NOP  
 ;\*\*\*\*\*  
 ;ROUTINE TO INSURE THE UNIT CAN ENTER LINEAR ADDRESSING  
 ;MODE. 81 CHARACTERS ARE ISSUED TO THE UNIT UNDER TEST  
 ;THEN THE CURSOR POSITION IS READ AND MUST BE ROW1, COL.0.  
 ;\*\*\*\*\*  
 ;\*\*\*\*\*  
 †ST4: SCOPE  
 MOV #5, \$TIMES ;:DO 5 ITERATIONS  
 MOV #CKLIN, \$LPADR ;:SET SCOPE LOOP ADDRESS

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 20  
 DZVTH.P11 ERROR POINTER TABLE

SEQ 0031

1025 004070 004037 015146  
 1026 004074 013701 015136  
 1027 004100 012703 000120  
 1028 004104 004037 017076  
 1029 004110 013721 002050  
 1030 004114 013721 002052  
 1031 004120 012737 000123 015144  
 1032 004126 004037 015552  
 1033 004132 000402  
 1034 004134 104011  
 1035 004136 000421  
 1036 004140 023777 002132 010462  
 1037 004146 001415  
 1038 004150 013737 002056 001124  
 1039 004156 000337 001124  
 1040 004162 013737 002012 001126  
 1041 004170 104001  
 1042 004172 013746 002132  
 1043 004176 004037 016216  
 1044 004202 000240  
 1045  
 1046  
 1047  
 1048  
 1049  
 1050  
 1051  
 1052  
 1053  
 1054  
 1055  
 1056  
 1057 004204 000004  
 1058 004206 012737 000010 001156  
 1059 004214 012737 004222 001106  
 1060 004222 013701 015136  
 1061 004226 012737 001001 002224  
 1062 004234 005037 002222  
 1063 004240 004037 015146  
 1064 004244 013721 002042  
 1065 004250 013721 002142  
 1066 004254 013721 002056  
 1067 004260 013721 002060  
 1068 004264 012703 000050  
 1069 004270 004037 017076  
 1070 004274 012737 000057 015144

CKLIN: JSR RO, RESETV ;RESET THE UNIT-SET MAINT AND LINEAR MODES  
 MOV TBBUF, R1  
 MOV #80, R3  
 JSR RO, BLDINC ;LOAD XMIT BUFFER WITH 80 CHAR AND  
 MOV RCUR, (R1)+ ;READ CURSOR POSINION.  
 MOV #83, XMCNT  
 JSR RO, XMITREC ;XMIT THE BUFFER.  
 BR 1\$  
 ERROR 11 ;LAST XMIT CAUSED UNIT TO HANG.  
 BR LINXT ;EXIT TEST  
 1\$: CMP RO1COD, @RBBUF ;CURSOR AT ROW1, COL. 0?  
 BEQ LINXT ;YES-EXIT  
 MOV ESCO, \$GDDAT  
 SWAB \$GDDAT  
 MOV DRECT, \$BDDAT ;ISSUE ESC SEQUENCE AND CURSOR  
 ERROR 1  
 MOV RO1COD, -(SP) ;:PUSH RO1COD ON STACK  
 JSR RO, CURER  
 LINXT: NOP

;\*\*\*\*\*  
 ;TEST TO INSURE OPERATION OF XON/XOFF COMMANDS  
 ;FROM VT61. XOFF IS FORCED BY TRANSMITTING LINE 23 WHILE SIMUL-  
 ;TANEOUSLY FILLING THE SILO WITH DATA. AFTER SENSING  
 ;THE XOFF, THE TEST WAITS FOR THE TRANSMIT TO FINISH AND  
 ;INSURES XON OCCURS BEFORE THE MAX. TRANSFER TIME HAS ELAPSED.  
 ;(30 SECONDS)  
 ;\*\*\*\*\*

;\*\*\*\*\*  
 †ST5: SCOPE  
 MOV #10, \$TIMES ;:DO 10 ITERATIONS  
 MOV #BASC3, \$LPADR ;:SET SCOPE LOOP ADDRESS  
 BASC3: MOV TBBUF, R1 ;R1 = 1ST XMIT BUFFER ADDRESS.  
 MOV #1001, BLKM ;SET UP TO XMIT A SOM -DATA- EOM.  
 CLR VSTAT  
 JSR RO, RESETV ;RESET THE UNIT AND WAIT FOR XON.  
 MOV DCRAD, (R1)+ ;CURSOR TO ROW 23, COL.0  
 MOV R23C00, (R1)+  
 MOV ESCO, (R1)+ ;TRANSMIT THE LINE.  
 MOV XMTAL, (R1)+  
 MOV #40, R3  
 JSR RO, BLDINC ;40 CHAR. OF INCREMENTING CHAR.  
 MOV #47, XMCNT ;SET UP TO XMIT 47 BYTES



```

1071 004302 052777 000100 175424      BIS      #TENA, DVX600      ; TRANSMIT ENABLES
1072 004310 012703 000050                MOV      #40, R3      ; MAXIMUM DELAY EQUAL 400 M.S.
1073 004314 012737 000001 017074 25:    MOV      #1, DCOUNT
1074 004322 004037 017032                JSR      RO, DELAY    ; DELAY FOR 10 MILLISEC.
1075 004326 032737 100000 002222      BIT      #RXOFF, VSTAT ; CHECK FOR XOFF
1076 004334 001007                BNE     3$           ; FOUND IT EXIT THIS SECTION.
1077 004336 005303                DEC      R3           ; DELAYED 400 M.S.?
1078 004340 001365                BNE     2$           ; NO-KEEP LOOKING FOR XOFF.
1079 004342 104012                ERROR   12           ; GENERAL VT61 FAILURE MESSAGE
1080 004344 012746 100000      MOV      #100000, -(SP) ; PUSH #100000 ON STACK

```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 21  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0032

```

1081 004350 004037 015366      JSR      RO, CKSFT    ; GO REPORT ERROR
1082 004354                3$:
1083 004354 012746 000001      MOV      #XMDNE, -(SP) ; PUSH #XMDNE ON STACK
1084 004360 012746 000062      MOV      #50, -(SP)   ; PUSH #50. ON STACK
1085 004364 004037 020470      JSR      RO, WTBGND
1086 004370 000411                BR       EXIT3        ; TIMEOUT-EXIT TEST.
1087 004372 127727 024432 000021      CMPB   #ABUFP, #XON   ; RECEIVED A XON?
1088 004400 001405                BEQ     EXIT3        ; YES-NO ERROR-EXIT
1089
1090 004402 104012                ERROR   12           ; GENERAL VT61 FAILURE MESSAGE
1091 004404 012746 000001      MOV      #000001, -(SP) ; PUSH #000001 ON STACK
1092 004410 004037 015366      JSR      RO, CKSFT
1093 004414 004037 016136      EXIT3: JSR      RO, RESPTR ; RESET INTERRUPT POINTERS.
1094
1095 ;*****
1096 ;ROUTINE TO VERIFY OPERATION OF XOFF AND XON TO THE VT61.
1097 ;A FULL SCREEN TRANSMIT IS INITIATED AND A SERIES OF XOFF AND
1098 ;XON ARE ISSUED TO THE TERMINAL SEQUENTIALLY.
1099 ;ERRORS ARE REPORTED IF XOFF DOES NOT STOP OR XON RESTART
1100 ;THE TRANSMISSION. TEST IS ENDED WHEN EOM IS SENSED.
1101 ;*****
1102
1103 ;*****
1104 TST6: SCOPE
1105      MOV      #1, $TIMES ; DO 1 ITERATION
1106      MOV      #ONOF61, $LPADR ; SET SCOPE LOOP ADDRESS
1107
1108 ONOF61: JSR      RO, RESETV ; RESET THE UNIT AND WAIT FOR XON.
1109      BIC     #77577, VSTAT ; CLEAR THE FLAGS
1110      MOV     ZERO, -(SP) ; PUSH ZERO ON STACK
1111      MOV     XMTAL, -(SP) ; PUSH XMTAL ON STACK
1112      MOV     ESCO, -(SP) ; PUSH ESCO ON STACK
1113      JSR     RO, TESC
1114 ONOFLP: MOV     #10, DCOUNT ; ALLOW 100 M.S. FOR OPERATION
1115      JSR     RO, DELAY ; TO BEGIN.
1116      MOV     #XOFF, #TBUFP
1117      JSR     RO, XMIT1 ; SEND A XOFF TO VT61.
1118      MOV     #30, R4
1119 OFFLP:  MOV     #ABUFP, R5 ; ALLOW 300M.S. FOR XMIT TO CEASE
1120      MOV     #1, DCOUNT
1121      JSR     RO, DELAY
1122      CMP    #ABUFP, R5
1123      BEQ    ONOFA ; XMIT STOPPED-GO RESTART IT.
1124      DEC    R4
1125      BNE    OFFLP ; COUNTER NO EQUAL 300 MS-LOOP
1126      MOV     VSTAT, $GDADR ; UNIT DID NOT RESPOND TO XOFF
1127      ERROR  15 ; ISSUE ERROR
1128
1129 ONOFA:  MOV     #XON, #TBUFP
1130      JSR     RO, XMIT1 ; SEND A XON TO THE VT61.
1131      MOV     #30, R4 ; SET UP FOR 300MS DELAY.

```

H03

```

1132 004576 032737 020000 002222 ONLP: BIT #EOM, VSTAT ;EOM RECEIVED?
1133 004604 001020 BNE ONOFLT ;YES-EXIT
1134 004606 013705 031030 MOV ABUFF, R5
1135 004612 012737 000001 017074 MOV #1, DCOUNT
1136 004620 004037 017032 JSR #J, DELAY ;ALLOW 300 MS FOR XMIT TO RESTART
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 22
DZVTH.P11 ERROR POINTER TABLE
1137 004624 023705 031030 CMP ABUFF, R5
1138 004630 001317 BNE ONOFLT ;IT RESTARTED-GO STOP IT.
1139 004632 005304 DEC R4
1140 004634 001360 BNE ONLP ;NOT YET 300 MS LOOP.
1141 004636 013737 002222 001120 MOV VSTAT, $GDADR ;XMIT DIT NOT RESTART-ISSUE
1142 004644 104016 ERROR 16 ;ERROR AND EXIT
1143 004646 000240 ONOFLT: NOP
;*****
;ROUTINE TO TEST VT61 RAM AND THE COMMUNICATION PATHS.
;THIS ROUTINE ISSUES A SERIES OF PATTERNS(77/100, 100/77,
;52/125, INCREMENTING, AND REV. VIDEO INCREMENTING) TO THE VT61.
;THE SCREEN IS THEN TRANSMITTED TO THE HOST AND AFTER EACH
;ITERATION RECEIVED DATA IS CHECKED AND ALL ERRORS(INCLUDING
;TRANSMISSION) ARE REPORTED.
;MITTED TO THE HOST COMPUTER AND THE RESULTS ARE CHECKED AND
;ALL ERRORS(INCLUDING TRANSMISSION) REPORTED.
;*****
;*****
;*****
1157 004650 000004 ST7: SCOPE
1158 004652 012737 000001 001156 MOV #1, STIMES ;;DO 1 ITERATION
1159 004660 012737 004666 001106 MOV #MEM1, $LPADR ;;SET SCOPE LOOP ADDRESS
1161 004666 004037 015146 MEM1: JSR RC, RESETV ;RESET THE UNIT AND WAIT FOR XON.
1162 004672 005005 CLR R5 ;CLEAR PATTERN OFFSET.
1163 004674 016504 005402 MEMA: MOV MPATT(R5), R4 ;LOAD PATTERN TO BE TRANSMITTED
1164 004700 004037 016136 JSR R0, RESPTR ;RESET POINTERS
1165 004704 042737 077577 002222 BIC #77577, VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL
1166 004712 012702 003600 MOV #TOTCH, R2 ;LOAD A COUNT OF SCREEN
1167 004716 112777 000002 010216 MOVB #SOM, @TBUF ;ISSUE START OF MESSAGE.
1168 004724 004037 016026 JSR R0, XMIT1
1169 004730 005302 MEMB: DEC R2 ;DECREMENT XMIT COUNT
1170 004732 001414 BEQ 105 ;COUNT = ZERO?
1171
1172 004734 004037 005350 125: JSR R0, PATGN ;NO-GENERATE NEXT BYTE TO XMIT.
1173 004740 110477 010176 MOVB R4, @TBUF ;LOAD THE CHARACTER.
1174 004744 004037 016026 JSR R0, XMIT1 ;NO-XMIT ANOTHER BYTE.
1175 004750 023737 002176 002200 CMP FTLCNT, ALWCNT ;EXCEEDED FATAL ERROR COUNT?
1176 004756 103764 BLO MEMB ;NO-CHECK IF ANOTHER TRANSMISSION REQUIRED.
1177 004760 000137 005422 JMP MEMXT ;YES-GO ABORT TEST.
1178 004764 112777 000004 010150 105: MOVB #EOM, @TBUF ;ISSUE END OF MESSAGE.
1179 004772 004037 016026 JSR R0, XMIT1
1180 004776 004037 016136 JSR R0, RESPTR ;RESET INTERRUPT POINTERS.
1181
1182 005002 013701 015136 MOV TBUF, R1 ;LOAD XMIT BUFFER WITH
1183 005006 013721 002130 MOV ESCN, (R1)+
1184 005012 013721 001760 MOV CHOM, (R1)+ ;CURSOR HOME
1185 005016 013721 002124 MOV ESCZ, (R1)+ ;ESCAPE Z
1186 005022 013721 002056 MOV ESCO, (R1)+
1187 005026 013721 002060 MOV XMTAL, (R1)+ ;TRANSMIT ALL
1188 005032 013711 001752 MOV LNFED, (R1) ;LINE FEED.
1189 005036 012737 000010 015144 MOV #8, XMCNT ;SET UP TO XMIT 8 BYTES
1190 005044 004037 015552 JSR R0, XMREC ;XMIT WAIT FOR REC. EOM
1191 005050 000402 BR 15 ;NORMAL EXIT
1192 005052 104011 ERROR 11 ;LAST TRANSMIT CAUSED VT61 TO HANG

```

SEG 0033

1193	005054	000562			BR	MEMXT	;EXIT TEST
1194	005056	042737	077577	002222	1S: BIC	#77577,VSTAT	;CLEAR ALL FLAGS BUT XOFF AND XMKIL
1195	005064	005002			CLR	R2	;CLEAR RECEIVE COUNTER.
1196	005066	016504	005402		MOV	MPATT(R5),R4	;LOAD PATTERN
1197	005072	012703	030630		MOV	#TCRLB+300,R3	;SET UP ERROR STORAGE
1198	005076	013701	014630		MOV	RBBUF,R1	;SET UP RECEIVE POINTER
1199	005102	005037	002216		MEMC: CLR	DLAY	;SET UP TIME OUT DELAY
1200	005106	013737	014630	014634	MOV	RBBUF,RBUF	;RESET RECEIVE POINTER
1201	005114	023701	014634		1S: CMP	RBUF,R1	;RECEIVED A CHAR?
1202	005120	001013			BNE	MEMC	;YES-GO CHECK IT.
1203	005122	032737	020000	002222	BIT	#REOM,VSTAT	;HAVE WE RECEIVED EOM?
1204	005130	001033			BNE	CKDAT	;YES, GO CHECK FOR DATA ERRORS
1205	005132	005337	002216		DEC	DLAY	;RUN TIME OUT DELAY.
1206	005136	001366			BNE	1S	;NOT EXPIRED-KEEP LOOKING.
1207	005140	005237	002176		INC	FTLCNT	;TRANSMISSION FAILED-INCR. FATAL COUNT
1208	005144	104011			ERROR	11	
1209	005146	000525			BR	MEMXT	
1210	005150	005202			MEMD: INC	R2	;DATA IN. INCREMENT COUNTER
1211	005152	004037	005350		JSR	RO,PATGN	;GET GOOD CHARACTER,PUT IN R4 AND
1212	005156	122705	000010		CMPB	#10,R5	;CHECKING REV. VIDEO DATA?
1213	005162	001002			BNE	1S	;NO-DO NOT MODIFY
1214	005164	052704	000200		BIS	#BIT07,R4	;YES-FORCE BIT 7.
1215	005170	121104			1S: CMPB	(R1),R4	;COMPARE DATA
1216	005172	001743			BEQ	MEMC	
1217	005174	020227	003600		CMP	R2,#TOTCH	;COMPARING LAST CHAR?
1218	005200	001740			BEQ	MEMC	;YES-NEVER COUNT AS A ERROR.
1219							
1220	005202	020327	030700		CMP	R3,#TCRLB+350	;STORED 20 ERRORS?
1221	005206	103335			BHIS	MEMC	;YES-STORE NO MORE.
1222	005210	110423			MOVB	R4,(R3)+	;STORE THE GOOD DATA.
1223	005212	111123			MOVB	(R1),(R3)+	;STORE THE BAD DATA.
1224	005214	010223			MOV	R2,(R3)+	;STORE THE RECEIVE COUNT.
1225	005216	000731			BR	MEMC	
1226	005220	022703	030630		CKDAT: CMP	#TCRLB+300,R3	
1227	005224	001415			BEQ	CKMEM	
1228	005226	012701	030630		MOV	#TCRLB+300,R1	;LOAD FIRST ERROR ADDRESS.
1229	005232	004037	015530		1S: JSR	RO,CLREG	;CLEAR ERROR REGISTERS
1230	005236	112137	001124		MOVB	(R1)+,\$GDDAT	;LOAD THE GOOD DATA.
1231	005242	112137	001126		MOVB	(R1)+,\$BDDAT	;LOAD THE ERROR BUFFER
1232	005246	012137	001120		MOV	(R1)+,\$GDADR	;LOAD RECEIVE COUNT
1233	005252	104004			ERROR	4	;ISSUE DATA ERROR MESSAGE.
1234	005254	020103			CMP	R1,R3	;ISSUED ALL ERRORS?
1235	005256	103765			BLO	1S	;NO-CONTINUE
1236							
1237	005260	020227	003600		CKMEM: CMP	R2,#TOTCH	;DID WE XFER 1920 TIMES?
1238	005264	001406			BEQ	1S	;YES - GO CHECK STATUS
1239	005266	012737	003600	001124	MOV	#TOTCH,\$GDDAT	;NO, PUT GOOD COUNT IN GDDAT
1240	005274	010237	001126		MOV	R2,\$BDDAT	;AND ACTUAL COUNT IN BDDAT.
1241	005300	104005			ERROR	5	;ISSUE COUNT ERROR.
1242							
1243	005302				1S:		
1244	005302	012746	060000		MOV	#60000,-(SP)	;PUSH #60000 ON STACK
1245	005306	004037	015366		JSR	RO,CKSFT	
1246	005312	062705	000002		ADD	#2,R5	;INCREMENT PATTERN POINTER
1247	005316	005765	005402		TST	MPATT(R5)	;TEST NEXT PATTERN
1248	005322	001437			BEQ	MEMXT	;ZERO-END OF TEST EXIT.

1249	005324	100007			BPL	2S	;NOT INCRMENTING PATTERN.
1250	005326	122705	000010		CMPB	#10,R5	;SET REVERSE VIDEO?

J03

1251 005332 001004  
 1252 005334 012703 005416  
 1253 005340 004037 016076  
 1254 005344 000137 004674  
 1255  
 1256 005350 042704 000200  
 1257 005354 005704  
 1258 005356 100402  
 1259 005360 000304  
 1260 005362 000200  
 1261 005364 105204  
 1262 005366 120427 000177  
 1263 005372 103402  
 1264 005374 016504 005402  
 1265 005400 000200  
 1266  
 1267 005402 005402  
 1268 005402 037500  
 1269 005404 040077  
 1270 005406 025125  
 1271 005410 100040  
 1272 005412 100040  
 1273 005414 000000  
 1274  
 1275 005416 033 117 112  
 1276 005421 000  
 1277 005422 000240  
 1278  
 1279  
 1280  
 1281  
 1282  
 1283  
 1284  
 1285  
 1286  
 1287  
 1288  
 1289  
 1290  
 1291  
 1292  
 1293  
 1294 005424 000004  
 1295 005426 012737 000003 001156  
 1296 005434 012737 005442 001106  
 1297  
 1298 005442 004037 015146  
 1299 005446 012737 001001 002224  
 1300 005454 004037 016136  
 1301 005460 012703 006070  
 1302 005464 004037 016076  
 1303 005470 042737 077577 002222  
 1304 005476 013701 015136

BNE 2\$  
 MOV #SETREV,R3  
 JSR RO,LDXMIT  
 JMP MEMA  
 PATGN: BIC #200,R4  
 TST R4  
 BMI 1\$  
 SWAB R4  
 RTS RO  
 1\$: INCB R4  
 CMPB R4,#177  
 BLO 2\$  
 MOV MPATT(R5),R4  
 2\$: RTS RO  
 .EVEN  
 MPATT =  
 .WORD 037500  
 .WORD 040077  
 .WORD 025125  
 .WORD 100040  
 .WORD 100040  
 .WORD 0  
 ;SEQUENCE TO ENTER REVERSE VIDEO.  
 SETREV: .BYTE .ESC,.O,.EEMP,0  
 MEMXT: NOP

;NO.  
 ;YES-ENTER REVERSE VIDEO  
 ;AND RE-ISSUE INCREMENTING PATTERN.  
 ;NOT ZERO, GO EXERCISE IT.  
 ;CLEAR REV. VIDEO BIT IF SET.  
 ;CHECK R4 FOR PATTERN  
 ;IF MINUS, DO INCREMENTING.  
 ;OTHERWISE SWAP BYTES AND  
 ;EXIT.  
 ;ADD ONE TO INCREMENTING  
 ;HAVE WE EXCEEDED LIMIT  
 ;NO, EXIT  
 ;YES, RESET PATTERN AND  
 ;EXIT.  
 ;PATTERN 77,100  
 ;PATTERN 100,77  
 ;PATTERN 52,125  
 ;PATTERN INCREMENTING  
 ;PATTERN INCREMENTING-REV. VIDEO.  
 ;PATTERN TABLE TERMINATOR

\*\*\*\*\*

;ROUTINE TO TEST THE ABILITY OF THE VT61 TO CALCULATE  
 ;AND TRANSMIT CHECKSUMS OF BOTH TRANSMITTED AND RECEIVED  
 ;DATA. SUBTEST A TRANSMITS A FULL BUFFER UPDATING A CALCULATED  
 ;CHECKSUM ON EACH CHARACTER TRANSMITTED. AN ESCAPE SEQUENCE  
 ;REQUESTING THE RECEIVER CHECKSUM IS EMBEDDED AT THE END OF  
 ;XMIT BUFFER AND THE RECEIVED CHECKSUM IS COMPARED TO THE  
 ;CALCULATED. SUBTEST B PERFORMS THE SAME TYPE OF CHECK ON  
 ;THE VT61 TRANSMIT CHECKSUM,UTILIZING THE DATA SENT TO THE VT61  
 ;IN SUBTEST A,DURING A FULL SCREEN TRANSMIT.

\*\*\*\*\*

\*\*\*\*\*

TST10: SCOPE  
 MOV #3,STIMES ;DO 3 ITERATIONS  
 MOV #CKSUMA,\$LPADR ;SET SCOPE LOOP ADDRESS  
 CKSUMA: JSR RO,RESETV ;RESET THE UNIT AND WAIT FOR XON.  
 MOV #1001,BLKM ;SET UP TO XMIT A SOM -DATA- EOM.  
 JSR RO,RESPTR ;RESET INTERRUPT POINTERS  
 MOV #ITSUMA,R3 ;DIS. RECT. MODE AND CLEAR CHECKSUM  
 JSR RO,LDXMIT  
 BIC #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL  
 MOV TBBUF,R1 ;LOAD XMIT BUFFER WITH

20-SEP-76 10:22 PAGE 25

MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0036

1305 005502 012703 000473  
 1306 005506 004037 017076  
 1307 005512 113721 002130  
 1308 005516 113721 001760  
 1309 005522 113721 002056  
 1310 005526 113721 002057  
 1311 005532 113711 002074

MOV #315,R3  
 JSR RO,BLDINC ;314 INCREMENTING CHAR.  
 MOVB ESCN,(R1)+  
 MOVB CHOM,(R1)+ ;CURSOR HOME  
 MOVB ESCO,(R1)+  
 MOVB ESCO+1,(R1)+  
 MOVB TXRCK,(R1) ;TRANSMIT RECEIVER CHECKSUM.

K03

1312	005536	005004			CLR	R4	:CLEAR CHECKSUM REGISTER	
1313	005540	012705	000004		MOV	#EOM,R5	:PRELOAD CHECKSUM REG. WITH	
1314	005544	004037	017516		JSR	RD,CALCK	:EOM FROM PRIOR XMIT.	
1315	005550	052737	002000	002222	BIS	#CKSUM,VSTAT	:REQUEST CHECKSUM CALCULATIONS.	
1316	005556	012737	000500	015144	MOV	#320.,XMCNT	:SETUP TO XMIT 320 BYTES	
1317	005564	052777	000100	174142	BIS	#TENB,@VXCSR	:ENABLE XMIT INTERRUPTS	
1318	005572	012746	020000		MOV	#REOM,-(SP)	:PUSH #REOM ON STACK	
1319	005576	012746	000012		MOV	#10,-(SP)	:PUSH #10. ON STACK	
1320	005602	004037	020470		JSR	RD,WTBGND	:LOOK FOR EOM.	
1321	005606	000534			BR	CKEXT	:ERROR EXIT IF NOT FOUND	
1322	005610	127704	007014		CMPB	@RBBUF,R4	:COMPARE CHECKSUMS	
1323	005614	001414			BEQ	CKSUMB	:GOOD GO TO SUBTEST B	
1324	005616	004037	015530		JSR	RD,CLREG	:BAD COMPARE	
1325	005622	110437	001124		MOVB	R4,\$GDDAT	:LOAD CALCULATED CHECKSUM	
1326	005626	117737	006776	001126	MOVB	@RBBUF,\$BDDAT	:AND VT61 RECEIVER CHECKSUM	
1327	005634	104013			ERROR	13	:ISSUE ERROR	
1328	005636	012746	060001		MOV	#60001,-(SP)	:PUSH #60001 ON STACK	
1329	005642	004037	015366		JSR	RD,CKSFT	:ERROR.	
1330								
1331	005646	042737	077577	002222	CKSUMB:	BIC	#77577,VSTAT	:CLEAR ALL FLAGS BUT XGFF AND XMKIL
1332	005654	005004			CLR	R4	:CLEAR CHECKSUM REGISTER	
1333	005656	012737	001001	002224	MOV	#1001,BLKM	:SET UP TO XMIT A SOM -DATA- EOM.	
1334	005664	052737	000100	002222	BIS	#TXSUM,VSTAT	:SET UP FOR XMIT CHECKSUM GENERATION.	
1335	005672	013701	015136		MOV	TBBUF,R1	:LOAD XMIT BUFFER WITH	
1336	005676	004037	017564		JSR	RD,LDBUF	:LOAD THE BUFFER WITH:	
1337	005702	033	117	134	.BYTE	.ESC,.0,.CLTCK,.ESC,.0,.XMTAL,.ESC,.0,.TXTCK,0		
1338	005705	033	117	126				
1339	005710	033	117	136				
1340	005713	000						
1341	005714	012737	000011	015144	MOV	#9.,XMCNT	:SET UP TO XMIT 9 BYTES	
1342	005722	052777	000100	174004	BIS	#TENB,@VXCSR	:ALLOW XMIT INTERRUPTS	
1343	005730	012746	000001		MOV	#XMDNE,-(SP)	:PUSH #XMDNE ON STACK	
1344	005734	012746	000002		MOV	#2,-(SP)	:PUSH #2 ON STACK	
1345	005740	004037	020470		JSR	RD,WTBGND	:LOOK FOR XMIT DONE.	
1346	005744	000455			BR	CKEXT	:TIME OUT - EXIT TEST.	
1347	005746	005037	002216		CKSRC:	CLR	DLAY	:SET UP TIME OUT DELAY
1348	005752	013702	031030		MOV	ABUFP,R2	:RESET THE RECEIVER FLAG	
1349	005756	023702	031030		1\$:	CMP	ABUFP,R2	:RECEIVED A CHAR?
1350	005762	001007			BNE	2\$	:YES-GO CHECK IT.	
1351	005764	005337	002216		DEC	DLAY	:RUN TIME OUT DELAY.	

# L03

```

1352 005770 001372          BNE      1$
1353 005772 005237 002176  INC      FTLCNT          ;TIMED OUT-INCREMENT FATAL XMIT COUNT
1354 005776 104011          ERROR    11              ;ISSUE HUNG MESSAGE AND EXIT.
1355 006000 000437          BR       CKEXT
1356 006002 122777 000004 023020 2$:  CMPB    #EOM, JABUFP    ;RECEIVED EOM CHAR?
1357 006010 001356          BNE      CKSRC
1358 006012 042737 020000 002222  BIC      #REOM, VSTAT    ;CLEAR THE EOM FLAG
1359 006020 032737 020000 002222  BIT      #REOM, VSTAT    ;NOW WAIT FOR LAST EOM FLAG
1360 006026 001774          BEQ      -6              ;FROM XMIT TRANSMITTER CHECKSUM.

MAINDEC-11-DZVTH-A      MACY11 27(732) 20-SEP-76 10:22 PAGE 26
DZVTH.P11              ERROR POINTER TABLE
                                                    SEQ 0037

1361 006030 120477 006574          CMPB    R4, JRBUFF      ;COMPARE 61 TO HOST CHECKSUM.
1362 006034 001421          BEQ      CKEXT          ;EQUAL - EXIT TEST
1363 006036 004037 015530          JSR     R0, CLREG
1364 006042 110437 001124          MOVB   R4, $GDDAT      ;LOAD THE HOST CALCULATED CHECKSUM
1365 006046 117737 006556 001126  MOVB   JRBUFF, $BDDAT  ;LOAD THE VT61 TRANSMITTED CHECKSUM
1366 006054 104014          ERROR    14              ;ISSUE VT61 XMIT CHECKSUM ERROR
1367 006056 012746 060001          MOV     #60001, -(SP)  ;PUSH #60001 ON STACK
1368 006062 004037 015366          JSR     R0, CKSFT      ;CHECK FOR STATUS ERROR
1369 006066 000404          BR      CKEXT
1370
1371 006070          033      117      103  ITSUMA: .BYTE .ESC, .0, .DRECT, .ESC, .0, .CLCK, 0, 0
1372 006073          033      117      133
1373 006076          000      000
1374
1375 006100 J04037 016136          CKEXT: JSR     R0, RESPTR
1376
1377          ;*****
1378          ;ROUTINE TO INSURE BASIC CURSOR COMMANDS
1379          ;RESULT IN CORRECT CURSOR MOVEMENT. COMMANDS
1380          ;ARE ISSUED IN THE SEQUENCE: RESET, CURSOR RIGHT,
1381          ;CURSOR DOWN, CURSOR LEFT, AND CURSOR UP. THE READ
1382          ;CURSOR POSITION COMMAND IS ISSUED AFTER EVERY
1383          ;CURSOR COMMAND AND CURRENT IS COMPARED TO GOOD
1384          ;AND ANY ERRORS REPORTED.
1385          ;*****
1386
1387          ;*****
1388          ;*****
1389          ;*****
1389 006106 012737 000005 001156  ST11:  MOV     #5, $TIMES    ;;DO 5 ITERATIONS
1390 006114 012737 006122 001106  MOV     #CURS1A, $LPADR ;;SET SCOPE LOOP ADDRESS
1391
1392 006122 013701 015136          CURS1A: MOV    TBBUF, R1      ;LOAD XMIT BUFFER ADDRESS
1393 006126 004037 015146          JSR     R0, RESETV     ;RESET THE UNIT AND WAIT FOR XON.
1394 006132 004037 017564          JSR     R0, LDBUF      ;LOAD THE BUFFER WITH:
1395 006136          033      103      033  .BYTE  .ESC, .CRT, .ESC, .0, .RDCUR, .ESC, .CDWN, .ESC
1396 006141          117      131      033
1397 006144          102      033
1398 006146          117      131      033  .BYTE  .0, .RDCUR, .ESC, .CLFT, .ESC, .0, .RDCUR
1399 006151          104      033      117
1400 006154          131
1401 006155          033      101      033  .BYTE  .ESC, .CUP, .ESC, .0, .RDCLR, .BEL, 0
1402 006160          117      131      007
1403 006163          000
1404 006164 012737 000024 015144  MOV     #20, XMCNT      ;SET TO XMIT 20 CHARACTERS
1405 006172 012737 000004 016020  MOV     #4, RECITT      ;SET RECEIVE ITERATION TO 4
1406 006200 012737 030430 016022  MOV     #TCRLB+100, WDSTOR ;SET UP WORD STORAGE POINTER
1407 006206 004037 015552          JSR     R0, XIREC      ;XMIT AND WAIT FOR REC.DONE
1408 006212 000402          BR      11$            ;NORMAL EXIT
1409 006214 104011          ERROR    11              ;LAST XMIT CAUSED VT61 TO HANG.
1410 006216 000436          BR      CUR1XT          ;EXIT TEST
1411 006220 012701 006304          11$:  MOV     #GDCURP, R1    ;R1=GOOD POSITION TABLE

```

MQ3

```

1412 006224 012702 030430      MOV      #TCRLB+100000 ;R2=ACTUAL CURSOR POSITION
1413 006230 012703 001762      MOV      #CRT,R3      ;R3=CURSOR COMMAND TABLE
1414
1415 006234 021112      12$:    CMP      (R1),(R2) ;COMPARE GOOD TO ACTUAL
1416 006236 001415      BEQ      2$          ;OK-GO UPDATE POINTERS.
MAINDEC-11-DZVTH-A      MACY11 27(732) 20-SEP-76 10:22 PAGE 27
DZVTH.P11              ERROR POINTER TABLE
                                                    SEQ 0038

1417 006240 113737 002130 001125      MOV      ESCN,$GDDAT+1
1418 006246 111337 001124      MOV      (R3),$GDDAT ;LOAD COMMAND IN ESC ERROR
1419 006252 005037 001126      CLR      $BDDAT
1420 006256 104001      ERROR 1 ;AND ISSUE IT
1421 006260 011237 027630      MOV      (R2),RCRLB ;LOAD BAD CURSOR POSITION
1422 006264 011146      MOV      (R1),-(SP) ;PUSH (R1) ON STACK
1423 006266 004037 016216      JSR      RD,CURER ;LOAD AND ISSUE CURSOR ERROR MESSAGE
1424 006272 022122      2$:    CMP      (R1)+,(R2)+ ;INCREMENT POSITION POINTERS.
1425 006274 022337 001770      CMP      (R3)+,CUP ;CHECK FOR COMMAND TERM.(CUP).
1426 006300 001355      BNE      12$        ;NOT AT TERMINATOR-COMPARE AGAIN
1427 006302 000404      BR       CUR1XT    ;EXIT TEST
1428
1429
1430 006304 020440      GDCURP: .WORD 20440 ;ROW 0, COL. 1
1431 006306 020441      .WORD 20441 ;ROW 1, COL. 1
1432 006310 020041      .WORD 20041 ;ROW 1, COL. 0
1433 006312 020040      .WORD 20040 ;ROW 0, COL. 0
1434 006314 000240      CUR1XT: NOP
1435
1436 ;*****
1437 ;ROUTINE TO INSURE THAT READ CHARACTER AT CURSOR
1438 ;FUNCTIONS CORRECTLY. COMMAND SEQUENCE IS: RESET, A, CURSOR
1439 ;LEFT, READ CHARACTER AT CURSOR.
1440 ;AN ERROR IS REPORTED IF THE LAST READ IS NOT AN "A".
1441 ;*****
1442
1443 ;*****
1444 006316 000004      1ST12: SCOPE
1445 006320 012737 000005 001156      MOV      #5,$TIMES ;DO 5 ITERATIONS
1446 006326 012737 006334 001106      MOV      #CURS1B,$LPADR ;SET SCOPE LOOP ADDRESS
1447
1448 006334 013701 015136      CURS1B: MOV      TBBUF,R1
1449 006340 004037 015146      JSR      RD,RESETV ;RESET THE UNIT AND WAIT FOR XCN.
1450 006344 012721 000101      MOV      #101,(R1)+ ;A
1451 006350 113721 002130      MOV      ESCN,(R1)+
1452 006354 113721 001766      MOV      CLFT,(R1)+ ;CURSOR LEFT
1453 006360 013721 002056      MOV      ESCOI,(R1)+
1454 006364 013711 002066      MOV      TCUCH,(R1) ;TRANSMIT CH. AT CURSOR
1455 006370 012737 000006 015144      MOV      #6,XMCNT ;SET UP TO XMIT 6 CHARACTERS
1456 006376 004037 015552      JSR      RD,XMREC ;XMIT STRING AND WAIT FOR EOM.
1457 006402 000402      BR       10$      ;NORMAL EXIT
1458 006404 104011      ERROR 11 ;LAST XMIT CAUSED VT61 TO HANG/FAIL
1459 006406 000430      BR       2$      ;EXIT TEST
1460 006410 127727 006214 000101 10$:    CMPB   @RBAUF,#101 ;CHARACTER READ=A
1461 006416 001424      BEQ      2$      ;YES-NEXT SUBTEST
1462 006420 013737 002056 001124      MOV      ESCOI,$GDDAT
1463 006426 000337 001124      SWAB   $GDDAT ;REASSEMBLE ESC DATA
1464 006432 005037 001126      CLR      $BDDAT
1465 006436 113737 002066 001127      MOV      TCUCH,$BDDAT+1 ;LOAD FAILING ESC SEQUENCE
1466 006444 104001      ERROR 1 ;AND ISSUE IT
1467 006446 004037 015530      JSR      RD,CLREG
1468 006452 112737 000101 001124      MOV      #101,$GDDAT ;LOAD GOOD CH. AND CH.
1469 006460 117737 006144 001126      MOV      @RBBUF,$BDDAT
1470 006465 104004      ERROR 4 ;READ AND ISSUE THEM.
1471
1472 006470 000240      2$:    NOP ;END OF TEST

```



```
1473 ;*****
1474 ;ROUTINE TO VERIFY OPERATION OF REPLACE AND INSERT MODE.
1475 ;INITIALLY ROW 0 IS WRITTEN TO 80 INCREMENTING CHAR.
1476 ;ON THE FIRST PASS(REPLACE MODE) A CHARACTER IS REPLACED
1477 ;AT HOME AND THE CHAR. AT ROW0,COL.0(172) AND ROW1,COL0(NULL)
1478 ;ARE VERIFIED. ON THE SECOND PASS, INSERT MODE IS ENTERED
1479 ;AND THE RESULTING INSERTION(AT HOME) IS VERIFIED.ROW0,COL0
1480 ;SHOULD BE 172 AND ROW1,COL0 SHOULD BE 161.
1481 ;*****
1482
1483 ;*****
1484 006472 000004 1ST13: SCOPE
1485 006474 012737 000005 001156 MOV #5,$TIMES ;;DO 5 ITERATIONS
1486 006502 012737 006510 001106 MOV #INRPL,$LPADR ;;SET SCOPE LOOP ADDRESS
1487
1488 006510 004037 015146 INRPL: JSR R0,RESETV ;RESET THE UNIT
1489 006514 013701 015136 MOV TBBUF,R1
1490 006520 005201 INC R1 ;LEAVE ROOM IN BUFFER FOR SOM.
1491 006522 012703 000120 MOV #80.,R3 ;CREATE A LINE OF 80 INCREMENTING
1492 006526 004037 017076 JSR R0,BLDINC ;CHAR. ON THE SCREEN.
1493 006532 105011 CLR R1
1494 006534 013703 015136 MOV TBBUF,R3
1495 006540 004037 016076 JSR R0,LDXMIT
1496 006544 005005 CLR R5 ;USE R5 AS TEST INDEXER.
1497 006546 012737 000002 016020 INAG: MOV #2,RECITT ;SET UP TO RECEIVE 2 CHAR.
1498 006554 012737 030530 016024 MOV #TCRLB+200,BYSTOR ;SET UP STORAGE AREA.
1499 006562 013701 015136 MOV TBBUF,R1
1500 006566 004037 017564 JSR R0,LDBUF ;LOAD THE BUFFER WITH:
1501 006572 033 110 172 .BYTE .ESC,.CHOM,172,ESC,.CHOM,.ESC,.0,.TCUCH
1502 006575 033 110 033
1503 006600 117 127
1504 006602 033 102 033 .BYTE .ESC,.CDWN,.ESC,.0,.TCUCH,0
1505 006605 117 127 000
1506 006610 012737 000015 015144 MOV #13.,XMCNT ;SET UP TO XMIT 13 CAHR.
1507 006616 004037 015552 JSR R0,XMREC
1508 006622 000402 BR 1$ ;NORMAL EXIT
1509 006624 104011 ERROR 11 ;LAST XMIT CAUSED UNIT TO HANG.
1510 006626 000433 BR INRXT ;EXIT TEST.
1511 006630 026537 006706 030530 1$: CMP TDATA(R5),TCRLB+200 ;COMPARE GOOD TO REC.DATA.
1512 006636 001407 BEQ 2$ ;GOOD-LOOP OR EXIT.
1513 006640 016537 006700 001126 MOV TFUNCT(R5),$BDDAT
1514 006646 013737 002116 001124 MOV ESCP,$GDDAT ;LOAD ESCAPE SEQ. ERROR.
1515 006654 104001 ERROR 1
1516 006656 005725 2$: TST (R5)+ ;INCREMENT INDEXER.
1517 006660 020527 000004 CMP R5,#4 ;THRU WITH TEST?
1518 006664 001414 BEQ INRXT ;YES-EXIT.
1519 006666 012703 006712 MOV #ENSRT,R3 ;NO-SECOND PASS- ENTER
1520 006672 004037 016076 JSR R0,LDXMIT ;INSERT MODE AND DO AGAIN.
1521 006676 000723 BR INAG
1522
1523 006700 000151 000111 177777 TFUNCT: .WORD .ERPL,.EINST,-1
1524 006706 172 000 172 TDATA: .BYTE 172,0,172,160
1525 006711 160
1526 006712 033 120 111 ENSRT: .BYTE .ESC,.P,.EINST,0
1527 006715 000
1528 006716 000240 INRXT: NOP
```

1529  
1530

\*\*\*\*\*



BOH

:ROUTINE TO INSURE WILL SCROLL IF A LINE FEED  
:IS ISSUED FROM ROW 23 OR A CURSOR RIGHT FROM ROW23,COL. 73.  
:IN SUBTEST A, ROW 0 IS INITIALLY WRITTEN TO A 0 AND ROW 1  
:A 1. AFTER COMPLETION OF A LINE FEED(AND RESULTING SCROLL)  
:ROW 00,COL.00 IS EXPECTED TO CONTAIN A 1.  
:IN SUBTEST B, THE CURSOR IS PLACED AT ROW23,COL.73  
:AND A DATA CHARACTER "A" IS ENTERED. THE CURSOR  
:POSITION IS THEN READ AND SHOULD BE ROW23,COL.00. THE  
:CHARACTER AT HOME IS VERIFIED TO BE A NULL.

\*\*\*\*\*

\*\*\*\*\*

1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566  
1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591

```
TEST14: SCOPE
MOV #5, $TIMES ;; DO 5 ITERATIONS
MOV #CKSCRA, $LPADR ;; SET SCOPE LOOP ADDRESS

CKSCRA: JSR RO, RESETV ; RESET THE UNIT.
MOV TBBUF, R1
JSR RO, LDBUF ; LOAD THE XMIT BUFFER WITH:
.BYTE 60, .ESC, .CDWN, .ESC, .CLFT, 61, .ESC, .Y, .R23, .COO

.BYTE .LNFED, .ESC, .CHOM, .ESC, .O, .TCUCH, .BEL, 0

MOV #16, XMCNT ; SET UP TO XMIT 16 BYTES.
JSR RO, XPREC
BR 15 ; NORMAL EXIT
ERROR 11 ; LAST XMIT CAUSED UNIT TO HANG.
BR GDSCRL ; EXIT TEST.
CMPB 2RBBUF, #61 ; CHARACTER AT HOME A 1?
BEQ CKSCRB ; YES-NEXT TEST
ERROR 23 ; NO-ISSUE NO SCROLL ERROR.
CKSCRB: MOV #2, RECITT ; SET UP FOR TWO REC. LOOPS.
MOV #TCRLB+200, WDSTOR ; SET UP CURSOR POSITION STORAGE.
MOV TBBUF, R1
JSR RO, LDBUF ; LOAD XMIT BUFFER WITH:
.BYTE .ESC, .Y, .R23, .C79, 101, .ESC, .O, .RDCUR

.BYTE .ESC, .CHOM, .ESC, .O, .TCUCH, 0

MOV #13, XMCNT ; SET UP TO XMIT 13 BYTES.
JSR RO, XPREC ; XMIT AND WAIT FOR RECEIVED DONE.
BR 15
ERROR 11 ; LAST XMIT CAUSED VT61 TO HANG.
BR GDSCRL ; ERROR EXIT
CMPB 2RBBUF, ZERO ; NULL RECEIVED?
BEQ GDSCRL ; YES-EXIT TEST
ERROR 23 ; NO-ISSUE NO SCROLL ERROR.
MOV TCRLB+200, 2RBBUF ; LOAD RECEIVED CURSOR POSITION.
MOV R23COO, -(SP) ; PUSH R23COO ON STACK
JSR RO, CURER ; GO ISSUE CURSOR ERROR.
```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 30  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0041

GDSCRL: NOP  
\*\*\*\*\*  
:THIS TEST INSURES THAT THE VT61 CURSOR CAN BE  
:POSITIONED TO VERY POSSIBLE ROW/COLUMN POSITON  
:ON THE SCREEN. THIS IS TESTED BY FILLING THE

1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602 007142 000004  
1603 007144 012737 000001 001156  
1604 007152 012737 007150 001106  
1605  
1606 007160 042737 077577 002222  
1607 007166 004037 015146  
1608 007172 012702 003600  
1609 007176 112777 000002 005736  
1610 007204 004037 016026  
1611 007210 005302  
1612 007212 001413  
1613  
1614 007214 112777 000101 005720  
1615 007222 004037 016026  
1616 007226 023737 002176 002200  
1617 007234 103765  
1618 007236 000137 007640  
1619 007242 112777 000004 005672  
1620 007250 004037 016026  
1621 007254 004037 016136  
1622 007260 013737 002156 016420  
1623 007266 013701 015136  
1624 007272 013721 002042  
1625 007276 010102  
1626 007300 013721 002156  
1627 007304 112721 000040  
1628 007310 012737 000005 015144  
1629 007316 042737 077577 002222  
1630 007324 052777 000100 172402  
1631 007332 012746 000001  
1632 007336 012746 000002  
1633 007342 004037 020470  
1634 007346 000534  
1635 007350 021237 002152  
1636 007354 001405  
1637 007356 004037 016314  
1638 007362 013712 016420  
1639 007366 000750  
1640 007370 004037 016136

COMPLETE SCREEN CHARACTER(A) AND THEN  
POSITIONING THE CURSOR (VIA DCA) TO EVERY POSITION  
AND THE "A" AT THAT POSITION IS REPLACED WITH A SPACE.  
THE SCREEN IS THEN READ TO VERIFY THAT ONLY SPACES  
EXIST ON THE SCREEN. ALL POSITIONS CONTAINING  
NON-SPACES ARE REPORTED.

```

*****
*****
1ST15: SCOPE
MOV #1,STIMES ;;DO 1 ITERATION
MOV #CURS2,$LPAOR ;;SET SCOPE LOOP ADDRESS
CURS2: BIC #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL
JSR RO,RESETV ;RESET THE UNIT AND WAIT FOR XON.
MOV #TOTCH,R2 ;LOAD A COUNT OF SCREEN(1920).
MOVB #SOM,$TBUF ;ISSUE START OF MESSAGE.
JSR RO,XMIT1
1$: DEC R2 ;DECREMENT XMIT COUNT
BEQ 10$ ;COUNT = ZERO?
MOVB #101,$TBUF ;LOAD THE CHARACTER(A).
JSR RO,XMIT1 ;NO-XMIT ANOTHER BYTE.
CMP FTLCNT,ALWCNT ;EXCEEDED FATAL ERROR COUNT?
BLO 1$ ;NO-CHECK IF DONE NOW
JMP C2XT ;YES-ABORT TESTING THIS UNIT.
10$: MOVB #EOM,$TBUF ;ISSUE END OF MESSAGE.
JSR RO,XMIT1
JSR RO,RESPTR ;RESET INTERRUPT POINTERS.
MOV R23C78,LNRW ;SET UP 1ST ADDRESS
MOV TBUF,R1 ;LOAD XMIT BUFFER WITH
MOV OCRAD,(R1)+
MOV R1,R2 ;R2 POINTS TO CURSOR ADD. IN BUFFER
MOV R23C78,(R1)+ ;CURSOR TO LOWER RIGHT -1.
MOVB #40,(R1)+ ;SPACE
2$: MOV #5,XMCNT ;SET UP TO XMIT 5 CHARACTERS
BIC #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL
BIS #TENA,$VXCSR ;XMIT INTERRUPTS.
MOV #XMDNE,-(SP) ;PUSH #XMDNE ON STACK
MOV #2,-(SP) ;PUSH #2 ON STACK
JSR RO,WTBGND ;LOOK FOR XMIT DONE
BR C2XT ;NOT FOUND-ERROR EXIT
CMP (R2),CUMME ;DELETED TO HOME?
BEQ 3$ ;YES
JSR RO,CMPPOS ;NO-GET NEXT POSITION TO BE DELETED
MOV LNRW,(R2) ;LOAD IT IN XMIT BUFFER
BR 2$ ;AND DELETE IT.
3$: JSR RO,RESPTR ;RESET INTERRUPT POINTERS

```

MAINDEC-11-DZVTH-A  
DZVTH.P11  
MACY11 27(732)  
ERROR POINTER TABLE

20-SEP-76 10:22 PAGE 31

SEQ 0042

1641 007374 013737 002152 016420  
1642 007402 012737 001001 002224  
1643 007410 013701 015136  
1644 007414 010102  
1645 007416 042737 077577 002222  
1646 007424 013721 002130  
1647 007430 013721 001760  
1648 007434 013721 002056  
1649 007440 013721 002060  
1650 007444 012737 000005 015144  
1651 007452 052777 000100 172254  
1652 007460 012746 000001

```

MOV CUMME,LNRW ;LOAD INITIAL CHECK POSITION(HOME)
MOV #1001,BLKM ;SET UP TO XMIT A SOM -DATA- EOM.
MOV TBUF,R1 ;LOAD XMIT BUFFER WITH
MOV R1,R2 ;STORE ERRORS IN XMIT BUFFER
BIC #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL
MOV ESCN,(R1)+ ;CURSOR HOME
MOV CHOM,(R1)+
MOV ESCO,(R1)+
MOV XMTAL,(R1)+ ;TRANSMIT ALL
MOV #5,XMCNT
BIS #TENA,$VXCSR ;SET XMIT ENABLE
MOV #XMDNE,-(SP) ;PUSH #XMDNE ON STACK

```

004

```

1653 007464 012746 000003      MOV      #3,-(SP)      ;; PUSH #3 ON STACK
1654 007470 004037 020470      JSR      RD,WTBGND    ;; LOCK FOR SOM OR XMIT DONE
1655 007474 000461          BR       C2XT         ;; NOT FOUND-ERROR EXIT
1656 007476 013701 014634      4$:     MOV      RBUF,R1  ;; SET UP RECEIVE FLAG
1657 007502 005037 002216      CLR      DLAY        ;; SET UP TIME OUT DELAY
1658 007506 020137 014634      40$:    CMP      R1,RBUF     ;; CHARACTER RECEIVED?
1659 007512 103411          BLO     41$          ;; YES-GO CHECK IT.
1660 007514 032737 020000 002222      BIT      #REOM,VSTAT  ;; LOOK FOR END OF MESSAGE
1661 007522 001025          BNE     C2CK        ;; FOUND IT, EXIT TEST
1662 007524 005337 002216      DEC      DLAY        ;; RUN TIME OUT DELAY.
1663 007530 001366          BNE     40$        ;; AND LOOK FOR RECEIVED CH.
1664 007532 104011          ERROR   11         ;; LAST XMIT CAUSED VT61 TO HANG.
1665 007534 000420          BR      C2CK        ;; GO SEE IF ANY ERRORS STORED.
1666 007536 013737 014630 014634 41$:    MOV      RBBUF,RBUF  ;; RESET RECEIVE POINTER
1667 007544 127727 005060 000040      CMPB    @RBBUF,#40   ;; CHAR EQUAL A SPACE?
1668 007552 001003          BNE     6$         ;; NOT A SPACE-MUST BE ERROR-STORE IT
1669 007554 004037 016356      5$:     JSR      RD,CPPOS    ;; UPDATE CURSOR POSITION
1670 007560 000746          BR      4$         ;;
1671 007562 022702 030354      6$:     CMP      #TCRLB+20.,R2 ;; STORED 10 ERRORS?
1672 007566 101772          BLOS   5$         ;; YES-IGNORE ANY FURTHER ERRORS.
1673 007570 013722 016420      MOV     LNRW,(R2)+  ;; STORE FAILING CURSOR POSITION
1674 007574 000767          BR      5$         ;;
1675
1676 007576 020237 015136      C2CK:   CMP      R2,TBBUF  ;; ANY ERRORS STORED?
1677 007602 001416          BEQ    C2XT        ;; NO EXIT TEST
1678 007604 013701 015136      MOV     TBBUF,R1   ;; USE R1 AS ERROR POINTER
1679 007610 021137 002044      1$:     CMP      (R1),R23C79 ;; CURSOR TO LOWER RIGHT?
1680 007614 001411          BEQ    C2XT        ;; YES-NOT AN ERROR.
1681 007616 104012          ERROR   12        ;; NO-ISSUE ERROR MESSAGES
1682 007620 012746 020040      MOV     #20040,-(SP) ;; PUSH #20040 ON STACK
1683 007624 012177 005000      MOV     (R1)+,@RBBUF ;; LOAD FAILING POS.
1684 007630 004037 016216      JSR     RD,CURER   ;; ISSUE CURSOR ERROR
1685 007634 020102          CMP    R1,R2      ;; DONE WITH ERRORS?
1686 007636 103764          BLO   1$         ;; NO, DUMP ANOTHER.
1687 007640 000240      C2XT:   NOP         ;; EXIT TEST
1688
1689          ;*****
1690          ;ROUTINE TO INSURE PROPER OPERATION OF CARRIAGE RETURN
1691          ;AND LINE FEED DURING NORMAL MODE. INITIALLY THE CURSOR IS
1692          ;SET(VIA D.C.A.) TO ROW0, COL 20 AND A LINE FEEL IS ISSUED
1693          ;THE CURSOR POSITION IS THEN READ AND MUST BE ROW1, COL20.
1694          ;A CARRIAGE RETURN IS THEN ISSUED AND CURSOR POSITION VERIFIED
1695          ;TO BE ROW1, COL0.
1696

```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 32  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0043

```

1697          ;*****
1698          ;*****
1699          ;*****
1700 007642 000004      1ST16: SCOPE
1701 007644 012737 000005 001156      MOV     #5,STIMES   ;; DO 5 ITERATIONS
1702 007652 012737 007660 001106      MOV     #NWLN,$LPADR ;; SET SCOPE LOOP ADDRESS
1703
1704 007660 004037 015146      NWLN:   JSR     RD,RESETV   ;; RESET THE UNIT AND ENTER MAINT.MODE
1705 007664 013701 015136      MOV     TBBUF,R1
1706 007670 004037 017564      JSR     RD,LDBUF    ;; LOAD XMIT BUFFER WITH-
1707 007674          033      131      040      .BYTE  .ESC,.Y,.R00,.C20
1708 007677          064      .BYTE  .LNFED,.ESC,.0,.RDCUR,.BEL,0
1709 007700          012      033      117
1710 007703          131      007      000
1711 007706 012737 000011 015144      MOV     #9,XMCNT    ;; SETUP TO XMIT 9 CHARACTERS
1712 007714 004037 015552      JSR     RD,XMREC    ;; GO DO IT
1713 007720 000402          BR      30$        ;; NORMAL EXIT.

```

E04

```

1714 007722 104011 ERROR 11 ;TRANSMISSION CAUSED VT61 TO FAIL/HANG
1715 007724 000454 BR 4$ ;EXIT TEST
1716 007726 023777 002134 004674 30$: CMP R01C20, @RBBUF ;CHECK CURSOR POS. S/B ROW 1, COL 20.
1717 007734 001412 BEQ 3$
1718 007736 005037 001124 CLR $GDDAT
1719 007742 013737 001752 001126 MOV LNFED, $BDDAT
1720 007750 104001 ERROR 1 ;ISSUE IT
1721 007752 013746 002134 MOV R01C20, -(SP) ;:PUSH R01C20 ON STACK
1722 007756 004037 016216 JSR R0, CURER ;:SETUP AND ISSUE CURSOR ERROR
1723 007762 013701 015136 3$: MOV TBBUF, R1
1724 007766 013721 001750 MOV CARRT, (R1)+ ;LOAD XMIT BUFFER WITH
1725 007772 013721 002056 MOV ESCOI, (R1)+ ;CARRIAGE RETURN, READ CURSOR
1726 007776 013721 002052 MOV RDCUR, (R1)+ ;POSITION
1727 010002 012737 000004 015144 MOV #4, XMCNT ;SET UP TO TRANSMIT 4 CHARACTERS
1728 010010 004037 015552 JSR R0, XMREC ;GO DO IT
1729 010014 000402 BR 40$ ;NORMAL EXIT.
1730 010016 104011 ERROR 11 ;TRANSMISSION CAUSED VT61 TO FAIL/HANG
1731 010020 000416 BR 4$ ;EXIT TEST
1732 010022 023777 002132 004600 40$: CMP R01C00, @RBBUF ;CHECK CURSOR POS. S/B ROW1, COL 0.
1733 010030 001412 BEQ 4$ ;EXIT TEST IF GOOD.
1734 010032 005037 001124 CLR $GDDAT
1735 010036 013737 001750 001126 MOV CARRT, $BDDAT
1736 010044 104001 ERROR 1 ;ISSUE IT
1737 010046 013746 002132 MOV R01C00, -(SP) ;:PUSH R01C00 ON STACK
1738 010052 004037 016216 JSR R0, CURER ;:SET UP AND ISSUE CURSOR ERROR
1739 010056 000240 4$: NOP

;*****
;ROUTINE TO VERIFY PROPER OPERATION OF ERASE TO END-OF-
;SCREEN. SCREEN IS WRITTEN TO 1920 INCREMENTING CHAR.
;ERASE TO END OF SCREEN IS THEN ISSUED AND THE
;ENTIRE SCREEN IS READ VERIFYING THAT IT IS ALL NULLS.
;*****

;*****
†ST17: SCOPE
1751 010060 000004 MOV #3, $TIMES ;;DO 3 ITERATIONS
1752 010062 012737 000003 001156 20-SEP-76 10:22 PAGE 33
MAINDEC-11-DZVTH-A MACY11 27(732)
DZVTH.P11 ERROR POINTER TABLE SEQ 0044

1753 010070 012737 010076 001106 MOV #ERSE, $LPADR ;;SET SCOPE LOOP ADDRESS
1754
1755
1756 010076 004037 015146 ERSE: JSR R0, RESETV ;RESET THE UNIT -SET MAINT. MODE.
1757 010102 005077 004522 CLR @RBBUF ;CLEAR THE CHECK LOCATION.
1758 010106 004037 017124 JSR R0, DATSC ;FILL THE SCREEN.
1759 010112 013701 015136 MOV TBBUF, R1
1760 010116 004037 017564 JSR R0, LDBUF ;LOAD XMIT BUFFER WITH:
1761 010122 033 110 033 .BYTE .ESC, .CHOM, .ESC, .EOS, .ESC, .O, .XMTAL, O
1762 010125 112 033 117
1763 010130 126 000
1764 010132 113737 002130 001125 MOVVB ESCN, $GDDAT+1
1765 010140 113737 001772 001124 MOVVB EOS, $GDDAT ;LOAD ERROR WITH ERASE TO EOS
1766 010146 005037 001126 CLR $BDDAT
1767 010152 005077 004452 CLR @RBBUF
1768 010156 012737 000007 015144 MOV #7, XMCNT ;SET UP TO XMIT 7 BYTES
1769 010164 004037 015552 JSR R0, XMREC ;XMIT AND WAIT FOR REC. DONE
1770 010170 000402 BR 5$
1771 010172 104011 ERROR 11 ;ESC ERROR
1772 010174 000413 BR ERSXT ;EXIT TEST
1773 010176 127737 004426 002166 5$: CMPB @RBBUF, ZERO ;VT61 XMITTED SOM/EOM ONLY?
1774 010204 001407 BEQ ERSXT ;YES-EXIT TEST.

```

F04

1775 010206 104001  
1776 010210 004037 015530  
1777 010214 117737 004410 001126  
1778 010222 104004  
1779 010224 000240

ERROR 1 ;NO-ERASE TO END OF SCREEN  
JSR RD,CLREG ;GO CLEAR ERROR STORAGE  
MOV B 2RBBUF,\$BDDAT  
ERROR 4 ;ISSUE DATA ERROR  
ERSXT: NUP

1780  
1781  
1782  
1783  
1784  
1785  
1786  
1787  
1788  
1789  
1790  
1791  
1792  
1793  
1794  
1795  
1796

\*\*\*\*\*  
;ROUTINE TO SET UP END OF PASS INDICATION.  
;SELF TEST(ESC P T) IS ISSUED TO THE UNIT UNDER TEST  
;AND AN ERROR IS ISSUED IF THE UNIT CANNOT RESPOND AFTER  
;SELF TEST IS COMPLETE. IF SELF TEST IS SUCCESSFUL THE  
;SCREEN IS WRITTEN TO 23 LINES OF INCREMENTING CHARACTERS  
;AND 23 LINES OF INCREMENTING CHAR. IN REVERSE VIDEO.  
;THE IDENT IS THEN CHECKED AND IF A COPIER IS PRESENT A  
;COPY SCREEN COMMAND IS ISSUED(NOTE: THIS COMMAND WILL CAUSE  
;THE UNIT TO BE "BUSY" AND NOT RESPOND TO ANY FURTHER COMMANDS  
;UNTIL THE SCREEN HAS BEEN COMPLETELY COPIED.)  
\*\*\*\*\*

1797 010226 000004  
1798 010230 012737 000001 001156  
1799 010236 012737 010244 001106  
1800  
1801 010244  
1802 010244 013746 002166  
1803 010250 013746 002120  
1804 010254 013746 002056  
1805 010260 004037 013322  
1806 010264 004037 015256  
1807 010270 000407  
1808 010272 013737 001730 001124

\*\*\*\*\*  
;\*\*\*\*\*  
;\*\*\*\*\*  
TST20: SCOPE  
MOV #1,STIMES ;DO 1 ITERATION  
MOV #LSTST,\$LPADR ;SET SCOPE LOOP ADDRESS  
  
LSTST:  
MOV ZERO,-(SP) ;PUSH ZERO ON STACK  
MOV TSTER,-(SP) ;PUSH TSTER ON STACK  
MOV ESCO,-(SP) ;PUSH ESCO ON STACK  
JSR RD,TESC ;TRANSMIT IT.  
JSR RD,GETON ;GO LOOK FOR A XON.  
BR 1\$ ;VT61 RESPONDED-NOT HUNG  
MOV VRCSR,\$GDDAT ;LOAD THE ADDRESS

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 34  
DZVTH.P11 ERROR POINTER TABLE

SEQ 0045

1809 010300 013737 001740 001126  
1810 010306 104010  
1811 010310 004037 015146  
1812 010314 005037 002206  
1813 010320 042737 077577 002222  
1814 010326 012737 001001 002224  
1815 010334 013701 015136  
1816 010340 012703 000500  
1817 010344 004037 017076  
1818 010350 012737 001700 015144  
1819 010356 052777 000100 171350  
1820 010364 012746 000001  
1821 010370 012746 000012  
1822 010374 004037 020470  
1823 010400 000430  
1824 010402 005737 002206  
1825 010406 001007  
1826 010410 012703 005416  
1827 010414 004037 016076  
1828 010420 005237 002206  
1829 010424 000735  
1830 010426 032737 000001 002122  
1831 010434 001412  
1832 010436 013746 002166  
1833 010442 012746 000135  
1834 010446 013746 002100  
1835 010452 004037 013322

MOV VECT,\$BDDAT ;LOAD THE VECTOR  
ERROR 10 ;REPORT SELF TEST FAILURE  
1\$: JSR RD,RESETV ;RESET AND SET MAINT. MODE.  
CLR BUBCT ;SET UP HALF-SCREEN FLAG.  
2\$: BIC #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL.  
MOV #1001,BLKM ;SET UP TO XMIT A SOM -DATA- EOM.  
MOV TBBUF,R1 ;SET UP BEG. OF XMIT BUFFER  
MOV #320,R3 ;FILL BUFFER WITH INCREMENTING CHAR.  
JSR RD,BLDINC  
MOV #960.,XMCNT ;SEND 12 LINE TO VT61  
BIS #TENA,\$VXCSR ;ENABLE XMIT INTERRUPTS  
MOV #XMDNE,-(SP) ;PUSH #XMDNE ON STACK  
MOV #10,-(SP) ;PUSH #10. ON STACK  
JSR RD,WTBGND ;LOOK FOR XMDNE.  
BR ENDOSEL ;NOT FOUND-EXIT.  
TST BUBCT ;DONE WITH SCREEN?  
BNE 3\$ ;YES-EXIT  
MOV #SETREV,R3 ;NO-ISSUE ENTER REVERSE VIDEO  
JSR RD,LDXMIT ;ESCAPE SEQUENCE.  
INC BUBCT ;INCREMENT SCREEN HALF FLAG.  
BR 2\$ ;AND ISSUE SECOND HALF IN REV. VIDEO.  
3\$: BIT #BIT00,IDENT ;IDENT = COPIER?  
BEQ ENDOSEL ;NO  
MOV ZERO,-(SP) ;PUSH ZERO ON STACK  
MOV #.CPYSC,-(SP) ;PUSH #.CPYSC ON STACK  
MOV ESCN,-(SP) ;PUSH ESCN ON STACK  
JSR RD,TESC

GO4

1836 010456 004037 017572  
 1837 010462 105737 002174  
 1838 010466 001402  
 1839 010470 000137 003062  
 1840 010474 042777 000100 171226  
 1841  
 1842  
 1843  
 1844  
 1845  
 1846  
 1847  
 1848  
 1849  
 1850  
 1851 010502  
 1852 010502 000004  
 1853 010504 005037 001102  
 1854 010510 005037 001156  
 1855 010514 005237 001100  
 1856 010520 042737 100000 001100  
 1857 010526 005327  
 1858 010530 000001  
 1859 010532 003022  
 1860 010534 012737  
 1861 010536 000001  
 1862 010540 010530  
 1863 010542 104400 010604  
 1864 010546 013746 001100  
 MAINDEC-11-DZVTH-A MACY11 27(732)  
 DZVTH.P11 END OF PASS ROUTINE

1865 010552 104404  
 1866 010554 104400 010621  
 1867 010560  
 1868  
 1869 010560 013700 000042  
 1870 010564 001405  
 1871 010566 000005  
 1872 010570 004710  
 1873 010572 000240  
 1874 010574 000240  
 1875 010576 000240  
 1876 010600  
 1877 010600 000137 002516  
 1878 010604 005015 047105 }020104  
 1879 010612 040520 051523 }021440  
 1880 010620 000  
 1881 010621 377 377 000  
 1882  
 1883  
 1884  
 1885  
 1886  
 1887  
 1888  
 1889  
 1890  
 1891  
 1892 010624 000004  
 1893 010626 012737 000001 001156  
 1894 010634 012737 010642 001106  
 1895  
 1896 010642 004037 016136

```

JSR      RO,CKABRT ;CHECK FOR A PERIPHERAL ABORT.
MODE     ;IF IN MAN MODE DO NOT ENTER EOP.
ENDSEL:  TSTB
        BEQ     ENDP5
        JMP     ASTR1
ENDP5:   BIC     #RDENA,#VRC5R ;CLEAR REC.INT. BEFORE NEXT UNIT SELECT.
;*****
.SBTTL   END OF PASS ROUTINE

;*INCREMENT THE PASS NUMBER ($PASS)
;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO MODCA

$EOP:
        CLR     $TSTNM          ;;ZERO THE TEST NUMBER
        CLR     $TIMES          ;;ZERO THE NUMBER OF ITERATIONS
        INC     $PASS           ;;INCREMENT THE PASS NUMBER
        BIC     #100000,$PASS  ;;DON'T ALLOW A NEG. NUMBER
        DEC     (PC)+          ;;LOOP?
$EOPCT: .WORD   1
        BGT     $DOAGN          ;;YES
        MOV     (PC)+,#(PC)+    ;;RESTORE COUNTER
$ENDCT: .WORD   1
        TYPE    $ENDMG          ;;TYPE "END PASS #"
        MOV     $PASS,-(SP)     ;;SAVE $PASS FOR TYPEOUT

        TYPDS          ;;GO TYPE--DECIMAL ASCII WITH SIGN
        TYPE    ,SENUL        ;;TYPE A NULL CHARACTER
$GET42:
        MOV     #42,RO          ;;GET MONITOR ADDRESS
        BEQ     $DOAGN          ;;BRANCH IF NO MONITOR
        RESET          ;;CLEAR THE WORLD
        JSR    PC,(RO)         ;;GO TO MONITOR
        NOP          ;;SAVE ROOM
        NOP          ;;FOR
        NOP          ;;ACT11
$DOAGN:
        JMP     #MODCA         ;;RETURN
$ENDMG: .ASCIZ  <15><12>/END PASS #/

$ENULL: .BYTE  -1,-1,0          ;;NULL CHARACTER STRING
;*****
;ROUTINE TO ECHO THE KEYBOARD. KEYS FOR TAB,BELL,CARRIAGE
;AND LINE FEED ECHO A MNEMONIC, NON-DISPLAY CHAR. ECHO OCTAL
;EQUIVALENTS AND DISPLAY CHAR. ECHO THEMSELVES.
;(EXAMPLES-CHAR.,SPACE,ESC,SPACE OR 037,SPACE.) A
;CONTROL C (003) WILL CAUSE A TEST EXIT.
;*****
;*****
TST21:  SCOPE
        MOV     #1,$TIMES      ;;DO 1 ITERATION
        MOV     #KYBD,$LPADR   ;;SET SCOPE LOOP ADDRESS
KYBD:   JSR     RO,RESPTR

```

SEQ 0046



H04

```

1897 010646 012702 025634      MOV      #DKYBD,R2      ;LOAD MESSAGE ADDRESS INR2
1898 010652 004037 017172      JSR      RO,DSMES      ;DISPLAY KEYBOARD MESSAGE
1899 010656 012703 026222      MOV      #DCNTZ,R3      ;ISSUE CONTROL C EXIT MESSAGE
1900 010662 004037 016076      JSR      RO,LDXMIT
1901 010666 012703 011124      MOV      #EXMAIN,R3
1902 010672 004037 016076      JSR      RO,LDXMIT      ;ISSUE EXIT MAINTENANCE MODE.
1903 010676 042737 077577 002222 KYSTRT: BIC      #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL.
1904 010704 105777 020120      TSTB    @ABUFF        ;SEE IF A CHAR. RECEIVED
1905 010710 001001          SNE      11$          ;YES-GO PROCESS IT
1906 010712 000001          WAIT           ;WAIT FOR A CH.
1907 010714 117701 020110      11$:  MOVB    @ABUFF,R1 ;GET RAW RECEIVED DATA
1908 010720 004037 020414      JSR      RO,EXTST      ;CHECK FOR EXIT CONDITIONS
1909 010724 000402          BR       10$          ;NO EXIT -CONTINUE.
1910 010726 000137 003062      JMP      ASTAT        ;EXIT TEST 4
1911 010732 105077 020072      10$:  CLRB    @ABUFF        ;CLEAR CHAR FROM BUFFER
1912 010736 032737 000400 002222 BIT      #ESC,VSTAT    ;CHAR.=ESC(033)?
1913 010744 001405          BEQ      12$          ;NO
1914 010746 005037 014636      CLR      ESAMB        ;YES - RESET ESC ASSEMBLY FLAG
1915 010752 012703 025627      MOV      #DESC,R3      ;LOAD ESC MESSAGE ADDRESS
1916 010756 000454          BR       KYBXMT
1917 010760 120127 000041      12$:  CMPB    R1,#41      ;CHAR. LESS THAN 41 OR
1918 010764 103415          BLO      2$           ;HIGHER THAN 176, GO ECHO
1919 010766 120127 000176      CMPB    R1,#176      ;OCTAL EQUIVALENT
1920 010772 101012          BHI      2$

```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 36  
DZVTH.P11 END OF PASS ROUTINE

SEQ 0047

```

1921 010774 110177 004142      MOVB    R1,@TBUF      ;LOAD CHAR. IN XMIT BUFF.
1922 011000 004037 016026      JSR      RO,XMIT1     ;GO XMIT IT
1923 011004 112777 000040 004130 MOVB    #40,@TBUF     ;LOAD A SPACE
1924 011012 004037 016026      JSR      RO,XMIT1     ;AND XMIT IT.
1925 011016 000727          BR       KYSTRT
1926 011020 120137 001746      2$:  CMPB    R1,BEL      ;CHAR.=BELL?
1927 011024 001003          BNE      3$
1928 011026 012703 026103      MOV      #DBELL,R3    ;LOAD BELL MESSAGE ADDRESS
1929 011032 000426          BR       KYBXMT
1930 011034 120137 001754      3$:  CMPB    R1,TAB      ;CHAR. =TAB?
1931 011040 001003          BNE      4$
1932 011042 012703 026064      MOV      #DTAB,R3     ;YES-ECHO 'TAB'
1933 011046 000420          BR       KYBXMT
1934 011050 123701 001750      4$:  CMPB    CARRT,R1    ;CHAR.=CARRIAGE RETURN?
1935 011054 001003          BNE      5$
1936 011056 012703 026071      MOV      #DCR,R3      ;YES - ECHO 'C/R'.
1937 011062 000412          BR       KYBXMT
1938 011064 120137 001752      5$:  CMPB    R1,LFED     ;CHAR.=LINE FEED?
1939 011070 001003          BNE      6$          ;NO CHECK FOR CONTROL Z
1940 011072 012703 026076      MOV      #DLF,R3      ;YES - ECHO 'L/F'.
1941 011076 000404          BR       KYBXMT
1942 011100 004037 017266      6$:  JSR      RO,BINOC    ;CONVERT BINARY TO OCTAL
1943 011104 012703 002162      MOV      #SVER1,R3
1944 011110 042737 077577 002222 KYBXMT: BIC      #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL.
1945 011116 004037 016076      JSR      RO,LDXMIT    ;GO XMIT BUFFER
1946 011122 000665          BR       KYSTRT      ;WAIT FOR NEXT CHAR.

```

```

1947
1948 ;SEQUENCE TO EXIT MAINTENANCE MODE.
1949 011124 033 117 141 EXMAIN: .BYTE .ESC,.O,.DMAIN,O
1950 011127 000

```

```

1951 ;*****
1952 ;ROUTINE TO UTILIZE THE VT61 AS A PRINTER CONTROLLER.
1953 ;AFTER TEST MESSAGE IS DISPLAYED, THE TEST WAITS
1954 ;FOR A C/R BEFORE ACTUALLY ENTERING TEST. A PATTERN
1955 ;OF INCREMENTING, ROLLING CHAR. WILL BE OUTPUTTED UNTIL A
1956 ;CONTROL C(003) IS RECEIVED.
1957

```

1958  
 1959  
 1960  
 1961  
 1962 011130 000004  
 1963 011132 012737 000001 001156  
 1964 011140 012737 011146 001106  
 1965  
 1966 011146 012702 026266  
 1967 011152 004037 017172  
 1968 011156 012703 011124  
 1969 011162 004037 016076  
 1970 011166 004037 017364  
 1971 011172  
 1972 011172 013746 002166  
 1973 011176 013746 001774  
 1974 011202 013746 002130  
 1975 011206 004037 013322  
 1976 011212 013701 015136

```

;*****
;*****
†ST22: SCOPE
      MOV      #1,STIMES      ;;DO 1 ITERATION
      MOV      #TPRNT,$LPADR  ;;SET SCOPE LOOP ADDRESS

TPRNT: MOV      #DPRNT,R2     ;LOAD PRINTER MESSAGE ADDRESS
      JSR      RO,DSMES       ;AND ISSUE IT
      MOV      #EXMAIN,R3
      JSR      RO,LDXMIT      ;ISSUE EXIT MAINTENANCE MODE.
      JSR      RO,GTCR        ;GO SET CARRIAGE RETURN

3$:   MOV      ZERO,-(SP)     ;;PUSH ZERO ON STACK
      MOV      EPNT,-(SP)    ;;PUSH EPNT ON STACK
      MOV      ESCN,-(SP)    ;;PUSH ESCN ON STACK
      JSR      RO,TE$C
      MOV      T$BUF,R1      ;LOAD R1 WITH XMIT BUFFER
  
```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 37  
 DZVTH.P11 END OF PASS ROUTINE

SEQ 0048

1977 011216 012705 000041  
 1978 011222 042737 077577 002222  
 1979 011230 013701 015136  
 1980 011234 012703 000132  
 1981 011240 004037 017102  
 1982 011244 013721 001750  
 1983 011250 013721 001752  
 1984 011254 012737 000134 015144  
 1985 011262 052777 000100 170444  
 1986 011270 032737 000001 002222  
 1987 011276 001774  
 1988 011300 004037 017572  
 1989 011304 004037 020414  
 1990 011310 000402  
 1991 011312 000137 003062  
 1992 011316 122705 000177  
 1993 011322 001337  
 1994 011324 000734

```

4$:   MOV      #41,R5        ;R5=1ST CHAR
5$:   BIC      #77577,VSTAT  ;CLEAR ALL FLAGS BUT XOFF AND XMKIL.
      MOV      T$BUF,R1
      MOV      #132,R3       ;R3= LINE WIDTH
      JSR      RO,BLDINA     ;GO BUILD A SLIDING PATTERN.
      MOV      CARRT,(R1)+   ;LOAD A C/R AND L/F
      MOV      LNFED,(R1)+
      MOV      #134,XMCNT    ;SET UP TO XMIT BY BYTES.
      BIS      #TEN$,VXCSR
      BIT      #XMDONE,VSTAT ;WAIT FOR XMIT DONE
      BEQ      #-6
      JSR      RO,CKABRT     ;CHECK FOR A PERIPHERAL ABORT.
      JSR      RO,EXTST     ;CHECK FOR EXIT REQUEST.
      BR      6$            ;NO-CONTINUE
      JMP      A$TRT        ;YES-EXIT TEST!!
6$:   CMPB    #177,R5       ;EXCEEDED PATT. LIMIT?
      BNE     5$            ;NO
      BR     4$            ;YES RESET IT
  
```

```

;*****
;ROUTINE TO LOOP DATA/COMMANDS FROM THE VT61 BACK TO
;THE VT61. DATA TRANSMISSIONS RESULTING FROM A ESC
;SEQUENCE WILL ALSO BE LOOPED AND WILL ENTER THE SCREEN
;AT THE CURSOR POSITION.THIS TEST CAN BE USED TO SIMULATE,
;OR CREATE, SPECIFIC SCREEN PATTERNS AND OPERATIONS.
;*****
  
```

2005  
 2006 011326 000004  
 2007 011330 012737 000001 001156  
 2008 011336 012737 011344 001106  
 2009  
 2010 011344 004037 016136  
 2011 011350 012702 026111  
 2012 011354 004037 017172  
 2013 011360 012703 011124  
 2014 011364 004037 016076  
 2015 011370 004037 020164  
 2016 011374 000137 003062  
 2017  
 2018

```

;*****
;*****
†ST23: SCOPE
      MOV      #1,STIMES      ;;DO 1 ITERATION
      MOV      #LPTST,$LPADR  ;;SET SCOPE LOOP ADDRESS

LPTST: JSR      RO,RESPTR     ;RESET POINTERS
      MOV      #DLOOP,R2     ;LOAD LOOP MESSAGE ADDRESS
      JSR      RO,DSMES       ;DISPLAY IT
      MOV      #EXMAIN,R3
      JSR      RO,LDXMIT      ;ISSUE EXIT MAINTENANCE MODE.
      JSR      RO,LOOP        ;GO LOOP VT61
      JMP      A$TRT        ;ENTER MAN MODE VIA SCOPE ROUTINE.
  
```

;\*\*\*\*\*



# J04

; PRODUCTION, KEYBOARD TEST. ALL KEYS MUST BE DEPRESSED  
; IN THE SEQUENCE INDICATED ON THE SCREEN. ALL ERRORS  
; OR MISTAKES ARE DISPLAYED IN OCTAL POSITIONAL FORMAT AND THE  
; CORRECT KEY POSITION IN THE ROW IS DISPLAYED IN DECIMAL.  
; THIS TEST IS RUN IN MAINTENANCE MODE, THEREFORE THE KEYS  
; WILL ECHO THEIR POSITION, NOT THEIR INDICATED MNEMONIC. 10  
; ERRORS WILL CAUSE AN AUTOMATIC EXIT FROM TEST.

;\*\*\*\*\*

;\*\*\*\*\*

†ST24: SCOPE  
MOV #1,\$TIMES ;:DO 1 ITERATION  
MOV #PDKBD,\$LPADR ;:SET SCOPE LOOP ADDRESS

20-SEP-76 10:22 PAGE 38

2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030 011400 000004  
2031 011402 012737 000001 001156  
2032 011410 012737 011416 001106  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 END OF PASS ROUTINE

SEQ 0049

2033  
2034  
2035 011416 012702 026502 PDKBD: MOV #DKBD ,R2  
2036 011422 004037 017172 JSR RO ,DSMES ;:DISPLAY KEYBOARD TEST MESSAGE.  
2037 011426 005037 002206 CLR BUBCT ;:CLEAR ERROR COUNT LOCATION.  
2038 011432 005005 CLR R5  
2039  
2040 011434 016504 011560 DOAROW: MOV DTTBL(R5),R4 ;:SET UP 'GOOD' CHAR. POINTER  
2041 011440 016503 011532 MOV MSTBL(R5),R3  
2042 011444 001414 BEQ FEXIT ;:MESSAGE WAS ZERO-EXIT.  
2043 011446 100421 BMI CLMAIN ;:IF MESSAGE IS -1,CLEAR MAINT. MODE.  
2044 011450 004037 016076 JSR RO,LDXMIT ;:ISSUE 'ROW OR FUNCTION' MESSAGE.  
2045 011454 004037 017716 JSR RO,CKKBD ;:GO CHECK IT.  
2046 011460 123727 002206 000012 CMPB BUBCT,#10. ;:TEN ERROR EXIT?  
2047 011466 103401 BLO IS ;:NO-CONTINUE.  
2048 011470 000402 BR FEXIT ;:YES-EXIT TEST.  
2049 011472 005725 IS: TST (R5)+ ;:INCREMENT OFFSET.  
2050 011474 000757 BR DOAROW ;:NO-DO NEXT ROW/FUNCTION.  
2051 011476 012702 026253 FEXIT: MOV #DEXT,R2  
2052 011502 004037 017172 JSR RO,DSMES ;:ISSUE EXIT MESSAGE  
2053 011506 000137 003062 J\*P ASRT  
2054 011512 012703 011526 CLMAIN: MOV #RSMIN,R3 ;:SET UP TO EXIT MAINT. MODE.  
2055 011516 004037 016076 JSR RO,LDXMIT  
2056 011522 005725 TST (R5)+ ;:INCREMENT OFFSET.  
2057 011524 000743 BR DOAROW ;:NOW TEST CONTROL AND SHIFT FUNCTIONS.  
2058 011526 033 117 141 RSMIN: .BYTE .ESC,.0,.DMAIN,0  
2059 011531 000

; TABLE OF MESSAGE ADDRESSES.

2060  
2061  
2062  
2063  
2064 011532 026705 027012 027047 MSTBL: .WORD DTOP,DSEC,DTHRD,DBOT  
2065 011540 027176  
2066 011542 027254 027300 177777 .WORD DSPCE,DKPD,-1,DCONT,DLSHFT,DRSHFT,0  
2067 011550 027126 026633 026737  
2068 011556 000000  
2069  
2070 011560 027501 027522 027542 DTTBL: .WORD ROW1,ROW2,ROW3,ROW4,SPCB  
2071 011566 027560 027602  
2072 011572 027604 000000 027576 .WORD KYPD,0,CNTRA,SHFTA,SHFTA  
2073 011600 027600 027600

;\*\*\*\*\*

; SUBROUTINE TO ALLOW SETUP FROM MULTIPLE ENTRIES

;\*\*\*\*\*

SETA:

2074  
2075  
2076  
2077  
2078  
2079 011604

```

2080 011604 012706 001100      MOV      #SCMTAG,R6      K04      ;:FIRST LOCATION TO BE CLEARED
2081 011610 005026              CLR      (R6)+          ;:CLEAR MEMORY LOCATION
2082 011612 022706 001126      CMP      #SBDDAT,R6    ;:DONE?
2083 011616 001374              BNE     .-6            ;:LOOP BACK IF NO
2084 011620 012706 001100      MOV      #STACK,SP     ;:SETUP THE STACK POINTER
2085 011624 012737 020604 000020  MOV      #SCOPE,@IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
2086 011632 012737 000340 000022  MOV      #340,@IOTVEC+2 ;:LEVEL 7
2087 011640 012737 021060 000030  MOV      #ERROR,@EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
2088 011646 012737 000340 000032  MOV      #340,@EMTVEC+2 ;:LEVEL 7
MAINDEC-11-DZVTH-A          MACY11 27(732) 20-SEP-76 10:22 PAGE 39
DZVTH.P11                  END OF PASS ROUTINE
                                SEQ 0050

2089 011654 012737 022436 000034  MOV      #STRAP,@TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
2090 011662 012737 000340 000036  MOV      #340,@TRAPVEC+2 ;:LEVEL 7
2091 011670 012737 022276 000024  MOV      #SPWRDN,@PWRVEC ;:POWER FAILURE VECTOR
2092 011676 012737 000340 000026  MOV      #340,@PWRVEC+2  ;:LEVEL 7
2093 011704 013737 010536 010530  MOV      SENDCT,SEOPCT  ;:SETUP END-OF-PROGRAM COUNTER
2094 011712 005037 001156              CLR      $TIMES        ;:INITIALIZE NUMBER OF ITERATIONS
2095 011716 005037 001160              CLR      $ESCAPE      ;:CLEAR THE ESCAPE ON ERROR ADDRESS
2096 011722 112737 000001 001115  MOVB    #1,$ERMAX     ;:ALLOW ONE ERROR PER TEST
2097 011730 012737 011730 001106  MOV     #.,$LPAADR    ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
2098 011736 012737 011736 001110  MOV     #.,$LPERR     ;:SETUP THE ERROR LOOP ADDRESS
2099 011744 013746 000004              MOV     @#4,-(SP)     ;:SAVE ERROR VECTOR
2100 011750 013746 000006              MOV     @#6,-(SP)
2101 011754 012737 011770 000004  MOV     #1,$.4        ;:SET UP TIMEOUT VECTOR
2102 011762 005777 167150              TST    @SWR           ;:TRY TO REFERENCE HARDWARE SWR
2103 011766 000407              BR     2$            ;:BRANCH IF NO TIMEOUT TRAP OCCURS
2104 011770 012737 000176 001136 1$: MOV    #SWREG,SWR    ;:POINT TO SOFTWARE SWITCH REG.
2105 011776 012737 000174 001140  MOV    #DISPREG,DISPLAY ;:POINT TO SOFTWARE DISPLAY REG.
2106 012004 022626              CMP    (SP)+,(SP)+   ;:RESTORE STACK
2107 012006 012637 000006 2$: MOV    (SP)+,@#6    ;:RESTORE ERROR VECTOR
2108 012012 012637 000004              MOV    (SP)+,@#4
2109 012016 104400 022542              TYPE   $STUPM        ;:ISSUE SET-UP MESSAGE.
2110 012022 012737 012042 000010  MOV    #TRPA,@#10    ;:AND VECTOR
2111 012030 000230              SPL    0             ;:PROCESSOR IS 11/45?
2112 012032 012737 000004 017072  MOV    #4,PMULT      ;:YES-DELAY MULTIPLIER = 4
2113 012040 000416              BR     RTRP
2114
2115 012042 022626              TRPA:  POP2SP        ;:NO
2116 012044 012737 012066 000010  MOV    #TRPB,@#10    ;:RELOAD TRAP ADDRESS
2117 012052 006737 002160              SXT    CHRD          ;:PROCESSOR IS 11/40 OR 35?
2118 012056 012737 000002 017072  MOV    #2,PMULT      ;:YES-DELAY MULTIPLIER=2
2119 012064 000404              BR
2120
2121 012066 022626              TRPB:  POP2SP
2122 012070 012737 000001 017072  MOV    #1,PMULT      ;:PROCESSOR MUST BE 11/05
2123 012076 012737 000012 000010  RTRP:  MOV    #12,@#10 ;:RESTORE TRAP CATCHER
2124 012104 105737 002174              TSTB   MODE          ;:CHECK MODE FOR CORRECT EXIT.
2125 012110 001402              BEQ    70$
2126 012112 000137 002274              JMP    MANSA         ;:EXIT TO MANUAL SELECT
2127 012116 000137 002240 70$:  JMP    AUTOA         ;:EXIT TO AUTO MODE.
2128 ;*****
2129 ;THIS ROUTINE MAPS ALL POSSIBLE DL11 ADDRESSES AND STORES
2130 ;THEM IN A TABLE (INTAB). ALL ADDRESSES WHICH DO NOT
2131 ;RESULT IN TIMEOUTS ARE STORED.
2132 ;*****
2133
2134 012122 012701 000300  TRPVEC: MOV    #300,R1    ;:START AT BEG. OF FLOATING VECTORS
2135 012126 012702 000302              MOV    #302,R2
2136 012132 012703 000004              MOV    #4,R3        ;:R3 CONTAINS IOT TRAP INST.
2137 012136 010221 1$:  MOV    R2,(R1)+      ;:START LOADING ADDRESSES
2138 012140 010321              MOV    R3,(R1)+      ;:LOAD THE TRAP
2139 012142 062702 000004              ADD    #4,R2         ;:ASSUME 4 REGISTERS PER INTERFACE
2140 012146 020127 001000              CMP    R1,#1000     ;:DONE?

```

L04

```

2141 012152 002771          BLT      1$          ;NO CONTINUE LOADING TRAPS
2142 012154 012737 000340 000006      MOV      #340,2#6    ;SET TIMEOUT TRAP TO A PSW OF 7.
2143 012162 012737 012222 000004      MCV      #TPENT,2#4  ;SET UP TIME-OUT TRAP ADDRESS
2144 012170 005001          CLR      R1          ;CLEAR THE TABLE POINTER
MAINDEC-11-DZVTH-A  MACY11 27(732) 20-SEP-76 10:22 PAGE 40
DZVTH.P11          END OF PASS ROUTINE
                                           SEQ 0051

2145 012172 012705 001650          MOV      #INTAB,R5   ;R5=DESTINATION TABLE
2146 012176 016102 001714      FADD:   MOV      STRTAB(R1),R2 ;PUT THE ADDRESS TO BE TESTED IN R2
2147 012202 026102 001722      TRPE:   CMP      ENDTAB(R1),R2 ;HAVE WE EXCEEDED END OF TABLE ADDRESS?
2148 012206 103407          BLO     TBLCK       ;YES GET NEXT BASE ADDRESS.
2149 012210 005712          TST     2R2        ;ADDRESS THE DEVICE IF POSSIBLE
2150 012212 010225          MOV     R2,(R5)+    ;IF WE GOT THIS FAR THERE IS A DEVICE THERE-SAVE IT
2151 012214 062702 000010      FADD1:  ADD      #10,R2    ;INCREMENT TO THE NEXT POSSIBLE ADDRESS
2152 012220 000770          BR      TRPE       ;GO TEST THE NEXT ADDRESS
2153 012222 022626          TPENT:  POP2SP      ;RESTORE THE STACK AND TEST
2154 012224 000773          BR      FADD1      ;NEXT ADDRESS
2155 012226 005721          TBLCK:  TST      (R1)+    ;BUMP AREA COUNTER BY 2.
2156 012230 032701 000004          BIT     #BIT02,R1   ;SEE IF BOTH DL11 AREAS CHECKED.
2157 012234 001760          BEQ     FADD       ;NO-GO CHECK THE OTHER AREA
2158 012236 005015          CLR     (R5)       ;SET UP TABLE TERMINATOR OF ZEROS.
2159 012240 000200          RTS     R0
2160 ;*****
2161 ;THIS ROUTINE WILL INSURE THAT THE DEVICE(DL11)
2162 ;WILL INTERRUPT WHEN XMIT INT. ENABLE BIT IS SET.
2163 ;*****
2164
2165 012242 005046          CDEV:   CLR      -(SP)    ;CLEAR THE PSW,LSI11 STYLE.
2166 012244 012746 012252          MOV     #100$,-(SP)
2167 012250 000002          RTI
2168 012252 012737 000004 000004 100$:  MOV     #4,2#4      ;INSTALL IOT TRAP INST. AT LOCATION 4.
2169 012260 012737 012356 000020      MOV     #TDEV,2#IOTVEC ;SET UP IOT TRAP EXIT ADDRESS
2170 012266 012737 000340 000022      MOV     #340,2#IOTVEC+2 ;SET PSW TO 7-ALLOW NO OTHER INTERRUPTS
2171 012274 000005          RESET    ;INSURE ALL XMIT FLAGS HIGH.
2172 012276 012703 001550          MOV     #VVECT,R3   ;VECTOR STORAGE ADDRESS SET
2173 012302 012702 001650          MOV     #INTAB,R2   ;PRIMARY DEVICE TABLE ADDRESS SET
2174 012306 012705 001610          MOV     #DLTBL,R5   ;FIN DEVICE TABLE ADDRESS SET.
2175 012312 012701 001730      CDEVA:  MOV     #VRCSR,R1  ;VT61 DEVICE ADDRESS SET.
2176 012316 005712          TST     (R2)        ;CHECKED ALL DEVICES?
2177 012320 001506          BEQ     AOUT        ;YES-EXIT
2178 012322 100403          BMI     1$         ;INSURE ADDRESS IS IN PROPER RANGE(17XXXX)
2179
2180 012324 062702 000002          ADD     #2,R2       ;ADDRESS IS DEFINITELY NOT GOOD -PURGE
2181 012330 000770          BR      CDEVA      ;AND LOOK FOR ANOTHER.
2182 012332 004037 013040          1$:    JSR     RD,LDADD   ;LOAD NEXT ADDRESSES TO BE CHECKED
2183 012336 012701 001200          MOV     #1200,R1    ;NOW USE R1 AS FAILSAFE COUNTER
2184 012342 052777 000100 167364      BIS     #TENA,2#VXCSR ;SET XMIT ENABLE
2185 012350 005301          DEC     R1          ;IF DEVICE DOES NOT INTERRUPT WITHIN
2186 012352 001376          BNE     -2         ;APPROX. 200US IT IS NOT A DL11.
2187 012354 000756          BR      CDEVA      ;THEREFORE, GO TRY ANOTHER DEVICE.
2188 012356 042777 000100 167350      TDEV:  BIC     #TENA,2#VXCSR ;CLEAR XMIT ENABLE.
2189 012364 162716 000010          SUB     #10,(R6)    ;RESET TO RECEIVER VECTOR ADDRESS
2190 012370 012613          MOV     (R6)+,(R3) ;STORE IT IN VECTOR TABLE(VVECT).
2191 012372 005726          TST     (R6)+      ;POP THE OLD PSW AND DISCARD
2192 012374 022626          POP2SP ;POP THE ADD. AND PSW PRIOR TO INTERRUPT.
2193 ;*****
2194 ;THIS ROUTINE IS A QUICK TEST OF ANY DL11 ENCOUNTERED
2195 ;A DATA PATTERN WILL BE RUN ON ALL ENTRIES IN INTAB
2196 ;*****
2197 012376 005046          CLR     -(SP)      ;CLEAR THE PSW,LSI11 STYLE.
2198 012400 012746 012406          MOV     #100$,-(SP)
2199 012404 000002          RTI
2200 012406 012301          100$:  MOV     (R3)+,R1    ;GET THE RECEIVE VECTOR ADDRESS
MAINDEC-11-DZVTH-A  MACY11 27(732) 20-SEP-76 10:22 PAGE 41

```

```

2201 012410 012721 013650      MOV      #RECAD,(R1)+      ;AND STORE SAME.
2202 012414 012721 000340      MOV      #340,(R1)+      ;SET RECEIVE PSW TO 7.
2203 012420 012721 013732      MOV      #TSMAD,(R1)+    ;STORE THE XMIT VECTOR ADDRESS
2204 012424 012711 000340      MOV      #340,(R1)      ;SET XMIT PSW TO 7.
2205 012430 012704 000001      MOV      #BIT00,R4      ;R4 IS NOW DATA PATTERN OF 1.
2206 012434 005001              CLR      R1              ;SET UP FAILSAFE DELAY.
2207 012436 052777 000100 167264  BIS      #RDENA,@VRCSR    ;SET RECEIVE ENABLE.
2208 012444 052777 000104 167262  BIS      #TCOMB,@VXCSR    ;ENABLE XMIT INT. AND MAINTENACE .
2209 012452 105704              1$: TSTB   R4              ;XMIT PATTERN COMPLETE?
2210 012454 001423              BEQ      GDAD            ;YES GO STORE THIS ADDRESS
2211 012456 005301              DEC      R1              ;CYCLE TIMEOUT DELAY
2212 012460 001374              BNE     1$              ;NOT YET 'TIMEOUT' KEEP CYCLING.
2213 012462 162703 000002      SUB      #2,R3          ;RESET VECTOR POINTER
2214 012466 042777 000104 167240  BIC      #TCOMB,@VXCSR    ;CLEAR XMIT AND RECEIVE INT. ENABLES.
2215 012474 042777 000100 167226  BIC      #RDENA,@VRCSR
2216 012502 104400 023020      TYPE    ,DLERR          ;ISSUE DL11 FAILURE MESSAGE.
2217 012506 013746 001730      MOV      VRCSR,-(SP)     ;SAVE VRCSR FOR TYPEOUT
2218                                ;TYPE BD. ADDRESS
2219 012512 104402              TYPOS                                ;GO TYPE--OCTAL ASCII
2220 012514 006                                .BYTE 6                      ;TYPE 6 DIGIT(S)
2221 012515 001                                .BYTE 1                      ;TYPE LEADING ZEROS
2222 012516 104400 001167      TYPE    ,SCRLF
2223 012522 000673              BR      CDEVA            ;GO TRY ANOTHER SET OF ADDRESSES.
2224 012524 013725 001730  GDAD:  MOV      VRCSR,(R5)+    ;SAVE GOOD ADDRESS IN DL TABLE
2225 012530 005077 167176      CLR      @VRBUF         ;CLEAR ANY RECEIVE FLAG STILL SET.
2226 012534 000666              BR      CDEVA            ;CHECK ANOTHER DL11
2227 012536 005015  AOUT:  CLR      (R5)          ;SET A ZERO TABLE TERMINATOR.
2228 012540 012737 000006 000004  MOV      #6,@#4         ;RESTORE LOCATION 4 TO HALT CONDITION
2229 012546 005037 000006      CLR      @#6           ;TO CATCH ERRORS AND ILLEGAL INTERRUPTS.
2230 012552 012737 020604 000020  MOV      #SSCOPE,@#IOTVEC ;RELOAD IOT VECTOR FOR SCOPE
2231 012560 012737 000340 000022  MOV      #340,@#IOTVEC+2 ;LOOP.
2232 012566 012701 000300      MOV      #300,R1
2233 012572 012702 000302      MOV      #302,R2
2234 012576 010221  1$:  MOV      R2,(R1)+
2235 012600 005021              CLR      (R1)+          ;RESTORE HALTS TO ALL LOCATIONS CONTAINING IOTS
2236 012602 062702 000004      ADD      #4,R2
2237 012606 020127 001000      CM?     R1,#1000        ;TO LOCATION 1000
2238 012612 103771              BLO     1$
2239 012614 000005              RESET
2240 012616 000200              RTS      R0              ;CLEAR ALL FLAGS

```

```

;*****
;INITIALIZATION ROUTINE FOR AUTO SELECTION. THIS ROUTINE
;WILL INSURE THAT ALL DL11S IN DLTBL HAVE A VT61 CONNECTED
;ALL UNITS WHICH CANNOT CORRECTLY RESPOND WILL BE PURGED.
;*****

```

```

2248 012620 012702 001610  INITA:  MOV      #DLTBL,R2      ;R2 POINTS TO DL11 ADDRESS TABLE
2249 012624 012703 001550      MOV      #VVECT,R3      ;R3 POINTS TO DL11 VECTOR
2250 012630 012701 001730  11$:  MOV      #VRCSR,R1      ;POINTER TO VT61 DL11
2251 012634 005712              TST      (R2)            ;SEE IF ALL CHECKED
2252 012636 001447              BEQ      INTXT           ;YES-EXIT
2253 012640 004037 013040      JSR      RO,LOADD        ;NO-GO LOAD THE ADDRESSES
2254 012644 062703 000002      ADD      #2,R3          ;UPDATE VECTOR COUNT
2255 012650 004037 015326      JSR      RO,ZFLAG        ;ISSUE ESCZ AND LOOK FOR RESPONSE.
2256 012654

```

```

2257 012654 012637 002160      MOV      (SP)+,CHR      ;POP STACK INTO CHR
2258 012660 100414              BMI     5$              ;TIMEOUT OCCURRED NO CHARACTER
2259 012662 123727 002160 000140  CMPB   CHRD,#140        ;CHECK IDENT FOR VT61 IDENTIFIERS

```

N04

```

2260 012670 103410          BLO      5$      ;NOT A VT61-SET UP TO PURGE ADDRESS
2261 012672 123727 002160 000172  CMPB    CHRDL,#172 ;IDENTS ARE SMALL A THRU Z
2262 012700 101004          BHI      5$      ;NOT A VT61-PURGE
2263 012702          4$:
2264 012702 012637 002160      MOV     (SP)+,CHRD ;;POP STACK INTO CHRD
2265 012706 001375          BNE     4$
2266 012710 000747          BR      11$      ;TEST ANOTHER ADDRESS
2267 012712          5$:
2268 012712 012637 002160      MOV     (SP)+,CHRD ;;POP STACK INTO CHRD
2269 012716 001375          BNE     5$
2270 012720 162702 000002      SUB     #2,R2      ;RESET ADDRESS AND VECTOR FOINTERS'
2271 012724 162703 000002      SUB     #2,R3
2272 012730 010246          MOV     R2,-(SP)   ;;PUSH R2 ON STACK
2273 012732 012746 000001      MOV     #1,-(SP)  ;;PUSH #1 ON STACK
2274 012736 004037 013250      JSR    RO,BBLUP
2275 012742 010346          MOV     R3,-(SP)   ;;PUSH R3 ON STACK
2276 012744 012746 000001      MOV     #1,-(SP)  ;;PUSH #1 ON STACK
2277 012750 004037 013250      JSR    RO,BBLUP
2278 012754 000725          BR      11$      ;TRY ANOTHER DL11 ADDRESS.
2279
2280 012756 005737 001610      INTXT: TST     DLTBL ;CHECK TO INSURE GOOD ADDRESSES
2281 012762 001012          BNE     EXINT     ;YES-GO TO NEXT TEST
2282 012764 104400 022727          TYPE   ,NOVT     ;NO-ISSUE NO VT61 MESSAGE.
2283 012770 012737 005670 017074      MOV     #3000.,DCOUNT ;SET DELAY TO 30 SEC.
2284 012776 004037 017032          JSR    RO,DELAY   ;AND DO IT.
2285 013002 062700 000004          ADD     #4,RO     ;SET UP 'NO VT61 FOUND' EXIT
2286 013006 000200          RTS     RO
2287 013010 012702 001610      EXINT: MOV     #DLTBL,R2 ;LOAD AND ISSUE GOOD ADDRESSES
2288 013014 104400 022656          TYPE   ,DUNTST  ;OF RESPONSIVE VT61S.
2289 013020          1$:
2290 013020 012246          MOV     (R2)+,-(SP) ;;SAVE (R2)+ FOR TYPEOUT
2291
2292          ;;TYPE AN ADDRESS
2293 013022 104402          TYPOS
2294 013024 006          .BYTE 6          ;;GO TYPE--OCTAL ASCII
2295 013025 001          .BYTE 1          ;;TYPE 6 DIGIT(S)
2296 013026 104400 001167          TYPE 1$CRLF     ;;TYPE LEADING ZEROS
2297 013032 005712          TST     (R2)      ;AT END OF GOOD UNITS?
2298 013034 001371          BNE     1$        ;NO PRINT ANOTHER ADDRESS.
2299 013036 000200          RTS     RO
;*****

```

# 805

:SUBROUTINE TO LOAD 4 ADDRESSES FROM THE LOCATION AT (R2).  
:TO 4 LOCATION POINTED TO BY R1(TO VXBUF+2).ROUTINE USES R4 AS  
:WORK REG AND EXITS WITH R2 INCREMENTED BY 2.

:\*\*\*\*\*

013040 012204  
013042 010421  
013044 052704 000002  
013050 020127 001740  
013054 002772  
013056 000200

LCADD: MOV (R2)+,R4 ;LOAD THE ADDRESS  
IS: MOV R4,(R1)+ ;STORE AN ADDRESS  
ADD #2,R4 ;INCREMENT ADDRESS  
CMP R1,#VXBUF+2 ;LOADED 4?  
BLT IS ;NO LOAD ANOTHER  
RTS R0 ;YES-EXIT

:\*\*\*\*\*

NOV-11-DZVTH-A MACY11 27(732)  
H.P.1 END OF PASS ROUTINE

20-SEP-76 10:22 PAGE 43

SEQ 0054

:ROUTINE TO RECEIVE CHARACTER(S). ENTERED WITH  
:NUMBER OF CHARACTERS TO RECEIVE ON THE STACK.  
:ROUTINE EXITS WITH CHARACTER(S) ON STACK. IF A  
:PROGRAM TIME-OUT (100 M.S.) OCCURS BEFORE A CHARACTER  
:IS RECEIVED ROUTINE EXITS WITH -1 ON STACK. FORMAT  
:FOR DATA IS (BYTE2, BYTE1) ETC. A WORD OF ZEROS TERMINATES  
:DATA STRING ON THE STACK. SOM/EOM, IF SENT, ARE RECEIVED  
:BUT NOT STORED.

:\*\*\*\*\*

013060  
013060 012637 002220  
013064 012637 002206  
013070 013746 002166  
013074 005037 002160  
013100 005037 002216  
013104 032777 000200 166616  
013112 001007  
013114 005337 002216  
013120 001371  
013122 012737 177777 002160  
013130 000442  
013132 117737 166574 002160  
013140 042737 000200 002160  
013146 122737 000057 002160  
013154 001007  
013156 105337 002207  
013162 001757  
013164 123727 002207 000213  
013172 103740  
013174 122737 000002 002160  
013202 001003  
013204 105237 002206  
013210 000731  
013212 122737 000004 002160  
013220 001410  
013222 105337 002206  
013226 001403  
013230 013746 002160  
013234 000717  
013236  
013236 013746 002160  
013242  
013242 013746 002220  
013246 000200

RECTM: MOV (SP)+,ROSVE ;POP STACK INTO ROSVE  
MOV (SP)+,#BUBCT ;POP STACK INTO #BUBCT  
MOV ZERO,-(SP) ;PUSH ZERO ON STACK  
IS: CLR CHR0 ;CLEAR CHARACTER STORAGE LOCATION.  
CLR DLAY ;SET UP FAILSAFE DELAY  
3S: BIT #RECDN,#VRC5R ;SEE IF DONE FLAG SET  
BNE 4S  
DEC DLAY ;DECREMENT FAILSAFE CNTR.  
BNE 3S ;NOT AT ZERO-CONTINUE WAITING.  
31S: MOV #-1,CHR0 ;SET UP FOR FAILSAFE EXIT.  
BR RECEX ;EXIT ROUTINE.  
4S: MOVB #VXBUF,CHR0 ;STORE THIS CHARACTER.  
BIC #200,CHR0 ;STRIP PARITY BIT.  
CMPB #SLSH,CHR0 ;RECEIVED A IDENT SLASH(57)?  
BNE 41S ;NO-STORE A CHARACTER.  
DECB BUBCT+1 ;DECREMENT ALLOWABLE SLASH COUNT.  
BEQ 31S ;COUNT EQUAL ZERO-SET UP ERROR EXIT.  
CMPB BUBCT+1,#139. ;RECEIVED FIRST SLASH?  
BLO IS ;YES-IGNORE THIS ONE.  
41S: CMPB #SOM,CHR0 ;IS CHAR. ACTUALLY SOM?  
BNE 5S ;NO  
INCB BUBCT ;YES -SET UP TO RECEIVE EOM ALSO  
IS ;AND RECEIVE NEXT CHAR.  
5S: CMPB #EOM,CHR0 ;CHAR. = EOM?  
BEQ RECEXA ;YES- DO NOT PUSH IT ON STACK  
DECB BUBCT ;DECREMENT CHARACTER COUNT.  
BEQ RECEX ;COUNT=0. EXIT WERE DONE.  
MOV CHR0,-(SP) ;PUSH CHR0 ON STACK  
BR IS ;GO READ AGAIN.

RECEX: MOV CHR0,-(SP) ;PUSH CHR0 ON STACK  
RECEXA: MOV ROSVE,-(SP) ;PUSH ROSVE ON STACK  
RTS R0

2360  
2361  
2362  
2363  
2364  
2365  
2366  
2367  
2368

```
*****
; THIS ROUTINE WILL 'BUBBLE UP' XX WORDS TO
; ELIMINATE NON-RESPONSIVE ADDRESSES. ENTERED
; WITH ADDRESS TO BE 'BUBBLED' TO ON THE STACK. LOCATIONS
; ELIMINATED WILL BE FILLED WITH ZEROS. THE STACK MUST ALSO
; BE LOADED WITH THE NUMBER OF POSITIONS TO BUBBLE.
*****
```

MAINDEC-11-02VTH-A MACY11 27(732)  
CZVTH.P11 END OF PASS ROUTINE

20-SEP-76 10:22 PAGE 44

SEQ 0055

2369  
2370  
2371  
2372  
2373  
2374  
2375  
2376  
2377  
2378  
2379  
2380  
2381  
2382  
2383  
2384  
2385  
2386  
2387  
2388  
2389  
2390  
2391  
2392  
2393  
2394  
2395  
2396  
2397  
2398  
2399  
2400  
2401  
2402  
2403  
2404  
2405  
2406  
2407  
2408  
2409  
2410  
2411  
2412  
2413  
2414  
2415  
2416  
2417  
2418  
2419  
2420

013250 012637 002220  
013250 012637 002206  
013260 012637 002204  
013264 010446  
013266 013704 002204  
013272 012437 002160  
013276 012464 177774  
013302 001375  
013304 005337 002206  
013310 001366  
013312  
013312 012604  
013314 013746 002220  
013320 000200  
  
013322  
013322 012637 002220  
013326 010437 002206  
013332 112777 000002 166376  
013340 012705 177777  
013344 012604  
013346 001415  
013350 110405  
013352 105704  
013354 001406  
013356 032777 000200 166350  
013364 001774  
013366 110477 166344  
013372 000304  
013374 120405  
013376 001760  
013400 000764  
013402 032777 000200 166324  
013410 001774  
013412 012777 000004 166316  
013420 032777 000200 166306  
013426 001774  
013430 013704 002206  
013434 013746 002220  
013440 000200

```
BBLUP:
MOV (SP)+, ROSVE ;; POP STACK INTO ROSVE
MOV (SP)+, BUBCT ;; POP STACK INTO BUBCT
MOV (SP)+, TOADD ;; POP STACK INTO TOADD
MOV R4, -(SP) ;; PUSH R4 ON STACK
2$: MOV @TOADD, R4 ;; PUT LAST GOOD DL11 ADDRESS IN R4
MOV (R4)+, CHRD ;; MOVE NEXT WORD TO CHRD FOR STORAGE
1$: MOV (R4)+, -4(R4) ;; BUBBLE UP DATA.
BNE 1$ ;; BUBBLE UNTIL ZERO BYTE MOVED.
DEC BUBCT ;; SUBTRACT ONE FROM BUBBLE COUNT.
BNE 2$ ;; IF BUBBLE COUNT NOT ZERO - DO AGAIN.

3$: MOV (SP)+, R4 ;; POP STACK INTO R4
MOV ROSVE, -(SP) ;; PUSH ROSVE ON STACK
RTS RD ;; YES-EXIT
```

```
*****
; THIS ROUTINE OUTPUTS THE ESC SEQUENCE FOUND ON
; THE STACK. A WORD OF ZEROS MUST TERMINATE THE SEQUENCE.
; FORMAT FOR STACK WORD IS SEQ-ESC, IE-XXX033.
*****
```

```
TESC:
MOV (SP)-, ROSVE ;; POP STACK INTO ROSVE
MOV R4, BUBCT ;; SAVE R4.
MOV B, @SOM, @VXBUF ;; SEND A START OF MESSAGE.
1$: MOV #1, R5 ;; ALL ONES THO CHECK LOCATION.
MOV (R6)+, R4 ;; GET COMMAND FROM STACK.
BEQ 3$ ;; IF ZERO TERMINATOR FOUND-EXIT.
MOV B, R4, R5 ;; LOAD CHECK BYTE.
2$: TSTB R4 ;; CHECK BYTE FOR A ZERO.
BEQ 20$ ;; IF ZERO-DO NOT XMIT IT.
BIT #TRDY, @VXCSR
BEQ .-6 ;; WAIT FOR XMIT READY BIT
MOV B, R4, @VXBUF ;; XMIT A BYTE.
20$: SWAB R4 ;; GET THE OTHER BYTE.
CMPB R4, R5 ;; IF GOOD COMPARE WE HAVE CHECKED BOTH
BEQ 1$ ;; BYTES SO POP ANOTHER WORD.
BR 2$ ;; GO XMIT ANOTHER BYTE
3$: BIT #TRDY, @VXCSR ;; SEE IF READY SET
BEQ .-6
MOV #EOM, @VXBUF ;; SEND A EOM.
BIT #TRDY, @VXCSR ;; SEE IF READY SET
BEQ .-6
MOV BUBCT, R4 ;; RESTORE R4.
MOV ROSVE, -(SP) ;; PUSH ROSVE ON STACK
RTS RD
```

```
*****
; ROUTINE TO READ A CHARACTER FROM THE CONSOLE.
; EXITS WITH CHARACTER ON THE STACK.
*****
```



013442 012637 002220  
013442 001774 MACY11 27(732)  
MAINDEC-11-DZVTH-A 20-SEP-76 10:22 PAGE 45  
DZVTH.P11 END OF PASS ROUTINE

\*\*\*\*\*

CONRD: MOV (SP)+,ROSVÉ ;:POP STACK INTO ROSVE  
20-SEP-76 10:22 PAGE 45

SEQ 0056

013446 032777 000200 165466  
013454 001774  
013456 117746 165462  
013462 042716 000200  
013466 013746 002220  
013472 000200

BIT #RECDN,#STKS ;:LOOK FOR DONE BIT  
BEQ #-5 ;:WAIT FOR IT  
MOVB #STKB,-(R6) ;:PUSH CHARACTER TO STACK  
BIC #200,(R6) ;:STRIP ANY PARITY BIT.  
MOV ROSVÉ,-(SP) ;:PUSH ROSVE ON STACK  
RTS RO

\*\*\*\*\*  
;MANUAL TEST SELECT MONITOR  
;SELECTS TESTS TO BE EXECUTED FROM THOSE ENTERED IN  
;INITIAL DIALOGUE. IF TEST 377 WAS REQUESTED THE TESTS WILL  
;REPEAT INFINITELY.  
\*\*\*\*\*

013474 105737 002174  
013500 001012  
013502 023737 002176 002200  
013510 103405  
013512 104400 024461  
013516 000005  
013520 000137 011604  
013524 000200  
013526 005726  
013530 022626  
013532 005037 002176  
013536 032777 000200 165376  
013544 001407  
013546 117701 165372  
013552 042701 000200  
013556 122701 000003  
013562 001755  
013564 117701 166402  
013570 003005  
013572 042777 000100 166130  
013600 000137 002516  
013604 005301  
013606 006301  
013610 016137 022472 013646  
013616 062737 000002 013646  
013624 005237 002172  
013630 005037 177776  
013634 005046  
013636 012746 013644  
013642 000002  
013644 000137 013644

MONIT: TSTB MODE ;:TEST MODE SWITCH  
BNE 1\$ ;:MANUAL MODE  
CMP FTLCNT,ALWCNT ;:COMPARE FATAL XIMITS WITH ALLOWED.  
BLO 100\$ ;:FATALS LESS THAN ALLOWED-CONTINUE.  
TYPE ,DABRT ;:ISSUE ABORT MESSAGE.  
200\$: RESET ;:CLEAR ALL INTERFACE FLAGS.  
JMP SETA ;:SET UP TO RESTART TEST.  
100\$: RTS RO ;:AUTO MODE  
1\$: TST (R6)+ ;:POP THE STACK  
POP2SP ;:POP SCOPE RETURN AND VECTOR  
CLR FTLCNT ;:DO NOT INC. FATAL COUNT IN MANUAL MODE.  
10\$: BIT #RECDN,#STKS ;:CONSOLE ACTIVE?  
BEQ 11\$  
MOVB #STKB,R1 ;:STORE INPUT BUFFER  
BIC #200,R1 ;:CLEAR THE PARITY BIT  
CMPB #3,R1 ;:CHAR. EQUAL ESC. C?  
BEQ 200\$ ;:YES-EXIT  
11\$: MOVB #TSTPTR,R1 ;:GET THE NEXT TEST #  
BGT 2\$ ;:NOT AT END OF LIST  
BIC #RDENA,#VRCR ;:CLEAR REC. INTERRUPTS BEFORE NEXT UNIT SELECT.  
JMP MODCA ;:END OF LIST-GO SET UP NEXT 61  
2\$: DEC R1 ;:ADJUST OFFSET  
ASL R1 ;:USE TEST # TO FORM ADDRESS OFFSET  
MOV TSTADD(R1),JMPADD+2 ;:LOAD NEW ADDRESS  
ADD #2,JMPADD+2 ;:BYPASS INITIAL SCOPE LOOP  
INC TSTPTR ;:INCREMENT TEST OPINTER  
CLR PSW ;:SET NON-INT. PRIORITY TO ZERO  
CLR -(SP) ;:CLEAR THE PSW,LSI 11 STYLE.  
MOV #JMPADD,-(SP)  
RTI  
JMPADD: JMP JMPADD ;:EXIT TO NEXT SELECTED TEST

\*\*\*\*\*  
;FOLLOWING ROUTINES ARE INTERRUPT HANDLERS FOR THE  
;DL11 QUICK-TEST.  
\*\*\*\*\*

013650 117737 166056 002160  
013656 042737 000200 002160  
013664 120437 002160  
013670 001407  
013672 042777 000104 166034  
MAINDEC-11-DZVTH-A MACY11 27(732)

RECAD: MOVB #VRBUF,CHRD ;:GET THE RECEIVED CHAR.  
BIC #200,CHRD ;:CLEAR ANY PARITY.  
CMPB R4,CHRD ;:COMPARE RECEIVED TO XMITTED  
BEQ UPD4 ;:AND UPDATE PATTERN IF OK.  
TOFF: BIC #TCOMB,#VXCSR ;:DATA ERROR OCCURED OR WE ARE DONE  
20-SEP-76 10:22 PAGE 46



```

2481 013700 042777 000100 166022 REEX: BIC #RDENA,#VRCSR ;EITHER WAY-EXIT.
2482 013706 000002 RTI
2483 013710 052777 000100 166016 UPD4: BIS #TENA,#VXCSR ;ENABLE XMIT INT.
2484 013716 106304 ASLB R4 ;UPDATE DATA PATTERN.
2485 013720 032704 000200 BIT #BIT07,R4 ;ROTATED TO PARITY BIT?
2486 013724 001770 BEQ REEX ;NO-CONTINUE TESTING
2487 013726 005004 CLR R4 ;YES-SET UP COMPLETE FLAG
2488 013730 000760 BR TOFF ;AND EXIT.
2489 013732 110477 166000 TSMAD: MOVB R4,#VXBUF ;XMIT DATA
2490 013736 042777 000100 165770 BIC #TENA,#VXCSR ;CLEAR XMIT INT. UNTIL LAST BIT REC.
2491 013744 000002 RTI

```

```

;*****
;RECEIVE INTERRUPT ROUTINE.AFTER EACH RECEIVE
;CYCLE BUFFER POINTER (RBUF) WILL BE SET TO (RBBUF).
;MAX. EXECUTION TIME IS APPROX 200US, AVERAGE =100US.
;UPON RECEIPT OF XON, XMKIL BIT IS CHECKED IN VSTAT
;AND IF SET, WILL BE CLEARED AND XMIT INT. ENABLE SET.
;LOCATION ESAMB IS USED FOR ESC ASSEMBLY FLAGS. IE. BIT
;DO SET MEANS A033 WAS RECEIVED, BIT 01 SET MEANS AN ESCP
;SEQUENCE IS BEING ASSEMBLED. BIT 03
;SET INDICATES AND ESCAPE 0 SEQUENCE IS BEING ASSEMBLED.
;LOCATIONS STRO AND STRP ARE USED TO STORE ESCAPE
;0 AND ESCAPE P SEQUENCES DETECTED,BUT NOT UTILIZED IN TEST.
;*****

```

```

2507 013746 INTRC: MOV R1,-(SP) ;:PUSH R1 ON STACK
2508 013746 010146 MOV #VRBUF,R1 ;:USE R1 FOR STORAGE OF STATUS AND CH.
2509 013750 017701 165756 BIC #200,R1 ;:STRIP PARITY BIT.
2510 013754 042701 000200 BIT #TXSUM,VSTAT ;:CHECKSUM CALCULATION REQUESTED?
2511 013760 032737 000100 002222 BEQ 11$ ;:NO
2512 013766 001403 MOV R1,R5 ;:YES-STORE CHAR. AND
2513 013770 010105 JSR RD,CALCK ;:CALCULATE THE CHECKSUM.
2514 013772 004037 017516 INC ABUF ;:INCREMENT THE RAW DATA POINTER
2515 013776 005237 031030 11$: CMP ABUF,#ABBUF+50. ;:AT THE END OF BUFFER?
2516 014002 023727 031030 031114 BNE 12$ ;:NO
2517 014010 001003 MOV #ABBUF,ABUF ;:YES-RESET IT
2518 014012 012737 031032 031030 12$: MOVB R1,#ABUF ;:STORE THE RAW DATA
2519 014020 110177 015004 BEQ 6$ ;:IF CHAR. IS NULL-GO STORE IT
2520 014024 001505 BIT #BIT00+BIT01+BIT03,ESAMB ;:ESC OR ESC 0?
2521 014026 032737 000013 014636 BNE A$ESC ;:YES-KEEP ASSEMBLING
2522 014034 001150 CMPB R1,ESCN ;:BYTE = ESCN?
2523 014036 120137 002130 BHI 6$ ;:NO-PROBABLY A DISPLAY CH.-STORE IT.
2524 014042 101076 BNE 1$ ;:NO-DECODE FOR XON,XOFF,SOM,EOM
2525 014044 001007 MOV #1,ESAMB ;:YES SET ESC ASSEMBLY FLAG.
2526 014046 012737 000001 014636 BIS #ESC,VSTAT ;:SET ESC RECEIVED FLAG
2527 014054 052737 000400 002222 BR RSTER ;:AND EXIT
2528 014062 000515 1$: CMPB R1,#XOFF ;:SEE IF RECEIVED BYTE WAS XOFF
2529 014064 120127 000023 BNE 2$ ;:NO
2530 014070 001004 BIS #R'OFF,VSTAT ;:YES, SET XOFF IN STATUS REG.
2531 014072 052737 100000 002222 BR RSTER ;:EXIT
2532 014100 000506 2$: CMPB R1,#XON ;:SEE IF BYTE WAS XON
2533 014102 120127 000021 BNE 3$ ;:NO
2534 014106 001016 BIC #RXOFF,VSTAT ;:YES, CLEAR XOFF IN VSTAT.
2535 014110 042737 100000 002222 BIT #XMKIL,VSTAT ;:CHECK XMIT KILL BIT.
2536 014116 032737 000200 002222

```

```

2537 014124 001474 BEQ RSTER ;:NOT SET, EXIT
2538 014126 052777 000100 165600 BIS #TENA,#VXCSR ;:SET XMIT INT. ENABLE.
2539 014134 042737 000200 002222 BIC #XMKIL,VSTAT ;:CLEAR THE XMIT KILLED FLAG

```

F05

```

2540 014142 000465 BR RSTER ;EXIT
2541 014144 120127 0C0002 3$: CMPB R1,#SOM ;SEE IF BYTE WAS SOM
2542 014150 001004 BNE 4$ ;NO
2543 014152 052737 040000 002222 31$: BIS #RSOM,VSTAT ;YES, SET SOM IN VSTAT.
2544 014150 000456 BR RSTER ;EXIT
2545
2546 014162 120127 000004 4$: CMPB R1,#EOM ;WAS BYTE EOM?
2547 014166 001012 BNE 5$ ;NO
2548 014170 052737 020000 002222 BIS #REOM,VSTAT ;NOW SET EOM IN VSTAT.
2549 014176 013737 014630 014634 MOV RBBUF,RBUF ;RESET THE BUFFER POINTER.
2550 014204 042737 000100 002222 SIC #TXSUM,VSTAT ;CLEAR CHECKSUM REQUEST BIT.
2551 014212 000441 BR RSTER ;AND EXIT
2552 014214 123701 001750 5$: CMPB CARRT,R1 ;CHAR. =CARRIAGE RETURN?
2553 014220 001403 BEQ 51$ ;YES-GO SET END OF LINE FLAG
2554 014222 123701 001752 CMPB LNFED,R1 ;CHAR.= LINEFEED?
2555 014226 001004 BNE 6$ ;NO- GO STORE IT
2556 014230 052737 001000 002222 51$: BIS #EPL,VSTAT ;SET END OF LINE INDICATOR
2557 014236 000427 BR RSTER
2558
2559 014240 023737 014634 014632 6$: CMP RBBUF,REBUF ;IS CIRCULAR BUFFER FILLED?
2560 014246 001003 BNE 61$ ;NO
2561 014250 013737 014630 014634 MOV RBBUF,RBUF ;YES, RESET POINTER TO BEGINNING
2562 014256 032737 000020 002222 61$: BIT #COMGP,VSTAT ;RECEIVING GRAPHICS CHAR.?
2563 014264 001402 BEQ 7$ ;NO
2564 014266 162701 000137 SUB #137,R1 ;YES-SUBTRACT 137 FROM RECEIVED CHAR.
2565
2566 014272 032737 000040 002222 7$: BIT #REVID,VSTAT ;REVERSE VIDEO MODE?
2567 014300 001402 BEQ 70$ ;NO STORE RECEIVED BYTE.
2568 014302 052701 000200 BIS #200,R1 ;YES-FORCE BIT7 AS REV. VIDEO IND.
2569 014306 110177 000322 70$: MOVB R1,RBBUF ;STORE BYTE AND
2570 014312 005237 014634 INC RBBUF ;INCREMENT POINTER.
2571
2572 014316 005701 RSTER: TST R1 ;CHECK FOR STATUS ERROR
2573 014320 100014 BPL RECXT ;NO, EXIT ROUTINE
2574
2575 014322 052737 004000 002222 BIS #RSTT,VSTAT ;SET STATUS ERROR FLAG IN VSTAT
2576 014330 027727 000326 177777 CMP #STSTEP,#-1 ;IS ERROR TABLE FULL?
2577 014336 001405 BEQ RECXT ;YES, EXIT ROUTINE
2578 014340 010177 000316 MOV R1,#STSTEP ;NO, STORE STATUS ERR. AND CHECK
2579 014344 062737 000002 014662 ADD #2,STSTEP ;INCREMENT STATUS ERR. POINTER
2580
2581 014352 RECXT: MOV (SP)+,R1 ;POP STACK INTO R1
2582 014352 012601 RTI ;EXIT
2583 014354 000002 ASESC: BIT #2,ESAMB ;ASSEMBLING ESC P?
2584 014356 032737 000002 014636 BNE AESCP ;YES-GO GET LAST CH,
2585 014364 001063 BIT #BIT03,ESAMB ;ASSEMBLING ESC O?
2586 014366 032737 000010 014636 BNE AESCO ;YES
2587 014374 001062 CMPB #120,R1 ;CH.= A P?
2588 014376 122701 000120 BNE 10$ ;NO KEEP CHECKING
2589 014402 001004 BIS #BIT01,ESAMB ;YES-SET ESCP ASSEMBLY FLAG
2590 014404 052737 000002 014636 BR RSTER ;AND EXIT
2591 014412 000741 RSTER ;CHAR.IS AN ESC ? ?
2592 014414 122701 000077 10$: CMPB #77,R1

```

M3INDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 48  
DZVTH.P11 END OF PASS ROUTINE

SEQ 0059

```

2593 014420 001403 BEQ 110$ ;YES-FAKE AN ESC O.
2594 014422 122701 000117 CMPB #117,R1 ;CHAR = 0?
2595 014426 001004 BNE 11$ ;NO
2596 014430 052737 000010 014636 110$: BIS #BIT03,ESAMB ;YES SET ESC O ASSEMBLY FLAG
2597 014436 000727 BR RSTER ;AND EXIT
2598 014440 123701 002052 11$: CMPB RDCUR,R1 ;BYTE= CURSOR POSITION?
2599 014444 001004 BNE 1$ ;NO-
2600 014446 052737 000004 002222 BIS #CURPOS,VSTAT ;YES-SET RECEIVED CURSOR POSITION.

```

G05

```

2601 014454 000424          BR      CESAM
2602 014456 122701 000057 1$:  CMPB  #SLSH,R1      ;BYTE=TERMINAL ID ESC?
2603 014462 001004          BNE   2$          ;NO-CHECK FOR GRAPHICS SEQUENCE.
2604 014464 052737 000002 002222  BIS   #TRMID,VSTAT ;YES-SET TERM. IDENT FLAG IN VSTAT
2605 014472 000415          BR      CESAM
2606 014474 122701 000106 2$:  CMPB  #CKGP,R1      ;RECEIVED GRAPHICS CHAR. SEQUENCE?
2607 014500 001004          BNE   3$          ;NO
2608 014502 052737 000020 002222  BIS   #COMGP,VSTAT ;YES-SET GRAPHICS DATA FLAG.
2609 014510 000406          BR      CESAM
2610 014512 122701 000107 3$:  CMPB  #NCKGP,R1     ;RECEIVED RESET GRAPHICS SEQ.?
2611 014516 001003          BNE   CESAM       ;NO
2612 014520 042737 000020 002222  BIC   #COMGP,VSTAT ;YES-SET NORMAL CHAR. RECEIVE.
2613 014526 005037 014636  CESAM: CLR   ESAMB     ;CLEAR ASSEMBLY FLAG.
2614 014532 000671          BR      RSTER     ;AND EXIT.
2615
2616 014534 110137 014666  AESCP: MOVB  R1,STRP   ;STORE ANY UNCHECKED FOR ESC. P
2617 014540 000772          BR      CESAM
2618
2619 014542 123701 002020  AESCC: CMPB  EEMP,R1     ;BYTE=ESC 0 -REV. VIDEO- ?
2620 014546 001004          BNE   1$          ;NO
2621 014550 052737 000040 002222  BIS   #REVID,VSTAT ;YES-SET REVERSE VIDEO MODE IN VSTAT.
2622 014556 000763          BR      CESAM
2623
2624 014560 123701 002022  1$:  CMPB  DEMP,R1     ;BYTE=ESC 0 DISABLE REV. VIDEO MODE?
2625 014564 001004          BNE   2$          ;NO
2626 014566 042737 000040 002222  BIC   #REVID,VSTAT ;YES-CLEAR REVERSE VIDEO MODE IN VSTAT.
2627 014574 000754          BR      CESAM
2628 014576 122701 000171  2$:  CMPB  #CPABRT,R1    ;COPIER ABORT?
2629 014602 001403          BEQ   3$          ;YES-SET ABORT FLAG IN VSTAT
2630 014604 122701 000172  CMPB  #PRABRT,R1    ;PRINTER ABORT?
2631 014610 001004          BNE   4$          ;NO
2632 014612 052737 010000 002222  3$:  BIS   #PABRT,VSTAT ;YES-SET THE ABORT FLAG.
2633 014620 000742          BR      CESAM     ;AND EXIT.
2634 014622 110137 014664  4$:  MOVB  R1,STRO     ;STORE ESCAPE 0 COMMAND
2635 014626 000737          BR      CESAM
2636
2637 014630 000000  RBBUF: .WORD          ;ADDRESS OF START OF BUFFER
2638 014632 000000  REBUF: .WORD          ;ADDRESS OF END OF BUFFER.
2639 014634 000000  RBUFP: .WORD          ;READ BUFFER POINTER.
2640 014636 000000  ESAMB: .WORD  0      ;ESCAPE SEQ.ASSEMBLY AREA
2641
2642 014640  STTER:
2643 014640 000000          0
2644 014642 000000          0
2645 014644 000000          0
2646 014646 000000          0
2647 014650 000000          0
2648 014652 000000          0

```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 49  
DZVTH.P11 END OF PASS ROUTINE

SEQ 0060

```

2649 014654 000000          0
2650 014656 000000          0
2651 014660 177777          .WORD  -1          ;STATUS REGISTER DELIMITER.
2652 014662 000000  STTEP: .WORD          ;STATUS ERROR POINTER.
2653 014664 000000  STRO:  .WORD  0      ;ESCAPE 0 STORAGE
2654 014666 000000  STRP:  .WORD          ;ESCAPE P STORAGE
2655
2656 ;*****
2657 ;TRANSMIT INTERRUPT ROUTINE.
2658 ; IF XOFF BIT IS SET IN VSTAT , TRANSMISSION WILL NOT OCCUR
2659 ;AND XMIT INT. ENABLE BIT WILL BE CLEARED AND THE ROUTINE
2660 ;WILL BE EXITED IMMEDIATELY. IF AFTER THE TRANSMISSION
2661 ;OF THE CHARACTER DURING THIS INTERRUPT CYCLE, THE

```

HQ5

;XMIT COUNT (XMCNT) EQUAL TO ZERO.  
;THE XMIT DONE BIT WILL BE SET IN VSTAT AND XMIT  
;INT ENABLE BIT WILL CLEARED. TRANSMIT COUNT(XMCNT) MUST BE  
;SET TO THE NUMBER OF BYTE/CHARACTER TO TRANSMIT.  
;IF LOCATION BLKM IS SET TO 1001 A SOM WILL PRECEED THE  
;DATA AND A EOM WILL FOLLOW IT. IF XMZER IS SET TO NON-  
;ZERO, ALL DATA(INCLUDING ZEROS) WILL BE XMITTED.

2662  
2663  
2664  
2665  
2666  
2667  
2668  
2669  
2670 014670 005737 002222  
2671 014674 100004  
2672 014676 052737 000200 002222  
2673 014704 000510  
2674  
2675 014706 105737 002225  
2676 014712 001406  
2677 014714 112777 000002 165014  
2678 014722 105037 002225  
2679 014726 000002  
2680 014730 005737 015144  
2681 014734 001006  
2682 014736 112777 000004 164772  
2683 014744 105037 002224  
2684 014750 000452  
2685 014752 105777 000164  
2686 014756 001016  
2687 014760 005737 020466  
2688 014764 001023  
2689 014766 023737 015142 015140  
2690 014774 001004  
2691 014776 013737 015136 015142  
2692 015004 000740  
2693 015006 005237 015142  
2694 015012 000735  
2695  
2696 015014 032737 002000 002222 15:  
2697 015022 001404  
2698 015024 117705 000112  
2699 015030 004037 017516  
2700 015034 117777 000102 164674 22\$:  
2701 015042 023737 015142 015140  
2702 015050 001004  
2703 015052 013737 015136 015142  
2704 015060 000402

\*\*\*\*\*  
INTXM: TST VSTAT ;HAS 61 TRANSMITTED XOFF?  
BPL NOKIL ;NO XMIT ANOTHER  
BIS #XMKIL,VSTAT ;SET XMIT KILLED BIT IN VSTAT  
BR KIENA ;GO KILL XMIT ENABLE  
  
NOKIL: TSTB BLKM+1 ;SOM/EOM TRANSMIT?  
BEQ NOSOM ;NO  
MOVB #SOM,2VXBUF ;YES-ISSUE START OF MESSAGE.  
CLRB BLKM+1 ;AND CLEAR SOM FLAG.  
  
NOSOM: TST XMCNT ;XMITTED THE BUFFER?  
BNE 100\$ ;NO-XMIT A NORMAL CHAR.  
MOVB #EOM,2VXBUF ;YES SEND EOM AND EXIT  
CLRB BLKM  
BR 2\$  
  
100\$: TSTB 2TBUF ;CHECK FOR CH.= ZERO. IF SO DO NOT XMIT  
BNE 1\$ ;OR COUNT BYTE. OR ARE WE  
TST XMZER ;XMITTING ZEROS?  
BNE 22\$ ;YES-XMIT NEXT BYTE  
CMP TBUF,TEBUF ;AT END OF BUFFER?  
BNE 10\$ ;NO  
MOV TBUF,TBUF ;YES-RESET BUFFER POINTER  
BR NOKIL  
  
10\$: INC TBUF  
BR NOKIL ;LOOK FOR NON-ZERO BYTE TO TRANSMIT.  
  
15: BIT #CKSUM,VSTAT ;CHECKSUM REQUESTED?  
BEQ 22\$  
MOVB 2TBUF,R5 ;YES,LOAD THE BYTE  
JSR RD,CALCK ;AND CALCULATE THE NEW CHECKSUM.  
22\$: MOVB 2TBUF,2VXBUF ;TRANSMIT A CHARACTER  
CMP TBUF,TEBUF ;AT END OF CIRCULAR BUFFER?  
BNE 11\$ ;NO  
MOV TBUF,TBUF ;YES, RESET IT TO START.  
BR 12\$ ;BY-PASS INCREMENT BUFF. POINTER

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 50  
DZVTH.P11 END OF PASS ROUTINE

SEQ 0061

2705 015062 005237 015142  
2706  
2707 015066 005337 015144  
2708 015072 001401  
2709 015074 000002  
2710 015076 105737 002224  
2711 015102 001014  
2712 015104 052737 000001 002222  
2713 015112 042737 002000 002222  
2714 015120 013737 015136 015142  
2715 015126 042777 000100 164600  
2716 015134 000002  
2717  
2718  
2719 015136 000000  
2720 015140 000000  
2721 015142 000000  
2722

11\$: INC TBUF ;INCREMENT BUFFER POINTER.  
  
12\$: DEC XMCNT ;DECREMENT THE TRANSMIT COUNT  
BEQ 2\$ ;YES,CLEANUP,REQUEST ERRORS AND EXIT.  
RTI ;NO, CONTINUE  
  
2\$: TSTB BLKM ;SOM/EOM XMIT?  
BNE TXEX ;YES-DO NOT SET XMDNE UNTIL EOM SENT.  
BIS #XMDNE,VSTAT ;SET THE DONE BIT IN VSTAT.  
BIC #CKSUM,VSTAT ;CLEAR THE CHECKSUM FLAG WHEN DONE.  
MOV TBUF,TBUF ;RESET BUFFER POINTER.  
KIENA: BIC #TENA,2VXCSR ;CLEAR XMIT. INT. ENABLE  
TXEX: RTI  
  
TBUF: .WORD ;CONTAINS INITIAL ADDRESS  
TEBUF: .WORD ;CONTAIN LAST ADDRESS  
TBUF: .WORD ;CONTAINS CURRENT LOCATION

XMCNT: .WORD 0 ;LOADED WITH NUMBER OF XMTS.  
;\*\*\*\*\*

;SUBROUTINE TO ISSUE RESET TO THE VT61, ENTERS MAINTENANCE MODE  
;AND FORCES LINEAR ADDRESSING.  
;\*\*\*\*\*

2723 015144 000000  
2724  
2725  
2726  
2727  
2728  
2729  
2730  
2731 015146 113737 001102 002226  
2732 015154 013746 002166  
2733 015160 013746 002126  
2734 015164 013746 002056  
2735 015170 004037 013322  
2736 015174 004037 015256  
2737 015200 000405  
2738 015202 005237 002176  
2739 015206 010037 001120  
2740 015212 104017  
2741 015214  
2742 015214 013746 002166  
2743 015220 013746 002002  
2744 015224 013746 002056  
2745 015230 013746 002012  
2746 015234 013746 002056  
2747 015240 004037 013322  
2748 015244 005037 002222  
2749 015250 005037 016746  
2750 015254 000200

RESETV: MOV \$TSTNM, TSTNM ;LOAD THE TEST NUMBER IN ERROR PRINT AREA.  
MOV ZERO, -(SP) ;;PUSH ZERO ON STACK  
MOV RESET, -(SP) ;;PUSH RESET ON STACK  
MOV ESCO, -(SP) ;;PUSH ESCO ON STACK  
JSR RO, TESC ;GO XIMT IT  
JSR RO, GETON ;GO LOOK FOR XON.  
BR 15 ;FOUND IT.  
INC FTLCNT ;ADD 1 TO FATAL XMIT COUNT.  
MOV RO, \$GDADR ;NO XON ISSUE XON ERROR  
ERROR 17  
  
15: MOV ZERO, -(SP) ;;PUSH ZERO ON STACK  
MOV EMAIN, -(SP) ;;PUSH EMAIN ON STACK  
MOV ESCO, -(SP) ;;PUSH ESCO ON STACK  
MOV DRECT, -(SP) ;;PUSH DRECT ON STACK  
MOV ESCO, -(SP) ;;PUSH ESCO ON STACK  
  
25: JSR RO, TESC  
CLR VSTAT ;CLEAR INT. FLAGS AFTER TERMINAL RESET  
CLR HDFLG ;CLEAR PRINT HEADER FLAG.  
RTS RO

;\*\*\*\*\*  
;SUBROUTINE TO WAIT FOR AN XON. NO XON EXIT IS PC +2.  
;\*\*\*\*\*

2751  
2752  
2753  
2754  
2755  
2756 015256 012737 000454 002206  
2757 015264 105077 013540  
2758 015270 127727 013534 000021  
2759 015276 001412  
2760 015300 012737 000001 017074  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 END OF PASS ROUTINE

GETON: MOV #300, BUBCT ;SET UP TO LOOK FOR 3 SEC.  
CLRB 2ABUFP  
15: CMPB 2ABUFP, #XON ;RECEIVED A XON?  
BEQ GOTON ;YES-EXIT.  
MOV #1, DCOUNT ;NO-DELAY 10 M.S.  
20-SEP-76 10:22 PAGE 51

2761 015306 004037 017032  
2762 015312 005337 002206  
2763 015316 001364  
2764 015320 062700 000002  
2765 015324 000200  
2766  
2767  
2768  
2769  
2770  
2771  
2772  
2773  
2774 015326  
2775 015326 012637 015364  
2776 015332 013746 002166  
2777 015336 013746 002124  
2778 015342 004037 013322  
2779 015346 012746 106003  
2780 015352 004037 013060  
2781 015356 013746 015364  
2782 015362 000200  
2783 015364 000000

JSR RO, DELAY  
DEC BUBCT ;AT END OF DELAY?  
BNE 15 ;NO  
ADD #2, RO ;YES-SET UP ERROR EXIT.  
GOTON: RTS RO  
  
;\*\*\*\*\*  
;SUBROUTINE TO ISSUE ESCZ AND LOOK FOR A RESPONSE-EITHER  
;A -1 OR THE RETURNED IDENT. THE -1 INDICATES NO  
;RESPONSE FROM THE UNIT UNDER TEST.  
;\*\*\*\*\*  
ZFLAG: MOV (SP)+, ROSV1 ;;POP STACK INTO ROSV1  
MOV 2#ZERO, -(SP) ;;PUSH 2#ZERO ON STACK  
MOV 2#ESZ, -(SP) ;;PUSH 2#ESZ ON STACK  
JSR RO, TESC ;GO ISSUE ESZ SEQUENCE  
MOV #106003, -(SP) ;;PUSH #106003 ON STACK  
JSR RO, RECTM ;GO READ THE CHARACTER  
MOV ROSV1, -(SP) ;;PUSH ROSV1 ON STACK  
RTS RO  
ROSV1: .WORD 0

J05

2784  
 2785  
 2786  
 2787  
 2788  
 2789  
 2790  
 2791 015366  
 2792 015366 012637 002220  
 2793 015372 010137 002162  
 2794 015376 010237 002164  
 2795  
 2796 015402 012601  
 2797 015404 013702 002222  
 2798  
 2799 015410 042702 003576  
 2800 015414 020102  
 2801 015416 001432  
 2802  
 2803 015420 010137 001124  
 2804 015424 013737 002222 001126  
 2805 015432 104003  
 2806  
 2807  
 2808  
 2809  
 2810  
 2811  
 2812  
 2813 015434 012701 014640  
 2814 015440 013702 014662  
 2815 015444 020102  
 2816 015446 001416  
 MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 52  
 DZVTH.P11 END OF PASS ROUTINE

```

;*****
;ROUTINE TO CHECK SOFTWARE STATUS REGISTER (VSTAT)
;RECEIVE FLAGS ONLY. ENTERED WITH ANTICIPATED
;STATUS WORD ON THE STACK.
;*****
  
```

```

CKSFT:
MOV (SP)+,ROSVE ;;POP STACK INTO ROSVE
MOV R1,SVER1 ;;SAVE R1
MOV R2,SVER2 ;;SAVE R2

MOV (SP)+,R1 ;;POP STACK INTO R1
MOV VSTAT,R2 ;;SET R2 EQUAL TO VSTAT

BIC #003576,R2 ;;CLEAR NON-ERROR BITS
CMP R1,R2 ;;COMPARE ANTICIPATED TO ACTUAL.
BEQ NOER ;;NO UNUSAL BITS EXIT

MOV R1,$GDDAT ;;MOVE GOOD STATUS TO MESSAGE
MOV VSTAT,$BDDAT ;;MOVE BAD STATUS TO MESSAGE
ERROR 3 ;;ISSUE ERROR MESSAGE.
  
```

```

;*****
;ROUTINE TO PRINT THE STATUS REGISTER IN THE FOLLOWING
;FORMAT: STATUS BITS (XXX 000), CHARACTER TRANSFERRED (000 X X)
;*****
  
```

```

MOV #STTER,R1 ;;SET R1 EQUAL TO FIRST ENTRY
MOV STSTEP,R2 ;;SET R2 EQUAL LAST ENTRY
1$: CMP R1,R2 ;;ARE THEY EQUAL
BEQ NOER ;;YES-RESET POINTERS AND EXIT.
  
```

```

JSR RO,CLREG ;;CLEAR ERROR PRINT LOC.
MOV VRCSR,$GADR ;;LOAD ADDRESS
MOV JVRCSR,$GDDAT ;;LOAD CSR
2$: MOVB (R1)+,$BDDAT ;;MOVE CHARACTER AND
MOVB (R1)+,$BDADR+1 ;;STATUS BITS TO ERROR REGISTERS.
ERROR 2 ;;ISSUE ERROR MESSAGE
BR 1$ ;;DO AGAIN
NOER: MOV SVER1,R1 ;;RESTORE R1 AND
MOV SVER2,R2 ;;R2.
MOV #STTER,STSTEP ;;RESET STATUS ERROR POINTER.
MOV ROSVE,-(SP) ;;PUSH ROSVE ON STACK
RTS RO ;;EXIT
  
```

```

;*****
;SUBROUTINE TO CLEAR ERROR/DATA OUTPUT LOCATIONS. NEEDED
;ONLY WHEN DISPLAYING BYTES IN WORD LOCATIONS.
;*****
  
```

```

CLREG: CLR $GADR
CLR $BDADR
CLR $GDDAT
CLR $BDDAT
RTS RO
  
```

```

;*****
;SUBROUTINE TO TRANSMIT THE BUFFER AND WAIT FOR XMIT DONE
;AND END OF RECEIVE MESSAGE. SUBROUTINE WILL LOOP IF LOCATION
;RECITT IS PRE-LOADED WITH A NUMBER HIGHER THAN(IE. MULTIPLE
;RECEIVES CAN BE ACCOMPLISHED WITH ONLY ONE ENTRY TO SUB-
  
```

SEQ 0063



K05

;ROUTINE).WDSTOR AND BYSTOR ARE THE WORD(CURSOR POS.) AND BYTE STORAGE LOCATIONS,RESPECTIVELY.DEFAULT STORAGE IS THE REC. BUFFER.

;\*\*\*\*\*

2845									
2846									
2847									
2848									
2849									
2850	015552								
2851	015552	010546							
2852	015554	012737	001001	002224					
2853	015562	042737	077577	002222					
2854	015570	013701	016024						
2855	015574	013702	016022						
2856	015600	052777	000100	164126					
2857	015606	042737	061466	002222					
2858	015614	005037	002216						
2859	015620	032737	000001	002222					
2860	015626	001015							
2861	015630	032737	020000	002222					
2862	015636	001401							
2863	015640	000435							
2864	015642	032737	100000	002222					
2865	015650	001761							
2866	015652	005337	002216						
2867	015656	001364							
2868	015660	000416							
2869									
2870	015662	013705	031030						
2871	015666	005037	002216						
2872	015672	032737	020000	002222					
MAINDEC-11-DZVTH-A									
DZVTH.P11									
END OF PASS ROUTINE									
				20-SEP-76	10:22	PAGE	53		
2873	015700	001015							
2874	015702	020537	031030						
2875	015706	001365							
2876	015710	005337	002216						
2877	015714	001366							
2878	015716	062700	000002						
2879	015722	005237	002176						
2880	015726	004037	016136						
2881	015732	000422							
2882	015734	020102							
2883	015736	001413							
2884	015740	032737	000004	002222					
2885	015746	001403							
2886	015750	017722	176654						
2887	015754	000404							
2888	015756	005701							
2889	015760	001402							
2890	015762	117721	176642						
2891	015766	005337	016020						
2892	015772	001305							
2893	015774	004037	020560						
2894	016000								
2895	016000	012746	060001						
2896	016004	004037	015366						
2897	016010	004037	016136						
2898	016014	012605							
2899	016016	000200							
2900	016020	000000							
2901	016022	000000							
2902	016024	000000							
2903									
2904									
2905									

;\*\*\*\*\*

;SUBROUTINE TO XMIT THE BYTE AT TBUFP.

SEQ 0064

```

2906 ;*****L05*****
2907
2908 016026 042737 000001 002222 XMIT1: BIC #1,VSTAT ;CLEAR XMIT DONE FLAG
2909 016034 012737 000001 015144 MOV #1,XMCNT ;SET UP TO XMIT 1 BYTE
2910 016042 052777 000100 153664 BIS #TENA,@VXCSR
2911 016050
2912 016050 012746 000001 15: MOV #XMDNE,-(SP) ;;PUSH #XMDNE ON STACK
2913 016054 012746 000001 MOV #1,-(SP) ;;PUSH #1 ON STACK
2914 016060 004037 020470 JSR RO,WTBGND ;LOOK FOR XMIT DONE
2915 016064 000401 BR FTLEXT ;HUNG TRANSMIT-CLEAR FLAGS AND EXIT
2916 016066 000402 BR NORXT ;NORMAL EXIT.
2917 016070 005037 002222 FTLEXT: CLR VSTAT ;CLEAR ANY FLAGS
2918 016074 000200 NORXT: RTS RO ;AND EXIT
2919
2920 ;*****
2921 ;SUBROUTINE TO ISSUE A BYTE AT A TIME UNTIL A ZERO
2922 ;BYTE IS ENCOUNTERED.
2923 ;*****
2924
2925 016076 112777 000002 177036 LDXMITE: MOV #SOM,@TBUF ;SEND THE START OF MESSAGE.
2926 016104 000403 BR 25
2927 016106 112377 177030 15: MOV (R3)+,@TBUF ;MOVE A BYTE TO XMIT BUFFER
2928 016112 001403 BEQ LDOUT ;IF A ZERO BYTE-EXIT
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 54
DZVTH.P11 END OF PASS ROUTINE SEQ 0065
2929 016114 004037 016026 25: JSR RO,XMIT1 ;GO XMIT A BYTE
2930 016120 000772 BR 15 ;XMIT AGAIN.
2931 016122 112777 000004 177012 LDOUT: MOV #EOM,@TBUF ;SEND THE END OF MESSAGE.
2932 016130 004037 016026 JSR RO,XMIT1
2933 016134 000200 RTS RO
2934
2935 ;*****
2936 ;ROUTINE TO RESET ALL INTERRUPT POINTERS.
2937 ;*****
2938
2939 016136 042777 000100 163570 RESPTR: BIC #TENA,@VXCSR ;CLEAR INTERRUPT ENABLES
2940 016144 013737 014630 014634 MOV RBUF,RBUF ;RESET RECEIVE BUF POINTER
2941 016152 013737 015136 015142 MOV TBUF,TBUF ;RESET XMIT BUF POINTER
2942 016160 012737 014640 014662 MOV #STTER,STTEP ;RESET RECEIVE STATUS ERR POINTER
2943 016166 005037 015144 CLR XMCNT ;CLEAR TRANSMIT COUNT
2944 016172 005037 014636 CLR ESAMB ;CLEAR ESC ASSEMBLY FLAGS
2945 016176 012737 000001 016020 MOV #1,RECITT ;RESET REC. ITERATION COUNT
2946 016204 005037 016022 CLR WDSTOR ;CLEAR STORAGE POINTERS
2947 016210 005037 016024 CLR BYSTOR
2948 016214 000200 RTS RO
2949
2950
2951 ;*****
2952 ;SUBROUTINE TO ISSUE CURSOR POSITION ERROR. GOOD
2953 ;LINE/COLUMN MUST BE A WORD ON STACK. ERROR
2954 ;POSITION IS EXPECTED TO BE @RBUF.
2955 ;*****
2956
2957 CURER:
2958 016216 012637 002220 MOV (SP)+,ROSVE ;;POP STACK INTO ROSVE
2959 016222 012637 002160 MOV (SP)+,CHRD ;;POP STACK INTO CHRD
2960 016226 162737 020040 002160 SUB #20040,CHRD ;EXTRACT MOD 40 FROM GOOD POSITION
2961 016234 004037 015530 JSR RO,CLREG
2962 016240 113737 002161 001124 MOV CHRD+1,$GDDAT ;LOAD MESSAGE WITH GOOD
2963 016246 113737 002160 001120 MOV CHRD,$GDADR ;LINE AND COLUMN
2964 016254 017737 176350 002160 MOV @RBUF,CHRD ;LINE AND COLUMN.
2965 016262 162737 020040 002160 SUB #20040,CHRD ;EXTRACT MOD 40 FROM BAD POSITION.
2966 016270 113737 002161 001126 MOV CHRD+1,$BDDAT ;LOAD MESSAGE WITH BAD

```



MOS

```

2967 016276 113737 002160 001122      MOVB   CHR0,$BDADR05 ;LINE AND COLUMN.
2968 016304 104006                      ERROR   6             ;ISSUE ERROR
2969 016306 013746 002220      MOV    ROSVE,-(SP)   ;;PUSH ROSVE ON STACK
2970 016312 000200      RTS    RO
2971
2972 ;*****
2973 ;*****
2974 ;*****
2975 ;SUBROUTINE TO DECREMENT CURSOR POSITION IN A
2976 ;LINEAR SEQUENCE. (IE. ROW 20, COL 1 ;ROW 20 COLD ;ROW 17, COL 157).
2977 ;*****
2978
2979 016314 123727 016421 000040  CMPOS:  CMPB   LNRW+1,#40   ;AT LEFT EDGE OF ROW?
2980 016322 001403                      BEQ    1$             ;YES, GO ADJUST COL. ROW.
2981 016324 105337 016421                      DECB  LNRW+1         ;NO, DECREMENT COL. AND EXIT
2982 016330 000200      RTS    RO
2983 016332 123727 016420 000040  1$:    CMPB   LNRW,#40   ;AT ROW 0?
2984 016340 001405                      BEQ    2$             ;YES, NO DECREMENT POSSIBLE-EXIT.
MAINDEC-11-DZVTH-A      MACY11 27(732) 20-SEP-76 10:22 PAGE 55
DZVTH.P11              END OF PASS ROUTINE
SEQ 0066

2985 016342 105337 016420          DECB  LNRW           ;NO, DECREMENT ROW AND
2986 016346 112737 000157 016421  2$:    MOVB  #157,LNRW+1   ;SET COL. TO RIGHT EDGE.
2987 016354 000200      RTS    RO
2988
2989 ;*****
2990 ;SUBROUTINE TO INCREMENT CURSOR POSITION IN A LINEAR
2991 ;SEQUENCE (IE. ROW 10, COL 78, ROW 10, COL 79, ROW 11, COL 0).
2992 ;*****
2993
2994 016356 123727 016421 000157  CPPOS:  CMPB   LNRW+1,#157   ;AT RIGHT EDGE OF ROW
2995 016364 001403                      BEQ    1$             ;YES, ADJUST ROW AND COLUMN.
2996 016366 105237 016421                      INCB  LNRW+1         ;NO, INCREMENT COL. COUNT
2997 016372 000200      RTS    RO             ;AND EXIT
2998 016374 123727 016420 000067  1$:    CMPB   LNRW,#67     ;AT BOTTOM ROW?
2999 016402 001405                      BEQ    2$             ;YES, NO INCREMENT POSSIBLE-EXIT.
3000 016404 105237 016420          INCB  LNRW           ;NO, INCREMENT ROW COUNT AND
3001 016410 112737 000040 016421  2$:    MOVB  #40,LNRW+1   ;SET COL. TO LEFT EDGE.
3002 016416 000200      RTS    RO
3003
3004 016420 000000      LNRW:  .WORD  0      ;CONTAINS UPDATED CURSOR POSITION.
3005 ;*****
3006
3007 ;SUBROUTINE TO XMIT, RECEIVE AND COMPARE. DATA ERRORS
3008 ;ARE REPORTED FROM SUBROUTINE. IF THE TRANSMIT OR
3009 ;RECEIVE LOOPS 'TIME OUT', EXIT FROM SUBROUTINE WILL
3010 ;BE NORMAL EXIT +2. SUBROUTINE ENTERED WITH (R1)=
3011 ;GOOD DATA BUFFER, (R2)=RECEIVE DATA BUFFER AND
3012 ;R3=COMPARE COUNT. IF THE VT61 DOES NOT HANG,THE ROUTINE
3013 ;WILL WAIT FOR END OF REC. MESSAGE(EOM).
3014
3015 ;*****
3016
3017
3018 016422      XRCMP:
3019 016422 010446      MOV    R4,-(SP)     ;;PUSH R4 ON STACK
3020 016424 005004      CLR    R4           ;;USE R4 A RECEIVE COUNTER.
3021 016426 012737 001001 002224      MOV    #1001,2LKM  ;SET UP FOR A SOM/EOM TRANSMIT.
3022 016434 042737 077577 002222      BIC   #77577,VSTAT ;CLEAR ALL FLAGS BUT XOFF AND XMKIL.
3023 016442 052777 000100 163264      BIS   #TENA,OVXCSR ;SET INTERRUPT ENABLES.
3024 016450 005037 016746          CLR    HDFLG        ;CLEAR ERROR 13 PRINT FLAG
3025 016454 012705 031000          MOV    #TCRLB+450,R5 ;R5 IS ERROR STORAGE POINTER
3026 016460 005037 002216      1$:    CLR    DLAY         ;SET UP TIME OUT DELAY
3027 016464 032737 000001 002222      BIT   #XMDNE,VSTAT ;XMIT DONE?

```

N05

```

3028 016472 001014          BNE      XREC      ;YES-GO RECEIVE
3029 016474 023737 014630 014634 2$:  CMP      RBBUF,RBUF ;HAS RECEIVE OPERATION BEGUN?
3030 016502 103410          BLO      XREC      ;YES-GO RECEIVE
3031 016504 032737 100000 002222  BIT      #RXOFF,VSTAT ;XMIT XOFF SET?
3032 016512 001762          BEQ      1$        ;NO-KEEP LOOKING FOR XMIT DONE?
3033 016514 005337 002216  DEC      DLAY      ;YES RUN DELAY AND LOOK
3034 016520 001365          BNE      2$        ;FOR XON OR RECEIVED CH.
3035 016522 000432          BR       XRERR     ;TRANSMIT TIMEOUT-SET UP ERROR EXIT
3036
3037 016524 005037 002216  XREC:  CLR      DLAY      ;SET UP TIME OUT DELAY
3038 016530 020237 014634  1$:  CMP      R2,RBUF   ;INSURE COMPARE POINTER
3039 016534 103410          BLO      2$        ;LESS THAN RECEIVE POINTER
3040 016536 032737 020000 002222  BIT      #REOM,VSTAT ;RECEIVE EOM?
MAINDEC-11-DZVTH-A      MACY11 27(732) 20-SEP-76 10:22  PAGE 56
DZVTH.P11              END OF PASS ROUTINE

```

SEQ 0067

```

3041 016544 001030          BNE      XREXT     ;YES-SET UP TO EXIT
3042 016546 005337 002216  DEC      DLAY      ;RUN TIMEOUT DELAY
3043 016552 001416          BEQ      XRERR     ;TIME OUT OCCURRED-ERROR EXIT
3044 016554 000765          BR       1$        ;RETURN TO CHECK RECEIVE COUNT
3045 016556 005204          INC      R4        ;ADD 1 TO RECEIVE COUNTER.
3046 016560 122122          CMPB     (R1)+,(R2)+ ;COMPARE CHARACTERS
3047 016562 001407          BEQ      4$        ;EQUAL-COMPARE AGAIN
3048 016564 020527 031030  CMP      R5,#TCRLB+500 ;ALLREADY STORED 50 ERRORS?
3049 016570 103004          BHIS     4$        ;YES-BYPASS STORAGE
3050 016572 114125          MOV      -(R1),(R5)+ ;STORE GOOD DATA
3051 016574 114225          MOV      -(R2),(R5)+ ;STORE BAD DATA
3052 016576 010425          MOV      R4,(R5)+  ;LOAD RECEIVE COUNT
3053 016600 132122          BITB     (R1)+,(R2)+ ;RESET POINTERS AND
3054 016602 005303          4$:  DEC      R3        ;CHECK COMPARE COUNT
3055 016604 001410          BEQ      XREXT     ;ALL DONE-EXIT
3056 016606 000746          BR       XREC      ;COMPARE ANOTHER
3057 016610 062700 000002  XRERR:  ADD      #2,R0 ;SET UP ERROR EXIT
3058 016614 005237 002176  INC      FTLCNT    ;INCREMENT FATAL XMIT COUNT.
3059 016620 004037 016136  JSR      R0,RESPTR ;RESET INTERRUPT POINTERS.
3060 016624 000440          BR       XROUT
3061 016626          XREXT:
3062 016626 012746 020000  MOV      #REOM,-(SP) ;PUSH #REOM ON STACK
3063 016632 012746 000004  MOV      #4,-(SP)   ;PUSH #4 ON STACK
3064 016636 004037 020470  JSR      R0,WTBGND
3065 016642 000431          BR       XROUT
3066 016644 162705 031000  SUB      #TCRLB+450,R5 ;NO EOM-ISSUE ERROR AND EXIT.
3067 016650 010501          MOV      R5,R1     ;NOW EXTRACT ERROR COUNT-IF ANY.
3068 016652 012705 031000  MOV      #TCRLB+450,R5 ;AND STORE IT IN R1
3069 016656 005701          TST     R1         ;RELOAD ERROR POINTER
3070 016660 001422          BEQ      XROUT     ;TEST FOR ERRORS
3071 016662 005737 016746  TST     H7FLG      ;NO-CHECK STATUS AND EXIT
3072 016666 001003          BNE      1$        ;DATA ERROR HEADER PRINTED?
3073 016670 104012          ERROR   12        ;YES-BYPASS HEADER PRINT
3074 016672 005237 016746  INC      H7FLG     ;PRINT DATA ERROR HEADER
3075 016676 004037 015530  1$:  JSR      R0,CLREG  ;SET HEADER PRINT FLAG
3076 016702 112537 001124  MOV      (R5)+,$GDDAT ;ERROR WAS LEGTIMATE. LOAD
3077 016706 112537 001126  MOV      (R5)+,$BDDAT ;ERROR MESSAGE AND ISSUE
3078 016712 012537 001120  MOV      (R5)+,$GDADR ;IT.
3079 016716 104004          ERROR   4         ;LOAD RECEIVE COUNT
3080 016720 162701 000004  SUB      #4,R1     ;ISSUE DATA COMPARE ERROR
3081 016724 001364          BNE      1$        ;INCREMENT ERROR COUNT
3082 016726 004037 020560  XROUT: JSR      R0,CKOFF ;PRINT ANOTHER IF NOT AT ZERO
3083 016732 012746 060001  MOV      #60001,-(SP) ;SEE IS XOFF IS LP
3084 016736 004037 015366  JSR      R0,CKSFT  ;PUSH #60001 ON STACK
3085 016742 012604          MOV      (SP)+,R4  ;CHECK FOR VSTAT /STATUS ERR.
3086 016744 000200          RTS     R0        ;POP STACK INTO R4
3087
3088 016746 000000          H7FLG: 0         ;EXIT SUBROUTINE

```

;INHIBIT PRINT FLAG.

\*\*\*\*\*  
:SUBROUTINE TO CREATE A 'RULER' IN LOCATIONS 200  
:TO 317.  
\*\*\*\*\*

MAIN DEC-11-22VTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 57  
22VTH.F11 END OF PASS ROUTINE

SEQ 0068

3097 016750 012701 030530  
3098 016754 012702 130461  
3099 016760 110221  
3100 016762 022701 030650  
3101 016766 103001  
3102 016770 000200  
3103 016772 105202  
3104 016774 122702 000272  
3105 017000 001003  
3106 017002 012702 030660  
3107 017006 000405  
3108 017010 122702 000072  
3109 017014 031361  
3110 017016 012702 130460  
3111 017022 110221  
3112 017024 105202  
3113 017026 000302  
3114 017030 000753

CPFUL: MOV #TCRLB+200,R1 ;LOAD STARTING ADDRESS  
MOV #130461,R2 ;LOAD INITIAL RULER ASCII CODES.  
1\$: MOV R2,(R1)+ ;STORE A RULER BYTE IN XMIT BUF.  
MOV #TCRLB+320,R1 ;RULER COMPLETE?  
BHS 2\$ ;NO  
RTS R0 ;AND EXIT.  
2\$: INCB R2 ;INCREMENT ASCII BYTE  
CMPB #272,R2 ;END OF REVERSE VIDEO?  
BNE 3\$ ;NO-SEE IF END OF NORMAL.  
BR 5\$ ;SET UP TO ISSUE REVERSE G.  
3\$: CMPB #72,R2 ;END OF NORMAL VIDEO?  
BNE 1\$ ;NOT AT END OF A VIDEO STRING.  
MOV #130460,R2 ;YES-SET UP TO ISSUE NORMAL D.  
5\$: MOV R2,(R1)+ ;DO IT  
INCB R2 ;SET BYTE TO NEXT ASCII CODE  
SWAB R2 ;REVERSE VIDEO MODE.  
BR 1\$ ;BEGIN NEXT STRING

\*\*\*\*\*  
:SUBROUTINE TO DELAY 10 M.S. TIME THE NUMBER INLOCATION  
:DCOUNT. THE PROCESSOR TYPE PRE-DETERMINES THE # OF LOOPS  
:REQUIRED TO DELAY 10 M.S. FOR ONE ITERATION. LOCATION  
:PMULT IS PRE-LOADED WITH : 11/45 = 4, 11/40 = 2  
:AND 11/10 = 1.  
\*\*\*\*\*

3124 017032  
3125 017032 010146  
3126 017034 010246  
3127 017036 013702 017072  
3128 017042 012701 002570  
3129 017046 005301  
3130 017050 001376  
3131 017052 005302  
3132 017054 001372  
3133 017056 005337 017074  
3134 017062 001365  
3135 017064 012602  
3136 017066 012601  
3137 017070 000200  
3138  
3139 017072 000000  
3140 017074 000000

DELAY: MOV R1,-(SP) ;;PUSH R1 ON STACK  
MOV R2,-(SP) ;;PUSH R2 ON STACK  
1\$: MOV PMULT,R2 ;LOAD PROCESSOR MULTIPLIER  
2\$: MOV #1400.,R1 ;LOAD 10 M.S. DELAY  
DEC R1 ;RUN BASIC DELAY  
BNE -2 ;RUN MULTIPLIER DELAY  
DEC R2 ;RUN MULTIPLIER DELAY  
BNE 2\$ ;RUN MULTIPLIER DELAY  
DEC DCOUNT ;RUN ITERATION COUNT  
BNE 1\$ ;RUN ITERATION COUNT  
MOV (SP)+,R2 ;;POP STACK INTO R2  
MOV (SP)+,R1 ;;POP STACK INTO R1  
RTS R0  
PMULT: 0 ;PROCESSOR MULTIPLIER  
DCOUNT: 0 ;ITERATION COUNT

\*\*\*\*\*  
:SUBROUTINE TO GENERATE A INCREMENTING PATTERN AT  
:(R1)+. ENTER WITH R3 EQUAL TO # OF CH. TO CREATE.  
:R5 IS UTILIZED AS A WORK REGISTER.  
\*\*\*\*\*

3141  
3142  
3143  
3144  
3145  
3146  
3147  
3148  
3149

3150 017076 012705 000041  
3151 017102 110521  
3152 017104 005303  
MAINDEC-11-DZVTH-A  
DZVTH.P11

MACY11 27(732)  
END OF PASS ROUTINE

BLDINC: MOV #41,R5  
BLDINA: MOVB R5,(R1)+  
DEC R3  
20-SEP-76 10:22 PAGE 58

C06

;LOAD R5 WITH INITIAL CH.  
;MOVE A CH. TO BUFFER  
;DECREMENT BYTE COUNT

SEQ 0069

3153 017106 001001  
3154 017110 000200  
3155 017112 105205  
3156 017114 122705  
3157 017120 001766  
3158 017122 000767  
3159  
3160  
3161  
3162  
3163  
3164  
3165

000177

BNE 2\$  
RTS R0  
2\$: INCB R5  
CMPB #177,R5  
SEQ BLDINC  
BR BLDINA

;NOT DONE-UPDATE PATTERN  
;EXIT-DONE.  
;UPDATE CH. PATTERN  
;PATTERN EXCEEDED MAX?  
;YES-RESET IT.  
;NO-ISSUE CURRENT PATTERN.

\*\*\*\*\*

;SUBROUTINE TO FILL THE SCREEN WITH INCREMENTING DATA  
\*\*\*\*\*

3166 017124 042737 077577 002222  
3167 017132 013701 015136  
3168 017136 012703 000500  
3169 017142 004037 017076  
3170 017146 012737 003600 015144  
3171 017154 052777 000100 162552  
3172  
3173 017162 032737 000001 002222  
3174 017170 001774

077577 002222  
015136  
000500  
017076  
003600 015144  
000100 162552  
000001 002222

DATSC: BIC #77577,VSTAT  
MOV TBBUF,R1  
MOV #320,R3  
JSR R0,BLDINC  
10\$: MOV #T0TCH,XMCNT  
BIS #TENA,@VXCSR  
1\$: BIT #XMDONE,VSTAT  
BEQ -6

;CLEAR INTERRUPT FLAGS.  
;FILL XMIT BUFFER WITH INCRE-  
;MENTING PATTERN  
;SET UP TO XMIT 1920 BYTES  
;XMIT DONE?  
;NO

\*\*\*\*\*

;SUBROUTINE TO RESET VT61 AND DISPLAY MESSAGE  
;POINTED TO BY R2.

\*\*\*\*\*

3183 017172 004037 015146  
3184 017176 042737 077577 002222  
3185 017204 012737 000005 015144  
3186 017212 013701 015136  
3187 017216 012721 000002  
3188 017222 013721 002056  
3189 017226 013721 002012  
3190 017232 005237 015144  
3191 017236 112221  
3192 017240 001374  
3193 017242 112711 000004  
3194 017246 052777 000100 162460  
3195 017254 032737 000001 002222  
3196 017262 001774  
3197 017264 000200  
3198  
3199  
3200  
3201  
3202  
3203  
3204  
3205  
3206  
3207 017266  
3208 017266 010546

015146  
077577 002222  
000005 015144  
015136  
000002  
002056  
002012  
015144  
000004  
000100 162460  
000001 002222

DSMES: JSR R0,RESETV  
BIC #77577,VSTAT  
MOV #5,XMCNT  
MOV TBBUF,R1  
MOV #SOM,(R1)+  
MOV ESCO,(R1)+  
MOV DRECT,(R1)+  
1\$: INC XMCNT  
MOVB (R2)+,(R1)+  
BNE 1\$  
MOVB #EOM,(R1)  
BIS #TENA,@VXCSR  
2\$: BIT #XMDONE,VSTAT  
BEQ 2\$  
RTS R0

;RESET THE UNIT AND WAIT FOR XON.  
;CLEAR ALL FLAGS EXCEPT XOFF AND XMKIL.  
;PRE-LOAD XMIT COUNT.  
;LOAD XMIT BUFFER WITH:  
;START OF MESSAGE  
;DISABLE RECTANGULAR MODE  
;INCREMENT TRANSMIT COUNT  
;DISPLAY MESSAGE  
;TERMINATE WITH END OF MESSAGE.  
;XMIT IT AND WAIT FOR  
;DONE

\*\*\*\*\*

;SUBROUTINE TO CONVERT A BINARY CHARACTER  
;TO 3 OCTAL CHARACTERS. R1 CONTAINS BINARY  
;NUMBER. RESULT IS STORED IN LOCATIONS SVER1,  
;SVER2

\*\*\*\*\*

3207 017266  
3208 017266 010546  
MAINDEC-11-DZVTH-A  
DZVTH.P11

010546  
MACY11 27(732)  
END OF PASS ROUTINE

BINOCT: MOV R5,-(SP)  
20-SEP-76 10:22 PAGE 58

::PUSH R5 ON STACK

SEQ 0070

# D06

```

3209 017270 012705 000002      MOV     #2,R5      ;LOAD ITERATION COUNT
3210 017274 000403              BR      2$        ;BYPASS SHIFTS FOR 1ST CONVERSION
3211 017276 106201      1$:    ASRB    R1              ;
3212 017300 106201      ASRB    R1              ;SHIFT A CHAR INTO POSITION
3213 017302 106201      ASRB    R1              ;
3214 017304 110165 002162      2$:    MOVB    R1,SVER1(R5) ;STORE THE BINARY OFFSET
3215 017310 142765 000370 002162  BICB    #370,SVER1(R5) ;CLEAR NON ESSENTIAL BITS
3216 017316 152765 000060 002162  BISB    #60,SVER1(R5) ;CONVERT OFFSET TO OCTAL
3217 017324 005305      DEC     R5          ;DECREMENT CONVERSION COUNT
3218 017326 100363      SPL     1$          ;NOT DONE CONVERT ANOTHER
3219 017330 112737 000040 002165  MOVB    #40,SVER2+1 ;LOAD A SPACE
3220 017336 012605      MOV     (SP)+,R5   ;POP STACK INTO R5
3221 01734C 000200      RTS     R0          ;
3222
3223 ;*****
3224 ;SUBROUTINE TO CONVERT AN OCTAL CHAR. TO BINARY. REG
3225 ;R1 CONTAINS OCTAL AND REG R2 IS BINARY ASSEMBLY AREA.
3226 ;*****
3227
3228 01734E 042701 177770  OCTBIN: BIC     #177770,R1 ;EXTRACT OCTAL COMPONENT
3229 017346 005702      TST     R2          ;FIRST CONVERSION?
3230 017350 001403      BEQ     NOSHFT     ;YES - DO NOT SHIFT
3231 017352 006302      ASL     R2          ;NO - SHIFT PREVIOUS CHAR.
3232 017354 006302      ASL     R2          ;
3233 017356 006302      ASL     R2          ;
3234 017360 060102  NOSHFT: ADD    R1,R2      ;ADD CURRENT CHAR.
3235 017362 000200      RTS     R0          ;
3236
3237 ;*****
3238 ;ROUTINE TO WAIT FOR C/R FROM VT6! UNDER TEST
3239 ;*****
3240
3241 017364 032777 000200 162336  GTCR:  BIT     #RECDN,@VRCSR ;WAIT FOR REVEIVE DONE
3242 017372 001774      BEQ     -6         ;
3243 017374 127737 162332 001750  CMPB    @VRBUF,CARRT ;CHAR = CARRIAGE RETURN?
3244 017402 001370      BNE     GTCR      ;NO-KEEP LOOKING
3245 017404 000200      RTS     R0          ;YES-EXIT
3246
3247

```

E06

```

3248
3249
3250
3251
3252
3253
3254 017406 004037 013442
3255 017412 012601
3256 017414 122701 000054
3257 017420 001411
3258 017422 123701 001750
3259 017426 001406
3260 017430 120127 000060
3261 017434 103421
3262 017436 120127 000067
3263 017442 101016
3264 017444 110137 017514
MAINDEC-11-DZVTH-A MACY11 27(732)
DZVTH.P11 END OF PASS ROUTINE

```

```

;*****
;SUBROUTINE TO GET A CHARACTER (NUMERIC) FROM THE
;CONSOLE. IF OTHER THAN A NUMERIC IS TYPED A
;"?" WILL BE ECHOED.
;*****

```

```

GTNUM: JSR      RO CONRD      ;GET A CHAR
        MOV     (SP)+,R1     ;POP STACK INTO R1
        CMPB   #54,R1       ;CHAR. =COMMA?
        BEQ    IS           ;YES-GO PRINT IT
        CMPB   CARRT,R1     ;CHAR. = CARRIAGE RETURN?
        BEQ    IS
        CMPB   R1,#60
        BLO   QUST         ;IF CHAR. IS LESS THAN 60
        CMPB   R1,#67     ;OR MORE THAN 67, TYPE
        SHI   QUST         ;A QUESTION MARK
IS:     MOVB   R1,TYPNUM
20-SEP-76 10:22 PAGE 60

```

SEQ 0071

```

3265 017450 104400 017514
3266 017454 123701 001752
3267 017460 001406
3268 017462 123701 001750
3269 017466 001003
3270 017470 113701 001752
3271 017474 000763
3272 017476 000200
3273 017500 112737 000077 017514
3274 017506 104400 017514
3275 017512 000735
3276 017514 000
3277 017515 000

```

```

        TYPE   TYPNUM
        CMPB   LNFED,R1
        BEQ    GTEXT
        CMPB   CARRT,R1     ;IF CHAR. - C/R SET UP TO ISSUE
        BNE   GTEXT         ;LINE FEED BEFORE EXITING.
        MOVB   LNFED,R1
        BR     IS
GTEXT: RTS      RO          ;GOOD CHAR., EXIT
QUST:  MOVB   #77,TYPNUM
        TYPE   TYPNUM      ;TYPE QUESTION MARK AND
        BR     GTNUM       ;KEEP LOOKING.
TYPNUM: .BYTE  0
        .BYTE  0

```

```

3280
3281
3282
3283
3284
3285
3286
3287
3288
3289 017516 042705 177400
3290 017522 120527 000021
3291 017526 001415
3292 017530 120527 000023
3293 017534 001412
3294
3295 017536 000241
3296 017540 105704
3297 017542 100001
3298
3299 017544 000261
3300 017546 106104
3301 017550 010403
3302 017552 040503
3303 017554 040405
3304 017556 050305
3305 017560 010504
3306 017562 000200
3307

```

```

;*****
;SUBROUTINE TO CALCULATE CHECKSUM ON THE LOWER
;BYTE OF R5. R4 IS STORAGE FOR THE CHECKSUM
;CHARACTER. ALGORITHM FOR CHECKSUM IS ROTATE
;CURRENT ONE PLACE LEFT AND XOR NEW CHAR. CHECKSUM
;IS THE LOWER 7 BITS OF R4
;*****

```

```

;*****
CALCK: BIC     #177400,R5     ;CLEAR UPPER BYTE OF R5
        CMPB   R5,#XON      ;CHAR. =XON?
        BEQ    NOCALC       ;YES DO NOT CALCULATE CHECKSUM
        CMPB   R5,#XOFF     ;CHAR =XOFF?
        BEQ    NOCALC       ;YES DO NOT CALCULATE CHECKSUM
        CLC
        TSTB   R4           ;INSURE CARRY BIT INITIALLY CLEAR
        BPL   IS           ;SET UP TO ROTATE R4
                          ;A FULL 8 BYTES
IS:     SEC
        ROLB   R4           ;R4 WAS NEG. SO ROTATE A ONE
        MOV    R4,R3        ;INTO LOW ORDER BIT.
        BIC   R5,R3         ;NOT A AND B
        BIC   R4,R5         ;NOT B AND A
        BIS   R3,R5         ;ORED
        MOV   R5,R4         ;EQUAL NEW CHECKSUM
NOCALC: RTS      RO
;*****

```

# F06

```

3308
3309 ;SUBROUTINE TO LOAD XMIT BUFFER FROM R0 THRU R1
3310 ;*****
3311
3312 017564 112021 LDBUF: MOV (R0)+,(R1)+ ;LOAD A BYTE
3313 017566 001376 BNE -2 ; UNTIL ZERO BYTE FOUND.
3314 017570 000200 RTS R0
3315 ;*****
3316 ;SUBROUTINE TO CHECK THE VT61 FOR A PERIPHERAL ABORT.
3317 ;*****
3318
3319 017572 032737 010000 002222 CKABRT: BIT #PABRT,VSTAT ;ABORT FLAG RECEIVED?
3320 017600 001445 BEQ 25 ;NO-EXIT
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 61
DZVTH.P11 END OF PASS ROUTINE
SEQ 0072

3321 017602 010037 001124 MOV R0,$GDDAT
3322 017606 162737 000004 001124 SUB #4,$GDDAT ;POINT ERR PC TO MAIN ROUTINE.
3323 017614 013737 002222 001126 MOV VSTAT,$BDDAT
3324 017622 104020 ERROR 20 ;ISSUE PERIPHERAL ABORT ERROR
3325
3326 017624 013701 015136 MOV TBBUF,R1
3327 017630 004037 017564 JSR R0,LDBUF ;LOAD THE XMIT BUFFER WITH:
3328 017634 033 117 137 .BYTE .ESC,.0,.IABT,.ESC,.0,.RABT
3329 017637 033 117 140
3330 017642 033 117 145 .BYTE .ESC,.0,.UNLKKB,0
3331 017645 000
3332 017646 012737 000011 015144 MOV #9,XMCNT ;SET UP TO XMIT 9 BYTES.
3333 017654 004037 015552 JSR R0,XMREC ;XMIT AND RECEIVE.
3334 017660 000240 NOP
3335 017662 123727 014664 000170 CMPB STRO,#NABRT ;ABORT FLAG CLEARED?
3336 017670 001411 BEQ 25 ;YES-EXIT
3337 017672 010037 001124 MOV R0,$GDDAT ;NO-SET UP AND ISSUE A CANT
3338 017676 162737 000004 001124 SUB #4,$GDDAT ;CLEAR ABORT FLAG ERROR MESSAGE.
3339 017704 013737 002222 001126 MOV VSTAT,$BDDAT
3340 017712 104021 ERROR 21
3341 017714 000200 25: RTS R0
3342
3343 ;*****
3344 ;SUBROUTINE TO COMPARE RECEIVED KEYBOARD POSITION WITH
3345 ;EXPECTED KEYBOARD POSITION. ERRORS ARE REPORTED
3346 ;AS POSITIONAL ERRORS AND NOT DATA COMPARE ERRORS.
3347 ;*****
3348
3349
3350 017716 105077 011106 CKKBD: CLRB #ABUFF ;CLEAR RECEIVE BYTE
3351 017722 005037 002160 CLR CHR ;CLEAR INPUT STORAGE.
3352 017726 105777 011076 KBDLP: TSTB #ABUFF ;WAIT FOR A INPUT.
3353 017732 001775 BEQ -4
3354
3355 017734 117737 011070 002160 MOVB #ABUFF ,CHR ;STORE IT AND
3356 017742 105077 011062 CLRB #ABUFF ;CLEAR THE INPUT AREA.
3357 017746 123714 002160 15: CMPB CHR ,(R4) ;RECEIVED EQUAL EXPECTED?
3358 017752 001500 BEQ GDSTRK ;NO-UPDATE POINTERS.
3359 017754 005237 002206 INC BUBCT ;INCREMENT ERROR COUNT.
3360 017760 023727 002206 000012 CMP BUBCT,#10. ;COUNT = 10?
3361 017766 103075 BHIS CNTF ;YES-EXIT SUBROUTINE.
3362 017770 010401 MOV R4,R1
3363 017772 166501 011560 SUB DTBL(R5),R1 ;EXTRACT KEY POSITION FROM ROW LOC.
3364 017776 005201 INC R1 ;CONVERT LOGICAL POS TO ACTUAL.
3365 020000 004037 017266 JSR R0,BINOC ;GET KEY POSITION IN OCTAL.
3366 020004 113737 002164 002162 MOVB SVER2,SVER1 ;RE-ASSEMBLE OCTAL BYTES.
3367 020012 123727 002163 000060 CMPB SVER1+1,#60 ;POSITION LESS THAN 8?
3368 020020 001413 BEQ LDPOS ;YES-GO LOAD IT.

```



G06

3369 020022 123727 002162 000062  
 3370 020030 103404  
 3371 020032 162737 000002 002162  
 3372 020040 000403  
 3373 020042 162737 000370 002162  
 3374 020050 113737 002162 027441  
 3375 020056 113737 002163 027440  
 3376 020064 012703 027363  
 MAINDEC-11-DZVTH-A MACY11 27(732)  
 DZVTH.P11 END OF PASS ROUTINE

CMPB SVER1, #62 ; POSITION GREATER THAN 8 AND LESS THAN 12?  
 BLO BOROW ; YES-SET UP TO BORROW.  
 SUB #2, SVER1 ; NO-JUST SUBTRACT 2.  
 BR LDPOS  
 BOROW: SUB #370, SVER1 ; SUBTRACT AND BORROW.  
 LDPOS: MOVB SVER1, KYSTRK+1 ; LOAD THE CONVERTED DECIMAL #.  
 MOVB SVER1+1, KYSTRK  
 DMPDCT: MOV #DKBERR, R3  
 20-SEP-76 10:22 PAGE 62

SEQ 0073

3377 020070 004037 016076  
 3378 020074 111401  
 3379 020076 004037 017266  
 3380 020102 012703 002162  
 3381 020106 004037 016076  
 3382 020112 012703 027472  
 3383 020116 004037 016076  
 3384 020122 113701 002160  
 3385 020126 004037 017266  
 3386 020132 012703 002162  
 3387 020136 004037 016076  
 3388 020142 012703 001167  
 3389 020146 004037 016076  
 3390 020152 000665  
 3391  
 3392 020154 005204  
 3393 020156 105714  
 3394 020160 001262  
 3395 020162 000200  
 3396  
 3397  
 3398  
 3399  
 3400  
 3401  
 3402  
 3403  
 3404  
 3405  
 3406 020164 005237 020466  
 3407 020170 012737 031030 014632  
 3408 020176 012737 027630 015136  
 3409 020204 004037 016136  
 3410 020210 042737 077577 002222  
 3411 020216 013704 014634  
 3412 020222 032737 000001 002222  
 3413 020230 001407  
 3414 020232 042737 000001 002222  
 3415 020240 013737 014630 014634  
 3416 020246 000763  
 3417 020250 032737 001400 002222  
 3418 020256 001004  
 3419 020260 023704 014634  
 3420 020264 001756  
 3421 020266 000426  
 3422 020270 117777 010534 174336  
 3423 020276 005237 014634  
 3424 020302 005037 014636  
 3425 020306 042737 001400 002222  
 3426 020314 005237 015144  
 3427 020320 123777 002130 010502  
 3428 020326 001733  
 3429 020330 113777 001752 174276

JSR RD, LDXTM ; ISSUE BODY OF KEYBOARD ERROR.  
 MOV (R4), R1  
 JSR RD, BINOC  
 MOV #SVER1, R3  
 JSR RD, LDXTM ; CONVERT AND ISSUE GOOD CHAR.  
 MOV #DSPACE, R3  
 JSR RD, LDXTM ; INSERT 6 SPACES IN MESSAGE.  
 MOVB CHRD, R1  
 JSR RD, BINOC  
 MOV #SVER1, R3  
 JSR RD, LDXTM ; CONVERT AND ISSUE RECEIVED CHAR.  
 MOV #SCRLF, R3  
 JSR RD, LDXTM ; ISSUE C/R AND L/F.  
 BR KBDLP ; LOOK FOR SAME KEY AGAIN.

GDSTRK: INC R4 ; INCREMENT KEYBOARD ROW COUNTER.  
 TSTB (R4) ; REACHED END OF ROW?  
 BNE KBDLP ; NO-LOOK FOR NEXT INPUT  
 CNTF: RTS ; YES-EXIT.

\*\*\*\*\*

; SUBROUTINE TO LOOP DATA THROUGH HOST COMPUTER. ALL  
 ; FUNCTIONS ARE ALLOWED, BUT BLOCK TRANSMITS WHICH  
 ; EXCEED 552 BYTES WILL RESULT IN THE TERMINATION  
 ; OF THE OPERATION AFTER 552 RECEIVED BYTES.

\*\*\*\*\*

LOOP: INC XMZER ; SET UP TO XMIT NULLS.  
 MOV #TCRLB+500, REBUF ; RESET BUFFER POINTERS  
 MOV #RCRLB, TBBUF  
 JSR RD, RESPTR ; RELOAD ALL INTERRUPT POINTERS  
 BIC #77577, VSTAT ; CLEAR ALL FLAGS BUT XOFF AND XMKIL.  
 MOV RBUF, R4 ; SET UP RECEIVE FLAG  
 LOOPPT: BIT #XMDNE, VSTAT ; XMIT COMPLETE?  
 LOOPPTA: BEQ LOOPR ; NO  
 BIC #XMDNE, VSTAT ; YES RESET FLAG  
 MOV RBBUF, RBUF ; RESET THE REC. BUFFER POINTER  
 BR LOOPPT  
 LOOPR: BIT #EPL+ESC, VSTAT ; RECEIVED AN ESC OR EPL?  
 BNE LPSTR ; YES-GO CHECK IT  
 CMP RBUF, R4 ; RECEIVED A DISPLAY CHAR?  
 BEQ LOOPPTA ; NO-LOOP  
 BR  
 LPSTR: MOVB RABUF, RBUF ; YES LOAD IT IN THE BUFFER  
 INC RBUF ; AND INCREMENT BUFFER POINTER  
 CLR ESAMB ; CLEAR ESC ASSEMBLY WORD  
 BIC #EPL+ESC, VSTAT ; CLEAR THE FLAGS  
 INC XMCNT ; INCREMENT XMIT COUNT  
 CMPB ESCN, RABUF ; CHAR. A ESC(033)?  
 BEQ LOOPPT ; YES WAIT FOR NEXT PART OF FUNCTION  
 MOVB LNFED, RBUF ; CHAR. WAS EPL ADD A LINE FEED.



H06

3430 020336 005237 014634  
3431 020342 000407  
3432 020344 023727 015144 000764  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 END OF PASS ROUTINE

INC RBUF  
BR FRCECT  
BUMPCT: CMP XMCNT, #500.  
20-SEP-76 10:22 PAGE 63

;AND ISSUE THEM.  
;BUFFER ABOUT FILLED?

SEQ 0074

3433 020352 103403  
3434 020354 005337 014634  
3435 020360 000716  
3436 020362 005237 015144  
3437 020366 023727 015144 000002  
3438 020374 101003  
3439 020376 052777 000100 161330  
3440 020404 004037 020414  
3441 020410 000702  
3442 020412 000200  
3443  
3444  
3445  
3446  
3447  
3448  
3449

BLO FRCECT  
DEC RBUF  
BR LOOP  
FRCECT: INC XMCNT  
CMP XMCNT, #2  
BHI XMWT  
BIS #TENA, VVXCSR  
XMWT: JSR RO, EXTST  
BR LOOP  
RTS RO

;NO  
;YES-RESET THE RECEIVE POINTER  
;INCREMENT THE XMIT COUNT  
;FIRST CHAR TO XMIT?  
;NO  
;YES-SET THE XMIT ENABLE  
;LOOK FOR END OF TEST COMMAND.  
;NONE FOUND.  
;AND EXIT

\*\*\*\*\*  
;SUBROUTINE TO CHECK FOR END OF TEST COMMAND. THE CONTROL  
;C KEY EXITS ALL TESTS EXCEPT THE BLOCK MODE TEST  
;WHICH IS EXITED ON A @ KEY.  
\*\*\*\*\*

3450 020414 127727 010410 000003  
3451 020422 001020  
3452  
3453 020424 012737 030327 014632  
3454 020432 012737 030330 015136  
3455 020440 004037 016136  
3456 020444 012702 026253  
3457 020450 004037 017172  
3458 020454 005037 020466  
3459 020460 062700 000002  
3460 020464 000200  
3461  
3462 020466 000000  
3463  
3464  
3465  
3466  
3467  
3468  
3469

EXTST: CMPB #ABUFF, #3  
BNE NOROUT  
ABSXT: MOV #RCRLB+477, REBUF  
MOV #TCRLB, TBBUF  
JSR RO, RESPTR  
MOV #DXT, R2  
JSR RO, DSMES  
CLR XMZER  
ADD #2, RO  
NOROUT: RTS RO

;LOOK FOR CONTROL C.  
;RESET THE BUFFERS  
;RESET ALL POINTERS  
;ISSUE EXIT MESSAGE  
;CLEAR THE ZERO TRANSMIT FLAG.  
;SET UP TEST EXIT.  
;EXIT SUBROUTINE.

XMZER: .WORD 0  
\*\*\*\*\*  
;SUB-ROUTINE TO LOOK FOR VSTAT BIT ON THE STACK  
;DELAY FACTOR IS FIRST WORD ON THE STACK AND VSTAT BIT  
;IS THE SECOND. MIN. DELAY IS 4 U.S FOR A MOS 11/45.  
\*\*\*\*\*

3470 020470 012637 002220  
3471 020474 012637 020556  
3472 020500 012637 020554  
3473 020504 005037 002216  
3474 020510 033737 020554 002222  
3475 020516 001012  
3476 020520 005337 002216  
3477 020524 001371  
3478 020526 005337 020556  
3479 020532 001364  
3480 020534 104011  
3481 020536 005237 002176  
3482 020542 000401  
3483 020544 005720  
3484 020546  
3485 020546 013746 002220  
3486 020552 000200  
3487 020554 000000  
3488 020556 000000

WTBGND:  
MOV (SP)+, ROSVE  
MOV (SP)+, VDLAY  
MOV (SP)+, VBIT  
1\$: CLR DLAY  
2\$: BIT VBIT, VSTAT  
BNE FNDBT  
DEC DLAY  
BNE 2\$  
DEC VDLAY  
BNE 1\$  
ERROR 11  
INC FTLCNT  
BR TIMEXT  
FNDBT: TST (RO)+  
TIMEXT: MOV ROSVE, -(SP)  
RTS RO  
VBIT: 0  
VDLAY: 0

::POP STACK INTO ROSVE  
::POP STACK INTO VDLAY  
::POP STACK INTO VBIT  
;SENSED THE CONDITION?  
;YES-EXIT.  
;NO-RUN DELAY.  
;DELAY FACTOR EXPIRED?  
;NO-LOOP  
;DELAY EXPIRED-ISSUE HUNG NIT  
;INCREMENT FATAL XMIT COUNT.  
;SET UP FOR NORMAL EXIT  
;;PUSH ROSVE ON STACK

MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 END OF PASS ROUTINE

20-SEP-76 10:22 PAGE 64

SEQ 0075

3489  
3490  
3491  
3492  
3493  
3494  
3495  
3496  
3497  
3498  
3499  
3500  
3501  
3502  
3503  
3504  
3505  
3506  
3507  
3508  
3509  
3510  
3511  
3512  
3513  
3514  
3515  
3516  
3517  
3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526  
3527  
3528  
3529  
3530  
3531  
3532  
3533  
3534  
3535  
3536  
3537  
3538  
3539  
3540  
3541  
3542  
3543  
3544  
3545  
3546  
3547  
3548

020560 005037 002216  
020564 032737 100000 002222  
020572 001403  
020574 005337 002216  
020600 001371  
020602 000200  
  
020604  
020604 004037 013474  
020610 032777 040000 160320  
020616 001111  
  
020620 000416  
  
020622 013746 000004  
020626 012737 020646 000004  
020634 005737 177060  
020640 012637 000004  
020644 000463  
020646 022626  
020650 012637 000004  
020654 000423  
  
020656  
020656 032777 000400 160 2  
020664 001404  
020666 127737 160244 11102  
020674 001462  
020676 105737 001103  
020702 001421  
020704 123737 001115 001103  
020712 101015  
020714 032777 001000 160214  
020722 001404  
020724 013737 001110 001106  
020732 000443  
020734 105037 001103  
020740 005037 001156  
  
020744 000415  
020746 032777 004000 160162  
020754 001011  
020756 005737 001100

```
*****  
;SUBROUTINE TO LOOK FOR XOFF BEFORE EXITING A RECEIVE ROUTINE.  
*****  
CKOFF: CLR      DLAY  
1$: BIT      #RXOFF,VSTAT ;IS XOFF SET?  
      BEQ      2$          ;NO-EXIT  
      DEC      DLAY        ;RUN DELAY.  
      BNE      1$  
2$: RTS      RO  
  
*****  
.SBTTL SCOPE HANDLER ROUTINE  
  
;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT  
;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)  
;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>  
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
;*SW14=1 LOOP ON TEST  
;*SW11=1 INHIBIT ITERATIONS  
;*SW09=1 LOOP ON ERROR  
;*SW08=1 LOOP ON TEST IN SWR<7:0>  
;*CALL  
;* SCOPE ;;SCOPE=IOT  
  
$SCOPE:  
1$: JSR      RO MONIT  
      BIT      #BIT14,$SWR ;;LOOP ON PRESENT TEST?  
      BNE      $OVER ;;YES IF SW14=1  
;*****START OF CODE FOR THE XOR TESTER*****  
$XTSTR: BR      6$  
; IF RUNNING ON THE "XOR" TESTER CHANGE  
; THIS INSTRUCTION TO A "NOP" (NOP=240)  
; SAVE THE CONTENTS OF THE ERROR VECTOR  
MOV      2$ERRVEC,-(SP) ;;SET FOR TIMEOUT  
MOV      $5,$ERRVEC ;;TIME OUT ON XOR?  
TST      2$177060 ;;RESTORE THE ERROR VECTOR  
MOV      (SP)+,2$ERRVEC ;;GO TO THE NEXT TEST  
BR      $SVLAD ;;CLEAR THE STACK AFTER A TIME OUT  
5$: CMP      (SP)+,(SP)+ ;;RESTORE THE ERROR VECTOR  
MOV      (SP)+,2$ERRVEC ;;LOOP ON THE PRESENT TEST  
BR      7$  
6$;*****END OF CODE FOR THE XOR TESTER*****  
      BIT      #BIT08,$SWR ;;LOOP ON SPEC. TEST?  
      BEQ      2$ ;;BR IF NO  
      CMPB     2$SWR,$TSTNM ;;ON THE RIGHT TEST? SWR<7:0>  
      BEQ      $OVER ;;BR IF YES  
2$: TSTB     $ERFLG ;;HAS AN ERROR OCCURRED?  
      BEQ      3$ ;;BR IF NO  
      CMPB     $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?  
      BHI      3$ ;;BR IF NO  
      BIT      #BIT09,$SWR ;;LOOP ON ERROR?  
      BEQ      4$ ;;BR IF NO  
7$: MOV      $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE  
      BR      $OVER  
4$: CLRB     $ERFLG ;;ZERO THE ERROR FLAG  
      CLR      $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE  
  
3$: BR      1$ ;;ESCAPE TO THE NEXT TEST  
      BIT      #BIT11,$SWR ;;INHIBIT ITERATIONS?  
      BNE      1$ ;;BR IF YES  
      TST      $PASS ;;IF FIRST PASS OF PROGRAM
```

JOB

```

3549 020762 001406          BEQ      1$      INHIBIT ITERATIONS
3550 020764 005237 001104    INC      $ICNT   INCREMENT ITERATION COUNT
3551 020770 023737 001156 001104    CMP      $TIMES,$ICNT CHECK THE NUMBER OF ITERATIONS MADE
3552 020776 002021          BGE      $OVER   BR IF MORE ITERATION REQUIRED
3553 021000 012737 000001 001104 1$:      MOV      #1,$ICNT REINITIALIZE THE ITERATION COUNTER
3554 021006 013737 021056 001156    MOV      $MXCNT,$TIMES SET NUMBER OF ITERATIONS TO DO
3555 021014 105237 001102    $SVLAD: INCB    $STNM   COUNT TEST NUMBERS
3556 021020 011637 001106    MOV      (SP),$LPADR SAVE SCOPE LOOP ADDRESS
3557 021024 011637 001110    MOV      (SP),$LPERR SAVE ERROR LOOP ADDRESS
3558 021030 005037 001160    CLR      $ESCAPE CLEAR THE ESCAPE FROM ERROR ADDRESS
3559 021034 112737 000001 001115    MOV      #1,$ERMAX ONLY ALLOW ONE(1) ERROR ON NEXT TEST
3560 021042 013777 001102 160070 $OVER:  MOV      $STNM,$DISPLAY DISPLAY TEST NUMBER
3561 021050 013716 001106    MOV      $LPADR,(SP) FUDGE RETURN ADDRESS
3562 021054 000002          RTI      FIXES PS
3563 021056 000005    $MXCNT: 5      MAX. NUMBER OF ITERATIONS
;*****
3564
3565
3566 .SBTTL  ERROR HANDLER ROUTINE
3567
3568 ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
3569 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
3570 ;*AND GO TO $ERRTYP ON ERROR
3571 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3572 ;*SW15=1      HALT ON ERROR
3573 ;*SW13=1      INHIBIT ERROR TYPEOUTS
3574 ;*SW10=1     BELL ON ERROR
3575 ;*SW09=1     LOOP ON ERROR
3576 ;*CALL
3577 ;*      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
3578
3579 021060          $ERROR:
3580 021060 105237 001103    7$:      INCB    $ERFLG   ;; SET THE ERROR FLAG
3581 021064 001775          BEQ      7$      ;; DON'T LET THE FLAG GO TO ZERO
3582 021066 013777 001102 160044    MOV      $STNM,$DISPLAY ;; DISPLAY TEST NUMBER AND ERROR FLAG
3583 021074 032777 002000 160034    BIT      #BIT10,$SWR   ;; BELL ON ERROR?
3584 021102 001402          BEQ      1$      ;; NO - SKIP
3585 021104 104400 001162    TYPE    $BELL      ;; RING BELL
3586 021110 005237 001112    1$:      INC      $ERTTL   ;; COUNT THE NUMBER OF ERRORS
3587 021114 011637 001116    MOV      (SP),$ERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
3588 021120 162737 000002 001116    SUB      #2,$ERRPC
3589 021126 117737 157764 001114    MOV      $ERRPC,$ITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
3590 021134 032777 020000 157774    BIT      #BIT13,$SWR   ;; SKIP TYPEOUT IF SET
3591 021142 001004          BNE      20$     ;; SKIP TYPEOUTS
3592 021144 004737 021450    JSR      PC,$ERRTYP ;; GO TO USER ERROR ROUTINE
3593 021150 104400 001167    TYPE    $CRLF
3594 021154
3595 021154 005777 157756    20$:     TST      $SWR      ;; HALT ON ERROR
3596 021160 100006          BPL      3$      ;; SKIP IF CONTINUE
3597 021162 000000          HALT     ;; HALT ON ERROR!
3598 021164 022737 010570 000042    CMP      #SENDAD,$#42 ;; ACT-11 AUTO-ACCEPT?
3599 021172 001001          BNE      3$      ;; BRANCH IF NO
3600 021174 000000          HALT     ;; YES
MAINDEC-11-DZVTH-A      MACY11 27(732) 20-SEP-76 10:22 PAGE 66
DZVTH.P11      ERROR HANDLER ROUTINE
;*****
3601 021176 032777 001000 157732 3$:      BIT      #BIT09,$SWR   ;; LOOP ON ERROR SWITCH SET?
3602 021204 001402          BEQ      4$      ;; BR IF NO
3603 021206 013716 001110    MOV      $LPERR,(SP) ;; FUDGE RETURN FOR LOOPING
3604 021212 005737 001160    4$:      TST      $ESCAPE   ;; CHECK FOR AN ESCAPE ADDRESS
3605 021216 001402          BEQ      5$      ;; BR IF NONE
3606 021220 013716 001160    MOV      $ESCAPE,(SP) ;; FUDGE RETURN ADDRESS FOR ESCAPE
3607 021224
3608 021224 000002          RTI      ;; RETURN
3609 ;*****

```

# K06

.SBTTL TYPE ROUTINE

```

3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656

```

\*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.  
 \*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.  
 \*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.  
 \*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.  
 \*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.  
 \*  
 \*CALL:  
 \*1) USING A TRAP INSTRUCTION  
 \* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING  
 \*OR  
 \* TYPE  
 \* MESADR  
 \*  
 \*2) USING A JSR INSTRUCTION  
 \* MOV PS,-(SP) ;;PUSH PROCESSOR STATUS WORD ON THE STACK  
 \* JSR PC,\$TYPE ;;CALL TYPE ROUTINE  
 \* MESADDR ;;FIRST ADDRESS OF MESSAGE  
 \$TYPE: TSTB \$TPFLG ;; IS THERE A TERMINAL?  
 BPL 1\$ ;;BR IF YES  
 HALT ;;HALT HERE IF NO TERMINAL  
 BR 3\$ ;;LEAVE  
 1\$: MOV RO,-(SP) ;;SAVE RO  
 MOV 22(SP),RO ;;GET ADDRESS OF ASCIZ STRING  
 2\$: MOVB (RO)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK  
 BNE 4\$ ;;BR IF IT ISN'T THE TERMINATOR  
 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK  
 60\$: MOV (SP)+,RO ;;RESTORE RO  
 3\$: ADD #2,(SP) ;;ADJUST RETURN PC  
 RTI ;;RETURN  
 4\$: CMPB #THT,(SP) ;;BRANCH IF <HT>  
 BEQ 8\$  
 CMPB #TCRLF,(SP) ;;BRANCH IF NOT <CRLF>  
 BNE 5\$  
 TST (SP)+ ;;POP <CR><LF> EQUIV  
 MOV PS,-(SP) ;;TYPE CR AND LF  
 JSR PC,\$TYPE  
 \$CRLF  
 BR 2\$ ;;GET NEXT CHARACTER  
 5\$: JSR PC,\$TYPEC ;;GO TYPE THIS CHARACTER  
 6\$: CMPB \$FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?  
 BNE 2\$ ;;IF NO GO GET NEXT CHAR.  
 MOV \$NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED  
 ;;AND THE NULL CHAR.

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 67  
 DZVTH.P11 TYPE ROUTINE

SEQ 0079

```

3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669
3670

```

7\$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?  
 BLT 6\$ ;;BR IF NO--GO POP THE NULL OFF OF STACK  
 JSR PC,\$TYPEC ;;GO TYPE A NULL  
 DECB \$CHARCNT ;;DO NOT COUNT AS A COUNT  
 BR 7\$ ;;LOOP  
 ;HORIZONTAL TAB PROCESSOR  
 8\$: MOVB #40,(SP) ;;REPLACE TAB WITH SPACE  
 9\$: JSR PC,\$TYPEC ;;TYPE A SPACE  
 BITB #7,\$CHARCNT ;;BRANCH IF NOT AT  
 BNE 9\$ ;;TAB STOP  
 TST (SP)+ ;;POP SPACE OFF STACK  
 BR 2\$ ;;GET NEXT CHARACTER

L06

```

3671 021400 105777 157542 $TYPEC: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY
3672 021404 100375 BPL $TYPEC
3673 021406 116677 000002 157534 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
3674 021414 122766 000015 000002 CMPB #15,2(SP) ;;BRANCH IF
3675 021422 001003 BNE 1$ ;;NOT <CR>
3676 021424 105037 021444 CLRB $CHARCNT
3677 021430 000406 BR $TYPEX ;;EXIT
3678 021432 122766 000012 000002 1$: CMPB #12,2(SP) ;;BRANCH IF
3679 021440 002002 BGE $TYPEX ;;<LF>
3680 021442 105227 INCB (PC)+ ;;INC SPACE
3681 021444 000000 $CHARCNT: .WORD 0 ;;COUNT
3682 021446 000207 $TYPEX: RTS PC
3683 ;; EQUATES
3684 000011 THT=11
3685 000200 TCRLF=200

```

\*\*\*\*\*

.SETTL ERROR MESSAGE TYPEOUT ROUTINE

```

; *THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
; *ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
; *AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

\$ERRTYP:

```

3695 021450 $ERRTYP:
3696 021450 10-400 001167 TYPE $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
3697 021454 010046 MOV RO,-(SP) ;; SAVE RO
3698 021456 005000 CLR RO ;; PICKUP THE ITEM INDEX
3699 021460 153700 001114 BISB @#$ITEMB,RO
3700 021464 001004 BNE 1$ ;; IF ITEM NUMBER IS ZERO, JUST
3701 ;; TYPE THE PC OF THE ERROR
3702 021466 013746 001116 MOV $ERRPC,-(SP) ;; SAVE $ERRPC FOR TYPEOUT
3703 ;; ERROR ADDRESS
3704 021472 104401 TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3705 021474 000445 BR 10$ ;; GET OUT
3706 021476 005300 1$: DEC RO ;; ADJUST THE INDEX SO THAT IT WILL
3707 021500 006300 ASL RO ;; WORK FOR THE ERROR TABLE
3708 021502 006300 ASL RO
3709 021504 006300 ASL RO
3710 021506 062700 001172 ADD #$ERRTB,RO ;; FORM TABLE POINTER
3711 021512 012037 021522 MOV (RO)+,2$ ;; PICKUP "ERROR MESSAGE" POINTER
3712 021516 001404 BEQ 3$ ;; SKIP TYPEOUT IF NO POINTER

```

```

3713 021520 104400 TYPE ;; TYPE THE "ERROR MESSAGE"
3714 021522 000000 2$: .WORD 0 ;; "ERROR MESSAGE" POINTER GOES HERE
3715 021524 104400 001167 TYPE $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
3716 021530 012037 021540 3$: MOV (RO)+,4$ ;; PICKUP "DATA HEADER" POINTER
3717 021534 001404 BEQ 5$ ;; SKIP TYPEOUT IF 0
3718 021536 104400 TYPE ;; TYPE THE "DATA HEADER"
3719 021540 000000 4$: .WORD 0 ;; "DATA HEADER" POINTER GOES HERE
3720 021542 104400 001167 TYPE $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
3721 021546 010146 5$: MOV R1,-(SP) ;; SAVE R1
3722 021550 012001 MOV (RO)+,R1 ;; PICKUP "DATA TABLE" POINTER
3723 021552 001415 BEQ 9$ ;; BR IF NO DATA TO BE TYPED
3724 021554 012000 MOV (RO)+,RO ;; PICKUP "DATA FORMAT" POINTER
3725 021556 105720 6$: TSTB (RO)+ ;; "OCTAL" OR "DECIMAL"
3726 021560 001003 BNE 7$ ;; BR IF DECIMAL
3727 021562 013146 MOV @ (R1)+,-(SP) ;; SAVE @ (R1)+ FOR TYPEOUT
3728 021564 104401 TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3729 021566 000402 BR 8$
3730 021570 7$:
3731 021570 013146 MOV @ (R1)+,-(SP) ;; SAVE @ (R1)+ FOR TYPEOUT

```

MO6

3732 021572 104404  
 3733 021574 005711  
 3734 021576 001403  
 3735 021600 104400 021620  
 3736 021604 000764  
 3737  
 3738 021606 012601  
 3739 021610 012600  
 3740 021612 104400 0C1167  
 3741 021616 000207  
 3742 021620 020040 000  
 3743 021624

```

8$:  TYPDS
    TST      (R1)
    BEQ     9$
    TYPE    11$
    BK      6$
    ;; GO TYPE--DECIMAL ASCII WITH SIGN
    ;; IS THERE ANOTHER NUMBER?
    ;; BR IF NO
    ;; TYPE TWO(2) SPACES
    ;; LOOP

9$:  MOV     (SP)+,R1
10$: MOV     (SP)+,R0
    TYPE    $CRLF
    RTS     PC
    ;; RESTORE R1
    ;; RESTORE R0
    ;; "CARRIAGE RETURN" & "LINE FEED"
    ;; RETURN
11$: .ASCIZ  / /
    .EVEN
    ;; TWO(2) SPACES
  
```

\*\*\*\*\*

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
; *OCTAL (ASCII) NUMBER AND TYPE IT.
; *$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
; *CALL:
; *   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
; *   TYPOS   N              ;; CALL FOR TYPEOUT
; *   .BYTE  N              ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
; *   .BYTE  M              ;; M=1 OR 0
; *                               ;; 1=TYPE LEADING ZEROS
; *                               ;; 0=SUPPRESS LEADING ZEROS
  
```

```

; *$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
; *$TYPOS OR $TYPOC
; *CALL:
; *   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
; *   TYPON   N              ;; CALL FOR TYPEOUT
  
```

```

; *$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
; *CALL:
; *   MOV     NUM,-(SP)      ;; NUMBER TO BE TYPED
; *   TYPOC   N              ;; CALL FOR TYPEOUT
  
```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 69  
 DZVTH.P11 BINARY TO OCTAL (ASCII) AND TYPE

SEQ 0080

3769  
 3770 021624 017646 000000  
 3771 021630 116637 000001 022047  
 3772 021636 112637 022051  
 3773 021642 062716 000002  
 3774 021646 000406  
 3775 021650 112737 000001 022047  
 3776 021656 112737 000006 022051  
 3777 021664 112737 000005 022046  
 3778 021672 010346  
 3779 021674 010446  
 3780 021676 010546  
 3781 021700 113704 022051  
 3782 021704 005404  
 3783 021706 062704 000006  
 3784 021712 110437 022050  
 3785 021716 113704 022047  
 3786 021722 016605 000012  
 3787 021726 005003  
 3788 021730 006105  
 3789 021732 000404  
 3790 021734 006105  
 3791 021736 006105  
 3792 021740 006105

```

$TYPOS: MOV     2(SP),-(SP)      ;; PICKUP THE MODE
        MOV     1(SP), $OFILL   ;; LOAD ZERO FILL SWITCH
        MOV     (SP)+, $OMODE+1 ;; NUMBER OF DIGITS TO TYPE
        ADD     #2, (SP)        ;; ADJUST RETURN ADDRESS
        BR      $TYPON
$TYPOC: MOV     #1, $OFILL      ;; SET THE ZERO FILL SWITCH
        MOV     #6, $OMODE+1    ;; SET FOR SIX(6) DIGITS
$TYPON: MOV     #5, $OCNT       ;; SET THE ITERATION COUNT
        MOV     R3, -(SP)       ;; SAVE R3
        MOV     R4, -(SP)       ;; SAVE R4
        MOV     R5, -(SP)       ;; SAVE R5
        MOV     $OMODE+1, R4    ;; GET THE NUMBER OF DIGITS TO TYPE
        NEG     R4
        ADD     #6, R4          ;; SUBTRACT IT FOR MAX. ALLOWED
        MOV     R4, $OMODE      ;; SAVE IT FOR USE
        MOV     $OFILL, R4     ;; GET THE ZERO FILL SWITCH
        MOV     12(SP), R5     ;; PICKUP THE INPUT NUMBER
        CLR     R3             ;; CLEAR THE OUTPUT WORD
1$:     ROL     R5              ;; ROTATE MSB INTO "C"
        BR     3$
2$:     ROL     R5              ;; GO DO MSB
        ROL     R5              ;; FORM THIS DIGIT
        ROL     R5
  
```

N06

```

3793 021742 010503          MOV      R5,R3
3794 021744 006103          3$:    ROL      R3
3795 021746 105337 022050        DECB    $OMODE
3796 021752 100016          BPL     7$
3797 021754 042703 177770        BIC     #177770,R3
3798 021760 001002          BNE     4$
3799 021762 005704          TST     R4
3800 021764 001403          BEQ     5$
3801 021766 005204          4$:    INC     R4
3802 021770 052703 000060        BIS     #'0,R3
3803 021774 052703 000040        5$:    BIS     #' ,R3
3804 022000 110337 022044        MOVB   R3,8$
3805 022004 104400 022044        TYPE   8$
3806 022010 105337 022046        7$:    DECB   $OCNT
3807 022014 003347          BGT     2$
3808 022016 002402          BLT     6$
3809 022020 005204          INC     R4
3810 022022 000744          BR      2$
3811 022024 012605          6$:    MOV     (SP)+,R5
3812 022026 012604          MCV     (SP)+,R4
3813 022030 012603          MOV     (SP)+,R3
3814 022032 016666 000002 000004        MOV     2(SP),4(SP)
3815 022040 012616          MOV     (SP)+,(SP)
3816 022042 000002          RTI
3817 022044          8$:    .BYTE  0
3818 022045          .BYTE  0
3819 022046          .BYTE  0
3820 022047          .BYTE  0
3821 022050 000000        $OCNT: .BYTE  0
3822          $OFILL: .BYTE  0
3823          $OMODE: .WORD  0
3824          ;*****

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 70  
DZVTH.P11 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0081

```

3825          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
3826          ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
3827          ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
3828          ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
3829          ;*REPLACED WITH SPACES.
3830          ;*CALL:
3831          ;*
3832          ;*      MOV      NUM,-(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
3833          ;*      TYPDS          ;;GO TO THE ROUTINE
3834
3835          $TYPDS:
3836          MOV      R0,-(SP)          ;;PUSH R0 ON STACK
3837          MOV      R1,-(SP)          ;;PUSH R1 ON STACK
3838          MOV      R2,-(SP)          ;;PUSH R2 ON STACK
3839          MOV      R3,-(SP)          ;;PUSH R3 ON STACK
3840          MOV      R5,-(SP)          ;;PUSH R5 ON STACK
3841          MOV      #20200,-(SP)      ;;SET BLANK SWITCH AND SIGN
3842          MOV      20(SP),R5        ;;GET THE INPUT NUMBER
3843          BPL     1$                ;;BR IF INPUT IS POS.
3844          NEG     R5                ;;MAKE THE BINARY NUMBER POS.
3845          MOVB   #'-,1(SP)          ;;MAKE THE ASCII NUMBER NEG.
3846          CLR     R0                ;;ZERO THE CONSTANTS INDEX
3847          MOV     #DBLK,R3          ;;SETUP THE OUTPUT POINTER
3848          MOVB   #' ,(R3)+          ;;SET THE FIRST CHARACTER TO A BLANK
3849          CLR     R2                ;;CLEAR THE BCD NUMBER
3850          MOV     $DTBL(R0),R1      ;;GET THE CONSTANT
3851          1$:    SUB     R1,R5        ;;FORM THIS BCD DIGIT
3852          BLT     4$                ;;BR IF DONE
3853          INC     R2                ;;INCREASE THE BCD DIGIT BY 1

```



```

3854 022134 000774 BR 38
3855 022136 060135 45: FOC R1,R5
3856 022140 005702 TST R2
3857 022142 001002 BNE 58
3858 022144 105716 TSTB (SP)
3859 022146 103407 BMI 78
3860 022150 106316 55: ASLB (SP)
3861 022152 103003 BCC 68
3862 022154 116663 000001 177777 MOVB 1(SP),-1(R3)
3863 022162 052702 000060 65: BIC #'C,R2
3864 022166 052702 000040 75: BIS #' R2
3865 022172 110223 MOVB R2,(R3)+
3866 022174 005720 TST (R0)+
3867 022176 020027 000010 CMP R0,#10
3868 022202 003746 BLT 28
3869 022204 003002 BGT 98
3870 022206 010502 MOV R5,R2
3871 022210 000764 BR 68
3872 022212 105726 85: TSTB (SP)+
3873 022214 100003 BPL 98
3874 022216 116663 177777 177776 MOVB -1(SP),-2(R3)
3875 022224 105013 95: CLRB (R3)
3876 022226 012605 MOV (SP)+,R5
3877 022230 012603 MOV (SP)+,R3
3878 022232 012602 MOV (SP)+,R2
3879 022234 012601 MOV (SP)+,R1
3880 022236 012600 MOV (SP)+,R0

```

```

:: ACC BACK THE CONSTANT
:: CHECK IF BCD DIGIT=3
:: FALL THROUGH IF 0
:: STILL DOING LEADING 0'S?
:: BR IF YES
:: MSD?
:: BR IF NO
:: YES--SET THE SIGN
:: MAKE THE BCD DIGIT ASCII
:: MAKE IT A SPACE IF NOT ALREADY A DIGIT
:: PUT THIS CHARACTER IN THE OUTPUT BUFFER
:: JUST INCREMENTING
:: CHECK THE TABLE INDEX
:: GO DO THE NEXT DIGIT
:: GO TO EXIT
:: GET THE LSD
:: GO CHANGE TO ASCII
:: WAS THE LSD THE FIRST NON-ZERO?
:: BR IF NO
:: YES--SET THE SIGN FOR TYPING
:: SET THE TERMINATOR
:: POP STACK INTO R5
:: POP STACK INTO R3
:: POP STACK INTO R2
:: POP STACK INTO R1
:: POP STACK INTO R0

```

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 71  
DZVTH.P11 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0082

```

3881 022240 104400 022266 TYPE SDBLK
3882 022244 016666 000002 000004 MOV 2(SP),4(SP)
3883 022252 012616 MOV (SP)+,(SP)
3884 022254 000002 RTI
3885 022256 023420 SOTBL: 10000.
3886 022260 001750 1000.
3887 022262 000144 100.
3888 022264 000012 10.
3889 022266 000004 SDBLK: .BLKW 4
;*****
.SBTL POWER DOWN AND UP ROUTINES
:POWER DOWN ROUTINE
$PWRDN: MOV $SILLUP,2#PWRVEC ;; SET FOR FAST UP
MOV #340,2#PWRVEC+2 ;; PRIO:7
MOV R0,-(SP) ;; PUSH R0 ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
MOV R3,-(SP) ;; PUSH R3 ON STACK
MOV R4,-(SP) ;; PUSH R4 ON STACK
MOV R5,-(SP) ;; PUSH R5 ON STACK
MOV SP,$SAVR6 ;; SAVE SP
MOV $PWRUP,2#PWRVEC ;; SET UP VECTOR
HALT
BR -2 ;; HANG UP

:POWER UP ROUTINE
$PWRUP: MOV $SAVR6,SP ;; GET SP
CLR $SAVR6 ;; WAIT LOOP FOR THE TTY
15: INC $SAVR6 ;; WAIT FOR THE INC
BNE 15 OF WORD
MOV (SP)+,R5 ;; POP STACK INTO R5
MOV (SP)+,R4 ;; POP STACK INTO R4

```

C07

3915 022366 012603  
 3916 022370 012602  
 3917 022372 012601  
 3918 022374 012600  
 3919 022376 012737 022276 000024  
 3920 022404 012737 000340 000026  
 3921 022412 104400  
 3922 022414 022426  
 3923 022416 000002  
 3924 022420 000000  
 3925 022422 000776  
 3926 022424 000000  
 3927 022426 005015 047520 042527  
 3928 022434 000122

```

MOV (SP)+,R3    ;; POP STACK INTO R3
MOV (SP)+,R2    ;; POP STACK INTO R2
MOV (SP)+,R1    ;; POP STACK INTO R1
MOV (SP)+,R0    ;; POP STACK INTO R0
MOV #SPWRDN,2#PWRVEC ;; SET UP THE POWER DOWN VECTOR
MOV #340,2#PWRVEC+2 ;; PRIO:7
TYPE           ;; REPORT THE POWER FAILURE
SPWRMG: .WORD  SPOWER ;; POWER FAIL MESSAGE POINTER
$ILLUP: HALT    ;; THE POWER UP SEQUENCE WAS STARTED
BR        .-2   ;; BEFORE THE POWER DOWN WAS COMPLETE
$SAVR6: 0
$POWER: .ASCIZ <15><12>"POWER"
  
```

.EVEN  
 ;\*\*\*\*\*

.SBTTL TRAP DECODER

;\*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
 ;\*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
 ;\*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL

MAINDEC-11-DZVTH-A MACY11 27(732)  
 DZVTH.P11 TRAP DECODER 20-SEP-76 10:22 PAGE 72

553 0083

3937  
 3938  
 3939 022436 010046  
 3940 022440 016600 000002  
 3941 022444 005740  
 3942 022446 111000  
 3943 022450 006300  
 3944 022452 016000 022460  
 3945 022456 000200  
 3946  
 3947  
 3948  
 3949  
 3950  
 3951  
 3952  
 3953  
 3954  
 3955 022460  
 3956 022460 021226  
 3957 022462 021650  
 3958 022464 021624  
 3959 022466 021664  
 3960 022470 022052  
 3961  
 3962 022472 003062 003450 003656  
 3963  
 3964 022500 004052 004204 004420  
 3965  
 3966 022506 004650 005424 006104  
 3967  
 3968 022514 006316 006472 006720  
 3969  
 3970 022522 007142 007642 010060  
 3971  
 3972 022530 010226 010624 011130  
 3973  
 3974 022536 011326 011400  
 3975

;\*GO TO THAT ROUTINE.

```

$TRAP: MOV R0,-(SP) ;; SAVE R0
MOV 2(SP),R0 ;; GET TRAP ADDRESS
TST -(R0) ;; BACKUP BY 2
MOVB (R0),R0 ;; GET RIGHT BYTE OF TRAP
ASL R0 ;; POSITION FOR INDEXING
MOV $TRPAD(R0),R0 ;; INDEX TO TABLE
RTS R0 ;; GO TO ROUTINE
  
```

.SBTTL TRAP TABLE

;\*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
 ;\*BY THE "TRAP" INSTRUCTION.

```

; ROUTINE
; -----
$TRPAD:
$STYPE ;;CALL=TYPE TRAP+0(104400) TTY TYPEOUT ROUTINE
$STYPOC ;;CALL=TYPOC TRAP+1(104401) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$STYPOS ;;CALL=TYPOS TRAP+2(104402) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$STYPON ;;CALL=TYPON TRAP+3(104403) TYPE OCTAL NUMBER (AS PER LAST CALL)
$STYPDS ;;CALL=TYPDS TRAP+4(104404) TYPE DECIMAL NUMBER (WITH SIGN)
  
```

```

TSTADD: TST1,TST2,TST3
TST4,TST5,TST6
TST7,TST10,TST11
TST12,TST13,TST14
TST15,TST16,TST17
TST20,TST21,TST22
TST23,TST24
  
```

D07

3976				
3977				
3978	022542	042523	020124	052126
3979	022550	030466	020123	047524
3980	022556	020040	052506	046114
3981	022564	042040	050125	042514
3982	022572	026130	006440	012
3983	022577	071	030066	041060
3984	022604	052501	026104	051040
3985	022612	046505	052117	026105
3986	022620	040520	044522	054524
3987	022626	046440	052101	044103
3988	022634	042105	052040	020117
3989	022642	047111	042524	043122
3990	022650	041501	006505	000012
3991				
3992				

STUPM: .ASCII /SET VT615 TO FULL DUPLEX, /<15><12>

.ASCIZ /9600BAUD, REMOTE, PARITY MATCHED TO INTERFACE /<15><12>

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 73  
DZVTH.P11 TRAP TABLE

SEQ 0084

3993				
3994	022656	005015	042101	051104
3995	022664	051505	042523	020123
3996	022672	044527	044124	051040
3997	022700	051505	047520	051516
3998	022706	053111	020105	052126
3999	022714	030466	020123	051101
4000	022722	035105	005015	000
4001	022727	015	047012	020117
4002	022734	052126	030466	051040
4003	022742	051505	047520	042116
4004	022750	042105	052040	020117
4005	022756	051505	055103	051440
4006	022764	050505	020056	052501
4007	022772	047524	051040	052105
4008	023000	054522	044440	020116
4009	023006	030063	051440	041505
4010	023014	006456	000012	
4011				
4012				
4013	023020	005015	046104	030461
4014	023026	043040	044501	042514
4015	023034	020104	052101	040440
4016	023042	042104	042522	051523
4017	023050	000		
4018				
4019	023051	115	047101	040525
4020	023056	020114	042524	052123
4021	023064	051440	046105	041505
4022	023072	042524	020104	006455
4023	023100	012		
4024	023101	105	052116	051105
4025	023106	040440	042104	042522
4026	023114	051523	051505	047440
4027	023122	020106	052126	030466
4028	023130	020123	047524	041040
4029	023136	020105	042524	052123
4030	023144	042105	005015	000
4031				
4032	023151	105	052116	051105
4033	023156	052040	051505	051524
4034	023164	052040	020117	042502
4035	023172	051040	047125	005015
4036	023200	000		

DUNTST: .ASCIZ <15><12>/ADDRESSES WITH RESPONSIVE VT615 ARE: /<15><12>

NOVT: .ASCIZ <15><12>/NO VT61 RESPONDED TO ESCZ SEQ. AUTO RETRY IN 30 SEC. /<15><12>

DLERR: .ASCIZ <15><12>/DL11 FAILED AT ADDRESS /

DMANA: .ASCII /MANUAL TEST SELECTED - /<15><12>

.ASCIZ /ENTER ADDRESSES OF VT615 TO BE TESTED /<15><12>

DMANB: .ASCIZ /ENTER TESTS TO BE RUN /<15><12>

# E07

4037  
4038 023201 101 020116 051505  
4039 023206 020103 042523 027121  
4040 023214 052040 020117 044124  
4041 023222 020105 052126 030466  
4042 023230 020040 040506 046111  
4043 023236 042105 026440 047440  
4044 023244 052103 046101 042440  
4045 023252 052521 053111 020056  
4046 023260 051511 006472 000012  
4047 023266 042524 052123 020043  
4048 023274 042440 051122 050040  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE

EM1: .ASCIZ /AN ESC SEQ. TO THE VT61 FAILED - OCTAL EQUIV. IS:/'15'<12>

DH1: .ASCIZ /TEST# ERR PC BYTE 1+2 BYTE 3+4/'15'<12>

20-SEP-76 10:22 PAGE 74

SEQ 0085

4049 023302 020103 041040 052131  
4050 023310 020105 025461 020062  
4051 023316 054502 042524 031440  
4052 023324 032053 005015 000  
4053  
4054 023331 122 041505 044505  
4055 023336 042526 051440 040524  
4056 023344 052524 020123 051105  
4057 023352 047522 027122 005015  
4058 023360 000  
4059 023361 101 042104 020056  
4060 023366 051440 040524 027124  
4061 023374 020040 051105 027122  
4062 023402 044502 051524 020040  
4063 023410 044103 051101 006456  
4064 023416 000012  
4065  
4066 023420 047523 052106 040527  
4067 023426 042522 024040 051526  
4068 023434 040524 024524 051440  
4069 023442 040524 052524 020123  
4070 023450 051105 047522 027122  
4071 023456 005015 000  
4072 023461 040 040520 051523  
4073 023466 026043 020040 042524  
4074 023474 052123 026043 020040  
4075 023502 054105 027120 052123  
4076 023510 052101 020054 040440  
4077 023516 052103 051456 040524  
4078 023524 006524 000012  
4079  
4080 023530 042107 020056 040504  
4081 023536 040524 042040 042517  
4082 023544 020123 047516 020124  
4083 023552 040515 041524 020110  
4084 023560 042522 027103 042040  
4085 023566 052101 006501 000012  
4086 023574 042524 052123 020043  
4087 023602 051054 041505 041456  
4088 023610 052116 026056 042107  
4089 023616 020056 040504 040524  
4090 023624 020054 042522 027103  
4091 023632 042040 052101 006501  
4092 023640 000012  
4093  
4094  
4095 023642 054502 042524 020123  
4096 023650 054105 042520 052103  
4097 023656 042105 042040 042517

EM2: .ASCIZ /RECEIVE STATUS ERROR./'15'<12>

DH2: .ASCIZ /ADD. STAT. ERR.BITS CHAR./'15'<12>

EM3: .ASCIZ /SOFTWARE (VSTAT) STATUS ERROR./'15'<12>

DH3: .ASCIZ / PASS#, TEST#, EXP.STAT, ACT.STAT/'15'<12>

EM4: .ASCIZ /GD. DATA DOES NOT MATCH REC. DATA/'15'<12>

DH4: .ASCIZ /TEST#, REC.CNT., GD. DATA, REC. DATA/'15'<12>

.EVEN

EM5: .ASCIZ /BYTES EXPECTED DOES NOT EQUAL BYTES RECEIVED/'15'<12>

# F07

4098	023664	020123	047516	020124
4099	023672	050505	040525	020114
4100	023700	054502	042524	020123
4101	023706	042522	042503	053111
4102	023714	042105	005015	000
4103	023721	102	052131	051505
4104	023726	042440	050130	026056

DH5: .ASCIZ /BYTES EXP., BYTES REC./<15><12>

MAINDEC-11-DZVTH-A  
DZVTH.P11

TRAP TABLE

MACY11 27(732)

20-SEP-76 10:22 PAGE 75

SEQ 0086

4105	023734	041040	052131	051505
4106	023742	051040	041505	006456
4107	023750	000012		

4108				
------	--	--	--	--

4109	023752	052503	051522	051117
4110	023760	050040	051517	052111
4111	023766	047511	044516	043516
4112	023774	042440	051122	051117

EM6: .ASCIZ /CURSOR POSITIONING ERROR/<15><12>

4113	024002	005015	000	
------	--------	--------	-----	--

4114	024005	107	020104	044514
------	--------	-----	--------	--------

DH6: .ASCIZ /GD LINE GD COL. BD LINE BD COL/<15><12>

4115	024012	042516	020040	042107
------	--------	--------	--------	--------

4116	024020	041440	046117	020056
------	--------	--------	--------	--------

4117	024026	020040	042102	046040
------	--------	--------	--------	--------

4118	024034	047111	020105	041040
------	--------	--------	--------	--------

4119	024042	020104	047503	006514
------	--------	--------	--------	--------

4120	024050	000012		
------	--------	--------	--	--

4121				
------	--	--	--	--

4122	024052	044504	042522	052103
------	--------	--------	--------	--------

EM7: .ASCIZ /DIRECT CURSOR ADDRESSING FAILURE/<15><12>

4123	024060	041440	051125	047523
------	--------	--------	--------	--------

4124	024066	020122	042101	051104
------	--------	--------	--------	--------

4125	024074	051505	044523	043516
------	--------	--------	--------	--------

4126	024102	043040	044501	052514
------	--------	--------	--------	--------

4127	024110	042522	005015	000
------	--------	--------	--------	-----

4128	024115	120	051501	021523
------	--------	-----	--------	--------

DH7: .ASCIZ /PASS# TEST # ERROR PC /<15><12>

4129	024122	020040	042524	052123
------	--------	--------	--------	--------

4130	024130	021440	020040	051105
------	--------	--------	--------	--------

4131	024136	047522	020122	041520
------	--------	--------	--------	--------

4132	024144	020040	006440	000012
------	--------	--------	--------	--------

4133	024152	040520	051523	020043
------	--------	--------	--------	--------

DH10: .ASCIZ /PASS# TEST# BD.ROW BD.COL/<15><12>

4134	024160	052040	051505	021524
------	--------	--------	--------	--------

4135	024166	020040	042102	051056
------	--------	--------	--------	--------

4136	024174	053517	020040	042102
------	--------	--------	--------	--------

4137	024202	041456	046117	005015
------	--------	--------	--------	--------

4138	024210	000		
------	--------	-----	--	--

4139				
------	--	--	--	--

4140	024211	114	051501	020124
------	--------	-----	--------	--------

EM11: .ASCIZ /LAST TRANSMISSION TO VT61 CAUSED UNIT TO FAIL-HANG./<15><12>

4141	024216	051124	047101	046523
------	--------	--------	--------	--------

4142	024224	051511	044523	047117
------	--------	--------	--------	--------

4143	024232	052040	020117	052126
------	--------	--------	--------	--------

4144	024240	030466	041440	052501
------	--------	--------	--------	--------

4145	024246	042523	020104	047125
------	--------	--------	--------	--------

4146	024254	052111	052040	020117
------	--------	--------	--------	--------

4147	024262	040506	046111	044055
------	--------	--------	--------	--------

4148	024270	047101	027107	005015
------	--------	--------	--------	--------

4149	024276	000		
------	--------	-----	--	--

4150				
------	--	--	--	--

4151	024277	126	033124	020061
------	--------	-----	--------	--------

EM12: .ASCIZ /VT61 UNDER TEST FAILED- ERROR DATA FOLLOWS/<15><12>

4152	024304	047125	042504	020122
------	--------	--------	--------	--------

4153	024312	042524	052123	043040
------	--------	--------	--------	--------

4154	024320	044501	042514	026504
------	--------	--------	--------	--------

4155	024326	042440	051122	051117
------	--------	--------	--------	--------

4156	024334	042040	052101	020101
------	--------	--------	--------	--------

4157	024342	047506	046114	053517
------	--------	--------	--------	--------

4158	024350	006523	000012	
------	--------	--------	--------	--

# G07

4159  
4160 024354 052126 030466 043040  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE

EM10: .ASCIZ /VT61 FAILED SELF TEST FUNCTION/<15><12>  
20-SEP-76 10:22 PAGE 76

SEG 0087

4161	024362	044501	042514	020104
4162	024370	042523	043114	052040
4163	024376	051505	020124	052506
4164	024404	041516	044524	047117
4165	024412	005015	000	
4166				
4167				
4168	024415	120	051501	021523
4169	024422	020054	052040	051505
4170	024430	021524	020054	042107
4171	024436	041456	051513	046525
4172	024444	020054	042102	041456
4173	024452	051513	046525	005015
4174	024460	000		
4175				
4176	024461	124	051505	044524
4177	024466	043516	040440	047502
4178	024474	052122	042105	052055
4179	024502	047517	046440	047101
4180	024510	020131	040506	040524
4181	024516	020114	046530	052111
4182	024524	006523	000012	
4183				
4184	024530	052126	030466	051040
4185	024536	041505	044505	042526
4186	024544	020122	044103	041505
4187	024552	051513	046525	041440
4188	024560	046517	040520	042522
4189	024566	042440	051122	051117
4190	024574	005015	000	
4191				
4192	024577	126	033124	020061
4193	024604	051124	047101	046523
4194	024612	052111	042524	020122
4195	024620	044103	041505	051513

DH12: .ASCIZ /PASS#, TEST#, GD.CKSUM, BD.CKSUM/<15><12>

DABRT: .ASCIZ /TESTING ABORTED-TOO MANY FATAL XMIT/<15><12>

EM13: .ASCIZ /VT61 RECEIVER CHECKSUM COMPARE ERROR/<15><12>

EM14: .ASCIZ /VT61 TRANSMITTER CHECKSUM COMPARE ERROR/<15><12>

# H07

4196	024626	046525	041440	046517
4197	024634	040520	042522	042440
4198	024642	051122	051117	005015
4199	024650	000		
4200				
4201		024652		
4202	024652	047125	052111	052440
4203	024660	042116	051105	052040
4204	024666	051505	020124	005015
4205	024674	041522	051123	020040
4206	024702	053040	041505	027124
4207	024710	020040	044440	042504
4208	024716	052116	005015	000
4209	024723	040	041522	051123
4210	024730	020040	053040	041505
4211	024736	027124	005015	000
4212	024743	120	044522	052116
4213	024750	051105	044440	020123
4214	024756	052101	040524	044103
4215	024764	042105	005015	000
4216	024771	103	050117	042511

MAINDEC-11-DZVTH-A  
DZVTH.P11

TRAP TABLE

MACY11 27(732)

DVUNIT: .EVEN .ASCII /UNIT UNDER TEST /<15><12>  
.ASCIZ /RCSR VECT. IDENT/<15><12>  
DH11: .ASCIZ / RCSR VECT./<15><12>  
DPRTR: .ASCIZ /PRINTER IS ATTACHED/<15><12>  
DCOPYR: .ASCIZ /COPIER IS ATTACHED/<15><12>  
20-SEP-76 10:22 PAGE 77

SEQ 0088

4217	024776	020122	051511	040440
4218	025004	052124	041501	042510
4219	025012	006504	000012	
4220	025016	047530	043106	052040
4221	025024	020117	052126	030466
4222	025032	043040	044501	042514
4223	025040	020104	047524	044040
4224	025046	046101	020124	046102
4225	025054	041517	020113	046530
4226	025062	052111	005015	000
4227	025067	130	047117	052040
4228	025074	020117	052126	030466
4229	025102	043040	044501	042514
4230	025110	020104	047524	051040
4231	025116	051505	040524	052122
4232	025124	041040	047514	045503
4233	025132	054040	044515	006524
4234	025140	000012		
4235	025142	047516	054040	047117
4236	025150	051040	041505	044505
4237	025156	042526	020104	044527
4238	025164	044124	047111	031440
4239	025172	051440	041505	020056
4240	025200	043101	042524	020122
4241	025206	020101	042522	042523
4242	025214	006524	000012	
4243	025220	040514	052123	050040
4244	025226	051105	050111	042510
4245	025234	040522	020114	050117
4246	025242	051105	052101	047511
4247	025250	020116	041101	051117
4248	025256	042524	006504	000012
4249	025254	047503	046125	020104
4250	025272	047516	020124	046103
4251	025300	040505	020122	040514
4252	025306	052123	040440	047502
4253	025314	052122	043040	040514
4254	025322	027107	005015	000
4255	025327	123	046517	047440

EM15: .ASCIZ /XOFF TO VT61 FAILED TO HALT BLOCK XMIT/<15><12>  
EM16: .ASCIZ /XON TO VT61 FAILED TO RESTART BLOCK XMIT/<15><12>  
EM17: .ASCIZ /NO XON RECEIVED WITHIN 3 SEC. AFTER A RESET/<15><12>  
EM20: .ASCIZ /LAST PERIPHERAL OPERATION ABORTED/<15><12>  
EM21: .ASCIZ /COUL'D NOT CLEAR LAST ABORT FLAG./<15><12>  
EM22: .ASCIZ /SOM OR EOM NOT RECEIVED DURING MAINT. MODE TRANSMIT/<15><12>



4256	025334	020122	047505	020115
4257	025342	047516	020124	042522
4258	025350	042503	053111	042105
4259	025356	042040	051125	047111
4260	025364	020107	040515	047111
4261	025372	027124	047440	042117
4262	025400	020105	051124	047101
4263	025406	046523	052111	005015
4264	025414	000		
4265	025415	114	047111	020105
4266	025422	042506	042105	047440
4267	025430	020122	052503	051522
4268	025436	051117	051040	043511
4269	025444	052110	044440	051523
4270	025452	042525	020104	051106
4271	025460	046517	051040	053517
4272	025466	031040	020063	044504

MAINDEC-11-DZVTH-A TRAP TABLE  
DZVTH.P11

EM23: .ASCIZ /LINE FEED OR CURSOR RIGHT ISSUED FROM ROW 23 DID NOT CAUSE SCREEN TO SC

20-SEP-76 10:22 PAGE 78

SEQ 0089

4273	025474	020104	047516	020124
4274	025502	040503	051525	020105
4275	025510	041523	042522	047105
4276	025516	052040	020117	041523
4277	025524	047522	046114	005015
4278	025532	000		
4279	025533	120	051501	020123
4280	025540	020054	020040	042524
4281	025546	052123	026040	020040
4282	025554	053040	052123	052101
4283	025562	005015	000	
4284	025565	120	051501	026123
4285	025572	020040	052040	051505
4286	025600	026124	020040	042440
4287	025606	051122	050040	026103
4288	025614	020040	053040	052123
4289	025622	052101	005015	000
4290				
4291	025627	105	041523	000040
4292				
4293				
4294				
4295	025634	042513	041131	040517
4296	025642	042122	052040	051505
4297	025650	006524	012	
4298	025653	113	054505	052123
4299	025660	047522	042513	020123
4300	025666	041505	047510	006472
4301	025674	012		
4302	025675	101	042040	051511
4303	025702	046120	054501	041440
4304	025710	040510	027122	036440
4305	025716	040440	042040	051511
4306	025724	046120	054501	041440
4307	025732	040510	027122	005015
4308	025740	031463	036440	042440
4309	025746	041523	005015	
4310	025752	032461	036440	041440
4311	025760	051055	005015	
4312	025764	031061	036440	046040
4313	025772	043055	005015	
4314	025776	033460	036440	041040
4315	026004	046105	006514	012
4316	026011	061	020060	020075

DM13: .ASCIZ /PASS , TEST , VSTAT/<15><12>

DM14: .ASCIZ /PASS, TEST, ERR PC, VSTAT/<15><12>

DESC: .ASCIZ /ESC /

DKYBD: .ASCII /KEYBOARD TEST/<15><12>

.ASCII /KEYSTROKES ECHO:/<15><12>

.ASCII /A DISPLAY CHAR. = A DISPLAY CHAR./<15><12>

.ASCII /33 = ESC/<15><12>

.ASCII /15 = C-R/<15><12>

.ASCII /12 = L-F/<15><12>

.ASCII /07 = BELL/<15><12>

.ASCII /10 = TAB/<15><12>

# J07

.ASCIZ /NON-DISPLAY CHAR.= OCTAL EQUIV/<15><12>

4317	026016	040524	006502	012
4318	026023	116	047117	042055
4319	026030	051511	046120	054501
4320	026036	041440	040510	027122
4321	026044	020075	041517	040524
4322	026052	020114	050505	044525
4323	026060	006526	000012	
4324				
4325	026064	040524	020102	000
4326	026071	103	051055	000040
4327	026076	026514	020106	000
4328	026103	102	046105	020114

MAINCEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE

DTAB: .ASCIZ /TAB /  
DCR: .ASCIZ /C-R /  
DLF: .ASCIZ /L-F /  
DBELL: .ASCIZ /BELL /  
20-SEP-76 10:22 PAGE 79

SEQ 0090

4329	026110	000		
4330				
4331	026111	114	047517	020120
4332	026116	042524	052123	026440
4333	026124	046040	047517	020120
4334	026132	047503	046515	047101
4335	026140	051504	040440	042116
4336	026146	042040	052101	020101
4337	026154	044124	052522	005015
4338	026162	047510	052123	041040
4339	026170	041501	020113	047524
4340	026176	053040	033124	020061
4341	026204	047125	042504	020122
4342	026212	042524	052123	020056
4343	026220	005015		
4344	026222	047503	052116	047522
4345	026230	020114	020103	042440
4346	026236	044530	051524	052040
4347	026244	051505	027124	005015
4348	026252	000		
4349				
4350	026253	105	044530	020124
4351	026260	042524	052123	000056
4352				
4353	026266	051120	047111	042524
4354	026274	020122	042524	052123
4355	026302	026440	005015	
4356	026306	031461	020062	047503
4357	026314	052514	047115	020123
4358	026322	043117	040440	051440
4359	026330	044514	044504	043516
4360	026336	050040	052101	042524
4361	026344	047122	053440	046111
4362	026352	020114	042502	
4363	026356	047503	052116	047111
4364	026364	052517	046123	020131
4365	026372	052517	050124	052125
4366	026400	042524	020104	047524
4367	026406	050040	044522	052116
4368	026414	051105	005015	
4369	026420	040503	027122	051040
4370	026426	052105	020056	047524
4371	026434	051440	040524	052122
4372	026442	005015	000	
4373				
4374	026445	114	051501	020124
4375	026452	046530	052111	041440
4376	026460	052501	042523	020104
4377	026466	052126	030466	044040

DLOOP: .ASCII /LOOP TEST - LOOP COMMANDS AND DATA THRU/<15><12>

.ASCII /HOST BACK TO VT61 UNDER TEST. /<15><12>

DCNTZ: .ASCIZ /CONTROL C EXITS TEST./<15><12>

DEXT: .ASCIZ /EXIT TEST./

DPRNT: .ASCII /PRINTER TEST -/<15><12>

.ASCII /132 COLUMNS OF A SLIDING PATTERN WILL BE/

.ASCII /CONTINUOUSLY OUTPUTTED TO PRINTER/<15><12>

DCRST: .ASCIZ /CAR. RET. TO START/<15><12>

DEVERR: .ASCIZ /LAST XMIT CAUSED VT61 HANG/<15><12>

# K07

4378 026474 047101 006507 000012  
4379 026502 051120 042117 041525  
4380 026510 044524 047117 045440  
4381 026516 054505 047502 051101  
4382 026524 020104 042524 052123  
4383 026532 020056 030061 042440  
4384 026540 051122 051117 020123  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE

DKBD: .ASCII /PRODUCTION KEYBOARD TEST. 10 ERRORS CAUSES TEST EXIT./<15><12>

20-SEP-76 10:22 PAGE 80

SEQ 0091

4385 026546 040503 051525 051505  
4386 026554 052040 051505 020124  
4387 026562 054105 052111 006456  
4388 026570 012  
4389 026571 104 050105 042522  
4390 026576 051523 045440 054505  
4391 026604 020123 051106 046517  
4392 026612 046040 043105 020124  
4393 026620 047524 051040 043511  
4394 026626 052110 005015 000  
4395 026633 104 050105 042522  
4396 026640 051523 046040 043105  
4397 026646 020124 044123 043111  
4398 026654 020124 042513 020131  
4399 026662 047101 020104 044124  
4400 026670 020105 040442 020042  
4401 026676 042513 020131 005015  
4402 026704 000  
4403 026705 104 050105 042522  
4404 026712 051523 045440 054505  
4405 026720 020123 047111 052040  
4406 026726 050117 051040 053517  
4407 026734 005015 000  
4408  
4409 026737 104 050105 042522  
4410 026744 051523 051040 043511  
4411 026752 052110 051440 044510  
4412 026760 052106 045440 054505  
4413 026766 040440 042116 052040  
4414 026774 042510 021040 021101  
4415 027002 045440 054505 006440  
4416 027010 000012  
4417 027012 042504 051120 051505  
4418 027020 020123 042513 051531  
4419 027026 044440 020116 042523  
4420 027034 047503 042116 051040  
4421 027042 053517 005015 000  
4422  
4423 027047 104 050105 042522  
4424 027054 051523 045440 054505  
4425 027062 020123 047111 052040  
4426 027070 044510 042122 051040  
4427 027076 053517 041040 043505  
4428 027104 047111 044516 043516  
4429 027112 053440 052111 020110  
4430 027120 040447 006447 000012  
4431 027126 042504 051120 051505  
4432 027134 020123 047503 052116  
4433 027142 047522 020114 042513  
4434 027150 020131 040454 042116  
4435 027156 052040 042510 021040  
4436 027164 021101 045440 054505  
4437 027172 006440 000012  
4438 027176 042504 051120 051505

.ASCIZ /DEPRESS KEYS FROM LEFT TO RIGHT/<15><12>

DLSHFT: .ASCIZ /DEPRESS LEFT SHIFT KEY AND THE "A" KEY /<15><12>

DTOP: .ASCIZ /DEPRESS KEYS IN TOP ROW/<15><12>

DRSHFT: .ASCIZ /DEPRESS RIGHT SHIFT KEY AND THE "A" KEY /<15><12>

DSEC: .ASCIZ /DEPRESS KEYS IN SECOND ROW/<15><12>

DTHRD: .ASCIZ /DEPRESS KEYS IN THIRD ROW BEGINNING WITH 'A' /<15><12>

DCONT: .ASCIZ /DEPRESS CONTROL KEY ,AND THE "A" KEY /<15><12>

DBOT: .ASCIZ /DEPRESS KEYS IN FORTH ROW EXCEPT SHIFT KEYS/<15><12>

4439 027204 020123 042513 051531  
4440 027212 044440 020116 047506  
MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE

4441 027220 052122 020110 047522  
4442 027226 020127 054105 042503  
4443 027234 052120 051440 044510  
4444 027242 052106 045440 054505  
4445 027250 006523 000012  
4446 027254 042504 051120 051505  
4447 027262 020123 050123 041501  
4448 027270 020105 040502 006522  
4449 027276 000012

DSPCE: .ASCIZ /DEPRESS SPACE BAR/<15><12>

4451 027300 042504 051120 051505  
4452 027306 020123 042513 050131  
4453 027314 042101 045440 054505  
4454 027322 026123 042514 052106  
4455 027330 052040 020117 044522  
4456 027336 044107 026124 052040  
4457 027344 050117 052040 020117  
4458 027352 047502 052124 046517  
4459 027360 005015 000

DKPD: .ASCIZ /DEPRESS KEYPAD KEYS,LEFT TO RIGHT, TOP TO BOTTOM/<15><12>

4461 027363 113 054505 047502  
4462 027370 051101 020104 051105  
4463 027376 047522 026122 042513  
4464 027404 020131 047520 044523  
4465 027412 044524 047117 044440  
4466 027420 020116 047522 020127  
4467 027426 044123 052517 042114  
4468 027434 041040 020105

DKBERR: .ASCII /KEYBOARD ERROR,KEY POSITION IN ROW SHOULD BE /

4469 027440 020040 005015  
4470 027444 041517 040524 020114  
4471 027452 042107 020054 041517  
4472 027460 040524 020114 040502  
4473 027466 006504 000012  
4474 027472 020040 020040 020040  
4475 027500 000

KYSTRK: .ASCII / /<15><12>  
.ASCIZ /OCTAL GD, OCTAL BAD/<15><12>

4476  
4477 027501 036 076 020  
4478 027504 013 032 012  
4479 027507 054 044 014  
4480 027512 041 071 057  
4481 027515 063 064 003  
4482 027520 114 000

ROW1: .BYTE 36,76,20,13,32,12,54,44,14,41,71,57,63,64,3,114,0

4483  
4484 027522 026 056 030  
4485 027525 073 052 022  
4486 027530 055 034 024  
4487 027533 031 051 077  
4488 027536 062 061 002  
4489 027541 000

ROW2: .BYTE 26,56,30,73,52,22,55,34,24,31,51,77,62,61,2,0

4490  
4491 027542 046 040 053  
4492 027545 023 072 042  
4493 027550 045 074 011  
4494 027553 021 047 027  
4495 027556 066 000

ROW3: .BYTE 46,40,53,23,72,42,45,74,11,21,47,27,66,0

MAINDEC-11-DZVTH-A MACY11 27(732)  
DZVTH.P11 TRAP TABLE



BIT13 =	020000	92#	3590																	
BIT14 =	040000	91#	3517																	
BIT15 =	100000	90#																		
BIT2 =	000004	113#																		
BIT3 =	000010	112#																		
BIT4 =	000020	111#																		
BIT5 =	000040	110#																		
BIT6 =	000100	109#																		
BIT7 =	000200	108#																		
BIT8 =	000400	107#																		
BIT9 =	001000	106#																		
BLDADA	002312	694#	714																	
BLDADD	002310	692#	698																	
BLDINA	017102	1981	3151#	3158																
BLDINC	017076	1028	1069	1306	1492	1817	3150#	3157	3169											
BLCTST	002410	708	711	716#																
BLKM	002224	661#	775*	1061*	1299*	1333*	1642*	1814*	2675	2678*	2683*	2710	2852*	3021*						
BOROW	020042	3370	3373#																	
BPTVEC=	000014	122#																		
BUBCT	002206	654#	1812*	1824	1828*	2037*	2046	2326*	2340*	2342	2346*	2350*	2372*	2379*						
		2394*	2414	2756*	2762*	3359*	3360													
BUMPCT	020344	3421	3432#																	
BYSTOR	016024	1498*	2854	2902#	2947*															
CALCK	017516	1314	2514	2699	3289#															
MAINDEC-11-DZVTH-A																				
DZVTH.P11																				
CROSS REFERENCE TABLE -- USER SYMBOLS																				
CARRT	001750	444#	1724	1735	1934	1982	2552	3243	3258	3268										
CDEV	012242	673	705	709	2165#															
CDEVA	012312	2175#	2181	2187	2223	2226														
CDWN	001764	460#																		
CESAM	014526	2601	2605	2609	2611	2613#	2617	2622	2627	2633	2635									
CHKITT	015766	2883	2887	2889	2891#															
CHOM	001760	454#	1184	1308	1547															
CHRD	002160	643#	783*	866*	867	870*	917*	2117*	2257*	2259	2261	2264*	2268*	2328*						
		2334*	2336*	2337*	2338	2344	2348	2352	2356	2376*	2476*	2477*	2478	2959*						
		2960*	2962	2963	2964*	2965*	2966	2967	3351*	3355*	3357	3384								
CKABRT	017572	1836	1988	3319#																
CKDAT	005220	1204	1226#																	
CKEOM	003564	944	948#																	
CKEXT	006100	1321	1346	1355	1362	1369	1375#													
CKGP =	000106	592#	2606																	
CKKBD	017716	2045	3350#																	
CKLIN	004070	1023	1025#																	
CKMEM	005260	1227	1237#																	
CKMNT	003466	931	933#																	
CKOFF	020560	2893	3082	3493#																
CKSCRA	006736	1545	1547#																	
CKSCR8	007026	1563	1565#																	
CKSFT	015366	1081	1092	1245	1329	1368	2791#	2896	3084											
CKSRC	005746	1347#	1357																	
CKSTR	015734	2863	2873	2882#																
CKSUM =	002000	378#	1315	2696	2713															
CKSUMA	005442	1296	1298#																	
CKSUMB	005646	1323	1331#																	
CKVST	016000	2881	2894#																	
CLFT	001766	463#	1452																	
CLMAIN	011512	2043	2054#																	
CLRCK	002014	496#																		
CLREG	015530	904	1229	1324	1363	1467	1776	2817	2835#	2961	3075									
CLTCK	002016	499#																		
CMPOS	016314	1637	2979#																	
CNTF	020162	3361	3395#																	
CNTRA	027576	2072	4503#																	

DABRT = 000022  
 DABRT = 013244  
 DABRT = 000111  
 DABRT = 016356  
 DABRT = 001744  
 DABRT = 016750  
 DABRT = 001750  
 DABRT = 002153  
 DABRT = 001770  
 DABRT = 016216  
 DABRT = 000004  
 DABRT = 003674  
 DABRT = 005122  
 DABRT = 006334  
 DABRT = 007160  
 DABRT = 006314  
 DABRT = 007576  
 DABRT = 007640  
 MACY11 27(732) 20-SEP-76 10:22  
 DZVTH.P11 CROSS REFERENCE TABLE -- USER SYMBOLS

DABRT	024461	2443	4176																		
DABRT	002032	517																			
DATSC	017124	1758	3166																		
DBELL	026103	1928	4328																		
DBOT	027176	2064	4438																		
DCNTZ	026222	1899	4344																		
DCONT	027126	2066	4431																		
DCOPYR	024771	805	4216																		
DCOUNT	017074	860	951	1073	1114	1120	1135	2283	2760	3133	3140										
DCR	026071	1936	4326																		
DCRAD	002042	530	590	997	1064	1624															
DCRST	026420	4369																			
DCISP	= 177570	37	170																		
DELAY	017032	861	952	1074	1115	1121	1136	2284	2761	3124											
DEMP	003636	843	874																		
DESC	002022	505	2624																		
DESC	025627	1915	4291																		
DEVERR	026445	4374																			
DEXT	026253	2051	3456	4350																	
DF0	001442	207	214	229	341																
DF1	001446	258	343																		
DF2	001450	236	345																		
DF3	001474	243	351																		
DF4	001534	264	271	294	301	308	336	359													
DF5	001537	360																			
DF6	001543	222	250	278	285	315	322	329	362												
DH1	023266	205	4047																		
DH10	024152	248	4133																		
DH11	024723	256	4209																		
DH12	024415	276	283	4168																	
DH13	025533	292	299	4279																	
DH14	025565	313	320	4284																	
DH2	023361	212	4059																		
DH3	023461	220	327	4072																	
DH4	023574	227	4086																		
DH5	023721	234	4103																		
DH6	024005	241	4114																		
DH7	024115	262	269	306	334	4128															
DISPLA	001140	170	2105	3560	3582																
DISPRE	000174	138	2105																		
DYBC	026502	2035	4379																		
DYERR	027363	3376	4461																		





EMS 023752 240 4109#  
 EM7 024052 247 4122#  
 ENOPS 010474 1839 1840#  
 ENOSEL 010462 1623 1831 1837#  
 ENDTAB 001722 422# 2147  
 ENSRT 006712 1519 1526#  
 EOM = 000004 640# 940 1178 1313 1356 1619 2348 2411 2546 2682 2931 3193  
 EOS 001772 469# 1765  
 EPL = 001000 379# 2556 3417 3425  
 MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 88  
 DZVTH.P11 CROSS REFERENCE TABLE -- USER SYMBOLS SEQ 0098

EPNT 001774 473# 1973  
 ERPL 002036 522#  
 ERRVEC= 000004 118# 3522 3523\* 3525\* 3528\*  
 ERSE 010076 1753 1756#  
 ERSXT 010224 1772 1774#  
 ESAMB 014636 1914# 2521 2526\* 2584 2586 2590\* 2596\* 2613\* 2640# 2944\* 3424\*  
 ESC = 000400 380# 1912 2527 3417 3425  
 ESCN 002130 606# 885 1183 1307 1417 1451 1646 1764 1834 1974 2523 3427  
 ESCO 002056 542# 598 889 1038 1066 1112 1186 1309 1310 1648 1804 2734 2744  
 ESCOI = 002056 2746 3188  
 ESCP 002116 598# 981 999 1453 1462 1725  
 ESCPI = 002116 587# 599 891 1514  
 ESCYI = 002042 599#  
 ESCZ 002124 590#  
 ESCZI = 002124 600 602# 936 938 2777  
 ESSE0 002214 600# 1185  
 ESTEX 003436 657# 849# 851 907 908  
 ESTST 003100 843 916#  
 EXINT 013010 831 833#  
 EXIT3 004414 2281 2287#  
 EXMAIN 011124 1086 1088 1093#  
 EXMNT 003654 1901 1949# 1968 2013  
 EXTST 020414 958 963# 3440 3450#  
 FADD 012176 1908 1989  
 FADD1 012214 2146# 2157  
 FEXIT 011476 2151# 2154  
 FNDST 020544 2042 2048 2051#  
 FRCECT 020362 3475 3483#  
 FTEXT 003442 3431 3433 3436#  
 FTLCNT 002176 914 918#  
 FTLEXT 016070 650# 810# 912\* 913 1175 1207\* 1353\* 1616 2441 2449\* 2738\* 2879\* 3058\*  
 GCMD 003136 3481#  
 GOAD 012524 2915 2917#  
 GOCURP 006304 841# 882 886 889 892 895 902  
 GOSCR 007140 2210 2224#  
 GOSTRK 020154 1411 1430#  
 GTON 015256 1561 1578 1580 1585#  
 GNS = \*\*\*\*\* U 3358 3392#  
 GOTON 015324 1806 2736 2756#  
 GTCR 017364 137 3956 3957 3958 3959 3960  
 GTEXT 017476 2759 2765#  
 GTNUM 017406 1970 3241# 3244  
 HOFFLG 016746 3267 3269 3272#  
 IABT 002024 694 720 3275  
 IDENT 002122 2749# 3024# 3071# 3088#  
 INAG 006546 508#  
 INITA 012620 597# 779# 781\* 797 803 806 867 1830  
 INRPL 006510 1497# 1521  
 INRXT 006716 1486 1488#  
 INTAB 001650 1510 1518 1528#  
 412# 691 717 815 2145 2173

E08

INTRC 013746  
INTXM 014670  
INTXT 012756  
INXMT 003164  
DZVTH.P11

762 2507#  
764 2670#  
2252 2280#  
850# 898#  
MACY11 27(732)

20-SEP-76 10:22 PAGE 89  
-- USER SYMBOLS

SEQ 0099

CROSS REFERENCE TABLE

IOTVEC=	000020	123#	2085#	2086*	2169*	2170*	2230*	2231*						
ITSUMA	006070	1301	1371#											
JMPADD	013644	2462*	2463#	2467	2469#									
KBOLP	017726	3352#	3390	3394										
KIENA	015126	2673	2715#											
KYBO	010642	1894	1896#											
KYBXT	011110	1916	1929	1933	1937	1941	1944#							
KYPD	027604	2072	4509#											
KYSTRK	027440	3374*	3375#	4469#										
KYSTRT	010676	1903#	1925	1946										
LDADD	013040	760	2182	2253	2305#									
LDBUF	017564	1336	1394	1500	1549	1568	1706	1760	3312#	3327				
LDOUT	016122	2928	2931#											
LDPOS	020050	3368	3372	3374#										
LDMIT	016076	1253	1302	1495	1520	1827	1900	1902	1945	1969	2014	2044	2055	2925#
		3377	3381	3383	3387	3389								
LINXT	004202	1035	1037	1044#										
LKKB	007006	488#												
LNFED	001752	446#	699	728	1188	1719	1938	1983	2554	3266	3270	3429		
LNRW	016420	1622*	1638	1641*	1673	2979	2981*	2983	2985*	2986*	2994	2996*	2998	3000*
		3001*	3004#											
LOOP	020164	2015	3406#											
LOOPR	020250	3413	3417#											
LOPT	020216	3411#	3416	3428	3435	3441								
LOPTA	020222	3412#	3420											
LPSTR	020270	3418	3422#											
LPTST	011344	2008	2010#											
LSTST	010244	1799	1801#											
MAINT =	000004	402#												
MANS	002262	142	687#											
MANSA	002274	689#	707	712	759	2126								
MEMA	004674	1163#	1254											
MEMB	004730	1169#	1176											
MEMC	005102	1159#	1216	1218	1221	1225								
MEMD	005150	1202	1210#											
MEMXT	005422	1177	1193	1209	1248	1277#								
MEMI	004666	1159	1161#											
MODCA	002516	748#	1877	2459										
MODCK	002502	675	726	733	746#	758								
MODE	002174	649#	670*	687*	732*	753	813	1837	2124	2439				
MONIT	013474	2439#	3516											
MPATT =	005402	1163	1196	1247	1254	1267#								
MSTBL	011532	2041	2064#											
MSTRT	000204	142#												
MABRT =	000170	596#	3335											
NCKGP =	000107	593#	2610											
NOCALC	017562	3291	3293	3306#										
NOER	015504	2801	2816	2824#										
NOKIL	014706	2671	2675#	2692	2694									
NOROUT	020464	3451	3460#											
NORXT	016074	2916	2918#											
NOSHFT	017360	3230	3234#											
NOSOM	014730	2676	2680#											
NOVT	022727	2282	4001#											
NULN	007660	1702	1704#											
OCTBIN	017342	713	735	3228#										

OFFLP	004520	1119#	1125											
ONE	002202	652#												
ONLP	004576	1132#	1140											
ONOPA	004560	1123	1129#											
ONOFFLP	004470	1114#	1138											
ONOFFXT	004646	1133	1143#											
ONOFF61	004436	1106	1108#											
PABRT =	010000	376#	2632	3319										
PATGN	005350	1172	1211	1256#										
PC =%	000007	49#	1857*	1860*	1872*	3592*	3649*	3652*	3659*	3666*	3680*	3682*	3741*	
PDKBO	011416	2032	2035#											
PIRQ =	177772	35#												
PIRQVE=	000240	129#												
PMULT	017072	2112*	2118*	2122*	3127	3139#								
POPIT	003246	869#	915											
POF2SP=	022626	366#	2115	2121	2153	2192	2448							
PRABRT=	000172	595#	2630											
PRESC	002212	656#	836*	840	854	885*	888*	891*	905					
PRO =	000000	52#												
PR1 =	000040	53#												
PR2 =	000100	54#												
PR3 =	000140	55#												
PR4 =	000200	56#												
PR5 =	000240	57#												
PR6 =	000300	58#												
PR7 =	000340	59#												
PS =	177776	32#	33	3648										
PSW =	177776	33#	2465*											
PUSH2S=	024646	367#												
PWRVEC=	000024	124#	2091*	2092*	3895*	3896*	3904*	3919*	3920*					
QUST	017500	3261	3263	3273#										
RABT	002110	564#												
RBBUF	014630	772*	1036	1198	1200	1322	1326	1361	1365	1460	1469	1562	1579	1582*
		1666	1667	1683*	1716	1732	1757*	1767*	1773	1777	2549	2561	2637#	2886
		2890	2940	2964	3029	3415								
RBUFP	014634	1200*	1201	1656	1658	1666*	2549*	2559	2561*	2569*	2570*	2639#	2940*	3029
		3038	3411	3415*	3419	3422*	3423*	3429*	3430*	3434*				
		770	772	989	1006	1421*	3408	3453	4519#					
RCRLB	027630	770	772	989	1006	1421*	3408	3453	4519#					
RCUR	002050	535#	1029											
RDCUR	002052	538#	982	1000	1030	1726	2598							
RDENA =	000100	395#	812	834	918	1840	2207	2215	2458	2481				
REBUF	014632	770*	2559	2638#	3407*	3453*								
RECAD	013650	2201	2476#											
RECDN =	000200	393#	2330	2425	2450	3241								
RECEX	013236	2335	2351	2355#										
RECEXA	013242	2349	2357#											
RECITT	016020	1405*	1497*	1565*	2891*	2900#	2945*							
RECTH	013060	2324#	2780											
RECXT	014352	2573	2577	2581#										
REEX	013706	2482#	2486											
REOM =	020000	375#	949	957	1132	1203	1318	1358	1359	1660	2548	2861	2872	3040
		3062												
RERR =	100000	396#												
RESET	002126	604#	2733											
RESETV	015146	933	980	1025	1063	1108	1161	1298	1393	1449	1488	1547	1607	1704
		1756	1811	2731#	3183									
MAINDEC-11-DZVTH-A		MACY11	27(732)	20-SEP-76	10:22	PAGE	91							
DZVTH.P11		CROSS REFERENCE TABLE -- USER SYMBOLS												
RESPTR	016136	774	1093	1164	1180	1300	1375	1621	1640	1896	2010	2880	2897	2939#
		3059	3409	3455										
RESVEC=	000010	119#												

REVID = 000040  
 RFMER = 020000  
 RORUN = 040000  
 ROW1 027501  
 ROW2 027522  
 ROW3 027542  
 ROW4 027560  
 RPAR = 010000  
 RSMIN = 011526  
 RSON = 040000  
 RSTER = 014316  
 RSTT = 004000  
 RTRP = 012076  
 RXOFF = 100000  
 RC = %000000

383#	2566	2621	2626	G08										
398#														
397#														
2070	4477#													
2070	4484#													
2070	4491#													
2070	4497#													
399#														
2054	2058#													
374#	943	955	2543											
2528	2532	2537	2540	2544	2551	2557	2572#	2591	2597	2614				
377#	2575													
2113	2119	2123#												
373#	1075	2531	2535	2864	3031	3494								
40#	672*	673*	674*	690*	694*	705*	709*	710*	713*	720*	735*	760*		
774*	778*	856*	861*	864*	904*	933*	935*	937*	939*	941*	952*	980*		
985*	994*	1002*	1012*	1025*	1028*	1032*	1043*	1063*	1069*	1074*	1081*	1085*		
1092*	1093*	1108*	1113*	1115*	1117*	1121*	1130*	1136*	1161*	1164*	1168*	1172*		
1174*	1179*	1180*	1190*	1211*	1229*	1245*	1253*	1260*	1265*	1298*	1300*	1302*		
1306*	1314*	1320*	1324*	1329*	1336*	1345*	1363*	1368*	1375*	1393*	1394*	1407*		
1423*	1449*	1456*	1467*	1488*	1492*	1495*	1500*	1507*	1520*	1547*	1549*	1558*		
1568*	1575*	1584*	1607*	1610*	1615*	1620*	1621*	1633*	1637*	1640*	1654*	1669*		
1684*	1704*	1706*	1712*	1722*	1728*	1738*	1756*	1758*	1760*	1769*	1776*	1805*		
1806*	1811*	1817*	1822*	1827*	1835*	1836*	1869*	1872	1896*	1898*	1900*	1902*		
1908*	1922*	1924*	1942*	1945*	1967*	1969*	1970*	1975*	1981*	1988*	1989*	2010*		
2012*	2014*	2015*	2036*	2044*	2045*	2052*	2055*	2159*	2182*	2240*	2253*	2255*		
2274*	2277*	2284*	2285*	2286*	2298*	2310*	2359*	2384*	2416*	2430*	2446*	2514*		
2699*	2735*	2736*	2739	2747*	2750*	2761*	2764*	2765*	2778*	2780*	2782*	2817*		
2828*	2839*	2878*	2880*	2893*	2896*	2897*	2899*	2914*	2918*	2929*	2932*	2933*		
2948*	2961*	2970*	2982*	2987*	2997*	3002*	3057*	3059*	3064*	3075*	3082*	3084*		
3086*	3102*	3137*	3154*	3169*	3183*	3197*	3221*	3235*	3245*	3254*	3272*	3306*		
3312	3314*	3321	3327*	3333*	3337	3341*	3365*	3377*	3379*	3381*	3383*	3385*		
3387*	3389*	3395*	3409*	3440*	3442*	3455*	3457*	3459*	3460*	3483	3486*	3498*		
3516*	3635	3636*	3637	3640*	3697	3698*	3699*	3706*	3707*	3708*	3709*	3710*		
3711	3716	3722	3724*	3725	3739*	3836	3846*	3850	3866	3867	3880*	3897		
3918*	3939	3940*	3941	3942*	3943*	3944*	3945*							
659#	2325*	2358	2371*	2383	2393*	2415	2424*	2429	2792*	2827	2958*	2969		
3470*	3485													
2775*	2781	2783#												
617#														
614#														
616#														
619#														
607#	1036	1042	1732	1737										
608#	1716	1721												
41#	695	699	721	728	748*	833*	841	948*	953*	979*	981*	982*		
989*	990	996*	997*	998*	999*	1000*	1006*	1008	1026*	1029*	1030*	1060*		
1064*	1065*	1066*	1067*	1182*	1183*	1184*	1185*	1186*	1187*	1188*	1198*	1201		
1215	1223	1228*	1230	1231	1232	1234	1304*	1307*	1308*	1309*	1310*	1311*		
1335*	1392*	1411*	1415	1422	1424	1448*	1450*	1451*	1452*	1453*	1454*	1489*		
1490*	1493*	1499*	1548*	1567*	1623*	1624*	1625	1626*	1627*	1643*	1644	1646*		
1647*	1648*	1649*	1656*	1658	1678*	1679	1683	1685	1705*	1723*	1724*	1725*		
1726*	1759*	1815*	1907*	1917	1919	1921	1926	1930	1934	1938	1976*	1979*		

ROSVE 002220  
 ROSV1 015364  
 ROOC08 002150  
 ROOC11 002144  
 ROOC20 002146  
 ROOC80 002154  
 ROIC00 002132  
 ROIC20 002134  
 R1 =%000001

1982*	1983*	2134*	2137*	2138*	2140	2144*	2146	2147	2155	2156	2175*	2183*
2185*	2200*	2201*	2202*	2203*	2204*	2206*	2211*	2232*	2234*	2235*	2237	2250*
2306*	2308	2452*	2453*	2454	2456*	2460*	2461*	2462	2508	2509*	2510*	2513
2519	2523	2529	2533	2541	2546	2552	2554	2564*	2568*	2569	2572	2578
2582*	2588	2592	2594	2598	2602	2606	2610	2616	2619	2624	2628	2630
2634	2793	2796*	2800	2803	2813*	2815	2820	2821	2824*	2854*	2882	2888
2890*	3046	3050	3053	3067*	3069	3080*	3097*	3099*	3100	3111*	3125	3128*
3129*	3136*	3151*	3167*	3186*	3187*	3188*	3189*	3191*	3193*	3211*	3212*	3213*

R12000 002140  
R2 =%000002

R22000 002136  
R23000 002142  
R23078 002156  
R23079 002044  
R3 =%000003

R4 =%000004

R5 =%000005

R6 =%000006  
R7 =%000007  
SEQ4 003344  
SETA 011604  
SETREV 005416  
SHFTA 027600  
SLSH = 000057  
SOM = 000002  
SP =%000006

MAINDEC-11-DZVTH-A  
DZVTH.P11

MACY11 27(732) 20-SEP-76 10:22 PAGE 93  
CROSS REFERENCE TABLE -- USER SYMBOLS

3214	3228*	3234	3255*	3256	408	3260	3262	3264	3266	3268	3270*	3312*
3326*	3362*	3363*	3364*	3378*	3384*	3721	3722*	3727	3731	3733	3738*	3837
3850*	3851	3855	3879*	3898	3917*							
610#												
42#	692*	697	701	703	719*	723	730	749*	751	769	840*	899*
901*	1166*	1169*	1195*	1210*	1217	1224	1237	1240	1348*	1349	1412*	1415
1421	1424	1608*	1611*	1625*	1635	1638*	1644*	1671	1673*	1676	1685	1897*
1966*	2011*	2035*	2051*	2135*	2137	2139*	2146*	2147	2149	2150	2151*	2173*
2176	2180*	2233*	2234	2236*	2248*	2251	2270*	2272	2287*	2290	2296	2305
2794	2797*	2799*	2800	2814*	2815	2825*	2855*	2882	2896*	3038	3046	3051
3053	3098*	3099	3103*	3104	3106*	3108	3110*	3111	3112*	3113*	3126	3127*
3131*	3135*	3191	3229	3231*	3232*	3233*	3234*	3456*	3838	3849*	3853*	3856
3863*	3864*	3865	3870*	3878*	3899	3916*						
609#												
612#	1065	1583										
620#	1622	1626										
532#	998	1008	1011	1679								
43#	691*	697*	703*	704*	717*	723*	730*	731*	750*	761	762*	763*
764*	765*	841*	844	849	874	877	880	897	899	900*	901	1027*
1068*	1072*	1077*	1197*	1220	1222*	1223*	1224*	1226	1234	1252*	1301*	1305*
1413*	1418	1425	1491*	1494*	1519*	1816*	1826*	1899*	1901*	1915*	1928*	1932*
1936*	1940*	1943*	1968*	1980*	2013*	2041*	2054*	2136*	2138	2172*	2190*	2200
2213*	2249*	2254*	2271*	2275	2927	3054*	3152*	3168*	3301*	3302*	3304	3376*
3380*	3382*	3386*	3388*	3778	3787*	3793*	3794*	3797*	3802*	3803*	3804	3813*
3839	3847*	3848*	3862*	3865*	3874*	3875*	3877*	3900	3915*			
44#	718*	724*	725	837*	847	852	858	884*	894*	1118*	1124*	1131*
1139*	1163*	1173	1196*	1214*	1215	1222	1256*	1257	1259*	1261*	1262	1264*
1312*	1322	1325	1332*	1361	1364	2040*	2205*	2209	2305*	2306	2307*	2374
2375*	2376	2377*	2382*	2394	2397*	2399	2400	2404	2405*	2406	2414*	2478
2484*	2485	2487*	2489	3019	3020*	3045*	3052	3085*	3296	3300*	3301	3303
3305*	3357	3362	3378	3392*	3393	3411*	3419	3779	3781*	3782*	3783*	3784
3785*	3799	3801*	3809*	3812*	3901	3914*						
45#	1119*	1122	1134*	1137	1162*	1153	1196	1212	1246*	1247	1250	1264
1313*	1496*	1511	1513	1516	1517	1977*	1992	2038*	2040	2041	2049	2056
2145*	2150*	2158*	2174*	2224*	2227*	2396*	2399*	2406	2513*	2698*	2851	2870*
2874	2898*	3025*	3048	3050*	3051*	3052*	3066*	3067	3068*	3076	3077	3078
3150*	3151	3155*	3156	3208	3209*	3214*	3215*	3216*	3217*	3220*	3289*	3290
3292	3302	3303*	3304*	3305	3363	3780	3786*	3788*	3790*	3791*	3792*	3793
3811*	3840	3842*	3844*	3851*	3855*	3870	3876*	3902	3913*			
46#	48	2080*	2081*	2082	2189*	2190	2191	2397	2427*	2428*	2447	
47#	49											
848	897#											
671	688	2079#	2445									
1252	1275#	1826										
2072	4505#											
591#	2338	2602										
639#	934	1167	1609	2344	2395	2541	2677	2925	3187			
48#	766*	767*	779	783	787*	792*	797*	839*	851*	854*	866	870

SEQ 0103

		3839*	3840*	3841*	3842	3845*	<del>3848</del> 108	3860*	3862	3872	3874	3876	3877	3878
		3879	3880	3882*	3883*	3897*	3898*	3899*	3900*	3901*	3902*	3903	3909*	3913
		3914	3915	3916	3917	3918	3939*	3940						
SPCB	027602	2070	4507#											
SPTN	003336	846	894#											
STACK =	001100	29#	2084											
START	000200	141#												
STKLMT=	177774	34#												
STRBYT	015756	2885	2888#											
STRO	014664	2634*	2653#	3335										
STRP	014666	2616*	2654#											
STRTAB	001714	419#	2146											
STTEP	014662	2576	2578*	2579*	2652#	2814	2826*	2942*						
STTER	014640	2642#	2813	2826	2942									
STUPM	022542	2109	3978#											
SVER1	002162	644#	1943	2793*	2824	3214*	3215*	3216*	3366*	3367	3369	3371*	3373*	3374
		3375	3380	3386										
SVER2	002164	645#	2794*	2825	3219*	3366								
SWR	001136	169#	2102	2104*	3517	3531	3533	3539	3546	3583	3590	3595	3601	
SWREG	000176	139#	2104											
SW0	= 000001	87#												
SW00	= 000001	77#	87											
SW01	= 000002	76#	86											
SW02	= 000004	75#	85											
SW03	= 000010	74#	84											
SW04	= 000020	73#	83											
SW05	= 000040	72#	82											
SW06	= 000100	71#	81											
SW07	= 000200	70#	80											
SW08	= 000400	69#	79											
SW09	= 001000	68#	78											
SW1	= 000002	86#												
SW10	= 002000	67#												
SW11	= 004000	66#												
SW12	= 010000	65#												
SW13	= 020000	64#												
SW14	= 040000	63#												
SW15	= 100000	62#												
SW2	= 000004	85#												
SW3	= 000010	84#												
SW4	= 000020	83#												
SW5	= 000040	82#												
SW6	= 000100	81#												
MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 94														
DZVTH.P11 CROSS REFERENCE TABLE -- USER SYMBOLS														
SW7	= 000200	80#												
SW8	= 000400	79#												
SW9	= 001000	78#												
TAB	001754	448#	1930											
TBBUF	015136	773*	979	996	1026	1060	1182	1304	1335	1392	1448	1489	1494	1499
		1548	1567	1623	1643	1676	1678	1705	1723	1759	1815	1976	1979	2691
		2703	2714	2719#	2941	3167	3186	3326	3408*	3454*				
TBITVE=	000014	120#												
TBLCK	012226	2148	2155#											
TBUFP	015142	934*	936*	938*	940*	1116*	1129*	1167*	1173*	1178*	1609*	1614*	1619*	1921*
		1923*	2685	2689	2691*	2693*	2698	2700	2701	2703*	2705*	2714*	2721#	2925*
		2927*	2931*	2941*										
TCOMB =	000104	403#	2208	2214	2480									
TCRLB	030330	771	773	1197	1220	1226	1228	1406	1412	1498	1511	1566	1582	1671
		3025	3048	3066	3068	3097	3100	3407	3454	4521#				
TCPLF =	000200	3645	3625#											
TCUCH	002066	549#	1454	1465										
TDATA	006706	1511	1524#											



# JOB

TDEV	012356	2169	2188#											
TEBUF	015140	771*	2689	2701	2720#									
TENA =	000100	401#	1071	1317	1342	1630	1651	1819	1985	2184	2188	2483	2490	2538
TESC	013322	2715	2856	2910	2939	3023	3171	3194	3439					
TFUNCT	006700	956	1113	1805	1835	1975	2392#	2735	2747	2778				
THT =	000011	1513	1523#											
TIMEXT	020546	3643	3684#											
TKVEC =	000060	3482	3484#											
TOADD	002204	127#												
TOFF	013672	653#	2373*	2375										
TOTCH =	003600	2480#	2488											
TOTCI =	003601	405#	1166	1217	1237	1239	1608	3170						
TPENT	012222	406#												
TPREG	002210	2143	2153#											
TPRNT	011146	655#												
TPVEC =	000064	1964	1966#											
TRAPVE =	000034	128#												
TROY =	000200	126#	2089*	2090*										
TRMID =	000002	400#	2402	2409	2412									
TRPA	012042	386#	2604											
TRPB	012066	2110	2115#											
TRPE	012202	2116	2121#											
TRPVEC	012122	2147#	2152											
TRTVEC =	000014	672	690	2134#										
TSMAD	013732	121#												
TSTADD	022472	2203	2489#											
TSTER	002120	2462	3962#											
TSTNM	002226	589#	1803											
TSTPTR	002172	338	349	353	355	357	662#	835*	2731*					
TST1	003062	648#	756	815*	2456	2464*								
TST10	005424	829#	3962											
TST11	006104	1294#	3966											
TST12	006316	1388#	3966											
TST13	006472	1444#	3968											
TST14	006720	1484#	3968											
TST15	007142	1543#	3968											
TST16	007642	1602#	3970											
		1700#	3970											

# K08

TST17	010060	1751#	3970															
TST2	003450	929#	3962															
TST20	010226	1797#	3972															
TST21	010624	1892#	3972															
TST22	011130	1962#	3972															
TST23	011326	2006#	3974															
TST24	011400	2030#	3974															
TST3	003656	975#	3962															
TST4	004052	1021#	3964															
TST5	004204	1057#	3964															
TST6	004420	1104#	3964															
TST7	004650	1157#	3966															
TXEX	015134	2711	2716#															
TXRCK	002074	554#	1311															
TXSUM =	000100	382#	1334	2511	2550													
TXTCK	002102	559#																
TYPDS =	104404	1865	3732	3960#														
TYPE =	104400	689	716	785	786	802	805	808	1863	1866	2109	2216	2222	2282				
		2288	2295	2443	3265	3274	3585	3593	3696	3713	3715	3718	3720	3735				
		3740	3805	3881	3921	3956#												
TYPNUM	017514	3264*	3265	3273*	3274	3276#												
TYPFC =	104401	3704	3728	3957#														
TYPON =	104403	3959#																
TYPDS =	104402	789	794	799	2219	2292	3958#											
TYP6	002170	647#																
TERR	003360	868	904#															
UN_KKB	002010	490#																
UPD4	013710	2479	2483#															
VBIT	020554	3472*	3474	3487#														
VDLAY	020556	3471*	3478*	3488#														
VECPT	001710	416#	747*	750	792	809*												
VECT	001740	432#	761*	1809														
VRBLF	001732	429#	862	2225*	2336	2476	2509	3243										
VRCSR	001730	428#	748	787	812*	834*	918*	1808	1840*	2175	2207*	2215*	2217	2224				
		2250	2330	2458*	2481*	2818	2819	3241										
VSTAT	002222	660#	777*	943	949	955	957	960	1062*	1075	1109*	1126	1132	1141				
		1165*	1194*	1203	1303*	1315*	1331*	1334*	1358*	1359	1606*	1629*	1645*	1660				
		1813*	1903*	1912	1944*	1978*	1986	2511	2527*	2531*	2535*	2536	2539*	2543*				
		2548*	2550*	2556*	2562	2566	2575*	2600*	2604*	2608*	2612*	2621*	2626*	2632*				
		2670	2672*	2696	2712*	2713*	2748*	2797	2804	2853*	2857*	2859	2861	2864				
		2872	2884	2908*	2917*	3022*	3027	3031	3040	3166*	3173	3184*	3195	3319				
		3323	3339	3410*	3412	3414*	3417	3425*	3474	3494								
VVECT	001550	410#	747	2172	2249													
VXBUF	001736	431#	2308	2395*	2404*	2411*	2489*	2677*	2682*	2700*								
VXCSR	001734	430#	1071*	1317*	1342*	1630*	1651*	1819*	1985*	2184*	2188*	2208*	2214*	2402				
		2409	2412	2480*	2483*	2490*	2538*	2715*	2856*	2910*	2939*	3023*	3171*	3194*				
		3439*																
WOSTOR	016022	1406*	1566*	2855	2901*	2946*												
WTBGND	020470	1085	1320	1345	1633	1654	1822	2914	3064	3469*								
XMAO2	015716	2868	2878#															
XMCNT	015144	983*	1001*	1031*	1070*	1189*	1316*	1341*	1404*	1455*	1506*	1557*	1574*	1628*				
		1650*	1711*	1727*	1768*	1818*	1984*	2680	2707*	2723#	2909*	2943*	3170*	3185*				
		3190*	3332*	3426*	3432	3436*	3437	3437										
XMDNE =	000001	387#	1083	1343	1631	1652	1820	1986	2712	2859	2912	3027	3173	3195				
		3412	3414															
XMITT	015606	2857#	2892															
MAINDEC-11-DZVTH-A		MACY11 27(732) 20-SEP-76 10:22 PAGE 96																
DZVTH.P11		CROSS REFERENCE TABLE -- USER SYMBOLS																
XMIT1	016026	935	937	939	941	1117	1130	1168	1174	1179	1610	1615	1620	1922				
XMYIL =	004200	1924	2908#	2929	2932													
		381#	2536	2539	2672													







.XMTAL = 000126  
MAINDEC-11-DZVTH-A  
DZVTH.P11

543# 1337 :761  
536# 1550 1569 1707  
MACY11 27(732) 20-SEP-76 10:22 PAGE 101  
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0110

COMEN	130#														
ENDCOM	130#														
ERRJR	30#	911	961	567	992	1004	1010	1034	1041	1079	1090	1127	1142	1192	1208
	1223	1241	1327	1354	1366	1409	1420	1458	1466	1470	1509	1515	1560	1564	1577
	1581	1664	1691	1714	1720	1730	1736	1771	1775	1778	1810	2740	2805	2822	2968
	3073	3079	3324	3340	3480										
ESCAPE	130#														
FILE	130#														
NEWST	130#	127	928	974	1020	1058	1107	1156	1293	1387	1443	1483	1542	1601	1699
	1750	1796	1891	1961	2005	2029									
FOP	130#	719	782	865	869	916	2256	2263	2267	2324	2326	2370	2372	2373	2381
	2392	2423	2581	2774	2791	2796	2898	2957	2959	3085	3135	3220	3255	3469	3471
	3472	3876	3913												
PUSH	130#	838	850	854	993	1011	1042	1080	1082	1084	1091	1110	1111	1112	1243
	1318	1319	1328	1343	1344	1367	1422	1583	1631	1632	1652	1653	1682	1721	1737
	1801	1803	1804	1820	1821	1832	1833	1834	1971	1973	1974	2272	2273	2275	2276
	2327	2352	2355	2357	2374	2383	2415	2429	2507	2732	2733	2734	2741	2743	2744
	2745	2746	2776	2779	2781	2827	2850	2894	2911	2913	2969	3018	3061	3063	3083
	3124	3207	3484	3835	3897										
SCOPE	31#	829	929	975	1021	1057	1104	1157	1294	1388	1444	1484	1543	1602	1700
	1751	1797	1852	1892	1962	2006	2030								
SETTRA	3947#	3957	3958	3959	3960										
SETUP	130#	2079													
SKIP	130#														
SLASH	130#														
SPACE	130#														
STARS	130#	143	185	369	371	389	391	407	409	425	427	437	439	449	451
	477	479	510	512	525	527	567	569	571	573	581	583	635	638	665
	668	678	685	738	744	817	818	825	828	920	926	928	964	971	974
	1014	1018	1020	1047	1054	1056	1095	1101	1103	1145	1154	1156	1279	1291	1293
	1377	1385	1387	1436	1441	1443	1473	1481	1483	1530	1540	1542	1588	1599	1601
	1689	1697	1699	1742	1748	1750	1783	1794	1796	1841	1882	1889	1891	1952	1959
	1961	1996	2003	2005	2018	2027	2029	2075	2077	2128	2132	2160	2163	2193	2196
	2242	2246	2299	2303	2312	2322	2362	2368	2386	2390	2418	2421	2432	2437	2470
	2474	2493	2505	2656	2669	2724	2729	2752	2754	2767	2772	2785	2789	2808	2811
	2830	2833	2840	2848	2904	2906	2920	2923	2935	2937	2951	2955	2972	2974	2977
	2989	2992	3005	3016	3090	3095	3116	3122	3142	3148	3161	3164	3176	3181	3199
	3206	3223	3226	3237	3239	3248	3252	3280	3287	3307	3310	3315	3317	3343	3347
	3397	3404	3444	3448	3463	3467	3489	3491	3500	3564	3609	3687	3744	3822	3890
	3930														
TRMTRP	3947#														
TYPBIN	130#														
TYPDEC	130#	1864	3730												
TYPNUM	130#														
TYPOCS	130#	787	792	797	2217	2289									
TYPOCT	130#	3702	3727												
TYPTXT	130#														
SSCHRE	143#														
SSCHTH	143#														
SSESCA	130#														
SSNEWT	130#	828	928	974	1020	1056	1103	1156	1293	1387	1443	1483	1542	1601	1699
	1750	1796	1891	1961	2005	2029									
SSSET	3947#	3957	3958	3959	3960										
SSSKIP	130#														
.EQUAT	3#	25													
.HEADE	3#														

SEQ 0111

.SETUP 3# 665  
 .SARHI 3# 13  
 .SARLO 3# 25  
 .SCATC 3# 130  
 .SCNTR 3# 143  
 .SEOP 3# 1841  
 .SERRO 3# 3564  
 .SERRT 3# 3687  
 .SPOHE 3# 3890  
 .SSAVE 3#  
 .SSCOP 3# 3500  
 .STRAP 3# 3930  
 .STYPD 3# 3822  
 .STYPE 3# 3609  
 .STYPO 3# 3744

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 104  
 DZVTH.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

SEQ 0112

ADD	809	1246	2139	2151	2180	2236	2254	2285	2307	2463	2579	2764	2879	3057	3234
	3459	3641	3710	3773	3783	3855									
ASL	2461	3231	3232	3233	3707	3708	3709	3943							
ASLB	2484	3860													
ASRB	3211	3212	3213												
BCC	3861														
BEQ	702	707	726	804	807	814	842	845	853	875	878	881	898	909	956
	991	1009	1037	1088	1123	1170	1216	1218	1227	1238	1248	1323	1360	1362	1416
	1461	1512	1518	1563	1580	1612	1636	1677	1680	1717	1733	1774	1831	1838	1870
	1913	1987	2042	2125	2157	2177	2210	2252	2341	2349	2351	2398	2401	2403	2407
	2410	2413	2426	2451	2455	2479	2486	2512	2520	2537	2553	2563	2567	2577	2593
	2629	2676	2697	2708	2759	2801	2816	2862	2865	2883	2885	2889	2928	2980	2984
	2995	2999	3032	3043	3047	3055	3070	3157	3174	3196	3230	3242	3257	3259	3267
	3291	3293	3320	3336	3353	3358	3368	3413	3420	3428	3495	3532	3534	3536	3540
	3549	3581	3584	3602	3605	3644	3712	3717	3723	3734	3800				
BGE	3552	3679													
BGT	1859	2457	3807	3869											
BHI	1920	2262	2524	3263	3438	3538									
BHIS	914	1221	3049	3101	3361										
BIC	834	1109	1165	1194	1256	1303	1331	1358	1606	1629	1645	1813	1840	1856	1903
	1944	1978	2188	2214	2215	2337	2428	2453	2458	2477	2480	2481	2490	2510	2535
	2539	2550	2612	2626	2713	2715	2799	2853	2857	2908	2939	3022	3166	3184	3228
	3289	3302	3303	3410	3414	3425	3797								
BICB	3215														
BIS	812	918	1071	1214	1315	1317	1334	1342	1630	1651	1819	1985	2184	2207	2208
	2483	2527	2531	2538	2543	2548	2556	2568	2575	2540	2596	2600	2604	2608	2621
	2632	2672	2712	2856	2910	3023	3171	3194	3304	3430	3802	3803	3863	3864	
BISB	3216	3699													
BIT	803	806	943	949	955	957	1075	1132	1203	1359	1660	1830	1912	1986	2156
	2330	2402	2409	2412	2425	2450	2485	2511	2521	2536	2562	2566	2584	2586	2696
	2859	2861	2864	2872	2884	3027	3031	3010	3173	3195	3241	3319	3412	3417	3474
	3494	3517	3531	3539	3546	3583	3590	3611							
BITB	3053	3667													
BLO	845	1176	1235	1263	1617	1659	1686	1918	2047	2148	2233	2260	2343	2442	3030
	3039	3261	3370	3433											
BLOS	1672														
BLT	2141	2309	3658	3808	3852	3868									
BMI	843	848	1258	2043	2178	2258	3859								
BME	696	700	722	729	752	754	784	868	871	944	946	950	954	958	1076
	1078	1125	1133	1138	1140	1202	1204	1206	1213	1251	1350	1352	1357	1426	1661
	1663	1668	1825	1905	1927	1931	1935	1939	1993	2083	2180	2212	2265	2269	2281
	2297	2331	2333	2339	2345	2378	2380	2440	2517	2522	2523	2530	2534	2542	2547
	2555	2560	2585	2587	2589	2595	2599	2603	2607	2611	2620	2625	2631	2681	2686
	2688	2690	2702	2711	2763	2860	2867	2873	2875	2877	2892	3028	3034	3041	3072
	3081	3105	3109	3130	3132	3134	3153	3192	3244	3269	3313	3394	3418	3451	3475
	3477	3479	3497	3518	3547	3591	3599	3638	3646	3654	3668	3675	3700	3726	3798



BR	3857	3912	859	1249	2573	2671	3218	3297	3596	3632	3672	3796	3843	3873	895
BR	757	750	709	712	714	727	733	736	752	872	882	886	889	892	895
	676	699	915	988	1003	1005	1033	1035	1086	1191	1193	1209	1225	1321	1346
	922	915	5.6	988	1003	1005	1033	1035	1086	1191	1193	1209	1225	1321	1346
	1355	1369	1408	1410	1427	1457	1459	1508	1510	1521	1559	1561	1576	1578	1624
	1639	1655	1665	1670	1674	1713	1715	1729	1731	1770	1772	1807	1823	1829	1909
	1916	1925	1929	1933	1937	1941	1946	1990	1994	2048	2050	2057	2103	2113	2119
	2152	2154	2181	2187	2223	2226	2266	2278	2335	2347	2353	2408	2488	2528	2532
	2540	2544	2551	2557	2591	2597	2601	2605	2609	2614	2617	2622	2627	2633	2635
	2673	2684	2692	2694	2704	2737	2823	2863	2868	2881	2897	2915	2916	2926	2930
MAINDEC-11-DZVTH-A			MACY11	27(732)	20-SEP-76	10:22	PAGE	105							
DZVTH.F11	CROSS	REFERENCE	TABLE	--	PERMANENT	SYMBOLS									SEQ 0113
	3035	3044	3056	3060	3065	3107	3114	3158	3210	3271	3275	3372	3390	3416	3421
	3431	3435	3441	3482	3520	3526	3529	3542	3545	3634	3651	3661	3670	3677	3705
	3729	3736	3774	3789	3810	3854	3871	3906	3925						
CLC	3295														
CLR	670	692	718	719	766	775	776	777	781	810	836	837	942	1062	1162
	1195	1199	1312	1332	1347	1419	1464	1496	1657	1718	1734	1757	1766	1767	1812
	1853	1854	1914	2037	2038	2081	2094	2095	2144	2158	2165	2197	2206	2225	2227
	2229	2235	2328	2329	2449	2465	2466	2487	2613	2748	2749	2835	2836	2837	2838
	2858	2871	2917	2943	2944	2946	2947	3020	3024	3026	3037	3251	3424	3458	3473
	3493	3544	3558	3698	3787	3846	3849	3910							
CLRB	731	1493	1911	2678	2683	2757	3350	3356	3543	3676	3875				
COMP	725	913	990	1008	1036	1122	1137	1175	1201	1217	1220	1226	1234	1237	1349
	1415	1424	1425	1511	1517	1616	1635	1658	1671	1676	1679	1685	1716	1732	2082
	2106	2140	2147	2237	2308	2441	2516	2559	2576	2689	2701	2800	2815	2874	2882
	3029	3038	3048	3100	3360	3419	3432	3437	3527	3551	3598	3867			
COMPB	695	699	721	728	844	867	874	877	880	1087	1212	1215	1250	1262	1322
	1356	1361	1460	1562	1579	1667	1773	1917	1919	1926	1930	1934	1938	1992	2046
	2259	2261	2338	2342	2344	2348	2406	2454	2478	2523	2529	2533	2541	2546	2552
	2554	2588	2592	2594	2598	2602	2606	2610	2619	2624	2628	2630	2758	2979	2983
	2994	2998	3046	3104	3108	3156	3243	3256	3258	3260	3262	3266	3268	3290	3292
DEC	3335	3357	3367	3369	3427	3450	3533	3537	3643	3645	3653	3674	3678	3678	3678
	945	953	1077	1124	1139	1169	1205	1351	1611	1662	1857	2185	2211	2332	2379
	2460	2707	2762	2866	2876	2891	3033	3042	3054	3129	3131	3133	3152	3217	3434
	3476	3478	3496	3706											
DEC8	2340	2350	2981	2985	3657	3660	3795	3806							
EMT	30														
HALT	137	3597	3600	3633	3905	3924									
INC	724	912	1207	1210	1353	1490	1828	1855	2464	2515	2570	2693	2705	2738	2879
	3045	3058	3074	3190	3359	3364	3392	3406	3423	3426	3430	3436	3481	3550	3586
	3801	3809	3853	3911											
INCB	1261	2346	2996	3000	3103	3112	3155	3555	3580	3680					
IOT	31														
JMP	141	142	671	675	688	711	755	759	1177	1254	1618	1839	1877	1910	1991
	2016	2053	2126	2127	2445	2459	2469								
JSR	572	673	674	690	694	705	709	710	713	720	735	760	774	778	856
	861	864	904	933	935	937	939	941	952	980	985	994	1002	1012	1025
	1028	1032	1043	1063	1069	1074	1081	1085	1092	1093	1108	1113	1115	1117	1121
	1130	1136	1161	1164	1168	1172	1174	1179	1180	1190	1211	1229	1245	1253	1298
	1300	1302	1306	1314	1320	1324	1329	1336	1345	1363	1368	1375	1393	1394	1407
	1423	1449	1456	1467	1488	1492	1495	1500	1507	1520	1547	1549	1558	1568	1575
	1584	1607	1610	1615	1620	1621	1633	1637	1640	1654	1669	1684	1704	1706	1712
	1722	1728	1738	1756	1758	1760	1769	1776	1805	1806	1811	1817	1822	1827	1835
	1836	1872	1896	1898	1900	1902	1908	1922	1924	1942	1945	1967	1969	1970	1975
	1981	1988	1989	2010	2012	2014	2015	2036	2044	2045	2052	2055	2182	2253	2255
	2274	2277	2284	2514	2699	2735	2736	2747	2761	2778	2780	2817	2880	2893	2896
	2897	2914	2929	2932	2961	3059	3064	3075	3082	3084	3169	3183	3254	3327	3333
	3365	3377	3379	3381	3383	3385	3387	3389	3409	3440	3455	3457	3516	3592	3649
	3652	3659	3666												
MOV	687	691	697	703	704	717	746	747	748	749	750	761	762	763	764
	765	767	769	770	771	772	773	779	783	787	792	797	811	815	830
	831	831	839	840	841	849	851	854	860	866	870	884	885	888	891





1103	1105	1106	1107	1145	1154	1156	1159	1160	1279	1291	1293	1295	1296
1297	1377	1385	1387	1389	1390	1391	1436	1443	1445	1446	1447	1473	1481
1493	1495	1486	1487	1530	1540	1542	1544	1545	1588	1599	1601	1603	1604
1605	1689	1697	1699	1701	1702	1703	1742	1750	1752	1753	1754	1783	1794
1796	1798	1799	1800	1841	1845	1846	1847	1848	1850	1852	1858	1861	1863
1867	1868	1877	1878	1882	1889	1891	1893	1894	1895	1952	1961	1963	1964
1965	1996	2003	2005	2007	2008	2009	2018	2027	2029	2031	2032	2033	2075
2080	2084	2085	2087	2089	2091	2093	2094	2095	2097	2109	2128	2160	2163
2193	2196	2220	2221	2242	2246	2293	2294	2299	2303	2312	2322	2368	2386
2390	2418	2421	2432	2437	2470	2474	2493	2505	2656	2669	2724	2752	2754
2767	2772	2785	2789	2808	2811	2830	2833	2840	2848	2904	2906	2923	2935
2937	2951	2955	2972	2974	2977	2989	2992	3005	3016	3090	3095	3116	3142
3148	3161	3164	3176	3181	3199	3206	3223	3226	3237	3239	3248	3280	3287
3307	3310	3315	3317	3343	3347	3397	3404	3444	3448	3463	3467	3491	3500
3506	3511	3516	3517	3529	3531	3532	3533	3535	3536	3537	3548	3556	3557
3562	3563	3564	3570	3580	3583	3590	3592	3593	3595	3598	3608	3609	3637
3687	3705	3721	3744	3822	3890	3903	3913	3921	3923	3927	3939	3943	3947
3957	3958	3959	3960	3961	3961	3903	3913	3921	3923	3927	3939	3943	3947
. IFF	21	23	24	25	28	28	38	144	152	179	186	369	391
	407	409	425	427	437	439	439	449	477	479	510	512	567
	569	571	573	581	583	635	635	638	668	678	685	738	792
	796	600	801	818	825	829	831	830	920	926	929	930	975
	976	1014	1018	1021	1022	1047	1057	1054	1058	1095	1101	1104	1145
	1154	1157	1158	1159	1279	1291	1295	1294	1377	1385	1388	1389	1444
	1445	1473	1481	1484	1485	1530	1543	1540	1544	1588	1599	1602	1689
	1697	1700	1701	1742	1748	1751	1783	1752	1794	1797	1798	1842	1853
	1858	1861	1878	1882	1889	1892	1894	1893	1952	1959	1962	1964	2003
	2006	2007	2008	2018	2027	2030	2032	2031	2075	2077	2084	2128	2163
	2193	2196	2221	2222	2242	2246	2295	2294	2299	2303	2312	2362	2386
	2390	2418	2421	2432	2437	2470	2493	2505	2505	2656	2669	2724	2754
	2767	2772	2785	2789	2808	2811	2830	2840	2848	2904	2906	2920	2935
	2937	2951	2955	2972	2974	2977	2989	2992	3005	3016	3090	3095	3142
	3148	3161	3164	3176	3181	3199	3206	3223	3226	3237	3239	3248	3287
	3308	3311	3315	3317	3343	3347	3397	3404	3444	3448	3463	3467	3501
	3530	3533	3534	3537	3563	3565	3570	3583	3608	3609	3610	3688	3745
	3823	3891	3923	3931	3940	3940	3940	3940	3940	3940	3940	3940	3940
. IFT	3545	3593											
. IFTF	3543	3592											
. IIF	3	8	13	18	19	20	24	25	137	185	788	793	1847
	1853	1854	1865	1878	1882	2085	2087	2094	2095	2097	2098	2218	3507
	3508	3509	3510	3511	3512	3544	3545	3560	3563	3571	3572	3573	3575
	3598	3609	3687	3703	3728	3732	3956	3957	3958	3959	3960		
. IRP	665	779	783	828	839	851	854	866	870	917	928	974	1020
	1042	1056	1080	1083	1084	1091	1103	1110	1111	1112	1156	1244	1319
	1328	1343	1344	1367	1387	1422	1443	1483	1542	1583	1601	1631	1653
	1682	1699	1721	1737	1750	1796	1802	1803	1804	1820	1821	1832	1891
	1961	1972	1973	1974	2005	2029	2257	2264	2268	2272	2273	2275	2326
	2327	2352	2356	2358	2371	2372	2373	2374	2382	2383	2393	2415	2508
	2582	2732	2733	2734	2742	2743	2744	2745	2746	2775	2776	2779	2796
	2827	2851	2895	2898	2912	2913	2958	2959	2969	3019	3062	3063	3125
	3135	3208	3220	3255	3470	3471	3472	3485	3516	3836	3876	3897	
. LIST	2	3	24	130	137	179	369	370	371	372	389	390	407
	408	409	410	425	426	427	428	437	438	439	440	449	452
	477	478	479	480	510	511	512	513	525	526	527	528	569

MAINDEC-11-DZVTH-A MACY11 27(732) 20-SEP-76 10:22 PAGE 109  
 DZVTH.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

SEQ 0117

570	571	572	573	574	581	582	583	584	635	636	638	639	665	666
668	669	678	679	685	686	738	739	744	745	818	819	825	826	828
830	920	921	926	927	928	930	964	965	971	972	974	976	1014	1015
1018	1019	1020	1022	1047	1048	1054	1055	1056	1058	1095	1096	1101	1102	1103
1105	1145	1146	1154	1155	1156	1158	1279	1280	1291	1292	1293	1295	1377	1378
1385	1386	1387	1389	1436	1437	1441	1442	1443	1445	1473	1474	1481	1482	1483
1485	1530	1531	1540	1541	1542	1544	1588	1589	1599	1600	1601	1603	1689	1690

109

1697	1698	1699	1701	1742	1743	1748	1750	1752	1783	1784	1794	1795	1796
1798	1853	1882	1883	1889	1890	1891	1893	1952	1953	1959	1960	1961	1963
1997	2003	2004	2005	2007	2018	2019	2027	2028	2029	2031	2075	2076	2077
2128	2129	2132	2133	2160	2161	2163	2164	2193	2194	2196	2197	2242	2243
2247	2299	2300	2303	2304	2312	2313	2322	2323	2362	2363	2368	2369	2386
2390	2391	2418	2419	2421	2422	2432	2433	2437	2438	2470	2471	2472	2474
2476	2493	2494	2505	2506	2656	2657	2669	2670	2724	2725	2729	2730	2752
2754	2755	2767	2768	2772	2773	2785	2786	2789	2790	2808	2809	2811	2812
2831	2833	2834	2840	2841	2848	2849	2904	2905	2906	2907	2920	2921	2923
2935	2936	2937	2938	2951	2952	2955	2956	2972	2973	2974	2975	2977	2978
2990	2992	2993	3005	3006	3016	3017	3090	3091	3095	3096	3116	3117	3122
3142	3143	3148	3149	3161	3162	3164	3165	3176	3177	3181	3182	3199	3200
3207	3223	3224	3226	3227	3237	3238	3239	3240	3248	3249	3252	3253	3280
3287	3288	3315	3316	3317	3318	3343	3344	3347	3348	3397	3398	3404	3405
3445	3448	3449	3463	3464	3467	3468	3489	3490	3491	3492	3511	3598	3947
3957	3958	3959	3960	3961									

.MACRO  
.MCALL  
.MLIST

25	143	3947											
3	130												
1	3	24	130	137	179	369	370	372	389	390	391	392	407
408	409	410	425	426	427	428	437	439	440	449	450	451	452
477	478	479	480	510	511	512	513	525	526	527	528	567	569
570	571	572	573	574	581	582	583	584	635	636	638	665	666
668	669	678	679	685	686	738	739	744	745	818	819	825	826
830	920	921	926	927	928	930	964	965	971	972	974	976	828
1018	1019	1020	1022	1047	1048	1054	1055	1056	1058	1095	1096	1014	1015
1105	1145	1146	1154	1155	1156	1158	1279	1280	1291	1292	1293	1101	1103
1385	1386	1387	1389	1436	1437	1441	1442	1443	1445	1473	1474	1481	1378
1485	1530	1531	1540	1541	1542	1544	1588	1589	1599	1600	1601	1603	1483
1697	1698	1699	1701	1742	1743	1748	1749	1750	1752	1783	1784	1794	1690
1798	1853	1882	1883	1889	1890	1891	1893	1952	1953	1959	1960	1961	1796
1997	2003	2004	2005	2007	2018	2019	2027	2028	2029	2031	2075	2076	1996
2128	2129	2132	2133	2160	2161	2163	2164	2193	2194	2196	2197	2242	2078
2247	2299	2300	2303	2304	2312	2313	2322	2323	2362	2363	2368	2369	2246
2390	2391	2418	2419	2421	2422	2432	2433	2437	2438	2470	2471	2472	2387
2476	2493	2494	2505	2506	2656	2657	2669	2670	2724	2725	2729	2730	2475
2754	2755	2767	2768	2772	2773	2785	2786	2789	2790	2808	2809	2811	2475
2831	2833	2834	2840	2841	2848	2849	2904	2905	2906	2907	2920	2921	2830
2935	2936	2937	2938	2951	2952	2955	2956	2972	2973	2974	2975	2977	2924
2990	2992	2993	3005	3006	3016	3017	3090	3091	3095	3096	3116	3117	2989
3142	3143	3148	3149	3161	3162	3164	3165	3176	3177	3181	3182	3199	3123
3207	3223	3224	3226	3227	3237	3238	3239	3240	3248	3249	3252	3253	3206
3287	3288	3315	3316	3317	3318	3343	3344	3347	3348	3397	3398	3404	3281
3445	3448	3449	3463	3464	3467	3468	3489	3490	3491	3492	3511	3598	3444
3957	3958	3959	3960	3961									3956

.PAGE  
.REPT

143	185	371	389	391	407	409	425	427	437	439	449	451	477	479
137	369	525	527	567	569	571	573	581	583	635	638	665	668	678
510	512	744	818	825	920	926	964	971	1014	1018	1047	1054	1095	1101
685	738	1279	1291	1377	1385	1436	1441	1473	1481	1530	1540	1588	1599	1689
1145	1154													

MAINDEC-11-DZVTH-A  
DZVTH.P11  
MACY11 27(732)  
CROSS REFERENCE TABLE  
20-SEP-76 10:22  
PERMANENT SYMBOLS  
PAGE 110

SEQ 0118

1697	1742	1748	1783	1794	1882	1889	1952	1959	1996	2003	2018	2027	2075	2077
2128	2132	2160	2163	2193	2196	2242	2246	2299	2303	2312	2322	2362	2368	2386
2390	2418	2421	2432	2437	2470	2474	2493	2505	2642	2656	2669	2724	2729	2752
2754	2767	2772	2785	2789	2808	2811	2830	2833	2840	2848	2904	2906	2920	2923
2935	2937	2951	2955	2972	2974	2977	2989	2992	3005	3016	3090	3095	3116	3122
3142	3148	3161	3164	3176	3181	3199	3206	3223	3226	3237	3239	3248	3252	3280
3287	3315	3317	3343	3347	3397	3404	3444	3448	3463	3467	3489	3491	3932	3948
14	26	131	145	187	1843	3502	3566	3611	3689	3746	3824	3892	3932	3948
3														
137	138	139	152	155	156	157	158	161	162	163	164	165	166	167
168	169	170	338	340	347	349	353	355	357	416	417	419	420	421
422	423	424	428	429	430	431	432	433	434	442	444	446	448	450

.SBTTL  
.TITLE  
.WORD

454	457	460	463	466	469	473	109	478	483	485	488	490	493	496
499	503	505	508	511	515	517	520	522	526	530	532	533	535	538
539	542	544	545	547	549	550	552	554	555	557	559	560	562	564
565	568	587	589	597	602	604	606	607	608	609	610	612	614	616
617	618	619	620	643	644	645	646	647	648	649	650	651	652	653
654	656	657	658	659	660	661	662	1268	1269	1270	1271	1272	1273	1430
1431	1432	1433	1523	1858	1861	2064	2066	2070	2072	2637	2638	2639	2640	2651
2652	2653	2654	2719	2720	2721	2723	2783	2900	2901	2902	3004	3462	3681	3714
3719	3821	3922	4522											

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\* DZVTH/SOL/CRF=DZVTH  
 RUN-TIME: 47 41 10 SECONDS  
 RUN-TIME RATIO: 257/100=2.5  
 CORE USED: 20K (39 PAGES)

