

.REM -

IDENTIFICATION

PRODUCT CODE: AC-F706G-MC
PRODUCT NAME: CXDCAGO DC11 MODULE
PRODUCT DATE: SEPTEMBER 1978
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE OR EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973,1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT:

DCA IS AN IOMOD THAT EXERCISES UP TO SIXTEEN DC11 ASYNCHRONOUS INTERFACES. IT IS CAPABLE OF EXERCISING ALL DC11 MODELS. IT USES MAINTENANCE MODE TO EXIT AND IN RECEIVE A BINARY PATTERN OUTPUT AND RECEIVED IN 64 CHARACTER BURSTS. THE MAJOR PORTION OF THE ERROR CHECKING IS DEFERRED TO LEVEL 0. ALL LINES SELECTED FOR TEST (UP TO 16 DC11-S WITH CONTIGUOUS ADDRESSES AND VECTORS) ARE ACTIVATED AND RUN CONCURRENTLY. ALL TRANSMIT AND RECEIVE ERRORS ARE REPORTED ON THE CONSOLE TTY.

2. REQUIREMENTS:

HARDWARE: AT LEAST ONE DC11 INTERFACE

STORAGE:: DCA REQUIRES:
1. DECIMAL WORDS: 868
2. OCTAL WORDS: 1544
3. OCTAL BYTES: 3310

3. PASS DEFINITION:

ONE PASS OF THE DCA MODULE CONSISTS OF TRANSMITTING AND RECEIVING 8192. (TOTAL) CHARACTERS.

4. EXECUTION TIME:

VARIABLES WITH BAUD RATE BUT SHOULD TAKE AN AVERAGE OF ONE MINUTES TO COMPLETE ONE PASS WHEN RUNNING ALONE.

5. CONFIGURATION PARAMETERS:

DEFAULT PARAMETERS:

DVA: 174000, VCT: 300, BR1: 5, BR2: 0, DVC: 1

REQUIRED PARAMETERS:

AT CONFIGURATION TIME THE USER MUST SPECIFY:

VCT: VECTOR ADDRESS OF FIRST DC11 IF NOT 300
DVC: NO OF DC11'S IF GREATER THAN 1

6. DEVICE OPTION SETUP:

NONE REQUIRED

7. MODULE OPERATION:

7.1 TEST SEQUENCE:

- A. START: USING THE DEVICE SELECTION PARAMETER "DVID" THIS SECTION OF CODE SETS UP THE VECTORS OF ALL SELECTED LINES TO POINT TO THE APPROPRIATE JSR IN THE JSR LINKING TABLE.
- B. SETCSR: THIS PIECE OF CODE INSERTS THE PROPER CSR ADDRESS OF EACH ACTIVE LINE INTO THE THIRD WORD OF EACH JSR TABLE ENTRY.
- C. STUP: THIS ROUTINE INITIALIZES ALL TABLES, BUFFERS, FLAGS AND COUNTERS, THEN PROCEEDS TO TURN ON THE INTERRUPTS FOR ALL ACTIVE LINES. IT USES THE CONTENTS OF THE ACTIVE DEVICE TABLE TO FIND OUT WHICH LINES TO KICK OFF AFTER INITIALIZING ALL LINES. IT WAITS FOR COMPLETION OF 64 TRANSMITTER AND RECEIVER INTERRUPTS VIA A BREAK LOOP. IF THE 64 INTERRUPTS HAVE OCCURRED ON BOTH TRANSMITTER AND RECEIVER OR IF THE BREAK LOOP TIMES OUT, CONTROL PASSES TO ERCHK.

(7.1 CONT'D)

D. TINT:

THE TRANSMITTER SERVICE ROUTINE SIMPLY
QUEUES UP THE REQUEST FOR SERVICE IN
A FIFO QUEUE. UPDATES TO THE POINTER IN
RETURNS CONTROL BACK TO THE MONITOR AND
A PIPE. THE ELEMENT THAT GETS STORED
IN THE QUEUE IS A POINTER TO THE INTER-
RUPTING CSR ADDRESS. THE ACTUAL SER-
VICING IS DONE LATER WHERE THE SERVICE
CODE IS EXECUTED AT LEVEL 0.

E. TSERV:

THIS CODE RETRIEVES A POINTER FROM THE
FIFO QUEUE AND BUILDS THE CSR ADDRESS.
THE FOLLOWING SEQUENCE IS EXECUTED:

1. TEST FOR END OF 64. CHAR BURST - IF
END EXIT - IF NOT GO TO 2
2. TEST READY FLAG - IF NOT ASSERTED GO
PROCEED FALSE INTERRUPT - IF ASSERTED
PROCEED TO STEP 3
3. COUNT THE INTERRUPT FOR INDIVIDUAL
LINE
4. GENERATE AND OUTPUT NEXT CHARACTER,
KEEP TRACK OF THE NUMBER OF CHARACTERS
OUTPUT ON THE LINE, AND THEN EXIT BACK TO
THE MONITOR.

F. RINT:

THE RECEIVER SERVICE ROUTINE STORES
DATA AND STATUS INFORMATION IN A RE-
CEIVER STARTUP TABLE. TESTS FOR THE
END OF A 64 CHAR BURST SEQUENCE AND
THEN EXECUTES AN "RTI". IT ALSO COUNTS
RECEIVE INTERRUPTS IN A SEPARATE
COUNTER FOR EACH LINE.

G. ERRCHK:

THE BULK OF THE ERROR CHECKING AND RE-
PORTING IS DONE HERE AT THE END OF EACH
64. CHAR BURST. THE FOLLOWING SEQUENCE
IS EXECUTED:

1. TURN OFF RCVR AND XMTR INTR. ENABLES
FOR ALL ACTIVE LINES
2. SCAN THROUGH THE RECEIVER STATUS TABLE
(64 ENTRIES OF TWO WORDS EACH) TO CHECK
FOR AND REPORT:

(7.1, SECTION G CONT'D)

- A.) RARITY, FRAMING AND OVER-RUN ERRORS.
 - B.) RCVR FALSE INTERRUPTS
 - C.) DATA COMPARE ERRORS. ONLY IF A AND B DID NOT OCCUR.
3. CHECK RECEIVER AND TRANSMITTER INTERRUPT COUNTS FOR EACH LINE TO BE SURE THAT NO LINES WERE DROPPED OR HAD TOO MANY INTERRUPTS.
4. GO TO THE ENPS ROUTINE AFTER CHECKING ALL 64 ENTRIES.
- H. ENPS: COUNT THE 64 CHAR BURST AND TEST FOR 128 BURSTS (8192 CHARS). IF NOT END OF PASS GO TO I. IF END REPORT END OF PASS AND GO TO C.
- I. RESYNC: RESYNC THE DATA BUFFERS AND THEN RESTART AT STEP C.

7.2

DESCRIPTION OF TABLES, QUEUES, AND BUFFERS

- A. RSTAR: THIS IS A 128. WORD STATUS TABLE CONSISTING OF 64. TWO WORD ENTRIES. IT GETS LOADED DURING RECEIVER INTERRUPT SERVICE AND CHECKED AT THE END OF EACH 64. CHAR BURST. EACH ENTRY HAS THE FOLLOWING FORMAT:
- 1ST WORD: CONTENTS OF RC5R
 - 2ND WORD: LO BYTE = RCVD DATA BYTE
HI BYTE = LINE NUMBER
- B. RCNT: 16 BYTE TABLE CONTAINING AN 8 BIT INTERRUPT COUNTER FOR EACH RCVR. THE APPROPRIATE BYTE GETS INCREMENTED DURING RCVR INTR SERVICE AND CHECKED FOR EQUIVALENCE TO THE NUMBER OF CHARACTERS TRANSMITTED.
- C. TCNT: 16 BYTE TABLE CONTAINING AN 8-BIT INTERRUPT COUNTER FOR EACH TRANSMITTER. THE APPROPRIATE BYTE GETS INCREMENTED DURING DEFERRED INTR. SERVICE AND CHECKED FOR EQUIVALENCE TO THE NUMBER OF CHARACTERS TRANSMITTED.

(7.2 CONT'D)

- D. DCNT: 16 BYTE TABLE CONTAINING AN 8-BIT DATA COUNTER FOR EACH LINE. THE APPROPRIATE BYTE GETS INCREMENTED EACH TIME A CHARACTER IS TRANSMITTED ON THE LINE AND CLEARED BEFORE THE BEGINNING OF EACH 64 WORD BURST.
- E. TQ: 16 WORD FIFO QUEUE FOR TRANSMITTER SERVICE. LOADED DURING XMTR INTERRUPT SERVICE WITH A POINTER TO THE CSR ADDRESS AND UNLOADED DURING DEFERRED XMTR SERVICE.
- F. XBWF: 16 BYTE XMTP DATA BUFFERS - ONE BYTE/XMTR
- G. RBWF: 16 BYTE RCVR DATA BUFFERS - ONE BYTE/RCVR.
- H. JSPTAB: A 128 WORD TABLE THAT CONTAINS 64 JSR INSTRUCTIONS WITH TWO TRAILING ARGUMENTS. EACH RECEIVER AND EACH XMTR HAS AN ASSIGNED JSR IN THE TABLE OF THE FOLLOWING FORMAT:

```
JSR  R5,RINT(TINT)
0
N
```

WHERE THE 0 GETS OVERLAYED WITH THE ADDRESS OF THE CSR FOR LINE N AND N IS THE LINE NO. IN OCTAL (00-17)

8. OPERATOR OPTIONS:

- A. THE USER CAN USE THE "MOD" COMMAND TO DUMP THE TABLES BUFFERS DESCRIBED IN 7.2 TO OBTAIN MORE DETAILED ERROR INFORMATION.
 - B. THE USER CAN MODIFY "DVID1" (APC 14) TO SELECT OR Deselect INDIVIDUAL DC11'S.
9. NON-STANDARD PRINTOUTS:

- THERE ARE TWO ERROR PRINTOUTS WHICH SUPPLY SPECIAL INFORMATION IN THE CSRC AND STATC VALUES (CONSULT LISTING).


```
404 000432 000767 BR 3S ;GO TEST FOR END OF TABLE
405
406 ;THIS ROUTINE CLEARS BUFFERS AND TABLES, INITIALIZES FLAGS, AND STARTS
407 ;UP ALL SELECTED LINES.
408 000434 004767 002122 JSR PC,CLRBUF ;GO CLEAR XMTR. AND RCVR. BUFFERS
409 000440 004767 002152 RESTRT: JSR PC,DTAB ;SET UP THE ACTIVE DEVICE TABLE.
410 000444 004767 002130 STUP1: JSR PC,CLRTAB ;GO CLEAR TABLES AND QUEUES
411 000450 005067 002072 CLR TXCNT ;CLEAR TX TOTAL INTERRUPT COUNTER.
412 000454 005067 002070 CLR RXCNT ;CLEAR RX TOTAL INTERRUPT COUNTER.
413 000460 012767 01764 002066 MOV #RSTAB,SVPTR ;INITIALIZE RCVR. STATUS TABLE POINTER
414 000466 012767 002444 002062 MOV #TO,QPTR1 ;SET UP XMTR FIFO QUEUE POINTERS
415 000474 012767 002444 002056 MOV #TO,QPTR2
416 000502 016700 002176 MOV ACTDEV,R0 ;GET COUNT OF ACTIVE DEVICES
417 000506 116002 00264 1S: MOV DDEVTAB(R0),R2 ;GET AN ACTIVE LINE NO.
418 000512 004767 001102 JSR PC,GETADR ;GO BUILD CSR ADDRESS IN R3
419 000516 005763 000002 TST 2(R3) ;READ RCVR DRR TO PLSH DONE BIT
420 000522 052763 003130 BHS #3130,(R3) ;ENABLE RECEIVER INTERRUPTS
421 000526 052763 000434 000004 INCB #434,(R3) ;ENABLE MAINT. MODE
422 000534 105262 002504 000006 MOV #RBUF(R2),6(R3) ;OUTPUT CHAR ONTO TX
423 000540 116263 002504 000006 INCB TXCNT ;UP COUNT OF CHARS OUTPUT.
424 000546 105267 001774 INCB DCNT(R2) ;COUNT CHARACTERS OUTPUT ON THIS LINE
425 000552 052763 000100 000004 BHS #100,(R3) ;ENABLE TX INTERRUPTS-
426 000556 052763 000300 DEC R0 ;COUNT ONE KICKED OFF
427 000564 005300 BPL 1S ;GO TEST FOR NEXT ONE
428 000566 100347 000006 001754 MOV #6,CNTR ;INITIAL COUNTER TO WAIT AT LEAST
429 000570 012767 ;30 SECONDS BEFORE TIMING OUT
430
431 000576 005004 10S: CLR R4
432 000600 104407 000000 2S: BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR.
433 000604 104407 000000 2S: BREAKS,BEGIN ;THEN CONTINUE AT NEXT INSTRUCTION.
434 000610 122767 000100 001731 CMPR #64, TXCNT+1 ;64 TRANSMITTER INTERRUPTS?
435 000616 003004 BGT 3S ;NO- BRANCH TO WAIT
436 000620 02767 000100 001722 CMP #4, RXCNT ;YES- 64 RECEIVER INTERRUPTS?
437 000624 024405 BLE 4S ;YES- GO CHECK FOR ERRORS
438 000630 005304 DEC R4 ;TIMEOUT?
439 000632 001362 BNE 2S ;NO- WAIT SOME MORE
440 000634 005367 001712 DEC CNTR ;EACH PASS OF THE SMALL LOOP TAKES
441 ;AT LEAST 5 SECONDS
442 ;BRANCH IF NOT DONE WITH 6 PASSES OF
443 000640 001356 BNE 10S ;THE SMALL COUNTER
444
445 000642 000167 000272 4S: JMP ERRCHK
446
447 ;TRANSMITTER INTERRUPT SERVICE - ENTERED VIA APPROPRIATE JSR TABLE
448 ;ENTRY WITH R5 POINTING TO THE CSR ADDRESS - CONTENTS OF R5
449 ;GETS QUEUED UP IN FIFO QUEUE AND ROUTINE RETURNS CONTROL BACK TO
450 ;THE MONITOR VIA DRR TO DEFER SERVICE AT INTERRUPT LEVEL 0
451 000646 010577 001704 TINT: MOV R5,QPTR1 ;STORE CONTENTS OF R5 IN THE QUEUE
452 000652 052767 000002 001676 ADD #2,QPTR1 ;UPDATE THE QUEUE POINTER
453 000656 02767 002504 001670 CMP #TO+40,QPTR1 ;POINTER AT END OF QUEUE?
454 000662 001003 BNE 1S ;RR IF NOT
455 000670 012767 002444 001660 MOV #TO,QPTR1 ;RESET THE POINTER
456 000676 012605 1S: MOV (R5)+,R5 ;RESTORE THE OTHER GUY'S R5
457
458 000700 000004 000000 000706 ;DRQS,BEGIN,TSERV ; QUEUE UP TO CONTINUE AT TSERV AND RTI
459 ;-----
```

```
460 ;DEFERRED XMTR SERVICE - THIS ROUTINE RETRIEVES POINTER TO CSR ADDRESS
461 ;FROM THE FIFO QUEUE AND SERVICES THE LINE AT LEVEL 0
462 TSERV: MOV #QPTR2,R0 ;GET POINTER FROM THE QUEUE
463 000706 017700 001646 ADD #2,QPTR2 ;UPDATE THE QUEUE POINTER
464 000712 052767 000002 001640 CMP #TO+40,QPTR2 ;POINTER AT HIGH LIMIT
465 000720 022767 002504 001632 BNE 1S ;RR IF NOT
466 000730 012767 002444 001622 MOV #TO,QPTR2 ;RESET THE POINTER
467 000736 012001 1S: MOV (R0)+,R1 ;MOV CSR ADDRESS INTO R1
468 000740 011000 MOV (R0),R0 ;MOV LINE # INTO R0
469 000742 105267 001601 INCB TXCNT ;COUNT TOTAL TX INTERRUPTS.
470 000746 105260 002404 INCB TCNT(R0) ;COUNT THE INTERRUPT
471 000752 105711 TSTB (R1) ;XMTR READY FLAG ASSERTED?
472 000754 100011 BPL 4S ;RR IF NOT
473 000756 122767 000100 001562 CMPR #64, TXCNT ;64 CHARACTERS TRANSMITTED?
474 000764 001427 BEQ 5S ;YES- BRANCH TO EXIT
475 000766 105260 002504 000002 INCB #RBUF(R0) ;GENERATE NEXT DATA BYTE
476 000772 116061 002504 000002 MOV #RBUF(R0),2(R1) ;LOAD THE XMTR BUFFER
477 001000 105267 001542 INCB TXCNT ;UP TOTAL COUNT OF CHARS OUTPUT.
478 001004 105260 002424 INCB DCNT(R0) ;COUNT CHARACTERS OUTPUT ON THIS LINE
479 001010 104400 000000 4S: EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
480 001014 010167 177050 MOV R1,CSRA ;SAVE CSR ADDRESS
481 001018 105267 177056 MOV (R1),RCR ;SAVE CONTENTS OF THE CSR
482 001024 142771 000100 BICR #100,(R1) ;DISABLE XMTR INTERRUPT
483 001030 012767 000011 177050 MOV #11,ERRTYP ;ILLEGAL INTERRUPT
484 ;*****
485 ;*****
486 ;*****
487 ;*****
488 ;*****
489 ;*****
490 ;*****
491 ;*****
492 ;*****
493 ;*****
494 ;*****
495 ;*****
496 ;*****
497 ;*****
498 ;*****
499 ;*****
500 ;*****
501 ;*****
502 ;*****
503 ;*****
504 ;*****
505 ;*****
506 ;*****
507 ;*****
508 ;*****
509 ;*****
510 ;*****
511 ;*****
512 ;*****
513 ;*****
514 ;*****
515 ;*****
516 ;*****
517 ;*****
518 ;*****
519 ;*****
520 ;*****
521 ;*****
522 ;*****
523 ;*****
524 ;*****
525 ;*****
526 ;*****
527 ;*****
528 ;*****
529 ;*****
530 ;*****
531 ;*****
532 ;*****
533 ;*****
534 ;*****
535 ;*****
536 ;*****
537 ;*****
538 ;*****
539 ;*****
540 ;*****
541 ;*****
542 ;*****
543 ;*****
544 ;*****
545 ;*****
546 ;*****
547 ;*****
548 ;*****
549 ;*****
550 ;*****
551 ;*****
552 ;*****
553 ;*****
554 ;*****
555 ;*****
556 ;*****
557 ;*****
558 ;*****
559 ;*****
560 ;*****
561 ;*****
562 ;*****
563 ;*****
564 ;*****
565 ;*****
566 ;*****
567 ;*****
568 ;*****
569 ;*****
570 ;*****
571 ;*****
572 ;*****
573 ;*****
574 ;*****
575 ;*****
576 ;*****
577 ;*****
578 ;*****
579 ;*****
580 ;*****
581 ;*****
582 ;*****
583 ;*****
584 ;*****
585 ;*****
586 ;*****
587 ;*****
588 ;*****
589 ;*****
590 ;*****
591 ;*****
592 ;*****
593 ;*****
594 ;*****
595 ;*****
596 ;*****
597 ;*****
598 ;*****
599 ;*****
600 ;*****
601 ;*****
602 ;*****
603 ;*****
604 ;*****
605 ;*****
606 ;*****
607 ;*****
608 ;*****
609 ;*****
610 ;*****
611 ;*****
612 ;*****
613 ;*****
614 ;*****
615 ;*****
616 ;*****
617 ;*****
618 ;*****
619 ;*****
620 ;*****
621 ;*****
622 ;*****
623 ;*****
624 ;*****
625 ;*****
626 ;*****
627 ;*****
628 ;*****
629 ;*****
630 ;*****
631 ;*****
632 ;*****
633 ;*****
634 ;*****
635 ;*****
636 ;*****
637 ;*****
638 ;*****
639 ;*****
640 ;*****
641 ;*****
642 ;*****
643 ;*****
644 ;*****
645 ;*****
646 ;*****
647 ;*****
648 ;*****
649 ;*****
650 ;*****
651 ;*****
652 ;*****
653 ;*****
654 ;*****
655 ;*****
656 ;*****
657 ;*****
658 ;*****
659 ;*****
660 ;*****
661 ;*****
662 ;*****
663 ;*****
664 ;*****
665 ;*****
666 ;*****
667 ;*****
668 ;*****
669 ;*****
670 ;*****
671 ;*****
672 ;*****
673 ;*****
674 ;*****
675 ;*****
676 ;*****
677 ;*****
678 ;*****
679 ;*****
680 ;*****
681 ;*****
682 ;*****
683 ;*****
684 ;*****
685 ;*****
686 ;*****
687 ;*****
688 ;*****
689 ;*****
690 ;*****
691 ;*****
692 ;*****
693 ;*****
694 ;*****
695 ;*****
696 ;*****
697 ;*****
698 ;*****
699 ;*****
700 ;*****
701 ;*****
702 ;*****
703 ;*****
704 ;*****
705 ;*****
706 ;*****
707 ;*****
708 ;*****
709 ;*****
710 ;*****
711 ;*****
712 ;*****
713 ;*****
714 ;*****
715 ;*****
716 ;*****
717 ;*****
718 ;*****
719 ;*****
720 ;*****
721 ;*****
722 ;*****
723 ;*****
724 ;*****
725 ;*****
726 ;*****
727 ;*****
728 ;*****
729 ;*****
730 ;*****
731 ;*****
732 ;*****
733 ;*****
734 ;*****
735 ;*****
736 ;*****
737 ;*****
738 ;*****
739 ;*****
740 ;*****
741 ;*****
742 ;*****
743 ;*****
744 ;*****
745 ;*****
746 ;*****
747 ;*****
748 ;*****
749 ;*****
750 ;*****
751 ;*****
752 ;*****
753 ;*****
754 ;*****
755 ;*****
756 ;*****
757 ;*****
758 ;*****
759 ;*****
760 ;*****
761 ;*****
762 ;*****
763 ;*****
764 ;*****
765 ;*****
766 ;*****
767 ;*****
768 ;*****
769 ;*****
770 ;*****
771 ;*****
772 ;*****
773 ;*****
774 ;*****
775 ;*****
776 ;*****
777 ;*****
778 ;*****
779 ;*****
780 ;*****
781 ;*****
782 ;*****
783 ;*****
784 ;*****
785 ;*****
786 ;*****
787 ;*****
788 ;*****
789 ;*****
790 ;*****
791 ;*****
792 ;*****
793 ;*****
794 ;*****
795 ;*****
796 ;*****
797 ;*****
798 ;*****
799 ;*****
800 ;*****
801 ;*****
802 ;*****
803 ;*****
804 ;*****
805 ;*****
806 ;*****
807 ;*****
808 ;*****
809 ;*****
810 ;*****
811 ;*****
812 ;*****
813 ;*****
814 ;*****
815 ;*****
816 ;*****
817 ;*****
818 ;*****
819 ;*****
820 ;*****
821 ;*****
822 ;*****
823 ;*****
824 ;*****
825 ;*****
826 ;*****
827 ;*****
828 ;*****
829 ;*****
830 ;*****
831 ;*****
832 ;*****
833 ;*****
834 ;*****
835 ;*****
836 ;*****
837 ;*****
838 ;*****
839 ;*****
840 ;*****
841 ;*****
842 ;*****
843 ;*****
844 ;*****
845 ;*****
846 ;*****
847 ;*****
848 ;*****
849 ;*****
850 ;*****
851 ;*****
852 ;*****
853 ;*****
854 ;*****
855 ;*****
856 ;*****
857 ;*****
858 ;*****
859 ;*****
860 ;*****
861 ;*****
862 ;*****
863 ;*****
864 ;*****
865 ;*****
866 ;*****
867 ;*****
868 ;*****
869 ;*****
870 ;*****
871 ;*****
872 ;*****
873 ;*****
874 ;*****
875 ;*****
876 ;*****
877 ;*****
878 ;*****
879 ;*****
880 ;*****
881 ;*****
882 ;*****
883 ;*****
884 ;*****
885 ;*****
886 ;*****
887 ;*****
888 ;*****
889 ;*****
890 ;*****
891 ;*****
892 ;*****
893 ;*****
894 ;*****
895 ;*****
896 ;*****
897 ;*****
898 ;*****
899 ;*****
900 ;*****
901 ;*****
902 ;*****
903 ;*****
904 ;*****
905 ;*****
906 ;*****
907 ;*****
908 ;*****
909 ;*****
910 ;*****
911 ;*****
912 ;*****
913 ;*****
914 ;*****
915 ;*****
916 ;*****
917 ;*****
918 ;*****
919 ;*****
920 ;*****
921 ;*****
922 ;*****
923 ;*****
924 ;*****
925 ;*****
926 ;*****
927 ;*****
928 ;*****
929 ;*****
930 ;*****
931 ;*****
932 ;*****
933 ;*****
934 ;*****
935 ;*****
936 ;*****
937 ;*****
938 ;*****
939 ;*****
940 ;*****
941 ;*****
942 ;*****
943 ;*****
944 ;*****
945 ;*****
946 ;*****
947 ;*****
948 ;*****
949 ;*****
950 ;*****
951 ;*****
952 ;*****
953 ;*****
954 ;*****
955 ;*****
956 ;*****
957 ;*****
958 ;*****
959 ;*****
960 ;*****
961 ;*****
962 ;*****
963 ;*****
964 ;*****
965 ;*****
966 ;*****
967 ;*****
968 ;*****
969 ;*****
970 ;*****
971 ;*****
972 ;*****
973 ;*****
974 ;*****
975 ;*****
976 ;*****
977 ;*****
978 ;*****
979 ;*****
980 ;*****
981 ;*****
982 ;*****
983 ;*****
984 ;*****
985 ;*****
986 ;*****
987 ;*****
988 ;*****
989 ;*****
990 ;*****
991 ;*****
992 ;*****
993 ;*****
994 ;*****
995 ;*****
996 ;*****
997 ;*****
998 ;*****
999 ;*****
1000 ;*****
```



```

516 ;THIS ROUTINE DISABLES INTERRUPTS FROM ALL ACTIVE LINES
517 ERCHK: MOV ACTDEV,R0 ;GET COUNT OF ACTIVE DEVICES
518 1S: MOV DEVTAB(R0),R2 ;GET ACTIVE LINE NO.
519 JSR PC,GETADR ;GO BUILD ADDRESS IN R3
520 BIC #100,(R3) ;TURN OFF RECEIVER.
521 BIC #100,(R3) ;TURN OFF TRANSMITTER.
522 DEC R0 ;COUNT ONE GOV OFF
523 BPL 1S ;BR TIL ALL OFF
524
525 ;THIS ROUTINE SCANS THROUGH THE 64 ENTRY RECEIVER STATUS TABLE
526 ;CHECKING FOR AND REPORTING ANY ERRORS.
527 CHK1: CMP RCNT,#64 ;MAKE SURE COUNT IS NO LARGER THAN TABLE
528 BLE 1S ;
529 MOV #64,RCNT
530 1S: MOV RSTAB,R1 ;GET STATUS TABLE POINTER
531 CLR R0 ;INDICATE NO HARDWARE FAILURES YET.
532 2S: MOVB J(R1),R2 ;GET LINE NO. INTO R2
533 TST (R1) ;ERROR SET?
534 BPL 4S ;BRANCH IF NOT
535 JSR PC,RCVERR ;GO SETUP TO REPORT ERROR
536 CLR ERRTYP ;UNKNOWN ERROR
537 *****
538 HRDERS,BEGIN,NULL ;CARRIER TRANS + RING + OVERRUN
539 *****
540 BTB #BIT13,(R1) ;RING INDICATOR SET?
541 BCC 4S ;BRANCH IF NOT
542 MSGNS,BEGIN,RING ;ASCII MESSAGE CALL WITH COMMON HEADER
543 MOV #1,R1 ;SETUP TO DROP LINE
544 3S: ASL R1
545 DEC R2 ;SHFT BIT TO ALLIGN WITH INDICATOR IN DVICE
546 BPL 3S
547 BIC R1,DVICE ;DROP THE LINE
548 JMP ENPS ;SKIP REST OF CHECKING SINCE RING INDICATOR
549 ;SET WILL CAUSE ALL COUNTS TO BE BAD
550 4S: TSTR (R1) ;POINT TO LO BYTE OF CSR
551 BMI 5S ;BR IF DUNE WAS SET
552 JSR PC,RCVERR ;SETUP FOR ERROR REPORT
553 MOV #1,ERRTYP ;LEGAL INTERRUPT
554 *****
555 HRDERS,BEGIN,NULL ;RECEIVER FALSE INTERRUPT
556 *****
557 INCB RBUF(R2) ;BUMP EXPECTED DATA
558 TST R0 ;HARDWARE ERRORS?
559 BCC 6S ;DO NOT REPORT DATA ERRORS THEN.
560 BIC #340,RBUF(R2) ;MASK OFF BITS <7:5> TO CHECK ONLY
561 BIC #340,(R1) ;FIRE BITS IN
562 CMPEB RBUF(R2),J(R1) ;DID RCVD DATA CHECK OK?
563 BEQ 6S ;BR IF YES
564 JSR PC,DATBAD ;GO REPORT DATA ERROR
565 6S: CMP (R1)+,(R1)+ ;POINT R1 TO NEXT TABLE ENTRY
566 DEC RCNT ;ALL CHARS RECEIVED CHECKED?
567 BNE 2S ;NO- GO CHECK NEXT ENTRY
568
569 ;THIS ROUTINE REPORTS ANY LINE RECEIVING AN INCORRECT NUMBER OF INTERRUPTS
570 CKLINS: MOV ACTDEV,R1 ;GET ACTIVE DEVICE COUNT
571

```

```

572 3S: MOV DEVTAB(R1),R2 ;GET ACTIVE DEVICE LINE NO.
573 CMPEB RCNT(R2),DCNT(R2) ;CORRECT NUMBER OF RCVR INTERRUPTS?
574 BCC 4S ;BR IF YES
575 JSR PC,BADR ;GO REPORT BAD RCVR
576 CMPEB TCNT(R2),DCNT(R2) ;CORRECT NUMBER OF XMTR INTERRUPTS?
577 BEQ 5S ;BR IF YES
578 JSR PC,BADT ;GO REPORT BAD XMTR
579 5S: DEC R1 ;COUNT ONE GOV CHECKED
580 BPL 3S ;BR TIL ALL CHECKED
581 JMP ENPS ;GO CHECK FOR END OF PASS
582
583 RING: MRING
584 001450 001454 -
585 001452 177777 -1
586
587 MRING: .ASCIZ /%RING SET- BAD LINF DROPPED%/
588 001454 051045 047111 020107
589 001462 042523 026524 041040
590 001470 042101 046040 047111
591 001476 020105 051104 050117
592 001504 022520 022504 000
593 .EVEN
594
595 ;ROUTINE TO REPORT BAD LINES (TOO MANY OR TOO FEW INTERRUPTS)
596 BADR: JSR PC,GETADR ;GO BUILD CSR ADDRESS
597 MOV R3,CSRA ;SAVE CSR ADDRESS
598 MOVB DCNT(R2),ACSR ;CHARACTERS XMTD
599 MOVB RCNT(R2),ASTAT ;# OF RCVR INTERRUPTS
600 MOV #14,ERRTYP ;WRONG # OF INTERRUPTS
601 *****
602 HRDERS,BEGIN,NULL ;INCORRECT NUMBER OF RCVR INTERRUPTS
603 *****
604 ;NOTE THAT CSRC VALUE IS # OF CHARACTERS
605 ;TRANSMITTED, AND STATC VALUE IS # OF
606 ;RECEIVER INTERRUPTS
607
608 RTS PC ;RETURN TO CALLER
609
610 BADT: JSR PC,GETADR ;GO BUILD CSR ADDRESS
611 CMP (R3)+,(R3)+ ;MAKE IT A XMTR CSR ADDRESS
612 MOV R3,CSRA ;SAVE CSR ADDRESS
613 MOVB DCNT(R2),ACSR ;CHARACTERS XMITTED
614 MOVB TCNT(R2),ASTAT ;# OF XMTR INTERRUPTS
615 MOV #14,ERRTYP ;WRONG # OF INTERRUPTS
616 *****
617 HRDERS,BEGIN,NULL ;INCORRECT NUMBER OF XMTR INTERRUPTS
618 *****
619 ;NOTE THAT CSRC VALUE IS # OF CHARACTERS
620 ;TRANSMITTED, AND STATC VALUE IS # OF
621 ;TRANSMITTER INTERRUPTS
622
623 RTS PC ;RETURN TO CALLER
624
625 GETADR: MOV R2,R3 ;GET LINE NO.
626 ASL R2 ;BUILD CSR ADDRESS
627

```

628 001624* 006303
629 001626* 006303
630 001630* 066703 176152
631 001634* 000207
632
633
634 001636* 004767 177756
635 001648* 010367 176232
636 001648* 110167 000002 176234
637 001654* 005721
638 001656* 010167 176222
639 001664* 005741
640 001664* 012705 002524*
641 001670* 060205
642 001672* 111567 176210
643 001676* 010567 176200
644
645 001702* 104404 000000*
646
647 001706* 000207
648
649
650 001710* 005200
651 001716* 004767 177702
652 001722* 011167 176154
653 001722* 011167 176154
654 001726* 000207
655
656
657 001730*
658 001730* 104413 000000*
659
660 001734* 000167 176474
661
662
663 001740* 012700 002524*
664 001744* 012701 002504*
665 001750* 112021
666 001752* 022700 002544*
667 001756* 001374
668 001760* 000167 176454
669
670
671
672 001764* 000200
673 002364* 000010
674 002404* 000010
675 002424* 000010
676
677 002444* 000020
678
679 002504* 000010
680 002524* 000010
681
682
683

```

ASL R3
ASL R3
ADD ADDR,R3
RTS PC ;RETURN TO CALLER

;ROUTINE TO REPORT RCVR DATA COMPARE ERRORS
DATPAD: JSR PC,GETADR ;GO BUILD CSR ADDRESS
MOV R5,CSRA ;SAVE CSR ADDRESS
MOV (R1),AWAS ;SAVE BAD DATA
TST (R1)+ ;GENERATE RCVR DATA ADDRESS
MOV R1,ASADR ;SAVE ADDRESS OF BAD DATA
TST - (R1) ;RESET R1
MOV #RBUF,R5 ;GENERATE ADDRESS OF GOOD DATA
ADD R2,R5
MOV (R5),ASB ;SAVE GOOD DATA
MOV R5,SBADR ;SAVE ADDRESS OF GOOD DATA
;*****2******
DATERS,BEGIN ;DATA ERROR!!!
;*****2******
RTS PC ;RETURN TO CALLER

;ROUTINE TO SETUP FOR RECEIVER ERROR PRINTOUTS
RCVERR: INC R0 ;INDICATE HARDWARE ERROR-
JSR PC,GETADR ;GO BUILD CSR ADDRESS
MOV R5,CSRA ;STUFF IT IN CSRA
MOV (R1),ACSR ;GET CONTENTS IN ACSR
RTS PC ;RETURN TO CALLER

;THIS ROUTINE CHECKS FOR AND REPORTS END OF PASS
ENPS: ENDIRS,BEGIN ;SIGNAL END OF ITERATION
JMP RSTRT ;MONITOR SHALL TEST END OF PASS

;THIS ROUTINE RESTARTS EACH 64 CHAR XFR SEQUENCE
RESYNC: MOV #RBUF,R0 ;RESYNC DATA FOR NEXT PASS
MOV #R1,R1
1S: MOV (R0)+,(R1)+
CMP #RBUF+20,R0 ;DONE 16 BYTES?
BNE STUP1 ;BR IF NOT
JMP STUP1 ;RESUME.

;TABLES AND BUFFERS
RSTAB: .BLKW 128. ;128 WORD(64 ENTRIES)RCVR STATUS TABLE
RCNT: .BLKW 8. ;RCVR INTERRUPT COUNTERS
TCNT: .BLKW 8. ;XMTR INTERRUPT COUNTERS
DCNT: .BLKW 8. ;CHARACTER COUNTERS
TQ: .BLKW 16. ;16 WORD XMTR FIFO QUEUE
XBUF: .BLKW 8. ;16 BYTE XMTR DATA BUFFERS
RBUF: .BLKW 8. ;16 BYTE RCVR DATA BUFFERS

;POINTERS, CONSTANTS, AND VARIABLES

```

684 002544* 000000
685 002546* 000000
686
687 002550* 000000
688 002552* 000000
689 002554* 000000
690 002556* 000000
691 002560* 000000
692
693
694
695 002562* 012700 002504*
696 002566* 005020 002544*
697 002570* 012700 002544*
698 002574* 001374
699 002576* 000207
700
701
702 002600* 012700 001764*
703 002604* 005020
704 002606* 022700 002504*
705 002612* 001374
706 002614* 000207
707
708
709
710
711 002616* 005000
712 002620* 005100
713 002622* 005001
714 002624* 005101
715 002626* 016702 000054
716 002632* 005200
717 002634* 022700 000020
718 002640* 001003
719 002642* 010167 000036
720 002646* 000207
721 002650* 006202
722 002652* 103367
723 002654* 005201
724 002656* 110061 002664*
725 002662* 000763
726
727 002664* 000010
728 002704* 000000
729 002706* 000000
730
731
732
733 002710* 004567 176134
734 002714* 000000
735 002716* 000000
736 002720* 004567 175722
737 002724* 000000
738 002726* 000000
739 002730* 004567 176114

```

COUNT: OPEN ;END OF PASS COUNTER
TCXNT: OPEN ;TX TOTAL INTERRUPTS COUNTER (HIGH BYTE)-
;TOTAL CHARACTERS TRANSMITTED (LOW BYTE)
HCXNT: OPEN ;RX TOTAL INTERRUPTS COUNTER
CQTR: OPEN ;BREAK LUP COUNTER
SVPTR: OPEN ;TEMP STORAGE FOR RSTAB POINTER
QPTR1: OPEN ;XMTR FIFO QUEUE POINTER - LOAD
QPTR2: OPEN ;XMTR FIFO QUEUE POINTER - UNLOAD

;SUBROUTINE TO CLEAR DATA BUFFERS AT BEGINING OF EACH NEW PASS
CLRBUF: MOV #RBUF,R0 ;SET UP R0 TO POINT TO BEGINING
1S: MOV (R0)+,R0 ;CLEAR A WORD
CMP #RBUF+20,R0 ;END OF RCVR BUFFER?
BNE 1S ;BR IF NOT
RTS PC ;RETURN TO CALLER

;SUBROUTINE TO CLEAR TABLES AND QUEUES
CLRTAB: MOV #RSTAB,R0 ;SET UP R0 TO POINT TO BEGINING
1S: CLR (R0)+ ;CLEAR A WORD
CMP #TQ+40,R0 ;END?
BNE 1S ;BR IF NOT
RTS PC ;RETURN TO CALLER

;THIS ROUTINE SETS UP AN ACTIVE DEVICE TABLE TO REMEMBER HOW MANY
;AND WHICH LINES WERE ACTIVE DURING TEST - IT IS USED DURING THE
;ERROR CHECKING ROUTINES FOR VARIOUS PURPOSES
DTAB: CLR R0 ;SET UP R0 AS TOTAL LINE COUNTER
COM R0 ;INITIALLY SET TO MINUS ONE
CLR R1 ;SET UP R1 AS ACTIVE LINE COUNTER
COM R1 ;INITIALLY SET TO MINUS ONE
1S: MOV DVICE,R2 ;GET DEVICE SELECTION PARAMETER
INC R0 ;COUNT ONE DEVICE
CMP #16,R0 ;16 LINES CHECKED?
BNE 2S ;BR IF NOT
MOV R1,ACTDEV ;SAVE THE COUNT OF ACTIVE LINES
RTS PC ;RETURN TO CALLER
2S: ASR R2 ;SHIFT SELECT BIT INTO "C"
BCC 1S ;BR IF NOT SELECTED
INC R1 ;COUNT ACTIVE LINE
MOV R0,DEVTAB(R1) ;STORE ACTIVE LINE NO. IN THE TABLE
BR 1S ;GO TEST NEXT LINE

DEVTAB: .BLKW 8. ;16 BYTE ACTIVE DEVICE TABLE
ACTDEV: OPEN ;STORES COUNT OF NO. OF ACTIVE LINES MINUS ONE
DVICE: OPEN ;DEVICE SELECTION INDICATOR

;JSR LINK TABLE CONSISTING OF 32 JSR'S (16 RCVR AND 16 XMTR) THAT
;LINK THE INTERRUPTS TO THE COMMON SERVICE ROUTINES
JSRTAB: JSR R5,RINT ;RECEIVER LINK FOR LINE 0
0 ;SET UP WITH RCVR CSR ADDRESS
0 ;LINE NUMBER
JSR R5,TINT ;XMTR LINK FOR LINE 0
0 ;SET UP WITH XMTR CSR ADDRESS
0 ;LINE NUMBER
JSR R5,RINT ;LINK FOR LINE 1

```

740	002734	000000	0			
741	002730	000000	1	JSR	R5,TINT	
743	002744	000000	0			
744	002746	000001	1	JSR	R5,RINT	;LINK FOR LINE 2
745	002754	000000	0			
747	002756	000002	2	JSR	R5,TINT	
748	002760	004567	0			
749	002764	000000	0			
750	002766	000000	0			
751	002770	004567	0	JSR	R5,RINT	;LINK FOR LINE 3
752	002774	000000	0			
753	002776	000003	3	JSR	R5,TINT	
754	003000	004567	0			
755	003004	000000	0			
756	003006	000003	3	JSR	R5,RINT	;LINK FOR LINE 4
757	003010	004567	0			
758	003014	000000	0			
759	003016	000004	4	JSR	R5,TINT	
760	003020	004567	0			
761	003024	000000	0			
762	003026	000004	4	JSR	R5,RINT	;LINK FOR LINE 5
763	003030	004567	0			
764	003034	000000	0			
765	003036	000005	5	JSR	R5,TINT	
766	003040	004567	0			
767	003044	000000	0			
768	003046	000005	5	JSR	R5,RINT	;LINK FOR LINE 6
769	003050	004567	0			
770	003054	000000	0			
771	003056	000006	6	JSR	R5,TINT	
772	003060	004567	0			
773	003064	000000	0			
774	003066	000006	6	JSR	R5,RINT	;LINK FOR LINE 7
775	003070	004567	0			
776	003074	000000	0			
777	003076	000007	7	JSR	R5,TINT	
778	003078	004567	0			
779	003104	000000	0			
780	003106	000007	7	JSR	R5,RINT	;LINK FOR LINE 10
781	003110	004567	0			
782	003114	000000	0			
783	003116	000010	10	JSR	R5,TINT	
784	003120	004567	0			
785	003124	000000	0			
786	003126	000010	10	JSR	R5,RINT	;LINK FOR LINE 11
787	003130	004567	0			
788	003134	000000	0			
789	003136	000011	11	JSR	R5,TINT	
790	003140	000000	0			
791	003144	000000	0			
792	003146	000011	11	JSR	R5,RINT	;LINK FOR LINE 12
793	003150	004567	0			
794	003154	000000	0			
795	003156	000012	12			

796	003160	004567	175462	JSR	R5,TINT	
797	003164	000000		0		
798	003166	000012		12		
799	003170	004567	175654	JSR	R5,RINT	;LINK FOR LINE 13
800	003174	000000		0		
801	003176	000013		13		
802	003200	004567	175442	JSR	R5,TINT	
803	003204	000000		0		
804	003206	000013		13		
805	003210	004567	175634	JSR	R5,RINT	;LINK FOR LINE 14
806	003214	000000		0		
807	003216	000014		14		
808	003220	004567	175422	JSR	R5,TINT	
809	003224	000000		0		
810	003226	000014		14		
811	003230	004567	175614	JSR	R5,RINT	;LINK FOR LINE 15
812	003234	000000		0		
813	003236	000015		15		
814	003240	004567	175402	JSR	R5,TINT	
815	003244	000000		0		
816	003246	000015		15		
817	003250	004567	175574	JSR	R5,RINT	;LINK FOR LINE 16
818	003254	000000		0		
819	003256	000016		16		
820	003260	004567	175362	JSR	R5,TINT	
821	003264	000000		0		
822	003266	000016		16		
823	003270	004567	175554	JSR	R5,RINT	;LINK FOR LINE 17
824	003274	000000		0		
825	003276	000017		17		
826	003300	004567	175342	JSR	R5,TINT	
827	003304	000000		0		
828	003306	000017		17		
829						
830		000001				

.RND

SRADR	000102R	339#	643*																
SPTCSR	000344R	379#	386#																
SOPCNT	000042R	328#																	
SOPERS	104406	328#																	
SOPPAS	000046R	324#																	
SPOINT	000032R	318#																	
SPSTZ	= 000040	311#																	
SR1	000016R	311#	351																
SR2	000020R	312#																	
SR3	000022R	313#																	
SR4	000024R	314#																	
START	000224R	314#	360#																
STAT	000026R	316#																	
STUP1	000440R	409#	668																
SVPTR	002554R	413#	498	505*	689#														
SVR0	000062R	331#																	
SVR1	000064R	332#																	
SVR2	000066R	333#																	
SVR3	000070R	334#																	
SVR4	000072R	335#																	
SVR5	000074R	336#																	
SVR6	000076R	337#																	
SYSCNT	000052R	326#																	
TCNT	002404R	471#	576	614	674#														
TINT	000646R	451#	736	742	748	754	760	766	772	778	784	790	796	802					
		808	814	820	826														
		414	415	453	455	465	467	677#	704										
TS	002444R	414#																	
TSPDFD	= 000022	358#																	
TSEV	000706R	458#	463#																
TXCNT	002546R	411#	424*	435	470*	474	478*	685#											
VPCYDR	000010R	307#	363																
WISADR	000104R	341#	638*																
WDFP	000116R	348#	361*																
WDTN	000114R	347#	360*																
XHUP	002504R	423#	476*	477	664	679#	695												
XFLAG	= 000005R	305#																	
	003310R	544	592#	672#	673#	674#	675#	677#	679#	680#	727#								

. ARS. 000000 000
 003310 001

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

XDCAGO, XDCAGO/SOL/CRF:SYM=DDXCOM,XDCAGO
 RUN-TIME: 17.3 SECONDS
 RUN-TIME RATIO: 15/4=3.1
 CORE USED: 7K (13 PAGES)