

IDENTIFICATION

PRODUCT CODE: MAINDEC-15-D7BC-D-(D)
PRODUCT NAME: PDP-15 BASIC EXERCISER
DATE CREATED: June 18, 1970
MAINTAINER: DIAGNOSTICS GROUP
AUTHOR: JOHN W. RICHARDSON

29

1. ABSTRACT

The PDP-15 Basic Exerciser is designed to exercise the CP, core memory and models 33 or 35 teleprinters with the program interrupt facility enabled. The program will also test the real time clock, high speed reader and high speed punch, if these options are present on the PDP-15 being used. The operator must specify the I/O configuration with the A C switches as described in section 5.1.

The Basic Exerciser consists of a condensed version of the PDP-15 Instruction Tests. These tests run continuously, and are interrupted at a device rate by the I/O device (s). The real time clock, if used, will interrupt and suspend all operations at random time intervals. The instruction test or I/O device resumes operation after the clock interrupt has been serviced.

Ten A C S functions (described in sect. 5.1) are provided to enable the operator to (1) inhibit the instruction and memory tests and run the I/O device (s) alone; (2) inhibit program interrupts and run the instruction tests alone; (3) loop continuously on the adder test; (4) inhibit program relocation; (5) inhibit the real time clock, but continue testing with program interrupt and all other devices enabled; (6) run the instruction tests and the clock and punch with the read and print sequence inhibited; (7) run the reader, real time clock and instruction tests with the punch and Teletype inhibited; (8) run the read and print sequence, real time clock, instruction tests with the punch inhibited; (9) run the Teletype and instruction tests with the punch and reader inhibited. Items 6, 7 and 8 above, are applicable only when the high speed reader and punch option is installed.

2. REQUIREMENTS

2.1 Equipment

A PDP-15 with at least 8K of core memory.

2.2 Storage

The program requires the entire 8K of core memory to perform all tests. The program initially resides in memory locations 00000 to 7757 (octal). When the program is relocated to the high order 4K field, it occupies locations 10022 to 17757 (octal).

3. LOADING PROCEDURE

The tape supplied is in the .ABS format.

- a. Set the ADDRESS switches to 17700.
- b. Place all AC switches on a 0; the BANK MODE switch on.
- c. Place the tape in the reader.
- d. Press I/O RESET, and then READ-IN.

4. STARTING PROCEDURE

4.1 Starting Addresses

200, or 10200 if the program is currently in the upper 4K field.

4.1.1 Restarting Addresses

32, or 10032 if the program is currently in the upper 4K field.

4.2 Operator Action Without High Speed Reader and Punch

- a. Set the ADDRESS switches to 00200.
- b. Place ACS 9 on a 1 to indicate no high speed reader and punch.
- c. If a real time clock is not installed place ACS 5 on a 1. Otherwise, leave on a 0.
- d. Press I/O RESET, and then START.
- e. The program will run until an error halt occurs, or manually stopped by the operator.

4.2.1 Operator Action With High Speed Reader and Punch

- a. Set the ADDRESS switches to 00200.
- b. Place all ACS on a 0.
- c. If a real time clock is not installed place ACS 5 on a 1. Otherwise, leave on a 0.
- d. Press I/O RESET, and then START.
- e. Approximately 3 1/2 feet of leader will be punched. This leader is blank except for one frame, which has all channels punched.

- f. Place the punched frame directly over the high speed reader drive sprocket, and arrange the tape between the reader and punch for minimum binding.
- g. Press CONTINUE.
- h. The program will run until an error halt occurs, or manually stopped by the operator.

4.2.2 Restarting Procedure

- a. Set the ADDRESS switches to 00032.
- b. Set ACS 5 and 9 according to the I/O configuration being used. Other AC switches may be set at this point. See section 5.1.
- c. If the high speed reader and punch are used, make sure there is tape in the reader. The tape does not have to be blank leader when restarting.
- d. Press I/O RESET, and then START.
- e. The program will run until an error halt occurs, or manually stopped by the operator.

The program may also be restarted from 200, if new leader is desired.

5. OPERATIONAL SWITCH SETTINGS

The ACS functions provided are listed in section 5.1. To make changes in the ACS settings, the program must be stopped by the operator before the changes are made. The program must then be restarted from address 32 (or 10032). The program may not acknowledge the new ACS settings if the above procedure is not followed.

5.1 ACS Functions

<u>ACS</u>	<u>Function</u>
0 (1)	Run only the I/O device (s). Program interrupt will be enabled.
1 (1)	Inhibit the I/O device (s). Program interrupt is disabled. The real-time clock is on. The complete instruction test will be performed.
2 (1)	Loop continuously on the "add random pairs" test. The I/O devices and program interrupt will be enabled unless specified otherwise by an ACS.

5.1 Continued

<u>ACS</u>	<u>Function</u>
4 (1)	Inhibit program relocation. Unless otherwise specified, the program will run in a normal way, but will not relocate from its current 4K field location to the opposite field after completing the instruction tests.
5 (1)	Inhibit clock. Unless otherwise specified, program action is normal except that the clock should always be off.
6 (1)*	Inhibit the reader and TTY. The punch will run continuously. Tape must be in the reader to prevent the no-tape indicator from being set. Program action is normal unless otherwise specified.
7 (1)*	Inhibit the punch and TTY. The reader will run continuously. A loop or fan-fold tape with any data may be used. Program action is normal unless otherwise specified.
8 (1)*	Inhibit the punch. The reader will read 52 characters at full speed and then halt. The TTY will then print the 52 characters read. Any tape loop or fan-fold tape may be used. Program action is normal unless otherwise specified.
9 (1)	No high speed reader and punch installed.
(0)	The high speed reader and punch option is present.

With ACS 9 on a 1 switches 6, 7 and 8 are ignored.

If the reader and punch option is installed, the I/O devices may be controlled with several combinations of ACS 6, 7 and 8. If ACS 7 and 8 are set to ones, the reader will run continuously, as if ACS 7 only were on a 1. If ACS 6 and 7 or 6 and 8 are set to ones, all devices will be inhibited. Program interrupt and the real time clock (if installed) will be enabled unless otherwise specified.

*Applies only if the high speed reader/punch option is installed.

5.2 Subroutine Abstracts

The PDP-15 Basic Exerciser may be thought of as three separate programs, i.e., the instruction tests; control of the I/O device (s), and operation of the real time clock if installed. The instruction tests will be interrupted by the I/O device (s) at the device rate. The real time clock will randomly interrupt any of the above operations at a rate determined by the program. After each clock interrupt, the clock is re-initialized with a new number obtained by a random number generator. The clock interrupts take first priority, followed by the Teletype, reader and punch.

5.2.1 Instruction Tests

The instruction test portion of the Basic Exerciser performs tests on all operate group and memory reference instructions. The individual instructions are looped a random number of times before proceeding to the next test. The maximum number of loops made on any one test is 32,767.

The adder is tested using two different methods. The first performs bit by bit tests on the adder using the ADD instruction. Besides checking for correct results after an addition, the link is tested during overflow and no overflow conditions.

The second method, the "Add Random Pairs" test, tests the adder using one pair of random numbers (A and B) and their 1's complement values (-A and -B), and the ADD instruction. These four values are added in various combinations, the results of which are compared against precalculated results. The precalculated results are obtained by adding the two pairs together using the TAD instruction. Four additions are made, the results of which are used in the test. The link is tested after each addition. If it is a 1, a 1 is added to the result to simulate an end-around-carry.

The numbers added and their sums are indicated in the listing using the following symbols:

-B+(-A)	=	SUMNEG
A+B	=	SUMPOS
B-A	=	BMASUM
A-B	=	AMBSUM

The values of A, -A, B and -B plus their sums are used to test the combinations of ADD's shown below.

<u>ADD</u>	<u>SUM SHOULD EQUAL</u>
A + B	SUMPOS
-B + A	AMBSUM
-B + (-A)	SUMNEG
B - A	BMASUM

5.2.1 Continued

<u>ADD</u>	<u>SUM SHOULD EQUAL</u>
(A + B) - A	BPOS (B)
(B - A) - B	ANEG (-A)
(-A-B) + A	BNEG (-B)
(A - B) + B	APOS (A)
<u>77777</u> + A	APOS
A + B - A	BPOS
A + B - A - A	BMASUM (B - A)
A + B - A - A - B	ANEG
A + B - A - A - B - B	SUMNEG (-A -B)
A + B - A - A - B - B + A	BNEG
A + B - A - A - B - B + A + A	AMBSUM (-B + A)
A + B - A - A - B - B + A + A + B	APOS

After completing one pass of the above tests, a second pass is made on the same tests. The second pass makes all "B" constants "A", and all "A" constants "B" before repeating.

Immediately following the second pass, one random number and its 1s complement is obtained and saved in APOS and ANEG, respectively. Bit 0 of APOS is tested for equaling 0 or 1. If the value is 1, the bit remains unchanged, and the respective bit in the complement number is changed to equal a 1. The two numbers are then added together, the sum of which should equal all 0's except for bit 0. If the ADD is successful, the program continues testing all other bit positions in the same manner.

Example: (Bit 0 altered)

<u>Step</u>	<u>APOS Value</u>	<u>ANEG Value</u>
1	577776	200001
2	577776	600001 (bit 0 altered)
3	Add together. Result should = altered bit.	

```

+ 101 111 111 111 111 110
+ 110 000 000 000 000 001
+ 011 111 111 111 111 111
+ 1 (end around carry)
-----
100 000 000 000 000 000

```

The sum equals the altered bit position.

After completing the adder tests, the remaining memory reference instructions

5.2.1 Continued

are tested and the program relocates the entire Basic Exerciser to the opposite 4K field. All memory reference instructions and memory locations used for testing are adjusted accordingly. All locations within the program which reference any memory location between 0 and 21 are not adjusted. These locations are used during program interrupts, auto-indexing tests, etc., and must not be altered. Program interrupt is disabled while relocation is taking place.

After relocation of the program is completed, the exerciser is automatically restarted at location 112 (or 10112). This location is tagged SEQUEN. The operator is able to determine the location of the program by observing the PC.

The Teletype BELL will ring once for each completed pass of the program. One pass is defined as the program performing all tests from each 4K field, and then relocating back to the field in which the program was first initiated.

When operating the Basic Exerciser with program interrupt inhibited (ACS 1 on a 1), the message "COMPLETE" will be printed after five complete passes of the program. This message is printed after ten passes when ACS 4 (inhibit relocation) and ACS 1 are on a 1. This feature is included as a means to determine the number of successful passes completed by the program if it is to be run for extended periods of time.

5.2.2 Punch, Read, Print Sequence

This section applies only to those PDP-15's with the high speed reader and punch option installed. The instruction tests will be interrupted, at a device rate, by the punch, reader, or Teletype. The data punched consists of the alphabet characters, followed by numbers 0 through 9, with a space character being punched between each letter or numeral character. The reader will read the tape at punch speed, storing away any punched character. Frames of all 0's are ignored. The punch and read sequence consists of 52 ASCII characters punched, read and stored away in an input buffer (tagged TTBUFA). After reading the 52nd character, the contents of TTBUFA are transferred directly to another 52 - location buffer tagged TTBUFB. This second buffer is provided to enable the operator to stop the program and compare the contents of either buffer A or buffer B with the punched data on tape. Punch and read operation is halted after the 52nd character is read and stored. The contents of TTBUFB are then printed on the Teletype. The punch and read sequence continues immediately after the 52nd character is printed. The data punched and read should appear on the Teletype as the example below.

```
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9
```


The punch and read sequence generates 72 characters altogether, even though only 52 are punched, read and printed at one time. The alphabet and numbers sets with a space between each character enables a full line to be printed. The spacing also enables the operator to more easily detect a misprinted character. Each group of 72 characters is separated by 8 blank frames. The group which is positioned in the reader is the current line being printed. A carriage return and a line feed is punched at the end of each group. The program will punch 6 extra blank frames between two groups, approximately every fourteenth group, to enable the slack between reader and punch to remain constant.

5.2.3 Use of the Real Time Clock

This section applies only to those PDP-15's with the real time clock option installed. The instruction and memory tests, and the punch, read and print sequence are both interrupted randomly by the real time clock. When a clock interrupt occurs, all other operations are halted until the clock interrupt has been serviced. Immediately after the clock interrupt is granted, it is reset to a new random value. This value is chosen by the program to ensure that the clock interrupts no sooner than 2 seconds, nor later than 9 seconds. The clock is again enabled after being reset to a new value, and the instruction test or read, punch and print sequence is allowed to continue from the point of interrupt.

At times, the Basic Exerciser may appear to be caught in a loop after a clock interrupt occurs. The console indicators will show the clock and PIE as being disabled, and the punch, read and print sequence will be halted for several seconds. The program during this time is attempting to generate a number for the clock which falls within the 2 to 9 second limit. All operations will be resumed as soon as a suitable random value is found.

The operator may disable the clock interrupts by restarting from location 32 with ACS 5 on a 1.

5.2.4 Interrupt Service Routine

Program interrupts by the clock, punch, reader or Teletype are all serviced by a common routine. A common routine for reentering the instruction test is also used.

Locations 0 through 6 are used to save the contents of the AC and PC immediately after an interrupt occurs. The contents of the AC are stored in the location tagged SAVAC. The contents of the link and PC are stored in the location tagged RJMP. The program then enters a routine which determines which of the four devices interrupted the program. This routine is tagged SRVINT. SRVINT will test for device flags in the

following order: clock, Teletype, no-tape flags, reader, punch. The first device flag found to be set indicates the device which must be reinitiated by the program.

Immediately after servicing the proper device, a routine is entered which will restore the contents of the link and AC at the time of the program interrupt. The routine is tagged RTNIT. RTNIT first restores the AC (from SAVAC); restores the link (by testing bit 0 of R JMP); enable program interrupt; and then returns to the instruction test by a JMP indirect on the contents of R JMP.

The operator may disable program interrupts by restarting from location 32 with ACS 1 on a 1.

5.3 Program and Operator Action

See Sections 4.2 and 5.2.

6. ERRORS

6.1 Error Halts and Description

Reference the program listing for all error halts.

All error halts are tagged EXXX, and are commented to aid debugging. Each test is self-contained, any may be looped. See Section 6.2.1 for looping instructions.

Unless a solution is obvious from following the listing, the proper MAINDEC diagnostic for the device in error should be run. This should be necessary mainly when errors are caused by one of the I/O devices.

Incorrect operation of the real time clock will appear as clock interrupts occurring sooner than 2 seconds apart, or greater than 9 seconds, or possibly no clock interrupts will occur.

Printing of incorrect data may be caused by the data being incorrectly punched, read or printed. Storage registers, and their locations in the program, which the punch, read, print sequence use are listed below.

<u>Tag</u>	<u>Function</u>
SAVAC	Saves contents of AC after a program interrupt.
R JMP	Saves contents of PC and link after a program interrupt.

6.1

Continued

<u>Tag</u>	<u>Function</u>
WORK	Bit 1 if set indicates TTY is in use.
GOPNCH	Contains contents of PC at exit from punch routine.
SETCLK	Routine which sets a random value in clock register 7 when program interrupt is disabled.
CLKSET	Same function as SETCLK, but is used only after a clock interrupt.
TTOUT	Location pointer for TTBUFB when printing.
TTIN	Location pointer for TTBUFA when reading with a high speed reader.
TTBUFA	Storage buffer for characters read with a high speed reader.
TTBUFB	Storage for characters to be printed. Contents should equal TTBUFA.
STORE	Contains character punched.
SETTY	Routine which is entered after 52 characters have been punched and read. Sets up TTBUFB before printing.
GENRAN	Random number generator used when PI is disabled.
RANGEN	Same as GENRAN, but used only after an interrupt.

When using the teleprinter alone (ACS 9 on a 1) the characters printed are generated by the routine tagged PNXT on the program listing. After generating one character, the routine will either immediately print it (ACS 9 on a 1), or punch it with the high speed punch (ACS 9 on a 0).

When operating with the high speed reader and punch (ACS 9 on a 0) the data punched is in ASCII mode, and one printed line is indicated on the paper tape by 8 blank frames separating each line. The punched data starts with character A (301) and ends with a line feed (212). A space character (240) is punched between all alphabet and number characters.

When data is incorrectly printed, stop the program during print-out. This will enable TTBUFA and TTBUFB to be examined before the contents of either are changed. The contents of TTBUFA will be changed as soon as reading begins.

The line of punched characters in the reader is the line currently being printed. The operator may inspect the tape for an incorrect character punched. If it appears correctly on the tape, it may have been read or printed incorrectly. The characters read are stored in a 52-word buffer beginning at location tagged TTBUFA. The characters being printed are stored in a 52-word buffer beginning at location tagged TTBUFB. If the program was stopped during printing, these two buffers should contain exactly the same information. The first character read or printed is stored in the first location of either buffer. One character is stored per location. If the data was read incorrectly, the contents of TTBUFA will not equal the last 52 characters on the tape. If the data on tape, and in TTBUFA and TTBUFB are equal, the teleprinter may be at fault.

6.2

Error Recovery

Press CONTINUE to receive further error halts or to continue testing, as indicated by the listing.

Recovery from error halts in the Add Random Pairs test is accomplished by pressing CONTINUE one or more times, depending on the type of error encountered. Pressing CONTINUE after a halt due to an incorrect sum will result in a second halt. The AC will equal the incorrect sum at the first halt, and the sum used for comparison at the second halt. If the error halt is the result of a LINK error, the next test in sequence will be executed.

Looping on Individual Tests

Looping on individual tests, except for the interrupt routines, Add Random Pairs test and Memory test, is accomplished by placing a JMP instruction in the first location of the test to be looped. Restart the program at location 32, if program interrupt is to be enabled. Restart at the first location of the test to be looped, if interrupts are not wanted.

The complete series of tests for any one instruction may be looped by placing a NOP in the location which contains ISZ WORK3. This instruction appears at the end of each series of tests for each instruction. Restart at location 32, or at the beginning of the test to be looped.

Looping on Add Random Pairs

The complete series of tests may be looped by restarting from location 32 with ACS 2 on a 1.

The individual tests may be looped by changing the LAW instruction, appearing after each test, to a JMP. For example, to loop on (A-B) + B = A (tagged AMBPBT), change the LAW AMBPBT instruction to JMP AMBPBT. Restart from location 32, or AMBPBT.

Error Print-outs

The program continually tests for reader or punch no tape indicators being set. When either indicator is set the message "R NO TAPE", or "P NO TAPE" will be printed. The program continues on in sequence after either print-out.

7. OPERATING RESTRICTIONS

All MAINDEC diagnostics which apply to the PDP-15 configuration being used should be run before attempting to run this program.

8. MISCELLANEOUS

8.1 Execution Time

Approximately 2 minutes are required to execute all tests for one 4K field.

9. PROGRAM DESCRIPTION

The Basic Exerciser performs tests on all memory reference and operate instructions.

During normal operation, i.e., with ACS 5 and 9 set for the I/O configuration in use, and all other ACS on a 0, the program will exercise the I/O device (s) and program interrupt while the instruction test portion is running. The PC indicators will change according to the portion of the instruction test being executed.

When the I/O device (s) is operated with the instruction test inhibited (ACS 0 on a 1) the MI will indicate a constant 600151 (JMP 151). On the listing this is written as JMP. . at location 151. Program interrupt is enabled at location 150, and all device interrupts will occur immediately after the execution of the JMP instruction. The interrupts are handled in the same manner as if the instruction test were operating; the only difference being that the interrupt service routine (RTNIT) always returns to location 150 after reinitiating the device which caused the interrupt, instead of returning to the instruction test.

If no errors occur, the Basic Exerciser will run until stopped by the operator.

10. LISTINGS

/IOT DEFINITIONS

/

700001	CLSF=700001
700004	CLOF=700004
700044	CLON=700044

/

700101	RSF=700101
700102	RCF=700102
700112	RRB=700112
700104	RSA=700104
700144	RSB=700144

/

700201	PSF=700201
700202	PCF=700202
700204	PSA=700204
700244	PSB=700244

/

700301	KSF=700301
700312	KRB=700312

/

700401	TSF=700401
700402	TCF=700402
700406	TLS=700406
740030	IAC=740030
742030	SWHA=742030

/

```

        .TITLE BX8K
/PDP-15 BASIC EXERCISER FOR 8K OR MORE
/
/COPYRIGHT 1969, DIGITAL EQUIPMENT CORP., MAYNARD, MASS.
,ABS

```

```

740000  NOP1=NOP
740000  NOP2=NOP
740000  NOP3=NOP
740040  HALT=HLT

```

```

/
        ,LOC 22

```

00022

```

00022 750004  /BEGIN  LAS
00023 507345  AND K3400  /CHECK FOR SWITCHES 7,8 OR 9
00024 740200  SZA
00025 600032  JMP ,+5
00026 107217  JMS PNLEDR
00027 107231  JMS PNMARK
00030 107217  JMS PNLEDR
00031 740040  HALT
00032 147520  DZM WORK4
00033 147334  DZM BREAK
00034 703302  CAF
00035 147514  DZM WORK
00036 147001  DZM GOPNCH
00037 206704  LAC DATABL
00040 047352  DAC TTIN  /SETUP POINTERS
00041 047351  DAC TTOUT
00042 447351  ISZ TTOUT
00043 167351  DZM* TTOUT  /CLEAR TTY BIN
00044 207351  LAC TTOUT
00045 546705  SAD ENDBIN
00046 741000  SKP
00047 600042  JMP ,=5
00050 206704  LAC DATABL  /RESTORE POINTER
00051 047351  DAC TTOUT
00052 206360  LAC ENDTBL
00053 047335  DAC WDCNT
00054 777737  LAW -41
00055 047273  DAC CRLF
00056 447335  ISZ WDCNT
00057 167335  DZM* WDCNT  /CLEAR ERROR TABLE
00060 447273  ISZ CRLF
00061 600056  JMP ,=3
        .EJECT

```

00062	700002		IOF	/PI OFF
00063	750004		LAS	
00064	507425		AND K400	
00065	741200		SNA	
00066	600076		JMP TELLY	/NO TTY
00067	207302		LAC KJMP	/JMP E646*3
00070	047002		DAC GOPNCH+1	
00071	760377		LAW 377	
00072	700406		TLS	/SET FLAG
00073	207245		LAC TLSSF+6	
00074	046567		DAC RTNIT-3	
00075	600107		JMP SEQUEN=3	
00076	700104	TELLY	RSA	/INITIALIZE READER, PUNCH
00077	750004		LAS	
00100	507427		AND K3K	
00101	741200		SNA	/IF ACS 7 OR 8 A 1, DON'T PUNCH
00102	700204		PSA	
00103	206656		LAC E645+1	
00104	046567		DAC RTNIT=3	
00105	206406		LAC YADRAN+2	/NOP
00106	047002		DAC GOPNCH+1	
00107	200147		LAC INITPI	/INITPI = PNSTR
00110	047001		DAC GOPNCH	
00111	047527		DAC RJMP	/(RJMP) = PNSTR
00112	207501	SEQUEN	LAC KSKP	/RESTORE ADDRESS 1 (SKP)
00113	040001		DAC 1	
00114	206526		LAC SAV3	/RESTORE ADDRESS 3
00115	040003		DAC 3	
00116	207535		LAC SAV4	/RESTORE ADDRESS 4
00117	040004		DAC 4	
00120	206527		LAC SAV5	/RESTORE ADDRESS 5
00121	040005		DAC 5	
00122	206530		LAC SAV6	/RESTORE ADDRESS 6
00123	040006		DAC 6	
00124	207533		LAC KHALT	/RESTORE ADDRESS 2 (HALT)
00125	040002		DAC 2	
00126	040021		DAC 21	
00127	447520		ISZ WORK4	/PASS COUNTER
00130	750004		LAS	
00131	507437		AND K10K	
00132	741200		SNA	/CHECK ACS 5 FOR INHIBIT CLOCK
00133	106614		JMS SETCLK	
00134	750004		LAS	
00135	741100		SPA	
00136	600150		JMP INHIT	/INHIBIT INST, TEST
00137	740010		RAL	
00140	740100		SMA	/CHECK FOR INHIBIT PI
00141	700042		ION	/PI ON
00142	750004		LAS	
00143	507343		AND K100K	
00144	740200		SZA	/CHECK LOOP ON RANDOM ADD
00145	602413		JMP RANADD=2	/LOOP
00146	600152		JMP IOTST-2	
00147	006710	/	INITPI PNSTR	

00150 700042
00151 600151

/
/INHIBIT INSTRUCTION TEST
INHIT ION
JMP . /WAIT FOR PI
/
.EJECT

/TEST CLEAR AC AT EVENT TIME 1 WITH MB 14.

```

/
00152 106336 JMS GENRAN /GET NO. FOR LOOP
00153 106362 JMS CKNO
00154 750001 IOTST CLA: CMA /AC = 7777777
00155 700110 700110
00156 740200 SEA /AC = 0
00157 740040 E24 HALT /ERROR, AC NOT 0
/
00160 750001 CLA: CMA /AC = 777777
00161 700210 700210
00162 740200 SEA /AC = 0
00163 740040 E25 HALT /ERROR, AC NOT 0
/
00164 750001 CLA: CMA /AC = 777777
00165 700310 700310
00166 740200 SEA /AC = 0
00167 740040 E26 HALT /ERROR, AC NOT 0
/
00170 750001 CLA: CMA /AC = 777777
00171 700010 700010
00172 740200 SEA /AC = 0
00173 740040 E27 HALT /ERROR, AC NOT 0
/
00174 600201 JMP 201
/
00200 ,LOC 200
00200 600022 JMP BEGIN
/

```

/TEST IORS BIT 0 = 1 IF PI ENABLED.

```

/
00201 750004 LAS
00202 740010 RAL
00203 741100 SPA
00204 600210 JMP ,+4 /PI INHIBITED
00205 700314 IORS
00206 740100 SMA
00207 740040 E27A HALT /ERROR, PI ENABLED, BUT IORS-0 NOT SET
/
00210 447517 ISZ WORK3 /CHECK DONE LOOPING
00211 600154 JMP IOTST /LOOP
00212 106336 JMS GENRAN /GET NO. FOR NEXT TEST
00213 106362 JMS CKNO
,EJECT

```

```

/TEST IOT 3344 (DBR), L = 0
/
00214 744000  TSOBR  CLL           /LINK = 0
00215 100237      JMS DBRX
00216 741400      SZL
00217 740040  E28  HALT           /ERROR, DBR FAILED; LINK NOT 0
/
/TEST IOT 3344 (DBR), L = 1
/
00220 744002      CLLCML           /L = 1
00221 100237      JMS DBRX
00222 740400      SNL
00223 740040  E29  HALT           /ERROR, DBR FAILED.   LINK NOT 1
/
/TEST IOT 3344 (DBR), L = 0
/
00224 754000      CLLICLA           /AC, L = 0
00225 100242      JMS DBRXX
00226 740400      SNL
00227 740040  E30  HALT           /ERROR, DBR FAILED, LINK NOT 1
/
/TEST IOT 3344 (DBR), L = 1
/
00230 754002      CLLICMLICLA        /L = 1, AC = 0
00231 100250      JMS DBRXXX
00232 751400      CLASZL
00233 740040  E31  HALT           /ERROR, DBR FAILED; LINK NOT 0
00234 447517      ISZ WORK3          /CHECK DONE LOOPING
00235 600214      JMP TSOBR           /LOOP
00236 600256      JMP OPRAT          /START INSTRUCTION TEST
/
DBRX  0           /LEAVE LINK ALONE
00237 000000      703344          /DBR
00240 703344      JMP* DBRX
/
DBRXX 0
00242 000000      LAC DBRXX
00243 200242      TAD K400K           /SET LINK TO A ONE
00244 347435      DAC DBRXX
00245 040242      703344          /DBR
00246 703344      JMP* DBRXX
/
DBRXXX 0
00250 000000      LAC DBRXXX
00251 200250      AND M400K           /CLEAR LINK
00252 507511      DAC DBRXXX
00253 040250      703344          /DBR
00254 703344      JMP* DBRXXX
00255 620250      .EJECT

```

```

/TEST OPERATE GROUP
/
00256 106336 OPRAT JMS GENRAN /GET NO, FOR LOOP ON TEST
00257 106362 JMS CKNO
00260 777777 OPERAT LAW 1777 /AC = 777777
/
00261 741000 SKP /TEST SKP
00262 740040 E32 HALT /ERROR; SKP FAILED TO SKIP
/
/TEST CLA = SZA
00263 750000 CLA /AC = 0
00264 740200 SZA
00265 740040 E33 HALT /ERROR; CLA OR SZA FAILED TO SKIP
/
/TEST SMA
00266 750000 CLA /AC = 0
00267 740100 SMA
00270 741000 SKP
00271 740040 E34 HALT /ERROR; SAME SKIPPED
/
/TEST SPA
00272 750000 CLA
00273 741100 SPA
00274 740040 E35 HALT /ERROR; SPA FAILED TO SKIP
/
/TEST SNA
00275 750000 CLA
00276 741200 SNA
00277 741000 SKP
00300 740040 E36 HALT /ERROR; SNA SKIPPED
/
/TEST SZL = CLL
00301 744000 CLL /LINK = 0
00302 741400 SZL
00303 740040 E37 HALT /ERROR; SZL FAILED TO SKIP OR
/CLL FAILED TO CLEAR LINK
/
/TEST SNL
00304 744000 CLL /LINK = 0
00305 740400 SNL
00306 741000 SKP
00307 740040 E38 HALT /ERROR; SNL SKIPPED
,EJECT

```

00310	754000	/TEST CLA CLL	/AC, LINK = 0
00311	740200	CLA!CLL	
00312	740040	SZA	
		E39 HALT	/ERROR; AC NOT 0
		/	
00313	754000	/TEST CLA CLL	/AC AND LINK = 0
00314	741400	CLA!CLL	
00315	740040	SZL	
		E40 HALT	/ERROR; LINK NOT 0
		/	
00316	750000	/TEST SKP SPA	
00317	741100	CLA	
00320	740040	SKP!SPA	
		E41 HALT	/ERROR; SKP!SPA FAILED TO SKIP
		/	
00321	750000	/TEST SKP SNA	
00322	741200	CLA	
00323	741000	SKP!SNA	
00324	740040	SKP	
		E42 HALT	/ERROR; SKP!SNA SKIPPED
		/	
00325	744000	/TEST SKP SZL	
00326	741400	CLL	/LINK = 1
00327	740040	SKP!SZL	
		E43 HALT	/ERROR; SKP!SZL FAILED TO SKIP
		/	
00330	750000	/TEST SPA SNA	
00331	741300	CLA	
00332	741000	SPA!SNA	
00333	740040	SKP	
		E44 HALT	/ERROR; SPA!SNA SKIPPED
		/	
00334	754000	/TEST SPA SZL	
00335	741500	CLA!CLL	/LINK AND AC = 0
00336	740040	SPA!SZL	
		E45 HALT	/ERROR; SPA!SZL FAILED TO SKIP
		/	
00337	754000	/TEST SNA SZL	
00340	741600	CLA!CLL	/LINK AND AC = 0
00341	741000	SNA!SZL	
00342	740040	SKP	
		E46 HALT	/ERROR; SNA!SZL SKIPPED
		/	
00343	754000	/TEST SNA, SPA, SKP, SZL	
00344	741700	CLA!CLL	/AC AND LINK = 0
00345	741000	SKP!SPA!SZL!SNA	
00346	740040	SKP	
		E47 HALT	/ERROR; SNA!SPA!SKP!SZL SKIPPED
		,EJECT	

```

00347 750000 /TEST SMA SZA
00350 740300 CLA
00351 740040 SMA!SZA
E48 HALT /ERROR: SMA SZA FAILED TO SKIP
/
00352 754000 /TEST SMA SNL
00353 740500 CLA!CLL /LINK AND AC = 0
00354 741000 SMA!SNL
00355 740040 SKP
E49 HALT /ERROR: SMA!SNL SKIPPED
/
00356 754000 /TEST SZA SNL
00357 740600 CLA!CLL
00360 740040 SZA!SNL
E50 HALT /ERROR: SZA!SNL SKIPPED
/
00361 754000 /TEST SMA SZA SNL
00362 740700 CLA!CLL
00363 740040 SMA!SZA!SNL
E51 HALT /ERROR: SMA!SZA!SNL FAILED TO SKIP
/
00364 744000 /TEST CML = SZL
00365 740002 CLL /LINK = 0
00366 741400 CML /LINK = 1
00367 741000 SZL
00370 740040 SKP
E52 HALT /ERROR: SZL SKIPPED OR
/CML FAILED TO SET LINK
/
00371 744000 /TEST CLL
00372 740002 CLL /LINK = 0
00373 744000 CML /LINK = 1
00374 741400 CLL /LINK = 0
00375 740040 SZL
E53 HALT /ERROR: CLL FAILED TO CLEAR LINK
/
00376 744000 /TEST CML
00377 740002 CLL /LINK = 0
00400 740002 CML /LINK = 1
00401 741400 CML /LINK = 0
00402 740040 SZL
E54 HALT /ERROR: CML FAILED TO SET LINK
/
00403 744000 /TEST CLL CML
00404 740002 CLL /LINK = 1
00405 744002 CML /LINK = 1
00406 741400 CLL!CML /LINK = 1
00407 741000 SZL
00410 740040 SKP
E55 HALT /ERROR: CLL!CML FAILED TO SET LINK
,EJECT

```

```

/TEST CLL CML
00411 744000          CLL          /LINK = 0
00412 740002          CML          /LINK = 1
00413 744000          CLL          /LINK = 0
00414 744002          CLL!CML      /LINK = 1
00415 741400          SZL
00416 741000          SKP
00417 740040          E56      HALT          /ERROR: CLL!CML FAILED TO SET LINK
/
/TEST SKP SZL
00420 744000          CLL          /LINK = 0
00421 741400          SKP!SZL
00422 740040          E57      HALT          /ERROR: SKP!SZL FAILED TO SKIP
/
/TEST SZL SNA
00423 750000          CLA          /AC = 0
00424 744002          CLL!CML      /LINK = 1
00425 741600          SZL!SNA
00426 741000          SKP
00427 740040          E58      HALT          /ERROR: SZL!SNA SKIPPED
/
/TEST SZL SPA
00430 750000          CLA          /AC = 0
00431 744002          CLL!CML      /LINK = 1
00432 741500          SZL!SPA
00433 741000          SKP
00434 740040          E59      HALT          /ERROR: SZL!SPA SKIPPED
/
/TEST CLA CLL CML
00435 754002          CLA!CLL!CML /AC = 0,      LINK = 1
00436 741400          SZL
00437 741000          SKP
00440 740040          E60      HALT          /ERROR: LINK NOT 1
/
/TEST CLA CLL CML
00441 754002          CLA!CLL!CML /AC = 0, LINK = 1
00442 740200          SZA
00443 740040          E61      HALT          /ERROR: AC NOT 0
/
/TEST SNL SZA
00444 754002          CLA!CLL!CML /AC = 0, LINK = 1
00445 740600          SNL!SZA
00446 740040          E62      HALT          /ERROR: SNL!SZA FAILED TO SKIP
/
/TEST SNL SMA
00447 754002          CLA!CLL!CML /AC = 0, LINK = 1
00450 740500          SNL!SMA
00451 740040          E63      HALT          /ERROR: SNL!SMA FAILED TO SKIP
          ,EJECT

```

```

00452 754002 /TEST SNL SZA SMA
00453 740700 CLA!CLL!CML /AC = 0, LINK = 1
00454 740040 SNL!SZA!SMA
E64 HALT /ERROR; SNL!SZA!SMA FAILED TO SKIP
/
00455 750000 /TEST CMA CLA
00456 740001 CLA /AC = 0
00457 750000 CMA /AC = ONES
00460 741200 CLA
00461 741000 SNA
00462 740040 SKP
E65 HALT /ERROR; CLA FAILED TO CLEAR AC
/
00463 750000 /TEST CMA SPA
00464 740001 CLA /AC = 0
00465 741100 CMA /AC = ONES
00466 741000 SPA
00467 740040 SKP
E66 HALT /ERROR; SPA SKIPPED OR
/CMA FAILED TO SET AC BIT 0
/
00470 750000 /TEST CMA SNA
00471 740001 CLA /AC = 0
00472 741200 CMA /AC = ONES
00473 740040 SNA
E67 HALT /ERROR; SNA FAILED TO SKIP
/OR CMA FAILED TO SET ANY AC BIT
/
00474 750000 /TEST CMA
00475 740001 CLA /AC = 0
00476 740001 CMA /AC = ONES
00477 741200 CMA /AC = 0
00500 741000 SNA
00501 740040 SKP
E68 HALT /ERROR; CMA FAILED TO
/COMPLEMENT AC TO 0
/
00502 750001 /TEST CLA CMA
00503 741200 CLA!CMA /AC = ONES
00504 740040 SNA
E69 HALT /ERROR; CLA!CMA FAILED TO
/SET ANY AC BIT
.EJECT

```



```

/TEST SZA
00505 750001 CLA: CMA /AC = ONES
00506 740200 SZA
00507 741000 SKP
00510 740040 E70 HALT /ERROR; SZA SKIPPED
/
/TEST SMA
00511 750001 CLA: CMA /AC = ONES
00512 740100 SMA
00513 740040 E71 HALT /ERROR; SMA FAILED TO SKIP
/
/TEST SKP SPA
00514 750001 CLA: CMA /AC = ONES
00515 741100 SKP: SPA
00516 741000 SKP
00517 740040 E72 HALT /ERROR; SKP: SPA SKIPPED
/
/TEST SKP SNA
00520 750001 CLA: CMA /AC = ONES
00521 741200 SKP: SNA
00522 740040 E73 HALT /ERROR; SKP: SNA FAILED TO SKIP
/
/TEST SPA SNA
00523 750001 CLA: CMA /AC = ONES
00524 741300 SPA: SNA
00525 741000 SKP
00526 740040 E74 HALT /ERROR; SPA: SNA SKIPPED
/
/TEST SKP SNA SPA
00527 754003 CLA: CMA: CLL: CML /AC = ONES; LINK = 1
00530 741700 SNA: SPA: SKP: SZL
00531 741000 SKP
00532 740040 E75 HALT /ERROR; SKP: SNA: SPA: SZL SKIPPED
/
/TEST SMA: SZA
00533 750001 CLA: CMA /AC = ONES
00534 740300 SMA: SZA
00535 740040 E76 HALT /ERROR; SMA: SZA FAILED TO SKIP
/
/TEST SMA SZA SNL
00536 754003 CLA: CMA: CLL: CML /AC = ONE; LINK = 1
00537 740700 SMA: SZA: SNL
00540 740040 E77 HALT /ERROR; SMA: SZA: SNL
/
/TEST NOP
00541 750001 CLA: CMA /AC = ONES
00542 740000 NOP
00543 740001 CMA /AC = 0
00544 740200 SZA
00545 740040 E78 HALT /ERROR; NOP ALTERED THE AC
/
.EJECT

```

```

/TEST NOP
00546 750000          CLA          /AC = 0
00547 740000          NOP
00550 740200          SZA
00551 740040      E79  HALT          /ERROR; NOP SET AN AC BIT
/
/TEST NOP
00552 744002          CLL!CML       /LINK = 1
00553 740000          NOP
00554 740400          SNL
00555 740040      E80  HALT          /ERROR; NOP CLEARED THE LINK
/
/TEST NOP
00556 744000          CLL          /LINK = 0
00557 740000          NOP
00560 741400          SZL
00561 740040      E81  HALT          /ERROR; NOP SET THE LINK
/
/TEST SZA CMA
00562 750000          CLA          /AC = 0
00563 740201          SZA!CMA       /AC = ONES
00564 740040      E82  HALT          /ERROR; SZA FAILED TO SKIP
/
/TEST SZA CLA
00565 750001          CLA!CMA       /AC = ONES
00566 750200          SZA!CLA       /AC = 0
00567 741000          SKP
00570 740040      E83  HALT          /ERROR; SZA SKIPPED
/
/TEST SZL CML
00571 744000          CLL          /LINK = 0
00572 741402          SZL!CML
00573 740040      E84  HALT          /ERROR; SZL FAILED TO SKIP
/
/TEST SZL CLL
00574 744002          CLL!CML       /LINK = 1
00575 745400          SZL!CLL
00576 741000          SKP
00577 740040      E85  HALT          /ERROR; SZL SKIPPED
/
/TEST SKP SZL SPA LA CLL
00600 754003          CLA!CMA!CLL!CML /AC = ONES, LINK = 1
00601 755500          SKP!SZL!SPA!CLA!CLL /AC = 0, LINK = 0
00602 741000          SKP
00603 740040      E86  HALT          /ERROR; SKP!SZL!SPA SKIPPED
          ,EJECT

```

```

/TEST SZA SNL CMA CLL
00604 754002 CLA!CLL!CML /AC = 0, LINK = 1
00605 744601 SZA!SNL!CMA!CLL /AC=ONES, LINK=?
00606 740040 E87 HALT /ERROR, SZA!SNL FAILED TO SKP
/
/TEST CLA SKP
00607 750001 CLA!CMA /AC = ONES
00610 751000 SKP!CLA /AC = 0
00611 740000 NOP
00612 740200 SZA
00613 740040 E88 HALT /ERROR, CLA FAILED TO CLEAR AC
/
/TEST SKP CLA CMA
00614 750000 CLA /AC = 0
00615 751001 SKP!CLA!CMA /AC = ONES
00616 740000 NOP
00617 740001 CMA
00620 740200 SZA
00621 740040 E89 HALT /ERROR, CLA!CMA FAILED TO
/COMPLEMENT THE AC
/
/TEST SKP CLL CML
00622 744000 CLL /LINK = 0
00623 745002 SKP!CLL!CML /LINK = 1
00624 740000 NOP
00625 740400 SNL
00626 740040 E90 HALT /ERROR, CLL!CML FALED TO SET THE LINK
/
/TEST CMA SERIES
00627 750001 CLA!CMA /AC = ONES
00630 740001 CMA /AC = 0
00631 740001 CMA /AC = ONES
00632 740001 CMA /AC = 0
00633 740001 CMA /AC = ONES
00634 740001 CMA /AC = 0
00635 740200 SZA
00636 740040 E91 HALT /ERROR, AC NOT 0 CMA FAILED
/
/TEST CML SERIES
00637 744002 CLL!CML /LINK = 1
00640 740002 CML /LINK = 0
00641 740002 CML /LINK = 1
00642 740002 CML /LINK = 0
00643 740002 CML /LINK = 1
00644 740002 CML /LINK = 0
00645 741400 SZL
00646 740040 E92 HALT /ERROR, LINK NOT 0 CML FAILED
/
ISZ WORK3 /CHECK DONE LOOPING
00647 447517 JMP OPERAT /LOOP
00650 600260 JMS GENRAN /GET NO. FOR NEXT LOOP
00651 106336 JMS CKNO
00652 106362 .EJECT

```

```

00653 754002
00654 740020
00655 740020
00656 740020
00657 740020
00660 740020
00661 740020
00662 740020
00663 740020
00664 740020
00665 740020
00666 740020
00667 740020
00670 740020
00671 740020
00672 740020
00673 740020
00674 740020
00675 740020
00676 741600
00677 740040

```

```

/
/TEST RAR SERIES AND LINK
RTAT CLA:CLL:CML /AC = 0, LINK = 1
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
RAR
SNA:SZL
E113 HALT /ERROR; AC BIT 17 NOT 1, OR LINK = 1
      /AFTER ROTATE SERIES
      .EJECT

```

```

/TEST RAL SERIES AND LINK
00700 754002 CLAICLLICML /AC = 0, LINK = 1
00701 740010 RAL
00702 740010 RAL
00703 740010 RAL
00704 740010 RAL
00705 740010 RAL
00706 740010 RAL
00707 740010 RAL
00710 740010 RAL
00711 740010 RAL
00712 740010 RAL
00713 740010 RAL
00714 740010 RAL
00715 740010 RAL
00716 740010 RAL
00717 740010 RAL
00720 740010 RAL
00721 740010 RAL
00722 740010 RAL
00723 741600 SNAISZL
00724 740040 E114 HALT /ERROR: AC BIT 0 NOT 1, OR LINK = 1
/AFTER ROTATE SERIES

/TEST RTL SERIES AND LINK
00725 754002 CLAICLLICML /AC = 0, LINK = 1
00726 742010 RTL
00727 742010 RTL
00730 742010 RTL
00731 742010 RTL
00732 742010 RTL
00733 742010 RTL
00734 742010 RTL
00735 742010 RTL
00736 742010 RTL
00737 741600 SNAISZL
00740 740040 E115 HALT /ERROR: AC BIT 0 NOT 1, OR LINK = 1
/AFTER ROTATE SERIES

/TEST RTR SERIES AND LINK
00741 754002 CLAICLLICML /AC = 0, LINK = 1
00742 742020 RTR
00743 742020 RTR
00744 742020 RTR
00745 742020 RTR
00746 742020 RTR
00747 742020 RTR
00750 742020 RTR
00751 742020 RTR
00752 742020 RTR
00753 741600 SNAISZL
00754 740040 E116 HALT /ERROR: AC BIT 17 NOT 1, OR LINK = 1
/AFTER ROTATE SERIES

.EJECT

```

/PDP-15 BASIC EXERCISER - TAPE 2

/

/RAR SERIES

00755	754001	RTSS	CLA!CMA!CLL	/AC = ONES, LINK = 0
00756	740020		RAR; RAR;	RAR; RAR
00757	740020			
00760	740020			
00761	740020			
00762	740020		RAR; RAR;	RAR; RAR
00763	740020			
00764	740020			
00765	740020			
00766	740020		RAR; RAR;	RAR; RAR
00767	740020			
00770	740020			
00771	740020			
00772	740020		RAR; RAR;	RAR; RAR
00773	740020			
00774	740020			
00775	740020			
00776	740020		RAR; RAR	
00777	740020			
01000	740003		CMA!CML	/AC = 000001, LINK = 0
01001	741600		SNA!SZL	
01002	740040	E140	HALT	/ERROR; AC BIT 17 NOT 1, OR LINK = 0 /AFTER ROTATE SERIES

/

/

/TEST RAL SERIES TEST

01003	754001		CLA!CMA!CLL	/AC = ONES, LINK = 0
01004	740010		RAL; RAL;	RAL; RAL
01005	740010			
01006	740010			
01007	740010			
01010	740010		RAL; RAL;	RAL; RAL
01011	740010			
01012	740010			
01013	740010			
01014	740010		RAL; RAL;	RAL; RAL
01015	740010			
01016	740010			
01017	740010			
01020	740010		RAL; RAL;	RAL; RAL
01021	740010			
01022	740010			
01023	740010			
01024	740010		RAL; RAL;	CML /AC = 377777, LINK = 0
01025	740010			
01026	740002			
01027	741500		SPA!SZL	
01030	740040	E141	HALT	/ERROR; AC BIT 2 NOT 0, OR LINK = 0 /AFTER ROTATE SERIES

.EJECT


```

/
/TEST RAL!SNA
01063 754002 CLA!CLL!CML /AC = 0, LINK = 1
01064 741210 RAL!SNA
01065 741000 SKP
01066 740040 E162 HALT /ERROR; SNA SKIPPED
/
/TEST RAR!SNA
01067 754002 CLA!CLL!CML /AC = 0, LINK = 1
01070 741220 RAR!SNA
01071 741000 SKP
01072 740040 E163 HALT /ERROR; SNA SKIPPED
/
/TEST RTL!SNA
01073 754002 CLA!CLL!CML /AC = 0, LINK = 1
01074 743210 RTL!SNA
01075 741000 SKP
01076 740040 E164 HALT /ERROR; SNA SKIPPED
/
/TEST RTR!SNA
01077 754002 CLA!CLL!CML /AC = 0, LINK = 1
01100 743220 RTR!SNA
01101 741000 SKP
01102 740040 E165 HALT /ERROR; SNA SKIPPED
/
/TEST RAL!SNA
01103 754002 CLA!CLL!CML /AC = 0, LINK = 1
01104 740020 RAR /AC = 400000
01105 741210 SNA!RAL
01106 740040 E166 HALT /ERROR. SNA FAILED TO SKIP
/
/TEST RAR!SNA
01107 754002 CLA!CLL!CML /AC = 0, LINK = 1
01110 740010 RAL /AC = 000001
01111 741220 SNA!RAR
01112 740040 E167 HALT /ERROR; SNA FAILED TO SKIP
,EJECT

```


01113	754002	/TEST RTL!SNA	
01114	742020	CLA!CLL!CML	/AC = 0, LINK = 1
01115	743210	RTR	/AC = 200000
01116	740040	SNA!RTL	
		E168 HALT	/ERROR; SNA FAILED TO SKIP
		/	
		/TEST RTR!SNA	
01117	754002	CLA!CLL!CML	/AC = 0, LINK = 1
01120	742010	RTL	
01121	743220	SNA!RTR	
01122	740040	E169 HALT	/ERROR; SNA FAILED TO SKIP
		/	
		/TEST CLL!SNA!RAR	
01123	754001	CLA!CMA!CLL	/AC = ONES, LINK = 0
01124	751220	CLA!SNA!RAR	
01125	740040	E170 HALT	/ERROR; SNA FAILED TO SKIP
01126	447517	ISE WORK3	/CHECK DONE LOOPING
01127	600653	JMP RTAT	/LOOP
01130	106336	JMS GENRAN	/GET NO FOR NEXT LOOP
01131	106362	JMS CKNO	
		/	
		.EJECT	

```

/
/TEST LAW 760000
01132 754000 TLAW CLA!CLL /AC = 0
01133 760000 LAW 00000 /AC = 760000
01134 740010 RAL /AC = 740000
01135 744400 SNL!CLL /LINK = 1
01136 740040 E206 HALT /ERROR; AC NOT 0 NOT A 1,
/LAW 760000 FAILED
01137 740010 RAL /AC = 700000
01140 744400 SNL!CLL /LINK = 1
01141 740040 E207 HALT /ERROR; AC BIT 1 NOT A 1
/LAW 760000 FAILED
01142 740010 RAL /AC = 600000
01143 744400 SNL!CLL /LINK = 1
01144 740040 E208 HALT /ERROR; AC BIT 2 NOT A 1
/LAW 760000 FAILED
01145 740010 RAL /AC = 400000
01146 744400 SNL!CLL /LINK = 1
01147 740040 E209 HALT /ERROR; AC BIT 3 NOT A 1
/LAW 760000 FAILED
01150 740010 RAL /AC = 000000
01151 744400 SNL!CLL /LINK = 1
01152 740040 E210 HALT /ERROR; AC BIT 4 NOT A 1
/LAW 760000 FAILED
01153 740200 SZA /AC = 000000
01154 740040 E211 HALT /ERROR; AC BITS 5=17 NOT 0
/LAW 760000 FAILED

/
/TEST LAW 760000, AC = ONES
01155 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
01156 760000 LAW 00000 /AC = 760000
01157 741400 SZL
01160 740040 E212 HALT /ERROR; LINK NOT A 0, LAW SET LINK
RAL /AC = 740000
01161 740010 RAL /LINK = 1
01162 744400 SNL!CLL /LINK = 1
01163 740040 E213 HALT /ERROR; AC BIT 0 NOT A 1,
/LAW 760000 FAILED
01164 740010 RAL /AC = 700000
01165 744400 SNL!CLL /LINK = 1
01166 740040 E214 HALT /ERROR; AC BIT 1 NOT A 1
/LAW 760000 FAILED

/
01167 740010 RAL /AC = 600000
01170 744400 SNL!CLL /LINK = 1
01171 740040 E215 HALT /ERROR; AC BIT 2 NOT A 1
/LAW 760000 FAILED
01172 740010 RAL /AC = 400000
01173 744400 SNL!CLL /LINK = 1
01174 740040 E216 HALT /ERROR; AC BIT 3 NOT A 1, LAW 760000 FAILED
01175 740010 RAL /AC = 000000
01176 744400 SNL!CLL /LINK = 1
01177 740040 E217 HALT /ERROR; AC BIT 4 NOT A 1, LAW 760000 FAILED
01200 740200 SZA /AC = 000000
01201 740040 E218 HALT /ERROR; AC BITS 5=17 NOT 0
/LAW 760000 FAILED

```

PAGE 22

BX8K

BX8K

,EJECT

```

/TEST LAW 777777, AC=0, L=0
01202 754000 CLA:CLL /AC = 0
01203 777777 LAW 17777 /AC = 760200
01204 740001 CMA
01205 740200 SZA
01206 740040 E219 HALT /ERROR, AC NOT 0
/ERROR, AC NOT 0
/LAW 17777 FAILED
SZA /AC = 400760
01207 741400 E220 HALT /LINK NOT 0
01210 740040 /
/TEST LAW 777777, AC=0, L=1
01211 754002 CLA:CLL:CML /AC = 0
01212 777777 LAW 17777
01213 740001 CMA
01214 740200 SZA
01215 740040 E221 HALT /ERROR, LINK NOT 0
01216 740400 SNL
01217 740040 E222 HALT /ERROR, LINK NOT 0
/
/TEST LAW 777777, AC=1, L=0
01220 754001 CLA:CMACLL /AC = 0
01221 777777 LAW 17777
01222 740001 CMA
01223 740200 SZA
01224 740040 E223 HALT /ERROR, AC NOT 0
01225 741400 SZA /AC = 100760
01226 740040 E224 HALT /ERROR, LINK NOT 0
,EJECT

```

```
01227 754003 /TEST LAW 777777, AC=1, L=1
01230 777777 CLA!CMA!CLL!CML /AC = 0
01231 740001 LAW 17777
01232 740200 CMA
01233 740040 SZA
01234 740400 E225 HALT /ERROR, AC NOT 0
01235 740040 E226 HALT /ERROR, LINK NOT 1
01236 447517 ISZ WORK3 /CHECK DONE LOOPING
01237 601132 JMP TLAW /LOOP
01240 106336 JMS GENRAN /GET NO. FOR NEXT LOOP
01241 106362 JMS CKNO
      .EJECT
```

```

/TEST LAC 0'S
/
01242 754000 LACK CLA:CLL /AC = 0, LINK = 0
01243 207411 LAC K0 /000000
01244 740200 SZA
01245 740040 E258 HALT /ERROR. AC NOT 0 AFTER LAC K0
01246 741400 SZA
01247 740040 E259 HALT /ERROR. LINK NOT 0 AFTER LAC K0
/
01250 754002 CLA:CLL:CML /AC = 0, LINK = 1
01251 207411 LAC K0
01252 740200 SZA
01253 740040 E260 HALT /ERROR. AC NOT 0
01254 740400 SNL
01255 740040 E261 HALT /ERROR. LINK NOT 1 AFTER LAC K0
/
01256 754001 CLA:CMA:CLL /AC = 1'S, LIN = 0
01257 207411 LAC K0
01260 740200 SZA
01261 740040 E262 HALT /ERROR. AC NOT 0 AFTER LAC K0
01262 741400 SZA
01263 740040 E263 HALT /ERROR. LINK NOT 0 AFTER LAC K0
/
01264 754003 CLA:CMA:CLL:CML /AC = 1'S, LINK = 1
01265 207411 LAC K0
01266 740200 SZA
01267 740040 E264 HALT /ERROR. AC NOT 0
01270 740400 SNL
01271 740040 E265 HALT /ERROR. LINK NOT 1
/
/TEST LAC 1'S
/
01272 754000 CLA:CLL /AC = 0, LINK = 0
01273 207454 LAC K7S /777777
01274 740001 CMA
01275 740200 SZA
01276 740040 E266 HALT /ERROR. AC NOT 0 LAC K7S FAILED
01277 741400 SZA
01300 740040 E267 HALT /ERROR. LINK NOT 0 AFTER LAC K7S
/
01301 754002 CLA:CLL:CML /AC = 0, LINK = 1
01302 207454 LAC K7S
01303 740001 CMA
01304 740200 SZA
01305 740040 E268 HALT /ERROR. AC NOT 0
01306 740400 SNL
01307 740040 E269 HALT /ERROR. LINK NOT 1 AFTER LAC K7S
.EJECT

```

01310	754001		CLA!CMA!CLL	/AC = 1'S, LINK = 0
01311	207454		LAC K7S	
01312	740001		CMA	
01313	740200		SZA	
01314	740040	E270	HALT	/ERROR, AC NOT 0, LAC K7S FAILED
01315	741400		SZL	
01316	740040	E271	HALT	/ERROR, LINK NOT 1 AFTER LAC K7S
		/		
01317	754003		CLA!CMA!CLL!CML	/AC = 1'S, LINK = 1
01320	207454		LAC K7S	
01321	740001		CMA	
01322	740200		SZA	
01323	740040	E272	HALT	/ERROR, AC NOT 0
01324	740400		SNL	
01325	740040		HALT	/ERROR, LINK NOT 1 AFTER LAC K7S
		/		
01326	750000		CLA	
01327	207467		LAC K101	/AC = 525252
01330	207466		LAC K010	/AC = 252525
01331	207454		LAC K7S	/AC = 777777
01332	740001		CMA	
01333	740200		SZA	
01334	740040	E273	HALT	/ERROR, AC NOT 0
01335	447517		ISZ WORK3	/CHECK FOR DONE LOOPING
01336	601242		JMP LACK	/LOOP
01337	106336		JMS GENRAN	/GET NO, FOR LOOP
01340	106362		JMS CKNO	
		/		
		/TEST AND		
		/		
01341	750000		ANDAC	/AC = 0
01342	507411		AND K0	
01343	740200		SZA	
01344	740040	E274	HALT	/ERROR, AC NOT 0 AFTER AND K0
		/		
01345	750001		CLA!CMA	/AC = 1'S
01346	507411		AND K0	
01347	740200		SZA	
01350	740040	E275	HALT	/ERROR, AC NOT 0 AFTER AND K0
		/		
01351	750000		CLA	/AC = 0
01352	507454		AND K7S	
01353	740200		SZA	
01354	740040	E276	HALT	/ERROR, AC NOT 0 AFTER AND K7S
		/		
01355	750001		CLA!CMA	/AC = 1'S
01356	507454		AND K7S	
01357	740001		CMA	
01360	740200		SZA	
01361	740040	E277	HALT	/ERROR, AC NOT 2 AFTER AND K7S
			.EJECT	

/SEQUENTIAL AND

```

/
01362 754002          CLA!CLL!CML      /AC = 0, LINK = 1
01363 507411          AND K0
01364 507454          AND K7S
01365 507467          AND K101
01366 507466          AND K010
01367 740001          CMA
01370 507411          AND K0
01371 507454          AND K7S
01372 507467          AND K101
01373 507466          AND K010
01374 740200          SZA
01375 740040          E278  HALT          /ERROR, AC NOT 0
01376 740400          SNL
01377 740040          E279  HALT          /ERROR, LINK NOT 1
01400 447517          ISZ WORK3      /CHECK FOR DONE LOOPING
01401 601341          JMP ANDAC      /LOOP
01402 106336          JMS GENRAN     /GET NO, FOR NEXT LOOP
01403 106362          JMS CKNO

```

/TEST XOR

```

/
01404 750000          XORAC  CLA      /AC = 0
01405 247411          XOR K0
01406 740200          SZA
01407 740040          E280  HALT          /ERROR, AC NOT 0 AFTER XOR K0
/
01410 750001          CLA!CMA      /AC = 1'S
01411 247411          XOR K0
01412 740001          CMA
01413 740200          SZA
01414 740040          E281  HALT          /ERROR, AC NOT 0
/
01415 750000          CLA      /AC = 0
01416 247454          XOR K7S     /777777
01417 740001          CMA
01420 740200          SZA
01421 740040          E282  HALT          /ERROR, AC NOT 0 AFTER XOR K7S
/
01422 750001          CLA!CMA      /AC = 1'S
01423 247454          XOR K7S
01424 740200          SZA
01425 740040          E283  HALT          /ERROR, AC NOT 0 AFTER XOR K7S
          ,EJECT

```


/SEQUENTIAL XOR

```

01426 750000
01427 247467
01430 247466
01431 247411
01432 247454
01433 247466
01434 247467
01435 247467
01436 247466
01437 740200
01440 740040

01441 447517
01442 601404
01443 106336
01444 106362

```

E284

/TEST TAD

```

01445 754000
01446 347411
01447 740200
01450 740040
01451 741400
01452 740040

01453 754001
01454 347411
01455 740001
01456 740200
01457 740040
01460 741400
01461 740040

01462 754002
01463 347454
01464 740001
01465 740200
01466 740040
01467 740400
01470 740040

01471 754001
01472 347454
01473 740020
01474 740001
01475 740200
01476 740040
01477 741400
01500 740040

```

TADAC

E285

E286

E287

E288

E289

E290

E291

E292

```

          CLA
          XOR K101
          XOR K010
          XOR K0
          XOR K7S
          XOR K010
          XOR K101
          XOR K101
          XOR K010
          SZA
          HALT

          ISZ WORK3
          JMP XORAC
          JMS GENRAN
          JMS CKNO

          TADAC
          CLA!CLL
          TAD K0
          SZA
          HALT
          SZL
          HALT

          CLA!CMA!CLL
          TAD K0
          CMA
          SZA
          HALT
          SZL
          HALT

          CLA!CLL!CML
          TAD K7S
          CMA
          SZA
          HALT
          SNL
          HALT

          CLA!CMA!CLL
          TAD K7S
          RAR
          CMA
          SZA
          HALT
          SZL
          HALT
          .EJECT

```

/AC = 0

/525252

/252525

/000000

/777777

/ERROR, AC NOT 0

/CHECK FOR DONE LOOPING

/LOOP

/GET NO. FOR NEXT LOOP

/AC = 0, LINK = 0

/ERROR, AC NOT 0 AFTER TAD K0

/ERROR, LINK NOT 0 AFTER TAD K0

/AC = 1'S, LINK = 0

/ERROR, AC NOT 0

/ERROR, LINK NOT 0

/AC = 0, LINK = 1

/777777

/ERROR, TAD K7S FAILED

/ERROR, CARRY OUT OR OVERFLOW

/FAILED, LINK NOT 0

/AC = 1'S, LINK = 0

/ERROR, TAD K7S TO 1'S FAILED

/ERROR, LINK NOT 0

/TEST OVERFLOW

```

/
01501 754001          CLA!CMA!CLL      /AC = 1'S, LINK = 0
01502 347412          TAD K1          /000001
01503 740200          SZA
01504 740040          E293  HALT          /ERROR. AC NOT 7 AFTER TAD K1
01505 740400          SNL
01506 740040          E294  HALT          /ERROR. LINK NOT 1 OVERFLOW FAILED
/
01507 754003          CLA!CMA!CLL!CML /AC = 1'S, LINK = 1
01510 347412          TAD K1
01511 740200          SZA
01512 740040          E295  HALT          /ERROR. AC NOT 0
01513 741400          SZL
01514 740040          E296  HALT          /ERROR. LINK NOT 0 OVERFLOW FAILED
/
/TAD 525252, AC = 252525, LINK = 0
/
01515 754000          CLA!CLL
01516 347466          TAD K010
01517 347467          TAD K101          /AC = 1'S
01520 740001          CMA
01521 740200          SZA
01522 740040          E297  HALT          /ERROR. AC NOT 0
01523 741400          SZL
01524 740040          E298  HALT          /ERROR. LINK NOT 0
/
/TAD 252525, AC = 525252, LINK = 1
/
01525 754002          CLA!CLL!CML
01526 347467          TAD K101
01527 347466          TAD K010          /AC = 1'S
01530 740001          CMA
01531 740200          SZA
01532 740040          E299  HALT          /ERROR. AC NOT 0
01533 740400          SNL
01534 740040          E300  HALT          /ERROR. LINK NOT 0
/
/SEQUENTIAL LAC, TAD, XOR
/
01535 754000          CLA!CLL          /AC = 0, LINK = 0
01536 207466          LAC K010
01537 347467          TAD K101          /AC = 1'S
01540 247466          XOR K010
01541 347466          TAD K010          /AC = 1'S
01542 347412          TAD K1
01543 740400          SNL
,EJECT

```

```

01544 740040 E301 HALT /ERROR, LINK NOT 1
01545 207467 LAC K101
01546 247454 XOR K7S
01547 347467 TAD K101
01550 247454 XOR K7S
01551 740200 SZA
01552 740040 E302 HALT /ERROR, AC NOT 0
01553 447517 ISZ WORK3 /CHECK DONE LOOPING
01554 601445 JMP TADAC /LOOP
01555 106336 JMS GENRAN /GET NO, FOR NEXT LOOP
01556 106362 JMS CKNO
/
/
/TEST ADD
/TEST ADD K1S TO K6S, LINK = 0
ADDAC CLAI:CLL /AC = 0, LINK = 0
01557 754000 ADD K1S /111111
01560 307446 ADD K6S /666666
01561 307453 CMA /AC = 0
01562 740001 SZA
01563 740200 E303 HALT /ERROR; ADD K1S TO K6S FAILED
01564 740040 SZA
01565 741400 E304 HALT /ERROR; LINK NOT A0
01566 740040 SZA
/
/TEST ADD K2S TO K5S, LINK = 0
01567 754000 CLAI:CLL /AC, LINK = 0
01570 307447 ADD K2S /22222
01571 307452 ADD K5S /555555
01572 740001 CMA /AC = 0
01573 740200 SZA
01574 740040 E305 HALT /ERROR; ADD K2S TO K5S FAILED
01575 741400 SZA
01576 740040 E306 HALT /ERROR; LINK NOT A 0
/
/TEST ADD K3S TO K4S, LINK = 0
01577 754000 CLAI:CLL /AC, LINK = 0
01600 307450 ADD K3S /33333
01601 307451 ADD K4S /444444
01602 740001 CMA /AC = 0
01603 740200 SZA
01604 740040 E307 HALT /ERROR; ADD K3S TO K4S FAILED
01605 741400 SZA
01606 740040 E308 HALT /ERROR; LINK NOT A0
/
/TEST ADD K4S TO K3S, LINK = 0
01607 754000 CLAI:CLL /AC, LINK = 0
01610 307451 ADD K4S /444444
01611 307450 ADD K3S /333333
01612 740001 CMA /AC = 0
01613 740200 SZA
01614 740040 E309 HALT /ERROR; AND K4S TO K3S FAILED
01615 741400 SZA
01616 740040 E310 HALT /ERROR; LINK NOT A0
.EJECT

```

```

/TEST ADD K5S TO K2S, LINK = 0
01617 754000          CLAI:CLL          /AC, LINK = 0
01620 307452          ADD K5S            /555555
01621 307447          ADD K2S            /222222
01622 740001          CMA                /AC = 0
01623 740200          SZA
01624 740040          E311  HALT          /ERROR; ADD K5S TO K2S FAILED
01625 741400          SZL
01626 740040          E312  HALT          /ERROR; LINK NOT A 0
/
/TEST AND K6S TO K1S, LINK = 0
01627 754000          CLAI:CLL          /AC, LINK = 0
01630 307453          ADD K6S            /666666
01631 307446          ADD K1S            /111111
01632 740001          CMA                /AC = 0
01633 740200          SZA
01634 740040          E313  HALT          /ERROR; ADD K6S TO K1S FAILED
01635 741400          SZL
01636 740040          E314  HALT          /ERROR; LINK NOT A 0
/
/TEST ADD K7S TO K0S, LINK = 0
01637 754000          CLAI:CLL          /AC, LINK = 0
01640 307454          ADD K7S            /777777
01641 307411          ADD K0             /000000
01642 740001          CMA                /AC = 0
01643 740200          SZA
01644 740040          E315  HALT          /ERROR; ADD K7S TO K0S FAILED
01645 741400          SZL
01646 740040          E316  HALT          /ERROR; LINK NOT A 0
/
/TEST ADD 252525, AC = 525252, LINK = 0
01647 754001          CLL:CLAI:CMA      /AC = ONES, LINK = 0
01650 207467          LAC K101           /AC = 525252
01651 307466          ADD K010           /AC = 252525
01652 740001          CMA                /AC = 0
01653 740200          SZA
01654 740040          E317  HALT          /ERROR; ADD K101 TO K010 FAILED
01655 741400          SZL
01656 740040          E318  HALT          /ERROR; LINK NOT A 0
/
/TEST ADD 525252, AC = 252525, LINK = 0
01657 744000          CLL                /LINK = 0
01660 207466          LAC K010           /AC = 252525
01661 307467          ADD K101           /525252
01662 740001          CMA                /AC = 0
01663 740200          SZA
01664 740040          E319  HALT          /ERROR; ADD K010 TO K101 FAILED
01665 741400          SZL
01666 740040          E320  HALT          /ERROR; LINK NOT A 0
          ,EJECT

```

```

/TEST ADD K7S, AC = K400K, LINK = 0
01667 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
01670 207435 LAC K400K /AC = 400K
01671 307454 ADD K7S /ONES
01672 507454 AND K7S /AC = 400K
01673 247435 XOR K400K
01674 740200 SZA /AC = 0
01675 740040 E321 HALT /ERROR; ADD=0 TO K400K FAILED
01676 741400 SZL
01677 740040 E322 HALT /ERROR; LINK NOT A 0, CARRY FAILED
/
/TEST ADD K200K, AC = K200K, LINK = 0
01700 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
01701 207441 LAC K200K /AC = 200K
01702 307441 ADD K200K /ONES
01703 507454 AND K7S /AC = 400K
01704 247435 XOR K400K
01705 740200 SZA /AC = 0
01706 740040 E323 HALT /ERROR; ADD K200K TO K200K FAILED
01707 740400 SNL
01710 740040 E324 HALT /ERROR; LINK NOT A ONES, CARRY FAILED
/
/TEST ADD K7S, AC = K100K, LINK = 1
01711 754003 CLA!CMA!CLL!CML /AC = ONES, LINK = 1
01712 207343 LAC K100K /AC = 100K
01713 307454 ADD K7S /ONES
01714 507454 AND K7S /AC = 100K
01715 247343 XOR K100K
01716 740200 SZA /AC = 0
01717 740040 E325 HALT /ERROR; ADD=0 TO K100K FAILED
01720 740400 SNL
01721 740040 E326 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K7S, AC = K40K, LINK = 0
01722 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
01723 207434 LAC K40K /AC = 40K
01724 307454 ADD K7S /ONES
01725 507454 AND K7S /AC = 40K
01726 247434 XOR K40K
01727 740200 SZA /AC = 0
01730 740040 E327 HALT /ERROR; ADD=0 TO K40K FAILED
01731 741400 SZL
01732 740040 E328 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
.EJECT

```

```

01733 754001 /TEST ADD K7S, AC = K20K, LINK = 0
01734 207440 CLAICMAICLL /AC = ONES, LINK = 0
01735 307454 LAC K20K /AC = 20K
01736 507454 ADD K7S /ONES
01737 247440 AND K7S /AC = 20K
01740 740200 XOR K20K
01741 740040 SZA /AC = 0
01742 741400 E329 HALT /ERROR; ADD=0 TO K20K FAILED
01743 740040 S2L
E330 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
01744 754001 /TEST AND K7S, AC = K10K, LINK = 0
01745 207437 CLAICMAICLL /AC = ONES, LINK = 2
01746 307454 LAC K10K /AC = 10K
01747 507454 ADD K7S /ONES
01750 247437 AND K7S /AC = 10K
01751 740200 XOR K10K
01752 740040 SZA /AC = 0
01753 741400 E331 HALT /ERROR; ADD=0 TO K10K FAILED
01754 740040 S2L
E332 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
01755 754001 /TEST ADD K7S, AC = K4K, LINK = 0
01756 207430 CLAICMAICLL /AC = ONES, LINK = 0
01757 307454 LAC K4K /AC = 4K
01760 507454 ADD K7S /ONES
01761 247430 AND K7S /AC = 4K
01762 740200 XOR K4K
01763 740040 SZA /AC = 0
01764 741400 E333 HALT /ERROR; ADD=0 TO K4K FAILED
01765 740040 S2L
E334 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
01766 754001 /TEST ADD K7S, AC = K2K, LINK = 0
01767 207426 CLAICMAICLL /AC = ONES, LINK = 0
01770 307454 LAC K2K /AC = 2K
01771 507454 ADD K7S /ONES
01772 247426 AND K7S /AC = 2K
01773 740200 XOR K2K
01774 740040 SZA /AC = 0
01775 741400 E335 HALT /ERROR; ADD=0 TO K2K2 FAILED
01776 740040 S2L
E336 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
.EJECT

```

```

01777 754001      /TEST ADD K7S, AC = K1K, LINK = 0
02000 207424      CLA!CMA!CLL      /AC = ONES, LINK = 0
02001 307454      LAC K1K          /AC = 1K
02002 507454      ADD K7S          /ONES
02003 247424      AND K7S          /AC = 1K
02004 740200      XOR K1K
02005 740040      SZA             /AC = 0
02006 741400      E337 HALT        /ERROR; ADD=0 TO K1K FAILED
02007 740040      SZL
E338 HALT        /ERROR; LINK NOT A ZERO, CARRY FAILED
/
02010 754001      /TEST ADD K7S, AC = K400, LINK = 0
02011 207425      CLA!CMA!CLL      /AC = ONES, LINK = 0
02012 307454      LAC K400         /AC = 400
02013 507454      ADD K7S          /ONES
02014 247425      AND K7S          /AC = 400
02015 740200      XOR K400
02016 740040      SZA             /AC = 0
02017 741400      E339 HALT        /ERROR; ADD=0 TO K400 FAILED
02020 740040      SZL
E340 HALT        /ERROR; LINK NOT A ZERO, CARRY FAILED
02021 447517      ISZ WORK3       /CHECK DONE LOOPING
02022 601557      JMP ADDAC        /LOOP
02023 106336      JMS GENRAN       /GET NO. FOR NEXT LOOP
02024 106362      JMS CKNO
      .EJECT

```

```

/TEST ADD K7S, AC = K20, LINK = 0
02025 754001 ADDAC1 CLA!CMA!CLL /AC = ONES, LINK = 0
02026 207421 LAC K20 /AC = 20
02027 307454 ADD K7S /ONES
02030 507421 AND K20 /AC = 20
02031 247421 XOR K20
02032 740200 SZA /AC = 0
02033 740040 E347 HALT /ERROR; ADD =0 TO K20 FAILED
02034 741400 SZL
02035 740040 E348 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
/TEST ADD K7S, AC = K10, LINK = 0
02036 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
02037 207415 LAC K10 /AC = 10
02040 307454 ADD K7S /ONES
02041 507454 AND K7S /AC = 10
02042 247415 XOR K10
02043 740200 SZA /AC = 0
02044 740040 E349 HALT /ERROR; ADD = 0 TO K10 FAILED
02045 741400 SZL
02046 740040 E350 HALT /ERROR; LINK NOT A ZERO CARRY FAILED
/
/TEST ADD K7S, AC = 4, LINK = 0
02047 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
02050 207414 LAC K4 /AC = 4
02051 307454 ADD K7S /ONES
02052 507454 AND K7S /AC = 4
02053 247414 XOR K4
02054 740200 SZA /AC = 0
02055 740040 E351 HALT /ERROR; ADD =0 TO K4 FAILED
02056 741400 SZL
02057 740040 E352 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
/TEST ADD K7S, AC = K2, LINK = 0
02060 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
02061 207413 LAC K2 /AC = 2
02062 307454 ADD K7S /ONES
02063 507454 AND K7S /AC = 2
02064 247413 XOR K2
02065 740200 SZA /AC = 0
02066 740040 E353 HALT /ERROR; ADD =0 TO K2 FAILED
02067 741400 SZL
02070 740040 E354 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
/
/TEST ADD K7S, AC = K1, LINK = 0
02071 754001 CLA!CMA!CLL /AC = ONES, LINK = 0
02072 207412 LAC K1 /AC = 1
02073 307454 ADD K7S /ONES
02074 507454 AND K7S /AC = 1
02075 247412 XOR K1
02076 740200 SZA /AC = 0
02077 740040 E355 HALT /ERROR; ADD =0 TO K1 FAILED
02100 741400 SZL
02101 740040 E356 HALT /ERROR; LINK NOT A ZERO, CARRY FAILED
.EJECT

```



```

/TEST ADD K400K, AC = ONES, LINK = 0
02102 744000      CLL           /LINK = 0
02103 777777      LAW 17777      /AC = ONES
02104 507454      AND K7S        /AC = ONES
02105 307435      ADD K400K      /400K
02106 247435      XOR K400K
02107 740200      SZA           /AC = 0
02110 740040      E357  HALT      /ERROR: ADD K400K TO =0 FAILED
02111 741400      SZA
02112 740040      E358  HALT      /ERROR: LINK NOT A ZERO, CARRY FAILED
/
/TEST ADD K200K, AC = ONES, LINK = 1
02113 744002      CLL!CML      /LINK = 1
02114 777777      LAW 17777      /AC = ONES
02115 507454      AND K7S        /AC = ONES
02116 307441      ADD K200K      /200K
02117 247441      XOR K200K
02120 740200      SZA           /AC = 0
02121 740040      E359  HALT      /ERROR: ADD K200K TO =0 FAILED
02122 740400      SNL
02123 740040      E360  HALT      /ERROR: LINK NOT A ONE, LINK RESET
/
/TEST ADD K100K, AC = ONES, LINK = 1
02124 744002      CLL!CML      /LINK = 1
02125 777777      LAW 17777      /AC = ONES
02126 507454      AND K7S        /AC = ONES
02127 307343      ADD K100K     /100K
02130 247343      XOR K100K
02131 740200      SZA           /AC = 0
02132 740040      E361  HALT      /ERROR: ADD K100K TO =0 FAILED
02133 740400      SNL
02134 740040      E362  HALT      /ERROR: LINK NOT A ONE, LINK RESET
/
/TEST ADD K40K, AC = ONES, LINK = 1
02135 744002      CLL!CML      /LINK = 1
02136 777777      LAW 17777      /AC = ONES
02137 507454      AND K7S        /AC = ONES
02140 307434      ADD K40K      /40K
02141 247434      XOR K40K
02142 740200      SZA           /AC = 0
02143 740040      E363  HALT      /ERROR: ADD K40K TO =0 FAILED
02144 740400      SNL
02145 740040      E364  HALT      /ERROR: LINK NOT A ONE, LINK RESET
/
/TEST ADD K20K, AC = ONES, LINK = 1
02146 744002      CLL!CML      /LINK = 1
02147 777777      LAW 17777      /AC = ONES
02150 507454      AND K7S        /AC = ONES
02151 307440      ADD K20K      /20K
02152 247440      XOR K20K
02153 740200      SZA           /AC = 0
02154 740040      E365  HALT      /ERROR: ADD K20K TO =0 FAILED
02155 740400      SNL
02156 740040      E366  HALT      /ERROR: LINK NOT A ONE, LINK RESET
/PDP-15 BASIC EXERCISER - TAPE 3

```

```

/TEST ADD K10K, AC = ONES, LINK = 1
02157 744002 CLL!CML /LINK = 1
02160 777777 LAW 17777 /AC = ONES
02161 507454 AND K7S /AC = ONES
02162 307437 ADD K10K /10K
02163 247437 XOR K10K
02164 740200 SZA /AC = 0
02165 740040 E367 HALT /ERROR; ADD K10, TO =0 FAILED
02166 740400 SNL
02167 740040 E368 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K4K, AC = ONES, LINK = 1
02170 744002 CLL!CML /LINK = 1
02171 777777 LAW 17777 /AC = ONES
02172 507454 AND K7S /AC = ONES
02173 307430 ADD K4K /4K
02174 247430 XOR K4K
02175 740200 SZA /AC = 0
02176 740040 E369 HALT /ERROR; ADD K4K TO =0 FAILED
02177 740400 SNL
02200 740040 E370 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K2K, AC = ONES, LINK = 1
02201 744002 CLL!CML /LINK = 1
02202 777777 LAW 17777 /AC = ONES
02203 507454 AND K7S /AC = ONES
02204 307426 ADD K2K /2K
02205 247426 XOR K2K
02206 740200 SZA /AC = 0
02207 740040 E371 HALT /ERROR; AC K2K TO =0 FAILED
02210 740400 SNL
02211 740040 E372 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K1K, AC = ONES, LINK = 1
02212 744002 CLL!CML /LINK = 1
02213 777777 LAW 17777 /AC = ONES
02214 507454 AND K7S /AC = ONES
02215 307424 ADD K1K /1K
02216 247424 XOR K1K
02217 740200 SZA /AC = 0
02220 740040 E373 HALT /ERROR; ADD K1K TO =0 FAILED
02221 740400 SNL
02222 740040 E374 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K400, AC = ONES, LINK = 1
02223 744002 CLL!CML /LINK = 1
02224 777777 LAW 17777 /AC = ONES
02225 507454 AND K7S /AC = ONES
02226 307425 ADD K400 /400
02227 247425 XOR K400
02230 740200 SZA /AC = 0
02231 740040 E375 HALT /ERROR; ADD K400 TO =0 FAILED
02232 740400 SNL
02233 740040 E376 HALT /ERROR; LINK NOT A ONE, LINK RESET
,EJECT

```

```

/TEST ADD K200, AC = ONES, LINK = 1
02234 744002      CLL!CML      /LINK = 1
02235 777777      LAW 17777    /AC = ONES
02236 507454      AND K7S      /AC = ONES
02237 307432      ADD K200     /200
02240 247432      XOR K200
02241 740200      SZA          /AC = 0
02242 740040      E377 HALT    /ERROR; ADD K200 TO =0 FAILED
02243 740400      SNL
02244 740040      E378 HALT    /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K100, AC = ONES, LINK = 1
02245 744002      CLL!CML      /LINK = 1
02246 777777      LAW 17777    /AC = ONES
02247 507454      AND K7S      /AC = ONES
02250 307420      ADD K100     /100
02251 247420      XOR K100
02252 740200      SZA          /AC = 0
02253 740040      E379 HALT    /ERROR; ADD K100 TO =0 FAILED
02254 740400      SNL
02255 740040      E380 HALT    /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K40, AC = ONES, LINK = 1
02256 744002      CLL!CML      /LINK = 1
02257 777777      LAW 17777    /AC = ONES
02260 507454      AND K7S      /AC = ONES
02261 307423      ADD K40      /40
02262 247423      XOR K40
02263 740200      SZA          /AC = 0
02264 740040      E381 HALT    /ERROR; ADD K40 TO =0 FAILED
02265 740400      SNL
02266 740040      E382 HALT    /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K20, AC = ONES, LINK = 1
02267 744002      CLL!CML      /LINK = 1
02270 777777      LAW 17777    /AC = ONES
02271 507454      AND K7S      /AC = ONES
02272 307421      ADD K20     /20
02273 247421      XOR K20
02274 740200      SZA          /AC = 0
02275 740040      E383 HALT    /ERROR; ADD K20 TO =0 FAILED
02276 740400      SNL
02277 740040      E384 HALT    /ERROR; LINK NOT A ONE, LINK RESET
/
/TEST ADD K10, AC = ONES, LINK = 1
02300 744002      CLL!CML      /LINK = 1
02301 777777      LAW 17777    /AC = ONES
02302 507454      AND K7S      /AC = ONES
02303 307415      ADD K10
02304 247415      XOR K10
02305 740200      SZA          /AC = 0
02306 740040      E385 HALT    /ERROR; ADD K10 TO =0 FAILED
02307 740400      SNL
02310 740040      E386 HALT    /ERROR; LINK NOT A ONE, LINK RESET
      .EJECT

```

```

02311 744002 /TEST ADD K4, AC = ONES, LINK = 1
02312 777777 CLLICML /LINK = 1
02313 507454 LAW 17777 /AC = ONES
02314 307414 AND K7S /AC = ONES
02315 247414 ADD K4 /4
02316 740200 XOR K4
02317 740040 E387 HALT /AC = 0
02320 740400 SNL /ERROR; ADD K4 TO #0 FAILED
02321 740040 E388 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
02322 744002 /TEST ADD K2, AC = ONES, LINK = 1
02323 777777 CLLICML /LINK = 1
02324 507454 LAW 17777 /AC = ONES
02325 307413 AND K7S /AC = ONES
02326 247413 ADD K2 /2
02327 740200 XOR K2
02330 740040 E389 HALT /AC = 0
02331 740400 SNL /ERROR; ADD K2 TO #0 FAILED
02332 740040 E390 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
02333 744002 /TEST ADD K1, AC = ONES, LINK = 1
02334 777777 CLLICML /LINK = 1
02335 507454 LAW 17777 /AC = ONES
02336 307412 AND K7S /AC = ONES
02337 247412 ADD K1 /1
02340 740200 XOR K1
02341 740040 E391 HALT /AC = 0
02342 740400 SNL /ERROR; ADD K1 TO #0 FAILED
02343 740040 E392 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
02344 744000 /TEST ADD K7S, AC = ONES; LINK = 0
02345 207454 CLL /LINK = 0
02346 307454 LAC K7S /AC = ONES
02347 740001 ADD K7S /ONES
02350 740200 CHA /AC = ONES
02351 740040 E393 HALT /AC = 0
02352 741400 SEL /ERROR; ADD K7S TO ALL ONES FAILED
02353 740040 E394 HALT /ERROR; LINK NOT A ONE, LINK RESET
/
02354 744002 /TEST ADD 525253, AC = 252525, LINK = 1
02355 207466 CLLICML /LINK = 1
02356 307470 LAC K010 /AC = 252525
02357 247412 ADD K53 /525253
02360 740200 XOR K1 /000001
02361 740040 E395 HALT /AC = 0
02362 740400 SNL /ERROR; ADD K5253 TO K5252 FAILED
02363 740040 E396 HALT /ERROR; LINK NOT A ONE, LINK RESET
,EJECT

```

```

02364 744000      /TEST ADD 252525, AC = 525253, LINK RESET
02365 207470      CLL                /LINK = 0
02366 307466      LAC K53           /AC = 525253
02367 247412      ADD K010          /252525
02370 740200      XOR K1            /000001
02371 740040      SEA                /AC = 0
02372 741400      E397 HALT        /ERROR: ADD K2525 TO K5253 FAILED
02373 740040      SZL
E398 HALT        /ERROR: LINK NOT A ZERO, CARRY FAILED
/
02374 754000      /TEST ADD SERIES
02375 307446      CLAI CLL         /LINK = 0, AC = 0
02376 307447      ADD K1S          /AC = 111111
02377 307450      ADD K2S          /AC = 333333
02400 307451      ADD K3S          /AC = 666666
02401 307452      ADD K4S          /AC = 333333, LINK = 1
02402 307453      ADD K5S          /AC = 111111
02403 307454      ADD K6S          /AC = 777777
02404 740001      ADD K7S          /AC = 777777
02405 740200      CMA                /AC = 0
02406 740040      SEA
E399 HALT        /ERROR: ADD SERIES FAILED
02407 740400      SNL
E400 HALT        /ERROR: LINK NOT A 1
02411 447517      ISE WORK3         /CHECK DONE LOOPING
02412 602025      JMP ADDAC1        /LOOP
02413 106336      JMS GENRAN        /GET NO, FOR NEXT LOOP
02414 106362      JMS CKNO
      .EJECT

```

```

/ADD RANDOM PAIRS TEST
/
02415 106336 RANADD JMS GENRAN /GET RANDOM NUMBER
02416 741100 SPA /* NO
02417 740001 CMA /* MAKE IT +
02420 741200 SNA /* NOT ALLOWED
02421 602415 JMP RANADD
02422 043051 DAC APOS /IT IS + A
02423 740001 CMA /*1 COMPLEMENT
02424 043052 MINUSA DAC ANEG /IT IS - A
02425 106336 JMS GENRAN /GET NEXT RANDOM
02426 741100 SPA /* NO
02427 740001 CMA /* MAKE +
02430 741200 SNA /* NOT ALLOWED
02431 602425 JMP MINUSA+1
02432 043053 DAC BPOS /IT IS + B
02433 740001 CMA /*MAKE 1'S COMP
02434 043054 MINUSB DAC BNEG /IT IS - B
02435 777777 LAW =1
02436 043062 DAC PASS2
02437 744000 CLL
02440 203054 LAC BNEG /RESTART HERE TO REGENERATE NEW COMPARES
02441 343052 TAD ANEG /*B =A
02442 741400 SEL /*EOC IF ADD
02443 347412 TAD K1 /*YES MAKE CARRY
02444 043055 MINSAB DAC SUMNEG /*SAVE =A =B
/
/NOW GENERATE A + B
02445 203051 LAC APOS /GET +A
02446 744000 CLL
02447 343053 TAD BPOS /*B
02450 741400 SEL /*EOC IF ADD
02451 347412 TAD K1 /*YES ADD CARRY
02452 043056 APLUSB DAC SUMPOS
.EJECT
    
```

```

/ NOW GENERATE B=A
02453 203053 LAC BPOS /GET B
02454 744000 CLL
02455 343052 TAD ANEG /B=A
02456 741400 SZL /EOC
02457 347412 TAD K1 /YES ADD CARRY
02460 043057 BMINS A DAC BMSUM /SAVE B=A
/
/ NOW GENERATE A=B
02461 203051 LAC APOS /GET A
02462 744000 CLL
02463 343054 TAD BNEG /A=B
02464 741400 SZL /EOC
02465 347412 TAD K1 /YES ADD CARRY
02466 043060 AMINS B DAC AMSUM /A=B
/
/ IF A+B IS AN OVERFLOW SITUATION
/ MAKE OFLOW TESTS THAT APPLY = SNL
/ IF A+B IS NOT OVERFLOW MAKE
/ OVERFLOW TEST THAT APPLY = SZL
/
02467 203056 LAC SUMPOS /GET A+B
02470 751100 SPAICLA /STILL POS RESULT
02471 207537 LAC KSNL /NEG RESULT IS OVERFLOW
02472 741200 SNA /AC = SNL IS OVERFLOW
02473 207536 LAC KSZL /+ RESULT IS NO OVERFLOW
02474 042517 DAC OFLCK1 /SET UP ALL OFLOW
02475 042545 DAC OFLCK3 /TESTS WHERE OFLOW
02476 042662 DAC OFLCH1 /MAY OR MAY NOT OCCUR
02477 042677 DAC OFLCH2 /AC = SNL IS A+B OFLOW
02500 042715 DAC OFLCH3 /AC = SZL IS A+B NOT OFLOW
02501 042734 DAC OFLCH4 /IF A+B OFLOW A=B DOES ALSO
02502 042754 DAC OFLCH5 /IF A+B NOT OFLOW
02503 042775 DAC OFLCH6 /THEN NONE OF THESE
02504 043017 DAC OFLCH7 /ADDS CAN OVERFLOW
02505 042573 DAC OFLCK5
02506 042621 DAC OFLCK7
.EJECT

```

```

/NOW DO A COMPLETE SERIES OF
/ONES COMP ADDITIONS
/SHOULD GET THE SAME RESULTS AS
/THE TAD'S WITH EOC TAD (1
/

```

```

/FIRST TEST A+B
/

```

02507	744000	APLSBT	CLL	/FOR OVERFLOW CHECK
02510	203051		LAC APOS	/GET A
02511	303053		ADD BPOS	/A+B
02512	543056		SAD SUMPOS	/SHOULD = PREVIOUS A+B
02513	602517		JMP ,+4	/OK
02514	740040	E401	HLT	/DISPLAY 1'S A+B
02515	203056		LAC SUMPOS	/GET 2'S COMP GEN
02516	740040		HLT	/DISPLAY 2'S A+B
02517	741400	OFLCK1	SEL	/OR SNL IF OVERFLOW
02520	740040	E402	HLT	/LINK OR OVERFLOW FAILED
02521	762507		LAW APLSBT	/MAKE JUMP FOR SCOPE LOOP
			.EJECT	


```

/2ND TEST =B+A
02522 744000 AMNSBT CLL
02523 203054 LAC RNEG /GET A
02524 303051 ADD APOS /A-B
02525 543060 SAD AMBSUM /SHOULD = PREVIOUS A-B
02526 602532 JMP ,+4 /OK
02527 740040 E403 HLT /DISPLAY 1'S A=B
02530 203060 LAC AMBSUM
02531 740040 HLT /DISPLAY 2'S A=B
02532 741400 OFLCK2 SZL /SHOULD NOT OVERFLOW
02533 740040 E404 HLT
02534 762522 LAW AMNSBT /MAKE JMP FOR SCOPE

```

```

/
/NOW 3RD TEST IS =A =B
02535 744000 MAPLMB CLL
02536 203052 LAC ANEG /GET =A
02537 303054 ADD BNEG /PLS =B
02540 543055 SAD SUMNEG /SHOULD = PREVIOUS =A-B
02541 602545 JMP ,+4 /OK
02542 740040 E405 HLT /DISPLAY 1'S -A-B
02543 203055 LAC SUMNEG
02544 740040 HLT /DISPLAY 2'S -A-B
02545 741400 OFLCK3 SZL /OR SNL
02546 740040 E406 HLT /LINK FAILED
02547 762535 LAW MAPLMB /MAKE JMP FOR SCOPE

```

```

/
/FOURTH TEST IN THIS SERIES
/IS TEST B=A
02550 744000 BMNSAT CLL
02551 203053 LAC BPOS /GET B
02552 303052 ADD ANEG /ADD =A
02553 543057 SAD BMASUM /SHOULD = PREVIOUS B=A
02554 602560 JMP ,+4 /OK
02555 740040 HLT /DISPLAY 1'S B=A
02556 203057 LAC BMASUM
02557 740040 HLT /DISPLAY 2'S B=A
02560 741400 SZL /CAN NOT OVERFLOW
02561 740040 HLT /OVERFLOW FAILED
02562 762550 LAW BMNSAT /MAKE JMP FOR SCOPE
.EJECT

```

```

/FIFTH TEST IN THIS SERIES
/IS TEST (A+B)-A = B
02563 744000 ABMATS CLL
02564 203056 LAC SUMPOS
02565 303052 ADD ANEG
02566 543053 SAD BPOS
02567 602573 JMP ,+4
02570 740040 E407 HLT
02571 203053 LAC RPOS
02572 740040 HLT
02573 741400 OFLCK5 SZL /CAN OVERFLOW SNL IF A+B OVERFLOW
02574 740040 E408 HLT /ILLEGAL LINK
02575 762563 LAW ABMATS /MAKE JMP FOR SCOPE
/
/SIXTH TEST IN THIS SERIES
/IS TEST (B-A)+B = -A
02576 744000 BMAMBT CLL
02577 203057 LAC BMASUM
02600 303054 ADD BNEG
02601 543052 SAD ANEG
02602 602606 JMP ,+4
02603 740040 E409 HLT
02604 203052 LAC ANEG
02605 740040 HLT
02606 741400 OFLCK6 SZL /CAN NOT OVERFLOW
02607 740040 E410 HLT
02610 762576 LAW BMAMBT /MAKE JMP FOR SCOPE
/
/SEVENTH TEST IN THIS SERIES
/IS (-A-B)+A = -B
02611 744000 MABPAT CLL
02612 203055 LAC SUMNEG
02613 303051 ADD APOS
02614 543054 SAD BNEG
02615 602621 JMP ,+4
02616 740040 E411 HLT
02617 203054 LAC BNEG
02620 740040 HLT
02621 741400 OFLCK7 SZL /CAN BE OVERFLOW IF A+B OVERFLOW THEN IS SNL
02622 740040 E412 HLT /ILLEGAL LINK
02623 762611 LAW MABPAT /MAKE JMP FOR SCOPE
,EJECT

```

/EIGHTH TEST OF THE SERIES

/IS (A=B) *B = A

02624	744000	AMBPBT	CLL	
02625	203060		LAC AMBSUM	
02626	303053		ADD BPOS	
02627	543051		SAD APOS	
02630	602634		JMP ,+4	
02631	740040	E413	HLT	
02632	203051		LAC APOS	
02633	740040		HLT	
02634	741400	OFLCK8	SZL	/CAN NOT OVERFLOW
02635	740040	E414	HLT	
02636	762624	LAW AMBPBT		/MAKE JMP FOR SCOPE

/

/9TH TEST OF SERIES

/NOW TEST AC = 777777 + A = A

/

02637	754001	M0ACPA	CLL:CLAICMA	/SET AC = 777777
02640	303051		ADD APOS	/+ A
02641	543051		SAD APOS	/SHOULD = A
02642	602646		JMP ,+4	/TEST LINK
02643	740040	E415	HLT	/FAILED RESULTS
02644	203051		LAC APOS	
02645	740040		HLT	/DISPLAY A
02646	741400	OFLCK9	SZL	/CANNOT OVERFLOW
02647	740040	E416	HLT	/OVERFLOW FAILED L = 1
02650	762637	LAW M0ACPA		/MAKE JMP FOR SCOPE
			,EJECT	

```

/ THE NEXT SERIES OF TESTS
/ ARE ADD SEQUENCES THE RESULTS
/ OF WHICH HAVE ALREADY BEEN
/ COMPUTED AND VERIFIED
/
/ FIRST SERIES TESTS A+B OK, THEN (A+B)-A = B
/ SEE ABMATS FOR SHORTER TEST OR APLSBT OR MZACPA
/ NOW TRY A+B=A = B
SERS01  CLLICLAICMA
        ADD APOS
        ADD BPOS
        ADD ANEG
        SAD BPOS
        JMP ,+4
E417    HLT
        LAC BPOS
        HLT
OFLCH1  SZL          /OR SNL IF A+B OVERFLOW
E418    HLT          /LINK FAILURE
        LAW SERS01   /MAKE JMP FOR SCOPE
/
/ HAVE TESTED B=A PREVIOUS
/ SEE BMNSAT FOR SHORTER TEST
/ NOW TRY A+B-A=A = B-A
SERS02  CLLICLAICMA
        ADD APOS
        ADD BPOS
        ADD ANEG
        ADD ANEG
        SAD BMASUM
        JMP ,+4
E419    HLT
        LAC BMASUM
        HLT
OFLCH2  SNL          /OR SZL IF NO OVERFLOW
E420    HLT
        LAW SERS02   /MAKE JMP FOR SCOPE
        .EJECT

```

```

02651  754001
02652  303051
02653  303053
02654  303052
02655  543053
02656  602662
02657  740040
02660  203053
02661  740040
02662  741400
02663  740040
02664  762651

```

```

02665  754001
02666  303051
02667  303053
02670  303052
02671  303052
02672  543057
02673  602677
02674  740040
02675  203057
02676  740040
02677  740400
02700  740040
02701  762665

```

/HAVE TESTED (B-A)-B = -A PREVIOUS
 /SEE BMAMBT FOR SHORTER TEST
 /NOW TRY A+B-A-A-B = -A

02702	754001	SERS03	CLL!CLA!CMA	
02703	303051		ADD APOS	
02704	303053		ADD BPOS	
02705	303052		ADD ANEG	
02706	303052		ADD ANEG	
02707	303054		ADD BNEG	
02710	543052		SAD ANEG	
02711	602715		JMP ,+4	
02712	740040	E421	HLT	
02713	203052		LAC ANEG	
02714	740040		HLT	
02715	741400	OFLCH3	SZL	/SNL IF A+B OVERFLOW
02716	740040	E422	HLT	/OVERFLOW FAILED
02717	762702		LAW SERS03	/MAKE JMP FOR SCOPE

/
 /HAVE TEST -A-B NOW TRY A+B-A-A-B-B = -A-B
 /SEE MAPLMB FOR SHORTER TEST

02720	754001	SERS04	CLL!CLA!CMA	
02721	303051		ADD APOS	
02722	303053		ADD BPOS	
02723	303052		ADD ANEG	
02724	303052		ADD ANEG	
02725	303054		ADD BNEG	
02726	303054		ADD BNEG	
02727	543055		SAD SUMNEG	
02730	602734		JMP ,+4	
02731	740040	E423	HLT	
02732	203055		LAC SUMNEG	
02733	740040		HLT	
02734	741400	OFLCH4	SZL	/SNL IF A+B OVERFLOW
02735	740040	E424	HLT	/OVERFLOW FAILED OR LINK FAILED
02736	762720		LAW SERS04	/MAKE JMP FOR SCOPE LOOP
			.EJECT	

```

/HAVE TESTED (+A+B)*A = -B NOW A+B-A-A-B-B+A = -B
/USE MABPAT FOR SHORTER TEST
SERSE5  CLL:CLA:OMA
        ADD APOS
        ADD BPOS
        ADD ANEG
        ADD ANEG
        ADD BNEG
        ADD BNEG
        ADD APOS
        SAD BNEG
        JMP ,+4
E425   HLT
        LAC BNEG
        HLT
OFLCH5 SNL                /OR SZL IF A+B DO NOT OVERFLOW
E426   HLT                /LINK OR OVERFLOW FAILED
        LAW SERSE5        /MAKE JMP FOR SCOPE

```

```

/
/HAVE DONE +B+A PREVIOUSLY
/NOW DO A+B-A-A-B-B+A+A = +B+A
/USE AMNSBT FOR SHORTER TEST
SERSE6  CLL:CLA:OMA
        ADD APOS
        ADD BPOS
        ADD ANEG
        ADD ANEG
        ADD BNEG
        ADD BNEG
        ADD APOS
        ADD APOS
        SAD AMBSUM
        JMP ,+4
E427   HLT
        LAC AMBSUM
        HLT
OFLCH6 SZL                /OR SNL IF A+B OVERFLOW
E428   HLT                /OVERFLOW OR LINK FAILED
        LAW SERSE6        /MAKE JMP FOR SCOPE
        .EJECT

```

```

02737  754001
02740  303051
02741  303053
02742  303052
02743  303052
02744  303054
02745  303054
02746  303051
02747  543054
02750  602754
02751  740040
02752  203054
02753  740040
02754  740400
02755  740040
02756  762737

02757  754001
02760  303051
02761  303053
02762  303052
02763  303052
02764  303054
02765  303054
02766  303051
02767  303051
02770  543060
02771  602775
02772  740040
02773  203060
02774  740040
02775  741400
02776  740040
02777  762757

```

/HAVE DONE (-B+A)+B PREVIOUSLY
 /NOW DOE A+B-A-A-B-B+A+A+B = A
 /USE AMBPBT FOR SHORTER EST

03000	754001	SERS27	CLL:CLA:OMA	
03001	303051		ADD APOS	
03002	303053		ADD BPOS	
03003	303052		ADD ANEG	
03004	303052		ADD ANEG	
03005	303054		ADD BNEG	
03006	303054		ADD BNEG	
03007	303051		ADD APOS	
03010	303051		ADD APOS	
03011	303053		ADD BPOS	
03012	543051		SAO APOS	
03013	603017		JMP ,+4	
03014	740040	E429	HLT	
03015	203051		LAC APOS	
03016	740040		HLT	
03017	740400	OPLCH7	SNL	/OR SZL IF A+B NOT OVERFLOW
03020	740040	E430	HLT	/LINK OR OVERFLOW FAILED
03021	763000	LAW SERS07		/MAKE JMP FOR SCOPE LOOP

/

/AFTER ONE PASS
 /MAKE ALL B CONSTANTS A
 /AND MAKE ALL A CONSTANTS B

03022	443062	CONCHG	ISZ PASS2	/2ND PASS
03023	603044		JMP CKLP	/YES DONE 2ND
03024	203051		LAC APOS	/A
03025	043053		DAC BPOS	/IS NOW B
03026	203054		LAC BNEG	/BNEG
03027	043052		DAC ANEG	/IS ANEG
03030	740001		CMA	
03031	043051		DAC APOS	/B IS A
03032	203053		LAC BPOS	
03033	740001		CMA	/ANEG
03034	043054		DAC BNEG	/IS NEG
03035	203057		LAC BMSUM	
03036	040010		DAC 10	
03037	203060		LAC AMBSUM	/A=B
03040	043057		DAC BMSUM	/IS NOW A=B
03041	200010		LAC 10	/B=A
03042	043060		DAC AMBSUM	/IS NOW A=B
03043	602507		JMP APLSBT	/OVERFLOW SERUP
			.EJECT	

BX8K

BX8K

03044 447517
 03045 602415
 03046 106336
 03047 106362
 03052 603063

CKLP ISZ WORK3
 JMP RANADD
 JMS GENRAN
 JMS CKNO
 JMP ADEDON

/CHECK DONE LOOPING
 /LOOP
 /GET NO. FOR NEXT LOOP

03051 000000
 03052 000000
 03053 000000
 03054 000000
 03055 000000
 03056 000000
 03057 000000
 03060 000000

/
 /
 APOS 0 /A
 ANEG 0 /-A
 BPOS 0 /B
 BNEG 0 /-B
 SUMNEG 0 /-A+(-B)
 SUMPOS 0 /A+B
 BMASUM 0 /B*(-A)
 AMBSUM 0 /A*(-B)

03061 000000

/
 MSKBIT 0
 ,EJECT


```

03062 000000 PASS2 0
/GET A RANDOM NUMBER AND ITS 1'S COMPLEMENT
/EACH BIT WILL HAVE A 2 IN ONE OF THE TWO NUMBERS
/MAKE THE 0 BIT = 1 AND ADD THE NUMBERS BOTH WAYS
/FIRST ADD IS THE (AC) IS THE ALTERED 2 = 1
/SECOND ADD IS THE (MB) IS THE ALTERED 2 = 1
/THE RESULT OF BOTH ADDS SHOULD = THE ALTERED BIT = 1
/
03063 106336 ADEDON JMS GENRAN /GET RANDOM NUMBER
03064 043051 DAC APOS /SAVE IT
03065 740001 CMA /MAKE ONES COMPLEMENT
03066 043052 DAC ANEG /AND SAVE IT
/
/THE FIRST BIT TO BE ALTERED IS 0 THEN CONTINUE TO 17
03067 207435 LAC K400K
03070 043061 DAC MSKBIT
/
/SET UP NEXT BIT TO TEST = ALTERED NUMBER GOES TO BPOS
03071 203051 BISETU LAC APOS
03072 503061 AND MSKBIT
03073 740200 SZA /DOES APOS BIT = 0
03074 603103 JMP MODNEG /NO ALTER ANEG
03075 203051 LAC APOS
03076 243061 XOR MSKBIT
03077 043053 DAC BPOS /MODIFIED NUMBER GOES TO APOS
03100 203052 LAC ANEG
03101 043054 DAC BNEG /UNMOD NUMBER GOES TO BNEG
03102 603110 JMP BITTS1
/
/THE ONES COMP NUMBER HAS THE 0 BIT MODIFY IT
03103 203052 MODNEG LAC ANEG
03104 243061 XOR MSKBIT
03105 043053 DAC BPOS /MOD NUMBER TO BPOS
03106 203051 LAC APOS
03107 043054 DAC BNEG /UNMOD NUMBER TO BNEG
/
/COMPLEMENTED BIT TEST1 (AC) = MODIFIED NUMBER AT ADD
/
03110 744000 BITTS1 CLL
03111 203053 LAC BPOS /GET MODIFIED NUMBER
03112 303054 ADD BNEG /ADD UNMODIFIED
03113 543061 SAD MSKBIT /RESULT SHOULD = BIT CHANGED
03114 603120 JMP ,+4
03115 740040 E431 HLT /DISPLAY INCORRECT RESULTS
03116 203061 LAC MSKBIT
03117 740040 HLT /DISPLAY BIT ALTERED AND EXP
03120 741400 OFLCH8 SZL /NO OVERFLOW
03121 740040 E432 HLT /OVERFLOW NOT ALLOWED
03122 763110 LAW BITTS1 /MAKE JMP FOR SCOPE LOOP
.EJECT

```

```

/COMP BIT TEST 2 (MB) = MODIFIED NUMBER AT ADD
/
03123 744000 BITTS2 CLL
03124 203054 LAC RNEG /GET UNMODIFIED NUMBER
03125 303053 ADD RPOS /ADD MODIFIER
03126 543061 SAD MSKBIT /RESULT SHOULD = BIT CHANGED
03127 603133 JMP ,+4 /OK
03130 740040 E433 HLT /DISPLAY INCORRECT RESULTS
03131 203061 LAC MSKBIT
03132 740040 HLT /DISPLAY BIT ALTERED AND EXP
03133 741400 OFLCH9 SZL /SHOULD NOT OVERFLOW
03134 740040 E434 HLT
03135 763123 LAW BITTS2 /MAKE JMP FOR SCOPE LOOP
/
/POSITION MASK BIT OVER 1 PLACE
/IF 17 HAS BEEN DONE CONTINUE
/
03136 203061 LAC MSKBIT /GET LAST
03137 744020 RCR /POSITION
03140 043061 DAC MSKBIT /SAVE
03141 740200 SZA /DONE ALL BITS
03142 603071 JMP BISETU /DO FOR NEXT BIT
/
/END OF TEST SEQUENCE
/
03143 447517 ISZ WORK3 /CHECK DONE LOOPING
03144 603063 JMP ADEDON /LOOP
03145 106336 JMS GENRAN /GET NO. FOR NEXT LOOP
03146 106362 JMS CKNO
03147 750004 LAS /CHECK FOR CONTINUOUS LOOP
03150 742010 RTL /CK ACS 2
03151 741100 SPA
03152 602415 JMP RANADD /LOOP
/PDP-15 BASIC EXERCISER - TAPE 4
/TEST SAD
/
03153 207411 SADAC LAC K0 /AC = 0
03154 547411 SAD K0
03155 741000 SKP
03156 740040 E435 HALT /ERROR, SAD K0 SKIPPED
/
03157 207411 LAC K0 /AC = 0
03160 547454 SAD K7S
03161 740040 E436 HALT /ERROR, SAD K7S FAILED TO SKIP
/
03162 207454 LAC K7S /AC = 1'S
03163 547411 SAD K0
03164 740040 E437 HALT /ERROR, SAD K0 FAILED TO SKIP
/
03165 207454 LAC K7S /AC = 1'S
03166 547454 SAD K7S
03167 741000 SKP
03170 740040 E438 HALT /ERROR, SAD K7S SKIPPED
/
/SAD, TAD

```

03171 750000
03172 347411
03173 547411
03174 741000
03175 740040

E439

/
CLA
TAD K0
SAD K0
SKP
HALT

/AC = 0

/ERROR, SAD K0 SKIPPED

03176 750000
03177 347411
03200 547454
03201 740040

E440

/
CLA
TAD K0
SAD K7S
HALT

/AC = 0

/ERROR, SAD K7S FAILED TO SKIP

03202 750000
03203 347454
03204 547411
03205 740040

E441

/
CLA
TAD K7S
SAD K0
HALT

/AC = 0

/ERROR, SAD K0 FAILED TO SKIP

03206 750000
03207 347454
03210 547454
03211 741000
03212 740040

E442

/
CLA
TAD K7S
SAD K7S
SKP
HALT

/AC = 0

/ERROR, SAD K7S SKIPPED

/EJECT

/SEQUENTIAL SAD

03213	207411	LAC K0	/AC = 0
03214	547454	SAD K7S	
03215	760001	LAW 1	/760001
03216	547454	SAD K7S	
03217	760002	LAW 2	/760002
03220	547454	SAD K7S	
03221	760004	LAW 4	/760004
03222	547454	SAD K7S	
03223	760010	LAW 10	/760010
03224	547454	SAD K7S	
03225	760020	LAW 20	/760020
03226	547454	SAD K7S	
03227	760040	LAW 40	/760040
03230	740200	SEA	
03231	740040	HALT	/ERROR, AC NT 0. CONTENTS OF /AC = LAST SAD THAT FAILED

E443

/TEST SAD, SKP SERIES

03232	750000	CLA	/AC = 0
03233	547454	SAD K7S	
03234	760001	LAW 1	/760001
03235	741000	SKP	
03236	760002	LAW 2	/760002
03237	547454	SAD K7S	
03240	760004	LAW 4	/760004
03241	741000	SKP	
03242	760010	LAW 10	/760010
03243	547454	SAD K7S	
03244	760020	LAW 20	/760020
03245	741000	SKP	
03246	760040	LAW 40	/760040
03247	740200	SEA	
03250	740040	HALT	/ERROR, AC NOT 0, CONTSNTS /OP AC = LAST SAD OR SKP

E444

03251	447517	ISZ WORK3	/CHECK DONE LOOPING
03252	603153	JMP SADAC	/LOOP
03253	106336	JMS GENRAN	/GET NO. FOR NEXT LOOP
03254	106362	JMS CKNO	

.EJECT

/TEST DZM

03255	207533	DZMAC	LAC KHALT	/AC = 740040
03256	151111		DZM 11111	/ADDR 1111 OR 01111
03257	211111		LAC 11111	
03260	740200		SEA	
03261	740040	E445	HALT	/ERROR, DZM FAILED AT 11111 /OR 01111
/				
03262	207533		LAC KHALT	/AC = 740040
03263	152222		DZM 12222	
03264	212222		LAC 12222	
03265	740200		SEA	
03266	740040	E446	HALT	/ERROR, DZM FAILED AT 1222 OR /02222
/				
03267	207533		LAC KHALT	/AC = 740040
03270	153333		DZM 13333	
03271	213333		LAC 13333	
03272	740200		SEA	
03273	740040	E447	HALT	/ERROR, DZM FAILED AT 13333 OR /03333
/				
03274	207533		LAC KHALT	/AC = 740040
03275	154444		DZM 14444	
03276	214444		LAC 14444	
03277	740200		SEA	
03300	740040	E448	HALT	/ERROR, DZM FAILED AT 14444 /OR 04444
/				
03301	207533		LAC KHALT	/AC = 740040
03302	155555		DZM 15555	
03303	215555		LAC 15555	
03304	740200		SEA	
03305	740040	E449	HALT	/ERROR, DZM FAILED AT 15555 /OR 05555
/				
03306	207533		LAC KHALT	/AC = 740040
03307	156666		DZM 16666	
03310	216666		LAC 16666	
03311	740200		SEA	
03312	740040	E450	HALT	/ERROR, DZM FAILED AT 16666 /OR 06666
/				
03313	207533		LAC KHALT	/AC = 740040
03314	157777		DZM 17777	
03315	217777		LAC 17777	
03316	740200		SEA	
03317	740040	E451	HALT	/ERROR, DZM FAILED AT 17777 /OR 07777

.EJECT

```

/
03320 207533 LAC KHALT /AC = 740040
03321 152525 DEM 12525
03322 212525 LAC 12525
03323 740200 SZA
03324 740040 E452 HALT /ERROR, DEM FAILED AT 12525
/ OR 02525
/
03325 207533 LAC KHALT /AC = 740040
03326 152525 DEM 15252
03327 212525 LAC 15252
03330 740200 SZA
03331 740040 E453 HALT /ERROR, DEM FAILED AT 15252 OR 02525
/
/TEST AC AFTER A DEM
/
03332 207454 LAC K7S /AC = 777777
03333 157777 DEM 17777
03334 740001 CMA
03335 740200 SZA
03336 740040 E454 HALT /ERROR, AC CHANGED AFTER A DEM
/
//TEST AC, LINK, ADR, 17777 OR 07777 AFTER A DEM
/
03337 754001 CLA: CMA: CLL /AC = 1'S, LINK = 0
03340 307454 ADD K7S
03341 157777 DEM 17777
03342 740001 CMA
03343 740200 SZA
03344 740040 E455 HALT /ERROR, AC NOT 1'S AFTER A DEM
03345 741400 SZL
03346 740040 E456 HALT /ERROR, LINK NOT 0
03347 217777 LAC 17777
03350 740200 SZA
03351 740040 E457 HALT /ERROR, DEM FAILED AT 177777 OR 07777
/
/SEQUENTIAL DEM
/
03352 207454 LAC K7S /AC = 1'S
03353 152525 DEM 12525
03354 152525 DEM 15252
03355 157777 DEM 17777
03356 150000 DEM 10000
03357 740001 CMA /AC = 0
03360 750200 CLA: SZA
03361 740040 E458 HALT /ERROR, AC NOT 1'S AFTER
/DEM SERIES
.EJECT

```

03362	352525		TAD 12525	
03363	355252		TAD 15252	
03364	357777		TAD 17777	
03365	350000		TAD 10000	
03366	740200		SZA	
03367	740040	E459	HALT	/ERROR, DZM FAILED
		/		
03370	447517		ISZ WORK3	/CHECK DONE LOOPING
03371	603255		JMP DZMAC	/LOOP
03372	106336		JMS GENRAN	/GET NO. FOR NEXT LOOP
03373	106362		JMS CKNO	
		/		
		/		
		/	TEST DAC	
		/		
03374	207455	DACAC	LAC K51S	/AC = 11111
03375	051111		DAC 11111	
03376	551111		SAD 11111	
03377	741000		SKP	
03400	740040	E460	HALT	/ERROR, DAC ADR CONTENTS NOT EQUAL /TO AC, DAC FAILED
03401	207456		LAC K12S	/AC = 12222
03402	052222		DAC 12222	
03403	552222		SAD 12222	
03404	741000		SKP	
03405	740040	E461	HALT	/ERROR, 122222 OR 022222 CONTENTS /NOT = TO AC, DAC FAILED
03406	207457		LAC K13S	/AC = 13333
03407	053333		DAC 13333	
03410	553333		SAD 13333	
03411	741000		SKP	
03412	740040	E462	HALT	/ERROR, 133333 OR 033333 CONTENTS /NOT = TO AC DAC FAILED
03413	207460		LAC K14S	/AC = 14444
03414	054444		DAC 14444	
03415	554444		SAD 14444	
03416	741000		SKP	
03417	740040	E463	HALT	/ERROR, 144444 OR 033333 CONTENTS /NOT = TO AC, DAC FAILED
03420	207461		LAC K15S	/AC = 15555
03421	055555		DAC 15555	
03422	555555		SAD 15555	
03423	741000		SKP	
03424	740040	E464	HALT	/ERROR, 155555 OR 055555 CONTENTS /NO = AC, DAC FAILED
			.EJECT	

BX8K

BX8K

03425	207462		LAC K16S	/AC = 166666
03426	056666		DAC 16666	
03427	556666		SAD 16666	
03430	741000		SKP	
03431	740040	E465	HALT	/ERROR, 16666 OR 06666 CONTENTS /NOT = AC, DAC FAILED /AC = 17777
03432	207463		LAC K17S	
03433	057777		DAC 17777	
03434	557777		SAD 17777	
03435	741000		SKP	
03436	740040	E466	HALT	/ERROR, 17777 OR 07777 CONTENTS /NOT = AC, DAC FAILED /AC = 252525
03437	207466		LAC K010	
03440	052525		DAC 12525	
03441	552525		SAD 12525	
03442	741000		SKP	
03443	740040	E467	HALT	/ERROR, 12525 OR 02525 CONTENTS /AC = AC, DAC FAILED /AC = 525252
03444	207467		LAC K101	
03445	055252		DAC 15252	
03446	555252		SAD 15252	
03447	741000		SKP	
03450	740040	E468	HALT	/ERROR, 15252 OR 05252 CONTENTS /NOT = AC, DAC FAILED
/				
/SEQUENTIAL DAC				
/				
03451	744000		CLL	/L = 0
03452	207454		LAC K7S	/AC = 1'S
03453	052525		DAC 12525	
03454	055252		DAC 15252	
03455	057777		DAC 17777	
03456	051000		DAC 11000	
03457	051111		DAC 11111	
03460	740001		CMA	/AC = 0
03461	750200		CLA:SZ A	
03462	740040	E469	HALT	/ERROR, AC NOT 1'S AFTER DAC SERIES
03463	312525		ADD 12525	/ONES
03464	315252		ADD 15252	/ONES
03465	317777		ADD 17777	/ONES
03466	311000		ADD 11000	/ONES
03467	311111		ADD 11111	/ONES
03470	740001		CMA	/AC = 0
03471	740200		SZ A	
03472	740040	E470	HALT	/ERROR, DAC FAILED, ONE OR MORE /ADDRESSES NOT ONES
/				
03473	447517		ISZ WORK3	/CHECK DONE LOOPING
03474	603374		JMP DACAC	/LOOP
03475	106336		JMS GENRAN	/GET NO, FOR NEXT LOOP
03476	106362		JMS CKNO	
			,EJECT	

/TEST ISZ

```

/
03477 207411 ISZAC LAC K0 /AC = 0
03500 250100 DAC 10100
03501 450100 ISZ 10100
03502 751001 SKP:CLA:DMA
03503 740040 E471 HALT /ERROR, ISZ SKIPPED
03504 507412 AND K1 /AC = 1
03505 550100 SAD 10100
03506 741000 SKP
03507 740040 E472 HALT /ERROR, 10100 OR 00100 NOT 1
/ISZ FAILED
/AC = 377777

03510 207511 LAC M400K
03511 050100 DAC 10100
03512 450100 ISZ 10100
03513 751001 SKP:CLA:DMA
03514 740040 E473 HALT /ERROR, ISZ SKIPPED
03515 507435 AND K400K
03516 550100 SAD 10100
03517 741000 SKP
03520 740040 E474 HALT /ERROR, 10100 OR 00100 NOT 400000
/ISZ FAILED
/AC = 777776

03521 207503 LAC M1
03522 050100 DAC 10100
03523 450100 ISZ 10100
03524 751001 SKP:CLA:DMA
03525 740040 E475 HALT /ERROR, ISZ SKIPPED
03526 507454 AND K75
03527 550100 SAD 10100
03530 741000 SKP
03531 740040 E476 HALT /ERROR, 10100 OR 00100 NOT 777777
/ISZ FAILED
/AC = 777776

03532 207503 LAC M1
03533 057777 DAC 17777
03534 457777 ISZ 17777
03535 751001 SKP:CLA:DMA
03536 740040 E477 HALT /ERROR, ISZ SKIPPED
03537 507454 AND K75
03540 557777 SAD 17777
03541 741000 SKP
03542 740040 E478 HALT /ERROR, 1777 OR 07777 NOT 777777
/ISZ FAILED
/AC = 377777

03543 207511 LAC M400K
03544 057777 DAC 17777
03545 457777 ISZ 17777
03546 751001 SKP:CLA:DMA
03547 740040 E479 HALT /ERROR, ISZ SKIPPED
03550 507435 AND K400K
03551 557777 SAD 17777
03552 741000 SKP
.EJECT

```

	BX8K	BX8K		
03553	740040	E480	HALT	/ERROR, 17777 OR 07777 NOT 400000 /ISZ FAILED
03554	207411		LAC K0	
03555	057777		DAC 17777	
03556	457777		ISZ 17777	
03557	751001		SKP:CLA:OMA	
03560	740040	E481	HALT	/ERROR, ISZ SKIPPED
03561	507412		AND K1	
03562	557777		SAD 17777	
03563	741000		SKP	
03564	740040	E482	HALT	/ERROR, 17777 OR 07777 NOT 1 /ISZ FAILED
03565	750000		CLA	/AC = 0
03566	247454		XOR K7S	/AC = 1'S
03567	051111		DAC 11111	
03570	451111		ISZ 11111	
03571	740040	E483	HALT	/ERROR, ISZ FAILED TO SKIP
03572	211111		LAC 11111	
03573	740200		SZA	
03574	740040	E484	HALT	/ERROR, 11111 OR 01111 NOT 2 /ISZ FAILED
03575	750000		CLA	/AC = 0
03576	247454		XOR K7S	/AC = 1'S
03577	052222		DAC 12222	
03600	452222		ISZ 12222	
03601	740040	E485	HALT	/ERROR, ISZ FAILED TO SKIP
03602	212222		LAC 12222	
03603	740200		SZA	
03604	740040	E486	HALT	/ERROR, 12222 OR 02222 NOT 0 /ISZ FAILED
03605	750000		CLA	
03606	247454		XOR K7S	/AC = 1'S
03607	053333		DAC 13333	
03610	453333		ISZ 13333	
03611	740040	E487	HALT	/ERROR, ISZ DID NOT SKIP
03612	213333		LAC 13333	
03613	740200		SZA	
03614	740040	E488	HALT	/ERROR, 13333 OR 03333 NOT 0 /ISZ FAILED
03615	750000		CLA	
03616	247454		XOR K7S	/AC = 1'S
03617	054444		DAC 14444	
03620	454444		ISZ 14444	
03621	740040	E489	HALT	/ERROR, ISZ DID NOT SKIP
03622	214444		LAC 14444	
03623	740200		SZA	
03624	740040	E490	HALT	/ERROR, 14444 OR 04444 NOT 0 /ISZ FAILED

.EJECT

03625	750000		CLA	
03626	247454		XOR K7S	/AC = 1'S
03627	055555		DAC 15555	
03630	455555		ISZ 15555	
03631	740040	E491	HALT	/ERROR, ISZ DID NOT SKIP
03632	215555		LAC 15555	
03633	740200		SEA	
03634	740040	E492	HALT	/ERROR, 15555 OR 05555 NOT 0 /ISZ FAILED
03635	750000		CLA	
03636	247454		XOR K7S	/AC = 1'S
03637	056666		DAC 16666	
03640	456666		ISZ 16666	
03641	740040	E493	HALT	/ERROR, ISZ DID NOT SKIP
03642	216666		LAC 16666	
03643	740200		SEA	
03644	740040	E494	HALT	/ERROR, 16666 OR 06666 NOT 0 /ISZ FAILED
03645	750000		CLA	
03646	247454		XOR K7S	/AC = 1'S
03647	057777		DAC 17777	
03650	457777		ISZ 17777	
03651	740040	E495	HALT	/ERROR, ISZ DID NOT SKIP
03652	217777		LAC 17777	
03653	740200		SEA	
03654	740040	E496	HALT	/ERROR, 17777 OR 07777 NOT 0 /ISZ FAILED
03655	750000		CLA	
03656	247454		XOR K7S	/AC = 1'S
03657	052525		DAC 12525	
03660	452525		ISZ 12525	
03661	740040	E497	HALT	/ERROR, ISZ DID NOT SKIP
03662	212525		LAC 12525	
03663	740200		SEA	
03664	740040	E498	HALT	/ERROR, 12525 OR 02525 NOT 0 /ISZ FAILED
03665	750000		CLA	
03666	247454		XOR K7S	/AC = 1'S
03667	055252		DAC 15252	
03670	455252		ISZ 15252	
03671	740040	E499	HALT	/ERROR, ISZ DID NOT SKIP
03672	215252		LAC 15252	
03673	740200		SEA	
03674	740040	E500	HALT	/ERROR, 15252 OR 05252 NOT 0 /ISZ FAILED

.EJECT

/TEST ISZ, SKP

```

/
03675 207454 LAC K7S /AC = 1'S
03676 052525 DAC 12525 /12525 OR 02525
03677 055252 DAC 15252 /15252 OR 05252
03700 057777 DAC 17777 /17777 OR 07777
03701 051000 DAC 11000 /11000 OR 01000
03702 050100 DAC 10100 /10100 OR 00100
03703 452525 ISZ 12525
03704 741000 SKP
03705 455252 ISZ 15252
03706 741000 SKP
03707 457777 ISZ 17777
03710 741000 SKP
03711 451000 ISZ 11000
03712 741000 SKP
03713 450100 ISZ 10100
03714 740040 E501 HALT /ERROR, ISZ DID NOT SKIP
03715 312525 ADD 12525
03716 315252 ADD 15252
03717 317777 ADD 17777
03720 311000 ADD 11000
03721 310100 ADD 10100
03722 740001 CMA
03723 740200 SZA
03724 740040 E502 HALT /ERROR, ALL ADRS. NOT 0
/

```

/SEQUENTIAL ISZ, NO=SKIP

```

/
03725 207511 LAC M400K /AC = 377777
03726 052525 DAC 12525 /OR 02525
03727 055252 DAC 15252 /OR 05252
03730 057777 DAC 17777 /OR 07777
03731 051000 DAC 11000 /OR 01000
03732 050100 DAC 10100 /OR 00100
03733 452525 ISZ 12525
03734 455252 ISZ 15252
03735 457777 ISZ 17777
03736 451000 ISZ 11000
03737 450100 ISZ 10100
03740 750000 CLA /AC = 0
03741 312525 ADD 12525
03742 315252 ADD 15252
03743 317777 ADD 17777
03744 311000 ADD 11000
03745 310100 ADD 10100
03746 247436 XOR K402K /RESULT = 40002
03747 740200 SZA
03750 740040 E503 HALT /ERROR, ALL ADRES, NOT 40002
.EJECT

```

```

/TEST ISZ=SKP, SKIP
/
03751 207454 LAC K7S /AC = 1'S
03752 055252 DAC 15252
03753 455252 ISZ 15252
03754 741000 SKP
03755 741000 SKP
03756 740040 E504 HALT /ERROR, ISZ=SKIP DID NOT SKIP
/
/TEST SKP=ISZ, SKIP
/
03757 207454 LAC K7S /AC = 17S
03760 055252 DAC 15252
03761 741000 SKP
03762 740000 NOP
03763 455252 ISZ 15252
03764 740040 E505 HALT /ERROR, SKP=ISZ DID NOT SKIP
/
/TEST SKP=ISZ, NO=SKIP
/
03765 207411 LAC K0 /AC = 0
03766 055252 DAC 15252
03767 741000 SKP
03770 740000 NOP
03771 455252 ISZ 15252
03772 741000 SKP
03773 740040 E506 HALT /ERROR, SKP=ISZ SKIPPED
/
03774 447517 ISZ WORK3 /CHECK DONE LOOPING
03775 603477 JMP ISZAC /LOOP
03776 106336 JMS GENRAN /GET NO. FOR NEXT LOOP
03777 106362 JMS CKNO
.EJECT

```

```

/TEST JMP
/
04000 207552 LAC JMPRET
04001 740200 SZA
04002 740040 E507 HALT /ERROR JMP ,=7, ,+4 OR ,+5 FAILED
04003 204163 INIT4K LAC JMPSEQ
04004 047552 DAC JMPRET /LOAD 4K WITH JMP TO 70
04005 204005 LAC ,
04006 507437 AND K10K /SEE IF IN UPPER 4K NOW
04007 740200 SZA
04010 604014 JMP ,+4 /IN UPPER 4K
04011 207437 LAC K10K /LOWER 4K
04012 047513 DAC RJCNT
04013 604020 JMP ,+5
04014 207421 LAC K20
04015 047513 DAC RJCNT
04016 741000 SKP
04017 147552 DZM JMPRET /CLEAR ERROR TABLE
04020 204163 LAC JMPSEQ
04021 067513 DAC RJCNT /STORE JMP 70
04022 447513 ISZ RJCNT /INCR, ADDRESS
04023 207513 LAC RJCNT
04024 546007 SAD K17777 /WILL = SAD 07777 WHEN IN
04025 741000 SKP / UPPER 4K
04026 604017 JMP ,=7
04027 207552 LAC JMPRET
04030 740200 SZA
04031 740040 E508 HALT /ERROR, JMPP,+4, ,+5 OR ,=7 FAILED
04032 204164 LAC MOD /PRESS CONTINUE TO DETERMINE
04033 044000 DAC E507=2 /JMP FAILURE
04034 740000 MODX NOP
/
04035 207553 LAC J111
04036 740200 SZA
04037 740040 E509 HALT /ERROR, RJMP OR JMP TO 11111
/OR 01111 FAILED
04040 204165 LAC RJ111
04041 047553 DAC J111 /STORE JMP ADDRESS IN TABLE
04042 051111 DAC 11111
04043 611111 JMP 11111 /JMP TO 11111 OR 01111
04044 741000 SKP
04045 147553 RJMP1 DZM J111 /CLEAR ERROR WORD TABLE
04046 207554 LAC J222
04047 740200 SZA
04050 740040 E510 HALT /ERROR, RJMP OR JMP TO 12222
/OR 02222 FAILED
04051 204166 LAC RJ222
04052 047554 DAC J222
04053 052222 DAC 12222
04054 612222 JMP 12222 /JMP 1222 OR 02222
04055 741000 SKP
04056 147554 RJMP2 DZM J222 /CLEAR ERROR TABLE
,EJECT

```

04057	207555		LAC J333	
04060	740200		SEA	
04061	740040	E511	HALT	/ERROR, RJMP OR JMP TO 13333 /OR 03333 FAILED
04062	204167		LAC RJ333	
04063	047555		DAC J333	
04064	053333		DAC 13333	
04065	613333		JMP 13333	/JMP TO 13333 OR 03333
04066	741000		SKP	
04067	147555	RJMP3	DEM J333	/CLEAR ERROR TABLE
		/		
04070	207556		LAC J444	
04071	740200		SEA	
04072	740040	E512	HALT	/ERROR, RJMP OR JMP TO 14444 /OR 04444 FAILED
04073	204170		LAC RJ444	
04074	047556		DAC J444	
04075	054444		DAC 14444	
04076	614444		JMP 14444	/JMP TO 14444 OR 04444
04077	741000		SKP	
04100	147556	RJMP4	DEM J444	/CLEAR ERROR TABLE
		/		
04101	207557		LAC J555	
04102	740200		SEA	
04103	740040	E513	HALT	/ERROR, RJMP OR JMP TO 15555 /OR 05555 FAILED
04104	204171		LAC RJ555	
04105	047557		DAC J555	
04106	055555		DAC 15555	
04107	615555		JMP 15555	/JMP TO 15555 OR 05555
04110	741000		SKP	
04111	147557	RJMP5	DEM J555	/CLEAR ERROR TABLE
		/		
04112	207560		LAC J666	
04113	740200		SEA	
04114	740040	E514	HALT	/ERROR, RJMP OR JMP TO 16666 /OR 06666 FAILED
04115	204172		LAC RJ666	
04116	047560		DAC J666	
04117	056666		DAC 16666	
04120	616666		JMP 16666	/JMP TO 16666 OR 06666
04121	741000		SKP	
04122	147560	RJMP6	DEM J666	/CLEAR ERROR TABLE
		/		
			REJECT	

PA	67	BX8K	BX8K		
	04123	207561		LAC J777	
	04124	740200		SEA	
	04125	740040	E515	HALT	/ERROR, RJMP OR JMP TO 17777 /OR 07777 FAILED
	04126	204173		LAC RJ777	
	04127	047561		DAC J777	
	04130	057777		DAC 17777	
	04131	617777		JMP 17777	/JMP TO 17777 OR 07777
	04132	741000		SKP	
	04133	147561	RJMP7	DZM J777	/CLEAR ERROR TABLE
	04134	207563	/	LAC J252	
	04135	740200		SEA	
	04136	740040	E516	HALT	/ERROR, RJMP OR MP TO 12525 /OR 02525 FAILED
	04137	204174		LAC RJ252	
	04140	047563		DAC J252	
	04141	052525		DAC 12525	
	04142	612525		JMP 12525	/JMP TO 12525 OR 02525
	04143	741000		SKP	
	04144	147563	RJMP8	DZM J252	/CLEAR ERROR TABLE
	04145	207562	/	LAC J525	
	04146	740200		SEA	
	04147	740040	E517	HALT	/ERROR, RJMP OR JMP TO 15252 /OR 05252 FAILED
	04150	204175		LAC RJ525	
	04151	047562		DAC J525	
	04152	055252		DAC 15252	
	04153	615252		JMP 15252	/JMP TO 15252 OR 05252
	04154	741000		SKP	
	04155	147562	RJMP9	DZM J525	/CLEAR ERROR TABLE
	04156	447517	/	ISE WORK3	/CHECK DONE LOOPING
	04157	604035		JMP MODX+1	/LOOP
	04160	106336		JMS GENRAN	/GET NO. FOR NEXT LOOP
	04161	106362		JMS CKNO	
	04162	604176		JMP TSCAL	/TEST CAL
			/		
			/		/JMP CONSTANTS, THESE ARE MODIFIED WHEN IN HI 4K
			/		
	04163	600112	JMPSEQ	JMP SEQUEN	
	04164	604035	MOD	JMP MODX+1	
	04165	604045	RJ111	JMP RJMP1	
	04166	604056	RJ222	JMP RJMP2	
	04167	604067	RJ333	JMP RJMP3	
	04170	604100	RJ444	JMP RJMP4	
	04171	604111	RJ555	JMP RJMP5	
	04172	604122	RJ666	JMP RJMP6	
	04173	604133	RJ777	JMP RJMP7	
	04174	604144	RJ252	JMP RJMP8	
	04175	604155	RJ525	JMP RJMP9	
				.EJECT	


```

/TEST CAL
/
04176 207564 TSCAL LAC CAL0
04177 740200 SZA
04200 740040 E518 HALT /ERROR, CAL FROM 17757 OR 07757
04201 707704 LEM /CLEAR EXTEND MODE
04202 754000 CLA:CLL /AC = 0, LINK = 2
04203 770020 LAW 10020 /AC = 770020
04204 150704 DEM 10704 /CAL AT 10704 OR 00704
04205 207444 LAC K2021
04206 047564 DAC CAL0 /STORE ERROR CODE 2021
04207 204252 LAC RCAL0
04210 040021 DAC 21 /RJMP FROM CAL
04211 610704 JMP 10704 /JMP TO 10704 OR 00704
04212 147564 RCALS0 DEM CAL0 /CLEAR ERROR TABLE
04213 200020 LAC 20
04214 544253 SAD KCAL0 /10705 OR 00705
04215 741000 SKP
04216 740040 E519 HALT /ERROR, (20) NOT 210705 OR 200705
04217 210704 LAC 10704
04220 740200 SZA
04221 740040 E519A HALT /ERROR (10704 OR 00704) NOT 0
/
/TEST CAL LINK = 1
/
04222 207565 LAC CAL1
04223 740200 SZA
04224 740040 E520 HALT /ERROR, CAL FROM 10704 OR 00704
04225 744002 CLL:CHL /LINK = 1
04226 207445 LAC K2120
04227 047565 DAC CAL1 /STORE ERROR CODE 2120
04230 204254 LAC RCAL1
04231 040021 DAC 21 /RJMP FROM CAL
04232 610704 JMP 10704 /JMP TO 10704 OR 00704
04233 147565 RCALS1 DEM CAL1 /CLEAR ERROR TABLE
04234 200020 LAC 20
04235 544255 SAD KCALE /110705 OR 400705
04236 741000 SKP
04237 740040 E521 HALT /ERROR, (20) NOT 610705 OR 600705
04240 210704 LAC 10704
04241 740200 SZA
04242 740040 E521A HALT /ERROR (10704 OR 00704) NOT 0
/
04243 207533 LAC KHALT
04244 040021 DAC 21
04245 447517 ISZ WORK3 /CHECK DONE LOOPING
04246 604176 JMP TSCAL /LOOP
04247 106336 JMS GENRAN /GET NO. FOR NEXT LOOP
04250 106362 JMS CKNO
04251 604256 JMP TSJMS /TEST JMS

```

```

/
,EJECT

```

/CAL CONSTANTS, THESE ARE MODIFIED WHEN IN HI 4K

04252 604212
04253 210705
04254 604233
04255 610705

/
RCAL0 JMP RCALS0
KCAL0 210705
RCAL1 JMP RCALS1
KCAL1 610705
.EJECT

```

/TEST JMS
/
04256 207566 TSJMS LAC JSM71
04257 740200 SEA
04260 740040 E522 HALT /ERROR, JMS FROM 07777 TO 11111
/OR FROM 17777 TO 01111
/LINK = 0
04261 744000 CLL
04262 204543 LAC RJSM71 /JMP TO RJMS71
04263 051112 DAC 11112 /RJMP FROM JMS DESTIN
04264 204544 LAC RSM71 /JMS 11111
04265 047777 DAC 07777
04266 047566 DAC JSM71
04267 771112 LAW 11112 /AC = 771112
04270 607777 JMP 07777
04271 147566 RJMS71 DZM JSM71 /CLEAR ERROR TABLE
04272 211111 LAC 11111
04273 544602 SAD K210K
04274 741000 SKP
04275 740040 E523 HALT /ERROR, (11111 OR 01111) NOT
/210000 OR 200000
04276 207567 LAC JSM72
04277 740200 SEA
04300 740040 E524 HALT /ERROR, JMS FROM 07776 TO 12222
/OR FROM 17776 TO 02222
04301 707704 LEM
04302 744000 CLL
04303 204546 LAC RJSM72 /JMP TO RJMS72
04304 052223 DAC 12223
04305 204547 LAC RSM72 /JMS 12222
04306 047776 DAC 07776
04307 047567 DAC JSM72
04310 772223 LAW 12223 /AC = 772223
04311 607776 JMP 07776
04312 147567 RJMS72 DZM JSM72 /CLEAR ERROR TABLE
04313 212222 LAC 12222
04314 544603 SAD K277
04315 741000 SKP
04316 740040 E525 HALT /ERROR, (12222 OR 02222) NOT
/207777 OR 217777
04317 207570 LAC JSM73
04320 740200 SEA
04321 740040 E526 HALT /ERROR, JMS FROM 07775 TO 13333
/OR FROM 17775 TO 03333
04322 707704 LEM
04323 744000 CLL
04324 204551 LAC RJSM73 /JMP TO RJMS73
04325 053334 DAC 13334
04326 204552 LAC RSM73 /JMS 13333
04327 047775 DAC 07775
04330 047570 DAC JSM73
04331 773334 LAW 13334 /AC = 773334
04332 607775 JMP 07775
.EJECT

```

	BX8K	BX8K	
04333	147570	RJMS73	DZM JSM73
04334	213333		LAC 13333
04335	544604		SAD K276
04336	741000		SKP
04337	740040	E527	HALT
			/ERROR, (13333 OR 03333) NOT /207776 OR 217776
04340	207571		LAC JSM74
04341	740200		SZA
04342	740040	E528	HALT
			/ERROR, JMS FROM 07774 TO 14444 /OR FROM 17774 TO 04444
04343	707704		LEM
04344	744000		CLL
04345	204554		LAC RJSM74
04346	054445		DAC 14445
04347	204555		LAC RSM74
04350	047774		DAC 07774
04351	047571		DAC JSM74
04352	774445		LAW 14445
04353	607774		JMP 07774
04354	147571	RJMS74	DZM JSM74
04355	214444		LAC 14444
04356	544605		SAD K275
04357	741000		SKP
04360	740040	E529	HALT
			/ERROR, (14444 OR 04444) NOT /207775 OR 217775
04361	207572		LAC JSM75
04362	740200		SZA
04363	740040	E530	HALT
			/ERROR, JMS FROM 07773 TO 15555 /OR FROM 17773 TO 05555
04364	707704		LEM
04365	744000		CLL
04366	204557		LAC RJSM75
04367	055556		DAC 15556
04370	204560		LAC RSM75
04371	047773		DAC 07773
04372	047572		DAC JSM75
04373	775556		LAW 15556
04374	607773		JMP 07773
04375	147572	RJMS75	DZM JSM75
04376	215555		LAC 15555
04377	544606		SAD K274
04400	741000		SKP
04401	740040	E531	HALT
			/ERROR, (15555 OR 05555) NOT /207774 OR 217774
04402	207573		LAC JSM76
04403	740200		SZA
04404	740040	E532	HALT
			/ERROR, JMS FROM 07772 TO 16666 /OR 17772 TO 06666

.EJECT

PAGE 72

BX8K

BX8K

04405 707704
04406 744000
04407 204562
04410 056667
04411 204563
04412 047772
04413 047573
04414 776667
04415 607772
04416 147573
04417 216666
04420 544607
04421 741000
04422 740040

04423 207575
04424 740200
04425 740040

RJMS76

E533

E536

LEM
CLL
LAC RJMS76
DAC 16667
LAC RSM76
DAC 07772
DAC JSM76
LAW 16667
JMP 07772
DZM JSM76
LAC 16666
SAD K273
SKP
HALT

LAC JS252
SEA
HALT

.EJECT

/JMP TO RJMS76

/JMS 16666

/AC = 776667

/CLEAR ERROR TABLE

/ERROR, (16666 OR 06666) NOT
/207773 OR 217773

/ERROR, JMS FROM 12525 TO 15252
/OR FROM 02525 TO 05252

```

04426 744002          CLL!CML          /LINK = 1
04427 204567          LAC RJSM25       /JMP TO RJMS14
04430 055253          DAC 15253
04431 204570          LAC RSM25        /JMS 15252
04432 052525          DAC 12525
04433 047575          DAC JS252
04434 775253          LAW 15253        /AC = 775253
04435 612525          JMP 12525
04436 147575          RJMS14 DZM JS252     /CLEAR ERROR TABLE
04437 215252          LAC 15252
04440 544610          SAD K626         /612526 OR 602526
04441 741000          SKP
04442 740040          E537  HALT       /ERROR, (15252 OR 05252) NOT
                                /612526 OR 602526

04443 207576          LAC JS525
04444 740200          SEA
04445 740040          E538  HALT       /ERROR, JMS FROM 15252 TO 12525
                                /OR 05252 TO 02525
                                /LINK = 1

04446 744002          CLL!CML
04447 204572          LAC RJSM52       /RJMP TO RJMS15
04450 052526          DAC 12526
04451 204573          LAC RSM52        /JMS 12525
04452 055252          DAC 15252
04453 047576          DAC JS525
04454 772526          LAW 12526        /AC = 772526
04455 615252          JMP 15252
04456 147576          RJMS15 DZM JS525     /CLEAR ERROR TABLE
04457 212525          LAC 12525
04460 544611          SAD K615        /615253 OR 605253
04461 741000          SKP
04462 740040          E539  HALT       /ERROR, (12525 OR 02525) NOT
                                /615253 OR 605253

/PDP-15 BASIC EXERCISER = TAPE 5
/TEST JMS SERIES
/

04463 207577          LAC JSSS
04464 740200          SEA
04465 740040          E540  HALT       /ERROR, JMS SERIES FAILED
/

04466 744002          CLL!CML          /LINK = 1
04467 104470          JS1  JMS ,+1
04470 740040          E541  HALT       /ERROR, JMS SERIES
04471 104472          JS2  JMS ,+1
04472 740040          E542  HALT       /ERROR, JMS SERIES
04473 104474          JS3  JMS ,+1
04474 740040          E543  HALT       /ERROR, JMS SERIES
04475 707704          LEM
04476 744000          CLL
04477 104500          JS4  JMS ,+1
04500 740040          E544  HALT       /ERROR, JMS SERIES
04501 147577          RJMSS DZM JSSS     /CLEAR ERROR TABLE
04502 204576          LAC KJS1        /TEST JS1, LINK = 1
04503 347442          TAD K600K
04504 740001          CMA
04505 344470          TAD JS1+1

```

04506	740001		CMA	
04507	740200		SEA	
04510	740040	E545	HALT	/ERROR, JS1+1
04511	204577		LAC KJS2	/TEST JS2, LINN = 1
04512	347442		TAD K600K	
04513	740001		CMA	
04514	344472		TAD JS2+1	
04515	740001		CMA	
04516	740200		SEA	
04517	740040	E546	HALT	/ERROR, JS2+1
04520	204600		LAC KJS3	/TEST JS3, LINK = 1
04521	347442		TAD K600K	
04522	740001		CMA	
04523	344474		TAD JS3+1	
04524	740001		CMA	
04525	740200		SEA	
04526	740040	E547	HALT	/ERROR, JS3+1
04527	204601		LAC KJS4	/TEST JS4, EXT = 0, LINK = 0
04530	347441		TAD K200K	
04531	740001		CMA	
04532	344500		TAD JS4+1	
04533	740001		CMA	
04534	740200		SEA	
04535	740040	E548	HALT	/ERROR, JS4+1
		/		
04536	447517		ISE WORK3	/CHECK DONE LOOPING
04537	604256		JMP TSJMS	/LOOP
04540	106336		JMS GENRAN	/GET NO. FOR NEXT LOOP
04541	106362		JMS CKNO	
04542	604613		JMP TSXCT	/TEST XCT
			.EJECT	

/CONSTANTS FOR JMS, MODIFIED WHEN IN HI 4K

04543	604271	RJSM71	JMP RJMS71
04544	111111	RSM71	JMS 11111
04545	010000	K10000	10000
04546	604312	RJSM72	JMP RJMS72
04547	112222	RSM72	JMS 12222
04550	007777	K77	07777
04551	604333	RJSM73	JMP RJMS73
04552	113333	RSM73	JMS 13333
04553	007776	K76	07776
04554	604354	RJSM74	JMP RJMS74
04555	114444	RSM74	JMS 14444
04556	007775	K75	07775
04557	604375	RJSM75	JMP RJMS75
04560	115555	RSM75	JMS 15555
04561	007774	K74	07774
04562	604416	RJSM76	JMP RJMS76
04563	116666	RSM76	JMS 16666
04564	007773	K73	07773
04565	117777	RSM77	JMS 17777
04566	007772	K72	07772
04567	604436	RJSM25	JMP RJMS14
04570	115252	RSM25	JMS 15252
04571	412526	K426	412526
04572	604456	RJSM52	JMP RJMS15
04573	112525	RSM52	JMS 12525
04574	007771	K71	07771
04575	415253	K415	415253
04576	004470	KJS1	JS1+1
04577	004472	KJS2	JS2+1
04600	004474	KJS3	JS3+1
04601	004500	KJS4	JS4+1
04602	210000	K210K	210000
04603	207777	K277	207777
04604	207776	K276	207776
04605	207775	K275	207775
04606	207774	K274	207774
04607	207773	K273	207773
04610	612526	K626	612526
04611	615253	K615	615253
04612	215253	K2152	215253

/

.EJECT


```

/TEST XCT
/
04613 754003 TSXCT CLA!CMA!CLL!CML /AC = ONES; LINK = 0
04614 404615 XCT ,+1 /NOP
04615 740000 NOP
04616 740400 SNL
04617 740040 E549 HALT /ERROR; XCT NOP; LINK WAS RESET
04620 740001 CMA
04621 740200 SZA
04622 740040 E550 HALT /ERROR; XCT NOP; AC NOT ONES
/
04623 754000 /TEST EXECUTE NOP, AC = 0, LINK = 0
04624 404625 CLA!CLL /AC = 0, LINK = 0
04625 740000 XCT ,+1
04626 741400 NOP
04627 740040 E551 SEL /ERROR; XCT NOP; LINK WAS SET
04630 740200 SZA
04631 740040 E552 HALT /ERROR; XCT NOP; AC NOT 0
/
04632 407501 /TEST XCT SKP XCT KSKP /SKIP
04633 740040 E553 HALT /ERROR; XCT SKP FAILED
04634 750001 CLA!CMA /AC = ONES
04635 407502 XCT KCLA /CLA
04636 740200 SZA
04637 740040 E554 HALT /ERROR; XCT CLA FAILED
/
04640 750000 /TEST XCT LAW CLA /AC = 0
04641 407454 XCT K7S /LAW = 17777
04642 740001 CMA /AC = 0
04643 740200 SZA
04644 740040 E555 HALT /ERROR; XCT LAW FAILED
/TEST XCT ISZ
04645 750001 CLA!CMA /AC = ONES
04646 057777 DAC 17777
04647 405066 XCT XCTISE /ISZ 17777
04650 740040 E556 HALT /ERROR; XCT ISZ FAILED TO SKP
/
04651 744002 /TEST XCT TAD CLL!CML /LINK = 1
04652 777777 LAW 17777 /AC = ONES
04653 057777 DAC 17777 /17777=777777
04654 405070 XCT XCTTAD /TAD K1
04655 740200 SZA
04656 740040 E557 HALT /ERROR; XCT TAD FAILED, AC NOT 0
04657 741400 SEL
04660 740040 E558 HALT /ERROR; XCT TAD FAILED LINK
.EJECT

```

```

04661 754003 /TEST XCT RAL, AC = ONES, LINK = 1
04662 407524 CLA!CMA!CLL!CML /AC = ONES, LINK = 1
04663 740001 XCT XCTRAL /RAL
04664 740200 CMA /AC = 0
04665 740040 SZA
04666 744400 E559 HALT /ERROR; XCT RAL FAILED AC DROPPED A BIT
04667 740040 SNL!CLL
E560 HALT /ERROR; XCTRAL FAILED LINK DROPPED
/
/TEST XCT DAC
04670 207450 LAC K3S /AC = 333333
04671 405067 XCT XCTDAC /DAC 17777
04672 347451 TAD K4S /AC = 777777
04673 740001 CMA /AC = 0
04674 740200 SZA
04675 740040 E561 HALT /ERROR; XCT DAC FAILED, K3S
/NOT STORED AT 17777
EJECT

```

/TEST XCT JMS

/

04676	207600		LAC XCT11	
04677	740200		SEA	
04700	740040	E562	HALT	/ERROR, XCT (16666 OR 06666) /FROM 11111 OR 01111 /XCT (16666 OR 06666)
04701	205044		LAC XT11S	
04702	047600		DAC XCT11	/OR 01111
04703	051111		DAC 11111	/JMS 11111 OR 01111
04704	205045		LAC XTR11	/OR 06666
04705	056666		DAC 16666	/RJMP TO RXCT1
04706	205046		LAC XT1R	/OR 01112
04707	051112		DAC 11112	/OR 01111 AND XCT (16666 OR 06666)
04710	611111		JMP 11111	/CLEAR ERROR TABLE
04711	147600	RXCT1	DZM XCT11	/OR 01111
04712	211111		LAC 11111	
04713	545047		SAD K12	
04714	741000		SKP	
04715	740040	E563	HALT	/ERROR, RJMP ADR, NOT 211112 /OR 201112
04716	207601		LAC XCT12	
04717	740200		SEA	
04720	740040	E564	HALT	/ERROR, XCT (15555 OR 05555) /FROM 12222 OR 02222 /XCT (15555 OR 05555)
04721	205050		LAC XT12S	
04722	047601		DAC XCT12	
04723	052222		DAC 12222	/JMS 12222 OR 02222
04724	205051		LAC XTR12	
04725	055555		DAC 15555	/RJMP TO RXCT2
04726	205052		LAC XT2R	
04727	052223		DAC 12223	
04730	612222		JMP 12222	
04731	147601	RXCT2	DZM XCT12	/CLEAR ERROR TABLE
04732	212222		LAC 12222	
04733	545053		SAD K23	
04734	741000		SKP	
04735	740040	E565	HALT	/ERROR, RJMP NOT 212223 /OR 202223
04736	207602		LAC XCT13	
04737	740200		SEA	
04740	740040	E566	HALT	/ERROR, XCT (14444 OR 04444) /FROM 13333 OR 03333

.EJECT

04741	205054		LAC XT13S	/XCT (14444 OR 04444)
04742	047602		DAC XCT13	
04743	053333		DAC 13333	
04744	205055		LAC XTR13	/JMS 13333 OR 23333
04745	054444		DAC 14444	
04746	205056		LAC XT3R	/RJMP TO RXCT3
04747	053334		DAC 13334	
04750	613333		JMP 13333	
04751	147602	RXCT3	DZM XCT13	/CLEAR ERROR TABLE
04752	213333		LAC 13333	
04753	545057		SAD K34	
04754	741000		SKP	
04755	740040	E567	HALT	/ERROR, RJMP NOT 213334 OR 223334
04756	207603		LAC XCT17	
04757	740200		SEA	
04760	740040	E568	HALT	/ERROR, XCT (17776 OR 07776) /FROM 07776 OR 17776
04761	205060		LAC XT17S	/XCT (17776 OR 07776)
04762	047603		DAC XCT17	
04763	047776		DAC 07776	/OR 17776
04764	205061		LAC XTR17	/JMS 07776 OR 17776
04765	057776		DAC 17776	/OR 07776
04766	205062		LAC XT4R	/RJMP TO RXCT4
04767	047777		DAC 07777	/OR 17777
04770	607776		JMP 07776	/OR 17776
04771	147603	RXCT4	DZM XCT17	/CLEAR ERROR TABLE
04772	207776		LAC 07776	/FOR 17776
04773	544603		SAD K277	
04774	741000		SKP	
04775	740040	E569	HALT	/ERROR, RJMP NOT 207777 OR 217777
04776	207604		LAC XCT125	
04777	740200		SEA	
05000	740040	E570	HALT	/ERROR, XCT (12525 OR 02525) /FROM 15252 OR 05252
05001	205063		LAC XCT12S	
05002	047604		DAC XCT125	/XCT (12525 OR 02525)
05003	055252		DAC 15252	/OR 05252
05004	205064		LAC XCTR12	
05005	052525		DAC 12525	/JMS 15252 OR 05252
05006	205065		LAC XT5R	/RJMP TO RXCT5
05007	055253		DAC 15253	
05010	615252		JMP 15252	
05011	147604	RXCT5	DZM XCT125	/CLEAR ERROR TABLE
05012	215252		LAC 15252	
05013	544612		SAD K2152	
05014	741000		SKP	
05015	740040	E571	HALT	/ERROR, RJMP NOT 215253 OR 205253
			,EJECT	

/TEST XCT SERIES

```

/
05016 754003 CLA!CMA!CLL!CML /AC = ONES, LINK = 1
05017 405020 XCT ,+1; XCT ,+1; XCT ,+1
05020 405021
05021 405022
05022 405023 XCT ,+1; XCT ,+1; XCT ,+1
05023 405024
05024 405025
05025 405026 XCT ,+1; XCT ,+1; XCT ,+1
05026 405027
05027 405030
05030 405031 XCT ,+1
05031 740000 NOP
05032 740001 CMA
05033 740200 SZA
05034 740040 E572 HALT /ERROR, XCT SERIES FAILED AC NOT ONES
05035 740400 SNL
05036 740040 E573 HALT /ERROR, LINK CHANGED
05037 447517 ISZ WORK3 /CHECK DONE LOOPING
05040 604613 JMP TSXCT /LOOP
05041 106336 JMS GENRAN /GET NO FOR NEXT LOOP
05042 106362 JMS CKNO
05043 605071 JMP LACIN /TEST LAC INDIRECT

```

/XCT CONSTANTS, MODIFIED WHEN IN UPPER 4K

```

/
05044 416666 XT11S XCT 16666
05045 111111 XTR11 JMS 11111
05046 604711 XT1R JMP RXCT1
05047 211112 K12
05050 415555 XT12S XCT 15555
05051 112222 XTR12 JMS 12222
05052 604731 XT2R JMP RXCT2
05053 212223 K23 212223
05054 414444 XT13S XCT 14444
05055 113333 XTR13 JMS 13333
05056 604751 XT3R JMP RXCT3
05057 213334 K34 213334
05060 417776 XT17S XCT 17776
05061 107776 XTR17 JMS 07776
05062 604771 XT4R JMP RXCT4
05063 412525 XCT12S XCT 12525
05064 115252 XCTR12 JMS 15252
05065 605011 XT5R JMP RXCT5
05066 457777 XCT15Z ISZ 17777
05067 057777 XCTDAC DAC 17777
05070 347412 XCTTAD TAD K1
.EJECT

```

```

/TEST LAC INDIRECT
/
05071 204550 LACIN LAC K77
05072 057777 DAC 17777 /((17777 OR 07777) = 07777 OR 17777
05073 207511 LAC M400K /377777
05074 047777 DAC 07777 /OR 17777
05075 237777 LAC* 17777 /OR 07777
05076 347435 YAD K400K /AC = 777777
05077 740001 CMA
05100 740200 SEA
05101 740040 E584 HALT /ERROR, LAC* 17777 OR 07777 FAILED
/
05102 204553 LAC K76
05103 056666 DAC 16666 /((16666 OR 06666) = 07776 OR 17776
05104 207510 LAC M40K /377777
05105 047776 DAC 07776
05106 236666 LAC* 16666 /AC = 737777
05107 347434 YAD K40K /AC = 777777
05110 740001 CMA
05111 740200 SEA
05112 740040 E585 HALT /ERROR, LAC* 16666 OR 06666 FAILED
/
05113 204556 LAC K75
05114 055555 DAC 15555 /((15555 OR 05555) = 07775 OR 17775
05115 207507 LAC M4K /AC = 773777
05116 047775 DAC 07775
05117 235555 LAC* 15555 /AC = 773777
05120 347430 YAD K4K /AC = 777777
05121 740001 CMA
05122 740200 SEA
05123 740040 E586 HALT /ERROR, LAC* 15555 OR 05555 FAILED
/
05124 204561 LAC K74
05125 054444 DAC 14444 /((14444 OR 04444) = 07774 OR 17774
05126 207506 LAC M400 /AC = 777377
05127 047774 DAC 07774
05130 234444 LAC* 14444 /AC = 777377
05131 347425 YAD K400 /AC = 777777
05132 740001 CMA
05133 740200 SEA
05134 740040 E587 HALT /ERROR, LAC* 14444 OR 04444 FAILED
/
05135 204564 LAC K73
05136 053333 DAC 13333 /((13333 OR 03333) = 07773 OR 17773
05137 207505 LAC M40 /AC = 777737
05140 047773 DAC 07773
05141 233333 LAC* 13333 /AC = 777737
05142 347423 YAD K40 /AC = 77777
05143 740001 CMA
05144 740200 SEA
05145 740040 E588 HALT /ERROR, LAC* 13333 OR 03333 FAILED
,EJECT

```

05146 204566
 05147 052222
 05150 207504
 05151 047772
 05152 232222
 05153 347414
 05154 740001
 05155 740200
 05156 740040

E589

/

05157 204574
 05160 051111
 05161 207503
 05162 047771
 05163 231111
 05164 347412
 05165 740001
 05166 740200
 05167 740040

E590

/

05170 205326
 05171 052525
 05172 207467
 05173 052525
 05174 235252
 05175 347466
 05176 740001
 05177 740200
 05200 740040

E591

/

05201 447517
 05202 605071
 05203 106336
 05204 106362

LAC K72
 DAC 12222
 LAC M4
 DAC 07772
 LAC* 12222
 TAD K4
 CMA
 SEA
 HALT

/(12222 OR 02222) = 07772 OR 17772
 /AC = 777773
 /AC = 777773
 /AC = 777777

/ERROR, LAC* 12222 OR 02222 FAILED

LAC K71
 DAC 11111
 LAC M1
 DAC 07771
 LAC* 11111
 TAD K1
 CMA
 SEA
 HALT

/(11111 OR 01111) = 07771 OR 17771
 /AC = 777776
 /AC = 777776
 /AC = 777777

/ERROR, LAC* 11111 OR 01111 FAILED

LAC INK52
 DAC 15252
 LAC K101
 DAC 12525
 LAC* 15252
 TAD K010
 CMA
 SEA
 HALT

/(15252 OR 05252) = 02525 OR 12525
 /AC = 525252
 /AC = 525252
 /AC = 777777

/ERROR, LAC* 15252 OR 05252 FAILED

ISE WORK3
 JMP LACIN
 JMS GENRAN
 JMS CKNO
 .EJECT

/CHECK DONE LOOPING
 /LOOP
 /GET NO, FOR NEXT LOOP

```

      /TEST XCT JMS INDIRECT
      /
05205  744000  XTJMSI  CLL
05206  750000          CLA
05207  547605          SAD JST77
05210  741000          SKP
05211  740040  E592  HALT          /ERROR, JMS DEST'IB ERROR
      /
05212  206006          LAC K17776  /DIRECT ADDRESS
05213  047777          DAC 07777
05214  205327          LAC JMSI1    /JMS* 07777 OR 17777
05215  047605          DAC JST77    /ERROR TABLE
05216  055252          DAC 15252
05217  205330          LAC RJMI1    /JMP RJSI1
05220  057777          DAC 17777
05221  415252          XCT 15252    /XCT TEST
05222  741000          SKP
05223  147605  RJSI1  DZM JST77
05224  217776          LAC 17776
05225  504550          AND K77
05226  545331          SAD RJSI1X  /RJSI1X = RJSI1+1
05227  751000          CLA!SKP
05230  740040  E593  HALT          /ERROR (17776 OR 07776) NOT =
      /TO RJSI1+1
      /
      /TEST JMS INDIRECT
      /
05231  744002          STL
05232  750000          CLA
05233  547606          SAD JST66
05234  741000          SKP
05235  740040  E594  HALT          /ERROR, JMS DEST'IN ERROR
      /
05236  206023          LAC K11111  /DIRECT ADR, 11111 OR 01111
05237  056666          DAC 16666    /OR 06666
05240  205332          LAC JSI66    /JMS* 16666 OR 06666
05241  047606          DAC JST66
05242  055252          DAC 15252    /JMS* 16666 OR 06666 AT 15252
      /OR 05252
05243  205333          LAC RJMI2    /JMP RJSI2
05244  051112          DAC 11112    /OR 01112
05245  615252          JMP 15252    /OR 05252
05246  741000          SKP
05247  147606  RJSI2  DZM JST66    /CLEAR ERROR TABLE
05250  211111          LAC 11111
05251  544611          SAD K615
05252  751000          CLA!SKP
05253  740040  E595  HALT          /ERROR, RJMP ADR, (11111 OR 01111)
      /NOT 615253 OR 625253
      /EJECT

```


05254	750000		CLA	
05255	547607		SAD JST55	
05256	741000		SKP	
05257	740040	E596	HALT	/ERROR, JMS DEST'N ERROR
05260	206021		LAC K12222	/DIRECT ADR, 12222 OR 02222
05261	055555		DAC 15555	/OR 055555
05262	205335		LAC JSI55	/JMS* 15555 OR 05555
05263	047607		DAC JST55	
05264	055252		DAC 15252	/JMS* 15555 OR 05555 AT
				/15252 OR 05252
05265	205336		LAC RJMI3	/JMP RJSI3
05266	052223		DAC 12223	/OR 02223
05267	615252		JMP 15252	/OR 05252
05270	741000		SKP	
05271	147607	RJSI3	DZM JST55	/CLEAR ERROR TABLE
05272	212222		LAC 12222	/OR 02222
05273	544611		SAD K615	
05274	751000		CLA!SKP	
05275	740040	E597	HALT	/ERROR, RJMP ADR, (12222 OR 02222)
				/NOT 615253 OR 605253
05276	750000		CLA	
05277	547610		SAD JST44	
05300	741000		SKP	
05301	740040	E598	HALT	/ERROR, JMS DEST'N ERROR
05302	206017		LAC K13333	/DIRECT ADR, 13333 OR 03333
05303	054444		DAC 14444	/OR 04444
05304	205337		LAC JSI44	/JMS* 14444 OR 04444
05305	047610		DAC JST44	
05306	055252		DAC 15252	/OR 05252
05307	205340		LAC RJMI4	
05310	053334		DAC 13334	/OR 03334
05311	615252		JMP 15252	/OR 05252
05312	741000		SKP	
05313	147610	RJSI4	DZM JST44	/CLEAR ERROR TABLE
05314	213333		LAC 13333	/OR 03333
05315	544611		SAD K615	
05316	751000		CLA!SKP	
05317	740040	E599	HALT	/ERROR, RJMP ADR (13333 OR 03333)
				/NOT 615253 OR 605253
05320	447517		ISE WORK3	/CHECK DONE LOOPING
05321	605205		JMP XTJMSI	/LOOP
05322	106336		JMS GENRAN	/GET NO, FOR NEXT LOOP
05323	106362		JMS CKNO	
05324	700004		CLOF	
05325	605341		JMP XTXCT	/TEST XCT INDIRECTS
			.EJECT	

```

/CONSTANTS FOR LAC*, XCT JMS* MODIFIED
/WHEN IN UPPER 4K
/
05326 012525 INK52 12525
05327 127777 JMSI1 JMS* 07777
05330 605223 RJMI1 JMP RJSI1
05331 005222 RJSI1X RJSI1-1
05332 136666 JSI66 JMS* 16666
05333 605247 RJMI2 JMP RJSI2
05334 015253 K15253 15253
05335 135555 JSI55 JMS* 15555
05336 605271 RJMI3 JMP RJSI3
05337 134444 JSI44 JMS* 14444
05340 605313 RJMI4 JMP RJSI4
/PDP-15 BASIC EXERCISER - TAPE 6
/TEST XCT INDIRECT
/
05341 700002 XTXCT IOF /PI OFF FOR XCT* TO USE
/LOCATION 0
05342 207411 LAC K0
05343 057777 DAC 17777 /OR 07777
05344 205412 LAC XCTDZM
05345 040000 DAC 0 /DZM 12525 OR 02525
05346 777777 LAW 17777
05347 052525 DAC 12525 /(12525 OR 02525) = 777777
05350 437777 XCT* 17777 /OR 07777
05351 212525 LAC 12525 /OR 02525
05352 740200 SZA
05353 740040 E600 HALT /ERROR, XCT* A DZM FAILED
/(12525 OR 02525) NOT 777777
/
/TEST ISZ INDIRECT, PI IS OFF
/
05354 207411 LAC K0
05355 057777 DAC 17777 /OR 07777
05356 777777 LAW 17777
05357 040000 DAC 0 /(0) = 777777
05360 477777 ISZ* 17777
05361 740040 E601 HALT /ERROR ISZ* FAILED TO SKIP/
.EJECT

```

/TEST XCT* ADD* PI IS OFF

/

05362	777777	LAW -1	
05363	040017	DAC 17	/C(17) = 777777
05364	040010	DAC 10	
05365	205413	LAC ADDI	/ADD* 10
05366	040000	DAC 0	/AND* 17776 OR 07776
05367	740031	CMA! IAC	/AC = 457770 (COMPLEMENT OF AND* 10).
05370	420017	XCT* 17	/ADD ADD* 10 WITH ITS COMPLEMENT
05371	547412	SAD K1	/AC MUST EQUAL OCTAL 1
05372	741000	SKP	
05373	740040	E602 HALT	/ERROR, XCT* 17 /FOLLOWED BY ADD* 10 FAILED, /CHECK DONE LOOPING /LOOP
05374	447517	ISZ WORK3	
05375	605341	JMP XTXCT	
05376	106336	JMS GENRAN	/GET NO, FOR NEXT LOOP
05377	106362	JMS CKNO	
05400	207501	LAC KSKP	
05401	040001	DAC 1	/RESTORE LOC 1
05402	750004	LAS	
05403	740010	RAL	
05404	740100	SMA	
05405	700042	ION	/PI BACK ON
05406	507440	AND K20K	
05407	741200	SNA	/TEST ACS5
05410	106614	JMS SETCLK	/CLOCK BACK ON
05411	605414	JMP AUTOIN	/TEST INDEX REGISTERS
		.EJECT	

```

/CONSTANTS FOR PRECEDING LOOPS, MODIFIED WHEN IN UPPER 4K
/
XCTOZM  DZM 12525
05412    152525
05413    320010
ADDI     ADD* 10
/
/TEST AUTO=INDEX (XOR* 10)
/
05414    206006
05415    040010
05416    207446
05417    057777
05420    260010
05421    740200
05422    740040
E603     HALT
          LAC K17776
          DAC 10
          LAC K1S
          DAC 17777
          XOR* 10
          SZA
          /((10) = 17776 OR 07776
          /AC = 11111
          /OR 07777
          /ERROR, XOR* 10 FAILED
          /AC NOT 111111

05423    200010
05424    546007
05425    741000
05426    740040
E604     HALT
          LAC 10
          SAD K17777
          SKP
          /ERROR, (10) NOT INCREMENTED+1
/
05427    206010
05430    040010
05431    207447
05432    056666
05433    260010
05434    740200
05435    740040
E605     HALT
          LAC K16665
          DAC 10
          LAC K2S
          DAC 16666
          XOR* 10
          SZA
          /((10) = 16665 OR 06665
          /AC = 22222
          /OR 06666
          /ERROR, XOR* 10 FAILED
          /AC NOT 22222

05436    200010
05437    546011
05440    741000
05441    740040
E606     HALT
          LAC 10
          SAD K16666
          SKP
          /ERROR, (10) NOT INCREMENTED+1
/
05442    206012
05443    040010
05444    207450
05445    055555
05446    260010
05447    740200
05450    740040
05451    200010
05452    546013
05453    741000
05454    740040
E607     HALT
          LAC K15554
          DAC 10
          LAC K3S
          DAC 15555
          XOR* 10
          SZA
          /((10) = 15554 OR 05554
          /AC = 333333
          /ERROR, XOR* 10 FAILED, AC NOT 333333

E608     HALT
          LAC 10
          SAD K15555
          SKP
          /ERROR, (10) NOT INCREMENTED +1
          ,EJECT

```

05455	206014		LAC K14443	
05456	040010		DAC 10	/(10) = 14443 OR 04443
05457	207451		LAC K4S	/AC = 444444
05460	054444		DAC 14444	
05461	260010		XOR* 10	
05462	740200		SZA	
05463	740040	E609	HALT	/ERROR, XOR* 10 FAILED AC NOT 444444
05464	200010		LAC 10	
05465	546015		SAD K14444	
05466	741000		SKP	
05467	740040	E610	HALT	/ERROR, (10) NOT INCREMENTED +1
05470	206016		LAC K13332	
05471	040010		DAC 10	/(10) = 13332 OR 03332
05472	207452		LAC K9S	/AC = 55555
05473	053333		DAC 13333	
05474	260010		XOR* 10	
05475	740200		SZA	
05476	740040	E611	HALT	/ERROR, XOR* 10 FAILED AC NOT 555555
05477	200010		LAC 10	
05500	546017		SAD K13333	
05501	741000		SKP	
05502	740040	E612	HALT	/ERROR, (10) NOT INCREMENTED+1
		/		
05503	206020		LAC K12221	
05504	040010		DAC 10	/(10) = 12221 OR 02221
05505	207453		LAC K6S	/AC = 666666
05506	052222		DAC 12222	
05507	260010		XOR* 10	
05510	740200		SZA	
05511	740040	E613	HALT	/ERROR, XOR* 10 FAILED, AC NOT 666666
05512	200010		LAC 10	
05513	546021		SAD K12222	
05514	741000		SKP	
05515	740040	E614	HALT	/ERROR, (10) NOT INCREMENTED+1
05516	206022		LAC K11110	
05517	040010		DAC 10	/(10) = 11110 OR 01110
05520	207454		LAC K7S	/AC = 777777
05521	051111		DAC 11111	
05522	260010		XOR* 10	
05523	740200		SZA	
05524	740040	E615	HALT	/ERROR, XOR* 10 FAILED, AC NOT 777777
05525	200010		LAC 10	
05526	546023		SAD K11111	
05527	741000		SKP	
05530	740040	E616	HALT	/ERROR, (10) NOT INCREMENTED +1
			.EJECT	

```

/TEST ISZ* 11
/
05531 206024          LAC K15252
05532 040011          DAC 11          /(11) = 15252 OR 05252
05533 207454          LAC K75
05534 055253          DAC 15253          /OR 05253
05535 460011          ISZ* 11
05536 740040          E617  HALT          /ERROR, ISZ FAILED TO SKIP
                                /AUTO-INDEX 11 FAILED

05537 215253          LAC 15253
05540 740200          SZA
05541 740040          E618  HALT          /ERROR, (15253 OR 05253) NOT 0
                                /ISZ FAILED

05542 200011          LAC 11
05543 545334          SAD K15253
05544 741000          SKP
05545 740040          E619  HALT          /ERROR, (11) NOT INCREMENTED+1
/
/AUTO=INDEX JMP* 12,
/
05546 207611          LAC AUTJMP
05547 740200          SZA
05550 740040          E620  HALT          /ERROR, JMP* 12 FAILED TO REACH 15253
05551 207534          LAC JMPAUT          /JMP* 12
05552 047611          DAC AUTJMP
05553 206025          LAC AUTRET          /RJMP TO AUTR
05554 055253          DAC 15253
05555 206024          LAC K15252
05556 040012          DAC 12          /(12) = 15252
05557 620012          JMP* 12
05560 741000          SKP
05561 147611          AUTR  DEM AUTJMP          /CLEAR ERROR TABLE
05562 200012          LAC 12
05563 545334          SAD K15253
05564 741000          SKP
05565 740040          E621  HALT          /ERROR, (12) NOT INCREMENTED+1
/
/AUTO=INDEX (DAC* 13),
/
05566 204553          LAC K76
05567 040013          DAC 13          /(13) = 07776 OR 17776
05570 204553          LAC K76
05571 047777          DAC 07777          /(07777) = 07776
05572 207411          LAC K0
05573 060013          DAC* 13
05574 207777          LAC 07777
05575 740200          SZA
05576 740040          E622  HALT          /ERROR, (07777) NOT 0, DAC* 13 FAILED
05577 200013          LAC 13
05600 544550          SAD K77
05601 741000          SKP
05602 740040          E623  HALT          /ERROR (13) NOT INCREMENTED+1
                                .EJECT

```

```

/AUTO-INDEX (XCT* 14),
/
05603 204574          LAC K71
05604 040014          DAC 14          /(14) = 07771
05605 207525          LAC AUTCMA
05606 047772          DAC 07772       /(07772) = CMA
05607 750001          CLA: CMA
05610 420014          XCT* 14
05611 740200          SZA
05612 740040          E624 HALT       /ERROR, AC NOT 0 (XCT* 14) A CMA
05613 200014          LAC 14
05614 544566          SAD K72
05615 741000          SKP
05616 740040          E625 HALT       /ERROR, (14) NOT INCREMENTED+1
/AUTO-INDEX (TAD* 15),
/
05617 206006          LAC K17776
05620 040015          DAC 15          /(15) = 17776 OR 07776
05621 207412          LAC K1
05622 057777          DAC 17777       /OR 07777
05623 754001          CLL: CLA: CMA
05624 360015          TAD* 15
05625 740200          SZA
05626 740040          E626 HALT       /ERROR, AC NOT 0 (TAD* 15)
05627 740400          SNL
05630 740040          E627 HALT       /ERROR, LINK NOT 1 (TAD* 15)
05631 200015          LAC 15
05632 546007          SAD K17777
05633 741000          SKP
05634 740040          E628 HALT       /ERROR, (15) NOT INCREMENTED+1
05635 217777          LAC 17777
05636 547412          SAD K1
05637 741000          SKP
05640 740040          E629 HALT       /ERROR, (17777 OR 07777) NOT 1
/AUTO-INDEX (SAD* 16),
/
05641 204561          LAC K74
05642 040016          DAC 16          /(16) = 07774
05643 207465          LAC K5252
05644 047775          DAC 07775       /(07775) = 5252
05645 560016          SAD* 16
05646 741000          SKP
05647 740040          E630 HALT       /ERROR, SAD SKIPPED (SAD* 16)
05650 207775          LAC 07775
05651 547465          SAD K5252
05652 741000          SKP
05653 740040          E631 HALT       /ERROR, (07775) NOT 5252
05654 200016          LAC 16
05655 544556          SAD K75
05656 741000          SKP
05657 740040          E632 HALT       /ERROR, (16) NOT INCREMENTED+1
.EJECT

```


/AUTO=INDEX (XCT* 15),

05731	204564		LAC K73	
05732	040015		DAC 15	/(15) = 07773
05733	207530		LAC LAWAUT	
05734	047774		DAC 07774	/(07774) = XCT* 15
05735	207531		LAC LAWFUL	
05736	047775		DAC 07775	/(07775) = LAW 17777
05737	750000		CLA	/AC = 0
05740	420015		XCT* 15	
05741	740001		CMA	
05742	740200		SZA	
05743	740040	E640	HALT	/ERROR, AC NOT ONES /LAW 1777 DID NOT OCCUR
05744	200015		LAC 15	
05745	544556		SAD K75	
05746	741000		SKP	
05747	740040	E641	HALT	/ERROR, (15) NOT 7775 (XCT* 15)
05750	447517		ISE WORK3	/CHECK DONE LOOPING
05751	605414		JMP AUTOIN	/LOOP
05752	106336		JMS GENRAN	
05753	106362		JMS CKNO	
			.EJECT	

/
 /TEST LAW X WITH TAD, AC SHOULD ALWAYS
 /BE CLEAR AFTER THE TAD, LAW -1 TO
 /LAW -20000 ARE USED, AND THE PROPER BIT IS
 /ALWAYS ADDED TO GIVE OVERFLOW.

05754 207412
 05755 046004
 05756 777777
 05757 346004
 05760 741200
 05761 605764
 05762 740040
 05763 605756

LAWD LAC K1
 DAC BITN /START WITH BIT 17
 LAWS LAW -1 /THIS LAW WILL ROTATE LEFT
 TAD BITN /SHOULD OVERFLOW + AC = 0
 SNA
 JMP ,+3 /OK
 ER1 HALT /ERROR, AC NOT 0 AFTER A
 JMP LAWS /DO SAME TAD AGAIN.

05764 206004
 05765 744010
 05766 046004
 05767 405756
 05770 744010
 05771 245756
 05772 546005
 05773 741000
 05774 605756
 05775 777777
 05776 045756
 05777 447517
 06000 605754
 06001 106336
 06002 106362
 06003 606030

LAC BITN
 RCL /NEXT BIT POSITION,
 DAC BITN
 XCT LAWS
 RCL /2'S COMPLEMENT OF C(BITN)
 DAC LAWS
 SAD KNOP /DONE IF = A NOP
 SKP
 JMP LAWS /TEST NEXT BIT POSITION
 LAW -1
 DAC LAWS /RESTORE LAWS
 ISZ WORK3
 JMP LAWD /LOOP
 JMS GENRAN
 JMS CKNO
 JMP TIAC /TEST IAC

06004 000000
 06005 740000

/
 BITN 0
 KNOP 740000
 .EJECT

/CONSTANTS FOR AUTO-INDEXING. MODIFIED WHEN IN HI 4K

```
06006 017776 K17776 17776
06007 017777 K17777 17777
06010 016665 K16665 16665
06011 016666 K16666 16666
06012 015554 K15554 15554
06013 015555 K15555 15555
06014 014443 K14443 14443
06015 014444 K14444 14444
06016 013332 K13332 13332
06017 013333 K13333 13333
06020 012221 K12221 12221
06021 012222 K12222 12222
06022 011110 K11110 11110
06023 011111 K11111 11111
06024 015252 K15252 15252
06025 005561 AUTRET JMP AUTR
06026 005673 AUTRJM JMP AUTRE1
06027 005672 AURJMP AUTRE1-1
      .EJECT
```

```

/TEST IAC
/
06030 750000
06031 740032 TIAC CLA /AC = 0
06032 547412 IAC /AC+1
06033 741000 SAD K1
06034 740040 EX01 SKP
HALT /ERROR, AC NOT = 000001
/
06035 744000 CLL /L = 0
06036 777777 LAW -1 /AC = 777777
06037 740030 IAC /AC OVERFLOW
06040 740200 SZA
06041 740040 EX02 HALT /ERROR, AC NOT ZERO
06042 740400 SNL /L MUST BE 1
06043 740040 EX03 HALT /ERROR, LINK NOT COMPLEMENTED
/
06044 744002 STL /LINK = 1
06045 777777 LAW -1 /AC = 777777
06046 740030 IAC /OVERFLOW THE AC
06047 740200 SZA
06050 740040 EX04 HALT /ERROR, AC NOT ZERO
06051 741400 SZL
06052 740040 EX05 HALT /ERROR, L NOT COMPLEMENTED
/
/TEST IAC WITH MICROPROGRAMMING
/
06053 207412 LAC K1
06054 740031 CMA:IAC /AC = 777776 + 1
06055 740001 CMA
06056 741200 SNA /AC MUST = 0
06057 606062 JMP ,+3
06060 740001 CMA
06061 740040 EX06 HALT /ERROR, CMA:IAC FAILED
/
06062 754031 CLL:CLA:CMA:IAC /L = 0, AC = 777777 + 1
06063 740400 SNL
06064 740040 EX07 HALT /ERROR, LINK OR IAC FAILED
06065 740200 SZA
06066 740040 EX10 HALT /ERROR, AC OR IAC FAILED
/
06067 750000 CLA /AC = 0
06070 740230 SZA:IAC
06071 740040 EX13 HALT /ERROR, SZA:IAC FAILED
/
06072 760000 LAW /AC = 760000
06073 740230 SZA:IAC
06074 741000 SKP
,EJECT

```

```

06075 740040 EX14 HALT /ERROR, SEA:IAC FAILED
06076 741230 SNA:IAC
06077 740040 EX15 HALT /ERROR, SNA:IAC FAILED
/
06100 447517 ISZ WORK3
06101 606030 JMP TIAC /LOOP
06102 106336 JMS GENRAN
06103 106362 JMS CKNO
/
/TEST SWHA
/
/
06104 777000 TSWH LAW 17000 /AC = 777000
06105 742030 SWHA /AC = 000777
06106 547347 SAD K777
06107 741000 SKP
06110 740040 EX16 HALT /ERROR, SWHA FAILED WITH
/AC = 777000,
/
06111 207464 LAC K2525 /AC = 002525
06112 742030 SWHA
06113 547472 SAD K502 /AC SHOULD BE 525002
06114 741000 SKP /OK
06115 740040 EX17 HALT /ERROR, SWHA FAILED WITH
/AC = 002525,
/
/TEST CONDITIONAL SKIPS WITH SWHA
/
06116 207435 LAC K400K /AC = 400000
06117 742130 SMA:SWHA /SHOULD SKIP, THEN SWAP
06120 740040 EX18 HALT /ERROR, SMA:SWHA DIDN'T SKIP
06121 743130 SPA:SWHA
06122 740040 EX19 HALT /ERROR, SPA:SWHA FAILED, C(AC)
/SHOULD BE 000001 IF IT IS
/STILL 400000 MAYBE SMA:SWHA
/ABOVE FAILED,
/SHOULD AGAIN = 400000
06123 547435 SAD K400K
06124 741000 SKP /OK
06125 740040 EX20 HALT /ERROR, ONE OF THE TWO
/PREVIOUS SWHA'S FAILED,
/
06126 447517 ISZ WORK3
06127 606104 JMP TSWH /LOOP
06130 106336 JMS GENRAN
06131 106362 JMS CKNO
/
.EJECT

```

```

/
/TEST INDEX GROUP INSTRUCTIONS
/
/XG DEFINITIONS
/
720000 AAS=720000 /ADD TO AC; SKIP IF = OR > LR
721000 PAX=721000 /PLACE AC IN XR
722000 PAL=722000 /PLACE AC IN LR
723000 AAC=723000 /ADD TO AC
724000 PXA=724000 /PLACE XR IN AC
725000 AXS=725000 /ADD TO XR; SKIP IF = OR > LR
726000 PXL=726000 /PLACE XR IN LR
730000 PLA=730000 /PLACE LR IN AC
731000 PLX=731000 /PLACE LR IN XR
734000 CLAC=734000 /CLEAR AC
735000 CLX=735000 /CLEAR XR
736000 CLLR=736000 /CLEAR LR
737000 AXR=737000 /ADD TO XR
707764 EBA=707764 /ENTER 9 MODE (BANK ADDRESS)
707762 EPA=707762 /ENTER 15 MODE (4K PAGES)
707761 SBA=707761 /SKIP IF IN 9 MODE
707741 EXBA=707741 /SKIP IF A POP=15
/
/TEST XG IN 9 MODE TO MAKE SURE THE AC OR
/LINK DOES NOT CHANGE
/
06132 754000 TSXG CLA:CLL /AC, LINK = 0
06133 720000 AAS /ADD TO AC; COMPARE TO LR
06134 740200 SZA
06135 740040 EX21 HALT /ERROR, AAS CHANGED C(AC)...
/...WHILE IN 9 MODE,

06136 741400 SZL
06137 740040 EX22 HALT /ERROR, AAS CHANGED C(L)...
/... WHILE IN 9 MODE.
/
/TRY PAX IN 9 MODE
/
06140 754000 CLA:CLL /AC, LINK = 0
06141 721000 PAX
06142 740200 SZA
06143 740040 EX23 HALT /ERROR, PAX CHANGED C(AC)...
/...WHILE I 9 MODE

06144 741400 SZL
06145 740040 EX24 HALT /ERROR, PAX CHANGED C(L)...
/...WHILE IN 9 MODE
/
/TRY PAL IN 9 MODE
/
06146 754000 CLA:CLL /AC, LINK = 0
06147 722000 PAL
06150 740200 SZA
06151 740040 EX25 HALT /ERROR, PAL CHANGED C(AC)...
/...WHILE IN 9 MODE

06152 741400 SZL
06153 740040 EX26 HALT /ERROR, PAL CHANGED C(L)...

```

PAGE 98

BX8K

BX8K

/...WHILE IN 9 MODE

/

.EJECT

/
/PLA IN 9 MODE, LR SHOULD INITIALLY BE 7.
/

06206	754001		CLA!CMA!CLL	
06207	730000		PLA	
06210	740200		SZA	
06211	740040	EX36	HALT	/ERROR, PLA CHANGED C(AC)... /...IN 9 MODE
06212	741400		SZL	
06213	740040	EX37	HALT	/ERROR, PLA CHANGED C(L)... /...IN 9 MODE

/
/PLX IN 9 MODE, XR, LR SHOULD INITIALLY BE 2.
/

06214	754000		CLA!CLL	
06215	731000		PLX	
06216	740200		SZA	
06217	740040	EX38	HALT	/ERROR, PLX CHANGED C(AC)... /...IN 9 MODE
06220	741400		SZL	
06221	740040	EX39	HALT	/ERROR, PLX CHANGED C(L)... /...IN 9 MODE

/
/CLAC IN 9 MODE
/

06222	754001		CLA!CMA!CLL	
06223	734000		CLAC	
06224	740200		SZA	
06225	740040	EX40	HALT	/ERROR, CLAC WORKED IN 9 MODE
06226	741400		SZL	
06227	740040	EX41	HALT	/ERROR, CLAC CHANGED C(L)... /...IN 9 MODE

/
/CLX IN 9 MODE
/

06230	754001		CLA!CMA!CLL	
06231	735000		CLX	
06232	740001		CMA	
06233	740200		SZA	
06234	740040	EX42	HALT	/ERROR, CLX CHANGED C(AC)... /...IN 9 MODE
06235	741400		SZL	
06236	740040	EX43	HALT	/ERROR, CLX CHANGED C(L)... /...IN 9 MODE

/
/CLLR IN 9 MODE
/

06237	754001		CLA!CMA!CLL	
06240	736000		CLLR	
06241	740001		CMA	
06242	740200		SZA	
			.EJECT	

PAGE	01	BX8K	BX8K		
06243	740040	EX44	HALT	/ERROR, CLLR CHANGED C(AC)...	
				/...IN 9 MODE	
06244	741400		SZL		
06245	740040	EX45	HALT	/ERROR, CLLR CHANGED C(L)...	
				/...IN 9 MODE	
			/		
			/AXR IN 9 MODE		
			/		
06246	754000		CLA:CLL		
06247	737777		AXR+777		
06250	724000		PXA	/XR TO AC	
06251	547454		SAD K7S		
06252	741000		SKP		
06253	740040	EX46	HALT	/ERROR, AXR FAILED...	
				/...IN 9 MODE	
06254	741400		SZL		
06255	740040	EX47	HALT	/ERROR, AXR CHANGED C(L)...	
				/...IN 9 MODE	
06256	735000		CLX	/CLEAR XR	
			/		
			/TEST SBA (SKIP IF BANK MODE)		
			/		
06257	754001		CLA:MA:CLL		
06260	707761		SBA		
06261	740040	EX48	HALT	/ERROR, SBA DID NOT SKIP...	
				/...CP SHOULD BE IN 9 MODE	
06262	740001		CMA		
06263	740200		SZA		
06264	740040	EX49	HALT	/ERROR, SBA CHANGED C(AC).	
06265	741400		SZL		
06266	740040	EX50	HALT	/ERROR, SBA CHANGED C(L).	
			/		
			/TEST EXBA (SKIP IF POP=15) AND EPA (ENTER 15 MODE)		
			/		
06267	754000		CLA:CLL		
06270	707741		EXBA		
06271	740040	EX51	HALT	/ERROR, EXBA DIDN'T SKIP...	
				/...IS THIS A POP=15?	
06272	700002		IOF		
06273	707762		EPA	/ENTER 15 MODE	
06274	707761		SBA	/SKIP IF IN 9 MODE	
06275	741000		SKP		
06276	740040	EX52	HALT	/ERROR, SBA SKIPPED AFTER...	
				/AN EPA WAS ISSUED.	
				/BACK TO 9 MODE	
06277	707764		EBA		
06300	707761		SBA		
06301	740040	EX53	HALT	/ERROR, SBA DIDN'T SKIP...	
				/...AFTER AN EBA.	
			/		
06302	750004		LAS		
06303	740010		RAL		
06304	740100		SMA		
06305	700042		ION		
06306	447517		ISZ	WORK3	
06307	606132		JMP	TSXG	/LOOP

```

/
/TEST IOT 3341 (SKIP IF PC24/5) IF ACS 9 = 1
/
06310 757204 PC05 LAS
06311 507425 AND K400 /CHECK ACS 9
06312 741222 SNA
06313 606320 JMP ,+5 /ACS 9 = 0 (NO PC15)
06314 703341 703341 /SKIP IF PC15 INSTALLED.
06315 606322 JMP ,+5
06316 740040 EX54 HALT /ERROR, ACS 9 IS SET, INDICATING
/NO PC15, BUT 703341 SKIPPED.

06317 606314 JMP ,=3
06320 703341 703341 /SHOULD SKIP
06321 740040 EX55 HALT /ERROR, PC15 INSTALLED, BUT
/703341 DIDN'T SKIP
/
06322 700002 IOP /PI OFF
06323 750004 LAS
06324 507440 AND K20K
06325 741200 SNA /SKIP = DON'T RELOCATE
06326 606410 JMP ENTST
06327 760207 LAW 207
06330 107237 JMS TLSSF /BELL FOR ONE PASS
06331 750004 LAS
06332 507433 AND K207
06333 740200 SEA
06334 107303 JMS PINOT /PI INHIBITED
06335 600112 JMP SEQUEN /START OVER
,EJECT

```

/RANDOM NUMBER GENERATORS

```

/
GENRAN 0
        LAC RANDEX
        SAD ENDTBL           /CHECK FOR END OF TABLE
        SKP                  /END
        JMP RANTAD=1        /GENERATE RANDOM
        LAC TBLTOP
        DAC RANDEX          /RESET INDEX TO FIRST
        LAC RANCON          /POSITION MODIFIER
        CLL!RAL            /1 LEFT
        SZL                 /WAS BIT 0 A 1
        TAD K1              /YES MAKE 17 A 1
        DAC RANCON          /RESTORE MODIFIER
        LAC* RANDEX         /GET FIRST CONTROL
        TAD RANCON          /ADD MODIFIER
        DAC* RANDEX         /NEW CONTROL = RANDOM
        ISE RANDEX         /STEP POINTER
        JMP* GENRAN        /EXIT

/
RANDEX RANTBL+10
ENDTBL RANTBL+10
TBLTOP RANTBL

/
CKNO 0
        AND K37S           /MAKE 65K OR LESS
        CMA
        DAC WORK3         /LOOP COUNTER
        JMP* CKNO         /EXIT

/
RANGEN 0
        LAC RANDEX
        SAD ENDTBL           /CHECK FOR TABLE END
        SKP                  /END
        JMP TADRAN=1        /GENERATE RANDOM
        LAC TBLTOP
        DAC RANDEX          /RESET INDEX TO FIRST
        LAC RANCON          /POSITION MODIFIER
        CLL!RAL            /1 LEFT
        SZL                 /WAS BIT 0 A 1
        TAD K1              /MAKE 17 A 1
        DAC RANCON          /RESTORE MODIFIER
        LAC* RANDEX         /GET FIRST CONTROL
        TAD RANCON          /ADD MODIFIER
        DAC* RANDEX         /NEW CONTROL = RANDOM
        NOP
        JMP* RANGEN        /EXIT
        .EJECT

```

```

26336 000000
26337 206357
26340 546360
26341 741000
26342 606352
26343 206361
26344 046357
26345 207540
26346 744010
26347 741400
26350 347412
26351 047540
26352 226357
26353 347540
26354 066357
26355 446357
26356 626336

```

```

06357 007551
26360 007551
26361 007541

```

```

06362 000000
06363 507471
06364 740001
06365 047517
06366 626362

```

```

06367 000000
06370 206357
06371 546360
06372 741000
06373 606403
06374 206361
06375 046357
06376 207540
06377 744010
06400 741400
06401 347412
06402 047540
06403 226357
06404 347540
06405 066357
06406 740000
06407 626367

```

```

/POP-15 BASIC EXERCISER 2      TAPE 7
/
/Routine FOR PROGRAM RELOCATION
/
06410 702022 ENTST IOF /PI OFF DURING RELOCATION
06411 206411 LAC .
06412 507437 AND K10K
06413 740200 SZA /SEE IF IN LO OR HI 4K
06414 606503 JMP MVBK /HI 4K
06415 740001 CMA
06416 047516 DAC WORK2 /SOURCE ADDRESS
06417 207342 LAC K777 /DEST'N ADR, TO HI 4K
06420 047517 DAC WORK3
06421 207516 MOVE LAC WORK2
06422 047337 DAC MOVES
06423 207517 LAC WORK3
06424 047340 DAC MOVED
06425 447337 RFROM ISZ MOVES
06426 227337 LAC* MOVES /SOURCE ADR.
06427 047517 DAC WORK3 /SAVE INSTRUCTION
06430 507443 AND K700K
06431 247443 XOR K700K
06432 740200 SZA /ORERATE INST, IF 0
06433 606510 JMP MRINS /MEMORY REF
06434 207517 LAC WORK3
06435 447340 MVRTN ISZ MOVED
06436 067340 DAC* MOVED /STORE IN OPPOSITE 4K
06437 547327 SAD LIMITA /DONE WITH INST, IF EQUAL
06440 741020 SKP /MOVE CONSTANT TABLES
06441 606425 JMP RFROM /MOVE ANOTHER INST.
06442 147517 DCM WORK3
06443 447337 MVCST ISZ MOVES
06444 227337 LAC* MOVES /SOURCE
06445 447340 ISZ MOVED
06446 067340 DAC* MOVED /DEST'N
06447 207337 LAC MOVES
06450 546707 SAD ENDOUT
06451 741000 SKP
06452 606443 JMP MVCST
.EJECT

```

26453 204602
26454 247437
26455 054602
26456 204545
26457 247437
26460 054545
26461 207352
26462 247437
26463 057352
26464 207351
26465 247437
26466 057351
26467 750004
26470 507433
26471 740200
26472 107303

LAC K210K
XOR K10K
DAC K210K+10000
LAC K10000
XOR K10K
DAC K10000+10000
LAC TTIN
XOR K10K
DAC TTIN+10000
LAC TTOUT
XOR K10K
DAC TTOUT+10000
LAS /LOWER
AND K207
SZA /CHECK FOR INHIBIT PI
JMS PINOT /INHIBITED
.EJECT

06473	206473	BGNAGN	LAC .	
06474	507437		AND K10K	
06475	740200		SZA	/SEE WHICH 4K
06476	741000		SKP	
06477	627333		JMP* BGNHI	/START OVER IN HI 4K
06500	760207		LAW 207	/BELL
06501	107237		JMS TLSSF	
06502	627332		JMP* BGNLO	/START IN LOW 4K
/				
/SETUP TO MOVE TO LOW 4K				
/				
06503	777777	MVBK	LAW 17777	/DESTIN
06504	047517		DAC WORK3	
06505	207342		LAC K7777	/SOURCE
06506	047337		DAC MOVES	
06507	606423		JMP MOVE+2	/MOVE PROGRAM
/				
/ADJUST MEMORY REF, INSTRUCTIONS, DO NOT ADJUST IF				
/ADR, PORTION=ANY ADR, FROM 0 TO 21.				
/				
06510	147335	MRINS	DEM WDCNT	/ADR, COMPARE WORD
06511	207517		LAC WORK3	/INST, TO BE MODIFIED
06512	507342		AND K7777	/CLEAR BITS 0-5
06513	047516		DAC WORK2	/SAVE
06514	207335		LAC WDCNT	
06515	547422		SAD K22	/DONE IF EQUAL TO 22
06516	606523		JMP ,+5	
06517	547516		SAD WORK2	/COMPARE
06520	606434		JMP MVRTN=1	/ADR, IS SOME REG, FROM 0
/TO 21, MOVE WITHOUT ADJUSTING				
/ADR, COUNT+1				
06521	447335		ISZ WDCNT	
06522	606514		JMP ,=6	/10000
06523	207437		LAC K10K	/ADJUST INST, BY 10000
06524	247517		XOR WORK3	/MOVE
06525	606435		JMP MVRTN	
/				
06526	047526	SAV3	DAC SAVAC	/THESE ARE MODIFIED FOR
06527	047527	SAV5	DAC RJMP	/RELOCATION
06530	606531	SAV6	JMP SRVINT	
.EJECT				

```

/
/SERVICE ALL INTERRUPTS
/
06531 750004 SRVINT LAS /READ ACS
06532 507437 AND K10K /BIT 5
06533 740200 SZA /CHECK BIT 5
06534 606543 JMP NOCLK /CHECK CLOCK FLAG
06535 200007 LAC 7 /RTC REGISTER
06536 741100 SPA /RTC OVERFLOW IF SKIP
06537 606546 JMP E642A+1 /NO OVERFLOW YET
06540 700001 CLSF /CLSF SHOULD SKIP
06541 740040 E642 HLT /CLOCK REG, SAYS OFERFLOW, BUT
/RTC FLAG NOT SET,
/NO OVERFLOW YET
06542 606606 JMP CLKINT /SERVICE CLOCK
/
06543 700001 NOCLK CLSF /SHOULD NOT SKIP
06544 741000 SKP /OK
06545 740040 E642A HLT /RTC FLAG IS SET. IT WAS
/NEVER SELECTED BY THE PROGRAM,
/
06546 700301 KSF
06547 741000 SKP
06550 606572 JMP RTNIT
/
06551 700314 IORS
06552 741100 SPA /STATUS WORD BIT 0 MUST = 0
06553 740040 E643 HALT /ERROR, BIT 0 SET, PI OFF
06554 207514 LAC WORK
06555 740010 RAL
06556 741100 SPA /SEE IF TTY IN USE AT TIME
/OF PI
06557 606646 JMP TTYINT /CONTINUE PRINTING
06560 700314 IORS /I/O STATUS WORD
06561 507344 AND K1400
06562 740200 SZA /CHECK FOR NO TAPE FLAGS
06563 107167 JMS RNFLG /EITHER READER OR PUNCH NO TAPE
06564 700101 RSP /CHECK FOR PI FROM READER
06565 741000 SKP
06566 607020 JMP READA /READ MORE
06567 700201 PSF /CHECK PUNCH PI
06570 606572 JMP RTNIT /SOME OTHER DEVICE
06571 627001 JMP* GOPNCH /PUNCH MORE
/
/SETUP TO RETURN TO INSTRUCTION TEST
/
06572 744000 RTNIT CLL
06573 700312 KRB
06574 207527 LAC RJMP /C(0) AT PI
06575 741100 SPA /CHECK LINK
06576 744002 STL /RESTORE LINK
06577 507463 AND K17S
06600 546605 SAD ILINT
06601 740040 E644 HALT /ERROR, PI OCCURRED AFTER LAC SAVAC
/INSTEAD OF JMP * RJMP,
/AC AT TIME OF PI
06602 207526 LAC SAVAC
06603 700042 PION ION /PI ON
06604 627527 JMP* RJMP /CONTENTS OF (0) AFTER PI

```



```
06605 206603 /
        ILINT PION
06606 700024 /
        CLKINT CLOF /RTC OFF: CLEAR RTC FLAG
06607 700001 CLSF
06610 741000 SKP
06611 740040 E644A HLT /CLOCK FLAG STILL SET
                                /AFTER A CLOF
06612 106631 JMS CLKSET /RESET CLOCK TO RANDOM VALUE
06613 606572 JMP RYNT /RETURN TO INST. TEST
        ,EJECT
```

```

/
/SETUP CLOCK VALUES
/
06614 000000 SETCLK 0
06615 106336 JMS GENRAN /GET A NO. FOR CLOCK
06616 047335 DAC WDCNT /SAVE
06617 507347 AND K777 /MAX. TIME = 9 SECS.
06620 047335 DAC WDCNT /SAVE
06621 347350 TAD M167 /MIN. TIME = 2 SEC.
06622 741100 SPA /POS. = 2 SECS. OR MORE
06623 606615 JMP SETCLK*1 /NEG = LESS THAN 2 SEC.
06624 207335 LAC WDCNT
06625 740001 CMA
06626 040007 DAC 7 /PUT VALUE IN (7)
06627 700044 CLON /CLOCK ON
06630 626614 JMP* SETCLK /EXIT

/
CLKSET 0
06631 000000 JMS RANGEN /GET A NO. FOR CLOCK
06632 106367 DAC WDCNT /SAVE
06633 047335 AND K777 /MAX. TIME = 9 SECS.
06634 507347 DAC WDCNT /SAVE
06635 047335 TAD M167 /MIN. TIME = 2 SECS.
06636 347350 SPA /POS. = 2 SECS. OR MORE
06637 741100 JMP CLKSET*1 /NEG. = LESS THAN 2 SECS.
06640 606632 LAC WDCNT
06641 207355 CMA
06642 740001 DAC 7 /PUT VALUE IN (7)
06643 040007 CLON /CLOCK ON
06644 700044 JMP* CLKSET /EXIT
06645 626631 .EJECT

```

```

/SETUP FOR READ, PUNCH, OR PRINT
/
06646 207351 TTYINT LAC TTOUT
06647 546707 SAD ENDOUT /IF EQUAL GO PUNCH AND READ
06650 606665 JMP PREADY
06651 207441 LAC K200K
06652 047514 DAC WORK
06653 700101 RSF
06654 741000 SKP
06655 740040 E645 HALT /ERROR, READ FLAG UP
06656 700201 PSF
06657 741000 SKP
06660 740040 E646 HALT /ERROR, PUNCH FLAG UP
06661 447351 ISZ TTOUT /TTOUT = CHAR, BIN POINTER
06662 227351 LAC* TTOUT /GET CHAR, FROM TTY BIN
06663 700406 TLS /PRINT ONE CHARACTER
06664 606572 JMP RYNT /RETURN TO INST, TEST

/
06665 147514 PREADY DZM WORK
06666 147353 DZM CNTA
06667 147354 DZM CNTB
06670 700402 TCF /CLEAR TTY FLAG
06671 750004 LAS
06672 507424 AND K1K
06673 741200 SNA /TEST ACS 8 A 1
06674 606677 JMP ,+3
06675 700104 RSA /SELECT READER
06676 606572 JMP RYNT /RETURN TO INST, TEST
06677 207001 LAC GOPNCH
06700 741200 SNA /0*1ST TIME THRU
06701 606710 JMP PNSTRY /START SEQUENCE
06702 700104 RSA /SELECT READER
06703 627001 JMP* GOPNCH /CONTINUE SEQUENCE

/
06704 007612 DATABL TTBUFA-1
06705 007676 ENDBIN TTBUFA+63
06706 007676 OUTTOP TTBUFA+63
06707 007762 ENDOUT TTBUFA+147
,EJECT

```

```

/
/PUNCH DATA
/
PNSTRT  JMS  CR LF          /CR,LF
        LAS
        AND  K400
        SZA
        JMP  PNXT-2        /TTY ONLY
        TCF                /CLEAR TTY FLAG
        LAS
        AND  K3K          /MASK ACS 7 AND 8
        SNA                /IF EITHER IS A 1, DON'T PUNCH
        JMP  ,+3          /PUNCH DATA
        PCF                /CLEAR PUNCH FLAG, NO MORE
                               /PI'S FROM PUNCH SHOULD OCCUR,
                               /RETURN TO INST, TEST

06723   606572           JMP  RTNIT
06724   750000           CLA
06725   700104           RSA
06726   107001           JMS  GOPNCH          /SELECT READER AND PUNCH
06727   207357           LAC  K300          /TO INITIATE SEQUENCE
06730   047361           DAC  STORE
06731   447361           PNXT  ISZ  STORE
06732   207361           LAC  STORE
06733   107001           JMS  GOPNCH          /PUNCH CHAR, IN AC 10=17
06734   207362           LAC  SPCE          / (SPCE)=240
06735   107001           JMS  GOPNCH          /PUNCH SPACE
06736   207361           LAC  STORE
06737   547363           SAD  K332          /DONE WITH ALPHABET IF EQUAL
06740   741000           SKP
06741   606731           JMP  PNXT          /PUNCH MORE CHARS.
06742   207355           LAC  K257
06743   047361           DAC  STORE
06744   447361           PNXTA ISZ  STORE
06745   207361           LAC  STORE
06746   107001           JMS  GOPNCH
06747   207362           LAC  SPCE
06750   107001           JMS  GOPNCH
06751   207361           LAC  STORE
06752   547356           SAD  K271
06753   741000           SKP
06754   606744           JMP  PNXTA
06755   207364           LAC  KCRLF          / (KCRLF)=CR,LF
06756   047361           DAC  STORE
06757   107001           JMS  GOPNCH          /PUNCH CR
06760   207361           LAC  STORE
06761   107264           JMS  ROTAT9        /ROTATE 9 RIGHT
06762   107001           JMS  GOPNCH          /PUNCH LF
06763   777770           LAW  =10
06764   047361           DAC  STORE
06765   750001           CLA!CMA          /AC = 777777
06766   700010           /CLEAR AC WITH MR 14
06767   740200           SZA
06772   740040           E647 HALT          /ERROR, EVENT TIME 1 DIDN'T
                               /CLEAR AC,

06771   750004           LAS

```

PAGE 112

BX8K

BX8K

06772 507425
06773 740200
06774 606727
06775 107001
06776 447361
06777 606765
07000 606727

AND K400
SZA
JMP PNXT=2
JMS GOPNCH
ISZ STORE
JMP E647=3
JMP PNXT=2
.EJECT

/TTY ONLY
/PUNCH 8 FRAMES OF 0'S

/START NEW LINE

```

07001 000000 GOPNCH 0
07002 606663 JMP E646+3 /PRINT
07003 700204 PSA
07004 700201 PSF
07005 741007 SKP
07006 740040 E647A HLT /PUNCH FLAG SET
07007 750004 LAS
07010 507430 AND K4K /MASK ACS 6
07011 740200 SZA /IF A 1, DON'T USE CNTA OR CNTB
07012 606572 JMP RTNIT /RETURN TO INST, TEST
07013 447353 ISZ CNTA /CNTA=PUNCH SELECTED
07014 207354 LAC CNTB
07015 740200 SZA /0=WAIT FOR PI
07016 607053 JMP SUB1 /1=SELECT READER AGAIN
07017 606572 JMP RTNIT /RETURN TO INST, TEST

/READ PUNCHED INFO
/
READA LAS
07020 750004 AND K3K /MASK ACS 7 AND R
07021 507427 SZA /IF EITHER IS A 1, READ FULL SPEED
07022 740200 JMP READB
07023 607135 LAS
07024 750004 AND K4K /MASK ACS 6
07025 507430 SNA /IF A 1, CLEAR READER FLAG, NO
07026 741200 /MORE PI'S FROM READER

07027 607032 JMP ,+3
07030 700112 RRB /CLEAR READER FLAG
07031 606572 JMP RTNIT /RETURN TO INST, TEST AND
/WAIT FOR PUNCH PI
/READ ONE
/0=NO DATA IN READER YET

07032 700112 RRB
07033 740200 SZA
07034 607041 JMP ZRONOT
07035 207353 LAC CNTA /SEE IF PUNCH IS SELECTED
07036 740200 SZA
07037 607053 JMP SUB1 /YES, SUBTRACT FROM CNTA
07040 607051 JMP TADD1 /READER SELECTED
07041 447352 ZRONOT ISZ TTIN /STORE CHAR. IN TTY BIN
07042 067352 DAC* TTIN
07043 207352 LAC TTIN
07044 546703 SAD ENDBIN /CHECK FOR 52 CHARACTERS STORED
07045 607061 JMP SETTY /DONE, SETUP TO PRINT
07046 207353 LAC CNTA
07047 740200 SZA
07050 607053 JMP ,+3

/
TADD1 ISZ CNTB
07051 447354 JMP RTNIT /RETURN TO INST, TEST
07052 606572 SUB1 LAW -1
07053 777777 TAD CNTA /(CNTA)-1
07054 347353 DAC CNTA
07055 047353 DZM CNTB
07056 147354 RSA
07057 700104 JMP RTNIT /RETURN TO INST, TEST
07060 606572
/
.EJECT

```

```

07061 700201   SETTY  PSF           /WAIT FOR PUNCH
07062 607061   JMP  ,=1
07063 700202   PCF           /CLEAR PUNCH FLAG
07064 700402   TCF           /CLEAR TTY FLAG
07065 207334   LAC BREAK
07066 547417   SAD K12A
07067 607112   JMP PUN6
07070 447334   ISZ BREAK
07071 206704   LAC DATABL   /RESTORE INPUT/OUTPUT POINTERS
07072 047352   DAC TTIN     /READER TO BIN
07073 206706   LAC OUTTOP
07074 047351   DAC TTOUT    /BIN TO TTY
07075 447352   XFR1 ISZ TTIN  /TRANSFER BUFFER A TO BUFFER B
07076 227352   LAC* TTIN
07077 447351   ISZ TTOUT
07100 067351   DAC* TTOUT
07101 207351   LAC TTOUT
07102 546707   SAD ENDOUT   /DONE IF EQUAL TO TTRUFB+63
07103 741000   SKP
07104 607075   JMP XFR1     /TRANSFER ANOTHER
07105 206704   LAC DATABL   /RESTORE BUFFER POINTERS
07106 047352   DAC TTIN
07107 206706   LAC OUTTOP   /TTBUFB-1
07110 047351   DAC TTOUT
07111 606651   JMP TTYINT+3 /BEGIN PRINTING

/
07112 207001   PUN6 LAC GOPNCH
07113 507463   AND K17S
07114 547134   SAD K647     /PUNCH 0'S ONLY AT END OF BLOCK
07115 741000   SKP
07116 607071   JMP XFR1-4   /((GOPNCH) NOT= GOPNCH=3
07117 777771   LAW =7
07120 047334   DAC BREAK    /FRAME COUNTER
07121 777777   LAW =1       /AC=777777
07122 700010   700010      /CLEAR AC WITH BIT 14
07123 740200   SZA
07124 740040   E648 HALT       /ERROR, MB14 DIDN'T CLEAR AC
07125 700204   PSA         /PUNCH BLANK FRAME
07126 700201   PSF
07127 607126   JMP ,=1
07130 447334   ISZ BREAK
07131 607121   JMP E648=3
07132 700202   PCF         /CLEAR PUNCH FLAG
07133 607071   JMP XFR1-4   /SETUP TO PRINT

/
07134 006776   K647 GOPNCH=3
/
      .EJECT

```

```

/READB ROUTINE IS USED ONLY WHEN PUNCH IS INHIBITED
/BY ACS 7 OR 8, OR BOTH, READER RUNS AT FULL SPEED.
/
07135 750004 READB LAS
07136 507430 AND K4K /MASK ACS 6
07137 741200 SNA /IF A 1, DON'T READ
07140 607143 JMP ,+3
07141 700112 RRB /CLEAR READER FLAG
07142 606572 JMP RTNIT /RETURN TO INST, TEST
07143 700112 RRB /GET CHAR, FROM BUFFER.
07144 741200 SNA /0 = NO DATA IN READER YET,
07145 607153 JMP SELECT /SELECT READER AGAIN
07146 447352 ISZ TTIN /BUFFER POINTER +1
07147 067352 DAC* TTIN /STORE CHAR, IN TTBUFA
07150 207352 LAC TTIN
07151 546705 SAD ENDBIN /CHECK FOR 52 CHARS. STORED
07152 607160 JMP ,+6 /TTBUFA IS FULL
07153 700104 SELECT RSA /SELECT READER
07154 700101 RSF
07155 741000 SKP
07156 740040 E649 HLT /READER FLAG SET
07157 606572 JMP RTNIT /RETURN TO INST, TEST
/
07160 206704 LAC DATABL
07161 047352 DAC TTIN /RESTORE TTBUFA POINTER
07162 750004 LAS
07163 507431 AND K6K /MASK ACS 6 AND 7
07164 740200 SZA /IF EITHER A 1, DON'T PRINT
07165 607153 JMP SELECT /SELECT READER AGAIN
07166 607064 JMP SETTY*3 /SETUP TO PRINT
/
/SERVICE NO TAPE CONDITIONS
/
07167 000000 RNFLG 0
07170 507424 AND K1K /CHECK FOR READER NO TAPE
07171 740200 SZA
07172 607177 JMP ,+5 /READER
07173 760320 LAW 320 /PUNCH NO TAPE
07174 247365 XOR K520K
07175 047402 DAC NTFLG+1
07176 607201 JMP OUTFLG /PRINT R OR P NO TAPE
07177 760322 LAW 322 /READER NO TAPE
07200 607174 JMP ,=4
/
OUTFLG LAC NTFL
07201 207216 DAC WDCNT
07202 047335 JMS CRLF /CR,LF
07203 107273 ISZ WDCNT
07204 447335 LAC* WDCNT
07205 227335 SNA
07206 741200 JMP CLRFLG
07207 607214 JMS TLSSF
07210 107237 JMS ROTAT9
07211 107264 JMS TLSSF
07212 107237 JMS TLSSF
07213 607204 JMP OUTFLG+3

```


PAGE 116

BX8K

BX8K

07214
07215
07216

107273
627167
207401

CLRFLG
NTFL

JMS CRLF
JMP* RNFLG
NTFLG
.EJECT

/CRLF
/RETURN TO SEQUENCE

PAGE 117

BX8K

BX8K

```

/PUNCH LEADER
/
PNLEDR 2
LAW =310
DAC WDCNT
CLA
PSA
PSF
JMP ,=1
ISE WDCNT
JMP ,=4
JMP* PNLEDR

/
PNMARK 0
LAW =1
PSA
PSF
JMP ,=1
JMP* PNMARK /EXIT
,EJECT
```

```

/PRINT A CHARACTER
/
07237 000000 TLSSF 0
07240 047342 DAC MOVED
07241 207514 LAC WORK
07242 740010 RAL
07243 740100 SMA /CHECK TTY FLAG
07244 607247 JMP ,+3
07245 700401 TSF
07246 607245 JMP ,=1 /WAIT FOR FLAG
07247 207340 LAC MOVED
07250 700406 TLS
07251 700401 TSF
07252 607251 JMP ,=1
07253 207002 LAC GOPNCH+1
07254 547302 SAD KJMP
07255 607262 JMP ,+5
07256 207514 LAC WORK /CLEAR TTY IF BIT 1 = 0
07257 740010 RAL
07260 740100 SMA
07261 700402 TCF
07262 207340 LAC MOVED
07263 627237 JMP* TLSSF

/ROTATE 9 RIGHT
/
07264 000000 ROTAT9 0
07265 742020 RTR; RTR; RTR
07266 742020
07267 742020
07270 742020 RTR; RAR
07271 740020
07272 627264 JMP* ROTAT9

/CARRIAGE RETURN, LINEFEED
/
07273 000000 CRLF 0
07274 760215 LAW 215 /CR
07275 107237 JMS TLSSF
07276 547300 SAD ,+2
07277 627273 JMP* CRLF /EXIT
07300 760212 LAW 212 /LF
07301 607275 JMP CRLF+2

/
07302 606663 KJMP JMP E646+3
/
.EJECT

```

```

/PRINT "COMPLETE"
/
PINOT 0
LAC WORK4 /PASS COUNTER
SAD K12A /PRINT IF EQUAL TO 1
SKP
JMP* PINOT /START PROGRAM
DEM WORK4
DEM WORK4+10000
LAC COMPA
DAC 14 /PRINT COMPLETE
JMS CRLF
LAC* 14
SNA /DONE PRINTING IF 0
JMP ,+5
JMS TLSSF /PRINT 1 CHAR
JMS ROTAT9
JMS TLSSF /PRINT 2ND
JMP ,+6 /GET NEXT PAIR
JMS CRLF /CR, LF
JMP* PINOT

/
COMPA COMP
.EJECT

```

/CONSTANT TABLE FOR CHECKERBOARD AND PI
 /SERVICE ROUTINES

07327	752525	LIMITA	752525	/DELIMITER
07330	000000	PATR	0	
07331	000000	PATWD	0	
07332	000112	SGNLO	SEQUEN	
07333	010112	BGNHI	SEQUEN+10000	
07334	000000	RREAK	0	
07335	000000	WDCNT	0	
07336	777776	WC256	777776	
07337	000000	MOVES	0	
07340	000000	MOVED	0	
07341	777777	BITSUP	777777	
07342	007777	K7777	7777	
07343	100000	K100K	100000	
07344	001400	K1400	1400	
07345	003400	K3400	3400	
07346	500000	K500K	500000	
07347	000777	K777	777	
07350	777611	M167	777611	
07351	000000	TTOUT	0	
07352	000000	TTIN	0	
07353	000000	CNTA	0	
07354	000000	CNTB	0	
07355	000257	K257	257	
07356	000271	K271	271	
07357	000300	K300	300	
07360	000301	K301	301	
07361	000000	STORE	0	
07362	000240	SPCE	240	
07363	000332	K332	332	
07364	212215	KCRLF	212215	
07365	520000	K520K	520000	
07366	000000	LWR	0	
07367	000000	UPR	0	
07370	000000	WC02	0	
07371	000000	WC04	0	
07372	000000	WC32	0	

.EJECT

```

/
/PRINT ROUTINE CONSTANTS
/"COMPLETE"
/
COMP      ,
          317303; 320315; 305314; 305324; ?
27373    007373
27374    317303
27375    320315
27376    305314
27377    305324
27402    000000

```

```

/
/R OR P NO TAPE
/
NTFLG    ,
          0
          317316; 324240; 320301
          240305; 207207
          0
27401    007401
27402    000000
27403    317316
27404    324240
27405    320301
27406    240305
27407    207207
27410    000000

```

```

/CONSTANT AND ERROR TABLES.      NOT MODIFIED WHEN IN HI 4K

```

```

/
K0       0
K1       1
K2       2
K4       4
K10      10
K11      11
K12A     12
K100     100
K20      20
K22      22
K40      40
K1K      1000
K400     400
K2K      2000
K3K      3000
K4K      4000
K6K      6000
K200     200
K207     207400
K40K     40000
K400K    400000
K402K    400002
K10K     10000
K20K     20000
K200K    200000
K600K    600000
K700K    700000
K2021    2021
K2120    2120
K1S      111111
K2S      222222
K3S      333333
27411    000000
27412    000001
27413    000002
27414    000004
27415    000010
27416    000011
27417    000012
27420    000100
27421    000020
27422    000022
27423    000040
27424    001000
27425    000400
27426    002000
27427    003000
27430    004000
27431    006000
27432    000200
27433    207400
27434    040000
27435    400000
27436    400002
27437    010000
27440    020000
27441    200000
27442    600000
27443    700000
27444    002021
27445    002120
27446    111111
27447    222222
27450    333333

```

PAGE 122

BX8K

BX8K

07451	444444	K4S	444444
07452	555555	K5S	555555
07453	666666	K6S	666666
07454	777777	K7S	777777
07455	011111	K51S	11111
07456	012222	K12S	12222
07457	013333	K13S	13333
07460	014444	K14S	14444
07461	015555	K15S	15555
07462	016666	K16S	16666
07463	017777	K17S	17777
07464	002525	K2525	2525
07465	005252	K5252	5252
07466	252525	K010	252525
07467	525252	K101	525252
07470	525253	K53	525253
07471	077777	K37S	077777
07472	525002	K502	525002

.EJECT

07473	700042	K7X42	700042
07474	700002	K7XX2	700002
07475	760002	K76X2	760002
07476	100002	K1XX2	100002
07477	604002	K6X42	604002
07500	344002	K344X2	344002
07501	741000	KSKP	SKP
07502	750000	KCLA	CLA
07503	777776	M1	777776
07504	777773	M4	777773
07505	777737	M40	777737
07506	777377	M400	777377
07507	773777	M4K	773777
07510	737777	M40K	737777
07511	377777	M400K	377777
07512	000377	K377	377
		/	
07513	000000	RJCNT	0
07514	000000	WORK	0
07515	000000	WORK1	0
07516	000000	WORK2	0
07517	000000	WORK3	0
07520	000000	WORK4	0
07521	000000	IIADR	0
07522	000000	AUTNOT	0
07523	000000	TCLK	0
07524	740010	XCTRAL	RAL
07525	740001	AUTCMA	CMA
07526	000000	SAVAC	0
07527	000000	RJMP	0
07530	420015	LAWAUT	XCT* 15
07531	777777	LAWFUL	LAW 17777
07532	120015	JMSAUT	JMS* 15
07533	740040	KHALT	740040
07534	620012	JMPAUT	JMP* 12
07535	200000	SAV4	LAC 0
07536	741400	KS2L	741400
07537	740400	KSNL	740400
07540	123456	RANCON	123456
07541	654321	RANTBL	654321
07542	361416		361416
07543	055363		055363
07544	546060		546060
07545	243035		243035
07546	762572		762572
07547	453237		453237
07550	150214		150214
07551	000000		0
		.EJECT	

/ERROR TABLES

```

07552 000000 /JMPRET 0 /JMP 22
07553 000000 J111 0 /JMP 11111 (E509)
07554 000000 J222 0 /JMP 12222 (E510)
07555 000000 J333 0 /JMP 13333 (E5111)
07556 000000 J444 0 /JMP 14444 (E512)
07557 000000 J555 0 /JMP 15555 (E513)
07560 000000 J666 0 /JMP 16666 (E514)
07561 000000 J777 0 /JMP 17777 (E515)
07562 000000 J525 0 /JMP 15252 (E516)
07563 000000 J252 0 /JMP 12525 (E517)
07564 000000 CAL0 0 /CAL FROM 17757 EXT, LINK = 0 (E518)
07565 000000 CAL1 0 /CAL FROM 17757, LINK = 1 (E520)
07566 000000 JSM71 0 /JMS FROM 07777 TO 11111 (E522)
07567 000000 JSM72 0 /JMS FROM 07776 TO 12222 (E524)
07570 000000 JSM73 0 /JMS FROM 07775 TO 13333 (E526)
07571 000000 JSM74 0 /JMS FROM 07774 TO 14444 (E528)
07572 000000 JSM75 0 /JMS FROM 07773 TO 15555 (E530)
07573 000000 JSM76 0 /JMS FROM 07772 TO 16666 (E532)
07574 000000 JSM77 0 /JMS FROM 07771 TO 17777 (E534)
07575 000000 JS252 0 /JMS FROM 12525 TO 15252 (E536)
07576 000000 JS525 0 /JMS FROM 15252 TO 12525 (E538)
07577 000000 JSSS 0 /JMS SERIES TEST (E540)
/
07600 000000 XCT11 0 /XCT JMS, FROM 11111 XCT (16666) (E562)
07601 000000 XCT12 0 /XCT JMS, FROM 12222 XCT (15555) (E564)
07602 000000 XCT13 0 /XCT JMS, FROM 13333 XCT (14444) (E566)
07603 000000 XCT17 0 /XCT J,S FROM 07776 XCT (17776) (E568)
07604 000000 XCT125 0 /XCT JMS, FROM 12525 XCT (15252)
/
07605 000000 JST77 0 /JMS* 07777 (E592)
07606 000000 JST66 0 /JMS* 16666 (E594)
07607 000000 JST55 0 /JMS* 15555 (E596)
07610 000000 JST44 0 /JMS* 14444 (E598)
07611 000000 AUTJMP 0 /JMP* 12 (AUTO-INDEX) (E620)
07612 000000 AUTJMS 0 /JMS* 17 (AUTO-INDEX) (E633)
07613 000000 TTBUFA 0
07614 752525 752525
000000 .END
SIZE=07615 NO ERROR LINES

```

AAC	723000
AAS	720000
ABMATS	02563
ADDAC	01557
ADDAC1	02025
ADDI	05413
ADEDON	03063
AMBPBT	02624
AMBSUM	03060
AMINSB	02466
AMNSBT	02522
ANDAC	01341
ANEG	03052
APLSBT	02507
APLUSB	02452
APOS	03051
AURJMP	06027
AUTCMA	07525
AUTJMP	07611
AUTJMS	07612
AUTNOT	07522
AUTOIN	05414
AUTR	05561
AUTRET	06025
AUTRE1	05673
AUTRJM	06026
AXR	737000
AXS	725000
BEGIN	00022
BGNAGN	06473
BGNHI	07333
BGNLO	07332
BISETU	03071
BITN	06004
BITSUP	07341
BITTS1	03110
BITTS2	03123
BMAMBT	02576
BMASUM	03057
BMINSA	02400
BMNSAT	02550
BNEG	03054
BPOS	03053
BREAK	07334
CAL0	07564
CAL1	07565
CKLP	03044
CKNO	06362
CLAC	734000
CLKINT	06606
CLKSET	06631
CLLR	736000
CLOF	700004
CLON	700044
CLRFLG	07214

CLSF	700001
CLX	735000
CNTA	07353
CNTB	07354
COMP	07373
COMPA	07326
CONCHG	03022
CRLF	07273
DACAC	03374
DATABL	06704
DBRX	00237
DBRXX	00242
DBRXXX	00250
DZMAC	03255
EBA	707764
ENDBIN	06705
ENDOUT	06707
ENDTBL	06360
ENTST	06410
EPA	707762
ER1	05762
EXBA	707741
EX01	06034
EX02	06041
EX03	06043
EX04	06050
EX05	06052
EX06	06061
EX07	06064
EX10	06066
EX13	06071
EX14	06075
EX15	06077
EX16	06110
EX17	06115
EX18	06120
EX19	06122
EX20	06125
EX21	06135
EX22	06137
EX23	06143
EX24	06145
EX25	06151
EX26	06153
EX27	06157
EX28	06161
EX29	06165
EX30	06167
EX31	06172
EX32	06174
EX33	06176
EX34	06203
EX35	06205
EX36	06211
EX37	06213

EX38	06217
EX39	06221
EX40	06225
EX41	06227
EX42	06234
EX43	06236
EX44	06243
EX45	06245
EX46	06253
EX47	06255
EX48	06261
EX49	06264
EX50	06266
EX51	06271
EX52	06276
EX53	06301
EX54	06316
EX55	06321
E113	00677
E114	00724
E115	00740
E116	00754
E140	01002
E141	01030
E142	01045
E143	01062
E162	01066
E163	01072
E164	01076
E165	01102
E166	01106
E167	01112
E168	01116
E169	01122
E170	01125
E206	01136
E207	01141
E208	01144
E209	01147
E210	01152
E211	01154
E212	01160
E213	01163
E214	01166
E215	01171
E216	01174
E217	01177
E218	01221
E219	01206
E220	01210
E221	01215
E222	01217
E223	01224
E224	01226
E225	01233

E226	01235
E24	00157
E25	00163
E258	01245
E259	01247
E26	00167
E260	01253
E261	01255
E262	01261
E263	01263
E264	01267
E265	01271
E266	01276
E267	01300
E268	01305
E269	01307
E27	00173
E27A	00207
E270	01314
E271	01316
E272	01323
E273	01334
E274	01344
E275	01350
E276	01354
E277	01361
E278	01375
E279	01377
E28	00217
E280	01407
E281	01414
E282	01421
E283	01425
E284	01440
E285	01450
E286	01452
E287	01457
E288	01461
E289	01466
E29	00223
E290	01470
E291	01476
E292	01500
E293	01504
E294	01506
E295	01512
E296	01514
E297	01522
E298	01524
E299	01532
E30	00227
E300	01534
E301	01544
E302	01552
E303	01564

E304	01566
E305	01574
E306	01576
E307	01604
E308	01606
E309	01614
E31	00233
E310	01616
E311	01624
E312	01626
E313	01634
E314	01636
E315	01644
E316	01646
E317	01654
E318	01656
E319	01664
E32	00262
E320	01666
E321	01675
E322	01677
E323	01706
E324	01710
E325	01717
E326	01721
E327	01730
E328	01732
E329	01741
E33	00265
E330	01743
E331	01752
E332	01754
E333	01763
E334	01765
E335	01774
E336	01776
E337	02005
E338	02007
E339	02016
E34	00271
E340	02020
E347	02033
E348	02035
E349	02044
E35	00274
E350	02046
E351	02055
E352	02057
E353	02066
E354	02070
E355	02077
E356	02101
E357	02110
E358	02112
E359	02121

E36	00300
E360	02123
E361	02132
E362	02134
E363	02143
E364	02145
E365	02154
E366	02156
E367	02165
E368	02167
E369	02176
E37	00303
E370	02200
E371	02207
E372	02211
E373	02220
E374	02222
E375	02231
E376	02233
E377	02242
E378	02244
E379	02253
E38	00307
E380	02255
E381	02264
E382	02266
E383	02275
E384	02277
E385	02306
E386	02310
E387	02317
E388	02321
E389	02330
E39	00312
E390	02332
E391	02341
E392	02343
E393	02351
E394	02353
E395	02361
E396	02363
E397	02371
E398	02373
E399	02406
E40	00315
E400	02410
E401	02514
E402	02520
E403	02527
E404	02533
E405	02542
E406	02546
E407	02570
E408	02574
E409	02603

E41	00320
E410	02607
E411	02616
E412	02622
E413	02631
E414	02635
E415	02643
E416	02647
E417	02657
E418	02663
E419	02674
E42	00324
E420	02700
E421	02712
E422	02716
E423	02731
E424	02735
E425	02751
E426	02755
E427	02772
E428	02776
E429	03014
E43	00327
E430	03020
E431	03115
E432	03121
E433	03130
E434	03134
E435	03156
E436	03161
E437	03164
E438	03170
E439	03175
E44	00333
E440	03201
E441	03205
E442	03212
E443	03231
E444	03250
E445	03261
E446	03266
E447	03273
E448	03300
E449	03305
E45	00336
E450	03312
E451	03317
E452	03324
E453	03331
E454	03336
E455	03344
E456	03346
E457	03351
E458	03361
E459	03367

E46	00342
E460	03400
E461	03405
E462	03412
E463	03417
E464	03424
E465	03431
E466	03436
E467	03443
E468	03450
E469	03462
E47	00346
E470	03472
E471	03503
E472	03507
E473	03514
E474	03520
E475	03525
E476	03531
E477	03536
E478	03542
E479	03547
E48	00351
E480	03553
E481	03560
E482	03564
E483	03571
E484	03574
E485	03601
E486	03604
E487	03611
E488	03614
E489	03621
E49	00355
E490	03624
E491	03631
E492	03634
E493	03641
E494	03644
E495	03651
E496	03654
E497	03661
E498	03664
E499	03671
E50	00360
E500	03674
E501	03714
E502	03724
E503	03750
E504	03756
E505	03764
E506	03773
E507	04002
E508	04031
E509	04037

E51	00363
E510	04050
E511	04061
E512	04072
E513	04103
E514	04114
E515	04125
E516	04136
E517	04147
E518	04200
E519	04216
E519A	04221
E52	00370
E520	04224
E521	04237
E521A	04242
E522	04260
E523	04275
E524	04300
E525	04316
E526	04321
E527	04337
E528	04342
E529	04360
E53	00375
E530	04363
E531	04401
E532	04404
E533	04422
E536	04425
E537	04442
E538	04445
E539	04462
E54	00402
E540	04465
E541	04470
E542	04472
E543	04474
E544	04500
E545	04510
E546	04517
E547	04526
E548	04535
E549	04617
E55	00410
E550	04622
E551	04627
E552	04631
E553	04633
E554	04637
E555	04644
E556	04650
E557	04656
E558	04660
E559	04665

E56	02417
E560	04667
E561	04675
E562	24700
E563	04715
E564	04720
E565	04735
E566	04740
E567	04755
E568	04760
E569	04775
E57	00422
E570	05000
E571	05015
E572	05034
E573	05036
E58	00427
E584	05101
E585	05112
E586	05123
E587	05134
E588	05145
E589	05156
E59	00434
E590	05167
E591	05200
E592	05211
E593	05230
E594	05235
E595	05253
E596	05257
E597	05275
E598	05301
E599	05317
E60	00440
E600	05353
E601	05361
E602	05373
E603	05422
E604	05426
E605	05435
E606	05441
E607	05450
E608	05454
E609	05463
E61	00443
E610	05467
E611	05476
E612	05502
E613	05511
E614	05515
E615	05524
E616	05530
E617	05536
E618	05541

E619	05545
E62	00440
E620	05550
E621	05565
E622	05576
E623	05602
E624	05612
E625	05616
E626	05626
E627	05630
E628	05634
E629	05640
E63	00451
E630	05647
E631	05653
E632	05657
E633	05662
E634	05700
E635	05704
E636	05712
E637	05716
E638	05721
E639	05730
E64	00454
E640	05743
E641	05747
E642	06541
E642A	06545
E643	06553
E644	06601
E644A	06611
E645	06655
E646	06660
E647	06770
E647A	07006
E648	07124
E649	07156
E65	00462
E66	00467
E67	00473
E68	00501
E69	00504
E70	00510
E71	00513
E72	00517
E73	00522
E74	00526
E75	00532
E76	00535
E77	00540
E78	00545
E79	00551
E80	00555
E81	00561
E82	00564

E83	00572
E84	00573
E85	00577
E86	00623
E87	00626
E88	00613
E89	00621
E90	00626
E91	00636
E92	00646
GENRAN	06336
GOPNCH	07001
HALT	740040
IAC	740030
IIADR	07521
ILINT	06605
INHIT	00150
INITPI	00147
INIT4K	04003
INK52	05326
IOTST	00154
ISZAC	03477
JMPAUT	07534
JMPRET	07552
JMPSEQ	04163
JMSAUT	07532
JMSI1	05327
JSI44	05337
JSI55	05335
JSI66	05332
JSM71	07566
JSM72	07567
JSM73	07570
JSM74	07571
JSM75	07572
JSM76	07573
JSM77	07574
JSSS	07577
JST44	07610
JST55	07607
JST66	07606
JST77	07605
JS1	04467
JS2	04471
JS252	07575
JS3	04473
JS4	04477
JS525	07576
J111	07553
J222	07554
J252	07563
J333	07555
J444	07556
J525	07562
J555	07557

J666	07560
J777	07561
KCALE	04255
KCAL0	04253
KCLA	07502
KCRLF	07364
KHALT	07533
KJMP	07302
KJS1	04576
KJS2	04577
KJS3	04600
KJS4	04601
KNOP	06005
KRB	700312
KSF	700301
KSKP	07501
KSNL	07537
KSZL	07536
K0	07411
K010	07466
K1	07412
K1K	07424
K1S	07446
K1XX2	07476
K10	07415
K10K	07437
K100	07420
K100K	07343
K10000	04545
K101	07467
K11	07416
K11110	06022
K11111	06023
K12	05047
K12A	07417
K12S	07456
K12221	06020
K12222	06021
K13S	07457
K13332	06016
K13333	06017
K14S	07460
K1400	07344
K14443	06014
K14444	06015
K15S	07461
K15252	06024
K15253	05334
K15554	06012
K15555	06013
K16S	07462
K16665	06010
K16666	06011
K17S	07463
K17776	06006

K17777	06007
K2	07413
K2K	07426
K2S	07447
K2Z	07421
K20K	07440
K200	07432
K200K	07441
K2021	07444
K207	07433
K210K	04602
K2120	07445
K2152	04612
K22	07422
K23	05053
K2525	07464
K257	07355
K271	07356
K273	04607
K274	04606
K275	04605
K276	04604
K277	04603
K3K	07427
K3S	07450
K300	07357
K301	07360
K332	07363
K34	05057
K3400	07345
K344X2	07500
K37S	07471
K377	07512
K4	07414
K4K	07430
K4S	07451
K40	07423
K40K	07434
K400	07425
K400K	07435
K402K	07436
K415	04575
K426	04571
K5S	07452
K500K	07346
K502	07472
K51S	07455
K520K	07365
K5252	07465
K53	07470
K6K	07431
K6S	07453
K6X42	07477
K600K	07442
K615	04611

K626	04610
K647	07134
K7S	07454
K7XX2	07474
K7X42	07473
K700K	07443
K71	04574
K72	04566
K73	04564
K74	04561
K75	04556
K76	04553
K76X2	07475
K77	04550
K777	07347
K7777	07342
LACIN	05071
LACK	01242
LAWAUT	07530
LAWD	05754
LAWFUL	07531
LAWS	05756
LEM	707704
LIMITA	07327
LWR	07366
MABPAT	02611
MAPLMB	02535
MINSAB	02444
MINUSA	02424
MINUSB	02434
MOD	04164
MODNEG	03103
MODX	04034
MOVE	06421
MOVED	07340
MOVES	07337
MRINS	06510
MSKBIT	03061
MVBK	06503
MVCST	06443
MVRTN	06435
M0ACPA	02637
M1	07503
M167	07350
M4	07504
M4K	07507
M40	07505
M40K	07510
M400	07506
M400K	07511
NOCLK	06543
NOP1	740000
NOP2	740000
NOP3	740000
NTFL	07216

NTFLG	07401
OFLCH1	02662
OFLCH2	02677
OFLCH3	02715
OFLCH4	02734
OFLCH5	02754
OFLCH6	02775
OFLCH7	03017
OFLCH8	03120
OFLCH9	03133
OFLCK1	02517
OFLCK2	02532
OFLCK3	02545
OFLCK5	02573
OFLCK6	02606
OFLCK7	02621
OFLCK8	02634
OFLCK9	02646
OPERAT	00260
OPRAT	00256
OUTFLG	07201
OUTTOP	06706
PAL	722000
PASS2	03062
PATR	07330
PATWD	07331
PAX	721000
PCF	700202
PC05	06310
PINOT	07303
PION	06603
PLA	730000
PLX	731000
PNLEDR	07217
PNMARK	07231
PNSTRY	06710
PNXT	06731
PNXTA	06744
PREADY	06665
PSA	700204
PSB	700244
PSF	700201
PUN6	07112
PXA	724000
PXL	726000
RANADD	02415
RANCON	07540
RANDEX	06357
RANGEN	06367
RANTAD	06353
RANTBL	07541
RCALS0	04212
RCALS1	04233
RCAL0	04252
RCAL1	04254

RCF	700102
READA	070200
READR	071335
RFROM	06425
RJCNT	07513
RJMI1	05330
RJMI2	05333
RJMI3	05336
RJMI4	05340
RJMP	07527
RJMP1	04045
RJMP2	04056
RJMP3	04067
RJMP4	04100
RJMP5	04111
RJMP6	04122
RJMP7	04133
RJMP8	04144
RJMP9	04155
RJMSS	04501
RJMS14	04436
RJMS15	04456
RJMS71	04271
RJMS72	04312
RJMS73	04333
RJMS74	04354
RJMS75	04375
RJMS76	04416
RJS11	05223
RJS11X	05331
RJS12	05247
RJS13	05271
RJS14	05313
RJSM25	04567
RJSM52	04572
RJSM71	04543
RJSM72	04546
RJSM73	04551
RJSM74	04554
RJSM75	04557
RJSM76	04562
RJ111	04165
RJ222	04166
RJ252	04174
RJ333	04167
RJ444	04170
RJ525	04175
RJ555	04171
RJ666	04172
RJ777	04173
RNFLG	07167
ROTAT9	07264
RRB	700112
RSA	700104
RSB	700144

RSF	700101
RSM25	04570
RSM52	04573
RSM71	04544
RSM72	04547
RSM73	04552
RSM74	04555
RSM75	04560
RSM76	04563
RSM77	04565
RTAT	00653
RTNIT	06572
RTSS	00755
RXCT1	04711
RXCT2	04731
RXCT3	04751
RXCT4	04771
RXCT5	05011
SADAC	03153
SAVAC	07526
SAV3	06526
SAV4	07535
SAV5	06527
SAV6	06530
SBA	707761
SELECT	07153
SEQUEN	00112
SERS01	02651
SERS02	02665
SERS03	02702
SERS04	02720
SERS05	02737
SERS06	02757
SERS07	03000
SETCLK	06614
SETTY	07061
SPCE	07362
SRVINT	06531
STORE	07361
SUB1	07053
SUMNEG	03055
SUMPOS	03056
SNWA	742030
TADAC	01445
TADD1	07051
TADRAN	06404
TBLTOP	06361
TCF	700402
TCLK	07523
TELLY	00076
TIAC	06030
TLAW	01132
TLS	700406
TLSSF	07237
TSCAL	04176

TSDBR	22214
TSF	700401
TSJMS	24256
TSWH	26124
TSXCT	24613
TSXG	26132
TTBUFA	27613
TTIN	27352
TTOUT	27351
TTYINT	26646
UPR	27367
WC02	27370
WC04	27371
WC256	27336
WC32	27372
WDCNT	27335
WORK	27514
WORK1	27515
WORK2	27516
WORK3	27517
WORK4	27520
XCTDAC	25067
XCTDEM	25412
XCTISZ	25066
XCTRAL	27524
XCTR12	25064
XCTTAD	25070
XCT11	27600
XCT12	27601
XCT12S	25063
XCT125	27604
XCT13	27602
XCT17	27603
XFR1	27075
XORAC	21404
XTJMSI	25205
XTR11	25045
XTR12	25051
XTR13	25055
XTR17	25061
TXCT	25341
XT1R	25046
XT11S	25044
XT12S	25050
XT13S	25054
XT17S	25060
XT2R	25052
XT3R	25056
XT4R	25062
XT5R	25065
ZRONOT	27041

BEGIN	00022
TELLY	00076
SEQUEN	00112
INITPI	00147
INHIT	00152
IOTST	00154
E24	00157
E25	00163
E26	00167
E27	00173
E27A	00207
TSDBR	00214
E28	00217
E29	00223
E30	00227
E31	00233
DBRX	00237
DBRXX	00242
DBRXXX	00250
OPRAT	00256
OPERAT	00260
E32	00262
E33	00265
E34	00271
E35	00274
E36	00300
E37	00303
E38	00307
E39	00312
E40	00315
E41	00320
E42	00324
E43	00327
E44	00333
E45	00336
E46	00342
E47	00346
E48	00351
E49	00355
E50	00360
E51	00363
E52	00370
E53	00375
E54	00402
E55	00410
E56	00417
E57	00422
E58	00427
E59	00434
E60	00440
E61	00443
E62	00446
E63	00451
E64	00454
E65	00462

E66	00467
E67	00473
E68	00501
E69	00524
E70	00510
E71	00513
E72	00517
E73	00522
E74	00526
E75	00532
E76	00535
E77	00540
E78	00545
E79	00551
E80	00555
E81	00561
E82	00564
E83	00570
E84	00573
E85	00577
E86	00603
E87	00606
E88	00613
E89	00621
E90	00626
E91	00636
E92	00646
RTAT	00653
E113	00677
E114	00724
E115	00740
E116	00754
RTSS	00755
E140	01002
E141	01030
E142	01045
E143	01062
E162	01066
E163	01072
E164	01076
E165	01102
E166	01106
E167	01112
E168	01116
E169	01122
E170	01125
TLAW	01132
E206	01136
E207	01141
E208	01144
E209	01147
E210	01152
E211	01154
E212	01160
E213	01163

E214	01166
E215	01171
E216	01174
E217	01177
E218	01201
E219	01206
E220	01210
E221	01215
E222	01217
E223	01224
E224	01226
E225	01233
E226	01235
LACK	01242
E258	01245
E259	01247
E260	01253
E261	01255
E262	01261
E263	01263
E264	01267
E265	01271
E266	01276
E267	01300
E268	01305
E269	01307
E270	01314
E271	01316
E272	01323
E273	01334
ANDAC	01341
E274	01344
E275	01350
E276	01354
E277	01361
E278	01375
E279	01377
XORAC	01404
E280	01407
E281	01414
E282	01421
E283	01425
E284	01440
TADAC	01445
E285	01450
E286	01452
E287	01457
E288	01461
E289	01466
E290	01470
E291	01476
E292	01500
E293	01504
E294	01506
E295	01512

E296	01514
E297	01522
E298	01524
E299	01532
E300	01534
E301	01544
E302	01552
ADDAC	01557
E303	01564
E304	01566
E305	01574
E306	01576
E307	01604
E308	01606
E309	01614
E310	01616
E311	01624
E312	01626
E313	01634
E314	01636
E315	01644
E316	01646
E317	01654
E318	01656
E319	01664
E320	01666
E321	01675
E322	01677
E323	01706
E324	01710
E325	01717
E326	01721
E327	01730
E328	01732
E329	01741
E330	01743
E331	01752
E332	01754
E333	01763
E334	01765
E335	01774
E336	01776
E337	02005
E338	02007
E339	02016
E340	02020
ADDAC1	02025
E347	02033
E348	02035
E349	02044
E350	02046
E351	02055
E352	02057
E353	02066
E354	02070

E355	02077
E356	02101
E357	02110
E358	02112
E359	02121
E360	02123
E361	02132
E362	02134
E363	02143
E364	02145
E365	02154
E366	02156
E367	02165
E368	02167
E369	02176
E370	02200
E371	02207
E372	02211
E373	02220
E374	02222
E375	02231
E376	02233
E377	02242
E378	02244
E379	02253
E380	02255
E381	02264
E382	02266
E383	02275
E384	02277
E385	02306
E386	02310
E387	02317
E388	02321
E389	02330
E390	02332
E391	02341
E392	02343
E393	02351
E394	02353
E395	02361
E396	02363
E397	02371
E398	02373
E399	02406
E400	02410
RANADD	02415
MINUSA	02424
MINUSB	02434
MINSAB	02444
APLUSB	02452
BMINSA	02460
AMINSB	02466
APLSBT	02507
E401	02514

OFLCK1	02517
E402	02520
AMNSBT	02522
E403	02527
OFLCK2	02532
E404	02533
MAPLMB	02535
E405	02542
OFLCK3	02545
E406	02546
BMNSAT	02550
ABMAT5	02563
E407	02570
OFLCK5	02573
E408	02574
BMAMBT	02576
E409	02603
OFLCK6	02606
E410	02607
MABPAT	02611
E411	02616
OFLCK7	02621
E412	02622
AMBPBT	02624
E413	02631
OFLCK8	02634
E414	02635
M0ACPA	02637
E415	02643
OFLCK9	02646
E416	02647
SERS01	02651
E417	02657
OFLCH1	02662
E418	02663
SERS02	02665
E419	02674
OFLCH2	02677
E420	02700
SERS03	02702
E421	02712
OFLCH3	02715
E422	02716
SERS04	02720
E423	02731
OFLCH4	02734
E424	02735
SERS05	02737
E425	02751
OFLCH5	02754
E426	02755
SERS06	02757
E427	02772
OFLCH6	02775
E428	02776

SERS07	03000
E429	03014
OFLCH7	03017
E430	03020
CONCHG	03022
CKLP	03044
APOS	03051
ANEG	03052
BPOS	03053
BNEG	03054
SUMNEG	03055
SUMPOS	03056
BMASUM	03057
AMBSUM	03060
MSKBIT	03061
PASS2	03062
ADEDON	03063
BISETU	03071
MODNEG	03103
BITTS1	03110
E431	03115
OFLCH8	03120
E432	03121
BITTS2	03123
E433	03130
OFLCH9	03133
E434	03134
SADAC	03153
E435	03156
E436	03161
E437	03164
E438	03170
E439	03175
E440	03201
E441	03205
E442	03212
E443	03231
E444	03250
DZMAC	03255
E445	03261
E446	03266
E447	03273
E448	03300
E449	03305
E450	03312
E451	03317
E452	03324
E453	03331
E454	03336
E455	03344
E456	03346
E457	03351
E458	03361
E459	03367
DACAC	03374

E460	03400
E461	03405
E462	03412
E463	03417
E464	03424
E465	03431
E466	03436
E467	03443
E468	03450
E469	03462
E470	03472
ISZAC	03477
E471	03503
E472	03507
E473	03514
E474	03520
E475	03525
E476	03531
E477	03536
E478	03542
E479	03547
E480	03553
E481	03560
E482	03564
E483	03571
E484	03574
E485	03601
E486	03604
E487	03611
E488	03614
E489	03621
E490	03624
E491	03631
E492	03634
E493	03641
E494	03644
E495	03651
E496	03654
E497	03661
E498	03664
E499	03671
E500	03674
E501	03714
E502	03724
E503	03750
E504	03756
E505	03764
E506	03773
E507	04002
INIT4K	04003
E508	04031
MODX	04034
E509	04037
RJMP1	04045
E510	04050

RJMP2	04056
E511	04061
RJMP3	04067
E512	04072
RJMP4	04100
E513	04103
RJMP5	04111
E514	04114
RJMP6	04122
E515	04125
RJMP7	04133
E516	04136
RJMP8	04144
E517	04147
RJMP9	04155
JMPSEQ	04163
MOD	04164
RJ111	04165
RJ222	04166
RJ333	04167
RJ444	04170
RJ555	04171
RJ666	04172
RJ777	04173
RJ252	04174
RJ525	04175
TSCAL	04176
E518	04200
RCALS0	04212
E519	04216
E519A	04221
E520	04224
RCALS1	04233
E521	04237
E521A	04242
RCAL0	04252
KCAL0	04253
RCAL1	04254
KCALE	04255
TSJMS	04256
E522	04260
RJMS71	04271
E523	04275
E524	04300
RJMS72	04312
E525	04316
E526	04321
RJMS73	04333
E527	04337
E528	04342
RJMS74	04354
E529	04360
E530	04363
RJMS75	04375
E531	04401

E532	04404
RJMS76	04416
E533	04422
E536	24425
RJMS14	04436
E537	04442
E538	04445
RJMS15	04456
E539	04462
E540	04465
JS1	04467
E541	04470
JS2	04471
E542	04472
JS3	04473
E543	04474
JS4	04477
E544	04500
RJMSS	04501
E545	04510
E546	04517
E547	04526
E548	04535
RJSM71	04543
RSM71	04544
K10000	04545
RJSM72	04546
RSM72	04547
K77	04550
RJSM73	04551
RSM73	04552
K76	04553
RJSM74	04554
RSM74	04555
K75	04556
RJSM75	04557
RSM75	04560
K74	04561
RJSM76	04562
RSM76	04563
K73	04564
RSM77	04565
K72	04566
RJSM25	04567
RSM25	04570
K426	04571
RJSM52	04572
RSM52	04573
K71	04574
K415	04575
KJS1	04576
KJS2	04577
KJS3	04600
KJS4	04601
K210K	04602

K277	04603
K276	04604
K275	04605
K274	04606
K273	04607
K626	04610
K615	04611
K2152	04612
TSXCT	04613
E549	04617
E550	04622
E551	04627
E552	04631
E553	04633
E554	04637
E555	04644
E556	04650
E557	04656
E558	04660
E559	04665
E560	04667
E561	04675
E562	04700
RXCT1	04711
E563	04715
E564	04720
RXCT2	04731
E565	04735
E566	04740
RXCT3	04751
E567	04755
E568	04760
RXCT4	04771
E569	04775
E570	05000
RXCT5	05011
E571	05015
E572	05034
E573	05036
XT11S	05044
XTR11	05045
XT1R	05046
K12	05047
XT12S	05050
XTR12	05051
XT2R	05052
K23	05053
XT13S	05054
XTR13	05055
XT3R	05056
K34	05057
XT17S	05060
XTR17	05061
XT4R	05062
XCT12S	05063

XCTR12	05064
XT5R	05065
XCTIS2	05066
XCTDAC	05067
XCTTAD	05070
LACIN	05071
E584	05101
E585	05112
E586	05123
E587	05134
E588	05145
E589	05156
E590	05167
E591	05200
XTJMSI	05205
E592	05211
RJS11	05223
E593	05230
E594	05235
RJS12	05247
E595	05253
E596	05257
RJS13	05271
E597	05275
E598	05301
RJS14	05313
E599	05317
INK52	05326
JMS11	05327
RJM11	05330
RJS11X	05331
JSI66	05332
RJM12	05333
K15253	05334
JSI55	05335
RJM13	05336
JSI44	05337
RJM14	05340
TXCT	05341
E600	05353
E601	05361
E602	05373
XCTDZM	05412
ADDI	05413
AUTOIN	05414
E603	05422
E604	05426
E605	05435
E606	05441
E607	05450
E608	05454
E609	05463
E610	05467
E611	05476
E612	05502

E613	05511
E614	05515
E615	05524
E616	05530
E617	05536
E618	05541
E619	05545
E620	05550
AUTR	05561
E621	05565
E622	05576
E623	05602
E624	05612
E625	05616
E626	05626
E627	05630
E628	05634
E629	05640
E630	05647
E631	05653
E632	05657
E633	05662
AUTRE1	05673
E634	05700
E635	05704
E636	05712
E637	05716
E638	05721
E639	05730
E640	05743
E641	05747
LAWD	05754
LAWS	05756
ER1	05762
BITN	06004
KNOP	06005
K17776	06006
K17777	06007
K16665	06010
K16666	06011
K15554	06012
K15555	06013
K14443	06014
K14444	06015
K13332	06016
K13333	06017
K12221	06020
K12222	06021
K11110	06022
K11111	06023
K15252	06024
AUTRET	06025
AUTRJM	06026
AURJMP	06027
T LAC	06030

EX01	06034
EX02	06041
EX03	06243
EX04	06050
EX05	06052
EX06	06061
EX07	06064
EX10	06066
EX13	06071
EX14	06075
EX15	06077
TSWH	06104
EX16	06110
EX17	06115
EX18	06120
EX19	06122
EX20	06125
TSXG	06132
EX21	06135
EX22	06137
EX23	06143
EX24	06145
EX25	06151
EX26	06153
EX27	06157
EX28	06161
EX29	06165
EX30	06167
EX31	06172
EX32	06174
EX33	06176
EX34	06203
EX35	06205
EX36	06211
EX37	06213
EX38	06217
EX39	06221
EX40	06225
EX41	06227
EX42	06234
EX43	06236
EX44	06243
EX45	06245
EX46	06253
EX47	06255
EX48	06261
EX49	06264
EX50	06266
EX51	06271
EX52	06276
EX53	06301
PC05	06310
EX54	06316
EX55	06321
GENRAN	06336

RANTAD	06353
RANDEX	06357
ENDTRL	06360
TBLTOP	06361
CKNO	06362
RANGEN	06367
TADRAN	06404
ENTST	06410
MOVE	06421
RFROM	06425
MVRTN	06435
MVCST	06443
BGNAGN	06473
MVBK	06503
MRINS	06510
SAV3	06526
SAV5	06527
SAV6	06530
SRVINT	06531
E642	06541
NOCLK	06543
E642A	06545
E643	06553
RINIT	06572
E644	06601
PION	06603
ILINT	06605
CLKINT	06606
E644A	06611
SETCLK	06614
CLKSET	06631
TTYINT	06646
E645	06655
E646	06660
PREADY	06665
DATABL	06704
ENDBIN	06705
OUTTOP	06706
ENDOUT	06707
PNSTRY	06710
PNXT	06731
PNXTA	06744
E647	06770
GOPNCH	07001
E647A	07006
READA	07020
ZRONOT	07041
TADD1	07051
SUB1	07053
SETTY	07061
XFR1	07075
PUN6	07112
E648	07124
K647	07134
READR	07135

SELECT	07153
E649	07156
RNFLG	07167
OUTFLG	07201
CLRFLG	07214
NTFL	07216
PNLEDR	07217
PNMARK	07231
TLSSF	07237
ROTAT9	07264
GRLF	07273
KJMP	07302
PINOT	07303
COMPA	07326
LIMITA	07327
PATR	07330
PATWD	07331
BGNLO	07332
BGNHI	07333
BREAK	07334
WDCNT	07335
WC256	07336
MOVES	07337
MOVED	07340
BITSUP	07341
K7777	07342
K100K	07343
K1400	07344
K3400	07345
K500K	07346
K777	07347
M167	07350
TTOUT	07351
TTIN	07352
CNTA	07353
CNTB	07354
K257	07355
K271	07356
K300	07357
K301	07360
STORE	07361
SPCE	07362
K332	07363
KCRLF	07364
K520K	07365
LWR	07366
UPR	07367
WC02	07370
WC04	07371
WC32	07372
COMP	07373
NTFLG	07401
K0	07411
K1	07412
K2	07413

K4	07414
K10	07415
K11	07416
K12A	07417
K100	07420
K20	07421
K22	07422
K40	07423
K1K	07424
K400	07425
K2K	07426
K3K	07427
K4K	07430
K6K	07431
K200	07432
K207	07433
K40K	07434
K400K	07435
K402K	07436
K10K	07437
K20K	07440
K200K	07441
K600K	07442
K700K	07443
K2021	07444
K2120	07445
K1S	07446
K2S	07447
K3S	07450
K4S	07451
K5S	07452
K6S	07453
K7S	07454
K51S	07455
K12S	07456
K13S	07457
K14S	07460
K15S	07461
K16S	07462
K17S	07463
K2525	07464
K5252	07465
K010	07466
K101	07467
K53	07470
K37S	07471
K502	07472
K7X42	07473
K7XX2	07474
K76X2	07475
K1XX2	07476
K6X42	07477
K344X2	07500
KSKP	07501
K2A	07502

M1	07503
M4	07504
M42	07505
M422	07506
M4K	07507
M42K	07510
M422K	07511
K377	07512
RJCNT	07513
WORK	07514
WORK1	07515
WORK2	07516
WORK3	07517
WORK4	07520
IADR	07521
AUTNOT	07522
TCLK	07523
XCTRAL	07524
AUTCMA	07525
SAVAC	07526
RJMP	07527
LAWAUT	07530
LAWFUL	07531
JMSAUT	07532
KHALT	07533
JMPAUT	07534
SAV4	07535
KSEL	07536
KSNL	07537
RANCON	07540
RANTBL	07541
JMPRET	07552
J111	07553
J222	07554
J333	07555
J444	07556
J555	07557
J666	07560
J777	07561
J525	07562
J252	07563
CAL0	07564
CAL1	07565
JSM71	07566
JSM72	07567
JSM73	07570
JSM74	07571
JSM75	07572
JSM76	07573
JSM77	07574
JS252	07575
JS525	07576
JSSS	07577
XCT11	07600
XCT12	07601

XCT13	07602
XCT17	07603
XCT125	07604
JST77	07605
JST66	07606
JST55	07607
JST44	07610
AUTJMP	07611
AUTJMS	07612
TTBUFA	07613
CLSF	700001
CLOF	700004
CLON	700044
RSF	700101
RCP	700102
RSA	700104
RRB	700112
RSB	700144
PSP	700201
PCF	700202
PSA	700204
PSB	700244
KSP	700301
KRB	700312
TSP	700401
TCF	700402
TLS	700406
LEM	707704
EXBA	707741
SBA	707761
EPA	707762
EBA	707764
AAS	720000
PAX	721000
PAL	722000
AAC	723000
PXA	724000
AXS	725000
PXL	726000
PLA	730000
PLX	731000
CLAC	734000
CLX	735000
CLLR	736000
AXR	737000
NOP1	740000
NOP2	740000
NOP3	740000
IAC	740030
HALT	740040
SWHA	742030

IDENTIFICATION

PRODUCT CODE:	MAINDEC-15-D7BC-DN
PRODUCT NAME:	PDP-15 8K BASIC EXERCISER ADDENDUM
DATE CREATED:	AUGUST 7, 1970
MAINTAINER:	DIAGNOSTIC GROUP
AUTHOR:	J. W. RICHARDSON

The purpose of the 8K Basic Exerciser is to exercise the PDP-15 Central Processor and I/O Control logic by running an instruction test and alternately selecting the teletype and PC15.

The method of feeding the paper tape directly from the high speed punch to the high speed reader is unorthodox, but necessary. Due to the tension placed on the reader, the paper tape may sometimes skew causing a punched character to be misread. This will appear as a misprint on the teletype.

The frequency of misprinting will vary, but will generally appear no more than once every several lines of print. The misprint is not due to a reader or teletype fault.

A user may determine definitely if a real error exists by allowing the program to punch for a period of time, removing the tape and placing it in the reader hopper. The reader will then read the tape directly from the hopper. The main document lists the AC switch settings which will enable the program to operate in this manner.