

**FLOATING-POINT SYSTEM  
PROGRAMMING MANUAL**

**PDP-8**



# **PDP-8 FLOATING-POINT SYSTEM PROGRAMMING MANUAL**

September 1965

**DIGITAL EQUIPMENT CORPORATION • MAYNARD, MASSACHUSETTS**

Reprinted January 1967  
Reprinted June 1967  
Reprinted November 1967

Copyright 1965 by Digital Equipment Corporation

## P R E F A C E

The PDP-8 comes to the user complete with an extensive selection of system programs and routines making the full data processing capability of the new computer immediately available to each user, eliminating many commonly experienced initial programming delays.

The programs described in these abstracts come from two sources, past programming effort on the PDP-5 computer, and present and continuing programming effort on the PDP-8. Thus the PDP-8 programming system takes advantage of the many man-years of program development and field testing by PDP-5 users.

Although in many cases PDP-8 programs originated as PDP-5 programs, all utility and functional program documentation is issued in a new, recursive format introduced with the PDP-8.

Programs written by users of either the PDP-5 or the PDP-8 and submitted to the users' library (DECUS - Digital Equipment Corporation Users' Society) are immediately available to PDP-8 users.

Consequently, users of either computer can take immediate advantage of the continuing program developments for the other.



## CONTENTS

<u>Chapter</u>		<u>Page</u>
1	INTRODUCTION .....	1-1
2	FLOATING-POINT REPRESENTATION .....	2-1
	Arithmetic .....	2-4
	Basic Floating-Point Commands .....	2-4
	Interpreter .....	2-4
	Floating-Point Instructions .....	2-4
3	FLOATING-POINT INPUT/OUTPUT .....	3-1
	Floating-Point Input .....	3-1
	Flags .....	3-1
	Rubout .....	3-2
	Floating-Point Output .....	3-3
	Entry .....	3-3
	Program Example .....	3-3
	The Basic Package .....	3-5
	Subroutines .....	3-5
	Description of Basic Function .....	3-6
	Addition .....	3-6
	Subtraction .....	3-6
	Multiplication .....	3-6
	Division .....	3-6
	Square .....	3-7
	Square Root .....	3-7
	Error Flag .....	3-7
	Summary of Basic Package .....	3-8
	Entry Points .....	3-8
	Flags .....	3-8
	Commands .....	3-8
	Storage .....	3-9
	Fixed to Floating/Floating to Fixed Point .....	3-9
	Extended Floating-Point Package .....	3-10
	Sine .....	3-11

## CONTENTS (continued)

<u>Chapter</u>		<u>Page</u>
3 (cont)	Cosine .....	3-11
	Arc Tangent .....	3-11
	Logarithm .....	3-12
	Floating Exponent .....	3-13
	Output Controller .....	3-14
	Floating Point Package Versions .....	3-16
4	PROGRAM LISTINGS .....	4-1
	Floating Point Arithmetic Interpreter .....	4-1
	Floating Point I/O Routines .....	4-14
	Double Precision Decimal-Binary .....	4-15
	Input and Conversion .....	4-15
	Floating Output "E" Format .....	4-17
	Floating Point Input .....	4-19
	Floating Point Package .....	4-23
	Floating Point Exponential .....	4-23
	Negation Subroutine .....	4-24
	Floating Point Arc Tangent .....	4-25
	Floating Logarithm .....	4-26
	Floating Point Sine .....	4-27
	Floating Point Cosine .....	4-28
	Floating Output Program .....	4-31

# CHAPTER 1

## INTRODUCTION

The PDP-8 Floating-Point System enables the programmer to concentrate on the logic of his computation rather than on decimal points. The system maintains a constant number of significant digits throughout the computation, thereby enhancing the accuracy of the result.

Floating-point notation is particularly useful for computations involving numerous multiplications and divisions where magnitudes are likely to vary widely and where only crude predictions can be made as to the amount of variation involved. The main advantage of the PDP-8 Floating-Point System is derived from the ability to store very large or very small numbers by storing only the significant digits together with the exponent for that number. In an integral or fractional fixed-point machine, the programmer must either include all of the 0's between the significant digits and the decimal point (and in so doing lose considerable accuracy), or account for the point in each step of his programming.

The PDP-8 Floating-Point System is constructed as a self-contained package which includes its own input, arithmetic, and output routines. It allows the programmer to use floating-point arithmetic without having to construct his own arithmetic subroutines. For example, the polynomial:

$$Y = AX^3 + BX^2 + CX + D$$

may be programmed as follows (the variables X and Y, and the parameters A, B, C, and D are stored in registers of the same name):

```
.....  
JMS I 7      /ENTER FLOATING PACKAGE  
FGET A      /LOAD PSEUDO AC  
FMPY X      /MULTIPLY  
FADD B      /ADD  
FMPY X      /MULTIPLY  
FADD C      /ADD  
FMPY X      /MULTIPLY  
FADD D      /ADD  
FPUT Y      /STORE  
FEXT        /EXIT FLOATING PACKAGE  
.....
```



## CHAPTER 2

### FLOATING-POINT REPRESENTATION

A floating-point number consists of a mantissa and an exponent. For example, the decimal number 12 may be represented as:

$$\begin{aligned} & 1200.0 \cdot 10^{-2} \\ & 120.00 \cdot 10^{-1} \\ & 12.000 \cdot 10^0 \\ & 1.2000 \cdot 10^1 \\ & .12000 \cdot 10^2 \\ & \dots \\ & \text{etc.} \end{aligned}$$

where the exponents are the numbers  $-2, -1, 0$ , etc.

Since the PDP-8 is a binary machine, floating-point numbers are stored as floating-point binary internally. For example, the binary number 110 (6 decimal) may be represented as:

$$\begin{aligned} & \dots \\ & 11000.0 \cdot 2^{-2} \quad (24 \cdot 1/4 = 6) \\ & 1100.00 \cdot 2^{-1} \quad (12 \cdot 1/2 = 6) \\ & 110.000 \cdot 2^0 \quad (6 \cdot 1 = 6) \\ & 11.0000 \cdot 2^1 \quad (3 \cdot 2 = 6) \\ & 1.10000 \cdot 2^2 \quad (3/2 \cdot 4 = 6) \\ & .110000 \cdot 2^3 \quad (3/4 \cdot 8 = 6) \\ & \dots \\ & \text{etc.} \end{aligned}$$

Notice that the binary exponent is always a signed integer. The PDP-8 Floating-Point System uses the convention:

$$1/2 \leq |\text{MANTISSA}| < 1.$$

When this is true, the word is said to be normalized.

The value of the number is then:

$$\text{MANTISSA} \cdot 2^{\text{EXPONENT}}$$

where the MANTISSA is a signed quantity. The result of this convention is that more significant bits are retained. For example, the number .10 (decimal) is equal to:

| 0.00 011 001 100 | 110 011 001 100 | 110 011 001 100 110 ....


in binary.

When this word is stored in two 12-bit words (24 bits), the leading 0's are nonsignificant and only 20 bits of significance are maintained. If the number is rewritten as:

$2^{-3} \cdot | 0.11 001 100 110 | 011 001 100 110 | 011 001 100 110 ....$

and the mantissa stored in two 12-bit words, 23 bits of significance are maintained.

The exponent is stored in a third word making a total of three words for storage.



The number .1 (decimal) would be stored as:

111 111 111 101 | 011001100110 | 011001100110

or written in octal:

7775 3146 3146

The address of this number would be considered 2146 if it were stored as follows:

2146/7775

2147/3146

2150/3146

The number -.1 would be:

7775

4631 (double precision 2's complement of mantissa)

4632

Since the mantissa is greater (in magnitude) than 1/2 and less than 1, its binary point is considered to be between bit 0 and bit 1 of the high order mantissa word.

Further examples:

$$12 \text{ (decimal)} \\ 1100. = (2^4) (0.110000000000000000000000)$$

would be stored as (written in octal):

0004  
3000  
0000

<u>Octal</u>	<u>Decimal</u>	<u>Floating Binary</u>		
-1	-1	0001	6000	0000
-10	-8	0004	6000	0000
.4	.5	0000	2000	0000
3	3	0002	3000	0000
14	12	0004	3000	0000
.2	.25	7777	2000	0000

Convert the decimal number 1.6 to PDP-8 floating-binary form for storage.

An easy method to convert a decimal fraction to an octal fraction is illustrated below:

$$\begin{array}{r} .6 \\ \times 8 \\ \hline 4) .8 \\ \times 8 \\ \hline 6) .4 \\ \times 8 \\ \hline 3) .2 \\ \times 8 \\ \hline 1) .6 \\ \times 8 \\ \hline 4) .8 \\ \times 8 \\ \hline 6) .4 \\ \times 8 \\ \hline 3) .2 \\ \times 8 \\ \hline 1) .6 \end{array} \quad \begin{aligned} 1.6_{10} &= 1.46314631_8 \\ &= 1.100110011001100110011001 \\ &= (2^1) (0.11001100110011001100110) \end{aligned}$$

## ARITHMETIC

Since floating-point numbers are stored in a three-register format, the floating-point system uses a "pseudo" floating accumulator (FAC) which consists of three registers in the floating-point package: 44, 45, and 46. Register 44 contains the exponent; 45 and 46 contain the high and low order parts of the mantissa, respectively.

### BASIC FLOATING-POINT COMMANDS

The basic floating-point commands include the following:

- load floating accumulator
- store floating accumulator
- add to floating accumulator
- subtract from floating accumulator
- multiply by floating accumulator
- divide into floating accumulator
- normalize floating accumulator

All arithmetic operations are called through an interpreter. The command codes have a format that is almost identical to the format of the PDP-8 memory reference instruction, namely:



where the op code is from 000 to 111 or  $0_8 - 7_8$ .

## INTERPRETER

The interpreter contains, at all times, the address of the memory location containing the next pseudo instruction to be executed. This is initially stored when the program enters the interpreter using a JMS instruction. When the interpreter encounters an instruction with an op code of 0 and with bits 8-11 of the pseudo instruction equal to 0, it exits to the next memory location.

### FLOATING-POINT INSTRUCTIONS

The floating-point instructions are:

<u>Op Code</u>	<u>Mnemonic</u>	<u>Effect</u>
1	FADD	Floating Addition Add the contents of the effective address to the floating accumulator.

2	FSUB	Floating Subtract Subtract the contents of the effective address from the floating accumulator.
3	FMPY	Floating Multiply Multiply the floating accumulator by the contents of the effective address.
4	FDIV	Floating Divide Divide the floating accumulator by the contents of the effective address.
5	FGET	Floating Get Load the floating accumulator with the contents of the effective address.
6	FPUT	Floating Put Store the contents of the floating accumulator at the locations specified by the effective address. The contents of the floating accumulator are unchanged.
7	FNOR	Floating Normalize Normalize the contents of the floating accumulator.

0 is decoded as follows:

Bits 8-11 = 0000	Floating Exit Return control to following instruction
= 0001	Floating Square Square the contents of the floating accumulator
= 0010	Floating Square Root Take the root of the absolute value of the floating accumulator
= 0011-1111	Expandable commands

This may be summarized:

$$\begin{array}{ll}
 \text{FADD } Y; 1000; C(\text{FAC}) + C(Y) \rightarrow C(\text{FAC}) & \\
 \text{FSUB } Y; 2000; C(\text{FAC}) - C(Y) \rightarrow C(\text{FAC}) & \\
 \text{FMPY } Y; 3000; C(\text{FAC}) \times C(Y) \rightarrow C(\text{FAC}) & \\
 \text{FDIV } Y; 4000; C(\text{FAC}) \div C(Y) \rightarrow C(\text{FAC}) & \\
 \text{FGET } Y; 5000; C(Y) \rightarrow C(\text{FAC}) & 
 \end{array}
 \left. \begin{array}{l} \text{Result is normalized} \\ \text{C(Y) unchanged} \end{array} \right\}$$

FPUT Y; 6000; C(FAC) → C(Y)  
 FNOR ; 7000; C(FAC) normalized → C(FAC)  
 FEXT ; 0000; exit from interpreter to instruction following this command  
 SQUARE ; 0001; C(FAC)<sup>2</sup> → C(FAC)  
 SQROOT; 0002; C(FAC)<sup>1/2</sup> → C(FAC)

The assembler recognizes all of these mnemonics except for SQUARE and SQROOT which may be defined as:

SQUARE=0001  
 SQROOT=0002

The floating-point interpreter is entered with an effective JMS 5600.

For example:

```

SQROOT=0002
*7
5600
*200
      JMS I 7    200/    4407
      FGET A    201/    5206
      SQROOT    202/    0002
      FPUT I B   203/    6611
      FEXT      204/    0000
      HLT       205/    7402
A,     0003      206/    0003
      2000      207/    2000
      0000      210/    0000
B,     300       211/    0300
$
```

When this program is started at 0200, it will halt at location 205. The state of the machine will be:

44/	0002	
45/	2000	floating accumulator contains
46/	0000	2.0, i.e., $(4.0)^{1/2}$
206/	0003	
207/	2000	register A contains 4.0
210/	0000	
300/	0002	
301/	2000	answer stored here
302/	0000	

## CHAPTER 3

### FLOATING-POINT INPUT/OUTPUT

#### FLOATING-POINT INPUT

The basic floating-point package contains an input routine to read characters from the 33 ASR keyboard. Numbers are read in in decimal and converted to the internal floating-point binary format. Input format is floating decimal. The number 726.7 may be read in in any of the following forms:

726.7  
.7267E3  
.7267E+03  
+7267E-1  
etc.

Input is terminated when a character is typed that is not a part of this format. The conversion of "12.0." would be terminated on the second "." and the binary number:

000000000100	(octal 0004)
011000000000	(octal 3000)
000000000000	(octal 0000)

would be in the floating-point accumulator upon completion of the conversion.

#### Flags

There are several flags associated with the input routine that are useful to the programmer.

- |      |  |
|------|--|
| 0056 | This register is a switch that has the following meaning:<br><br>If C(56) = 0, do not type a line-feed after a carriage-return was read.<br>If C(56) = 7777, type a line-feed when a carriage-return is inputted.<br>This switch is initially set to 7777. |
| 0057 | This register contains the character that terminated the input conversion.   |
| 0060 | This register contains 0000 if no input conversion was made; i.e., a space or other terminator was initially typed.  |

The input routine is entered with an effective JMS 7400. It returns control to the instruction following the calling JMS upon receipt of a terminator. The floating accumulator contains the input number in normalized floating-binary. Register 0057 contains the terminating character in ASCII, and C(0060) indicates whether or not there was a valid input.

For example:

```
*5  
7400  
*7  
5600  
*200  
JMS I 5      /INPUT ROUTINE  
JMS I 7      /CALL FLOATING POINT  
FPUT A  
FEXT  
JMS I 5  
JMS I 7  
FPUT B  
FEXT  
HLT  
A, 0  
0  
B, 0  
0  
0  
$
```

When this program is started at 0200 and the following is typed:

X2.0Y

The program will halt at location 0210, and A and B will contain

```
A, 0  
0  
0      and C(57) = 0331, the second TERMINATOR  
B, 0002  
2000  
0000
```

The first input was considered a 0 because a terminator "X" was inputted.

This program could be written to ignore the non-numeric information as follows:

```
*5
    7400
*7
    5600
*200
    JMS I 5      /CALL INPUT ROUTINE
    TAD 60       /ANY VALID INPUT?
    SNA CLA
    JMP .-3      /NO - IGNORE
    JMS I 7      /YES
    FPUT A       /STORE IT
    FEXT
    JMS I 5      /GET NEXT
    TAD 60
    SNA CLA      /VALID?
    JMP .-3      /NO - IGNORE
    JMS I 7      /YES
    FPUT B       /STORE IT
    FEXT
    HLT      /HALT
A, 0
0
0
B, 0
0
0
$
```

Register 57 may be used for integrating control characters into the input.

#### Rubout

There is one special input character, the rubout. If it is struck before an input delimiter, the input routine is restarted and previous numbers deleted.

For example, assume the input routine has been entered.

276 ~~1~~1T

The input routine would exit with 1 (decimal) in the floating accumulator or:

44/ 0001
 2000
 0000

### FLOATING-POINT OUTPUT

The basic floating-point package contains an output routine. Upon entry the contents of the floating accumulator are converted to floating-point decimal and typed out on the ASR 33 in the following format:

$\pm 0.XXXXXXXE\pm XX$

For example, if the floating accumulator contained:

44/        0002  
          2000  
          0000

and the output routine were entered,

+0.2000000E+01

would be typed.

### Entry

The output routine is entered by an effective JMS 7200. After outputting the contents of the floating accumulator, it returns control to the instruction following the calling JMS instruction. The contents of the floating accumulator are lost. The floating-output routine has a flag or program switch in location 0055 on page 0.

If C(0055) does not equal 0, type a carriage-return/line-feed following each output. This location initially contains 7777.

### Program Example

```
/SOLVE THE QUADRATIC EQUATION
/AX2+BX+C=0 FOR VALUES
/OF A, B, C.      TYPE OUT ROOTS
SQROOT=0002
SQUARE=0001
*5    7400      /POINTER TO INPUT ROUTINE
          7200      /POINTER TO OUTPUT ROUTINE
          5600      /POINTER TO INTERPRETER
*200
          KCC
          TLS
BEGIN,   JMS 15      /INPUT A
          JMS 17      /ENTER INTERPRETER
```

	FMPY TWO	/2.0
	FPUT A	/STORE 2.0·A
	FEXT	
	JMS I 5	/INPUT B
	JMS I 7	/ENTER INTERPRETER
	FPUT B	/STORE B
	FEXT	
	JMS I 5	/INPUT C
	JMS I 7	/ENTER INTERPRETER
	FMPY TWO	/MULTIPLY BY 2.
	FMPY A	/MULTIPLY BY 2A
	FPUT TEMP	/4AC
	FGET B	
	SQUARE	/B SQUARED
	FSUB TEMP	/B SQUARED -4AC
	SQROOT	/TAKE SQUARE ROOT
	FPUT TEMP	/STORE IT
	FGET B	
	FMPY MIN1	/-1·B = - B
	FPUT B	/STORE
	FSUB TEMP	/-B-SQUARE ROOT
	FDIV A	
	FEXT	/ANSWER IN FAC
	JMS I 6	/OUTPUT IT
	JMS I 7	/ENTER INTERPRETER
	FGET B	/-B
	FADD TEMP	/-B + SQUARE ROOT
	FDIV A	
	FEXT	/ANSWER IN FAC
	JMS I 6	/OUTPUT IT
TWO,	JMP BEGIN	/CONTINUE
	0002	/CONSTANT 2.0
	2000	
	0000	
MIN1,	0001	/CONSTANT -1.0
	6000	
	0000	
TEMP,	0	
	0	
	0	
A,	0	
	0	
	0	
B,	0	
	0	
	0	
C,	0	
	0	
	0	
\$		

Both the input-conversion routine and the output-conversion routine use a typeout subroutine that contains the instructions:

```
...
TSF
JMP .-1
TLS
CLA
...
```

This means that the teleprinter flag must be set when these routines are entered or it must be in the process of typing. A TLS instruction can be put into the initialization section of a program.

## THE BASIC PACKAGE

### Subroutines

When the floating-point interpreter encounters a 0 op code, it further decodes bits 8-11. If these bits equal 0, the interpreter exits. If the bits are nonzero, they are used in a table look-up to specify the address of a subroutine. The called subroutine may use the floating-point interpreter, the input, or the output, but it may not use bits 8-11 to call another subroutine. The look-up table is on page 16 of the interpreter listing. For example, if the user wished to define a routine that negated the contents of the floating accumulator, the following steps would be taken:


On page 6 of the interpreter listing, there is a routine to negate the floating accumulator. It is a subroutine and has, as entry point, the address 6000. If the negate subroutine were to be called by 0010 in the interpreter mode, the word 6000 would be placed in address 6554 of the calling table. Input and output could be called in the interpreter mode if 7400 were placed in 6555 (0011) and 7200 were placed in 6556 (0012).

```
NEGATE = 0010
INPUT   = 0011
OUTPUT  = 0012
SQUARE  = 0001
*7
5600
*200
KCC
TLS
JMS I 7 /ENTER INTERPRETER
INPUT   /CALL INPUT ROUTINE
SQUARE  /SQUARE IT
NEGATE  /CALL OUTPUT ROUTINE
OUTPUT  /CALL OUTPUT ROUTINE
FEXT    /EXIT
HLT     /HALT
$
```

## DESCRIPTION OF BASIC FUNCTION

### Addition

Floating-point addition is carried out by first aligning the binary points of the two numbers. This is accomplished by scaling the smaller number to the right. Then the mantissas are both scaled right once so that overflow will not occur into the sign bit. A 2's complement addition of the mantissas is then made. The result is normalized and control returns to the interpreter. This may be represented as:



### Subtraction

Floating-point subtraction is accomplished by negating the operand, and then calling the addition sub-program.

Negate Operand  
Call Addition


### Multiplication

Floating-point multiplication is accomplished by adding the exponents together and then performing a double-precision multiplication. The result is normalized and control returns to the interpreter.

Add Exponents  
Multiply Mantissas carrying result to 35 bits  
Normalize  
Return to Interpreter

### Division

Floating-point division is accomplished by subtracting the exponent of the divisor from the exponent of the dividend. The mantissa is divided and the result is normalized. Control returns to the interpreter.




### Square

The square routine calls the multiplication routine internally.

### Square Root

The square root is calculated using Newton's method in which an initial approximation is made and then each succeeding approximation is calculated. The routine exits when two successive approximations are equal to within the least significant bit of the mantissas.

Form first approximation,  $X_1$ , of  $\sqrt{N}$ :



Return to interpreter

### Error Flag

Division by 0 causes C(61) to be incremented by 1. The quotient is set to the highest positive number.

Attempting to extract the square of a negative number causes C(61) to be incremented by 1. The root of the absolute value is taken.

The contents of 61 are set to 0 at the beginning of each divide and square root operation.

## SUMMARY OF BASIC PACKAGE

### Entry Points

5600	Arithmetic Interpreter
7400	Floating Input
7200	Floating Output

NOTE: Both the input and the output routines require that register 7 contains the interpreter entry point: 5600.

### Flags

55	If $\neq 0$ , type carriage-return/line-feed after output.
56	If $\neq 0$ , follow each input carriage-return by a line-feed.
57	Contains the input terminating character.
60	Equals 0 if no valid input.
61	Is nonzero if (a) divide by 0 or (b) square root of a negative number.

### Commands

FADD	1000	Floating Add
FSUB	2000	Floating Subtract
FMPY	3000	Floating Multiply
FDIV	4000	Floating Divide
FGET	5000	Floating Get
FPUT	6000	Floating Put
FNOR	7000	Floating Normalize
FEXT	0000	Floating Exit
SQUARE	0001	Square
SQROOT	0002	Square Root
	0003	
	....	Expandable
	0017	

### Storage

The floating accumulator is in registers:


- 44 - Exponent
- 45 - High Order Mantissa
- 46 - Low Order Mantissa

The basic floating-point package (Digital 8-5A-S) uses memory locations:

7; 40-61; 5600-7577

### FIXED TO FLOATING/FLOATING TO FIXED

Since the floating-point package stores numbers in the following format:



and since the exponent indicates where the real exponent is, this information may be used to either convert a floating-point number to fixed point or to convert a fixed-point number to floating point.

For example, assume that there is an integer in the accumulator that is less in magnitude than 2047. To float this number, the following sequence of steps may be employed:

C,	...	
	DCA 45	/PUT INTO HIGH-ORDER MANTISSA
	DCA 46	/PUT 0 INTO LOW-ORDER MANTISSA
	TAD C13	/11 (10) INTO
	DCA 44	/EXPONENT
	JMS I 7	/CALL INTERPRETER
	FNOR	/NORMALIZE
	FEXT	/LEAVE INTERPRETER
	...	
C13,	0013	/11 (DECIMAL)

At point C, we have set the binary point of the integer to the right end of the high order mantissa word, or eleven (decimal) locations to the right of the implicit binary point.

To float this number, the floating accumulator is scaled right until the exponent contains the location of the desired binary point. To fix the floating accumulator as an 11-bit signed integer, the following sequence of coding may be employed:

```

....  

CLA  

TAD 44      /FETCH EXPONENT  

SZA SMA      /IS THE NUMBER <1?  

JMP .+3      /NO:  

CLA          /YES: FIX IT TO 0  

JMP DONE+1  

TAD M13      /NO: SET BINARY POINT AT  

SNA          /11 (10) PLACES TO RIGHT OF CURRENT POINT  

JMP DONE      /IT IS ALREADY THERE: ALL DONE  

SMA          /TEST TO SEE IF IT IS TOO LARGE  

JMP ERROR    /YES: NUMBER >2**11  

DCA 44      /NO: SET SCALE COUNT  

GO,          CLL      /0 TO C(L)  

             TAD 45      /FETCH MANTISSA  

             SPA      /IS IT <0?  

             CML      /YES: PUT A 1 IN LEFT BIT  

             RAR      /SCALE RIGHT  

             DCA 45      /RESTORE IT  

             ISZ 44      /TEST IF SHIFTED ENOUGH  

             JMP 00      /NO: CONTINUE  

DONE,        TAD 45      /ANSWER IN C(AC)  

             ....  

             ....  

M13,        -13       /-11 (DECIMAL)

```

This may be coded as a subroutine.

#### EXTENDED FLOATING-POINT PACKAGE

The extended floating-point package contains the following additional commands:

- 0003      Floating Sine  
Take the sine of the angle in the floating accumulator (considered to be in radians) and leave the result in the floating accumulator.
- 0004      Floating Cosine  
Take the cosine of the angle in the floating accumulator (considered to be in radians) and leave the result in the floating accumulator.
- 0005      Floating Arc Tangent  
Take the arc tangent of the number in the floating accumulator and leave the result (in radians) in the floating accumulator.
- 0006      Floating Exponent  
Raise e to the C(FAC) power. Leave the result in the floating accumulator.
- ,0007     Floating Logarithm  
Take the natural logarithm of the absolute value of the number in the floating accumulator.

### Sine

The sine routine uses the following identities:

$$\sin(-X) = -\sin(X)$$

$$\sin(X) = \sin(2\pi N + F) = \sin(F)$$

where  $0 < F < 2\pi$  and  $N$  is an integer:

$$\sin(\pi - F) = -\sin(F)$$

Using these identities,  $F$  is reduced to the range  $-\pi/2 < F < \pi/2$ .

If  $Y = 2F/\pi$  so that  $-1 < Y < 1$ , then:

$$\sin(X) = (C_1 F + C_3 F^3 + C_5 F^5 + C_7 F^7 + C_9 F^9)$$

where:

$$C_1 = 1.57079631847$$

$$C_3 = -0.64596371106$$

$$C_5 = +0.07968967928$$

$$C_7 = -0.00467376557$$

$$C_9 = +0.00015148419$$

The sine subroutine is valid over the range:

$$-2\pi .2047 < X < 2\pi .2047$$

### Cosine

The cosine routine uses the identity:

$$\cos(X) = \sin(\pi/2 - X)$$

It then uses the SINE routine.

### Arc Tangent

The arc tangent routine uses the following identities:

$$\arctan(-X) = -\arctan(X)$$

$$\text{IF } X > 1; \text{ then } \arctan(X) = \pi/2 - \arctan(1/X)$$

$$\text{FOR } 0 < X < 1,$$

$$\text{ARCTAN}(X) = \frac{x(A_0 + A_1x^2 + A_2x^4)}{B_0 + B_1x^2 + B_2x^4}$$

where:

$$A_0 = +0.6402481953$$

$$A_1 = +0.4229908144$$

$$A_2 = +0.0264694361$$

$$B_0 = +0.6402487022$$

$$B_1 = +0.6363779373$$

$$B_2 = +0.1108328778$$

The result is in the range:

$$-\pi/2 < \text{ARCTAN}(X) < \pi/2$$

$$-\infty < X < \infty$$

### Logarithm

The logarithm routine uses the identities:

For  $X < 1$ :

$$\text{LOG}(X) = \text{LOG}(2^N \cdot F) \quad (1 < F < 2)$$

$$= N \text{LOG}(2) + \text{LOG}(F)$$

$$\text{LOG}(1+Y) = \sum_{C=1}^{8} A_i Y^i$$

where:

$$A_1 = +0.9999964239$$

$$A_2 = -0.4998741238$$

$$A_3 = +0.3317990258$$

$$A_4 = +0.2407338084$$

$$A_5 = +0.1676540711$$

$$A_6 = -0.0953293897$$

$A_7 = +0.0360884937$

$A_8 = -0.0064553442$

for:

$0 < X < 1$ , the identity:

$\text{LOG}(X) = -\text{LOG}(1/X)$  is used.

### Floating Exponent

The exponent routine uses the identity for  $X > 0$ ,

$$e^X = 2^{X \cdot \log_2 e} = 2^{N+F} = 2^N \cdot 2^F$$

where  $N$  is an integer and  $-1 < F < 1$

$$2^F = 1 + \frac{2F}{A - F + BF^2 - \frac{C}{D + F^2}}$$

where:

$A = +9.95459578$

$B = +0.03465735903$

$C = +617.97226053$

$D = +87.417497202$

$\log_2 e = 1.4426950409$

If  $X < 0$

$$e^x = \frac{1}{e^{-x}}$$

Example, input A, B, and output:

$$Y = \text{LOG}(\text{COS}(A/B) + \sqrt{A \cdot B})$$

SQRROT=0002 /DEFINITIONS TO ASSEMBLER

COS=0004

LOG=0006

\*5

7400

7200

5600

/USES EXTENDED INTERPRETER

```

*200
KCC
TLS
BEGIN, JMS I 5      /INPUT A
                  JMS I 7      /ENTER INTERPRETER
                  FPUT A       /STORE A
                  FEXT        /EXIT
                  JMS I 5      /INPUT B
                  JMS I 7      /ENTER INTERPRETER
                  FPUT B       /STORE B
                  FMPY A       /A·B
                  SQROOT       /EXTRACT ROOT
                  FPUT TEMP    /STORE IT
                  FGET A       /LOAD FAC WITH A
                  FDIV B       /DIVIDE BY B
                  COS          /TAKE COSINE
                  FADD TEMP    /ADD
                  LOG          /TAKE LOG.
                  FEXT
                  JMS I 6      /OUTPUT ANSWER
                  JMP BEGIN
A,   0
      0
      0
B,   0
      0
      0
TEMP, 0
      0
      0
$
```

#### Output Controller

There is an additional routine available that formats floating-point output. It is available with both the basic floating-point package and the extended package.

The controller routine requires two parameters for output formatting. It is called by an effective JMS 7200. At this point:

C(62) = total number of digits to be outputted. If C(62)=0, output in E format.

C(AC) = number of digits to the right of the decimal point. If it equals 0, do not type a ".".

If the number in the floating accumulator is larger than the field width allows, "X's" will be typed. The sign is typed and leading 0's are suppressed.

Example: If the contents of the floating accumulator are 678.234 (decimal).

<u>C(62)</u>	<u>C(AC)</u>	<u>Output</u>
3	0	+ 678
4	0	+ 678
4	1	+ 678.2
5	2	+ 678.23
6	2	+ 678.23
3	2	+ 678.
2	0	+ XX
0	1	+ 0.678234E+03

### FLOATING POINT PACKAGE VERSIONS

Four versions of the floating-point package are available:

#### Digital 8-5A-S

This is the basic floating-point package. It consists of the input/output package and the basic arithmetic instructions. Its core limits are:

7; 40-61; 5600-7577

#### Digital 8-5B-S

This is the basic floating-point package with the output controller. Its limits are:

7; 40-62; 5400-7577

The output controller does not type a carriage-return/line-feed after output and, hence, the programmer must provide his own routine to do so. Because of the way in which the typeout routine in the floating-point packages are constructed, the user must construct similar typeout routines in order to avoid timing errors in the teleprinter. In other words, the floating-point package uses a routine similar to:

```
TSF
JMP .-1
TLS
```

to do its typing. The user must use a similar routine, i.e., one that waits for the teleprinter flag to be set before executing the TLS instruction.

#### Digital 8-5C-S

This is the basic floating-point package with the extended functions. In addition, two interpretive commands are provided for input and output. The additional interpretive commands are:

SINE	3
COSINE	4
ARCTANGENT	5
EXPONENTIAL	6
LOG	7
INPUT	13
OUTPUT	14

Its core limits are:

7; 40-61; 4757-7577

Using this package, the routine on page 3-14 and 3-15 for calculating:

$Y = \log(\cos(A/B) + \sqrt{A \cdot B})$  may be rewritten as:

```

SQROOT=2
FCOS=4
FLOG=6
INPUT=13
OUTPUT=14

*7
5600

*200
KCC
TLS
BEGIN, JMS I 7 /CALL INTERPRETER
    INPUT /READ A
    FPUT A /STORE IT
    INPUT /READ B
    FPUT B
    FMPY A /A·B
    SQROOT
    FPUT TEMP /(A·B)**.5
    FGET A
    FDIV B
    FCOS
    FADD TEMP
    FLOG
    OUTPUT
    FEXT
    JMP BEGIN
A, 0
0
0
B, 0
0
0
TEMP, 0
0
0
$
```

### Digital 8-5D-S

This is the basic package, the output controller, and the extended functions. Its core limits are:

7; 40-62; 4557-7577

## CHAPTER 4

### PROGRAM LISTINGS

```
/FLOATING POINT ARITHMETIC INTERPRETER
*40
0040 0000 EX1,      0          /OPERAND STORAGE
0041 0000 AC1H,     0
0042 0000 AC1L,     0
0043 0000 OVER1,    0
0044 0000 EXP,      0          /F.A.
0045 0000 HORD,     0
0046 0000 LORD,     0
0047 0000 OVER2,    0
0050 0000 EXP1,     0
0051 0000 QUOL,    0
0052 0000 FPAC1,   0
0053 0000          0
0054 0000          0
*61
0061 0000 FLAG,    0          /ARITHMETIC ERROR FLAG
*5600
5600 0000 FPNT,    0
5601 7300 CLA CLL
5602 3043 DCA OVER1
5603 3047 DCA OVER2
5604 1600 TAD I FPNT   /GET NEXT INSTRUCTION
5605 3253 DCA JUMP
5606 1253 TAD JUMP
5607 0263 AND PAGENO /GET PAGE BIT
5610 7650 SNA CLA    /PAGE ZERO?
5611 5214 JMP .+3     /YES
5612 1261 TAD MASK5 /NO
5613 0200 AND FPNT   /C(FPNT)0-4 CONTAINS PAGE BITS
5614 3256 DCA ADDR
5615 1262 TAD MASK7 /GET 7 BIT ADDRESS
5616 0253 AND JUMP
5617 1256 TAD ADDR
5620 3256 DCA ADDR
5621 1264 TAD INDRCT /INDIRECT BIT=1?
5622 0253 AND JUMP
5623 7650 SNA CLA
5624 5227 JMP LOOP01 /NO-GO ON
5625 1656 TAD I ADDR /YES DEFER
5626 3256 DCA ADDR
5627 2200 LOOP01,   ISZ FPNT
5630 1656          TAD I ADDR
5631 3040          DAC EX1    /EXPONENT
5632 1256          TAD ADDR
```

5633	3257	DCA SAVE	
5634	2257	ISZ SAVE	
5635	1657	TAD I SAVE	
5636	3041	DCA AC1H	/HIGH ORDER MANTISSA
5637	2257	ISZ SAVE	
5640	1657	TAD I SAVE	
5641	3042	DAC AC1L	/LOW ORDER MANTISSA
5642	1253	TAD JUMP	
5643	7106	CLL RTL	
5644	7006	RTL	
5645	0260	AND MASK3	/GET BITS 0-2, IE OPCODE
5646	1265	TAD TABLE	/LOOKUP IN TABLE
5647	3254	DCA JUMP2	
5650	1654	TAD I JUMP2	
5651	3254	DCA JUMP2	
5652	5654	JMP I JUMP2	/GO THERE
5653	0000	JUMP,	0
5654	0000	JUMP2,	0
5655	0000	GO2,	0
5656	0000	ADDR,	0
5657	0000	SAVE,	0
5660	0017	MASK3,	0017
5661	7600	MASK5,	7600
5662	0177	MASK7,	0177
5663	0200	PAGENO,	0200
5664	0400	INDRCT,	0400
5665	5666	TABLE,	.+1
5666	5742	EXIT	/TABLE USED IN INTERPRETING
5667	5716	FLAD	/BITS 0-2 OF PSEUDO
5670	5737	FLSU	/INSTRUCTION
5671	5761	FLMY	
5672	6305	FLDV	/IF OPCODE=0, GO TO EXIT
5673	5676	FLGT	/AND INTERPRET BITS 8-11
5674	5705	FLPT	
5675	5773	NORF	
5676	1040	FLGT,	TAD EX1 /FGET=5
5677	3044		DCA EXP
5700	1041		TAD AC1H
5701	3045		DCA HORD
5702	1042		TAD AC1L
5703	3046		DCA LORD
5704	5201		JMP FPNT+1
5705	1044	FLPT,	TAD EXP /PUT=6
5706	3656		DCA I ADDR
5707	2256		ISZ ADDR
5710	1045		TAD HORD
5711	3656		DCA I ADDR
5712	2256		ISZ ADDR
5713	1046		TAD LORD
5714	3656		DCA I ADDR
5715	5201		JMP FPNT+1
5716	4771	FLAD,	JMS I ALGN /FLAD=1 - FIRST ALIGN EXPONENTS
5717	5201		JMP FPNT+1 /RETURN IF NO ALIGNMENT IS POSSIBLE
5720	4772		JMS I UNORM /LARGER OF THE TWO IS IN F.A.

5721	7100	CLL		
5722	1043	TAD OVER1	/TRIPLE PRECISION ADDITION	
5723	1047	TAD OVER2	/SINCE BITS ARE SHIFTED	
5724	3047	DCA OVER2	/RIGHT	
5725	7004	RAL		
5726	1042	TAD AC1L		
5727	1046	TAD LORD		
5730	3046	DCA LORD		
5731	7004	RAL		
5732	1041	TAD AC1H		
5733	1045	TAD HORD		
5734	3045	DCA HORD		
5735	4770	JMS I NORM	/NORMALIZE THE RESULT	
5736	5201	JMP FPNT+1		
5737	4741	FLSU,	JMS I OPMINS	/FSUB=2 - NEGATE THE OPERAND
5740	5316		JMP FLAD	/ADD
5741	6400	OPMINS,	MINUS2	
5742	1253	EXIT,	TAD JUMP	/OPCODE=0
5743	0260		AND MASK3	/ARE BITS 8-11=0?
5744	7450		SNA	
5745	5600		JMP I FPNT	/YES=FEXT
5746	1360		TAD ACON6	/LOOKUP ON TABLE
5747	3254		DCA JUMP2	
5750	1654		TAD I JUMP2	
5751	3254		DCA JUMP2	
5752	1200		TAD FPNT	
5753	3255		DCA GO2	
5754	4654		JMS I JUMP2	/CALL AS A SUBROUTINE
5755	1255		TAD GO2	/RESTORE F.P. POINTER
5756	3200		DCA FPNT	
5757	5201		JMP FPNT+1	/GET NEXT PSEUDO INSTRUCTION
5760	6544	ACON6,	TABLE6-1	/CALLING CAN BE TO A DEPTH ONE
5761	7201	FLMY,	CLA IAC	/FMPY=3
5762	1040		TAD EX1	
5763	1044		TAD EXP	/ADD EXPONENTS TOGETHER
5764	3044		DCA EXP	
5765	4767		JMS I MULT	/MULTIPLY
5766	5201		JMP FPNT+1	
5767	6221	MULT,	DMULT	
5770	6600	NORM,	DNORM	
5771	6020	ALGN,	ALIGN	
5772	6564	UNORM,	DUNORM	
5773	4770	NORF,	JMS I NORM	
5774	5201		JMP FPNT+1	
		*6000		
6000	0000	ACMINS,	0	/ROUTINE TO PERFORM
6001	7300		CLL CLA	
6002	1047		TAD OVER2	/TRIPLE PRECISION NEGATION
6003	7041		CMA IAC	/OF FLOATING AC
6004	3047		DCA OVER2	
6005	1046		TAD LORD	
6006	7040		CMA	
6007	7430		SZL	

6010	7101	CLL IAC	
6011	3046	DCA LORD	
6012	1045	TAD HORD	
6013	7040	CMA	
6014	7430	SZL	
6015	7101	CLL IAC	
6016	3045	DCA HORD	
6017	5600	JMP I ACMINS	
6020	0000	0	/SUBROUTINE TO ALIGN
6021	1045	TAD HORD	/BINARY POINTS FOR
6022	7640	SZA CLA	/ADD-SUBTRACT
6023	5227	JMP .+4	
6024	1046	TAD LORD	/IS MANTISSA ZERO?
6025	7650	SNA CLA	
6026	5337	JMP NOHERE	/YES
6027	1041	TAD AC1H	/IS OPERAND ZERO?
6030	7640	SZA CLA	
6031	5235	JMP .+4	
6032	1042	TAD AC1L	
6033	7650	SNA CLA	
6034	5620	JMP I ALIGN	/BOTH ARE ZERO-EXIT
6035	1040	TAD EX1	
6036	7041	CMA IAC	
6037	1044	TAD EXP	
6040	7450	SNA	/ARE EXPONENTS EQUAL?
6041	5314	JMP DONE	/YES
6042	7500	SMA	
6043	7041	CMA IAC	
6044	3342	DCA AMOUNT	
6045	1342	TAD AMOUNT	
6046	1343	TAD TEST2	
6047	7700	SMA CLA	/CAN EXPONENTS BE ALIGNED?
6050	5256	JMP .+6	/YES
6051	4316	JMS OUTGO	/NO
6052	7430	SZL	
6053	1350	TAD TAG2	
6054	1347	TAD TAG1	
6055	5325	JMP NOGO	
6056	4316	JMS OUTGO	
6057	7420	SNL	/SET UP ADDRESSES
6060	1350	TAD TAG2	
6061	1347	TAD TAG1	
6062	3344	DCA TEST3	
6063	1342	TAD AMOUNT	
6064	7041	CMA IAC	
6065	1744	TAD I TEST3	
6066	3744	DCA I TEST3	
6067	2344	ISZ TEST3	
6070	1344	TAD TEST3	
6071	3345	DCA TEST4	
6072	2345	ISZ TEST4	
6073	1345	TAD TEST4	
6074	3346	DCA TEST5	
6075	2346	ISZ TEST5	

6076	7100	SHIFT,	CLL	/THIS ROUTINE DOES
6077	1744		TAD I TEST3	/THE ACUTAL SHIFTING
6100	7510		SPA	
6101	7020		CML	
6102	7010		RAR	
6103	3744		DCA I TEST3	
6104	1745		TAD I TEST4	
6105	7010		RAR	
6106	3745		DCA I TEST4	
6107	1746		TAD I TEST5	
6110	7010		RAR	
6111	3746		DCA I TEST5	
6112	2342		ISZ AMOUNT	
6113	5276		JMP SHIFT	
6114	2220	DONE,	ISZ ALIGN	
6115	5620		JMP I ALIGN	
6116	0000	OUTGO,	0	/DETERMINE WHICH TO SHIFT
6117	1040		TAD EX1	
6120	7041		CMA IAC	
6121	1044		TAD EXP	
6122	7004		RAL	
6123	7200		CLA	
6124	5716		JMP I OUTGO	
6125	3344	NOGO,	DCA TEST3	/CAN'T BE ALIGNED
6126	1744		TAD I TEST3	/LARGEST GOES INTO FAC
6127	3044		DCA EXP	
6130	2344		ISZ TEST3	
6131	1744		TAD I TEST3	
6132	3045		DCA HORD	
6133	2344		ISZ TEST3	
6134	1744		TAD I TEST3	
6135	3046		DCA LORD	
6136	5620		JMP I ALIGN	
6137	1040	NOHERE,	TAD EX1	/MANTISSA=0
6140	3044		DCA EXP	
6141	5314		JMP DONE	
6142	0000	AMOUNT,	0	
6143	0030	TEST2,	0030	
6144	0000	TEST3,	0	
6145	0000	TEST4,	0	
6146	0000	TEST5,	0	
6147	0044	TAG1,	EXP	
6150	7774	TAG2,	EX1-EXP	
6151	5601	RETN2,	FPNT+1	
6152	1362	ERROR1,	TAD GOOF	/DIVISION BY ZERO
6153	3044		DCA EXP	/SET TO LARGEST + VALUE
6154	1362		TAD GOOF	
6155	3045		DCA HORD	
6156	7040		CMA	
6157	3046		DCA LORD	
6160	2061		ISZ FLAG	/SET FLAG
6161	5751		JMP I RETN2	
6162	3777	GOOF,	3777	

6163	0000	SQUARE,	0	
6164	4407		JMS I 0007	
6165	6052		FPUT FPAC1	
6166	3052		FMPY FPAC1	
6167	0000		FEXT	
6170	5763		JMP I SQUARE	
6171	0000	EXIT6,	0	/DUMMY SUBROUTINE
6172	5771		JMP I EXIT6	
		*6200		
6200	0000	DIV1,	0	/SHIFT FAC RIGHT
6201	7300		CLA CLL	
6202	1045		TAD HORD	
6203	7510		SPA	
6204	7120		CLL CML	
6205	7010		RAR	
6206	3045		DCA HORD	
6207	1046		TAD LORD	
6210	7010		RAR	
6211	3046		DCA LORD	
6212	1047		TAD OVER2	
6213	7010		RAR	
6214	3047		DCA OVER2	
6215	7100		CLL	
6216	2044		ISZ EXP	
6217	7000		NOP	
6220	5600		JMP I DIV1	
6221	0000	DMULT,	0	/DOUBLE PRECISION MULTIPLY
6222	7300		CLA CLL	/SAVE PRODUCT TRIPLE PRECISION
6223	1363		TAD SMACLA	
6224	3347		DCA SNSWIT	/CALLS A SINGLE PRECISION
6225	4336		JMS SIGN	/MULTIPLY 3 TIMES
6226	1042		TAD AC1L	
6227	3756		DCA I MP2PT	
6230	1046		TAD LORD	
6231	4755		JMS I MP4PT	
6232	7200		CLA	
6233	1757		TAD I MP5PT	
6234	3047		DCA OVER2	
6235	1045		TAD HORD	
6236	3756		DCA I MP2PT	
6237	1042		TAD AC1L	
6240	4755		JMS I MP4PT	
6241	1047		TAD OVER2	
6242	3047		DCA OVER2	
6243	7004		RAL	
6244	1757		TAD I MP5PT	
6245	3367		DCA D	
6246	7004		RAL	
6247	3370		DCA KEEP	
6250	1041		TAD AC1H	
6251	3756		DCA I MP2PT	
6252	1046		TAD LORD	
6253	4755		JMS I MP4PT	

6254	1047	TAD OVER2
6255	3047	DCA OVER2
6256	7004	RAL
6257	1757	TAD I MP5PT
6260	1367	TAD D
6261	3367	DCA D
6262	7004	RAL
6263	1370	TAD KEEP
6264	3370	DCA KEEP
6265	1045	TAD HORD
6266	3756	DCA I MP2PT
6267	1041	TAD AC1H
6270	4755	JMS I MP4PT
6271	1367	TAD D
6272	3046	DCA LORD
6273	7004	RAL
6274	1757	TAD I MP5PT
6275	1370	TAD KEEP
6276	3045	DCA HORD
6277	4760	JMS I NORMF
6300	3047	DCA OVER2
6301	2365	ISZ SGN
6302	5621	JMP I DMULT
6303	4773	JMS I MINS
6304	5621	JMP I DMULT
6305	1041	FLDV, TAD AC1H
6306	7640	SZA CLA
6307	5313	JMP .+4
6310	1042	TAD AC1L
6311	7650	SNA CLA
6312	5774	JMP I ERROR /DIVISION BY ZERO
6313	1040	TAD EX1
6314	7041	CMA IAC
6315	1044	TAD EXP
6316	7001	IAC
6317	3044	DCA EXP /SUBTRACT EXPONENTS
6320	1362	TAD SPACLA
6321	3347	DCA SNSWIT
6322	4336	JMS SIGN /SET UP SIGNS
6323	4761	JMS I DIVIDE /DIVIDE
6324	1757	TAD I MP5PT
6325	1041	TAD AC1H /ROUND OFF IN 23RD BIT
6326	7630	SZL CLA
6327	7001	IAC
6330	3042	DCA AC1L
6331	3041	DCA AC1H
6332	2365	ISZ SGN /TEST SIGN
6333	4773	JMS I MINS /NEGATE
6334	5735	JMP I .+1 /ADD ROUNDING
6335	5720	FLAD+2
6336	0000	SIGN, 0 /TEST SIGN OF RESULT
6337	1366	TAD REST /SET UP BY MULTIPLY AND
6340	3365	DCA SGN /DIVIDE

6341	1045		TAD HORD	
6342	7700		SMA CLA	
6343	5346		JMP .+3	
6344	4773		JMS I MINS	
6345	2365		ISZ SGN	
6346	1041		TAD AC1H	
6347	7700	SNSWIT,	SMA CLA	/OR SPA CLA
6350	5736		JMP I SIGN	
6351	4771		JMS I MINS2	
6352	2365		ISZ SGN	
6353	7000		NOP	
6354	5736		JMP I SIGN	
6355	6437	MP4PT,	MP4	
6356	6471	MP2PT,	MP2	
6357	6465	MP5PT,	MP5	
6360	6600	NORMF,	DNORM	
6361	6472	DIVIDE,	DUBDIV	
6362	7710	SPACLA,	SPA CLA	
6363	7700	SMACLA,	SMA CLA	
6364	5601	RETURN,	FPNT+1	
6365	0000	SGN,	0	
6366	7776	REST,	7776	
6367	0000	D,	0	
6370	0000	KEEP,	0	
6371	6400	MINS2,	MINUS2	/-AC1H,AC1L
6372	6420	RAR2,	DIV2	/AC1H,AC1L/2
6373	6000	MINS,	ACMINS	
6374	6152	ERROR,	ERROR1	
		*6400		
6400	0000	MINUS2,	0	/NEGATE OPERAND
6401	7300		CLA CLL	/TRIPLE PRECISION
6402	1043		TAD OVER1	
6403	7041		CMA IAC	
6404	3043		DCA OVER1	
6405	1042		TAD AC1L	
6406	7040		CMA	
6407	7430		SZL	
6410	7101		CLL IAC	
6411	3042		DCA AC1L	
6412	1041		TAD AC1H	
6413	7040		CMA	
6414	7430		SZL	
6415	7101		CLL IAC	
6416	3041		DCA AC1H	
6417	5600		JMP I MINUS2	
6420	0000	DIV2,	0	/SHIFT OPERAND RIGHT
6421	7300		CLA CLL	/TRIPLE PRECISION
6422	1041		TAD AC1H	
6423	7510		SPA	
6424	7120		CLL CML	
6425	7010		RAR	
6426	3041		DCA AC1H	
6427	1042		TAD AC1L	

6430	7010	RAR
6431	3042	DCA AC1L
6432	1043	TAD OVER1
6433	7010	RAR
6434	3043	DCA OVER1
6435	7100	CLL
6436	5620	JMP I DIV2
6437	0000	MP4,
		0
		/SINGLE PRECISION MULTIPLY
6440	3266	DCA MP1
6441	3265	DCA MP5
6442	1270	TAD THIR
6443	3267	DCA MP3
6444	7100	CLL
6445	1266	TAD MP1
6446	7010	RAR
6447	3266	DCA MP1
6450	1265	TAD MP5
6451	7420	SNL
6452	5255	JMP .+3
6453	7100	CLL
6454	1271	TAD MP2
6455	7010	RAR
6456	3265	DCA MP5
6457	2267	ISZ MP3
6460	5245	JMP MP4+6
6461	1266	TAD MP1
6462	7010	RAR
6463	7100	CLL
6464	5637	JMP I MP4
6465	0000	MP5,
6466	0000	MP1,
6467	0000	MP3,
6470	7764	THIR,
6471	0000	MP2,
6472	0000	DUBDIV,
		0
		/DOUBLE PRECISION DIVIDE
6473	7300	CLA CLL
6474	3051	DCA QUOL
6475	1344	TAD MIF
6476	3267	DCA MP3
6477	5306	JMP DVX
6500	1046	DV3,
		TAD LORD
6501	7004	RAL
6502	3046	DCA LORD
6503	1045	TAD HORD
6504	7004	RAL
6505	3045	DCA HORD
6506	1042	DVX,
		TAD AC1L
6507	1046	TAD LORD
6510	3271	DCA MP2
6511	7004	RAL
6512	1045	TAD HORD
6513	1041	TAD AC1H
6514	7420	SNL

6515	5321	JMP DV2-1		
6516	3045	DCA HORD		
6517	1271	TAD MP2		
6520	3046	DCA LORD		
6521	7200	CLA		
6522	1051	DV2, TAD QUOL		
6523	7004	RAL		
6524	3051	DCA QUOL		
6525	1047	TAD OVER2		
6526	7004	RAL		
6527	3047	DCA OVER2		
6530	2267	ISZ MP3		
6531	5300	JMP DV3		
6532	1051	TAD QUOL		
6533	3046	DCA LORD		
6534	1045	TAD HORD		
6535	7106	CLL RTL		
6536	3265	DCA MP5		
6537	1047	TAD OVER2		
6540	3045	DCA HORD		
6541	3047	DCA OVER2		
6542	1265	TAD MP5		
6543	5672	JMP I DUBDIV		
6544	7751	MIF, TABLE6, 7751	SQUARE	/TABLE FOR INTERPRETATION
6545	6163	TABLE6,	SQROOT	/OF BITS 8-11
6546	6656		EXIT6	/CONTAINS ABSOLUTE ADDRESSES
6547	6171		EXIT6	/OF PROGRAMS CALLED AS
6550	6171		EXIT6	/ROUTINES
6551	6171		EXIT6	/EXIT6=A DUMMY OR NOP
6552	6171		EXIT6	
6553	6171		EXIT6	
6554	6171		EXIT6	
6555	6171		EXIT6	
6556	6171		EXIT6	
6557	6171		EXIT6	
6560	6171		EXIT6	
6561	6171		EXIT6	
6562	6171		EXIT6	
6563	6171		EXIT6	
6564	0000	DUNORM, 4220	0 JMS DIV2	
6565	4220			/SHIFT OPERAND RIGHT
6566	4772		JMS I RAR1	
6567	2040		ISZ EX1	
6570	7000		NOP	
6571	5764		JMP I DUNORM	
6572	6200	RAR1, *6600	DIV1	
6600	0000	DNORM, 7300	0 CLA CLL	/SUBROUTINE TO NORMALIZE /FLOATING ACCUMULATOR
6601	7300			
6602	3255		DCA AMT1	
6603	3254		DCA SIGN1	
6604	1045		TAD HORD	
6605	7510		SPA	/IS MANTISSA NEGATIVE?

6606	2254	ISZ SIGN1	/YES	
6607	7640	SZA CLA	/IS MANTISSA=0?	
6610	5217	JMP GO6	/NO	
6611	1046	TAD LORD		
6612	7640	SZA CLA		
6613	5217	JMP GO6		
6614	1047	TAD OVER2		
6615	7650	SNA CLA		
6616	5251	JMP EXIT2	/YES	
6617	1254	GO6,	TAD SIGN1	/NO
6620	7640	SZA CLA	/NEGATIVE?	
6621	4653	JMS I NEG	/YES	
6622	1045	LOP,	TAD HORD	/WILL SHIFT BE TOO FAR?
6623	7104	RAL CLL		
6624	7710	SPA CLA		
6625	5241	JMP EXIT1	/YES	
6626	1047	TAD OVER2		
6627	7104	CLL RAL		
6630	3047	DCA OVER2		
6631	1046	TAD LORD		
6632	7004	RAL		
6633	3046	DCA LORD		
6634	1045	TAD HORD		
6635	7004	RAL		
6636	3045	DCA HORD		
6637	2255	ISZ AMT1	/COUNT NO. OF TIMES SHIFTED	
6640	5222	JMP LOP		
6641	1255	EXIT1,	TAD AMT1	/CORRECT EXPONENT
6642	7041	CMA IAC		
6643	1044	TAD EXP		
6644	3044	DCA EXP		
6645	1254	TAD SIGN1	/NEGATIVE?	
6646	7640	SZA CLA		
6647	4653	JMS I NEG	/YES	
6650	5600	JMP I DNORM		
6651	3044	EXIT2,	DCA EXP	/SET TO ZERO
6652	5600	JMP I DNORM		
6653	6000	NEG,	ACMINS	
6654	0000	SIGN1,	0	
6655	0000	AMT1,	0	
6656	0000	SQROOT,	0	
6657	3362	DCA FLAG1	/FLOATING SQUARE ROOT	
6660	4407	JMS I 007	/TAKES ROOT OF ABSOLUTE	
6661	6052	FPUT FPAC1		
6662	0000	FEXT	/VALUE	
6663	1045	TAD HORD		
6664	7710	SPA CLA		
6665	5351	JMP SQEND1	/NUMBER IS NEGATIVE	
6666	1044	TAD EXP		
6667	7100	CLL		
6670	7510	SPA		
6671	7020	CML		
6672	7010	RAR		
6673	3356	DCA ITER1	/MAKE FIRST APPROXIMATION	

6674	7430	SZL	
6675	2356	ISZ ITER1	
6676	7000	NOP	
6677	1361	TAD SQCON1	
6700	3357	DCA ITER1+1	
6701	3360	DCA ITER1+2	
6702	1053	TAD FPAC1+1	
6703	7640	SZA CLA	
6704	5310	JMP CLCU	
6705	1054	TAD FPAC1+2	
6706	7650	SNA CLA	
6707	5354	JMP SQEND	/NUMBER=0
6710	4407	CLCU,	JMS I 0007
6711	5052	FGET FPAC1	
6712	4356	FDIV ITER1	
6713	1356	FADD ITER1	
6714	0000	FEXT	
6715	7240	CLA CMA	
6716	1044	TAD EXP	
6717	3044	DCA EXP	
6720	1044	TAD EXP	
6721	7041	CMA IAC	
6722	1356	TAD ITER1	
6723	7640	SZA CLA	/ARE EXPONENTS EQUAL?
6724	5345	JMP ROOTGO	/NO
6725	1045	TAD HORD	/ARE HIGH-ORDER MANTISSAS EQUAL?
6726	7041	CMA IAC	
6727	1357	TAD ITER1+1	
6730	7640	SZA CLA	
6731	5345	JMP ROOTGO	/NO
6732	1046	TAD LORD	
6733	7041	CMA IAC	
6734	1360	TAD ITER1+2	/DO LOW-ORDER MANTISSAS AGREE?
6735	7500	SMA	
6736	7041	CMA IAC	/WITHIN ONE BIT?
6737	7001	IAC	
6740	7710	SPA CLA	
6741	5345	JMP ROOTGO	/NO
6742	1362	TAD FLAG1	
6743	3061	DCA FLAG	
6744	5656	JMP I SQROOT	
6745	4407	ROOTGO,	JMS I 0007
6746	6356	FPUT ITER1	
6747	0000	FEXT	
6750	5310	JMP CLCU	
6751	4653	SQEND1,	JMS I NEG /NEGATE FAC
6752	2362		ISZ FLAG1
6753	5260		JMP SQROOT+2
6754	3044	SQEND,	DCA EXP
6755	5656		JMP I SQROOT
6756	0000	ITER1,	0
6757	0000		0
6760	0000		0
6761	3015	SQCON1,	3015
6762	0000	FLAG1,	0

ACMINS	6000	FLPT	5705	NORMF	6360
ACON6	5760	FLSU	5737	OPMINS	5741
AC1H	0041	FPAC1	0052	OUTGO	6116
AC1L	0042	FPNT	5600	OVER1	0043
ADDR	5656	GOOF	6162	OVER2	0047
ALGN	5771	GO2	5655	PAGENO	5663
ALIGN	6020	GO6	6617	QUOL	0051
AMOUNT	6142	HORD	0045	RAR1	6572
AMT1	6655	INDRCT	5664	RAR2	6372
CLCU	6710	ITER1	6756	REST	6366
D	6367	JUMP	5653	RETN2	6151
DIVIDE	6361	JUMP2	5654	RETURN	6364
DIV1	6200	KEEP	6370	ROOTGO	6745
DIV2	6420	LOOP01	5627	SAVE	5657
DMULT	6221	LOP	6622	SGN	6365
DNORM	6600	LORD	0046	SHIFT	6076
DONE	6114	MASK3	5660	SIGN	6336
DUBDIV	6472	MASK5	5661	SIGN1	6654
DUNORM	6564	MASK7	5662	SMACLA	6363
DVX	6506	MIF	6544	SNSWIT	6347
DV2	6522	MINS	6373	SPACLA	6362
DV3	6500	MINS2	6371	SQCON1	6761
ERROR	6374	MINUS2	6400	SQEND	6754
ERROR1	6152	MP1	6466	SQEND1	6751
EXIT	5742	MP2	6471	SQROOT	6656
EXIT1	6641	MP2PT	6356	SQUARE	6163
EXIT2	6651	MP3	6467	TABLE	5665
EXIT6	6171	MP4	6437	TABLE6	6545
EXP	0044	MP4PT	6355	TAG1	6147
EXP1	0050	MP5	6465	TAG2	6150
EX1	0040	MP5PT	6357	TEST2	6143
FLAD	5716	MULT	5767	TEST3	6144
FLAG	0061	NEG	6653	TEST4	6145
FLAG1	6762	NOGO	6125	TEST5	6146
FLDV	6305	NOHERE	6137	THIR	6470
FLGT	5676	NORF	5773	UNORM	5772
FLMY	5761	NORM	5770		

/FLOATING POINT I/O ROUTINES  
/REQUIRES FLOATING POINT INTERPRETER  
/ENTRY AT 0007

\*7  
0007 5600 FPNT, 5600

\*44  
0044 0000 EXPONT, 0  
0045 0000 HORDER, 0  
0046 0000 LORDER, 0

\*52  
0052 0000 FPAC1, 0  
0053 0000 0  
0054 0000 0  
0055 7777 SWIT1, 7777 /IF = 0, NO CR-LF AFTER OUTPUT  
0056 7777 SWIT2, 7777 /IF = 0, NO LF AFTER CR IN INPUT  
0057 0000 CHAR, 0 /CONTAINS LAST CHARACTER READ  
0060 0000 DSWIT, 0 /= 0 IF NO CONVERSION TOOK PLACE

\*6767  
6767 0000 PRCHAR, 0  
6770 1056 TAD SWIT2  
6771 7650 SNA CLA  
6772 5767 JMP I PRCHAR  
6773 1377 TAD LFED  
6774 4776 JMS I OPUT  
6775 5767 JMP I PRCHAR  
6776 7344 OPUT, OUT  
6777 0212 LFED, 0212

/DOUBLE PRECISION DECIMAL-BINARY  
 /INPUT AND CONVERSION  
 \*7000

7000	0000	DECONV,	0	
7001	7200		CLA	/INITIALIZE MANTISSA
7002	3045		DCA HORDER	
7003	3046		DCA LORDER	
7004	3265		DCA SIGN	
7005	3266		DCA DNUMBR	
7006	4342		JMS INPUT	
7007	1336		TAD PLUS	/TEST FOR SIGN
7010	7450		SNA	
7011	5217		JMP DECON	
7012	1335		TAD MINUS	
7013	7440		SZA	
7014	5220		JMP .+4	
7015	7240		CLA CMA	
7016	3265		DCA SIGN	/IF-, SET SWITCH
7017	4342	DECON,	JMS INPUT	
7020	7200		CLA	
7021	1057		TAD CHAR	/IS IT A DIGIT
7022	1337		TAD MIN9	
7023	7500		SMA	
7024	5600		JMP I DECONV	/NO
7025	1340		TAD PLUS10	
7026	7510		SPA	
7027	5600		JMP I DECONV	/NO
7030	3263		DCA DIGIT	/YES
7031	1045		TAD HORDER	
7032	0341		AND MASK	/OVERFLOW?
7033	7440		SZA	
7034	5217		JMP DECON	/YES-IGNORE
7035	2060		ISZ DSWIT	
7036	2266		ISZ DNUMBR	/INDEX NUMBER OF DIGITS
7037	4241		JMS MULT10	
7040	5217		JMP DECON	/CONTINUE
7041	0000	MULT10,	0	/ROUTINE TO MULTIPLY
7042	1046		TAD LORDER	/DOUBLE PRECISION WORD
7043	3261		DCA LTEMP	/BY TEN (DECIMAL)
7044	1045		TAD HORDER	/REMAIN=REMAINDER
7045	3262		DCA HTEMP	
7046	3264		DCA REMAIN	
7047	4267		JMS MULT2	/CALL SUBROUTINE TO
7050	4267		JMS MULT2	/MULTIPLY BY TWO
7051	4303		JMS DUBLAD	/CALL DOUBLE ADD
7052	4267		JMS MULT2	
7053	1263		TAD DIGIT	/ADD LAST DIGIT RECEIVED
7054	3261		DCA LTEMP	
7055	3262		DCA HTEMP	
7056	4303		JMS DUBLAD	
7057	1264		TAD REMAIN	/EXIT WITH REMAINDER
7060	5641		JMP I MULT10	/IN AC
7061	0000	LTEMP,	0	/DOUBLE PRECISION WORD
7062	0000	HTEMP,	0	
7063	0000	DIGIT,	0	/STORAGE FOR DIGIT
7064	0000	REMAIN,	0	
7065	0000	SIGN,	0	/=0 IF PLUS: =7777 IF MINUS
7066	0000	DNUMBR,	0	/=NUMBER OF DIGITS
7067	0000	MULT2,	0	/MULTIPLY LORDER, HORDER BY 2

7070	7300	CLA CLL	
7071	1046	TAD LORDER	
7072	7004	RAL	
7073	3046	DCA LORDER	
7074	1045	TAD HORDER	
7075	7004	RAL	
7076	3045	DCA HORDER	
7077	1264	TAD REMAIN	
7100	7004	RAL	
7101	3264	DCA REMAIN	
7102	5667	JMP I MULT2	
7103	0000	DUBLAD, 0	/DOUBLE PRECISION ADDITION
7104	7300	CLA CLL	
7105	1046	TAD LORDER	
7106	1261	TAD LTEMP	
7107	3046	DCA LORDER	
7110	7004	RAL	
7111	1045	TAD HORDER	
7112	1262	TAD HTEMP	
7113	3045	DCA HORDER	
7114	7004	RAL	
7115	1264	TAD REMAIN	
7116	3264	DCA REMAIN	
7117	5703	JMP I DUBLAD 0	
7120	0000	MSIGN, CLA CLL	/ROUTINE TO FORM /2'S COMPLEMENT IF
7121	7300	ISZ SIGN	/MINUS
7122	2265	JMP I MSIGN	/SIGN=0000: EXIT
7123	5720	TAD LORDER	
7124	1046	CMA IAC	
7125	7041	DCA LORDER	
7126	3046	TAD HORDER	
7127	1045	CMA	
7130	7040	SZL	
7131	7430	IAC	
7132	7001	DCA HORDER	
7133	3045	JMP I MSIGN	
7134	5720	253-255	/TEST FOR SIGN
7135	7776	MINUS, PLUS,	-253 -253
7136	7525	MIN9, PLUS12,	-272 272-260
7137	7506	MASK,	7600
7140	0012		/TEST FOR OVERFLOW
7141	7600	/INPUT A CHARACTER, IF CR, TEST /INPUT SWITCH TO SEE IF LF SHOULD /BE TYPED. IF RUBOUT, RESTART INPUT	
7142	0000	INPUT, 0	/INPUT A CHARACTER
7143	7200	CLA	
7144	6031	KSF	
7145	5344	JMP .-1	
7146	6036	KRB	
7147	3057	DCA CHAR	
7150	1057	TAD CHAR	
7151	4766	JMS I OUTPUT	
7152	1057	TAD CHAR	
7153	7450	SNA	
7154	5343	JMP INPUT+1	/IGNORE BLANKS
7155	1370	TAD MRBOUT	
7156	7450	SNA	
7157	5767	JMP I RESTRT	/RUBOUT-RESTART INPUT
7160	1371	TAD MINCR	

7161	7650	SNA CLA	
7162	4765	JMS I PRINT	/CR - SEE IF TO BE FOLLOWED
7163	1057	TAD CHAR	/BY LF
7164	5742	JMP I INPUT	/EXIT ROUTINE
7165	6767	PRINT,	PRCHAR
7166	7344	OUTPUT,	OUT
7167	7401	RESTRT,	FLINTP+1
7170	7401	MRBOUT,	-377
7171	0162	MINCR,	377-215
/FLOATING OUTPUT "E" FORMAT			
/USES:           TSF			
/                JMP .-1			
/                TLS			
*7200			
7200	0000	FLOUTP,     0	
7201	4217	JMS FOUTCN	/CONVERT MANTISSA AND OUTPUT
7202	1324	TAD BEXP	
7203	3044	DCA EXPONT	
7204	1343	TAD CHE	
7205	4344	JMS OUT	
7206	4737	JMS I FEXPPT	/CONVERT EXPONENT AND OUTPUT
7207	1055	TAD SWIT1	/PRINT CR-LF?
7210	7650	SNA CLA	
7211	5600	JMP I FLOUTP	/NO-EXIT
7212	1341	TAD CARRTN /YES	
7213	4344	JMS OUT	
7214	1342	TAD LNFEED	
7215	4344	JMS OUT	
7216	5600	JMP I FLOUTP	/EXIT
/THIS WHOLE SUBROUTINE MAY BE ALTERED TO BUFFER			
/THE OUTPUT DIGITS : CHANGE JMS OUTDG TO DCA I 10, ETC.			
7217	0000	FOUTCN,     0	
7220	7300	CLA CLL	
7221	1045	TAD HORDER	/NUMBER>0??
7222	7710	SPA CLA	
7223	7220	CLA CML	/NO SET LINK
7224	1327	TAD SPLUS	/YES
7225	7430	SZL	
7226	1330	TAD SMINUS /NO	
7227	4344	JMS OUT	
7230	4352	JMS OUTDG	/OUTPUT "0"
7231	1331	TAD PERIOD	
7232	4344	JMS OUT	/OUTPUT "."
7233	7300	CLA CLL	
7234	1045	TAD HORDER	
7235	7700	SMA CLA	
7236	5242	JMP FG01	
7237	7040	CMA	/NUMBER IS NEGATIVE
7240	3733	DCA I SNPT	/NEGATE
7241	4732	JMS I MSNPT	
7242	7240	FG01,        CLA CMA	/SUBTRACT 1 FROM BINARY EXPONENT
7243	1044	TAD EXPONT	/COMPENSATE AT FG04
7244	3044	DCA EXPONT	
7245	3324	DCA BEXP	/INITIALIZE DECIMAL EXPONENT
7246	1044	FG02,        TAD EXPONT	/IS -4<EXPONENT<-1
7247	7500	SMA	
7250	5263	JMP FG03	/TOO LARGE: MULTIPLY BY 1/10
7251	1326	TAD FOUR	

7252	7700	SMA CLA	
7253	5270	JMP FG04	
7254	4407	JMS I FPNT	/TOO SMALL-TIMES TEN
7255	3740	FMPY I TENPT	/TEN
7256	0000	FEXT	
7257	7240	CLA CMA	
7260	1324	TAD BEXP	
7261	3324	DCA BEXP	
7262	5246	JMP FG02	
7263	4407	FG03,	JMS I FPNT
7264	3372	FG03,	FMPY C.10 /ONE TENTH
7265	0000	FEXT	
7266	2324	ISZ BEXP	
7267	5246	JMP FG02	
7270	3734	FG04,	DCA I DPT /MULTIPLY BY TWO
7271	4736	FG04,	JMS I M2PT /IE.SHIFT LEFT
7272	4735	FG04,	JMS I M10PT /MULTIPLY BY TEN
7273	7410	SKP	
7274	4357	FG05A,	JMS DIVITWO /COMPENSATE FOR
7275	2044	FG05A,	ISZ EXPONT /BINARY EXPONENT
7276	5274	FG05A,	JMP FG05A
7277	7450	FG05A,	SNA /IS FIRST DIGIT A ZERO
7300	5311	FG05A,	JMP FG07 /YES, IGNORE
7301	4352	FG06,	JMS OUTDG /MULTIPLICATIONS YIELD
7302	1325	FG06,	TAD MINUS7 /DECIMAL DIGITS AS HIGH
7303	3044	FG06,	DCA EXPONT /ORDER REMAINDERS
7304	4735	FG06A,	JMS I M10PT /IE. .672X10=6+.72.. ETC
7305	4352	FG06A,	JMS OUTDG
7306	2044	FG06A,	ISZ EXPONT
7307	5304	FG06A,	JMP FG06A
7310	5617	FG06A,	JMP I FOUTCN
7311	7240	FG07,	CLA CMA /IGNORE FIRST DIGIT
7312	1324	FG07,	TAD BEXP /SUBTRACT 1 FROM
7313	3324	FG07,	DCA BEXP /DECIMAL EXPONENT
7314	1045	FG07,	TAD HORDER
7315	7640	FG07,	SZA CLA
7316	5322	FG07,	JMP .+4
7317	1046	FG07,	TAD LORDER
7320	7650	FG07,	SNA CLA
7321	3324	FG07,	DCA BEXP
7322	7240	FG07,	CLA CMA
7323	5302	FG07,	JMP FG06+1
7324	0000	BEXP,	0
7325	7772	MINUS7,	1172
7326	0004	FOUR,	0004
7327	0253	SPLUS,	253
7330	0002	SMINUS,	255-253
7331	0256	PERIOD,	256
7332	7120	MSNPT,	MSIGN
7333	7065	SNPT,	SIGN
7334	7063	DPT,	DIGIT
7335	7041	M10PT,	MULT10
7336	7067	M2PT,	MULT2
7337	7522	FEXPPT,	FEXC
7340	7504	TENPT,	TEN
7341	0215	CARRTN,	0215
7342	0212	LNFEED,	0212
7343	0305	CHE,	305

/POINTERS

7344	0000	OUT,	0	/OUTPUT ONE ASCII CHARACTER
7345	6041		TSF	
7346	5345		JMP .-1	
7347	6046		TLS	
7350	7200		CLA	
7351	5744		JMP I OUT	
7352	0000	OUTDG,	0	/OUTPUT ONE DIGIT
7353	1356		TAD C260	
7354	4344		JMS OUT	
7355	5752		JMP I OUTDG	
7356	0260	C260,	0260	
7357	0000	DIVTWO,	0	/DIVIDE BY TWO IE.
7360	7110		CLL RAR	/ROTATE RIGHT
7361	3344		DCA OUT	/TEMPORARY STORAGE
7362	1045		TAD HORDER	
7363	7010		RAR	
7364	3045		DCA HORDER	
7365	1046		TAD LORDER	
7366	7010		RAR	
7367	3046		DCA LORDER	
7370	1344		TAD OUT	
7371	5757		JMP I DIVTWO	
7372	7775	C.10,	7775	/CONSTANT .10 USED IN
7373	3146		3146	/FLOATING OUTPUT-PROVIDES
7374	3147		3147	
			/FLOATING POINT INPUT	
		*7400		
7400	0000	FLINTP,	0	
7401	7240		CLA CMA	/INITIALIZE "PERIOD SWITCH"
7402	3313		DCA PRSW	
7403	3060		DCA DSWIT	
7404	4716		JMS I DPCVPT	/7777 = NO PERIOD
7405	7200		CLA	
7406	1057		TAD CHAR	
7407	1312		TAD PER	
7410	7640		SZA CLA	
7411	5220		JMP FIG01	
7412	1313		TAD PRSW	/PERIOD FOUND
7413	7650		SNA CLA	/SECOND PERIOD
7414	5222		JMP FIG02	/YES, TERMINATE
7415	3721		DCA I DPN	/NO - SET NUMBER OF DIGITS TO 0
7416	3313		DCA PRSW	/SET PERIOD SWITCH TO 0
7417	5717		JMP I DPCSPT	/CONVERT REST OF STRING
7420	1313	FIG01,	TAD PRSW	/PERIOD READ IN PREVIOUSLY?
7421	7650		SNA CLA	
7422	1721	FIG02,	TAD I DPN	/YES:-NUMBER OF DIGITS IN SEXP
7423	7041		CMA IAC	/NO
7424	3314		DCA SEXP	
7425	4720		JMS I MSGNPT	/TEST SIGN
7426	1311	FIG03,	TAD C27	
7427	3044		DCA EXPONT	
7430	4407		JMS I FPNT	/NORMALIZE F.P. NUMBER
7431	7000		FNOR	
7432	6052		FPUT FPAC1	
7433	0000		FEXT	/SAVE NUMBER
7434	1057		TAD CHAR	
7435	1310		TAD MINUSE	

7436	7640	SZA CLA	/*E" READ IN?
7437	5252	JMP ENDFI	/NO
7440	4716	JMS I DPCVPT	/YES - CONVERT DECIMAL EXPONENT
7441	4720	JMS I MSGNPT	/TEST SIGN
7442	1045	TAD HORDER	/EXPONENT TOO LARGE??
7443	7510	SPA	
7444	7001	IAC	
7445	7640	SZA CLA	
7446	5277	JMP EXCESS	/YES
7447	1046	TAD LORDER	/NO: DECIMAL POINT IS
7450	1314	TAD SEXP	/C(SEXP) PLACES TO RIGHT
7451	3314	DCA SEXP	/OF LAST DIGIT

/END OF FLOATING POINT INPUT  
 /COMPENSATE FOR DECIMAL EXPONENTS

7452	4407	ENDFI,	JMS I FPNT	/RESTORE MANTISSA
7453	5052		FGET FPAC1	
7454	0000		FEXT	
7455	1314		TAD SEXP	
7456	7450		SNA	
7457	5600		JMP I FLINTP	
7460	7700		SMA CLA	
7461	5270		JMP FIG04	
7462	4407		JMS I FPNT	
7463	3707		FMPY I PC.10	/TIMES .1000
7464	0000		FEXT	
7465	2314		ISZ SEXP	
7466	5255		JMP ENDFI+3	
7467	5600		JMP I FLINTP	
7470	4407	FIG04,	JMS I FPNT	
7471	3304		FMPY TEN	/MULTIPLY BY 10
7472	0000		FEXT	
7473	7240		CLA CMA	
7474	1314		TAD SEXP	
7475	3314		DCA SEXP	
7476	5255		JMP ENDFI+3	
7477	1315	EXCESS,	TAD C3777	
7500	3044		DCA EXPONT	
7501	1315		TAD C3777	
7502	3045		DCA HORDER	
7503	5600		JMP I FLINTP	
7504	0004	TEN,	0004	
7505	2400		2400	
7506	0000		0000	
7507	7372	PC.10,	C.10	.10
7510	7473	MINUSE,	-305	
7511	0027	C27,	0027	
7512	7522	PER,	-256	
7513	0000	PRSW,	0	
7514	0000	SEXP,	0	
7515	3777	C3777,	3777	/CONTAINS DECIMAL EXPONENT
7516	7000	DPCVPT,	DECONV	
7517	7017	DPCSPT,	DECON	
7520	7120	MSGNPT,	MSIGN	
7521	7066	DPN,	DNUMBR	
		/OUTPUT THE EXPONENT		
7522	0000	FEXC,	0	
7523	7300		CLA CLL	

7524	1044	TAD EXPONT	
7525	7510	SPA	
7526	7061	CMA IAC CML	
7527	3044	DCA EXPONT	
7530	1366	TAD C253	
7531	7430	SZL	
7532	1367	TAD C255	
7533	4774	JMS I DGPT	
7534	3045	DCA HORDER	
7535	1044	TAD EXPONT	
7536	2045	ISZ HORDER	
7537	1370	TAD M144	
7540	7500	SMA	
7541	5336	JMP .-3	
7542	1371	TAD C144	
7543	3044	DCA EXPONT	
7544	7040	CMA	
7545	1045	TAD HORDER	
7546	7440	SZA	
7547	4774	JMS I DGPT	
7550	3045	DCA HORDER	
7551	1044	TAD EXPONT	
7552	2045	ISZ HORDER	
7553	1372	TAD M12	
7554	7500	SMA	
7555	5352	JMP .-3	
7556	1373	TAD C12	
7557	3046	DCA LORDER	
7560	7240	CLA CMA	
7561	1045	TAD HORDER	
7562	4774	JMS I DGPT	
7563	1046	TAD LORDER	
7564	4774	JMS I DGPT	
7565	5722	JMP I FEXC	
7566	7773	C253,	0253-260
7567	0002	C255,	255-253
7570	7634	M144,	7634
7571	0144	C144,	0144
7572	7766	M12,	7766
7573	0012	C12,	0012
7574	7352	DGPT,	OUTDG

BEXP	7324	HORDER	0045
CARRTN	7341	HTEMP	7062
CHAR	0057	INPUT	7142
CHE	7343	LFED	6777
C.10	7372	LNFEED	7342
C12	7573	LORDER	0046
C144	7571	LTEMP	7061
C253	7566	MASK	7141
C255	7567	MINCR	7171
C260	7356	MINUS	7135
C27	7511	MINUSE	7510
C3777	7515	MINUS7	7325
DECON	7017	MIN9	7137
DECONV	7000	MRBOUT	7170
DGPT	7574	MSGNPT	7520
DIGIT	7063	MSIGN	7120
DIVTWO	7357	MSNPT	7332
DNUMBR	7066	MULT10	7041
DPCSP1	7517	MULT2	7067
DPCVPT	7516	M10PT	7335
DPN	7521	M12	7572
DPT	7334	M144	7570
DSWIT	0060	M2PT	7336
DUBLAD	7103	OPUT	6776
ENDFI	7452	OUT	7344
EXCESS	7477	OUTDG	7352
EXPONT	0044	OUTPUT	7166
FEXC	7522	PC.10	7507
FEXPPT	7337	PER	7512
FG01	7242	PERIOD	7331
FG02	7246	PLUS	7136
FG03	7263	PLUS12	7140
FG04	7270	PRCHAR	6767
FG05A	7274	PRINT	7165
FG06	7301	PRSW	7513
FG06A	7304	REMAIN	7064
FG07	7311	RESTR1	7167
FIG01	7420	SEXP	7514
FIG02	7422	SIGN	7065
FIG03	7426	SMINUS	7330
FIG04	7470	SNPT	7333
FLINTP	7400	SPLUS	7327
FLOUTP	7200	SWIT1	0055
FOUR	7326	SWIT2	0056
FOUTCN	7217	TEN	7504
FPAC1	0052	TENPT	7340
FPNT	0007		

EXTENDED FUNCTIONS  
 /FLOATING POINT PACKAGE

GETSGN=TAD 45  
 CLFPNT=JMS I 7

/FLOATING POINT EXPONENTIAL

\*5000

5000	0000	FEXP,	0
5001	1045		GETSGN
5002	7710		SPA CLA
5003	4310		JMS FNEG
5004	3304		DCA SIGN
5005	4407		CLFPNT
5006	3273		FMPY LG2E
5007	6315		FPUT X
5010	0000		FEXT
5011	4706		JMS I FIXIT
5012	1045		GETSGN
5013	3305		DCA FLAG2
5014	4707		JMS I FLOAT
5015	4407		CLFPNT
5016	6320		FPUT XSQR
5017	5315		FGET X
5020	2320		FSUB XSQR
5021	6315		FPUT X
5022	3315		FMPY X
5023	6320		FPUT XSQR
5024	1270		FADD D
5025	6323		FPUT TEMP
5026	5265		FGET C
5027	4323		FDIV TEMP
5030	2315		FSUB X
5031	1257		FADD A
5032	6323		FPUT TEMP
5033	5262		FGET B
5034	3320		FMPY XSQR
5035	1323		FADD TEMP
5036	6323		FPUT TEMP
5037	5315		FGET X
5040	4323		FDIV TEMP
5041	3301		FMPY TWO
5042	1276		FADD ONE
5043	0000		FEXT
5044	1305		TAD FLAG2
5045	1044		TAD 44
5046	3044		DCA 44
5047	2304		ISZ SIGN
5050	5600		JMP I FEXP
5051	4407		CLFPNT
5052	6315		FPUT X
5053	5276		FGET ONE
5054	4315		FDIV X
5055	0000		FEXT
5056	5600		JMP I FEXP
/CONSTANTS FOR FEXP			
5057	0004	A,	0004
5060	2372		2372
5061	1402		1402

5062	7774	B,	7774
5063	2157		2157
5064	5157		5157
5065	0012	C,	0012
5066	5454		5454
5067	0343		0343
5070	0007	D,	0007
5071	2566		2566
5072	5341		5341
5073	0001	LG2E,	0001
5074	2705		2705
5075	2435		2435
5076	0001	ONE,	0001
5077	2000		2000
5100	0000		0000
5101	0002	TWO,	0002
5102	2000		2000
5103	0000		0000
5104	0000	SIGN,	0
5105	0000	FLAG2,	0
5106	4757	FIXIT,	FIX
5107	5563	FLOAT,	FLOA
		/NEGATION	SUBROUTINE
5110	0000	FNEG,	0
5111	4714		JMS I ACMINS
5112	7240		CLA CMA
5113	5710		JMP I FNEG
5114	6000	ACMINS,	6000
			/CALL SUBROUTINE IN
			/INTERPRETER
			/POINTER TO INTERPRETER
			/TEMPORARY STORAGE
5115	0000	X,	0
5116	0000		0
5117	0000		0
5120	0000	XSQR,	0
5121	0000		0
5122	0000		0
5123	0000	TEMP,	0
5124	0000		0
5125	0000		0
5126	0000	ZER,	0
5127	0000		0
5130	0000		0
			/MAIN ALGORITHM FOR ARCTANGENT
5131	4407	ARCALG,	CLFPNT
5132	5315		FGET X
5133	3315		FMPY X
5134	6320		FPUT XSQR
5135	3373		FMPY BET2
5136	1370		FADD BET1
5137	3320		FMPY XSQR
5140	1365		FADD BETZ
5141	6323		FPUT TEMP
5142	5362		FGET ALF2
5143	3320		FMPY XSQR
5144	1357		FADD ALF1
5145	3320		FMPY XSQR
5146	1354		FADD ALFZ
5147	3315		FMPY X
5150	4323		FDIV TEMP
5151	0000		FEXT
5152	5753		JMP I .+1
5153	5226		ARCRTN

		/CONSTANTS - FLOATING ARC TANGENT	
5154	0000	ALFZ,	0000
5155	2437		2437
5156	1643		1643
5157	7777	ALF1,	7777
5160	3304		3304
5161	4434		4434
5162	7773	ALF2,	7773
5163	3306		3306
5164	5454		5454
5165	0000	BETZ,	0000
5166	2437		2437
5167	1646		1646
5170	0000	BET1,	0000
5171	2427		2427
5172	2323		2323
5173	7775	BET2,	7775
5174	3427		3427
5175	7052		7052
		/FLOATING POINT ARC TANGENT	
	*5200		
5200	0000	ARTN,	0
5201	1045		GETSGN
5202	7710		SPA CLA
5203	4642		JMS I NEGIT
5204	3243		DCA FLAG1
5205	4407		CLFPNT
5206	6644		FPUT I X1
5207	5644		FGET I X1
5210	2645		FSUB I CON1
5211	0000		FEXT
5212	1045		GETSGN
5213	7710		SPA CLA
5214	5223		JMP GO
5215	4407		CLFPNT
5216	5645		FGET I CON1
5217	4644		FDIV I X1
5220	6644		FPUT I X1
5221	0000		FEXT
5222	7240		CLA CMA
5223	3251	GO,	DCA FLOG
5224	5625		JMP I .+1
5225	5131		ARCALG
5226	2251	ARCRTN,	ISZ FLOG
5227	5235		JMP EXIT
5230	4407		CLFPNT
5231	6644		FPUT I X1
5232	5246		FGET PIOT
5233	2644		FSUB I X1
5234	0000		FEXT
5235	2243	EXIT,	ISZ FLAG1
5236	5600		JMP I ARTN
5237	4642		JMS I NEGIT
5240	7200		CLA
5241	5600		JMP I ARTN
		/CONSTANTS FOR ARCTANGENT	
5242	5110	NEGIT,	FNEG
5243	0000	FLAG1,	0
5244	5115	X1,	X
5245	5076	CON1,	ONE

5246	0001	PIOT,	0001
5247	3110		3110
5250	3755		3755
		/FLOATING	LOGARITHM
5251	0000	FLOG,	0
5252	1045		GETSGN
5253	7440		SZA
5254	5261		JMP OK
5255	4407		CLFPNT
5256	4775		FDIV I ZERO
5257	0000		FEXT
5260	5651		JMP I FLOG
5261	7710	OK,	SPA CLA
5262	4642		JMS I NEGIT
5263	4407		CLFPNT
5264	6774		FPUT I TEM
5265	2645		FSUB I CON1
5266	0000		FEXT
5267	1045		GETSGN
5270	7450		SNA
5271	5350		JMP ZERGO
5272	7710		SPA CLA
5273	5341		JMP INVERT
5274	3243	START,	DCA FLAG1
5275	7040		CMA
5276	1774		TAD I TEM
5277	3045		DCA 45
5300	4777		JMS I FLOATP
5301	4407		CLFPNT
5302	3776		FMPY I LOG2
5303	6644		FPUT I X1
5304	0000		FEXT
5305	7001		IAC
5306	3774		DCA I TEM
5307	4407		CLFPNT
5310	5774		FGET I TEM
5311	2645		FSUB I CON1
5312	6774		FPUT I TEM
5313	3773		FMPY I L8
5314	1772		FADD I L7
5315	3774		FMPY I TEM
5316	1771		FADD I L6
5317	3774		FMPY I TEM
5320	1770		FADD I L5
5321	3774		FMPY I TEM
5322	1365		FADD L4
5323	3774		FMPY I TEM
5324	1362		FADD L3
5325	3774		FMPY I TEM
5326	1357		FADD L2
5327	3774		FMPY I TEM
5330	1354		FADD L1
5331	3774		FMPY I TEM
5332	1644		FADD I X1
5333	0000		FEXT
5334	2243		ISZ FLAG1
5335	5651		JMP I FLOG
5336	4642		JMS I NEGIT
5337	7200		CLA
5340	5651		JMP I FLOG

5341	4407	INVERT,	CLFPNT
5342	5645		FGET I CON1
5343	4774		FDIV I TEM
5344	6774		FPUT I TEM
5345	0000		FEXT
5346	7240		CLA CMA
5347	5274	ZERGO,	JMP START
5350	4407		CLFPNT
5351	5775		FGET I ZERO
5352	0000		FEXT
5353	5651		JMP I FLOG
5354	0000	L1,	0000
5355	3777		3777
5356	7742		7742
5357	7777	L2,	7777
5360	4000		4000
5361	4100		4100
5362	7777	L3,	7777
5363	2517		2517
5364	0307		0307
5365	7776	L4,	7776
5366	4113		4113
5367	7211		7211
5370	5547	L5,	LOG5
5371	5552	L6,	LOG6
5372	5555	L7,	LOG7
5373	5560	L8,	LOG8
5374	5123	TEM,	TEMP
5375	5126	ZERO,	ZER
5376	5544	LOG2,	LOGE2
5377	5563	FLOATP,	FLOA
		/FLOATING POINT SINE	
	*5400		
5400	0000	FSIN,	0
5401	1045		GETSGN
5402	7740		SMA SZA CLA
5403	5210		JMP MOD
5404	1045		GETSGN
5405	7700		SMA CLA
5406	5600		JMP I FSIN
5407	4741		JMS I NEGT
5410	3343	MOD,	DCA PNTR
5411	4407		CLFPNT
5412	4315		FDIV TWOPI
5413	6724		FPUT I XSQ2
5414	0000		FEXT
5415	4742		JMS I FIXR
5416	4363		JMS FLOA
5417	4407		CLFPNT
5420	6723		FPUT I X2
5421	5724		FGET I XSQ2
5422	2723		FSUB I X2
5423	3315		FMPY TWOPI
5424	6723		FPUT I X2
5425	2320		FSUB PI
5426	0000		FEXT
5427	1045		GETSGN
5430	7710		SPA CLA
5431	5241		JMP PCHECK
5432	4407		CLFPNT
5433	6723		FPUT I X2
5434	0000		FEXT

5435	1343	TAD PNTR	
5436	7650	SNA CLA	
5437	7040	CMA	
5440	3343	DCA PNTR	
5441	4407	PCHECK, CLFPNT	/X<PI/2?
5442	5723	FGET I X2	
5443	2714	FSUB I PI2	
5444	0000	FEXT	
5445	1045	GETSGN	
5446	7710	SPA CLA	
5447	5255	JMP PALG	/YES
5450	4407	CLFPNT	/NO
5451	5320	FGET PI	/SIN(X)=SIN(PI-X)
5452	2723	FSUB I X2	
5453	6723	FPUT I X2	
5454	0000	FEXT	
5455	4407	PALG, CLFPNT	
5456	5723	FGET I X2	
5457	4714	FDIV I PI2	
5460	6723	FPUT I X2	
5461	3723	FMPY I X2	
5462	6724	FPUT I XSQ2	
5463	5325	FGET C9	
5464	3724	FMPY I XSQ2	
5465	1330	FADD C7	
5466	3724	FMPY I XSQ2	
5467	1333	FADD C5	
5470	3724	FMPY I XSQ2	
5471	1336	FADD C3	
5472	3724	FMPY I XSQ2	
5473	1714	FADD I PI2	
5474	3723	FMPY I X2	
5475	0000	FEXT	
5476	2343	ISZ PNTR	
5477	5600	JMP I FSIN	
5500	4741	JMS I NEGT	
5501	7200	CLA	
5502	5600	JMP I FSIN	
		/FLOATING POINT COSINE	

5503	0000	FCOS, 0	
5504	4407	CLFPNT	/COS(X)=SIN(PI/2-X)
5505	6723	FPUT I X2	
5506	5714	FGET I PI2	
5507	2723	FSUB I X2	
5510	0000	FEXT	
5511	1303	TAD FCOS	
5512	3200	DCA FSIN	
5513	5201	JMP FSIN+1	

#### /CONSTANTS AND POINTERS

5514	5246	PI2,	PIOT	/PI/2
5515	0003	TWOPi,	0003	
5516	3110		3110	
5517	3755		3755	
5520	0002	PI,	0002	
5521	3110		3110	
5522	3755		3755	
5523	5115	X2,	X	
5524	5120	XSQ2,	XSQR	

		/SINE CONSTANTS
5525	7764	C9,
5526	2366	2366
5527	5735	5735
5530	7771	C7,
5531	5466	5466
5532	6317	6317
5533	7775	C5,
5534	2431	2431
5535	5053	5053
5536	0000	C3,
5537	5325	5325
5540	0420	0420
5541	5110	NEGT,
5542	4757	FIXR,
5543	0000	PNTR, 0
		/LOGARITHM CONSTANTS
5544	0000	LOGE2,
5545	2613	2613
5546	4414	4414
5547	7776	LOG5,
5550	2535	2535
5551	3301	3301
5552	7775	LOG6,
5553	4746	4746
5554	0771	0771
5555	7774	LOG7,
5556	2236	2236
5557	4304	4304
5560	7771	LOG8,
5561	4544	4544
5562	1735	1735
		/FLOAT C(45)
5563	0000	FLOA, 0
5564	7300	CLA CLL
5565	3046	DCA 46
5566	1374	TAD C13
5567	3044	DCA 44
5570	4407	CLFPNT
5571	7000	FNOR
5572	0000	FEXT
5573	5763	JMP I FLOA
5574	0013	C13, 0013 *4757
		/FIX C(FAC)
4757	0000	FIX, 0
4760	1044	TAD 44
4761	7540	SMA SZA
4762	5365	JMP .+3
4763	7200	CLA
4764	5375	JMP FIXEND
4765	1377	TAD M13
4766	3044	DCA 44
4767	1044	LOOP, TAD 44
4770	7700	SMA CLA
4771	5757	JMP I FIX
4772	4774	JMS I .+2
4773	5367	JMP LOOP
4774	6200	6200

/DIV1 IN INTERPRETER

4775 3045 FIXEND, DCA 45  
 4776 5757 JMP I FIX  
 4777 7765 M13, -13

A	5457	LOG2	5376
ACMINS	5114	LOG5	5547
ALFZ	5154	LOG6	5552
ALF1	5157	LOG7	5555
ALF2	5162	LOG8	5560
ARCALG	5131	LOOP	4767
ARCRTN	5226	L1	5354
ARTN	5200	L2	5357
B	5062	L3	5362
BETZ	5165	L4	5365
BET1	5170	L5	5370
BET2	5173	L6	5371
C	5065	L7	5372
CLFPNT	4407	L8	5373
CON1	5245	MOD	5410
C13	5574	M13	4777
C3	5536	NEGIT	5242
C5	5533	NEGT	5541
C7	5530	OK	5261
C9	5525	ONE	5076
D	5070	PALG	5455
EXIT	5235	PCHECK	5441
FCOS	5503	PI	5520
FEXP	5000	PIOT	5246
FIX	4757	PI2	5514
FIXEND	4775	PNTR	5543
FIXIT	5106	SIGN	5104
FIXR	5542	START	5274
FLAG1	5243	TEM	5374
FLAG2	5105	TEMP	5123
FLOA	5563	TWO	5101
FLOAT	5107	TWOPI	5515
FLOATP	5377	X	5115
FLOG	5251	XSQR	5120
FNEG	5110	XSQ2	5524
FSIN	5400	X1	5244
GETSGN	1045	X2	5523
GO	5223	ZER	5126
INVERT	5341	ZERGO	5350
LG2E	5073	ZERO	5375
LOGE2	5544		

/FLOATING OUTPUT PROGRAM  
 /IF(62)=0, THEN OUTPUT IN E FORMAT  
 /ELSE, C(62)=NUMBER OF DIGITS  
 /C(AC)=NUMBER OF PLACES TO RIGHT OF .  
 /IF C(AC)=0, THEN DON'T OUTPUT POINT  
 /SIGN AND . NOT COUNTED IN OUTPUT  
 /CONTENTS OF 15 LOST DURING OPERATION

\*7201

7201	4777	JMS I 7377 /ALTERATIONS FLOATING OUTPUT
7202	4217	JMS 7217
7203	1324	TAD 7324
7204	4776	JMS I 7376

\*7207

7207	7200	CLA
------	------	-----

\*7227

7227	3415	DCA I 15
7230	7000	NOP
7231	7000	NOP
7232	7000	NOP

\*7301

7301	3415	DCA I 15
------	------	----------

\*7305

7305	3415	DCA I 15
------	------	----------

\*7376

7376	5412	TGO
7377	5400	EDIT
5400	0000	EDIT,
5401	3352	0
5402	1062	DCA SAC
5403	7041	TAD 62
5404	3347	CMA IAC
5405	1357	DCA COUNT1
5406	3350	TAD M8
5407	1363	DCA COUNT2
5410	3015	TAD SAD1
5411	5600	DCA 15
5412	0000	JMP I EDIT
5413	3044	0
5414	1363	DCA 44
5415	3015	TAD SAD1
5416	1415	DCA 15
5417	4761	TAD I 15
5420	1062	JMS I OUT1
5421	7650	TAD 62
5422	5327	SNA CLA
5423	2212	JMP EFORM
5424	2212	ISZ TGO
5425	1044	ISZ TGO
5426	7510	TRYAGN,
5427	5300	TAD 44
5430	1352	SPA
5431	7041	JMP MINS
5432	1062	TAD SAC
		CMA IAC
		TAD 62

5433	7510	SPA	
5434	5266	JMP ERR	
5435	7450	SNA	
5436	5245	JMP G01	
5437	7041	CMA IAC	
5440	3351	DCA CNTR	
5441	1353	TAD SPCE	
5442	4321	JMS OUT	
5443	2351	ISZ CNTR	
5444	5241	JMP .-3	
5445	1044	G01,	TAD 44
5446	7041	CMA IAC	
5447	7450	SNA	
5450	5256	JMP G02	
5451	3351	DCA CNTR	
5452	4337	JMS GET	
5453	4321	JMS OUT	
5454	2351	ISZ CNTR	
5455	5252	JMP .-3	
5456	1352	G02,	TAD SAC
5457	7650	SNA CLA	
5460	5263	JMP .+3	
5461	1354	TAD PERIOD	
5462	4761	JMS I OUT1	
5463	4337	JMS GET	
5464	4321	JMS OUT	
5465	5263	JMP .-2	
5466	1352	ERR,	TAD SAC
5467	7700	SMA CLA	
5470	5274	JMP ERGO	
5471	1356	TAD CHX	
5472	4321	JMS OUT	
5473	5271	JMP .-2	
5474	7240	ERGO,	CLA CMA
5475	1352	TAD SAC	
5476	3352	DCA SAC	
5477	5225	JMP TRYAGN	
5500	7200	MINS,	CLA
5501	1062	TAD 62	
5502	7041	CMA IAC	
5503	1352	TAD SAC	
5504	7450	SNA	
5505	5313	JMP G03	
5506	3351	DCA CNTR	
5507	1353	TAD SPCE	
5510	4321	JMS OUT	
5511	2351	ISZ CNTR	
5512	5307	JMP .-3	
5513	1354	G03,	TAD PERIOD
5514	4761	JMS I OUT1	
5515	4321	JMS OUT	
5516	2044	ISZ 44	
5517	5315	JMP .-2	
5520	5263	JMP G02+5	
5521	0000	OUT,	0
5522	4762	JMS I OUT2	

5523	2347	ISZ COUNT1
5524	5721	JMP I OUT
5525	1355	TAD CHE
5526	5612	JMP I TGO
5527	4762	EFORM,
5530	1354	JMS I OUT2
5531	4761	TAD PERIOD
5532	1360	JMS I OUT1
5533	3347	TAD M7
5534	4337	DCA COUNT1
5535	4321	JMS GET
5536	5334	JMS OUT
		JMP .-2
5537	0000	GET,
5540	2350	ISZ COUNT2
5541	5345	JMP .+4
5542	7240	CLA CMA
5543	3350	DCA COUNT2
5544	5737	JMP I GET
5545	1415	TAD I 15
5546	5737	JMP I GET
5547	0000	COUNT1,
5550	0000	COUNT2,
5551	0000	CNTR,
5552	0000	SAC,
5553	7760	SPCE,
5554	0256	PERIOD,
5555	0305	CHE,
5556	0050	CHX,
5557	7770	M8,
5560	7771	M7,
5561	7344	OUT1,
5562	7352	OUT2,
5563	5563	SAD1,
		BUFFER,
BUFFER	5564	
CHE	5555	
CHX	5556	
CNTR	5551	
COUNT1	5547	
COUNT2	5550	
EDIT	5400	
EFORM	5527	
ERGO	5474	
ERR	5466	
GET	5537	
G01	5445	
G02	5456	
G03	5513	
MINNS	5500	
M7	5560	
M8	5557	
OUT	5521	
OUT1	5561	
OUT2	5562	
PERIOD	5554	
SAC	5552	
SAD1	5563	
SPCE	5553	
TGO	5412	
TRYAGN	5425	





**digital**  
**EQUIPMENT**  
**CORPORATION**  
**MAYNARD, MASSACHUSETTS**

PRINTED IN U.S.A.