

Micro Fiche Scan

Name of device(s) tested:

RA60/80/81,UDA50A,KDA50Q

Test description:

UDA50/KDA50 DECX MOD

MAINDEC Number or Package Identifier (after SEP 1977):

CXDUBD0

Fiche Document Part Number:

AH-S915D-MC

Fiche preparation date unknown, using copyright year:

1984


Image resolution:

1-bit black&white, compressed for minimal file size

COPYRIGHT (C) 1981-84 by d|i|g|i|t|a|l

B1

A



IDENTIFICATION

PRODUCT CODE: AC S914D MC
PRODUCT NAME: CXDUBDO UDA50A/KDA50 Q DECX MOD
PRODUCT DATE: 20-SEP-1984
MAINTAINER: ROGER OAKY
AUTHOR: JOHN MERTZ

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DEC	DIBOL	RSX
DEC/CMS	Edujystem	UNIBUS
DECnet	IAS	VAX
DECsystem-10	MASSBUS	VMS
DECSYSTEM-20	PDP	VT
DECUS	PDT	Digital Logo
DECwriter	RSTS	

.ENABL LC

.REM E

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
3.0	START UP
4.0	PASS DEFINITION
5.0	EXECUTION TIME
6.0	CONFIGURATION REQUIREMENTS
7.0	DEVICE/OPTION SETUP
8.0	MODULE OPERATION
9.0	OPERATION OPTIONS
10.0	PRINTOUTS
11.0	DUAL PORT OPERATION
12.0	GLOSSARY
13.0	BIBLIOGRAPHY

1.0 ABSTRACT

The exerciser will be similar to that of other disk subsystem exercisers. Writes will be performed to the disks followed by read and compare of the data read. The controller will do all error retrying. Errors will be reported on the console TTY.

All desired disk drives on the controller will be exercised simultaneously. If disk accessing is not required, then data written will go only as far as the controller's RAM memory.

If the results of the exerciser requires more information, two other PDP-11 diagnostic programs are available. They are:

CZUDHA0 - UDA50A/KDA50-Q and Disk Drive Diagnostic
CZUDIA0 - UDA50A/KDA50-Q Disk Drive Exerciser
CZUDKA0 UDA50A/KDA50 Q Disk Formatter.

2.0 REQUIREMENTS

Hardware for all cases:

One DEC/X11 module configures for one UDA50A or KDA50-Q

controller.

Hardware for disk accessing:

One controller with at least one drive is the minimum amount or one controller with four drives is the maximum amount.

Hardware for no disk accessing:

One controller is the only requirement.

Storage: DUBD requires

Decimal words -- 4096 MAX

3.0 START-UP

On the initial start, the program will clear bit1 of 'SR1' and type the following messages.

DUBDO PA:0060162 APC: 000674 PASS #00000

'IF YOU WISH TO DESTROY CUSTOMER DATA, SET BIT1 (NOT BIT0) IN SWITCH REGISTER 1(SR1) OF DUBJ? EQUAL TO 1.'

DUBDO PA:0060210 APC: 000722 PASS #00000
 '! OPERATING WITH NO DISK ACCESSING !'

This will occur regardless of the condition of SR1 (bit1) at configure time.

If the operator wishes to exercise the drive, SR1 (bit1) must be modified at location 16 of CXDUBDO module (see section 9). This can be accomplished by using the 'MOD' command supplied by the DECX11 run time system. Unless the program is reloaded or the operator modifies the location again, the contents of SR1 will remain the same on all subsequent starts.

On all subsequent starts, the condition of SR1 (bit1) will type to terminal in the following manner.

If bit1 of SR1 is equal to 0 (zero), the following warning will be typed.

DUBDO PA:0060210 APC: 000722 PASS #00000
 '! OPERATING WITH NO DISK ACCESSING !'

If bit1 of SR1 is equal to 1 (one), the following warning will be typed.

DUBDO PA:0060210 APC: 000722 PASS #00000
 '! CUSTOMER DATA WILL BE DESTROYED !'

<<<< NOTE >>>>

When this DEC/X11 module runs in diskless mode, its data rate exceeds all other devices. This may cause erroneous data lates from other devices.

4.0 PASS DEFINITION

One pass of the DUBD module consists of 512 iterations of the basic test sequence (write, read, data-check). The test sequence writes a user defined number of words (default is 256) words, reads 256 words, and data-compare same.

5.0 EXECUTION TIME

The default execution time of one pass of DUBD running alone on a PDP-11/44 under sequential disk accessing mode will be approximately 20 seconds. Under random accessing mode, the time is 40 seconds. For no disk accessing, the time is five seconds

6.0 CONFIGURATION REQUIREMENTS

Default Parameters:

DEVADR: 172150, VECTOR: 154, BR1: 4, DEVCNT: 1, SR1:
0, SR2: 0

REQUIRED PARAMETERS:

Additional controller module(s) configured must have different Unibus address(es) and vector(s).

7.0 DEVICE/OPTION SETUP

For disk mode, make certain that all units are powered up, write enabled, connected to a controller via the SDI and ready.

For diskless mode, make certain the controller is powered up.

8.0 MODULE OPERATION

TEST SEQUENCE DISK MODE:

- A. Setup device register addresses and module variables.
Set controller characteristic.
- B. Reset all units on line and drop all that are not.

- C. Get a unit address.
- D. Get a disk address and a fresh block of data.
- E. Do a write -- if errors, report.
- F. Do a read -- if errors, report.
- G. Do a data-check -- if errors, report and continue.
- H. Make unit available.
- I. Wait for available attention message.
- J. If end of pass, report and go to D.
- K. If end of testing unit, go to C; else go to D.

Blocks determined defective won't be replaced by the exerciser during this sequence. The exerciser makes full use of the controller which does revectoring on its own.

TEST SEQUENCE DISKLESS MODE:

- A. Get a fresh block of data.
- B. Do a write to controller RAM buffer -- if errors, report.
- C. Do a read from controller RAM buffer -- if errors, report.
- D. Do a data-check -- if errors, report and continue.
- E. If end of pass, report.
- F. Go to A.

9.0 OPERATION OPTIONS

One or more software switch registers can be used by the module program general purpose switches. These words are used to define or specify a unique device option or to point to a specific routine in the module. Any option must be specified by the operator before the module is run. Switch Register 1 has the following characteristics.

- SR1 Bit 1 set (1): Allow disk transfers.
 <<<< NOTE >>>> IF SET, CUSTOMER DATA WILL BE DESTROYED!
 reset (0): No disk transfers.
- SR1 Bit 2 set (1): Do not report errors as they occur.
 reset (0): Report errors as they occur.
- SR1 Bit 3 set (1): Do not print error summary at end of pass.
 reset (0): Print error summary at end of pass.
- SR1 Bit 9 set (1): Run Dual port mode (only valid if SR1 Bit 1 is set)
 reset (0): Do not run Dual port mode
- SR1 Bit 10 set (1): Select random block addressing. (only valid if SR1 Bit 1 is set)
 reset (0): Select sequential block

addressing.

SR1 Bit 11 set (1): Bypass data compare.
 reset (0): Do data compare.

Switch register 2 has the following characteristics.

SR2 Bits 0 to 5: Burst rate.

A burst rate to speed up NPR transfers by the controller can be used. This value is 6 bits maximum and set up in SR2 at configure time.

<<<< NOTE >>>>

The DVID1 mask reflects the number of units chosen for testing and which units on the system are to be tested. Example: If DVID1 contains a 1, only the first unit found on the system will be tested. A unit's order on the system is judged by its unit number. The lowest unit number zero (0). Unit 0 would be the first tested on the system.

If DVID1 contains a 10, the fourth unit on the system will be tested. If the first two units are chosen, DVID1 is 3. Four consecutive units means DVID1 is 17. Six units, DVID1 is 77.

If there is not a unit corresponding to the DVID1 bit setting, the bit set in DVID1 gets cleared. The exerciser will readjust the mask and drop the nonexistent units if more units are chosen than actually are present. The module is dropped if all DVID1 bits are cleared.

If the number of units chosen is less than the actual number of units present, only the desired units will be used during the exercise.

<<<< ANOTHER NOTE >>>>

Make sure all subunit drives are accounted for. Destroying customer data is not desirable.

<<<< ONE MORE NOTE >>>>

If SR1 Bit 3 is reset, a summary status is printed every 15 passes. This status is formatted as follows:

DUBDO PA: 00060470 ACP: 001210 PASS #00000

SOFT ERROR COUNT #00000 *** HARD ERROR COUNT #00000
 CHECK DATA ERROR COUNT #00000

A. Most printouts have the standard formats described in the DEC/X11 document.

B. Non-standard printouts include error messages which dump the following:

- 1) Summary status
- 2) Flags and endcode
- 3) Unit number
- 4) Byte count
- 5) Hi 16-bit LBN value
- 6) Lo 16-bit LBN value
- 7) Extended address
- 8) Physical address

All values except for PASS, RUNTIME and ERRCNT are printed in octal. PASS, RUNTIME and ERRCNT are printed in decimal.
 Example:

DUBD0 PA: 00064116 APC: 004630 PASS: 00000 ERRCNT: 00001
 CSRA: 172150 CSRC: 000000 ASTAT: 000006 ERRTYP: 000006
 RUNTIME: 000:00:22

DUBD0 PA: 00064052 APC: 004564 PASS: 00000

STATUS ENDCOD UNITNU BYTECO HI LBN LO LBN EXTADR PHYADR
 000006 000242 000005 000000 000003 116321 000001 062100

STATUS - response of the command sent to the controller. This is contained in the last five bits of the word. Here is a list of status codes.

- 0 - success
- 1 - invalid command
- 2 - command aborted
- 3 - unit offline
- 4 - unit available
- 5 - media error
- 6 - write protected
- 7 - compare error
- 10 - data error
- 11 - host buffer access error
- 12 - controller error
- 13 - drive error

ENDCOD ending code of the command sent. This shows what command was sent to the UDA. Here is a list of all possible endcodes this module uses.

- 100 - AVAILABLE ATTENTION MESSAGE (not a command but a message sent to the host from the UDA)
- 200 - INVALID COMMAND
- 203 - GET UNIT STATUS
- 204 - SET CONTROLLER CHARACTERISTICS
- 210 - AVAILABLE
- 211 - ONLINE

230 - MAINTENANCE READ
 231 - MAINTENANCE WRITE
 241 - READ
 242 - WRITE

UNITNU - unit number of the drive that is being accessed.
 This is not relevant if the user is running diskless mode.

BYTECO - size of the buffer in bytes.

HI LBN - high logical block number (upper 16 bits) which tells the user where on the disk the data is going. This is only valid for disk mode.

LO LBN - low logical block number (lower 16 bits).

EXTADR - extended address of the read/write buffer.

PHYADR - physical address of the read/write buffer.

C. If the controller failed to pass its internal diagnostic, one of the following messages will be printed.

If the diagnostic found a fault:

DUBDO PA: 00062052 APC: 002564 PASS: 00000
 CONTROLLER INIT ERROR, FOUND BY DIAGNOSTIC
 SA REGISTER = xxxxxx IN STEP yyyy
 ADDR = zzzzzz

If a step bit was not set as expected during the initialization sequence of the controller:

DUBDO PA: 00062152 APC: 002664 PASS: 00000
 CONTROLLER INIT ERROR, STEP NOT SET
 SA REGISTER = xxxxxx IN STEP yyyy
 ADDR = zzzzzz

If data passed back from the controller was not equal to the expected value:

DUBDO PA: 00062252 APC: 002764 PASS: 00000
 CONTROLLER INIT ERROR, EXPECTED DATA WAS INCORRECT
 SA REGISTER = xxxxxx IN STEP yyyy
 ADDR = zzzzzz

Where xxxxxx can have any of the following values and meanings:

104000 - Fatal sequencer error
 104040 - D processor ALU error
 104041 - D proc ROM parity error
 105102 - D proc with no Board #2 or RAM parity error
 105105 - D proc RAM buffer error
 105152 - D proc SDI error
 105153 - D proc write mode wrap SERDES error

105154 - D proc read mode SERDES, RSGEN, and ECC error
 106040 - U proc ALU error
 106041 - U proc Control Register error
 106042 - U proc DFAIL/ROM parity error/Board #1 test count is wrong
 106047 - U proc Constant ROM error with D proc running SDI test
 106055 - Unexpected trap found, aborted diagnostic
 106071 - U proc ROM error
 106072 - U proc ROM parity error
 106200 - Step 1 data error (MSB not set)
 107103 - U proc RAM parity error
 107107 - U proc RAM buffer error
 107115 - Board #2 test count was wrong
 112300 - Step 2 error
 122240 - NPR error
 122300 - Step 3 error
 142300 - Step 4 error

Where yyyyy is the step in which the error was found.

Where zzzzz is the address of the UDA.

If the maximum number of retries has been exceeded, the following message will be printed.

DUBDO PA: 00061414 APC:002126 PASS #00000

RETRY COUNT EXCEEDED, ABORT

This means the controller did not successfully complete the initialization in four passes. The module is then dropped.

D. If the UDA did not successfully clear the ring buffer in the host area, the following message will be printed.

DUBDO PA: 00061414 APC:002126 PASS #00000

RING AREA NOT CLEARED

This is a fatal error. It means that the controller did not access host memory that the controller would use to communicate with the host. The module is then dropped.

E. If the SAregister displays a non-zero value after the initialization sequence is done, the following message will be printed.

DUBDO PA: 00064252 APC: 004764 PASS: 00000

SA REGISTER IS NOT ZERO, = xxxxxx
 CONTROLLER IS GOING THROUGH INITIALIZATION

Where xxxxxx can have the following values and meanings.

004400 - controller has been initied by either a bus init or by writing into the IP register.
 100001 - bus envelope/packet read error (parity or timeout)

100002 - bus envelopepacket write error (parity or timeout)
 100003 - controller ROM and RAM parity error
 100004 - controller RAM parity error
 100005 - controller ROM parity error
 100006 - bus ring read error
 100007 - bus ring write error
 100010 - bus interrupt master failure
 100011 - Host access timeout error
 100012 - Host exceeded credit limit
 100013 - controller SDI hardware fatal error
 100014 - DM XFC fatal error
 100015 - Hardware timeout of instruction loop
 100016 - Invalid virtual circuit identifier
 100017 - Interrupt write error on bus

E. If a drive is dropped by the exerciser, one of the following messages will be printed.

If the drive had an error it could not handle properly after an iteration, the following message will be printed:

DUBD0 PA: 00063012 APC: 003524 PASS #00000

DRIVE 00000 DROPPED.
 DEVICE ID BIT = 000001
 ERRORS CAUSED DRIVE TO BE DROPPED

If the drive was not found by the exerciser, the following message will be printed:

DUBD0 PA: 00063012 APC: 003524 PASS #00000

DRIVE 00000 DROPPED.
 DEVICE ID BIT = 000001
 UNIT WAS NOT FOUND BY THE EXERCISER

If there were more device count bits set than the actual number of drives found, the following message will be printed:

DUBD0 PA: 00063012 APC: 003524 PASS #00000

DRIVE 00000 DROPPED.
 DEVICE ID BIT = 000001
 DVIC: BIT SET HIGHER THAN ACTUAL # OF DRIVES FOUND

Solution: try a lesser number of units in DVID1 (loc 14)

11.0 DUAL PORT OPERATION

To run a dual port operation, set bit9 of SR1. The exerciser will check the unit to see if it is offline or available.

The controller will retain control of a unit until the MSCP Available command is entered by the host. During this time, the other controller is not allowed access to the unit through the other port between the write and read. The other controller senses when the unit becomes available and takes it. The MSCP Available command is only executed if SR1 bit 9 and SR1 bit 1 are set. This allows dual porting and disk accessing respectively.

DEC/X11 will only dual port a drive with another DEC/X11 exerciser.

12.0 GLOSSARY

DUBD follows the module name format described in the DEC/X11 Programmer's Guide.

- DU-- Identifies the hardware and thus the module.
- B- Distiguishes between two or more different modules for the same generic device. The sequence A, B, C, ETC. must be used for each additional example.
- D Specifies the module revision.

IOMODX is a type of module in an extended input/output mode. These modules are interrupt driven and are capable of input/output operation. Some added capabilities provided include:

- a Use of monitor supplied write buffers.
- a Ability to change the size of the write buffers.
- a Access to the monitor's check data utility.
- a Conversion routines to get 18 bit addresses from 16 bit addresses.

13.0 BIBLIOGRAPHY

- CXQUAAO 'DEC/X11 USER'S MANUAL' Sept 1978
- CXQAFDO 'DEC/X11 PROGRAMMERS'S GUIDE' Sept 1978
- CXQUBAO 'DEC/X11 CROSS-REFERENCE MANUAL' Sept 1978

2
3

.DSABL LC

```

1
3 000000
000000

000000 104 125 102
000003 104 040
000005 000
000006 172150
000010 000154
000012 200
000013 000
000014 000001
000016 000000
000020 000000
000022 000000
000024 000000

000026 150000
000030 000660
000032 000252
000034 000000
000036 001000
000040 000000
000042 000000
000044 000000
000046 000000
000050 000000
000052 000000
000054 000000
000056 000000
000060 000000
000062 000000
000064 000000
000066 000000
000070 000000
000072 000000
000074 000000
000076 000000
000100 000000
000102
000102 000000
000104
000104 000000
000106
000106 000000
000110 000000
000112 001036
000114 000000
000116 000000
000120 000000
000122 000104

.SBTTL MODULE HEADER BLOCK
IOMODX <DUBD > ,172150,154,4,0,0,1000,104,RBUF,256.,256.
MODULE 150000,DUBD ,172150,154,4,0,0,1000,104,RBUF,256.,256.
.TITLE DUBD DEC/X11 SYSTEM EXERCISER MODULE
; DOXCOM VERSION 6 23-MAY-78
.LIST BIN
;*****
BEGIN:
MODNAM: .ASCII /DUBD / ;MODULE NAME.

XFLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
ADDR: 172150*0 ;1ST DEVICE ADDR.
VECTOR: 154*0 ;1ST DEVICE VECTOR.
BR1: .BYTE PRTY4*0 ;1ST BR LEVEL.
BR2: .BYTE PRTY0*0 ;2ND BR LEVEL.
DVID1: 0*1 ;DEVICE INDICATOR 1.
SR1: OPEN ;SWITCH REGISTER 1
SR2: OPEN ;SWITCH REGISTER 2
SR3: OPEN ;SWITCH REGISTER 3
SR4: OPEN ;SWITCH REGISTER 4
;*****
STAT: 150000 ;STATUS WORD.
INIT: START ;MODULE START ADDR.
SPOINT: MODSP ;MODULE STACK POINTER.
PASCNT: 0 ;PASS COUNTER.
ICONT: 1000 ;# OF ITERATIONS PER PASS=1000
ICOUNT: 0 ;LOC TO COUNT ITERATIONS
SOFCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS
HRDCNT: 0 ;LOC TO SAVE TOTAL HARD ERRORS
SOFPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS
HRDPAS: 0 ;LOC TO SAVE HARD ERRORS PER PASS
SYSCNT: 0 ;# OF SYS ERRORS ACCUMULATED
RANNUM: 0 ;HOLDS RANDOM # WHEN RAND MACRO IS CALLED
CONFIG: ;RESERVED FOR MONITOR USE
RES1: 0 ;RESERVED FOR MONITOR USE
RES2: 0 ;RESERVED FOR MONITOR USE
SVR0: OPEN ;LOC TO SAVE R0.
SVR1: OPEN ;LOC TO SAVE R1.
SVR2: OPEN ;LOC TO SAVE R2.
SVR3: OPEN ;LOC TO SAVE R3.
SVR4: OPEN ;LOC TO SAVE R4.
SVR5: OPEN ;LOC TO SAVE R5.
SVR6: OPEN ;LOC TO SAVE R6.
CSRA: OPEN ;ADDR OF CURRENT CSR.
SBADR: ;ADDR OF GOOD DATA, OR
ACSR: OPEN ;CONTENTS OF CSR.
WASADR: ;ADDR OF BAD DATA, OR
ASTAT: OPEN ;STATUS REG CONTENTS.
ERRTYP: ;TYPE OF ERROR
ASB: OPEN ;EXPECTED DATA.
AWAS: OPEN ;ACTUAL DATA.
RSTRAT: RESTRAT ;RESTART ADDRESS AFTER END OF PASS
WOTO: OPEN ;WORDS TO MEMORY PER ITERATION
WOTP: OPEN ;WORDS FROM MEMORY PER ITERATION
INTP: OPEN ;# OF INTERRUPTS PER ITERATION
IDNUM: 104 ;MODULE IDENTIFICATION NUMBER=104

```

000124	007126	RBUFVA: RBUF	;READ BUFFER VIRTUAL ADDRESS
000126	000000	RBUFPA: OPEN	;READ BUFFER PHYSICAL ADDRESS
000130	000000	RBUFEA: OPEN	;READ BUFFER EA BITS
000132	000400	RBUFSZ: 256.	;SIZE OF THE READ BUFFER
000134	000000	WBUFPA: OPEN	;WRITE BUFFER PHYSICAL ADDRESS
000136	000000	WBUFEA: OPEN	;WRITE BUFFER EA BITS
000140	000400	WBUFREQ: 256.	;WRITE BUFFER SIZE REQUESTED
000142	000000	WBUFSZ: OPEN	;WRITE BUFFER SIZE AVAILABLE
000144	000000	CDERCT: OPEN	;CDATA/DATCK ERROR COUNT
000146	000000	CDWDCT: OPEN	;CDATA/DATCK WORD COUNT
000150	000000	FREE: OPEN	;RESERVED FOR FUTURE USE
	000040	.REPT SPSIZ	;MODULE STACK STARTS HERE.
		.NLIST	
		.WORD 0	
		.LIST	
		.ENDR	
000252		MODSP:	
4		;.....	
5		;.....	
6		.SBTTL MODULE STORAGE AREA	
7		VERSION 1.0 FOR RELEASE	
8		VERSION 1.1 NO LONGER TEST AFTER STEP 4	
9		NO LONGER WAIT FOR INTERRUPT AFTER SENDING MSCP AVAILABLE COMMAND	
10		VERSION 2.0 USE BIT 9 IN SR1 FOR DUAL PORTING. (DON'T SEND MSCP AVAILABLE	
11		COMMAND IF WE WANT JUST SEQUENTIAL OR RANDOM ACCESS MODE --	
12		IN OTHER WORDS, ONLY SEND ONLINE COMMAND ONCE DURING PASS UNLESS	
13		DUAL PORT MODE)	
14		VERSION 3.0 KDA50-Q SUPPORT ADDED	
15	000002	SR.XFR = BIT01 ;NO DISK TRANSFER 0 = NO DISK TRANSFER, 1 = DO DISK TRANSFER	
16	000004	SR.REP = BIT02 ;REPORT ERROR AS THEY OCCUR 0 = REPORT, 1 = DON'T REPORT	
17	000010	SR.SUM = BIT03 ;REPORT ERRORS ON END OF PASS 0 = REPORT, 1 = DON'T REPORT	
18	001000	SR.DUA = BIT09 ;DUAL PORT 0 = NO DUAL PORT, 1 = DUAL PORT	
19	002000	SR.SEQ = BIT10 ;RANDOM (NOT SEQUENTIAL) DISK ADDRESSING 0 = SEQUENTIAL, 1 = RANDOM	
20	004000	SR.CMP = BIT11 ;NO DATA COMPARE 0 = DO DATA COMPARE, 1 = DON'T DO DATA COMPARE	
21			
22		;IPREG: .WORD 0 ; CONTROLLER POLLING REG	
23	000252 000000	SAREG: .WORD 0 ; CONTROLLER STATUS REG	
24			
25	000254 000000	CINTR: .WORD 0 ;COMMAND INTERRUPT INDICATOR	
26	000256 000000	RINTR: .WORD 0 ;RESPONCE INTERRUPT INDICATOR	
27			
28	000260	RSPONC: .BLKW 2. ;MESSAGE RING	
29	000264	COMMND: .BLKW 2. ;COMMAND RING	
30			
31	000270 000000	CMDREF: .WORD 0 ;COMMAND REFERENCE NUMBER	
32			
33	000272 000000	RSPLN: .WORD 0 ;RESPONCE PACKET LENGTH	
34	000274 000000	RSPVIR: .WORD 0 ;RESPONCE PACKET VIRTUAL CIRCUIT	
35	000276	RSPACK: .BLKW 24. ;RESPONCE PACKET	
36			
37	000356 000000	CMPLN: .WORD 0 ;COMMAND PACKET LENGTH	
38	000360 000000	CMPVIR: .WORD 0 ;COMMAND PACKET VIRTUAL CIRCUIT	
39	000362	CMPPACK: .BLKW 24. ;COMMAND PACKET	
40			
41	000442 000264	VA: .WORD COMMND ;GENERIC VIRTUAL ADDRESS FOR GETPA	
42	000444 000000	PA: .WORD OPEN ;GENERIC PHYSICAL ADDRESS	

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20 Sep 84 10:17 Page 4 2
 MODULE STORAGE AREA

43	000446	000000	EA:	.WORD	OPEN		;GENERIC EXTENDED ADDRESS
44							
45	000450	000000	RBFFEA:	.WORD	0		;READ BUFFER EXTENDED ADDRESS SAVE AREA
46	000452	000000	WBFFEA:	.WORD	0		;WRITE BUFFER EXTENDED ADDRESS SAVE AREA
47							
48	000454	000000	NUM:	.WORD	0		;ADDRESS USED IN OTOA
49	000456	000000	OLDPA:	.WORD	0		;THE OLD PHYSICAL ADDRESS
50	000460	000000	OLDEA:	.WORD	0		;THE OLD EXTENDED ADDRESS TO CHECK IF ; CONTROLLER WILL BE REINITED
51							
52							
53		000017	PRTNUM = 15.				;PRINT MESSAGE EVERY 15TH TIME
54	000462	000017	PRNMSG:	.WORD	PRTNUM		;PRINT WORD SAVES THE VALUE TO CHECK FOR WHEN ; THE NEXT TIME AN END OF PASS MESSAGE IS WRITTEN
55							;TIMER VALUE TO WAIT 2-3 SECONDS AFTER DAP COMMAND
56		002260	TIMER = 1200.				
57							
58	000464	177777	EXPAV:	.WORD	177777		;EXPECTING AN AVAILABLE ATTENTION MESSAGE = 0 ;NOT EXPECTING AN AVAILABLE ATTENTION MESSAGE = 177777
59							
60							
61	000466		ADR1:	.BLKB	6		
62	000474	000		.BYTE	0		
63	000475		ADR2:	.BLKB	6		
64	000503	000		.BYTE	0		
65	000504		ADR3:	.BLKB	6		
66	000512	000		.BYTE	0		
67	000513		ADR4:	.BLKB	6		
68	000521	000		.BYTE	0		
69	000522		ADR5:	.BLKB	6		
70	000530	00^		.BYTE	0		
71	000531		ADR6:	.BLKB	6		
72	000537	000		.BYTE	0		
73	000540		ADR7:	.BLKB	6		
74	000546	000		.BYTE	0		
75	000547		ADR8:	.BLKB	6		
76	000555	000		.BYTE	0		
77				.EVEN			

```

1      .SBTTL MORE MODULE STORAGE
2      ;
3      ;DO NOT CHANGE THE ORDER OF THE NEXT 4 LOCATIONS
4      ;NEEDED FOR MAP 22 ROUTINE
5 000556 000000 PA18: .WORD 0
6 000560 000000 XMEM: .WORD 0
7 000562 000000 PA22: .WORD 0
8 000564 000000 EA22: .WORD 0
9
10 000566 000000 SECL: .WORD 0 ;CURRENT SECTOR LO ORDER ADDRESS
11 000570 000000 SECH: .WORD 0 ;CURRENT SECTOR HI ORDER ADDRESS
12
13 000572 000000 UNSZL: .WORD 0 ;UNIT SIZE LO ORDER LIMIT FROM ONLINE CMND
14 000574 000000 UNSZH: .WORD 0 ;UNIT SIZE HI ORDER LIMIT
15
16 000576 003300 LIMIT: .WORD 3300 ;4K - 1200 = MOST WORDS MAITW CAN TAKE
17
18 000600 000001 DVICE: .WORD 1 ;DEVICE TO TEST
19 000602 000000 UNITNO: .WORD 0 ;UNIT NUMBER
20 000604 000000 TRY: .WORD 0 ;NUMBER OF TRIES
21 000606 000001 PORTID: .WORD 1 ;BIT POSITION SELECTS THE PORT
22 000610 000000 UNITFL: .WORD 0 ;SAVE UNIT FLAGS
23 000612 000000 WORK: .WORD 0 ;TEMPORARY WORK AREA
24
25          005670 TIMOUT = 3000. ;TIME OUT GADGE
26          000004 RLIM = 4 ;RETRY LIMIT
27
28 000614 000000 000001 TABLEW: .WORD 0,1 ;TABLE ENTRY UNITNO,PORTID
29 000620 177777 177777 .WORD -1,-1 ;CURRENT LAST TABLE ENTRY
30 000624 .BLKW 12. ;REST OF TABLE
31 000654 177777 177777 TEND: .WORD -1,-1 ;END MARKER
32
33          ;S: .WORD 0,0,0,0,0,0,0,0 ;FOR HARD AND SOFT ERRORS
34          ; .WORD 177777
35
36          ;TABLE: .WORD S ;EACH ENTRY OF THE TABLE POINTS TO
37          ; .WORD S+2 ;THE CORRESPONDING ENTRY OF S.
38          ; .WORD S+4 ;THIS IS USED IN HRDR & SOFER
39          ; .WORD S+6
40          ; .WORD S+10
41          ; .WORD S+12
42          ; .WORD S+14
43          ; .WORD S+16
44          ; .WORD 177777

```

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20 Sep 84 10:17 Page 6
 MODULE PRIVATE DATA

```

1          .SBTTL  MODULE PRIVATE DATA
2
3          000001  BIT00 = 1
4          000002  BIT01 = 2
5          000004  BIT02 = 4
6          000010  BIT03 = 10
7          000020  BIT04 = 20
8          000040  BIT05 = 40
9          000100  BIT06 = 100
10         000200  BIT07 = 200
11         000400  BIT08 = 400
12         001000  BIT09 = 1000
13         002000  BIT10 = 2000
14         004000  BIT11 = 4000
15         010000  BIT12 = 10000
16         020000  BIT13 = 20000
17         040000  BIT14 = 40000
18         100000  BIT15 = 100000
19
20         ;
21         ;      ERROR BITS
22         ;
23         000000  ERR.0 = 0      ;NOT DEFINED
24         000001  ERR.1 = 1      ;DATA ERROR
25         000003  ERR.3 = 3      ;CONTROLLER NOT READY
26         000006  ERR.6 = 6      ;DRIVE NOT READY, OFF LINE OR NON EXESTENT
27         000032  ERR.32 = 32    ;NPR ERROR
28

```

```

1          .SBTTL CONTROLLER BIT DEFINITIONS
2
3          ; SA REGISTER UNIVERSAL READ BITS
4
5          004000      SA.S1= 004000      ;STEP 1 STATUS BIT
6          010000      SA.S2= 010000      ;STEP 2 STATUS BIT
7          020000      SA.S3= 020000      ;STEP 3 STATUS BIT
8          040000      SA.S4= 040000      ;STEP 4 STATUS BIT
9          100000      SA.ERR= 100000     ;ERROR INDICATOR
10
11         ; SA REGISTER ERROR STATUS BITS
12
13         003777      SA.ERC= 003777     ;ERROR CODE
14
15         ; SA REGISTER STEP ONE READ BITS
16
17         ;;SA.CTP=    003400            ;CONTROLLER TYPE
18         002000      SA.NSI= 002000     ;NON SETTABLE INTERRUPT
19         001000      SA.Q22= 001000    ;22 BIT ADDRESS BUS
20         000400      SA.DIA= 000400    ;DIAG BIT IN SA REGISTER
21         000100      SA.MAP= 000100    ;MAPPING BIT
22         000040      SA.SM = 000040    ;SPECIAL MODE BIT FOR KDA50-Q
23
24         ; SA REGISTER STEP ONE WRITE BITS
25
26         000177      SA.VEC= 000177     ; INTERRUPT VECTOR (DIVIDED BY 4)
27         000200      SA.INT= 000200     ; INTERRUPT ENABLE DURING INITIALIZATION
28         003400      SA.RSP= 003400     ; MESSAGE RING LENGTH
29         034000      SA.CMD= 034000     ; COMMAND RING LENGTH
30
31         ; SA REGISTER STEP TWO READ BITS
32
33         000177      SA.VCE= 000177     ;INTERRUPT VECTOR ECHO
34         000200      SA.INE= 000200     ;INTERRUPT ENABLE ECHO
35
36         ; SA REGISTER STEP TWO WRITE BITS
37
38
39         000001      SA.PRG= 000001     ;LOW ORDER MESSAGE RING BYTE ADDRESS
40
41         ; SA REGISTER STEP THREE READ BITS
42
43         000017      SA.RSE= 000017     ;RESPONCE RING LENGTH ECHO
44         000360      SA.CME= 000360     ;COMMAND RING LENGTH ECHO
45
46         ; SA REGISTER STEP THREE WRITE BITS
47
48
49         040000      SA.LFC= 040000     ;HIGH ORDER MESSAGE RING BYTE ADDRESS
50
51         ; SA REGISTER STEP FOUR READ BITS
52
53         000377      SA.MCV= 000377     ; CONTROLLER MICROCODE VERSION
54
55         ; SA REGISTER STEP FOUR WRITE BITS
56
57         000001      SA.GO= BIT0        ;GO BIT TO START CONTROLLER FIRMWARE

```

```

1          .SBTTL COMMAND/MESSAGE DESCRIPTOR BIT DEFINITIONS
2
3          100000          RG.OWN= BIT15          ;SET WHEN CONTROLLER OWNS RING
4          040000          RG.FLG= BIT14          ;FLAG BIT
5
6          ;OFFSETS INTO HOST COMMUNICATIONS AREA WITH ONE DESCRIPTOR TO EACH RING
7
8          000010          HC.SIZ= 8.             ;SIZE OF HOST COMM AREA IN BYTES
9          000060          PKTSIZ= 48.           ;SIZE OF PACKETS IN BYTES
10
11         000000          HC.RES= 0.             ;RESPONCE RING START
12         000002          HC.RCT= 2.             ;RESPONCE RING CONTROL WORD
13         000004          HC.CMD= 4.             ;COMMAND RING START
14         000006          HC.CCT= 6.             ;CONTROL RING CONTROL WORD
15         000276          HC.RPK= RSPACK         ;START OF RESPONCE PACKET BUFFER
16         000356          HC.CPK= HC.RPK+PKTSIZ ;START OF COMMAND PACKET BUFFER

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29

.SBTTL COMMAND PACKET OPCODES

000001	OP.ABO= 01	;ABORT COMMAND
000020	OP.ACC= 20	;ACCESS COMMAND
000010	OP.AVL= 10	;AVAILABLE COMMAND
000021	OP.CCD= 21	;COMPARE CONTROLLER DATA COMMAND
000040	OP.CMP= 40	;COMPARE HOST DATA COMMAND
000013	OP.DAP= 13	;DETERMINE ACCESS PATHS COMMAND
000022	OP.ERS= 22	;ERASE COMMAND
000023	OP.FLU= 23	;FLUSH COMMAND
000002	OP.GCS= 02	;GET COMMAND STATUS COMMAND
000003	OP.GUS= 03	;GET UNIT STATUS COMMAND
000011	OP.ONL= 11	;ONLINE COMMAND
000041	OP.RD= 41	;READ COMMAND
000024	OP.RPL= 24	;REPLACE COMMAND
000004	OP.SCC= 04	;SET CONTROLLER CHARACTERISTICS COMMAND
000012	OP.SUC= 12	;SET UNIT CHARACTERISTICS COMMAND
000042	OP.WR= 42	;WRITE COMMAND
000030	OP.MRD= 30	;MAINTENANCE READ COMMAND
000031	OP.MWR= 31	;MAINTENANCE WRITE COMMAND
000200	OP.END= 200	;END PACKET FLAG
000100	OP.AVA= 100	;AVAILABLE ATTENTION MESSAGE
000101	OP.ERL= 101	;ERROR LOG ATTENTION MESSAGE
000102	OP.SMC= 102	;SHADOW COPY COMPLETE ATTENTION MESSAGE
000102	OP.ACP= 102	;ACCESS PATH ATTENTION MESSAGE

;NOTE: END PACKET OPCODES (ALSO CALLED ENDCODES) ARE FORMED BY ADDING THE END
;PACKET FLAG TO THE COMMAND OPCODE. THE UNKNOWN COMMAND END PACKET CONTAINS
;JUST THE END PACKET FLAG IN ITS OPCODE FIELD.

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page 10
 COMMAND MODIFIERS

1		.SBTTL COMMAND MODIFIERS	
2			
3	040000	MD.CMP= 040000	;COMPARE
4	100000	MD.EXP= 100000	;EXPRESS REQUEST
5	010000	MD.ERR= 010000	;FORCE ERROR
6	004000	MD.SCH= 004000	;SUPPRESS CACHING (HIGH SPEED)
7	002000	MD.SCL= 002000	;SUPPRESS CACHING (LOW SPEED)
8	001000	MD.SEC= 001000	;SUPPRESS ERROR CORRECTION
9	000400	MD.SER= 000400	;SUPPRESS ERROR RECOVERY
10	000200	MD.SSH= 000200	;SUPPRESS SHADOWING
11	000100	MD.WBN= 000100	;WRITE-BACK (NON-VOLATILE)
12	000040	MD.WBV= 000040	;WRITE BACK (VOLATILE)
13	000001	MD.SPD= 000001	;SPIN-DOWN
14	000001	MD.FEU= 000001	;FLUSH ENTIRE UNIT
15	000002	MD.VOL= 000002	;VOLATILE ONLY
16	000001	MD.NXU= 000001	;NEXT UNIT
17			
18		.SBTTL END PACKET FLAGS	
19			
20	000200	EF.BBR= 000200	;BAD BLOCK REPORTED
21	000100	EF.BBU= 000100	;BAD BLOCK UNREPORTED
22	000040	EF.LOG= 000040	;ERROR LOG GENERATED
23	000020	EF.SEX= 000020	;SERIOUS EXCEPTION
24			
25		.SBTTL UNIT FLAGS	
26			
27			
28	000001	UF.CMR= 000001	;COMPARE READS
29	000002	UF.CMW= 000002	;COMPARE WRITES
30	010000	UF.RPL= 010000	;HOST INITIATED BAD BLOCK REPLACEMENT
31	040000	UF.INA= 040000	;INACTIVE SHADOW SET UNIT
32	000200	UF.RMV= 000200	;REMOVEABLE MEDIA
33	004000	UF.SCH= 004000	;SUPPRESS CACHING (HIGH SPEED)
34	002000	UF.SCL= 002000	;SUPPRESS CACHING (LOW SPEED)
35	000040	UF.WBN= 000040	;WRITE-BACK (NON-VOLATILE)
36	020000	UF.WPH= 020000	;WRITE PROTECT(HARDWARE)
37	010000	UF.WPS= 010000	;WRITE PROTECT(SOFTWARE OR VOLUME)
38	000004	UF.576= 000004	;576 BYTE SECTORS

```

1          .SBTTL CONTROLLER FLAGS
2
3          000200      CF.AVL= 000200      ;ENABLE AVAILABLE ATTENTION MESSAGES
4          000100      CF.MSC= 000100      ;ENABLE MISCELLANEOUS ERROR LOG MESSAGES
5          000040      CF.OTH= 000040      ;ENABLE OTHER HOST'S ERROR LOG MESSAGES
6          000020      CF.THS= 000020      ;ENABLE THIS HOST'S ERROR LOG MESSAGES
7          000002      CF.SH0= 000002      ;SHADOWING
8          000001      CF.576= 000001      ;576 BYTE SECTORS
9
10         .SBTTL COMMAND PACKET OFFSETS
11
12         ;          GENERIC COMMAND PACKET OFFSETS:
13         000000      P.CRF= 0.           ;COMMAND REFERENCE NUMBER
14         000004      P.UNIT= 4.          ;UNIT NUMBER
15         000010      P.OPCD= 8.          ;OPCODE
16         000012      P.MOD= 10.         ;MODIFIERS
17         000014      P.BCNT= 12.        ;BYTE COUNT
18         000020      P.BUFF= 16.        ;BUFFER DESCRIPTOR
19         000020      P.ADPA= 16.        ;BUFFER'S PHYSICAL ADDRESS (P.BUFF)
20         000022      P.ADEA= 18.        ;BUFFER'S EXTENDED ADDRESS (P.BUFF*2)
21         000034      P.LBN= 28.         ;LOGICAL BLOCK NUMBER
22         000040      P.SFTW= 32.        ;SOFTWARE WORDS
23
24         ;          ABORT AND GET COMMAND STATUS COMMAND PACKET OFFSETS:
25         000014      P.OTRF= 12.        ;OUTSTANDING REFERENCE NUMBER
26
27         ;          ONLINE AND SET UNIT CHARACTERISTICS COMMAND PACKET OFFSETS:
28         000016      P.UNFL= 14.        ;UNIT FLAGS
29         000020      P.HSTI= 16.        ;HOST IDENTIFIER
30         000024      P.UNTI= 20.        ;UNIT IDENTIFIER
31         000034      P.ELGF= 28.        ;ERROR LOG FLAGS
32         000040      P.SHUN= 32.        ;SHADOW UNIT
33         000042      P.CPSP= 34.        ;COPY SPEED
34
35         ;          REPLACE COMMAND PACKET OFFSETS:
36         000014      P.RBN= 12.         ;REPLACEMENT BLOCK NUMBER
37
38         ;          SET CONTROLLER CHARACTERISTICS COMMAND PACKET OFFSETS:
39         000014      P.VRSN= 12.        ;MSCP VERSION
40         000016      P.CNTF= 14.        ;CONTROLLER FLAGS
41         000020      P.HTMO= 16.        ;HOST TIMEOUT
42         000022      P.USEF= 18.        ;USE FRACTION
43         000024      P.TIME= 20.        ;QUAD-WORD TIME AND DATE
44
45         ;          MAINTENANCE READ AND MAINTENANCE WRITE COMMAND PACKET OFFSETS:
46         000034      P.RGID= 28.        ;REGION ID
47         000040      P.RGOF= 32.        ;REGION OFFSET

```


DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20 Sep 84 10:17 Page 12
 END PACKET OFFSETS

```

1          .SBTTL END PACKET OFFSETS
2
3          ;
4          000000      P.CRF= 0.          ;COMMAND REFERENCE NUMBER
5          000004      P.UNIT= 4.         ;UNIT NUMBER
6          000010      P.OPCD= 8.         ;OPCODE (ALSO CALLED ENDCODE)
7          000011      P.FLGS= 9.         ;END PACKET FLAGS
8          000012      P.STS= 10.        ;MODIFIERS
9          000014      P.BCNT= 12.        ;BYTE COUNT
10         000034      P.FBBK= 28.        ;FIRST BAD BLOCK
11         000040      P.SFTW= 32.        ;SOFTWARE WORDS
12
13         ;
14         000014      P.OTRF= 12.        ;OUTSTANDING REFERENCE NUMBER
15         000020      P.CMST= 16.        ;COMMAND STATUS
16
17         ;
18         000014      P.MLUN= 12.        ;MULTI-UNIT CODE
19         000016      P.UNFL= 14.        ;UNIT FLAGS
20         000020      P.HSTI= 16.        ;HOST IDENTIFIER
21         000024      P.UNTI= 20.        ;UNIT IDENTIFIER
22         000040      P.SHUN= 32.        ;SHADOW UNIT
23         000042      P.SHST= 34.        ;SHADOW STATUS
24         000044      P.TRCK= 36.        ;TRACK SIZE
25         000046      P.GRP= 38.        ;GROUP SIZE
26         000050      P.CYL= 40.        ;CYLINDER SIZE
27         000054      P.RCTS= 44.        ;RCT TABLE SIZE
28         000056      P.RBNS= 46.        ;RBN / TRACK
29         000057      P.RCTC= 47.        ;RCT COPIES
30
31         ;
32         000014      P.MLUN= 12.        ;MULTI-UNIT CODE
33         000016      P.UNFL= 14.        ;UNIT FLAGS
34         000020      P.HSTI= 16.        ;HOST IDENTIFIER
35         000024      P.UNTI= 20.        ;UNIT IDENTIFIER
36         000040      P.SHUN= 32.        ;SHADOW UNIT
37         000044      P.UNSZ= 36.        ;UNIT SIZE
38         000050      P.VSER= 40.        ;VOLUME SERIAL NUMBER
39
40         ;
41         000014      P.VRSN= 12.        ;MSCP VERSION
42         000016      P.CNTF= 14.        ;CONTROLLER FLAGS
43         000020      P.CTMO= 16.        ;CONTROLLER TIMEOUT
44         000022      P.CNCL= 18.        ;CONTROLLER COMMAND LIMIT
45         000024      P.CNTI= 20.        ;CONTROLLER ID
46         000034      P.MEDI= 28.        ;MEDIA TYPE
47         000042      P.SHST= 34.        ;SHADOW STATUS
48
49         ;ERROR LOG ATTENTION MESSAGE PACKET OFFSETS
50
51         000000      P.CRF= 0.          ;COMMAND REFERENCE NUMBER
52         000004      P.UNIT= 4.         ;UNIT NUMBER
53         000006      P.CNT= 6.          ;COUNT
54         000010      P.OPCD= 8.         ;OPCODE
55         000011      P.FLGS= 9.         ;ERROR LOG FLAGS
56         000012      P.SZOF= 10.        ;SIZE OR OFFSET
57         000014      P.LGDT= 12.        ;START OF ERROR LOG DATA

```

```

1          .SBTTL ERROR LOG FLAGS
2
3          000200      EF.FRS= 000200      ;FIRST PACKET
4          000100      EF.LST= 000100      ;LAST PACKET
5          000001      EF.MIS= 000001      ;MESSAGE MISSING
6
7          ;ERROR LOG MESSAGE OFFSETS
8
9          000000      L.EVNT= 0.          ;EVENT CODE
10         000002      L.SLOT= 2.         ;SLOT NUMBER
11         000004      L.CNTI= 4.         ;CONTROLLER IDENTIFIER
12         000014      L.CNTI= 12.        ;CONTROLLER SOFTWARE REVISION
13         000015      L.CHVR= 13.        ;CONTROLLER HARDWARE REVISION
14         000016      L.UNTI= 14.        ;UNIT IDENTIFIER
15         000026      L.USVR= 22.        ;UNIT SOFTWARE REVISION
16         000027      L.UHVR= 23.        ;UNIT HARDWARE REVISION
17         000030      L.ERLC= 24.        ;ERROR LOCATION
18         000034      L.CYL= 28.         ;CYLINDER
19         000040      L.GRP= 32.         ;GROUP
20         000041      L.TRCK= 33.        ;TRACK
21         000042      L.SCTR= 34.        ;SECTOR
22         000044      L.VSER= 36.        ;VOLUME SERIAL NUMBER
23         000050      L.DATA= 40.        ;EVENT DEPENDENT DATA
24
25         ;STATUS AND EVENT COE DEFINITIONS
26
27         000037      ST.MSK= 37          ;STATUS / EVENT CODE MASK
28         000040      ST.SUB= 40          ;SUB-CODE MULTIPLIER
29         000000      ST.SUC= 0           ;SUCCESS
30         000001      ST.CMD= 1           ;INVALID COMMAND
31         000002      ST.ABO= 2           ;COMMAND ABORTED
32         000003      ST.OFL= 3           ;UNIT-OFFLINE
33         000004      ST.AVL= 4           ;UNIT-AVAILABLE
34         000005      ST.MFE= 5           ;MEDIA ERROR
35         000006      ST.WPR= 6           ;WRITE PROTECTED
36         000007      ST.CMP= 7           ;COMPARE ERROR
37         000010      ST.DAT= 10          ;DATA ERROR
38         000011      ST.HST= 11          ;HOST BUFFER ACCESS ERROR
39         000012      ST.CNT= 12          ;CONTROLLER ERROR
40         000013      ST.DRV= 13          ;DRIVE ERROR
41         000037      ST.DIA= 37          ;MESSAGE FROM AN INTERNAL DIAGNOSTIC
42
43         ;
44         ;          SUBCODES FOR ST.OFL
45         ;
46         000040      SC.NVL = 40          ;NO VOLUME MOUNTED
47         ;
48         000100      SC.IOP = 100         ; OR DRIVE DISAVLED VIA RUN/STOP SWITCH
49         000400      SC.DIS = 400        ;UNIT INOPERATIVE
50         ;
51         000200      SC.DUP = 200        ;UNIT DISABLED BY FIELD SERVICE
52         ;
53         ;          SUBCODES FOR ST.DRV
54         ;
55         000040      SC.STO = 40          ;SDI RESPONCE TIME OUT
56         000100      SC.INV = 100        ;INVALID SDI RESPONCE

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

.SBTTL MODULE CODE
*****
:
:   INIT VALUES
:   INIT CONTROLLER
:   XFER TO DISK?
:       F FOR J = 1,CYCLE LIMIT
:       MAINTENANCE WRITE
:       MAINTENANCE READ
:       CHECK DATA?
:           T CHECK
:       NEXT J
:       T FOR J = 1,CYCLE LIMIT
:       GET UNIT STATUS
:           IF DRIVE IS NOT AVAILABLE, WAIT UNTIL IT IS
:       DRIVE THERE?
:       F DROP
:           ALL DRIVES DROPPED?
:           T DROP MODULE
:           F ---
:       T ONLINE
:       ONLINE?
:           T PICK 61GCK - IF RANDOM, GET RAND # MOD X
:           ELSE INCREMENT
:               IF LBN > LIMIT THEN LBN < 0
:
:       WRITE
:       READ
:       CHECK DATA ?
:           T CHECK
:       AVAILABLE DRIVE(I)
:       F TRY TO BRING ONLINE AGAIN
:
:   NEXT J
*****

```

```

*****
:
:   START CODE
:
:   IF THE CODE IS RESTARTED, CLEAR THE OLD ADDRESSES SO THE
:   THE CONTROLLER WILL GET REINITED.
:
:
*****

```

```

46 000660
47 000660 005227 177777
48 000664 001006
49 000666 042767 000002 177122
50 000674 104403 000000' 005352'
51 000702 032767 000002 177106 1$:
52 000710 001404
53 000712 104403 000000' 005356'
54 000720 000403
55 000722
56 000722 104403 000000' 005362' 2$:
57 000730 3$:

```

```

START:
INC      0-1          ;FIRST TIME THRU HERE?
BNE      1$          ;BR IF NO
BIC      0SR.XFR,SR1 ;DO NOT ALLOW DISK TRANSFERS
MSGN$,BEGIN,WARN1   ;ASCII MESSAGE CALL WITH COMMON HEADER
BIT      0SR.XFR,SR1 ;WILL CUSTOMER DATA BE OVERWRITTEN?
BEQ      2$          ;BR IF NO
MSGN$,BEGIN,WARN2   ;ASCII MESSAGE CALL WITH COMMON HEADER
BR       3$          ;
2$:
MSGN$,BEGIN,WARN3   ;ASCII MESSAGE CALL WITH COMMON HEADER
3$:

```

```

58 000730 005067 177210
59 000734 012767 177777 177522
60 000742 012767 000017 177512
61 000750 016767 177040 177622
62 000756 005067 177632
63 000762 012767 000001 177626
64 000770 005067 177274
65 000774 104417 000000
66 001000 016767 177050 177560
67 001006 005067 177556
68 001012 016767 176770 177232
69 001020 062767 000002 177224
70 001026 005067 177424
71 001032 005067 177422
72
73

```

```

CLR CDERT
MOV #177777,EXPAV
MOV #PRNUM,PRMSG
MOV DVID1,DVICE
CLR TABLEW
MOV #1,TABLEW*2
CLR CMDREF
RAND$,BEGIN
MOV RANNUM,SECL
CLR SECH
MOV ADDR,SAREG
ADD #2,SAREG
CLR OLDEA
CLR OLDEA

```

```

; CLEAR DATA CHECK ERROR COUNT
; NOT EXPECTING AN INTERRUPT
; INITIALIZE PRINT WORD
; DVICE HAS DESIRED BITS SET
; SET TABLE FOR UNIT 0
; SET TABLE FOR PORTID FOR UNIT 0
; COMMAND REF # = 0

; FOR RESTARTING (INITIAL SECTOR ADDR)
; STORE IN SA REG
; SA REGISTER HAS PROPER ADDRESS
; OLD PHYSICAL ADDRESS CLEARED
; OLD EXTENDED ADDRESS CLEARED
; FOR RESTARTING. THIS WILL FORCE A
; CONTROLLER REINIT TO TAKE PLACE

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30

31
32

33
34

35
36
37
38
39
40
41
42

```

13 001036
14 001036 012767 000260' 177376
15 001044 104415 000000' 000442'
16 001052 026767 177366 177376
17 001060 001004
18 001062 026767 177360 177370
19 001070 001412
20 001072 016767 177346 177356
21 001100 016767 177342 177352
22 001106 004767 000332
23 001112 005067 177466
24 001116
25 001116 032767 000010 176672
26 001124 001034
27 001126 026767 177330 176700
28 001134 001030
29 001136 062767 000017 177316
30

    001144 104421 000000' 000042'
    001152 000475'

31 001154 105067 177322
32

    001160 104421 000000' 000044'
    001166 000504'

33 001170 105067 177315
34

    001174 104421 000000' 000144'
    001202 000466'

35 001204 105067 177263
36 001210 104403 000000' 005314'
37 001216 012777 004334' 176564 1$:
38
39 001224 104415 000000' 000124'
40 001232 016700 176672
41 001236 004767 000572
42 001242 010067 177202
    
```

```

;.....
;
; RESTART SEQUENCE
;
; CHECK THE ADDRESS OF THE RINGS TO SEE IF THEY WERE RELOCATED
; IF THEY WERE, REINIT THE CONTROLLER.
;
; GET THE NEW ADDRESSES. IF THE DISKLESS OPERATION IS DESIRED
; THEN DO THE MAINTENANCE WRITE AND READ. ELSE DO THE WRITE
; AND READ WITH A DRIVE.
;.....
RESTR1:
MOV @RSPONC,VA ;DID THE RINGS RELOCATE?
GETPA$,BEGIN,VA ;GET PHYSICAL ADDRESS FROM 16 BIT VA
CMP PA,OLDPA ;IS THE OLD PHYS ADDR = NEW ONE?
BNE RESTR2 ;IF SO, REINIT
CMP EA,OLDEA ;IS THE OLD EXTN ADDR = NEW ONE?
BEQ RESTR1 ;IF NOT, DON'T REINIT
RESTR2: MOV PA,OLDPA ;ELSE SET THE OLD RING ADDR
MOV EA,OLDEA ;AND THE OLD EXTENED ADDR
JSR PC,INITUD ;AND INIT THE CONTROLLER
CLR TRY ;CLEAR RETRY COUNT

RESTR1:
BIT @SR.SUM,SR1 ;DO WE WANT THE REPORT?
BNE 1$ ;IF NOT, SKIP THE REPORT
CMP PRMSG,PASCNT ;DO WE PRINT?
BNE 1$ ;IF PASS COUNT IS NOT = PRINT WORD, SKIP
ADD @PRTNUM,PRMSG ;PRINT WORD IS INCREMENT
;.....
;CONVERT SOFCNT TO ASCII AND
;STORE AT ADR2
BTOD$,BEGIN,SOFCNT,ADR2

;.....
CLRB ADR2*5
;.....
;CONVERT MRDCNT TO ASCII AND
;STORE AT ADR3
BTOD$,BEGIN,MRDCNT,ADR3

;.....
CLRB ADR3*5
;.....
;CONVERT CDERCT TO ASCII AND
;STORE AT ADR1
BTOD$,BEGIN,CDERCT,ADR1

;.....
CLRB ADR1*5
MSGN$,BEGIN,ERRPAS ;ASCII MESSAGE CALL WITH COMMON HEADER
MOV @NTRUPT,@VECTOR ;GET VECTOR ADDRESS
;SET POINTER
;GET PHYSICAL ADDRESS FROM 16-BIT RBUFVA
GETPA$,BEGIN,RBUFVA
MOV RBUFEA,RO ;GET EA TO ADJUST
JSR PC,ASR04 ;GO ADJUST IT
MOV RO,RBFFEA ;PUT ADJUSTED VALUE IN A SAVE AREA
    
```

```

43 001246 005067 :77330          CLR      UNITNO          ;PRESET UNIT #
44 001252 032767 000002 176536  BIT      @SR,XFR,SR1     ;DISK XFER???
45 001260 001454          BEQ      MA10NC          ;NO! DO MAINTENANCE (DISKLESS) ROUTINES
46          ;*****
47          ; DO THE DISK OPERATIONS
48          ; CHECK TO SEE WHICH PORTS ARE AVAILABLE
49          ;*****
50
51 001262 004767 001032          JSR      PC,SETUP        ;FIND DRIVES/SET UP TABLE
52 001266 005767 177306          TST      DVICE          ;ELSE, TEST FOR ANY MORE DRIVES
53 001272 001002          BNE      LOOP1          ;IF TRUE, DO A CYCLE
54
55 001274 104410 000000'          END$,BEGIN              ;
56
57 001300          LOOP1:
58 001300 104414 000000'          GMBUF$, BEGIN          ;GET WRITE BUFFER INFORMATION
59 001304 016700 176626          MOV      WBUF EA,RO     ;GET WRITE BUFFER INFORMATION
60 001310 004767 000520          JSR      PC,ASR04       ;ADJUST IT
61 001314 010067 177132          MOV      RO,WBFF EA     ;STORE EA IN SAVE AREA
62 001320 012704 000614'          MOV      @TABLEW,R4    ;R4 -> TABLE OF UNITNO AND PORTID
63 001324 012703 000001          MOV      @1,R3         ;R3 IS AN INDEX TO DVICE
64 001330          LOOP2:
65 001334 001412          BIT      R3,DVICE       ;HAS THE DRIVE BEEN DROPPED
66 001336 016467 000002 177242  BEQ      9$             ;IF SO, SKIP THIS DRIVE
67 001344 011467 177232          MOV      2(R4),PORTID  ;SET UP PORTID
68          ; *** DO A DISK CYCLE
69 001350 004767 001250          MOV      (R4),UNITNO   ;SET UP UNITNO
70 001354 103002          JSR      PC,CYCLED      ;DO A CYCLE FOR DISK OPERATION
71 001356 004767 002026          BCC      9$             ;IF SUCCESSFUL, CONTINUE
72 001362          JSR      PC,DROP1     ;IF NOT, DROP DRIVE
73 001362 062704 000004          9$: ADD      @4,R4        ;POINT TO NEXT ENTRY OF THE TABLE
74 001366 006303          ASL      R3             ;R3 POINTS TO NEXT BIT
75 001370 022704 000654'          CMP      @TEND,R4      ; POINT BEYOND LAST ENTRY?
76 001374 001403          BEQ      12$           ; IF NOT, THEN TRY AGAIN.
77 001376 020367 177176          CMP      R3,DVICE      ;IF R3 > DVICE THEN DONE WITH ITERATION
78 001402 003752          BLE      LOOP2        ;IF < OR =, LOOP
79 001404          12$:
80 001404 104413 000000'          ENDIT$,BEGIN          ;SIGNAL END OF ITERATION.
81 001410 000733          BR       LOOP1         ;MONITOR SHALL TEST END OF PASS
82          ;AND DO AGAIN
83
84          ;*****
85          ; MAINTENANCE ROUTINE, DO THE DISKLESS CODE
86          ;*****
87
88 001412          MA10NC:
89 001412 104414 000000'          GMBUF$, BEGIN          ;GET WRITE BUFFER INFORMATION
90 001416 016700 176514          MOV      WBUF EA,RO     ;GET EA TO ADJUST
91 001422 004767 000406          JSR      PC,ASR04       ;ADJUST IT
92 001426 010067 177020          MOV      RO,WBFF EA     ;STORE EA IN SAVE AREA
93 001432 004767 001464          JSR      PC,CYCLEL      ;SIGNAL END OF ITERATION.
94 001442 000763          ENDIT$,BEGIN          ;MONITOR SHALL TEST END OF PASS
          BR       MA10NC

```

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20 Sep 84 10:17 Page 16
MODULE CODE

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22 001444 012767 000260' 176770 INITUD: MOV @RSPONC,VA ;VA -> RSPONC
23 001452 104415 000000' 000442' GETPA$,BEGIN, VA ;GET PHYSICAL ADDRESS FROM 16-BIT VA
24 001460 005004 CLR R4 ;R4 IS USED IF AN ERROR IS DETECTED
25 001462 012702 000001 MOV @1,R2 ;R2 = STEP INDICATOR REG FOR MSG'S
26 001466 005077 176314 CLR @ADDR ;WRITE TO IP REGISTER TO INIT CONTROLLER
27 001472 012701 002260 MOV @TIMER,R1 ;SET TIME OUT LIMIT
28 001476 017700 176550 1$: MOV @SAREG,R0 ;R0 HAS SA REGISTER DATA
29 001502 032700 100000 BIT @<SA.ERR>,R0 ;CHECK FOR ERROR
30 001506 001007 BNE 2$ ;IF FOUND, GET OUT OF LOOP
31 001510 104407 000000' BREAK$,BEGIN ;TEMPORARY RETURN TO MONITOR....
001514 104407 000000' BREAK$,BEGIN ;THEN CONTINUE AT NEXT INSTRUCTION.
32 001520 005301 DEC R1 ;TIME OUT?
33 001522 001365 BNE 1$ ;IF NOT, LOOP
34 001524 000404 BR 4$ ;IF DONE, CONTINUE
35 001526 012703 004000 2$: MOV @SA.S1,R3 ;R3 = STEP 1 BIT
36 001532 000167 000412 JMP ERROR1 ;IF HERE, ERROR
37 001536 042700 001140 4$: BIC @<SA.Q22+SA.MAP+SA.SM>,R0 ;CLEAR KDA50-Q DEPENDENT BITS
38 001542 022700 004400 CMP @<SA.S1+SA.DIA>,R0 ;DID DATA COMPARE PROPERLY?
39 001546 001402 BEQ 5$ ;IF SO, CONTINUE
40 001550 000167 000370 JMP ERROR3 ;REPORT ERROR
41 ; STEP 2
42 001554 016705 176230 5$: MOV VECTOR,R5 ;VECTOR GIVEN
43 001560 006205 ASR R5 ;SET TO APPROPRIATE VALUE
44 001562 006205 ASR R5 ; = VECTOR/4
45 001564 052705 100200 BIS @<SA.INT+BIT15>,R5 ;ACTIVATE INTERRUPTS & SET MSB FOR STEP 1
46 ;LEN'S ARE 0
47 001570 010500 MOV R5,R0 ;STORE R5 IN R0 FOR SUBROUTINE
48 001572 012703 004000 MOV @SA.S1,R3 ;R3 HAS STEP BIT FOR SUBROUTINE
49 001576 004767 000244 JSR PC,SNDSTP ;SEND STEP DATA
50 001602 042705 100000 BIC @BIT15,R5 ;CLEAR MSB FOR COMPARE DATA
51 001606 042700 000200 BIC @BIT07,R0 ;WAS BIT07 ONLY BIT SET?, SHOULD BE
52 001612 001404 BEQ 6$
53 001614 052700 010200 BIS @<SA.S2+BIT07>,R0 ;SET R0 TO REPORT THE ERROR
54 001620 000167 000320 JMP ERROR3 ;REPORT ERROR
55 001624 016700 176614 6$: MOV PA,R0 ;R0 GETS PHYSICAL ADDRESS
56 001630 004767 000212 JSR PC,SNDSTP ;SEND STEP DATA

```

```

57 001634 042705 177400      BIC    #177400,R5      ;HIGH BYTE CLEARED
58 001640 020500              CMP    R5,R0          ;CHECK ECHO DATA
59 001642 001402              BEQ    7$             ;IF OK, SKIP
60 001644 000167 000274      JMP    ERROR3         ;IF NOT, REPORT ERROR
61 001650              7$:
62              ;
63 001650 016700 176572      MOV    EA,R0          ;ADJUST THE EXTENDED ADDRESS BITS
64 001654 004767 000154      JSR    PC,ASR04       ;SHIFT EXTENDED ADDRESS BITS FOR CONTROLLER
65 001660 004767 000162      JSR    PC,SENDSTP     ;SEND STEP DATA
66 001664 012700 000254      MOV    #RSPONC-4,R0   ;RO -> RING ENVELOP
67              ;
68 001670 005720              8$:
69 001672 001117              TST    (R0)           ;IS THE RING ENTRY = 0?
70 001674 022700 000270      BNE    ERROR5        ;IF NOT, ERROR
71 001700 001373              CMP    #CMDREF,R0    ;IS RO POINTING PAST THE RINGS?
72 001702 016700 176112      BNE    8$            ;IF NOT, LOOP
73 001706 000241              MOV    SR2,R0        ;RO = BURST VALUE
74 001710 006300              CLC                    ;CLEAR CARRY
75 001712 006300              ASL    R0             ;ALIGN BURST FOR STEP 4
76 001714 052700 000001      ASL    R0             ;
77 001720 010077 176326      BIS    #SA.GO,R0     ;SET GO BIT
78 001724 012767 000362' 176510  MOV    RO,#SAREG     ;SEND DATA TO CONTROLLER/INIT DONE
79 001732 104415 000000' 000442'  MOV    #CMPACK,VA    ;GET COMMAND PACKET PA AND EA
80 001740 016767 176500 176316  GETPA$,BEGIN,VA     ;GET PHYSICAL ADDRESS FROM 16-BIT VA
81 001746 016700 176474      MOV    PA,COMMAND    ;STORE ADDRESS IN THE RING
82 001752 004767 000056      MOV    EA,R0         ;SAVE IN RO
83 001756 010067 176304      JSR    PC,ASR04       ;SHIFT EXTENDED ADDRESS BITS FOR CONTROLLER
84              MOV    RO,COMMAND+2 ;MOVE ADJUSTED EA INTO RING
85 001762 012767 000276' 176452  MOV    #RSPACK,VA    ;GET RESPONSE PACKET PA AND EA
86 001770 104415 000000' 000442'  GETPA$,BEGIN,VA     ;GET PHYSICAL ADDRESS FROM 16-BIT VA
87 001776 016767 176442 176254  MOV    PA,RSPONC     ;STORE ADDRESS IN THE RING
88 002004 016700 176436      MOV    EA,R0         ;SAVE IN RO
89 002010 004767 000020      JSR    PC,ASR04       ;SHIFT EXTENDED ADDRESS BITS FOR CONTROLLER
90 002014 010067 176242      MOV    RO,RSPONC+2   ;MOVE ADJUSTED EA INTO RING
91 002020 012777 004334' 175762  MOV    #INTRPT,@VECTOR ;STORE INTERRUPT ADDRESS IN VECTOR
92 002026 005067 176552      CLR    TRY           ;CLEAR TRY SO DRIVE WILL
93              ;GO BACK ONLINE IF NECESSARY
94 002032 000207      RTS    PC
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109 002034
110 002034 006200
111 002036 006200
112 002040 006200
113 002042 006200

```

```

*****
ASR04
ARITHMETIC SHIFT RIGHT REG 0 FOUR TIMES

EXTENDED ADDRESS BITS (16 & 17) ARE SET IN BIT POSITION 4 & 5
RESPECTIVELY. SHIFT RIGHT FOUR TIMES TO REPOSTION THE VALUE

INPUT  RO = UNADJUSTED EXTENDED ADDRESS BITS

OUTPUT RO = ADJUSTED EXTENDED ADDRESS BITS
*****
ASR04:
ASR    RO          ;SHIFT 10
ASR    RO          ;SHIFT 4
ASR    RO          ;SHIFT 2
ASR    RO          ;SHIFT 1

```


DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep 84 10:17 Page 16 2
MODULE CODE

```

114 002044 000207          RTS      PC          ;RETURN
115
116          ;*****
117          ;
118          ; SEND STEP DATA
119          ;
120          ; INPUT:  R0 HAS DATA TO BE SENT TO CONTROLLER FOR STEP
121          ;          R3 HAS PREVIOUS STEP FLAG SET
122          ;
123          ; OUTPUT: R0 HAS DATA SENT FROM CONTROLLER TO HOST FOR ECHO AND NEXT STEP
124          ;          R3 HAS CURRENT STEP FLAG SET
125          ;*****
126
127 002046 016701 175736  SNDSTP: MOV      VECTOR,R1          ;
128 002052 012721 002072'  MOV      @INTA,(R1)+          ;SET UP INTERRUPT HANDLER ADDRESS
129 002056 116711 175730  MOVB     BR1,(R1)          ;SET PRIORITY LEVEL
130 002062 010077 176164  MOV      R0,@SAREG          ;SEND STEP1 WRITE FORMMATED DATA
131
132 002066 104400 000000'  EXIT$,BEGIN          ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
133
134 002072          INTA:
135 002072 000004 000000' 002100'  PIRQ$,BEGIN,3$          ; QUEUE UP TO CONTINUE AT 3$ AND RTI
          ;-----
136 002100          3$:
137 002100 017700 176146  MOV      @SAREG,R0          ;GET STEP N FORMATTED DATA
138 002104 032700 100000  BIT      @SA.ERR,R0          ;TEST FOR ERROR
139 002110 001017          BNE     ERROR1          ;IF NOT OK, REPORT
140 002112 005202          INC     R2          ;SET STEP REGISTER
141 002114 006303          ASL     R3          ;R3 HAS STEP BIT PROPERLY SET
142 002116 030300          BIT      R3,R0          ;WAS STEP N SET?
143 002120 001002          BNE     4$          ;IF SO, CONTINUE
144 002122 000167 000020  JMP     ERROR2          ;IF NOT CORRECT STEP, ERROR
145 002126 040300          BIC     R3,R0          ;CLEAR THE STEP BIT, FOR COMPARE
146 002130 000207          RTS      PC          ;RETURN

```

MODULE CODE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

33
34

35
36
37
38
39
40
41
42
43
44
45
46

```

*****
:
:   ERROR 1
:   PRINT AN ERROR REPORTED BY THE CONTROLLER DIAGNOSTICS
:
:   ERROR2
:   PRINT THE VALUE OF THE SA REGISTER WHEN THE STEP BIT WAS NOT SET
:
:   ERROR3
:   PRINT A THE VALUE OF THE SA REGISTER WHEN THE ECHO WAS NOT SET
:   CORRECTLY
:
:   INPUT  R0 -> SA REGISTER
:          R2 = STEP COUNT
:
:   OUTPUT THE RETRY COUNT IS INCREMENTED
:          IF THE RETRY COUNT > RETRY LIMIT, END MODULE
:
:   ERRORS
:   RING WASN'T ALL ZERO -> ERROR
:   DROP UDBAO
:
*****

```

```

002132
002132 104403 000000' 005372'
002140 104410 000000'
002144 005204
002146 005204
002150 005204
002152 010267 176276

002156 104420 000000' 000454'
002164 000475'

002166 017767 176060 176260

002174 104420 000000' 000454'
002202 000466'

002204 005304
002206 001003
002210 104403 000000' 005202'
002216 005304
002220 001003
002222 104403 000000' 005226'
002230 005304
002232 001003
002234 104403 000000' 005234'

```

```

*****
:
:   ERRORS:
:   MSGN$,BEGIN,ZERO      ;ASCII MESSAGE CALL WITH COMMON HEADER
:   END$,BEGIN            ;
:
:   ERROR3: INC  R4          ;R4 = 3 FOR ERROR3
:   ERROR2: INC  R4          ;R4 = 2 FOR ERROR2
:   ERROR1: INC  R4          ;R4 = 1 FOR ERROR1
:   MOV     R2,NUM          ;STORE STEP REG IN A NUMBER FOR CONVRT
:   *****
:   ;CONVERT NUM TO ASCII AND
:   ;STORE AT ADR2
:
:   OTOA$,BEGIN,NUM,ADR2
:
:   ;*****
:   MOV     @SAREG,NUM      ;STORE VALUE IN A NUMBER
:   ;*****
:   ;CONVERT NUM TO ASCII AND
:   ;STORE AT ADR1
:
:   OTOA$,BEGIN,NUM,ADR1
:   ;*****
:
:   DEC     R4              ;ERROR 1?
:   BNE    1$              ;IF NOT, CHECK IF IT IS THE NEXT ERROR
:   MSGN$,BEGIN,INITE1    ;ASCII MESSAGE CALL WITH COMMON HEADER
:
:   1$:
:   DEC     R4              ;ERROR 2?
:   BNE    2$              ;IF NOT, CHECK IF IT IS THE NEXT ERROR
:   MSGN$,BEGIN,INITE2    ;ASCII MESSAGE CALL WITH COMMON HEADER
:
:   2$:
:   DEC     R4              ;ERROR 3?
:   BNE    3$              ;IF NOT, CHECK IF IT IS THE NEXT ERROR
:   MSGN$,BEGIN,INITE3    ;ASCII MESSAGE CALL WITH COMMON HEADER

```

```

47 002242          3$: ;*****
48                ;*****
                ;CONVERT ADDR TO ASCII AND
                ;STORE AT ADR3
    002242 104420 000000' 000006'
    002250 000504'
                OTOA$,BEGIN,ADDR,ADR3
                ;*****
                ;*****
49 002252 104405 000000' 000000
                HRDR$,BEGIN,NULL
                ;*****
50 002260 104403 000000' 005210'
51 002266 005267 176312
52 002272 022767 000004 176304
53 002300 001402
54 002302 000167 176352
55 002306          6$: MSGN$,BEGIN,INITER ;ASCII MESSAGE CALL WITH COMMON HEADER
    002306 104403 0000C0' 005366'
56 002314 104410 000000'
57                END$,BEGIN ;

```

```

;*****
;*****
;CONVERT ADDR TO ASCII AND
;STORE AT ADR3
OTOA$,BEGIN,ADDR,ADR3
;*****
;*****
HRDR$,BEGIN,NULL
;*****
MSGN$,BEGIN,INITER ;ASCII MESSAGE CALL WITH COMMON HEADER
INC TRY ;INCREMENT RETRY COUNT
CMP @RLIM,TRY ;IS THE RETRY COUNT EXCEEDED?
BEQ 6$ ;IF SO, END IT
JMP START ;IF NOT, TRY AGAIN

```

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16 002320
17
18 002320 004767 001650
19 002324 005367 175740
20 002330 001110
21 002332 012703 000001
22 002336 012704 000614'
23 002342 011467 176234
24 002346 016714 176230
25 002352 010367 176230
26 002356 010364 000002
27 002362 012764 177777 000004
28 002370 016464 000004 000006
29 002376 012767 002400 176206
30 002404 004767 001526
31 002410 103006
32 002412 005367 176174
33 002416 001372
34 002420 004767 000774
35 002424 000437
36 002426 016767 175650 176146
37
38
39 002434 012702 000614'
40 002440 012705 000001
41 002444 020227 000654'
42 002450 001420
43 002452 020305
44 002454 001416
45 002456 026712 176120
46 002462 001404
47 002464 062702 000004
48 002470 006305
49 002472 000764
50 002474 011467 176102
51 002500 010367 176102
52 002504 004767 000720
53 002510 000405
54 002512
55
56 002512 026714 176064
57 002516 001402

```

```

;*****
;
;   SET UP
;
;   GO FIND OUT WHAT DRIVES ARE OUT THERE.
;   A TABLE IS FILLED WITH UNIT NUMBERS(MAX IS 16)
;
;   THIS SHOULD ONLY BE DONE AT THE VERY BEGINNING OF RUNNING
;   THIS DECX MODULE; THEN NOT RUN AGAIN.
;
;   INPUT:  DVICE HAS APPROPRIATE BITS SET.  THE # OF BITS =
;           # OF DRIVES WANTED TO TEST.
;           POSITION OF BITS = WHICH DRIVE IN THE SYSTEM IS DESIRED.
;*****
SETUP:
; *** SET CONTRL CHAR AND WAIT FOR THE ATTENTION MESSAGES
; JSR PC,SCC ;SET CONTROLLER CHARACTERISTICS
; DEC CMDREF ;ONLY SET UP AT BEGINNING OF MODULE
; BNE 19$ ; (USE DRIVES FOUND AT BEGINNING)
; MOV #1,R3 ;INITIAL PORTID VALUE
; MOV #TABLEW,R4 ;R4 -> TABLEW
; MOV (R4),UNITNO ;INITIAL UNITNO IN TABLEW
1$: MOV UNITNO,(R4) ;UNIT NO SET IN TABLEW;READY TO TEST
; MOV R3,PORTID ;PORT ID SET
; MOV R3,2(R4) ;PORTID SET IN TABLEW
; MOV #17777,4(R4) ;INSERT NEW -1,-1 FOR LAST ENTRY
; MOV 4(R4),6(R4) ; OF THE TABLEW
; MOV #2400,WORK ;WORK = RETRY LIMIT
3$: JSR PC,GTSTAT ;GET STATUS, GET NEXT UNIT NUMBER
; BCC 7$ ;OK, CONTINUE
; DEC WORK ;ELSE IF OFFLINE, DECR COUNT
; BNE 3$ ;IF COUNT > 0, TRY AGAIN.
5$: JSR PC,DROP2 ;DROP THE DRIVE
; BR 17$ ;TRY NEXT UNIT
7$: MOV P.UNIT+RSPACK,UNITNO ;UNIT NUMBER FROM RESPONCE PACKET IN UNITNO
; *** CHECK FOR CASE WHERE THE MORE UNITS THEN DRIVES HAVE BEEN SPECIFIED.
; *** NEXT UNIT MODIFIER WILL GIVE A DUPLICATE UNIT NUMBER.
; MOV #TABLEW,R2 ;R2 -> TABLE TO FIND DUPLICATE
; MOV #1,R5 ;R5 IS TEMP PORTID
9$: CMP R2,#TEND ;REACHED THE BOTTOM?
; BEQ 15$ ;IF SO, EXIT
; CMP R3,R5 ;REACHED THE LATEST ENTRY?
; BEQ 15$ ;IF SO, EXIT
; CMP UNITNO,(R2) ;DO WE HAVE A DUPLICATE UNIT NUMBER?
; BEQ 13$ ;IF SO, ERROR
11$: ADD #4,R2 ;IF NOT, POINT TO NEXT POINTER
; ASL R5
; BR 9$ ;AND CONTINUE
13$: MOV (R4),UNITNO ;DROP DRIVE FROM TABLE
; MOV R3,PORTID
; JSR PC,DROP3 ;AND DROP IT
; BR 17$
15$:
; ***
; CMP UNITNO,(R4) ;IS THE UNITNO CORRECT?
; BEQ 17$ ;IF SO, CHECK FOR NEXT UNIT

```

MODULE CODE

```

58 002520 016714 176056          MOV      UNITNO,(R4)          ;ELSE, CORRECT THE UNIT NUMBER IN TABLE
59 002524          17$:      ASL      R3              ;NEXT PORTID SET
60 002524 006303          CMP      DVICE,R3          ;DONE?
61 002526 026703 176046          BMI      19$              ;IF R3 > DVICE, ALL DESIRED DRIVES ARE FOUND
62 002532 100407          INC      UNITNO           ;NEXT UNITNO SET
63 002534 005267 176042          ADD      @4,R4            ;POINT TO NEXT ENTRY TO TEST DRIVE
64 002540 062704 000004          CMP      @TEND,R4        ;POINT TO END? IF SO, TABLE FULL
65 002544 022704 000654          BHI      1$              ;IF R4 NOT REACHED END, GO TEST
66 002550 101276          19$:      RTS      PC
67 002552          19$:      RTS      PC
68 002552 000207
69
70          :*****
71          :
72          :      TSTOFL
73          :      TEST TO SEE WHAT KIND OF AN OFFLINE CONDITION HAS OCCURED.
74          :
75          :*****
76 002554 022700 000003          TSTOFL: CMP      @ST.OFL,R0 ;WAS THE DRIVE FOUND OFFLINE?
77 002560 001403          BEQ      10$              ;CHECK WHAT KIND OF OFFLINE
78 002562 022700 000013          CMP      @ST.DRV,R0      ;WAS IT A DRIVE ERROR? -> SDI?
79 002566 001012          BNE      13$              ;IF IT WAS NOT, ERROR (DROP DRIVE)
80 002570 032767 000740 175512 10$: BIT      @<SC.NVL+SC.DIS+SC.DUP+SC.IOP>,P.STS+RSPACK ;WERE ANY OF THESE BITS SET?
81          ; = NO VOLUME MOUNTED, UNIT DISABLED BY FIELD SREVICE
82          ; OR DUPLICATE UNIT NUMBER OR UNIT INOPERATIVE
83 002576 001004          BNE      12$              ;IF SO, EXIT
84 002600 032767 177000 175502          BIT      @+C<SC.NVL+SC.DIS+SC.DUP+SC.IOP+ST.MSK>,P.STS+RSPACK ; ANY OTHER DATA?
85 002606 001002          BNE      13$              ;IF SO, DROP
86 002610 000241          12$:      CLC              ;CLEAR CARRY
87 002612 000207          RTS      PC              ;RETURN
88 002614 000261          13$:      SEC              ;SET CARRY, DRIVE WAS FOUND TO BE OFFLINE
89          ; OR ANOTHER ERROR
90 002616 004767 002124          JSR      PC,ERRORH      ;REPORT ERROR
91 002622 000207          RTS      PC              ;RETURN

```

MODULE CODE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

```

*****
CYCLE DISK
DO THE DISK CYCLE
DO GET STATUS COMMANDS TO ASSURE THAT THE DRIVE
IS AVAILABLE (FOR DUAL PORTING)
CHECK DRIVE TO BE ONLINE
IF TRUE
PICK THE BLOCK
WRITE
READ
DATA CHECK
MAKE THE DRIVE AVAILABLE
ELSE DROP DRIVE
*****
CYCLED:
BIT #SR.DUA,SHL ;DUAL PORT?
BNE 2$ ;IF NOT, CONTINUE
; *** CHECK IF WE DO ONLINE FOR THE FIRST TIME.
TST TRY ;IF TRY HAS SET MSB, DON'T DO ONLINE
BMI 16$ ; DON'T DO ONLINE
BR 10$ ; ELSE DO ONLINE (1ST TIME THROUGH IN THIS PASS)
; ***
; *** DO GET STATUS COMMANDS TO ASSURE THE DRIVE IS AVAILABLE TO THE CONTROLLER
; *** FOR DUAL PORTING.
; ***
2$: MOV #10,R1 ;R1 = # OF GET STATUS TO DO
4$: JSR PC,GTSTAT ;IS THE DRIVE OFFLINE?
BCC 6$ ;IF ALL OK, DO THE CYCLE
JSR PC,TSTOFL ;ELSE, CHECK IF OFFLINE
BCS 24$ ;IF IT ERRED, DROP THE DRIVE
; *** HANDLE OFF LINE DRIVE, WAIT FOR AVAILABLE ATTENTION MESSAGE
CLR EXPAV ;EXPECT AN AVAILABLE ATTENTION MESSAGE
BIS #<RG.OWN+RG.FLG>,RSPONC+2 ;SET RING FOR ATTN MESSAGE
JSR PC,INTERP ;WAIT FOR MESSAGE
; 2ND ATTENTION MESSAGE
BR 10$
6$: DEC R1 ;DONE?
BNE 4$ ;IF NOT DONE, TRY AGAIN
10$: JSR PC,ONLINE ;DO AND ONLINE COMMAND
BCS 2$ ;IF CARRY WAS SET, TRY AGAIN
14$: MOV P,UNSZ+2+RSPACK,UNSZH ;IS THE UNIT SIZE HI ADDRESS
MOV P,UNSZ+RSPACK,UNSZL ;GET UNIT SIZE/IS IT = 0?
BNE 16$ ;IF NOT ZERO, CONTINUE WITH ITERATION
TST UNSZH ;IS UNSZH ALSO 0?
BEQ CYCLED ;IF 0, TRY TO BRING ONLINE AGAIN
; *** SET MSB OF TRY TO SHOW THAT INITIAL ONLINE IS DONE
MOV #100000,TRY
*****
THE FOLLOWING SEGMENT SETS THE LIMIT FOR THE UNIT SIZE.
THE VALUE (UNIT SIZE - (WRITE BUFFER SIZE/NORMAL BLOCK SIZE))
IS THE LAST SECTOR POSSIBLE TO RIGHT TO.

```

18	002624			
19	002624	032767	001000	175164
20	002632	001004		
22	002634	005767	175744	
23	002640	100443		
24	002642	000422		
29	002644	012701	000010	
30	002650	004767	001262	
32	002656	004767	177672	
35	002664	005067	175574	
36	002670	052767	140000	175364
37	002676	004767	001426	
39	002702	000402		
40	002704	005301		
41	002706	001360		
42	002710	004767	001316	
43	002714	103753		
44	002716	016767	175422	175650
45	002724	016767	175412	175640
46	002732	001006		
47	002734	005767	175634	
48	002740	001731		
50	002742	012767	100000	175634

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page 19 1
MODULE CODE

```

58
59 002750
60 002750 016700 175166
61 002754 005001
62 002756 005201
63 002760 162700 000400
64 002764 100374
65 002766 160167 175600
66
67 002772 004767 000156
68 002776 004767 001134
69 003002 103720
70 003004 022700 000004
71 003010 001715
72
73 003012 004767 000720
74 003016 103007
75 003020 032767 001000 174770
76 003026 001306
77 003030 004767 001712
78 003034 000421
79
80 003036 004767 000730
81 003042 103416
82 003044 032767 004000 174744
83 003052 001004
84
85 003054 104412 000000' 000126'
86 003062 003064'
87 003064 032767 001000 174724
88 003072 001402
89
90 003074 004767 001014
91 003100 000241
92
93 003102 000207
94
95
96
97 003104
98 003104 005067 175354
99 003110 052767 140000 175144
100 003116 000167 001206
101
102
103
104
105
106
107
108
109
110 003122
111 003122 004767 000470
112 003126 004767 000430
113 003132 032767 004600 174656

```

```

;*****
16$: MOV WBUFSZ,RO ;WBUFSZ IN RO AS A LIMIT
CLR R1 ;R1 = # OF BLOCKS
18$: INC R1 ;INCREMENT THE # OF BLOCKS
SUB #1,RO ;DECREMENT A BLOCK
BPL 18$ ;BR IF > 0
SUB R1,UNSZL ;ADJUST THE UNIT SIZE
; *** NOW PICK WHICH BLOCK TO WRITE TO
JSR PC,PICKBK ;ELSE SELECT A SECTOR TO TEST
JSR PC,GTSTAT ;DID WE NOT GET THE DRIVE ONLINE?
BCS 2$ ;IF WE DID NOT, GO BACK TO TOP AND TRY AGAIN
CMP #ST.AVL,RO ;IS IT AVAILABLE?
BEQ 2$ ;IF SO, GO BACK TO TOP AND TRY AGAIN
; *** WRITE TO THE BLOCK SELECTED
JSR PC,WRITE ;WRITE THE DATA FOR USER DEFINED # OF WORDS
BCC 19$ ;IF OK, CONTINUE
BIT #SR.DUA,SR1 ;ARE WE DOING DUAL PORT?
BNE 2$ ;IF YES, RETRY
JSR PC,ERRORH ;ELSE, HARD ERROR
BR 22$ ;AND EXIT; BCS 22$ ;IF ERROR, EXIT
; *** READ IT BACK
19$: JSR PC,READ ;READ A BLOCK
BCS 22$ ;IF ERROR, EXIT
BIT #SR.CMP,SR1 ;DO A DATA COMPARE?
BNE 20$ ;IF NOT, SKIP THE COMPARE
; *** COMPARE DATA
CDATA$,BEGIN,RBUFA ; REQUEST FOR MONITOR TO CHECK DATA
; IF ERROR, CONTINUE
20$: BIT #SR.DUA,SR1 ;DO WE DO AN AVAILABLE?
BEQ 22$ ;IF NOT(BIT NOT SET) SKIP AVAILABLE
; *** MAKE THE DRIVE AVAILABLE
JSR PC,AVAILB ;RELEASE THE DRIVE
22$: CLC ;EVERY THING WAS OK
;WASTE A LITTLE TIME SO OTHER
; CONTROLLER CAN GRAB DRIVE
24$: RTS PC ;RETURN
; *** SUBROUTINE TO WAIT FOR AN INTERRUPT
; *** RETURNS AFTER THE INTERRUPT OCCURS
DOINTR: CLR EXPVAV ;EXPECT AN AVAILABLE ATTENTION MESSAGE
BIS #<RG.OWN+RG.FLG>,RSPONC+2 ; SET OWN AND FLAG FOR RESPONSE RING
JMP INTERP ;WAIT FOR ATTENTION MESSAGE & RETURN
;*****
; DISKLESS CYCLE
; DO A MAITENENCE WRITE
; AND A MAITENENCE READ
; AND CHECK THE DATA
;*****
CYCLEL: JSR PC,MAITW ;DO A MAINTENENCE WRITE
JSR PC,MAITR ;DO A MAINTENENCE READ
BIT #SR.CMP,SR1 ;DO A DATA COMPARE?

```

```
114 003140 001004      BNE      21$           ;IF NOT, SKIP THE COMPARE
115 003142 104412 000000' 000126'   CDATE$,BEGIN,RBUFPA ; REQUEST FOR MONITOR TO CHECK DATA
      003150 003152'           .+2           ; IF ERROR, CONTINUE
116 003152           21$:          RTS      PC
117 003152 000207
```



```

1
2
3
4
5
6
7
8
9
10
11 003154
12 003154 032767 002000 174634
13 003162 001467
14 003164
15 003164 104417 000000
16 003170 016746 174660
17 003174 104417 000000
18 003200 016746 174650
19
20
21
22 003204 000241
23 003206 042716 100000
24 003212 012667 175352
25 003216 005767 175352
26 003222 001430
27
28 003224 016700 175344
29 003230 005100
30 003232 012701 100000
31 003236 030100
32 003240 001403
33 003242 000241
34 003244 006001
35 003246 000773
36 003250 040100
37 003252 000241
38 003254 006001
39 003256 001374
40 003260 040067 175304
41 003264 026767 175300 175302
42 003272 002420
43 003274 001405
44 003276 006267 175266
45 003302 000414
46
47
48
49 003304 005067 175260
50 003310 005767 175256
51 003314 001406
52 003316 166716 175250
53 003322 103375
54 003324 066716 175242
55 003330 000401
56 003332 005016
57 003334 012667 175226

```

```

.....
;
; PICK A BLOCK TO WRITE TO.
;
; EITHER PICK THE NEXT SEQUENTIAL BLOCK (DEFAULT) OR TAKE ONE AT
; RANDOM.
;
; OUTPUT: FILL SECH & SECL (CURRENT SECTOR ADDR)
;
.....
PICKBK:
BIT @SP,SEQ,SR1 ;CHECK SR1 FOR RANDOM ACCESS MODE
BEQ SEQACC ;BR IF SEQUENTIAL ACCESS

RANACC:
RAND$,BEGIN
MOV RANUM,-(SP) ;GENERATE THE SECTOR ADDRESS
RAND$,BEGIN
MOV RANUM,-(SP) ;GENERATE THE SECTOR ADDRESS

;
; ADJUST HI ADDRESS FIRST
;
;
CLC ;CLEAR CARRY FOR ROTATE
BIC #100000,(SP) ;CLEAR UPPER BIT MAKES SURE VALUE'S
MOV (SP),SECH ;STORE IN SECTOR HI ADDRESS
TST UNSZH ;IS THE MAX SIZE 0?
BEQ 3$ ;IF 0, GET LOW SECTOR ADDRESS
; *** UNSZH > 0 IF CODE FALLS THROUGH HERE
MOV UNSZH,RO ;RO = MAX VALUE
COM RO ;RO COMPLEMENT, NOW FIND MS ZERO
MOV #100000,R1 ;R1 IS INDEX INTO MAX VALUE
1$: BIT R1,RO ;HAVE 0 YET?
BEQ 2$ ;IF 1ST 0 REACHED, CLEAR REST OF THE BITS
CLC ;CLEAR CARRY FOR ROR
ROR R1 ;POINT TO NEXT BIT
BR 1$ ;BRANCH TO TEST AGAIN
2$: BIC R1,RO ;CLEAR REST OF THE BITS
CLC ;CLEAR CARRY FOR ROR
ROR R1 ;IF R1 ROTATES INTO CARRY, R1 = 0
BNE 2$ ;IF R1 NOT 0, MORE BITS TO CLEAR
BIC RO,SECH ;CLEAR UPPER BITS OF HIGH SECTOR VALUE
CMP SECH,UNSH ;IF THE HIGH SECTOR VALUE > MAX VALUE?
BLT 7$ ;IF <, EXIT
BEQ 4$ ;IF =, TEST LOW ORDER VALUE
ASR SECH ;SECH = SECH/2 CAN'T BE > MAX NOW
BR 7$ ;EXIT

;
; GET LOW SECTOR ADDRESS
;
3$: CLR SECH ;CLEAR HI SECTOR SIZE
TST UNSZL ;IS THE HIGHEST POSSIBLE = 0?
BEQ 6$ ;IF TRUE, DON'T DO LOOP
5$: SUB UNSZL,(SP) ;ELSE, SECL = SECL - UNSZL (ADJUST)
BCC 5$ ;IF UNSZL > SECL, LOOP
ADD UNSZL,(SP) ;ELSE SUBTRACTED ONCE TOO OFTEN
BR 7$ ; AND EXIT
6$: CLR (SP) ;CLEAR LO SECTOR ADDRESS (IF HIGHEST POSSIBLE = 0)
7$: MOV (SP),SECL ;SAVE LO SECTOR ADDRESS

```

```

58 003340 000207          RTS      PC          ; RETURN
59
60
61          ;GENERATE DISK ADDRESS BY SEQUENTIAL ADDRESSING
62
63 003342          SEQACC:
64 003342 005267 175220    INC      SECL          ; INCREMENT THE SECTOR ADDRESS
65 003346 001405          BEQ      16$          ; BR IF ZERO
66 003350 026767 175212 175214  CMP     SECL,UNSZL     ; OVER LIMIT?
67 003356 103413          BLO     18$          ; BR IF LOWER
68 003360 000402          BR      17$          ; SKIP THE INCREMENT
69 003362          16$:
70 003362 005267 175202    INC      SECH          ; INCREMENT SECTOR HIGH ADDRESS
71 003366          17$:
72 003366 026767 175176 175200  CMP     SECH,UNSZH     ; OVER LIMIT?
73 003374 103404          BLO     18$          ; BR IF LOWER
74 003376 005067 175164    CLR     SECL          ; RESET THE STARTING SECTOR ADDRESS
75 003402 005067 175162    CLR     SECH          ;
76
77 003406          18$:
78 003406 000207          RTS      PC

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31

32
33

34
35
36
37
38
39
40
41
42
43
44
45
46

```

.....
;
; DROP A DRIVE
;
; A DRIVE WOULDN'T RESPOND, DROP IT. SET THIS UP IN DVICE.
;
; INPUT UNITNO = UNIT NUMBER OF DRIVE TO DROP
;        PORTID = BIT SET TO DROP DRIVE
;
; OUTPUT DVICE HAS A BIT CLEARED. THE BIT POSITION
;        REPRESENTS THE DRIVE
;
.....

```

```

16 003410          DROP1:  MOV    #1,NUM
17 003410 012767 000001 175036 BR    DROP4
18 003416 000407
19 003420          DROP2:  MOV    #2,NUM
20 003420 012767 000002 175026 BR    DROP4
21 003426 000403
22 003430          DROP3:  MOV    #3,NUM
23 003430 012767 000003 175016
24 003436 036767 175144 175134 DROP4: BIT    PORTID,DVICE      ;HAS THE DRIVE BEEN DROPPED, DON'T DROP AGAIN
25 003444 001445          BEQ    10$
26 003446 022767 177777 175132          CMP    #177777,PORTID      ;IF DRIVE HAS BEEN DROPPED, DON'T DROP AGAIN
;                                (WILL ZERO DVICE PREMATURE)
27
28 003454 001441          BEQ    10$      ;IF -, DRIVE HAS BEEN DROPPED > EXIT ROUTINE
29
30 003456 046767 175124 175114          BIC    PORTID,DVICE      ;DROP THE DRIVE
31
;.....
;CONVERT UNITNO TO ASCII AND
;STORE AT ADR2
003464 104421 000000' 000602' BTOD$,BEGIN,UNITNO,ADR2
003472 000475'
;.....
32 003474 105067 175002          CLRB  ADR2+5
33
;.....
;CONVERT PORTID TO ASCII AND
;STORE AT ADR1
003500 104420 000000' 000606' OTOA$,BEGIN,PORTID,ADR1
003506 000466'
;.....
34 003510 012764 177777 000002          MOV    #177777,2(R4)      ;DESELECT DRIVE SO IT WON'T BE USED AGAIN.
35 003516 005367 174732          DEC    NUM                ;DROPPED FOR WHICH ERROR?
36 003522 001004          BNE    1$                 ;IF NOT FOR ERRORS, CONTINUE
37 003524 104403 000000' 005242'          MSGN$,BEGIN,DRP1          ;ASCII MESSAGE CALL WITH COMMON HEADER
38 003532 000412          BR    10$
39 003534 005367 174714          1$: DEC    NUM                ;WAS UNIT NOT FOUND?(NON EXISTENT UNIT)
40 003540 001004          BNE    2$                 ;IF NOT, CONTINUE
41 003542 104403 000000' 005260'          MSGN$,BEGIN,DRP2          ;ASCII MESSAGE CALL WITH COMMON HEADER
42 003550 000403          BR    10$
43 003552          2$: MSGN$,BEGIN,DRP3          ;ASCII MESSAGE CALL WITH COMMON HEADER
003552 104403 000000' 005276'          ; ACTUAL UNITS FOUND
44
45 003560 000207          10$: RTS    PC
46

```


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

```

:*****:
:      :
:      MAITENENCE READ      :
:      :
:      SET UP A PACKET WITH:  :
:      OPCODE & MODIFIER      :
:      REGION ID & REGION OFFSET :
:      READ BUFFER DESCRIPTOR  :
:      BYTE COUNT             :
:      THEN SEND THE PACKET   :
:*****:

```

```

13 003562 004767 001066
14 003566 012767 000030 174576
15 003574 016767 174650 174602
16 003602 016767 174320 174572
17 003610 016700 174316
18 003614 000424

```

```

MAITR: JSR PC,CLRPAK ;CLEAR THE PACKETS
        MOV #OP.MRD,P.OPCD+CMACK ;SET THE OPCODE
        MOV RBFFEA,P.ADEA+CMACK ;SET THE BUFFER DESCRIPTOR
        MOV RBUFPA,P.ADPA+CMACK ;
        MOV RBUFSZ,RO ;STORE THE BUFFER SIZE IN WORDS
        BR MAITP ;SET UP THE REST OF THE PACKET

```

```

:*****:
:      :
:      MAITENENCE WRITE     :
:      :
:      SET UP A PACKET WITH:  :
:      OPCODE & MODIFIER      :
:      REGION ID & REGION OFFSET :
:      WRITE BUFFER DESCRIPTOR  :
:      BYTE COUNT (EITHER WBUFSZ OR LIMIT IF WBUFSZ > LIMIT) :
:      THEN SEND THE PACKET   :
:*****:

```

```

33 003616 004767 001032
34 003622 012767 000031 174542
35 003630 016767 174616 174546
36 003636 016767 174272 174536
37 003644 026767 174272 174724
38 003652 100403
39 003654 016700 174716
40 003660 000402
41 003662 016700 174254
42 003666 006300
43 003670 010067 174502
44 003674 012767 000020 174370
45 003702 012767 000044 174446
46 003710 012767 000001 174500
47 003716 012767 177777 174434
48 003724 012767 177777 174342
49 003732 000167 00032?

```

```

MAITW: JSR PC,CLRPAK ;CLEAR THE PACKETS
        MOV #OP.MWR,P.OPCD+CMACK ;SET THE OPCODE
        MOV WBFFEA,P.ADEA+CMACK ;SET THE BUFFER DESCRIPTOR
        MOV WBUFPA,P.ADPA+CMACK ;
        CMP WBUFSZ,LIMIT ;IS THE BUFFER SIZE > LIMIT?
        BMI 16 ;IF NOT, WBUFSZ IS OK
        MOV LIMIT,RO ;STORE THE BUFFER SIZE IN WORDS
        BR MAITP ;AND SKIP
16: MOV WBUFSZ,RO ;STORE THE BUFFER SIZE IN WORDS
MAITP: ASL RO ;MAKE IT NUMBER OF BYTES
        MOV RO,P.BCNT+CMACK ;SET WRITE BUFFER SIZE
        MOV #16,RSPLN ;SET RESPONSE PACKET LENGTH
        MOV #36,CMPLEN ;SET COMMAND PACKET LENGTH
        MOV #1,P.RGID+CMACK ;SET REGION ID = 1
        MOV #177777,CMPVIR ;SET COMMAND VIRTUAL CIRCUIT ( 1 FOR DM)
        MOV #177777,RSPVIR ;SET COMMAND VIRTUAL CIRCUIT
        JMP SEND ;SEND THE PACKET

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41

003736	004767	000712	
003742	012767	000042	174422
003750	016700	174166	
003754	016767	174154	174420
003762	016767	174464	174414
003770	000415		
003772	004767	000656	
003776	012767	000041	174366
004004	016700	174122	
004010	016767	174434	174366
004016	016767	174104	174356
004024	012767	000040	174240
004032	012767	000040	174316
004040	006300		
004042	010067	174330	
004046	016767	174514	174342
004054	016767	174510	174336
004062	000476		

```

*****
:
:   WRITE
:
:   SET UP OP CODE, MODIFIERS,BUFFER SIZE (BYTE COUNT),
:   BUFFER DESCRIPTOR (PYSICAL AND EXTENDED ADDRESS)
:   LET READ SET SIMULAR DATA IN THE PACKET;
:   DISK ADDRESS AND CYLINDER ID (LOGICAL BLOCK NUMBER),
:   THEN SEND THE PACKET.
:
*****

```

```

WRITE:  JSR      PC,CLRPAK          ;CLEAR PACKETS
        MOV      #OP.WR,P.OPCD.CMPACK ;SET THE OPCODE
WRITEA: MOV      WBUFZ,R0          ;STORE THE BUFFER SIZE IN WORDS
        MOV      WBUFPA,P.ADPA.CMPACK ;SET THE BUFFER DESCRIPTOR(PA)
        MOV      WBFEEA,P.ADEA.CMPACK ;SET THE BUFFER DESCRIPTOR(EA)
        BR       READA           ;

```

```

*****
:
:   READ
:
:   SET UP OP CODE, MODIFIERS,BUFFER SIZE (BYTE COUNT),
:   BUFFER DESCRIPTOR (PYSICAL AND EXTENDED ADDRESS),
:   DISK ADDRESS AND CYLINDER ID (LOGICAL BLOCK NUMBER),
:   THEN SEND THE PACKET.
:
*****

```

```

READ:   JSR      PC,CLRPAK          ;CLEAR PACKETS
        MOV      #OP.RD,P.OPCD.CMPACK ;SET THE OPCODE
        MOV      RBUFZ,R0          ;STORE THE BUFFER SIZE IN WORDS
        MOV      RBFFEA,P.ADEA.CMPACK ;SET THE BUFFER DESCRIPTOR
        MOV      RBUFPA,P.ADPA.CMPACK ;
READA:  MOV      #32.,RSPLN        ;SET RESPONCE PACKET LENGTH
        MOV      #32.,CMPLN       ;SET COMMAND PACKET LENGTH
        ASL      R0                ;MAKE IT NUMBER OF BYTES
        MOV      R0,P.BCNT.CMPACK  ;SET READ BUFFER SIZE
        MOV      SECL,P.LBN.CMPACK ;SET LOGICAL BLOCK NUMBER
        MOV      SECH,P.LBN+2.CMPACK ;
        BR       SEND             ;SEND THE PACKET

```

MODULE CODE

```

1
2
3
4
5
6
7
8 004064 004767 000564
9 004070 012767 000013 174274
10 004076 012767 000074 174166
11 004104 012767 000074 174244
12 004112 000462
13
14
15
16
17
18
19
20
21 004114 004767 000534
22 004120 012767 000010 174244
23 004126 012767 000014 174136
24 004134 000413
25
26
27
28
29
30
31
32
33
34 004136 004767 000512
35 004142 012767 000003 174222
36 004150 012767 000001 174216
37 004156 012767 000060 174106
38 004164 012767 000014 174164
39 004172 000432

```

```

;*****
;
;   DETERMINE ACCESS PATHS
;
;   SET UP CODE, GO SEND PACKET
;*****
DAP: JSR PC,CLRPAK ;CLEAR PACKETS
      MOV #OP.DAP,P.OPCD+CMACK ;SET OPCODE
      MOV #60.,RSPLN ;SET LENGTHS
      MOV #60.,CMPLN ;
      BR SEND ;SEND THE PACKET
;*****
;
;   AVAILABLE PACKET
;
;   SET OP CODE AND MODIFIERS THEN SEND THE PACKET
;*****
AVAILB: JSR PC,CLRPAK ;CLEAR PACKETS
         MOV #OP.AVL,P.OPCD+CMACK ;SET THE OPCODE
         MOV #12.,RSPLN ;SET RESPONCE PACKET LENGTH
         BR GTSTAA ;SEND THE PACKET
;*****
;
;   GET UNIT STATUS
;
;   SET OPCODE AND MODIFIER (FOR THEN NEXT UNIT
;   THEN SEND THE PACKET
;*****
GTSTAT: JSR PC,CLRPAK ;CLEAR PACKETS
         MOV #OP.GUS,P.OPCD+CMACK ;SET THE OPCODE
         MOV #MD.NXU,P.MOD+CMACK ;CLEAR MODIFIERS
         MOV #48.,RSPLN ;SET RESPONCE PACKET1 LENGTH
GTSTAA: MOV #12.,CMPLN ;SET COMMAND PACKET LENGTH
         BR SEND ;SEND THE PACKET
;*****

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

```
*****  
: SET CONTROLLER CHARACTERISTICS ;  
:  
: SET OP CODE AND CONTROLLER FLAG (ENABLE ATTENTION MSGS)  
: CLEAR MSCP VERSION, HOST TIMEOUT, USE FRACTION,  
: AND ALL OF QUAD WORD TIME AND DATE.  
: THEN SEND PACKET  
:*****
```

004174
004174 004767 000454 174150
004200 012767 000040 174056
004206 012767 000034 174056
004214 012767 000004 174150
004222 012767 000200 174150
004230 000413

```
SCC: JSR PC,CLRPAK ;GO CLEAR THE COMMAND PACKET  
MOV #32.,CMPLEN ;SET UP COMMAND PACKET LENGTH  
MOV #28.,RSPLN ;SET UP RESPONSE PACKET LENGTH  
MOV #OP.SCC,P.OPCD+CMACK ;SET THE OPCODE  
MOV #CF.AVL,P.CNTF+CMACK ;SET THE CONTROLLER FLAGS  
; TO ENABLE ATTENTION MSGS  
BR SEND ;SEND THE PACKET
```

```
*****  
: ONLINE ;  
:  
: SET OPCODE, MODIFIERS, UNIT ID, HOST ID  
: SHADOW UNIT, ERROR FLAGS  
: THEN SEND PACKET  
:*****
```

004232 004767 000416 174026
004236 012767 00004C 174104
004244 012767 000044 174104
004252 012767 000011 174112

```
ONLINE: JSR PC,CLRPAK ;CLEAR PACKETS  
MOV #32.,RSPLN ;SET RESPONSE PACKET LENGTH  
MOV #36.,CMPLEN ;SET COMMAND PACKET LENGTH  
MOV #OP.ONL,P.OPCD+CMACK ;SET THE OPCODE
```


MODULE CODE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55

004260	005267	174004	
004264	001775		
004266	016767	173776	174066
004274	016767	174302	174064
004302	042767	040000	173756
004310	052767	100000	173750
004316	052767	140000	173736
004324	005777	173456	
004330			
004330	104400	000000	
004334			
004334	000004	000000	004342
004342			
004342	005067	173710	
004346	022767	000100	173732
004354	001524		
004356	022767	000102	173722
004364	001527		
004366			
004366	016700	173716	
004372	001513		
004374	042700	177740	
004400	001510		
004402	005067	173500	
004406	122700	000013	
004412	001015		
004414	032767	001000	173374
004422	001472		
004424	022767	000053	173656
004432	001464		
004434	022767	000113	173646
004442	001460		
004444	000461		

SEND - SEND A PACKET
INTERP - WAIT FOR AN INTERRUPT

SET UP THE COMMAND REFERENCE NUMBER AND UNITNO IN THE PACKET
SET OWN, CLEAR FLAG IN THE COMMAND RING (FOR CONTROLLER)
SET OWN & FLAG IN MESSAGE RING (FOR INTERRUPTS BY CONTROLLER)
AFTER INTERRUPT, MAKE SURE THE PACKET WAS PROCESSED (NO HARD
OR SOFT ERRORS) THEN RETURN TO CYCLED.

INPUT: CMPACK IS FILLED EXCEPT FOR CMDREF & UNITNO
INTERRUPT VECTOR AND BR LEVEL ARE ESTABLISHED

OUTPUT: MSPACK IS FILLED
CLEAR CARRY IF COMMAND PACKET WAS OK
ELSE GO DO A HARD/SOFT ERROR

```

SEND:  INC    CMDREF      ;NEW COMMAND REFERENCE NUMBER
        BEQ    SEND       ;COMMAND REF # CANNOT = 0
        MOV    CMDREF,P.CRF+CMPPACK ;SET COMMAND REF NUMBER
        MOV    UNITNO,P.UNIT+CMPPACK ;SET UNIT NUMBER
        BIC    @RG.FLG,COMMND*2     ;CLEAR FLAG
        BIS    @RG.OWN,COMMND*2     ;SET OWN FOR COMMAND RING
        BIS    @<RG.OWN+RG.FLG>,RSPONC*2 ;SET OWN AND FLAG FOR MESSAGE RING
        TST    @ADDR            ;FORCE POLLING TO PACKET

```

INTERP: EXIT\$,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.

```

;INTERRUPT:
;-----
;PIRQ$,BEGIN,1$ ; QUEUE UP TO CONTINUE AT 1$ AND RTI
;-----

```

```

1$:
CLR     RINTR            ;CLEAR INTERRUPT FLAG
CMP     @OP.AVA,P.OPCD+RSPACK ;WAS AN AVAILABLE ATTENTION RECIEVED?
BEQ     15$              ;IF IT WAS, EXIT
CMP     @OP.ACP,P.OPCD+RSPACK ;WAS THE ACCESS PATH ATTENTION RECIEVED?
BEQ     16$              ;IF IT WAS, GO PROCESS
                     ; ELSE CHECK SUCCESS

```

```

2$:
MOV     P.STS+RSPACK,R0   ; SUCCESS?
BEQ     14$              ;IF YES, EXIT
BIC     @177740,R0        ;CLEAR UPPER 11 BITS OF SUB-STATUS
BEQ     14$              ;IF SUCCESS = 0, EXIT OK
CLR     ERRYP            ;IF GOT HERE, ERROR
CMPB    @ST.DRV,R0       ; DRIVE ERROR?
BNE     3$               ;IF NOT NEXT TEST
BIT     @SR.DUA,SR1     ;ARE WE DUAL PORTING?
BEQ     12$              ;IF NOT, GO REPORT ERROR/ELSE EXPECTED
CMP     @<ST.DRV+SC.STO>,P.STS+RSPACK ;IS IT AN SDI RESPONSE TIMEOUT?
BEQ     10$              ;IF TRUE, DRIVE IS NOT ONLINE, EXIT
CMP     @<ST.DRV+SC.INV>,P.STS+RSPACK ;IS IT THE INVALID SDI RESPONSE?
BEQ     10$              ;IF TRUE, DRIVE IS NOT ONLINE, EXIT
BR      12$              ;ELSE HARD ERROR

```

DURD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page 26 1
MODULE CODE

```

56 004446          3$:      CMPB      #ST.CNT,RO      ; CONTROLLER ERROR?
57 004446 122700 000012      BNE      4$      ; IF NOT NEXT TEST
58 004452 001004          MOV      #ERR.3,ERRTYP  ; ELSE, SET ERROR TYPE
59 004454 012767 000003 173424 BR      ERRORH    ; AND HARD ERROR
60 004462 000531          4$:      CMPB      #ST.HST,RO      ; HOST BUFFER ACCESS ERROR?
61 004464          BNE      5$      ; IF NOT NEXT TEST
62 004464 122700 000011      MOV      #ERR.32,ERRTYP  ; ELSE, SET ERROR TYPE
63 004470 001004          BR      ERRORH    ; AND HARD ERROR
64 004472 012767 000032 173406
65 004500 000522          5$:      CMPB      #ST.DAT,RO      ; DATA ERROR?
66 004502          BNE      6$      ; IF NOT NEXT TEST
67 004502 122700 000010      MOV      #ERR.1,ERRTYP  ; ELSE, SET ERROR TYPE
68 004506 001004          BR      ERRORS    ; AND SOFT ERROR
69 004510 012767 000001 173370
70 004516 000533          6$:      CMPB      #ST.WPR,RO      ; WRITE PROTECTED?
71 004520          BEQ      12$     ; ELSE HARD ERROR
72 004520 122700 000006
73 004524 001431          8$:      CMPB      #ST.AVL,RO      ; STILL AVAILABLE?
74 004526          BNE      9$      ; IF NOT NEXT TEST
75 004526 122700 000004      CMP      #OP.GUS,P.OPCD+CMPACK ; ELSE, IF COMMAND WAS
76 004532 001005          ; GET UNIT STATUS
77 004534 022767 000003 173630 BEQ      14$     ; THEN EXPECTED & LEAVE ROUTINE
78          BR      12$     ; ELSE HARD ERROR
79 004542 001427
80 004544 000421          9$:      CMPB      #ST.OFL,RO      ; UNIT OFFLINE?
81 004546          BNE      13$     ; IF NOT NEXT TEST
82 004546 122700 000003      ; *** OFFLINE WHEN TRIED ONLINE OR GET UNIT STATUS
83 004552 001022      CMP      #OP.ONL,P.OPCD+CMPACK ; WAS IT AN ONLINE COMMAND?
84          BEQ      10$     ; IF SO, SET CARRY/EXIT
85 004554 022767 000011 173610 CMP      #OP.GUS,P.OPCD+CMPACK ; IS IT GET UNIT STATUS COMMAND?
86 004562 001410          BEQ      10$     ; IF SO, SET CARRY/EXIT
87 004564 022767 000003 173600 CMP      #OP.WR,P.OPCD+CMPACK ; IS IT WRITE COMMAND?
88 004572 001404          BEQ      10$     ; IF NOT, REPORT HARD ERROR
89 004574 022767 000042 173570 BNE      12$     ; ELSE, SET CARRY TO
90 004602 001002          10$:     SEC      ; AND RETURN TO DROP DRIVE/AWAIT AVAILABLE DRIVE
91 004604 000261          RTS      PC
92 004606 000207      ; *** HARD ERROR EXIT WITH ERROR TYPE = 6
93          12$:     MOV      #ERR.6,ERRTYP  ; ELSE, SET ERROR TYPE
94 004610          BR      ERRORH    ; AND HARD ERROR
95 004610 012767 000006 173270
96 004616 000453      ; *** SOFT ERROR EXIT WITH ERROR TYPE = 0
97          13$:     BR      ERRORS    ; ERROR WITH ERRTP = 0 & IS A SOFT ERROR
98 004620          ; ST.CMP,ST.MFE,..ST.ABO,ST.CMD
99 004620 000472
100          ; *** SUCCESSFUL EXIT
101          14$:     CLC
102 004622          RTS      PC      ; CLEAR CARRY 'CAUSE PACKET IS OK
103 004622 000241          ; ELSE, OK, SO FAR.
104 004624 000207
105 004626          15$:     ; *** WAIT FOR ATTENTION INTERRUPT
106          ; *** DID WE GET AN AVAILABLE ATTENTION MESSAGE THAT WE EXPECTED?
107          TST      EXPV
108 004626 005767 173632      BNE      16$     ; IF EXPV IS NOT 0, WE GOT ONE WE DIDN'T EXPECT
109 004632 001004          MOV      #177777,EXPV  ; CLEAR EXPECTED AVAILABLE ATTENTION MESSAGE WORD
110 004634 012767 177777 173622 BR      14$     ; AND RETURN
111 004642 000767
112 004644          16$:

```

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page 26-2
MODULE CODE

113 004644 052767 140000 173410
114 004652 000626
115

BIS @<RG.OWN+RG.FLG>,RSPONC+2 ;
BR INTERP ;WAIT FOR RESPONSE OF LAST PACKET SENT

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15

16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

```

;*****
;
; CLEAR PACKETS
;
; ASSUMPTION: 1) RESPONSE BUFFER PRECEDES THE COMMAND BUFFER
;              2) TWO WORDS BEFORE EACH BUFFER IS FOR LENGTH
;                OF PACKET AND VIRTUAL CIRCUIT
;
; OUTPUT: R2 = 0 WHEN DONE
;         R5 = END OF COMMAND PACKET WHEN DONE
;*****
CLRPAK:
MOV    @SAREG,NUM          ;IF SA REG NOT ZERO, STORE IN NUM
BEQ    5$                  ;IF SA REG IS ZERO, CLEAR PACKETS
;*****
;CONVERT NUM TO ASCII AND
;STORE AT ADR1
OTOA$,BEGIN,NUM,ADR1
;*****
MSGN$,BEGIN,SANOTO        ;ASCII MESSAGE CALL WITH COMMON HEADER
MOV    R3,-(SP)           ;SAVE R3
MOV    R4,-(SP)           ;SAVE R4
JSR    PC,INITUD          ;RE INIT SA REGISTER
MOV    (SP)+,R3           ;RESTORE R3
MOV    (SP)+,R4           ;RESTORE R4
JSR    PC,SCC             ;SET CONTROLLER CHARS AGAIN
INC    HRDCNT             ;INCREMENT HARD ERROR COUNT
;DOING THIS WILL CAUSE ANOTHER CALL TO CLRPAK
5$:   MOV    #52.,R2       ;R2 = # OF WORDS TO CLEAR
MOV    @RSPLN,R5          ;R5 -> RSPLN, 1ST WORD TO CLEAR
6$:   CLR    (R5)+         ;CLEAR WORD
DEC    R2                 ;R2 = ZERO? (DONE CONDITION)
BNE    6$                 ;IF NOT ZERO, LOOP
RTS    PC                 ;RETURN
;*****
;
; HARD ERROR CARRY WILL BE SET
;*****
ERRORH:
BIT    @SR.REP,SR1        ;DO WE REPORT THE ERROR?
BEQ    7$                 ;IF SO, REPORT
INC    HRDCNT             ;ELSE, INCREMENT THE HARD ERROR
; COUNT IF NOT REPORTED
BR     8$                 ;SKIP REPORT
7$:   JSR    PC,SETTAB     ;SET UP TABLE
;*****
HRDR$,BEGIN,NULL
;*****
8$:   JSR    PC,PRINTE
SEC
RTS    PC                 ;RETURN TO CYCLED
;*****
;

```

12	004654			
13	004654	017767	173372	173572
14	004662	001421		
15				
16	004664	104420	000000'	000454'
	004672	000466'		
16	004674	104403	000000'	005334'
17	004702	010346		
18	004704	010446		
19	004706	004767	174532	
20	004712	012603		
21	004714	012604		
22	004716	004767	177252	
23	004722	005267	173116	
24				
25	004726	012702	000064	5\$:
26	004732	012705	000272'	
27	004736	005025		6\$:
28	004740	005302		
29	004742	001375		
30	004744	000207		
37	004746			
38	004746	032767	000004	173042
39	004754	001403		
40	004756	005267	173062	
41				
42	004762	000407		
43	004764	004767	000056	7\$:
44				
	004770	104405	000000'	000000
45	004776	004767	000070	
46	005002	000261		
47	005004	000207		

```

51          ;          SOFT ERROR          CARRY WILL BE SET          ;
52          ;          ;          ;          ;          ;          ;          ;          ;          ;
53          ;          ;          ;          ;          ;          ;          ;          ;          ;
54 005006   ;          ;          ;          ;          ;          ;          ;          ;          ;
55 005006   032767 000004 173002   ;          ;          ;          ;          ;          ;          ;
56 005014   001403   ;          ;          ;          ;          ;          ;          ;          ;
57 005016   005267 173020   ;          ;          ;          ;          ;          ;          ;
58          ;          ;          ;          ;          ;          ;          ;          ;          ;
59 005022   000407   ;          ;          ;          ;          ;          ;          ;          ;
60 005024   004767 000016   9%:  ;          ;          ;          ;          ;          ;          ;
61          ;          ;          ;          ;          ;          ;          ;          ;          ;
62 005030   104406 000000' 000000   ;          ;          ;          ;          ;          ;          ;
63          ;          ;          ;          ;          ;          ;          ;          ;          ;
64 005036   004767 000030   ;          ;          ;          ;          ;          ;          ;
65 005042   000261   ;          ;          ;          ;          ;          ;          ;          ;
66 005044   000207   ;          ;          ;          ;          ;          ;          ;          ;
67          ;          ;          ;          ;          ;          ;          ;          ;          ;
68          ;          ;          ;          ;          ;          ;          ;          ;          ;
69          ;          ;          ;          ;          ;          ;          ;          ;          ;
70          ;          ;          ;          ;          ;          ;          ;          ;          ;
71          ;          ;          ;          ;          ;          ;          ;          ;          ;
72          ;          ;          ;          ;          ;          ;          ;          ;          ;
73 005046   ;          ;          ;          ;          ;          ;          ;          ;          ;
74 005046   016767 172734 173024   ;          ;          ;          ;          ;          ;          ;
75 005054   016767 173230 173022   ;          ;          ;          ;          ;          ;          ;
76 005062   017767 173164 173012   ;          ;          ;          ;          ;          ;          ;
77 005070   000207   ;          ;          ;          ;          ;          ;          ;          ;
78          ;          ;          ;          ;          ;          ;          ;          ;          ;
79          ;          ;          ;          ;          ;          ;          ;          ;          ;
80          ;          ;          ;          ;          ;          ;          ;          ;          ;
81          ;          ;          ;          ;          ;          ;          ;          ;          ;
82          ;          ;          ;          ;          ;          ;          ;          ;          ;
83          ;          ;          ;          ;          ;          ;          ;          ;          ;
84          ;          ;          ;          ;          ;          ;          ;          ;          ;
85 005072   ;          ;          ;          ;          ;          ;          ;          ;          ;
86          ;          ;          ;          ;          ;          ;          ;          ;          ;
87          ;          ;          ;          ;          ;          ;          ;          ;          ;
88          ;          ;          ;          ;          ;          ;          ;          ;          ;
89          ;          ;          ;          ;          ;          ;          ;          ;          ;

```

```

                                ;STORE AT ADR4
005122 104420 000000' 000312'   OTOA$,BEGIN,P.BCNT.RSPACK,ADR4
005130 000513'
90 ;.....
;.....
                                ;CONVERT P.LBN-2.CMPACK TO ASCII AND
                                ;STORE AT ADR5
005132 104420 000000' 000420'   OTOA$,BEGIN,P.LBN-2.CMPACK,ADR5
005140 000522'
91 ;.....
;.....
                                ;CONVERT P.LBN.CMPACK TO ASCII AND
                                ;STORE AT ADR6
005142 104420 000000' 000416'   OTOA$,BEGIN,P.LBN.CMPACK,ADR6
005150 000531'
92 ;.....
;.....
                                ;CONVERT P.ADEA.CMPACK TO ASCII AND
                                ;STORE AT ADR7
005152 104420 000000' 000404'   OTOA$,BEGIN,P.ADEA.CMPACK,ADR7
005160 000540'
93 ;.....
;.....
                                ;CONVERT P.ADPA.CMPACK TO ASCII AND
                                ;STORE AT ADR8
005162 104420 000000' 000402'   OTOA$,BEGIN,P.ADPA.CMPACK,ADR8
005170 000547'
94 005172 104403 000000' 005376'   MSGN$,BEGIN,BANNER ;ASCII MESSAGE CALL WITH COMMON HEADER
95 005200 000207
96

```

1		.SBTTL MODULE MESSAGES
2	005202 005444	INITE1: MSG2
3	005204 005515	MSG4
4	005206 177777	177777
5		
6	005210 005475	INITER: MSG3
7	005212 000466	ADR1
8	005214 005675	MSG10
9	005216 000475	ADR2
10	005220 006023	MSG14
11	005222 000508	ADR3
12	005224 177777	177777
13		
14	005226 005444	INITE2: MSG2
15	005230 005542	MSG5
16	005232 177777	177777
17		
18	005234 005444	INITE3: MSG2
19	005236 005560	MSG6
20	005240 177777	177777
21		
22	005242 005652	DRP1: MSG8
23	005244 000475	ADR2
24	005246 005662	MSG9
25	005250 006245	MSG20
26	005252 000466	ADR1
27	005254 006732	MSGD1
28	005256 177777	177777
29		
30	005260 005652	DRP2: MSG8
31	005262 000475	ADR2
32	005264 005662	MSG9
33	005266 006245	MSG20
34	005270 000466	ADR1
35	005272 006776	MSGD2
36	005274 177777	177777
37		
38	005276 005652	DRP3: MSG8
39	005300 000475	ADR2
40	005302 005662	MSG9
41	005304 006245	MSG20
42	005306 000466	ADR1
43	005310 007040	MSGD3
44	005312 177777	177777
45		
46	005314 005707	ERRPAS: MSG11
47	005316 000475	ADR2
48	005320 005733	MSG12
49	005322 000504	ADR3
50	005324 005771	MSG13
51	005326 000466	ADR1
52	005330 005442	MSG1
53	005332 177777	177777
54		
55	005334 006105	SANOTO: MSG17
56	005336 000466	ADR1
57	005340 006142	MSG18

DUDD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page 28 1
 MODULE MESSAGES

58	005342	177777	177777
59			
60	005344	006034'	UNIOFF: MSG16
61	005346	000466'	ADR1
62	005350	177777	177777
63			
64	005352	006556'	WARN1: MSG40
65	005354	177777	177777
66			
67	005356	006433'	WARN2: MSG37
68	005360	177777	177777
69			
70	005362	006364'	WARN3: MSG36
71	005364	177777	177777
72			
73	005366	005615'	ABORT: MSG7
74	005370	177777	177777
75			
76	005372	006215'	ZERO: MSG19
77	005374	177777	177777
78			
79	005376	006270'	BANNER: MSG21
80	005400	000466'	ADR1
81	005402	006362'	MSG23
82	005404	000475'	ADR2
83	005406	006362'	MSG23
84	005410	000504'	ADR3
85	005412	006362'	MSG23
86	005414	000513'	ADR4
87	005416	006362'	MSG23
88	005420	000522'	ADR5
89	005422	006362'	MSG23
90	005424	000531'	ADR6
91	005426	006362'	MSG23
92	005430	000540'	ADR7
93	005432	006362'	MSG23
94	005434	000547'	ADR8
95	005436	005442'	MSG1
96	005440	177777	177777


```

1
2
3
4 005442      045      000      .SBTTL  MORE MODULE MESSAGES
5 005444      045      103      .NLIST  BEX
6 005475      045      123      MSG1:   .ASCIZ  '#
7 005515      106      117      MSG2:   .ASCIZ  '#CONTROLLER INIT ERROR, '
8 005542      123      101      MSG3:   .ASCIZ  '#SA REGISTER = '
9 005560      105      125      MSG4:   .ASCIZ  '#FOUND BY DIAGNOSTIC '
10 005615     045      105      MSG5:   .ASCIZ  '#STEP NOT SET.'
11 005652     045      120      MSG6:   .ASCIZ  '#EXPECTED DATA WAS INCORRECT '
12 005662     040      105      MSG7:   .ASCIZ  '#RETRY COUNT EXCEEDED, ABORT'
13 005675     040      122      MSG8:   .ASCIZ  '#DRIVE '
14 005707     045      104      MSG9:   .ASCIZ  '#DROPPED. '
15 005733     040      116      MSG10:  .ASCIZ  '# IN STEP '
16 005771     045      117      MSG11:  .ASCIZ  '#SOFT ERROR COUNT #'
17 006023     045      040      MSG12:  .ASCIZ  '*** HARD ERROR COUNT #'
18 006034     045      110      MSG13:  .ASCIZ  '#CHECK DATA ERROR COUNT #'
19 006105     045      104      MSG14:  .ASCIZ  '#ADDR = '
20 006142     045      116      MSG16:  .ASCIZ  '#UNIT WAS FOUND OFFLINE. UNIT NUMBER = '
21 006215     045      101      MSG17:  .ASCIZ  '#SA REGISTER IS NOT ZERO. = '
22 006245     045      117      MSG18:  .ASCIZ  '#CONTROLLER IS GOING THROUGH INITIALIZATION'
23 006270     045      111      MSG19:  .ASCIZ  '#RING AREA NOT CLEARED#'
24 006362     040      105      MSG20:  .ASCIZ  '#DEVICE ID BIT = '
25 006364     040      124      MSG21:  .ASCIZ  '#STATUS ENCOD UNITNU BYTECO HI LBN LO LBN EXTADR PHYADR#'
26 006433     007      040      MSG23:  .ASCIZ  ' '
27 006504     040      041      MSG36:  .ASCIZ  '# ! OPERATING WITH NO DISK ACCESSING !#'
28 006556     040      007      MSG37:  .ASCII  '<07><07>' ! CUSTOMER DATA WILL BE OVERWRITTEN !#'
29 006651     040      055      .ASCIZ  '-----#<07><07>'
30 006732     045      106      MSG40:  .ASCII  '# IF YOU WISH TO DESTROY CUSTOMER DATA, SET BIT1 (NOT BIT0)#'
31 006776     045      116      .ASCIZ  '# IN SWITCH REGISTER 1(SR1) OF DUBD? EQUAL TO 1.#'
32 007040     045      122      MSGD1:  .ASCIZ  '#ERRORS CAUSED DRIVE TO BE DROPPED#'
33          .EVEN
34 007126     045      116      MSGD2:  .ASCIZ  '#UNIT WAS NOT FOUND BY EXERCISER#'
35          .END
          RBUF:  .BLKW  256.          ;THE READ BUFFER
          .END
000001

```

Symbol table

ABORT 005366R
 ACSR 000102R
 ADDR 000006R
 ADDR22= 001000
 ADR1 000466R
 ADR2 000475R
 ADR3 000504R
 ADR4 000513R
 ADR5 000522R
 ADR6 000531R
 ADR7 000540R
 ADR8 000547R
 ASB 000106R
 ASR04 002034R
 ASTAT 000104R
 AVAILB 004114R
 AWAS 000110R
 BANNER 005376R
 BEGIN 000000R
 BIT0 = 000001
 BIT00 = 000001
 BIT01 = 000002
 BIT02 = 000004
 BIT03 = 000010
 BIT04 = 000020
 BIT05 = 000040
 BIT06 = 000100
 BIT07 = 000200
 BIT08 = 000400
 BIT09 = 001000
 BIT1 = 000002
 BIT10 = 002000
 BIT11 = 004000
 BIT12 = 010000
 BIT13 = 020000
 BIT14 = 040000
 BIT15 = 100000
 BIT2 = 000004
 BIT3 = 000010
 BIT4 = 000020
 BIT5 = 000040
 BIT6 = 000100
 BIT7 = 000200
 BIT8 = 000400
 BIT9 = 001000
 BREAK# = 104407
 BR1 000012R
 BR2 000013R
 BTOD# = 104421
 CDATA# = 104412
 CDERCT 000144R
 CDWDCT 000146R
 CF.AVL = 000200
 CF.MSC = 000100
 CF.OTH = 000040
 CF.SMD = 000002
 CF.TMS = 000020

CF.576 = 000001
 CINTR 000254R
 CLRPAK 004654R
 CMDREF 000270R
 CMPACK 000362R
 CMPLN 000356R
 CMPVIR 000360R
 COMMAND 000264R
 CONFIG 000056R
 CSRA 000100R
 CYCLED 002624R
 CYCLEL 003122R
 DAP 004064R
 DATCK# = 104411
 DATER# = 104404
 DOINTR 003104R
 DROP1 003410R
 DROP2 003420R
 DROP3 003430R
 DROP4 003436R
 DRP1 005242R
 DRP2 005260R
 DRP3 005276R
 DVICE 000600R
 DVID1 000014R
 EA 000446R
 EA22 000564R
 EF.BBR = 000200
 EF.BBU = 000100
 EF.FRS = 000200
 EF.LOG = 000040
 EF.LST = 000100
 EF.MIS = 000001
 EF.SEX = 000020
 ENDIT# = 104413
 END# = 104410
 ERRORH 004746R
 ERRORS 005006R
 ERROR1 002150R
 ERROR2 002146R
 ERROR3 002144R
 ERROR5 002132R
 ERRPAS 005314R
 ERRYTP 000106R
 ERR.0 = 000000
 ERR.1 = 000001
 ERR.3 = 000003
 ERR.32 = 000032
 ERR.6 = 000006
 EXIT# = 104400
 EXPVAV 000464R
 FREE 000150R
 GETPA# = 104415
 GTSTAA 004164R
 GTSTAT 004136R
 GMBUF# = 104414
 HC.CCT = 000006

HC.CMD = 000004
 HC.CPK = 000356R
 HC.RCT = 000002
 HC.RES = 000000
 HC.RPK = 000276R
 HC.SIZ = 000010
 HRDCNT 000044R
 HRDER# = 104405
 HRDPAS 000050R
 ICONT 000036R
 ICOUNT 000040R
 IDNUM 000122R
 IMODX. = 000000
 INIT 000030R
 ITER 005210R
 INITE1 005202R
 INITE2 005226R
 INITE3 005234R
 INITUD 001444R
 INTA 002072R
 INTERP 004330R
 INTR 000120R
 LIMIT 000576R
 LOOP1 001300R
 LOOP2 001330R
 L.CHVR = 000015
 L.CNTI = 000014
 L.CYL = 000034
 L.DATA = 000050
 L.ERLC = 000030
 L.EVNT = 000000
 L.GRP = 000040
 L.SCTR = 000042
 L.SLOT = 000002
 L.TRCK = 000041
 L.UHVR = 000027
 L.UNTI = 000016
 L.USVR = 000026
 L.VSER = 000044
 MAITP 003666R
 MAITR 003562R
 MAITW 003616R
 MAP22# = 104416
 MA10NC 001412R
 MD.CMP = 040000
 MD.ERR = 010000
 MD.EXP = 100000
 MD.FEU = 000001
 MD.NXU = 000001
 MD.SCH = 004000
 MD.SCL = 002000
 MD.SEC = 001000
 MD.SER = 000400
 MD.SPD = 000001
 MD.SSH = 000200
 MD.VOL = 000002
 MD.WBN = 000100

MD.WBV = 000040
 MODNAM 000000R
 MODSP 000252R
 MSGD1 006732R
 MSGD2 006776R
 MSGD3 007040R
 MSGN# = 104403
 MSGS# = 104402
 MSG# = 104401
 MSG1 005442R
 MSG10 005675R
 MSG11 005707R
 MSG12 005733R
 MSG13 005771R
 MSG14 006023R
 MSG16 006034R
 MSG17 006105R
 MSG18 006142R
 MSG19 006215R
 MSG2 005444R
 MSG20 006245R
 MSG21 006270R
 MSG23 006362R
 MSG3 005475R
 MSG36 006364R
 MSG37 006433R
 MSG4 005515R
 MSG40 006556R
 MSG5 005542R
 MSG6 005560R
 MSG7 005615R
 MSG8 005652R
 MSG9 005662R
 NTRUPT 004334R
 NULL = 000000
 NUM 000454R
 OLDEA 000460R
 OLDPA 000456R
 ONEFIL = 000001
 ONLINE 004232R
 OPEN = 000000
 OP.ABO = 000001
 OP.ACC = 000020
 OP.ACP = 000102
 OP.AVA = 000100
 OP.AVL = 000010
 OP.CCD = 000021
 OP.CMP = 000040
 OP.DAP = 000013
 OP.END = 000200
 OP.ERL = 000101
 OP.ERS = 000022
 OP.FLU = 000023
 OP.GCS = 000002
 OP.GUS = 000003
 OP.MRD = 000030
 OP.MWR = 000031

OP.ONL = 000011
 OP.RD = 000041
 OP.RPL = 000024
 OP.SCC = 000004
 OP.SMC = 000102
 OP.SUC = 000012
 OP.WR = 000042
 OTOA# = 104420
 PA 000444R
 PASCNT 000034R
 PA18 000556R
 PA22 000562R
 PICKBK 003154R
 PIRQ# = 000004
 PKTSIZ = 000060
 POPSP = 005726
 POPSP2 = 022626
 PORTID 000606R
 PRINTE 005072R
 PRNMSG 000462R
 PRTNUM = 000017
 PRTY = 000000
 PRTY0 = 000000
 PRTY1 = 000040
 PRTY2 = 000100
 PRTY3 = 000140
 PRTY4 = 000200
 PRTY5 = 000240
 PRTY6 = 000300
 PRTY7 = 000340
 PS = 177776
 PSW = 177776
 PUSH = 005746
 PUSH2 = 024646
 PWRFLG = 000002
 P.ADEA = 000022
 P.ADPA = 000020
 P.BCNT = 000014
 P.BUFF = 000020
 P.CMST = 000020
 P.CNCL = 000022
 P.CNT = 000006
 P.CNTF = 000016
 P.CNTI = 000024
 P.CPSP = 000042
 P.CRF = 000000
 P.CTMO = 000020
 P.CYL = 000050
 P.ELGF = 000034
 P.FBK = 000034
 P.FLGS = 000011
 P.GRP = 000046
 P.HSTI = 000020
 P.HTMO = 000020
 P.LBN = 000034
 P.LGDT = 000014
 P.MEDI = 000034

Symbol table

P.MLUN=	000014	RESTR1	001036R	SA.S1 =	004000	SR4	000024R	UF.CMW=	000002
P.MOD =	000012	RESTR1	001116R	SA.S2 =	010000	START	000660R	UF.INA=	040000
P.OPCD=	000010	RESTR2	001072R	SA.S3 =	020000	STAT	000026R	UF.RMV=	000200
P.OTRF=	000014	RES1	000056R	SA.S4 =	040000	ST.ABO=	000002	UF.RPL=	010000
P.RBN =	000014	RES2	000060R	SA.VCE=	000177	ST.AVL=	000004	UF.SCH=	004000
P.RBNS=	000056	RG.FLG=	040000	SA.VEC=	000177	ST.CMD=	000001	UF.SCL=	002000
P.RCTC=	000057	RG.OWN=	100000	SBADR	000102R	ST.CMP=	000007	UF.WBN=	000040
P.RCTS=	000054	RINTR	000256R	SCC	004174R	ST.CNT=	000012	UF.WPH=	020000
P.RGID=	000034	RLIM =	000004	SC.DIS=	000400	ST.DAT=	000010	UF.WPS=	010000
P.RGOF=	000040	RSPACK	000276R	SC.DUP=	000200	ST.DIA=	000037	UF.S76=	000004
P.SFTW=	000040	RSPLN	000272R	SC.INV=	000100	ST.DRV=	000013	UNIOFF	005344R
P.SHST=	000042	RSPONC	000260R	SC.IOP=	000100	ST.HST=	000011	UNITFL	000610R
P.SHUN=	000040	RSPVIR	000274R	SC.IOP=	000100	ST.MFE=	000005	UNITNO	000602R
P.STS =	000012	RSTRT	000112R	SC.NVL=	000040	ST.MSK=	000037	UNSZH	000574R
P.SZOF=	000012	R6	=#000006	SC.STO=	000040	ST.OFL=	000003	UNSZL	000572R
P.TIME=	000024	R7	=#000007	SECH	000570R	ST.SUB=	000040	VA	000442R
P.TRCK=	000044	SANOT0	005334R	SECL	000566R	ST.SUC=	000000	VECTOR	000010R
P.UNFL=	000016	SAREG	000252R	SEND	004260R	ST.WPR=	000006	WARN1	005352R
P.UNIT=	000004	SA.CMD=	034000	SEQACC	003342R	SVR0	000062R	WARN2	005356R
P.UNSZ=	000044	SA.CME=	000360	SETTAB	005046R	SVR1	000064R	WARN3	005362R
P.UNTI=	000024	SA.DIA=	000400	SETUP	002320R	SVR2	000066R	WASADR	000104R
P.USEF=	000022	SA.DIA=	000400	SNDSTP	002046R	SVR3	000070R	WFFEA	000452R
P.VRSN=	000014	SA.ERC=	003777	SOFcnt	000042R	SVR4	000072R	WBUFEA	000136R
P.VSER=	000050	SA.ERR=	100000	SOFER1=	104406	SVR5	000074R	WBUFPA	000134R
RANACC	003164R	SA.GO =	000001	SFPAS	000046R	SVR6	000076R	WBUFRQ	000140R
RAND\$ =	104417	SA.INE=	000200	SPOINT	000032R	SYSCNT	000052R	WBUFSZ	000142R
RANNUM	000054R	SA.INT=	000200	SPSIZ =	000040	TABLEW	000614R	WDFR	000116R
RBFFEA	000450R	SA.LFC=	040000	SR.CMP=	004000	TEND	000654R	WDT0	000114R
RBUF	007126R	SA.MAP=	000100	SR.DUA=	001000	TIMER =	002260	WORK	000612R
RBUFEA	000130R	SA.MCV=	000377	SR.REP=	000004	TIMEOUT=	005670	WRITE	003736R
RBUFPA	000126R	SA.NSI=	002000	SR.SEG=	002000	TRPDFD=	000022	WRITEA	003750R
RBUFSZ	000132R	SA.PRG=	000001	SR.SUM=	000010	TRY	000604R	XFLAG	000005R
RBUFVA	000124R	SA.Q22=	001000	SR.XFR=	000002	TSTOFL	002554R	XMEM	000560R
READ	003772R	SA.RSE=	000017	SR1	000016R	UF.CMR=	000001	ZERO	005372R
READA	004024R	SA.RSP=	003400	SR2	000020R				
		SA.SM =	000040	SR3	000022R				

. ABS. 000000 000 (RW,I,GBL,ABS,OVR)
 010126 001 (RW,I,LCL,REL,CON)

Errors detected: 0

*** Assembler statistics

Work file reads: 0
 Work file writes: 0
 Size of work file: 12704 Words (50 Pages)
 Size of core pool: 14336 Words (56 Pages)
 Operating system: RT-11 (Under RTEM !1)

Elapsed time: 00:00:54.00
 XDUBDO,XDUBDO/C=XDUBDO.DOC,DDXCOM.MAC,XDUBDO.MAC

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20-Sep-84 10:17 Page S-3
 Cross reference table (CREF V05.01)

ERRYP	4-30	26-46*	26-59*	26-64*	26-69*	26-95*
EXIT\$	4-30	16-132	26-29			
EXPAV	4-580	14-59*	19-35*	19-98*	26-108	26-110*
FREE	4-30					
GETPA\$	4-30	15-15	15-39	16-23	16-79	16-86
GTSTAA	24-24	24-380				
GTSTAT	18-30	19-30	19-68	24-340		
GWBUF\$	4-30	15-57	15-88			
HC.CCT	8-140					
HC.CMD	8-130					
HC.CPK	8-160					
HC.RCT	8-120					
HC.RES	8-110					
HC.RPK	8-150	8-16				
HC.SIZ	8-80					
HRDCNT	4-30	15-32	27-23*	27-40*		
HRDER\$	4-30	17-49	27-44			
HRDPAS	4-30					
ICONY	4-30					
ICOUNT	4-30					
IDNUM	4-30					
IMODX.	4-30	15-57	15-88			
INIT	4-30					
INITE1	17-38	28-20				
INITE2	17-42	28-140				
INITE3	17-46	28-180				
INITER	17-50	28-60				
INITUD	15-22	16-220	27-19			
INTA	16-128	16-1340				
INTERP	19-37	19-100	26-280	26-114		
INTR	4-30					
L.CHVR	13-130					
L.CNTI	13-110	13-120				
L.CYL	13-180					
L.DATA	13-230					
L.ERLC	13-170					
L.EVNT	13-90					
L.GRP	13-190					
L.SCTR	13-210					
L.SLOT	13-100					
L.TRCK	13-200					
L.UHVR	13-160					
L.UNTI	13-140					
L.USVR	13-150					
L.VSER	13-220					
LIMIT	5-160	22-37	22-39			
LOOP1	15-53	15-570	15-81			
LOOP2	15-630	15-78				
MA10NC	15-45	15-880	15-94			
MAITP	22-18	22-40	22-420			
MAITR	19-112	22-130				
MAITW	19-111	22-330				
MAP22\$	4-30					
MD.CMP	10-30					
MD.ERR	10-50					
MD EXP	10-40					

DUBD DEC/X11 SYSTEM EXERCISER M MACRO V05.01b Thursday 20 Sep 84 10:17 Page 5 6
 Cross reference table (CREF V05.01)

P.SHST	12-230	12-470						
P.SHUN	11-320	12-220	12-360					
P.STS	12-80	18-80	18-84	26-42	26-51	26-53	27-75	27-86
P.SZOF	12-560							
P.TIME	11-430							
P.TRCK	12-240							
P.UNFL	11-280	12-190	12-330					
P.UNIT	11-140	12-50	12-520	18-36	26-23*	27-88		
P.UNSZ	12-370	19-44	19-45					
P.UNTI	11-300	12-210	12-350					
P.USEF	11-424							
P.VRSN	11-390	12-410						
P.VSER	12-380							
PA	4-420	15-16	15-20	16-55	16-80	16-87		
PA18	5-50							
PA22	5-70							
PASCNT	4-30	15-27						
PICKBK	19-67	20-110						
PIRQ1	4-30	16-135	26-32					
PKTSIZ	8-90	8-16						
POPSP	4-30							
POPSP2	4-30							
PORTID	5-210	15-66*	18-25*	18-51*	21-24	21-26	21-30	21-33
PRINTE	27-45	27-62	27-850					
PRMSG	4-540	14-60*	15-27	15-29*				
PRTNUM	4-530	4-54	14-60	15-29				
PRTY	4-30							
PRTY0	4-3	4-30						
PRTY1	4-30							
PRTY2	4-30							
PRTY3	4-30							
PRTY4	4-3	4-30						
PRTY5	4-30							
PRTY6	4-30							
PRTY7	4-30							
PS	4-30							
PSW	4-30							
PUSH	4-30							
PUSH2	4-30							
PURFLG	4-30							
R6	4-30							
R7	4-30							
RANACC	20-140							
RAND1	4-30	14-65	20-15	20-17				
RANUM	4-30	14-66	20-16	20-18				
RBFFEA	4-450	15-42*	22-15	23-33				
RBUF	4-3	29-340						
RBUFEA	4-30	15-40						
RBUFPA	4-30	19-85	19-115	22-16	23-34			
RBUFSZ	4-30	22-17	23-32					
RBUFVA	4-30	15-39						
READ	19-80	23-300						
READA	23-17	23-350						
RES1	4-30							
RES2	4-30							
RESTR1	15-19	15-240						

