

FP11-F

FP11F FLTG PNT B  
CKFPBA0

AH-F635A-MC

COPYRIGHT 1980  
FICHE 1 OF 2

JAN 1980

digital  
MADE IN USA

This image shows a microfiche card with a grid of frames. Each frame contains a small, high-contrast image of a document page, likely containing technical or financial data. The frames are arranged in a regular grid pattern across the card. The text within the frames is too small to be legible, but the overall layout suggests a structured data set.

FP11-F

FP11F FLTG PNT B  
CKFPBA0

AH-F635A-MC

COPYRIGHT 1980  
FICHE 2 OF 2

JAN 1980

**digital**

MADE IN USA



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46

.REM 8

IDENTIFICATION

PRODUCT CODE: AC-F633A-MC  
PRODUCT NAME: CKFPBA0 FP11F FLTG PNT PRT B  
DATE CREATED: OCTOBER, 1979  
MAINTAINER: DIAGNOSTIC ENGINEERING  
AUTHOR: ANTHONY VEZZA, DAN MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY OCCUR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979 BY DIGITAL EQUIPMENT CORPORATION

48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78

HISTORY  
-----

NO CHANGES TO THE 11/34 FLOATING POINT DIAGNOSTICS PART 'A' WERE FOUND TO BE NEEDED TO ADAPT IT FOR USE ON THE 11/44.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'B' VERSION COVER THE 11/44:

1. TEST 22 - PROCESSOR LOOKS TO SEE IF APT IS CONTROLLING THE TEST, AND IF IT IS, CHECKS TO SEE IF THE USER HAS SELECTED THIS TEST BY CHECKING BIT 7 IN THE SWITCH REGISTER. IT HAS ALSO BEEN CHANGED SO THAT IF BIT 7 IS \*ONE\*, THE CODE WILL SELECT THE TEST.

THE FOLLOWING WAS ADDED TO THE 11/34 FLOATING POINT DIAGNOSTIC TO MAKE THE 'C' VERSION COVER THE 11/44:

1. TEST 76 - CHECKS THAT FP PROCESSOR DOESN'T ACCESS D-SPACE UNTIL CONDITIONS WARRANT.
2. TEST 77 - CHECKS THAT SR1 MATCHES WHAT ACTUALLY HAPPENED TO THE REGISTER OF THE INSTRUCTION, AND THAT THE VALUE OF AUTO INCREMENT/DECREMENT WAS PROPER.

## CONTENTS

80	
81	
82	
83	1. ABSTRACT
84	
85	2. REQUIREMENTS
86	2.1 EQUIPMENT
87	2.2 STORAGE
88	2.3 PRELIMINARY PROGRAMS
89	
90	3. LOADING PROCEDURE
91	
92	4. STARTING PROCEDURE
93	4.1 CONTROL SWITCH SETTINGS
94	4.2 STARTING ADDRESS
95	4.3 PROGRAM AND OPERATOR INTERACTION
96	
97	5. OPERATING PROCEDURE
98	5.1 OPERATIONAL SWITCH SETTINGS
99	5.3 OPERATOR ACTION
100	
101	6. ERRORS
102	6.1 SUMMARY
103	6.2 ERROR RECOVERY
104	
105	7. RESTRICTIONS
106	7.1 STARTING RESTRICTIONS
107	7.2 OPERATING RESTRICTIONS
108	
109	8. MISCELLANEOUS
110	8.1 EXECUTION TIMES
111	8.2 STACK POINTER
112	8.3 PASS COUNT
113	8.4 T-BIT TRAPPING
114	8.5 SOFTWARE SWITCH REGISTER
115	8.6 INTERRUPTS TEST
116	8.7 ACT, APT AND XXDP COMPATIBILITY
117	
118	9. PROGRAM DESCRIPTION
119	9.1 CKFPBA0
120	
121	10. LISTING
122	10.1 CKFPBA0
123	
124	
125	
126	
127	
128	
129	

131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187

1.

## ABSTRACT

-----

## THE THREE PROGRAMS:

CKFPAA0 CKFPBA0 CKFPCA0

ARE DESIGN TO DETECT AND REPORT LOGIC FAULTS IN THE PDP 11/44 FP11-F FLOATING POINT PROCESSOR. THE DESIGN IS AN ATTEMPT TO REACH ALL ROM STATES, TAKE ALL BRANCH MICRO TESTS (BUT'S) AND VERIFY ALL THE LOGIC. THEY CONSIST OF 157 (OCT) INDIVIDUAL TESTS SEQUENCED TO DETECT AND ATTEMPT TO IDENTIFY FAULTS WITH A MINIMUM HARDWARE OR SOFTWARE LEVEL. THE TESTS ARE PARTIONED INTO THREE STAND-ALONE PROGRAMS DESCRIBED BELOW.

NOTE THAT ERROR REPORTS IN THESE PROGRAMS ARE BASED UPON THE KNOWLEDGE THAT ALL PREVIOUS TESTS HAVE BEEN RUN AND IN MOST CASE THAT THERE IS ONLY A SINGLE POINT FAULT IN THE FP11-F. IF THE PROGRAMS OR TESTS ARE NOT RUN IN ORDER THEN ERROR MESSAGES MAY NOT BE ACCURATE.

## A. CKFPAA0

## CKFPAA0 TESTS:

LDFPS  
STFPS  
CFCC  
SETF, SETD, SETI AND SETL  
STST  
LDF AND LDD (ALL SOURCE MODES)  
STD (MODE 0 AND 1)  
ADDF, ADDD AND SUBD (MOST CONDITIONS)

## B. CKFPBA0

## CKFPBA0 TESTS:

ADDF, ADDD AND SUBD (ALL CONDITIONS NOT TESTED IN CKFPBA0)  
CMPD AND CMPF  
DIVD AND DIVF  
MULD AND MULF  
MODD AND MODF

## C. CKFPCA0

## CKFPCA0 TESTS:

STF AND STD (ALL MODES)  
STCFD AND STCDF  
CLRD AND CLRF

188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244

NEGF AND NEGD  
ABSF AND ABSD  
TSTF AND TSTD  
NEGF, ABSF AND TSIF (ALL SOURCE MODES)  
NEGF, ABSF AND TSTF (ALL SOURCE MODES)  
LDFPS (ALL SOURCE MODES)  
LDCIF AND LDCLF  
LDCID AND LDCLD  
LDEXP  
STFPS (ALL DESTINATION MODES)  
STCFL AND STCFI  
STCDL AND STCDI  
STEXP  
STST

2. REQUIREMENTS

2.1 EQUIPMENT

A PDP 11/44 (WITH OR WITHOUT CONSOLE), LA30 (OR EQUIVALENT) AND AN FP11-F FLOATING POINT PROCESSOR. NOTE THAT A SPECIAL INTERRUPTS TEST MODULE IS BEING DESIGNED FOR USE IN THE MANUFACTURING ENVIRONMENT. WHEN THIS DEVICE IS PRESENT THE PROGRAM CKFPBA0 WILL MAKE USE OF IT TO TEST THE FPP INTERRUPT ON BUS REQUEST FUNCTIONS.

2.2 STORAGE

ALL THREE PROGRAM REQUIRE A MEMORY SYSTEM OF AT LEAST 16K TO LOAD AND RUN.

2.3 PRELIMINARY PROGRAMS

THESE THREE DIAGNOSTICS WILL ASSUME THAT THE PDP 11/44 CENTRAL PROCESSOR IS FAULTLESS, THEREFORE WHEN IN DOUBT RUN THE PDP 11/44 PROCESSOR DIAGNOSTICS BEFORE THESE FP11-F DIAGNOSTICS.

3. LOADING PROCEDURE

THE PROGRAMS WILL BE SUPPLIED ON THE 11/44 DIAGNOSTIC MEDIA. REFER TO THE XXDP OPERATING MANUAL FOR FURTHER INFORMATION.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SEE SECTION 5.1

4.2 PROGRAM AND OPERATOR ACTION

245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301

1. LOAD PROGRAM INTO MEMORY
2. LOAD ADDRESS 200
3. SET CONSOLE SWITCHES (IF CONSOLE IS PRESENT)
4. PRESS START  
ON FIRST PASS THE PROGRAM WILL IDENTIFY ITSELF. NOTE THAT IF THERE IS NO PHYSICAL CONSOLE THE PROGRAM WILL REQUEST THE OPERATOR FOR INITIAL VALUE FOR THE SOFTWARE SWITCH REGISTER (SEE SECTION 8.5). IF RUNNING UNDER ACT, APT OR CHAIN THIS DOES NOT APPLY.
5. THE PROGRAM WILL LOOP AND AN END OF PASS AND ERROR SUMMARY WILL BE TYPED AT THE END OF EVERY PASS.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

THE SWITCH SETTING ARE:

	OCTAL	
SW<15>=1...	100000	HALT ON ERROR
SW<14>=1...	40000	LOOP ON CURRENT TEST
SW<13>=1...	20000	INHIBIT ERROR TYPE OUTS
SW<12>=1...	10000	INHIBIT T-BIT TRAPPING
SW<11>=1...	4000	INHIBIT ITERATIONS
SW<10>=1...	2000	RING TTY BELL ON ERROR
SW<9>=1....	1000	LOOP ON ERROR
SW<8>=1....	400	LOOP ON TEST SPECIFIED IN SW<6> THROUGH SW<0>
SW<7>=1....	200	PRINT ERROR SUMMARY EVEN IF SW<13>=1, THIS APPLIES ONLY TO PROGRAM CKFPAA0.
SW<7>=1....	200	SELECT CORRECT INTERRUPT TEST IN PROGRAM CKFPBA0. IF APT IS SELECTING THE TEST, THE SWITCH REGISTER IS EXAMINED TO SEE IF THE USER HAS SELECTED THIS TEST BY A <1> IN SW<7>

6. ERRORS

6.1 SUMMARIES

IN PROGRAM CKFPAA0, TESTS 1 AND 11 HAVE A SPECIAL ERROR SUMMARY FEATURE. THESE TWO TEST RUN MANY TEST PATTERNS THROUGH THE LOGIC. AFTER AN ERROR IS ENCOUNTERED, ONLY THE FIRST FIVE ERRORS ARE REPORTED (TYPED ON THE TTY). EVERY ERROR THOUGH IS LOGGED AND AN ERROR SUMMARY IS PRINTED WHEN THE TEST IS COMPLETE. NOTE THAT IF SW<13>=1 THIS



302 SUMMARY WILL NOT BE TYPED UNLESS SW<7>=1. IN OTHER  
 303 WORDS TO GET JUST AN ERROR SUMMARY FROM EITHER OF  
 304 THESE TWO TESTS 1 AND 11 IN PROGRAM CKFPAA0 BOTH  
 305 SWITCHES 13 AND 7 MUST = 1.  
 306  
 307 6.2 ERROR RECOVERY  
 308  
 309 SW<15:9>=0... MOST ERRORS WILL CAUSE EXECUTION TO  
 310 GO TO THE START OF THE NEXT TEST  
 311 AFTER THE MESSAGE IS TYPED. A FEW  
 312 TESTS ARE IN SECTIONS. IN THESE  
 313 TESTS AN ERROR WILL CAUSE EXECUTION  
 314 TO GO TO THE NEXT SECTION AFTER THE  
 315 MESSAGE IS TYPED.  
 316  
 317 SW<15>=1... THE PROGRAM WILL HALT AFTER TYPING  
 318 THE ERROR MESSAGE. PRESSING THE  
 319 CONSOLE CONTINUE WILL CAUSE THE  
 320 PROGRAM TO CONTINUE AS IF SW<15>=0.  
 321  
 322 7. RESTRICTIONS  
 323 -----  
 324  
 325 NONE  
 326  
 327  
 328 8. MISCELLANEOUS  
 329 -----  
 330  
 331 8.1 EXECUTION TIMES  
 332  
 333 LESS THAN 10 SECONDS FOR EACH PROGRAM ON ANY PASS.  
 334  
 335 8.2 STACK POINTER  
 336  
 337 THE STACK POINTER IS INITIALIZED TO 1100 IN EACH OF  
 338 THE THREE PROGRAMS.  
 339  
 340 8.3 PASS COUNT  
 341  
 342 THE PROGRAM MAKES ONE PASS FOR EACH END OF PASS  
 343 MESSAGE TYPED. THE END OF PASS MESSAGE DESCRIBES  
 344 THE TOTAL NUMBER OF PASSES COMPLETED AND THE TOTAL  
 345 NUMBER OF ERRORS SINCE THE LAST END OF PASS MESSAGE.  
 346  
 347 8.4 T-BIT TRAPPING  
 348  
 349 IF SW<12>=0 EACH PROGRAM WILL RUN WITH TRACE TRAPS  
 350 ON EVERY OTHER PASS. FIRST PASS WILL NOT ENABLE  
 351 TRACE TRAPS. NOTE SW<12>=1 DISABLES T-BIT TRAPS.  
 352  
 353 8.5 SOFTWARE SWITCH REGISTER  
 354  
 355 EACH OF THE THREE PROGRAMS WILL RUN WITH OR WITHOUT  
 356 A CONSOLE SWITCH REGISTER. IF A PHYSICAL CONSOLE  
 357 SWITCH REGISTER IS PRESENT ON THE SYSTEM, THEN THESE  
 358 PROGRAMS WILL GO AHEAD AND USE IT FOR THE SWITCH

359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415

FUNCTIONS DESCRIBED IN 5.1 ABOVE. IF HOWEVER THERE IS NO CONSOLE SWITCH REGISTER ON THE SYSTEM A SOFTWARE SWITCH REGISTER WILL BE USED. THIS SOFTWARE SWITCH REGISTER CAN BE EXAMINED OR MODIFIED AT ANY TIME BY THE USER IF HE TYPES CONTROL G WHILE THE PROGRAM IS RUNNING. THIS CONTROL G WILL CAUSE THE CONTENTS OF THE SOFTWARE SWITCH REGISTER TO BE TYPED ON THE TTY AND ASK THE USER FOR A NEW VALUE. WHEN THE USER TYPES A VALUE AND CARRIAGE RETURN THEN THE PROGRAM WILL RESUME TESTING AT THE SAME POINT AT WHICH IT LEFT OFF WHEN THE USER TYPED CONTROL G. NOTE THAT WHEN NOT RUNNING UNDER ACT, APT OR CHAIN THE USER WILL BE ASKED FOR A SOFTWARE SWITCH REGISTER VALUE AFTER LOADING ADDRESS 200 AND STARTING THE PROGRAM THE FIRST TIME THE PROGRAM IS RUN AFTER LOADING (ONLY IF NO CONSOLE SWITCH REGISTER IS ON THE SYSTEM).

8.6 INTERRUPTS TEST

IN PROGRAM CKFPBA0, THERE IS A SPECIAL TEST FOR CHECKING THE CORRECT FLOWS OF THE FPP. THIS TEST CAN BE RUN ONLY IF A SPECIAL TEST MODULE IS IN THE SYSTEM. THIS MODULE WILL PROBABLY ONLY BE USED IN MANUFACTURING. IF THIS MODULE IS NOT IN THE SYSTEM THIS TEST WILL AUTOMATICALLY BE DESELECTED. IF THIS TEST MODULE IS ON THE SYSTEM AND SW<7>=0 THIS TEST WILL BE RUN. IF SW<7>=1 THIS TEST WILL BE DESELECTED.

8.7 ACT, APT AND XXDP COMPATIBILITY

THESE PROGRAMS ARE FULLY COMPATIBLE WITH:  
APT  
ACT  
XXDP MONITOR AND CHAIN PROGRAMS.

9. PROGRAM DESCRIPTION

TEST 1 ROUND\TRUNK TEST

416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472

THIS IS A TEST OF THE ROUND\TRUNK FLOWS. IN PARTICULAR TWO THINGS ARE TESTED: FIRST A CONDITION IN WHICH ROUNDING RESULTS IN THE NEED FOR RENORMALIZATION, AND SECOND THE PSW CONDITION CODES N AND Z BIT COMBINATIONS

TEST 2                    OVER\UNDER TEST

THIS IS A PARTIAL TEST OF THE OVER\UNDER FLOWS. ONE OVERFLOW AND TWO UNDERFLOW CONDITIONS ARE CHECKED. THE REMAINING UNDERFLOW COND. AND THE REMAINING OVERFLOW COND. WILL BE CHECKED LATER USING THE XXX INSTRUCTION. HERE EACH CONDITION TESTED IS CHECKED BOTH WITH TRAPS ENABLED (FIU=1 OR FIV=1) AND ALSO WITH TRAPS DISABLED (FIU=0 OR FIV=0).

TEST 3                    LDCFD AND LDCDF TEST

THIS IS A TEST OF LDCFD AND LDCDF.

TEST 4                    CMPD TEST

THIS IS A TEST OF THE CMPD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS

TEST 5                    DIVD WITH (FSRC=0) AND (BUT FD) TEST

THIS IS A TEST OF THE DIVD INSTRUCTION WITH A ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH TRAP ENABLED AND TRAPS DISABLED.

TEST 6                    DIVF TEST

THIS IS A TEST OF THE DIVF INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.

TEST 7                    DIVD TEST

THIS IS A TEST OF THE DIVD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.

TEST 10                   MULF TEST

THIS IS A TEST OF THE MULF INSTRUCTION. IT MAKES USE OF A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS.

473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529

TEST 11                    MULD TEST

THIS IS A TEST OF THE MULD INSTRUCTION. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 12                    UNDER\OVER FLOW, USING MULF WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS USING THE MULF INSTRUCTION WITH TRAPS DISABLED. NOTE THAT A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS.

TEST 13                    UNDER\OVER FLOW, USING MULD WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS THAT CAN ARRISE USING THE MULD INSTRUCTION WITH TRAPS DISABLED. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 14                    UNDER\OVER FLOW, USING MULF WITH TRAPS ENABLED, TEST

THIS IS A TEST OF THE UNDERFLOW AND OVERFLOW CONDITIONS THAT CAN OCCUR USING THE MULF INSTRUCTION. A SUBROUTINE IS CALLED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE RESULTS. HERE THE PARTICULAR INTERRUPT, EITHER OVERFLOW OR UNDERFLOW, IS ENABLED SO A TRAP SHOULD OCCUR.

TEST 15                    UNDER\OVER FLOW, USING MULD WITH TRAPS ENABLED, TEST

THIS IS A TEST OF THE OVER FLOW AND UNDER FLOW CONDITIONS USING THE MULD INSTRUCTION WITH TRAPS ENABLED. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND CHECK THE RESULTS.

TEST 16                    MODF TEST

THIS IS A TEST OF THE MODF INSTRUCTION, WHICH MAKES USE OF A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.

TEST 17                    MODD TEST

THIS IS A TEST OF THE MODD INSTRUCTION. IT MAKES USE OF A SUBROUTINE TO SET UP THE ARGUMENTS, EXECUTE

530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586

THE INSTRUCTION AND CHECK THE RESULTS.

TEST 20                    UNDER\OVER FLOW, USING MODF WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE MODF OVERFLOW AND UNDERFLOW CONDITIONS. IT MAKES USE OF A SUBROUTINE TO SETUP THE OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS. TRAPS ARE DISABLED DURING THIS TEST.

TEST 21                    UNDER\OVER FLOW, USING MODD WITH TRAPS DISABLED, TEST

THIS IS A TEST OF THE MODD INSTRUCTION'S OVER FLOW AND UNDER FLOW CONDITIONS. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.

TEST 22                    INTERRUPT CORRECT FLOWS TEST

THIS IS A TEST OF THE 'CORRECT' FLOWS. THIS PART OF THE MICRO CODE HAS AS ITS PURPOSE INSURING THAT INTERRUPT REQUESTS MADE DURING CERTAIN LENGTHY FPP INSTRUCTIONS GET HONORED. THIS IS DONE IN A WAY SUCH THAT IF AN INTERRUPT REQUEST OCCURS DURING ONE OF THESE INSTRUCTIONS THE STATE OF THAT INSTRUCTION'S EXECUTION WILL BE THE SAME AS IF THAT INSTRUCTION HAD NEVER BEEN FETCHED AND ITS EXECUTION NEVER STARTED. THUS THE MICRO CODE WILL RESTORE ALL REGISTERS, BACK UP THE PC AND LEAVE THE FPS AND ACO THROUGH ACS UNMODIFIED. THE INSTRUCTIONS FOR WHICH THIS IS NECESSARY ARE:

ADD (OR SUB)  
DIV  
MUL  
MCD

(BOTH DOUBLE AND FLOATING)

ALL ADDRESSING MODES WILL BE TRIED WITH THE ADDD INSTRUCTION. THEN EACH OF THE OTHER INSTRUCTIONS WILL BE TRIED USING MODE 1. NOTE THAT THIS TEST NEEDS A SPECIAL INTERRUPT MODULE, WHICH WILL PROBABLY ONLY BE PRESENT IN DEC'S MANUFACTURING ENVIRONMENT, TO RUN. THIS SPECIAL EQUIPMENT IS DESIGNED TO RAISE AN INTERRUPT REQUEST IN THE PROCESSOR IF A BIT IS SET IN ITS STATUS REGISTER AND ONLY WHEN AN FPP INSTRUCTION IS ENCOUNTERED. THEREFORE THIS TEST WILL BE RUN CONDITIONALLY (DEPENDENT UPON WHETHER OR NOT THE STATUS REGISTER OF THE TEST EQUIPMENT TIMES OUT WHEN REFERENCED). THIS TEST CAN ALSO BE SELECTED BY TURNING SWITCH 7 OF THE SWITCH REGISTER (PHYSICAL OR VIRTUAL) ON. THE TEST ASSUMES THAT THE TEST EQUIPMENT'S STATUS REGISTER IS AT LOCATION 777774 (NOTE THAT ALL REFERENCES TO THIS LOCATION ARE MADE INDIRECT

587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625

THROUGH THIS PROGRAMS LOCATION CORINT, SO THAT IF THE USER HAS MODIFIED THE TEST EQUIPMENT'S STATUS REGISTER TO RESPOND TO A DIFFERENT ADDRESS LOCATION CORINT MUST BE MADE TO CONTAIN THAT STATUS REGISTER'S NEW ADDRESS). THIS PROGRAM ASSUMES THAT THE TRAP VECTOR FOR THE TEST EQUIPMENT IS 110. AGAIN NOTE THAT ALL REFERENCES TO THIS TRAP VECTOR ARE INDIRECT, THROUGH THIS PROGRAM'S LOCATION CORTRP (IF THE TEST EQUIPMENT IS MADE TO TRAP TO A DIFFERENT VECTOR LOCATION CORTRP MUST CONTAIN THE ADDRESS OF THIS VECTOR).

10.

LISTING

-----

&

000266  
000002

MNUMBER=266  
PROGNUM=2

.LIST ME  
.NLIST MD,MC,CND

856 000000  
 863  
 864  
 865  
 866  
 867  
 868

```
.ENABL ABS
.MCALL .HEADER,.SWRHI,.EQUAT,.SETUP,.SCATCH,.$ACT11,. $CMTAG
.MCALL .SEOP,.$SCOPE,.$ERROR,.$SAVE,.$TYPE,.$TYPOCT
.MCALL .STYPDEC,.$STRAP,.$POWER,.$APTHDR,.$APTBL
.MCALL .SAPTYPE,.$READ
.MCALL .EQUIV ;REMOVE FOR PDP-10 ASSEMBLY
```

```
.TITLE CKFPBA0 FP11F FLTG PNT PRT B
;*COPYRIGHT (C) 1979
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
```

000001  
 160000

```
$TN=1
$SWR=160000 ;:HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
```

869  
 870  
 871  
 872  
 873  
 874  
 875  
 876  
 877

000244  
 177400  
 000200  
 000011  
 000015

```
FPVECT=244
$SWR=177400
$SWRMSK=200
TAB=11
CRLF=15
```

001100  
 104000  
 000004

```
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
ERROR=EMT
SCOPE=IOT
```

000011  
 000012  
 000015  
 000200  
 177776  
 177776  
 177774  
 177772  
 177570  
 177570

```
;*MISCELLANEOUS DEFINITIONS
HT= 11 ;:CODE FOR HORIZONTAL TAB
LF= 12 ;:CODE FOR LINE FEED
CR= 15 ;:CODE FOR CARRIAGE RETURN
CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;:PROCESSOR STATUS WORD
PSW=PS
STKLMT= 177774 ;:STACK LIMIT REGISTER
PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;:HARDWARE SWITCH REGISTER
DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
```

000000  
 000001  
 000002  
 000003  
 000004  
 000005  
 000006  
 000007  
 000006  
 000007

```
;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0 ;:GENERAL REGISTER
R1= %1 ;:GENERAL REGISTER
R2= %2 ;:GENERAL REGISTER
R3= %3 ;:GENERAL REGISTER
R4= %4 ;:GENERAL REGISTER
R5= %5 ;:GENERAL REGISTER
R6= %6 ;:GENERAL REGISTER
R7= %7 ;:GENERAL REGISTER
SP= %6 ;:STACK POINTER
PC= %7 ;:PROGRAM COUNTER
```

000000  
 C00040  
 000100  
 000140

```
;*PRIORITY LEVEL DEFINITIONS
PR0= 0 ;:PRIORITY LEVEL 0
PR1= 40 ;:PRIORITY LEVEL 1
PR2= 100 ;:PRIORITY LEVEL 2
PR3= 140 ;:PRIORITY LEVEL 3
```

```
000200 PR4= 200 ::PRIORITY LEVEL 4
000240 PR5= 240 ::PRIORITY LEVEL 5
000300 PR6= 300 ::PRIORITY LEVEL 6
000340 PR7= 340 ::PRIORITY LEVEL 7
;*'SWITCH REGISTER' SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00
;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
```



```
000001          BIT0=BIT00
000004          ;*BASIC "CPU" TRAP VECTOR ADDRESSES
000010          ERRVEC= 4          ;; TIME OUT AND OTHER ERRORS
000014          RESVEC= 10         ;; RESERVED AND ILLEGAL INSTRUCTIONS
000014          TBITVEC=14        ;; 'T' BIT
000014          TRTVEC= 14         ;; TRACE TRAP
000014          BPTVEC= 14         ;; BREAKPOINT TRAP (BPT)
000020          IOTVEC= 20         ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024          PWRVEC= 24         ;; POWER FAIL
000030          EMTVEC= 30         ;; EMULATOR TRAP (EMT) **ERROR**
000034          TRAPVEC=34        ;; "TRAP" TRAP
000060          TKVEC= 60          ;; TTY KEYBOARD VECTOR
000064          TPVEC= 64         ;; TTY PRINTER VECTOR
000240          PIRQVEC=240       ;; PROGRAM INTERRUPT REQUEST VECTOR

878             .SBTTL FPP REGISTER DEFINITIONS
879             AC0      =%0
880             AC1      =%1
881             AC2      =%2
882             AC3      =%3
883             AC4      =%4
884             AC5      =%5
885             AC6      =%6
886             AC7      =%7
888
889             .SBTTL TRAP CATCHER
000000          .=0
000000          ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
000000          ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
000000          ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
000174          .=174
000174          000000          DISPREG: .WORD 0          ;; SOFTWARE DISPLAY REGISTER
000176          000000          SWREG:   .WORD 0          ;; SOFTWARE SWITCH REGISTER
000200          000137 004336     .SBTTL STARTING ADDRESS(ES)
000200          JMP @#START ;; JUMP TO STARTING ADDRESS OF PROGRAM
```

890

.SBTTL COMMON TAGS

\*\*\*\*\*  
\*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
\*USED IN THE PROGRAM.

.=1100

001100 001100  
001100 000000  
001102 000  
001103 000  
001104 000000  
001106 000000  
001110 000000  
001112 000000  
001114 000  
001115 001  
001116 000000  
001120 000000  
001122 000000  
001124 000000  
001126 000000  
001130 000000  
001132 000000  
001134 000  
001135 000  
001136 000000  
001140 177570  
001142 177570  
001144 177560  
001146 177562  
001150 177564  
001152 177566  
001154 000  
001155 002  
001156 012  
001157 000  
001160 000000

\$CMTAG: .WORD 0  
\$TSTNM: .BYTE 0  
\$ERFLG: .BYTE 0  
\$ICNT: .WORD 0  
\$LPADR: .WORD 0  
\$LPERR: .WORD 0  
\$ERTTL: .WORD 0  
\$ITEMB: .BYTE 0  
\$ERMAX: .BYTE 1  
\$ERRPC: .WORD 0  
\$GDADR: .WORD 0  
\$BDADR: .WORD 0  
\$GDDAT: .WORD 0  
\$BDDAT: .WORD 0  
\$AUTOB: .BYTE 0  
\$INTAG: .BYTE 0  
\$SWR: .WORD DSWR  
\$DISPLAY: .WORD DDISP  
\$TKS: 177560  
\$TKB: 177562  
\$TPS: 177564  
\$TPB: 177566  
\$NULL: .BYTE 0  
\$FILLS: .BYTE 2  
\$FILLC: .BYTE 12  
\$TPFLG: .BYTE 0  
\$REGAD: .WORD 0

:::START OF COMMON TAGS  
:::CONTAINS THE TEST NUMBER  
:::CONTAINS ERROR FLAG  
:::CONTAINS SUBTEST ITERATION COUNT  
:::CONTAINS SCOPE LOOP ADDRESS  
:::CONTAINS SCOPE RETURN FOR ERRORS  
:::CONTAINS TOTAL ERRORS DETECTED  
:::CONTAINS ITEM CONTROL BYTE  
:::CONTAINS MAX. ERRORS PER TEST  
:::CONTAINS PC OF LAST ERROR INSTRUCTION  
:::CONTAINS ADDRESS OF 'GOOD' DATA  
:::CONTAINS ADDRESS OF 'BAD' DATA  
:::CONTAINS 'GOOD' DATA  
:::CONTAINS 'BAD' DATA  
:::RESERVED--NOT TO BE USED  
:::AUTOMATIC MODE INDICATOR  
:::INTERRUPT MODE INDICATOR  
:::ADDRESS OF SWITCH REGISTER  
:::ADDRESS OF DISPLAY REGISTER  
:::TTY KBD STATUS  
:::TTY KBD BUFFER  
:::TTY PRINTER STATUS REG. ADDRESS  
:::TTY PRINTER BUFFER REG. ADDRESS  
:::CONTAINS NULL CHARACTER FOR FILLS  
:::CONTAINS # OF FILLER CHARACTERS REQUIRED  
:::INSERT FILL CHARS. AFTER A 'LINE FEED'  
:::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)  
:::CONTAINS THE ADDRESS FROM  
:::WHICH (\$REGO) WAS OBTAINED

000024  
001162 000000  
001164 000000  
001166 000000  
001170 000000  
001172 000000  
001174 000000  
001176 000000  
001200 000000  
001202 000000  
001204 000000  
001206 000000  
001210 000000  
001212 000000  
001214 000000  
001216 000000  
001220 000000  
001222 000000  
001224 000000  
001226 000000

.REPT \$CM3  
\$REG0: .WORD 0  
\$REG1: .WORD 0  
\$REG2: .WORD 0  
\$REG3: .WORD 0  
\$REG4: .WORD 0  
\$REG5: .WORD 0  
\$REG6: .WORD 0  
\$REG7: .WORD 0  
\$REG10: .WORD 0  
\$REG11: .WORD 0  
\$REG12: .WORD 0  
\$REG13: .WORD 0  
\$REG14: .WORD 0  
\$REG15: .WORD 0  
\$REG16: .WORD 0  
\$REG17: .WORD 0  
\$REG20: .WORD 0  
\$REG21: .WORD 0  
\$REG22: .WORD 0

:::CONTAINS ((\$REGAD)+0)  
:::CONTAINS ((\$REGAD)+2)  
:::CONTAINS ((\$REGAD)+4)  
:::CONTAINS ((\$REGAD)+6)  
:::CONTAINS ((\$REGAD)+10)  
:::CONTAINS ((\$REGAD)+12)  
:::CONTAINS ((\$REGAD)+14)  
:::CONTAINS ((\$REGAD)+16)  
:::CONTAINS ((\$REGAD)+20)  
:::CONTAINS ((\$REGAD)+22)  
:::CONTAINS ((\$REGAD)+24)  
:::CONTAINS ((\$REGAD)+26)  
:::CONTAINS ((\$REGAD)+30)  
:::CONTAINS ((\$REGAD)+32)  
:::CONTAINS ((\$REGAD)+34)  
:::CONTAINS ((\$REGAD)+36)  
:::CONTAINS ((\$REGAD)+40)  
:::CONTAINS ((\$REGAD)+42)  
:::CONTAINS ((\$REGAD)+44)

```
001230 000000 $REG23: .WORD 0 ;;CONTAINS (($REGAD)+46)
000024 .REPT 24
001232 000000 $TMP0: .WORD 0 ;;USER DEFINED
001234 000000 $TMP1: .WORD 0 ;;USER DEFINED
001236 000000 $TMP2: .WORD 0 ;;USER DEFINED
001240 000000 $TMP3: .WORD 0 ;;USER DEFINED
001242 000000 $TMP4: .WORD 0 ;;USER DEFINED
001244 000000 $TMP5: .WORD 0 ;;USER DEFINED
001246 000000 $TMP6: .WORD 0 ;;USER DEFINED
001250 000000 $TMP7: .WORD 0 ;;USER DEFINED
001252 000000 $TMP10: .WORD 0 ;;USER DEFINED
001254 000000 $TMP11: .WORD 0 ;;USER DEFINED
001256 000000 $TMP12: .WORD 0 ;;USER DEFINED
001260 000000 $TMP13: .WORD 0 ;;USER DEFINED
001262 000000 $TMP14: .WORD 0 ;;USER DEFINED
001264 000000 $TMP15: .WORD 0 ;;USER DEFINED
001266 000000 $TMP16: .WORD 0 ;;USER DEFINED
001270 000000 $TMP17: .WORD 0 ;;USER DEFINED
001272 000000 $TMP20: .WORD 0 ;;USER DEFINED
001274 000000 $TMP21: .WORD 0 ;;USER DEFINED
001276 000000 $TMP22: .WORD 0 ;;USER DEFINED
001300 000000 $TMP23: .WORD 0 ;;USER DEFINED
001302 000000 $TIMES: 0 ;;MAX. NUMBER OF ITERATIONS
001304 000000 $ESCAPE:0 ;;ESCAPE ON ERROR ADDRESS
001306 207 377 377 $BELL: .ASCIZ <207><377><377> ;;CODE FOR BELL
001311 000
001312 077
001313 015
001314 012 000
$QUES: .ASCII /?/ ;;QUESTION MARK
$CRLF: .ASCII <15> ;;CARRIAGE RETURN
$LF: .ASCIZ <12> ;;LINE FEED
*****
.SBTTL APT MAILBOX-ETABLE
*****
.EVEN
001316 $MAIL: ;;APT MAILBOX
001316 000000 $MSGTY: .WORD AMSGTY ;;MESSAGE TYPE CODE
001320 000000 $FATAL: .WORD AFATAL ;;FATAL ERROR NUMBER
001322 000000 $TESTN: .WORD ATESTN ;;TEST NUMBER
001324 000000 $PASS: .WORD APASS ;;PASS COUNT
001326 000000 $DEVCT: .WORD ADEVCT ;;DEVICE COUNT
001330 000000 $UNIT: .WORD AUNIT ;;I/O UNIT NUMBER
001332 000000 $MSGAD: .WORD AMSGAD ;;MESSAGE ADDRESS
001334 000000 $MSGLG: .WORD AMSGLG ;;MESSAGE LENGTH
001336 $ETABLE: ;;APT ENVIRONMENT TABLE
001336 000 $ENV: .BYTE AENV ;;ENVIRONMENT BYTE
001337 000 $ENVM: .BYTE AENVM ;;ENVIRONMENT MODE BITS
001340 000000 $SWREG: .WORD ASWREG ;;APT SWITCH REGISTER
001342 000000 $USWR: .WORD AUSWR ;;USER SWITCHES
001344 000000 $CPUOP: .WORD ACPUOP ;;CPU TYPE,OPTIONS
;*
;* BITS 15-11=CPU TYPE
;* 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
;* 11/70=06,PDQ=07,Q=10
;* BIT 10=REAL TIME CLOCK
;* BIT 9=FLOATING POINT PROCESSOR
;* BIT 8=MEMORY MANAGEMENT
001346 000 $MAMS1: .BYTE AMAMS1 ;;HIGH ADDRESS,M.S. BYTE
001347 000 $MTYP1: .BYTE AMTYP1 ;;MEM. TYPE,BLK#1
;* MEM. TYPE BYTE -- (HIGH BYTE)
```

```

          900 NSEC CORE=001
          300 NSEC BIPOLAR=002
          500 NSEC MOS=003
001350 000000 $MADR1: .WORD AMADR1 ;;HIGH ADDRESS,BLK#1
          ;;MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
001352 000 $MAMS2: .BYTE AMAMS2 ;;HIGH ADDRESS,M.S. BYTE
001353 000 $MTYP2: .BYTE AMTYP2 ;;MEM.TYPE,BLK#2
001354 000000 $MADR2: .WORD AMADR2 ;;MEM.LAST ADDRESS,BLK#2
001356 000 $MAMS3: .BYTE AMAMS3 ;;HIGH ADDRESS,M.S.BYTE
001357 000 $MTYP3: .BYTE AMTYP3 ;;MEM.TYPE,BLK#3
001360 000000 $MADR3: .WORD AMADR3 ;;MEM.LAST ADDRESS,BLK#3
001362 000 $MAMS4: .BYTE AMAMS4 ;;HIGH ADDRESS,M.S.BYTE
001363 000 $MTYP4: .BYTE AMTYP4 ;;MEM.TYPE,BLK#4
001364 000000 $MADR4: .WORD AMADR4 ;;MEM.LAST ADDRESS,BLK#4
001366 000000 $VECT1: .WORD AVECT1 ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
001370 000000 $VECT2: .WORD AVECT2 ;;INTERRUPT VECTOR#2BUS PRIORITY#2
001372 000000 $BASE: .WORD ABASE ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
001374 000000 $DEVM: .WORD ADEVM ;;DEVICE MAP
001376 000000 $CDW1: .WORD ACDW1 ;;CONTROLLER DESCRIPTION WORD#1
001400 000000 $CDW2: .WORD ACDW2 ;;CONTROLLER DESCRIPTION WORD#2
001402 000000 $DDW0: .WORD ADDW0 ;;DEVICE DESCRIPTOR WORD#0
001404 000000 $DDW1: .WORD ADDW1 ;;DEVICE DESCRIPTOR WORD#1
001406 000000 $DDW2: .WORD ADDW2 ;;DEVICE DESCRIPTOR WORD#2
001410 000000 $DDW3: .WORD ADDW3 ;;DEVICE DESCRIPTOR WORD#3
001412 000000 $DDW4: .WORD ADDW4 ;;DEVICE DESCRIPTOR WORD#4
001414 000000 $DDW5: .WORD ADDW5 ;;DEVICE DESCRIPTOR WORD#5
001416 000000 $DDW6: .WORD ADDW6 ;;DEVICE DESCRIPTOR WORD#6
001420 000000 $DDW7: .WORD ADDW7 ;;DEVICE DESCRIPTOR WORD#7
001422 000000 $DDW8: .WORD ADDW8 ;;DEVICE DESCRIPTOR WORD#8
001424 000000 $DDW9: .WORD ADDW9 ;;DEVICE DESCRIPTOR WORD#9
001426 000000 $DDW10: .WORD ADDW10 ;;DEVICE DESCRIPTOR WORD#10
001430 000000 $DDW11: .WORD ADDW11 ;;DEVICE DESCRIPTOR WORD#11
001432 000000 $DDW12: .WORD ADDW12 ;;DEVICE DESCRIPTOR WORD#12
001434 000000 $DDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13
001436 000000 $DDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14
001440 000000 $DDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15
001442 $ETEND:

```

.SBTTL ERROR POINTER TABLE  
 : \*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
 : \*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
 : \*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
 : \*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
 : \*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:  
 : \* EM ::POINTS TO THE ERROR MESSAGE  
 : \* DH ::POINTS TO THE DATA HEADER  
 : \* DT ::POINTS TO THE DATA  
 : \* DF ::POINTS TO THE DATA FORMAT

894	001442	000266			\$ERRTB:	.REPT	MNUMBER
896	001442	037724	066262	070604	: ITEM 1	.WORD	EM1,DH1,DT1,DF1
	001450	070056			: ITEM 2	.WORD	EM2,DH2,DT2,DF2
	001452	037756	066352	070642	: ITEM 3	.WORD	EM3,DH3,DT3,DF3
	001460	070074			: ITEM 4	.WORD	EM4,DH4,DT4,DF4
	001462	040012	066262	070604	: ITEM 5	.WORD	EM5,DH5,DT5,DF5
	001470	070056			: ITEM 6	.WORD	EM6,DH6,DT6,DF6
	001472	040117	066262	070604	: ITEM 7	.WORD	EM7,DH7,DT7,DF7
	001500	070056			: ITEM 10	.WORD	EM10,DH10,DT10,DF10
	001502	040224	066262	070604	: ITEM 11	.WORD	EM11,DH11,DT11,DF11
	001510	070056			: ITEM 12	.WORD	EM12,DH12,DT12,DF12
	001512	040331	066262	070604	: ITEM 13	.WORD	EM13,DH13,DT13,DF13
	001520	070056			: ITEM 14	.WORD	EM14,DH14,DT14,DF14
	001522	040436	066262	070604	: ITEM 15	.WORD	EM15,DH15,DT15,DF15
	001530	070056			: ITEM 16	.WORD	EM16,DH16,DT16,DF16
	001532	040543	066262	070604	: ITEM 17	.WORD	EM17,DH17,DT17,DF17
	001540	070056					
	001542	040650	066262	070604			
	001550	070056					
	001552	040757	066262	070604			
	001560	070056					
	001562	041066	066262	070604			
	001570	070056					
	001572	041202	066262	070604			
	001600	070056					
	001602	041314	066262	070604			
	001610	070056					
	001612	041426	066262	070604			
	001620	070056					
	001622	041523	066417	070670			
	001630	070106					

ERROR POINTER TABLE

001632	041600	066262	070710	:ITEM 20	.WORD	EM20,DH20,DT20,DF20
001640	070115					
001642	041632	066466	070732	:ITEM 21	.WORD	EM21,DH21,DT21,DF21
001650	070115					
001652	041664	066555	070754	:ITEM 22	.WORD	EM22,DH22,DT22,DF22
001660	070115					
001662	041745	066262	070772	:ITEM 23	.WORD	EM23,DH23,DT23,DF23
001670	070125					
001672	042022	066262	070772	:ITEM 24	.WORD	EM24,DH24,DT24,DF24
001700	070125					
001702	042120	066262	070772	:ITEM 25	.WORD	EM25,DH25,DT25,DF25
001710	070125					
001712	042205	066262	070772	:ITEM 26	.WORD	EM26,DH26,DT26,DF26
001720	070125					
001722	042120	066262	070772	:ITEM 27	.WORD	EM27,DH27,DT27,DF27
001730	070125					
001732	042303	066262	070772	:ITEM 30	.WORD	EM30,DH30,DT30,DF30
001740	070125					
001742	042355	066262	070772	:ITEM 31	.WORD	EM31,DH31,DT31,DF31
001750	070125					
001752	041770	066262	070772	:ITEM 32	.WORD	EM32,DH32,DT32,DF32
001760	070125					
001762	042422	066262	070772	:ITEM 33	.WORD	EM33,DH33,DT33,DF33
001770	070151					
001772	042445	066262	070772	:ITEM 34	.WORD	EM34,DH34,DT34,DF34
002000	070151					
002002	042477	066262	070772	:ITEM 35	.WORD	EM35,DH35,DT35,DF35
002010	070151					
002012	042552	066262	070772	:ITEM 36	.WORD	EM36,DH36,DT36,DF36
002020	070151					
002022	042620	066262	070772	:ITEM 37	.WORD	EM37,DH37,DT37,DF37
002030	070125					
002032	042643	066262	070772	:ITEM 40	.WORD	EM40,DH40,DT40,DF40
002040	070125					
002042	042675	066262	070772	:ITEM 41	.WORD	EM41,DH41,DT41,DF41
002050	070125					
002052	042750	066262	070772	:ITEM 42	.WORD	EM42,DH42,DT42,DF42
002060	070125					

002062	043101	066262	070772	:ITEM 43	.WORD	EM43,DH43,DT43,DF43
002070	070125					
002072	043232	066262	070772	:ITEM 44	.WORD	EM44,DH44,DT44,DF44
002100	070125					
002102	043300	066262	070772	:ITEM 45	.WORD	EM45,DH45,DT45,DF45
002110	070125					
002112	043353	066262	070772	:ITEM 46	.WORD	EM46,DH46,DT46,DF46
002120	070151					
002122	043430	066262	070772	:ITEM 47	.WORD	EM47,DH47,DT47,DF47
002130	070151					
002132	043564	066262	070772	:ITEM 50	.WORD	EM50,DH50,DT50,DF50
002140	070151					
002142	043637	066262	070772	:ITEM 51	.WORD	EM51,DH51,DT51,DF51
002150	070151					
002152	043705	066262	070772	:ITEM 52	.WORD	EM52,DH52,DT52,DF52
002160	070151					
002162	051535	066262	071120	:ITEM 53	.WORD	EM53,DH53,DT53,DF53
002170	070245					
002172	051566	066262	071120	:ITEM 54	.WORD	EM54,DH54,DT54,DF54
002200	070245					
002202	051503	066262	071120	:ITEM 55	.WORD	EM55,DH55,DT55,DF55
002210	070245					
002212	051616	066262	071120	:ITEM 56	.WORD	EM56,DH56,DT56,DF56
002220	070245					
002222	051707	066262	071120	:ITEM 57	.WORD	EM57,DH57,DT57,DF57
002230	070245					
002232	051777	066262	071120	:ITEM 60	.WORD	EM60,DH60,DT60,DF60
002240	070245					
002242	052101	066262	071120	:ITEM 61	.WORD	EM61,DH61,DT61,DF61
002250	070245					
002252	052275	066262	071120	:ITEM 62	.WORD	EM62,DH62,DT62,DF62
002260	070245					
002262	052471	066262	071120	:ITEM 63	.WORD	EM63,DH63,DT63,DF63
002270	070245					
002272	052602	066262	071120	:ITEM 64	.WORD	EM64,DH64,DT64,DF64
002300	070245					
002302	052721	066262	071120	:ITEM 65	.WORD	EM65,DH65,DT65,DF65
002310	070245					

002312	053034	066262	071120	:ITEM 66	.WORD	EM66,DH66,DT66,DF66
002320	070245					
002322	053103	066262	071120	:ITEM 67	.WORD	EM67,DH67,DT67,DF67
002330	070245					
002332	053166	066262	071120	:ITEM 70	.WORD	EM70,DH70,DT70,DF70
002340	070277					
002342	053217	066262	071120	:ITEM 71	.WORD	EM71,DH71,DT71,DF71
002350	070277					
002352	053247	066262	071120	:ITEM 72	.WORD	EM72,DH72,DT72,DF72
002360	070277					
002362	053247	066262	071120	:ITEM 73	.WORD	EM73,DH73,DT73,DF73
002370	070277					
002372	053301	066262	071120	:ITEM 74	.WORD	EM74,DH74,DT74,DF74
002400	070277					
002402	053410	066262	071120	:ITEM 75	.WORD	EM75,DH75,DT75,DF75
002410	070277					
002412	053501	066262	071120	:ITEM 76	.WORD	EM76,DH76,DT76,DF76
002420	070277					
002422	053571	066262	071120	:ITEM 77	.WORD	EM77,DH77,DT77,DF77
002430	070277					
002432	053701	066262	071120	:ITEM 100	.WORD	EM100,DH100,DT100,DF100
002440	070277					
002442	053764	066262	071120	:ITEM 101	.WORD	EM101,DH101,DT101,DF101
002450	070277					
002452	054160	066262	071120	:ITEM 102	.WORD	EM102,DH102,DT102,DF102
002460	070277					
002462	054354	066262	071120	:ITEM 103	.WORD	EM103,DH103,DT103,DF103
002470	070277					
002472	054466	066262	071120	:ITEM 104	.WORD	EM104,DH104,DT104,DF104
002500	070277					
002502	054633	066262	071120	:ITEM 105	.WORD	EM105,DH105,DT105,DF105
002510	070277					
002512	054742	066262	071120	:ITEM 106	.WORD	EM106,DH106,DT106,DF106
002520	070277					
002522	055051	066262	071120	:ITEM 107	.WORD	EM107,DH107,DT107,DF107
002530	070277					
002532	055160	066262	071120	:ITEM 110	.WORD	EM110,DH110,DT110,DF110
002540	070277					



002542	043775	066262	070772	:ITEM 111	.WORD	EM111,DH111,DT111,DF111
002550	070125					
002552	044052	066262	070772	:ITEM 112	.WORD	EM112,DH112,DT112,DF112
002560	070125					
002562	044130	066262	070772	:ITEM 113	.WORD	EM113,DH113,DT113,DF113
002570	070125					
002572	044206	066262	070772	:ITEM 114	.WORD	EM114,DH114,DT114,DF114
002600	070125					
002602	044265	066623	071044	:ITEM 115	.WORD	EM115,DH115,DT115,DF115
002610	070175					
002612	044343	066623	071044	:ITEM 116	.WORD	EM116,DH116,DT116,DF116
002620	070175					
002622	044422	066623	071044	:ITEM 117	.WORD	EM117,DH117,DT117,DF117
002630	070175					
002632	044560	066623	071044	:ITEM 120	.WORD	EM120,DH120,DT120,DF120
002640	070175					
002642	044716	066623	071044	:ITEM 121	.WORD	EM121,DH121,DT121,DF121
002650	070175					
002652	045053	066623	071044	:ITEM 122	.WORD	EM122,DH122,DT122,DF122
002660	070175					
002662	045210	066262	070772	:ITEM 123	.WORD	EM123,DH123,DT123,DF123
002670	070151					
002672	045266	066262	070772	:ITEM 124	.WORD	EM124,DH124,DT124,DF124
002700	070151					
002702	045345	066262	070772	:ITEM 125	.WORD	EM125,DH125,DT125,DF125
002710	070151					
002712	045423	066262	070772	:ITEM 126	.WORD	EM126,DH126,DT126,DF126
002720	070151					
002722	045502	066623	071044	:ITEM 127	.WORD	EM127,DH127,DT127,DF127
002730	070221					
002732	045560	066623	071044	:ITEM 130	.WORD	EM130,DH130,DT130,DF130
002740	070221					
002742	045637	066623	071044	:ITEM 131	.WORD	EM131,DH131,DT131,DF131
002750	070221					
002752	045775	066262	070772	:ITEM 132	.WORD	EM132,DH132,DT132,DF132
002760	070151					
002762	046133	066623	071044	:ITEM 133	.WORD	EM133,DH133,DT133,DF133
002770	070221					

002772	046271	066623	071044	:ITEM 134	.WORD	EM134,DH134,DT134,DF134
003000	070221					
003002	046426	066262	070772	:ITEM 135	.WORD	EM135,DH135,DT135,DF135
003010	070151					
003012	046563	066623	071044	:ITEM 136	.WORD	EM136,DH136,DT136,DF136
003020	070221					
003022	046720	066623	071044	:ITEM 137	.WORD	EM137,DH137,DT137,DF137
003030	070175					
003032	047006	066623	071044	:ITEM 140	.WORD	EM140,DH140,DT140,DF140
003040	070175					
003042	043775	066623	071044	:ITEM 141	.WORD	EM141,DH141,DT141,DF141
003050	070175					
003052	044052	066623	071044	:ITEM 142	.WORD	EM142,DH142,DT142,DF142
003060	070175					
003062	047075	066623	071044	:ITEM 143	.WORD	EM143,DH143,DT143,DF143
003070	070175					
003072	047153	066623	071044	:ITEM 144	.WORD	EM144,DH144,DT144,DF144
003100	070175					
003102	047232	066262	070772	:ITEM 145	.WORD	EM145,DH145,DT145,DF145
003110	070125					
003112	047377	066262	070772	:ITEM 146	.WORD	EM146,DH146,DT146,DF146
003120	070125					
003122	047544	066262	070772	:ITEM 147	.WORD	EM147,DH147,DT147,DF147
003130	070125					
003132	047710	066262	070772	:ITEM 150	.WORD	EM150,DH150,DT150,DF150
003140	070125					
003142	050054	066623	071044	:ITEM 151	.WORD	EM151,DH151,DT151,DF151
003150	070221					
003152	050142	066623	071044	:ITEM 152	.WORD	EM152,DH152,DT152,DF152
003160	070221					
003162	045210	066623	071044	:ITEM 153	.WORD	EM153,DH153,DT153,DF153
003170	070221					
003172	045266	066623	071044	:ITEM 154	.WORD	EM154,DH154,DT154,DF154
003200	070221					
003202	050231	066623	071044	:ITEM 155	.WORD	EM155,DH155,DT155,DF155
003210	070221					
003212	050307	066623	071044	:ITEM 156	.WORD	EM156,DH156,DT156,DF156
003220	070221					

003222	050366	066262	070772	:ITEM 157	.WORD	EM157,DH157,DT157,DF157
003230	070151					
003232	050533	066623	071044	:ITEM 160	.WORD	EM160,DH160,DT160,DF160
003240	070221					
003242	050671	066262	070772	:ITEM 161	.WORD	EM161,DH161,DT161,DF161
003250	070151					
003252	051036	066262	070772	:ITEM 162	.WORD	EM162,DH162,DT162,DF162
003260	070151					
003262	051202	066623	071044	:ITEM 163	.WORD	EM163,DH163,DT163,DF163
003270	070221					
003272	051337	066262	070772	:ITEM 164	.WORD	EM164,DH164,DT164,DF164
003300	070151					
003302	055270	066623	071206	:ITEM 165	.WORD	EM165,DH165,DT165,DF165
003310	070331					
003312	055354	066623	071206	:ITEM 166	.WORD	EM166,DH166,DT166,DF166
003320	070331					
003322	055437	066623	071206	:ITEM 167	.WORD	EM167,DH167,DT167,DF167
003330	070331					
003332	055471	066623	071206	:ITEM 170	.WORD	EM170,DH170,DT170,DF170
003340	070331					
003342	055557	066623	071206	:ITEM 171	.WORD	EM171,DH171,DT171,DF171
003350	070331					
003352	055702	066623	071206	:ITEM 172	.WORD	EM172,DH172,DT172,DF172
003360	070331					
003362	055767	066623	071206	:ITEM 173	.WORD	EM173,DH173,DT173,DF173
003370	070331					
003372	056135	066623	071206	:ITEM 174	.WORD	EM174,DH174,DT174,DF174
003400	070331					
003402	056303	066623	071206	:ITEM 175	.WORD	EM175,DH175,DT175,DF175
003410	070331					
003412	056415	066623	071206	:ITEM 176	.WORD	EM176,DH176,DT176,DF176
003420	070363					
003422	056501	066623	071206	:ITEM 177	.WORD	EM177,DH177,DT177,DF177
003430	070363					
003432	056564	066623	071206	:ITEM 200	.WORD	EM200,DH200,DT200,DF200
003440	070363					
003442	056616	066623	071206	:ITEM 201	.WORD	EM201,DH201,DT201,DF201
003450	070363					

003452	056705	066623	071206	:ITEM 202	.WORD	EM202,DH202,DT202,DF202
003460	070363					
003462	057047	066623	071206	:ITEM 203	.WORD	EM203,DH203,DT203,DF203
003470	070363					
003472	057211	066623	071206	:ITEM 204	.WORD	EM204,DH204,DT204,DF204
003500	070363					
003502	057277	066623	071206	:ITEM 205	.WORD	EM205,DH205,DT205,DF205
003510	070363					
003512	057445	066623	071206	:ITEM 206	.WORD	EM206,DH206,DT206,DF206
003520	070363					
003522	057613	066762	071316	:ITEM 207	.WORD	EM207,DH207,DT207,DF207
003530	070425					
003532	057655	067052	071274	:ITEM 210	.WORD	EM210,DH210,DT210,DF210
003540	070415					
003542	057717	067052	071316	:ITEM 211	.WORD	EM211,DH211,DT211,DF211
003550	070425					
003552	060063	066762	071370	:ITEM 212	.WORD	EM212,DH212,DT212,DF212
003560	070451					
003562	060247	066762	071370	:ITEM 213	.WORD	EM213,DH213,DT213,DF213
003570	070451					
003572	060433	066762	071370	:ITEM 214	.WORD	EM214,DH214,DT214,DF214
003600	070451					
003602	060617	066762	071370	:ITEM 215	.WORD	EM215,DH215,DT215,DF215
003610	070451					
003612	061003	067052	071316	:ITEM 216	.WORD	EM216,DH216,DT216,DF216
003620	070425					
003622	061165	067113	071452	:ITEM 217	.WORD	EM217,DH217,DT217,DF217
003630	070501					
003632	061227	066722	071316	:ITEM 220	.WORD	EM220,DH220,DT220,DF220
003640	070425					
003642	061457	067052	071316	:ITEM 221	.WORD	EM221,DH221,DT221,DF221
003650	070425					
003652	061723	066722	071316	:ITEM 222	.WORD	EM222,DH222,DT222,DF222
003660	070425					
003662	062154	067052	071316	:ITEM 223	.WORD	EM223,DH223,DT223,DF223
003670	070425					
003672	062421	066722	071316	:ITEM 224	.WORD	EM224,DH224,DT224,DF224
003700	070425					

003702	062652	067052	071316	:ITEM 225	.WORD	EM225,DH225,DT225,DF225
003710	070425					
003712	063117	067166	071370	:ITEM 226	.WORD	EM226,DH226,DT226,DF226
003720	070451					
003722	063252	067255	071370	:ITEM 227	.WORD	EM227,DH227,DT227,DF227
003730	070451					
003732	063405	067166	071370	:ITEM 230	.WORD	EM230,DH230,DT230,DF230
003740	070451					
003742	063541	067255	071274	:ITEM 231	.WORD	EM231,DH231,DT231,DF231
003750	070451					
003752	057655	067255	071316	:ITEM 232	.WORD	EM232,DH232,DT232,DF232
003760	070451					
003762	063675	067344	071472	:ITEM 233	.WORD	EM233,DH233,DT233,DF233
003770	070510					
003772	063734	067405	071526	:ITEM 234	.WORD	EM234,DH234,DT234,DF234
004000	070525					
004002	064020	067473	071546	:ITEM 235	.WORD	EM235,DH235,DT235,DF235
004010	070534					
004012	064066	067533	071526	:ITEM 236	.WORD	EM236,DH236,DT236,DF236
004020	070525					
004022	064121	067405	071526	:ITEM 237	.WORD	EM237,DH237,DT237,DF237
004030	070525					
004032	064205	067621	071526	:ITEM 240	.WORD	EM240,DH240,DT240,DF240
004040	070525					
004042	064241	067344	071472	:ITEM 241	.WORD	EM241,DH241,DT241,DF241
004050	070510					
004052	064344	067621	071526	:ITEM 242	.WORD	EM242,DH242,DT242,DF242
004060	070525					
004062	064400	067344	071472	:ITEM 243	.WORD	EM243,DH243,DT243,DF243
004070	070510					
004072	064503	067344	071472	:ITEM 244	.WORD	EM244,DH244,DT244,DF244
004100	070510					
004102	064542	067344	071472	:ITEM 245	.WORD	EM245,DH245,DT245,DF245
004110	070510					
004112	043405	066262	070772	:ITEM 246	.WORD	EM246,DH246,DT246,DF246
004120	070151					
004122	064624	067711	071560	:ITEM 247	.WORD	EM247,DH247,DT247,DF247
004130	070540					

ERROR POINTER TABLE

004132	064660	067756	071576	:ITEM 250	.WORD	EM250,DH250,DT250,DF250
004140	070540					
004142	064712	067756	071576	:ITEM 251	.WORD	EM251,DH251,DT251,DF251
004150	070540					
004152	064745	066352	071610	:ITEM 252	.WORD	EM252,DH252,DT252,DF252
004160	070546					
004162	065036	066262	071622	:ITEM 253	.WORD	EM253,DH253,DT253,DF253
004170	070552					
004172	065122	066262	071622	:ITEM 254	.WORD	EM254,DH254,DT254,DF254
004200	070552					
004202	065207	066262	071622	:ITEM 255	.WORD	EM255,DH255,DT255,DF255
004210	070552					
004212	065275	066262	071622	:ITEM 256	.WORD	EM256,DH256,DT256,DF256
004220	070552					
004222	065364	066262	071622	:ITEM 257	.WORD	EM257,DH257,DT257,DF257
004230	070552					
004232	065452	066262	071622	:ITEM 260	.WORD	EM260,DH260,DT260,DF260
004240	070552					
004242	065541	066262	071622	:ITEM 261	.WORD	EM261,DH261,DT261,DF261
004250	070552					
004252	065631	066262	071622	:ITEM 262	.WORD	EM262,DH262,DT262,DF262
004260	070552					
004262	065722	066262	071622	:ITEM 263	.WORD	EM263,DH263,DT263,DF263
004270	070552					
004272	066007	066262	071622	:ITEM 264	.WORD	EM264,DH264,DT264,DF264
004300	070552					
004302	066074	066262	071622	:ITEM 265	.WORD	EM265,DH265,DT265,DF265
004310	070552					
004312	066161	070016	071610	:ITEM 266	.WORD	EM266,DH266,DT266,DF266
004320	070546					

897  
898  
899

```

.SBTTL ACT11 HOOKS
:*****
:HOOKS REQUIRED BY ACT11
      $SVPC=,           ;SAVE PC
      =46
      $ENDAD           ;:1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
      =52
      .WORD 0           ;:2)SET LOC.52 TO ZERO
      =$SVPC           ;: RESTORE PC
.SBTTL APT PARAMETER BLOCK
    
```

000046 004322  
000052 000046  
000000 033356  
004322 000052

900

\*\*\*\*\*  
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT  
\*\*\*\*\*

000024 004322  
000024 000024  
000044 000200  
000044 000044  
000044 004322  
000044 004322

.\$X=. ;;SAVE CURRENT LOCATION  
=24 ;;SET POWER FAIL TO POINT TO START OF PROGRAM  
200 ;;FOR APT START UP  
=44 ;;POINT TO APT INDIRECT ADDRESS PNTR.  
\$APTHDR ;;POINT TO APT HEADER BLOCK  
=.\$X ;;RESET LOCATION COUNTER

\*\*\*\*\*  
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC  
:INTERFACE SPEC.

004322  
004322 000000  
004324 001316  
004326 000010  
004330 000040  
004332 000000  
004334 000052

\$APTHD:  
\$HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.  
\$MADR: .WORD \$MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)  
\$STMT: .WORD 10 ;;RUN TIM OF LONGEST TEST  
\$PASTM: .WORD 40 ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)  
\$UNITM: .WORD 0 ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT  
.WORD \$ETEND-\$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

901  
902  
903 004336

START:  
:SBTTL INITIALIZE THE COMMON TAGS

004336 012706 001100  
004342 005026  
004344 022706 001140  
004350 001374  
004352 012706 001100

;;CLEAR THE COMMON TAGS (\$CMTAG) AREA  
MOV # \$CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED  
CLR (R6)+ ;;CLEAR MEMORY LOCATION  
CMP #SWR,R6 ;;DONE?  
BNE -6 ;;LOOP BACK IF NO  
MOV #STACK,SP ;;SETUP THE STACK PCINTER

004356 012737 033436 000020  
004364 012737 000340 000022  
004372 012737 033716 000030  
004400 012737 000340 000032  
004406 012737 035734 000034  
004414 012737 000340 000036  
004422 012737 036020 000024  
004430 012737 000340 000026  
004436 016767 026536 026526  
004444 005067 174632  
004450 005067 174630  
004454 112767 000001 174433

;;INITIALIZE A FEW VECTORS  
MOV # \$SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE  
MOV #340,@#IOTVEC+2 ;;LEVEL 7  
MOV # \$ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE  
MOV #340,@#EMTVEC+2 ;;LEVEL 7  
MOV # \$TRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS  
MOV #340,@#TRAPVEC+2;LEVEL 7  
MOV # \$PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR  
MOV #340,@#PWRVEC+2 ;;LEVEL 7  
MOV \$ENDCT,\$EOPCT ;;SETUP END-OF-PROGRAM COUNTER  
CLR \$TIMES ;;INITIALIZE NUMBER OF ITERATIONS  
CLR \$ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS  
MOVB #1,\$ERMAX ;;ALLOW ONE ERROR PER TEST

004462 012737 033422 000014  
004470 012737 000340 000016  
004476 012767 000002 026716  
004504 012737 004532 000010  
004512 005046  
004514 012746 004522  
004520 000006  
004522 012767 000006 026672 64\$:  
004530 000402  
004532 062706 000010 65\$:  
004536 012737 000012 000010 66\$:  
004544 005067 026660  
004550 012767 004550 174330

;;INITIALIZE THE 'T-BIT' TRAP VECTOR. THEN LOAD LOCATION '\$RTRN', IN  
;;THE 'END-OF-PASS' (\$EOP) ROUTINE, WITH A 'RTI' OR 'RTT'.  
MOV # \$RTRN,@#TBITVEC ;;SET 'T' BIT VECTOR TO \$RTRN  
MOV #340,@#TBITVEC+2 ;;LEVEL 7  
MOV #RTI,\$RTRN ;;SET \$RTRN TO A RTI  
MOV #65\$,@#RESVEC ;;TRY TO DO A RTT  
CLR -(SP) ;;DUMMY PS  
MOV #64\$,-(SP) ;;AND PC  
RTT ;;TRY THE RTT  
MOV #RTT,\$RTRN ;;RTT IS LEGAL--SET \$RTRN TO A RTT  
BR 66\$  
ADD #10,SP ;;RTT ILLEGAL--CLEAN OFF THE STACK  
MOV #RESVEC+2,@#RESVEC ;;RESTORE TRAP CATCHER  
CLR \$TBIT ;;CLEAR 'T' BIT SWITCH  
MOV #,\$LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE

```
004556 012767 004556 174324      MOV    #,$LPERR      ;;SETUP THE ERROR LOOP ADDRESS
                                ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
                                ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
004564 013746 000004              MOV    @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
004570 012737 004624 000004      MOV    #67$,@#ERRVEC ;;SET UP ERROR VECTOR
004576 012767 177570 174334      MOV    #DSWR,SWR     ;;SETUP FOR A HARDWARE SWICH REGISTER
004604 012767 177570 174330      MOV    #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
004612 022777 177777 174320      CMP    #-1,@SWR     ;;TRY TO REFERENCE HARDWARE SWR
004620 001012                      BNE    69$          ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
                                ;;AND THE HARDWARE SWR IS NOT = -1
004622 000403                      BR     68$          ;;BRANCH IF NO TIMEOUT
004624 012716 004632              67$:  MOV    #68$,(SP)   ;;SET UP FOR TRAP RETURN
004630 000002                      RTI
004632 012767 000176 174300      68$:  MOV    #SWREG,SWR   ;;POINT TO SOFTWARE SWR
004640 012767 000174 174274      MOV    #DISPREG,DISPLAY
004646 012637 000004              69$:  MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
004652 005067 174446              CLR    $PASS        ;;CLEAR PASS COUNT
004656 132767 000200 174453      BITB  #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
004664 001403                      BEQ    70$          ;;YES,USE NON-APT SWITCH
004666 012767 001340 174244      MOV    #SSWREG,SWR  ;;NO,USE APT SWITCH REGISTER
004674
904  .SBTTL  TYPE PROGRAM NAME
                                ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
004674 005227 177777              INC    #-1          ;;FIRST TIME?
004700 001047                      BNE    71$          ;;BRANCH IF NO
004702 022737 033356 000042      CMP    #SENDAD,@#42 ;;ACT-11?
004710 001443                      BEQ    71$          ;;BRANCH IF YES
004712 104401 004760              TYPE  ,72$        ;;TYPE ASCIZ STRING
                                .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
004716 005737 000042              TST   @#42         ;;ARE WE RUNNING UNDER XXDP/ACT?
004722 001012                      BNE    73$          ;;BRANCH IF YES
004724 126727 174406 000001      CMPB  $ENV,#1      ;;ARE WE RUNNING UNDER APT?
004732 001406                      BEQ    73$          ;;BRANCH IF YES
004734 026727 174200 000176      CMP   SWR,#SWREG   ;;SOFTWARE SWITCH REG SELECTED?
004742 001005                      BNE    74$          ;;BRANCH IF NO
004744 104405                      GTSWR              ;;GET SOFT-SWR SETTINGS
004746 000403                      BR     74$
004750 112767 000001 174156      73$:  MOVB  #1,$AUTOB   ;;SET AUTO-MODE INDICATOR
004756 000420              74$:  BR     71$          ;;GET OVER THE ASCIZ
005020              ;;72$:  .ASCIZ <CRLF>*CKFPBAO FP11F FLTG PNT PRT B*<CRLF>
                                71$:
905  LOOP:
906
907
908
919  ;;*****
                                *TEST 1          ROUND\TRUNK TEST
                                *
                                * THIS IS A TEST OF THE ROUND\TRUNK
                                * FLOWS. IN PARTICULAR TWO THINGS ARE TESTED:
                                * FIRST A CONDITION IN WHICH ROUNDING
                                * RESULTS IN THE NEED FOR RENORMALIZATION, AND
                                * SECOND THE PSW CONDITION CODES N AND
                                * Z BIT COMBINATIONS
                                *
                                ;;*****
```



```

005020 000004          TST1:  SCOPE
920
921                      ;ROUND AND NORMALIZE TEST
922
923 005022          HH1:
005022 104413          LPERR                      ;SET UP THE LOOP ON ERROR ADDRESS.
924 005024 012704 003200      MOV #3200,R4          ;SET FIU, FIV, AND FD
925 005030 170104          LDFPS R4
926 005032 012737 005052 001236      MOV #HH2,@#STMP2
927 005040 012700 006602          MOV #HHP0,R0          ;SET ACO OPERAND
928 005044 172410          LDD (R0),ACO
929 005046 012700 006612          MOV #HHP1,R0          ;FSPC
930 005052 172010          HH2:  ADDD (R0),ACO          ;TEST INSTRUCTION
931 005054 170205          STFPS R5          ;GET FPS
932 005056 012700 006572          MOV #HHDATO,R0        ;GET THE RESULT
933 005062 174010          STD ACO,(R0)
934 005064 012701 006622          MOV #HHP2,R1          ;IS IT CORRECT
935 005070 012702 000004          MOV #4,R2
936 005074 022021          HH3:  CMP (R0)+,(R1)+
937 005076 001415          BEQ HH6
938 005100 012700 006572          MOV #HHDATO,R0        ;DID FLOW GO
939 005104 012701 006632          MOV #HHP3,R1          ;FROM STATE 663
940 005110 012702 000004          MOV #4,R2          ;TO 313 INSTEAD
941 005114 022021          HH4:  CMP (R0)+,(R1)+          ;OF TO 353
942 005116 001402          BEQ HH5
943 005120 000137 005612          JMP @#HHERO
944 005124 077205          HH5:  SOB R2,HH4
945 005126 000137 005660          JMP @#HHER1
946 005132 077220          HH6:  SOB R2,HH3
947 005134 020405          CMP R4,R5          ;FPS CORRECT?
948 005136 001402          BEQ HH7
949 005140 000137 005726          JMP @#HHERO0
950
951                      ;THIS IS A TEST OF THE ABILITY
952                      ;OF NORMALIZE TO PRODUCE A ZERO EXP. AND
953                      ;OF THE R\T ALGORITHM TO PORPERLY SET THE FPS
954
955 005144          HH7:
005144 104413          LPERR                      ;SET UP THE LOOP ON ERROR ADDRESS.
956 005146 012704 043200      MOV #043200,R4        ;SET FIU,FIV,AND FD
957                      ;FID
958 005152 170104          LDFPS R4
959 005154 012737 005202 001236      MOV #HH8,@#STMP2
960 005162 012737 006522 000244      MOV #HHTRAP,@#FPVECT ;IN CASE UNDERFLOW
961 005170 012700 006652          MOV #HHP5,R0          ;TRAP OCCURS
962 005174 172410          LDD (R0),ACO          ;SET ACO OPERAND
963 005176 012700 006662          MOV #HHP6,R0          ;FSPC
964 005202 172010          HH8:  ADDD (R0),ACO          ;TEST INSTRUCTION
965 005204 170205          STFPS R5          ;GET FPS
966 005206 012700 006572          MOV #HHDATO,R0        ;GET THE RESULT
967 005212 174010          STD ACO,(R0)
968 005214 012701 006642          MOV #HHP4,R1          ;IS IT CORRECT
969 005220 012702 000004          MOV #4,R2
970 005224 022021          HH9:  CMP (R0)+,(R1)+
971 005226 001402          BEQ HH10
972 005230 000137 005774          JMP @#HHER2
973 005234 077205          HH10: SOB R2,HH9

```

```

974 005236 052704 100004      BIS      #100004,R4      ;FPS CORRECT?
975 005242 020405      CMP      R4,R5
976 005244 001402      BEQ     HH11
977 005246 000137 006042      JMP     @#HHER3
978                               ;THIS IS A TEST OF THE R\T ALGORITHM'S
979                               ;ABILITY TO SET BOTH N AND Z ON A - 0 RESULT.
980 005252                               HH11:
981 005252 104413      LPERR                               ;SET UP THE LOOP ON ERROR ADDRESS.
982 005254 012704 043200      MOV     #043200,R4      ;SET FIV, FIV, AND FD
983 005260 170104      LDFPS  R4
984 005262 012737 005302 001236      MOV     #HH12,@#STMP2
985 005270 012700 006702      MOV     #HHP8,R0      ;SET ACO OPERAND
986 005274 172410      LDD    (R0),ACO
987 005276 012700 006712      MOV     #HHP9,R0      ;FSPC
988 005302 172010      HH12:  ADDD  (R0),ACO      ;TEST INSTRUCTION
989 005304 170205      STFPS  R5      ;GET FPS
990 005306 012700 006572      MOV     #HHDAT0,R0      ;GET THE RESULT
991 005312 174010      STD    ACO,(R0)
992 005314 012701 006672      MOV     #HHP7,R1      ;IS IT CORRECT
993 005320 012702 000004      MOV     #4,R2
994 005324 022021      HH13:  CMP     (R0)+,(R1)+
995 005326 001415      BEQ    HH16
996 005330 012700 006572      MOV     #HHDAT0,R0
997 005334 012701 006642      MOV     #HHP4,R1
998 005340 012702 000004      MOV     #4,R2
999 005344 022021      HH14:  CMP     (R0)+,(R1)+
1000 005346 001402      BEQ    HH15
1001 005350 000137 006110      JMP     @#HHER4
1002 005354 077205      HH15:  SOB    R2,HH14
1003 005356 000137 006156      JMP     @#HHER5
1004 005362 077220      HH16:  SOB    R2,HH13
1005 005364 052704 100014      BIS     #100014,R4      ;FPS CORRECT?
1006 005370 020405      CMP     R4,R5
1007 005372 001402      BEQ    HH17
1008 005374 000137 006224      JMP     @#HHER6
1009                               ;TEST THAT CC ARE CLEARED BY R\T
1010 005400                               HH17:
1011 005400 104413      LPERR                               ;SET UP THE LOOP ON ERROR ADDRESS.
1012 005402 012704 000200      MOV     #00200,R4      ;SET FIV, FIV, AND FD
1013 005406 170104      LDFPS  R4
1014 005410 012737 005436 001236      MOV     #HH18,@#STMP2
1015 005416 012737 036660 000244      MOV     #FPSPUR,@#FPVECT
1016 005424 012700 006702      MOV     #HHP8,R0      ;SET ACO OPERAND
1017 005432 012700 006702      LDD    (R0),ACO
1018 005436 172010      HH18:  MOV     #HHP8,R0      ;FSPC
1019 005440 170205      ADDD  (R0),ACO      ;TEST INSTRUCTION
1020 005442 012700 006572      STFPS  R5      ;GET FPS
1021 005446 174010      MOV     #HHDAT0,R0      ;GET THE RESULT
1022 005450 012701 006722      STD    ACO,(R0)
1023 005454 012702 000004      MOV     #HHP10,R1      ;IS IT CORRECT
1024 005460 022021      HH19:  MOV     #4,R2
1025 005462 001402      CMP     (R0)+,(R1)+
1026 005464 000137 006272      BEQ    HH20
1027 005470 077205      HH20:  JMP     @#HHER7
1028 005472 052704 000000      SOB    R2,HH19
1028 005472 052704 000000      BIS     #00000,R4      ;FPS CORRECT?
  
```

1029	005476	020405				CMP	R4,R5	
1030	005500	001402				BEQ	HH21	
1031	005502	000137	006340			JMP	@#HHER8	
1032								:TEST THAT N IS SET BY R\T
1033	005506					HH21:		
	005506	104413				LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
1034	005510	012704	003200			MOV	#3200,R4	:SET FIV, FIV, AND FD
1035	005514	170104				LDFPS	R4	
1036	005516	012737	005536	001236		MOV	#HH22,@#STMP2	
1037	005524	012700	006652			MOV	#HHP5,R0	:SET ACO OPERAND
1038	005530	172410				LDD	(R0),ACO	
1039	005532	012700	006652			MOV	#HHP5,R0	:FSPC
1040	005536	172010				HH22: ADDD	(R0),ACO	:TEST INSTRUCTION
1041	005540	170205				STFPS	R5	:GET FPS
1042	005542	012700	006572			MOV	#HHDATO,R0	:GET THE RESULT
1043	005546	174010				STD	ACO,(R0)	
1044	005550	012701	006732			MOV	#HHP11,R1	:IS IT CORRECT
1045	005554	012702	000004			MOV	#4,R2	
1046	005560	022021				HH23: CMP	(R0)+,(R1)+	
1047	005562	001402				BEQ	HH24	
1048	005564	000137	006406			JMP	@#HHER9	
1049	005570	077205				HH24: SOB	R2,HH23	
1050	005572	052704	000010			BIS	#10,R4	
1051	005576	020405				CMP	R4,R5	:FPS CORRECT?
1052	005600	001402				BEQ	HH25	
1053	005602	000137	006454			JMP	@#HHER10	
1054	005606	000137	006742			HH25: JMP	@#HHDONE	
1055	005612					HHER0:		
	005612	010537	001252			MOV	R5,@#STMP10	
	005616	010437	001254			MOV	R4,@#STMP11	
	005622	012737	006612	001240		MOV	#HHP1,@#STMP3	
	005630	012737	006602	001242		MOV	#HHP0,@#STMP4	
	005636	012737	006572	001244		MOV	#HHDATO,@#STMP5	
	005644	012737	006622	001246		MOV	#HHP2,@#STMP6	
	005652	104207				1\$: ERROR	+207	
	005654	000137	006742			JMP	@#HHDONE	
1056	005660					HHER1:		
	005660	010537	001252			MOV	R5,@#STMP10	
	005664	010437	001254			MOV	R4,@#STMP11	
	005670	012737	006612	001240		MOV	#HHP1,@#STMP3	
	005676	012737	006602	001242		MOV	#HHP0,@#STMP4	
	005704	012737	006572	001244		MOV	#HHDATO,@#STMP5	
	005712	012737	006622	001246		MOV	#HHP2,@#STMP6	
	005720	104211				1\$: ERROR	+211	
	005722	000137	006742			JMP	@#HHDONE	
1057	005726					HHER00:		
	005726	010537	001252			MOV	R5,@#STMP10	
	005732	010437	001254			MOV	R4,@#STMP11	
	005736	012737	006612	001240		MOV	#HHP1,@#STMP3	
	005744	012737	006602	001242		MOV	#HHP0,@#STMP4	
	005752	012737	006572	001244		MOV	#HHDATO,@#STMP5	
	005760	012737	006622	001246		MOV	#HHP2,@#STMP6	
	005766	104210				1\$: ERROR	+210	
	005770	000137	006742			JMP	@#HHDONE	
1058	005774					HHER2:		
	005774	010537	001252			MOV	R5,@#STMP10	
	006000	010437	001254			MOV	R4,@#STMP11	

	006004	012737	006662	001240	MOV	#HHP6,@#STMP3
	006012	012737	006652	001242	MOV	#HHP5,@#STMP4
	006020	012737	006572	001244	MOV	#HHDATO,@#STMP5
	006026	012737	006642	001246	MOV	#HHP4,@#STMP6
	006034	104207			1\$:	ERROR
	006036	000137	006742		JMP	+207
1059	006042					@#HHDONE
	006042	010537	001252		HER3:	
	006046	010437	001254		MOV	R5,@#STMP10
	006052	012737	006662	001240	MOV	R4,@#STMP11
	006060	012737	006652	001242	MOV	#HHP6,@#STMP3
	006066	012737	006572	001244	MOV	#HHP5,@#STMP4
	006074	012737	006642	001246	MOV	#HHDATO,@#STMP5
	006102	104214			1\$:	ERROR
	006104	000137	006742		JMP	+214
1060	006110					@#HHDONE
	006110	010537	001252		HER4:	
	006114	010437	001254		MOV	R5,@#STMP10
	006120	012737	006712	001240	MOV	R4,@#STMP11
	006126	012737	006702	001242	MOV	#HHP9,@#STMP3
	006134	012737	006572	001244	MOV	#HHP8,@#STMP4
	006142	012737	006672	001246	MOV	#HHDATO,@#STMP5
	006150	104207			1\$:	ERROR
	006152	000137	006742		JMP	+207
1061	006156					@#HHDONE
	006156	010537	001252		HER5:	
	006162	010437	001254		MOV	R5,@#STMP10
	006166	012737	006712	001240	MOV	R4,@#STMP11
	006174	012737	006702	001242	MOV	#HHP9,@#STMP3
	006202	012737	006572	001244	MOV	#HHP8,@#STMP4
	006210	012737	006672	001246	MOV	#HHDATO,@#STMP5
	006216	104216			1\$:	ERROR
	006220	000137	006742		JMP	+216
1062	006224					@#HHDONE
	006224	010537	001252		HER6:	
	006230	010437	001254		MOV	R5,@#STMP10
	006234	012737	006712	001240	MOV	R4,@#STMP11
	006242	012737	006702	001242	MOV	#HHP9,@#STMP3
	006250	012737	006572	001244	MOV	#HHP8,@#STMP4
	006256	012737	006672	001246	MOV	#HHDATO,@#STMP5
	006264	104215			1\$:	ERROR
	006266	000137	006742		JMP	+215
1063	006272					@#HHDONE
	006272	010537	001252		HER7:	
	006276	010437	001254		MOV	R5,@#STMP10
	006302	012737	006702	001240	MOV	R4,@#STMP11
	006310	012737	006702	001242	MOV	#HHP8,@#STMP3
	006316	012737	006572	001244	MOV	#HHP8,@#STMP4
	006324	012737	006722	001246	MOV	#HHDATO,@#STMP5
	006332	104207			1\$:	ERROR
	006334	000137	006742		JMP	+207
1064	006340					@#HHDONE
	006340	010537	001252		HER8:	
	006344	010437	001254		MOV	R5,@#STMP10
	006350	012737	006702	001240	MOV	R4,@#STMP11
	006356	012737	006702	001242	MOV	#HHP8,@#STMP3
	006364	012737	006572	001244	MOV	#HHP8,@#STMP4
					MOV	#HHDATO,@#STMP5

```

006372 012737 006722 001246      MOV    #HHP10,@#STMP6
006400 104212      1$:    ERROR  +212
006402 000137 006742      JMP    @#HHDONE
1065 006406      HHER9:  MOV    R5,@#STMP10
006406 010537 001252      MOV    R4,@#STMP11
006412 010437 001254      MOV    #HHP5,@#STMP3
006416 012737 006652 001240      MOV    #HHP5,@#STMP4
006424 012737 006652 001242      MOV    #HHDATO,@#STMP5
006432 012737 006572 001244      MOV    #HHP11,@#STMP6
006440 012737 006732 001246      1$:    ERROR  +207
006446 104207      JMP    @#HHDONE
1066 006450 000137 006742      HHER10: MOV    R5,@#STMP10
006454 010537 001252      MOV    R4,@#STMP11
006460 010437 001254      MOV    #HHP5,@#STMP3
006464 012737 006652 001240      MOV    #HHP5,@#STMP4
006472 012737 006652 001242      MOV    #HHDATO,@#STMP5
006500 012737 006572 001244      MOV    #HHP11,@#STMP6
006506 012737 006732 001246      1$:    ERROR  +213
006514 104213      JMP    @#HHDONE
1067 006516 000137 006742      HHTRAP: MOV    @#STMP2,R3      ;WAS THE TRAP TO 244
1068 006522 013703 001236      ADD    #2,R3          ;ON THE INSTRUCTION
1069 006526 062703 000002      CMP    R3,(SP)       ;BEING TESTED?
1070 006532 020316      BEQ    1$
1071 006534 001402      JMP    @#FPSPUR
1072 006536 000137 036660      1$:    MOV    (SP),@#STMP2  ;FAILURE OF FPS INTERRUPT
1073 006542 011637 001236      ;DISABLE BIT (FID=1)
1074 006546 022626      CMP    (SP)+,(SP)+  ;TO INHIBIT TRAP.
1075 006550 170201      STFPS  R1
1076 006552 010137 001240      MOV    R1,@#STMP3
1077 006556 170301      STST  R1
1078 006560 010137 001242      MOV    R1,@#STMP4
1079 006564 104217      2$:    ERROR  +217
1080 006566 000137 006742      JMP    @#HHDONE
1081 006572 000000      HHDATO: 0
1082 006574 000000      0
1083 006576 000000      0
1084 006600 000000      0
1085 006602 000452      HHP0:  452
1086 006604 125252      125252
1087 006606 125252      125252
1088 006610 125253      125253
1089 006612 000252      HHP1:  252
1090 006614 125252      125252
1091 006616 125252      125252
1092 006620 125252      125252
1093 006622 000600      HHP2:  600      ;HHP0 + HHP1 WITH
1094 006624 000000      0              ;PROPER NORMALIZATION
1095 006626 000000      0
1096 006630 000000      0
1097 006632 000400      HHP3:  400      ;HHP0 + HHP1 WITH
1098 006634 000000      0              ;BAD NORMALIZATION
1099 006636 000000      0
1100 006640 000000      0
1101 006642 000000      HHP4:  0
1102 006644 000000      0
  
```

1103 006646 000000  
1104 006650 000000  
1105 006652 100200  
1106 006654 000000  
1107 006656 000000  
1108 006660 000000  
1109 006662 000300  
1110 006664 000000  
1111 006666 000000  
1112 006670 000000  
1113 006672 100000  
1114 006674 000000  
1115 006676 000000  
1116 006700 000000  
1117 006702 000200  
1118 006704 000000  
1119 006706 000000  
1120 006710 000000  
1121 006712 100300  
1122 006714 000000  
1123 006716 000000  
1124 006720 000000  
1125 006722 000400  
1126 006724 000000  
1127 006726 000000  
1128 006730 000000  
1129 006732 100400  
1130 006734 000000  
1131 006736 000000  
1132 006740 000000  
1133 006742 104412  
006742 104412

HHP5: 100200  
HHP6: 300  
HHP7: 100000  
HHP8: 200  
HHP9: 100300  
HHP10: 400  
HHP11: 100400  
HMDONE: RSETUP

;HHP7 = HHP8 + HHP9  
; = HHP5 + HHP6

;HHP10 = HHP8 + HHP8

;HHP11 = HHP5 + HHP5

;GO INITIALIZE THE FPS AND STACK; AND  
;SEE IF THE USER HAS EXPRESSED  
;THE DESIRE TO CHANGE THE SOFTWARE  
;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
;THE USER TYPED CONTROL G?).

1134  
1148  
1149

\*\*\*\*\*  
;TEST 2 OVER\UNDER TEST  
;\*  
;\*THIS IS A PARTIAL TEST OF THE OVER\UNDER  
;\*FLOWS. ONE OVERFLOW AND TWO UNDERFLOW  
;\*CONDITIONS ARE CHECKED. THE REMAINING  
;\*UNDERFLOW COND. AND THE REMAINING OVERFLOW  
;\*COND. WILL BE CHECKED LATER USING THE  
;\*XXX INSTRUCTION. HERE EACH CONDITION TESTED  
;\*IS CHECKED BOTH WITH TRAPS ENABLED  
;\*(FIU=1 OR FIV=1) AND ALSO WITH TRAPS  
;\*DISABLED (FIU=0 OR FIV=0).  
;\*  
\*\*\*\*\*  
TST2: SCOPE  
;TEST OVERFLOW CONDITION WITH TRAP DISABLER FIV=0  
GG1: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.

1150 006744 000004  
1151  
1152 006746 104413  
006746 104413

```

1153 006750 012704 000200      MOV      #200,R4          ;CLEAR FIU, FIV, AND SET FD
1154 006754 170104      LDFPS   R4
1155 006756 012737 007004 001236      MOV      #GG2,@#STMP2
1156 006764 012737 010036 000244      MOV      #GGER0,@#FPVECT
1157 006772 012700 011610      MOV      #GGP5,R0        ;SET ACO OPERAND
1158 006776 172410      LDD     (R0),ACO
1159 007000 012700 011610      MOV      #GGP5,R0        ;FSRC
1160 007004 172010      GG2:    ADDD   (R0),ACO    ;TEST INSTRUCTION
1161 007006 170205      STFPS   R5              ;GET FPS
1162 007010 012700 011540      MOV      #GGDATO,R0     ;GET THE RESULT
1163 007014 174010      STD     ACO,(R0)
1164 007016 012701 011620      MOV      #GGP6,R1      ;IS IT CORRECT
1165 007022 012702 000004      MOV      #4,R2
1166 007026 022021      GG3:    CMP    (R0)+,(R1)+
1167 007030 001402      BEQ     GG4
1168 007032 000137 010134      JMP     @#GGER1
1169 007036 077205      GG4:    SOB   R2,GG3
1170 007040 052704 000006      BIS     #6,R4          ;FPS CORRECT?
1171 007044 020405      CMP     R4,R5
1172 007046 001402      BEQ     GG5
1173 007050 000137 010202      JMP     @#GGER2
1174
1175      ;TEST OVERFLOW WITH TRAPS ENABLED
1176      ;FIV = 1
1176 007054      GG5:    LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
1177 007056 012704 001200      MOV      #1200,R4      ;CLEAR FIU, SET FIV, AND FD
1178 007062 170104      LDFPS   R4
1179 007064 012737 007112 001236      MOV      #GG6,@#STMP2
1180 007072 012737 007130 000244      MOV      #GG7,@#FPVECT
1181 007100 012700 011610      MOV      #GGP5,R0        ;SET ACO OPERAND
1182 007104 172410      LDD     (R0),ACO
1183 007106 012700 011610      MOV      #GGP5,R0        ;FSPC
1184 007112 172010      GG6:    ADDD   (R0),ACO    ;TEST INSTRUCTION
1185 007114 170000      CFCC
1186 007116 012700 011540      MOV      #GGDATO,R0
1187 007122 174010      STD     ACO,(R0)
1188 007124 000137 010250      JMP     @#GGER3
1189 007130 013703 001236      GG7:    MOV    @#STMP2,R3
1190 007134 062703 000002      ADD     #2,R3
1191 007140 020316      CMP     R3,(SP)
1192 007142 001402      BEQ     1$
1193 007144 000137 036660      JMP     @#FPSPUR
1194 007150 011637 001236      1$:    MOV    (SP),@#STMP2
1195 007154 022626      CMP    (SP)+,(SP)+
1196 007156 170205      STFPS   R5
1197 007160 012700 011540      MOV      #GGDATO,R0     ;GET THE RESULT
1198 007164 174010      STD     ACO,(R0)
1199 007166 012701 011620      MOV      #GGP6,R1      ;IS IT CORRECT
1200 007172 012702 000004      MOV      #4,R2
1201 007176 022021      GG8:    CMP    (R0)+,(R1)+
1202 007200 001402      BEQ     GG9
1203 007202 000137 010316      JMP     @#GGER4
1204 007206 077205      GG9:    SOB   R2,GG8
1205 007210 052704 100006      BIS     #100006,R4
1206 007214 020405      CMP     R4,R5          ;FPS CORRECT?
1207 007216 001402      BEQ     1$
1208 007220 000137 010366      JMP     @#GGER6

```

```

1209 007224 012704 000010      1$:  MOV      #10,R4
1210                               :CHECK FEC
1211 007230 170305              STST     R5
1212 007232 020405              CMP      R4,R5
1213 007234 001402              BEQ      GG10
1214 007236 000137 010320      JMP      @#GGER5
1215                               :CHECK UNDER FLOW CONDITION WITH
1216                               :TRAPS DISABLED (FIU = 0)
1217 007242                      GG10:
      007242 104413              LPERR                    ;SET UP THE LOOP ON ERROR ADDRESS.
1218 007244 012704 000200      MOV      #0200,R4        ;SET FIU, FIV, AND FD
      007244 170104              LDFPS   R4
1219 007250 170104              MOV      #GG11,@#STMP2
1220 007252 012737 007300 001236  MOV      #GGER7,@#FPVECT
1221 007260 012737 010434 000244  MOV      #GGP2,R0
1222 007266 012700 011560      MOV      (R0),AC0        ;SET ACO OPERAND
1223 007272 172410              LDD      (R0),AC0        ;FSRC
1224 007274 012700 011570      MOV      #GGP3,R0
1225 007300 172010      GG11:  ADDD     (R0),AC0    ;TEST INSTRUCTION
1226 007302 170205              STFPS   R5              ;GET FPS
1227 007304 012700 011540      MOV      #GGDAT0,R0      ;GET THE RESULT
1228 007310 174010              STD     AC0,(R0)
1229 007312 012701 011620      MOV      #GGP6,R1        ;IS IT CORRECT
1230 007316 012702 000004      MOV      #4,R2
1231 007322 022021      GG12:  CMP      (R0)+,(R1)+
1232 007324 001402              BEQ      GG13
1233 007326 000137 010532      JMP      @#GGER8
1234 007332 077205      GG13:  SOB     R2,GG12
1235 007334 052704 000004      BIS     #4,R4            ;FPS CORRECT?
1236 007340 020405              CMP     R4,R5
1237 007342 001402              BEQ     GG14
1238 007344 000137 010600      JMP     @#GGER9
1239                               :CHECK UNDERFLOW CONDITION WITH
1240                               :TRAP ENABLED (FIU = 1)
1241 007350                      GG14:
      007350 104413              LPERR                    ;SET UP THE LOOP ON ERROR ADDRESS.
1242 007352 012704 002200      MOV      #2200,R4        ;SET FIU, FIV, AND FD
      007352 170104              LDFPS   R4
1243 007356 170104              MOV      #GG15,@#STMP2
1244 007360 012737 007406 001236  MOV      #GG16,@#FPVECT
1245 007366 012737 007424 000244  MOV      #GGP2,R0
1246 007374 012700 011560      MOV      (R0),AC0        ;SET ACO OPERAND
1247 007400 172410              LDD     (R0),AC0        ;FSPC
1248 007402 012700 011570      MOV      #GGP3,R0
1249 007406 172010      GG15:  ADDD     (R0),AC0    ;TEST INSTRUCTION
1250 007410 170000              CFCC
1251 007412 012700 011540      MOV      #GGDAT0,R0
1252 007416 174010              STD     AC0,(R0)
1253 007420 000137 010646      JMP     @#GGER10
1254 007424 013703 001236      GG16:  MOV     @#STMP2,R3
1255 007430 062703 000002      ADD     #2,R3
1256 007434 021603              CMP     (SP),R3
1257 007436 001402              BEQ     1$
1258 007440 000137 036660      JMP     @#FPSPUR
1259 007444 011637 001236      1$:   MOV     (SP),@#STMP2
1260 007450 022626              CMP     (SP)+,(SP)+
1261 007452 170205              STFPS   R5              ;GET FPS
1262 007454 012700 011540      MOV     #GGDAT0,R0      ;GET THE RESULT
1263 007460 174010              STD     AC0,(R0)

```



1264	007462	012701	011630		MOV	#GGP7,R1		:IS IT CORRECT
1265	007466	012702	000004		MOV	#4,R2		
1266	007472	022021		GG17:	CMP	(R0)+,(R1)+		
1267	007474	001402			BEQ	GG18		
1268	007476	000137	010714		JMP	@#GGER11		
1269	007502	077205		GG18:	SOB	R2,GG17		
1270	007504	052704	100000		BIS	#100000,R4		
1271	007510	020405			CMP	R4,R5		:FPS CORRECT?
1272	007512	001402			BEQ	2\$		
1273	007514	000137	010762		JMP	@#GGER12		
1274	007520			2\$:				
1275	007520	012704	000012	1\$:	MOV	#12,R4		
1276				:CHECK	FEC			
1277	007524	170305			STST	R5		
1278	007526	020405			CMP	R4,R5		
1279	007530	001402			BEQ	GG19		
1280	007532	000177	001272		JMP	@GGER13		
1281								:CHECK UNDERFLOW CONDITION WITH TRAPS
1282								:DISABLED (FIU = 0)
1283	007536			GG19:				
	007536	104413			LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
1284	007540	012704	000200		MOV	#0200,R4		:SET FIU, FIV, AND FD
1285	007544	170104			LDFPS	R4		
1286	007546	012737	007574	001236	MOV	#GG20,@#STMP2		
1287	007554	012737	011076	000244	MOV	#GGER14,@#FPVECT		
1288	007562	012700	011560		MOV	#GGP2,R0		:SET ACO OPERAND
1289	007566	172410			LDD	(R0),ACO		
1290	007570	012700	011640		MOV	#GGP8,R0		:FSPC
1291	007574	172010		GG20:	ADDD	(R0),ACO		:TEST INSTRUCTION
1292	007576	170205			STFPS	R5		:GET FPS
1293	007600	012700	011540		MOV	#GGDAT0,R0		:GET THE RESULT
1294	007604	174010			STD	ACO,(R0)		
1295	007606	012701	011620		MOV	#GGP6,R1		:IS IT CORRECT
1296	007612	012702	000004		MOV	#4,R2		
1297	007616	022021		GG21:	CMP	(R0)+,(R1)+		
1298	007620	001402			BEQ	GG22		
1299	007622	000137	011174		JMP	@#GGER15		
1300	007626	077205		GG22:	SOB	R2,GG21		
1301	007630	052704	000004		BIS	#4,R4		:FPS CORRECT?
1302	007634	020405			CMP	R4,R5		
1303	007636	001402			BEQ	GG23		
1304	007640	000137	011242		JMP	@#GGER16		

1306

;CHECK UNDERFLOW CONDITION WITH TRAP

```

1308                                     ;ENABLED (FIU = 1)
1309 007644                               GG23: LPERR                               ;SET UP THE LOOP ON ERROR ADDRESS.
      007644 104413                       MOV #2200,R4                               ;SET FIU, FIV, AND FD
1310 007646 012704 002200                 LDFPS R4
1311 007652 170104                       MOV #GG24,@#STMP2
1312 007654 012737 007702 001236         MOV #GG25,@#FPVECT
1313 007662 012737 007720 000244         MOV #GGP2,R0                               ;SET ACO OPERAND
1314 007670 012700 011560                 MOV #GGP8,R0                               ;FSRC
1315 007674 172410                       LDD (R0),ACO                               ;TEST INSTRUCTION
1316 007676 012700 011640                 GG24: ADDD (R0),ACO
      007702 172010                       CFCC
1317 007704 170000                       MOV #GGDAT0,R0
1318 007706 012700 011540                 STD ACO,(R0)
1319 007712 174010                       JMP @#GGER17
1320 007714 000137 011310                 GG25: MOV @#STMP2,R0
1321 007714 000137 011310                 ADD #2,R0
1322 007720 013700 001236                 CMP R0,(SP)
1323 007724 062700 000002                 BEQ 1$
1324 007730 020016                       JMP @#FPSPUR
1325 007732 001402                       1$: MOV (SP),@#STMP2
1326 007734 000137 036660                 CMP (SP)+,(SP)+
1327 007740 011637 001236                 STFPS R5                               ;GET FPS
1328 007744 022626                       MOV #GGDAT0,R0                               ;GET THE RESULT
1329 007746 170205                       STD ACO,(R0)
1330 007750 012700 011540                 MOV #GGP9,R1                               ;IS IT CORRECT
1331 007754 174010                       MOV #4,R2
1332 007756 012701 011650                 GG26: CMP (R0)+,(R1)+
1333 007762 012702 000004                 BEQ GG27
1334 007766 022021                       JMP @#GGER18
1335 007770 001402                       GG27: SOB R2,GG26
1336 007772 000137 011356                 BIS #100004,R4
1337 007776 077205                       CMP R4,R5                               ;FPS CORRECT?
1338 010000 052704 100004                 BEQ 1$
1339 010004 020405                       JMP GGER20
1340 010006 001402                       1$: MOV #12,R4
1341 010010 000167 001456                 ;CHECK FEC
1342 010014 012704 000012                 STST R5
1343                                     CMP R4,R5
1344 010020 170305                       BEQ GG28
1345 010022 020405                       JMP GGER19
1346 010024 001402
1347 010026 000167 001372                 GG28: JMP @#GGDONE
1348
1349 010032 000137 011660                 GGER0: MOV @#STMP2,R1
1350                                     ADD #2,R1
1351 010036 013701 001236                 CMP R1,(SP)
1352 010042 062701 000002                 BEQ 10$
1353 010046 020116                       5$: JMP @#FPSPUR
1354 010050 001402                       10$:
1355 010052 000137 036660                 STST R1
1356 010056 000137 036660                 CMP R1,#10
1357 010056 170301                       BNE 5$
1358 010060 020127 000010                 CMP (SP)+,(SP)+
1359 010064 001372                       MOV #GGDAT0,R0
1360 010066 022626                       STD ACO,(R0)
1361 010070 012700 011540                 MOV #GGP5,@#STMP3
1362 010074 174010
1363 010076 012737 011610 001240

```

	010104	012737	011610	001242	MOV	#GGP5,@#STMP4
	010112	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010120	012737	011620	001246	MOV	#GGP6,@#STMP6
	010126	104220			1\$: ERROR	+220
	010130	000137	011660		JMP	@#GGDONE
1364						
1365	010134				GGER1:	
	010134	010537	001252		MOV	R5,@#STMP10
	010140	010437	001254		MOV	R4,@#STMP11
	010144	012737	011610	001240	MOV	#GGP5,@#STMP3
	010152	012737	011610	001242	MOV	#GGP5,@#STMP4
	010160	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010166	012737	011620	001246	MOV	#GGP6,@#STMP6
	010174	104207			1\$: ERROR	+207
	010176	000137	011660		JMP	@#GGDONE
1366						
1367	010202				GGER2:	
	010202	010537	001252		MOV	R5,@#STMP10
	010206	010437	001254		MOV	R4,@#STMP11
	010212	012737	011610	001240	MOV	#GGP5,@#STMP3
	010220	012737	011610	001242	MOV	#GGP5,@#STMP4
	010226	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010234	012737	011620	001246	MOV	#GGP6,@#STMP6
	010242	104232			1\$: ERROR	+232
	010244	000137	011660		JMP	@#GGDONE
1368						
1369	010250				GGER3:	
	010250	010537	001252		MOV	R5,@#STMP10
	010254	010437	001254		MOV	R4,@#STMP11
	010260	012737	011610	001240	MOV	#GGP5,@#STMP3
	010266	012737	011610	001242	MOV	#GGP5,@#STMP4
	010274	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010302	012737	011620	001246	MOV	#GGP6,@#STMP6
	010310	104221			1\$: ERROR	+221
	010312	000137	011660		JMP	@#GGDONE
1370						
1371	010316	000706			GGER4:	BR GGER1
1372						
1373	010320				GGER5:	
	010320	010537	001252		MOV	R5,@#STMP10
	010324	010437	001254		MOV	R4,@#STMP11
	010330	012737	011610	001240	MOV	#GGP5,@#STMP3
	010336	012737	011610	001242	MOV	#GGP5,@#STMP4
	010344	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010352	012737	011620	001246	MOV	#GGP6,@#STMP6
	010360	104226			1\$: ERROR	+226
	010362	000137	011660		JMP	@#GGDONE
1374						
1375	010366				GGER6:	
	010366	010537	001252		MOV	R5,@#STMP10
	010372	010437	001254		MOV	R4,@#STMP11
	010376	012737	011610	001240	MOV	#GGP5,@#STMP3
	010404	012737	011610	001242	MOV	#GGP5,@#STMP4
	010412	012737	011540	001244	MOV	#GGDAT0,@#STMP5
	010420	012737	011620	001246	MOV	#GGP6,@#STMP6
	010426	104227			1\$: ERROR	+227
	010430	000137	011660		JMP	@#GGDONE

1376						
1377	010434	013701	001236		GGER7:	MOV @#\$TMP2,R1
1378	010440	062701	000002			ADD #2,R1
1379	010444	020116				CMP R1,(SP)
1380	010446	001402				BEQ 10\$
1381	010450	000137	036660		5\$:	JMP @#FPSPUR
1382	010454				10\$:	
1383	010454	170301				STST R1
1384	010456	020127	000012			CMP R1,#12
1385	010462	001372				BNE 5\$
1386	010464	022626				CMP (SP)+,(SP)+
1387	010466	012700	011540			MOV #GGDAT0,R0
1388	010472	174010				STD AC0,(R0)
1389	010474	012737	011570	001240		MOV #GGP3,@#\$TMP3
	010502	012737	011560	001242		MOV #GGP2,@#\$TMP4
	010510	012737	011540	001244		MOV #GGDAT0,@#\$TMP5
	010516	012737	011620	001246		MOV #GGP6,@#\$TMP6
	010524	104224			1\$:	ERROR +224
	010526	000137	011660			JMP @#GGDONE
1390						
1391	010532				GGER8:	MOV R5,@#\$TMP10
	010532	010537	001252			MOV R4,@#\$TMP11
	010536	010437	001254			MOV #GGP3,@#\$TMP3
	010542	012737	011570	001240		MOV #GGP2,@#\$TMP4
	010550	012737	011560	001242		MOV #GGDAT0,@#\$TMP5
	010556	012737	011540	001244		MOV #GGP6,@#\$TMP6
	010564	012737	011620	001246		MOV #GGP6,@#\$TMP6
	010572	104207			1\$:	ERROR +207
	010574	000137	011660			JMP @#GGDONE
1392						
1393	010600				GGER9:	MOV R5,@#\$TMP10
	010600	010537	001252			MOV R4,@#\$TMP11
	010604	010437	001254			MOV #GGP3,@#\$TMP3
	010610	012737	011570	001240		MOV #GGP2,@#\$TMP4
	010616	012737	011560	001242		MOV #GGDAT0,@#\$TMP5
	010624	012737	011540	001244		MOV #GGP6,@#\$TMP6
	010632	012737	011620	001246		MOV #GGP6,@#\$TMP6
	010640	104232			1\$:	ERROR +232
	010642	000137	011660			JMP @#GGDONE
1394						
1395	010646				GGER10:	MOV R5,@#\$TMP10
	010646	010537	001252			MOV R4,@#\$TMP11
	010652	010437	001254			MOV #GGP3,@#\$TMP3
	010656	012737	011570	001240		MOV #GGP2,@#\$TMP4
	010664	012737	011560	001242		MOV #GGDAT0,@#\$TMP5
	010672	012737	011540	001244		MOV #GGP7,@#\$TMP6
	010700	012737	011630	001246		MOV #GGP7,@#\$TMP6
	010706	104225			1\$:	ERROR +225
	010710	000137	011660			JMP @#GGDONE
1396						
1397	010714				GGER11:	MOV R5,@#\$TMP10
	010714	010537	001252			MOV R4,@#\$TMP11
	010720	010437	001254			MOV #GGP3,@#\$TMP3
	010724	012737	011570	001240		MOV #GGP2,@#\$TMP4
	010732	012737	011560	001242		MOV #GGDAT0,@#\$TMP5
	010740	012737	011540	001244		MOV #GGP7,@#\$TMP6
	010746	012737	011630	001246		MOV #GGP7,@#\$TMP6

	010754	104207		1\$:	ERROR	+207
	010756	000137	011660		JMP	@#GGDONE
1398						
1399	010762			GGER12:		
	010762	010537	001252		MOV	R5,@#\$TMP10
	010766	010437	001254		MOV	R4,@#\$TMP11
	010772	012737	011570	001240	MOV	#GGP3,@#\$TMP3
	011000	012737	011560	001242	MOV	#GGP2,@#\$TMP4
	011006	012737	011540	001244	MOV	#GGDAT0,@#\$TMP5
	011014	012737	011630	001246	MOV	#GGP7,@#\$TMP6
	011022	104231		1\$:	ERROR	+231
	011024	000137	011660		JMP	@#GGDONE
1400						
1401	011030			GGER13:		
	011030	010537	001252		MOV	R5,@#\$TMP10
	011034	010437	001254		MOV	R4,@#\$TMP11
	011040	012737	011570	001240	MOV	#GGP3,@#\$TMP3
	011046	012737	011560	001242	MOV	#GGP2,@#\$TMP4
	011054	012737	011540	001244	MOV	#GGDAT0,@#\$TMP5
	011062	012737	011630	001246	MOV	#GGP7,@#\$TMP6
	011070	104230		1\$:	ERROR	+230
	011072	000137	011660		JMP	@#GGDONE
1402						
1403	011076	013701	001236	GGER14:	MOV	@#\$TMP2,R1
1404	011102	062701	000002		ADD	#2,R1
1405	011106	020116			CMP	R1,(SP)
1406	011110	001402			BEQ	10\$
1407	011112	000137	036660	5\$:	JMP	@#FPSPUR
1408	011116			10\$:		
1409	011116	170301			STST	R1
1410	011120	020127	000012		CMP	R1,#12
1411	011124	0C1372			BNE	5\$
1412	011126	022626			CMP	(SP)+,(SP)+
1413	011130	012700	011540		MOV	#GGDAT0,R0
1414	011134	174010			STD	AC0,(R0)
1415						
1416	011136	012737	011550	001240	MOV	#GGP1,@#\$TMP3
	011144	012737	011570	001242	MOV	#GGP3,@#\$TMP4
	011152	012737	011540	001244	MOV	#GGDAT0,@#\$TMP5
	011160	012737	011620	001246	MOV	#GGP6,@#\$TMP6
	011166	104222		1\$:	ERROR	+222
	011170	000137	011660		JMP	@#GGDONE
1417						
1418	011174			GGER15:		
	011174	010537	001252		MOV	R5,@#\$TMP10
	011200	010437	001254		MOV	R4,@#\$TMP11
	011204	012737	011560	001240	MOV	#GGP2,@#\$TMP3
	011212	012737	011640	001242	MOV	#GGP8,@#\$TMP4
	011220	012737	011540	001244	MOV	#GGDAT0,@#\$TMP5
	011226	012737	011620	001246	MOV	#GGP6,@#\$TMP6
	011234	104207		1\$:	ERROR	+207
	011236	000137	011660		JMP	@#GGDONE
1419						
1420	011242			GGER16:		
	011242	010537	001252		MOV	R5,@#\$TMP10
	011246	010437	001254		MOV	R4,@#\$TMP11
	011252	012737	011560	001240	MOV	#GGP2,@#\$TMP3

```

011260 012737 011640 001242      MOV      #GGP8,@#STMP4
011266 012737 011540 001244      MOV      #GGDATO,@#STMP5
011274 012737 011620 001246      MOV      #GGP6,@#STMP6
011302 104232      1$:      ERROR      +232
011304 000137 011660      JMP      @#GGDONE

1421
1422 011310      GGER17:
011310 010537 001252      MOV      R5,@#STMP10
011314 010437 001254      MOV      R4,@#STMP11
011320 012737 011560 001240      MOV      #GGP2,@#STMP3
011326 012737 011640 001242      MOV      #GGP8,@#STMP4
011334 012737 011540 001244      MOV      #GGDATO,@#STMP5
011342 012737 011650 001246      MOV      #GGP9,@#STMP6
011350 104223      1$:      ERROR      +223
011352 000137 011660      JMP      @#GGDONE

1423
1424 011356      GGER18:
011356 010537 001252      MOV      R5,@#STMP10
011362 010437 001254      MOV      R4,@#STMP11
011366 012737 011560 001240      MOV      #GGP2,@#STMP3
011374 012737 011640 001242      MOV      #GGP8,@#STMP4
011402 012737 011540 001244      MOV      #GGDATO,@#STMP5
011410 012737 011650 001246      MOV      #GGP9,@#STMP6
011416 104207      1$:      ERROR      +207
011420 000137 011660      JMP      @#GGDONE

1425
1426 011424      GGER19:
011424 010537 001252      MOV      R5,@#STMP10
011430 010437 001254      MOV      R4,@#STMP11
011434 012737 011560 001240      MOV      #GGP2,@#STMP3
011442 012737 011640 001242      MOV      #GGP8,@#STMP4
011450 012737 011540 001244      MOV      #GGDATO,@#STMP5
011456 012737 011650 001246      MOV      #GGP9,@#STMP6
011464 104230      1$:      ERROR      +230
011466 000137 011660      JMP      @#GGDONE

1427
1428 011472      GGER20:
011472 010537 001252      MOV      R5,@#STMP10
011476 010437 001254      MOV      R4,@#STMP11
011502 012737 011560 001240      MOV      #GGP2,@#STMP3
011510 012737 011640 001242      MOV      #GGP8,@#STMP4
011516 012737 011540 001244      MOV      #GGDATO,@#STMP5
011524 012737 011650 001246      MOV      #GGP9,@#STMP6
011532 104231      1$:      ERROR      +231
011534 000137 011660      JMP      @#GGDONE

1429
1430 011540 000000      GGDATA:  0
1431 011542 000000      0
1432 011544 000000      0
1433 011546 000000      0
1434
1435 011550 000300      GGP1:    300
1436 011552 000000      0
1437 011554 000000      0
1438 011556 000000      0
1439 011560 100200      GGP2:    100200
1440 011562 000000      0

```

```

1441 011564 000000 0
1442 011566 000000 0
1443 011570 000200 GGP3: 200
1444 011572 000000 0
1445 011574 000000 0
1446 011576 000001 1
1447 011600 010200 GGP4: 10200
1448 011602 000000 0
1449 011604 000000 0
1450 011606 000000 0
1451 011610 077600 GGP5: 77600 ;OVER FLOW = GGP5 + GGP5
1452 011612 000000 0
1453 011614 000000 0
1454 011616 000000 0
1455 011620 000000 GGP6: 0 ;OVERFLOW RESULT
1456 011622 000000 ;UNDERFLOW RESULT
1457 011624 000000 ;GGP6 = GGP4 + GGP5
1458 011626 000000 ; = GGP3 + GGP2 (FIU = 0)
1459 ; = GGP3 + GGP1
1460 011630 062400 GGP7: 62400 ;GGP7 = GGP3 + GGP2 (FIU = 1)
1461 011632 000000 0
1462 011634 000000 0
1463 011636 000000 0
1464 011640 000340 GGP8: 340
1465 011642 000000 0
1466 011644 000000 0
1467 011646 000000 0
1468 011650 000100 GGP9: 100
1469 011652 000000 0
1470 011654 000000 0
1471 011656 000000 0
1472 011660 GGDONE: 0
011660 104412 RSETUP ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

```

1473  
1479  
1480

```

:*****
:*TEST 3 LDCFD AND LDCDF TEST
:*
:*THIS IS A TEST OF LDCFD AND LDCDF.
:*
:*****

```

```

1481 011662 000004 TST3: SCOPE
1482 011664 104413 ;TEST FOR CORRECT AUTO INCREMENT CONSTANT.
011664 104413 HX1: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
1483 011666 012704 000200 MOV #200,R4
1484 011672 170104 LDFPS R4
1485 011674 012700 013300 MOV #HXP1,R0
1486 011700 172410 LDD (R0),AC0
1487 011702 012700 013310 MOV #HXP2,R0
1488 011706 012737 011714 001236 HX2: MOV #HX2,@#STMP2
1489 011714 177420 LDCFD (R0)+,AC0
1490 011716 020027 013314 CMP R0,#HXP2+4 ;IS R0 CORRECT

```



1491	011722	001402			BEQ	HX3		
1492	011724	000137	012656		JMP	@#HXER1		
1493	011730			HX3:				
1494	011730	170205			STFPS	R5		:GET FPS
1495	011732	012700	013270		MOV	#HXDATO,R0		
1496	011736	174010			STD	ACO,(R0)		:GET ACO
1497	011740	012701	013360		MOV	#HXP7,R1		:SEE IF RESULT IS
1498	011744	012702	000004		MOV	#4,R2		:CORRECT
1499	011750	022120		HX4:	CMP	(R1)+,(R0)+		
1500	011752	001415			BEQ	HX7		
1501	011754	012701	013310		MOV	#HXP2,R1		:DID FD GET
1502	011760	012700	013270		MOV	#HXDATO,R0		:COMPLIMENTED?
1503	011764	012702	000004		MOV	#4,R2		
1504	011770	022120		HX5:	CMP	(R1)+,(R0)+		
1505	011772	001402			BEQ	HX6		
1506	011774	000137	012716		JMP	@#HXER2		
1507	012000	077205		HX6:	SOB	R2,HX5		
1508	012002	000137	012746		JMP	@#HXER3		
1509	012006	077220		HX7:	SOB	R2,HX4		
1510	012010	012704	000200		MOV	#200,R4		:FPS CORRECT?
1511	012014	020405			CMP	R4,R5		
1512	012016	001402			BEQ	HX8		
1513	012020	000137	013014		JMP	@#HXER8		
1514				:NOW	TEST	LDCDF		
1515	012024			HX8:				
	012024	104413			LPERR			:SET UP THE LOOP ON ERROR ADDRESS.
1516	012026	012704	000200			MOV #200,R4		
1517	012032	170104				LDFPS R4		
1518								
1519	012034	012700	013300		MOV	#HXP1,R0		
1520	012040	172410			LDD	(R0),ACO		
1521								
1522	012042	012700	013310		MOV	#HXP2,R0		
1523	012046	012737	012056	001236	MOV	#HX9,@#STMP2		
1524								
1525	012054	170001			SETF			
1526								
1527	012056	177420		HX9:	LDCDF	(R0)+,ACO		:TEST INSTRUCTION
1528								
1529	012060	020027	013320		CMP	R0,#HXP2+10		:WAS A GOOD
1530	012064	001402			BEQ	HX10		:CONSTANT USED
1531	012066	000137	012676		JMP	@#HXER5		:TO INCREMENT R0?
1532								
1533	012072			HX10:				
1534	012072	170205			STFPS	R5		
1535	012074	012700	013270		MOV	#HXDATO,R0		
1536	012100	170011			SETD			
1537	012102	174010			STD	ACO,(R0)		:GET RESULT
1538	012104	012701	013370		MOV	#HXP8,R1		
1539	012110	012702	000004		MOV	#4,R2		
1540	012114	022120		HX11:	CMP	(R1)+,(R0)+		:IS IT CORRECT?
1541	012116	001415			BEQ	HX14		
1542								
1543	012120	012701	013360		MOV	#HXP7,R1		
1544	012124	012700	013270		MOV	#HXDATO,R0		
1545	012130	012702	000004		MOV	#4,R2		
1546	012134	022110		HX12:	CMP	(R1)+,(R0)		:DID FD FAIL TO GET

```

1547 012136 001402          BEQ    HX13          ;COMPLIMENTED?
1548 012140 000137 013032    JMP    @#HXER6
1549 012144 077205          SOB    R2,HX12
1550 012146 000137 013062    JMP    @#HXER7
1551
1552 012152 077220          HX14: SOB    R2,HX11
1553
1554 012154 012704 000000    MOV    #0,R4          ;FPS CORRECT?
1555 012160 020405          CMP    R4,R5
1556 012162 001402          BEQ    HX15
1557 012164 000137 013014    JMP    @#HXER8
1558
1559          ;TEST GR7 IMMEDIATE MODE CONSTANT
1560
1561 012170          HX15:
      012170 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1562
1563 012172 012704 000200    MOV    #200,R4
1564 012176 170104          LDFPS R4          ;SET FD
1565 012200 012737 012216 001236    MOV    #HX16,@#STMP2
1566 012206 012737 013112 000004    MOV    #HXER9,@#ERRVECT
1567 012214 005001          CLR    R1
1568 012216 177427 043243    HX16: LDCFD #5201,AC0
1569 012222 005201          HX165: INC    R1
1570 012224 005201          INC    R1
1571 012226 005201          INC    R1
1572 012230 012737 036712 000004    MOV    #CPSPUR,@#ERRVECT
1573 012236 020127 000003    CMP    R1,#3          ;SEE IF PC WAS
1574 012242 001402          BEQ    HX17          ;CORRECT
1575 012244 000137 013146    JMP    @#HXER10
1576
1577 012250          HX17:
      012250 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1578
1579 012252 012704 000200    MOV    #200,R4
1580 012256 170104          LDFPS R4
1581 012260 012737 012306 001236    MOV    #HX18,@#STMP2
1582 012266 012700 013350    MOV    #HXP6,R0
1583 012272 172410          LDD    (R0),AC0
1584 012274 012737 036712 000004    MOV    #CPSPUR,@#ERRVECT
1585 012302 012700 013310    MOV    #HXP2,R0
1586 012306 177410          HX18: LDCFD (R0),AC0
1587
1588 012310 012700 013270    MOV    #HXDAT0,R0
1589 012314 174010          STD    AC0,(R0)      ;GET RESULT.
1590 012316 012701 013360    MOV    #HXP7,R1
1591 012322 012702 000004    MOV    #4,R2
1592 012326 022021          HX19: CMP    (R0)+,(R1)+ ;IS RESULT CORRECT?
1593 012330 001402          BEQ    HX20
1594 012332 000137 012716    JMP    @#HXER2
1595 012336 077205          HX20: SOB    R2,HX19
1596
1597          ;TEST LDCFD WITH NEGATIVE OPERAND
1598 012340          HX21:
      012340 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1599 012342 012704 000200    MOV    #200,R4
1600 012346 170104          LDFPS R4
    
```

1601	012350	012737	012370	001236	MOV	#HX22,@#\$TMP2	
1602	012356	012700	013350		MOV	#HXP6,R0	
1603	012362	172410			LDD	(R0),AC0	
1604	012364	012700	013330		MOV	#HXP4,R0	
1605	012370	177410		HX22:	LDCFD	(R0),AC0	
1606							
1607	012372	012700	013270		MOV	#HXDAT0,R0	
1608	012376	174010			STD	AC0,(R0)	;GET RESULT
1609							
1610	012400	012701	013340		MOV	#HXP5,R1	
1611	012404	012702	000004		MOV	#4,R2	
1612	012410	022120		HX23:	CMP	(R1)+,(R0)+	
1613	012412	001415			BEQ	HX26	
1614							
1615	012414	012701	013360		MOV	#HXP7,R1	
1616	012420	012700	013270		MOV	#HXDAT0,R0	
1617	012424	012702	000004		MOV	#4,R2	
1618	012430	022120		HX24:	CMP	(R1)+,(R0)+	;WAS SIGN INCORRECT
1619	012432	001402			BEQ	HX25	
1620	012434	000137	013200		JMP	@#HXER11	
1621	012440	077205		HX25:	SOB	R2,HX24	
1622	012442	000137	013220		JMP	@#HXER12	
1623							
1624	012446	077220		HX26:	SOB	R2,HX23	
1625							
1626				;TEST	LDCFD	0	
1627							
1628	012450			HX27:			
	012450	104413			LPERR		;SET UP THE LOOP ON ERROR ADDRESS.
1629	012452	012704	000200		MOV	#200,R4	
1630	012456	170104			LDFPS	R4	
1631							
1632	012460	012700	013300		MOV	#HXP1,R0	
1633	012464	172410			LDD	(R0),AC0	
1634	012466	172010			ADDD	(R0),AC0	
1635							
1636	012470	012737	012502	001236	MOV	#HX28,@#\$TMP2	
1637	012476	012700	013300		MOV	#HXP1,R0	
1638	012502	177410		HX28:	LDCFD	(R0),AC0	
1639							
1640	012504	170205			STFPS	R5	
1641							
1642	012506	012700	013270		MOV	#HXDAT0,R0	
1643	012512	174010			STD	AC0,(R0)	;GET RESULT
1644							
1645	012514	012701	013300		MOV	#HXP1,R1	
1646	012520	012702	000004		MOV	#4,R2	
1647	012524	022120		HX29:	CMP	(R1)+,(R0)+	;IS IT 0?
1648	012526	001402			BEQ	HX30	
1649	012530	000137	013250		JMP	@#HXER13	
1650	012534	077205		HX30:	SOB	R2,HX29	
1651							
1652	012536	012704	000204		MOV	#204,R4	;FPS CORRECT
1653	012542	020405			CMP	R4,R5	
1654	012544	001402			BEQ	HX31	
1655	012546	000137	012776		JMP	@#HXER4	
1656							

```

1657          ;TEST   LDCFD   0
1658
1659 012552    HX31:
      012552    104413    LFERR
1660 012554    012704    000200    MOV     #200,R4          ;SET UP THE LOOP ON ERROR ADDRESS.
1661 012560    170104    LDFPS   R4
1662
1663 012562    012700    013350    MOV     #HXP6,R0
1664 012566    172410    LDD     (R0),AC0
1665
1666 012570    012737    012602    001236    MOV     #HX32,@#$TMP2
1667 012576    012700    013300    MOV     #HXP1,R0
1668 012602    177410    HX32:   LDCFD   (R0),AC0
1669
1670 012604    170205    STFPS   R5
1671
1672 012606    012700    013270    MOV     #HXDAT0,R0
1673 012612    174010    STD     AC0,(R0)        ;GET RESULT
1674
1675 012614    012701    013300    MOV     #HXP1,R1
1676 012620    012702    000004    MOV     #4,R2
1677 012624    022120    HX33:   CMP     (R1)+,(R0)+    ;IS IT ZERO?
1678 012626    001402    BEQ     HX34
1679 012630    000137    013250    JMP     @#HXER13
1680 012634    077205    HX34:   SOB     R2,HX33
1681
1682 012636    012704    000204    MOV     #204,R4        ;FPS CORRECT?
1683 012642    020405    CMP     R4,R5
1684 012644    001402    BEQ     HX35
1685 012646    000137    012776    JMP     @#HXER4
1686 012652    000137    013400    HX35:   JMP     @#HXDONE
1687
1688          ;R0 INCORRECT
1689
1690 012656    012737    013314    001242    HXER1:  MOV     #HXP2+4,@#$TMP4
1691 012664    010037    001240    MOV     R0,@#$TMP3
1692 012670    104234    1$:     ERROR  +234
1693 012672    000137    013400    JMP     @#HXDONE
1694
1695 012676    012737    013320    001242    HXER5:  MOV     #HXP2+10,@#$TMP4
1696 012704    010037    001240    MOV     R0,@#$TMP3
1697 012710    104237    1$:     ERROR  +237
1698 012712    000137    013400    JMP     @#HXDONE
1699          ;REPORT BAD DATA
1700 012716    012737    013310    001244    HXER2:  MOV     #HXP2,@#$TMP5
1701 012724    012737    013360    001250    MOV     #HXP7,@#$TMP7
1702 012732    012737    013270    001246    HXER22:MOV     #HXDAT0,@#$TMP6
1703 012740    104233    1$:     ERROR  +233
1704 012742    000137    013400    JMP     @#HXDONE
1705
1706 012746    012737    013310    001244    HXER3:  MOV     #HXP2,@#$TMP5
1707 012754    012737    013360    001250    MOV     #HXP7,@#$TMP7
1708 012762    012737    013270    001246    HXER33:MOV     #HXDAT0,@#$TMP6
1709 012770    104241    1$:     ERROR  +241
1710 012772    000137    013400    JMP     @#HXDONE
1711
1712 012776    010537    001240    HXER4:  MOV     R5,@#$TMP3

```

1713	013002	010437	001242			MOV	R4,@#\$TMP4	
1714	013006	104240			1\$:	ERROR	+240	
1715	013010	000137	013400			JMP	@#HXDONE	
1716								
1717	013014	010537	001240		HXER8:	MOV	R5,@#\$TMP3	
1718	013020	010437	001242			MOV	R4,@#\$TMP4	
1719	013024	104242			1\$:	ERROR	+242	
1720	013026	000137	013400			JMP	@#HXDONE	
1721	013032	012737	013310	001244	HXER6:	MOV	#HXP2,@#\$TMP5	
1722	013040	012737	013370	001250		MOV	#HXP8,@#\$TMP7	
1723	013046	012737	013270	001246	HXER66:	MOV	#HXDATO,@#\$TMP6	
1724	013054	104244			1\$:	ERROR	+244	
1725	013056	000137	013400			JMP	@#HXDONE	
1726								
1727	013062	012737	013310	001244	HXER7:	MOV	#HXP2,@#\$TMP5	
1728	013070	012737	013370	001250		MOV	#HXP8,@#\$TMP7	
1729	013076	012737	013270	001246		MOV	#HXDATO,@#\$TMP6	
1730	013104	104243			1\$:	ERROR	+243	
1731	013106	000137	013400			JMP	@#HXDONE	
1732								
1733	013112	032716	000001		HXER9:	BIT	#1,(SP)	:SEE IF IT
1734	013116	001005				BNE	1\$	:AN ODD ADDRESS
1735	013120	022716	012222			CMP	#HX165,(SP)	
1736	013124	001402				BEQ	1\$	
1737	013126	000137	036712			JMP	@#CPSPUR	
1738								
1739	013132	011637	001236		1\$:	MOV	(SP),@#\$TMP2	
1740	013136	022626				CMP	(SP)+,(SP)+	
1741	013140	104235			2\$:	ERROR	+235	
1742	013142	000137	013400			JMP	@#HXDONE	
1743								
1744	013146	162701	000003		HXER10:	SUB	#3,R1	
1745	013152	006301				ASL	R1	
1746	013154	012702	012222			MOV	#HX165,R2	
1747	013160	010237	001242			MOV	R2,@#\$TMP4	
1748	013164	160102				SUB	R1,R2	
1749	013166	010237	001240			MOV	R2,@#\$TMP3	
1750	013172	104236			1\$:	ERROR	+236	
1751	013174	000137	013400			JMP	@#HXDONE	
1752								
1753	013200	012737	013330	001244	HXER11:	MOV	#HXP4,@#\$TMP5	
1754	013206	012737	013340	001250		MOV	#HXP5,@#\$TMP7	
1755	013214	000137	012732			JMP	@#HXER22	
1756	013220	012737	013330	001244	HXER12:	MOV	#HXP4,@#\$TMP5	
1757	013226	012737	013340	001250		MOV	#HXP5,@#\$TMP7	
1758	013234	012737	013270	001246		MOV	#HXDATO,@#\$TMP6	
1759	013242	104245			1\$:	ERROR	+245	
1760	013244	000137	013400			JMP	@#HXDONE	
1761								
1762	013250	012737	013300	001244	HXER13:	MOV	#HXP1,@#\$TMP5	
1763	013256	012737	013300	001250		MOV	#HXP1,@#\$TMP7	
1764	013264	000137	012732			JMP	@#HXER22	
1765								
1766	013270	000000			HXDATC:	0		
1767	013272	000000				0		
1768	013274	000000				0		
1769	013276	000000				0		

1770  
 1771 013300 000000  
 1772 013302 000000  
 1773 013304 000000  
 1774 013306 000000  
 1775  
 1776 013310 000577  
 1777 013312 177776  
 1778 013314 177777  
 1779 013316 177776  
 1780 013320 005201  
 1781 013322 000000  
 1782 013324 000000  
 1783 013326 000000  
 1784 013330 100577  
 1785 013332 177776  
 1786 013334 177777  
 1787 013336 177776  
 1788 013340 100577  
 1789 013342 177776  
 1790 013344 000000  
 1791 013346 000000  
 1792 013350 000252  
 1793 013352 125252  
 1794 013354 125252  
 1795 013356 125252  
 1796  
 1797 013360 000577  
 1798 013362 177776  
 1799 013364 000000  
 1800 013366 000000  
 1801 013370 000577  
 1802 013372 177777  
 1803 013374 000000  
 1804 013376 000000  
 1805  
 1806 013400  
 013400 104412

HXP1: 0  
 0  
 0  
 0  
 HXP2: 577  
 177776  
 177777  
 177776  
 HXP3: 5201  
 0  
 0  
 0  
 HXP4: 100577  
 177776  
 177777  
 177776  
 HXP5: 100577  
 177776  
 0  
 0  
 HXP6: 252  
 125252  
 125252  
 125252  
 HXP7: 577  
 177776  
 0  
 0  
 HXP8: 577  
 177777  
 0  
 0  
 HXDONE:  
 RSETUP

:GO INITIALIZE THE FPS AND STACK; AND  
 :SEE IF THE USER HAS EXPRESSED  
 :THE DESIRE TO CHANGE THE SOFTWARE  
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS  
 :THE USER TYPED CONTROL G?).

1807  
 1808  
 1809  
 1817  
 1818

```

:*****
:*TEST 4      CMPD TEST
:*
:*THIS IS A TEST OF THE CMPD INSTRUCTION. NOTE THAT A SUBROUTINE
:*IS USED TO SET UP OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE
:*RESULTS
:*
:*****
TST4:  SCOPE
;TEST THE CMPD INSTRUCTION WITH (FSRC=AC=0)

```

013402 000004  
 1819  
 1820

```

1821 013404          AAA1:
      013404 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1822 013406 004737 014216      JSR          PC,@#CMPSUB
1823 013412 000000 000000 000000 1$: .WORD 0,0,0,0          ;AC0
      013420 000000
1824 013422 000000 000000 000000 2$: .WORD 0,0,0,0          ;FSRC
      013430 000000
1825 013432 000200          3$: 200          ;FPS BEFORE EXECUTION
1826 013434 000204          204          ;FPS AFTER EXECUTION
1827 013436 000200          200          ;ERROR FPS
1828 013440 104001          4$: ERROR +1          ;FPS ERROR
1829
1830
1831          ;TEST CMPD WITH (AC=0) AND FSRC POSITIVE.
1832 013442          AAA2:
      013442 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1833 013444 004737 014216      JSR          PC,@#CMPSUB
1834 013450 000000 000000 000000 1$: .WORD 0,0,0,0          ;AC
      013456 000000
1835 013460 025252          2$: 25252          ;FSRC
1836 013462 052525          52525
1837 013464 125252          125252
1838 013466 052525          52525
1839 013470 000200          3$: 200          ;FPS BEFORE EXECUTION
1840 013472 000200          200          ;FPS AFTER EXECUTION
1841 013474 000210          210          ;ERROR FPS
1842 013476 104003          4$: ERROR +3          ;FPS ERROR
1843
1844          ;TEST CMPD WITH (AC=0) AND FSRC NEGATIVE
1845 013500          AAA3:
      013500 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1846 013502 004737 014216      JSR          PC,@#CMPSUB
1847 013506 000000 000000 000000 1$: .WORD 0,0,0,0          ;AC
      013514 000000
1848 013516 125252          2$: 125252          ;FSRC
1849 013520 125252          125252
1850 013522 052525          52525
1851 013524 125252          125252
1852 013526 000200          3$: 200          ;FPS BEFORE EXECUTION
1853 013530 000210          210          ;FPS AFTER EXECUTION
1854 013532 000200          200          ;ERROR FPS
1855 013534 104004          4$: ERROR +4          ;FPS ERROR.
1856
1857          ;TEST CMPD WITH (FSRC=0) AND AC POSITIVE
1858 013536          AAA4:
      013536 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1859 013540 004737 014216      JSR          PC,@#CMPSUB
1860 013544 025252          1$: 25252          ;AC
1861 013546 052525          52525
1862 013550 125252          125252
1863 013552 052525          52525
1864 013554 000000 000000 000000 2$: .WORD 0,0,0,0          ;FSRC
      013562 000000
1865 013564 000200          3$: 200          ;FPS BEFORE EXECUTION
1866 013566 000210          210          ;FPS AFTER EXECUTION
1867 013570 000200          200          ;ERROR FPS
1868 013572 104005          4$: ERROR +5          ;FPS ERROR
    
```

```

1869
1870
1871
1872 013574      ;TEST CMPD WITH (FSRC=0) AND AC NEGATIVE
      013574 104413 AAA5:
1873 013576 004737 014216      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      013602 125252      JSR      PC,@#CMPSUB
1874 013604 125252      1$:      125252      ;AC
      013606 052525      125252
1875 013610 125252      52525
1876 013612 125252      125252
1877 013612 000000 000000 2$:      .WORD      0,0,0,0      ;FSRC
      013620 000000
1879 013622 000200      3$:      200      ;FPS BEFORE EXECUTION
1880 013624 000200      200      ;FPS AFTER EXECUTION
1881 013626 000210      210      ;ERROR FPS
1882 013630 104006      4$:      ERROR      +6      ;FPS ERROR
1883
1884
1885 013632      ;TEST CMPD WITH AC POSITIVE AND FSRC NEGATIVE
      013632 104413 AAA6:
1886 013634 004737 014216      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      013640 052525      JSR      PC,@#CMPSUB
1887 013642 125252      1$:      52525      ;AC
      013644 125252      125252
1888 013646 052525      52525
1889 013650 125252      125252
1890 013652 125252      2$:      125252      ;;FSRC
      013654 052525      52525
1891 013656 125252      52525
1892 013660 000200      3$:      200      ;FPS BEFORE EXECUTION
1893 013662 000210      210      ;FPS AFTER EXECUTION
1894 013664 000200      200      ;ERROR FPS
1895 013666 104007      4$:      ERROR      +7      ;FPS ERROR
1896
1897
1898
1899
1900
1901
1902 013670      ;TEST CMPD WITH AC NEGATIVE AND FSRC POSITIVE
      013670 104413 AAA7:
1903 013672 004737 014216      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      013676 125252      JSR      PC,@#CMPSUB
1904 013700 052525      1$:      125252      ;AC
      013702 125252      52525
1905 013704 052525      125252
1906 013706 052525      52525
1907 013710 125252      2$:      52525      ;FSRC
      013712 052525      125252
1908 013714 125252      52525
1909 013716 000200      3$:      125252
1910 013720 000200      200      ;FPS BEFORE EXECUTION
1911 013722 000210      200      ;FPS AFTER EXECUTION
1912 013724 104010      210      ;ERROR FPS
1913 013726 104010      4$:      ERROR      +10      ;FPS ERROR.
1914
1915
1916
1917
1918
1919 013726      ;TEST CMPD WITH AC POSITIVE AND FSRC POSITIVE
      013726 104413 ;AND EAC LESS THAN EFSRC.
1920 013730 004737 014216      AAA8:
      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      JSR      PC,@#CMPSUB

```



```

1921 013734 012345      1$:      12345      ;AC
1922 013736 067654      67654
1923 013740 032101      32101
1924 013742 023456      23456
1925 013744 023456      2$:      23456      ;FSRC
1926 013746 076543      76543
1927 013750 021012      21012
1928 013752 034567      34567
1929 013754 000200      3$:      200      ;FPS BEFORE EXECUTION
1930 013756 000200      200      ;FPS AFTER EXECUTION
1931 013760 000210      210      ;ERROR FPS
1932 013762 104011      4$:      ERROR +11      ;FPS ERROR
1933
1934
1935

```

;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND EAC GREATER THAN EFSRC

```

1936 013764 104413      AAA9:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
1937 013766 004737      014216      JSR      PC,@#CMPSUB
1938 013772 045676      1$:      45676      ;AC
1939 013774 054321      54321
1940 013776 012345      12345
1941 014000 067654      67654
1942 014002 034567      2$:      34567      ;FSRC
1943 014004 065432      65432
1944 014006 101234      101234
1945 014010 056765      56765
1946 014012 000200      3$:      200      ;FPS BEFORE EXECUTION
1947 014014 000210      210      ;FPS AFTER EXECUTION
1948 014016 000200      200      ;ERROR FPS
1949 014020 104012      4$:      ERROR +12
1950

```

;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE AND AC EQUAL TO FSRC

```

1951
1952 014022 104413      AAA10:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
1953 014024 004737      014216      JSR      PC,@#CMPSUB
1954 014030 012345      1$:      12345      ;AC
1955 014032 067012      67012
1956 014034 034567      34567
1957 014036 012345      012345
1958 014040 012345      2$:      12345      ;FSRC
1959 014042 067012      67012
1960 014044 034567      34567
1961 014046 012345      012345
1962 014050 000200      3$:      200      ;FPS BEFORE EXECUTION

```

```

1964 014052 000204          204          ;FPS AFTER EXECUTION
1965 014054 000200          200          ;ERROR FPS
1966 014056 104013      4$:  ERROR  +13          ;FPS ERROR
1967
1968          ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
1969          ;AND FSRC GREATER THAN AC.
1970 014060      AAA11:
      014060 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1971 014062 004737 014216      JSR          PC,@#CMPSUB
1972 014066 012345      1$:  12345          ;AC
      014070 007012          67012
1973 014072 034567          34567
1974 014074 012345          012345
1975 014076 012345      2$:  12345          ;FSRC
      014100 070123          70123
1976 014076 012345          45670
1977 014100 070123          123456
1978 014102 045670          200
1979 014104 123456          200          ;FPS BEFORE EXECUTION
1980 014106 000200          200          ;FPS AFTER EXECUTION
1981 014110 000200          210          ;ERROR FPS
1982 014112 000210          4$:  ERROR  +14          ;FPS ERROR
1983 014114 104014
1984
1985          ;TEST CMPD WITH AC POSITIVE, FSRC POSITIVE, EAC EQUAL TO EFSRC,
1986          ;AND AC GREATER THAN FSRC.
1987 014116      AAA12:
      014116 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
1988 014120 004737 014216      JSR          PC,@#CMPSUB
1989 014124 054321      1$:  54321          ;AC
      014126 076543          76543
1990 014126 076543          21076
1991 014130 021076          54321
1992 014132 054321      2$:  54321          ;FSRC
      014134 054321          65432
1993 014134 054321          107654
1994 014136 065432          32107
1995 014140 107654          200
1996 014142 032107          3$:  200          ;FPS BEFORE EXECUTION
1997 014144 000200          210          ;FPS AFTER EXECUTION
1998 014146 000210          200          ;ERROR FPS
1999 014150 000200          4$:  ERROR  +15          ;FPS ERROR
2000 014152 104015
2001
2002          ;TEST CMPD WITH AC NEGATIVE, FSRC NEGATIVE, EAC EQUAL TO EFSRC,
2003          ;AND AC GREATER THAN FSRC
2004 014154      AAA13:
      014154 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2005 014156 004737 014216      JSR          PC,@#CMPSUB
2006 014162 112345      1$:  112345          ;AC
      014164 043210          43210
2007 014164 043210          76543
2008 014166 076543          21076
2009 014170 021076          112345
2010 014172 112345      2$:  112345          ;FSRC
      014174 054321          54321
2011 014174 054321          07654
2012 014176 007654          32107
2013 014200 032107          200
2014 014202 000200          3$:  200          ;FPS BEFORE EXECUTION
2015 014204 000210          210          ;FPS AFTER EXECUTION
2016 014206 000200          200          ;ERROR FPS
2017 014210 104016          4$:  ERROR  +16          ;FPS ERROR

```

2018  
 2019  
 2020 014212 000137 014406  
 2021  
 2022  
 2023  
 2024  
 2025  
 2026  
 2027  
 2028  
 2029  
 2030  
 2031  
 2032  
 2033  
 2034  
 2035  
 2036  
 2037  
 2038  
 2039  
 2040  
 2041  
 2042  
 2043  
 2044  
 2045  
 2046 014216 012601  
 2047  
 2048 014220 016100 000020  
 2049 014224 170100  
 2050  
 2051 014226 012737 014250 001236  
 2052 014234 010100  
 2053 014236 172410  
 2054  
 2055 014240 010100  
 2056 014242 062700 000010  
 2057  
 2058 014246 000240  
 2059 014250 173410  
 2060  
 2061 014252 170205  
 2062  
 2063 014254 016104 000022  
 2064  
 2065 014260 010137 001240  
 2066 014264 010137 001242  
 2067 014270 062737 000010 001242  
 2068 014276 010537 001244  
 2069 014302 010437 001246  
 2070 014306 020405  
 2071 014310 001410  
 2072  
 2073  
 2074 014312 026105 000024

JMP @#AAADONE ;FINISHED CMPD TEST.

:THIS SUBROUTINE, CMPSUB, IS CALLED TO SET UP, EXECUTE  
 :AND CHECK THE RESULTS OF A CMPD INSTRUCTION.  
 :IT IS CALLED THUS:

```

:
:          JSR      PC,@#CMPSUB
:          ACARG:  .WORD  X,X,X,X           ;AC OPERAND
:          FSRCARG: .WORD  X,X,X,X         ;FSRC OPERAND
:          FPSB:   .WORD  X                ;FPS BEFORE EXECUTION
:          FPSA:   .WORD  X                ;FPS AFTER EXECUTION
:          FPSE:   .WORD  X                ;ERROR FPS
:          ERR:    ERROR  +X              ;FPS ERROR
:          CONT:
:
:          ;RETURN ADDRESS
    
```

:THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN  
 :FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, CMPD, IS EXECUTED.  
 :AFTER THE EXECUTION THE FPS IS CHECKED AGAINST FPSA. IF IT IS A MATCH  
 :THEN THERE WAS NO ERROR AND CONTROL IS RETURNED TO CONT. IF  
 :THE FPS IS INCORRECT IT IS COMPARED WITH FPSE IN AN ATTEMPT TO ANALYSE  
 :THE FAILURE. IF THE FPS IS THE SAME AS FPSE THEN CONTROL IS  
 :RETURNED TO THE ERROR CALL AT LOCATION ERR. IF THE FPS WAS  
 :NOT CORRECT BUT DIDN'T MATCH FPSE A GENERAL ERROR IS REPORTED  
 :AND CONTROL IS PASSED TO CONT.

```

CMPSUB: MOV      (SP)+,R1           ;PICK UP A POINTER TO THE
:          ;ARGUMENTS.
:          MOV      20(R1),R0      ;GET THE FPS BEFORE EXECUTION.
:          LDFPS   R0              ;LOAD IT INTO THE FPS.
:
:          MOV      #1$,@#STMP2   ;SAVE ADDRESS OF CMPD INSTRUCTION.
:          MOV      R1,R0          ;GET ADDRESS OF AC OPERAND.
:          LDD      (R0),ACO       ;LOAD ACO OPERAND
:
:          MOV      R1,R0          ;COMPUTE FSRC OPERAND
:          ADD      #10,R0         ;ADDRESS
:
:          NOP
:          1$:  CMPD      (R0),ACO  ;FOR SCOPING.
:          ;EXECUTE THE TEST INSTRUCTION.
:
:          STFPS   R5              ;SAVE FPS AFTER INSTRUCTION.
:
:          MOV      22(R1),R4      ;GET EXPECTED FPS.
:          ;IF INCORRECT SET UP FOR
:          ;AN ERROR CALL.
:
:          MOV      R1,@#STMP3
:          MOV      R1,@#STMP4
:          ADD      #10,@#STMP4
:          MOV      R5,@#STMP5
:          MOV      R4,@#STMP6
:
:          CMP      R4,R5          ;WAS FPS CORRECT?
:          BEQ     3$              ;BRANCH IF YES.
:
:          CMP      24(R1),R5      ;WAS THE FPS THE SAME
    
```

```

2075                                     ;AS THE EXPECTED INCORRECT FPS?
2076 014316 001003                       BNE 2$                               ;BRANCH IF NO MATCH.
2077
2078 014320 062701 000026                 ADD #26,R1                            ;IF THE EXPECTED INCORRECT
2079                                     ;FPS MATCHED THE RESULTANT FPS
2080 014324 000111                       JMP (R1)                               ;RETURN TO THE ERROR CALL
2081                                     ;IN THE CALLING ROUTINE.
2082
2083 014326 104001 2$: ERROR +1           ;OTHERWISE REPORT INCORRECT FPS
2084 014330 000411                       BR 5$
2085
2086 014332 012700 014376                 3$: MOV #CMPTMP,R0                    ;IF FPS WAS CORRECT MAKE SURE
2087 014336 174010                       STD ACO,(R0)                          ;ACO WAS NOT AFFECTED BY CMPD.
2088 014340 010102                       MOV R1,R2
2089 014342 012703 000004                 MOV #4,R3
2090 014346 022220                       4$: CMP (R2)+,(R0)+
2091 014350 001003                       BNE 6$
2092 014352 077303                       SOB R3,4$
2093
2094 014354 000161 000030                 5$: JMP 30(R1)                        ;RETURN
2095
2096 014360                               6$:                                     ;REPORT ACO MODIFIED BY CMPD
2097 014360 010137 001240                 MOV R1,@#$TMP3
2098 014364 012737 014376 001242         MOV #CMPTMP,@#$TMP4
2099 014372 104002                       7$: ERROR +2
2100 014374 000767                       BR 5$                                  ;RETURN
2101
2102 014376 000000 000000 000000         CMPTMP: .WORD 0,0,0,0
2103 014404 000000
2104
2105
2106 014406                               AAADONE:
2106 014406 104412                       RSETUP                                ;GO INITIALIZE THE FPS AND STACK; AND
                                           ;SEE IF THE USER HAS EXPRESSED
                                           ;THE DESIRE TO CHANGE THE SOFTWARE
                                           ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                           ;THE USER TYPED CONTROL G?).
2107
2108
2109
2117
2118
    
```

2107  
2108  
2109  
2117  
2118

```

*****
;*TEST 5      DIVD WITH (FSRC=0) AND (BUT FD) TEST
;*
;*THIS IS A TEST OF THE DIVD INSTRUCTION WITH A
;*ZERO DIVISOR. THE CONDITION IS CHECKED WITH BOTH
;*TRAP ENABLED AND TRAPS DISABLED.
;*
*****
    
```

2119 014410 000004  
 2120  
 2121 014412 104413  
 2122 014414 012704 040200  
 2123  
 2124

```

TST5:  SCOPE
;FIRST TEST DIVD WITH (FSRC=AC=0) AND TRAPS DISABLED.
LPERR
BBB0:  MOV #40200,R4 ;SET UP THE LOOP ON ERROR ADDRESS.
;SET UP FPS
;WITH INTERRUPTS
;DISABLED.
    
```

```

2125 014420 170104          LDFPS  R4
2126 014422 012737 014664 000244  MOV    #BBBER1,@#FPVECT;SET UP FOR ANY FP INTERRUPTS.
2127 014430 012737 014450 001236  MOV    #BBB1,@#STMP2
2128 014436 012700 015070          MOV    #BBBP1,R0      ;SET UP ACO = 0
2129 014442 172410          LDD    (R0),ACO
2130 014444 012701 015070          MOV    #BBBP1,R1      ;FSRC = 0
2131
2132 014450 174411          BBB1:  DIVD   (R1),ACO      ;TEST INSTRUCTION
2133
2134 014452 170205          STFPS  R5              ;GET FPS
2135 014454 170303          STST   R3              ;GET FEC
2136
2137 014456 012704 140204          MOV    #140204,R4      ;EXPECTED FPS.
2138 014462 020405          CMP    R4,R5           ;IS FPS CORRECT.
2139 014464 001131          BNE    BBBER2         ;IF INCORRECT BRANCH.
2140
2141 014466 012702 000004          MOV    #4,R2           ;EXPECTED FEC.
2142 014472 020203          CMP    R2,R3           ;IS FEC CORRECT?
2143 014474 001140          BNE    BBBER3         ;IF INCORRECT BRANCH.
2144
2145          ;TEST DIVD WITH (FSRC=0) AND TRAPS DISABLED.
2146 014476          BBB2:  LPERR
2147 014476 104413          MOV    #40200,R4      ;SET UP THE LOOP ON ERROR ADDRESS.
2148 014500 012704 040200          MOV    #40200,R4      ;LOAD FPS WITH TRAPS DISABLED.
2149 014504 170104          LDFPS  R4
2150 014506 012737 014526 001236  MOV    #BBB3,@#STMP2
2151 014514 012700 015100          MOV    #BBBP2,R0      ;SET UP ACO OPERAND (NON ZERO).
2152 014520 172410          LDD    (R0),ACO
2153 014522 012700 015070          MOV    #BBBP1,R0      ;FSRC=0
2154 014526 174410          BBB3:  DIVD   (R0),ACO
2155
2156 014530 170205          STFPS  R5              ;GET FPS.
2157 014532 170303          STST   R3              ;GET FEC.
2158
2159 014534 012704 140200          MOV    #140200,R4      ;EXPECTED FPS.
2160 014540 020405          CMP    R4,R5           ;IS FPS CORRECT?
2161 014542 001102          BNE    BBBER2         ;IF INCORRECT BRANCH.
2162
2163 014544 012702 000004          MOV    #4,R2           ;EXPECTED FEC.
2164 014550 020203          CMP    R2,R3           ;WAS FEC CORRECT?
2165 014552 001111          BNE    BBBER3         ;IF INCORRECT BRANCH.
2166
2167          ;TEST DIVD WITH FSRC=0) AND TRAPS ENABLED.
2168 014554          BBB4:  LPERR
2169 014554 104413          MOV    #200,R4        ;SET UP THE LOOP ON ERROR ADDRESS.
2170 014556 012704 000200          MOV    #200,R4        ;SET UP FPS. TRAP ENABLED.
2171 014562 170104          LDFPS  R4
2172 014564 012737 014612 001236  MOV    #BBB5,@#STMP2
2173 014572 012700 015100          MOV    #BBBP2,R0      ;SET UP ACO OPERAND (NON ZERO).
2174 014576 172410          LDD    (R0),ACO
2175
2176 014600 012737 014620 000244  MOV    #BBB6,@#FPVECT ;SET UP FOR THE EXPECTED INTERRUPT.
2177 014606 012700 015070          MOV    #BBBP1,R0      ;FSRC=0
2178
2179 014612 174410          BBB5:  DIVD   (R0),ACO      ;TEST INSTRUCTION (SHOULD RESULT IN TRAP).
    
```

```

2180 014614 170000          CFCC
2181
2182 014616 000502          BR      BBBER4          ;GO REPORT FAILURE, NO TRAP.
2183
2184 014620 022716 014614  BBB6:  CMP      #BBB5+2,(SP)  ;TRAP TO HERE WHEN THE DIVISION BY 0
2185                                     ;OCCURS. FIRST SEE IF THE ADDRESS OF
2186                                     ;THE TRAP IS 2+THE ADDRESS OF THE TEST
2187                                     ;DIVD INSTRUCTION.
2188 014624 001402          BEQ      1$
2189 014626 000137 036660          JMP      @#FPSPUR          ;IF NOT THEN REPORT AN UNEXPECTED
2190                                     ;FP TRAP.
2191 014632 170205          1$:   STFPS   R5          ;GET FPS.
2192 014634 170303          STST   R3          ;GET FEC.
2193 014636 022626          CMP      (SP)+,(SP)+      ;RESET THE STACK.
2194
2195 014640 012704 100200          MOV      #100200,R4        ;EXPECTED FPS.
2196 014644 020405          CMP      R4,R5          ;IS FPS CORRECT?
2197 014646 001040          BNE     BBBER2          ;IF INCORRECT BRANCH.
2198
2199 014650 012702 000004          MOV      #4,R2          ;EXPECTED FEC.
2200 014654 020203          CMP      R2,R3          ;IS FEC CORRECT?
2201 014656 001047          BNE     BBBER3          ;IF INCORRECT BRANCH.
2202
2203 014660 000137 015110          JMP      @#BBBDONE        ;OTHERWISE GO TO NEXT TEST.
2204
2205
2206                                     ;TRAP HERE IF AN UNEXPECTED INTERRUPT OCCURS.
2207 014664 062737 000002 001236  BBBER1: ADD     #2,@#STMP2  ;SEE IF THE INTERRUPT OCCURRED
2208                                     ;DURING THE EXECUTION OF THE DIVD
2209                                     ;INSTRUCTION BEING TESTED.
2210 014672 021637 001236          CMP      (SP),@#STMP2
2211 014676 001402          BEQ      1$
2212 014700 000137 036660          JMP      @#FPSPUR          ;IF NOT REPORT UNEXPECTED FP TRAP.
2213
2214 014704 022626          1$:   CMP      (SP)+,(SP)+      ;RESET THE STACK.
2215 014706 170303          STST   R3          ;GET FEC.
2216 014710 170205          STFPS  R5          ;GET FPS.
2217 014712 012737 000004 001240  MOV      #4,@#STMP3        ;EXPECTED FEC.
2218 014720 010337 001242          MOV      R3,@#STMP4
2219 014724 010537 001244          MOV      R5,@#STMP5
2220 014730 010037 001250          MOV      R0,@#STMP7
2221 014734 012737 140200 001246  MOV      #140200,@#STMP6
2222 014742 104017          2$:   ERROR  +17          ;REPORT (BUT FD) FAILED RESULTING IN AN FP TRAP
2223                                     ;WITH TRAPS DISABLED.
2224 014744 000137 015110          JMP      @#BBBDONE
2225
2226                                     ;REPORT FPS INCORRECT:
2227 014750 010537 001242  BBBER2: MOV      R5,@#STMP4
2228 014754 010437 001244          MOV      R4,@#STMP5
2229 014760 010037 001246          MOV      R0,@#STMP6
2230 014764 010137 001250          MOV      R1,@#STMP7
2231 014770 104020          1$:   ERROR  +20
2232 014772 000137 015110          JMP      @#BBBDONE
2233
2234                                     ;REPORT FEC INCORRECT:
2235 014776 010337 001242  BBBER3: MOV      R3,@#STMP4
2236 015002 010237 001240          MOV      R2,@#STMP3
    
```

```

2237 015006 010037 001246      MOV    R0,@#STMP6
2238 015012 010137 001250      MOV    R1,@#STMP7
2239 015016 104021      1$:   ERROR  +21
2240 015020 000137 015110      JMP    @#BBBDONE
2241
2242      ;REPORT NO TRAP OCCURRED AFTER TRYING TO DIVIDE
2243      ;BY ZERO WITH ALL TRAPS ENABLED.
2244 015024 170303      BBBER4: STST  R3          ;GET FEC.
2245 015026 170205      STFPS  R5          ;GET FPS.
2246 015030 012737 000004 001242      MOV    #4,@#STMP4
2247 015036 010337 001240      MOV    R3,@#STMP3
2248 015042 010537 001244      MOV    R5,@#STMP5
2249 015046 012737 100200 001246      MOV    #100200,@#STMP6
2250 015054 010037 001250      MOV    R0,@#STMP7
2251 015060 010137 001252      MOV    R1,@#STMP10
2252 015064 104022      1$:   ERROR  +22
2253 015066 000410      BR     BBBDONE
2254
2255 015070 000000 000000 000000 BBBP1: .WORD  0,0,0,0
2256 015076 000000
2256 015100 012345 054321 023456 BBBP2: .WORD  12345,54321,23456,76543
2256 015106 076543
2257
2258
2259
2260 015110      BBBDONE:
2260 015110 104412      RSETUP      ;GO INITIALIZE THE FPS AND STACK; AND
                ;SEE IF THE USER HAS EXPRESSED
                ;THE DESIRE TO CHANGE THE SOFTWARE
                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                ;THE USER TYPED CONTROL G?).

2261
2262
2270
2271      ;*****
                ;*TEST 6      DIVF TEST
                ;*
                ;*THIS IS A TEST OF THE DIVF INSTRUCTION. NOTE THAT A SUBROUTINE IS
                ;*USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE
                ;*RESULTS.
                ;*
                ;*****
2272 015112 000004      TST6:  SCOPE
2273
2274      ;CHECK DIVF WITH (AC=0).
                CCC1:
2275 015114 104413      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
2275 015116 004767 000552      JSR    PC,DIVFSUB
2276 015122 000000 000000      1$:   .WORD  0,0      ;AC
2277 015126 012345 067012      2$:   .WORD  12345,67012 ;FSRC
2278 015132 000000 000000      3$:   .WORD  0,0      ;RES
2279 015136 000000      4$:   0      ;FPS BEFORE EXECUTION.
2280 015140 000004      4      ;FPS AFTER EXECUTION
2281 015142 012345 067012      5$:   .WORD  12345,67012 ;ERROR RESULT
2282 015146 104023      6$:   ERROR  +23      ;RESULT BAD.
2283
2284      ;TEST DIVF WITH AC POSITIVE, FSRC POSITIVE AND IN ROUND MODE.
    
```

```

2285 015150          CCC2:
      015150 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2286 015152 004737 015674      JSR          PC,@#DIVFSUB
2287 015156 065652 125252      1$: .WORD     65652,125252      ;AC
2288 015162 065600 000000      2$: .WORD     65600,0          ;FSRC
2289 015166 040252 125252      3$: .WORD     40252,125252     ;RES
2290 015172 003000          4$: 3000          ;FPS BEFORE EXECUTION.
2291 015174 003000          4$: 3000          ;FPS AFTER EXECUTION.
2292 015176 040052 125252      5$: .WORD     40052,125252     ;ERROR RESULT.
2293 015202 104024          6$: ERROR      +24          ;DIV NORMALIZE FAILURE.
2294
2295          ;TEST DIVF WITH AC POSITIVE, FSRC POSITIVE.
2296 015204          CCC3:
      015204 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2297 015206 004767 000462      JSR          PC,DIVFSUB
2298 015212 076400 000000      1$: .WORD     76400,0          ;AC
2299 015216 076400 000000      2$: .WORD     76400,0          ;FSRC
2300 015222 040200 000000      3$: .WORD     40200,0          ;RES
2301 015226 001000          4$: 1000          ;FPS BEFORE EXECUTION.
2302 015230 001000          4$: 1000          ;FPS AFTER EXECUTION.
2303 015232 140200 000000      5$: .WORD     140200,0        ;ERROR RES.
2304
2305 015236 104025          6$: ERROR      +25          ;SIGN BAD.
2306
2307          ;TEST DIVF WITH BOTH OPERANDS POSITIVE.
2308 015240          CCC4:
      015240 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2309 015242 004737 015674      JSR          PC,@#DIVFSUB
2310 015246 056777 177777      1$: .WORD     56777,177777     ;AC
2311 015252 054200 000000      2$: .WORD     54200,0          ;FSRC
2312 015256 042777 177777      3$: .WORD     42777,177777     ;RES
2313 015262 000000          4$: 0            ;FPS BEFORE EXECUTION.
2314 015264 000000          4$: 0            ;FPS AFTER EXECUTION.
2315 015266 002000 002000      5$: .WORD     2000,2000        ;ERROR RES.
2316 015272 104023          6$: ERROR      +23
2317
2318          ;TEST THE DIVF INSTRUCTION:
2319 015274          CCC5:
      015274 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2320 015276 004737 015674      JSR          PC,@#DIVFSUB
2321 015302 012377 177777      1$: .WORD     12377,177777     ;AC
2322 015306 012300 000000      2$: .WORD     12300,0          ;FSRC
2323 015312 040252 125252      3$: .WORD     40252,125252     ;RES
2324 015316 000000          4$: 0            ;FPS BEFORE EXECUTION.
2325 015320 000000          4$: 0            ;FPS AFTER EXECUTION.
2326 015322 177777 177777      5$: .WORD     -1,-1          ;ERROR RES.
2327 015326 104023          6$: ERROR      +23
2328
2329          ;TEST DIVIDE ALGORITHM. TEST ROUND CONSTANT.
2330 015330          CCC6:
      015330 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
2331 015332 004737 015674      JSR          PC,@#DIVFSUB
2332 015336 064600 000001      1$: .WORD     64600,1          ;AC
2333 015342 066600 000000      2$: .WORD     66600,0          ;FSRC
2334 015346 036200 000001      3$: .WORD     36200,1          ;RES
2335 015352 000000          4$: 0            ;FPS BEFORE EXECUTION.
2336 015354 000000          4$: 0            ;FPS AFTER EXECUTION.

```



```

T6 DIVF TEST
2337 C15356 003000 003000 5$: .WORD 3000,3000 ;ERROR RES.
2338 015362 104023 6$: ERROR +23
2339
2340 ;TEST DIVF.
2341 015364 CCC7: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015364 104413 JSR PC,@#DIVFSUB
2342 015366 004737 015674 1$: .WORD 34577,177776 ;AC
2343 015372 034577 177776 2$: .WORD 23400,0 ;FSRC
2344 015376 023400 000000 3$: .WORD 51377,177776 ;RES
2345 015402 051377 177776 4$: 17 ;FPS BEFORE EXECUTION.
2346 015406 000017 0 ;FPS AFTER EXECUTION.
2347 015410 000000 5$: .WORD 3400,3400 ;ERROR RES.
2348 015412 003400 003400 6$: ERROR +23
2349 015416 104023
2350
2351
2352 ;DIVF TEST.
2353 015420 CCC8: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015420 104413 JSR PC,@#DIVFSUB
2354 015422 004737 015674 1$: .WORD 67652,125252 ;AC
2355 015426 067652 125252 2$: .WORD 56500,0 ;FSRC
2356 015432 056500 000000 3$: .WORD 51343,107070 ;RES
2357 015436 051343 107070 4$: 0 ;FPS BEFORE EXECUTION.
2358 015442 000000 0 ;FPS AFTER EXECUTION.
2359 015444 000000 5$: .WORD 51543,107070 ;ERROR RES.
2360 015446 051543 107070 6$: ERROR +26 ;DIDN'T INCREMENT THE EXPONENT
2361 015452 104026 ;AFTER DIVID NORMALIZATION.
2362
2363
2364 ;DIVF WITH AC NEGATIVE, FSRC NEGATIVE.
2365 015454 CCC9: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015454 104413 JSR PC,@#DIVFSUB
2366 015456 004737 015674 1$: .WORD 140400,0 ;AC
2367 015462 140400 000000 2$: .WORD 140500,0 ;FSRC
2368 015466 140500 000000 3$: .WORD 040052,125253 ;RES
2369 015472 040052 125253 4$: 0 ;FPS BEFORE EXECUTION.
2370 015476 000000 0 ;FPS AFTER EXECUTION.
2371 015500 000000 5$: .WORD 140052,125253 ;ERROR RES.
2372 015502 140052 125253 6$: ERROR +27 ;BAD SIGN.
2373 015506 104027
2374
2375 ;DIVF WITH AC NEGATIVE AND FSRC POSITIVE.
2376 015510 CCC10: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015510 104413 JSR PC,@#DIVFSUB
2377 015512 004737 015674 1$: .WORD 160077,0 ;AC
2378 015516 160077 000000 2$: .WORD 40277,0 ;FSRC
2379 015522 040277 000000 3$: .WORD 160000,0 ;RES
2380 015526 160000 000000 4$: 7 ;FPS BEFORE EXECUTION.
2381 015532 000007 0 ;FPS AFTER EXECUTION.
2382 015534 000010 5$: .WORD 60000,0 ;ERROR RES.
2383 015536 060000 000000 6$: ERROR +27 ;BAD SIGN.
2384 015542 104027
2385
2386 ;DIVF WITH AC POSITIVE AND FSRC NEGATIVE.
2387 015544 CCC11: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      015544 104413 JSR PC,@#DIVFSUB
2388 015546 004737 015674

```

2389 015552 040400 000000  
2390 015556 140500 000000  
2391 015562 140052 125253  
2392 015566 000017  
2393 015570 000010  
2394 015572 040052 125253  
2395 015576 104027

1\$: .WORD 40400,0 ;AC  
2\$: .WORD 140500,0 ;FSRC  
3\$: .WORD 140052,125253 ;RES  
4\$: 17 ;FPS BEFORE EXECUTION.  
10 ;FPS AFTER EXECUTION.  
5\$: .WORD 40052,125253 ;ERROR RES.  
6\$: ERROR +27 ;BAD SIGN.

2396  
2397  
2398

;TEST DIVF BOTH OPERANDS POSITIVE AND TRUNCATE MODE.

2399 015600  
015600 104413  
2400 015602 004737 015674  
2401 015606 060100 000001  
2402 015612 040300 000000  
2403 015616 060000 000000  
2404 015622 000052  
2405 015624 000040  
2406 015626 060000 000001  
2407 015632 104030

CCC12:  
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,@#DIVFSUB  
1\$: .WORD 60100,1 ;AC  
2\$: .WORD 40300,0 ;FSRC  
3\$: .WORD 60000,0 ;RES  
4\$: 52 ;FPS BEFORE EXECUTION.  
40 ;FPS AFTER EXECUTION.  
5\$: .WORD 60000,1 ;ERROR RES.  
6\$: ERROR +30 ;TRUNCATION ERROR

2408  
2409

;DIVF WITH POSITIVE OPERANDS AND ROUND MODE.

2410 015634  
015634 104413  
2411 015636 004767 000032  
2412 015642 060100 000001  
2413 015646 040300 000000  
2414 015652 060000 000001  
2415 015656 000005  
2416 015660 000000  
2417 015662 060000 000000  
2418 015666 104031

CCC13:  
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
JSR PC,DIVFSUB  
1\$: .WORD 60100,1 ;AC  
2\$: .WORD 40300,0 ;FSRC  
3\$: .WORD 60000,1 ;RES  
4\$: 5 ;FPS BEFORE EXECUTION.  
0 ;FPS AFTER EXECUTION.  
5\$: .WORD 60000,0 ;ERROR RES.  
6\$: ERROR +31 ;ROUND ERROR.

2419  
2420 015670 000137 016120

JMP @#CCCDONE ;GO TO NEXT TEST.

2421  
2422

;THIS SUBROUTINE, DIVFSUB, IS CALLED TO SET UP, EXECUTE  
;AND CHECK THE RESULT OF A DIVF INSTRUCTION. IT IS CALLED THUS:

2423  
2424  
2425  
2426  
2427  
2428  
2429  
2430  
2431  
2432  
2433  
2434

```

:
:      JSR      PC,@#DIVFSUB
:      ACARG:  .WORD  X,X      ;AC OPERAND
:      FSRCARG: .WORD  X,X      ;FSRC OPERAND
:      RES:    .WORD  X,X      ;EXPECTED RESULT
:      FPSB:   .WORD  X        ;FPS BEFORE EXECUTION
:      FPSA:   .WORD  X        ;FPS AFTER EXECUTION
:      ERRES:  .WORD  X,X      ;ERROR RESULT
:      ERR:    ERROR  +X       ;RESULT ERROR
:      CONT:
:      ;RETURN ADDRESS
    
```

2435  
2436  
2437  
2438  
2439  
2440  
2441  
2442  
2443

;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN  
;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, DIVF IS EXECUTED.  
;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE  
;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS  
;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS  
;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT  
;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF  
;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO  
;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES

```

2444                                     ;THEN THE FAILURE IS REPORTED IN DIVFSUB AND CONTROL IS PASSED TO
2445                                     ;CONT. IF NO ERRORS ARE DETECTED THEN DIVFSUB RETURNS CONTROL
2446                                     ;TO CONT.
2447
2448 015674 012601          DIVFSUB:      MOV      (SP)+,R1          ;GET A POINTER TO THE ARGUMENTS.
2449 015676 012700 000200      MOV      #200,R0          ;SET FD MODE.
2450 015702 170100          LDFPS   R0
2451 015704 010100          MOV      R1,R0          ;LOAD THE AC OPERAND.
2452 015706 172410          LDD     (R0),AC0
2453 015710 016100 000014      MOV      14(R1),R0      ;LOAD THE FPS
2454 015714 170100          LDFPS   R0
2455 015716 012737 015732 001236      MOV      #1$,@#STMP2
2456 015724 010100          MOV      R1,R0
2457 015726 062700 000004      ADD     #4,R0          ;ESTABLISH A POINTER TO FSRC.
2458
2459 015732 174410          1$:     DIVF   (R0),AC0      ;TEST INSTRUCTION.
2460
2461 015734 170204          STFPS  R4          ;GET THE FPS.
2462 015736 012700 000200      MOV      #200,R0      ;SET FD MODE
2463 015742 170100          LDFPS   R0
2464
2465 015744 012700 016110      MOV      #DIVFT,R0      ;GET THE RESULT OF THE DIVF.
2466 015750 174010          STD     AC0,(R0)
2467
2468 015752 010102          MOV      R1,R2          ;SAVE THE DATA IN CASE OF ERROR.
2469 015754 010237 001240      MOV      R2,@#STMP3
2470 015760 062702 000004      ADD     #4,R2
2471 015764 010237 001242      MOV      R2,@#STMP4
2472 015770 062702 000004      ADD     #4,R2
2473 015774 010237 001244      MOV      R2,@#STMP5
2474 016000 012737 016110 001246      MOV      #DIVFT,@#STMP6
2475 016006 010437 001250      MOV      R4,@#STMP7
2476 016012 016137 000016 001252      MOV      16(R1),@#STMP10
2477
2478 016020 021061 000010      CMP     (R0),10(R1)     ;IS THE RESULT CORRECT?
2479 016024 001011          BNE     10$            ;IF INCORRECT BRANCH.
2480 016026 026061 000002 000012      CMP     2(R0),12(R1)
2481 016034 001005          BNE     10$
2482
2483 016036 026104 000016      CMP     16(R1),R4      ;IS FPS CORRECT?
2484 016042 001020          BNE     15$            ;IF INCORRECT BRANCH.
2485 016044 000161 000026      JMP     26(R1)         ;IF NO ERRORS OCCURRED RETURN.
2486
2487 016050 021061 000020          10$:    CMP     (R0),20(R1)     ;DOES THE INCORRECT RESULT
2488 016054 001010          BNE     11$            ;MATCH THE ANTICIPATED INCORRECT RESULT.
2489 016056 026061 000002 000022      CMP     2(R0),22(R1)
2490 016064 001004          BNE     11$            ;BRANCH IF NO.
2491
2492 016066 010102          MOV      R1,R2          ;IT MATCHED SO RETURN TO THE ERROR
2493                                ;REPORT AT THE CALLING ROUTINE.
2494 016070 062702 000024          ADD     #24,R2
2495 016074 000112          JMP     (R2)
2496
2497 016076          11$:
2498 016076 104023          12$:    ERROR  +23
2499 016100 000161 000026          13$:    JMP     26(R1)
2500

```

```

2501 016104          15$:          ;REPORT FPS INCORRECT.
2502 016104 104032  16$:  ERROR  +32
2503 016106 000774          BR      13$
2504
2505 016110 000000 000000 000000 DIVFT: .WORD 0,0,0,0
      016116 000000
2506
2507 016120          CCCDONE:
      016120 104412          RSETUP          ;GO INITIALIZE THE FPS AND STACK; AND
                                          ;SEE IF THE USER HAS EXPRESSED
                                          ;THE DESIRE TO CHANGE THE SOFTWARE
                                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                          ;THE USER TYPED CONTROL G?).

```

2508  
2509  
2516  
2517

```

:*****
:*TEST 7          DIVD TEST
:*
:*THIS IS A TEST OF THE DIVD INSTRUCTION. NOTE THAT A SUBROUTINE IS
:*USED TO SET UP THE OPERANDS, EXECUTE THE INSTRUCTION AND CHECK THE RESULTS.
:*
:*****

```

```

2518 016122 000004  TST7:  SCOPE
2519
2520          ;DIVD TEST WITH POSITIVE OPERANDS AND IN ROUND MODE.
      DDD1:
2521          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
      016124 104413          JSR      PC,@#DIVDSUB
2522 016126 004737 016614          .WORD 34277,0,0,0 ;AC
      016132 034277 000000 000000 1$:
2523 016140 000000          .WORD 40277,0,0,0 ;FSRC
      016142 040277 000000 000000 2$:
2524 016150 000000          .WORD 34200,0,0,0 ;RES
      016152 034200 000000 000000 3$:
2525 016162 000200          4$: 200 ;FPS BEFORE EXECUTION.
2526 016164 000200          200 ;FPS AFTER EXECUTION.
2527 016166 177777 177777 177777 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
      016174 177777
2528 016176 104033          6$:  ERROR  +33
2529

```

```

2530          ;DIVD WITH AC NEGATIVE AND FSRC POSITIVE IN TRUNCATE MODE.
      DDD2:
2531 016200          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
      016200 104413          JSR      PC,@#DIVDSUB
2532 016202 004737 016614          .WORD 134277,0,0,0 ;AC
2533 016206 134277 000000 000000 1$:
      016214 000000          .WORD 40277,0,0,0 ;FSRC
2534 016216 040277 000000 000000 2$:
      016224 000000          .WORD 134200,0,0,0 ;RES
2535 016226 134200 000000 000000 3$:
      016234 000000          4$: 207 ;FPS BEFORE EXECUTION.
2536 016236 000207          210 ;FPS AFTER EXECUTION.
2537 016240 000210          5$: .WORD -1,-1,-1,-1 ;ERROR RESULT.
2538 016242 177777 177777 177777
      016250 177777
2539 016252 104033          6$:  ERROR  +33
2540

```

```

2541 ;DIVD TEST WITH OPERANDS BOTH NEGATIVE AND IN TRUNCATE MODE.
2542 016254 DDD3: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016254 104413 JSR PC,DIVDSUB
2543 016256 004767 000332 .WORD 134300,0,0,1 ;AC
2544 016262 134300 000000 000000 1$:
      016270 000001 .WORD 140300,0,0,0 ;FSRC
2545 016272 140300 000000 000000 2$:
      016300 000000 .WORD 34200,0,0,0 ;RES
2546 016302 034200 000000 000000 3$:
      016310 000000 4$: 250 ;FPS BEFORE EXECUTION.
2547 016312 000250 240 ;FPS AFTER EXECUTION.
2548 016314 000240 5$: .WORD 34200,0,0,1 ;ERROR RES.
2549 016316 034200 000000 000000
      016324 000001
2550 016326 104035 6$: ERROR +35 ;TRUNCATION ERROR.
2551
2552 ;DIVD WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
2553 016330 DDD4: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016330 104413 JSR PC,@#DIVDSUB
2554 016332 004737 016614 .WORD 34300,0,0,1 ;AC
2555 016336 034300 000000 000000 1$:
      016344 000001 .WORD 140300,0,0,0 ;FSRC
2556 016346 140300 000000 000000 2$:
      016354 000000 .WORD 134200,0,0,1 ;RES
2557 016356 134200 000000 000000 3$:
      016364 000001 4$: 207 ;FPS BEFORE EXECUTION.
2558 016366 000207 210 ;FPS AFTER EXECUTION.
2559 016370 000210 5$: .WORD 134200,0,0,0 ;ERROR RES.
2560 016372 134200 000000 000000
      016400 000000
2561 016402 104036 6$: ERROR +36 ;ROUND ERROR.
2562
2563 ;DIVD TEST.
2564 016404 DDD5: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016404 104413 JSR PC,@#DIVDSUB
2565 016406 004737 016614 .WORD 100400,0,0,0 ;AC
2566 016412 100400 000000 000000 1$:
      016420 000000 .WORD 500,0,0,0 ;FSRC
2567 016422 000500 000000 000000 2$:
      016430 000000 3$: .WORD 140052,125252 ;RES
2568 016432 140052 125252 -.WORD 125252,125252
2569 016436 125252 125252 4$: 7647 ;FPS BEFORE EXECUTION.
2570 016442 007647 7650 ;FPS AFTER EXECUTION.
2571 016444 007650 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
2572 016446 177777 177777 177777
      016454 177777
2573 016456 104033 6$: ERROR +33
2574
2575
2576 ;DIVD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
2577 016460 DDD6: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      016460 104413 JSR PC,@#DIVDSUB
2578 016462 004737 016614 .WORD 400,0,0,0 ;AC
2579 016466 000400 000000 000000 1$:
      016474 000000 .WORD 100500,0,0,0 ;FSRC
2580 016476 100500 000000 000000 2$:
      016504 000000

```

```

2581 016506 140052 125252 3$: .WORD 140052,125252 ;RES
2582 016512 125252 125253 .WORD 125252,125253
2583 016516 007707 4$: 7707 ;FPS BEFORE EXECUTION.
2584 016520 007710 7710 ;FPS AFTER EXECUTION.
2585 016522 177777 177777 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
    016530 177777
2586 016532 104033 6$: ERROR +33
2587
2588 ;DIVD TEST.
2589 016534 DDD7:
    016534 104413 .LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
2590 016536 004737 016614 JSR PC,@#DIVDSUB
2591 016542 170360 170360 1$: .WORD 170360,170360 ;AC
2592 016546 170360 170360 .WORD 170360,170360
2593 016552 170360 170360 2$: .WORD 170360,170360 ;FSRC
2594 016556 170360 170360 .WORD 170360,170360
2595 016562 040200 000000 3$: .WORD 40200,0,0,0 ;RES
    016570 000000
2596 016572 007717 4$: 7717 ;FPS BEFORE EXECUTION.
2597 016574 007700 7700 ;FPS AFTER EXECUTION.
2598 016576 177777 177777 5$: .WORD -1,-1,-1,-1 ;ERROR RES.
    016604 177777
2599 016606 104033 6$: ERROR +33
2600
2601 016610 000137 017054 JMP @#DDDDONE ;GO TO NEXT TEST.
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
  
```

;THIS SUBROUTINE, DIVDSUB, IS CALLED TO SET UP, EXECUTE  
 ;AND CHECK THE RESULT OF A DIVD INSTRUCTION. IT IS CALLED THUS:

```

:
:      JSR      PC,@#DIVDSUB
:      ACARG:  .WORD  X,X,X,X      ;AC OPERAND
:      FSRCARG: .WORD  X,X,X,X      ;FSRC OPERAND
:      RES:    .WORD  X,X,X,X      ;EXPECTED RESULT
:      FPSB:   .WORD  X              ;FPS BEFORE EXECUTION
:      FPSA:   .WORD  X              ;FPS AFTER EXECUTION
:      ERRES:  .WORD  X,X,X,X      ;ERROR RESULT
:      ERR:    ERROR  +X           ;RESULT ERROR
:      CONT:
:      ;RETURN ADDRESS
  
```

;THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN  
 ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, DIVD IS EXECUTED.

```

2620 ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
2621 ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
2622 ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
2623 ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
2624 ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
2625 ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
2626 ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
2627 ;THEN THE FAILURE IS REPORTED IN DIVDSUB AND CONTROL IS PASSED TO
2628 ;CONT. IF NO ERRORS ARE DETECTED THEN DIVDSUB RETURNS CONTROL
2629 ;TO CONT.
2630
2631 016614 012601 DIVDSUB: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.
2632 016616 012700 000200 MOV #200,R0 ;SET FD MODE.
2633 016622 170100 LDFPS R0
2634
2635 016624 010100 MOV R1,R0 ;SET UP THE ACO OPERAND.
2636 016626 172410 LDD (R0),ACO
2637 016630 016100 000030 MOV 30(R1),R0 ;LOAD THE FPS.
2638 016634 170100 LDFPS R0
2639
2640 016636 012737 016652 001236 MOV #1$,@#STMP2
2641 016644 010100 MOV R1,R0 ;ESTABLISH A POINTER TO FSRC.
2642 016646 062700 000010 ADD #10,R0
2643
2644 016652 174410 1$: DIVD (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
2645
2646 016654 170204 STFPS R4 ;GET THE FPS.
2647 016656 012700 000200 MOV #200,R0 ;SET FD MODE.
2648 016662 170100 LDFPS R0
2649
2650 016664 012700 017044 MOV #DIVDT,R0 ;GET THE RESULT.
2651 016670 174010 STD ACO,(R0)
2652
2653 016672 010102 MOV R1,R2 ;SAVE DATA IN CASE OF ERROR.
2654 016674 010237 001240 MOV R2,@#STMP3
2655 016700 062702 000010 ADD #10,R2
2656 016704 010237 001242 MOV R2,@#STMP4
2657 016710 062702 000010 ADD #10,R2
2658 016714 010237 001244 MOV R2,@#STMP5
2659 016720 012737 017044 001246 MOV #DIVDT,@#STMP6
2660 016726 010437 001250 MOV R4,@#STMP7
2661 016732 016137 000032 001252 MOV 32(R1),@#STMP10
2662
2663 016740 010102 MOV R1,R2 ;CHECK THE RESULT.
2664 016742 062702 000020 ADD #20,R2
2665 016746 012703 017044 MOV #DIVDT,R3
2666 016752 012705 000004 MOV #4,R5
2667 016756 022223 2$: CMP (R2)+,(R3)+ ;BRANCH IF RESULT INCORRECT.
2668 016760 001006 BNE 10$
2669 016762 077503 SOB R5,2$
2670
2671 016764 026104 000032 CMP 32(R1),R4 ;IS FPS CORRECT?
2672 016770 001023 BNE 15$ ;BRANCH IF INCORRECT.
2673 016772 000161 000046 JMP 46(R1) ;RETURN.
2674
2675 016776 010102 10$: MOV R1,R2 ;WAS INCORRECT RESULT ANTICIPATED?
2676 017000 062702 000034 ADD #34,R2

```

```

2677 017004 012703 017044      MOV    #DIVDT,R3
2678 017010 012705 000004      MOV    #4,R5
2679 017014 022223      11$:  CMP    (R2)+,(R3)+
2680 017016 001005      BNE    12$      ;BRANCH IF NO.
2681 017020 077503      SOB    R5,11$
2682 017022 010102      MOV    R1,R2      ;IF THE INCORRECT RESULT WAS
2683 017024 062702 000044      ADD    #44,R2      ;ANTICIPATED RETURN TO THE
2684                                ;ERROR REPORT IN THE CALLING
2685 017030 000112      JMP    (R2)        ;ROUTINE.
2686                                ;REPORT RESULT INCORRECT.
2687 017032      12$:
2688 017032 104033      13$:  ERROR  +33
2689 017034 000161 000046      14$:  JMP    46(R1)
2690                                ;REPORT FPS INCORRECT.
2691 017040      15$:
2692 017040 104034      16$:  ERROR  +34
2693 017042 000774      BR     14$
2694
2695 017044 000000 000000 000000 DIVDT: .WORD 0,0,0,0
      017052 000000
2696
2697 017054      DDDDONE:
      017054 104412      RSETUP      ;GO INITIALIZE THE FPS AND STACK; AND
      ;SEE IF THE USER HAS EXPRESSED
      ;THE DESIRE TO CHANGE THE SOFTWARE
      ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
      ;THE USER TYPED CONTROL G?).

```

2698  
 2699  
 2707  
 2708

```

:*****
:*TEST 10      MULF TEST
:*
:*THIS IS A TEST OF THE MULF INSTRUCTION. IT MAKES USE OF A SUBROUTINE
:*TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND CHECK THE
:*RESULTS.
:*
:*****

```

```

2709 017056 000004
2710
2711 017060      ;MULF WITH (FSRC=AC=0)
      017060 104413      EEE1:
2712 017062 004737 017640      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      JSR    PC,@#MULFSUB
2713 017066 000000 000000      1$:  .WORD 0,0      ;AC
2714 017072 000000 000000      2$:  .WORD 0,0      ;FSRC
2715 017076 000000 000000      3$:  .WORD 0,0      ;RES
2716 017102 007517      4$:  7517      ;FPS BEFORE EXECUTION.
      7504      ;FPS AFTER EXECUTION.
2717 017104 007504
2718 017106 177777 177777      5$:  .WORD -1,-1
2719 017112 104037      6$:  ERROR  +37
2720
2721      ;MULF WITH (FSRC=0).
2722 017114      EEE2:
      017114 104413      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
2723 017116 004737 017640      JSR    PC,@#MULFSUB
2724 017122 071625 034435      1$:  .WORD 71625,34435      ;AC

```



```

2725 017126 000000 000000 2$: .WORD 0,0 ;FSRC
2726 017132 000000 000000 3$: .WORD 0,0 ;RES
2727 017136 000013 177777 4$: 13 ;FPS BEFORE EXECUTION.
2728 017140 000004 177777 4: 4 ;FPS AFTER EXECUTION.
2729 017142 177777 177777 5$: .WORD -1,-1 ;ERROR RES.
2730 017146 104037 177777 6$: ERROR +37
2731
2732 ;MULF WITH (AC=0)
2733 017150 EEE3: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
017150 104413 JSR PC,@#MULFSUB
2734 017152 004737 017640 1$: .WORD 0,0 ;AC
2735 017156 000000 000000 2$: .WORD 071625,153443 ;FSRC
2736 017162 071625 153443 3$: .WORD 0,0 ;RES
2737 017166 000000 000000 4$: 7500 ;FPS BEFORE EXECUTION.
2738 017172 007500 000000 4$: 7504 ;FPS AFTER EXECUTION.
2739 017174 007504 000000 5$: .WORD -1,-1 ;ERROR RES.
2740 017176 177777 177777 6$: ERROR +37
2741 017202 104037 177777
2742
2743 ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.
2744 017204 EEE4: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
017204 104413 JSR PC,@#MULFSUB
2745 017206 004737 017640 1$: .WORD 40200,0 ;AC
2746 017212 040200 000000 2$: .WORD 40177,-1 ;FSRC
2747 017216 040177 177777 3$: .WORD 40177,-1 ;RES
2748 017222 040177 177777 4$: 17 ;FPS BEFORE EXECUTION.
2749 017226 000017 177777 4$: 0 ;FPS AFTER EXECUTION.
2750 017230 000000 177777 5$: .WORD 140177,-1 ;ERROR RES.
2751 017232 140177 177777 6$: ERROR +41 ;BAD SIGN.
2752 017236 104041 177777
2753
2754 ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN TRUNCATE MODE.
2755 017240 EEE5: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
017240 104413 JSR PC,MULFSUB
2756 017242 004767 000372 1$: .WORD 40177,-1 ;AC
2757 017246 040177 177777 2$: .WORD 40200,0 ;FSRC
2758 017252 040200 000000 3$: .WORD 40177,-1 ;RES
2759 017256 040177 177777 4$: 40 ;FPS BEFORE EXECUTION.
2760 017262 000040 177777 4$: 40 ;FPS AFTER EXECUTION.
2761 017264 000040 177777 5$: .WORD 37777,-1 ;ERROR RES.
2762 017266 037777 177777 6$: ERROR +42 ;ST 252 TO 044 INTO 444 (BUT Y62)
2763 017272 104042 177777 ;MUL. NORMALIZATION FAILURE.
2764
2765
2766 ;MULF WITH BOTH OPERANDS POSITIVE NORMALIZE TEST.
2767 017274 EEE6: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
017274 104413 JSR PC,@#MULFSUB
2768 017276 004737 017640 1$: .WORD 40100,0 ;AC
2769 017302 040100 000000 2$: .WORD 40100,0 ;FSRC
2770 017306 040100 000000 3$: .WORD 40020,0 ;RES
2771 017312 040020 000000 4$: 12 ;FPS BEFORE EXECUTION.
2772 017316 000012 000000 4$: 0 ;FPS AFTER EXECUTION.
2773 017320 000000 000000 5$: .WORD 42040,0 ;ERROR RES.
2774 017322 042040 000000 6$: ERROR +43 ;ST 252 TO 444 INTO 042 (BUT Y62)
2775 017326 104043 000000 ;MUL. NORMALIZATION FAILURE.
2776
2777

```

```

2778      ;MULF WITH BOTH OPERANDS POSITIVE IN ROUND MODE.
2779 017330 104413 017640 000000 000000 000000
      EEE7:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
                JSR      PC,@#MULFSUB
                .WORD    17500,0      ;AC
                .WORD    23652,125252 ;FSRC
                .WORD    3177,-1     ;RES
                7417      ;FPS BEFORE EXECUTION.
                7400      ;FPS AFTER EXECUTION.
                .WORD    -1,-1
                ERROR    +37

```

```

2788      ;MULF WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
2789 017364 104413 017640 000000 000000 000000
      EEE8:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
                JSR      PC,@#MULFSUB
                .WORD    40342,0     ;AC
                .WORD    176542,0    ;FSRC
                .WORD    176707,102000 ;RES
                7      ;FPS BEFORE EXECUTION.
                10      ;FPS AFTER EXECUTION.
                .WORD    76507,102000 ;ERROR RES.
                ERROR    +41         ;BAD SIGN.

```

```

2800      ;MULF WITH AC NEGATIVE AND FSRC POSITIVE IN ROUND MODE.
2801 017420 104413 017640 000000 000000 000000
      EEE9:      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
                JSR      PC,@#MULFSUB
                .WORD    140200,0    ;AC
                .WORD    7417,7417   ;FSRC
                .WORD    107417,7417 ;RES
                0      ;FPS BEFORE EXECUTION.
                10      ;FPS AFTER EXECUTION.
                .WORD    7417,7417   ;ERROR RES.
                ERROR    +41         ;BAD SIGN.

```

```

2810      ;MULF WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.
2811 017454 104413 017640 000000 000000 000000
      EEE10:     LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
                JSR      PC,@#MULFSUB
                .WORD    144600,0    ;AC
                .WORD    154000,0    ;FSRC
                .WORD    60400,0     ;RES
                17      ;FPS BEFORE EXECUTION.
                0      ;FPS AFTER EXECUTION.
                .WORD    160400,0    ;ERROR RES.
                ERROR    +41         ;BAD SIGN.

```

```

2822      ;MULF BOTH OPERANDS NEGATIVE IN ROUND MODE.
2823 017510 104413 017640 000000 000000 000000
      EEE11:     LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
                JSR      PC,@#MULFSUB
                .WORD    140300,0    ;AC
                .WORD    160000,1    ;FSRC
                .WORD    60100,2     ;RES
                10      ;FPS BEFORE EXECUTION.
                0      ;FPS AFTER EXECUTION.

```

```

2830 017536 060100 000001      5$:      .WORD  60100,1      ;ERROR RES.
2831 017542 104044              6$:      ERROR    +44        ;ROUND FAILURE.
2832
2833      ;MULF WITH AC POSITIVE AND FSRC NEGATIVE IN TRUNCATE MODE.
2834 017544      EEE12:
      017544 104413      LPERR              ;SET UP THE LOOP ON ERROR ADDRESS.
2835 017546 004737 017640      JSR      PC,@#MULFSUB
2836 017552 060000 000001      1$:      .WORD  60000,1      ;AC
2837 017556 140300 000000      2$:      .WORD  140300,0     ;FSRC
2838 017562 160100 000001      3$:      .WORD  160100,1     ;RES
2839 017566 007547              4$:      7547                ;FPS BEFORE EXECUTION.
2840 017570 007550              ;7550                ;FPS AFTER EXECUTION.
2841 017572 160100 000001      5$:      .WORD  160100,1     ;ERROR RES.
2842 017576 104045              6$:      ERROR    +45        ;TRUNCATION ERROR.
2843
2844      ;MULF WITH AC POSITIVE AND FSRC POSITIVE IN ROUND MODE.
2845 017600      EEE13:
      017600 104413      LPERR              ;SET UP THE LOOP ON ERROR ADDRESS.
2846 017602 004737 017640      JSR      PC,@#MULFSUB
2847 017606 040277 000000      1$:      .WORD  40277,0        ;AC
2848 017612 060000 000001      2$:      .WORD  60000,1     ;FSRC
2849 017616 060077 000001      3$:      .WORD  60077,1     ;RES
2850 017622 000014              4$:      14                  ;FPS BEFORE EXECUTION.
2851 017624 000000              ;0                    ;FPS AFTER EXECUTION.
2852 017626 060077 000002      5$:      .WORD  60077,2     ;ERROR RES.
2853 017632 104044              6$:      ERROR    +44        ;ROUND FAILURE. CONSTANT BAD.
2854
2855 017634 000167 000224      JMP      EEEDONE      ;GO TO THE NEXT TEST.
2856
2857      ;THIS SUBROUTINE, MULFSUB, IS CALLED TO SET UP, EXECUTE
2858      ;AND CHECK THE RESULT OF A MULF INSTRUCTION. IT IS CALLED THUS:
2859      :
2860      :
2861      :      JSR      PC,@#MULFSUB
2862      :      ACARG:  .WORD  X,X      ;AC OPERAND
2863      :      FSRCARG: .WORD  X,X      ;FSRC OPERAND
2864      :      RES:    .WORD  X,X      ;EXPECTED RESULT
2865      :      FPSB:   .WORD  X        ;FPS BEFORE EXECUTION
2866      :      FPSA:   .WORD  X        ;FPS AFTER EXECUTION
2867      :      ERRES:  .WORD  X,X      ;ERROR RESULT
2868      :      ERR:    ERROR  +X      ;RESULT ERROR
2869      :      CONT:   ;RETURN ADDRESS
2870      :
2871      ;THE OPERANDS ARE SET UP (USING ACO FOR THE AC OPERAND). THEN
2872      ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULF IS EXECUTED.
2873      ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
2874      ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
2875      ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
2876      ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
2877      ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
2878      ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
2879      ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
2880      ;THEN THE FAILURE IS REPORTED IN MULFSUB AND CONTROL IS PASSED TO
2881      ;CONT. IF NO ERRORS ARE DETECTED THEN MULFSUB RETURNS CONTROL
2882      ;TO CONT.
2883 017640 012601      MULFSUB:  MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
2884 017642 012700 000200      MOV      #200,R0        ;SET FD MODE.

```

2885	017646	170100			LDFPS	R0		
2886	017650	010100			MOV	R1,R0		;LOAD THE AC OPERAND.
2887	017652	172410			LDD	(R0),AC0		
2888	017654	016100	000014		MOV	14(R1),R0		;LOAD THE FPS
2889	017660	170100			LDFPS	R0		
2890	017662	012737	017676	001236	MOV	#1\$,@#STMP2		
2891	017670	010100			MOV	R1,R0		
2892	017672	062700	000004		ADD	#4,R0		;ESTABLISH A POINTER TO FSRC.
2893								
2894	017676	171010			1\$: MULF	(R0),AC0		;TEST INSTRUCTION.
2895								
2896	017700	170204			STFPS	R4		;GET THE FPS.
2897	017702	012700	000200		MOV	#200,R0		;SET FD MODE
2898	017706	170100			LDFPS	R0		
2899								
2900	017710	012700	020054		MOV	#MULFT,R0		;GET THE RESULT OF THE MULF.
2901	017714	174010			STD	AC0,(R0)		
2902								
2903	017716	010102			MOV	R1,R2		;SAVE THE DATA IN CASE OF ERROR.
2904	017720	010237	001240		MOV	R2,@#STMP3		
2905	017724	062702	000004		ADD	#4,R2		
2906	017730	010237	001242		MOV	R2,@#STMP4		
2907	017734	062702	000004		ADD	#4,R2		
2908	017740	010237	001244		MOV	R2,@#STMP5		
2909	017744	012737	020054	001246	MOV	#MULFT,@#STMP6		
2910	017752	010437	001250		MOV	R4,@#STMP7		
2911	017756	016137	000016	001252	MOV	16(R1),@#STMP10		
2912								
2913	017764	021061	000010		CMP	(R0),10(R1)		;IS THE RESULT CORRECT?
2914	017770	001011			BNE	10\$		;IF INCORRECT BRANCH.
2915	017772	026061	000002	000012	CMP	2(R0),12(R1)		
2916	020000	001005			BNE	10\$		
2917								
2918	020002	026104	000016		CMP	16(R1),R4		;IS FPS CORRECT?
2919	020006	001020			BNE	15\$		;IF INCORRECT BRANCH.
2920	020010	000161	000026		JMP	26(R1)		;IF NO ERRORS OCCURRED RETURN.
2921								
2922	020014	021061	000020		10\$: CMP	(R0),20(R1)		;DOES THE INCORRECT RESULT
2923	020020	001010			BNE	11\$		;MATCH THE ANTICIPATED INCORRECT RESULT.
2924	020022	026061	000002	000022	CMP	2(R0),22(R1)		
2925	020030	001004			BNE	11\$		;BRANCH IF NO.
2926								
2927	020032	010102			MOV	R1,R2		;IT MATCHED SO RETURN TO THE ERROR
2928								;REPORT AT THE CALLING ROUTINE.
2929	020034	062702	000024		ADD	#24,R2		
2930	020040	000112			JMP	(R2)		
2931								
2932	020042				11\$:			;REPORT RESULT INCORRECT.
2933	020042	104037			12\$:	ERROR	+37	
2934	020044	000161	000026		13\$:	JMP	26(R1)	
2935								
2936	020050				15\$:			;REPORT FPS INCORRECT.
2937	020050	104040			16\$:	ERROR	+40	
2938	020052	000774			BR	13\$		
2939								
2940	020054	000000	000000	000000	MULFT:	.WORD	0,0,0,0	
	020062	000000						

2941  
 2942 020064 104412  
 020064

EEDONE: RSETUP

;GO INITIALIZE THE FPS AND STACK; AND  
 ;SEE IF THE USER HAS EXPRESSED  
 ;THE DESIRE TO CHANGE THE SOFTWARE  
 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
 ;THE USER TYPED CONTROL G?).

2943  
 2944  
 2952  
 2953

\*\*\*\*\*  
 ;\*TEST 11 MULD TEST  
 ;\*  
 ;\*THIS IS A TEST OF THE MULD INSTRUCTION. NOTE THAT A SUBROUTINE IS  
 ;\*USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND  
 ;\*CHECK THE RESULTS.  
 ;\*  
 ;\*\*\*\*\*

2954 020066 000004

TST11: SCOPE

2955  
 2956

;MULD TEST WITH AC POSITIVE AND FSRC POSITIVE.

020070 104413  
 2957 020072 004737 020354  
 2958 020076 040200 000000 000000  
 020104 000000  
 2959 020106 023777 177777 177777  
 020114 177777  
 2960 020116 023777 177777 177777  
 020124 177777  
 2961 020126 000217  
 2962 020130 000200  
 2963 020132 023777 177777 000000  
 020140 000000  
 2964 020142 104047

FFF1:  
 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
 JSR PC,@#MULDSUB  
 1\$: .WORD 40200,0,0,0 ;AC  
 2\$: .WORD 23777,-1,-1,-1 ;FSRC  
 3\$: .WORD 23777,-1,-1,-1 ;RES  
 4\$: 217 ;FPS BEFORE EXECUTION.  
 200 ;FPS AFTER EXECUTION.  
 5\$: .WORD 23777,-1,0,0 ;ERROR RES.  
 6\$: ERROR +47 ;BAD CONSTANT USED IN ALGORITHM  
 ;USED 24 INSTEAD OF 56.

2965  
 2966  
 2967

;MULD TEST WITH BOTH OPERANDS POSITIVE TRUNCATION TEST.

2968 020144 104413  
 020144 004767 000202  
 2969 020146 065400 000000 000000  
 020160 000001  
 2971 020162 037577 177777 177777  
 020170 177776  
 2972 020172 064777 177777 177777  
 020200 177777  
 2973 020202 000247  
 2974 020204 000240  
 2975 020206 065000 000000 000000  
 020214 000000  
 2976 020216 104050

FFF2:  
 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
 JSR PC,MULDSUB  
 1\$: .WORD 65400,0,0,1 ;AC  
 2\$: .WORD 37577,-1,-1,-2 ;FSRC  
 3\$: .WORD 64777,-1,-1,-1 ;RES  
 4\$: 247 ;FPS BEFORE EXECUTION.  
 240 ;FPS AFTER EXECUTION.  
 5\$: .WORD 65000,0,0,0 ;ERROR RES.  
 6\$: ERROR +50 ;TRUNCATION ERROR.

2977  
 2978  
 2979

;MULD TEST WITH BOTH OPERANDS NEGATIVE IN ROUND MODE.

020220 104413  
 2980 020222 004737 020354

FFF3:  
 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.  
 JSR PC,@#MULDSUB

```

T11 MULD TEST
2981 020226 137577 177777 177777 1$: .WORD 137577,-1,-1,-2 ;AC
      020234 177776
2982 020236 165400 000000 000000 2$: .WORD 165400,0,0,1 ;FSRC
      020244 000001
2983 020246 065000 000000 000000 3$: .WORD 65000,0,0,0 ;RES
      020254 000000
2984 020256 007717 4$: 7717 ;FPS BEFORE EXECUTION.
2985 020260 007700 ;FPS AFTER EXECUTION.
2986 020262 064777 177777 177777 5$: .WORD 64777,-1,-1,-1 ;ERROR RES.
      020270 177777
2987 020272 104051 6$: ERROR +51 ;ROUND ERROR.
2988
2989 ;MULD TEST WITH AC POSITIVE AND FSRC NEGATIVE IN ROUND MODE.
2990 020274 FFF4: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      020274 104413 JSR PC,@#MULDSUB
2991 020276 004737 020354 .WORD 17500,0,0,0 ;AC
2992 020302 017500 000000 000000 1$: .WORD 17500,0,0,0 ;AC
      020310 000000
2993 020312 123652 125252 2$: .WORD 123652,125252 ;FSRC
2994 020316 125252 125252 .WORD 125252,125252
2995 020322 103177 177777 177777 3$: .WORD 103177,-1,-1,-1 ;RES
      020330 177777
2996 020332 000200 4$: 200 ;FPS BEFORE EXECUTION.
2997 020334 000210 210 ;FPS AFTER EXECUTION.
2998 020336 103200 000000 000000 5$: .WORD 103200,0,0,0 ;ERROR RES.
      020344 000000
2999 020346 104052 6$: ERROR +52 ;ROUND ERROR (BAD CONSTANT).
3000
3001 020350 000167 000240 JMP FFFDONE
3002
3003 ;THIS SUBROUTINE, MULDSUB, IS CALLED TO SET UP, EXECUTE
3004 ;AND CHECK THE RESULT OF A MULD INSTRUCTION. IT IS CALLED THUS:
3005
3006 :
3007 : JSR PC,@#MULDSUB
3008 : ACARG: .WORD X,X,X,X ;AC OPERAND
3009 : FSRCARG: .WORD X,X,X,X ;FSRC OPERAND
3010 : RES: .WORD X,X,X,X ;EXPECTED RESULT
3011 : FPSB: .WORD X ;FPS BEFORE EXECUTION
3012 : FPSA: .WORD X ;FPS AFTER EXECUTION
3013 : ERRES: .WORD X,X,X,X ;ERROR RESULT
3014 : ERR: ERROR +X ;RESULT ERROR
3015 : CONT: ;RETURN ADDRESS
3016
3017 ;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC OPERAND). THEN
3018 ;FPSB IS LOADED INTO THE FPS. THE INSTRUCTION, MULD IS EXECUTED.
3019 ;AFTER THE EXECUTION THE RESULT IS CHECKED AGAINST THE
3020 ;EXPECTED CORRECT RESULT, RES. IF IT IS CORRECT THEN THE FPS
3021 ;IS CHECKED WITH THE EXPECTED CORRECT FPS, FPSA. IF THE FPS WAS
3022 ;INCORRECT THEN IT IS REPORTED. IF THE RESULT WAS INCORRECT IT
3023 ;IS COMPARED WITH ERRES IN AN ATTEMPT TO ANALYSE THE ERROR. IF
3024 ;THE INCORRECT RESULT MATCHED ERRES THEN CONTROL IS PASSED TO
3025 ;THE ERROR CALL AT ERR. IF THE INCORRECT RESULT DID NOT MATCH ERRES
3026 ;THEN THE FAILURE IS REPORTED IN MULDSUB AND CONTROL IS PASSED TO
3027 ;CONT. IF NO ERRORS ARE DETECTED THEN MULDSUB RETURNS CONTROL
3028 ;TO CONT.
3029 020354 012601 MULDSUB: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.

```

```

3030 020356 012700 000200      MOV    #200,R0      ;SET FD MODE.
3031 020362 170100      LDFPS  R0
3032
3033 020364 010100      MOV    R1,R0      ;SET UP THE ACO OPERAND.
3034 020366 172410      LDD    (R0),ACO
3035 020370 016100 000030      MOV    30(R1),R0   ;LOAD THE FPS.
3036 020374 170100      LDFPS  R0
3037
3038 020376 012737 020412 001236      MOV    #1$,@#STMP2
3039 020404 010100      MOV    R1,R0      ;ESTABLISH A POINTER TO FSRC.
3040 020406 062700 000010      ADD    #10,R0
3041
3042 020412 171010      1$:    MULD   (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
3043
3044 020414 170204      STFPS  R4          ;GET THE FPS.
3045 020416 012700 000200      MOV    #200,R0     ;SET FD MODE.
3046 020422 170100      LDFPS  R0
3047
3048 020424 012700 020604      MOV    #MULDT,R0   ;GET THE RESULT.
3049 020430 174010      STD    ACO,(R0)
3050
3051 020432 010102      MOV    R1,R2      ;SAVE DATA IN CASE OF ERROR.
3052 020434 010237 001240      MOV    R2,@#STMP3
3053 020440 062702 000010      ADD    #10,R2
3054 020444 010237 001242      MOV    R2,@#STMP4
3055 020450 062702 000010      ADD    #10,R2
3056 020454 010237 001244      MOV    R2,@#STMP5
3057 020460 012737 020604 001246      MOV    #MULDT,@#STMP6
3058 020466 010437 001250      MOV    R4,@#STMP7
3059 020472 016137 000032 001252      MOV    32(R1),@#STMP10
3060
3061 020500 010102      MOV    R1,R2      ;CHECK THE RESULT.
3062 020502 062702 000020      ADD    #20,R2
3063 020506 012703 020604      MOV    #MULDT,R3
3064 020512 012705 000004      MOV    #4,R5
3065 020516 022223      2$:    CMP    (R2)+,(R3)+
3066 020520 001006      BNE   10$
3067 020522 077503      SOB   R5,2$      ;BRANCH IF RESULT INCORRECT.
3068
3069 020524 026104 000032      CMP    32(R1),R4   ;IS FPS CORRECT?
3070 020530 001023      BNE   15$
3071 020532 000161 000046      JMP    46(R1)      ;BRANCH IF INCORRECT.
3072
3073 020536 010102      10$:   MOV    R1,R2      ;WAS INCORRECT RESULT ANTICIPATED?
3074 020540 062702 000034      ADD    #34,R2
3075 020544 012703 020604      MOV    #MULDT,R3
3076 020550 012705 000004      MOV    #4,R5
3077 020554 022223      11$:   CMP    (R2)+,(R3)+
3078 020556 001005      BNE   12$
3079 020560 077503      SOB   R5,11$      ;BRANCH IF NO.
3080 020562 010102      MOV    R1,R2
3081 020564 062702 000044      ADD    #44,R2
3082
3083 020570 000112      JMP    (R2)
3084
3085 020572      12$:
3086 020572 104246      13$:   ERROR  +246      ;REPORT RESULT INCORRECT.

```

```

3087 020574 000161 000046      14$:   JMP      46(R1)
3088
3089 020600      15$:
3090 020600 104046      16$:   ERROR   +46
3091 020602 000774      BR      14$
3092
3093 020604 000000 000000 000000 MULDT: .WORD  0,0,0,0
      020612 000000
3094
3095 020614      FFFDONE:
      020614 104412      RSETUP

```

;REPORT FPS INCORRECT.

```

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

```

```

3096
3097
3106
3107
3108

```

```

;TEST TITLE:UNDER/OVERFLOW, USING MULF WITH TRAPS DISABLED
:*****
:*TEST 12      SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS USING
:*THE MULF INSTRUCTION WITH TRAPS DISABLED. NOTE THAT A SUBROUTINE
:*IS USED TO SET UP THE OPERANDS, EXECUTE THE MULF INSTRUCTION AND
:*CHECK THE RESULTS.
:*
:*****

```

```

3109 020616 000004
3110
3111 020620
      020620 104413
3112 020622 004737 021044
3113 020626 020200 000000
3114 020632 020000 000000
3115 020636 000000 000000
3116 020642 177777 177777
3117 020646 000000
3118 020650 000004
3119 020652 000012
3120 020654 177777
3121 020656 104117
3122 020660 000401
3123 020662 104114
3124 020664
3125
3126
3127 020664
      020664 104413
3128 020666 004737 021044
3129 020672 010200 000000
3130 020676 010000 000000
3131 020702 000000 000000
3132 020706 010000 000000
3133 020712 005013
3134 020714 005004

```

```

TST12: SCOPE
;UNDERFLOW, WITH EXPONENT OF RESULT = -129
IIII:
      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      JSR      PC,@#OVUNFNT
1$:   .WORD      20200,0      ;AC
2$:   .WORD      20000,0      ;FSRC
3$:   .WORD      0,0         ;RES
4$:   .WORD      -1,-1       ;ERROR RES.
5$:   0                ;FPS BEFORE EXECUTION.
      4                ;FPS AFTER EXECUTION.
6$:   12               ;FEC
      -1               ;FLAG
7$:   ERROR   +117       ;ST 331 TO 155 INTO 115 (BUT FIU)
      BR      8$
      ERROR   +114
8$:

```

```

;UNDERFLOW, WITH EXPONENT OF RESULT = -193
IIII2:
      LPERR      ;SET UP THE LOOP ON ERROR ADDRESS.
      JSR      PC,@#OVUNFNT
1$:   .WORD      10200,0     ;AC
2$:   .WORD      10000,0     ;FSRC
3$:   .WORD      0,0         ;RES
4$:   .WORD      10000,0     ;ERROR RES.
5$:   5013           ;FPS BEFORE EXECUTION.
      5004           ;FPS AFTER EXECUTION.

```



```

3135 020716 000012      6$:      12      :FEC
3136 020720 177777      :FLAG
3137 020722 104120      7$:      ERROR  +120  :SETTING FIUV OR FIV CAUSES TRAP
3138                                     :WITH FIU CLEAR.
3139 020724 000401      BR      8$
3140 020726 104114      ERROR  +114
3141 020730      8$:
3142
3143      :OVERFLOW, EXPONENT OF RESULT = 128
3144 020730      III3:
      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
      JSR      PC,@OVUNFNT
3145 020732 004737 021044      .WORD 60200,0      :AC
3146 020736 060200 000000      1$:      .WORD 60200,0      :FSRC
3147 020742 060000 000000      2$:      .WORD 60000,0      :RES
3148 020746 000000 000000      3$:      .WORD 0,0      :ERROR RES.
3149 020752 060000 000000      4$:      .WORD 60000,0      :FPS BEFORE EXECUTION.
3150 020756 000000      5$:      0      :FPS AFTER EXECUTION.
3151 020760 000006      6$:      6      :FEC
3152 020762 000010      7$:      10      :FLAG
3153 020764 000000      8$:      0      :ST 333 TO 136 INTO 116 (BUT FIV).
3154 020766 104121      BR      8$
3155 020770 000401      ERROR  +121
3156 020772 104113      BR      8$
3157 020774      ERROR  +113
3158
3159      :OVERFLOW, EXPONENT OF RESULT = 130
3160 020774      III4:
      LPERR      :SET UP THE LOOP ON ERROR ADDRESS.
      JSR      PC,@OVUNFNT
3161 020776 004737 021044      .WORD 60200,0      :AC
3162 021002 060200 000000      1$:      .WORD 60200,0      :FSRC
3163 021006 060200 000000      2$:      .WORD 60200,0      :RES
3164 021012 000000 000000      3$:      .WORD 0,0      :ERROR RES.
3165 021016 177777 177777      4$:      .WORD -1,-1      :FPS BEFORE EXECUTION.
3166 021022 006011      5$:      6011      :FPS AFTER EXECUTION.
3167 021024 006006      6$:      6006      :FEC
3168 021026 000010      7$:      10      :FLAG
3169 021030 000000      8$:      0      :SETTING FIUV OR FIU WITH
3170 021032 104122      BR      8$
3171      ERROR  +122      :FIV CLEAR CAUSES TRAP.
3172 021034 000401      BR      8$
3173 021036 104113      ERROR  +113
3174 021040 000167 000410      8$:      JMP      IIIDONE      :GO TO NEXT TEST.
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
  
```

```

:THIS SUBROUTINE, OVUNFNT, IS USED TO SET UP THE OPERANDS, EXECUTE
:THE MULF INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
:OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
:TO IT IS MADE THUS:
  
```

```

:
:      ACARG: .WORD  X,X      :AC OPERAND
:      FSRCARG: .WORD X,X      :FSRC OPERAND
:      RES: .WORD X,X      :EXPECTED RESULT
:      ERRES: .WORD X,X      :ERROR RESULT
:      FPSB: .WORD X      :FPS BEFORE EXECUTION
:      FPSA: .WORD X      :FPS AFTER EXECUTION
:      FEC: .WORD X      :EXPECTED FEC
  
```

```

3190          :          FLAG:  .WORD  X          :0/-1,OVER/UNDER FLOW FLAG
3191          :          ERR1:  ERROR  +X          :TRAP ERROR.
3192          :          BR      CONT          :
3193          :          ERR2:  ERROR  +X          :DATA, RESULT ERROR
3194          :          CONT:          :RETURN ADDRESS
3195          :
3196          :THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN
3197          :THE MULF INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE
3198          :RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS
3199          :COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNFNT RETURNS CONTROL
3200          :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFNT
3201          :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE
3202          :MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
3203          :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
3204          :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFNT
3205          :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
3206          :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFNT WILL
3207          :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
3208          :IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNFNT WILL READ THE FEC.
3209          :SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNFNT WILL
3210          :STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE
3211          :FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNFNT WILL REPORT
3212          :THE ERROR AND RETURN TO CONT. NOTE THAT OVUNFNT USES THE FLAG
3213          :TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
3214          :UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
3215
  
```

```

3216 021044 012601          OVUNFNT:  MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
3217 021046 012700 000200  MOV      #200,R0      ;SET FD MODE.
3218 021052 170100          LDFPS   R0
3219
3220 021054 010100          MOV      R1,R0        ;LOAD ACO, OPERAND.
3221 021056 172410          LDD     (R0),ACO
3222
3223 021060 010102          MOV      R1,R2        ;SAVE THE DATA PATTERNS IN CASE OF
3224 021062 010237 001240  MOV      R2,@#STMP3    ;ERROR.
3225 021066 062702 000004  ADD     #4,R2
3226 021072 010237 001242  MOV      R2,@#STMP4
3227 021076 062702 000004  ADD     #4,R2
3228 021102 010237 001244  MOV      R2,@#STMP5
3229 021106 016137 000022 001252  MOV      22(R1),@#STMP10
3230 021114 012737 021444 001246  MOV      #OVFNNT,@#STMP6
3231
3232 021122 016100 000020          MOV      20(R1),R0    ;LOAD THE FPS.
3233 021126 170100          LDFPS   R0
3234 021130 012737 021152 001236  MOV      #1$,@#STMP2
3235 021136 012737 021336 000244  MOV      #25$,@#FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
3236          :OF ERROR.
3237 021144 010100          MOV      R1,R0        ;COMPUTE THE ADDRESS OF FSRC.
3238 021146 062700 000004          ADD     #4,R0
3239
3240 021152 171010          1$:  MULF   (R0),ACO    ;TEST INSTRUCTION.
3241
3242 021154 170204          2$:  STFPS  R4            ;GET FPS.
3243 021156 170305          STST  R5            ;GET FEC.
3244 021160 012700 000200          MOV   #200,R0      ;SET FD MODE.
3245 021164 170100          LDFPS R0
3246 021166 012700 021444          MOV   #OVFNNT,R0   ;GET THE RESULT.
  
```

```

3247 021172 174010          STD   ACO,(R0)
3248 021174 010437 001250    MOV   R4,@#STMP7
3249 021200 010537 001254    MOV   R5,@#STMP11
3250
3251 021204 012700 021444    MOV   #OVFNIT,R0      ;CHECK THE RESULT.
3252 021210 010102          MOV   R1,R2
3253 021212 062702 000010    ADD   #10,R2
3254 021216 012703 000002    MOV   #2,R3
3255 021222 022022          3$:   CMP   (R0)+,(R2)+
3256 021224 001015          BNE   15$              ;BRANCH IF INCORRECT.
3257 021226 077303          SOB   R3,3$
3258
3259 021230 026104 000022    CMP   22(R1),R4       ;WAS FPS CORRECT?
3260 021234 001002          BNE   10$              ;BRANCH IF FPS IS INCORRECT.
3261
3262 021236 000161 000036    4$:   JMP   36(R1)         ;RETURN, TEST COMPLETED.
3263
3264          ;REPORT INCORRECT FPS.
3265 021242 005761 000026    10$:  TST   26(R1)         ;WAS THE RESULT OVER OR UNDER FLOW?
3266 021246 001002          BNE   12$              ;BRANCH IF UNDERFLOW.
3267
3268          ;REPORT FPS BAD AFTER OVERFLOW.
3269 021250 104111          11$:  ERROR +111
3270 021252 000771          BR    4$
3271
3272 021254          12$:
3273 021254 104112          13$:  ERROR +112
3274 021256 000767          BR    4$
3275
  
```

```

3277          ;RESULT INCORRECT.
3278 021260 012700 021444 15$:  MOV    #OVFNTT,R0    ;SEE IF FAILURE IS ANTICIPATED
3279 021264 010102          MOV    R1,R2          ;FAILURE.
3280 021266 062702 000014  ADD    #14,R2
3281 021272 012703 000002  MOV    #2,R3
3282 021276 022022 16$:  CMP    (R0)+,(R2)+
3283 021300 001007          BNE    17$          ;BRANCH IF NOT ANTICIPATED.
3284 021302 077303          SOB    R3,16$
3285
3286 021304 010102          MOV    R1,R2          ;ERROR WAS ANTICIPATED SO RETURN
3287 021306 062702 000034  ADD    #34,R2          ;TO THE ERROR REPORT IN THE CALLING
3288 021312 010237 001236  MOV    R2,@#STMP2      ;ROUTINE.
3289 021316 000112          JMP    (R2)
3290
3291 021320 005761 000026 17$:  TST    26(R1)          ;RESULT WAS NOT ANTICIPATED
3292
3293
3294
3295
3296 021324 001002          BNE    19$          ;SO ERROR MUST BE REPORTED HERE.
3297
3298
3299 021326 104113 18$:  ERROR  +113          ;FIRST SEE IF ARGUMENTS SHOULD
3300 021330 000742          BR     4$           ;HAVE RESULTED IN OVERFLOW OR UNDER
3301
3302 021332 19$:  ERROR  +114          ;FLOW BY LOOKING AT THE FLAG.
3303 021332 104114 20$:  ERROR  +114          ;BRANCH IF UNDERFLOW EXPECTED.
3304 021334 000740          BR     4$           ;REPORT RESULT INCORRECT, EXPECTING
3305
3306          ;IF AN FP TRAP OCCURS COME HERE.
3307 021336 011602 25$:  MOV    (SP),R2          ;GET ADDRESS OF TRAP.
3308 021340 022702 021154  CMP    #2$,R2          ;WAS THE TRAP DURING THE MULF INSTRUCTION?
3309 021344 001402          BEQ    26$          ;BRANCH IF YES.
3310 021346 000137 036660  JMP    @#FPSPUR        ;OTHERWISE GO REPORT A SPURIOUS
3311
3312 021352 022626 26$:  CMP    (SP)+,(SP)+      ;FP TRAP.
3313 021354 010237 001236  MOV    R2,@#STMP2      ;RESET THE STACK.
3314 021360 170204          STFPS  R4             ;SAVE DATA FOR ERROR REPORT.
3315 021362 170305          STST  R5             ;GET FPS.
3316 021364 012700 000200  MOV    #200,R0         ;GET FEC.
3317 021370 170100          LDFPS  R0             ;SET FD MODE.
3318 021372 012700 021444  MOV    #OVFNTT,R0      ;GET THE RESULT.
3319 021376 174010          STD   AC0,(R0)
3320 021400 010537 001254  MOV    R5,@#STMP11
3321 021404 020561 000024  CMP    R5,24(R1)
3322 021410 001004          BNE    27$          ;WAS THE FEC ANTICIPATED?
3323
3324 021412 010102          ;BRANCH IF NOT ANTICIPATED.
3325 021414 062702 000030  MOV    R1,R2          ;ERROR WAS ANTICIPATED SO
3326
3327 021420 000112          ADD    #30,R2          ;RETURN TO THE ERROR REPORT OF THE
3328
3329 021422 005761 000026  JMP    (R2)           ;CALLING ROUTINE.
3330
3331 27$:  TST    26(R1)          ;THE ERROR WAS NOT ANTICIPATED SO
3332 021426 001003          ;IT MUST BE REPORTED HERE. FIRST SEE IF EXPECTED
3333
3333          BNE    29$          ;OVERFLOW OR UNDER FLOW.
          ;BRANCH IF EXPECTING UNDERFLOW
  
```

```

3334                                     ;REPORT TRAPPED ON OVERFLOW WITH FIV=0
3335 021430 104115                       28$:  ERROR  +115
3336 021432 000161 000036                 JMP    36(R1)
3337
3338 021436                               29$:
3339 021436 104116                       30$:  ERROR  +116
3340 021440 000161 000036                 JMP    36(R1)
3341
3342 021444 000000 000000 -000000 .QVFNTT: .WORD 0,0,0,0
      021452 000000
3343
3344 021454                               IIIDONE:
      021454 104412                       RSETUP
  
```

```

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).
  
```

3345  
 3346  
 3347  
 3356  
 3357  
 3358

```

;TEST TITLE:UNDER/OVERFLOW, USING MULD WITH TRAP DISABLED
:*****
:*TEST 13 SEE COMMENT ABOVE FOR TEST TITLE
:*
:*THIS IS A TEST OF THE OVERFLOW AND UNDERFLOW CONDITIONS THAT CAN
:*ARRISE USING THE MULD INSTRUCTION WITH TRAPS DISABLED. A SUBROUTINE IS
:*USED TO SET UP THE OPERANDS, EXECUTE THE MULD INSTRUCTION AND
:*CHECK THE RESULTS.
:*
:*****
TST13: SCOPE
  
```

```

3359 021456 000004
3360
3361 021460
      021460 104413
3362 021462 004737 022004                 LPERR
      021466 020200 000000                 JSR   PC,@#OVUNDNT ;SET UP THE LOOP ON ERROR ADDRESS.
3363 021466 020200 000000                 1$:  .WORD 20200,0 ;AC
3364 021472 127272 000000                 .WORD 127272,0
3365 021476 020000 000000 000000         2$:  .WORD 20000,0,0,0 ;FSRC
      021504 000000
3366 021506 000000 000000 000000         3$:  .WORD 0,0,0,0 ;RES
      021514 000000
3367 021516 000000 000000                 4$:  .WORD 0,0 ;ERROR RES.
3368 021522 127272 000000                 .WORD 127272,0
3369 021526 000200                         5$:  200 ;FPS BEFORE EXECUTION.
3370 021530 000204                         204 ;FPS AFTER EXECUTION.
3371 021532 000012                         6$:  12 ;FEC
3372 021534 177777                         -1 ;FLAG
3373 021536 104131                         7$:  ERROR +131 ;ST 331 TO 155 INTO 115 (BUT FIU)
3374 021540 000401                         BR    8$
3375 021542 104132                         ERROR +132 ;ST 115 (BUT FD)
3376 021544
3377
3378
3379 021544                               ;UNDERFLOW, EXPONENT OF RESULT = -193
      021544 104413                         JJJ2:
      LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
  
```

3380	021546	004737	022004			JSR	PC, @#OVUNDNT	
3381	021552	010200	000000		1\$:	.WORD	10200,0	:AC
3382	021556	123456	000000			.WORD	123456,0	
3383	021562	010000	000000	000000	2\$:	.WORD	10000,0,0,0	:FSRC
	021570	000000						
3384	021572	000000	000000	000000	3\$:	.WORD	0,0,0,0	:RES
	021600	000000						
3385	021602	000000	000000	123456	4\$:	.WORD	0,0,123456,0	:ERROR RES
	021610	000000						
3386	021612	005213			5\$:		5213	:FPS BEFORE EXECUTION.
3387	021614	005204					5204	:FPS AFTER EXECUTION.
3388	021616	000012			6\$:		12	:FEC
3389	021620	177777					-1	:FLAG
3390	021622	104133			7\$:	ERROR	+133	:SETTING FIUV OR FIV BAD.
3391	021624	000401				BR	8\$	
3392	021626	104132				ERROR	+132	:ST 115 (BUT FD)
3393	021630				8\$:			
3394								
3395								:OVERFLOW, EXPONENT OF RESULT = 128
3396	021630				JJJ3:			
	021630	104413				LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3397	021632	004737	022004			JSR	PC, @#OVUNDNT	
3398	021636	060200	000000		1\$:	.WORD	60200,0	:AC
3399	021642	065432	000000			.WORD	65432,0	
3400	021646	060000	000000	000000	2\$:	.WORD	60000,0,0,0	:FSRC
	021654	000000						
3401	021656	000000	000000	000000	3\$:	.WORD	0,0,0,0	:RES
	021664	000000						
3402	021666	000000	000000	065432	4\$:	.WORD	0,0,65432,0	:ERROR RES.
	021674	000000						
3403	021676	000200			5\$:		200	:FPS BEFORE EXECUTION.
3404	021700	000206					206	:FPS AFTER EXECUTION.
3405	021702	000010			6\$:		10	:FEC
3406	021704	000000					0	:FLAG
3407	021706	104134			7\$:	ERROR	+134	:ST 333 TO 136 INTO 116 (BUT FIV)
3408	021710	000401				BR	8\$	
3409	021712	104135				ERROR	+135	:ST 116 (BUT FD)
3410	021714				8\$:			
3411								
3412								
3413								:OVERFLOW, EXPONENT OF RESULT = 130
3414	021714				JJJ4:			
	021714	104413				LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
3415	021716	004737	022004			JSR	PC, @#OVUNDNT	
3416	021722	060200	000000		1\$:	.WORD	60200,0	:AC
3417	021726	125252	000000			.WORD	125252,0	
3418	021732	060200	000000	000000	2\$:	.WORD	60200,0,0,0	:FSRC
	021740	000000						
3419	021742	000000	000000	000000	3\$:	.WORD	0,0,0,0	:RES
	021750	000000						
3420	021752	000000	000000	125252	4\$:	.WORD	0,0,125252,0	:ERROR RES.
	021760	000000						
3421	021762	006211			5\$:		6211	:FPS BEFORE EXECUTION.
3422	021764	006206					6206	:FPS AFTER EXECUTION.
3423	021766	000010			6\$:		10	:FEC
3424	021770	000000					0	:FLAG
3425	021772	104136			7\$:	ERROR	+136	:SETTING FIUV OR FIV BAD.

3426 021774 000401  
 3427 021776 104135  
 3428 022000 000137 022414

BR 8\$  
 ERROR +135 ;ST 116 (BUT FD)  
 8\$: JMP @#JJJDONE ;GO TO NEXT TEST.

; THIS SUBROUTINE, OVUNDNT, IS USED TO SET UP THE OPERANDS, EXECUTE  
 ; THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH  
 ; OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL  
 ; TO IT IS MADE THUS:

3429  
 3430  
 3431  
 3432  
 3433  
 3434  
 3435  
 3436  
 3437  
 3438  
 3439  
 3440  
 3441  
 3442  
 3443  
 3444  
 3445  
 3446  
 3447

ACARG: .WORD X,X,X,X	:AC OPERAND
FSRCARG: .WORD X,X,X,X	:FSRC OPERAND
RES: .WORD X,X,X,X	:EXPECTED RESULT
ERRES: .WORD X,X,X,X	:ERROR RESULT
FPSB: .WORD X	:FPS BEFORE EXECUTION
FPSA: .WORD X	:FPS AFTER EXECUTION
FEC: .WORD X	:EXPECTED FEC
FLAG: .WORD X	:0/-1,OVER/UNDER FLOW FLAG
ERR1: ERROR +X	:TRAP ERROR.
BR CONT	
ERR2: ERROR +X	:DATA, RESULT ERROR
CONT:	:RETURN ADDRESS

3448  
 3449  
 3450  
 3451  
 3452  
 3453  
 3454  
 3455  
 3456  
 3457  
 3458  
 3459  
 3460  
 3461  
 3462  
 3463  
 3464  
 3465  
 3466  
 3467

; THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN  
 ; THE MULD INSTRUCTION IS EXECUTED. IF NO TRAP OCCURS THEN THE  
 ; RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS  
 ; COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDNT RETURNS CONTROL  
 ; TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDNT  
 ; REPORTS THIS FAILURE AND THEN RETURNS TO CONT. IF THE RESULT OF THE  
 ; MULD IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE  
 ; ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN  
 ; THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDNT  
 ; WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE  
 ; RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDNT WILL  
 ; REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.  
 ; IF A TRAP OCCURS (IT SHOULD NOT) THEN OVUNDNT WILL READ THE FEC.  
 ; SHOULD THE FEC MATCH THE ANTICIPATED FEC OVUNDNT WILL  
 ; STORE ALL DATA AND TRANSFER CONTROL TO THE ERROR CALL AT ERR1. IF THE  
 ; FEC IS NOT THE SAME AS THE ANTICIPATED FEC OVUNDNT WILL REPORT  
 ; THE ERROR AND RETURN TO CONT. NOTE THAT OVUNDNT USES THE FLAG  
 ; TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN  
 ; UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).

3468 022004 012601  
 3469 022006 012700 000200  
 3470 022012 170100  
 3471  
 3472 022014 010100  
 3473 022016 172410  
 3474  
 3475 022020 010102  
 3476 022022 010237 001240  
 3477 022026 062702 000010  
 3478 022032 010237 001242  
 3479 022036 062702 000010  
 3480 022042 010237 001244  
 3481 022046 016137 000042 001252  
 3482 022054 012737 022404 001246

```
OVUNDNT:    MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS.
           MOV      #200,R0      ;SET FD MODE.
           LDFPS   R0

           MOV      R1,R0       ;LOAD ACO, OPERAND.
           LDD     (R0),ACO

           MOV      R1,R2       ;SAVE THE DATA PATTERNS IN CASE OF
           MOV      R2,@#STMP3 ;ERROR.
           ADD     #10,R2
           MOV      R2,@#STMP4
           ADD     #10,R2
           MOV      R2,@#STMP5
           MOV      42(R1),@#STMP10
           MOV     #OVDNTT,@#STMP6
```

```

3483
3484 022062 016100 000040      MOV      40(R1),R0      ;LOAD THE FPS.
3485 022066 170100              LDFPS   R0
3486 022070 012737 022112 001236  MOV      #1$,@#$TMP2
3487 022076 012737 022276 000244  MOV      #25$,@#$FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
3488                                ;OF ERROR.
3489 022104 010100              MOV      R1,R0          ;COMPUTE THE ADDRESS OF FSRC.
3490 022106 062700 000010      ADD      #10,R0
3491
3492 022112 171010              1$:     MULD   (R0),AC0   ;TEST INSTRUCTION.
3493
3494 022114 170204              2$:     STFPS  R4          ;GET FPS.
3495 022116 170305              STST    R5              ;GET FEC.
3496 022120 012700 000200      MOV      #200,R0       ;SET FD MODE.
3497 022124 170100              LDFPS   R0
3498 022126 012700 022404      MOV      #OVDNTT,R0    ;GET THE RESULT.
3499 022132 174010              STD     AC0,(R0)
3500 022134 010437 001250      MOV      R4,@#$TMP7
3501 022140 010537 001254      MOV      R5,@#$TMP11
3502
3503 022144 012700 022404      MOV      #OVDNTT,R0    ;CHECK THE RESULT.
3504 022150 010102              MOV      R1,R2
3505 022152 062702 000020      ADD      #20,R2
3506 022156 012703 000004      MOV      #4,R3
3507 022162 022022              3$:     CMP    (R0)+,(R2)+
3508 022164 001015              BNE     15$             ;BRANCH IF INCORRECT.
3509 022166 077303              SOB     R3,3$
3510
3511 022170 026104 000042      CMP      42(R1),R4     ;WAS FPS CORRECT?
3512 022174 001002              BNE     10$            ;BRANCH IF FPS IS INCORRECT.
3513
3514 022176 000161 000056      4$:     JMP    56(R1)       ;RETURN, TEST COMPLETED.
3515
3516              ;REPORT INCORRECT FPS.
3517 022202 005761 000046      10$:    TST    46(R1)     ;WAS THE RESULT OVER OR UNDER FLOW?
3518 022206 001002              BNE     12$            ;BRANCH IF UNDERFLOW.
3519
3520              ;REPORT FPS BAD AFTER OVERFLOW.
3521 022210 104123              11$:    ERROR +123
3522 022212 000771              BR      4$
3523
3524 022214              12$:
3525 022214 104124              13$:    ERROR +124
3526 022216 000767              BR      4$
3527
3528              ;RESULT INCORRECT.
3529 022220 012700 022404      15$:    MOV    #OVDNTT,R0 ;SEE IF FAILURE IS ANTICIPATED
3530 022224 010102              MOV    R1,R2           ;FAILURE.
3531 022226 062702 000030      ADD    #30,R2
3532 022232 012703 000004      MOV    #4,R3
3533 022236 022022              16$:    CMP    (R0)+,(R2)+
3534 022240 001007              BNE    17$             ;BRANCH IF NOT ANTICIPATED.
3535 022242 077303              SOB    R3,16$
3536
3537 022244 010102              MOV    R1,R2           ;ERROR WAS ANTICIPATED SO RETURN
3538 022246 062702 000054      ADD    #54,R2         ;TO THE ERROR REPORT IN THE CALLING
3539 022252 010237 001236      MOV    R2,@#$TMP2     ;ROUTINE.

```



```

3540 022256 000112          JMP      (R2)
3541
3542 022260 005761 000046 17$:  TST      46(R1)          ;RESULT WAS NOT ANTICIPATED
3543                                     ;SO ERROR MUST BE REPORTED HERE.
3544                                     ;FIRST SEE IF ARGUMENTS SHOULD
3545                                     ;HAVE RESULTED IN OVERFLOW OR UNDER
3546                                     ;FLOW BY LOOKING AT THE FLAG.
3547 022264 001002          BNE      19$          ;BRANCH IF UNDERFLOW EXPECTED.
3548
3549                                     ;REPORT RESULT INCORRECT, EXPECTING
3550 022266 104125 18$:  ERROR  +125          ;OVERFLOW.
3551 022270 000742          BR       4$
3552
3553 022272 19$:  ERROR  +126          ;REPORT RESULT INCORRECT, EXPECTING
3554 022272 104126 20$:  ERROR  +126          ;UNDERFLOW.
3555 022274 000740          BR       4$
3556
3557                                     ;IF AN FP TRAP OCCURS COME HERE.
3558 022276 011602 25$:  MOV      (SP),R2          ;GET ADDRESS OF TRAP.
3559 022300 022702 022114  CMP      #2$,R2          ;WAS THE TRAP DURING THE MULF INSTRUCTION?
3560 022304 001402          BEQ      26$          ;BRANCH IF YES.
3561 022306 000137 036660  JMP      @#FPSPUR          ;OTHERWISE GO REPORT A SPURIOUS
3562                                     ;FP TRAP.
3563 022312 022626 26$:  CMP      (SP)+,(SP)+          ;RESET THE STACK.
3564 022314 010237 001236  MOV      R2,@#$TMP2          ;SAVE DATA FOR ERROR REPORT.
3565 022320 170204          STFPS   R4              ;GET FPS.
3566 022322 170305          STST   R5              ;GET FEC.
3567 022324 012700 000200  MOV      #200,R0          ;SET FD MODE.
3568 022330 170100          LDFPS  R0
3569 022332 012700 022404  MOV      #OVDNTT,R0          ;GET THE RESULT.
3570 022336 174010          STD     AC0,(R0)
3571 022340 010537 001254  MOV      R5,@#$TMP1
3572 022344 020561 000044  CMP      R5,44(R1)
3573 022350 001004          BNE      27$          ;WAS THE FEC ANTICIPATED?
3574                                     ;BRANCH IF NOT ANTICIPATED.
3575 022352 010102          MOV      R1,R2          ;ERROR WAS ANTICIPATED SO
3576 022354 062702 000050  ADD      #50,R2          ;RETURN TO THE ERROR REPORT OF THE
3577                                     ;CALLING ROUTINE.
3578 022360 000112          JMP      (R2)
3579
3580 022362 005761 000026 27$:  TST      26(R1)          ;THE ERROR WAS NOT ANTICIPATED SO
3581                                     ;IT MUST BE REPORTED HERE. FIRST SEE IF EXPECTED
3582                                     ;OVERFLOW OR UNDER FLOW.
3583 022366 001003          BNE      29$          ;BRANCH IF EXPECTING UNDERFLOW
3584
3585                                     ;REPORT TRAPPED ON OVERFLOW WITH FIV=0
3586 022370 104127 28$:  ERROR  +127          ;
3587 022372 000161 000056  JMP      56(R1)
3588
3589 022376 29$:  ERROR  +130          ;REPORT TRAPPED ON UNDER FLOW WITH FIU=0
3590 022376 104130 30$:  ERROR  +130          ;
3591 022400 000161 000056  JMP      56(R1)
3592
3593 022404 000000 000000 000000 OVDNTT: .WORD 0,0,0,0
3594 022412 000000
3595 022414          JJJDONE:

```

022414 104412

RSETUP

:GO INITIALIZE THE FPS AND STACK; AND  
 :SEE IF THE USER HAS EXPRESSED  
 :THE DESIRE TO CHANGE THE SOFTWARE  
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS  
 :THE USER TYPED CONTROL G?).

3596  
 3597  
 3598  
 3610  
 3611  
 3612

:TEST TITLE:UNDER/OVERFLOW, USING MULF WITH TRAPS ENABLED

:\*\*\*\*\*

:\*TEST 14 SEE COMMENT ABOVE FOR TEST TITLE

:\*

:\*THIS IS A TEST OF THE UNDERFLOW AND OVERFLOW  
 :\*CONDITIONS THAT CAN OCCUR USING THE MULF INSTRUCTION.  
 :\*A SUBROUTINE IS CALLED TO SET UP THE OPERANDS,  
 :\* EXECUTE THE MULF INSTRUCTION AND CHECK  
 :\*THE RESULTS. HERE THE PARTICULAR INTERRUPT,  
 :\*EITHER OVERFLOW OR UNDERFLOW, IS ENABLED SO A TRAP SHOULD  
 :\*OCCUR.

:\*

:\*\*\*\*\*

022416 000004

TST14: SCOPE

3613  
 3614  
 3615  
 3616  
 3617  
 3618  
 3619  
 3620  
 3621  
 3622  
 3623  
 3624  
 3625  
 3626  
 3627  
 3628  
 3629

022420  
 022420 104413  
 022422 004737 022644  
 022426 020123 045676  
 022432 020200 000000  
 022436 000123 045676  
 022442 177777 177777  
 022446 002000  
 022450 102004  
 022452 000012  
 022454 177777  
 022456 104145  
 022460 000401  
 022462 104144  
 022464

:UNDERFLOW, EXPONENT OF RESULT = -129

KKK1:

LPERR JSR PC,@#OVUNFT :SET UP THE LOOP ON ERROR ADDRESS.  
 1\$: .WORD 20123,45676 :AC  
 2\$: .WORD 20200,0 :FSRC  
 3\$: .WORD 123,45676 :RES  
 4\$: .WORD -1,-1 :ERROR RES.  
 5\$: 2000 :FPS BEFORE EXECUTION.  
 102004 :FPS AFTER EXECUTION.  
 6\$: 12 :FEC  
 -1 :FLAG  
 7\$: ERROR +145 :ST 331 (BUT FIU) NO TRAP.  
 BR 8\$  
 ERROR +144

8\$:

:UNDERFLOW, EXPONENT OF THE RESULT = -193

KKK3:

LPERR JSR PC,@#OVUNFT :SET UP THE LOOP ON ERROR ADDRESS.  
 1\$: .WORD 10127,127272 :AC  
 2\$: .WORD 10200,0 :FSRC  
 3\$: .WORD 60127,127272 :RES  
 4\$: .WORD -1,-1 :ERROR RES.  
 5\$: 7017 :FPS BEFORE EXECUTION.  
 107000 :FPS AFTER EXECUTION.  
 6\$: 12 :FEC  
 -1  
 7\$: ERROR +146 :ST 137 (BUT FIU) NO TRAP.  
 BR 8\$  
 ERROR +144

8\$:

3630  
 3631  
 3632  
 3633  
 3634  
 3635  
 3636  
 3637  
 3638  
 3639  
 3640  
 3641  
 3642  
 3643  
 3644

022464  
 022464 104413  
 022466 004737 022644  
 022472 010127 127272  
 022476 010200 000000  
 022502 060127 127272  
 022506 177777 177777  
 022512 007017  
 022514 107000  
 022516 000012  
 022520 177777  
 022522 104146  
 022524 000401  
 022526 104144  
 022530



```

3700 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNFT
3701 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED
3702 :IN THE SAME WAY. IF THE RESULT OF THE
3703 :MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE
3704 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN
3705 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNFT
3706 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE
3707 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNFT WILL
3708 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.
3709 :IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.
3710 :NOTE THAT OVUNFT USES THE FLAG
3711 :TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN
3712 :UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).
3713
3714 022644 012601 OVUNFT: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS.
3715 022646 012700 000200 MOV #200,R0 ;SET FD MODE.
3716 022652 170100 LDFPS R0
3717
3718 022654 010100 MOV R1,R0 ;LOAD ACO, OPERAND.
3719 022656 172410 LDD (R0),ACO
3720
3721 022660 010102 MOV R1,R2 ;SAVE THE DATA PATTERNS IN CASE OF
3722 022662 010237 001240 MOV R2,@#STMP3 ;ERROR.
3723 022666 062702 000004 ADD #4,R2
3724 022672 010237 001242 MOV R2,@#STMP4
3725 022676 062702 000004 ADD #4,R2
3726 022702 010237 001244 MOV R2,@#STMP5
3727 022706 016137 000022 001252 MOV 22(R1),@#STMP10
3728 022714 012737 023246 001246 MOV #OVFTT,@#STMP6
3729
3730 022722 016100 000020 MOV 20(R1),R0 ;LOAD THE FPS.
3731 022726 170100 LDFPS R0
3732 022730 012737 022752 001236 MOV #1$,@#STMP2
3733 022736 012737 022762 000244 MOV #50$,@#FPVECT ;SET UP THE FP TRAP VECTOR IN CASE
3734 :OF ERROR.
3735 022744 010100 MOV R1,R0 ;COMPUTE THE ADDRESS OF FSRC.
3736 022746 062700 000004 ADD #4,R0
3737
3738 022752 171010 1$: MULF (R0),ACO ;TEST INSTRUCTION. SHOULD CAUSE TRAP.
3739 022754 170000 2$: CFCC
3740
3741 022756 000137 023206 JMP @#25$ ;FAILURE, NO TRAP.
3742
3743 022762 011602 50$: MOV (SP),R2 ;TRAP TO HERE AND SEE IF THE PC OF THE
3744 022764 020227 022754 CMP R2,#2$ ;TRAP WAS THAT OF THE MULF INSTRUCTION.
3745 022770 001402 BEQ 51$ ;BRANCH IF YES.
3746 022772 000137 036660 JMP @#FPSPUR ;OTHERWISE REPORT SPURIOUS FP ERROR.
3747
3748 022776 022626 51$: CMP (SP)+,(SP)+ ;RESET THE STACK
3749 023000 170204 STFPS R4 ;GET FPS.
3750 023002 170305 STST R5 ;GET FEC.
3751 023004 012700 000200 MOV #200,R0 ;SET FD MODE.
3752 023010 170100 LDFPS R0
3753 023012 012700 023246 MOV #OVFTT,R0 ;GET THE RESULT.
3754 023016 174010 STD ACO,(R0)
3755 023020 010437 001250 MOV R4,@#STMP7
3756 023024 010537 001254 MOV R5,@#STMP11
  
```

```

3757
3758 023030 012700 023246      MOV      #OVFTT,R0      ;CHECK THE RESULT.
3759 023034 010102              MOV      R1,R2
3760 023036 062702 000010      ADD      #10,R2
3761 023042 012703 000002      MOV      #2,R3
3762 023046 022022      3$:    CMP      (R0)+,(R2)+
3763 023050 001027              BNE      15$           ;BRANCH IF INCORRECT.
3764 023052 077303              SOB      R3,3$
3765
3766 023054 026104 000022      CMP      22(R1),R4     ;WAS FPS CORRECT?
3767 023060 001014              BNE      10$           ;BRANCH IF FPS IS INCORRECT.
3768
3769 023062 026105 000024      CMP      24(R1),R5     ;IS FEC CORRECT?
3770 023066 001002              BNE      5$            ;IF INCORRECT BRANCH.
3771 023070 000161 000036      4$:    JMP      36(R1)    ;RETURN, TEST COMPLETED.
3772
3773      ;REPORT INCORRECT FEC.
3774 023074 005761 000026      5$:    TST      26(R1)    ;WAS THE RESULT OVERFLOW OR UNDERFLOW?
3775 023100 001002              BNE      7$            ;BRANCH IF UNDERFLOW.
3776
3777      ;REPORT BAD FEC ON EXPECTED OVERFLOW.
3778 023102 104137      6$:    ERROR  +137
3779 023104 000771              BR       4$
3780
3781 023106      7$:
3782 023106 104140      8$:    ERROR  +140
3783 023110 000767              BR       4$
3784
3785      ;REPORT INCORRECT FPS.
3786 023112 005761 000026      10$:   TST      26(R1)    ;WAS THE RESULT OVER OR UNDER FLOW?
3787 023116 001002              BNE      12$           ;BRANCH IF UNDERFLOW.
3788
3789      ;REPORT FPS BAD AFTER OVERFLOW.
3790 023120 104141      11$:   ERROR  +141
3791 023122 000762              BR       4$
3792
3793 023124      12$:
3794 023124 104142      13$:   ERROR  +142
3795 023126 000760              BR       4$
3796
3797      ;RESULT INCORRECT.
3798 023130 012700 023246      15$:   MOV      #OVFTT,R0  ;SEE IF FAILURE IS ANTICIPATED
3799 023134 010102              MOV      R1,R2        ;FAILURE.
3800 023136 062702 000014      ADD      #14,R2
3801 023142 012703 000002      MOV      #2,R3
3802 023146 022022      16$:   CMP      (R0)+,(R2)+
3803 023150 001007              BNE      17$           ;BRANCH IF NOT ANTICIPATED.
3804 023152 077303              SOB      R3,16$
3805
3806 023154 010102              MOV      R1,R2        ;ERROR WAS ANTICIPATED SO RETURN
3807 023156 062702 000034      ADD      #34,R2       ;TO THE ERROR REPORT IN THE CALLING
3808 023162 010237 001236      MOV      R2,@#$TMP2   ;ROUTINE.
3809 023166 000112              JMP      (R2)
3810
3811 023170 005761 000026      17$:   TST      26(R1)    ;RESULT WAS NOT ANTICIPATED
3812      ;SO ERROR MUST BE REPORTED HERE.
3813      ;FIRST SEE IF ARGUMENTS SHOULD

```



```

3863 023306 000000
      023310 000177 177777 177777 3$: .WORD 177,-1,-1,-1 ;RES
      023316 177777
3864 023320 000177 177777 4$: .WORD 177,-1 ;ERROR RES.
3865 023324 125252 125252 .WORD 125252,125252
3866 023330 002200 5$: 2200 ;FPS BEFORE EXECUTION.
3867 023332 102204 102204 ;FPS AFTER EXECUTION.
3868 023334 000012 6$: 12 ;FEC
3869 023336 177777 -1 ;FLAG
3870 023340 104157 7$: ERROR +157 ;ST 331 (BUT FIU) NO TRAP.
3871 023342 000401 BR 8$
3872 023344 104160 ERROR +160 ;ST 155 (BUT FD)
3873 023346
3874
3875
3876 023346 ;UNDERFLOW, EXPONENT OF THE RESULT = -193
      023346 104413 LLL2: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
3877 023350 004737 023606 JSR PC,@#OVUNDT
3878 023354 010327 127272 1$: .WORD 10327,127272 ;AC
3879 023360 036363 045454 .WORD 36363,45454
3880 023364 010000 000000 000000 2$: .WORD 10000,0,0,0 ;FSRC
      023372 000000
3881 023374 060127 127272 3$: .WORD 60127,127272 ;RES
3882 023400 036363 045454 .WORD 36363,45454
3883 023404 177777 177777 177777 4$: .WORD -1,-1,-1,-1 ;ERROR RES.
      023412 177777
3884 023414 007217 5$: 7217 ;FPS BEFORE EXECUTION.
3885 023416 107200 107200 ;FPS AFTER EXECUTION.
3886 023420 000012 6$: 12 ;FEC
3887 023422 177777 -1 ;FLAG
3888 023424 104161 7$: ERROR +161 ;ST 137 (BUT FIU) NO TRAP.
3889 023426 000401 BR 8$
3890 023430 104156 ERROR +156
3891 023432
3892
3893 ;OVERFLOW, EXPONENT OF THE RESULT = 128
3894 023432 LLL3: LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
      023432 104413 JSR PC,@#OVUNDT
3895 023434 004737 023606 .WORD 60252,125252 ;AC
3896 023440 060252 125252 1$: .WORD 125252,125252 ;FSRC
3897 023444 125252 125252 .WORD 160100,0,0,0 ;FSRC
3898 023450 160100 000000 000000 2$: .WORD 160100,0,0,0
      023456 000000
3899 023460 100177 177777 177777 3$: .WORD 100177,-1,-1,-1 ;RES
      023466 177777
3900 023470 100177 177777 4$: .WORD 100177,-1 ;ERROR RES.
3901 023474 125252 125252 .WORD 125252,125252
3902 023500 001200 5$: 1200 ;FPS BEFORE EXECUTION.
3903 023502 101216 101216 ;FPS AFTER EXECUTION.
3904 023504 000010 6$: 10 ;FEC
3905 023506 000000 0 ;FLAG
3906 023510 104162 7$: ERROR +162 ;ST 333 (BUT FIV) NO TRAP.
3907 023512 000401 BR 8$
3908 023514 104163 ERROR +163 ;ST 700 (BUT FD).
3909 023516
3910
3911 ;OVERFLOW, EXPONENT OF THE RESULT = 130
  
```

```

3912 023516          LLL4:
      023516 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
3913 023520 004737 023606          JSR          PC,@#OVUNDT
3914 023524 060345 067654          1$: .WORD      60345,67654          ;AC
3915 023530 056765 045676          .WORD      56765,45676
3916 023534 060200 000000 000000 2$: .WORD      60200,0,0,0          ;FSRC
      023542 000000
3917 023544 000345 067654          3$: .WORD      345,67654          ;RES
3918 023550 056765 045676          .WORD      56765,45676
3919 023554 177777 177777 177777 4$: .WORD      -1,-1,-1,-1          ;ERROR RES.
      023562 177777
3920 023564 007215          5$: 7215          ;FPS BEFORE EXECUTION.
3921 023566 107202          .WORD      107202          ;FPS AFTER EXECUTION.
3922 023570 000010          6$: 10          ;FEC
3923 023572 000000          .WORD      0          ;FLAG
3924 023574 104164          7$: ERROR      +164          ;ST 133 (BUT FIV) NO TRAP
3925 023576 000401          BR          8$
3926 023600 104155          ERROR      +155
3927 023602 000137 024220          8$: JMP          @#LLLDONE
3928
3929          ;THIS SUBROUTINE, OVUNDT, IS USED TO SET UP THE OPERANDS, EXECUTE
3930          ;THE MULD INSTRUCTION AND CHECK THE RESULTS OF AN INSTRUCTION WITH
3931          ;OPERANDS WHICH SHOULD RESULT IN EITHER OVERFLOW OR UNDERFLOW. A CALL
3932          ;TO IT IS MADE THUS:
3933          :
3934          :          ACARG: .WORD      X,X,X,X          ;AC OPERAND
  
```



3936	:	FSRCARG: .WORD	X,X,X,X	:FSRC OPERAND
3937	:	RES: .WORD	X,X,X,X	:EXPECTED RESULT
3938	:	ERRES: .WORD	X,X,X,X	:ERROR RESULT
3939	:	FPSB: .WORD	X	:FPS BEFORE EXECUTION
3940	:	FPSA: .WORD	X	:FPS AFTER EXECUTION
3941	:	FEC: .WORD	X	:EXPECTED FEC
3942	:	FLAG: .WORD	X	:0/-1,OVER/UNDER FLOW FLAG
3943	:	ERR1: ERROR	+X	:TRAP ERROR.
3944	:	BR	CONT	
3945	:	ERR2: ERROR	+X	:DATA, RESULT ERROR
3946	:	CONT:		:RETURN ADDRESS

3947  
 3948 :THE OPERANDS ARE SET UP (USING ACO AS THE ACCUMULATOR). THEN  
 3949 :THE MULD INSTRUCTION IS EXECUTED. IF THE TRAP OCCURS THEN THE  
 3950 :RESULT IS CHECKED AGAINST RES. IF THE RESULT IS CORRECT THEN THE FPS IS  
 3951 :COMPARED WITH FPSA IF THIS TOO IS CORRECT OVUNDT RETURNS CONTROL  
 3952 :TO THE CALLING ROUTINE AT CONT. IF THE FPS IS BAD OVUNDT  
 3953 :REPORTS THIS FAILURE AND THEN RETURNS TO CONT. THE FEC IS TREATED  
 3954 :IN THE SAME WAY. IF THE RESULT OF THE  
 3955 :MULF IS INCORRECT, THE INCORRECT RESULT IS COMPARED WITH THE  
 3956 :ANTICIPATED FAILING DATA PATTERN, ERRES. IF THE FAILURE IN  
 3957 :THE RESULT WAS ANTICIPATED CORRECTLY TO BE ERRES THEN OVUNDT  
 3958 :WILL TRANSFER CONTROL TO THE ERROR CALL AT ERR2. OTHERWISE THE  
 3959 :RESULT WAS INCORRECT BUT WAS NOT ANTICIPATED AND OVUNDT WILL  
 3960 :REPORT THE FAILURE AFTER WHICH CONTROL WILL BE PASSED TO CONT.  
 3961 :IF NO TRAP OCCURS CONTROL IS PASSED TO ERR1.  
 3962 :NOTE THAT OVUNDT USES THE FLAG  
 3963 :TO TELL WHETHER OR NOT THESE PARTICULAR OPERANDS WILL RESULT IN  
 3964 :UNDERFLOW (FLAG=-1) OR OVERFLOW (FLAG=0).  
 3965

3966	023606	012601		OVUNDT: MOV	(SP)+,R1	:GET A POINTER TO THE ARGUMENTS.
3967	023610	012700	000200	MOV	#200,R0	:SET FD MODE.
3968	023614	170100		LDFPS	R0	
3969						
3970	023616	010100		MOV	R1,R0	:LOAD ACO, OPERAND.
3971	023620	172410		LDD	(R0),ACO	
3972						
3973	023622	010102		MOV	R1,R2	:SAVE THE DATA PATTERNS IN CASE OF
3974	023624	010237	001240	MOV	R2,@#STMP3	:ERROR.
3975	023630	062702	000010	ADD	#10,R2	
3976	023634	010237	001242	MOV	R2,@#STMP4	
3977	023640	062702	000010	ADD	#10,R2	
3978	023644	010237	001244	MOV	R2,@#STMP5	
3979	023650	016137	000042	MOV	42(R1),@#STMP10	
3980	023656	012737	024210	MOV	#OVDIT,@#STMP6	
3981						
3982	023664	016100	000040	MOV	40(R1),R0	:LOAD THE FPS.
3983	023670	170100		LDFPS	R0	
3984	023672	012737	023714	MOV	#1\$,@#STMP2	
3985	023700	012737	023724	MOV	#50\$,@#FPVECT	:SET UP THE FP TRAP VECTOR IN CASE
3986						:OF ERROR.
3987	023706	010100		MOV	R1,R0	:COMPUTE THE ADDRESS OF FSRC.
3988	023710	062700	000010	ADD	#10,R0	
3989						
3990	023714	171010		1\$: MULD	(R0),ACO	:TEST INSTRUCTION. SHOULD CAUSE TRAP.
3991	023716	170000		2\$: CFCC		
3992						

```

3993 023720 000137 024150          JMP      @#25$          :FAILURE, NO TRAP.
3994
3995 023724 011602          50$:  MOV      (SP),R2      :TRAP TO HERE AND SEE IF THE PC OF THE
3996 023726 020227 023716          CMP      R2,#2$        :TRAP WAS THAT OF THE MULF INSTRUCTION.
3997 023732 001402          BEQ      51$           :BRANCH IF YES.
3998 023734 000137 036660          JMP      @#FPSPUR      :OTHERWISE REPORT SPURIOUS FP ERROR.
3999
4000 023740 022626          51$:  CMP      (SP)+,(SP)+  :RESET THE STACK
4001 023742 170204          STFPS   R4             :GET FPS.
4002 023744 170305          STST    R5             :GET FEC.
4003 023746 012700 000.00          MOV      #200,R0       :SET FD MODE.
4004 023752 170100          LDFPS   R0
4005 023754 012700 024210          MOV      #OVDTT,R0     :GET THE RESULT.
4006 023760 174010          STD     ACO,(R0)
4007 023762 010437 001250          MOV      R4,@#TMP7
4008 023766 010537 001254          MOV      R5,@#TMP11
4009
4010 023772 012700 024210          MOV      #OVDTT,R0     :CHECK THE RESULT.
4011 023776 010102          MOV      R1,R2
4012 024000 062702 000020          ADD     #20,R2
4013 024004 012703 000004          MOV      #4,R3
4014 024010 022022          3$:  CMP      (R0)+,(R2)+  :BRANCH IF INCORRECT.
4015 024012 001027          BNE     15$
4016 024014 077303          SOB     R3,3$
4017
4018 024016 026104 000042          CMP      42(R1),R4     :WAS FPS CORRECT?
4019 024022 001014          BNE     10$           :BRANCH IF FPS IS INCORRECT.
4020
4021 024024 026105 000044          CMP      44(R1),R5     :IS FEC CORRECT?
4022 024030 001002          BNE     5$            :IF INCORRECT BRANCH.
4023 024032 000161 000056          4$:  JMP      56(R1)       :RETURN, TEST COMPLETED.
4024
4025          :REPORT INCORRECT FEC.
4026 024036 005761 000046          5$:  TST      46(R1)     :WAS THE RESULT OVERFLOW OR UNDERFLOW?
4027 024042 001002          BNE     7$            :BRANCH IF UNDERFLOW.
4028
4029          :REPORT BAD FEC ON EXPECTED OVERFLOW.
4030 024044 104151          6$:  ERROR   +151
4031 024046 000771          BR      4$
4032
4033 024050          7$:
4034 024050 104152          8$:  ERROR   +152
4035 024052 000767          BR      4$
4036
4037          :REPORT INCORRECT FPS.
4038 024054 005761 000046          10$: TST      46(R1)    :WAS THE RESULT OVER OR UNDER FLOW?
4039 024060 001002          BNE     12$          :BRANCH IF UNDERFLOW.
4040
4041          :REPORT FPS BAD AFTER OVERFLOW.
4042 024062 104153          11$: ERROR   +153
4043 024064 000762          BR      4$
4044
4045 024066          12$:
4046 024066 104154          13$: ERROR   +154
4047 024070 000760          BR      4$
4048
4049          :RESULT INCORRECT.

```

```
4050 024072 012700 024210      15$:  MOV    #OVDTT,R0      ;SEE IF FAILURE IS ANTICIPATED
4051 024076 010102              MOV    R1,R2          ;FAILURE.
4052 024100 062702 000030      ADD    #30,R2
4053 024104 012703 000004      MOV    #4,R3
4054 024110 022022              16$:  CMP    (R0)+,(R2)+
4055 024112 001007              BNE   17$            ;BRANCH IF NOT ANTICIPATED.
4056 024114 077303              SOB   R3,16$
4057
4058 024116 010102              MOV    R1,R2          ;ERROR WAS ANTICIPATED SO RETURN
4059 024120 062702 000054      ADD    #54,R2        ;TO THE ERROR REPORT IN THE CALLING
4060 024124 010237 001236      MOV    R2,@#STMP2   ;ROUTINE.
4061 024130 000112              JMP   (R2)
4062
4063 024132 005761 000046      17$:  TST   46(R1)      ;RESULT WAS NOT ANTICIPATED
4064                          ;SO ERROR MUST BE REPORTED HERE.
4065                          ;FIRST SEE IF ARGUMENTS SHOULD
4066                          ;HAVE RESULTED IN OVERFLOW OR UNDER
4067                          ;FLOW BY LOOKING AT THE FLAG.
4068 024136 001002              BNE   19$            ;BRANCH IF UNDERFLOW EXPECTED.
4069
4070                          ;REPORT RESULT INCORRECT, EXPECTING
4071 024140 104155              18$:  ERROR  +155      ;OVERFLOW.
4072 024142 000733              BR    4$
4073
4074 024144              19$:
4075 024144 104156              20$:  ERROR  +156      ;REPORT RESULT INCORRECT, EXPECTING
4076 024146 000731              BR    4$            ;UNDERFLOW.
4077
4078                          ;IF NO FP TRAP OCCURS COME HERE.
4079 024150 170204              25$:  STFPS  R4          ;GET FPS.
4080 024152 170305              STST  R5            ;GET FEC.
4081 024154 012700 000200      MOV    #200,R0       ;SET FD MODE.
4082 024160 170100              LDFPS R0
4083 024162 012700 024210      MOV    #OVDTT,R0     ;GET THE RESULT.
4084 024166 174010              STD   ACO,(R0)
4085 024170 010437 001250      MOV    R4,@#STMP7
4086 024174 010537 001254      MOV    R5,@#STMP11
4087 024200 010102              MOV    R1,R2
4088 024202 062702 000050      ADD    #50,R2        ;ERROR WAS ANTICIPATED SO
4089                          ;RETURN TO THE ERROR REPORT OF THE
4090 024206 000112              JMP   (R2)          ;CALLING ROUTINE.
4091
4092 024210 000000 000000 000000 OVDTT: .WORD 0,0,0,0
4093 024216 000000
4094 024220              LLLDONE:
4095 024220 104412              RSETUP              ;GO INITIALIZE THE FPS AND STACK; AND
4096                          ;SEE IF THE USER HAS EXPRESSED
4097                          ;THE DESIRE TO CHANGE THE SOFTWARE
4098                          ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
4099                          ;THE USER TYPED CONTROL G?).
4100
4101
4102
4103
4104
4105
4106
4107
```

::\*\*\*\*\*

```
024222 000004
4108
4109
4110 024224
      024224 104413
4111 024226 004737 025310
4112 024232 000000 000000
4113 024236 000000 000000
4114 024242 000000 000000
4115 024246 000000 000000
4116 024252 177777 177777
4117 024256 177777 177777
4118 024262 000013
4119 024264 000004
4120 024266 104056
4121 024270 000401
4122 024272 104057
4123 024274
4124
4125
4126 024274
      024274 104413
4127 024276 004737 025310
4128 024302 123456 076543
4129 024306 000000 000000
4130 024312 000000 000000
4131 024316 000000 000000
4132 024322 123456 076543
4133 024326 177777 177777
4134 024332 000000
4135 024334 000004
4136 024336 104056
4137 024340 000401
4138 024342 104057
4139 024344
4140
4141
4142 024344
      024344 104413
4143 024346 004737 025310
4144 024352 000000 000000
4145 024356 076543 021234
4146 024362 000000 000000
4147 024366 000000 000000
4148 024372 000000 000000
4149 024376 177777 177777
4150 024402 000003
4151 024404 000004
4152 024406 104053
4153 024410 000401
```

```
;*TEST 16      MODF TEST
;*
;*THIS IS A TEST OF THE MODF INSTRUCTION, WHICH MAKES USE OF
;*A SUBROUTINE TO SET UP THE OPERANDS, EXECUTE THE MODF INSTRUCTION
;*AND CHECK THE RESULTS.
;*
;*****
TST16: SCOPE
;MODF WITH (FSRC=AC=0)
GGG1:
      LPERR
      JSR      PC,@#MODFSUB      ;SET UP THE LOOP ON ERROR ADDRESS.
1$:   .WORD   0,0                ;AC
2$:   .WORD   0,0                ;FSRC
3$:   .WORD   0,0                ;FRACTIONAL RES.
4$:   .WORD   0,0                ;INTEGER RES.
5$:   .WORD  -1,-1              ;ERROR FRACTIONAL RES.
6$:   .WORD  -1,-1              ;ERROR INGETER RES.
7$:   13                          ;FPS BEFORE EXECUTION.
      4                          ;FPS AFTER EXECUTION.
8$:   ERROR   +56                ;STORE SINGLE ZERO BAD.
      BR      9$
      ERROR   +57
9$:
;MODF TEST, WITH (FSRC=0)
GGG2:
      LPERR
      JSR      PC,@#MODFSUB      ;SET UP THE LOOP ON ERROR ADDRESS.
1$:   .WORD   123456,76543       ;AC
2$:   .WORD   0,0                ;FSRC
3$:   .WORD   0,0                ;FRACTIONAL RES.
4$:   .WORD   0,0                ;INTEGER RESULT.
5$:   .WORD   123456,76543       ;ERROR FRACTIONAL RES.
6$:   .WORD   -1,-1             ;ERROR INTEGER RES.
7$:   0                          ;FPS BEFORE EXECUTION.
      4                          ;FPS AFTER EXECUTION.
8$:   ERROR   +56                ;STORE ZERO FAILURE.
      BR      9$
      ERROR   +57
9$:
;MODF TEST WITH (AC=0)
GGG3:
      LPERR
      JSR      PC,@#MODFSUB      ;SET UP THE LOOP ON ERROR ADDRESS.
1$:   .WORD   0,0                ;AC
2$:   .WORD   76543,21234       ;FSRC
3$:   .WORD   0,0                ;FRACTIONAL RES.
4$:   .WORD   0,0                ;INTEGER RES.
5$:   .WORD   0,0                ;ERROR FRACTIONAL RES.
6$:   .WORD  -1,-1              ;ERROR INTEGER RES.
7$:   3                          ;FPS BEFORE EXECUTION.
      4                          ;FPS AFTER EXECUTION.
8$:   ERROR   +53                ;RES.BAD
      BR      9$
```

4154 024412 104057  
 4155 024414  
 4156  
 4157  
 4158 024414  
       024414 104413  
 4159 024416 004737 025310  
 4160 024422 046252 125252  
 4161 024426 040300 000000  
 4162 024432 000000 000000  
 4163 024436 046377 177777  
 4164 024442 046252 125252  
 4165 024446 040300 000000  
 4166 024452 000013  
 4167 024454 000004  
 4168 024456 104053  
 4169 024460 000401  
 4170 024462 104060  
 4171 024464  
 4172  
 4173  
 4174 024464  
       024464 104413  
 4175 024466 004737 025310  
 4176 024472 077652 125252  
 4177 024476 040300 000000  
 4178 024502 000000 000000  
 4179 024506 077777 177777  
 4180 024512 077652 125252  
 4181 024516 040300 000000  
 4182 024522 000000  
 4183 024524 000004  
 4184 024526 104053  
 4185 024530 000401  
 4186 024532 104060  
 4187 024534  
 4188  
 4189  
 4190 024534  
       024534 104413  
 4191 024536 004737 025310  
 4192 024542 046200 000001  
 4193 024546 040340 000000  
 4194 024552 000000 000000  
 4195 024556 046340 000001  
 4196 024562 040000 000000  
 4197 024566 177777 177777  
 4198 024572 000013  
 4199 024574 000004  
 4200 024576 104061  
 4201  
 4202 024600 000401  
 4203 024602 104054  
 4204 024604  
 4205  
 4206  
 4207 024604

          ERROR +57  
 9\$:  
 :MODF TEST WITH EXPONENT OF THE RESULT = 25  
 GGG4:  
       LPERR                       ;SET UP THE LOOP ON ERROR ADDRESS.  
       JSR       PC,@#MODFSUB  
 1\$:       .WORD   46252,125252     ;AC  
 2\$:       .WORD   40300,0         ;FSRC  
 3\$:       .WORD   0,0             ;FRACTIONAL RES.  
 4\$:       .WORD   46377,-1       ;INTEGER RES.  
 5\$:       .WORD   46252,125252   ;ERROR FRACTIONAL RES.  
 6\$:       .WORD   40300,0         ;ERROR INTEGER RES.  
 7\$:       13                     ;FPS BEFORE EXECUTION.  
       4                         ;FPS AFTER EXECUTION.  
 8\$:       ERROR   +53             ;ST 134  
       BR        9\$  
       ERROR   +60  
 9\$:  
 :MODF TEST WITH EXPONENT OF THE RESULT = 127  
 GGG5:  
       LPERR                       ;SET UP THE LOOP ON ERROR ADDRESS.  
       JSR       PC,@#MODFSUB  
 1\$:       .WORD   77652,125252   ;AC  
 2\$:       .WORD   40300,0         ;FSRC  
 3\$:       .WORD   0,0             ;FRACTIONAL RES.  
 4\$:       .WORD   77777,-1       ;INTEGER RES.  
 5\$:       .WORD   77652,125252   ;ERROR FRACTIONAL RES.  
 6\$:       .WORD   40300,0         ;ERROR INTEGER RES.  
 7\$:       0                      ;FPS BEFORE EXECUTION.  
       4                         ;FPS AFTER EXECUTION.  
 8\$:       ERROR   +53  
       BR        9\$  
       ERROR   +60  
 9\$:  
 :MODF TEST WITH EXPONENT OF RESULT = 25  
 GGG6:  
       LPERR                       ;SET UP THE LOOP ON ERROR ADDRESS.  
       JSR       PC,@#MODFSUB  
 1\$:       .WORD   46200,1         ;AC  
 2\$:       .WORD   40340,0         ;FSRC  
 3\$:       .WORD   0,0             ;FRACTIONAL RES.  
 4\$:       .WORD   46340,1        ;INTEGER RES.  
 5\$:       .WORD   40000,0         ;ERROR FRACTIONAL RES.  
 6\$:       .WORD   -1,-1          ;ERROR INTEGER RES.  
 7\$:       13                     ;FPS BEFORE EXECUTION.  
       4                         ;FPS AFTER EXECUTION.  
 8\$:       ERROR   +61             ;BAD CONSTANT (NOT 24),  
                                   ;OR ST 525 TO 050 INTO 150.  
       BR        9\$  
       ERROR   +54  
 9\$:  
 :MODF TEST WITH EXPONENT OF THE RESULT = 24  
 GGG7:

```

024604 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4208 024606 004737 025310 JSR PC,@#MODFSUB ;AC
4209 024612 046000 000001 1$: .WORD 46000,1 ;FSRC
4210 024616 040340 000000 2$: .WORD 40340,0 ;FRACTIONAL RES.
4211 024622 040100 000000 3$: .WORD 40100,0 ;INTEGER RES.
4212 024626 046140 000001 4$: .WORD 46140,1 ;ERROR FRACTIONAL RES.
4213 024632 000000 000000 5$: .WORD 0,0 ;ERROR INTEGER RES.
4214 024636 177777 177777 6$: .WORD -1,-1 ;FPS BEFORE EXECUTION.
4215 024642 000000 7$: 0 ;FPS AFTER EXECUTION.
4216 024644 000000 8$: ERROR +62 ;BAD CONSTANT USED (NOT 24)
4217 024646 104062 BR 9$ ;OR ST 525 TO 150 INTO 050
4218 ERROR +54
4219 024650 000401 BR 9$
4220 024652 104054 ERROR +54
4221 024654 9$:
4222
4223 ;MODF TEST WITH EXPONENT OF THE RESULT = 10
4224 024654 GGG8:
024654 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4225 024656 004737 025310 JSR FC,@#MODFSUB ;AC
4226 024662 042577 177777 1$: .WORD 42577,-1 ;FSRC
4227 024666 040200 000000 2$: .WORD 40200,0 ;FRACTIONAL RES.
4228 024672 040177 176000 3$: .WORD 40177,176000 ;INTEGER RES.
4229 024676 042577 140000 4$: .WORD 42577,140000 ;ERROR FRACTIONAL RES.
4230 024702 177777 177777 5$: .WORD -1,-1 ;ERROR INTEGER RES.
4231 024706 177777 177777 6$: .WORD -1,-1 ;FPS BEFORE EXECUTION.
4232 024712 000000 7$: 0 ;FPS AFTER EXECUTION.
4233 024714 000000 8$: ERROR +53
4234 024716 104053 BR 9$
4235 024720 000401 ERROR +54
4236 024722 104054 9$:
4237 024724
4238
4239 ;MODF TEST WITH THE EXPONENT OF THE RESULT = 10
4240 024724 GGG9:
024724 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4241 024726 004737 025310 JSR PC,@#MODFSUB ;AC
4242 024732 042577 140001 1$: .WORD 42577,140001 ;FSRC
4243 024736 040200 000000 2$: .WORD 40200,0 ;FRACTIONAL RES.
4244 024742 034600 000000 3$: .WORD 34600,0 ;INTEGER RES.
4245 024746 042577 140000 4$: .WORD 42577,140000 ;ERROR FRACTIONAL RES.
4246 024752 000000 000000 5$: .WORD 0,0 ;ERROR INTEGER RES.
4247 024756 177777 177777 6$: .WORD -1,-1 ;FPS BEFORE EXECUTION.
4248 024762 000000 7$: 0 ;FPS AFTER EXECUTION.
4249 024764 000000 8$: ERROR +63 ;ST 532 TO 122 INTO NORMALIZE.
4250 024766 104063 BR 9$
4251 024770 000401 ERROR +54
4252 024772 104054 9$:
4253 024774
4254
4255 ;MODF TEST WITH EXPONENT OF THE RESULT = 9
4256 024774 GGG10:
024774 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4257 024776 004737 025310 JSR PC,@#MODFSUB ;AC
4258 025002 042377 100000 1$: .WORD 42377,100000 ;FSRC
4259 025006 040200 000000 2$: .WORD 40200,0 ;FRACTIONAL RES.
4260 025012 000000 000000 3$: .WORD 0,0

```

4261	025016	042377	100000	4\$:	.WORD	42377,100000	:INTEGER RES.
4262	025022	177777	177777	5\$:	.WORD	-1,-1	:ERROR FRACTIONAL RES.
4263	025026	177777	177777	6\$:	.WORD	-1,-1	:ERROR INTEGER RES.
4264	025032	000013		7\$:		13	:FPS BEFORE EXECUTION.
4265	025034	000004				4	:FPS AFTER EXECUTION.
4266	025036	104053		8\$:	ERROR	+53	
4267	025040	000401			BR	9\$	
4268	025042	104054			ERROR	+54	
4269	025044			9\$:			
4270							
4271							
4272	025044						
	025044	104413		GGG11:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
4273	025046	004737	025310		JSR	PC,@#MODFSUB	
4274	025052	040177	177777	1\$:	.WORD	40177,-1	:AC
4275	025056	040200	000000	2\$:	.WORD	40200,0	:FSRC
4276	025062	040177	177777	3\$:	.WORD	40177,-1	:FRACTIONAL RES.
4277	025066	000000	000000	4\$:	.WORD	0,0	:INTEGER RES.
4278	025072	000000	000000	5\$:	.WORD	0,0	:ERROR FRACTIONAL RES.
4279	025076	040177	177777	6\$:	.WORD	40177,-1	:ERROR INTEGER RES.
4280	025102	000017		7\$:		17	:FPS BEFORE EXECUTION.
4281	025104	000000				0	:FPS AFTER EXECUTION.
4282	025106	104064		8\$:	ERROR	+64	:ST 041 TO 046 INTO 246.
4283	025110	000401			BR	9\$	
4284	025112	104064			ERROR	+64	
4285	025114			9\$:			
4286							
4287							
4288	025114						
	025114	104413		GGG12:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
4289	025116	004737	025310		JSR	PC,@#MODFSUB	
4290	025122	034377	177777	1\$:	.WORD	34377,-1	:AC
4291	025126	040200	000000	2\$:	.WORD	40200,0	:FSRC
4292	025132	034377	177777	3\$:	.WORD	34377,-1	:FRACTIONAL RES.
4293	025136	000000	000000	4\$:	.WORD	0,0	:INTEGER RES.
4294	025142	000000	000000	5\$:	.WORD	0,0	:ERROR FRACTIONAL RES.
4295	025146	034377	177777	6\$:	.WORD	34377,-1	:ERROR INTEGER RES.
4296	025152	000000		7\$:		0	:FPS BEFORE EXECUTION.
4297	025154	000000				0	:FPS AFTER EXECUTION.
4298	025156	104064		8\$:	ERROR	+64	
4299	025160	000401			BR	9\$	
4300	025162	104064			ERROR	+64	
4301	025164			9\$:			
4302							
4303							
4304	025164						
	025164	104413		GGG13:	LPERR		:SET UP THE LOOP ON ERROR ADDRESS.
4305	025166	004737	025310		JSR	PC,@#MODFSUB	
4306	025172	020000	000001	1\$:	.WORD	20000,1	:AC
4307	025176	040300	000000	2\$:	.WORD	40300,0	:FSRC
4308	025202	020100	000002	3\$:	.WORD	20100,2	:FRACTIONAL RES.
4309	025206	000000	000000	4\$:	.WORD	0,0	:INTEGER RES.
4310	025212	020100	000001	5\$:	.WORD	20100,1	:ERROR FRACTIONAL RES.
4311	025216	000000	000000	6\$:	.WORD	0,0	:ERROR INTEGER RES.
4312	025222	000000		7\$:		0	:FPS BEFORE EXECUTION.
4313	025224	000000				0	:FPS AFTER EXECUTION.
4314	025226	104065		8\$:	ERROR	+65	:ROUND TRUNK, ST 126 INTO ROUND.

```

4315 025230 000401
4316 025232 104054
4317 025234
4318
4319
4320 025234
      025234 104413
4321 025236 004737 025310
4322 025242 142777 170000
4323 025246 040200 000000
4324 025252 140000 000000
4325 025256 142777 160000
4326 025262 040000 000000
4327 025266 042777 160000
4328 025272 000007
4329 025274 000010
4330 025276 104066
4331 025300 000401
4332 025302 104067
4333 025304 000167 000366
4334
4335
4336
4337
4338
4339
4340
4341
4342
4343
4344
4345
4346
4347
4348
4349
4350
4351
4352
4353
4354
4355
4356
4357
4358
4359
4360
4361
4362
4363
4364
4365
4366
4367
4368
4369 025310 012601
4370 025312 012700 000200
    
```

```

          BR      9$
          ERROR   +54
9$:
;MODF TEST WITH EXPONENT OF RESULT = 11
GGG14:
          LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
          JSR     PC,@#MODFSUB
1$:      .WORD   142777,170000 ;AC
2$:      .WORD   40200,0       ;FSRC
3$:      .WORD   140000,0     ;FRACTIONAL RES.
4$:      .WORD   142777,160000 ;INTEGER RES.
5$:      .WORD   40000,0      ;ERROR FRACTIONAL RES.
6$:      .WORD   42777,160000 ;ERROR INTEGER RES.
7$:      7                ;FPS BEFORE EXECUTION.
          10              ;FPS AFTER EXECUTION.
8$:      ERROR   +66       ;SIGN OF FRACTION.
          BR      9$
          ERROR   +67
9$:      JMP     GGGDONE    ;SIGN OF INTEGER.
                               ;GO TO NEXT TEST.

;THIS SUBROUTINE, MODFSUB, IS CALLED TO SETUP THE
;OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.
;IT IS CALLED THUS:
:
:          ACARG: .WORD   X,X          ;AC OPERAND
:          FSRCARG: .WORD  X,X          ;FSRC OPERAND
:          FRES: .WORD   X,X          ;FRACTIONAL RESULT
:          INTRES: .WORD  X,X          ;INTEGER RESULT
:          ERFRES: .WORD  X,X          ;ERROR FRACTION RESULT
:          ERINTRES: .WORD X,X          ;ERROR INTEGER RESULT
:          FPSB: .WORD   X             ;FPS BEFORE EXECUTION
:          FPSA: .WORD   X             ;FPS AFTER EXECUTION
:          ERR1:  ERROR  +X            ;FRACTION ERROR
:                   BR      CONT
:          ERR2:  ERROR  +X            ;INTEGER ERROR
:          CONT:                                     ;RETURN ADDRESS

;THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODF
;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
;THEN MODFSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
;FAILURE MATCHES THE TRUE RESULT THEN MODFSUB PASSES CONTROL TO THE
;ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
;FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
;IF A MATCH IS MADE HOWEVER, MODFSUB WILL RETURN CONTROL TO THE ERROR
;CALL AT ERR2.

MODFSUB:  MOV     (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS
          MOV     #200,R0      ;SET FD MODE.
    
```



```

4371 025316 170100          LDFPS  R0
4372 025320 010100          MOV    R1,R0          ;SET UP ACO
4373 025322 172410          LDD    (R0),ACO
4374 025324 012700 025666  MOV    #MODP1,R0      ;PUT A BACKGROUND PATTERN INTO AC1.
4375 025330 172510          LDD    (R0),AC1
4376 025332 016100 000030  MOV    30(R1),R0      ;SET UP THE FPS.
4377 025336 170100          LDFPS  R0
4378 025340 012737 025354 001236  MOV    #1$,@#STMP2
4379 025346 010100          MOV    R1,R0          ;COMPUTE THE ADDRESS OF THE FSRC.
4380 025350 062700 000004  ADD    #4,R0
4381
4382 025354 171410          1$:   MODF  (R0),ACO  ;EXECUTE THE TEST INSTRUCTION.
4383
4384 025356 170204          STFPS  R4              ;GET THE FPS.
4385 025360 012700 000200  MOV    #200,R0        ;SET FD MODE.
4386 025364 170100          LDFPS  RC
4387 025366 012700 025646  MOV    #MODFT0,R0     ;GET THE FRACTIONAL RESULT.
4388 025372 174010          STD    ACO,(R0)
4389 025374 012700 025656  MOV    #MODFT1,R0     ;GET THE INTEGER RESULT.
4390 025400 174110          STD    AC1,(R0)
4391
4392 025402 010102          MOV    R1,R2          ;SAVE THE DATA IN CASE OF ERROR.
4393 025404 010237 001240  MOV    R2,@#STMP3
4394 025410 062702 000004  ADD    #4,R2
4395 025414 010237 001242  MOV    R2,@#STMP4
4396 025420 062702 000004  ADD    #4,R2
4397 025424 010237 001244  MOV    R2,@#STMP5
4398 025430 062702 000004  ADD    #4,R2
4399 025434 010237 001246  MOV    R2,@#STMP6
4400 025440 012737 025646 001250  MOV    #MODFT0,@#STMP7
4401 025446 012737 025656 001252  MOV    #MODFT1,@#STMP10
4402 025454 010437 001254  MOV    R4,@#STMP11
4403 025460 016137 000032 001256  MOV    32(R1),@#STMP12
4404
4405 025466 012702 025646  MOV    #MODFT0,R2     ;CHECK THE FRACTIONAL RESULT.
4406 025472 026112 000010  CMP    10(R1),(R2)
4407 025476 001022          BNE    10$           ;BRANCH IF INCORRECT.
4408 025500 026162 000012 000002  CMP    12(R1),2(R2)
4409 025506 001016          BNE    10$
4410
4411 025510 012702 025656  MOV    #MODFT1,R2     ;CHECK THE INTEGER RESULT.
4412 025514 026112 000014  CMP    14(R1),(R2)
4413 025520 001026          BNE    15$           ;BRANCH IF INCORRECT.
4414 025522 026162 000016 000002  CMP    16(R1),2(R2)
4415 025530 001022          BNE    15$
4416
4417 025532 026104 000032  CMP    32(R1),R4      ;CHECK THE FPS.
4418 025536 001034          BNE    20$           ;BRANCH IF INCORRECT.
4419
4420 025540 000161 000042  9$:   JMP    42(R1)        ;RETURN.
4421
4422          ;FRACTIONAL ERROR.
4423 025544 026112 000020  10$:  CMP    20(R1),(R2)   ;WAS THE ERROR ANTICIPATED?
4424 025550 001010          BNE    11$           ;BRANCH IF NOT ANTICIPATED.
4425 025552 026162 000022 000002  CMP    22(R1),2(R2)
4426 025560 001004          BNE    11$
4427 025562 010102          MOV    R1,R2          ;THE ERROR WAS ANTICIPATED SO
  
```

```

4428 025564 062702 000034      ADD    #34,R2      ;RETURN TO THE ERROR REPORT AT THE
4429                                ;CALLING ROUTINE.
4430 025570 000112      JMP    (R2)
4431
4432 025572      11$:      ;THE ERROR WAS NOT ANTICIPATED SO
4433 025572 104053      12$:      ERROR +53      ;REPORT THE INCORRECT FRACTION HERE.
4434 025574 000761      BR      9$
4435
4436      ;INTEGER ERROR.
4437 025576 026112 000024      15$:      CMP    24(R1),(R2)      ;WAS THIS ERROR ANTICIPATED?
4438 025602 001010      BNE    16$      ;BRANCH IF NOT.
4439 025604 026162 000026 000002      CMP    26(R1),2(R2)
4440 025612 001004      BNE    16$
4441 025614 010102      MOV    R1,R2      ;THE ERROR WAS ANTICIPATED SO RETURN
4442 025616 062702 000040      ADD    #40,R2      ;TO THE ERROR REPORT IN THE CALLING
4443                                ;ROUTINE.
4444 025622 000112      JMP    (R2)
4445
4446 025624      16$:      ;THE ERROR WAS NOT ANTICIPATED SO REPORT
4447 025624 104054      17$:      ERROR +54      ;THE INTEGER FAILURE HERE.
4448 025626 000744      BR      9$
4449
4450      ;FPS INCORRECT.
4451 025630 010437 001254      20$:      MOV    R4,@#$TMP11      ;REPORT INCORRECT FPS.
4452 025634 016137 000032 001256      MOV    32(R1),@#$TMP12
4453 025642 104055      21$:      ERROR +55
4454 025644 000735      BR      9$
4455
4456 025646 000000 000000 000000 MODFT0: .WORD 0,0,0,0
4457 025654 000000
4458 025656 000000 000000 000000 MODFT1: .WORD 0,0,0,0
4459 025664 000000
4460 025666 177777 177777 177777 MODP1: .WORD -1,-1,-1,-1
4461 025674 177777
4462 025676      GGGDONE:
4463 025676 104412      RSETUP      ;GO INITIALIZE THE FPS AND STACK; AND
                                ;SEE IF THE USER HAS EXPRESSED
                                ;THE DESIRE TO CHANGE THE SOFTWARE
                                ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                ;THE USER TYPED CONTROL G?).
4463
4464
4465
4473
4474

```

```

*****
;*TEST 17      MODD TEST
;*
;*THIS IS A TEST OF THE MODD INSTRUCTION. IT MAKES USE OF A SUBROUTINE
;*TO SET UP THE ARGUMENTS, EXECUTE THE INSTRUCTION AND CHECK THE
;*RESULTS.
;*
*****
TST17: SCOPE

```

025700 000004  
 4475

```

4476                                     :MODD WITH (FSRC=AC=0)
4477 025702                               HHH1:
      025702 104413                       LPERR
4478 025704 004737 027406                 JSR PC,@#MODDSUB ;SET UP THE LOOP ON ERROR ADDRESS.
4479 025710 000000 000000 000000 1$: .WORD 0,0,0,0 ;AC
      025716 000000
4480 025720 000000 000000 000000 2$: .WORD 0,0,0,0 ;FSRC
      025726 000000
4481 025730 000000 000000 000000 3$: .WORD 0,0,0,0 ;FRACTIONAL RES.
      025736 000000
4482 025740 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
      025746 000000
4483 025750 000000 000000 000000 5$: .WORD 0,0,0,0 ;ERROR FRACTIONAL RES.
      025756 000000
4484 025760 000000 000000 177777 6$: .WORD 0,0,-1,-1 ;ERROR INTEGER RES.
      025766 177777
4485 025770 000200 7$: 200 ;FPS BEFORE EXECUTION.
4486 025772 000204 ;FPS AFTER EXECUTION.
4487 025774 104070 8$: ERROR +70
4488 025776 000401 BR 9$
4489 026000 104074 ERROR +74 ;ST 231 TO 142 INTO 143
4490 026002 9$:
4491
4492                                     :MODD TEST WITH FSRC=0
4493 026002                               HHH2:
      026002 104413                       LPERR
4494 026004 004737 027406                 JSR PC,@#MODDSUB ;SET UP THE LOOP ON ERROR ADDRESS.
4495 026010 012345 067012 1$: .WORD 012345,67012 ;AC
4496 026014 034567 012345 .WORD 34567,012345
4497 026020 000000 000000 000000 2$: .WORD 0,0,0,0 ;FSRC
      026026 000000
4498 026030 000000 000000 000000 3$: .WORD 0,0,0,0 ;FRACTIONAL RES.
      026036 000000
4499 026040 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
      026046 000000
4500 026050 012345 067012 5$: .WORD 012345,67012 ;ERROR FRACTIONAL RES.
4501 026054 034567 012345 .WORD 34567,012345
4502 026060 177777 177777 177777 6$: .WORD -1,-1,-1,-1 ;ERROR INTEGER RES.
      026066 177777
4503 026070 000213 7$: 213 ;FPS BEFORE EXECUTION.
4504 026072 000204 ;FPS AFTER EXECUTION.
4505 026074 104075 8$: ERROR +75 ;STORE DOUBLE ZERO
4506 026076 000401 BR 9$
4507 026100 104076 ERROR +76 ;AC V 1 <= ZERO ST 143
4508 026102 9$:
4509
4510                                     :MODD TEST WITH (AC=0)
4511 026102                               HHH3:
      026102 104413                       LPERR
4512 026104 004737 027406                 JSR PC,@#MODDSUB ;SET UP THE LOOP ON ERROR ADDRESS.
4513 026110 000000 000000 000000 1$: .WORD 0,0,0,0 ;AC
      026116 000000
4514 026120 072727 127272 2$: .WORD 72727,127272 ;FSRC
4515 026124 072727 127272 .WORD 72727,127272
4516 026130 000000 000000 000000 3$: .WORD 0,0,0,0 ;FRACTIONAL RES.
      026136 000000
4517 026140 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
  
```

4518	026146	000000									
	026150	177777	177777	177777	5\$:	.WORD	-1,-1,-1,-1			:ERROR FRACTIONAL RES.	
	026156	177777									
4519	026160	177777	177777	177777	6\$:	.WORD	-1,-1,-1,-1			:ERROR INTEGER RES.	
	026166	177777									
4520	026170	000213			7\$:		213			:FPS BEFORE EXECUTION.	
4521	026172	000204					204			:FPS AFTER EXECUTION.	
4522	026174	104070			8\$:	ERROR	+70				
4523	026176	000401				BR	9\$				
4524	026200	104071				ERROR	+71				
4525	026202				9\$:						
4526											
4527											
4528	026202										
	026202	104413				HHH4:				:MODD TEST WITH EXPONENT OF THE RESULT = 57	
4529	026204	004737	027406			LPERR				:SET UP THE LOOP ON ERROR ADDRESS.	
						JSR	PC,@#MODDSUB				
4530	026210	056252	125252		1\$:	.WORD	56252,125252			:AC	
4531	026214	125252	125250			.WORD	125252,125250				
4532	026220	040300	000000	000000	2\$:	.WORD	40300,0,0,0			:FSRC	
	026226	000000									
4533	026230	000000	000000	000000	3\$:	.WORD	0,0,0,0			:FRACTIONAL RES.	
	026236	000000									
4534	026240	056377	177777	177777	4\$:	.WORD	56377,-1,-1,-4			:INTEGER RES.	
	026246	177774									
4535	026250	000000	000000		5\$:	.WORD	0,0			:ERROR FRACTIONAL RES.	
4536	026254	125252	125252			.WORD	125252,125252				
4537	026260	056377	177777	177777	6\$:	.WORD	56377,-1,-1,-1			:ERROR INTEGER RES.	
	026266	177777									
4538	026270	000213			7\$:		213			:FPS BEFORE EXECUTION.	
4539	026272	000204					204			:FPS AFTER EXECUTION.	
4540	026274	104077			8\$:	ERROR	+77			:ST 526 TO 134 INTO 135	
4541	026276	000401				BR	9\$				
4542	026300	104077				ERROR	+77				
4543	026302				9\$:						
4544											
4545											
4546	026302										
	026302	104413				HHH5:				:MODD TEST WITH EXPONENT OF THE RESULT = 79	
4547	026304	004737	027406			LPERR				:SET UP THE LOOP ON ERROR ADDRESS.	
						JSR	PC,@#MODDSUB				
4548	026310	140240	000000	000000	1\$:	.WORD	140240,0,0,0			:AC	
	026316	000000									
4549	026320	063714	146314		2\$:	.WORD	63714,146314			:FSRC	
4550	026324	133572	167737			.WORD	133572,167737				
4551	026330	000000	000000	000000	3\$:	.WORD	0,0,0,0			:FRACTIONAL RES.	
	026336	000000									
4552	026340	163777	177777		4\$:	.WORD	163777,-1			:INTEGER RES.	
4553	026344	162531	125726			.WORD	162531,125726				
4554	026350	177777	177777	177777	5\$:	.WORD	-1,-1,-1,-1			:ERROR FRACTIONAL RES.	
	026356	177777									
4555	026360	063777	177777		6\$:	.WORD	63777,-1			:ERROR INTEGER RES.	
4556	026364	162531	125726			.WORD	162531,125726				
4557	026370	000210			7\$:		210			:FPS BEFORE EXECUTION.	
4558	026372	000204					204			:FPS AFTER EXECUTION.	
4559	026374	104070			8\$:	ERROR	+70				
4560	026376	000401				BR	9\$				
4561	026400	104100				ERROR	+100			:ST 526 BAD SIGN	
4562	026402				9\$:						

```

4563
4564 ;MODD TEST WITH EXPONENT OF THE RESULT = 57
4565 HHH6:
      LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4566 026402 104413 JSR PC,@#MODDSUB
4567 026404 004737 027406 .WORD 56200,0,0,1 ;AC
      026410 056200 000000 000000 1$:
      026416 000001 .WORD 40340,0,0,0 ;FSRC
4568 026420 040340 000000 000000 2$:
      026426 000000 .WORD 0,0,0,0 ;FRACTIONAL RES.
4569 026430 000000 000000 000000 3$:
      026436 000000 .WORD 56340,0,0,1 ;INTEGER RES.
4570 026440 056340 000000 000000 4$:
      026446 000001 .WORD 40000,0,0,0 ;ERROR FRACTIONAL RES.
4571 026450 040000 000000 000000 5$:
      026456 000000 .WORD 56340,0,0,1 ;ERROR INTEGER RES.
4572 026460 056340 000000 000000 6$:
      026466 000001 7$: 213 ;FPS BEFORE EXECUTION.
4573 026470 000213 204 ;FPS AFTER EXECUTION.
4574 026472 000204 8$: ERROR +101 ;CONSTANT BAD (NOT 56)
4575 026474 104101 9$: BR 9$ ;OR ST 525 TO 050 INTO 150
      000000 ERROR +101
4576
4577 026476 000401
4578 026500 104101
4579 026502
4580
4581

```

```

4582 ;MODD TEST WITH EXPONENT OF THE RESULT = 56
      HHH7:
      LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4583 026502 104413 JSR PC,@#MODDSUB
4584 026504 004737 027406 .WORD 56000,0,0,1 ;AC
      026510 056000 000000 000000 1$:
      026516 000001 .WORD 40340,0,0,0 ;FSRC
4585 026520 040340 000000 000000 2$:
      026526 000000 .WORD 40100,0,0,0 ;FRACTIONAL RES.
4586 026530 040100 000000 000000 3$:
      026536 000000 .WORD 56140,0,0,1 ;INTEGER RES.
4587 026540 056140 000000 000000 4$:
      026546 000001 .WORD 0,0,0,0 ;ERROR FRACTIONAL RES.
4588 026550 000000 000000 000000 5$:
      026556 000000 .WORD 56140,0,0,1 ;ERROR INTEGER RES.
4589 026560 056140 000000 000000 6$:
      026566 000001 7$: 213 ;FPS BEFORE EXECUTION.
4590 026570 000213

```

```

4592 026572 000200          200          ;FPS AFTER EXECUTION.
4593 026574 104102      8$:  ERROR  +102      ;BAD CONSTANT (NOT 56) OR
4594                                     BR      9$          ;ST 525 TO 150 INTO 050
4595 026576 000401          BR      9$
4596 026600 104102      9$:  ERROR  +102
4597 026602
4598
4599      ;MODD TEST WITH EXPONENT OF THE RESULT = 36
4600 026602      HHH8:
      026602 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4601 026604 004737 027406          JSR      PC,@#MODDSUB
4602 026610 051177 177777 177777 1$:  .WORD  51177,-1,-1,-1 ;AC
      026616 177777
4603 026620 040200 000000 000000 2$:  .WORD  40200,0,0,0 ;FSRC
      026626 000000
4604 026630 040177 177760 000000 3$:  .WORD  40177,-20,0,0 ;FRACTIONAL RES.
      026636 000000
4605 026640 051177 177777 177760 4$:  .WORD  51177,-1,-20,0 ;INTEGER RES.
      026646 000000
4606 026650 177777 177777 177777 5$:  .WORD  -1,-1,-1,-1 ;ERROR FRACTIONAL RES.
      026656 177777
4607 026660 177777 177777 177777 6$:  .WORD  -1,-1,-1,-1 ;ERROR INTEGER RES.
      026666 177777
4608 026670 000217          7$:  217          ;FPS BEFORE EXECUTION.
4609 026672 000200          200          ;FPS AFTER EXECUTION.
4610 026674 104070      8$:  ERROR  +70
4611 026676 000401          BR      9$
4612 026700 104071      9$:  ERROR  +71
4613 026702
4614
4615      ;MODD TEST WITH EXPONENT OF THE RESULT = 30
4616 026702      HHH9:
      026702 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4617 026704 004737 027406          JSR      PC,@#MODDSUB
4618 026710 040200 000000 000000 1$:  .WORD  40200,0,0,0 ;AC
      026716 000000
4619 026720 047577 177777          2$:  .WORD  47577,-1 ;FSRC
4620 026724 176000 000001          .WORD  176000,1
4621 026730 031600 000000 000000 3$:  .WORD  31600,0,0,0 ;FRACTIONAL RES.
      026736 000000
4622 026740 047577 177777          4$:  .WORD  47577,-1 ;INTEGER RES.
4623 026744 176000 000000          .WORD  176000,0
4624 026750 000000 000000 000000 5$:  .WORD  0,0,0,0 ;ERROR FRACTIONAL RES.
      026756 000000
4625 026760 047577 177777 177777 6$:  .WORD  47577,-1,-1,-1 ;ERROR INTEGER RES.
      026766 177777
4626 026770 000200          7$:  200          ;FPS BEFORE EXECUTION.
4627 026772 000200          200          ;FPS AFTER EXECUTION.
4628 026774 104103      8$:  ERROR  +103      ;(NORMALIZE) ST 532 TO 122
4629                                     ;INTO NORM.
4630 026776 000401          BR      9$
4631 027000 104104      9$:  ERROR  +104      ;AC V 1 <= X14
4632                                     ;OR ST 733 TO 156 INTO 157.
4633 027002
4634
4635      ;MODD TEST WITH EXPONENT OF THE RESULT = 31
4636 027002      HHH10:
  
```

```

4637 027002 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4637 027004 004737 027406   JSR          PC,@#MODDSUB
4638 027010 047777 177777   1$: .WORD     47777,-1      ;AC
4639 027014 177000 000000   .WORD     177000,0
4640 027020 040200 000000 000000 2$: .WORD     40200,0,0,0    ;FSRC
4641 027026 000000          .WORD     0,0,0,0        ;FRACTIONAL RES.
4641 027030 000000 000000 000000 3$: .WORD     0,0,0,0        ;INTEGER RES.
4642 027036 000000          .WORD     47777,-1
4642 027040 047777 177777   4$: .WORD     177000,0
4643 027044 177000 000000   .WORD     0,0,177000,0  ;ERROR FRACTIONAL RES.
4644 027050 000000 000000 177000 5$: .WORD     -1,-1,-1,-1   ;ERROR INTEGER RES.
4645 027056 000000 177777 177777 6$: .WORD     213
4646 027060 177777 177777 177777 7$: .WORD     204
4647 027070 000213          .WORD     +105          ;FPS BEFORE EXECUTION.
4648 027072 000204          .WORD     9$           ;FPS AFTER EXECUTION.
4649 027074 104105          .WORD     +71          ;(BUT FD) STORE X10
4650 027076 000401          .WORD     +71
4651 027100 104071          .WORD     +71
4652 027102          .WORD     +71
4653          .WORD     +71
4654          .WORD     +71

```

;MODD TEST WITH EXPONENT OF THE RESULT = 0  
 HHH11:

```

4655 027102 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4655 027104 004737 027406   JSR          PC,@#MODDSUB
4656 027110 040200 000000 000000 1$: .WORD     40200,0,0,0    ;AC
4657 027116 000000          .WORD     40177,72727   ;FSRC
4657 027120 040177 072727   2$: .WORD     127272,72727
4658 027124 127272 072727   .WORD     40177,72727   ;FRACTIONAL RES.
4659 027130 040177 072727   3$: .WORD     127272,72727
4660 027134 127272 072727   .WORD     0,0,0,0        ;INTEGER RES.
4661 027140 000000 000000 000000 4$: .WORD     -1,-1,-1,-1   ;ERROR FRACTIONAL RES.
4662 027146 000000 177777 177777 5$: .WORD     0,0,-1,-1    ;ERROR INTEGER RES.
4663 027150 177777 177777 177777 6$: .WORD     200
4664 027156 177777 177777 177777 7$: .WORD     200
4665 027160 000000 000000 177777 8$: .WORD     +70
4666 027166 177777          .WORD     9$
4667 027170 000200          .WORD     +106
4668 027172 000200          .WORD     +106
4669 027174 104070          .WORD     +106
4670 027176 000401          .WORD     +106
4671 027200 104106          .WORD     +106
4672 027202          .WORD     +106
4673          .WORD     +106
4674          .WORD     +106
4675          .WORD     +106
4676          .WORD     +106
4677          .WORD     +106
4678          .WORD     +106
4679          .WORD     +106
4680          .WORD     +106

```

;MODD TEST WITH EXPONENT OF THE RESULT = -115  
 HHH12:

```

4673 027202 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4673 027204 004737 027406   JSR          PC,@#MODDSUB
4674 027210 003377 177777   1$: .WORD     3377,-1      ;AC
4675 027214 177777 052525   .WORD     -1,52525
4676 027220 040200 000000 000000 2$: .WORD     40200,0,0,0    ;FSRC
4677 027226 000000          .WORD     3377,-1        ;FRACTIONAL RES.
4678 027230 003377 177777   3$: .WORD     -1,52525
4679 027234 177777 052525   .WORD     0,0,0,0        ;INTEGER RES.
4680 027240 000000 000000 000000 4$: .WORD     -1,-1,-1,-1   ;ERROR FRACTIONAL RES.
4681 027246 000000 177777 177777 5$: .WORD     -1,-1,-1,-1

```

```

4681 027256 177777
      027260 000000 000000 177777 6$: .WORD 0,0,-1,-1 ;ERROR INTEGER RES.
      027266 177777
4682 027270 000200 7$: 200 ;FPS BEFORE EXECUTION.
4683 027272 000200 200 ;FPS AFTER EXECUTION.
4684 027274 104070 8$: ERROR +70
4685 027276 000401 BR 9$
4686 027300 104107 ERROR +107 ;ST 446 TO 126 INTO 127 (BUT FD)
4687 027302 9$:
4688
4689
  
```

```

4690 027302 ;MODD TEST WITH EXPONENT OF THE RESULT = -63, IN ROUND MODE.
      027302 104413 HHH13:
4691 027304 004737 027406 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
4692 027310 040300 000000 000000 1$: JSR PC,@#MODDSUB
      027316 000000 .WORD 40300,0,0,0 ;AC
4693 027320 020200 000000 000000 2$: .WORD 20200,0,0,1 ;FSRC
      027326 000001 .WORD 20300,0,0,2 ;FRACTIONAL RES.
4694 027330 020300 000000 000000 3$: .WORD 20300,0,0,2 ;FRACTIONAL RES.
      027336 000002 .WORD 0,0,0,0 ;INTEGER RES.
4695 027340 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
      027346 000000 .WORD 0,0,-1,-1 ;ERROR FRACTIONAL RES.
4696 027350 000000 000000 177777 5$: .WORD 0,0,-1,-1 ;ERROR FRACTIONAL RES.
      027356 177777
4697 027360 177777 177777 177777 6$: .WORD -1,-1,-1,-1 ;ERROR INTEGER RES.
      027366 177777
4698 027370 000200 7$: 200 ;FPS BEFORE EXECUTION.
4699 027372 000200 200 ;FPS AFTER EXECUTION.
4700 027374 104110 8$: ERROR +110 ;ST 127 INTO RND/TR
4701 027376 000401 BR 9$
4702 027400 104071 ERROR +71
4703 027402 000137 030004 9$: JMP @#HHHDONE ;GO TO THE NEXT TEST.
4704
4705
  
```

```

;THIS SUBROUTINE, MODDSUB, IS CALLED TO SETUP THE
;OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
;IT IS CALLED THUS:
  
```

```

:
: ACARG: .WORD X,X,X,X ;AC OPERAND
: FSRCARG: .WORD X,X,X,X ;FSRC OPERAND
: FRES: .WORD X,X,X,X ;FRACTIONAL RESULT
: INTRES: .WORD X,X,X,X ;INTEGER RESULT
: ERFRES: .WORD X,X,X,X ;ERROR FRACTION RESULT
: ERINTRES: .WORD X,X,X,X ;ERROR INTEGER RESULT
: FPSB: .WORD X ;FPS BEFORE EXECUTION
: FPSA: .WORD X ;FPS AFTER EXECUTION
: ERR1: ERROR +X ;FRACTION ERROR
: BR CONT
: ERR2: ERROR +X ;INTEGER ERROR
: CONT: ;RETURN ADDRESS
  
```

```

;THE OPERANDS ARE SET UP (USING AC0 FOR THE AC ARGUMENT). THE MODD
;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
;THEN MODDSUB WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
  
```

4704  
4705  
4706  
4707  
4708  
4709  
4710  
4711  
4712  
4713  
4714  
4715  
4716  
4717  
4718  
4719  
4720  
4721  
4722  
4723  
4724  
4725  
4726  
4727  
4728



4729 :THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH  
 4730 :THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED  
 4731 :FAILURE MATCHES THE TRUE RESULT THEN MODDSUB PASSES CONTROL TO THE  
 4732 :ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS  
 4733 :NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER  
 4734 :FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.  
 4735 :IF A MATCH IS MADE HOWEVER, MODDSUB WILL RETURN CONTROL TO THE ERROR  
 4736 :CALL AT ERR2.  
 4737

```

4738 027406 012601 MODDSUB: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS
4739 027410 012700 000200 MOV #200,R0 ;SET FD MODE.
4740 027414 170100 LDFPS R0
4741 027416 010100 MOV R1,R0 ;SET UP ACO
4742 027420 172410 LDD (R0),ACO
4743 027422 012700 025666 MOV #MODP1,R0 ;PUT A BACKGROUND PATTERN INTO AC1.
4744 027426 172510 LDD (R0),AC1
4745 027430 016100 000060 MOV 60(R1),R0 ;SET UP THE FPS.
4746 027434 170100 LDFPS R0
4747 027436 012737 027452 001236 MOV #1$,@#STMP2
4748 027444 010100 MOV R1,R0 ;COMPUTE THE ADDRESS OF THE FSRC.
4749 027446 062700 000010 ADD #10,R0
4750
4751 027452 171410 1$: MODD (R0),ACO ;EXECUTE THE TEST INSTRUCTION.
4752
4753 027454 170204 STFPS R4 ;GET THE FPS.
4754 027456 012700 000200 MOV #200,R0 ;SET FD MODE.
4755 027462 170100 LDFPS R0
4756 027464 012700 027764 MOV #MODDT0,R0 ;GET THE FRACTIONAL RESULT.
4757 027470 174010 STD ACO,(R0)
4758 027472 012700 027774 MOV #MODDT1,R0 ;GET THE INTEGER RESULT.
4759 027476 174110 STD AC1,(R0)
4760
4761 027500 010102 MOV R1,R2 ;SAVE THE DATA IN CASE OF ERROR.
4762 027502 010237 001240 MOV R2,@#STMP3
4763 027506 062702 000010 ADD #10,R2
4764 027512 010237 001242 MOV R2,@#STMP4
4765 027516 062702 000010 ADD #10,R2
4766 027522 010237 001244 MOV R2,@#STMP5
4767 027526 062702 000010 ADD #10,R2
4768 027532 010237 001246 MOV R2,@#STMP6
4769 027536 012737 027764 001250 MOV #MODDT0,@#STMP7
4770 027544 012737 027774 001252 MOV #MODDT1,@#STMP10
4771 027552 016137 000062 001256 MOV 62(R1),@#STMP12
4772 027560 010437 001254 MOV R4,@#STMP11
4773
4774 027564 012702 027764 MOV #MODDT0,R2 ;CHECK THE FRACTIONAL RESULT.
4775 027570 010103 MOV R1,R3
4776 027572 062703 000020 ADD #20,R3
4777 027576 012705 000004 MOV #4,R5
4778 027602 022223 2$: CMP (R2)+,(R3)+ ;BRANCH IF INCORRECT.
4779 027604 001020 BNE 10$
4780 027606 077503 SOB R5,2$
4781
4782 027610 012702 027774 MOV #MODDT1,R2 ;CHECK THE INTEGER RESULT.
4783 027614 010103 MOV R1,R3
4784 027616 062703 000030 ADD #30,R3
4785 027622 012705 000004 MOV #4,R5
  
```

```

4786 027626 022223      3$:    CMP      (R2)+,(R3)+
4787 027630 001026      BNE      15$      ;BRANCH IF INCORRECT.
4788 027632 077503      SOB      R5,3$
4789
4790
4791 027634 026104 000062      CMP      62(R1),R4      ;CHECK THE FPS.
4792 027640 001042      BNE      20$      ;BRANCH IF INCORRECT.
4793
4794 027642 000161 000072      9$:    JMP      72(R1)      ;RETURN.
4795
4796      ;FRACTIONAL ERROR.
4797 027646 012702 027764      10$:   MOV      #MODDT0,R2      ;WAS THE FRACTIONAL ERROR ANTICIPATED?
4798 027652 010103      MOV      R1,R3
4799 027654 062703 000040      ADD      #40,R3
4800 027660 012705 000004      MOV      #4,R5
4801 027664 022223      50$:   CMP      (R2)+,(R3)+
4802 027666 001005      BNE      11$      ;BRANCH IF NOT ANTICIPATED.
4803 027670 077503      SOB      R5,50$
4804 027672 010102      MOV      R1,R2      ;THE ERROR WAS ANTICIPATED SO
4805 027674 062702 000064      ADD      #64,R2      ;RETURN TO THE ERROR REPORT AT THE
4806      ;CALLING ROUTINE.
4807 027700 000112      JMP      (R2)
4808
4809 027702      11$:
4810 027702 104070      12$:   ERROR   +70      ;THE ERROR WAS NOT ANTICIPATED SO
4811 027704 000756      BR      9$      ;REPORT THE INCORRECT FRACTION HERE.
4812
4813      ;INTEGER ERROR.
4814 027706 012702 027774      15$:   MOV      #MODDT1,R2      ;WAS THE INTEGER ERROR ANTICIPATED?
4815 027712 010103      MOV      R1,R3
4816 027714 062703 000050      ADD      #50,R3
4817 027720 012705 -000004      MOV      #4,R5
4818 027724 022223      60$:   CMP      (R2)+,(R3)+
4819 027726 001005      BNE      17$      ;BRANCH IF NOT ANTICIPATED.
4820 027730 077503      SOB      R5,60$
4821 027732 010102      MOV      R1,R2      ;THE ERROR WAS ANTICIPATED SO RETURN
4822 027734 062702 000070      ADD      #70,R2      ;TO THE ERROR REPORT IN THE CALLING
4823      ;ROUTINE.
4824 027740 000112      JMP      (R2)
4825
4826 027742      16$:
4827 027742 104071      17$:   ERROR   +71      ;THE ERROR WAS NOT ANTICIPATED SO REPORT
4828 027744 000736      BR      9$      ;THE INTEGER FAILURE HERE.
4829
4830      ;FPS INCORRECT.
4831 027746 010437 001254      20$:   MOV      R4,@#$TMP11      ;REPORT INCORRECT FPS.
4832 027752 016137 000062 001256      MOV      62(R1),@#$TMP12
4833 027760 104072      21$:   ERROR   +72
4834 027762 000727      BR      9$
4835
4836 027764 000000 000000 000000 MODDT0: .WORD 0,0,0,0
4837 027772 000000
4838 027774 000000 000000 000000 MODDT1: .WORD 0,0,0,0
4839 030002 000000
4840 030004      HHHDONE:
  
```

030004 104412

RSETUP

;GO INITIALIZE THE FPS AND STACK; AND  
 ;SEE IF THE USER HAS EXPRESSED  
 ;THE DESIRE TO CHANGE THE SOFTWARE  
 ;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
 ;THE USER TYPED CONTROL G?).

4841  
 4842  
 4843  
 4851  
 4852  
 4853

;TEST TITLE:UNDER/OVERFLOW, USING MODF WITH TRAPS DISABLED

\*\*\*\*\*  
 ;\*TEST 20 SEE COMMENT ABOVE FOR TEST TITLE

\*\*\*\*\*  
 ;\*THIS IS A TEST OF THE MODF OVERFLOW AND UNDERFLOW CONDITIONS. IT MAKES  
 ;\*USE OF A SUBROUTINE TO SETUP THE OPERANDS, EXECUTE THE MODF INSTRUCTION  
 ;\*AND CHECK THE RESULTS. TRAPS ARE DISABLED DURING THIS TEST.  
 ;\*

\*\*\*\*\*

030006 000004

4854  
 4855  
 4856  
 4857  
 4858  
 4859  
 4860  
 4861  
 4862  
 4863  
 4864  
 4865  
 4866  
 4867  
 4868  
 4869  
 4870  
 4871

TST20: SCOPE

;UNDERFLOW TEST, WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1

MMM1:

LPERR ;SET UP THE LOOP ON ERROR ADDRESS.

JSR PC,MODFOV

1\$: .WORD 20123,45676 ;AC

2\$: .WORD 20200,0 ;FSRC

3\$: .WORD 123,45676 ;FRACTIONAL RES.

4\$: .WORD 0,0 ;INTEGER RES.

5\$: .WORD -1,-1 ;ERROR FRACTIONAL RES.

6\$: .WORD -1,-1 ;ERROR INTEGER RES.

7\$: 42000 ;FPS BEFORE EXECUTION.

142004 ;FPS AFTER EXECUTION.

12 ;FEC

8\$: ERROR +170 ;FEC INCORRECT, UNDERFLOW.

BR 9\$

9\$: ERROR +171 ;AC V 1 (2,3) <= ZERO, ST 126.

;UNDERFLOW EXP OF RESULT = -193, FIU = 0, FID = 1

MMM2:

LPERR ;SET UP THE LOOP ON ERROR ADDRESS.

JSR PC,@MODFOV

1\$: .WORD 10200,0 ;AC

2\$: .WORD 10000,0 ;FSRC

3\$: .WORD 0,0 ;FRACTIONAL RES.

4\$: .WORD 0,0 ;INTEGER RES.

5\$: .WORD -1,-1 ;ERROR FRACTIONAL RES.

6\$: .WORD -1,-1 ;ERROR INTEGER RES.

7\$: 5013 ;FPS BEFORE EXECUTION.

5004 ;FPS AFTER EXECUTION.

12 ;FEC

8\$: NOP

BR 9\$

9\$: ERROR +171

4872  
 4873  
 4874  
 4875  
 4876  
 4877  
 4878  
 4879  
 4880  
 4881  
 4882  
 4883  
 4884  
 4885  
 4886  
 4887  
 4888  
 4889

;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1

```

4890 030134          MMM3:
      030134 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4891 030136 004737 030336  JSR          PC,@#MODFOV
4892 030142 060052 125252  1$: .WORD    60052,125252  ;AC
4893 030146 060200 000000  2$: .WORD    60200,0      ;FSRC
4894 030152 000000 000000  3$: .WORD    0,0         ;FRACTIONAL RES.
4895 030156 000052 125252  4$: .WORD    52,125252   ;INTEGER RES.
4896 030162 000000 000000  5$: .WORD    0,0         ;ERROR FRACTIONAL RES.
4897 030166 000000 000000  6$: .WORD    0,0         ;ERROR INTEGER RES.
4898 030172 041000          7$: 41000          ;FPS BEFORE EXECUTION.
4899 030174 141006          141006        ;FPS AFTER EXECUTION.
4900 030176 000010          10           ;FEC
4901 030200 104172  8$: ERROR    +172      ;BAD FEC ON OVERFLOW.
4902 030202 000401          BR          9$
4903 030204 104173          ERROR    +173      ;ST 520 TO STORE ZERO TWICE
4904                                     ;INTO 162
4905 030206  9$:
4906
4907 ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
4908 030206          MMM4:
      030206 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4909 030210 004737 030336  JSR          PC,@#MODFOV
4910 030214 060345 067654  1$: .WORD    60345,67654  ;AC
4911 030220 060200 000000  2$: .WORD    60200,0      ;FSRC
4912 030224 000000 000000  3$: .WORD    0,0         ;FRACTIONAL RES.
4913 030230 000000 000000  4$: .WORD    0,0         ;INTEGER RES.
4914 030234 000000 000000  5$: .WORD    0,0         ;ERROR FRACTIONAL RES.
4915 030240 000345 067654  6$: .WORD    345,67654   ;ERROR INTEGER RES.
4916 030244 006011          7$: 6011          ;FPS BEFORE EXECUTION.
4917 030246 006006          6006          ;FPS AFTER EXECUTION.
4918 030250 000010          10           ;FEC
4919 030252 000240  8$: NOP
4920 030254 000401          BR          9$
4921 030256 104174          ERROR    +174      ;ST 520 TO 162 INTO STORE ZERO TWICE.
4922 030260  9$:
4923
4924 ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, RESULT NEGATIVE
4925 ;AND FIV = 1, FID = 1
4926 030260          MMM5:
      030260 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
4927 030262 004737 030336  JSR          PC,@#MODFOV
4928 030266 160252 125252  1$: .WORD    160252,125252 ;AC
4929 030272 060000 000000  2$: .WORD    60000,0      ;FSRC
4930 030276 000000 000000  3$: .WORD    0,0         ;FRACTIONAL RES.
4931 030302 100052 125252  4$: .WORD    100052,125252 ;INTEGER RES.
4932 030306 000000 000000  5$: .WORD    0,0         ;ERROR FRACTIONAL RES.
4933 030312 000052 125252  6$: .WORD    52,125252   ;ERROR INTEGER RES.
4934 030316 041000          7$: 41000          ;FPS BEFORE EXECUTION.
4935 030320 141006          141006        ;FPS AFTER EXECUTION.
4936 030322 000010          10           ;FEC
4937 030324 104172  8$: ERROR    +172
4938 030326 000401          BR          9$
4939 030330 104175          ERROR    +175      ;ST 517, BAD SIGN.
4940 030332 000137 030732  9$: JMP          @#MMMDONE  ;GO TO THE NEXT TEST.
4941
4942 ;THIS SUBROUTINE, MODFOV, IS CALLED TO SETUP THE
4943 ;OPERANDS, EXECUTE THE MODF INSTRUCTION AND CHECK THE RESULTS.

```

```

4944      ;IT IS CALLED THUS:
4945      :
4946      :          ACARG: .WORD  X,X          ;AC OPERAND
4947      :          FSRCARG: .WORD X,X          ;FSRC OPERAND
4948      :          FRES: .WORD  X,X          ;FRACTIONAL RESULT
4949      :          INTRES: .WORD  X,X          ;INTEGER RESULT
4950      :          ERFRES: .WORD  X,X          ;ERROR FRACTION RESULT
4951      :          ERINTRES: .WORD X,X          ;ERROR INTEGER RESULT
4952      :          FPSB: .WORD  X             ;FPS BEFORE EXECUTION
4953      :          FPSA: .WORD  X             ;FPS AFTER EXECUTION
4954      :          FEC: .WORD  X             ;FEC
4955      :          ERR1: ERROR  +X            ;FEC ERROR
4956      :          BR      CONT              ;
4957      :          ERR2: ERROR  +X            ;INTEGER ERROR
4958      :          CONT:                    ;RETURN ADDRESS
4959      :
4960      :THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODF
4961      :INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
4962      :THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
4963      :THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
4964      :THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
4965      :THEN MODFOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
4966      :IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
4967      :THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
4968      :THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
4969      :FAILURE MATCHES THE TRUE RESULT THEN MODFOV PASSES CONTROL TO THE
4970      :ERROR CALL AT ERR1. LIKewise IF THE INTEGER PART OF THE RESULT IS
4971      :NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
4972      :FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
4973      :IF A MATCH IS MADE HOWEVER, MODFOV WILL RETURN CONTROL TO THE ERROR
4974      :CALL AT ERR2.
4975

```

```

4976 030336 012601      MODFOV: MOV      (SP)+,R1      ;GET A POINTER TO THE ARGUMENTS
4977 030340 012700 000200      MOV      #200,R0      ;SET FD MODE.
4978 030344 170100      LDFPS   R0
4979 030346 010100      MOV      R1,R0      ;SET UP ACO
4980 030350 172410      LDD     (R0),ACO
4981 030352 012700 025666      MOV      #MODP1,R0      ;PUT A BACKROUND PATTERN INTO AC1.
4982 030356 172510      LDD     (R0),AC1
4983 030360 016100 000030      MOV      30(R1),R0      ;SET UP THE FPS.
4984 030364 170100      LDFPS   R0
4985 030366 012737 030402 001236      MOV      #1$,@#$TMP2
4986 030374 010100      MOV      R1,I0      ;COMPUTE THE ADDRESS OF THE FSRC.
4987 030376 062700 000004      ADD     #4,R0
4988
4989 030402 171410      1$:   MODF   (R0),ACO      ;EXECUTE THE TEST INSTRUCTION.
4990
4991 030404 170204      STFPS   R4      ;GET THE FPS.
4992 030406 170305      STST   R5      ;GET FEC.
4993 030410 012700 000200      MOV      #200,R0      ;SET FD MODE.
4994 030414 170100      LDFPS   R0
4995 030416 012700 030712      MOV      #MODFDO,R0      ;GET THE FRACTIONAL RESULT.
4996 030422 174010      STD     ACO,(R0)
4997 030424 012700 030722      MOV      #MODFD1,R0      ;GET THE INTEGER RESULT.
4998 030430 174110      STD     AC1,(R0)
4999
5000 030432 010102      MOV      R1,R2      ;SAVE THE DATA IN CASE OF ERROR.

```

5001	030434	010237	001240		MOV	R2,@#STMP3	
5002	030440	062702	000004		ADD	#4,R2	
5003	030444	010237	001242		MOV	R2,@#STMP4	
5004	030450	062702	000004		ADD	#4,R2	
5005	030454	010237	001244		MOV	R2,@#STMP5	
5006	030460	062702	000004		ADD	#4,R2	
5007	030464	010237	001246		MOV	R2,@#STMP6	
5008	030470	012737	030712	001250	MOV	#MODFD0,@#STMP7	
5009	030476	012737	030722	001252	MOV	#MODFD1,@#STMP10	
5010	030504	010437	001254		MOV	R4,@#STMP11	
5011	030510	016137	000032	001256	MOV	32(R1),@#STMP12	
5012	030516	010537	001260		MOV	R5,@#STMP13	
5013	030522	016137	000034	001262	MOV	34(R1),@#STMP14	
5014							
5015	030530	012702	030712		MOV	#MODFD0,R2	;CHECK THE FRACTIONAL RESULT.
5016	030534	026112	000010		CMP	10(R1),(R2)	
5017	030540	001025			BNE	10\$	;BRANCH IF INCORRECT.
5018	030542	026162	000012	000002	CMP	12(R1),2(R2)	
5019	030550	001021			BNE	10\$	
5020							
5021	030552	012702	030722		MOV	#MODFD1,R2	;CHECK THE INTEGER RESULT.
5022	030556	026112	000014		CMP	14(R1),(R2)	
5023	030562	001016			BNE	15\$	;BRANCH IF INCORRECT.
5024	030564	026162	000016	000002	CMP	16(R1),2(R2)	
5025	030572	001012			BNE	15\$	
5026							
5027	030574	026104	000032		CMP	32(R1),R4	;CHECK THE FPS.
5028	030600	001024			BNE	20\$	;BRANCH IF INCORRECT.
5029							
5030	030602	026105	000034		CMP	34(R1),R5	;CHECK THE FEC.
5031	030606	001030			BNE	25\$	;BRANCH IF INCORRECT.
5032							
5033	030610	000161	000044		JMP	44(R1)	;RETURN.
5034							
5035							;FRACTIONAL ERROR.
5036	030614				10\$:		;THE ERROR WAS NOT ANTICIPATED SO
5037	030614	104165			12\$:	ERROR +165	;REPORT THE INCORRECT FRACTION HERE.
5038	030616	000774				BR 9\$	
5039							
5040							;INTEGER ERROR.
5041	030620	026112	000024		15\$:	CMP 24(R1),(R2)	;WAS THIS ERROR ANTICIPATED?
5042	030624	001010				BNE 16\$	;BRANCH IF NOT.
5043	030626	026162	000026	000002		CMP 26(R1),2(R2)	
5044	030634	001004				BNE 16\$	
5045	030636	010102				MOV R1,R2	;THE ERROR WAS ANTICIPATED SO RETURN
5046	030640	062702	000042			ADD #42,R2	;TO THE ERROR REPORT IN THE CALLING
5047							;ROUTINE.
5048	030644	000112				JMP (R2)	
5049							
5050	030646				16\$:		;THE ERROR WAS NOT ANTICIPATED SO REPORT
5051	030646	104166			17\$:	ERROR +166	;THE INTEGER FAILURE HERE.
5052	030650	000757				BR 9\$	
5053							
5054							;FPS INCORRECT.
5055	030652	010437	001254		20\$:	MOV R4,@#STMP11	;REPORT INCORRECT FPS.
5056	030656	016137	000032	001256		MOV 32(R1),@#STMP12	
5057	030664	104167			21\$:	ERROR +167	

```

5058 030666 000750 BR 9$
5059
5060 :REPORT FEC ERROR.
5061 030670 010537 001260 25$: MOV R5,@#$TMP13
5062 030674 016137 000034 001262 MOV 34(R1),@#$TMP14
5063 030702 010102 MOV R1,R2
5064 030704 062702 000036 ADD #36,R2
5065 030710 000112 JMP (R2)
5066
5067 030712 000000 000000 000000 MODFD0: .WORD 0,0,0,0
030720 000000
5068
5069 030722 000000 000000 000000 MODFD1: .WORD 0,0,0,0
030730 000000
5070
5071 030732 MMDONE:
030732 104412 RSETUP
  
```

```

;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).
  
```

5072  
5073  
5074  
5082  
5083  
5084

```

;TEST TITLE:UNDER/OVERFLOW, USING MODD WITH TRAPS DISABLED
;*****
;*TEST 21 SEE COMMENT ABOVE FOR TEST TITLE
;*
;*THIS IS A TEST OF THE MODD INSTRUCTION'S OVER FLOW AND UNDER FLOW
;*CONDITIONS. A SUBROUTINE IS USED TO SET UP THE OPERANDS, EXECUTE THE
;*MODD INSTUCTION AND CHECK THE RESULTS.
;*
;*****
TST21: SCOPE
  
```

```

030734 000004
5085
5086 ;UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -129, FIU = 1, FID = 1
5087 030736 NNN1:
030736 104413 LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
5088 030740 004737 031352 JSR PC,@#MODDOV
5089 030744 020252 125252 1$: .WORD 20252,125252 ;AC
5090 030750 125252 125252 .WORD 125252,125252
5091 030754 020100 000000 000000 2$: .WORD 20100,0,0,0 ;FSRC
030762 000000
5092 030764 000177 177777 177777 3$: .WORD 177,-1,-1,-1 ;FRACTIONAL RES.
030772 177777
5093 030774 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
031002 000000
5094 031004 020252 125252 5$: .WORD 20252,125252 ;ERROR FRACTIONAL RES.
5095 031010 125252 125252 .WORD 125252,125252
5096 031014 000000 000000 177777 6$: .WORD 0,0,-1,-1 ;ERROR INTEGER RES.
031022 177777
5097 031024 042200 7$: 42200 ;FPS BEFORE EXECUTION.
5098 031026 142204 142204 ;FPS AFTER EXECUTION.
5099 031030 000012 12 ;FEC
5100 031032 104201 8$: ERROR +201 ;FEC INCORRECT ON UNDERFLOW.
5101 031034 000401 BR 9$
  
```

```

5102 031036 104202          ERROR +202          ;ST 155 (BUT FD)
5103 031040          9$:
5104
5105          ;UNDERFLOW TEST WITH EXPONENT OF THE RESULT = -193, FIU = 0, FID = 1
5106 031040          NNN2:
      031040 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5107 031042 004737 031352  JSR          PC,@#MODDOV
5108 031046 010000 000000  1$: .WORD 10000,0          ;AC
5109 031052 123456 000000  .WORD 123456,0
5110 031056 010200 000000 000000 2$: .WORD 10200,0,0,0          ;FSRC
      031064 000000
5111 031066 000000 000000 000000 3$: .WORD 0,0,0,0          ;FRACTIONAL RES.
      031074 000000
5112 031076 000000 000000 000000 4$: .WORD 0,0,0,0          ;INTEGER RES.
      031104 000000
5113 031106 000000 000000 000000 5$: .WORD 0,0,0,0          ;ERROR FRACTIONAL RES.
      031114 000000
5114 031116 000000 000000          6$: .WORD 0,0          ;ERROR INTEGER RES.
5115 031122 123456 000000          .WORD 123456,0
5116 031126 005213          7$: 5213          ;FPS BEFORE EXECUTION.
5117 031130 005204          5204          ;FPS AFTER EXECUTION.
5118 031132 000012          12
5119 031134 000240          8$: NOP
5120 031136 000401          BR 9$
5121 031140 104203          ERROR +203          ;ST 047 (BUT FD).
5122 031142          9$:
5123
5124          ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 128, FIV = 1, FID = 1
5125 031142          NNN3:
      031142 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5126 031144 004737 031352  JSR          PC,@#MODDOV
5127 031150 060252 125252  1$: .WORD 60252,125252          ;AC
5128 031154 125252 125252  .WORD 125252,125252
5129 031160 060100 000000 000000 2$: .WORD 60100,0,0,0          ;FSRC
      031166 000000
5130 031170 000000 000000 000000 3$: .WORD 0,0,0,0          ;FRACTIONAL RES.
      031176 000000
5131 031200 000177 177777 177777 4$: .WORD 177,-1,-1,-1          ;INTEGER RES.
      031206 177777
5132 031210 000000 000000 000000 5$: .WORD 0,0,0,0          ;ERROR FRACTIONAL RES.
      031216 000000
5133 031220 000177 177777          6$: .WORD 177,-1          ;ERROR INTEGER RES.
5134 031224 125252 125252          .WORD 125252,125252
5135 031230 041200          7$: 41200          ;FPS BEFORE EXECUTION.
5136 031232 141206          141206          ;FPS AFTER EXECUTION.
5137 031234 000010          10          ;FEC
5138 031236 104204          8$: ERROR +204          ;FEC BAD ON OVERFLOW.
5139 031240 000401          BR 9$
5140 031242 104205          ERROR +205          ;ST 520 TO 162 INTO 163 (BUT FD).
5141 031244          9$:
5142
5143          ;OVERFLOW TEST WITH EXPONENT OF THE RESULT = 130, FIV = 0, FID = 1
5144 031244          NNN4:
      031244 104413          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5145 031246 004737 031352  JSR          PC,@#MODDOV
5146 031252 060200 000000  1$: .WORD 60200,0          ;AC
5147 031256 125252 000000          .WORD 125252,0
  
```



```

5148 031262 060200 000000 000000 2$: .WORD 60200,0,0,0 ;FSRC
      031270 000000
5149 031272 000000 000000 000000 3$: .WORD 0,0,0,0 ;FRACTIONAL RES.
      031300 000000
5150 031302 000000 000000 000000 4$: .WORD 0,0,0,0 ;INTEGER RES.
      031310 000000
5151 031312 000000 000000 000000 5$: .WORD 0,0,0,0 ;ERROR FRACTIONAL RES.
      031320 000000
5152 031322 000400 000000 6$: .WORD 400,0 ;ERROR INTEGER RES.
5153 031326 125252 000000 .WORD 125252,0
5154 031332 006211 7$: 6211 ;FPS BEFORE EXECUTION.
5155 031334 006206 6206 ;FPS AFTER EXECUTION.
5156 031336 000010 10 ;FEC
5157 031340 000240 8$: NOP
5158 031342 000401 BR 9$
5159 031344 104206 ERROR +206 ;ST 520 TO 162 INTO STORE ZERO TWICE.
5160 031346 000137 031760 9$: JMP @MNNNDONE ;GO TO NEXT TEST.

```

```

5161
5162 ;THIS SUBROUTINE, MODDOV, IS CALLED TO SETUP THE
5163 ;OPERANDS, EXECUTE THE MODD INSTRUCTION AND CHECK THE RESULTS.
5164 ;IT IS CALLED THUS:
5165

```

```

5166 :
5167 :
5168 :
5169 :
5170 :
5171 :
5172 :
5173 :
5174 :
5175 :
5176 :
5177 :
5178 :
5179 :
5180 :
5181 :
5182 :
5183 :
5184 :
5185 :
5186 :
5187 :
5188 :
5189 :
5190 :
5191 :
5192 :
5193 :
5194 :

```

ACARG:	.WORD	X,X,X,X	;AC OPERAND
FSRCARG:	.WORD	X,X,X,X	;FSRC OPERAND
FRES:	.WORD	X,X,X,X	;FRACTIONAL RESULT
INTRES:	.WORD	X,X,X,X	;INTEGER RESULT
ERFRES:	.WORD	X,X,X,X	;ERROR FRACTION RESULT
ERINTRES:	.WORD	X,X,X,X	;ERROR INTEGER RESULT
FPSB:	.WORD	X	;FPS BEFORE EXECUTION
FPSA:	.WORD	X	;FPS AFTER EXECUTION
ERR1:	ERROR	+X	;FRACTION ERROR
		BR	
ERR2:	ERROR	+X	;INTEGER ERROR
CONT:			;RETURN ADDRESS

```

5180 ;THE OPERANDS ARE SET UP (USING ACO FOR THE AC ARGUMENT). THE MODD
5181 ;INSTRUCTION IS EXECUTED. THEN THE RESULTS ARE RETRIEVED.
5182 ;THE FRACTION PART OF THE RESULT IS COMPARED WITH FRES. IF THIS IS CORRECT
5183 ;THEN THE INTEGER PART IS COMPARED WITH INTRES. IF BOTH OF THESE ARE CORRECT
5184 ;THEN THE FPS IS COMPARED WITH FPSA. AFTER EXECUTION IF NO ERRORS OCCURRED
5185 ;THEN MODDOV WILL RETURN TO CONT. IF THE FPS WAS INCORRECT
5186 ;IT IS REPORTED HERE. IF THE FRACTION IS INCORRECT IT IS COMPARED WITH
5187 ;THE ANTICIPATED BAD FRACTION, ERFRES. IF THIS DOESN'T MATCH
5188 ;THE TRUE RESULT THEN THE ERROR IS REPORTED HERE. IF THE ANTICIPATED
5189 ;FAILURE MATCHES THE TRUE RESULT THEN MODDOV PASSES CONTROL TO THE
5190 ;ERROR CALL AT ERR1. LIKEWISE IF THE INTEGER PART OF THE RESULT IS
5191 ;NOT CORRECT THEN IT IS COMPARED WITH THE ANTICIPATED INTEGER
5192 ;FAILURE. IF THIS DOESN'T MATCH THEN THE ERROR IS REPORTED HERE.
5193 ;IF A MATCH IS MADE HOWEVER, MODDOV WILL RETURN CONTROL TO THE ERROR
5194 ;CALL AT ERR2.

```

```

5195 031352 012601 MODDOV: MOV (SP)+,R1 ;GET A POINTER TO THE ARGUMENTS
5196 031354 012700 000200 MOV #200,R0 ;SET FD MODE.
5197 031360 170100 LDFPS R0
5198 031362 010100 MOV R1,R0 ;SET UP ACO
5199 031364 172410 LDD (R0),ACO
5200 031366 012700 025666 MOV #MODP1,R0 ;PUT A BACKGROUND PATTERN INTO AC1.

```

5201	031372	172510			LDD	(R0),AC1	
5202	031374	016100	000060		MOV	60(R1),R0	;SET UP THE FPS.
5203	031400	170100			LDFPS	R0	
5204	031402	012737	031416	001236	MOV	#1\$,@#STMP2	
5205	031410	010100			MOV	R1,R0	;COMPUTE THE ADDRESS OF THE FSRC.
5206	031412	062700	000010		ADD	#10,R0	
5207							
5208	031416	171410			1\$: MODD	(R0),AC0	;EXECUTE THE TEST INSTRUCTION.
5209							
5210	031420	170305			STST	R5	;GET THE FPS.
5211	031422	170204			STFPS	R4	;GET THE FPS.
5212	031424	012700	000200		MOV	#200,R0	;SET FD MODE.
5213	031430	170100			LDFPS	R0	
5214	031432	012700	031740		MOV	#MODDD0,R0	;GET THE FRACTIONAL RESULT.
5215	031436	174010			STD	AC0,(R0)	
5216	031440	012700	031750		MOV	#MODDD1,R0	;GET THE INTEGER RESULT.
5217	031444	174110			STD	AC1,(R0)	
5218							
5219	031446	010102			MOV	R1,R2	;SAVE THE DATA IN CASE OF ERROR.
5220	031450	010237	001240		MOV	R2,@#STMP3	
5221	031454	062702	000010		ADD	#10,R2	
5222	031460	010237	001242		MOV	R2,@#STMP4	
5223	031464	062702	000010		ADD	#10,R2	
5224	031470	010237	001244		MOV	R2,@#STMP5	
5225	031474	062702	000010		ADD	#10,R2	
5226	031500	010237	001246		MOV	R2,@#STMP6	
5227	031504	012737	031740	001250	MOV	#MODDD0,@#STMP7	
5228	031512	012737	031750	001252	MOV	#MODDD1,@#STMP10	
5229	031520	010437	001254		MOV	R4,@#STMP11	
5230	031524	016137	000062	001256	MOV	62(R1),@#STMP12	
5231	031532	010537	001260		MOV	R5,@#STMP13	
5232	031536	016137	000064	001262	MOV	64(R1),@#STMP14	
5233							
5234	031544	012702	031740		MOV	#MODDD0,R2	;CHECK THE FRACTIONAL RESULT.
5235	031550	010103			MOV	R1,R3	
5236	031552	062703	000020		ADD	#20,R3	
5237	031556	012700	000004		MOV	#4,R0	
5238	031562	022223			2\$: CMP	(R2)+,(R3)+	
5239	031564	001023			BNE	10\$	;BRANCH IF INCORRECT.
5240	031566	077003			SOB	R0,2\$	
5241							
5242	031570	012702	031750		MOV	#MODDD1,R2	;CHECK THE INTEGER RESULT.
5243	031574	010103			MOV	R1,R3	
5244	031576	062703	000030		ADD	#30,R3	
5245	031602	012700	000004		MOV	#4,R0	
5246	031606	022223			3\$: CMP	(R2)+,(R3)+	
5247	031610	001013			BNE	15\$	;BRANCH IF INCORRECT.
5248	031612	077003			SOB	R0,3\$	

```

5250
5251
5252 031614 026104 000062      CMP      62(R1),R4      ;CHECK THE FPS.
5253 031620 001027      BNE      20$           ;BRANCH IF INCORRECT.
5254
5255 031622 026105 000064      CMP      64(R1),R5      ;CHECK THE FEC.
5256 031626 001033      BNE      25$
5257
5258 031630 000161 000074      9$:      JMP      74(R1)      ;RETURN.
5259
5260      ;FRACTIONAL ERROR.
5261 031634      10$:
5262 031634 104176      12$:      ERROR    +176      ;THE ERROR WAS NOT ANTICIPATED SO
5263 031636 000774      BR        9$           ;REPORT THE INCORRECT FRACTION HERE.
5264
5265      ;INTEGER ERROR.
5266 031640 012702 031750      15$:      MOV      #MODDD1,R2      ;WAS THE INTEGER ERROR ANTICIPATED?
5267 031644 010103      MOV      R1,R3
5268 031646 062703 000050      ADD      #50,R3
5269 031652 012705 000004      MOV      #4,R5
5270 031656 022223      60$:      CMP      (R2)+,(R3)+
5271 031660 001005      BNE      17$           ;BRANCH IF NOT ANTICIPATED.
5272 031662 077503      SOB      R5,60$
5273 031664 010102      MOV      R1,R2
5274 031666 062702 000072      ADD      #72,R2
5275
5276 031672 000112      JMP      (R2)
5277
5278 031674      16$:
5279 031674 104177      17$:      ERROR    +177      ;THE ERROR WAS NOT ANTICIPATED SO REPORT
5280 031676 000754      BR        9$           ;THE INTEGER FAILURE HERE.
5281
5282      ;FPS INCORRECT.
5283 031700 010437 001254      20$:      MOV      R4,@$STMP11      ;REPORT INCORRECT FPS.
5284 031704 016137 000062 001256      MOV      62(R1),@$STMP12
5285 031712 104200      21$:      ERROR    +200
5286 031714 000745      BR        9$
5287
5288      ;REPORT FEC ERROR.
5289 031716 010537 001260      25$:      MOV      R5,@$STMP13
5290 031722 016137 000064 001262      MOV      64(R1),@$STMP14
5291 031730 010102      MOV      R1,R2
5292 031732 062702 000066      ADD      #66,R2
5293 031736 000112      JMP      (R2)
5294
5295 031740 000000 000000 000000  MODDD0: .WORD 0,0,0,0
5296 031746 000000
5297 031750 000000 000000 000000  MODDD1: .WORD 0,0,0,0
5298 031756 000000
5299 031760      NNNDONE:
5299 031760 104412      RSETUP      ;GO INITIALIZE THE FPS AND STACK; AND
;SEE IF THE USER HAS EXPRESSED
;THE DESIRE TO CHANGE THE SOFTWARE
;VIRTUAL CONSOLE SWITCH REGISTER (HAS
;THE USER TYPED CONTROL G?).

```

5300  
5342  
5343

```

*****
*TEST 22      INTERRUPT CORRECT FLOWS TEST
*
*THIS IS A TEST OF THE 'CORRECT' FLOWS. THIS PART OF THE MICRO CODE
*HAS AS ITS PURPOSE INSURING THAT INTERRUPT REQUESTS MADE DURING
*CERTAIN LENGTHY FPP INSTRUCTIONS GET HONORED. THIS IS DONE
*IN A WAY SUCH THAT IF AN INTERRUPT REQUEST OCCURS DURING ONE
*OF THESE INSTRUCTIONS THE STATE OF THAT INSTRUCTION'S
*EXECUTION WILL BE THE SAME AS IF THAT INSTRUCTION HAD NEVER
*BEEN FETCHED AND ITS EXECUTION NEVER STARTED. THUS THE MICRO CODE
*WILL RESTORE ALL REGISTERS, BACK UP THE PC AND LEAVE THE
*FPS AND ACO THROUGH ACS UNMODIFIED.
*THE INSTRUCTIONS FOR WHICH THIS IS NECESSARY ARE:
*
*   ADD (OR SUB)
*   DIV
*   MUL
*   MOD
*(BOTH DOUBLE AND FLOATING)
*ALL ADDRESSING MODES WILL BE TRIED WITH THE ADDD INSTRUCTION. THEN
*EACH OF THE OTHER INSTRUCTIONS WILL BE TRIED USING MODE 1.
*NOTE THAT THIS TEST NEEDS A SPECIAL INTERRUPT MODULE,
*WHICH WILL PROBABLY ONLY BE PRESENT IN DEC'S MANUFACTURING ENVIRONMENT,
*TO RUN. THIS SPECIAL EQUIPMENT IS DESIGNED TO RAISE AN
*INTERRUPT REQUEST IN THE PROCESSOR IF A BIT IS SET IN ITS STATUS
*REGISTER AND ONLY WHEN AN FPP INSTRUCTION IS ENCOUNTERED.
*THEREFORE THIS TEST WILL BE RUN CONDITIONALLY (DEPENDENT UPON WHETHER
*OR NOT THE STATUS REGISTER OF THE TEST EQUIPMENT TIMES OUT WHEN REFERENCED).
*THIS TEST CAN ALSO BE DESELECTED BY TURNING SWITCH 7 OF THE
*SWITCH REGISTER (PHYSICAL OR VIRTUAL) ON.
*THE TEST ASSUMES THAT THE TEST EQUIPMENT'S STATUS REGISTER IS AT
*LOCATION 777774 (NOTE THAT ALL REFERENCES TO THIS LOCATION ARE
*MADE INDIRECT THROUGH THIS PROGRAMS LOCATION CORINT, SO THAT
*IF THE USER HAS MODIFIED THE TEST EQUIPMENT'S STATUS REGISTER TO
*RESPOND TO A DIFFERENT ADDRESS LOCATION CORINT MUST BE
*MADE TO CONTAIN THAT STATUS REGISTER'S NEW ADDRESS).
*THIS PROGRAM ASSUMES THAT THE TRAP VECTOR FOR THE TEST EQUIPMENT IS 110.
*AGAIN NOTE THAT ALL REFERENCES TO THIS TRAP VECTOR ARE INDIRECT, THROUGH
*THIS PROGRAM'S LOCATION CORTRP (IF THE TEST EQUIPMENT IS
*MADE TO TRAP TO A DIFFERENT VECTOR LOCATION CORTRP MUST CONTAIN THE
*ADDRESS OF THIS VECTOR).
*

```

```

031762 000004
5344
5345 031764 132767 000200 147345
5346 031772 001406
5347 031774 032777 000200 147136
5348
5349 032002 001022
5350 032004 000137 033142
5351
5352 032010 012737 032034 000004
5353 032016 012777 000000 001112
5354 032024 012737 036712 000004
5355 032032 000406

```

```

*****
TST22:  SCOPE
          BITB    #200,$ENVM    ;SEE IF APT IS SELECTING TEST.
          BEQ     COR1         ;BRANCH TO AUTOSIZE IF NOT.
          BIT     #200,@SWR     ;SEE IF THE USER HAS SELECTED THIS
                               ;TEST USING THE SWITCH REGISTER.
          BNE     COR3         ;IF SO, PERFORM TEST.
          JMP     @#CORDONE     ;ELSE DO NOT RUN TEST.
COR1:    MOV     #COR2,@#ERRVECT ;SEE IF THE TEST EQUIPMENT'S STATUS
          MOV     #0,@CORINT    ;REGISTER TIMES OUT.
          MOV     #CPSPUR,@#ERRVECT
          BR     COR3          ;DIDN'T TIME OUT SO START TEST.

```

```

5356
5357 032034 022626          COR2:  CMP      (SP)+,(SP)+      ;IF THE REFERENCE TIMES OUT DO
5358 032036 012737 036712 000004  MOV      #CSPUR,@#ERRVECT
5359 032044 000137 033142          JMP      @#CORDONE      ;NOT RUN TEST.
5360
5361          ;TEST ADDD MODE 0
5362 032050          COR3:
5363 032050 005227 177777          INC      #-1
5364 032054 001002          BNE     COR33
5365 032056 104401          TYPE
5366 032060 037665          .WORD   CORMES
5367 032062          COR33:
5368 032062 104413          LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
5369 032064 004737 032642          JSR     PC,@#CORSUB
5370 032070 040200 000100 000200 1$:      .WORD   40200,100,200,300      ;AC0
5371 032100 123456          2$:      .WORD   123456      ;R0
5372 032102 000200          3$:      200      ;FPS
5373 032104 172000          4$:      ADDD   AC0,AC0      ;TEST INSTRUCTION.
5374 032106 000240          NOP
5375 032110 005037 033124          CLR     @#CORFLG      ;RESET INTERRUPT FLAG
5376 032114 104252          ERROR  +252      ;NO INTERRUPT! TEST EQUIPMENT FAILED.
5377 032116 000401          BR      11$
5378 032120 104253          5$:      ERROR  +253      ;INCORRECT STATE AT INTERRUPT.
5379 032122          11$:
5380          ;TEST ADDD MODE 1
5381 032122          COR4:
5382 032122 104413          LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
5383 032124 004737 032642          JSR     PC,@#CORSUB
5384 032130 040201 000555 077007 1$:      .WORD   40201,555,77007,111111 ;AC0
5385 032136 111111          2$:      .WORD   1$      ;R0
5386 032140 032130          3$:      217      ;FPS
5387 032142 000217          4$:      ADDD   (R0),AC0      ;TEST INSTRUCTION
5388 032144 172010          NOP
5389 032146 000240          CLR     @#CORFLG      ;RESET INTERRUPT FLAG
5390 032150 005037 033124          ERROR  +252      ;REPORT FAILURE. NO INTERRUPT.
5391 032154 104252          BR      11$
5392 032156 000401          ERROR  +254
5393 032160 104254          11$:
5394          ;TEST ADDD MODE 2
5395 032162          COR5:
5396 032162 104413          LPERR   ;SET UP THE LOOP ON ERROR ADDRESS.
5397 032164 004737 032642          JSR     PC,@#CORSUB
5398 032170 040202 111333 052525 1$:      .WORD   40202,111333,52525,70707 ;AC0
5399 032176 070707          2$:      .WORD   1$      ;R0
5400 032200 032170          3$:      205      ;FPS
5401 032202 000205          4$:      ADDD   (R0)+,AC0      ;TEST INSTRUCTION
5402 032204 172020          NOP
5403 032206 000240          CLR     @#CORFLG      ;RESET THE INTERRUPT FLAG
5404 032210 005037 033124          ERROR  +252      ;REPORT FAILURE. NO INTERRUPT.
5405 032214 104252          BR      11$
5406 032216 000401          ERROR  +255      ;CORRECT FLOWS FAILED.
5407 032220 104255          11$:

```

```

5408          :TEST ADDD MODE 3
5409 032222   COR6:
          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5410 032224   104413     JSR          PC,@#CORSUB
5411 032230   004737     032642   072746 1$: .WORD    40203,71735,72746,1 ;ACO
          040203
          032236   000001
5412 032240   032264     2$: .WORD    10$ ;RO
5413 032242   000206     3$: 206 ;FPS
5414 032244   172030     4$: ADDD    @ (R0)+,ACO ;TEST INSTRUCTION
5415 032246   000240     NOP
5416 032250   005037     033124   CLR      @#CORFLG ;RESET THE INTERRUPT FLAG
5417 032254   104252     ERROR   +252 ;REPORT FAILURE, NO INTERRUPT.
5418 032256   000403     BR      11$
5419 032260   104256     5$: ERROR   +256 ;CORRECT FLOWS FAILED.
5420 032262   000401     BR      11$
5421 032264   032230     10$: .WORD    1$ ;USED FOR THE ADDRESSING OF THE OPERAND
5422          ;IN THIS MODE.
5423 032266     11$:
5424          :TEST ADDD MODE 4
5425 032266   COR7:
          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5426 032270   104413     JSR          PC,@#CORSUB
5427 032274   004737     032642   070123 1$: .WORD    40204,123456,70123,45671 ;ACO
          040204
          032302   045671
5428 032304   032304     2$: .WORD    1$+10 ;RO
5429 032306   000212     3$: 212 ;FPS
5430 032310   172040     4$: ADDD    -(R0),ACO ;TEST INSTRUCTION
5431 032312   000240     NOP
5432 032314   005037     033124   CLR      @#CORFLG ;RESET THE INTERRUPT FLAG
5433 032320   104252     ERROR   +252 ;REPORT FAILURE, NO INTERRUPT.
5434 032322   000401     BR      11$
5435 032324   104257     ERROR   +257 ;CORRECT FLOWS FAILED
5436 032326     11$:
5437
5438          :TEST ADDD MODE 5
5439 032326   COR8:
          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5440 032330   104413     JSR          PC,@#CORSUB
5441 032334   004737     032642   021076 1$: .WORD    40205,76543,21076,54321 ;ACO
          040205
          032342   054321
5442 032344   032372     2$: .WORD    10$+2 ;RO
5443 032346   000213     3$: 213 ;FPS
5444 032350   172050     4$: ADDD    @-(R0),ACO ;TEST INSTRUCTION
5445 032352   000240     NOP
5446 032354   005037     033124   CLR      @#CORFLG ;RESET THE INTERRUPT FLAG
5447 032360   104252     ERROR   +252 ;REPORT ERROR, NO INTERRUPT.
5448 032362   000403     BR      11$
5449 032364   104260     5$: ERROR   +260 ;CORRECT FLOWS FAILED.
5450 032366   000401     BR      11$
5451 032370   032334     10$: .WORD    1$
5452 032372     11$:
5453
5454          :TEST ADDD MODE 6
5455 032372   COR9:
          LPERR          ;SET UP THE LOOP ON ERROR ADDRESS.
5456 032374   104413     JSR          PC,@#CORSUB
5457 032400   004737     032642   063730 1$: .WORD    40206,34353,63730,31323 ;ACO
          040206
          034353

```

```

5458 032406 031323
5459 032410 032377
5460 032412 000214
5461 032414 172060 000001
5462 032420 005037 033124
5463 032424 104252
5464 032426 000401
5465 032430 104261
5466
5467
5468 032432
5469 032432 104413
5470 032434 004737 032642
5471 032440 040210 070107 062426
5472 032446 055555
5473 032450 032473
5474 032452 000204
5475 032454 172070 000001
5476 032460 005037 033124
5477 032464 104252
5478 032466 000403
5479 032470 104262
5480 032472 000401
5481 032474 032440
5482
5483 032476
5484 032476 104413
5485 032500 004737 032642
5486 032504 040211 033445 056677
5487 032512 001122
5488 032514 032504
5489 032516 000205
5490 032520 174410
5491 032522 000240
5492 032524 005037 033124
5493 032530 104252
5494 032532 000401
5495 032534 104263
5496
5497 032536
5498 032536 104413
5499 032540 004737 032642
5500 032544 040212 165411 046252
5501 032552 063650
5502 032554 032544
5503 032556 000210
5504 032560 171010
5505 032562 000240
5506 032564 005037 033124
5507 032570 104252
5508 032572 000401
5509 032574 104264

2$: .WORD 1$-1 ;RO
3$: 214 ;FPS
4$: ADD 1(R0),ACO ;TEST INSTRUCTION
CLR @#CORFLG
ERROR +252 ;REPORT FAILURE NO TRAP.
BR 11$
5$: ERROR +261
11$:

;TEST ADDD MODE 7
COR10:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,@#CORSUB
1$: .WORD 40210,70107,62426,55555 ;ACO

2$: .WORD 10$-1 ;RO
3$: 204 ;FPS
4$: ADD @1(R0),ACO ;TEST INSTRUCTION
CLR @#CORFLG
ERROR +252 ;REPORT FAILURE NO TRAP
BR 11$
5$: ERROR +262 ;CORRECT FLOWS FAILED.
BR 11$
10$: .WORD 1$
11$:

;TEST DIVD MODE 1
COR11:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,@#CORSUB
1$: .WORD 40211,33445,56677,001122 ;ACO

2$: .WORD 1$ ;RO
3$: 205 ;FPS
4$: DIVD (R0),ACO ;TEST INSTRUCTION
NOP
CLR @#CORFLG
ERROR +252 ;REPORT FAILURE, NO TRAP.
BR 11$
5$: ERROR +263 ;CORRECT FLOWS FAILED.
11$:

;TEST MULD MODE 1
COR12:
LPERR ;SET UP THE LOOP ON ERROR ADDRESS.
JSR PC,@#CORSUB
1$: .WORD 40212,165411,46252,63650 ;ACO

2$: .WORD 1$ ;RO
3$: .WORD 210 ;FPS
4$: MULD (R0),ACO ;TEST INSTRUCTION
NOP
CLR @#CORFLG
ERROR +252 ;REPORT FAILURE, NO TRAP.
BR 11$
5$: ERROR +264 ;CORRECT FLOWS FAILED.
  
```

```

5508 032576          11$:
5509
5510                ;TEST MODD MODE 1
5511 032576          COR13:
      032576 104413          LPERR                ;SET UP THE LOOP ON ERROR ADDRESS.
5512 032600 004737 032642          JSR          PC,@#CORSUB
5513 032604 040213 045654 054542 1$:      .WORD      40213,45654,54542,171623      ;ACO
      032612 171623
5514 032614 032604          2$:      .WORD      1$                ;RO
5515 032616 000412          3$:      .WORD      412                ;FPS
5516 032620 171410          4$:      MODD      (R0),ACO          ;TEST INSTRUCTION.
5517 032622 000240          NOP
5518 032624 005037 033124          CLR          @#CORFLG
5519 032630 104252          ERROR      +252          ;REPORT FAILURE NO TRAP.
5520 032632 000401          BR          11$
5521 032634 104265          5$:      ERROR      +265          ;CORRECT FLOWS FAILED.
5522 032636 000137 033142          11$:      JMP          @#CORDONE          ;FINISHED TEST!

```

;THIS SUBROUTINE, CORSUB, IS CALLED TO SET UP THE OPERANDS  
;AND CHECK THE RESULTS IN THIS TEST. IT IS CALLED THUS:

```

:
:      JSR          PC,@#CORSUB
:      1$:      .WORD      X,X,X,X          ;ACO OPERAND
:      2$:      .WORD      X                ;RO
:      3$:      .WORD      X                ;FPS
:      4$:      INST
:
:      ADR
:
:      ERROR      +252          ;TEST INSTRUCTION TO BE
:      BR          11$          ;EXECUTED.
:
:      5$:      ERROR      +N            ;AN ADDRESS OFFSET FOR
:      BR          11$          ;CERTAIN MODES OR NOP.
:
:      10$:     .WORD      ADDRESS        ;NO TRAP ERROR.
:      11$:

```

;CORSUB WILL PICK UP A POINTER TO THE ARGUMENTS, IN R1. ACO, RO AND  
;THE FPS WILL BE SET TO THE DESIGNATED VALUES. THEN THE TEST MODULE  
;WILL BE SET UP TO INTERRUPT AND THE INSTRUCTION AT 4\$ EXECUTED. IF  
;NO TRAP OCCURS THEN THE TEST MODULE IS FAULTY. WHEN THE TRAP OCCURS  
;THE PC ON THE STACK SHOULD BE 4\$, AND ACO, RO AND THE FPS SHOULD NOT  
;HAVE BEEN MODIFIED. IF EVERYTHING IS CORRECT CORSUB WILL RETURN TO  
;5\$ PLUS TWO. IF AN ERROR IS DETECTED THEN CORSUB WILL RETURN TO THE  
;ERROR REPORT AT 5\$.  
;NOTE THAT A FLAG, CORFLG, IS SET TO -1 WHEN AN INTERRUPT IS PENDING.  
;CORFLG IS ZERO OTHERWISE.

```

5553 032642 005037 033124          CORSUB: CLR      @#CORFLG          ;SET FLAG TO INDICATE NO INTERRUPT
5554                                     ;PENDING.
5555 032646 012601          MOV          (SP)+,R1          ;GET A POINTER TO THE ARGUMENTS.
5556 032650 010102          MOV          R1,R2          ;SET ACO.
5557 032652 012700 000200          MOV          #200,R0
5558 032656 170100          LDFPS      R0
5559 032660 172412          LDD          (R2),ACO
5560 032662 016100 000012          MOV          12(R1),R0          ;SET UP THE FPS.
5561 032666 170100          LDFPS      R0
5562 032670 016100 000010          MOV          10(R1),R0          ;SET UP RO.

```



```

5563 032674 010102          MOV    R1,R2
5564 032676 062702 000014    ADD    #14,R2
5565 032702 010237 001236    MOV    R2,@#STMP2          ;SAVE ADDRESS OF INSTRUCTION IN CASE
5566                                     ;OF ERROR.
5567 032706 005037 177776    CLR    @#PSW                ;CLEAR THE PRIORITY TO ALLOW INTERRUPTS.
5568 032712 012777 032740 000220  MOV    #CORTV,@CORTRP      ;SET UP THE INTERRUPT VECTOR.
5569 032720 012767 177777 000176  MOV    #-1,CORFLG          ;SET THE FLAG TO INDICATE
5570                                     ;AN INTERRUPT IS PENDING.
5571 032726 012777 177777 000202  MOV    #-1,@CORINT         ;ENABLE THE TEST EQUIPMENT'S
5572                                     ;TRAP FUNCTION AND GO
5573 032734 000161 000014    JMP    14(R1)              ;EXECUTE THE INSTRUCTION.
5574
5575                                     ;TRAP TO HERE WHEN THE INTERRUPT OCCURS.
5576 032740 005137 033124    CORTV: COM @#CORFLG        ;FIRST SEE IF AN INTERRUPT WAS PENDING.
5577 032744 001060          BNE    CORTV1              ;IF NOT GO REPORT AN ERROR.
5578 032746 012777 000000 000162  MOV    #0,@CORINT          ;MAKE SURE THE TEST EQUIPMENT
5579                                     ;IS NOT INTERRUPT ENABLED.
5580
5581 032754 170204          STFPS  R4                  ;GET THE FPS.
5582 032756 012702 000200    MOV    #200,R2            ;GET ACO
5583 032762 170102          LDFPS  R2
5584 032764 012702 033126    MOV    #CORTMP,R2
5585 032770 174012          STD    ACO,(R2)
5586 032772 012737 033126 001240  MOV    #CORTMP,@#STMP3
5587 033000 010037 001244    MOV    R0,@#STMP5
5588 033004 010437 001250    MOV    R4,@#STMP7
5589 033010 011637 001254    MOV    (SP),@#STMP11
5590 033014 010102          MOV    R1,R2
5591 033016 010237 001242    MOV    R2,@#STMP4
5592 033022 062702 000010    ADD    #10,R2
5593 033026 012237 001246    MOV    (R2)+,@#STMP6
5594 033032 012237 001252    MOV    (R2)+,@#STMP10
5595 033036 010237 001256    MOV    R2,@#STMP12
5596 033042 021602          CMP    (SP),R2            ;SEE IF THE TRAP OCCURRED
5597                                     ;AT THE CORRECT ADDRESS.
5598 033044 001016          BNE    CORTV0
5599 033046 022626          CMP    (SP)+,(SP)+        ;RESET THE STACK.
5600 033050 020061 000010    CMP    R0,10(R1)          ;SEE IF R0 IS CORRECT.
5601 033054 001012          BNE    CORTV0              ;BR IF NOT CORRECT.
5602 033056 010102          MOV    R1,R2              ;SEE IF ACO WAS CORRECT
5603 033060 012703 033126    MOV    #CORTMP,R3
5604 033064 012705 000004    MOV    #4,R5
5605 033070 022223          1$:  CMP    (R2)+,(R3)+
5606 033072 001003          BNE    CORTV0              ;BRANCH IF INCORRECT.
5607 033074 077503          SOB   R5,1$
5608 033076 000161 000032    JMP    32(R1)              ;IF EVERYTHING IS CORRECT THEN RETURN.
5609
5610 033102 000161 000030    CORTV0: JMP    30(R1)        ;CORRECT FLOWS FAILED SO GO REPORT ERROR.
5611
5612 033106 011637 001236    CORTV1: MOV    (SP),@#STMP2 ;AN INTERRUPT OCCURRED WHEN THE FLAG
5613                                     ;CORFLG, DID NOT INDICATE THAT ONE WAS
5614                                     ;PENDING SO REPORT SPURIOUS TRAP.
5615 033112 005037 033124    CLR    @#CORFLG
5616 033116 022626          CMP    (SP)+,(SP)+
5617 033120 104266          ERROR +266
5618 033122 000407          BR    CORDONE
5619

```

5620 033124 000000 CORFLG: .WORD 0  
 5621 033126 000000 000000 000000 CORTMP: .WORD 0,0,0,0  
 033134 000000

5622  
 5623 033136 177774 CORINT: .WORD 177774

5624  
 5625  
 5626  
 5627  
 5628 033140 000110 CORTRP: .WORD 110

5629  
 5630  
 5631  
 5632  
 5633  
 5634  
 5635 033142  
 033142 104412 CORDONE: RSETUP

:THIS IS THE ADDRESS, 177774, OF THE  
 :TEST EQUIPMENT'S STATUS REGISTER.  
 :THE CONTENTS OF CORINT CAN BE MODIFIED  
 :IF THIS STATUS REGISTER'S ADDRESS IS  
 :CHANGED.  
 :THIS IS THE ADDRESS OF THE TEST EQUIPMENTS  
 :TRAP VECTOR. LIKE THE STATUS REGISTER'S ADDRESS  
 :DESCRIBED IMMEDIATELY ABOVE  
 :THIS VECTOR CAN BE CHANGED, BUT THE  
 :CONTENTS OF CORTRP MUST INDICATE THE  
 :CHANGE.

:GO INITIALIZE THE FPS AND STACK; AND  
 :SEE IF THE USER HAS EXPRESSED  
 :THE DESIRE TO CHANGE THE SOFTWARE  
 :VIRTUAL CONSOLE SWITCH REGISTER (HAS  
 :THE USER TYPED CONTROL G?).

5636  
 5637  
 5638  
 5639 033144 TST23:

5640  
 5641  
 5642  
 5643

.SBTTL END OF PASS ROUTINE  
 :\*\*\*\*\*  
 :\*INCREMENT THE PASS NUMBER (\$PASS)  
 :\*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM  
 :\*IF SW12=1 INHIBIT TRACE TRAP  
 :\*IF THERES A MONITOR GO TO IT  
 :\*IF THERE ISN'T JUMP TO LOOP  
 \$EOP:

033144	000004		SCOPE		
033146	005067	145730	CLR	\$TSTNM	::ZERO THE TEST NUMBER
033152	005067	146124	CLR	\$TIMES	::ZERO THE NUMBER OF ITERATIONS
033156	005267	146142	INC	\$PASS	::INCREMENT THE PASS NUMBER
033162	042767	100000 146134	BIC	#100000,\$PASS	::DON'T ALLOW A NEG. NUMBER
033170	005327		DEC	(PC)+	::LOOP?
033172	000001		\$EOPCT: .WORD	1	
033174	003074		BGT	\$DOAGN	::YES
033176	012737		MOV	(PC)+,@(PC)+	::RESTORE COUNTER
033200	000001		\$ENDCT: .WORD	1	
033202	033172		\$EOPCT		
033204	104401	033212	TYPE	,65\$	::TYPE ASCIZ STRING
033210	000407		BR	64\$	::GET OVER THE ASCIZ
			::65\$: .ASCIZ	<12><15>/END PASS #/	
033230			64\$:		
033230	016746	146070	MOV	\$PASS,-(SP)	::SAVE \$PASS FOR TYPEOUT
					::TYPE PASS NUMBER IN OCTAL
033234	104403		TYPOS		::GO TYPE--OCTAL ASCII
033236	006		.BYTE	6	::TYPE 6 DIGITS
033237	000		.BYTE	0	::SUPPRESS LEADING ZEROS

```

033240 104401 033246          TYPE      ,67$          ;;TYPE ASCIZ STRING
033244 000421                BR          66$          ;;GET OVER THE ASCIZ
                                ;;67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
                                66$:
033310 016746 145576          MOV      $ERTTL,-(SP)    ;;SAVE $ERTTL FOR TYPEOUT
033314 104403                TYPOS                    ;;TOTAL NUMBER OF ERRORS IN OCTAL
033316      006                .BYTE      6                    ;;GO TYPE--OCTAL ASCII
033317      000                .BYTE      0                    ;;TYPE 6 DIGITS
033320 104401 001313          TYPE      ,$CRLF        ;;SUPPRESS LEADING ZEROS
033324 005067 145562          CLR      $ERTTL        ;;TYPE CARRIAGE RETURN, LINE FEED
033330 013700 000042          $GET42: MOV    @#42,R0    ;;CLEAR ERROR TOTAL
033334 001414                BEQ      $DOAGN        ;;GET MONITOR ADDRESS
033336 005046                CLR      -(SP)         ;;BRANCH IF NO MONITOR
033340 012746 033346          MOV      #$CLR.T,-(SP)  ;;INSURE THE 'T' BIT IS CLEAR
033344 000426                BR       $RTRN         ;;SETUP FOR AN RTI OR RTT
                                ;;GO DO AN RTI OR RTT TO LOAD THE PSW
                                ;;WITH A CLEARED 'T' BIT
033346 013700 000042          $CLR.T: MOV    @#42,R0    ;;INSURE R0 CONTAINS THE MONITORS
033352 001405                BEQ      $DOAGN        ;;RETURN ADDRESS
033354 000005                RESET                   ;;CLEAR THE WORLD
033356 004710                $ENDAD: JSR   PC,(R0)    ;;GO TO MONITOR
033360 000240                NOP                       ;;SAVE ROOM
033362 000240                NOP                       ;;FOR
033364 000240                NOP                       ;;ACT11
033366 104400                $DOAGN: TRAP                    ;;PUSH OLD PSW AND PC ON STACK
033370 042716 000020          BIC      #20,(SP)      ;;CLEAR THE 'T' BIT
033374 032777 010000 145536  BIT      #BIT12,@SWR    ;;RUN WITH TRACE TRAP?
033402 001005                BNE      1$           ;;BR IF NO
033404 005167 000020          COM      $TBIT        ;;IS IT TIME FOR TRACE TRAP
033410 100402                BMI      1$           ;;BR IF NO
033412 052716 000020          BIS      #20,(SP)    ;;SET TRACE TRAP
033416 012746 033424          1$: MOV    #$LOOP,-(SP)  ;;JUMP TO START OF TEST
033422 000002                $RTRN: RTI                    ;;RETURN--THIS IS CHANGED TO
                                ;;AN 'RTT' IF 'RTT' IS A LEGAL
                                ;;INSTRUCTION
033424 000137                $LOOP: JMP     @(PC)+        ;;RETURN
033426 005020                $RTNAD: .WORD   LOOP
033430 000000                $TBIT:  .WORD   0           ;;'T' BIT STATE INDICATOR
033432      377      377      000 $ENULL: .BYTE  -1,-1,0      ;;NULL CHARACTER STRING
                                .EVEN
  
```

5644  
5645

033436

```

.SBTTL SCOPE HANDLER ROUTINE
;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1 LOOP ON TEST
;SW11=1 INHIBIT ITERATIONS
;SW09=1 LOOP ON ERROR
;SW08=1 LOOP ON TEST IN SWR<7:0>
;CALL
;*
* SCOPE          ;;SCOPE=IOT
$SCOPE:
  
```

```

033436 104406          CKSWR          ::TEST FOR CHANGE IN SOFT-SWR
033440 032777 040000 145472 1$: BIT #BIT14,@SWR ::LOOP ON PRESENT TEST?
033446 001114          BNE $OVER      ::YES IF SW14=1
          ::#####START OF CODE FOR THE XOR TESTER#####
033450 000416          $XTSTR: BR 6$      ::IF RUNNING ON THE 'XOR' TESTER CHANGE
          ::THIS INSTRUCTION TO A 'NOP' (NOP=240)
033452 013746 000004          MOV @#ERRVEC,-(SP) ::SAVE THE CONTENTS OF THE ERROR VECTOR
033456 012737 033476 000004          MOV #5,@#ERRVEC  ::SET FOR TIMEOUT
033464 005737 177060          TST @#177060     ::TIME OUT ON XOR?
033470 012637 000004          MOV (SP)+,@#ERRVEC ::RESTORE THE ERROR VECTOR
033474 000463          BR $SVLAD       ::GO TO THE NEXT TEST
033476 022626          5$: CMP (SP)+,(SP)+ ::CLEAR THE STACK AFTER A TIME OUT
033500 012637 000004          MOV (SP)+,@#ERRVEC ::RESTORE THE ERROR VECTOR
033504 000423          BR 7$         ::LOOP ON THE PRESENT TEST
033506          6$:;#####END OF CODE FOR THE XOR TESTER#####
033506 032777 000400 145424          BIT #BIT08,@SWR  ::LOOP ON SPEC. TEST?
033514 001404          BEQ 2$         ::BR IF NO
033516 127767 145416 145356          CMPB @SWR,$TSTNM ::ON THE RIGHT TEST? SWR<7:0>
033524 001465          BEQ $OVER      ::BR IF YES
033526 105767 145351          2$: TSTB $ERFLG   ::HAS AN ERROR OCCURRED?
033532 001421          BEQ 3$         ::BR IF NO
033534 126767 145355 145341          CMPB $ERMAX,$ERFLG ::MAX. ERRORS FOR THIS TEST OCCURRED?
033542 101015          BHI 3$         ::BR IF NO
033544 032777 001000 145366          BIT #BIT09,@SWR ::LOOP ON ERROR?
033552 001404          BEQ 4$         ::BR IF NO
033554 016767 145330 145324 7$: MOV $LPERR,$LPADR ::SET LOOP ADDRESS TO LAST SCOPE
033562 000446          BR $OVER      ::
033564 105067 145313          4$: CLRB $ERFLG   ::ZERO THE ERROR FLAG
033570 005067 145506          CLR $TIMES     ::CLEAR THE NUMBER OF ITERATIONS TO MAKE
033574 000415          BR 1$         ::ESCAPE TO THE NEXT TEST
033576 032777 004000 145334 3$: BIT #BIT11,@SWR  ::INHIBIT ITERATIONS?
033604 001011          BNE 1$         ::BR IF YES
033606 005767 145512          TST $PASS      ::IF FIRST PASS OF PROGRAM
033612 001406          BEQ 1$         ::INHIBIT ITERATIONS
033614 005267 145264          INC $ICNT     ::INCREMENT ITERATION COUNT
033620 026767 145456 145256          CMP $TIMES,$ICNT ::CHECK THE NUMBER OF ITERATIONS MADE
033626 002024          BGE $OVER      ::BR IF MORE ITERATION REQUIRED
033630 012767 000001 145246 1$: MOV #1,$ICNT   ::REINITIALIZE THE ITERATION COUNTER
033636 016767 000052 145436          MOV $MXCNT,$TIMES ::SET NUMBER OF ITERATIONS TO DO
033644 105267 145232          $SVLAD: INCB $TSTNM ::COUNT TEST NUMBERS
033650 116767 145226 145444          MOVB $TSTNM,$TESTN ::SET TEST NUMBER IN APT MAILBOX
033656 011667 145224          MOV (SP),$LPADR ::SAVE SCOPE LOOP ADDRESS
033662 011667 145222          MOV (SP),$LPERR ::SAVE ERROR LOOP ADDRESS
033666 005067 145412          CLR $ESCAPE    ::CLEAR THE ESCAPE FROM ERROR ADDRESS
033672 112767 000001 145215          MOVB #1,$ERMAX  ::ONLY ALLOW ONE(1) ERROR ON NEXT TEST
033700 016777 145176 145234 $OVER: MOV $TSTNM,@DISPLAY ::DISPLAY TEST NUMBER
033706 016716 145174          MOV $LPADR,(SP) ::FUDGE RETURN ADDRESS
033712 000002          RTI        ::FIXES PS
033714 000001          $MXCNT: 1    ::MAX. NUMBER OF ITERATIONS

```

5646  
5647

```

.SBTTL ERROR HANDLER ROUTINE
;*****
;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;*AND GO TO ERTYPE ON ERROR
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW15=1 HALT ON ERROR

```

```

;*SW13=1      INHIBIT ERROR TYPEOUTS
;*SW10=1      BELL ON ERROR
;*SW09=1      LOOP ON ERROR
;*CALL
;*           ERROR N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
$ERROR:
033716
033716 104406
033720 105267 145157 7$: CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
033724 001775          INCB          $ERFLG          ;;SET THE ERROR FLAG
033726 016777 145150 145206 BEQ          7$          ;;DON'T LET THE FLAG GO TO ZERO
033734 032777 002000 145176 MOV          $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
033742 001402          BIT          #BIT10,@SWR      ;;BELL ON ERROR?
033744 104401 001306          BEQ          1$          ;;NO - SKIP
033750 005267 145136          TYPE         $BELL          ;;RING BELL
033754 011667 145136          INC          $ERTTL        ;;COUNT THE NUMBER OF ERRORS
033760 162767 000002 145130 SUB          (SP),$ERRPC     ;;GET ADDRESS OF ERROR INSTRUCTION
033766 117767 145124 145120 MOVB         @$ERRPC,$ITEMB  ;;STRIP AND SAVE THE ERROR ITEM CODE
033774 032777 020000 145136 BIT          #BIT13,@SWR   ;;SKIP TYPEOUT IF SET
034002 001004          BNE          20$          ;;SKIP TYPEOUTS
034004 004767 002174          JSR          PC,ERTYPE    ;;GO TO USER ERROR ROUTINE
034010 104401 001313          TYPE         ,SCLF
034014
034014 122767 000001 145314 20$: CMPB         #APTENV,$ENV    ;;RUNNING IN APT MODE
034022 001007          BNE          2$          ;;NO,SKIP APT ERROR REPORT
034024 116767 145064 000004 MOVB         $ITEMB,21$     ;;SET ITEM NUMBER AS ERROR NUMBER
034032 004767 001010          JSR          PC,$ATY4      ;;REPORT FATAL ERROR TO APT
034036 000
034037 000          21$: .BYTE         0
034040 000777          .BYTE         0
034042 005777 145072          BR          22$          ;;APT ERROR LOOP
034046 100002          TST          @SWR          ;;HALT ON ERROR
034050 000000          BPL          3$          ;;SKIP IF CONTINUE
034052 104406          HALT          ;;HALT ON ERROR!
034054 032777 001000 145056 3$: CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
034062 001402          BIT          #BIT09,@SWR     ;;LOOP ON ERROR SWITCH SET?
034064 016716 145020          BEQ          4$          ;;BR IF NO
034070 005767 145210          MOV          $LPERR,(SP)   ;;FUDGE RETURN FOR LOOPING
034074 001402          TST          $ESCAPE     ;;CHECK FOR AN ESCAPE ADDRESS
034076 016716 145202          BEQ          5$          ;;BR IF NONE
034102          MOV          $ESCAPE,(SP)   ;;FUDGE RETURN ADDRESS FOR ESCAPE
034102 022737 033356 000042 5$: CMP          #$ENDAD,@#42  ;;ACT-11 AUTO-ACCEPT?
034110 001001          BNE          6$          ;;BRANCH IF NO
034112 000000          HALT          ;;YES
034114
034114 032777 001000 145016 6$: BIT          #BIT09,@SWR
034122 001013          BNE          ERM10
034124 011637 001162          MOV          (SP),@$REGO    ;SEE IF ERROR #377
034130 062737 177776 001162 ADD          #-2,@$REGO
034136 122777 000377 145016 CMPB         #377,@$REGO
034144 001002          BNE          ERM10
034146 062716 000002          ADD          #2,(SP)
034152 000002          ERM10: RTI

```

5648  
5649

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES
;*****
;*SAVE R0-R5
;*CALL:

```

```

034154
034154 010046
034156 010146
034160 010246
034162 010346
034164 010446
034166 010546
034170 016646 000022
034174 016646 000022
034200 016646 000022
034204 016646 000022
034210 000002

```

```

;* SAVREG
;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;*
;*TOP---(+16)
;* +2---(+18)
;* +4---R5
;* +6---R4
;* +8---R3
;*+10---R2
;*+12---R1
;*+14---R0
$SAVREG:
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI

```

```

034212
034212 012666 000022
034216 012666 000022
034222 012666 000022
034226 012666 000022
034232 012605
034234 012604
034236 012603
034240 012602
034242 012601
034244 012600
034246 000002

```

```

;*RESTORE R0-R5
;*CALL:
;* RESREG
$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
RTI

```

```

5650
5651

```

```

.SBTTL TYPE ROUTINE
;*****
;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;*
;*CALL:
;*1) USING A TRAP INSTRUCTION
;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;*OR
;* TYPE
;* MESADR
;*
$TYPE: TSTB $TPFLG ;;IS THERE A TERMINAL?
BPL 1$ ;;BR IF YES
HALT ;;HALT HERE IF NO TERMINAL

```

```

034250 105767 144703
034254 100002
034256 000000

```

034260	000430			BR	3\$	:: LEAVE
034262	010046			MOV	R0,-(SP)	:: SAVE R0
034264	017600	000002		MOV	@2(SP),R0	:: GET ADDRESS OF ASCIZ STRING
034270	122767	000001	145040	CMPB	#APTENV,\$ENV	:: RUNNING IN APT MODE
034276	001011			BNE	62\$	:: NO,GO CHECK FOR APT CONSOLE
034300	132767	000100	145031	BITB	#APTSPOOL,\$ENVM	:: SPOOL MESSAGE TO APT
034306	001405			BEQ	62\$	:: NO,GO CHECK FOR CONSOLE
034310	010067	000004		MOV	R0,61\$	:: SETUP MESSAGE ADDRESS FOR APT
034314	004767	000516		JSR	PC,\$ATY3	:: SPOOL MESSAGE TO APT
034320	000000			.WORD	0	:: MESSAGE ADDRESS
034322	132767	000040	145007	BITB	#APTCSUP,\$ENVM	:: APT CONSOLE SUPPRESSED
034330	001003			BNE	60\$	:: YES,SKIP TYPE OUT
034332	112046			MOV	(R0)+,-(SP)	:: PUSH CHARACTER TO BE TYPED ONTO STACK
034334	001005			BNE	4\$	:: BR IF IT ISN'T THE TERMINATOR
034336	005726			TST	(SP)+	:: IF TERMINATOR POP IT OFF THE STACK
034340	012600			MOV	(SP)+,R0	:: RESTORE R0
034342	062716	000002		ADD	#2,(SP)	:: ADJUST RETURN PC
034346	000002			RTI		:: RETURN
034350	122716	000011		CMPB	#HT,(SP)	:: BRANCH IF <HT>
034354	001430			BEQ	8\$	
034356	122716	000200		CMPB	#CRLF,(SP)	:: BRANCH IF NOT <CRLF>
034362	001006			BNE	5\$	
034364	005726			TST	(SP)+	:: POP <CR><LF> EQUIV
034366	104401			TYPE		:: TYPE A CR AND LF
034370	001313			\$CRLF		
034372	105067	000200		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT
034376	000755			BR	2\$	:: GET NEXT CHARACTER
034400	004767	000056		JSR	PC,\$TYPEC	:: GO TYPE THIS CHARACTER
034404	126726	144546		CMPB	\$FILLC,(SP)+	:: IS IT TIME FOR FILLER CHARS.?
034410	001350			BNE	2\$	:: IF NO GO GET NEXT CHAR.
034412	016746	144536		MOV	\$NULL,-(SP)	:: GET # OF FILLER CHARS. NEEDED
						:: AND THE NULL CHAR.
034416	105366	000001		DECB	1(SP)	:: DOES A NULL NEED TO BE TYPED?
034422	002770			BLT	6\$	:: BR IF NO--GO POP THE NULL OFF OF STACK
034424	004767	000032		JSR	PC,\$TYPEC	:: GO TYPE A NULL
034430	105367	000142		DECB	\$CHARCNT	:: DO NOT COUNT AS A COUNT
034434	000770			BR	7\$	:: LOOP
				:HORIZONTAL TAB	PROCESSOR	
034436	112716	000040		MOV	#'(SP)	:: REPLACE TAB WITH SPACE
034442	004767	000014		JSR	PC,\$TYPEC	:: TYPE A SPACE
034446	132767	000007	000122	BITB	#7,\$CHARCNT	:: BRANCH IF NOT AT
034454	001372			BNE	9\$	:: TAB STOP
034456	005726			TST	(SP)+	:: POP SPACE OFF STACK
034460	000724			BR	2\$	:: GET NEXT CHARACTER
034462	105777	144462		TSTB	@\$TPS	:: WAIT UNTIL PRINTER IS READY
034466	100375			BPL	\$TYPEC	
034470	116677	000002	144454	MOV	2(SP),@\$TPB	:: LOAD CHAR TO BE TYPED INTO DATA REG.
034476	105777	144442		TSTB	@\$TKS	:: SEE IF KEYBOARD IS TALKING.
034502	100021			BPL	2\$	:: BRANCH IF IT ISN'T.
034504	017746	144436		MOV	@\$TKB,-(SP)	:: PUSH CHARACTER ONTO STACK.
034510	042716	177600		BIC	#177600,(SP)	:: BIT CLEAR TOP BYTE AND PARITY BIT.
034514	022726	000023		CMP	#23,(SP)+	:: SEE IF THIS IS A ^S.
034520	001012			BNE	2\$	:: BRANCH TO CONTINUE IF IT ISN'T.
034522	105777	144416		TSTB	@\$TKS	:: WAIT FOR ANOTHER INPUT.
034526	100375			BPL	3\$	:: BRANCH BACK IF NOT READY.
034530	017746	144412		MOV	@\$TKB,-(SP)	:: PUSH NEXT CHARACTER ON STACK.
034534	042716	177600		BIC	#177600,(SP)	:: BIT CLEAR TOP BYTE AND PARITY BIT.

```

034540 022726 000021      CMP      #21,(SP)+      ;;SEE IF THIS IS A ^Q.
034544 001366              BNE      3$            ;;BRANCH BACK FOR MORE WAIT IF NOT.
034546 122766 000015 000002 2$:  CMPB    #CR,2(SP)      ;;IS CHARACTER A CARRIAGE RETURN?
034554 001003              BNE      1$            ;;BRANCH IF NO
034556 105067 000014      CLRB    $CHARCNT      ;;YES--CLEAR CHARACTER COUNT
034562 000406              BR       $TYPEX       ;;EXIT
034564 122766 000012 000002 1$:  CMPB    #LF,2(SP)      ;;IS CHARACTER A LINE FEED?
034572 001402              BEQ     $TYPEX       ;;BRANCH IF YES
034574 105227              INCB    (PC)+         ;;COUNT THE CHARACTER
034576 000000      $CHARCNT: .WORD 0    ;;CHARACTER COUNT STORAGE
034600 000207      $TYPEX: RTS      PC

```

5652  
5653

```

.SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS    ;;CALL FOR TYPEOUT
*   .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON    ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC    ;;CALL FOR TYPEOUT
034602 017646 000000 000211 $TYPOS: MOV    @ (SP),-(SP)    ;;PICKUP THE MODE
034606 116667 000001          MOVB   1(SP), $OFILL    ;;LOAD ZERO FILL SWITCH
034614 112667 000207          MOVB   (SP)+, $OMODE+1  ;;NUMBER OF DIGITS TO TYPE
034620 062716 000002          ADD    #2,(SP)        ;;ADJUST RETURN ADDRESS
034624 000406              BR     $TYPON
034626 112767 000001 000171 $TYPOC: MOVB  #1, $OFILL    ;;SET THE ZERO FILL SWITCH
034634 112767 000006 000165          MOVB  #6, $OMODE+1    ;;SET FOR SIX(6) DIGITS
034642 112767 000005 000154 $TYPON: MOVB  #5, $OCNT    ;;SET THE ITERATION COUNT
034650 010346              MOV    R3,-(SP)      ;;SAVE R3
034652 010446              MOV    R4,-(SP)      ;;SAVE R4
034654 010546              MOV    R5,-(SP)      ;;SAVE R5
034656 116704 000145          MOVB  $OMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
034662 005404              NEG    R4
034664 062704 000006          ADD    #6,R4        ;;SUBTRACT IT FOR MAX. ALLOWED
034670 110467 000132          MOVB  R4, $OMODE    ;;SAVE IT FOR USE
034674 116704 000125          MOVB  $OFILL,R4     ;;GET THE ZERO FILL SWITCH
034700 016605 000012          MOV    12(SP),R5    ;;PICKUP THE INPUT NUMBER
034704 005003              CLR    R3           ;;CLEAR THE OUTPUT WORD
034706 006105              1$:  ROL    R5         ;;ROTATE MSB INTO 'C'
034710 000404              BR     3$          ;;GO DO MSB
034712 006105              2$:  ROL    R5         ;;FORM THIS DIGIT
034714 006105              ROL    R5

```



```

034716 006105          ROL      R5
034720 010503          MOV      R5,R3
034722 006103          3$:    ROL      R3          ;;GET LSB OF THIS DIGIT
034724 105367 000076  DECB     $OMODE      ;;TYPE THIS DIGIT?
034730 100016          BPL      7$          ;;BR IF NO
034732 042703 177770  BIC      #177770,R3  ;;GET RID OF JUNK
034736 001002          BNE      4$          ;;TEST FOR 0
034740 005704          TST      R4          ;;SUPPRESS THIS 0?
034742 001403          BEQ      5$          ;;BR IF YES
034744 005204          4$:    INC      R4          ;;DON'T SUPPRESS ANYMORE 0'S
034746 052703 000060  BIS      #'0,R3     ;;MAKE THIS DIGIT ASCII
034752 052703 000040  5$:    BIS      #' ,R3  ;;MAKE ASCII IF NOT ALREADY
034756 110367 000040  MOVVB    R3,8$      ;;SAVE FOR TYPING
034762 104401 035022  TYPE     ,8$        ;;GO TYPE THIS DIGIT
034766 105367 000032  7$:    DECB     $OCNT  ;;COUNT BY 1
034772 003347          BGT      2$          ;;BR IF MORE TO DO
034774 002402          BLT      6$          ;;BR IF DONE
034776 005204          INC      R4          ;;INSURE LAST DIGIT ISN'T A BLANK
035000 000744          BR       2$          ;;GO DO THE LAST DIGIT
035002 012605          6$:    MOV      (SP)+,R5  ;;RESTORE R5
035004 012604          MOV      (SP)+,R4  ;;RESTORE R4
035006 012603          MOV      (SP)+,R3  ;;RESTORE R3
035010 016666 000002 000004  MOV      2(SP),4(SP) ;;SET THE STACK FOR RETURNING
035016 012616          MOV      (SP)+,(SP)
035020 000002          RTI
035022 000          8$:    .BYTE    0          ;;RETURN
035023 000          .BYTE    0          ;;STORAGE FOR ASCII DIGIT
035024 000          $OCNT:  .BYTE    0          ;;TERMINATOR FOR TYPE ROUTINE
035025 000          $OFILL: .BYTE    0          ;;OCTAL DIGIT COUNTER
035026 000000          $OMODE: .WORD    0          ;;ZERO FILL SWITCH
                                ;;NUMBER OF DIGITS TO TYPE
  
```

5654  
5655

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
035030 112767 000001 000236 $ATY1: MOVVB #1,$FFLG  ;;TO REPORT FATAL ERROR
035036 112767 000001 000226 $ATY3: MOVVB #1,$MFLG  ;;TO TYPE A MESSAGE
035044 000403          BR       $ATYC
035046 112767 000001 000220 $ATY4: MOVVB #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
035054          $ATYC:
035054 010046          MOV      R0,-(SP)    ;;PUSH R0 ON STACK
035056 010146          MOV      R1,-(SP)    ;;PUSH R1 ON STACK
035060 105767 000206          TSTB    $MFLG      ;;SHOULD TYPE A MESSAGE?
035064 001450          BEQ      5$          ;;IF NOT: BR
035066 122767 000001 144242  CMPB    #APTENV,$ENV  ;;OPERATING UNDER APT?
035074 001031          BNE      3$          ;;IF NOT: BR
035076 132767 000100 144233  BITB    #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
035104 001425          BEQ      3$          ;;IF NOT: BR
035106 017600 000004          MOV      @4(SP),R0   ;;GET MESSAGE ADDR.
035112 062766 000002 000004  ADD      #2,4(SP)    ;;BUMP RETURN ADDR.
035120 005767 144172          1$:    TST      $MSGTYPE  ;;SEE IF DONE W/ LAST XMISSION?
035124 001375          BNE      1$          ;;IF NOT: WAIT
035126 010067 144200          MOV      R0,$MSGAD  ;;PUT ADDR IN MAILBOX
035132 105720          2$:    TSTB    (R0)+      ;;FIND END OF MESSAGE
035134 001376          BNE      2$
035136 166700 144170          SUB      $MSGAD,R0  ;;SUB START OF MESSAGE
035142 006200          ASR      R0          ;;GET MESSAGE LNTH IN WORDS
035144 010067 144164          MOV      R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
035150 012767 000004 144140  MOV      #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
  
```

```

035156 000413 BR 5$
035160 017667 000004 000016 3$: MOV @4(SP),4$ ::PUT MSG ADDR IN JSR LINKAGE
035166 062766 000002 000004 ADD #2,4(SP) ::BUMP RETURN ADDRESS
035174 016746 142576 MOV 177776,-(SP) ::PUSH 177776 ON STACK
035200 004767 177044 JSR PC,$TYPE ::CALL TYPE MACRO
035204 000000 4$: .WORD 0
035206 5$:
035206 105767 000062 10$: TSTB $FFLG ::SHOULD REPORT FATAL ERROR?
035212 001416 BEQ 12$ ::IF NOT: BR
035214 005767 144116 TST $ENV ::RUNNING UNDER APT?
035220 001413 BEQ 12$ ::IF NOT: BR
035222 005767 144070 11$: TST $MSGTYPE ::FINISHED LAST MESSAGE?
035226 001375 BNE 11$ ::IF NOT: WAIT
035230 017667 000004 144062 MOV @4(SP),$FATAL ::GET ERROR #
035236 062766 000002 000004 ADD #2,4(SP) ::BUMP RETURN ADDR.
035244 005267 144046 INC $MSGTYPE ::TELL APT TO TAKE ERROR
035250 105067 000020 12$: CLRB $FFLG ::CLEAR FATAL FLAG
035254 105067 000013 CLRB $LFLG ::CLEAR LOG FLAG
035260 105067 000006 CLRB $MFLG ::CLEAR MESSAGE FLAG
035264 012601 MOV (SP)+,R1 ::POP STACK INTO R1
035266 012600 MOV (SP)+,R0 ::POP STACK INTO R0
035270 000207 RTS PC ::RETURN
035272 000 $MFLG: .BYTE 0 ::MESSG. FLAG
035273 000 $LFLG: .BYTE 0 ::LOG FLAG
035274 000 $FFLG: .BYTE 0 ::FATAL FLAG
          .EVEN
          APTSIZE=200
          APTENV=001
          APTSPOOL=100
          APTCSUP=040
  
```

5656  
5657

000200  
000001  
000100  
000040

```

.SBTTL TTY INPUT ROUTINE
:*****
.ENABL LSB
:*****
:SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
:ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
:SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
:WHEN OPERATING IN TTY FLAG MODE.
$CKSWR: CMP #SWREG,SWR ::IS THE SOFT-SWR SELECTED?
        BNE 15$ ::BRANCH IF NO
        TSTB @TKS ::CHAR THERE?
        BPL 15$ ::IF NO, DON'T WAIT AROUND
        MOVB @TKB,-(SP) ::SAVE THE CHAR
        BIC #^C177,(SP) ::STRIP-OFF THE ASCII
        CMP #7,(SP)+ ::IS IT A CONTROL G?
        BNE 15$ ::NO, RETURN TO USER
        CMPB $AUTOB,#1 ::ARE WE RUNNING IN AUTO-MODE?
        BEQ 15$ ::BRANCH IF YES
        TYPE , $CNTLG ::ECHO THE CONTROL-G (^G)
        $GTSWR: TYPE , $MSWR ::TYPE CURRENT CONTENTS
        MOV SWREG,-(SP) ::SAVE SWREG FOR TYPEOUT
        TYPOC ::GO TYPE--OCTAL ASCII(ALL DIGITS)
        TYPE , $MNEW ::PROMPT FOR NEW SWR
        19$: CLR -(SP) ::CLEAR COUNTER
        CLR -(SP) ::THE NEW SWR
        7$: TSTB @TKS ::CHAR THERE?
  
```

```

035374 100375          BPL      7$          ;; IF NOT TRY AGAIN
035376 117746 143544  MOVB    @STKB, -(SP)    ;; PICK UP CHAR
035402 042716 177600  BIC    #^C177, (SP)    ;; MAKE IT 7-BIT ASCII
035406 021627 000025  9$:    CMP    (SP), #25    ;; IS IT A CONTROL-U?
035412 001005          BNE    10$          ;; BRANCH IF NOT
035414 104401 035700  TYPE   , $CNTLU       ;; YES, ECHO CONTROL-U (^U)
035420 062706 000006  20$:  ADD    #6, SP        ;; IGNORE PREVIOUS INPUT
035424 000757          BR     19$          ;; LET'S TRY IT AGAIN
035426 021627 000015  10$:  CMP    (SP), #15    ;; IS IT A <CR>?
035432 001022          BNE    16$          ;; BRANCH IF NO
035434 005766 000004  TST    4(SP)          ;; YES, IS IT THE FIRST CHAR?
035440 001403          BEQ    11$          ;; BRANCH IF YES
035442 016677 000002 143470 MOV    2(SP), @SWR     ;; SAVE NEW SWR
035450 062706 000006  11$:  ADD    #6, SP        ;; CLEAR UP STACK
035454 104401 001313  14$:  TYPE   , $CRLF       ;; ECHO <CR> AND <LF>
035460 126727 143451 000001 CMPB   $INTAG, #1     ;; RE-ENABLE TTY KBD INTERRUPTS?
035466 001003          BNE    15$          ;; BRANCH IF NOT
035470 012777 000100 143446 MOV    #100, @STKS    ;; RE-ENABLE TTY KBD INTERRUPTS
035476 000002          RTI                    ;; RETURN
035500 004767 176756  16$:  JSR    PC, $TYPEC     ;; ECHO CHAR
035504 021627 000060  CMP    (SP), #60     ;; CHAR < 0?
035510 002420          BLT    18$          ;; BRANCH IF YES
035512 021627 000067  CMP    (SP), #67     ;; CHAR > 7?
035516 003015          BGT    18$          ;; BRANCH IF YES
035520 042726 000060  BIC    #60, (SP)+    ;; STRIP-OFF ASCII
035524 005766 000002  TST    2(SP)          ;; IS THIS THE FIRST CHAR
035530 001403          BEQ    17$          ;; BRANCH IF YES
035532 006316          ASL    (SP)          ;; NO, SHIFT PRESENT
035534 006316          ASL    (SP)          ;; CHAR OVER TO MAKE
035536 006316          ASL    (SP)          ;; ROOM FOR NEW ONE.
035540 005266 000002  17$:  INC    2(SP)          ;; KEEP COUNT OF CHAR
035544 056616 177776  BIS    -2(SP), (SP)  ;; SET IN NEW CHAR
035550 000707          BR     7$          ;; GET THE NEXT ONE
035552 104401 001312  18$:  TYPE   , $QUES       ;; TYPE ?<CR><LF>
035556 000720          BR     20$          ;; SIMULATE CONTROL-U

```

.DSABL LSB  
 \*\*\*\*\*

\*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY  
 \*CALL:  
 \* RDCHR ;: INPUT A SINGLE CHARACTER FROM THE TTY  
 \* RETURN HERE ;: CHARACTER IS ON THE STACK  
 \* ;: WITH PARITY BIT STRIPPED OFF

```

035560 011646          $RDCHR: MOV    (SP), -(SP)    ;; PUSH DOWN THE PC
035562 016666 000004 000002 MOV    4(SP), 2(SP)   ;; SAVE THE PS
035570 105777 143350  1$:  TSTB   @STKS        ;; WAIT FOR
035574 100375          BPL    1$          ;; A CHARACTER
035576 117766 143344 000004 MOVB   @STKB, 4(SP)   ;; READ THE TTY
035604 042766 177600 000004 BIC    #^C<177>, 4(SP) ;; GET RID OF JUNK IF ANY
035612 026627 000004 000023 CMP    4(SP), #23    ;; IS IT A CONTROL-S?
035620 001013          BNE    3$          ;; BRANCH IF NO
035622 105777 143316  2$:  TSTB   @STKS        ;; WAIT FOR A CHARACTER
035626 100375          BPL    2$          ;; LOOP UNTIL ITS THERE
035630 117746 143312 MOVB   @STKB, -(SP)   ;; GET CHARACTER
035634 042716 177600  BIC    #^C177, (SP)  ;; MAKE IT 7-BIT ASCII
035640 022627 000021  CMP    (SP)+, #21    ;; IS IT A CONTROL-Q?
035644 001366          BNE    2$          ;; IF NOT DISCARD IT

```

```
035646 000750          BR      1$          ;;YES, RESUME
035650 026627 000004 000140 3$:  CMP      4(SP),#140      ;;IS IT UPPER CASE?
035656 002407          BLT      4$          ;;BRANCH IF YES
035660 026627 000004 000175  CMP      4(SP),#175      ;;IS IT A SPECIAL CHAR?
035666 003003          BGT      4$          ;;BRANCH IF YES
035670 042766 000040 000004  BIC      #40,4(SP)      ;;MAKE IT UPPER CASE
035676 000002 4$:  RTI          ;;GO BACK TO USER
035700      136      125      015  $CNTLU: .ASCIZ /^U/<15><12>  ;;CONTROL 'U'
035703      012      000          ;;
035705      136      107      015  $CNTLG: .ASCIZ /^G/<15><12>  ;;CONTROL 'G'
035710      012      000          ;;
035712      015      012      123  $MSWR:  .ASCIZ <15><12>/SWR = /
035715      127      122      040
035720      075      040      000
035723      040      040      116  $MNEW:  .ASCIZ / NEW = /
035726      105      127      040
035731      075      040      000
```

5658  
5659

.SBTTL TRAP DECODER

```
*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.
```

```
035734 010046          $TRAP:  MOV      R0,-(SP)      ;;SAVE R0
035736 016600 000002  MOV      2(SP),R0      ;;GET TRAP ADDRESS
035742 005740          TST      -(R0)         ;;BACKUP BY 2
035744 111000          MOV      (R0),R0      ;;GET RIGHT BYTE OF TRAP
035746 006300          ASL      R0           ;;POSITION FOR INDEXING
035750 016000 035770  MOV      $TRPAD(R0),R0  ;;INDEX TO TABLE
035754 000200          RTS      R0           ;;GO TO ROUTINE
```

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO

```
035756 011646          $TRAP2: MOV      (SP),-(SP)   ;;MOVE THE PC DOWN
035760 016666 000004 000002  MOV      4(SP),2(SP)   ;;MOVE THE PSW DOWN
035766 000002          RTI          ;;RESTORE THE PSW
```

.SBTTL TRAP TABLE

```
*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
*BY THE 'TRAP' INSTRUCTION.
```

ROUTINE

```
035770 035756          $TRPAD: .WORD    $TRAP2
035772 034250          $TYPE   ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
035774 034626          $TYPOC  ;;CALL=TYPOC   TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
035776 034602          $TYPOS  ;;CALL=TYPOS   TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
036000 034642          $TYPON  ;;CALL=TYPON   TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
036002 035346          $GTSWR  ;;CALL=GTSWR   TRAP+5(104405)  GET SOFT-SWR SETTING
036004 035276          $CKSWR  ;;CALL=CKSWR   TRAP+6(104406)  TEST FOR CHANGE IN SOFT-SWR
036006 035560          $RDCHR  ;;CALL=RDCHR   TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
036010 034154          $SAVREG ;;CALL=SAVREG   TRAP+10(104410) SAVE R0-R5 ROUTINE
036012 034212          $RESREG ;;CALL=RESREG   TRAP+11(104411) RESTORE R0-R5 ROUTINE
5660 036014 036754          .RSET  ;;CALL=RSETUP   TRAP+12(104412) ROUTINE TO INITIALIZE AFTER EVERY TEST
5661 036016 036746          .LPER  ;;CALL=LPER    TRAP+13(104413) ROUTINE TO SET LOOP ON ERROR ADDRESS
5662      000030          $TERM=.-$TRPAD
```

5660  
5661  
5662  
5663  
5664

.SBTTL POWER DOWN AND UP ROUTINES

```
*****
;POWER DOWN ROUTINE
```

```

036020 012737 036176 000024 $PWRDN: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST UP
036026 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
036034 010046      MOV    R0,-(SP)      ;;PUSH R0 ON STACK
036036 010146      MOV    R1,-(SP)      ;;PUSH R1 ON STACK
036040 010246      MOV    R2,-(SP)      ;;PUSH R2 ON STACK
036042 010346      MOV    R3,-(SP)      ;;PUSH R3 ON STACK
036044 010446      MOV    R4,-(SP)      ;;PUSH R4 ON STACK
036046 010546      MOV    R5,-(SP)      ;;PUSH R5 ON STACK
036050 017746 143064      MOV    @SWR,-(SP)    ;;PUSH @SWR ON STACK
036054 010667 000122      MOV    SP,$SAVR6    ;;SAVE SP
036060 012737 036072 000024      MOV    #$PWRUP,@#PWRVEC ;;SET UP VECTOR
036066 000000      HALT
036070 000776      BR     -2           ;;HANG UP
;*****
;POWER UP ROUTINE
036072 012737 036176 000024 $PWRUP: MOV    #$ILLUP,@#PWRVEC ;;SET FOR FAST DOWN
036100 016706 000076      MOV    $SAVR6,SP    ;;GET SP
036104 005067 000072      CLR    $SAVR6       ;;WAIT LOOP FOR THE TTY
036110 005267 000066      1$:   INC    $SAVR6   ;;WAIT FOR THE INC
036114 001375      BNE    1$           ;;OF WORD
036116 012677 143016      MOV    (SP)+,@SWR   ;;POP STACK INTO @SWR
036122 012605      MOV    (SP)+,R5    ;;POP STACK INTO R5
036124 012604      MOV    (SP)+,R4    ;;POP STACK INTO R4
036126 012603      MOV    (SP)+,R3    ;;POP STACK INTO R3
036130 012602      MOV    (SP)+,R2    ;;POP STACK INTO R2
036132 012601      MOV    (SP)+,R1    ;;POP STACK INTO R1
036134 012600      MOV    (SP)+,R0    ;;POP STACK INTO R0
036136 012737 036020 000024      MOV    #$PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
036144 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
036152 104401      TYPE                                ;;REPORT THE POWER FAILURE
036154 037150      $PWRMG: .WORD  POWERM                ;;POWER FAIL MESSAGE POINTER
036156 012716      MOV    (PC)+,(SP)  ;;RESTART AT START
036160 004336      $PWRAD: .WORD  START                 ;;RESTART ADDRESS
036162 042766 000020 000002      BIC    #20,2(SP)   ;;CLEAR 'T' BIT
036170 005067 175234      CLR    $TBIT       ;;CLEAR THE 'T' BIT FLAG
036174 000002      RTI
036176 000000      $ILLUP: HALT      ;;THE POWER UP SEQUENCE WAS STARTED
036200 000776      BR     -2           ;; BEFORE THE POWER DOWN WAS COMPLETE
036202 000000      $SAVR6: 0          ;;PUT THE SP HERE

```

5665  
5666  
5667  
5668

5669  
5670  
5671  
5672  
5673  
5674

5675 036204 104401  
5676 036206 001313  
5677 036210 113737 001102 001232  
5678 036216 042737 177400 001232  
5679 036224 013737 001116 001234  
5680 036232 010046  
5681

```

.SBTTL ERROR TYPE OUT ROUTINE
;*****
;*****
;THIS ROUTINE IS CALLED TO TYPE AN ERROR MESSAGE WHICH IS INCLUDED
;IN THE ERROR MESSAGE DATA TABLE. IT IS CALLED BY THE $ERROR ROUTINE
;OR BY FIRST SETTING $ITEMB EQUAL TO THE ERROR TABLE ITEM TO BE PRINTED
;OUT AND THEN EXECUTING A:
;*
;*      JSR    PC,ERTYPE
;*
ERTYPE: TYPE                                ;TYPE A CRLF
        .WORD  $CRLF
        MOVB  @#$STNM,@#$TMP0
        BIC   #177400,@#$TMP0
        MOV   @#$ERRPC,@#$TMP1                ;GET PC OF CALL
        MOV   R0,-(SP)                        ;SAVE R0

```

5682	036234	113700	001114	MOVB	@#\$ITEMB,R0	;GET THE ITEM NUMBER.
5683	036240	042700	177400	BIC	#177400,R0	
5684	036244	001005		BNE	1\$	
5685						
5686	036246	013746	001116	MOV	@#\$ERRPC,-(SP)	;IF ZERO THEN JUST
5687	036252	104402		TYPOC		;PRINT THE PC
5688	036254	000137	036654	JMP	@#ERT5	
5689						
5690	036260	022700	000377	1\$: CMP	#377,R0	
5691	036264	001005		BNE	20\$	
5692	036266	016600	000004	MOV	4(SP),R0	
5693	036272	011000		MOV	(R0),R0	
5694	036274	062700	000400	ADD	#400,R0	
5695	036300	005300		20\$: DEC	R0	;OTHERWISE MAKE R0 AN
5696	036302	006300		ASL	R0	;INDEX FOR THE TABLE.
5697	036304	006300		ASL	R0	
5698	036306	006300		ASL	R0	
5699	036310	062700	001442	ADD	#\$ERRTB,R0	
5700						
5701	036314	012037	036324	MOV	(R0)+,@#2\$	;PICK UP THE ADDRESS
5702	036320	001404		BEQ	3\$	;OF THE EM, ERROR MESSAGE
5703	036322	104401		TYPE		
5704	036324	000000		2\$: .WORD	0	
5705	036326	104401		TYPE		
5706	036330	001313		.WORD	\$CRLF	
5707						
5708	036332	012037	036342	3\$: MOV	(R0)+,@#4\$	;GET THE DH,DATA HEADER
5709	036336	001404		BEQ	5\$	
5710	036340	104401		TYPE		
5711	036342	000000		4\$: .WORD	0	
5712	036344	104401		TYPE		
5713	036346	001313		.WORD	\$CRLF	
5714						
5715	036350	010146		5\$: MOV	R1,-(SP)	;SAVE R1,R2 AND R3
5716	036352	010246		MOV	R2,-(SP)	
5717	036354	010346		MOV	R3,-(SP)	
5718						
5719	036356	012001		MOV	(R0)+,R1	;GET THE ADDRESS OF THE
5720						;DATA TABLE.
5721	036360	001002		BNE	6\$	
5722	036362	000137	036642	JMP	@#ERT4	;RETURN IF NO DATA.
5723						
5724	036366	011000		6\$: MOV	(R0),R0	;GET A POINTER TO THE DATA
5725						;FORMAT TABLE.
5726	036370	105710		ERT1: TSTB	(R0)	;FORMAT ZERO?
5727	036372	001004		BNE	7\$	
5728						
5729	036374	013146		MOV	@(R1)+,-(SP)	;FORMAT ZERO SO TYPE
5730	036376	104402		TYPOC		;AN OCTAL NUMBER.
5731	036400	000137	036624	JMP	@#ERT2	
5732						
5733	036404			7\$: CMPB	#2,(R0)	;FORMAT TWO?
5734	036404	122710	000002	8\$: BNE	9\$	
5735	036410	001011				
5736						
5737	036412	013102		MOV	@(R1)+,R2	;FORMAT TWO SO TYPE TWO
5738	036414	012246		MOV	(R2)+,-(SP)	;OCTAL NUMBERS.

5739	036416	104402			TYPOC		
5740	036420	104401			TYPE		
5741	036422	037217			.WORD	SPACE	
5742	036424	011246			MOV	(R2),-(SP)	
5743	036426	104402			TYPOC		
5744	036430	000137	036624		JMP	@#ERT2	
5745							
5746	036434	122710	000003	9\$:	CMPB	#3,(R0)	;FORMAT THREE?
5747	036440	001021			BNE	10\$	
5748							
5749	036442	013102			MOV	@(R1)+,R2	;FORMAT THREE SO TYPE
5750	036444	012246			MOV	(R2)+,-(SP)	;FOUR OCTAL NUMBERS.
5751	036446	104402			TYPOC		
5752	036450	104401			TYPE		
5753	036452	037217			.WORD	SPACE	
5754	036454	012246			MOV	(R2)+,-(SP)	
5755	036456	104402			TYPOC		
5756	036460	104401			TYPE		
5757	036462	037217			.WORD	SPACE	
5758	036464	012246			MOV	(R2)+,-(SP)	
5759	036466	104402			TYPOC		
5760	036470	104401			TYPE		
5761	036472	037217			.WORD	SPACE	
5762	036474	011246			MOV	(R2),-(SP)	
5763	036476	104402			TYPOC		
5764	036500	000137	036624		JMP	@#ERT2	
5765							
5766	036504	122710	000004	10\$:	CMPB	#4,(R0)	;FORMAT FOUR?
5767	036510	001005			BNE	11\$	
5768							
5769	036512	013146			MOV	@(R1)+,-(SP)	;FORMAR FOUR SO TYPE
5770	036514	104403			TYPOS		;AN OCTAL NUMBER
5771	036516	016			.BYTE	16	;SUPPRESSING LEADING ZEROES.
5772	036517	000			.BYTE	0	
5773	036520	000137	036624		JMP	@#ERT2	
5774							
5775	036524	122710	000005	11\$:	CMPB	#5,(R0)	;FORMAT FIVE?
5776	036530	001006			BNE	13\$	
5777							
5778	036532	012137	036540		MOV	(R1)+,@#12\$	;FORMAT FIVE SO TYPE AN
5779	036536	104401			TYPE		;ASCIZ STRING.
5780	036540	000000		12\$:	.WORD	0	
5781	036542	000137	036630		JMP	@#ERT3	
5782							
5783	036546	122710	000011	13\$:	CMPB	#11,(R0)	;FORMAT ELEVEN?
5784	036552	001006			BNE	15\$	
5785							
5786	036554	013137	036562		MOV	@(R1)+,@#14\$	;FORMAT ELEVEN SO PICK
5787	036560	104401			TYPE		;A POINTER TO AN ASCIZ
5788	036562	000000		14\$:	.WORD	0	;STRING.
5789	036564	000137	036630		JMP	@#ERT3	
5790							
5791	036570	122710	000012	15\$:	CMPB	#12,(R0)	;FORMAT TWELVE?
5792	036574	001012			BNE	17\$	
5793							
5794	036576	013102			MOV	@(R1)+,R2	;FORMAT TWELVE SO TYPE
5795	036600	012703	000006		MOV	#6,R3	;TYPE SIX OCTAL NUMBERS

```

5796 036604 012246      16$:  MOV      (R2)+,-(SP)
5797 036606 104402      TYPOC
5798 036610 104401      TYPE
5799 036612 037217      .WORD   SPACE
5800 036614 077305      SOB     R3,16$
5801 036616 000137 036624    JMP     @#ERT2
5802
5803 036622 000000      17$:  HALT                      ;UNDEFINED FORMAT FOR DATA?????
5804
5805 036624 104401      ERT2:  TYPE                      ;PRINT A TAB AFTER TYPING
5806 036626 037215      .WORD   $TAB                  ;AN DATA TABLE ENTRY
5807
5808
5809
5810 036630 005200      ERT3:  INC      R0                      ;POINT TO THE NEXT FORMAT
5811 036632 005711      TST     (R1)                  ;END OF DATA TABLE.
5812 036634 001402      BEQ     ERT4
5813 036636 000137 036370    JMP     @#ERT1
5814
5815 036642 104401      ERT4:  TYPE                      ;DONE.
5816 036644 001313      .WORD   $CRLF
5817 036646 012603      MOV     (SP)+,R3              ;RESTORE R1,R2 AND R3
5818 036650 012602      MOV     (SP)+,R2
5819 036652 012601      MOV     (SP)+,R1
5820 036654 012600      ERT5:  MOV     (SP)+,R0
5821 036656 000207      RTS      PC                  ;RESTORE R0.
5822
5823
5824
5825
5826
5827

```

.SBTTL FPP SPURIOUS TRAP TO 244 HANDLER

```

:*****
:*****
:*THIS ROUTINE HANDLES UNEXPECTED TRAPS TO THE FPP TRAP VECTOR AT 244.
:*THE LAST FPP INSTRUCTION EXECUTED AND ITS ADDRESS HAS BEEN RECORDED
:*THESE ALONG WITH THE FEC, FPS AND PC OF TRAP ARE REPORTED.
:*
FPSPUR: MOV     (SP),@#$TMP2      ;SAVE PC OF TRAP.
        CMP     (SP)+,(SP)+      ;RESTORE SP.
        STFPS  R0                ;GET FPS
        MOV     R0,@#$TMP3
        STST   R0                ;GET FEC
1$:     MOV     R0,@#$TMP4
        ERROR  +247
        RSETUP                    ;GO INITIALIZE THE FPS AND STACK; AND
                                   ;SEE IF THE USER HAS EXPRESSED
                                   ;THE DESIRE TO CHANGE THE SOFTWARE
                                   ;VIRTUAL CONSOLE SWITCH REGISTER (HAS
                                   ;THE USER TYPED CONTROL G?).
        JMP     @#$EOP

```

```

5840 036706 000137 033144
5841
5842
5843
5844

```

.SBTTL CPU SPURIOUS TRAP TO 4 HANDLER

```

:*****
:*****
:*THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 4.
:*

```

```

5845
5846

```



5847 036712 011637 001236  
5848 036716 022626  
5849 036720 104250  
5850 036722 104412

CPSPUR: MOV (SP),@#STMP2 ;SAVE PC OF TRAP.  
CMP (SP)+,(SP)+  
1\$: ERROR +250  
RSETUP

;GO INITIALIZE THE FPS AND STACK; AND  
;SEE IF THE USER HAS EXPRESSED  
;THE DESIRE TO CHANGE THE SOFTWARE  
;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
;THE USER TYPED CONTROL G?).

5851 036724 000137 033144  
5852  
5853  
5854  
5855

JMP @#\$EOP

.SBTTL CPU SPURIOUS TRAP TO 10 HANDLER

\*\*\*\*\*  
\*\*\*\*\*  
\*THIS ROUTINE REPORTS UNEXPECTED CPU TRAPS TO VECTOR 10.  
\*

5856  
5857  
5858 036730 011637 001236  
5859 036734 022626  
5860 036736 104251  
5861 036740 104412

CPTWO: MOV (SP),@#STMP2 ;SAVE PC OF TRAP.  
CMP (SP)+,(SP)+  
1\$: ERROR +251  
RSETUP

;GO INITIALIZE THE FPS AND STACK; AND  
;SEE IF THE USER HAS EXPRESSED  
;THE DESIRE TO CHANGE THE SOFTWARE  
;VIRTUAL CONSOLE SWITCH REGISTER (HAS  
;THE USER TYPED CONTROL G?).

5862 036742 000137 033144  
5863  
5864  
5865  
5866  
5867  
5868  
5869

JMP @#\$EOP

.SBTTL SET LOOP ON ERROR ADDRESS ROUTINE

\*\*\*\*\*  
\*\*\*\*\*  
\*

5870  
5871 036746 011637 001110  
5872 036752 000002  
5873  
5874  
5875

.LPER: MOV (SP),@#\$LPERR  
RTI

.SBTTL FLAG RESET AND CONSOLE TEST ROUTINE

\*\*\*\*\*  
\*\*\*\*\*  
\*THIS ROUTINE WILL BE CALLED AT THE END OF EACH TEST TO  
\*RESET THE STACK, CLEAR THE FPS AND SEE IF THE USER HAS TYPED  
\*CONTROL G ON THE TERMINAL. IF THE USER HAS TYPED CONTROL G AND  
\*THERE IS NO PHYSICAL CONSOLE SWITCH REGISTER THEN THE CONTENTS  
\*OF THE SOFTWARE SWITCH REGISTER WILL BE TYPED IN OCTAL ON THE  
\*TELETYPE AND THE USER CAN MODIFY IT.  
\*

5883 036754 023727 001140 177570  
5884  
5885 036762 001001  
5886 036764 104406  
5887  
5888  
5889  
5890 036766 012737 036660 000244  
5891 036774 012737 036712 000004  
5892 037002 012737 036730 000010

.RSET: CMP @#SWR,#177570  
BNE 1\$  
CKSWR  
1\$: MOV #FPSPUR,@#FPVECT  
MOV #CPSPUR,@#ERRVECT  
MOV #CPTWO,@#10

;SEE IF THERE IS A PHYSICAL  
;CONSOLE SWITCH REGISTER.  
;BRANCH IF NO.  
;OTHERWISE TYPE THE CONTENTS  
;OF THE PROGRAM VIRTUAL SWITCH REGISTER  
;AND GIVE THE USER A CHANCE TO  
;MODIFY IT.

```
5893 037010 011600      MOV      (SP),R0      ;SAVE RETURN ADDRESS.  
5894 037012 012706 001100  MCV      #STACK,SP   ;RESET THE STACK POINTER.  
5895 037016 005004      CLR      R4           ;CLEAR THE FPS.  
5896 037020 170104      LDFPS   R4  
5897 037022 000110      JMP      (R0)        ;RETURN.  
5898  
5899
```

```
5900  
5901  
5902  
5903  
5904 037024 124 122 101 .NLIST BEX  
5905 037042 105 130 120 ;THESE ARE SPECIAL MESSAGES:  
5906 037065 107 117 124 MSA1: .ASCIZ 'TRAPPED AT:'<TAB><TAB>  
MSA2: .ASCIZ 'EXPECTED TRAP AT:'<TAB>  
MSA3: .ASCIZ 'GOT R0:'<TAB><TAB>
```

```

5908 037077      105      130      120 MSA4:  .ASCIZ  'EXPECTED R0:'<TAB>
5909 037115      107      117      124 MSA5:  .ASCIZ  'GOT ACO:'<TAB><TAB>
5910 037130      105      130      120 MSA6:  .ASCIZ  'EXPECTED ACO:'<TAB><TAB>
5911
5912
5913 037150      200      120      117 POWERM: .ASCIZ  <CRLF>'POWER FAILURE. PROGRAM RESTARTING.'<CRLF>
5914 037215      011      000      $TAB:  .ASCIZ  <TAB>
5915 037217      040      040      000 SPACE:  .ASCIZ  ' '
5916 037222      101      103      040 MS1:    .ASCIZ  'AC OPERAND:'<TAB><TAB>
5917 037240      106      123      122 MS2:    .ASCIZ  'FSRC OPERAND:'<TAB><TAB>
5918 037260      101      103      060 MS3:    .ASCIZ  'ACO BEFORE EXECUTION:'<TAB>
5919 037307      101      103      060 MS4:    .ASCIZ  'ACO AFTER EXECUTION:'<TAB>
5920 037335      105      130      120 MS5:    .ASCIZ  'EXPECTED RESULT:'<TAB>
5921 037357      107      117      124 MS6:    .ASCIZ  'GOT RESULT:'<TAB><TAB>
5922 037375      106      122      101 MS7:    .ASCIZ  'FRACTIONAL RESULT:'<TAB>
5923 037421      111      116      124 MS10:   .ASCIZ  'INTEGER RESULT:'<TAB>
5924 037443      105      130      120 MS11:   .ASCIZ  'EXPECTED FRACTION:'<TAB>
5925 037467      105      130      120 MS12:   .ASCIZ  'EXPECTED INTEGER:'<TAB>
5926 037512      114      117      101 MS37:   .ASCIZ  'LOADED DATA:'
5927 037530      122      105      101 MS40:   .ASCIZ  'READ DATA:'
5928 037544      105      130      120 MS415:  .ASCIZ  'EXPECTED DATA:'
5929 037564      104      101      124 MS41:   .ASCIZ  'DATA IN (R0) FSRC:'
5930 037610      104      101      124 MS42:   .ASCIZ  'DATA IN ACO:'
5931 037626      107      117      124 MS43:   .ASCIZ  'GOT RESULT:'
5932 037643      105      130      120 MS44:   .ASCIZ  'EXPECTED RESULT:'
5933 037665      200      124      105 CORMES: .ASCIZ  <CRLF>'TEST 22, TESTING INTERRUPTS.'<CRLF>
5934
5935
5936                                     ;THESE ARE ERROR MESSAGES:
5937 037724      106      120      123 EM1:    .ASCIZ  'FPS BAD AFTER CMPD (R),A.'
5938 037756      101      103      060 EM2:    .ASCIZ  'ACO MODIFIED BY CMPD (R),A.'
5942 040012      106      120      123 EM3:    .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5943 040036      050      102      125      .ASCIZ  '(BUT ENBT) STATE 225 WENT TO 475 INSTEAD OF 075.'
5944 040117      106      120      123 EM4:    .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5945 040143      050      102      125      .ASCIZ  '(BUT ENBT) STATE 225 WENT TO 075 INSTEAD OF 475.'
5946 040224      106      120      123 EM5:    .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5947 040250      050      102      125      .ASCIZ  '(BUT ENBT) STATE 035 WENT TO 075 INSTEAD OF 475.'
5948 040331      106      120      123 EM6:    .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5949 040355      050      102      125      .ASCIZ  '(BUT ENBT) STATE 035 WENT TO 475 INSTEAD OF 075.'
5950 040436      106      120      123 EM7:    .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5951 040462      050      102      125      .ASCIZ  '(BUT ENBT Y8) STATE 777 SHOULD HAVE GONE TO 007.'
5952 040543      106      120      123 EM10:   .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5953 040567      050      102      125      .ASCIZ  '(BUT ENBT Y8) STATE 777 SHOULD HAVE GONE TO 405.'
5954 040650      106      120      123 EM11:   .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5955 040674      050      102      125      .ASCIZ  '(BUT NBIT ZBIT) STATE 456 SHOULD HAVE GONE TO 010.'
5956 040757      106      120      123 EM12:   .ASCII   'FPS BAD AFTER CMPD.'<CRLF>
5957 041003      050      102      125      .ASCIZ  '(BUT NBIT ZBIT) STATE 456 SHOULD HAVE GONE TO 110.'
5958 041066      106      120      123 EM13:   .ASCII   'FPS BAD AFTER CMPD.'<CRLF>

```

5959	041112	104	111	104		.ASCIZ	/DIDN'T TAKE THE PATH: STATE 456, TO 012, TO 363 TO 120./
5960	041202				EM14:	.ASCII	'FPS BAD AFTER CMPD.' <crlf&gt;< td=""> </crlf&gt;<>
	041202	106	120	123		.ASCIZ	'(BUT XNBT XZBT) STATE 363 WENT TO 140 INSTEAD OF 100.'
5961	041226	050	102	125			
5962	041314				EM15:	.ASCII	'FPS BAD AFTER CMPD.' <crlf&gt;< td=""> </crlf&gt;<>
	041314	106	120	123		.ASCIZ	'(BUT XNBT XZBT) STATE 363 WENT TO 100 INSTEAD OF 140.'
5963	041340	050	102	125			
5964	041426				EM16:	.ASCII	'FPS BAD AFTER CMPD.' <crlf&gt;< td=""> </crlf&gt;<>
	041426	106	120	123		.ASCIZ	/DIDN'T TAKE THE PATH: STATE 777, TO 407./
5965	041452	104	111	104		.ASCIZ	'DIVD (R),A TRAPPED TO 244. FSRC=0 AND FID=1.'
5966	041523	104	111	126	EM17:	.ASCIZ	'FPS BAD AFTER DIVD (R),A.'
5967	041600	106	120	123	EM20:	.ASCIZ	'FEC BAD AFTER DIVD (R),A.'
5968	041632	106	105	103	EM21:	.ASCIZ	'DIVD (R),A DIDN'T TRAP TO 244. FSRC=0 AND FID=0./
5969	041664	104	111	126	EM22:	.ASCIZ	'DIVF (R),A FAILED.'
5970	041745	104	111	126	EM23:	.ASCIZ	'FPS BAD AFTER DIVF (R),A.'
5971	041770	106	120	123	EM32:	.ASCIZ	'DIVF (R),A FAILED.'
5975	042022				EM24:	.ASCII	'(BUT Y61) WENT TO STATE 006 INSTEAD OF 206.'
	042022	104	111	126		.ASCIZ	'DIVF (R),A FAILED.'
5976	042044	050	102	125			
5977	042120				EM25:	.ASCII	'XOR OF SIGN BITS FAILED STATE 470.'
	042120	104	111	126		.ASCIZ	'DIVF (R),A FAILED.'
5978	042142	130	117	122			
5979	042205				EM26:	.ASCII	'(BUT Y61) WENT TO STATE 206 INSTEAD OF 006.'
	042205	104	111	126		.ASCIZ	'DIVF (R),A FAILED.'
5980	042227	050	102	125			
5981	042120				EM27=EM25		
5982	042303				EM30:	.ASCII	'TRUNCATION ERROR. FT=1.'
	042303	104	111	126		.ASCIZ	'DIVF (R),A FAILED.'
5983	042325	124	122	125			
5984	042355				EM31:	.ASCII	'ROUND ERROR. FT=0.'
	042355	104	111	126		.ASCIZ	'DIVF (R),A FAILED.'
5985	042377	122	117	125			
5986	042422	104	111	126	EM33:	.ASCIZ	'DIVD (R),A FAILED.'
5987	042445	106	120	123	EM34:	.ASCIZ	'FPS BAD AFTER DIVD (R),A.'
5991	042477				EM35:	.ASCII	'DIVD (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	042477	104	111	126		.ASCIZ	'TRUNCATION ERROR. FT=1.'
5992	042522	124	122	125			
5993	042552				EM36:	.ASCII	'DIVD (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	042552	104	111	126		.ASCIZ	'ROUND ERROR. FT=0.'
5994	042575	122	117	125			
5995	042620	115	125	114	EM37:	.ASCIZ	'MULF (R),A FAILED.'
5999	042643	106	120	123	EM40:	.ASCIZ	'FPS BAD AFTER MULF (R),A.'
6000	042675				EM41:	.ASCII	'MULF (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	042675	115	125	114		.ASCIZ	'SIGN BIT BAD STATE 511.'
6001	042720	123	111	107			
6002	042750				EM42:	.ASCII	'MULF (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	042750	115	125	114		.ASCIZ	'NORMALIZATION FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
6003	042773	116	117	122			
6004	043021	050	102	125		.ASCIZ	'(BUT Y62) STATE 252 WENT TO 044 INSTEAD OF 444.'
6005	043101				EM43:	.ASCII	'MULF (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	043101	115	125	114		.ASCIZ	'NORMALIZATION FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
6006	043124	116	117	122			
6007	043152	050	102	125		.ASCIZ	'(BUT Y62) STATE 252 WENT TO 444 INSTEAD OF 044.'
6008	043232				EM44:	.ASCII	'MULF (R),A FAILED.' <crlf&gt;< td=""> </crlf&gt;<>
	043232	115	125	114		.ASCIZ	'ROUND ERROR. FT=0.'
6009	043255	122	117	125			
6010	043300				EM45:		

6011	043300	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6012	043323	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
6016	043353	106	120	123	EM46:	.ASCIZ	'FPS BAD AFTER MULF (R),A.'
6017	043405	115	125	114	EM246:	.ASCIZ	'MULD (R),A FAILED.'
	043430				EM47:		
6018	043430	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6019	043453	102	101	104		.ASCII	'BAD CONSTANT USED IN THE MUL ALGORITHM.'
6020	043522	200	125	123		.ASCIZ	<CRLF>'USED 24 INSTEAD OF 56 STATE 020.'
	043564				EM50:		
6021	043564	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6022	043607	124	122	125		.ASCIZ	'TRUNCATION ERROR. FT=1.'
	043637				EM51:		
6023	043637	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6024	043662	122	117	125		.ASCIZ	'ROUND ERROR. FT=0.'
	043705				EM52:		
6025	043705	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6026	043730	102	101	104		.ASCIZ	'BAD CONSTANT USED IN ROUNDING, FT=0.'
6027	043775	106	120	123	EM111:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTED OVERFLOW.'
6028	044052	106	120	123	EM112:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTED UNDERFLOW.'
	044130				EM113:		
6029	044130	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6030	044153	105	130	120		.ASCIZ	'EXPECTING OVERFLOW, FIV=0.'
	044206				EM114:		
6031	044206	115	125	114		.ASCII	'MULF (R),A FAILED.'<CRLF>
6032	044231	105	130	120		.ASCIZ	'EXPECTING UNDERFLOW, FIU=0.'
6033	044265	115	125	114	EM115:	.ASCIZ	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6040	044343	115	125	114	EM116:	.ASCIZ	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
	044422				EM117:		
6041	044422	115	125	114		.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6042	044500	050	102	125		.ASCIZ	'(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115.'
	044560				EM120:		
6043	044560	115	125	114		.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6044	044636	050	102	125		.ASCIZ	'(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115.'
	044716				EM121:		
6045	044716	115	125	114		.ASCII	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6046	044773	050	102	125		.ASCIZ	'(BUT FIV) STATE 333 WENT TO 136 INSTEAD OF 116.'
	045053				EM122:		
6047	045053	115	125	114		.ASCII	'MULF (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6048	045130	050	102	125		.ASCIZ	'(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116.'
6049	045210	106	120	123	EM123:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTING OVERFLOW.'
6050	045266	106	120	123	EM124:	.ASCIZ	'FPS BAD AFTER MULF (R),A. EXPECTING UNDERFLOW.'
	045345				EM125:		
6051	045345	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6052	045370	105	130	120		.ASCIZ	'EXPECTING OVERFLOW, FIV=0.'
	045423				EM126:		
6053	045423	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6054	045446	105	130	120		.ASCIZ	'EXPECTING UNDERFLOW, FIU=0.'
6055	045502	115	125	114	EM127:	.ASCIZ	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6062	045560	115	125	114	EM130:	.ASCIZ	'MULD (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
	045637				EM131:		
6063	045637	115	125	114		.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
6064	045715	050	102	125		.ASCIZ	'(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115.'
	045775				EM132:		
6065	045775	115	125	114		.ASCII	'MULD (R),A FAILED.'<CRLF>
6066	046020	105	130	120		.ASCII	'EXPECTING UNDERFLOW, FIU=0.'
6067	046053	200	050	102		.ASCIZ	<CRLF>'(BUT FD) STATE 115 WENT TO 424 INSTEAD OF 425.'
	046133				EM133:		

6068	046133	115	125	114	.ASCII	'MULF (R),A TRAPPED TO 244 ON UNDERFLOW. FIU=0.'
	046211	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115.'
6069	046271				EM134:	
	046271	115	125	114	.ASCII	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6070	046346	050	102	125	.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 136 INSTEAD OF 116.'
6071	046426				EM135:	
	046426	115	125	114	.ASCII	'MULD (R),A FAILED.<CRLF>
6072	046451	105	130	120	.ASCII	'EXPECTING OVERFLOW, FIV=0.'
6073	046503	200	050	102	.ASCIIZ	<CRLF>'(BUT FD) STATE 116 WENT TO 424 INSTEAD OF 425.'
6074	046563				EM136:	
	046563	115	125	114	.ASCII	'MULD (R),A TRAPPED TO 244 ON OVERFLOW. FIV=0.'
6075	046640	050	102	125	.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116.'
6076	046720	106	105	103	EM137:	'FEC BAD AFTER MULF (R),A. EXPECTING OVERFLOW, FEC=10.'
6077	047006	106	105	103	EM140:	'FEC BAD AFTER MULF (R),A. EXPECTING UNDERFLOW, FEC=12.'
6078		043775			EM141=EM111	
6079		044052			EM142=EM112	
6080	047075				EM143:	
	047075	115	125	114	.ASCII	'MULF (R),A FAILED.<CRLF>
6081	047120	105	130	120	.ASCIIZ	'EXPECTING OVERFLOW, FIV=1.'
6082	047153				EM144:	
	047153	115	125	114	.ASCII	'MULF (R),A FAILED.<CRLF>
6083	047176	105	130	120	.ASCIIZ	'EXPECTING UNDERFLOW, FIU=1.'
6090	047232				EM145:	
	047232	115	125	114	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6091	047317	050	102	125	.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 115 INSTEAD OF 155.'
6092	047377				EM146:	
	047377	115	125	114	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6093	047464	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 115 INSTEAD OF 155.'
6094	047544				EM147:	
	047544	115	125	114	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
6095	047630	050	102	125	.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 116 INSTEAD OF 136.'
6096	047710				EM150:	
	047710	115	125	114	.ASCII	'MULF (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
6097	047774	050	102	125	.ASCIIZ	'(BUT FIV) STATE 133 WENT TO 116 INSTEAD OF 136.'
6098	050054	106	105	103	EM151:	'FEC BAD AFTER MULD (R),A. EXPECTING OVERFLOW, FEC=10.'
6099	050142	106	105	103	EM152:	'FEC BAD AFTER MULD (R),A. EXPECTING UNDERFLOW, FEC=12.'
6100		045210			EM153=EM123	
6101		045266			EM154=EM124	
6102	050231				EM155:	
	050231	115	125	114	.ASCII	'MULD (R),A FAILED.<CRLF>
6103	050254	105	130	120	.ASCIIZ	'EXPECTING OVERFLOW, FIV=1.'
6104	050307				EM156:	
	050307	115	125	114	.ASCII	'MULD (R),A FAILED.<CRLF>
6105	050332	105	130	120	.ASCIIZ	'EXPECTING UNDERFLOW, FIU=1.'
6112	050366				EM157:	
	050366	115	125	114	.ASCII	'MULD (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6113	050453	050	102	125	.ASCIIZ	'(BUT FIU) STATE 331 WENT TO 115 INSTEAD OF 155.'
6114	050533				EM160:	
	050533	115	125	114	.ASCII	'MULD (R),A FAILED.<CRLF>
6115	050556	105	130	120	.ASCII	'EXPECTING UNDERFLOW, FIU=1.'
6116	050611	200	050	102	.ASCIIZ	<CRLF>'(BUT FD) STATE 155 WENT TO 426 INSTEAD OF 427.'
6117	050671				EM161:	
	050671	115	125	114	.ASCII	'MULD (R),A FAILED TO TRAP TO 244 ON UNDERFLOW. FIU=1.'
6118	050756	050	102	125	.ASCIIZ	'(BUT FIU) STATE 137 WENT TO 115 INSTEAD OF 155.'
6119	051036				EM162:	
	051036	115	125	114	.ASCII	'MULD (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
6120	051122	050	102	125	.ASCIIZ	'(BUT FIV) STATE 333 WENT TO 116 INSTEAD OF 136.'

6121	051202				EM163:	
	051202	115	125	114	.ASCII	'MULD (R),A FAILED.'<CRLF>
6122	051225	105	130	120	.ASCII	'EXPECTING OVERFLOW, FIV=1.'
6123	051257	200	050	102	.ASCIZ	<CRLF>'(BUT FD) STATE 700 WENT TO 426 INSTEAD OF 427.'
6124	051337				EM164:	
	051337	115	125	114	.ASCII	'MULD (R),A FAILED TO TRAP TO 244 ON OVERFLOW. FIV=1.'
6125	051423	050	102	125	.ASCIZ	'(BUT FIV) STATE 133 WENT TO 116 INSTEAD OF 136.'
6126	051503	106	120	123	EM55:	'FPS BAD AFTER MODF (R),A.'
6127	051535	115	117	104	EM53:	'MODF (R),A FRACTION BAD.'
6128	051566	115	117	104	EM54:	'MODF (R),A INTEGER BAD.'
6135	051616				EM56:	
	051616	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6136	051647	101	103	060	.ASCIZ	'ACO DID NOT GET 0 IN STATE 424.'
6137	051707				EM57:	
	051707	115	117	104	.ASCII	'MODF (R),A INTEGER BAD.'<CRLF>
6138	051737	101	103	061	.ASCIZ	'AC1 DID NOT GET 0 IN STATE 142.'
6139	051777				EM60:	
	051777	115	117	104	.ASCII	'MODF (R),A INTEGER BAD.'<CRLF>
6140	052027	101	103	061	.ASCIZ	'AC1 DID NOT GET THE INTEGER IN STATE 134.'
6141	052101				EM61:	
	052101	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6142	052132	101	040	102	.ASCII	'A BAD CONSTANT WAS USED (NOT 24) IN STATE 046.'
6143	052210	200	117	122	.ASCIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 050 INSTEAD OF 150.'
6144	052275				EM62:	
	052275	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6145	052326	101	040	102	.ASCII	'A BAD CONSTANT WAS USED (NOT 24) IN STATE 046.'
6146	052404	200	117	122	.ASCIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 150 INSTEAD OF 050.'
6147	052471				EM63:	
	052471	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6148	052522	050	102	125	.ASCIZ	'(BUT ZBT) STATE 532 WENT TO 102 INSTEAD OF 122.'
6149	052602				EM64:	
	052602	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6150	052633	050	102	125	.ASCIZ	'(BUT ENBT EZBT) STATE 041 WENT TO 046 INSTEAD OF 246.'
6151	052721				EM65:	
	052721	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6152	052752	050	102	125	.ASCIZ	'(BUT FT) STATE 126 SHOULD HAVE GONE TO 133. FT=0.'
6153	053034				EM66:	
	053034	115	117	104	.ASCII	'MODF (R),A FRACTION BAD.'<CRLF>
6154	053065	123	111	107	.ASCIZ	'SIGN BIT BAD.'
6155	053103				EM67:	
	053103	115	117	104	.ASCII	'MODF (R),A INTEGER BAD.'<CRLF>
6156	053133	123	111	107	.ASCIZ	'SIGN BIT BAD IN STATE 733.'
6157	053166	115	117	104	EM70:	'MODD (R),A FRACTION BAD.'
6158	053217	115	117	104	EM71:	'MODD (R),A INTEGER BAD.'
6159	053247	106	120	123	EM72:	'FPS BAD AFTER MODD (R),A.'
6160	053247				EM73=EM72	
6167	053301				EM74:	
	053301	115	117	104	.ASCII	'MODD (R),A INTEGER BAD.'<CRLF>
6168	053331	050	102	125	.ASCIZ	'(BUT FD) STATE 231 WENT TO 142 INSTEAD OF 143.'
6169	053410				EM75:	
	053410	115	117	104	.ASCII	'MODD (R),A FRACTION BAD.'<CRLF>
6170	053441	101	103	060	.ASCIZ	'ACO GETS 0 IN STATE 425 FAILED.'
6171	053501				EM76:	
	053501	115	117	104	.ASCII	'MODD (R),A INTEGER BAD.'<CRLF>
6172	053531	101	103	061	.ASCIZ	'AC1 GETS 0 IN STATE 143 FAILED.'
6173	053571				EM77:	
	053571	115	117	104	.ASCII	'MODD (R),A FRACTION BAD.'<CRLF>

6174	053622	050	102	125		.ASCIZ	'(BUT FD) STATE 526 WENT TO 134 INSTEAD OF 135.'
6175	053701				EM100:	.ASCII	'MODD (R),A INTEGER BAD.<CRLF>
	053701	115	117	104		.ASCIZ	'SIGN BIT BAD IN STATE 526.'
6176	053731	123	111	107			
6177	053764				EM101:	.ASCII	'MODD (R),A FRACTION BAD.<CRLF>
	053764	115	117	104		.ASCII	'A BAD CONSTANT WAS USED (NOT 56) IN STATE 046.'
6178	054015	101	040	102		.ASCIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 050 INSTEAD OF 150.'
6179	054073	200	117	122			
6180	054160				EM102:	.ASCII	'MODD (R),A FRACTION BAD.<CRLF>
	054160	115	117	104		.ASCII	'A BAD CONSTANT WAS USED (NOT 56) IN STATE 046.'
6181	054211	101	040	102		.ASCIZ	<CRLF>'OR (BUT NBIT) STATE 525 WENT TO 150 INSTEAD OF 050.'
6182	054267	200	117	122			
6183	054354				EM103:	.ASCII	'MODD (R),A FRACTION BAD.<CRLF>
	054354	115	117	104		.ASCIZ	'(BUT ZBIT) STATE 532 WENT TO 122 INSTEAD OF 102.'
6184	054405	050	102	125			
6185	054466				EM104:	.ASCII	'MODD (R),A INTEGER BAD.<CRLF>
	054466	115	117	104		.ASCII	'SET INTEGER IN AC1 FAILED.'
6186	054516	123	105	124		.ASCIZ	<CRLF>'OR (BUT FD) STATE 733 WENT TO 156 INSTEAD OF 157.'
6187	054550	200	117	122			
6188	054633				EM105:	.ASCII	'MODD (R),A INTEGER BAD.<CRLF>
	054633	115	117	104		.ASCIZ	'(BUT FD) STATE 122 WENT TO 424 INSTEAD OF 425.'
6189	054663	050	102	125			
6190	054742				EM106:	.ASCII	'MODD (R),A INTEGER BAD.<CRLF>
	054742	115	117	104		.ASCIZ	'(BUT FD) STATE 246 WENT TO 126 INSTEAD OF 127.'
6191	054772	050	102	125			
6192	055051				EM107:	.ASCII	'MODD (R),A INTEGER BAD.<CRLF>
	055051	115	117	104		.ASCIZ	'(BUT FD) STATE 446 WENT TO 126 INSTEAD OF 127.'
6193	055101	050	102	125			
6194	055160				EM110:	.ASCII	'MODD (R),A FRACTION BAD.<CRLF>
	055160	115	117	104		.ASCIZ	'(BUT FT) STATE 127 WENT TO 313 INSTEAD OF 113.'
6195	055211	050	102	125			
6208	055270				EM165:	.ASCII	/MODF (R),A FRACTION BAD. RESULT OVER OR UNDER FLOW./
	055270	115	117	104		.BYTE	0
6209	055353	000					
6210	055354				EM166:	.ASCII	/MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	055354	115	117	104		.BYTE	0
6211	055436	000					
6212	055437				EM167:	.ASCII	/FPS BAD AFTER MODF (R),A./
	055437	106	120	123		.BYTE	0
6213	055470	000					
6214	055471				EM170:	.ASCII	/FEC BAD AFTER MODF (R),A./
	055471	106	105	103		.ASCIZ	'EXPECTING UNDERFLOW, FEC=12.'
6215	055522	105	130	120			
6216	055557				EM171:	.ASCII	/MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	055557	115	117	104		.ASCIZ	<CRLF>'AC1 GETS 0 IN STATE 126 FAILED.'
6217	055641	200	101	103			
6218	055702				EM172:	.ASCII	/FEC BAD AFTER MODF (R),A./
	055702	106	105	103		.ASCIZ	'EXPECTING OVERFLOW, FEC=10.'
6219	055733	105	130	120			
6220	055767				EM173:	.ASCII	/MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	055767	115	117	104		.ASCIZ	<CRLF>'(BUT FIV FD) STATE 520 WENT TO 142 INSTEAD OF 162.'
6221	056051	200	050	102			
6222	056135				EM174:	.ASCII	/MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056135	115	117	104		.ASCIZ	<CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 142.'
6223	056217	200	050	102			
6224	056303				EM175:	.ASCII	/MODF (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
	056303	115	117	104			



6225	056365	200	123	111		.ASCIZ	<CRLF>'SIGN BAD IN STATE 517.'
6226	056415				EM176:		
	056415	115	117	104		.ASCII	/MODD (R),A FRACTION BAD. RESULT OVER OR UNDER FLOW./
6227	056500	000				.BYTE	0
6228	056501				EM177:		
	056501	115	117	104		.ASCII	/MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
6229	056563	000				.BYTE	0
6230	056564				EM200:		
	056564	106	120	123		.ASCII	/FPS BAD AFTER MODD (R),A./
6231	056615	000				.BYTE	0
6232	056616				EM201:		
	056616	106	105	103		.ASCII	/FEC BAD AFTER MODD (R),A./
6233	056647	200	105	130		.ASCIZ	<CRLF>'EXPECTING UNDERFLOW, FEC=12.'
6234	056705				EM202:		
	056705	115	117	104		.ASCII	/MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
6235	056767	200	050	102		.ASCIZ	<CRLF>'(BUT FD) STATE 241 WENT TO 126 INSTEAD OF 127.'
6236	057047				EM203:		
	057047	115	117	104		.ASCII	/MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
6237	057131	200	050	102		.ASCIZ	<CRLF>'(BUT FD) STATE 047 WENT TO 126 INSTEAD OF 127.'
6238	057211				EM204:		
	057211	106	105	103		.ASCII	/FEC BAD AFTER MODD (R),A./
6239	057242	200	105	130		.ASCIZ	<CRLF>'EXPECTING OVERFLOW, FEC=10.'
6240	057277				EM205:		
	057277	115	117	104		.ASCII	/MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
6241	057361	200	050	102		.ASCIZ	<CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 163.'
6242	057445				EM206:		
	057445	115	117	104		.ASCII	/MODD (R),A INTEGER BAD. RESULT OVER OR UNDER FLOW./
6243	057527	200	050	102		.ASCIZ	<CRLF>'(BUT FIV FD) STATE 520 WENT TO 162 INSTEAD OF 143.'
6244							
6245							
6338	057613				EM207:		
	057613	101	104	104		.ASCIZ	/ADD (R),A PRODUCED A BAD RESULT./
6339	057655				EM210:		
	057655	124	110	105		.ASCIZ	/THE FPS WAS BAD AFTER ADD (R),A./
6340	057717	101	104	104	EM211:	.ASCII	'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
6341	057772	200	127	105		.ASCII	<CRLF>'WENT FROM STATE 663 TO 313,'<CRLF>
6342	060027	111	116	123		.ASCIZ	'INSTEAD OF FROM 663 TO 353.'
6367	060063				EM212:		
	060063	101	104	104		.ASCII	'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	060136	200	124	110		.ASCII	<CRLF>'THE FPS WAS BAD.'<CRLF>
	060160	104	111	104		.ASCII	'DID NOT TAKE THE PATH:'<CRLF>
	060207	106	122	117		.ASCIZ	/FROM STATE 664, TO 505, TO 251./
6368	060247				EM213:		
	060247	101	104	104		.ASCII	'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	060322	200	124	110		.ASCII	<CRLF>'THE FPS WAS BAD.'<CRLF>
	060344	104	111	104		.ASCII	'DID NOT TAKE THE PATH:'<CRLF>
	060373	106	122	117		.ASCIZ	/FROM STATE 664, TO 505, TO 253./
6369	060433				EM214:		
	060433	101	104	104		.ASCII	'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	060506	200	124	110		.ASCII	<CRLF>'THE FPS WAS BAD.'<CRLF>
	060530	104	111	104		.ASCII	'DID NOT TAKE THE PATH:'<CRLF>
	060557	106	122	117		.ASCIZ	/FROM STATE 664, TO 705, TO 735./
6370	060617				EM215:		
	060617	101	104	104		.ASCII	'ADD (R),A FAILED IN THE ROUND\TRUNK FLOWS.'
	060672	200	124	110		.ASCII	<CRLF>'THE FPS WAS BAD.'<CRLF>
	060714	104	111	104		.ASCII	'DID NOT TAKE THE PATH:'<CRLF>
	060743	106	122	117		.ASCIZ	/FROM STATE 664, TO 705, TO 737./

6371	061003	124	110	105	EM216:	.ASCII	'THE (BUT FIU FORK IN THE OVER\UNDER FLOWS FAILED. FIU =1.'
6372	061074	200	127	105		.ASCII	<CRLF>'WENT FROM STATE 331 TO 115.'<CRLF>
6373	061131	111	116	123		.ASCIZ	'INSTEAD OF FROM 331 TO 155.'
6374	061165	101	104	104	EM217:	.ASCIZ	'ADD (R)A TRAPPED TO 244., FID=1.'
6375	061227				EM220:		
	061227	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./<CRLF>
	061262	124	110	105		.ASCII	'THE RESULT WAS AN OVERFLOW CONDITION BUT FIV= 0.'
	061342	200	050	102		.ASCIZ	<CRLF>/(BUT FIV) STATE 133 WENT TO 136 INSTEAD OF 116./
	061423	111	116	123		.ASCIZ	/INSTEAD OF FROM 133 TO 116./
6376	061457				EM221:		
	061457	101	104	104		.ASCII	/ADD (R),A FAILED TO TRAP TO 244./<CRLF>
	061521	124	110	105		.ASCII	'THE RESULT WAS A OVERFLOW CONDITION AND FIV=1.'<CRLF>
	061600	124	110	105		.ASCII	/THE (BUT FIV) FORK FAILED./<CRLF>
	061633	127	105	116		.ASCII	/WENT FROM STATE 133 TO 116./<CRLF>
	061667	111	116	123		.ASCIZ	/INSTEAD OF FROM 133 TO 136./
6377	061723				EM222:		
	061723	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./<CRLF>
	061756	124	110	105		.ASCII	'THE RESULT WAS AN UNDERFLOW CONDITION BUT FIU= 0.'
	062037	200	050	102		.ASCIZ	<CRLF>/(BUT FIU) STATE 331 WENT TO 155 INSTEAD OF 115./
	062120	111	116	123		.ASCIZ	/INSTEAD OF FROM 331 TO 115./
6378	062154				EM223:		
	062154	101	104	104		.ASCII	/ADD (R),A FAILED TO TRAP TO 244./<CRLF>
	062216	124	110	105		.ASCII	'THE RESULT WAS A UNDERFLOW CONDITION AND FIU=1.'<CRLF>
	062276	124	110	105		.ASCII	/THE (BUT FIU) FORK FAILED./<CRLF>
	062331	127	105	116		.ASCII	/WENT FROM STATE 331 TO 115./<CRLF>
	062365	111	116	123		.ASCIZ	/INSTEAD OF FROM 331 TO 155./
6379	062421				EM224:		
	062421	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./<CRLF>
	062454	124	110	105		.ASCII	'THE RESULT WAS AN UNDERFLOW CONDITION BUT FIU= 0.'
	062535	200	050	102		.ASCIZ	<CRLF>/(BUT FIU) STATE 137 WENT TO 155 INSTEAD OF 115./
	062616	111	116	123		.ASCIZ	/INSTEAD OF FROM 137 TO 115./
6380	062652				EM225:		
	062652	101	104	104		.ASCII	/ADD (R),A FAILED TO TRAP TO 244./<CRLF>
	062714	124	110	105		.ASCII	'THE RESULT WAS A UNDERFLOW CONDITION AND FIU=1.'<CRLF>
	062774	124	110	105		.ASCII	/THE (BUT FIU) FORK FAILED./<CRLF>
	063027	127	105	116		.ASCII	/WENT FROM STATE 137 TO 115./<CRLF>
	063063	111	116	123		.ASCIZ	/INSTEAD OF FROM 137 TO 155./
6381	063117				EM226:		
	063117	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./
	063151	200	102	105		.ASCII	<CRLF>'BECAUSE OF AN EXPECTED OVERFLOW CONDITION,'<CRLF>
	063225	102	125	124		.ASCIZ	'BUT THE FEC WAS BAD.'
6382	063252				EM227:		
	063252	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./
	063304	200	102	105		.ASCII	<CRLF>'BECAUSE OF AN EXPECTED OVERFLOW CONDITION,'<CRLF>
	063360	102	125	124		.ASCIZ	'BUT THE FPS WAS BAD.'
6383	063405				EM230:		
	063405	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./
	063437	200	102	105		.ASCII	<CRLF>'BECAUSE OF AN EXPECTED UNDERFLOW CONDITION,'<CRLF>
	063514	102	125	124		.ASCIZ	'BUT THE FEC WAS BAD.'
6384	063541				EM231:		
	063541	101	104	104		.ASCII	/ADD (R),A TRAPPED TO 244./
	063573	200	102	105		.ASCII	<CRLF>'BECAUSE OF AN EXPECTED UNDERFLOW CONDITION,'<CRLF>
	063650	102	125	124		.ASCIZ	'BUT THE FPS WAS BAD.'
6385	057655				EM232=EM210		
6386							
6387							
6388							

6393						
6397						
6404						
6414						
6415	063675				EM233:	.ASCIZ \LDCFD (R)+,A RESULT INCORRECT.\
	063675	114	104	103		
6416	063734				EM234:	.ASCIZ \LDCFD (R)+,A RESULT INCORRECT.\
	063734	122	060	040		.ASCII \RO BAD AFTER LDCFD (R)+,A.\
	063766	200	101	040		.ASCIZ <CRLF>'A BAD CONSTANT WAS USED.'
6417	064020				EM235:	.ASCIZ \PC BAD AFTER LDCFD #NUM,A. TRAP TO 4.\
	064020	120	103	040		
6418	064066				EM236:	.ASCIZ \PC BAD AFTER LDCFD #NUM,A.\
	064066	120	103	040		
6419	064121				EM237:	.ASCII \RO BAD AFTER LDCDF (R)+,A.\
	064121	122	060	040		.ASCIZ <CRLF>'A BAD CONSTANT WAS USED.'
	064153	200	101	040		
6420	064205				EM240:	.ASCIZ \FPS BAD AFTER LDCFD (R)+,A.\
	064205	106	120	123		
6421	064241				EM241:	.ASCII \LDCFD (R)+,A FAILED.\
	064241	114	104	103		.ASCII <CRLF>'THE FD '
	064265	200	124	110		.ASCII 'BIT WAS NOT COMPLIMENTED '
	064275	102	111	124		.ASCIZ 'IN STATE 017.'
	064326	111	116	040		
6422	064344				EM242:	.ASCIZ \FPS BAD AFTER LDCDF (R)+,A.\
	064344	106	120	123		
6423	064400				EM243:	.ASCII \LDCDF (R)+,A FAILED.\
	064400	114	104	103		.ASCII <CRLF>'THE FD '
	064424	200	124	110		.ASCII 'BIT WAS NOT COMPLIMENTED '
	064434	102	111	124		.ASCIZ 'IN STATE 017.'
	064465	111	116	040		
6424	064503				EM244:	.ASCIZ \LDCDF (R)+,A RESULT INCORRECT.\
	064503	114	104	103		
6425						
6426	064542	114	104	103	EM245:	.ASCII 'LDCFD (R),A FAILED.'
6427	064565	200	123	105		.ASCII <CRLF>'SET SIGN FAILED '
6428	064606	111	116	040		.ASCIZ 'IN STATE 512.'
6429	064624	125	116	105	EM247:	.ASCIZ 'UNEXPECTED FPP TRAP TO 244.'
6430	064660	125	116	105	EM250:	.ASCIZ 'UNEXPECTED CPU TRAP TO 4.'
6431	064712	125	116	105	EM251:	.ASCIZ 'UNEXPECTED CPU TRAP TO 10.'
6432						
6433	064745	103	117	122	EM252:	.ASCIZ 'CORRECT FLOWS INTERRUPT TEST MODULE FAILED TO INTERRUPT.'
6434						
6438						
6439	065036				EM253:	.ASCIZ /ADDD ACO,ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065036	101	104	104		
6440	065122				EM254:	.ASCIZ /ADDD (RO),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065122	101	104	104		
6441	065207				EM255:	.ASCIZ /ADDD (RO)+,ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065207	101	104	104		
6442	065275				EM256:	.ASCIZ /ADDD @ (RO)+,ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065275	101	104	104		
6443	065364				EM257:	.ASCIZ /ADDD -(RO),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065364	101	104	104		
6444	065452				EM260:	.ASCIZ /ADDD @-(RO),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065452	101	104	104		
6445	065541				EM261:	.ASCIZ /ADDD NUM(RO),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
	065541	101	104	104		

6446	065631				EM262:	
	065631	101	104	104	.ASCIZ	/ADDD @NUM(R0),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
6447	065722				EM263:	
	065722	104	111	126	.ASCIZ	/DIVD (R0),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
6448	066007				EM264:	
	066007	115	125	114	.ASCIZ	/MULD (R0),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
6449	066074				EM265:	
	066074	115	117	104	.ASCIZ	/MODD (R0),ACO FAILED IN THE INTERRUPT CORRECT FLOWS./
6450						
6451	066161	103	117	122	EM266:	.ASCIZ 'CORRECT FLOWS INTERRUPT TEST MODULE CAUSED UNEXPECTED INTERRUPT.'
6452						
6453						
6454						;THESE ARE ERROR DATA TABLE HEADERS:
6455	066262	040	040	124	DH1:	.ASCII ' TEST.'<TAB>'CALL AT PC.'<TAB>'ERROR AT PC.'<TAB>
6456	066323	107	117	124		.ASCIZ 'GOT FPS.'<TAB>'EXPECTED FPS.'
6457	066352	040	040	124	DH2:	.ASCIZ ' TEST.'<TAB>'CALL AT PC.'<TAB>'ERROR AT PC.'
6458	066262					DH3=DH1
6459	066262					DH4=DH1
6460	066262					DH5=DH1
6461	066262					DH6=DH1
6462	066262					DH7=DH1
6463	066262					DH10=DH1
6464	066262					DH11=DH1
6465	066262					DH12=DH1
6466	066262					DH13=DH1
6467	066262					DH14=DH1
6468	066262					DH15=DH1
6469	066262					DH16=DH1
6470	066413	040	040	124	DH17:	.ASCIZ ' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'<TAB>'FEC.'<TAB>'FPS.'
6471	066262					DH20=DH1
6472	066466	040	040	124	DH21:	.ASCII ' TEST.'<TAB>'PC OF CALL'<TAB>'PC OF ERROR.'<TAB>
6473	066526	107	117	124		.ASCIZ 'GOT FEC.'<TAB>'EXPECTED FEC.'
6474	066555	040	040	124	DH22:	.ASCIZ ' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'<TAB>'FPS.'
6475	066262					DH23=DH1
6476	066262					DH32=DH1
6477	066262					DH24=DH1
6478	066262					DH25=DH1
6479	066262					DH26=DH1
6480	066262					DH27=DH1
6481	066262					DH30=DH1
6482	066262					DH31=DH1
6483	066262					DH33=DH1
6484	066262					DH34=DH1
6485	066262					DH35=DH1
6486	066262					DH36=DH1
6487	066262					DH37=DH1
6488	066262					DH40=DH1
6489	066262					DH41=DH1
6490	066262					DH42=DH1
6491	066262					DH43=DH1
6492	066262					DH44=DH1
6493	066262					DH45=DH1
6494	066262					DH246=DH1
6495	066262					DH46=DH1
6496	066262					DH47=DH1
6497	066262					DH50=DH1
6498	066262					DH51=DH1

6499	066262			DH52=DH1
6500	066262			DH111=DH1
6501	066262			DH112=DH1
6502	066262			DH113=DH1
6503	066262			DH114=DH1
6504	066623	040	124	DH115: .ASCII ' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'<TAB>
6505	066664	117	124	.ASCIZ 'GOT FEC.' 'GOT FPS.' 'EXPECTED FPS.'
6506	066623			DH116=DH115
6507	066623			DH117=DH115
6508	066623			DH120=DH115
6509	066623			DH121=DH115
6510	066623			DH122=DH115
6511	066262			DH123=DH1
6512	066262			DH124=DH1
6513	066262			DH125=DH1
6514	066262			DH126=DH1
6515	066623			DH127=DH115
6516	066623			DH130=DH115
6517	066623			DH131=DH115
6518	066262			DH132=DH1
6519	066623			DH133=DH115
6520	066623			DH134=DH115
6521	066262			DH135=DH1
6522	066623			DH136=DH115
6523	066623			DH137=DH115
6524	066623			DH140=DH115
6525	066623			DH141=DH115
6526	066623			DH142=DH115
6527	066623			DH143=DH115
6528	066623			DH144=DH115
6529	066262			DH145=DH1
6530	066262			DH146=DH1
6531	066262			DH147=DH1
6532	066262			DH150=DH1
6533	066623			DH151=DH115
6534	066623			DH152=DH115
6535	066623			DH153=DH115
6536	066623			DH154=DH115
6537	066623			DH155=DH115
6538	066623			DH156=DH115
6539	066262			DH157=DH1
6540	066623			DH160=DH115
6541	066262			DH161=DH1
6542	066262			DH162=DH1
6543	066623			DH163=DH115
6544	066262			DH164=DH1
6545	066262			DH53=DH1
6546	066262			DH54=DH1
6547	066262			DH55=DH1
6548	066262			DH56=DH1
6549	066262			DH57=DH1
6550	066262			DH60=DH1
6551	066262			DH61=DH1
6552	066262			DH62=DH1
6553	066262			DH63=DH1
6554	066262			DH64=DH1
6555	066262			DH65=DH1

6556	066262	DH66=DH1
6557	066262	DH67=DH1
6558	066262	DH70=DH1
6559	066262	DH71=DH1
6560	066262	DH72=DH1
6561	066262	DH73=DH1
6562	066262	DH74=DH1

6564		066262				DH75=DH1	
6565		066262				DH76=DH1	
6566		066262				DH77=DH1	
6567		066262				DH100=DH1	
6568		066262				DH101=DH1	
6569		066262				DH102=DH1	
6570		066262				DH103=DH1	
6571		066262				DH104=DH1	
6572		066262				DH105=DH1	
6573		066262				DH106=DH1	
6574		066262				DH107=DH1	
6575		066262				DH110=DH1	
6576		066623				DH165=DH115	
6577		066623				DH166=DH115	
6578		066623				DH167=DH115	
6579		066623				DH170=DH115	
6580		066623				DH171=DH115	
6581		066623				DH172=DH115	
6582		066623				DH173=DH115	
6583		066623				DH174=DH115	
6584		066623				DH175=DH115	
6585		066623				DH176=DH115	
6586		066623				DH177=DH115	
6587		066623				DH200=DH115	
6588		066623				DH201=DH115	
6589		066623				DH202=DH115	
6590		066623				DH203=DH115	
6591		066623				DH204=DH115	
6592		066623				DH205=DH115	
6593		066623				DH206=DH115	
6594	066722	040	040	124		DH220: .ASCIZ	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF TRAP.'
6595	066762	040	040	124		DH207: .ASCII	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'
6596	067022	011	107	117		.ASCIZ	<TAB>'GOT FPS.'<TAB>'EXPECTED FPS.'
6597	067052	040	040	124		DH210: .ASCIZ	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'
6598		067052				DH211=DH210	
6599		066762				DH212=DH207	
6600		066762				DH213=DH207	
6601		066762				DH214=DH207	
6602		066762				DH215=DH207	
6603		067052				DH216=DH210	
6604	067113	040	040	124		DH217: .ASCII	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'
6605	067153	011	106	120		.ASCIZ	<TAB>'FPS.'<TAB>'FEC.'
6606		067052				DH221=DH210	
6607		066722				DH222=DH220	
6608		067052				DH223=DH210	
6609		066722				DH224=DH220	
6610		067052				DH225=DH210	
6611	067166	040	040	124		DH226: .ASCII	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF TRAP.'
6612	067225	011	107	117		.ASCIZ	<TAB>'GOT FEC.'<TAB>'EXPECTED FEC.'
6613	067255	040	040	124		DH227: .ASCII	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF TRAP.'
6614	067314	011	107	117		.ASCIZ	<TAB>'GOT FPS.'<TAB>'EXPECTED FPS.'
6615		067166				DH230=DH226	
6616		067255				DH231=DH227	
6617		067255				DH232=DH227	
6618							
6619							
6620	067344	040	040	124		DH233: .ASCIZ	' TEST.'<TAB>'PC OF CALL.'<TAB>'PC OF ERROR.'

```

6621
6622 067405      040      040      124  DH234: .ASCII ' TEST.<TAB>'PC OF CALL.<TAB>'PC OF ERROR.'
6623 067445      011      107      117  .ASCIZ <TAB>'GOT RO.<TAB>'EXPECTED RO.'
6624
6625 067473      040      040      124  DH235: .ASCII ' TEST.<TAB>'PC OF CALL.<TAB>
6626 067517      120      103      040  .ASCIZ 'PC OF TRAP.<TAB>
6627
6628 067533      040      040      124  DH236: .ASCII ' TEST.<TAB>'PC OF CALL.<TAB>
6629 067557      120      103      040  .ASCII 'PC OF ERROR.<TAB>'GOT PC.'
6630 067603      011      105      130  .ASCIZ <TAB>'EXPECTED PC.'
6631
6632          067405          DH237=DH234
6633
6634 067621      040      040      124  DH240: .ASCII ' TEST.<TAB>'PC OF CALL.<TAB>
6635 067645      120      103      040  .ASCII 'PC OF ERROR.<TAB>
6636 067662      107      117      124  .ASCIZ 'GOT FPS.<TAB>'EXPECTED FPS.'
6637
6638          067344          DH241=DH233
6639          067621          DH242=DH240
6640          067344          DH243=DH233
6641          067344          DH244=DH233
6642          067344          DH245=DH233
6643 067711      040      040      124  DH247: .ASCIZ ' TEST.<TAB>'PC OF CALL.<TAB>'PC OF TRAP.<TAB>'FEC.'
6644 067756      040      040      124  DH250: .ASCIZ ' TEST.<TAB>'PC OF CALL.<TAB>'PC OF TRAP.'
6645          067756          DH251=DH250
6646
6647          066352          DH252=DH2
6648          066262          DH253=DH1
6649          066262          DH254=DH1
6650          066262          DH255=DH1
6651          066262          DH256=DH1
6652          066262          DH257=DH1
6653          066262          DH260=DH1
6654          066262          DH261=DH1
6655          066262          DH262=DH1
6656          066262          DH263=DH1
6657          066262          DH264=DH1
6658          066262          DH265=DH1
6659 070016      040      040      124  DH266: .ASCIZ ' TEST.<TAB>'PC OF CALL.<TAB>'PC OF TRAP.'
6660
6661
6662          ;THESE ARE THE DATA FORMAT SPECIFIERS FOR THE DATA TABLE:
6663 070056      004      000      005  DF1: .BYTE 4,0,5,0,5,0,5,0,5,5,3,5,5,3
6664 070074      004      000      005  DF2: .BYTE 4,0,5,0,5,5,3,5,5,3
6665          070056          DF3=DF1
6666          070056          DF4=DF1
6667          070056          DF5=DF1
6668          070056          DF6=DF1
6669          070056          DF7=DF1
6670          070056          DF10=DF1
6671          070056          DF11=DF1
6672          070056          DF12=DF1
6673          070056          DF13=DF1
6674          070056          DF14=DF1
6675          070056          DF15=DF1
6676          070056          DF16=DF1
6677 070106      004      000      005  DF17: .BYTE 4,0,5,0,5,0,0

```



6678	070115	004	000	005	DF20: .BYTE	4,0,5,0,5,0,5,0
6679		070115			DF21=DF20	
6680		070115			DF22=DF20	
6681	070125	004	000	005	DF23: .BYTE	4,0,5,0,5,0,5,0,5,5,2,5,5,2,5,5,2,5,5,2
6682		070125			DF24=DF23	
6683		070125			DF32=DF23	
6684		070125			DF25=DF23	
6685		070125			DF26=DF23	
6686		070125			DF27=DF23	
6687		070125			DF30=DF23	
6688		070125			DF31=DF23	
6689	070151	004	000	005	DF33: .BYTE	4,0,5,0,5,0,5,0,5,5,3,5,5,3,5,5,3,5,5,3
6690		070151			DF34=DF33	
6691		070151			DF35=DF33	
6692		070151			DF36=DF33	
6693		070125			DF37=DF23	
6694		070125			DF40=DF23	
6695		070125			DF41=DF23	
6696		070125			DF42=DF23	
6697		070125			DF43=DF23	
6698		070125			DF44=DF23	
6699		070125			DF45=DF23	
6700		070151			DF246=DF33	
6701		070151			DF46=DF33	
6702		070151			DF47=DF33	
6703		070151			DF50=DF33	
6704		070151			DF51=DF33	
6705		070151			DF52=DF33	
6706		070125			DF111=DF23	
6707		070125			DF112=DF23	
6708		070125			DF113=DF23	
6709		070125			DF114=DF23	
6710	070175	004	000	005	DF115: .BYTE	4,0,5,0,5,0,0,0,5,5,2,5,5,2,5,5,2,5,5,2
6711		070175			DF116=DF115	
6712		070175			DF117=DF115	
6713		070175			DF120=DF115	
6714		070175			DF121=DF115	
6715		070175			DF122=DF115	
6716		070151			DF123=DF33	
6717		070151			DF124=DF33	
6718		070151			DF125=DF33	
6719		070151			DF126=DF33	
6720	070221	004	000	005	DF127: .BYTE	4,0,5,0,5,0,0,0,5,5,3,5,5,3,5,5,3,5,5,3
6721		070221			DF130=DF127	
6722		070221			DF131=DF127	
6723		070151			DF132=DF33	
6724		070221			DF133=DF127	
6725		070221			DF134=DF127	
6726		070151			DF135=DF33	
6727		070221			DF136=DF127	
6728		070175			DF137=DF115	
6729		070175			DF140=DF115	
6730		070175			DF141=DF115	
6731		070175			DF142=DF115	
6732		070175			DF143=DF115	
6733		070175			DF144=DF115	
6734		070125			DF145=DF23	

6735	070125			DF146=DF23	
6736	070125			DF147=DF23	
6737	070125			DF150=DF23	
6738	070221			DF151=DF127	
6739	070221			DF152=DF127	
6740	070221			DF153=DF127	
6741	070221			DF154=DF127	
6742	070221			DF155=DF127	
6743	070221			DF156=DF127	
6744	070151			DF157=DF33	
6745	070221			DF160=DF127	
6746	070151			DF161=DF33	
6747	070151			DF162=DF33	
6748	070221			DF163=DF127	
6749	070151			DF164=DF33	
6750	070245	000	005	DF53: .BYTE	4.0.5.0.5.0.5.0.5.5.2.5.5.2.5.5.2.5.5.2.5.5.2
6751	070245			DF54=DF53	
6752	070245			DF55=DF53	
6753	070245			DF56=DF53	
6754	070245			DF57=DF53	
6755	070245			DF60=DF53	
6756	070245			DF61=DF53	
6757	070245			DF62=DF53	
6758	070245			DF63=DF53	
6759	070245			DF64=DF53	
6760	070245			DF65=DF53	
6761	070245			DF66=DF53	
6762	070245			DF67=DF53	
6763	070277	000	005	DF70: .BYTE	4.0.5.0.5.0.5.0.5.5.3.5.5.3.5.5.3.5.5.3.5.5.3
6764	070277			DF71=DF70	
6765	070277			DF72=DF70	
6766	070277			DF73=DF70	
6767	070277			DF74=DF70	
6768	070277			DF75=DF70	
6769	070277			DF76=DF70	
6770	070277			DF77=DF70	
6771	070277			DF100=DF70	
6772	070277			DF101=DF70	
6773	070277			DF102=DF70	
6774	070277			DF103=DF70	
6775	070277			DF104=DF70	
6776	070277			DF105=DF70	
6777	070277			DF106=DF70	
6778	070277			DF107=DF70	
6779	070277			DF110=DF70	
6780	070331	000	005	DF165: .BYTE	4.0.5.0.5.0.0.0.5.5.2.5.5.2.5.5.2.5.5.2.5.5.2
6781	070331			DF166=DF165	
6782	070331			DF167=DF165	
6783	070331			DF170=DF165	
6784	070331			DF171=DF165	
6785	070331			DF172=DF165	
6786	070331			DF173=DF165	
6787	070331			DF174=DF165	
6788	070331			DF175=DF165	
6789	070363	000	005	DF176: .BYTE	4.0.5.0.5.0.0.0.5.5.3.5.5.3.5.5.3.5.5.3.5.5.3
6790	070363			DF177=DF176	
6791	070363			DF200=DF176	

6792	070363			DF201=DF176	
6793	070363			DF202=DF176	
6794	070363			DF203=DF176	
6795	070363			DF204=DF176	
6796	070363			DF205=DF176	
6797	070363			DF206=DF176	
6798	070415	000	005	DF210: .BYTE	4,0,5,0,5,0,5,0
6799	070425	000	005	DF207: .BYTE	4,0,5,0,5,5,5,3,5,5,5,3,5,5,5,3,5,5,5,3
6800	070425			DF211=DF207	
6801	070451	000	005	DF212: .BYTE	4,0,5,0,5,0,5,0,5,5,5,3,5,5,5,3,5,5,5,3,5,5,5,3
6802	070451			DF213=DF212	
6803	070451			DF214=DF212	
6804	070451			DF215=DF212	
6805	070425			DF216=DF207	
6806	070501	000	005	DF217: .BYTE	4,0,5,0,5,0,0
6807	070425			DF220=DF207	
6808	070425			DF221=DF207	
6809	070425			DF222=DF207	
6810	070425			DF223=DF207	
6811	070425			DF224=DF207	
6812	070425			DF225=DF207	
6813	070451			DF226=DF212	
6814	070451			DF227=DF212	
6815	070451			DF230=DF212	
6816	070451			DF231=DF212	
6817	070451			DF232=DF212	
6818	070510	000	005	DF233: .BYTE	4,0,5,0,5,5,3,5,5,3,5,5,3
6819	070525	000	005	DF234: .BYTE	4,0,5,0,5,0,0
6820					
6821	070534	000	005	DF235: .BYTE	4,0,5,0
6822	070525			DF236=DF234	
6823	070525			DF237=DF234	
6824	070525			DF240=DF234	
6825	070510			DF241=DF233	
6826	070525			DF242=DF234	
6827	070510			DF243=DF233	
6828	070510			DF244=DF233	
6829	070510			DF245=DF233	
6830	070540	000	005	DF247: .BYTE	4,0,5,0,5,0
6831	070540			DF250=DF247	
6832	070540			DF251=DF247	
6833					
6834	070546	000	005	DF252: .BYTE	4,0,5,0
6835	070552	000	005	DF253: .BYTE	4,0,5,0,5,0,5,0,5,5,0,5,5,0,5,5,0,5,5,0,5,5,0,5,5,3,5,5,3
6836	070552			DF254=DF253	
6837	070552			DF255=DF253	
6838	070552			DF256=DF253	
6839	070552			DF257=DF253	
6840	070552			DF260=DF253	
6841	070552			DF261=DF253	
6842	070552			DF262=DF253	
6843	070552			DF263=DF253	
6844	070552			DF264=DF253	
6845	070552			DF265=DF253	
6846	070546			DF266=DF252	
6847					
6848					

```
6849
6850
6851
6852
6853 070604 001232 001234 037215
6854 070624 001313 037222 001240
6855 070642 001232 001234 037215
6856 070604
6857 070604
6858 070604
6859 070604
6860 070604
6861 070604
6862 070604
6863 070604
6864 070604
6865 070604
6866 070604
6867 070604
6868 070670 001232 001234 037215
6869 070710 001232 001234 037215
6870 070732 001232 001234 037215
6871 070754 001232 001234 037215
6872 070772 001232 001234 037215
6873 071026 001313 037335 001244
6874 070772
6875 070772
6876 070772
6877 070772
6878 070772
6879 070772
6880 070772
6881 070772
6882 070772
6883 070772
6884 070772
6885 070772
6886 070772
6887 070772
6888 070772
6889 070772
6890 070772
6891 070772
6892 070772
6893 070772
6894 070772
6895 070772
6896 070772
6897 070772
6898 070772
6899 070772
6900 070772
6901 070772
6902 071044 001232 001234 037215
6903 071066 001313 037222 001240
6904 071102 001313 037335 001244
6905 071044
```

.EVEN

:THESE ARE ERROR DATA TABLES (FORMATTED ABOVE):

DT1: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP5,\$TAB,\$TMP6  
.WORD \$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4,0

DT2: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF,MS3,\$TMP3,\$CRLF,MS4,\$TMP4,0

DT3=DT1  
DT4=DT1  
DT5=DT1  
DT6=DT1  
DT7=DT1  
DT10=DT1  
DT11=DT1  
DT12=DT1  
DT13=DT1  
DT14=DT1  
DT15=DT1  
DT16=DT1

DT17: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TMP5,0  
DT20: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP5,0  
DT21: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP4,\$TAB,\$TMP3,0  
DT22: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP5,0  
DT23: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP7,\$TAB,\$TMP10,\$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP  
.WORD \$CRLF,MS5,\$TMP5,\$CRLF,MS6,\$TMP6,0

DT32=DT23  
DT24=DT23  
DT25=DT23  
DT26=DT23  
DT27=DT23  
DT30=DT23  
DT31=DT23  
DT33=DT23  
DT34=DT23  
DT35=DT23  
DT36=DT23  
DT37=DT23  
DT40=DT23  
DT41=DT23  
DT42=DT23  
DT43=DT23  
DT44=DT23  
DT45=DT23  
DT246=DT23  
DT46=DT23  
DT47=DT23  
DT50=DT23  
DT51=DT23  
DT52=DT23  
DT111=DT23  
DT112=DT23  
DT113=DT23  
DT114=DT23

DT115: .WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP11,\$TMP7,\$TAB,\$TMP10  
.WORD \$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4  
.WORD \$CRLF,MS5,\$TMP5,\$CRLF,MS6,\$TMP6,0

DT116=DT115

6906	071044			DT117=DT115	
6907	071044			DT120=DT115	
6908	071044			DT121=DT115	
6909	071044			DT122=DT115	
6910	070772			DT123=DT23	
6911	070772			DT124=DT23	
6912	070772			DT125=DT23	
6913	070772			DT126=DT23	
6914	071044			DT127=DT115	
6915	071044			DT130=DT115	
6916	071044			DT131=DT115	
6917	070772			DT132=DT23	
6918	071044			DT133=DT115	
6919	071044			DT134=DT115	
6920	070772			DT135=DT23	
6921	071044			DT136=DT115	
6922	071044			DT137=DT115	
6923	071044			DT140=DT115	
6924	071044			DT141=DT115	
6925	071044			DT142=DT115	
6926	071044			DT143=DT115	
6927	071044			DT144=DT115	
6928	070772			DT145=DT23	
6929	070772			DT146=DT23	
6930	070772			DT147=DT23	
6931	070772			DT150=DT23	
6932	071044			DT151=DT115	
6933	071044			DT152=DT115	
6934	071044			DT153=DT115	
6935	071044			DT154=DT115	
6936	071044			DT155=DT115	
6937	071044			DT156=DT115	
6938	070772			DT157=DT23	
6939	071044			DT160=DT115	
6940	070772			DT161=DT23	
6941	070772			DT162=DT23	
6942	071044			DT163=DT115	
6943	070772			DT164=DT23	
6944	071120	001232	001234 037215	DT53:	.WORD \$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP11,\$TAB,\$TMP12
6945	071140	001313	037222 001240		.WORD \$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4
6946	071154	001313	037443 001244		.WORD \$CRLF,MS11,\$TMP5,\$CRLF,MS12,\$TMP6
6947	071170	001313	037375 001250		.WORD \$CRLF,MS7,\$TMP7,\$CRLF,MS10,\$TMP10,0
6948	071120			DT54=DT53	
6949	071120			DT55=DT53	
6950	071120			DT56=DT53	
6951	071120			DT57=DT53	
6952	071120			DT60=DT53	
6953	071120			DT61=DT53	
6954	071120			DT62=DT53	
6955	071120			DT63=DT53	
6956	071120			DT64=DT53	
6957	071120			DT65=DT53	
6958	071120			DT66=DT53	
6959	071120			DT67=DT53	
6960	071120			DT70=DT53	
6961	071120			DT71=DT53	
6962	071120			DT72=DT53	

6963	071120				DT73=DT53	
6964	071120				DT74=DT53	
6965	071120				DT75=DT53	
6966	071120				DT76=DT53	
6967	071120				DT77=DT53	
6968	071120				DT100=DT53	
6969	071120				DT101=DT53	
6970	071120				DT102=DT53	
6971	071120				DT103=DT53	
6972	071120				DT104=DT53	
6973	071120				DT105=DT53	
6974	071120				DT106=DT53	
6975	071120				DT107=DT53	
6976	071120				DT110=DT53	
6977	071206	001232	001234	037215	DT165: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP13,\$TMP11,\$TMP12
6978	071226	001313	037222	001240	.WORD	\$CRLF,MS1,\$TMP3,\$CRLF,MS2,\$TMP4
6979	071242	001313	037443	001244	.WORD	\$CRLF,MS11,\$TMP5,\$CRLF,MS12,\$TMP6
6980	071256	001313	037375	001250	.WORD	\$CRLF,MS7,\$TMP7,\$CRLF,MS10,\$TMP10,0
6981	071206				DT166=DT165	
6982	071206				DT167=DT165	
6983	071206				DT170=DT165	
6984	071206				DT171=DT165	
6985	071206				DT172=DT165	
6986	071206				DT173=DT165	
6987	071206				DT174=DT165	
6988	071206				DT175=DT165	
6989	071206				DT176=DT165	
6990	071206				DT177=DT165	
6991	071206				DT200=DT165	
6992	071206				DT201=DT165	
6993	071206				DT202=DT165	
6994	071206				DT203=DT165	
6995	071206				DT204=DT165	
6996	071206				DT205=DT165	
6997	071206				DT206=DT165	
6998						
6999	071274	001232	001234	037215	DT210: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3
7000	071310	037215	001242	000000	.WORD	\$TAB,\$TMP4,0
7001	071316	001232	001234	037215	DT207: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$CRLF,MS41,\$CRLF,\$TMP3
7002	071336	001313	037610	001313	.WORD	\$CRLF,MS42,\$CRLF,\$TMP4,\$CRLF,MS43,\$CRLF,\$TMP5
7003	071356	001313	037643	001313	.WORD	\$CRLF,MS44,\$CRLF,\$TMP6,0
7004	071316				DT211=DT207	
7005	071370	001232	001234	037215	DT212: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP10,\$TAB,\$TMP11
7006	071410	001313	037564	001313	.WORD	\$CRLF,MS41,\$CRLF,\$TMP3,\$CRLF,MS42,\$CRLF,\$TMP4
7007	071430	001313	037626	001313	.WORD	\$CRLF,MS43,\$CRLF,\$TMP5,\$CRLF,MS44,\$CRLF,\$TMP6,0
7008	071370				DT213=DT212	
7009	071370				DT214=DT212	
7010	071370				DT215=DT212	
7011	071316				DT216=DT207	
7012	071452	001232	001234	037215	DT217: .WORD	\$TMP0,\$TMP1,\$TAB,\$TMP2,\$TAB,\$TMP3,\$TMP4,0
7013	071316				DT220=DT207	
7014	071316				DT221=DT207	
7015	071316				DT222=DT207	
7016	071316				DT223=DT207	
7017	071316				DT224=DT207	
7018	071316				DT225=DT207	
7019	071370				DT226=DT212	

```

7020          071370          DT227=DT212
7021          071370          DT230=DT212
7022          071274          DT231=DT210
7023          071316          DT232=DT207
7024
7025
7026
7027
7028
7029 071472 001232 001234 037215 DT233: .WORD $TMP0,$TMP1,$TAB,$TMP2,$CRLF
7030 071504 037512 001244 001313      .WORD MS37,$TMP5,$CRLF,MS40,$TMP6
7031 071516 001313 037564 001250      .WORD $CRLF,MS41,$TMP7,0
7032
7033 071526 001232 001234 037215 DT234: .WORD $TMP0,$TMP1,$TAB,$TMP2,$TAB,$TMP3,$TMP4,0
7034
7035 071546 001232 001234 037215 DT235: .WORD $TMP0,$TMP1,$TAB,$TMP2,0
7036
7037          071526          DT236=DT234
7038          071526          DT237=DT234
7039          071526          DT240=DT234
7040          071472          DT241=DT233
7041          071526          DT242=DT234
7042          071472          DT243=DT233
7043          071472          DT244=DT233
7044          071472          DT245=DT233
7045 071560 001232 001234 037215 DT247: .WORD $TMP0,$TMP1,$TAB,$TMP2,$TAB,$TMP3,0
7046 071576 001232 001234 037215 DT250: .WORD $TMP0,$TMP1,$TAB,$TMP2,0
7047
7048
7049 071610 001232 001234 037215 DT252: .WORD $TMP0,$TMP1,$TAB,$TMP2,0
7050
7051 071622 001232 001234 037215 DT253: .WORD $TMP0,$TMP1,$TAB,$TMP2,$TAB,$TMP7,$TAB,$TMP10
7052 071642 001313 037024 001254      .WORD $CRLF,MSA1,$TMP11,$CRLF,MSA2,$TMP12
7053 071656 001313 037065 001244      .WORD $CRLF,MSA3,$TMP5,$CRLF,MSA4,$TMP6
7054 071672 001313 037115 001240      .WORD $CRLF,MSA5,$TMP3,$CRLF,MSA6,$TMP4,0
7055          071622          DT254=DT253
7056          071622          DT255=DT253
7057          071622          DT256=DT253
7058          071622          DT257=DT253
7059          071622          DT260=DT253
7060          071622          DT261=DT253
7061          071622          DT262=DT253
7062          071622          DT263=DT253
7063          071622          DT264=DT253
7064          071622          DT265=DT253
7065
7066          071610          DT266=DT252
7067
7068
7069
7070
7071          ;12345
7072          000001          .END
  
```

AAADON 014406	AMSGTY= 000000	BPTVEC= 000014	DF10 = 070056	DF162 = 070151
AAA1 013404	AMTYP1= 000000	CCCCDON 016120	DF100 = 070277	DF163 = 070221
AAA10 014022	AMTYP2= 000000	CCC1 015114	DF101 = 070277	DF164 = 070151
AAA11 014060	AMTYP3= 000000	CCC10 015510	DF102 = 070277	DF165 = 070331
AAA12 014116	AMTYP4= 000000	CCC11 015544	DF103 = 070277	DF166 = 070331
AAA13 014154	APASS = 000000	CCC12 015600	DF104 = 070277	DF167 = 070331
AAA2 013442	APRIOR= 000000	CCC13 015634	DF105 = 070277	DF17 = 070106
AAA3 013500	APTCSU= 000040	CCC2 015150	DF106 = 070277	DF170 = 070331
AAA4 013536	APTENV= 000001	CCC3 015204	DF107 = 070277	DF171 = 070331
AAA5 013574	APTSIZ= 000200	CCC4 015240	DF11 = 070056	DF172 = 070331
AAA6 013632	APTSPO= 000100	CCC5 015274	DF110 = 070277	DF173 = 070331
AAA7 013670	ASWREG= 000000	CCC6 015330	DF111 = 070125	DF174 = 070331
AAA8 013726	AATESTN= 000000	CCC7 015364	DF112 = 070125	DF175 = 070331
AAA9 013764	AUNIT = 000000	CCC8 015420	DF113 = 070125	DF176 = 070363
ABASE = 000000	AUSWR = 000000	CCC9 015454	DF114 = 070125	DF177 = 070363
ACDW1 = 000000	AVECT1= 000000	CKSWR = 104406	DF115 = 070175	DF2 = 070074
ACDW2 = 000000	AVECT2= 000000	CMPSUB 014216	DF116 = 070175	DF20 = 070115
ACPUOP= 000000	BBBDON 015110	CMPTMP 014376	DF117 = 070175	DF200 = 070363
AC0 = %000000	BBBER1 014664	CNT = 000267	DF12 = 070056	DF201 = 070363
AC1 = %000001	BBBER2 014750	CORDON 033142	DF120 = 070175	DF202 = 070363
AC2 = %000002	BBBER3 014776	CORFLG 033124	DF121 = 070175	DF203 = 070363
AC3 = %000003	BBBER4 015024	CORINT 033136	DF122 = 070175	DF204 = 070363
AC4 = %000004	BBBP1 015070	CORMES 037665	DF123 = 070151	DF205 = 070363
AC5 = %000005	BBBP2 015100	CORSUB 032642	DF124 = 070151	DF206 = 070363
AC6 = %000006	BBB0 014414	CORTMP 033126	DF125 = 070151	DF207 = 070425
AC7 = %000007	BBB1 014450	CORTRP 033140	DF126 = 070151	DF21 = 070115
ADDW0 = 000000	BBB2 014476	CORTV 032740	DF127 = 070221	DF210 = 070115
ADDW1 = 000000	BBB3 014526	CORTV0 033102	DF13 = 070056	DF211 = 070425
ADDW10= 000000	BBB4 014554	CORTV1 033106	DF130 = 070221	DF212 = 070451
ADDW11= 000000	BBB5 014612	COR1 032010	DF131 = 070221	DF213 = 070451
ADDW12= 000000	BBB6 014620	COR10 032432	DF132 = 070151	DF214 = 070451
ADDW13= 000000	BIT0 = 000001	COR11 032476	DF133 = 070221	DF215 = 070451
ADDW14= 000000	BIT00 = 000001	COR12 032536	DF134 = 070221	DF216 = 070425
ADDW15= 000000	BIT01 = 000002	COR13 032576	DF135 = 070151	DF217 = 070501
ADDW2 = 000000	BIT02 = 000004	COR2 032034	DF136 = 070221	DF22 = 070115
ADDW3 = 000000	BIT03 = 000010	COR3 032050	DF137 = 070175	DF220 = 070425
ADDW4 = 000000	BIT04 = 000020	COR33 032062	DF14 = 070056	DF221 = 070425
ADDW5 = 000000	BIT05 = 000040	COR4 032122	DF140 = 070175	DF222 = 070425
ADDW6 = 000000	BIT06 = 000100	COR5 032162	DF141 = 070175	DF223 = 070425
ADDW7 = 000000	BIT07 = 000200	COR6 032222	DF142 = 070175	DF224 = 070425
ADDW8 = 000000	BIT08 = 000400	COR7 032266	DF143 = 070175	DF225 = 070425
ADDW9 = 000000	BIT09 = 001000	COR8 032326	DF144 = 070175	DF226 = 070451
ADEVCT= 000000	BIT1 = 000002	COR9 032372	DF145 = 070125	DF227 = 070451
ADEVVM = 000000	BIT10 = 002000	CPSPUR 036712	DF146 = 070125	DF23 = 070125
AENV = 000000	BIT11 = 004000	CPTWO 036730	DF147 = 070125	DF230 = 070451
AENVVM = 000000	BIT12 = 010000	CR = 000015	DF15 = 070056	DF231 = 070451
AFATAL= 000000	BIT13 = 020000	CRLF = 000200	DF150 = 070125	DF232 = 070451
AMADR1= 000000	BIT14 = 040000	DDDDON 017054	DF151 = 070221	DF233 = 070510
AMADR2= 000000	BIT15 = 100000	DDD1 016124	DF152 = 070221	DF234 = 070525
AMADR3= 000000	BIT2 = 000004	DDD2 016200	DF153 = 070221	DF235 = 070534
AMADR4= 000000	BIT3 = 000010	DDD3 016254	DF154 = 070221	DF236 = 070525
AMAMS1= 000000	BIT4 = 000020	DDD4 016330	DF155 = 070221	DF237 = 070525
AMAMS2= 000000	BIT5 = 000040	DDD5 016404	DF156 = 070221	DF24 = 070125
AMAMS3= 000000	BIT6 = 000100	DDD6 016460	DF157 = 070151	DF240 = 070525
AMAMS4= 000000	BIT7 = 000200	DDD7 016534	DF16 = 070056	DF241 = 070510
AMSGAD= 000000	BIT8 = 000400	DDISP = 177570	DF160 = 070221	DF242 = 070525
AMSGLG= 000000	BIT9 = 001000	DF1 = 070056	DF161 = 070151	DF243 = 070510



DF244 = 070510  
DF245 = 070510  
DF246 = 070151  
DF247 = 070540  
DF25 = 070125  
DF250 = 070540  
DF251 = 070540  
DF252 = 070546  
DF253 = 070552  
DF254 = 070552  
DF255 = 070552  
DF256 = 070552  
DF257 = 070552  
DF26 = 070125  
DF260 = 070552  
DF261 = 070552  
DF262 = 070552  
DF263 = 070552  
DF264 = 070552  
DF265 = 070552  
DF266 = 070546  
DF27 = 070125  
DF3 = 070056  
DF30 = 070125  
DF31 = 070125  
DF32 = 070125  
DF33 = 070151  
DF34 = 070151  
DF35 = 070151  
DF36 = 070151  
DF37 = 070125  
DF4 = 070056  
DF40 = 070125  
DF41 = 070125  
DF42 = 070125  
DF43 = 070125  
DF44 = 070125  
DF45 = 070125  
DF46 = 070151  
DF47 = 070151  
DF5 = 070056  
DF50 = 070151  
DF51 = 070151  
DF52 = 070151  
DF53 = 070245  
DF54 = 070245  
DF55 = 070245  
DF56 = 070245  
DF57 = 070245  
DF6 = 070056  
DF60 = 070245  
DF61 = 070245  
DF62 = 070245  
DF63 = 070245  
DF64 = 070245  
DF65 = 070245  
DF66 = 070245

DF67 = 070245  
DF7 = 070056  
DF70 = 070277  
DF71 = 070277  
DF72 = 070277  
DF73 = 070277  
DF74 = 070277  
DF75 = 070277  
DF76 = 070277  
DF77 = 070277  
DH1 = 066262  
DH10 = 066262  
DH100 = 066262  
DH101 = 066262  
DH102 = 066262  
DH103 = 066262  
DH104 = 066262  
DH105 = 066262  
DH106 = 066262  
DH107 = 066262  
DH11 = 066262  
DH110 = 066262  
DH111 = 066262  
DH112 = 066262  
DH113 = 066262  
DH114 = 066262  
DH115 = 066623  
DH116 = 066623  
DH117 = 066623  
DH12 = 066262  
DH120 = 066623  
DH121 = 066623  
DH122 = 066623  
DH123 = 066262  
DH124 = 066262  
DH125 = 066262  
DH126 = 066262  
DH127 = 066623  
DH13 = 066262  
DH130 = 066623  
DH131 = 066623  
DH132 = 066262  
DH133 = 066623  
DH134 = 066623  
DH135 = 066262  
DH136 = 066623  
DH137 = 066623  
DH14 = 066262  
DH140 = 066623  
DH141 = 066623  
DH142 = 066623  
DH143 = 066623  
DH144 = 066623  
DH145 = 066262  
DH146 = 066262  
DH147 = 066262  
DH15 = 066262

DH150 = 066262  
DH151 = 066623  
DH152 = 066623  
DH153 = 066623  
DH154 = 066623  
DH155 = 066623  
DH156 = 066623  
DH157 = 066262  
DH16 = 066262  
DH160 = 066623  
DH161 = 066262  
DH162 = 066262  
DH163 = 066623  
DH164 = 066262  
DH165 = 066623  
DH166 = 066623  
DH167 = 066623  
DH17 = 066413  
DH170 = 066623  
DH171 = 066623  
DH172 = 066623  
DH173 = 066623  
DH174 = 066623  
DH175 = 066623  
DH176 = 066623  
DH177 = 066623  
DH2 = 066352  
DH20 = 066262  
DH200 = 066623  
DH201 = 066623  
DH202 = 066623  
DH203 = 066623  
DH204 = 066623  
DH205 = 066623  
DH206 = 066623  
DH207 = 066762  
DH21 = 066466  
DH210 = 067052  
DH211 = 067052  
DH212 = 066762  
DH213 = 066762  
DH214 = 066762  
DH215 = 066762  
DH216 = 067052  
DH217 = 067113  
DH22 = 066555  
DH220 = 066722  
DH221 = 067052  
DH222 = 066722  
DH223 = 067052  
DH224 = 066722  
DH225 = 067052  
DH226 = 067166  
DH227 = 067255  
DH23 = 066262  
DH230 = 067166  
DH231 = 067255

DH232 = 067255  
DH233 = 067344  
DH234 = 067405  
DH235 = 067473  
DH236 = 067533  
DH237 = 067405  
DH24 = 066262  
DH240 = 067621  
DH241 = 067344  
DH242 = 067621  
DH243 = 067344  
DH244 = 067344  
DH245 = 067344  
DH246 = 066262  
DH247 = 067711  
DH25 = 066262  
DH250 = 067756  
DH251 = 067756  
DH252 = 066352  
DH253 = 066262  
DH254 = 066262  
DH255 = 066262  
DH256 = 066262  
DH257 = 066262  
DH26 = 066262  
DH260 = 066262  
DH261 = 066262  
DH262 = 066262  
DH263 = 066262  
DH264 = 066262  
DH265 = 066262  
DH266 = 070016  
DH27 = 066262  
DH3 = 066262  
DH30 = 066262  
DH31 = 066262  
DH32 = 066262  
DH33 = 066262  
DH34 = 066262  
DH35 = 066262  
DH36 = 066262  
DH37 = 066262  
DH4 = 066262  
DH40 = 066262  
DH41 = 066262  
DH42 = 066262  
DH43 = 066262  
DH44 = 066262  
DH45 = 066262  
DH46 = 066262  
DH47 = 066262  
DH5 = 066262  
DH50 = 066262  
DH51 = 066262  
DH52 = 066262  
DH53 = 066262  
DH54 = 066262

DH55 = 066262  
DH56 = 066262  
DH57 = 066262  
DH6 = 066262  
DH60 = 066262  
DH61 = 066262  
DH62 = 066262  
DH63 = 066262  
DH64 = 066262  
DH65 = 066262  
DH66 = 066262  
DH67 = 066262  
DH7 = 066262  
DH70 = 066262  
DH71 = 066262  
DH72 = 066262  
DH73 = 066262  
DH74 = 066262  
DH75 = 066262  
DH76 = 066262  
DH77 = 066262  
DISPLA = 001142  
DISPRE = 000174  
DIVDSU = 016614  
DIVDT = 017044  
DIVFSU = 015674  
DIVFT = 016110  
DSWR = 177570  
DT1 = 070604  
DT10 = 070604  
DT100 = 071120  
DT101 = 071120  
DT102 = 071120  
DT103 = 071120  
DT104 = 071120  
DT105 = 071120  
DT106 = 071120  
DT107 = 071120  
DT11 = 070604  
DT110 = 071120  
DT111 = 070772  
DT112 = 070772  
DT113 = 070772  
DT114 = 070772  
DT115 = 071044  
DT116 = 071044  
DT117 = 071044  
DT12 = 070604  
DT120 = 071044  
DT121 = 071044  
DT122 = 071044  
DT123 = 070772  
DT124 = 070772  
DT125 = 070772  
DT126 = 070772  
DT127 = 071044  
DT13 = 070604

DT130 = 071044  
 DT131 = 071044  
 DT132 = 070772  
 DT133 = 071044  
 DT134 = 071044  
 DT135 = 070772  
 DT136 = 071044  
 DT137 = 071044  
 DT14 = 070604  
 DT140 = 071044  
 DT141 = 071044  
 DT142 = 071044  
 DT143 = 071044  
 DT144 = 071044  
 DT145 = 070772  
 DT146 = 070772  
 DT147 = 070772  
 DT15 = 070604  
 DT150 = 070772  
 DT151 = 071044  
 DT152 = 071044  
 DT153 = 071044  
 DT154 = 071044  
 DT155 = 071044  
 DT156 = 071044  
 DT157 = 070772  
 DT16 = 070604  
 DT160 = 071044  
 DT161 = 070772  
 DT162 = 070772  
 DT163 = 071044  
 DT164 = 070772  
 DT165 = 071206  
 DT166 = 071206  
 DT167 = 071206  
 DT17 = 070670  
 DT170 = 071206  
 DT171 = 071206  
 DT172 = 071206  
 DT173 = 071206  
 DT174 = 071206  
 DT175 = 071206  
 DT176 = 071206  
 DT177 = 071206  
 DT2 = 070642  
 DT20 = 070710  
 DT200 = 071206  
 DT201 = 071206  
 DT202 = 071206  
 DT203 = 071206  
 DT204 = 071206  
 DT205 = 071206  
 DT206 = 071206  
 DT207 = 071316  
 DT21 = 070732  
 DT210 = 071274  
 DT211 = 071316

DT212 = 071370  
 DT213 = 071370  
 DT214 = 071370  
 DT215 = 071370  
 DT216 = 071316  
 DT217 = 071452  
 DT22 = 070754  
 DT220 = 071316  
 DT221 = 071316  
 DT222 = 071316  
 DT223 = 071316  
 DT224 = 071316  
 DT225 = 071316  
 DT226 = 071370  
 DT227 = 071370  
 DT23 = 070772  
 DT230 = 071370  
 DT231 = 071274  
 DT232 = 071316  
 DT233 = 071472  
 DT234 = 071526  
 DT235 = 071546  
 DT236 = 071526  
 DT237 = 071526  
 DT24 = 070772  
 DT240 = 071526  
 DT241 = 071472  
 DT242 = 071526  
 DT243 = 071472  
 DT244 = 071472  
 DT245 = 071472  
 DT246 = 070772  
 DT247 = 071560  
 DT25 = 070772  
 DT250 = 071576  
 DT251 = 071576  
 DT252 = 071610  
 DT253 = 071622  
 DT254 = 071622  
 DT255 = 071622  
 DT256 = 071622  
 DT257 = 071622  
 DT26 = 070772  
 DT260 = 071622  
 DT261 = 071622  
 DT262 = 071622  
 DT263 = 071622  
 DT264 = 071622  
 DT265 = 071622  
 DT266 = 071610  
 DT27 = 070772  
 DT3 = 070604  
 DT30 = 070772  
 DT31 = 070772  
 DT32 = 070772  
 DT33 = 070772  
 DT34 = 070772

DT35 = 070772  
 DT36 = 070772  
 DT37 = 070772  
 DT4 = 070604  
 DT40 = 070772  
 DT41 = 070772  
 DT42 = 070772  
 DT43 = 070772  
 DT44 = 070772  
 DT45 = 070772  
 DT46 = 070772  
 DT47 = 070772  
 DT5 = 070604  
 DT50 = 070772  
 DT51 = 070772  
 DT52 = 070772  
 DT53 = 071120  
 DT54 = 071120  
 DT55 = 071120  
 DT56 = 071120  
 DT57 = 071120  
 DT6 = 070604  
 DT60 = 071120  
 DT61 = 071120  
 DT62 = 071120  
 DT63 = 071120  
 DT64 = 071120  
 DT65 = 071120  
 DT66 = 071120  
 DT67 = 071120  
 DT7 = 070604  
 DT70 = 071120  
 DT71 = 071120  
 DT72 = 071120  
 DT73 = 071120  
 DT74 = 071120  
 DT75 = 071120  
 DT76 = 071120  
 DT77 = 071120  
 EEEDON = 020064  
 EEE1 = 017060  
 EEE10 = 017454  
 EEE11 = 017510  
 EEE12 = 017544  
 EEE13 = 017600  
 EEE2 = 017114  
 EEE3 = 017150  
 EEE4 = 017204  
 EEE5 = 017240  
 EEE6 = 017274  
 EEE7 = 017330  
 EEE8 = 017364  
 EEE9 = 017420  
 EMTVEC = 000030  
 EM1 = 037724  
 EM10 = 040543  
 EM100 = 053701

EM101 = 053764  
 EM102 = 054160  
 EM103 = 054354  
 EM104 = 054466  
 EM105 = 054633  
 EM106 = 054742  
 EM107 = 055051  
 EM11 = 040650  
 EM110 = 055160  
 EM111 = 043775  
 EM112 = 044052  
 EM113 = 044130  
 EM114 = 044206  
 EM115 = 044265  
 EM116 = 044343  
 EM117 = 044422  
 EM12 = 040757  
 EM120 = 044560  
 EM121 = 044716  
 EM122 = 045053  
 EM123 = 045210  
 EM124 = 045266  
 EM125 = 045345  
 EM126 = 045423  
 EM127 = 045502  
 EM13 = 041066  
 EM130 = 045560  
 EM131 = 045637  
 EM132 = 045775  
 EM133 = 046133  
 EM134 = 046271  
 EM135 = 046426  
 EM136 = 046563  
 EM137 = 046720  
 EM14 = 041202  
 EM140 = 047006  
 EM141 = 043775  
 EM142 = 044052  
 EM143 = 047075  
 EM144 = 047153  
 EM145 = 047232  
 EM146 = 047377  
 EM147 = 047544  
 EM15 = 041314  
 EM150 = 047710  
 EM151 = 050054  
 EM152 = 050142  
 EM153 = 045210  
 EM154 = 045266  
 EM155 = 050231  
 EM156 = 050307  
 EM157 = 050366  
 EM16 = 041426  
 EM160 = 050533  
 EM161 = 050671  
 EM162 = 051036  
 EM163 = 051202

EM164 = 051337  
 EM165 = 055270  
 EM166 = 055354  
 EM167 = 055437  
 EM17 = 041523  
 EM170 = 055471  
 EM171 = 055557  
 EM172 = 055702  
 EM173 = 055767  
 EM174 = 056135  
 EM175 = 056303  
 EM176 = 056415  
 EM177 = 056501  
 EM2 = 037756  
 EM20 = 041600  
 EM200 = 056564  
 EM201 = 056616  
 EM202 = 056705  
 EM203 = 057047  
 EM204 = 057211  
 EM205 = 057277  
 EM206 = 057445  
 EM207 = 057613  
 EM21 = 041632  
 EM210 = 057655  
 EM211 = 057717  
 EM212 = 060063  
 EM213 = 060247  
 EM214 = 060433  
 EM215 = 060617  
 EM216 = 061003  
 EM217 = 061165  
 EM22 = 041664  
 EM220 = 061227  
 EM221 = 061457  
 EM222 = 061723  
 EM223 = 062154  
 EM224 = 062421  
 EM225 = 062652  
 EM226 = 063117  
 EM227 = 063252  
 EM23 = 041745  
 EM230 = 063405  
 EM231 = 063541  
 EM232 = 057655  
 EM233 = 063675  
 EM234 = 063734  
 EM235 = 064020  
 EM236 = 064066  
 EM237 = 064121  
 EM24 = 042022  
 EM240 = 064205  
 EM241 = 064241  
 EM242 = 064344  
 EM243 = 064400  
 EM244 = 064503  
 EM245 = 064542

EM246	043405	EM70	053166	GGG5	024464	HHHDON	030004	HXER11	013200
EM247	064624	EM71	053217	GGG6	024534	HHH1	025702	HXER12	013220
EM25	042120	EM72	053247	GGG7	024604	HHH10	027002	HXER13	013250
EM250	064660	EM73	= 053247	GGG8	024654	HHH11	027102	HXER2	012716
EM251	064712	EM74	053301	GGG9	024724	HHH12	027202	HXER22	012732
EM252	064745	EM75	053410	GGP1	011550	HHH13	027302	HXER3	012746
EM253	065036	EM76	053501	GGP2	011560	HHH2	026002	HXER33	012762
EM254	065122	EM77	053571	GGP3	011570	HHH3	026102	HXER4	012776
EM255	065207	ERM10	034152	GGP4	011600	HHH4	026202	HXER5	012676
EM256	065275	ERROR	= 104000	GGP5	011610	HHH5	026302	HXER6	013032
EM257	065364	ERRVEC	= 000004	GGP6	011620	HHH6	026402	HXER66	013046
EM26	042205	ERTYPE	036204	GGP7	011630	HHH7	026502	HXER7	013062
EM260	065452	ERT1	036370	GGP8	011640	HHH8	026602	HXER8	013014
EM261	065541	ERT2	036624	GGP9	011650	HHH9	026702	HXER9	013112
EM262	065631	ERT3	036630	GG1	006746	HHP0	006602	HXP1	013300
EM263	065722	ERT4	036642	GG10	007242	HHP1	006612	HXP2	013310
EM264	066007	ERT5	036654	GG11	007300	HHP10	006722	HXP3	013320
EM265	066074	FFFDON	020614	GG12	007322	HHP11	006732	HXP4	013330
EM266	066161	FFF1	020070	GG13	007332	HHP2	006622	HXP5	013340
EM27	= 042120	FFF2	020144	GG14	007350	HHP3	006632	HXP6	013350
EM3	040012	FFF3	020220	GG15	007406	HHP4	006642	HXP7	013360
EM30	042303	FFF4	020274	GG16	007424	HHP5	006652	HXP8	013370
EM31	042355	FPSPUR	036660	GG17	007472	HHP6	006662	HX1	011664
EM32	041770	FPVECT	= 000244	GG18	007502	HHP7	006672	HX10	012072
EM33	042422	GGDATO	011540	GG19	007536	HHP8	006702	HX11	012114
EM34	042445	GGDONE	011660	GG2	007004	HHP9	006712	HX12	012134
EM35	042477	GGERO	010036	GG20	007574	HHTRAP	006522	HX13	012144
EM36	042552	GGER1	010134	GG21	007616	HH1	005022	HX14	012152
EM37	042620	GGER10	010646	GG22	007626	HH10	005234	HX15	012170
EM4	040117	GGER11	010714	GG23	007644	HH11	005252	HX16	012216
EM40	042643	GGER12	010762	GG24	007702	HH12	005302	HX165	012222
EM41	042675	GGER13	011030	GG25	007720	HH13	005324	HX17	012250
EM42	042750	GGER14	011076	GG26	007766	HH14	005344	HX18	012306
EM43	043101	GGER15	011174	GG27	007776	HH15	005354	HX19	012326
EM44	043232	GGER16	011242	GG28	010032	HH16	005362	HX2	011714
EM45	043300	GGER17	011310	GG3	007026	HH17	005400	HX20	012336
EM46	043353	GGER18	011356	GG4	007036	HH18	005436	HX21	012340
EM47	043430	GGER19	011424	GG5	007054	HH19	005460	HX22	012370
EM5	040224	GGER2	010202	GG6	007112	HH2	005052	HX23	012410
EM50	043564	GGER20	011472	GG7	007130	HH20	005470	HX24	012430
EM51	043637	GGER3	010250	GG8	007176	HH21	005506	HX25	012440
EM52	043705	GGER4	010316	GG9	007206	HH22	005536	HX26	012446
EM53	051535	GGER5	010320	GTSWR	= 104405	HH23	005560	HX27	012450
EM54	051566	GGER6	010366	HHDATO	006572	HH24	005570	HX28	012502
EM55	051503	GGER7	010434	HHDONE	006742	HH25	005606	HX29	012524
EM56	051616	GGER8	010532	HHER0	005612	HH3	005074	HX3	011730
EM57	051707	GGER9	010600	HHER00	005726	HH4	005114	HX30	012534
EM6	040331	GGGDON	025676	HHER1	005660	HH5	005124	HX31	012552
EM60	051777	GGG1	024224	HHER10	006454	HH6	005132	HX32	012602
EM61	052101	GGG10	024774	HHER2	005774	HH7	005144	HX33	012624
EM62	052275	GGG11	025044	HHER3	006042	HH8	005202	HX34	012634
EM63	052471	GGG12	025114	HHER4	006110	HH9	005224	HX35	012652
EM64	052602	GGG13	025164	HHER5	006156	HT	= 000011	HX4	011750
EM65	052721	GGG14	025234	HHER6	006224	HXDATO	013270	HX5	011770
EM66	053034	GGG2	024274	HHER7	006272	HXDONE	013400	HX6	012000
EM67	053103	GGG3	024344	HHER8	006340	HXER1	012656	HX7	012006
EM7	040436	GGG4	024414	HHER9	006406	HXER10	013146	HX8	012024

HX9 012056  
IIIDON 021454  
II11 020620  
II12 020664  
II13 020730  
II14 020774  
IOTVEC= 000020  
JJJDON 022414  
JJJ1 021460  
JJJ2 021544  
JJJ3 021630  
JJJ4 021714  
KKKDON 023256  
KKK1 022420  
KKK3 022464  
KKK4 022530  
KKK5 022574  
LF = 000012  
LLLDON 024220  
LLL1 023262  
LLL2 023346  
LLL3 023432  
LLL4 023516  
LOOP 005020  
LPERR = 104413  
MMMDON 030732  
MMM1 030010  
MMM2 030062  
MMM3 030134  
MMM4 030206  
MMM5 030260  
MNUMBE= 000266  
MODDD0 031740  
MODDD1 031750  
MODDOV 031352  
MODDSU 027406  
MODDT0 027764  
MODDT1 027774  
MODFDO 030712  
MODFD1 030722  
MODFOV 030336  
MODFSU 025310  
MODFT0 025646  
MODFT1 025656  
MODP1 025666  
MSA1 037024  
MSA2 037042  
MSA3 037065  
MSA4 037077  
MSA5 037115  
MSA6 037130  
MS1 037222  
MS10 037421  
MS11 037443  
MS12 037467  
MS2 037240  
MS3 037260

MS37 037512  
MS4 037307  
MS40 037530  
MS41 037564  
MS415 037544  
MS42 037610  
MS43 037626  
MS44 037643  
MS5 037335  
MS6 037357  
MS7 037375  
MULDSU 020354  
MULDT 020604  
MULFSU 017640  
MULFT 020054  
NANDON 031760  
NNN1 030736  
NNN2 031040  
NNN3 031142  
NNN4 031244  
OVDNTT 022404  
OVDTT 024210  
OVFNTT 021444  
OVFTT 023246  
OVUNDN 022004  
OVUNDT 023606  
OVUNFN 021044  
OVUNFT 022644  
PIRQ = 177772  
PIRQVE= 000240  
POWERM 037150  
PROGNUM= 000002  
PRO = 000000  
PR1 = 000040  
PR2 = 000100  
PR3 = 000140  
PR4 = 000200  
PR5 = 000240  
PR6 = 000300  
PR7 = 000340  
PS = 177776  
PSW = 177776  
PWRVEC= 000024  
RDCHR = 104407  
RESREG= 104411  
RESVEC= 000010  
RSETUP= 104412  
R6 = %000006  
R7 = %000007  
SAVREG= 104410  
SCOPE = 000004  
SPACE 037217  
STACK = 001100  
START 004336  
STKLMT= 177774  
SWR 001140  
SWREG 000176

SW0 = 000001  
SW00 = 000001  
SW01 = 000002  
SW02 = 000004  
SW03 = 000010  
SW04 = 000020  
SW05 = 000040  
SW06 = 000100  
SW07 = 000200  
SW08 = 000400  
SW09 = 001000  
SW1 = 000002  
SW10 = 002000  
SW11 = 004000  
SW12 = 010000  
SW13 = 020000  
SW14 = 040000  
SW15 = 100000  
SW2 = 000004  
SW3 = 000010  
SW4 = 000020  
SW5 = 000040  
SW6 = 000100  
SW7 = 000200  
SW8 = 000400  
SW9 = 001000  
TAB = 000011  
TBITVE= 000014  
TKVEC = 000060  
TPVEC = 000064  
TRAPVE= 000034  
TRTVEC= 000014  
TST1 005020  
TST10 017056  
TST11 020066  
TST12 020616  
TST13 021456  
TST14 022416  
TST15 023260  
TST16 024222  
TST17 025700  
TST2 006744  
TST20 030006  
TST21 030734  
TST22 031762  
TST23 033144  
TST3 011662  
TST4 013402  
TST5 014410  
TST6 015112  
TST7 016122  
TYPE = 104401  
TYPOC = 104402  
TYPON = 104404  
TYPOS = 104403  
\$APTHD 004322  
\$ATYC 035054

\$ATY1 035030  
\$ATY3 035036  
\$ATY4 035046  
\$AUTOB 001134  
\$BASE 001372  
\$BDADR 001122  
\$BDDAT 001126  
\$BELL 001306  
\$CDW1 001376  
\$CDW2 001400  
\$CHARC 034576  
\$CKSWR 035276  
\$CLR.T 033346  
\$CMTAG 001100  
\$CM1 = 000024  
\$CM2 = 000050  
\$CM3 = 000024  
\$CM4 = 000024  
\$CNTLG 035705  
\$CNTLU 035700  
\$CPUOP 001344  
\$CRLF 001313  
\$DDW0 001402  
\$DDW1 001404  
\$DDW10 001426  
\$DDW11 001430  
\$DDW12 001432  
\$DDW13 001434  
\$DDW14 001436  
\$DDW15 001440  
\$DDW2 001406  
\$DDW3 001410  
\$DDW4 001412  
\$DDW5 001414  
\$DDW6 001416  
\$DDW7 001420  
\$DDW8 001422  
\$DDW9 001424  
\$DEVCT 001326  
\$DEVM 001374  
\$DOAGN 033366  
\$ENDAD 033356  
\$ENDCT 033200  
\$ENULL 033432  
\$ENV 001336  
\$ENVM 001337  
\$EOP 033144  
\$EOPCT 033172  
\$ERFLG 001103  
\$ERMAX 001115  
\$ERROR 033716  
\$ERRPC 001116  
\$ERRTB 001442  
\$ERTTL 001112  
\$ESCAP 001304  
\$ETABL 001336  
\$ETEND 001442

\$FATAL 001320  
\$FFLG 035274  
\$FILLC 001156  
\$FILLS 001155  
\$GDADR 001120  
\$GDDAT 001124  
\$GET42 033330  
\$GTSWR 035346  
\$HD = 000003  
\$HIBTS 004322  
\$ICNT 001104  
\$ILLUP 036176  
\$INTAG 001135  
\$ITEMB 001114  
\$LF 001314  
\$LFLG 035273  
\$LOOP 033424  
\$LPADR 001106  
\$LPERR 001110  
\$MADR1 001350  
\$MADR2 001354  
\$MADR3 001360  
\$MADR4 001364  
\$MAIL 001316  
\$MAMS1 001346  
\$MAMS2 001352  
\$MAMS3 001356  
\$MAMS4 001362  
\$MBADR 004324  
\$MFLG 035272  
\$MNEW 035723  
\$MSGAD 001332  
\$MSGLG 001334  
\$MSGTY 001316  
\$MSWR 035712  
\$MTYP1 001347  
\$MTYP2 001353  
\$MTYP3 001357  
\$MTYP4 001363  
\$MXCNT 033714  
\$NULL 001154  
\$NWTST= 000001  
\$OCNT 035024  
\$OMODE 035026  
\$OVER 033700  
\$PASS 001324  
\$PASTM 004330  
\$PWRAD 036160  
\$PWRDN 036020  
\$PWRMG 036154  
\$PWRUP 036072  
\$QUES 001312  
\$RDCHR 035560  
\$RDSZ = 000001  
\$REGAD 001160  
\$REGO 001162  
\$REG1 001164

\$REG10	001202	\$RESRE	034212	\$TESTN	001322	\$TMP22	001276	\$TYPE	034250
\$REG11	001204	\$RTNAD	033426	\$TIMES	001302	\$TMP23	001300	\$TYPEC	034462
\$REG12	001206	\$RTRN	033422	\$TKB	001146	\$TMP3	001240	\$TYPEX	034600
\$REG13	001210	\$SAVRE	034154	\$TKS	001144	\$TMP4	001242	\$TYPOC	034626
\$REG14	001212	\$SAVR6	036202	\$TMP0	001232	\$TMP5	001244	\$TYPON	034642
\$REG15	001214	\$SCOPE	033436	\$TMP1	001234	\$TMP6	001246	\$TYPOS	034602
\$REG16	001216	\$SETUP=	000137	\$TMP10	001252	\$TMP7	001250	\$UNIT	001330
\$REG17	001220	\$STUP =	177777	\$TMP11	001254	\$TN =	000023	\$UNITM	004332
\$REG2	001166	\$SVLAD	033644	\$TMP12	001256	\$TPB	001152	\$USWR	001342
\$REG20	001222	\$SVPC =	004322	\$TMP13	001260	\$TPFLG	001157	\$VECT1	001366
\$REG21	001224	\$SWR =	177400	\$TMP14	001262	\$TPS	001150	\$VECT2	001370
\$REG22	001226	\$SWREG	001340	\$TMP15	001264	\$TRAP	035734	\$XTSTR	033450
\$REG23	001230	\$SWRMK=	000000	\$TMP16	001266	\$TRAP2	035756	\$\$GET4=	000001
\$REG3	001170	\$SWRMS=	000200	\$TMP17	001270	\$TRP =	000014	\$OF ILL	035025
\$REG4	001172	\$TAB	037215	\$TMP2	001236	\$TRPAD	035770	.LPER	036746
\$REG5	001174	\$TBIT	033430	\$TMP20	001272	\$TSTM	004326	.RSET	036754
\$REG6	001176	\$TERM =	000030	\$TMP21	001274	\$TSTNM	001102	.\$X =	004322
\$REG7	001200								

. ABS. 071710 000  
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 58376 WORDS ( 229 PAGES)

DYNAMIC MEMORY: 20434 WORDS ( 78 PAGES)

ELAPSED TIME: 00:15:56

CKFPBA0.BIN,CKFPBA0.SEQ/CRF=CKFPBA0.MLB/ML,CKFPBA0.P11

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
AAADON		014406	12-2020 #12-2106
AAA1		013404	#11-1821
AAA10		014022	#11-1952
AAA11		014060	#12-1970
AAA12		014116	#12-1987
AAA13		014154	#12-2004
AAA2		013442	#11-1832
AAA3		013500	#11-1845
AAA4		013536	#11-1858
AAA5		013574	#11-1872
AAA6		013632	#11-1885
AAA7		013670	#11-1902
AAA8		013726	#11-1919
AAA9		013764	#11-1936
ABASE	=	000000	8-890
ACDW1	=	000000	8-890
ACDW2	=	000000	8-890
ACPUOP	=	000000	8-890
ACO	=	%000000	#7-879 *9-928 *9-930 9-933 *9-962 *9-964 9-967 *9-986 *9-988
			9-991 *9-1016 *9-1018 9-1021 *9-1038 *9-1040 9-1043 *9-1158 *9-1160
			9-1163 *9-1182 *9-1184 9-1187 9-1198 *9-1223 *9-1225 9-1228 *9-1247
			*9-1249 9-1252 9-1263 *9-1289 *9-1291 9-1294 *11-1315 *11-1317 11-1320
			11-1331 11-1362 11-1388 11-1414 *11-1486 *11-1489 11-1496 *11-1520 *11-1527
			11-1537 *11-1568 *11-1583 *11-1586 11-1589 *11-1603 *11-1605 11-1608 *11-1633
			*11-1634 *11-1638 11-1643 *11-1664 *11-1668 11-1673 *12-2053 12-2059 12-2087
			*12-2129 *12-2132 *12-2152 *12-2154 *12-2174 *12-2179 *12-2452 *12-2459 12-2466
			*13-2636 *13-2644 13-2651 *13-2887 *13-2894 13-2901 *13-3034 *13-3042 13-3049
			*13-3221 *13-3240 13-3247 14-3319 *14-3473 *14-3492 14-3499 14-3570 *14-3719
			*14-3738 14-3754 14-3832 *15-3971 *15-3990 15-4006 15-4084 *15-4373 *15-4382
			15-4388 *16-4742 *16-4751 16-4757 *16-4980 *16-4989 16-4996 *16-5199 *16-5208
			16-5215 17-5373 *17-5373 *17-5386 *17-5400 *17-5414 *17-5430 *17-5444 *17-5460
			*17-5473 *17-5488 *17-5502 *17-5516 *17-5559 17-5585
AC1	=	%000001	#7-880 *15-4375 15-4390 *15-4744 16-4759 *16-4982 16-4998 *16-5201 16-5217
AC2	=	%000002	#7-881
AC3	=	%000003	#7-882
AC4	=	%000004	#7-883
AC5	=	%000005	#7-884
AC6	=	%000006	#7-885
AC7	=	%000007	#7-886
ADDW0	=	000000	8-890
ADDW1	=	000000	8-890
ADDW10	=	000000	8-890
ADDW11	=	000000	8-890
ADDW12	=	000000	8-890
ADDW13	=	000000	8-890
ADDW14	=	000000	8-890
ADDW15	=	000000	8-890
ADDW2	=	000000	8-890
ADDW3	=	000000	8-890
ADDW4	=	000000	8-890
ADDW5	=	000000	8-890
ADDW6	=	000000	8-890

SYMBOL CROSS REFERENCE		REFERENCES			
SYMBOL	VALUE				
ADDW7	= 000000	8-890	8-890		
ADDW8	= 000000	8-890	8-890		
ADDW9	= 000000	8-890	8-890		
ADEVCT	= 000000	8-890	8-890		
ADEVN	= 000000	8-890	8-890		
AENV	= 000000	8-890	8-890		
AENVN	= 000000	8-890	8-890		
AFATAL	= 000000	8-890	8-890		
AMADR1	= 000000	8-890	8-890		
AMADR2	= 000000	8-890	8-890		
AMADR3	= 000000	8-890	8-890		
AMADR4	= 000000	8-890	8-890		
AMAMS1	= 000000	8-890	8-890		
AMAMS2	= 000000	8-890	8-890		
AMAMS3	= 000000	8-890	8-890		
AMAMS4	= 000000	8-890	8-890		
AMSGAD	= 000000	8-890	8-890		
AMSGLG	= 000000	8-890	8-890		
AMSGTY	= 000000	8-890	8-890		
AMTYP1	= 000000	8-890	8-890		
AMTYP2	= 000000	8-890	8-890		
AMTYP3	= 000000	8-890	8-890		
AMTYP4	= 000000	8-890	8-890		
APASS	= 000000	8-890	8-890		
APRIOR	= 000000	8-890			
APTCSU	= 000040	17-5651	#17-5655		
APTENV	= 000001	17-5647	17-5651	17-5655	#17-5655
APTSIZ	= 000200	9-903	#17-5655		
APTSP0	= 000100	17-5651	17-5655	#17-5655	
ASWREG	= 000000	8-890	8-890		
ATESTN	= 000000	8-890	8-890		
AUNIT	= 000000	8-890	8-890		
AUSWR	= 000000	8-890	8-890		
AVECT1	= 000000	8-890	8-890		
AVECT2	= 000000	8-890	8-890		
BBBDON	015110	12-2203	12-2224	12-2232	12-2240 12-2253 #12-2260
BBBER1	014664	12-2126	#12-2207		
BBBER2	014750	12-2139	12-2161	12-2197	#12-2227
BBBER3	014776	12-2143	12-2165	12-2201	#12-2235
BBBER4	015024	12-2182	#12-2244		
BBBP1	015070	12-2128	12-2130	12-2153	12-2177 #12-2255
BBBP2	015100	12-2151	12-2173	#12-2256	
BBB0	014414	#12-2122			
BBB1	014450	12-2127	#12-2132		
BBB2	014476	#12-2146			
BBB3	014526	12-2150	#12-2154		
BBB4	014554	#12-2168			
BBB5	014612	12-2172	#12-2179	12-2184	
BBB6	014620	12-2176	#12-2184		
BIT0	= 000001	#7-877			
BIT00	= 000001	#7-877	7-877		
BIT01	= 000002	#7-877	7-877		

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES									
BIT02		= 000004	#7-877	7-877								
BIT03		= 000010	#7-877	7-877								
BIT04		= 000020	#7-877	7-877								
BIT05		= 000040	#7-877	7-877								
BIT06		= 000100	#7-877	7-877								
BIT07		= 000200	#7-877	7-877								
BIT08		= 000400	#7-877	7-877	17-5645							
BIT09		= 001000	#7-877	7-877	17-5645	17-5647	17-5647					
BIT1		= 000002	#7-877									
BIT10		= 002000	#7-877	17-5647								
BIT11		= 004000	#7-877	17-5645								
BIT12		= 010000	#7-877	17-5643								
BIT13		= 020000	#7-877	17-5647								
BIT14		= 040000	#7-877	17-5645								
BIT15		= 100000	#7-877									
BIT2		= 000004	#7-877									
BIT3		= 000010	#7-877									
BIT4		= 000020	#7-877									
BIT5		= 000040	#7-877									
BIT6		= 000100	#7-877									
BIT7		= 000200	#7-877									
BIT8		= 000400	#7-877									
BIT9		= 001000	#7-877									
BPTVEC		= 000014	#7-877									
CCCDON		016120	12-2420	#12-2507								
CCC1		015114	#12-2274									
CCC10		015510	#12-2376									
CCC11		015544	#12-2387									
CCC12		015600	#12-2399									
CCC13		015634	#12-2410									
CCC2		015150	#12-2285									
CCC3		015204	#12-2296									
CCC4		015240	#12-2308									
CCC5		015274	#12-2319									
CCC6		015330	#12-2330									
CCC7		015364	#12-2341									
CCC8		015420	#12-2353									
CCC9		015454	#12-2365									
CKSWR	=	104406	17-5645	17-5647	17-5647	#17-5659	17-5886					
CMPSUB		014216	11-1822	11-1833	11-1846	11-1859	11-1873	11-1886	11-1903	11-1920	11-1937	
			11-1953	12-1971	12-1988	12-2005	#12-2046					
CMPTMP		014376	12-2086	12-2098	#12-2102							
CNT	=	000267	#9-892	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-396	9-896	
			#9-896	9-896	9-896	#9-896	9-896	9-896	#9-896	9-896	9-896	





SYMBOL CROSS REFERENCE

SYMBOL	VALUE	REFERENCES	CREF						
CORFLG	033124	17-5375 17-5388 17-5402 17-5416 17-5432 17-5446 17-5461 17-5474 17-5490							
		17-5504 17-5518 17-5553 *17-5569 17-5576 17-5615 #17-5620							
CORINT	033136	17-5353 17-5571 17-5578 #17-5623							
CORMES	037665	17-5366 #18-5933							
CORSUB	032642	17-5369 17-5382 17-5396 17-5410 17-5426 17-5440 17-5456 17-5469 17-5484							
		17-5498 17-5512 #17-5553							
CORTMP	033126	17-5584 17-5586 17-5603 #17-5621							
CORTRP	033140	17-5568 #17-5628							
CORTV	032740	17-5568 #17-5576							
CORTVO	033102	17-5598 17-5601 17-5606 #17-5610							
CORTV1	033106	17-5577 #17-5612							
COR1	032010	17-5346 #17-5352							
COR10	032432	#17-5468							
COR11	032476	#17-5483							
COR12	032536	#17-5497							
COR13	032576	#17-5511							
COR2	032034	17-5352 #17-5357							
COR3	032050	17-5349 17-5355 #17-5362							
COR33	032062	17-5364 #17-5367							
COR4	032122	#17-5381							
COR5	032162	#17-5395							
COR6	032222	#17-5409							
COR7	032266	#17-5425							
COR8	032326	#17-5439							
COR9	032372	#17-5455							
CPSPUR	036712	11-1572 11-1584 11-1737 17-5354 17-5358 #17-5847 17-5891							
CPTWO	036730	#17-5858 17-5892							
CR	= 000015	#7-877 17-5651 17-5651							
CRLF	= 000200	#7-875 #7-877 9-904 9-904 17-5651 17-5651 18-5913 18-5913 18-5933							
		18-5933 18-5942 18-5944 18-5946 18-5948 18-5950 18-5952 18-5954 18-5956							
		18-5958 18-5960 18-5962 18-5964 18-5991 18-5993 18-6000 18-6002 18-6003							
		18-6005 18-6006 18-6008 18-6010 18-6017 18-6019 18-6020 18-6022 18-6024							
		18-6028 18-6030 18-6050 18-6052 18-6064 18-6066 18-6071 18-6073 18-6080							
		18-6082 18-6102 18-6104 18-6114 18-6116 18-6121 18-6123 18-6135 18-6137							
		18-6139 18-6141 18-6143 18-6144 18-6146 18-6147 18-6149 18-6151 18-6153							
		18-6155 18-6167 18-6169 18-6171 18-6173 18-6175 18-6177 18-6179 18-6180							
		18-6182 18-6183 18-6185 18-6187 18-6188 18-6190 18-6192 18-6194 18-6217							
		18-6221 18-6223 18-6225 18-6233 18-6235 18-6237 18-6239 18-6241 18-6243							
		18-6341 18-6341 18-6367 18-6367 18-6367 18-6368 18-6368 18-6368 18-6369							
		18-6369 18-6369 18-6370 18-6370 18-6370 18-6372 18-6372 18-6375 18-6375							
		18-6376 18-6376 18-6376 18-6376 18-6377 18-6377 18-6378 18-6378 18-6378							
		18-6378 18-6379 18-6379 18-6380 18-6380 18-6380 18-6380 18-6381 18-6381							
		18-6382 18-6382 18-6383 18-6383 18-6384 18-6384 18-6384 18-6416 18-6419 18-6421							
		18-6423 18-6427							
DDDDON	017054	12-2601 #13-2697							
DDD1	016124	#12-2520							
DDD2	016200	#12-2531							
DDD3	016254	#12-2542							
DDD4	016330	#12-2553							
DDD5	016404	#12-2564							
DDD6	016460	#12-2577							
DDD7	016534	#12-2589							

SYMBOL	VALUE	REFERENCES							
DDISP	= 177570	#7-877	8-890	9-903					
DF1	070056	9-896	#19-6663	19-6665	19-6666	19-6667	19-6668	19-6669	19-6670
		19-6672	19-6673	19-6674	19-6675	19-6676			19-6671
DF10	= 070056	9-896	#19-6670						
DF100	= 070277	9-896	#19-6771						
DF101	= 070277	9-896	#19-6772						
DF102	= 070277	9-896	#19-6773						
DF103	= 070277	9-896	#19-6774						
DF104	= 070277	9-896	#19-6775						
DF105	= 070277	9-896	#19-6776						
DF106	= 070277	9-896	#19-6777						
DF107	= 070277	9-896	#19-6778						
DF11	= 070056	9-896	#19-6671						
DF110	= 070277	9-896	#19-6779						
DF111	= 070125	9-896	#19-6706						
DF112	= 070125	9-896	#19-6707						
DF113	= 070125	9-896	#19-6708						
DF114	= 070125	9-896	#19-6709						
DF115	070175	9-896	#19-6710	19-6711	19-6712	19-6713	19-6714	19-6715	19-6728
		19-6730	19-6731	19-6732	19-6733				19-6729
DF116	= 070175	9-896	#19-6711						
DF117	= 070175	9-896	#19-6712						
DF12	= 070056	9-896	#19-6672						
DF120	= 070175	9-896	#19-6713						
DF121	= 070175	9-896	#19-6714						
DF122	= 070175	9-896	#19-6715						
DF123	= 070151	9-896	#19-6716						
DF124	= 070151	9-896	#19-6717						
DF125	= 070151	9-896	#19-6718						
DF126	= 070151	9-896	#19-6719						
DF127	070221	9-896	#19-6720	19-6721	19-6722	19-6724	19-6725	19-6727	19-6738
		19-6740	19-6741	19-6742	19-6743	19-6745	19-6748		19-6739
DF13	= 070056	9-896	#19-6673						
DF130	= 070221	9-896	#19-6721						
DF131	= 070221	9-896	#19-6722						
DF132	= 070151	9-896	#19-6723						
DF133	= 070221	9-896	#19-6724						
DF134	= 070221	9-896	#19-6725						
DF135	= 070151	9-896	#19-6726						
DF136	= 070221	9-896	#19-6727						
DF137	= 070175	9-896	#19-6728						
DF14	= 070056	9-896	#19-6674						
DF140	= 070175	9-896	#19-6729						
DF141	= 070175	9-896	#19-6730						
DF142	= 070175	9-896	#19-6731						
DF143	= 070175	9-896	#19-6732						
DF144	= 070175	9-896	#19-6733						
DF145	= 070125	9-896	#19-6734						
DF146	= 070125	9-896	#19-6735						
DF147	= 070125	9-896	#19-6736						
DF15	= 070056	9-896	#19-6675						
DF150	= 070125	9-896	#19-6737						





SYMBOL	VALUE	REFERENCES								
DF35	= 070151	9-896	#19-6691							
DF36	= 070151	9-896	#19-6692							
DF37	= 070125	9-896	#19-6693							
DF4	= 070056	9-896	#19-6666							
DF40	= 070125	9-896	#19-6694							
DF41	= 070125	9-896	#19-6695							
DF42	= 070125	9-896	#19-6696							
DF43	= 070125	9-896	#19-6697							
DF44	= 070125	9-896	#19-6698							
DF45	= 070125	9-896	#19-6699							
DF46	= 070151	9-896	#19-6701							
DF47	= 070151	9-896	#19-6702							
DF5	= 070056	9-896	#19-6667							
DF50	= 070151	9-896	#19-6703							
DF51	= 070151	9-896	#19-6704							
DF52	= 070151	9-896	#19-6705							
DF53	070245	9-896	#19-6750	19-6751	19-6752	19-6753	19-6754	19-6755	19-6756	19-6757
		19-6758	19-6759	19-6760	19-6761	19-6762				
DF54	= 070245	9-896	#19-6751							
DF55	= 070245	9-896	#19-6752							
DF56	= 070245	9-896	#19-6753							
DF57	= 070245	9-896	#19-6754							
DF6	= 070056	9-896	#19-6668							
DF60	= 070245	9-896	#19-6755							
DF61	= 070245	9-896	#19-6756							
DF62	= 070245	9-896	#19-6757							
DF63	= 070245	9-896	#19-6758							
DF64	= 070245	9-896	#19-6759							
DF65	= 070245	9-896	#19-6760							
DF66	= 070245	9-896	#19-6761							
DF67	= 070245	9-896	#19-6762							
DF7	= 070056	9-896	#19-6669							
DF70	070277	9-896	#19-6763	19-6764	19-6765	19-6766	19-6767	19-6768	19-6769	19-6770
		19-6771	19-6772	19-6773	19-6774	19-6775	19-6776	19-6777	19-6778	19-6779
DF71	= 070277	9-896	#19-6764							
DF72	= 070277	9-896	#19-6765							
DF73	= 070277	9-896	#19-6766							
DF74	= 070277	9-896	#19-6767							
DF75	= 070277	9-896	#19-6768							
DF76	= 070277	9-896	#19-6769							
DF77	= 070277	9-896	#19-6770							
DH1	066262	9-896	#18-6455	18-6458	18-6459	18-6460	18-6461	18-6462	18-6463	18-6464
		18-6465	18-6466	18-6467	18-6468	18-6469	18-6471	18-6475	18-6476	18-6477
		18-6478	18-6479	18-6480	18-6481	18-6482	18-6483	18-6484	18-6485	18-6486
		18-6487	18-6488	18-6489	18-6490	18-6491	18-6492	18-6493	18-6494	18-6495
		18-6496	18-6497	18-6498	18-6499	18-6500	18-6501	18-6502	18-6503	18-6511
		18-6512	18-6513	18-6514	18-6518	18-6521	18-6529	18-6530	18-6531	18-6532
		18-6539	18-6541	18-6542	18-6544	18-6545	18-6546	18-6547	18-6548	18-6549
		18-6550	18-6551	18-6552	18-6553	18-6554	18-6555	18-6556	18-6557	18-6558
		18-6559	18-6560	18-6561	18-6562	19-6564	19-6565	19-6566	19-6567	19-6568
		19-6569	19-6570	19-6571	19-6572	19-6573	19-6574	19-6575	19-6648	19-6649
		19-6650	19-6651	19-6652	19-6653	19-6654	19-6655	19-6656	19-6657	19-6658

SYMBOL CROSS REFERENCE

SYMBOL	VALUE	REFERENCES								
DH10	= 066262	9-896	#18-6463							
DH100	= 066262	9-896	#19-6567							
DH101	= 066262	9-896	#19-6568							
DH102	= 066262	9-896	#19-6569							
DH103	= 066262	9-896	#19-6570							
DH104	= 066262	9-896	#19-6571							
DH105	= 066262	9-896	#19-6572							
DH106	= 066262	9-896	#19-6573							
DH107	= 066262	9-896	#19-6574							
DH11	= 066262	9-896	#18-6464							
DH110	= 066262	9-896	#19-6575							
DH111	= 066262	9-896	#18-6500							
DH112	= 066262	9-896	#18-6501							
DH113	= 066262	9-896	#18-6502							
DH114	= 066262	9-896	#18-6503							
DH115	066623	9-896	#18-6504	18-6506	18-6507	18-6508	18-6509	18-6510	18-6515	18-6516
		18-6517	18-6519	18-6520	18-6522	18-6523	18-6524	18-6525	18-6526	18-6527
		18-6528	18-6533	18-6534	18-6535	18-6536	18-6537	18-6538	18-6540	18-6543
		19-6576	19-6577	19-6578	19-6579	19-6580	19-6581	19-6582	19-6583	19-6584
		19-6585	19-6586	19-6587	19-6588	19-6589	19-6590	19-6591	19-6592	19-6593
DH116	= 066623	9-896	#18-6506							
DH117	= 066623	9-896	#18-6507							
DH12	= 066262	9-896	#18-6465							
DH120	= 066623	9-896	#18-6508							
DH121	= 066623	9-896	#18-6509							
DH122	= 066623	9-896	#18-6510							
DH123	= 066262	9-896	#18-6511							
DH124	= 066262	9-896	#18-6512							
DH125	= 066262	9-896	#18-6513							
DH126	= 066262	9-896	#18-6514							
DH127	= 066623	9-896	#18-6515							
DH13	= 066262	9-896	#18-6466							
DH130	= 066623	9-896	#18-6516							
DH131	= 066623	9-896	#18-6517							
DH132	= 066262	9-896	#18-6518							
DH133	= 066623	9-896	#18-6519							
DH134	= 066623	9-896	#18-6520							
DH135	= 066262	9-896	#18-6521							
DH136	= 066623	9-896	#18-6522							
DH137	= 066623	9-896	#18-6523							
DH14	= 066262	9-896	#18-6467							
DH140	= 066623	9-896	#18-6524							
DH141	= 066623	9-896	#18-6525							
DH142	= 066623	9-896	#18-6526							
DH143	= 066623	9-896	#18-6527							
DH144	= 066623	9-896	#18-6528							
DH145	= 066262	9-896	#18-6529							
DH146	= 066262	9-896	#18-6530							
DH147	= 066262	9-896	#18-6531							
DH15	= 066262	9-896	#18-6468							
DH150	= 066262	9-896	#18-6532							
DH151	= 066623	9-896	#18-6533							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES					
DH152	=	066623	9-896 #18-6534					
DH153	=	066623	9-896 #18-6535					
DH154	=	066623	9-896 #18-6536					
DH155	=	066623	9-896 #18-6537					
DH156	=	066623	9-896 #18-6538					
DH157	=	066262	9-896 #18-6539					
DH16	=	066262	9-896 #18-6469					
DH160	=	066623	9-896 #18-6540					
DH161	=	066262	9-896 #18-6541					
DH162	=	066262	9-896 #18-6542					
DH163	=	066623	9-896 #18-6543					
DH164	=	066262	9-896 #18-6544					
DH165	=	066623	9-896 #19-6576					
DH166	=	066623	9-896 #19-6577					
DH167	=	066623	9-896 #19-6578					
DH17		066413	9-896 #18-6470					
DH170	=	066623	9-896 #19-6579					
DH171	=	066623	9-896 #19-6580					
DH172	=	066623	9-896 #19-6581					
DH173	=	066623	9-896 #19-6582					
DH174	=	066623	9-896 #19-6583					
DH175	=	066623	9-896 #19-6584					
DH176	=	066623	9-896 #19-6585					
DH177	=	066623	9-896 #19-6586					
DH2		066352	9-896 #18-6457	19-6647				
DH20	=	066262	9-896 #18-6471					
DH200	=	066623	9-896 #19-6587					
DH201	=	066623	9-896 #19-6588					
DH202	=	066623	9-896 #19-6589					
DH203	=	066623	9-896 #19-6590					
DH204	=	066623	9-896 #19-6591					
DH205	=	066623	9-896 #19-6592					
DH206	=	066623	9-896 #19-6593					
DH207		066762	9-896 #19-6595	19-6599	19-6600	19-6601	19-6602	
DH21		066466	9-896 #18-6472					
DH210		067052	9-896 #19-6597	19-6598	19-6603	19-6606	19-6608	19-6610
DH211	=	067052	9-896 #19-6598					
DH212	=	066762	9-896 #19-6599					
DH213	=	066762	9-896 #19-6600					
DH214	=	066762	9-896 #19-6601					
DH215	=	066762	9-896 #19-6602					
DH216	=	067052	9-896 #19-6603					
DH217		067113	9-896 #19-6604					
DH22		066555	9-896 #18-6474					
DH220		066722	9-896 #19-6594	19-6607	19-6609			
DH221	=	067052	9-896 #19-6606					
DH222	=	066722	9-896 #19-6607					
DH223	=	067052	9-896 #19-6608					
DH224	=	066722	9-896 #19-6609					
DH225	=	067052	9-896 #19-6610					
DH226		067166	9-896 #19-6611	19-6615				
DH227		067255	9-896 #19-6613	19-6616	19-6617			



SYMBOL	VALUE	REFERENCES				
DH23	= 066262	9-896	#18-6475			
DH230	= 067166	9-896	#19-6615			
DH231	= 067255	9-896	#19-6616			
DH232	= 067255	9-896	#19-6617			
DH233	067344	9-896	#19-6620	19-6638	19-6640	19-6641
DH234	067405	9-896	#19-6622	19-6632		19-6642
DH235	067473	9-896	#19-6625			
DH236	067533	9-896	#19-6628			
DH237	= 067405	9-896	#19-6632			
DH24	= 066262	9-896	#18-6477			
DH240	067621	9-896	#19-6634	19-6639		
DH241	= 067344	9-896	#19-6638			
DH242	= 067621	9-896	#19-6639			
DH243	= 067344	9-896	#19-6640			
DH244	= 067344	9-896	#19-6641			
DH245	= 067344	9-896	#19-6642			
DH246	= 066262	9-896	#18-6494			
DH247	067711	9-896	#19-6643			
DH25	= 066262	9-896	#18-6478			
DH250	067756	9-896	#19-6644	19-6645		
DH251	= 067756	9-896	#19-6645			
DH252	= 066352	9-896	#19-6647			
DH253	= 066262	9-896	#19-6648			
DH254	= 066262	9-896	#19-6649			
DH255	= 066262	9-896	#19-6650			
DH256	= 066262	9-896	#19-6651			
DH257	= 066262	9-896	#19-6652			
DH26	= 066262	9-896	#18-6479			
DH260	= 066262	9-896	#19-6653			
DH261	= 066262	9-896	#19-6654			
DH262	= 066262	9-896	#19-6655			
DH263	= 066262	9-896	#19-6656			
DH264	= 066262	9-896	#19-6657			
DH265	= 066262	9-896	#19-6658			
DH266	070016	9-896	#19-6659			
DH27	= 066262	9-896	#18-6480			
DH3	= 066262	9-896	#18-6458			
DH30	= 066262	9-896	#18-6481			
DH31	= 066262	9-896	#18-6482			
DH32	= 066262	9-896	#18-6476			
DH33	= 066262	9-896	#18-6483			
DH34	= 066262	9-896	#18-6484			
DH35	= 066262	9-896	#18-6485			
DH36	= 066262	9-896	#18-6486			
DH37	= 066262	9-896	#18-6487			
DH4	= 066262	9-896	#18-6459			
DH40	= 066262	9-896	#18-6488			
DH41	= 066262	9-896	#18-6489			
DH42	= 066262	9-896	#18-6490			
DH43	= 066262	9-896	#18-6491			
DH44	= 066262	9-896	#18-6492			
DH45	= 066262	9-896	#18-6493			

SYMBOL CROSS REFERENCE		REFERENCES								
SYMBOL	VALUE									
DH46	= 066262	9-896	#18-6495							
DH47	= 066262	9-896	#18-6496							
DH5	= 066262	9-896	#18-6460							
DH50	= 066262	9-896	#18-6497							
DH51	= 066262	9-896	#18-6498							
DH52	= 066262	9-896	#18-6499							
DH53	= 066262	9-896	#18-6545							
DH54	= 066262	9-896	#18-6546							
DH55	= 066262	9-896	#18-6547							
DH56	= 066262	9-896	#18-6548							
DH57	= 066262	9-896	#18-6549							
DH6	= 066262	9-896	#18-6461							
DH60	= 066262	9-896	#18-6550							
DH61	= 066262	9-896	#18-6551							
DH62	= 066262	9-896	#18-6552							
DH63	= 066262	9-896	#18-6553							
DH64	= 066262	9-896	#18-6554							
DH65	= 066262	9-896	#18-6555							
DH66	= 066262	9-896	#18-6556							
DH67	= 066262	9-896	#18-6557							
DH7	= 066262	9-896	#18-6462							
DH70	= 066262	9-896	#18-6558							
DH71	= 066262	9-896	#18-6559							
DH72	= 066262	9-896	#18-6560							
DH73	= 066262	9-896	#18-6561							
DH74	= 066262	9-896	#18-6562							
DH75	= 066262	9-896	#19-6564							
DH76	= 066262	9-896	#19-6565							
DH77	= 066262	9-896	#19-6566							
DISPLA	001142	#8-890	*9-903	*9-903	17-5645	17-5647				
DISPRE	000174	#7-889	9-903							
DIVDSU	016614	12-2521	12-2532	12-2543	12-2554	12-2565	12-2578	12-2590	#13-2631	
DIVDT	017044	13-2650	13-2659	13-2665	13-2677	#13-2695				
DIVFSU	015674	12-2275	12-2286	12-2297	12-2309	12-2320	12-2331	12-2342	12-2354	12-2366
		12-2377	12-2388	12-2400	12-2411	#12-2448				
DIVFT	016110	12-2465	12-2474	#12-2505						
DSWR	= 177570	#7-877	8-890	9-903						
DT1	070604	9-896	#19-6853	19-6856	19-6857	19-6858	19-6859	19-6860	19-6861	19-6862
		19-6863	19-6864	19-6865	19-6866	19-6867				
DT10	= 070604	9-896	#19-6861							
DT100	= 071120	9-896	#19-6968							
DT101	= 071120	9-896	#19-6969							
DT102	= 071120	9-896	#19-6970							
DT103	= 071120	9-896	#19-6971							
DT104	= 071120	9-896	#19-6972							
DT105	= 071120	9-896	#19-6973							
DT106	= 071120	9-896	#19-6974							
DT107	= 071120	9-896	#19-6975							
DT11	= 070604	9-896	#19-6862							
DT110	= 071120	9-896	#19-6976							
DT111	= 070772	9-896	#19-6898							
DT112	= 070772	9-896	#19-6899							



SYMBOL	VALUE	REFERENCES								
DT166	= 071206	9-896	#19-6981							
DT167	= 071206	9-896	#19-6982							
DT17	070670	9-896	#19-6868							
DT170	= 071206	9-896	#19-6983							
DT171	= 071206	9-896	#19-6984							
DT172	= 071206	9-896	#19-6985							
DT173	= 071206	9-896	#19-6986							
DT174	= 071206	9-896	#19-6987							
DT175	= 071206	9-896	#19-6988							
DT176	= 071206	9-896	#19-6989							
DT177	= 071206	9-896	#19-6990							
DT2	070642	9-896	#19-6855							
DT20	070710	9-896	#19-6869							
DT200	= 071206	9-896	#19-6991							
DT201	= 071206	9-896	#19-6992							
DT202	= 071206	9-896	#19-6993							
DT203	= 071206	9-896	#19-6994							
DT204	= 071206	9-896	#19-6995							
DT205	= 071206	9-896	#19-6996							
DT206	= 071206	9-896	#19-6997							
DT207	071316	9-896	#19-7001	19-7004	19-7011	19-7013	19-7014	19-7015	19-7016	19-7017
		19-7018	19-7023							
DT21	070732	9-896	#19-6870							
DT210	071274	9-896	#19-6999	19-7022						
DT211	= 071316	9-896	#19-7004							
DT212	071370	9-896	#19-7005	19-7008	19-7009	19-7010	19-7019	19-7020	19-7021	
DT213	= 071370	9-896	#19-7008							
DT214	= 071370	9-896	#19-7009							
DT215	= 071370	9-896	#19-7010							
DT216	= 071316	9-896	#19-7011							
DT217	071452	9-896	#19-7012							
DT22	070754	9-896	#19-6871							
DT220	= 071316	9-896	#19-7013							
DT221	= 071316	9-896	#19-7014							
DT222	= 071316	9-896	#19-7015							
DT223	= 071316	9-896	#19-7016							
DT224	= 071316	9-896	#19-7017							
DT225	= 071316	9-896	#19-7018							
DT226	= 071370	9-896	#19-7019							
DT227	= 071370	9-896	#19-7020							
DT23	070772	9-896	#19-6872	19-6874	19-6875	19-6876	19-6877	19-6878	19-6879	19-6880
		19-6881	19-6882	19-6883	19-6884	19-6885	19-6886	19-6887	19-6888	19-6889
		19-6890	19-6891	19-6892	19-6893	19-6894	19-6895	19-6896	19-6897	19-6898
		19-6899	19-6900	19-6901	19-6910	19-6911	19-6912	19-6913	19-6917	19-6920
		19-6928	19-6929	19-6930	19-6931	19-6938	19-6940	19-6941	19-6943	
DT230	= 071370	9-896	#19-7021							
DT231	= 071274	9-896	#19-7022							
DT232	= 071316	9-896	#19-7023							
DT233	071472	9-896	#19-7029	19-7040	19-7042	19-7043	19-7044			
DT234	071526	9-896	#19-7033	19-7037	19-7038	19-7039	19-7041			
DT235	071546	9-896	#19-7035							
DT236	= 071526	9-896	#19-7037							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES							
DT237	=	071526	9-896 #19-7038							
DT24	=	070772	9-896 #19-6875							
DT240	=	071526	9-896 #19-7039							
DT241	=	071472	9-896 #19-7040							
DT242	=	071526	9-896 #19-7041							
DT243	=	071472	9-896 #19-7042							
DT244	=	071472	9-896 #19-7043							
DT245	=	071472	9-896 #19-7044							
DT246	=	070772	9-896 #19-6892							
DT247	=	071560	9-896 #19-7045							
DT25	=	070772	9-896 #19-6876							
DT250	=	071576	9-896 #19-7046	19-7047						
DT251	=	071576	9-896 #19-7047							
DT252	=	071610	9-896 #19-7049	19-7066						
DT253	=	071622	9-896 #19-7051	19-7055	19-7056	19-7057	19-7058	19-7059	19-7060	19-7061
			19-7062 19-7063	19-7064						
DT254	=	071622	9-896 #19-7055							
DT255	=	071622	9-896 #19-7056							
DT256	=	071622	9-896 #19-7057							
DT257	=	071622	9-896 #19-7058							
DT26	=	070772	9-896 #19-6877							
DT260	=	071622	9-896 #19-7059							
DT261	=	071622	9-896 #19-7060							
DT262	=	071622	9-896 #19-7061							
DT263	=	071622	9-896 #19-7062							
DT264	=	071622	9-896 #19-7063							
DT265	=	071622	9-896 #19-7064							
DT266	=	071610	9-896 #19-7066							
DT27	=	070772	9-896 #19-6878							
DT3	=	070604	9-896 #19-6856							
DT30	=	070772	9-896 #19-6879							
DT31	=	070772	9-896 #19-6880							
DT32	=	070772	9-896 #19-6874							
DT33	=	070772	9-896 #19-6881							
DT34	=	070772	9-896 #19-6882							
DT35	=	070772	9-896 #19-6883							
DT36	=	070772	9-896 #19-6884							
DT37	=	070772	9-896 #19-6885							
DT4	=	070604	9-896 #19-6857							
DT40	=	070772	9-896 #19-6886							
DT41	=	070772	9-896 #19-6887							
DT42	=	070772	9-896 #19-6888							
DT43	=	070772	9-896 #19-6889							
DT44	=	070772	9-896 #19-6890							
DT45	=	070772	9-896 #19-6891							
DT46	=	070772	9-896 #19-6893							
DT47	=	070772	9-896 #19-6894							
DT5	=	070604	9-896 #19-6858							
DT50	=	070772	9-896 #19-6895							
DT51	=	070772	9-896 #19-6896							
DT52	=	070772	9-896 #19-6897							
DT53	=	071120	9-896 #19-6944	19-6948	19-6949	19-6950	19-6951	19-6952	19-6953	19-6954

SYMBOL CROSS REFERENCE		REFERENCES									
SYMBOL	VALUE	19-6955	19-6956	19-6957	19-6958	19-6959	19-6960	19-6961	19-6962	19-6963	
		19-6964	19-6965	19-6966	19-6967	19-6968	19-6969	19-6970	19-6971	19-6972	
		19-6973	19-6974	19-6975	19-6976						
DT54	= 071120	9-896	#19-6948								
DT55	= 071120	9-896	#19-6949								
DT56	= 071120	9-896	#19-6950								
DT57	= 071120	9-896	#19-6951								
DT6	= 070604	9-896	#19-6859								
DT60	= 071120	9-896	#19-6952								
DT61	= 071120	9-896	#19-6953								
DT62	= 071120	9-896	#19-6954								
DT63	= 071120	9-896	#19-6955								
DT64	= 071120	9-896	#19-6956								
DT65	= 071120	9-896	#19-6957								
DT66	= 071120	9-896	#19-6958								
DT67	= 071120	9-896	#19-6959								
DT7	= 070604	9-896	#19-6860								
DT70	= 071120	9-896	#19-6960								
DT71	= 071120	9-896	#19-6961								
DT72	= 071120	9-896	#19-6962								
DT73	= 071120	9-896	#19-6963								
DT74	= 071120	9-896	#19-6964								
DT75	= 071120	9-896	#19-6965								
DT76	= 071120	9-896	#19-6966								
DT77	= 071120	9-896	#19-6967								
EEEDON	020064	13-2855	#13-2942								
EEE1	017060	#13-2711									
EEE10	017454	#13-2812									
EEE11	017510	#13-2823									
EEE12	017544	#13-2834									
EEE13	017600	#13-2845									
EEE2	017114	#13-2722									
EEE3	017150	#13-2733									
EEE4	017204	#13-2744									
EEE5	017240	#13-2755									
EEE6	017274	#13-2767									
EEE7	017330	#13-2779									
EEE8	017364	#13-2790									
EEE9	017420	#13-2801									
EMTVEC	= 000030	#7-877	9-903	9-903							
EM1	037724	9-896	#18-5937								
EM10	040543	9-896	#18-5952								
EM100	053701	9-896	#18-6175								
EM101	053764	9-896	#18-6177								
EM102	054160	9-896	#18-6180								
EM103	054354	9-896	#18-6183								
EM104	054466	9-896	#18-6185								
EM105	054633	9-896	#18-6188								
EM106	054742	9-896	#18-6190								
EM107	055051	9-896	#18-6192								
EM11	040650	9-896	#18-5954								
EM110	055160	9-896	#18-6194								

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES	CREF
EM111		043775	9-896 #18-6026	18-6078
EM112		044052	9-896 #18-6027	18-6079
EM113		044130	9-896 #18-6028	
EM114		044206	9-896 #18-6030	
EM115		044265	9-896 #18-6032	
EM116		044343	9-896 #18-6033	
EM117		044422	9-896 #18-6040	
EM12		040757	9-896 #18-5956	
EM120		044560	9-896 #18-6042	
EM121		044716	9-896 #18-6044	
EM122		045053	9-896 #18-6046	
EM123		045210	9-896 #18-6048	18-6100
EM124		045266	9-896 #18-6049	18-6101
EM125		045345	9-896 #18-6050	
EM126		045423	9-896 #18-6052	
EM127		045502	9-896 #18-6054	
EM13		041066	9-896 #18-5958	
EM130		045560	9-896 #18-6055	
EM131		045637	9-896 #18-6062	
EM132		045775	9-896 #18-6064	
EM133		046133	9-896 #18-6067	
EM134		046271	9-896 #18-6069	
EM135		046426	9-896 #18-6071	
EM136		046563	9-896 #18-6074	
EM137		046720	9-896 #18-6076	
EM14		041202	9-896 #18-5960	
EM140		047006	9-896 #18-6077	
EM141	=	043775	9-896 #18-6078	
EM142	=	044052	9-896 #18-6079	
EM143		047075	9-896 #18-6080	
EM144		047153	9-896 #18-6082	
EM145		047232	9-896 #18-6090	
EM146		047377	9-896 #18-6092	
EM147		047544	9-896 #18-6094	
EM15		041314	9-896 #18-5962	
EM150		047710	9-896 #18-6096	
EM151		050054	9-896 #18-6098	
EM152		050142	9-896 #18-6099	
EM153	=	045210	9-896 #18-6100	
EM154	=	045266	9-896 #18-6101	
EM155		050231	9-896 #18-6102	
EM156		050307	9-896 #18-6104	
EM157		050366	9-896 #18-6112	
EM16		041426	9-896 #18-5964	
EM160		050533	9-896 #18-6114	
EM161		050671	9-896 #18-6117	
EM162		051036	9-896 #18-6119	
EM163		051202	9-896 #18-6121	
EM164		051337	9-896 #18-6124	
EM165		055270	9-896 #18-6208	
EM166		055354	9-896 #18-6210	
EM167		055437	9-896 #18-6212	

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
EM17		041523	9-896 #18-5966
EM170		055471	9-896 #18-6214
EM171		055557	9-896 #18-6216
EM172		055702	9-896 #18-6218
EM173		055767	9-896 #18-6220
EM174		056135	9-896 #18-6222
EM175		056303	9-896 #18-6224
EM176		056415	9-896 #18-6226
EM177		056501	9-896 #18-6228
EM2		037756	9-896 #18-5938
EM20		041600	9-896 #18-5967
EM200		056564	9-896 #18-6230
EM201		056616	9-896 #18-6232
EM202		056705	9-896 #18-6234
EM203		057047	9-896 #18-6236
EM204		057211	9-896 #18-6238
EM205		057277	9-896 #18-6240
EM206		057445	9-896 #18-6242
EM207		057613	9-896 #18-6338
EM21		041632	9-896 #18-5968
EM210		057655	9-896 #18-6339
EM211		057717	9-896 #18-6340
EM212		060063	9-896 #18-6367
EM213		060247	9-896 #18-6368
EM214		060433	9-896 #18-6369
EM215		060617	9-896 #18-6370
EM216		061003	9-896 #18-6371
EM217		061165	9-896 #18-6374
EM22		041664	9-896 #18-5969
EM220		061227	9-896 #18-6375
EM221		061457	9-896 #18-6376
EM222		061723	9-896 #18-6377
EM223		062154	9-896 #18-6378
EM224		062421	9-896 #18-6379
EM225		062652	9-896 #18-6380
EM226		063117	9-896 #18-6381
EM227		063252	9-896 #18-6382
EM23		041745	9-896 #18-5970
EM230		063405	9-896 #18-6383
EM231		063541	9-896 #18-6384
EM232	=	057655	9-896 #18-6385
EM233		063675	9-896 #18-6415
EM234		063734	9-896 #18-6416
EM235		064020	9-896 #18-6417
EM236		064066	9-896 #18-6418
EM237		064121	9-896 #18-6419
EM24		042022	9-896 #18-5975
EM240		064205	9-896 #18-6420
EM241		064241	9-896 #18-6421
EM242		064344	9-896 #18-6422
EM243		064400	9-896 #18-6423
EM244		064503	9-896 #18-6424

18-6385



SYMBOL	VALUE	REFERENCES	
EM245	064542	9-896	#18-6426
EM246	043405	9-896	#18-6016
EM247	064624	9-896	#18-6429
EM25	042120	9-896	#18-5977
EM250	064660	9-896	#18-6430
EM251	064712	9-896	#18-6431
EM252	064745	9-896	#18-6433
EM253	065036	9-896	#18-6439
EM254	065122	9-896	#18-6440
EM255	065207	9-896	#18-6441
EM256	065275	9-896	#18-6442
EM257	065364	9-896	#18-6443
EM26	042205	9-896	#18-5979
EM260	065452	9-896	#18-6444
EM261	065541	9-896	#18-6445
EM262	065631	9-896	#18-6446
EM263	065722	9-896	#18-6447
EM264	066007	9-896	#18-6448
EM265	066074	9-896	#18-6449
EM266	066161	9-896	#18-6451
EM27	= 042120	9-896	#18-5981
EM3	040012	9-896	#18-5942
EM30	042303	9-896	#18-5982
EM31	042355	9-896	#18-5984
EM32	041770	9-896	#18-5971
EM33	042422	9-896	#18-5986
EM34	042445	9-896	#18-5987
EM35	042477	9-896	#18-5991
EM36	042552	9-896	#18-5993
EM37	042620	9-896	#18-5995
EM4	040117	9-896	#18-5944
EM40	042643	9-896	#18-5999
EM41	042675	9-896	#18-6000
EM42	042750	9-896	#18-6002
EM43	043101	9-896	#18-6005
EM44	043232	9-896	#18-6008
EM45	043300	9-896	#18-6010
EM46	043353	9-896	#18-6012
EM47	043430	9-896	#18-6017
EM5	040224	9-896	#18-5946
EM50	043564	9-896	#18-6020
EM51	043637	9-896	#18-6022
EM52	043705	9-896	#18-6024
EM53	051535	9-896	#18-6127
EM54	051566	9-896	#18-6128
EM55	051503	9-896	#18-6126
EM56	051616	9-896	#18-6135
EM57	051707	9-896	#18-6137
EM6	040331	9-896	#18-5948
EM60	051777	9-896	#18-6139
EM61	052101	9-896	#18-6141
EM62	052275	9-896	#18-6144

18-5981

SYMBOL	VALUE	REFERENCES								
EM63	052471	9-896	#18-6147							
EM64	052602	9-896	#18-6149							
EM65	052721	9-896	#18-6151							
EM66	053034	9-896	#18-6153							
EM67	053103	9-896	#18-6155							
EM7	040436	9-896	#18-5950							
EM70	053166	9-896	#18-6157							
EM71	053217	9-896	#18-6158							
EM72	053247	9-896	#18-6159	18-6160						
EM73	= 053247	9-896	#18-6160							
EM74	053301	9-896	#18-6167							
EM75	053410	9-896	#18-6169							
EM76	053501	9-896	#18-6171							
EM77	053571	9-896	#18-6173							
ERM10	034152	17-5647	17-5647	#17-5647						
ERROR	= 104000	#7-877	9-1055	9-1056	9-1057	9-1058	9-1059	9-1060	9-1061	9-1062
		9-1063	9-1064	9-1065	9-1066	9-1079	11-1363	11-1365	11-1367	11-1369
		11-1373	11-1375	11-1389	11-1391	11-1393	11-1395	11-1397	11-1399	11-1401
		11-1416	11-1418	11-1420	11-1422	11-1424	11-1426	11-1428	11-1692	11-1697
		11-1703	11-1709	11-1714	11-1719	11-1724	11-1730	11-1741	11-1750	11-1759
		11-1828	11-1842	11-1855	11-1868	11-1882	11-1898	11-1915	11-1932	11-1949
		12-1966	12-1983	12-2000	12-2017	12-2083	12-2099	12-2222	12-2231	12-2239
		12-2252	12-2282	12-2293	12-2305	12-2316	12-2327	12-2338	12-2349	12-2361
		12-2373	12-2384	12-2395	12-2407	12-2418	12-2498	12-2502	12-2528	12-2539
		12-2550	12-2561	12-2573	12-2586	12-2599	13-2688	13-2692	13-2719	13-2730
		13-2741	13-2752	13-2763	13-2775	13-2787	13-2798	13-2809	13-2820	13-2831
		13-2842	13-2853	13-2933	13-2937	13-2964	13-2976	13-2987	13-2999	13-3086
		13-3090	13-3121	13-3123	13-3137	13-3140	13-3154	13-3156	13-3170	13-3173
		13-3269	13-3273	14-3299	14-3303	14-3335	14-3339	14-3373	14-3375	14-3390
		14-3392	14-3407	14-3409	14-3425	14-3427	14-3521	14-3525	14-3550	14-3554
		14-3586	14-3590	14-3625	14-3627	14-3641	14-3643	14-3657	14-3659	14-3673
		14-3675	14-3778	14-3782	14-3790	14-3794	14-3819	14-3823	14-3870	14-3872
		14-3888	14-3890	14-3906	14-3908	14-3924	14-3926	15-4030	15-4034	15-4042
		15-4046	15-4071	15-4075	15-4120	15-4122	15-4136	15-4138	15-4152	15-4154
		15-4168	15-4170	15-4184	15-4186	15-4200	15-4203	15-4217	15-4220	15-4234
		15-4236	15-4250	15-4252	15-4266	15-4268	15-4282	15-4284	15-4298	15-4300
		15-4314	15-4316	15-4330	15-4332	15-4433	15-4447	15-4453	15-4487	15-4489
		15-4505	15-4507	15-4522	15-4524	15-4540	15-4542	15-4559	15-4561	15-4575
		15-4578	16-4593	16-4596	16-4610	16-4612	16-4628	16-4631	16-4648	16-4650
		16-4666	16-4668	16-4684	16-4686	16-4700	16-4702	16-4810	16-4827	16-4833
		16-4867	16-4869	16-4886	16-4901	16-4903	16-4921	16-4937	16-4939	16-5037
		16-5051	16-5057	16-5100	16-5102	16-5121	16-5138	16-5140	16-5159	17-5262
		17-5279	17-5285	17-5376	17-5378	17-5389	17-5391	17-5403	17-5405	17-5417
		17-5419	17-5433	17-5435	17-5447	17-5449	17-5462	17-5464	17-5475	17-5477
		17-5491	17-5493	17-5505	17-5507	17-5519	17-5521	17-5617	17-5838	17-5849
		17-5860								
ERRVEC	= 000004	#7-877	9-903	9-903	9-903	11-1566	11-1572	11-1584	17-5352	17-5354
		17-5358	17-5645	17-5645	17-5645	17-5645	17-5891			
ERTYPE	036204	17-5647	#17-5675							
ERT1	036370	#17-5726	17-5813							
ERT2	036624	17-5731	17-5744	17-5764	17-5773	17-5801	#17-5805			
ERT3	036630	17-5781	17-5789	#17-5810						

SYMBOL	VALUE	REFERENCES
ERT4	036642	17-5722 17-5812 #17-5815
ERT5	036654	17-5688 #17-5820
FFFDON	020614	13-3001 #13-3095
FFF1	020070	#13-2956
FFF2	020144	#13-2968
FFF3	020220	#13-2979
FFF4	020274	#13-2990
FPSPUR	036660	9-1014 9-1071 9-1193 9-1258 11-1326 11-1355 11-1381 11-1407 12-2189
		12-2212 14-3310 14-3561 14-3746 15-3998 #17-5832 17-5890
FPVECT =	000244	#7-871 9-960 9-1014 9-1156 9-1180 9-1221 9-1245 9-1287 11-1313
		12-2126 12-2176 13-3235 14-3487 14-3733 15-3985 17-5890
GGDATO	011540	9-1162 9-1186 9-1197 9-1227 9-1251 9-1262 9-1293 11-1319 11-1330
		11-1361 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1387 11-1389
		11-1391 11-1393 11-1395 11-1397 11-1399 11-1401 11-1413 11-1416 11-1418
		11-1420 11-1422 11-1424 11-1426 11-1428 #11-1430
GGDONE	011660	11-1349 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1389 11-1391
		11-1393 11-1395 11-1397 11-1399 11-1401 11-1416 11-1418 11-1420 11-1422
		11-1424 11-1426 11-1428 #11-1472
GGERO	010036	9-1156 #11-1351
GGER1	010134	9-1168 #11-1365 11-1371
GGER10	010646	9-1253 #11-1395
GGER11	010714	9-1268 #11-1397
GGER12	010762	9-1273 #11-1399
GGER13	011030	9-1280 #11-1401
GGER14	011076	9-1287 #11-1403
GGER15	011174	9-1299 #11-1418
GGER16	011242	9-1304 #11-1420
GGER17	011310	11-1321 #11-1422
GGER18	011356	11-1336 #11-1424
GGER19	011424	11-1347 #11-1426
GGER2	010202	9-1173 #11-1367
GGER20	011472	11-1341 #11-1428
GGER3	010250	9-1188 #11-1369
GGER4	010316	9-1203 #11-1371
GGER5	010320	9-1214 #11-1373
GGER6	010366	9-1208 #11-1375
GGER7	010434	9-1221 #11-1377
GGER8	010532	9-1233 #11-1391
GGER9	010600	9-1238 #11-1393
GGGDON	025676	15-4333 #15-4462
GGG1	024224	#15-4110
GGG10	024774	#15-4256
GGG11	025044	#15-4272
GGG12	025114	#15-4288
GGG13	025164	#15-4304
GGG14	025234	#15-4320
GGG2	024274	#15-4126
GGG3	024344	#15-4142
GGG4	024414	#15-4158
GGG5	024464	#15-4174
GGG6	024534	#15-4190
GGG7	024604	#15-4207

SYMBOL CROSS REFERENCE

SYMBOL	VALUE	REFERENCES
GGG8	024654	#15-4224
GGG9	024724	#15-4240
GGP1	011550	11-1416 #11-1435
GGP2	011560	9-1222 9-1246 9-1288 11-1314 11-1389 11-1391 11-1393 11-1395 11-1397
		11-1399 11-1401 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 #11-1439
GGP3	011570	9-1224 9-1248 11-1389 11-1391 11-1393 11-1395 11-1397 11-1399 11-1401
		11-1416 #11-1443
GGP4	011600	#11-1447
GGP5	011610	9-1157 9-1159 9-1181 9-1183 11-1363 11-1363 11-1365 11-1365 11-1367
		11-1367 11-1369 11-1369 11-1373 11-1373 11-1375 11-1375 #11-1451 11-1367
GGP6	011620	9-1164 9-1199 9-1229 9-1295 11-1363 11-1365 11-1367 11-1369 11-1373
		11-1375 11-1389 11-1391 11-1393 11-1416 11-1418 11-1420 #11-1455
GGP7	011630	9-1264 11-1395 11-1397 11-1399 11-1401 #11-1460
GGP8	011640	9-1290 11-1316 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 #11-1464
GGP9	011650	11-1332 11-1422 11-1424 11-1426 11-1428 #11-1468
GG1	006746	#9-1152
GG10	007242	9-1213 #9-1217
GG11	007300	9-1220 #9-1225
GG12	007322	#9-1231 9-1234
GG13	007332	9-1232 #9-1234
GG14	007350	9-1237 #9-1241
GG15	007406	9-1244 #9-1249
GG16	007424	9-1245 #9-1254
GG17	007472	#9-1266 9-1269
GG18	007502	9-1267 #9-1269
GG19	007536	9-1279 #9-1283
GG2	007004	9-1155 #9-1160
GG20	007574	9-1286 #9-1291
GG21	007616	#9-1297 9-1300
GG22	007626	9-1298 #9-1300
GG23	007644	9-1303 #11-1309
GG24	007702	11-1312 #11-1317
GG25	007720	11-1313 #11-1322
GG26	007766	#11-1334 11-1337
GG27	007776	11-1335 #11-1337
GG28	010032	11-1346 #11-1349
GG3	007026	#9-1166 9-1169
GG4	007036	9-1167 #9-1169
GG5	007054	9-1172 #9-1176
GG6	007112	9-1179 #9-1184
GG7	007130	9-1180 #9-1189
GG8	007176	#9-1201 9-1204
GG9	007206	9-1202 #9-1204
GNS	= *****	7-889 7-889 9-904 17-5643 17-5643 17-5659 17-5659 17-5659 17-5659
		17-5659 17-5659 17-5659 17-5659 17-5659 17-5659 17-5659 17-5659 17-5659
		17-5659 17-5659 17-5659 17-5659 17-5659 17-5660 17-5660 17-5661 17-5661
GTSWR	= 104405	9-904 #17-5659
HHDATO	006572	9-932 9-938 9-966 9-990 9-996 9-1020 9-1042 9-1055 9-1056
		9-1057 9-1058 9-1059 9-1060 9-1061 9-1062 9-1063 9-1064 9-1065
		9-1066 #9-1081
HHDONE	006742	9-1054 9-1055 9-1056 9-1057 9-1058 9-1059 9-1060 9-1061 9-1062
		9-1063 9-1064 9-1065 9-1066 9-1080 #9-1133

SYMBOL CROSS REFERENCE

SYMBOL	VALUE	REFERENCES								
HHER0	005612	9-943	#9-1055							
HHER00	005726	9-949	#9-1057							
HHER1	005660	9-945	#9-1056							
HHER10	006454	9-1053	#9-1066							
HHER2	005774	9-972	#9-1058							
HHER3	006042	9-977	#9-1059							
HHER4	006110	9-1001	#9-1060							
HHER5	006156	9-1003	#9-1061							
HHER6	006224	9-1008	#9-1062							
HHER7	006272	9-1026	#9-1063							
HHER8	006340	9-1031	#9-1064							
HHER9	006406	9-1048	#9-1065							
HHHDON	030004	16-4703	#16-4840							
HHH1	025702	#15-4477								
HHH10	027002	#16-4636								
HHH11	027102	#16-4654								
HHH12	027202	#16-4672								
HHH13	027302	#16-4690								
HHH2	026002	#15-4493								
HHH3	026102	#15-4511								
HHH4	026202	#15-4528								
HHH5	026302	#15-4546								
HHH6	026402	#15-4565								
HHH7	026502	#15-4582								
HHH8	026602	#16-4600								
HHH9	026702	#16-4616								
HHP0	006602	9-927	9-1055	9-1056	9-1057	#9-1085				
HHP1	006612	9-929	9-1055	9-1056	9-1057	#9-1089				
HHP10	006722	9-1022	9-1063	9-1064	#9-1125					
HHP11	006732	9-1044	9-1065	9-1066	#9-1129					
HHP2	006622	9-934	9-1055	9-1056	9-1057	#9-1093				
HHP3	006632	9-939	#9-1097							
HHP4	006642	9-968	9-997	9-1058	9-1059	#9-1101				
HHP5	006652	9-961	9-1037	9-1039	9-1058	9-1059	9-1065	9-1065	9-1066	9-1066
		#9-1105								
HHP6	006662	9-963	9-1058	9-1059	#9-1109					
HHP7	006672	9-992	9-1060	9-1061	9-1062	#9-1113				
HHP8	006702	9-985	9-1015	9-1017	9-1060	9-1061	9-1062	9-1063	9-1063	9-1064
		9-1064	#9-1117							
HHP9	006712	9-987	9-1060	9-1061	9-1062	#9-1121				
HHTRAP	006522	9-960	#9-1067							
HH1	005022	#9-923								
HH10	005234	9-971	#9-973							
HH11	005252	9-976	#9-980							
HH12	005302	9-984	#9-988							
HH13	005324	#9-994	9-1004							
HH14	005344	#9-999	9-1002							
HH15	005354	9-1000	#9-1002							
HH16	005362	9-995	#9-1004							
HH17	005400	9-1007	#9-1010							
HH18	005436	9-1013	#9-1018							
HH19	005460	#9-1024	9-1027							

SYMBOL	VALUE	REFERENCES								
HH2	005052	9-926	#9-930							
HH20	005470	9-1025	#9-1027							
HH21	005506	9-1030	#9-1033							
HH22	005536	9-1036	#9-1040							
HH23	005560	#9-1046	9-1049							
HH24	005570	9-1047	#9-1049							
HH25	005606	9-1052	#9-1054							
HH3	005074	#9-936	9-946							
HH4	005114	#9-941	9-944							
HH5	005124	9-942	#9-944							
HH6	005132	9-937	#9-946							
HH7	005144	9-948	#9-955							
HH8	005202	9-959	#9-964							
HH9	005224	#9-970	9-973							
HT	= 000011	#7-877	17-5651	17-5651						
HXDATO	013270	11-1495	11-1502	11-1535	11-1544	11-1588	11-1607	11-1616	11-1642	11-1672
		11-1702	11-1708	11-1723	11-1729	11-1758	#11-1766			
HXDONE	013400	11-1686	11-1693	11-1698	11-1704	11-1710	11-1715	11-1720	11-1725	11-1731
		11-1742	11-1751	11-1760	#11-1806					
HXER1	012656	11-1492	#11-1690							
HXER10	013146	11-1575	#11-1744							
HXER11	013200	11-1620	#11-1753							
HXER12	013220	11-1622	#11-1756							
HXER13	013250	11-1649	11-1679	#11-1762						
HXER2	012716	11-1506	11-1594	#11-1700						
HXER22	012732	#11-1702	11-1755	11-1764						
HXER3	012746	11-1508	#11-1706							
HXER33	012762	#11-1708								
HXER4	012776	11-1655	11-1685	#11-1712						
HXER5	012676	11-1531	#11-1695							
HXER6	013032	11-1548	#11-1721							
HXER66	013046	#11-1723								
HXER7	013062	11-1550	#11-1727							
HXER8	013014	11-1513	11-1557	#11-1717						
HXER9	013112	11-1566	#11-1733							
HXP1	013300	11-1485	11-1519	11-1632	11-1637	11-1645	11-1667	11-1675	11-1762	11-1763
		#11-1771								
HXP2	013310	11-1487	11-1490	11-1501	11-1522	11-1529	11-1585	11-1690	11-1695	11-1700
		11-1706	11-1721	11-1727	#11-1776					
HXP3	013320	#11-1780								
HXP4	013330	11-1604	11-1753	11-1756	#11-1784					
HXP5	013340	11-1610	11-1754	11-1757	#11-1788					
HXP6	013350	11-1582	11-1602	11-1663	#11-1792					
HXP7	013360	11-1497	11-1543	11-1590	11-1615	11-1701	11-1707	#11-1797		
HXP8	013370	11-1538	11-1722	11-1728	#11-1801					
HX1	011664	#11-1482								
HX10	012072	11-1530	#11-1533							
HX11	012114	#11-1540	11-1552							
HX12	012134	#11-1546	11-1549							
HX13	012144	11-1547	#11-1549							
HX14	012152	11-1541	#11-1552							
HX15	012170	11-1556	#11-1561							

## SYMBOL CROSS REFERENCE

## CREF

SYMBOL	VALUE	REFERENCES		
HX16	012216	11-1565	#11-1568	
HX165	012222	#11-1569	11-1735	11-1746
HX17	012250	11-1574	#11-1577	
HX18	012306	11-1581	#11-1586	
HX19	012326	#11-1592	11-1595	
HX2	011714	11-1488	#11-1489	
HX20	012336	11-1593	#11-1595	
HX21	012340	#11-1598		
HX22	012370	11-1601	#11-1605	
HX23	012410	#11-1612	11-1624	
HX24	012430	#11-1618	11-1621	
HX25	012440	11-1619	#11-1621	
HX26	012446	11-1613	#11-1624	
HX27	012450	#11-1628		
HX28	012502	11-1636	#11-1638	
HX29	012524	#11-1647	11-1650	
HX3	011730	11-1491	#11-1493	
HX30	012534	11-1648	#11-1650	
HX31	012552	11-1654	#11-1659	
HX32	012602	11-1666	#11-1668	
HX33	012624	#11-1677	11-1680	
HX34	012634	11-1678	#11-1680	
HX35	012652	11-1684	#11-1686	
HX4	011750	#11-1499	11-1509	
HX5	011770	#11-1504	11-1507	
HX6	012000	11-1505	#11-1507	
HX7	012006	11-1500	#11-1509	
HX8	012024	11-1512	#11-1515	
HX9	012056	11-1523	#11-1527	
IIIDON	021454	13-3174	#14-3344	
IIII	020620	#13-3111		
IIII2	020664	#13-3127		
IIII3	020730	#13-3144		
IIII4	020774	#13-3160		
IOTVEC	= 000020	#7-877	9-903	9-903
JJJDON	022414	14-3428	#14-3595	
JJJ1	021460	#14-3361		
JJJ2	021544	#14-3379		
JJJ3	021630	#14-3396		
JJJ4	021714	#14-3414		
KKKDON	023256	14-3676	#14-3842	
KKK1	022420	#14-3615		
KKK3	022464	#14-3631		
KKK4	022530	#14-3647		
KKK5	022574	#14-3663		
LF	= 000012	#7-877	17-5651	17-5651
LLLDON	024220	14-3927	#15-4094	
LLL1	023262	#14-3858		
LLL2	023346	#14-3876		
LLL3	023432	#14-3894		
LLL4	023516	#14-3912		
LOOP	005020	#9-906	17-5643	

CKFPBAO  
 SYMBOL CROSS REFERENCE  
 SYMBOL VALUE  
 LPERR = 104413

CREATED BY MACRO ON 18-SEP-79 AT 13:50

PAGE 27  
 CREF

D 16

SEQ 0198

SYMBOL	VALUE	REFERENCES
		9-923 9-955 9-980 9-1010 9-1033 9-1152 9-1176 9-1217 9-1241
		9-1283 11-1309 11-1482 11-1515 11-1561 11-1577 11-1598 11-1628 11-1659
		11-1821 11-1832 11-1845 11-1858 11-1872 11-1885 11-1902 11-1919 11-1936
		11-1952 12-1970 12-1987 12-2004 12-2121 12-2146 12-2168 12-2274 12-2285
		12-2296 12-2308 12-2319 12-2330 12-2341 12-2353 12-2365 12-2376 12-2387
		12-2399 12-2410 12-2520 12-2531 12-2542 12-2553 12-2564 12-2577 12-2589
		13-2711 13-2722 13-2733 13-2744 13-2755 13-2767 13-2779 13-2790 13-2801
		13-2812 13-2823 13-2834 13-2845 13-2956 13-2968 13-2979 13-2990 13-3111
		13-3127 13-3144 13-3160 14-3361 14-3379 14-3396 14-3414 14-3615 14-3631
		14-3647 14-3663 14-3858 14-3876 14-3894 14-3912 15-4110 15-4126 15-4142
		15-4158 15-4174 15-4190 15-4207 15-4224 15-4240 15-4256 15-4272 15-4288
		15-4304 15-4320 15-4477 15-4493 15-4511 15-4528 15-4546 15-4565 15-4582
		16-4600 16-4616 16-4636 16-4654 16-4672 16-4690 16-4856 16-4873 16-4890
		16-4908 16-4926 16-5087 16-5106 16-5125 16-5144 17-5368 17-5381 17-5395
		17-5409 17-5425 17-5439 17-5455 17-5468 17-5483 17-5497 17-5511 #17-5661
		16-4940 #16-5071
MMMDON	030732	
MMM1	030010	#16-4856
MMM2	030062	#16-4873
MMM3	030134	#16-4890
MMM4	030206	#16-4908
MMM5	030260	#16-4926
MNUMBE	= 000266	#5-620
MODDDO	031740	16-5214 16-5227 16-5234 #17-5295
MODDD1	031750	16-5216 16-5228 16-5242 17-5266 #17-5297
MODDOV	031352	16-5088 16-5107 16-5126 16-5145 #16-5195
MODDSU	027406	15-4478 15-4494 15-4512 15-4529 15-4547 15-4566 15-4583 16-4601 16-4617
		16-4637 16-4655 16-4673 16-4691 #16-4738
MODDTO	027764	16-4756 16-4769 16-4774 16-4797 #16-4836
MODDT1	027774	16-4758 16-4770 16-4782 16-4814 #16-4838
MODFDO	030712	16-4995 16-5008 16-5015 #16-5067
MODFD1	030722	16-4997 16-5009 16-5021 #16-5069
MODFOV	030336	16-4857 16-4874 16-4891 16-4909 16-4927 #16-4976
MODFSU	025310	15-4111 15-4127 15-4143 15-4159 15-4175 15-4191 15-4208 15-4225 15-4241
		15-4257 15-4273 15-4289 15-4305 15-4321 #15-4369
MODFTO	025646	15-4387 15-4400 15-4405 #15-4456
MODFT1	025656	15-4389 15-4401 15-4411 #15-4458
MODP1	025666	15-4374 #15-4460 16-4743 16-4981 16-5200
MSA1	037024	#17-5904 19-7052
MSA2	037042	#17-5905 19-7052
MSA3	037065	#17-5906 19-7053
MSA4	037077	#18-5908 19-7053
MSA5	037115	#18-5909 19-7054
MSA6	037130	#18-5910 19-7054
MS1	037222	#18-5916 19-6854 19-6872 19-6903 19-6945 19-6978
MS10	037421	#18-5923 19-6947 19-6980
MS11	037443	#18-5924 19-6946 19-6979
MS12	037467	#18-5925 19-6946 19-6979
MS2	037240	#18-5917 19-6854 19-6872 19-6903 19-6945 19-6978
MS3	037260	#18-5918 19-6855
MS37	037512	#18-5926 19-7030
MS4	037307	#18-5919 19-6855
MS40	037530	#18-5927 19-7030



SYMBOL	VALUE	REFERENCES									
MS41	037564	#18-5929	19-7001	19-7006	19-7031						
MS415	037544	#18-5928									
MS42	037610	#18-5930	19-7002	19-7006							
MS43	037626	#18-5931	19-7002	19-7007							
MS44	037643	#18-5932	19-7003	19-7007							
MS5	037335	#18-5920	19-6873	19-6904							
MS6	037357	#18-5921	19-6873	19-6904							
MS7	037375	#18-5922	19-6947	19-6980							
MULDSU	020354	13-2957	13-2969	13-2980	13-2991	#13-3029					
MULDT	020604	13-3048	13-3057	13-3063	13-3075	#13-3093					
MULFSU	017640	13-2712	13-2723	13-2734	13-2745	13-2756	13-2768	13-2780	13-2791	13-2802	
		13-2813	13-2824	13-2835	13-2846	#13-2883					
MULFT	020054	13-2900	13-2909	#13-2940							
NNNDON	031760	16-5160	#17-5299								
NNN1	030736	#16-5087									
NNN2	031040	#16-5106									
NNN3	031142	#16-5125									
NNN4	031244	#16-5144									
OVDNTT	022404	14-3482	14-3498	14-3503	14-3529	14-3569	#14-3593				
OVDTT	024210	15-3980	15-4005	15-4010	15-4050	15-4083	#15-4092				
OVFNNT	021444	13-3230	13-3246	13-3251	14-3278	14-3318	#14-3342				
OVFTT	023246	14-3728	14-3753	14-3758	14-3798	14-3831	#14-3840				
OVUNDN	022004	14-3362	14-3380	14-3397	14-3415	#14-3468					
OVUNDT	023606	14-3859	14-3877	14-3895	14-3913	#15-3966					
OVUNFN	021044	13-3112	13-3128	13-3145	13-3161	#13-3216					
OVUNFT	022644	14-3616	14-3632	14-3648	14-3664	#14-3714					
PIRQ	= 177772	#7-877									
PIRQVE	= 000240	#7-877									
POWERM	037150	17-5664	#18-5913								
PROGNUM	= 000002	#5-621	9-904								
PRO	= 000000	#7-877									
PR1	= 000040	#7-877									
PR2	= 000100	#7-877									
PR3	= 000140	#7-877									
PR4	= 000200	#7-877									
PR5	= 000240	#7-877									
PR6	= 000300	#7-877									
PR7	= 000340	#7-877									
PS	= 177776	#7-877	7-877								
PSW	= 177776	#7-877	17-5567								
PWRVEC	= 000024	#7-877	9-903	9-903	17-5664	17-5664	17-5664	17-5664	17-5664	17-5664	
RDCHR	= 104407	#17-5659									
RESREG	= 104411	#17-5659									
RESVEC	= 000010	#7-877	9-903	9-903	9-903						
RSETUP	= 104412	9-1133	11-1472	11-1806	12-2106	12-2260	12-2507	13-2697	13-2942	13-3095	
		14-3344	14-3595	14-3842	15-4094	15-4462	16-4840	16-5071	17-5299	17-5635	
		#17-5660	17-5839	17-5850	17-5861						
R6	=%000006	#7-877	*9-903	*9-903	9-903						
R7	=%000007	#7-877									
SAVREG	= 104410	#17-5659									
SCOPE	= 000004	#7-877	9-919	9-1149	11-1480	11-1818	12-2118	12-2271	12-2517	13-2708	
		13-2953	13-3108	14-3358	14-3612	14-3855	15-4107	15-4474	16-4853	16-5084	

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES							
SPACE		037217	17-5343	17-5643						
STACK	=	001100	17-5741	17-5753	17-5757	17-5761	17-5799	#18-5915		
START		004336	#7-877	9-903	17-5894					
STKLMT	=	177774	7-889	#9-903	17-5664					
SWR		001140	#7-877							
			#8-890	9-903	*9-903	9-903	*9-903	*9-903	9-904	17-5347
			17-5645	17-5645	17-5645	17-5645	17-5645	17-5647	17-5647	17-5643
			17-5647	17-5657	17-5657	17-5664	17-5664	17-5883		17-5647
SWREG		000176	#7-889	9-903	9-904	17-5657	17-5657			
SW0	=	000001	#7-877							
SW00	=	000001	#7-877	7-877						
SW01	=	000002	#7-877	7-877						
SW02	=	000004	#7-877	7-877						
SW03	=	000010	#7-877	7-877						
SW04	=	000020	#7-877	7-877						
SW05	=	000040	#7-877	7-877						
SW06	=	000100	#7-877	7-877						
SW07	=	000200	#7-877	7-877						
SW08	=	000400	#7-877	7-877						
SW09	=	001000	#7-877	7-877						
SW1	=	000002	#7-877							
SW10	=	002000	#7-877							
SW11	=	004000	#7-877							
SW12	=	010000	#7-877							
SW13	=	020000	#7-877							
SW14	=	040000	#7-877							
SW15	=	100000	#7-877							
SW2	=	000004	#7-877							
SW3	=	000010	#7-877							
SW4	=	000020	#7-877							
SW5	=	000040	#7-877							
SW6	=	000100	#7-877							
SW7	=	000200	#7-877							
SW8	=	000400	#7-877							
SW9	=	001000	#7-877							
TAB	=	000011	#7-874	17-5904	17-5904	17-5905	17-5906	17-5906	18-5908	18-5909
			18-5910	18-5910	18-5914	18-5916	18-5916	18-5917	18-5917	18-5918
			18-5920	18-5921	18-5921	18-5922	18-5923	18-5924	18-5925	18-6455
			18-6455	18-6456	18-6457	18-6457	18-6470	18-6470	18-6470	18-6472
			18-6472	18-6472	18-6473	18-6474	18-6474	18-6474	18-6504	18-6504
			19-6594	19-6594	19-6595	19-6595	19-6596	19-6596	19-6597	19-6597
			19-6604	19-6605	19-6605	19-6611	19-6611	19-6612	19-6612	19-6613
			19-6614	19-6614	19-6620	19-6620	19-6622	19-6622	19-6623	19-6623
			19-6625	19-6626	19-6628	19-6628	19-6629	19-6630	19-6634	19-6634
			19-6636	19-6643	19-6643	19-6643	19-6644	19-6644	19-6659	19-6659
TBITVE	=	000014	#7-877	9-903	9-903					
TKVEC	=	000060	#7-877							
TPVEC	=	000064	#7-877							
TRAPVE	=	000034	#7-877	9-903	9-903					
TRTVEC	=	000014	#7-877							
TST1		005020	#9-919							
TST10		017056	#13-2708							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
TST11		020066	#13-2953
TST12		020616	#13-3108
TST13		021456	#14-3358
TST14		022416	#14-3612
TST15		023260	#14-3855
TST16		024222	#15-4107
TST17		025700	#15-4474
TST2		006744	#9-1149
TST20		030006	#16-4853
TST21		030734	#16-5084
TST22		031762	#17-5343
TST23		033144	#17-5639
TST3		011662	#11-1480
TST4		013402	#11-1818
TST5		014410	#12-2118
TST6		015112	#12-2271
TST7		016122	#12-2517
TYPE	=	104401	9-904 17-5365 17-5643 17-5643 17-5643 17-5647 17-5647 17-5651 17-5653 17-5657 17-5657 17-5657 17-5657 17-5657 17-5657 #17-5659 17-5664 17-5675 17-5703 17-5705 17-5710 17-5712 17-5740 17-5752 17-5756 17-5760 17-5779 17-5787 17-5798 17-5805 17-5815 17-5657 #17-5659 17-5687 17-5730 17-5739 17-5743 17-5751 17-5755 17-5759 17-5763 17-5797
TYPOC	=	104402	#17-5659
TYPON	=	104404	17-5643 #17-5659 17-5770
TYPOS	=	104403	17-5643
\$APTHD		004322	9-900 #9-900
\$ASTAT	=	*****	17-5655 17-5655
\$ATYC		035054	17-5655 #17-5655
\$ATY1		035030	#17-5655
\$ATY3		035036	17-5651 #17-5655
\$ATY4		035046	17-5647 #17-5655
\$AUTOB		001134	#8-890 *9-904 17-5657 17-5657 17-5657
\$BASE		001372	#8-890
\$BDADR		001122	#8-890
\$BDDAT		001126	#8-890
\$BELL		001306	#8-890 17-5647 17-5647 17-5647
\$CDW1		001376	#8-890
\$CDW2		001400	#8-890
\$CHARC		034576	*17-5651 *17-5651 17-5651 *17-5651 #17-5651
\$CKSWR		035276	#17-5657 17-5659 17-5659
\$CLR.T		033346	17-5643 #17-5643
\$CMTAG		001100	#8-890 9-903 9-903 9-903 9-903 9-903 9-903 9-903 9-903
\$CM1	=	000024	#8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890
\$CM2	=	000050	#8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890 #8-890 8-890 8-890

SYMBOL CROSS REFERENCE  
SYMBOL VALUE

REFERENCES

		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
\$CM3	= 000024	#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
\$CM4	= 000024	#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
		#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
\$CNTLG	035705	#8-890	8-890	8-890	#8-890	8-890	8-890	#8-890	8-890	8-890
\$CNTLU	035700	17-5657	#17-5657							
\$CPUOP	001344	17-5657	#17-5657							
\$CRLF	001313	#8-890								
		#8-890	17-5643	17-5647	17-5647	17-5647	17-5651	17-5651	17-5651	17-5657
		17-5676	17-5706	17-5713	17-5816	19-6854	19-6854	19-6855	19-6855	19-6872
		19-6872	19-6873	19-6873	19-6903	19-6903	19-6904	19-6904	19-6945	19-6945
		19-6946	19-6946	19-6947	19-6947	19-6978	19-6978	19-6979	19-6979	19-6980
		19-6980	19-7001	19-7001	19-7002	19-7002	19-7002	19-7002	19-7003	19-7003
		19-7006	19-7006	19-7006	19-7006	19-7007	19-7007	19-7007	19-7007	19-7029
		19-7030	19-7031	19-7052	19-7052	19-7053	19-7053	19-7054	19-7054	
\$DDW0	001402	#8-890								
\$DDW1	001404	#8-890								
\$DDW10	001426	#8-890								
\$DDW11	001430	#8-890								
\$DDW12	001432	#8-890								
\$DDW13	001434	#8-890								
\$DDW14	001436	#8-890								
\$DDW15	001440	#8-890								
\$DDW2	001406	#8-890								
\$DDW3	001410	#8-890								
\$DDW4	001412	#8-890								
\$DDW5	001414	#8-890								
\$DDW6	001416	#8-890								
\$DDW7	001420	#8-890								
\$DDW8	001422	#8-890								
\$DDW9	001424	#8-890								
\$DEVCT	001326	#8-890								
\$DEVVM	001374	#8-890								
\$DOAGN	033366	17-5643	17-5643	17-5643	#17-5643					
\$ENDAD	033356	9-899	9-904	#17-5643	17-5647					
\$ENDCT	033200	9-903	#17-5643							
\$ENULL	033432	#17-5643								
\$ENV	001336	#8-890	9-904	17-5647	17-5651	17-5655	17-5655			
\$ENVM	001337	#8-890	9-903	17-5345	17-5651	17-5651	17-5655			
\$EOP	033144	#17-5643	17-5840	17-5851	17-5862					
\$EOPCT	033172	*9-903	#17-5643	17-5643						
\$ERFLG	001103	#8-890	17-5645	17-5645	17-5645	*17-5645	17-5645	17-5645	*17-5647	17-5647
		17-5647								
\$ERMAX	001115	#8-890	*9-903	17-5645	*17-5645	17-5645	17-5645			
\$ERROR	033716	9-903	#17-5647							



SYMBOL	VALUE	REFERENCES	CREF
\$OCNT	035024	14-3612 #14-3612 14-3612 #14-3855 14-3855 #14-3855 14-3855 #15-4107 15-4107	
\$OMODE	035026	#15-4107 15-4107 #15-4474 15-4474 #15-4474 15-4474 #16-4853 16-4853 #16-4853	
\$COVER	033700	16-4853 #16-5084 16-5084 #16-5084 16-5084 #17-5343 17-5343 #17-5343 17-5343	
\$PASS	001324	*17-5653 *17-5653 #17-5653 17-5653 *17-5653 *17-5653 #17-5653	
\$PASTM	004330	*17-5653 *17-5653 17-5653 *17-5653 *17-5653 #17-5653	
\$PWRAD	036160	17-5645 17-5645 17-5645 #17-5645 17-5645 17-5643 17-5643 17-5643 17-5645 17-5645	
\$PWRDN	036020	#8-890 *9-903 *17-5643 *17-5643 17-5643 17-5643 17-5643 17-5645 17-5645	
\$PWARMG	036154	17-5645 #9-900 17-5645 #9-900	
\$PWRUP	036072	#17-5664 17-5664 #17-5664 17-5664	
\$QUES	001312	9-903 #17-5664 17-5664	
\$RDCHR	035560	#17-5664 17-5664 #17-5664 17-5664	
\$RDDEC	= *****	17-5647 17-5647 17-5647 17-5651 17-5651 17-5657	
\$RDLIN	= *****	17-5659 17-5659 17-5659	
\$RDOCT	= *****	17-5659 17-5659 17-5659	
\$RDSZ	= 000001	#17-5657 17-5657	
\$REGAD	001160	#8-890	
\$REG0	001162	#8-890 17-5647 17-5647 17-5647	
\$REG1	001164	#8-890	
\$REG10	001202	#8-890	
\$REG11	001204	#8-890	
\$REG12	001206	#8-890	
\$REG13	001210	#8-890	
\$REG14	001212	#8-890	
\$REG15	001214	#8-890	
\$REG16	001216	#8-890	
\$REG17	001220	#8-890	
\$REG2	001166	#8-890	
\$REG20	001222	#8-890	
\$REG21	001224	#8-890	
\$REG22	001226	#8-890	
\$REG23	001230	#8-890	
\$REG3	001170	#8-890	
\$REG4	001172	#8-890	
\$REG5	001174	#8-890	
\$REG6	001176	#8-890	
\$REG7	001200	#8-890	
\$RESRE	034212	#17-5649 17-5659	
\$RTNAD	033426	#17-5643	
\$RTRN	033422	9-903 *9-903 *9-903 17-5643 #17-5643	
\$R2A	= *****	17-5659	
\$SAVRE	034154	#17-5649 17-5659 17-5659	
\$SAVR6	036202	*17-5664 17-5664 *17-5664 *17-5664 #17-5664	
\$SCOPE	033436	9-903 #17-5645	
\$SETUP	= 000137	#7-887 7-887 #7-887 7-887 #7-887 7-887 #7-887 7-887 #7-887 7-887 #7-887	
		7-887 #7-887 7-887 #7-887 9-903 9-903 9-903 9-903 9-903 9-903	
		9-903 9-903 9-903 9-903 9-903 9-903 9-903 9-903 9-904 9-904	
		9-904 17-5643 17-5643 17-5645 17-5647 17-5647 17-5647 17-5647 17-5647 17-5657	
		17-5657 17-5664	



SYMBOL	VALUE	REFERENCES
\$TMP16	001266	#8-890
\$TMP17	001270	#8-890
\$TMP2	001236	#8-890 9-926 9-959 9-984 9-1013 9-1036 9-1067 9-1072 9-1155 9-1179 9-1189 9-1194 9-1220 9-1244 9-1254 9-1259 9-1286 11-1312 11-1322 11-1327 11-1351 11-1377 11-1403 11-1488 11-1523 11-1565 11-1581 11-1601 11-1636 11-1666 11-1739 12-2051 12-2127 12-2150 12-2172 12-2207 12-2210 12-2455 13-2640 13-2890 13-3038 13-3234 14-3288 14-3313 14-3486 14-3539 14-3564 14-3732 14-3808 15-3984 15-4060 15-4378 16-4747 16-4985 16-5204 17-5565 17-5612 17-5832 17-5847 17-5858 19-6853 19-6855 19-6868 19-6869 19-6870 19-6871 19-6872 19-6902 19-6944 19-6977 19-6999 19-7001 19-7005 19-7012 19-7029 19-7033 19-7035 19-7045 19-7046 19-7049 19-7051
\$TMP20	001272	#8-890
\$TMP21	001274	#8-890
\$TMP22	001276	#8-890
\$TMP23	001300	#8-890
\$TMP3	001240	#8-890 9-1055 9-1056 9-1057 9-1058 9-1059 9-1060 9-1061 9-1062 9-1063 9-1064 9-1065 9-1066 9-1076 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1389 11-1391 11-1393 11-1395 11-1397 11-1399 11-1401 11-1416 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 11-1691 11-1696 11-1712 11-1717 11-1749 12-2065 12-2097 12-2217 12-2236 12-2247 12-2469 13-2654 13-2904 13-3052 13-3224 14-3476 14-3722 15-3974 15-4393 16-4762 16-5001 16-5220 17-5586 17-5835 19-6854 19-6855 19-6870 19-6872 19-6903 19-6945 19-6978 19-6999 19-7001 19-7006 19-7012 19-7033 19-7045 19-7054 \$TMP4 001242 #8-890 9-1055 9-1056 9-1057 9-1058 9-1059 9-1060 9-1061 9-1062 9-1063 9-1064 9-1065 9-1066 9-1078 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1389 11-1391 11-1393 11-1395 11-1397 11-1399 11-1401 11-1416 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 11-1690 11-1695 11-1713 11-1718 11-1747 12-2066 12-2067 12-2098 12-2218 12-2227 12-2235 12-2246 12-2471 13-2656 13-2906 13-3054 13-3226 14-3478 14-3724 15-3976 15-4395 16-4764 16-5003 16-5222 17-5591 17-5837 19-6854 19-6855 19-6868 19-6869 19-6870 19-6872 19-6903 19-6945 19-6978 19-7000 19-7002 19-7006 \$TMP5 001244 #8-890 9-1055 9-1056 9-1057 9-1058 9-1059 9-1060 9-1061 9-1062 9-1063 9-1064 9-1065 9-1066 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1389 11-1391 11-1393 11-1395 11-1397 11-1399 11-1401 11-1416 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 11-1700 11-1706 11-1721 11-1727 11-1753 11-1756 11-1762 12-2068 12-2219 12-2228 12-2248 12-2473 13-2658 13-2908 13-3056 13-3228 14-3480 14-3726 15-3978 15-4397 16-4766 16-5005 16-5224 17-5587 19-6853 19-6868 19-6869 19-6871 19-6873 19-6904 19-6946 19-6979 19-7002 19-7007 19-7030 19-7053 \$TMP6 001246 #8-890 9-1055 9-1056 9-1057 9-1058 9-1059 9-1060 9-1061 9-1062 9-1063 9-1064 9-1065 9-1066 11-1363 11-1365 11-1367 11-1369 11-1373 11-1375 11-1389 11-1391 11-1393 11-1395 11-1397 11-1399 11-1401 11-1416 11-1418 11-1420 11-1422 11-1424 11-1426 11-1428 11-1702 11-1708 11-1723 11-1729 11-1758 12-2069 12-2221 12-2229 12-2237 12-2249 12-2474 13-2659 13-2909 13-3057 13-3230 14-3482 14-3728 15-3980 15-4399 16-4768 16-5007 16-5226 17-5593 19-6853 19-6873 19-6904 19-6946 19-6979 19-7003 19-7007 19-7030 19-7053 \$TMP7 001250 #8-890 11-1701 11-1707 11-1722 11-1728 11-1754 11-1757 11-1763 12-2220 12-2230 12-2238 12-2250 12-2475 13-2660 13-2910 13-3058 13-3248 14-3500 14-3755 14-3833 15-4007 15-4085 15-4400 16-4769 16-5008 16-5227 17-5588 19-6872 19-6902 19-6947 19-6980 19-7031 19-7051



SYMBOL CROSS REFERENCE		REFERENCES									
SYMBOL	VALUE	7-868	#7-868	9-919	9-919	#9-919	9-1149	9-1149	#9-1149	11-1480	
\$TN	= 000023	11-1480	#11-1480	11-1818	11-1818	#11-1818	12-2118	12-2118	#12-2118	12-2271	
		12-2271	#12-2271	12-2517	12-2517	#12-2517	13-2708	13-2708	#13-2708	13-2953	
		13-2953	#13-2953	13-3108	13-3108	#13-3108	14-3358	14-3358	#14-3358	14-3612	
		14-3612	#14-3612	14-3855	14-3855	#14-3855	15-4107	15-4107	#15-4107	15-4474	
		15-4474	#15-4474	16-4853	16-4853	#16-4853	16-5084	16-5084	#16-5084	17-5343	
		17-5343	#17-5343	17-5639							
\$TPB	001152	#8-890	17-5651	17-5651	17-5651						
\$TPFLG	001157	#8-890	17-5651	17-5651	17-5651						
\$TPS	001150	#8-890	17-5651	17-5651	17-5651						
\$STRAP	035734	9-903	#17-5659								
\$STRAP2	035756	#17-5659	17-5659								
\$TRP	= 000014	#17-5659	17-5659	17-5659	17-5659	17-5659	#17-5659	17-5659	17-5659	17-5659	
		17-5659	#17-5659	17-5659	17-5659	17-5659	17-5659	#17-5659	17-5659	17-5659	
		17-5659	17-5659	#17-5659	17-5659	17-5659	17-5659	17-5659	#17-5659	17-5659	
		17-5659	17-5659	17-5659	#17-5659	17-5659	17-5659	17-5659	17-5659	#17-5659	
		17-5659	17-5659	17-5659	17-5659	#17-5659	17-5659	17-5659	17-5659	17-5659	
		#17-5659	17-5660	17-5660	17-5660	17-5660	#17-5660	17-5661	17-5661	17-5661	
		17-5661	#17-5661								
\$TRPAD	035770	17-5659	#17-5659	17-5662							
\$STSM	004326	#9-900									
\$STSTM	001102	#8-890	*17-5643	17-5645	17-5645	*17-5645	17-5645	17-5645	17-5645	17-5645	
		17-5647	17-5647	17-5647	17-5677						
\$TYPBN	= *****	17-5659									
\$TYPDS	= *****	17-5659									
\$TYPE	034250	#17-5651	17-5655	17-5659	17-5659						
\$TYPEC	034462	17-5651	17-5651	17-5651	#17-5651	17-5651	17-5657				
\$TYPEX	034600	17-5651	17-5651	#17-5651							
\$TYPOC	034626	#17-5653	17-5659	17-5659							
\$TYPON	034642	17-5653	#17-5653	17-5659							
\$TYPOS	034602	#17-5653	17-5659								
\$UNIT	001330	#8-890									
\$UNITM	004332	#9-900									
\$USWR	001342	#8-890									
\$VECT1	001366	#8-890									
\$VECT2	001370	#8-890									
\$XTSTR	033450	#17-5645									
\$SGET4	= 000001	#17-5643	#17-5643	17-5643							
\$OFILL	035025	*17-5653	*17-5653	17-5653	#17-5653						
\$LOCAT	= *****	17-5645	17-5647								
.LPER	036746	17-5661	#17-5871								
.RSET	036754	17-5660	#17-5883								
.\$ASTA	= *****	17-5655	17-5655								
.\$X	= 004322	#9-900	9-900								



MACRO NAME	REFERENCES									
	#9-896	#9-896	#9-896							
LCM1	#18-6389	18-6416	18-6419							
LCM2	#18-6394	#18-6415	#18-6424							
LCM3	#18-6398	#18-6421	#18-6423							
LCM4	#18-6405	18-6420	18-6422							
LCM5	#18-6408	18-6417								
LDM1	#18-6263									
LDM2	#18-6269									
LDM3	#18-6273									
LDM4	#18-6277									
LDM5	#18-6281									
LDM6	#18-6284	#18-6411	#18-6418							
LDM7	#18-6288									
LDM8	#18-6292									
LDM9	#18-6296									
LD1M1	#18-6250									
LD1M2	#18-6254									
LD1M3	#18-6260									
LOADTP	#5-634									
LPER	#7-853	#9-923	#9-955	#9-980	#9-1010	#9-1033	#9-1152	#9-1176	#9-1217	#9-1241
	#9-1283	#11-1309	#11-1482	#11-1515	#11-1561	#11-1577	#11-1598	#11-1628	#11-1659	#11-1821
	#11-1832	#11-1845	#11-1858	#11-1872	#11-1885	#11-1902	#11-1919	#11-1936	#11-1952	#12-1970
	#12-1987	#12-2004	#12-2121	#12-2146	#12-2168	#12-2274	#12-2285	#12-2296	#12-2308	#12-2319
	#12-2330	#12-2341	#12-2353	#12-2365	#12-2376	#12-2387	#12-2399	#12-2410	#12-2520	#12-2531
	#12-2542	#12-2553	#12-2564	#12-2577	#12-2589	#13-2711	#13-2722	#13-2733	#13-2744	#13-2755
	#13-2767	#13-2779	#13-2790	#13-2801	#13-2812	#13-2823	#13-2834	#13-2845	#13-2956	#13-2968
	#13-2979	#13-2990	#13-3111	#13-3127	#13-3144	#13-3160	#14-3361	#14-3379	#14-3396	#14-3414
	#14-3615	#14-3631	#14-3647	#14-3663	#14-3858	#14-3876	#14-3894	#14-3912	#15-4110	#15-4126
	#15-4142	#15-4158	#15-4174	#15-4190	#15-4207	#15-4224	#15-4240	#15-4256	#15-4272	#15-4288
	#15-4304	#15-4320	#15-4477	#15-4493	#15-4511	#15-4528	#15-4546	#15-4565	#15-4582	#16-4600
	#16-4616	#16-4636	#16-4654	#16-4672	#16-4690	#16-4856	#16-4873	#16-4890	#16-4908	#16-4926
	#16-5087	#16-5106	#16-5125	#16-5144	#17-5368	#17-5381	#17-5395	#17-5409	#17-5425	#17-5439
	#17-5455	#17-5468	#17-5483	#17-5497	#17-5511					
MDO1	#18-6056	#18-6069	#18-6074							
MDO2	#18-6106	#18-6119	#18-6124							
MDU1	#18-6059	18-6062	18-6067							
MDU2	#18-6109	#18-6112	#18-6117							
MERROR	#7-756									
MFM4	#18-6196	#18-6208	#18-6226							
MFM5	#18-6199	#18-6210	#18-6216	#18-6220	#18-6222	#18-6224	#18-6228	#18-6234	#18-6236	#18-6240
	#18-6242									
MFM6	#18-6202	#18-6212	#18-6230							
MFM7	#18-6205	18-6214	18-6218	18-6232	18-6238					
MF01	#18-6034	#18-6044	#18-6046							
MF02	#18-6084	18-6094	18-6096							
MFU1	#18-6037	#18-6040	#18-6042							
MFU2	#18-6087	18-6090	18-6092							
MM1	#18-5996	#18-6000	#18-6002	#18-6005	#18-6008	#18-6010	#18-6028	#18-6030	#18-6080	#18-6082
MM2	#18-6013	#18-6017	#18-6020	#18-6022	#18-6024	#18-6050	#18-6052	#18-6064	#18-6071	#18-6102
	#18-6104	#18-6114	#18-6121							
MODDM1	#18-6161	18-6169	18-6173	18-6177	18-6180	18-6183	18-6194			
MODDM2	#18-6164	18-6167	18-6171	18-6175	18-6185	18-6188	18-6190	18-6192		

MACRO NAME	REFERENCES									
MODM1	#18-6129	18-6135	18-6141	18-6144	18-6147	18-6149	18-6151	18-6153		
MODM2	#18-6132	18-6137	18-6139	18-6155						
MSG	#9-909	#9-919	#9-1135	#9-1149	#11-1474	#11-1480	#11-1810	#11-1818	#12-2110	#12-2118
	#12-2263	#12-2271	#12-2510	#12-2517	#13-2700	#13-2708	#13-2945	#13-2953	#13-3098	#13-3108
	#14-3348	#14-3358	#14-3599	#14-3612	#14-3846	#14-3855	#15-4099	#15-4107	#15-4466	#15-4474
	#16-4844	#16-4853	#16-5075	#16-5084	#17-5301	#17-5343				
MULT	#7-877									
NAMEP	#5-648	9-904								
NEWTST	#7-877	9-919	9-1149	11-1480	11-1818	12-2118	12-2271	12-2517	13-2708	13-2953
	13-3108	14-3358	14-3612	14-3855	15-4107	15-4474	16-4853	16-5084	17-5343	
NTMPM	#5-644									
OU1	#18-6349	18-6375	18-6377	18-6379						
OU2	#18-6355	#18-6376	#18-6378	#18-6380						
OU3	#18-6362	18-6381	18-6382	18-6383	18-6384					
POP	#7-877	17-5649	17-5655	17-5655	17-5664	17-5664				
PUSH	#7-877	17-5649	17-5655	17-5655	17-5655	17-5664	17-5664			
REPORT	#7-877									
ROM	#7-679									
ROMAC	#7-811									
ROM1	#7-682									
ROM10	#7-703									
ROM11	#7-706									
ROM12	#7-709									
ROM13	#7-712									
ROM14	#7-715									
ROM15	#7-718									
ROM16	#7-721									
ROM17	#7-724									
ROM2	#7-685									
ROM20	#7-727									
ROM3	#7-688									
ROM30	#7-673									
ROM31	#7-676									
ROM4	#7-691									
ROM5	#7-694									
ROM6	#7-697									
ROM7	#7-700									
RSET	#5-651	#9-1133	#11-1472	#11-1806	#12-2106	#12-2260	#12-2507	#13-2697	#13-2942	#13-3095
	#14-3344	#14-3595	#14-3842	#15-4094	#15-4462	#16-4840	#16-5071	#17-5299	#17-5635	#17-5839
	#17-5850	#17-5861								
	#18-6343	#18-6367	#18-6368	#18-6369	#18-6370					
RTMAC	#5-639									
RTMPM	#7-877									
SETPRI	#17-5659	17-5659	17-5659	17-5659	17-5659	17-5659	17-5659	17-5659	17-5659	17-5659
SETTRA	17-5660	17-5661								
SETUP	#7-877	9-903								
SKIP	#7-877									
SLASH	#7-877									
SPACE	#7-860	#7-877								
SSKAD	#7-850									
STARS	#7-877	8-890	8-890	8-890	9-899	9-900	9-900	9-900	9-919	9-919
	9-1149	9-1149	11-1480	11-1480	11-1818	11-1818	12-2118	12-2118	12-2271	12-2271



CKFPBAO CREATED BY MACRO ON 18-SEP-79 AT 13:50  
MACRO CROSS REFERENCE  
MACRO NAME REFERENCES  
.STYPO #7-864 #17-5653

PAGE 41  
CREF

F 1

SEQ 0212